

SECTION **DLK**
DOOR & LOCK

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

CONTENTS

COUPE

BASIC INSPECTION	11	INTELLIGENT KEY	25
DIAGNOSIS AND REPAIR WORKFLOW	11	INTELLIGENT KEY : System Diagram	25
Work Flow	11	INTELLIGENT KEY : System Description	25
INSPECTION AND ADJUSTMENT	14	INTELLIGENT KEY : Component Parts Location...28	
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	14	INTELLIGENT KEY : Component Description	29
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	14	TRUNK OPEN FUNCTION	30
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	14	TRUNK LID OPENER SWITCH	30
FUNCTION DIAGNOSIS	15	TRUNK LID OPENER SWITCH : System Diagram	30
AUTOMATIC DOOR LOCKS	15	TRUNK LID OPENER SWITCH : System Description	30
System Diagram	15	TRUNK LID OPENER SWITCH : Component Parts Location	31
System Description	15	TRUNK LID OPENER SWITCH : Component Description	31
Component Parts Location	17	TRUNK REQUEST SWITCH	31
Component Description	17	TRUNK REQUEST SWITCH : System Diagram	32
DOOR LOCK FUNCTION	18	TRUNK REQUEST SWITCH : System Description	32
DOOR LOCK AND UNLOCK SWITCH	18	TRUNK REQUEST SWITCH : Component Parts Location	35
DOOR LOCK AND UNLOCK SWITCH : System Diagram	18	TRUNK REQUEST SWITCH : Component Description	36
DOOR LOCK AND UNLOCK SWITCH : System Description	18	INTELLIGENT KEY	37
DOOR LOCK AND UNLOCK SWITCH : Component Parts Location	19	INTELLIGENT KEY : System Diagram	37
DOOR LOCK AND UNLOCK SWITCH : Component Description	19	INTELLIGENT KEY : System Description	37
DOOR REQUEST SWITCH	19	INTELLIGENT KEY : Component Parts Location...39	
DOOR REQUEST SWITCH : System Diagram	20	INTELLIGENT KEY : Component Description	40
DOOR REQUEST SWITCH : System Description...20		WARNING FUNCTION	41
DOOR REQUEST SWITCH : Component Parts Location	23	System Description	41
DOOR REQUEST SWITCH : Component Description	24	Component Parts Location	46
		KEY REMINDER FUNCTION	48
		System Description	48
		Component Parts Location	49
		HOMELINK UNIVERSAL TRANSCEIVER	51

Component Description	51	PASSENGER SIDE :	
DIAGNOSIS SYSTEM (BCM)	52	Component Function Check	73
COMMON ITEM	52	PASSENGER SIDE : Diagnosis Procedure (With	
COMMON ITEM : Diagnosis Description	52	LH and RH Anti-Pinch)	73
COMMON ITEM : CONSULT-III Function	52	PASSENGER SIDE : Diagnosis Procedure (With	
DOOR LOCK	53	LH Anti-Pinch Only)	75
DOOR LOCK : CONSULT-III Function (BCM -		KEY SLOT	77
DOOR LOCK)	53	Description	77
INTELLIGENT KEY	53	Component Function Check	77
INTELLIGENT KEY : CONSULT-III Function		Diagnosis Procedure	77
(BCM - INTELLIGENT KEY)	53	Component Inspection	78
TRUNK	56	KEY CYLINDER SWITCH	79
TRUNK : CONSULT-III Function (BCM - TRUNK)..	56	Description	79
COMPONENT DIAGNOSIS	58	Component Function Check	79
U1000 CAN COMM CIRCUIT	58	Diagnosis Procedure (With LH and RH Anti-Pinch)	
Description	58	79
DTC Logic	58	Diagnosis Procedure (With LH Anti-Pinch Only)	80
Diagnosis Procedure	58	Component Inspection	82
U1010 CONTROL UNIT (CAN)	59	UNLOCK SENSOR	83
DTC Logic	59	Description	83
Diagnosis Procedure	59	Component Function Check	83
Special Repair Requirement	59	Diagnosis Procedure	83
B2622 INSIDE KEY ANTENNA 2	60	Component Inspection	85
Description	60	TRUNK LID OPENER SWITCH	86
DTC Logic	60	Description	86
Diagnosis Procedure	60	Component Function Check	86
B2623 INSIDE KEY ANTENNA 3	63	Diagnosis Procedure	86
Description	63	Component Inspection	87
DTC Logic	63	TRUNK LID OPENER CANCEL SWITCH	89
Diagnosis Procedure	63	Description	89
POWER SUPPLY AND GROUND CIRCUIT	66	Component Function Check	89
Diagnosis Procedure	66	Diagnosis Procedure	89
Special Repair Requirement	66	Component Inspection	90
DOOR SWITCH	67	TRUNK ROOM LAMP SWITCH	92
Description	67	Description	92
Component Function Check	67	Component Function Check	92
Diagnosis Procedure	67	Diagnosis Procedure	92
Component Inspection	69	Component Inspection	94
DOOR LOCK AND UNLOCK SWITCH	70	DOOR REQUEST SWITCH	95
DRIVER SIDE	70	Description	95
DRIVER SIDE : Description	70	Component Function Check	95
DRIVER SIDE : Component Function Check	70	Diagnosis Procedure	95
DRIVER SIDE : Diagnosis Procedure (With LH		Component Inspection	97
and RH Anti-Pinch)	70	TRUNK OPENER REQUEST SWITCH	99
DRIVER SIDE : Diagnosis Procedure (With LH		Description	99
Anti-Pinch Only)	72	Component Function Check	99
PASSENGER SIDE	73	Diagnosis Procedure	99
PASSENGER SIDE : Description	73	Component Inspection	101
		DOOR LOCK ACTUATOR	102
		DRIVER SIDE	102
		DRIVER SIDE : Description	102

DRIVER SIDE : Component Function Check	102	HOMELINK UNIVERSAL TRANSCEIVER	124	
DRIVER SIDE : Diagnosis Procedure	102	Description	124	A
PASSENGER SIDE	103	Component Function Check	124	
PASSENGER SIDE : Description	103	Diagnosis Procedure	124	B
PASSENGER SIDE :		ECU DIAGNOSIS	126	
Component Function Check	103	BCM (BODY CONTROL MODULE)	126	C
PASSENGER SIDE : Diagnosis Procedure	103	Reference Value	126	
TRUNK LID OPENER ACTUATOR	105	Terminal Layout	130	
Description	105	Physical Values	130	D
Component Function Check	105	Fail Safe	148	
Diagnosis Procedure	105	DTC Inspection Priority Chart	148	
INTELLIGENT KEY WARNING BUZZER	107	DTC Index	149	
Description	107	WIRING DIAGRAM	154	E
Component Function Check	107	HOMELINK UNIVERSAL TRANSCEIVER	154	F
Diagnosis Procedure	107	Wiring Diagram	154	
Component Inspection	108	POWER DOOR LOCK SYSTEM	156	G
OUTSIDE KEY ANTENNA	109	Wiring Diagram	156	
Description	109	INTELLIGENT KEY SYSTEM	166	H
Component Function Check	109	Wiring Diagram	166	
Diagnosis Procedure	109	TRUNK LID OPENER	182	I
REMOTE KEYLESS ENTRY RECEIVER	112	Wiring Diagram	182	
Description	112	SYMPTOM DIAGNOSIS	186	J
Component Function Check	112	INTELLIGENT KEY SYSTEM SYMPTOMS ...	186	
Diagnosis Procedure	112	Symptom Table	186	
INTELLIGENT KEY BATTERY AND FUNCTION	115	DOOR LOCK FUNCTION SYMPTOMS	187	
Description	115	DOOR LOCK AND UNLOCK SWITCH	187	
Component Function Check	115	DOOR LOCK AND UNLOCK SWITCH : Symptom		DLK
Diagnosis Procedure	115	Table	187	
KEY SLOT ILLUMINATION	117	DOOR REQUEST SWITCH	187	L
Description	117	DOOR REQUEST SWITCH : Symptom Table	187	
Component Function Check	117	INTELLIGENT KEY	188	M
Diagnosis Procedure	117	INTELLIGENT KEY : Symptom Table	188	
HORN FUNCTION	119	TRUNK OPEN FUNCTION SYMPTOMS	190	N
Description	119	TRUNK LID OPENER SWITCH	190	
Component Function Check	119	TRUNK LID OPENER SWITCH : Symptom Table	190	
Diagnosis Procedure	119	TRUNK REQUEST SWITCH	190	O
COMBINATION METER DISPLAY FUNCTION	121	TRUNK REQUEST SWITCH : Symptom Table ...	190	
Description	121	INTELLIGENT KEY	190	P
Component Function Check	121	INTELLIGENT KEY : Symptom Table	190	
Diagnosis Procedure	121	WARNING FUNCTION SYMPTOMS	192	
WARNING CHIME FUNCTION	122	Symptom Table	192	
Description	122	KEY REMINDER FUNCTION SYMPTOMS	194	
Component Function Check	122	Symptom Table	194	
Diagnosis Procedure	122	HAZARD FUNCTION	195	
HAZARD FUNCTION	123			
Description	123			
Component Function Check	123			
Diagnosis Procedure	123			

Symptom Table	195	TRUNK LID ASSEMBLY	224
HORN FUNCTION	196	TRUNK LID ASSEMBLY : Removal and Installation	224
Symptom Table	196	TRUNK LID ASSEMBLY : Adjustment	225
INTEGRATED HOMELINK TRANSMITTER ..	197	TRUNK LID LOCK	226
Symptom Table	197	TRUNK LID LOCK : Removal and Installation	226
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	198	FUEL FILLER LID	227
Work Flow	198	Exploded View	227
Inspection Procedure	200	Removal and Installation	227
Diagnostic Worksheet	202	REMOTE KEYLESS ENTRY RECEIVER	228
PRECAUTION	204	Removal	228
PRECAUTIONS	204	Installation	228
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	204	SEDAN WITH INTELLIGENT KEY	
Procedure without Cowl Top Cover	204	BASIC INSPECTION	229
Precaution for work	204	DIAGNOSIS AND REPAIR WORKFLOW	229
PREPARATION	205	Work Flow	229
PREPARATION	205	INSPECTION AND ADJUSTMENT	232
Special Service Tools	205	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	232
Commercial Service Tools	205	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	232
ON-VEHICLE REPAIR	206	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement ..	232
HOOD	206	FUNCTION DIAGNOSIS	233
HOOD ASSEMBLY	206	AUTOMATIC DOOR LOCKS	233
HOOD ASSEMBLY : Removal and Installation	206	System Diagram	233
HOOD ASSEMBLY : Adjustment	207	System Description	233
HOOD LOCK CONTROL	209	Component Parts Location	235
HOOD LOCK CONTROL : Component Parts Location	209	Component Description	236
HOOD LOCK CONTROL : Removal and Installation	209	DOOR LOCK FUNCTION	237
RADIATOR CORE SUPPORT	212	DOOR LOCK AND UNLOCK SWITCH	237
Removal and Installation	212	DOOR LOCK AND UNLOCK SWITCH : System Diagram	237
FRONT FENDER	214	DOOR LOCK AND UNLOCK SWITCH : System Description	237
Removal and Installation	214	DOOR LOCK AND UNLOCK SWITCH : Component Parts Location	238
DOOR	217	DOOR LOCK AND UNLOCK SWITCH : Component Description	239
FRONT DOOR	217	DOOR REQUEST SWITCH	239
FRONT DOOR : Removal and Installation	217	DOOR REQUEST SWITCH : System Diagram ...	239
FRONT DOOR : Adjustment	218	DOOR REQUEST SWITCH : System Description.	239
DOOR LOCK	220	DOOR REQUEST SWITCH : Component Parts Location	242
FRONT DOOR LOCK	220	DOOR REQUEST SWITCH : Component Description	244
FRONT DOOR LOCK : Component Parts Location	220	INTELLIGENT KEY	244
FRONT DOOR LOCK : Removal and Installation..	220	INTELLIGENT KEY : System Diagram	244
TRUNK LID	224	INTELLIGENT KEY : System Description	244

INTELLIGENT KEY : Component Parts Location	247	Diagnosis Procedure	281
INTELLIGENT KEY : Component Description	249		
TRUNK OPEN FUNCTION	250	U1010 CONTROL UNIT (CAN)	282
		DTC Logic	282
TRUNK LID OPENER SWITCH	250	Diagnosis Procedure	282
TRUNK LID OPENER SWITCH : System Diagram	250	Special Repair Requirement	282
TRUNK LID OPENER SWITCH : System Description	250	B2622 INSIDE KEY ANTENNA 2	283
TRUNK LID OPENER SWITCH :		Description	283
Component Parts Location	251	DTC Logic	283
TRUNK LID OPENER SWITCH :		Diagnosis Procedure	283
Component Description	251	B2623 INSIDE KEY ANTENNA 3	286
TRUNK REQUEST SWITCH	251	Description	286
TRUNK REQUEST SWITCH : System Diagram	252	DTC Logic	286
TRUNK REQUEST SWITCH : System Description	252	Diagnosis Procedure	286
TRUNK REQUEST SWITCH :		POWER SUPPLY AND GROUND CIRCUIT	289
Component Parts Location	255	Diagnosis Procedure	289
TRUNK REQUEST SWITCH :		Special Repair Requirement	289
Component Description	257	DOOR SWITCH	290
INTELLIGENT KEY	257	Description	290
INTELLIGENT KEY : System Diagram	257	Component Function Check	290
INTELLIGENT KEY : System Description	257	Diagnosis Procedure	290
INTELLIGENT KEY : Component Parts Location	259	Component Inspection	292
INTELLIGENT KEY : Component Description	261	DOOR LOCK AND UNLOCK SWITCH	293
WARNING FUNCTION	262	DRIVER SIDE	293
System Description	262	DRIVER SIDE : Description	293
Component Parts Location	267	DRIVER SIDE : Component Function Check	293
KEY REMINDER FUNCTION	270	DRIVER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)	293
System Description	270	DRIVER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)	295
Component Parts Location	271	PASSENGER SIDE	296
HOMELINK UNIVERSAL TRANSCEIVER	274	PASSENGER SIDE : Description	296
Component Description	274	PASSENGER SIDE :	
DIAGNOSIS SYSTEM (BCM)	275	Component Function Check	296
COMMON ITEM	275	PASSENGER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)	296
COMMON ITEM : Diagnosis Description	275	PASSENGER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)	298
COMMON ITEM : CONSULT-III Function	275	KEY SLOT	300
DOOR LOCK	276	Description	300
DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)	276	Component Function Check	300
INTELLIGENT KEY	276	Diagnosis Procedure	300
INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY)	276	Component Inspection	301
TRUNK	279	KEY CYLINDER SWITCH	302
TRUNK : CONSULT-III Function (BCM - TRUNK)	279	Description	302
COMPONENT DIAGNOSIS	281	Component Function Check	302
U1000 CAN COMM CIRCUIT	281	Diagnosis Procedure (With LH and RH Anti-Pinch)	302
Description	281	Diagnosis Procedure (With LH Anti-Pinch Only)	303
DTC Logic	281	Component Inspection	305
		UNLOCK SENSOR	306
		Description	306

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

Component Function Check	306	INTELLIGENT KEY WARNING BUZZER	330
Diagnosis Procedure	306	Description	330
Component Inspection	308	Component Function Check	330
TRUNK LID OPENER SWITCH	309	Diagnosis Procedure	330
Description	309	Component Inspection	331
Component Function Check	309	OUTSIDE KEY ANTENNA	332
Diagnosis Procedure	309	Description	332
Component Inspection	310	Component Function Check	332
TRUNK LID OPENER CANCEL SWITCH	311	Diagnosis Procedure	332
Description	311	REMOTE KEYLESS ENTRY RECEIVER	335
Component Function Check	311	Description	335
Diagnosis Procedure	311	Component Function Check	335
Component Inspection	312	Diagnosis Procedure	335
TRUNK ROOM LAMP SWITCH	313	INTELLIGENT KEY BATTERY AND FUNC-	TION
Description	313	339	Description
Component Function Check	313	Description	339
Diagnosis Procedure	313	Component Function Check	339
Component Inspection	315	Diagnosis Procedure	339
DOOR REQUEST SWITCH	316	KEY SLOT ILLUMINATION	341
Description	316	Description	341
Component Function Check	316	Component Function Check	341
Diagnosis Procedure	316	Diagnosis Procedure	341
Component Inspection	318	HORN FUNCTION	343
TRUNK OPENER REQUEST SWITCH	320	Description	343
Description	320	Component Function Check	343
Component Function Check	320	Diagnosis Procedure	343
Diagnosis Procedure	320	COMBINATION METER DISPLAY FUNC-	TION
Component Inspection	322	345	Description
DOOR LOCK ACTUATOR	323	Description	345
DRIVER SIDE	323	Component Function Check	345
DRIVER SIDE : Description	323	Diagnosis Procedure	345
DRIVER SIDE : Component Function Check	323	WARNING CHIME FUNCTION	346
DRIVER SIDE : Diagnosis Procedure	323	Description	346
PASSENGER SIDE	324	Component Function Check	346
PASSENGER SIDE : Description	324	Diagnosis Procedure	346
PASSENGER SIDE :		HAZARD FUNCTION	347
Component Function Check	324	Description	347
PASSENGER SIDE : Diagnosis Procedure	324	Component Function Check	347
REAR LH	325	Diagnosis Procedure	347
REAR LH : Description	325	HOMELINK UNIVERSAL TRANSCEIVER	348
REAR LH : Component Function Check	325	Description	348
REAR LH : Diagnosis Procedure	325	Component Function Check	348
REAR RH	326	Diagnosis Procedure	348
REAR RH : Description	326	ECU DIAGNOSIS	350
REAR RH : Component Function Check	326	BCM (BODY CONTROL MODULE)	350
REAR RH : Diagnosis Procedure	326	Reference Value	350
TRUNK LID OPENER ACTUATOR	328	Terminal Layout	354
Description	328	Physical Values	354
Component Function Check	328	Fail Safe	372
Diagnosis Procedure	328	DTC Inspection Priority Chart	372

DTC Index	373	PRECAUTION	429	
WIRING DIAGRAM	378	PRECAUTIONS	429	A
HOMELINK UNIVERSAL TRANSCEIVER	378	Caution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	429	B
Wiring Diagram	378	Caution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	429	C
POWER DOOR LOCK SYSTEM	380	Procedure without Cowl Top Cover	430	D
Wiring Diagram	380	Caution for work	430	
INTELLIGENT KEY SYSTEM	391	PREPARATION	431	
Wiring Diagram	391	PREPARATION	431	E
TRUNK LID OPENER	407	Special Service Tools	431	
Wiring Diagram	407	Commercial Service Tools	431	
SYMPTOM DIAGNOSIS	411	ON-VEHICLE REPAIR	432	F
INTELLIGENT KEY SYSTEM SYMPTOMS	411	HOOD	432	
Symptom Table	411	HOOD ASSEMBLY	432	G
DOOR LOCK FUNCTION SYMPTOMS	412	HOOD ASSEMBLY : Removal and Installation	432	
DOOR LOCK AND UNLOCK SWITCH	412	HOOD ASSEMBLY : Adjustment	433	
DOOR LOCK AND UNLOCK SWITCH : Symptom Table	412	HOOD LOCK CONTROL	435	H
DOOR REQUEST SWITCH	412	HOOD LOCK CONTROL : Component Parts Location	435	
DOOR REQUEST SWITCH : Symptom Table	412	HOOD LOCK CONTROL : Removal and Installation	435	I
INTELLIGENT KEY	413	RADIATOR CORE SUPPORT	438	J
INTELLIGENT KEY : Symptom Table	413	Removal and Installation	438	
TRUNK OPEN FUNCTION SYMPTOMS	415	FRONT FENDER	440	DLK
TRUNK LID OPENER SWITCH	415	Removal and Installation	440	
TRUNK LID OPENER SWITCH : Symptom Table	415	DOOR	443	
TRUNK REQUEST SWITCH	415	FRONT DOOR	443	L
TRUNK REQUEST SWITCH : Symptom Table	415	FRONT DOOR : Removal and Installation	443	
INTELLIGENT KEY	415	FRONT DOOR : Adjustment	444	
INTELLIGENT KEY : Symptom Table	415	BACK DOOR	445	M
WARNING FUNCTION SYMPTOMS	417	BACK DOOR : Removal and Installation	445	
Symptom Table	417	BACK DOOR : Adjustment	446	
KEY REMINDER FUNCTION SYMPTOMS	419	DOOR LOCK	449	N
Symptom Table	419	FRONT DOOR LOCK	449	
HAZARD FUNCTION	420	FRONT DOOR LOCK : Component Parts Location	449	O
Symptom Table	420	FRONT DOOR LOCK : Removal and Installation	449	
HORN FUNCTION	421	BACK DOOR LOCK	452	P
Symptom Table	421	BACK DOOR LOCK : Component Parts Location	452	
INTEGRATED HOMELINK TRANSMITTER	422	BACK DOOR LOCK : Removal and Installation	452	
Symptom Table	422	TRUNK LID	456	
SQUEAK AND RATTLE TROUBLE DIAGNOSES	423	TRUNK LID ASSEMBLY	456	
Work Flow	423			
Inspection Procedure	425			
Diagnostic Worksheet	427			

TRUNK LID ASSEMBLY : Removal and Installation	456	COMMON ITEM : Diagnosis Description	478
TRUNK LID ASSEMBLY : Adjustment	457	COMMON ITEM : CONSULT-III Function	478
TRUNK LID LOCK	458	DOOR LOCK	479
TRUNK LID LOCK : Removal and Installation	458	DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)	479
FUEL FILLER LID	459	MULTI REMOTE ENT	479
Exploded View	459	MULTI REMOTE ENT : CONSULT-III Function (BCM - MULTIREMOTE ENT)	479
Removal and Installation	459	TRUNK	481
REMOTE KEYLESS ENTRY RECEIVER	460	TRUNK : CONSULT-III Function (BCM - TRUNK)	481
Removal	460	COMPONENT DIAGNOSIS	482
Installation	460	U1000 CAN COMM CIRCUIT	482
SEDAN WITHOUT INTELLIGENT KEY		Description	482
BASIC INSPECTION	461	DTC Logic	482
DIAGNOSIS AND REPAIR WORKFLOW	461	Diagnosis Procedure	482
Work Flow	461	U1010 CONTROL UNIT (CAN)	483
INSPECTION AND ADJUSTMENT	464	DTC Logic	483
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	464	Diagnosis Procedure	483
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	464	Special Repair Requirement	483
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	464	B2622 INSIDE KEY ANTENNA 2	484
FUNCTION DIAGNOSIS	465	Description	484
AUTOMATIC DOOR LOCKS	465	DTC Logic	484
System Diagram	465	Diagnosis Procedure	484
System Description	465	B2623 INSIDE KEY ANTENNA 3	487
Component Parts Location	467	Description	487
Component Description	467	DTC Logic	487
DOOR LOCK FUNCTION	469	Diagnosis Procedure	487
System Diagram	469	POWER SUPPLY AND GROUND CIRCUIT ...	490
System Description	469	Diagnosis Procedure	490
Component Parts Location	470	Special Repair Requirement	490
Component Description	470	DOOR SWITCH	491
REMOTE KEYLESS ENTRY SYSTEM	471	Description	491
System Diagram	471	Component Function Check	491
System Description	471	Diagnosis Procedure	491
Component Parts Location	473	Component Inspection	493
Component Description	474	DOOR LOCK AND UNLOCK SWITCH	494
TRUNK OPEN FUNCTION	475	DRIVER SIDE	494
System Diagram	475	DRIVER SIDE : Description	494
System Description	475	DRIVER SIDE : Component Function Check	494
Component Parts Location	476	DRIVER SIDE : Diagnosis Procedure	494
Component Description	476	PASSENGER SIDE	496
HOMELINK UNIVERSAL TRANSCEIVER	477	PASSENGER SIDE : Description	496
Component Description	477	PASSENGER SIDE :	
DIAGNOSIS SYSTEM (BCM)	478	Component Function Check	496
COMMON ITEM	478	PASSENGER SIDE : Diagnosis Procedure	496
		KEY SLOT	498
		Description	498
		Component Function Check	498
		Diagnosis Procedure	498

Component Inspection	499	Component Function Check	519	
KEY CYLINDER SWITCH	500	Diagnosis Procedure	519	A
Description	500	KEYFOB BATTERY AND FUNCTION	523	
Component Function Check	500	Description	523	B
Diagnosis Procedure	500	Component Function Check	523	
Component Inspection	501	Diagnosis Procedure	523	C
TRUNK LID OPENER SWITCH	503	KEY SLOT ILLUMINATION	525	
Description	503	Description	525	D
Component Function Check	503	Component Function Check	525	
Diagnosis Procedure	503	Diagnosis Procedure	525	E
Component Inspection	504	HORN FUNCTION	527	
TRUNK LID OPENER CANCEL SWITCH	505	Description	527	F
Description	505	Component Function Check	527	
Component Function Check	505	Diagnosis Procedure	527	G
Diagnosis Procedure	505	COMBINATION METER DISPLAY FUNC-		
Component Inspection	506	TION	529	
TRUNK ROOM LAMP SWITCH	507	Description	529	H
Description	507	Component Function Check	529	
Component Function Check	507	Diagnosis Procedure	529	I
Diagnosis Procedure	507	WARNING CHIME FUNCTION	530	
Component Inspection	509	Description	530	J
DOOR LOCK ACTUATOR	510	Component Function Check	530	
DRIVER SIDE	510	Diagnosis Procedure	530	
DRIVER SIDE : Description	510	HAZARD FUNCTION	531	
DRIVER SIDE : Component Function Check	510	Description	531	
DRIVER SIDE : Diagnosis Procedure	510	Component Function Check	531	
PASSENGER SIDE	511	Diagnosis Procedure	531	
PASSENGER SIDE : Description	511	ECU DIAGNOSIS	532	
PASSENGER SIDE :		BCM (BODY CONTROL MODULE)	532	DLK
Component Function Check	511	Reference Value	532	
PASSENGER SIDE : Diagnosis Procedure	511	Terminal Layout	536	
REAR LH	512	Physical Values	536	L
REAR LH : Description	512	Fail Safe	554	
REAR LH : Component Function Check	512	DTC Inspection Priority Chart	554	
REAR LH : Diagnosis Procedure	512	DTC Index	555	M
REAR RH	513	WIRING DIAGRAM	560	
REAR RH : Description	513	HOMELINK UNIVERSAL TRANSCEIVER	560	N
REAR RH : Component Function Check	513	Wiring Diagram	560	
REAR RH : Diagnosis Procedure	513	POWER DOOR LOCK SYSTEM	562	O
TRUNK LID OPENER ACTUATOR	515	Wiring Diagram	562	
Description	515	REMOTE KEYLESS ENTRY SYSTEM	572	P
Component Function Check	515	Wiring Diagram	572	
Diagnosis Procedure	515	TRUNK LID OPENER	584	
OUTSIDE WARNING BUZZER	517	Wiring Diagram	584	
Description	517	SYMPTOM DIAGNOSIS	588	
Component Function Check	517	DOOR LOCK FUNCTION	588	
Diagnosis Procedure	517	Symptom Table	588	
Component Inspection	518			
REMOTE KEYLESS ENTRY RECEIVER	519			
Description	519			

REMOTE KEYLESS ENTRY SYSTEM	589	RADIATOR CORE SUPPORT	608
Symptom Table	589	Removal and Installation	608
TRUNK OPEN FUNCTION	591	FRONT FENDER	610
Symptom Table	591	Removal and Installation	610
WARNING FUNCTION	592	DOOR	613
Symptom Table	592	FRONT DOOR	613
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	594	FRONT DOOR : Removal and Installation	613
Work Flow	594	FRONT DOOR : Adjustment	614
Inspection Procedure	596	BACK DOOR	615
Diagnostic Worksheet	598	BACK DOOR : Removal and Installation	615
PRECAUTION	600	BACK DOOR : Adjustment	616
PRECAUTIONS	600	DOOR LOCK	619
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	600	FRONT DOOR LOCK	619
Procedure without Cowl Top Cover	600	FRONT DOOR LOCK : Component Parts Loca- tion	619
Precaution for work	600	FRONT DOOR LOCK : Removal and Installation	619
PREPARATION	601	BACK DOOR LOCK	621
PREPARATION	601	BACK DOOR LOCK : Component Parts Location	622
Special Service Tools	601	BACK DOOR LOCK : Removal and Installation	622
Commercial Service Tools	601	TRUNK LID	625
ON-VEHICLE REPAIR	602	TRUNK LID ASSEMBLY	625
HOOD	602	TRUNK LID ASSEMBLY : Removal and Installa- tion	625
HOOD ASSEMBLY	602	TRUNK LID ASSEMBLY : Adjustment	626
HOOD ASSEMBLY : Removal and Installation	602	TRUNK LID LOCK	627
HOOD ASSEMBLY : Adjustment	603	TRUNK LID LOCK : Removal and Installation	627
HOOD LOCK CONTROL	605	FUEL FILLER LID	628
HOOD LOCK CONTROL : Component Parts Lo- cation	605	Exploded View	628
HOOD LOCK CONTROL : Removal and Installa- tion	605	Removal and Installation	628
		REMOTE KEYLESS ENTRY RECEIVER	629
		Removal	629
		Installation	629

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[COUPE]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005428894

OVERALL SEQUENCE



DETAILED FLOW

JMKIA2270GB

DIAGNOSIS AND REPAIR WORKFLOW

[COUPE]

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT-III.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3

Symptom is described, DTC is not displayed>>GO TO 4

Symptom is not described, DTC is displayed>>GO TO 5

3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5

4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [DLK-148. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check. If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

YES >> GO TO 7

NO >> Refer to [GI-41. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

[COUPE]

< BASIC INSPECTION >

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

Is malfunctioning part detected?

YES >> GO TO 8

NO >> Check voltage of related BCM terminals using CONSULT-III.

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9

9. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is the inspection result normal?

NO (DTC is detected)>>GO TO 7

NO (Symptom remains)>>GO TO 6

YES >> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[COUPE]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005428895

Perform the system initialization when replacing BCM, replacing Intelligent Key or registering an additional Intelligent Key.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement


INFOID:000000005428896

Refer to the CONSULT-III Operation Manual for the initialization procedure.

FUNCTION DIAGNOSIS

AUTOMATIC DOOR LOCKS

System Diagram



System Description

INFOID:000000005428898

Input	Single	Function	Actuator
Door lock/unlock switch	Door lock/unlock signal	Door lock function	• Each door lock actuator
Door key cylinder switch			
Each door switch	Door open/close signal	Key reminder function	
Key slot	Key insert/remove signal		
Combination meter	Warning buzzer signal	Automatic door lock/unlock function	
	Vehicle speed signal		

DOOR LOCK FUNCTION

- The door lock and unlock switch (driver side) is build into power window main switch.
- The door lock and unlock switch (passenger side) is on door trim.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Door Key Cylinder

- With the door key inserted in the door key cylinder on driver side, turning it to “LOCK”, will lock door lock actuator of all doors.
- With the door key inserted in the door key cylinder on driver side, turning it to “UNLOCK” once unlocks the driver side door lock actuator; turning it to “UNLOCK” again within 60 seconds after the first unlock operation unlocks all of the other doors. - (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using “DOOR LOCK-UNLOCK SET” mode in “WORK SUPPORT”. Refer to [DLK-53. "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

AUTOMATIC DOOR LOCKS (LOCK OPERATION)

The automatic door locks function is the function that locks all doors linked with the vehicle speed or shift position.

Vehicle Speed Sensing Auto Door Lock*1

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

AUTOMATIC DOOR LOCKS

[COUPE]

< FUNCTION DIAGNOSIS >

If a door is opened and closed at any time during one ignition cycle (OFF → ON), even after initial auto door lock operation has taken place, the BCM will relock all doors when the vehicle speed reaches 24 km/h (15 MPH) or more again.

Setting change of Automatic Door Locks (LOCK) Function

The LOCK operation setting of the automatic door locks function can be changed.

With CONSULT-III

The ON/OFF switching of the automatic door locks (LOCK) function and the type selection of the automatic door locks (LOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-53, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (LOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the ignition switch ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

AUTOMATIC DOOR LOCKS (UNLOCK OPERATION)

The automatic door locks (UNLOCK) function is the function that unlocks all doors linked with the key position or shift position.

IGN OFF Interlock Door Unlock*1

All doors are unlocked when the power supply position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

Setting change of Automatic Door Locks (UNLOCK) Function

The UNLOCK operation setting of the automatic door locks function can be changed.

With CONSULT- III

The ON/OFF switching of the automatic door locks (UNLOCK) function and the type selection of the automatic door locks (UNLOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-53, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (UNLOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power supply position ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

*1: This function is set to ON before delivery.


AUTOMATIC DOOR LOCKS

[COUPE]

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000005428899



DLK1A1732ZZ

- | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. BCM M16, M17, M18, M19, M21
(view with instrument panel removed)</p> | <p>2. Main power window and door lock/unlock switch D27 (with left power window anti-pinch system)
Main power window and door lock/unlock switch D28 (with left and right power window anti-pinch system)</p> | <p>3. Power window and door lock/unlock switch RH D110 (with left power window anti-pinch system)
Power window and door lock/unlock switch RH D105 (with left and right power window anti-pinch system)</p> |
| <p>4. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112</p> | <p>5. Door switch LH B68
Door switch RH B109</p> | <p>6. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4</p> |
| <p>7. Combination meter M24</p> | | |

DLK

Component Description

INFOID:000000005428900

Item	Function
BCM	Controls the door lock function and fuel lid door lock actuator function.
Door lock and unlock switch	Input lock or unlock signal to BCM.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Door key cylinder switch	<ul style="list-style-type: none"> Input lock or unlock signal to power window main switch. Power window main switch transmits door lock/unlock signal to BCM.
Key slot	Input key insert/remove signal to BCM.
Combination meter	<ul style="list-style-type: none"> Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer. Transmits vehicle speed signal to CAN communication line.
Push-button ignition switch	Input push-button ignition switch ON/OFF condition to BCM.

DOOR LOCK FUNCTION

[COUPE]


< FUNCTION DIAGNOSIS >

DOOR LOCK FUNCTION

DOOR LOCK AND UNLOCK SWITCH

DOOR LOCK AND UNLOCK SWITCH : System Diagram

INFOID:000000005428901



ALKIA0178GB

DOOR LOCK AND UNLOCK SWITCH : System Description

INFOID:000000005428902

Switch	Input/output signal to BCM	BCM function	Actuator
Main power window and door lock/unlock switch	Door lock/unlock signal	Door lock/unlock control	Door lock actuator
Power window and door lock/unlock switch			
Door key cylinder switch			

DOOR LOCK FUNCTION

Functions Available by Operating the Door Lock and Unlock Switches on Driver Door and Passenger Door

- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all door lock actuators are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all door lock actuators are unlocked.

Functions Available by Operating the Key Cylinder Switch on Driver Door

- Interlocked with the locking operation of door key cylinder, door lock actuators of all door lock actuators are locked.

Selective Unlock Operation

- When door key cylinder is unlocked, door lock actuator driver side is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

Select unlock operation mode can be changed using DOOR LOCK-UNLOCK SET mode in "WORK SUPPORT". Refer to [DLK-53, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Key Reminder System

Refer to [DLK-48, "System Description"](#).


DOOR LOCK FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH : Component Parts Location

INFOID:000000005428903



ALKIA1016ZZ

1. BCM M16, M17, M18, M19, M21
(view with instrument panel removed)
2. Main power window and door lock/unlock switch D27 (with left power window anti-pinch system)
Main power window and door lock/unlock switch D28 (with left and right power window anti-pinch system)
3. Power window and door lock/unlock switch RH D110 (with left power window anti-pinch system)
Power window and door lock/unlock switch RH D105 (with left and right power window anti-pinch system)
4. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112
5. Door switch LH B68
Door switch RH B109
6. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4

DLK

DOOR LOCK AND UNLOCK SWITCH : Component Description

INFOID:000000005428904

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Transmits lock or unlock signal to BCM.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Transmits door open/close condition to BCM.

DOOR REQUEST SWITCH


DOOR LOCK FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

DOOR REQUEST SWITCH : System Diagram

INFOID:000000005428905



ALKIA0082GB

DOOR REQUEST SWITCH : System Description

INFOID:000000005428906

Only when pressing the request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communications between the Intelligent Key and the vehicle (BCM).

CAUTION:

The driver should always carry the Intelligent Key

- If an action that does not meet the operating conditions of the Intelligent Key system is taken, the buzzer goes off to inform the driver (Warning chime function).
- When a door lock is locked, unlocked or trunk open with request switch or remote controller button operation, the hazard lamps flash and the Intelligent Key warning buzzer or horn sounds (Hazard and buzzer/horn reminder function).
- The settings for each function can be changed with the CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with the CONSULT-III.

OPERATION DESCRIPTION/DOOR LOCK/UNLOCK

- When the BCM detects that each door request switch is pressed, it starts the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM sends the door lock/unlock signal and sounds Intelligent Key buzzer warning (lock: 2 time, unlock: 1 times) at the same time as a reminder.

OPERATION CONDITION

If the following conditions are not satisfied, door lock/unlock operation is not performed even if the request switch is operated.

Each request switch operation	Operation condition
Lock operation	<ul style="list-style-type: none"> All doors are closed Ignition switch is in OFF position Intelligent Key is out of key slot Intelligent Key is outside the vehicle Intelligent Key is within outside key antenna detection area
Unlock Operation	<ul style="list-style-type: none"> Intelligent Key is outside the vehicle Intelligent Key is within outside key antenna detection area *

DOOR LOCK FUNCTION


[COUPE]

< FUNCTION DIAGNOSIS >

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver and passenger door handles (1).



SELECTIVE UNLOCK FUNCTION

When an LOCK signal is sent from door request switch (driver side or passenger side), all doors will be locked. When an UNLOCK signal is sent from door request switch (driver side or passenger side) once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from door request switch (driver side and passenger side) again within 5 seconds, all other door will be unlocked.

HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, or trunk opening operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, IPDM E/R honks Intelligent Key warning buzzer as a reminder and transmits hazard request signal to BCM via CAN communication line.

BCM flashes hazard warning lamps as a reminder.

Operating function of hazard warning lamps and buzzer reminder

Operation	Hazard warning lamps flash	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice
Trunk open	—	Four times

How to change hazard and buzzer reminder mode

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

AUTO DOOR LOCK FUNCTION

When all doors are locked, ignition switch is in OFF position and key switch is OFF (Intelligent Key is not inserted in key slot), doors are unlocked with door request switch

When BCM does not receive the following signals within 60 seconds, all doors are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON (ignition switch is pressed)
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by "AUTO LOCK SET" mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

ROOM LAMP OPERATION

When the following conditions are met:

- Condition of interior lamp switch is in DOOR position
- Door switch OFF (all the doors are closed)

Intelligent Key system turns on interior lamp (for up to 30 seconds maximum) by receiving UNLOCK signal from door request switch. For detailed description, refer to [DLK-18, "DOOR LOCK AND UNLOCK SWITCH : System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Door lock function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Door request switch (Driver, Passenger)	Door lock actuator	Inside key antenna	Outside key antenna (Driver, Passenger)	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamp	Push-button ignition switch
Door lock/unlock function by request switch	×	×	×	×	×	×	×	×		×	×		
Hazard and buzzer reminder function for door lock/unlock operation									×	×	×	×	
Key reminder function	×	×	×	×	×	×	×	×	×	×	×	×	
Selective unlock function by request switch (Driver side)	×				×	×	×	×		×	×		
Selective unlock function by request switch (Passenger side)	×				×	×	×	×		×	×		
Auto door lock function	×	×		×	×	×				×	×		×



DOOR LOCK FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

DOOR REQUEST SWITCH : Component Parts Location

INFOID:000000005428907




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABKIA2287Z2

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Push button ignition switch M38 | 11. Key slot M40 | 12. Front console antenna M203
(view with center console assembly removed) |
| 13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116 | 14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116 | 15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112 |
| 16. Door switch LH B68
Door switch RH B109 | 17. Rear parcel shelf antenna B29 | 18. Trunk opener request switch T2 |
| 19. Rear bumper antenna B46 | 20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4 | |

DOOR REQUEST SWITCH : Component Description

INFOID:000000005428908

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Transmits lock or unlock signal to BCM.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Transmits door open/close condition to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Request switch	Transmits lock/unlock operation to BCM.

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >


[COUPE]

Item	Function
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

INTELLIGENT KEY

INTELLIGENT KEY : System Diagram

INFOID:000000005428909



INTELLIGENT KEY : System Description

INFOID:000000005428910

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION DESCRIPTION/DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal is transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- When BCM receives the door lock/unlock signal, it operates door lock actuator, flashes the hazard lamp (lock: 2 times, unlock: 1 time) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 time) as a reminder

OPERATION CONDITION

Remote controller operation	Operation condition	Operation
Lock	• All doors closed	All doors lock
Unlock	• Intelligent Key is out of key slot	All doors unlock

OPERATION AREA

- Operating Range
- To ensure the Intelligent Key works effectively, use within 80 cm range of each doors, however the operable range may differ according to surroundings. The remote control operation range is greater than that of the Intelligent Key. Refer to Owner's Manual for more details.

SELECTIVE UNLOCK FUNCTION

When a LOCK signal is transmitted from Intelligent Key, all doors will be locked.

When an UNLOCK signal is transmitted from Intelligent Key once, driver's door will be unlocked.

Then, if an UNLOCK signal is transmitted from Intelligent Key again within 5 seconds, all other doors will be unlocked.

HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM flashes hazard warning lamps as a reminder and sends horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

DOOR LOCK FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

Operating function of hazard and horn reminder

	C mode			S mode		
	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Intelligent Key operation	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Hazard warning lamp flash	Twice	Once	—	Twice	—	—
Horns sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if any door switch is ON (any door is OPEN).

How to change hazard and horn reminder mode

Ⓟ With CONSULT-III

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

ⓧ Without CONSULT-III

Refer to Owner's Manual for instructions.

AUTO DOOR LOCK FUNCTION

Auto Door Lock Function

When all doors are locked, ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), doors are unlocked with Intelligent Key button. When BCM does not receive the following signals within 60 seconds, all doors are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by DOOR LOCK-UNLOCK SET mode in "WORK SUPPORT". Refer to [DLK-53, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

PANIC ALARM FUNCTION

When ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), BCM receives PANIC ALARM signal from Intelligent Key.

BCM turns on and off headlamp intermittently and transmits theft warning horn signal to IPDM E/R. Then, IPDM E/R turns on and off horn intermittently.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off:

- After 25 seconds
- When BCM receives any signal from Intelligent Key

Panic alarm function mode can be changed by PANIC ALARM SET mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

KEYLESS POWER WINDOW DOWN (OPEN) FUNCTION

Front power windows (with left and right front power window anti-pinch system) open when the unlock button on Intelligent Key is activated and kept pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, Keyless power window down (open) function cannot be operated.

Keyless power window down operation mode can be changed by PW DOWN SET mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

ROOM LAMP ILLUMINATION OPERATION

When the following conditions are met:

- Condition of interior lamp switch is in DOOR position
- Door switch OFF (all the doors are closed)

Intelligent Key system turns on interior lamp (for 15 seconds) by receiving UNLOCK signal from Intelligent Key. For detailed description, refer to [DLK-25, "INTELLIGENT KEY : System Description".](#)

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Remote keyless entry functions	Intelligent Key	Key slot	Door request switch (Driver, Passenger)	Door switch	Door lock actuator	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	Horn	IPDM E/R	Head lamp
Door lock/unlock function by remote control button	×	×		×	×		×	×					
Hazard and horn reminder function	×					×	×	×	×	×	×	×	
Selective unlock function	×			×	×		×	×					
Keyless power window down (open) function	×	×					×	×					
Auto door lock function	×	×		×			×	×					
Panic alarm function	×	×	×				×	×	×		×	×	×

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK



DOOR LOCK FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

INTELLIGENT KEY : Component Parts Location


INFOID:000000005783184



DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABK1A2287ZZ

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Push button ignition switch M38 | 11. Key slot M40 | 12. Front console antenna M203
(view with center console assembly removed) |
| 13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116 | 14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116 | 15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112 |
| 16. Door switch LH B68
Door switch RH B109 | 17. Rear parcel shelf antenna B29 | 18. Trunk opener request switch T2 |
| 19. Rear bumper antenna B46 | 20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4 | |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY : Component Description

INFOID:000000005428912

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Intelligent key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

TRUNK OPEN FUNCTION


[COUPE]

< FUNCTION DIAGNOSIS >

TRUNK OPEN FUNCTION TRUNK LID OPENER SWITCH

TRUNK LID OPENER SWITCH : System Diagram

INFOID:000000005428913



ALKIA0180GB

TRUNK LID OPENER SWITCH : System Description

INFOID:000000005428914

Switch	Input/output signal to BCM	BCM function	Actuator
Trunk lid opener switch	Trunk open signal	Trunk open control	Trunk lid opener actuator
Trunk lid opener cancel switch			

TRUNK LID OPENER OPERATION

When trunk lid opener switch is ON, BCM opens trunk opener actuator.

BCM can open trunk lid opener actuator when

- vehicle speed is less than 5 km/h (3MPH)
- vehicle security system is disarmed or pre-armed phase

BCM does not open trunk lid opener actuator when

- trunk lid opener cancel switch is OFF (CANCEL)
- vehicle speed is more than 5 km/h (3MPH)
- vehicle security system is armed or alarm phase
- Within 3 seconds of removing the Intelligent Key from the key slot


TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

TRUNK LID OPENER SWITCH : Component Parts Location

INFOID:000000005428915



- 1. BCM M16, M17, M18, M20, M21 (view with instrument panel removed)
- 2. Trunk lid opener switch M75
- 3. Trunk lid opener cancel switch M74
- 4. Trunk lamp switch and trunk release solenoid (trunk release solenoid) T4

TRUNK LID OPENER SWITCH : Component Description

INFOID:000000005428916

Item	Function
BCM	Transmits trunk open operation to BCM.
Trunk lid opener switch	Transmits trunk open operation to BCM.
Trunk release solenoid	Opens the trunk with the open signal from BCM
Trunk lid opener cancel switch	Cancels the trunk open operation.

TRUNK REQUEST SWITCH

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

TRUNK REQUEST SWITCH : System Diagram

INFOID:000000005428917



TRUNK REQUEST SWITCH : System Description

INFOID:000000005428918

Only when pressing the request switch, it is possible to open the trunk by carrying the Intelligent Key.

- The Intelligent Key system is a system that makes it possible to open the trunk (trunk open function) by carrying the Intelligent Key which operates based on the results of electronic ID verification using two-way communications between the Intelligent Key and the vehicle (BCM).

CAUTION:

The driver should always carry the Intelligent Key

- If an action that does not meet the operating conditions of the Intelligent Key system is taken, the buzzer goes off to inform the driver (warning chime functions).
- When a trunk open with request switch or remote controller button operation, the hazard lamps flash and the Intelligent Key warning buzzer or horns sound (hazard and buzzer/horn reminder function).
- The settings for each function can be changed with the CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with the CONSULT-III.

OPERATION DESCRIPTION/TRUNK OPEN

- When the BCM detects that trunk open request switch is pressed, it starts the outside key antenna (trunk room) and inside key antenna corresponding to the pressed trunk open request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the trunk.
- If the Intelligent Key is within the outside key antenna (trunk room) detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM transmits the trunk open request signal and sounds Intelligent Key warning buzzer 4 consecutive times.
- When BCM receives the trunk open request signal, it operates the trunk release solenoid and opens the trunk.

OPERATION CONDITION

If the following conditions are not satisfied, trunk open operation is not performed even if the request switch is operated.

Each request switch operation	Operation condition
Trunk open operation	<ul style="list-style-type: none"> • Intelligent Key is within outside key antenna (trunk room) detection area* • Trunk cancel switch is ON • Key reminder functions operate (trunk)

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.


OUTSIDE KEY ANTENNA DETECTION AREA

TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

The outside key antenna detection area of trunk open function is in the range of approximately 80 cm (31.50 in) surrounding Trunk opener request switch (1). However, this operating range depends on the ambient conditions.



KEY REMINDER FUNCTION

Key reminder function	Operation condition	Operation
Trunk is closed	Right after trunk is closed under the following conditions <ul style="list-style-type: none"> • Intelligent Key is inside trunk room • All doors are closed • All doors are locked 	<ul style="list-style-type: none"> • Trunk open • Honk Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation will be perform at these cases.

CAUTION:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function will not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.
- When the key reminder function is operated when the trunk is opened/closed and the buzzers sound, if the following operations are performed, the key reminder function is cleared and buzzer sounds are stopped.
 - Remote controller door lock button operation of Intelligent Key
 - Remote controller door unlock button operation of Intelligent Key
 - When the trunk is closed, the Intelligent Key is not inside the vehicle
 - When any door is open

HAZARD AND BUZZER REMINDER FUNCTION

During trunk opening operation by request switch, the hazard warning lamps and Intelligent Key warning buzzer will flash or honk as a reminder.

When trunk open by each request switch, IPDM E/R honks Intelligent Key warning buzzer as a reminder and transmits hazard request signal to BCM via CAN communication line.

BCM flashes hazard warning lamps as a reminder.

Operating function of hazard and buzzer reminder

Operation	Hazard warning lamp flash	Intelligent Key warning buzzer honks
Trunk open	—	Four times

How to change hazard and buzzer reminder mode

🔑 With CONSULT-III

Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Trunk open function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Trunk room lamp switch	Trunk opener request switch	Trunk release solenoid	Inside key antenna	Outside key antenna (Trunk)	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamps	Trunk lid opener cancel switch
Trunk open function by the trunk opener request switch	×		×		×	×	×	×	×		×	×		×
Hazard and buzzer reminder function for door lock/unlock operation										×	×	×	×	
Buzzer reminder for trunk open operation										×	×	×		
Key reminder function	×	×	×	×				×	×	×	×	×	×	



TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

TRUNK REQUEST SWITCH : Component Parts Location

INFOID:000000005783183




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABKIA2287ZZ

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Push button ignition switch M38 | 11. Key slot M40 | 12. Front console antenna M203
(view with center console assembly removed) |
| 13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116 | 14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116 | 15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112 |
| 16. Door switch LH B68
Door switch RH B109 | 17. Rear parcel shelf antenna B29 | 18. Trunk opener request switch T2 |
| 19. Rear bumper antenna B46 | 20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4 | |

TRUNK REQUEST SWITCH : Component Description

INFOID:000000005428920

Item	Function
BCM	Controls trunk open function.
Trunk release solenoid	Transmits trunk open operation to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Trunk opener request switch	Transmits trunk open operation to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.

TRUNK OPEN FUNCTION

[COUPE]


< FUNCTION DIAGNOSIS >

Item	Function
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

INTELLIGENT KEY

INTELLIGENT KEY : System Diagram

INFOID:000000005428921



INTELLIGENT KEY : System Description

INFOID:000000005428922

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the trunk open button.

OPERATION DESCRIPTION/TRUNK OPEN FUNCTION

- When trunk button of the Intelligent Key is pressed, the trunk open signal is transmitted from the Intelligent Key to the BCM via remote keyless entry receiver.
- When BCM receives the trunk open request signal, it operates the trunk lid opener actuator and opens the trunk.

OPERATION CONDITION

Remote controller operation	Operation condition	Operation
Trunk open	• Press and hold the trunk open button for 0.5 second or more	Trunk open

OPERATION AREA

- To ensure the Intelligent Key works effectively, use within 80 cm (31.50 inches) range of each door, however the operable range may differ according to surroundings.

HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM flashes hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sound horns as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating function of hazard and horn reminder

	C mode			S mode		
	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Intelligent Key operation	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Hazard warning lamp flash	Twice	Once	—	Twice	—	—
Horn sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if any door switch is ON (any door is OPEN).

How to change hazard and horn reminder mode

Ⓟ With CONSULT-III

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

ⓧ Without CONSULT-III

TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

Refer to Owner's Manual for instructions.

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Key slot	Trunk room lamp switch	Trunk release solenoid	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamps	Horns	IPDM E/R
Trunk open function by remote control button	×	×	×	×		×	×				
Hazard and horn reminder function	×				×	×	×	×	×	×	×



TRUNK OPEN FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

INTELLIGENT KEY : Component Parts Location

INFOID:000000005783182




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABKIA2287Z2

1. Horn (low) E215
(view with front fender protector LH removed)
2. Horn (high) E216
(view with front fender protector LH removed)
3. IPDM E/R E17, E18
4. Fuse and fusible link box (horn relay H-1)
5. Intelligent Key warning buzzer E74
6. Remote keyless entry receiver M27
(view with instrument panel removed)
7. Trunk lid opener cancel switch M74
8. Combination meter M24
9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed)
10. Push button ignition switch M38
11. Key slot M40
12. Front console antenna M203
(view with center console assembly removed)
13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116
14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116
15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112
16. Door switch LH B68
Door switch RH B109
17. Rear parcel shelf antenna B29
18. Trunk opener request switch T2
19. Rear bumper antenna B46
20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4

INTELLIGENT KEY : Component Description

INFOID:000000005428924

Item	Function
BCM	Controls trunk open function.
Trunk release solenoid	Opens the trunk with the open signal from BCM.
Remote keyless entry receiver	Receives trunk open signal from the Intelligent Key, and then transmits to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with a buzzer sound.

WARNING FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

WARNING FUNCTION

System Description

INFOID:000000005428925

OPERATION DESCRIPTION

The warning functions are as follows and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, KEY warning lamp, key slot illumination and combination meter display in combination meter.

- Intelligent Key system malfunction
- OFF position warning
- P position warning
- ACC warning
- Take away warning
- Door lock operation warning
- Key warning
- Intelligent Key insert information
- Engine start information
- Intelligent key low battery warning
- Key ID warning

OPERATION CONDITION

Once the following condition from below is established, alert or warning will be executed.

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM, "KEY" warning lamp will illuminate.
OFF position warning	For internal	<ul style="list-style-type: none"> • Ignition switch: ACC position. • Door switch (driver side): ON (Door is open).
	For external	<p>OFF position warning (For internal) is in active mode, driver side door has been closed.</p> <p>NOTE: OFF position (For external) active only when each of the sequence has occurred as below: P position warning → ACC warning → OFF position warning (For internal) → OFF position warning (For internal)</p>
P position warning		<ul style="list-style-type: none"> • Shift position: Except P position • Engine is running to stopped (Ignition switch is ON to OFF)
ACC warning		<ul style="list-style-type: none"> • During P position warning is in active mode, shift position has changed P position. • Ignition switch: Except OFF position.
Take away warning	Door is open to close	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Door switch: ON to OFF (Door is open to close). • Intelligent Key can not be detected inside the vehicle.
	Door is open	<ul style="list-style-type: none"> • Door switch: ON (Door is open) • Key ID verification every 5 seconds when registered Intelligent Key can not be detected inside the vehicle.
	Push-ignition switch operation	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Press ignition switch. • Intelligent Key can not be detected inside the vehicle.
	Take away through window	<ul style="list-style-type: none"> • Engine is running. • Key ID verification every 30 seconds when registered Intelligent Key can not be detected inside the vehicle. • After vehicle speed verification, the registered Intelligent Key can not be detected inside the vehicle.
	Intelligent Key is removed from key slot	<ul style="list-style-type: none"> • When Intelligent Key is removed from key slot, Intelligent Key can not be detected inside the vehicle.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING FUNCTION

[COUPE]



< FUNCTION DIAGNOSIS >

Warning/Information functions		Operation procedure
Door lock operation warning	Request switch operation	When request switch is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • Door switch: ON (Any door is open). • Intelligent Key is inside vehicle.
	Intelligent Key button operation	When Intelligent Key button is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • Door switch: ON (Any door is open). • For 3 seconds after Intelligent Key is removed from key slot.
Key warning		<ul style="list-style-type: none"> • Ignition switch is OFF position. • Driver side door switch: ON (Driver side door is open). • Intelligent Key is inserted in key slot.
Intelligent Key insert information		<ul style="list-style-type: none"> • Door switch: ON to OFF (Door is open to close). • Ignition switch: OFF to ON position. • Intelligent Key is out of key slot. • Intelligent Key can not be detected inside the vehicle.
Engine start information	Ignition switch is ON position	<ul style="list-style-type: none"> • Ignition switch: ON position. • Shift position: P position • Engine is stopped
	Ignition switch is except ON position	<ul style="list-style-type: none"> • Ignition switch: Except ON position. • Shift position: P position • Intelligent Key is inserted in key slot. • Intelligent Key can be detected inside the vehicle.
Intelligent Key low battery warning		When Intelligent Key has low battery, it is detected by BCM after ignition switch is turned ON.
Key ID warning		When registered intelligent Key cannot be detected inside the vehicle after ignition switch is turned ON.

WARNING METHOD

The following table shows the alarm or warning methods with chime.





Meter display, "KEY" indicator or key slot illumination when the warning conditions are met.

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction		Illuminate	—	—	—	—
OFF position warning	For internal	—	—	—	Activate	—
	For external	—	—	—	—	Activate
P position warning		—	 <small>JMKIA0037GB</small>	—	Activate	—
ACC warning		—	 <small>JMKIA0047GB</small>	—	Activate	—

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Take away warning	Door is open to close	—		Flash	Activate	Activate
	Door is open	—		Flash	—	—
	Push-ignition switch operation	—		Flash	Activate	—
	Take away through window	—		Flash	Activate	—
	Intelligent Key is removed from key slot	—		Flash	—	—
Door lock operation warning	Request switch operation	—	—	—	—	Activate
	Intelligent Key operation	—	—	—	—	Activate
Key ID warning		—		—	—	—
Key warning		—		Flash	Activate	—
Intelligent Key insert information		—		Flash	—	—




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

WARNING FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Engine start information	Automatic transmission models	—	 <small>JMKIA0032GB</small>	—	—	—
	Manual transmission models	—	 <small>ALKIA1326GB</small>	—	—	—
Intelligent Key low battery warning		—	 <small>JMKIA0048GB</small>	—	—	—

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Park position switch	"KEY" warning lamp
		Intelligent Key system malfunction											×	×		
OFF position warning	For internal				×					×	×	×				
	For external				×				×		×	×				
P position warning				×						×	×	×	×		×	
ACC warning				×						×	×	×	×		×	
Take away warning	Door is open or close	×			×		×		×	×	×	×	×	×		
	Door is open	×			×		×			×	×	×	×	×		
	Push-ignition switch operation	×		×			×			×	×	×	×	×		
	Take away through window	×					×			×	×	×	×	×		
	Intelligent Key is removed from key slot	×	×				×				×	×	×	×		

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Warning function	Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Park position switch	"KEY" warning lamp
Door lock operation warning	×	×		×	×	×	×	×		×	×				
Key ID warning	×	×	×			×				×	×	×			
Key warning	×	×		×					×	×	×	×	×		
Intelligent Key insert information	×	×	×	×		×				×	×	×	×		
Engine start information	Ignition switch is ON position	×	×			×				×	×	×		×	
	Ignition switch is except ON position	×	×	×		×				×	×	×			
Intelligent Key low battery warning	×					×				×	×	×			

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK



WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]

Component Parts Location


INFOID:000000005783181



WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABK1A2287ZZ

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Push button ignition switch M38 | 11. Key slot M40 | 12. Front console antenna M203
(view with center console assembly removed) |
| 13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116 | 14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116 | 15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112 |
| 16. Door switch LH B68
Door switch RH B109 | 17. Rear parcel shelf antenna B29 | 18. Trunk opener request switch T2 |
| 19. Rear bumper antenna B46 | 20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4 | |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

KEY REMINDER FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

KEY REMINDER FUNCTION

System Description

INFOID:000000005428927

Key reminder is the function that prevents the key from being left in the vehicle. Key reminder has the following 3 functions.

Key reminder function	Operation condition	Operation
Driver door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none">• Door lock operation is performed• Driver side door is opened• Driver side door is in unlock state	All doors unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none">• Intelligent Key is inside the vehicle• Any door is opened• All doors are locked by door lock and unlock switch or door lock knob	<ul style="list-style-type: none">• All doors unlock• Sounds Intelligent Key warning buzzer
Trunk is closed	Right after trunk is closed under the following conditions <ul style="list-style-type: none">• Intelligent Key is inside trunk room• All doors are closed• All doors are locked	<ul style="list-style-type: none">• Trunk open• Sounds Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation will be performed in these cases.

CAUTION:

- **The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function will not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.**
- **When the key reminder function is operated when the trunk is open/closed and the buzzers sound, if the following operations are performed, the key reminder function is cleared and buzzer sounds are stopped.**
 - Remote controller door lock button operation of Intelligent Key
 - Remote controller door unlock button operation of Intelligent Key
 - When the trunk is closed, the Intelligent Key is not inside the vehicle
 - When any door is open



KEY REMINDER FUNCTION

[COUPE]

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000005783180




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

KEY REMINDER FUNCTION

< FUNCTION DIAGNOSIS >

[COUPE]



ABKIA2287ZZ

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Push button ignition switch M38 | 11. Key slot M40 | 12. Front console antenna M203
(view with center console assembly removed) |
| 13. Outside handle LH (outside key antenna) D17
Outside handle RH (outside key antenna) D116 | 14. Outside handle LH (request switch) D17
Outside handle RH (request switch) D116 | 15. Door lock assembly LH D25 (with left power window anti-pinch system)
Door lock assembly LH D26 (with left and right power window anti-pinch system)
Door lock actuator RH D112 |
| 16. Door switch LH B68
Door switch RH B109 | 17. Rear parcel shelf antenna B29 | 18. Trunk opener request switch T2 |
| 19. Rear bumper antenna B46 | 20. Trunk lamp switch and trunk release solenoid (trunk lamp switch) T4 | |

HOMELINK UNIVERSAL TRANSCEIVER

< FUNCTION DIAGNOSIS >

[COUPE]

HOMELINK UNIVERSAL TRANSCEIVER

Component Description

INFOID:000000005428929

Item	Function	Reference page
Homelink universal transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.	Refer to Owner's Manual

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[COUPE]

DIAGNOSIS SYSTEM (BCM) COMMON ITEM

COMMON ITEM : Diagnosis Description

INFOID:000000005783185

BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF DIAGNOSTIC RESULT	Displays the diagnosis results judged by BCM.
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system ¹	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioner	AIR CONDITONER		×	
Intelligent Key system ²	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
BCM	BCM	×		
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

1 : With remote keyless entry system

2: With intelligent Key system

COMMON ITEM : CONSULT-III Function

INFOID:000000005783186

ECU IDENTIFICATION

DIAGNOSIS SYSTEM (BCM)

[COUPE]

< FUNCTION DIAGNOSIS >

Displays the BCM part No.

SELF-DIAG RESULT

Refer to [BCS-70, "DTC Index"](#).

DOOR LOCK

DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)

INFOID:000000005783187

WORK SUPPORT

Work Item	Description
DOOR LOCK-UNLOCK SET	<ul style="list-style-type: none">• ON• OFF
AUTOMATIC DOOR LOCK SELECT	<ul style="list-style-type: none">• P RANGE• VH SPD
AUTOMATIC DOOR UNLOCK SELECT	<ul style="list-style-type: none">• MODE1• MODE2• MODE3• MODE4
AUTOMATIC LOCK/UNLOCK SELECT	<ul style="list-style-type: none">• LOCK/UNLOCK• LOCK ONLY• UNLOCK ONLY• OFF

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW-DR [ON/OFF]	Indicates condition of door request switch LH
REQ SW-AS [ON/OFF]	Indicates condition of door request switch RH
REQ SW-BD/TR [ON/OFF]	Indicates condition of back door request switch
DOOR SW-DR [ON/OFF]	Indicates condition of front door switch LH
DOOR SW-AS [ON/OFF]	Indicates condition of front door switch RH
DOOR SW-RR [ON/OFF]	Indicates condition of rear door switch RH
DOOR SW-RL [ON/OFF]	Indicates condition of rear door switch LH
DOOR SW-BK [ON/OFF]	Indicates condition of back door switch
KEY CYL LK-SW [ON/OFF]	Indicates condition of lock signal from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Indicates condition of unlock signal from door key cylinder switch
CDL LOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [OTR ULK / AS UNLK / DR UNLK / ALL UNLK / ALL LCK].

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY)

INFOID:000000005783188

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[COUPE]

Monitor item	Description
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode.
AUTO LOCK SET	Auto door lock time can be changed in this mode. <ul style="list-style-type: none"> • MODE1: 1 minute • MODE2: 5 minutes • MODE3: 30 seconds • MODE4: 2 minutes
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operate (ON) or not operate (OFF) in this mode.
ENGINE START BY I-KEY	Engine start function mode can be changed to operate (ON) or not operate (OFF) with this mode.
TRUNK/GLASS HATCH OPEN	Buzzer reminder function mode by back door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
PANIC ALARM SET	Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 0.5 sec. • MODE2: Non-operation • MODE3: 1.5 sec.
PW DOWN SET	Unlock button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 3 sec. • MODE2: Non-operation • MODE3: 5 sec.
TRUNK OPEN DELAY	Trunk button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 0.5 sec. • MODE2: 1.5 sec. • MODE3: OFF: No delay
LO- BATT OF KEY FOB WARN	Intelligent Key low battery warning mode can be changed to operate (ON) or not operate (OFF) with this mode.
ANTI KEY LOCK IN FUNCTI	Key reminder function mode can be changed to operate (ON) or not operate (OFF) with this mode.
HAZARD ANSWER BACK	Hazard reminder function mode can be selected from the following with this mode. <ul style="list-style-type: none"> • LOCK ONLY: Door lock operation only • UNLOCK ONLY: Door unlock operation only • LOCK/UNLOCK: Lock/unlock operation • OFF: Non-operation
ANS BACK I-KEY LOCK	Buzzer reminder function (lock operation) mode by door request switch (driver side and passenger side) can be selected from the following with this mode. <ul style="list-style-type: none"> • Horn chirp: Sound horn • Buzzer: Sound Intelligent Key warning buzzer • OFF: Non-operation
ANS BACK I-KEY UNLOCK	Buzzer reminder function (unlock operation) mode by door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
SHORT CRANKING OUTPUT	Starter motor can be forcibly activated.
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis.
HORN WITH KEYLESS LOCK	Horn reminder function mode by Intelligent Key button can be changed to operate (ON) or not operate (OFF) with this mode.

SELF-DIAG RESULT

Refer to [DLK-149. "DTC Index"](#).

DATA MONITOR

Monitor Item	Condition
REQ SW -DR	Indicates [ON/OFF] condition of door request switch (driver side).
REQ SW -AS	Indicates [ON/OFF] condition of door request switch (passenger side).

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[COUPE]

Monitor Item	Condition
REQ SW -BD/TR	Indicates [ON/OFF] condition of back door request switch.
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY2 -F/B	Indicates [ON/OFF] condition of ignition relay 2.
ACC RLY-F/B	Indicates [ON/OFF] condition of accessory relay.
CLUCH SW*1	Indicates [ON/OFF] condition of clutch switch.
BRAKE SW 1	Indicates [ON/OFF]*2 condition of brake switch power supply.
BRAKE SW 2	Indicates [ON/OFF] condition of brake switch.
DETE/CANCL SW	Indicates [ON/OFF] condition of P position.
SFT PN/N SW	Indicates [ON/OFF] condition of P or N position.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
PUSH SW -IPDM	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY1 -F/B	Indicates [ON/OFF] condition of ignition relay 1.
DETE SW -IPDM	Indicates [ON/OFF] condition of P position.
SFT PN -IPDM	Indicates [ON/OFF] condition of P or N position.
SFT P -MET	Indicates [ON/OFF] condition of P position.
SFT N -MET	Indicates [ON/OFF] condition of N position.
ENGINE STATE	Indicates [STOP/STALL/CRANK/RUN] condition of engine states.
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [mph].
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [mph].
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver side door status.
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger side door status.
ID OK FLAG	Indicates [SET/RESET] condition of key ID.
PRMT ENG STRT	Indicates [SET/RESET] condition of engine start possibility.
KEY SW -SLOT	Indicates [ON/OFF] condition of key slot.
TRNK/HAT MNTR	Indicates [ON/OFF] condition of trunk lid.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from Intelligent Key.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key.
RKE-PANIC	Indicates [ON/OFF] condition of PANIC button of Intelligent Key.
RKE-P/W OPEN	Indicates [ON/OFF] condition of P/W DOWN signal from Intelligent Key.
RKE-MODE CHG	Indicates [ON/OFF] condition of MODE CHANGE signal from Intelligent Key.
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
REVERSE SW	Indicates [ON/OFF] condition of R position.

*1: It is displayed but does not operate on M/T models.

*2: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT-III screen is touched.
PW REMOTO DOWN SET	This test is able to check power window down operation. The power window down is activated after "ON" on CONSULT-III screen is touched.
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation. The Intelligent Key warning buzzer is activated after "ON" on CONSULT-III screen is touched.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[COUPE]

Test item	Description
INSIDE BUZZER	<p>This test is able to check warning chime in combination meter operation.</p> <ul style="list-style-type: none"> • Take away warning chime sounds when "TAKE OUT" on CONSULT-III screen is touched. • Key warning chime sounds when "KEY" on CONSULT-III screen is touched. • OFF position warning chime sounds when "KNOB" on CONSULT-III screen is touched.
INDICATOR	<p>This test is able to check warning lamp operation.</p> <ul style="list-style-type: none"> • "KEY" Warning lamp illuminates when "KEY ON" on CONSULT-III screen is touched. • "KEY" Warning lamp blinks when "KEY IND" on CONSULT-III screen is touched.
INT LAMP	<p>This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT-III screen is touched.</p>
LCD	<p>This test is able to check meter display information</p> <ul style="list-style-type: none"> • Engine start information displays when "BP N" on CONSULT-III screen is touched. • Engine start information displays when "BP I" on CONSULT-III screen is touched. • Key ID warning displays when "ID NG" on CONSULT-III screen is touched. • P position warning displays when "SFT P" on CONSULT-III screen is touched. • Intelligent Key insert information displays when "INSRT" on CONSULT-III screen is touched. • Intelligent Key low battery warning displays when "BATT" on CONSULT-III screen is touched. • Take away through window warning displays when "NO KY" on CONSULT-III screen is touched. • Take away warning display when "OUTKEY" on CONSULT-III screen is touched. • OFF position warning display when "LK WN" on CONSULT-III screen is touched.
FLASHER	<p>This test is able to check hazard warning lamp operation. The hazard warning lamps are activated after "LH/RH/OFF" on CONSULT-III screen is touched.</p>
HORN	<p>This test is able to check horn operation. The horn is activated after "ON" on CONSULT-III screen is touched.</p>
P RANGE	<p>This test is able to check CVT shift selector power supply CVT shift selector power is supplied when "ON" on CONSULT-III screen is touched.</p>
ENGINE SW ILLUMI	<p>This test is able to check push-ignition switch illumination operation. Push-ignition switch illumination illuminates when "ON" on CONSULT-III screen is touched.</p>
LOCK INDICATOR	<p>This test is able to check LOCK indicator in push-ignition switch operation. LOCK indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.</p>
ACC INDICATOR	<p>This test is able to check ACC indicator in push-ignition switch operation. ACC indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.</p>
IGNITION ON IND	<p>This test is able to check ON indicator in push-ignition switch operation. ON indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.</p>
KEY SLOT ILLUMI	<p>This test is able to check key slot illumination operation. Key slot illumination blinks when "ON" on CONSULT-III screen is touched.</p>
TRUNK/BACK DOOR	<p>This test is able to check back door opener actuator open operation. This actuator opens when "OPEN" on CONSULT-III screen is touched.</p>

TRUNK

TRUNK : CONSULT-III Function (BCM - TRUNK)

INFOID:000000005783189

DATA MONITOR

Monitor Item	Contents
PUSH SW	Indicates [ON/OFF] condition of push button ignition switch.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
VEH SPEED 1	Indicates [mph] condition of vehicle speed signal from combination meter.
TR CANCEL SW	Indicates [ON/OFF] condition of trunk cancel switch.
TR/BD OPEN SW	Indicates [ON/OFF] condition of trunk opener switch.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[COUPE]

Monitor Item	Contents
TRNK/HAT MNTR	Indicates [ON/OFF] condition of trunk lid.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key.

A

B

ACTIVE TEST

Test Item	Description
TRUNK/GLASS HATCH	This test is able to check trunk open operation. Trunk opens when "OPEN" on CONSULT-III screen is touched.

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000005428935

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.
 CAN Communication Signal Chart. Refer to [LAN-26, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000005428936

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1000	CAN COMM CIRCUIT	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none"> • Transmission • Receiving (ECM) • Receiving (VDC/TCS/ABS) • Receiving (METER/M&A) • Receiving (TCM) • Receiving (MULTI AV) • Receiving (IPDM E/R)

Diagnosis Procedure

INFOID:000000005428937

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-8, "CAN Communication Control Circuit"](#).
 NO >> Refer to [GI-41, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[COUPE]

< COMPONENT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000005428938

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1010	CONTROL UNIT (CAN)	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:000000005428939

1. REPLACE BCM

When DTC [U1010] is detected, replace BCM.

>> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000005428940

1. REQUIRED WORK WHEN REPLACING BCM

Initialize NVIS by CONSULT-III. For the details of initialization refer to CONSULT-III Operation Manual.

>> Work End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2622 INSIDE KEY ANTENNA 2

[COUPE]

< COMPONENT DIAGNOSIS >

B2622 INSIDE KEY ANTENNA 2

Description

INFOID:000000005428944

Detects whether Intelligent Key is inside the vehicle.
Installed in the console.

DTC Logic

INFOID:000000005428945

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none">• Front console antenna• Between BCM and front console antenna.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-III

1. Perform front console antenna INSIDE ANT DIAGNOSIS on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is front console antenna DTC detected?

- YES >> Refer to [DLK-60, "Diagnosis Procedure"](#).
NO >> Front console antenna is OK.


Diagnosis Procedure

INFOID:000000005428946

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



B2622 INSIDE KEY ANTENNA 2

< COMPONENT DIAGNOSIS >

[COUPE]

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M19	Front console antenna	61	Ground	Place Intelligent Key inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
			Ground	Place Intelligent Key outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
- NO >> GO TO 2

2. CHECK FRONT CONSOLE ANTENNA CIRCUIT

1. Disconnect BCM and front console antenna connector.
2. Check continuity between BCM connector and front console antenna connector.

BCM connector	Terminal	Front console antenna connector		Terminal	Continuity
A: M19	60	B: M203	Console	2	Yes
	61			1	

3. Check continuity between BCM connector and ground.


BCM connector	Terminal	Ground	Continuity
A: M19	Console		60
		61	

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and front console antenna.

3. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 2

1. Replace front console antenna (New antenna or other antenna).
2. Connect BCM and front console antenna connector.




B2622 INSIDE KEY ANTENNA 2

[COUPE]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals				Condition	Signal (Reference value.)
(+)		(-)	BCM connector		
Terminal					
M19	Front console antenna	61	Ground	Place Intelligent Key inside the vehicle.	
				Place Intelligent Key outside the vehicle.	

Is the inspection result normal?

- YES >> Replace front console antenna. Refer to [IP-17. "Disassembly and Assembly"](#).
 NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

B2623 INSIDE KEY ANTENNA 3

[COUPE]

< COMPONENT DIAGNOSIS >

B2623 INSIDE KEY ANTENNA 3

Description

INFOID:000000005428947

Detects whether Intelligent Key is inside the vehicle.
Installed in the trunk room.

DTC Logic

INFOID:000000005428948

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3 CIRCUIT	An excessive high or low voltage from rear parcel shelf antenna is sent to BCM.	<ul style="list-style-type: none">rear parcel shelf antennaBetween BCM and rear parcel shelf antenna

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓟ With CONSULT-III

1. Perform rear parcel shelf antenna INSIDE ANT DIAGNOSIS on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is rear parcel shelf antenna DTC detected?

- YES >> Refer to [DLK-63. "Diagnosis Procedure"](#).
NO >> rear parcel shelf antenna is OK.


Diagnosis Procedure

INFOID:000000005428949

Regarding Wiring Diagram information, refer to [DLK-166. "Wiring Diagram"](#).

1. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



B2623 INSIDE KEY ANTENNA 3

[COUPE]

< COMPONENT DIAGNOSIS >

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M21	Rear parcel shelf antenna	115	Ground	Place Intelligent Key inside the vehicle.	<p>JMKIA0062GB</p>
				Place Intelligent Key outside the vehicle.	<p>JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
 NO >> GO TO 2


2. CHECK REAR PARCEL SHELF ANTENNA CIRCUIT

1. Disconnect BCM and rear parcel shelf antenna connector.
2. Check continuity between BCM connector and rear parcel shelf antenna connector.

BCM connector	Terminal	Rear parcel shelf antenna connector		Terminal	Continuity
A: M21	114	B: B29	Trunk room	2	Yes
	115			1	

3. Check continuity between BCM connector and ground.

BCM connector		Terminal	Ground	Continuity
A: M21	Trunk room	114		
		115		



Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness between BCM and rear parcel shelf antenna.

3. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 2


1. Replace rear parcel shelf antenna (New antenna or other antenna).
2. Connect BCM and rear parcel shelf antenna connector.

B2623 INSIDE KEY ANTENNA 3

[COUPE]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals			Condition	Signal (Reference value.)
(+)		(-)		
BCM connector	Terminal			
M21	Trunk room	115	Ground	<p>Place Intelligent Key inside the vehicle.</p>
				<p>Place Intelligent Key outside the vehicle.</p>

Is the inspection result normal?

- YES >> Replace rear parcel shelf antenna. Refer to [INT-15. "Removal and Installation"](#).
- NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

POWER SUPPLY AND GROUND CIRCUIT

[COUPE]

< COMPONENT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000005783578

Regarding Wiring Diagram information, refer to [BCS-75, "COUPE : Wiring Diagram"](#) or [BCS-84, "SEDAN : Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check if the following BCM fuse or fusible link are blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	H
11		10


Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground
Connector	Terminal	
M16	1	
M17	11	
		Battery voltage




Is the measurement normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	13		Yes



Does continuity exist?

- YES >> Inspection End.
NO >> Repair or replace harness.

Special Repair Requirement

INFOID:000000005783579

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-6, "CONFIGURATION \(BCM\) : Special Repair Requirement"](#).

>> Work End.

DOOR SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

DOOR SWITCH

Description

INFOID:000000005428952

Detects door open/close condition.

Component Function Check

INFOID:000000005428953

1.CHECK FUNCTION

With CONSULT-III

Check door switches DOOR SW-DR, DOOR SW-AS in Data Monitor mode with CONSULT-III.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	

Is the inspection result normal?

- YES >> Door switch is OK.
- NO >> Refer to [DLK-67, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428954

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL




1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



DOOR SWITCH

< COMPONENT DIAGNOSIS >

[COUPE]

Terminals		(-)	Door condition	Voltage (V) (Approx.)	
(+)	Terminal				
BCM connector	Terminal				
M18	58	Ground	Driver side	OPEN	0
			CLOSE		
	OPEN		0		
	CLOSE				
	32		Passenger side	OPEN	0
			CLOSE		

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
A: M18	58	B: B68 (Driver side)	2	Yes
	32	B: B109 (Passenger side)		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	58	Ground	No
	32		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and door switch.

3. CHECK DOOR SWITCH


Refer to [DLK-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Replace malfunctioning door switch.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).



DOOR SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

>> Inspection End.

Component Inspection

INFOID:000000005428955


1. CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
2	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace malfunctioning door switch.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005428956

Transmits door lock/unlock operation to BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005428957

1. CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> With LH and RH anti-pinch, refer to [DLK-70, "DRIVER SIDE : Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [DLK-72, "DRIVER SIDE : Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).


DRIVER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:000000005428958

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Read voltage signal between BCM connector and ground with oscilloscope when door lock and unlock switch (driver side) is turned "LOCK" or "UNLOCK".




2. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (driver side) is turned "LOCK" or "UNLOCK".

DOOR LOCK AND UNLOCK SWITCH

< COMPONENT DIAGNOSIS >

[COUPE]

Terminal		Condition	Signal (Reference value)
(+)	(-)		
BCM connector	Terminal		
M18	40	Ground	

PIIA1297E

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2


2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
D28	15	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.




ALKIA1042ZZ

3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and main power window and door lock/unlock switch connector.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
A: M18	40	B: D28	12	Yes



ALKIA1043ZZ

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	40		No

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

>> Inspection End.

DRIVER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)

INFOID:000000005428959

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).


1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage at the main power window and door lock/unlock switch connector when the switch (driver side) is turned to "LOCK" or "UNLOCK".

Connector	Main power window and door lock/unlock switch state	Terminal		Voltage
D28	Neutral → Lock	5	Ground	Battery voltage → 0
	Neutral → Unlock	6	Ground	Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 5
NO >> GO TO 2




2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
D28	10	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.




3. CHECK POWER WINDOW SWITCH

Check continuity between main power window and door lock/unlock switch terminals.

Main power window and door lock/unlock switch state	Terminals	Continuity
Lock	5 - 10	Yes
Unlock	6 - 10	Yes
Neutral/Unlock	5 - 10	No
Neutral/Lock	6 - 10	No

Is the inspection result normal?

- YES >> GO TO 4
NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-78, "Removal and Installation"](#).



4. CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.


DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and main power window and door lock/unlock switch connector.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
A: M18	36	B: D28	5	Yes
	39		6	



- Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	36	No
	39	

Is the inspection result normal?

- YES >> GO TO 5
- NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005428960

Transmits door lock/unlock operation to BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005428961

1.CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.
- NO >> With LH and RH anti-pinch, refer to [DLK-73. "PASSENGER SIDE : Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).
- NO >> With LH anti-pinch only, refer to [DLK-75. "PASSENGER SIDE : Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

PASSENGER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:000000005428962

Regarding Wiring Diagram information, refer to [DLK-156. "Wiring Diagram"](#).


DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Read voltage signal between BCM connector and ground with oscilloscope when door lock and unlock switch (passenger side) is turned "LOCK" or "UNLOCK".
2. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (passenger side) is turned "LOCK" or "UNLOCK".



Terminal (+)		Terminal (-)	Condition	Signal (Reference value)
BCM connector	Terminal			
M18	40	Ground	Door is closed	<p>PIIA1297E</p>

Is the inspection result normal?

- YES >> GO TO 4
NO >> GO TO 2


2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between front power window switch (passenger side) connector and ground.

Power window and door lock/unlock switch RH connector	Terminal		Continuity
D115	11	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.




3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and front power window switch (passenger side) connector.

BCM connector	Terminal	Front power window switch (passenger side) connector	Terminal	Continuity
A: M18	40	B: D115	16	Yes

3. Check continuity between BCM connector and ground.



DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

BCM connector	Terminal	Ground	Continuity
A: M18	40		No

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

- YES >> Inspection End.

PASSENGER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)

INFOID:000000005428963

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).


1.CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage at the power window and door lock/unlock switch RH connector when the switch (passenger side) is turned to "LOCK" or "UNLOCK".

Connector	Power window and door lock/unlock switch RH state	Terminal		Voltage
D115	Neutral → Lock	2	Ground	Battery voltage → 0
	Neutral → Unlock	1	Ground	Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2




2.CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between power window and door lock/unlock switch RH connector and ground.

Power window and door lock/unlock switch RH connector	Terminal		Continuity
D115	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.



3.CHECK POWER WINDOW SWITCH

DOOR LOCK AND UNLOCK SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

Check continuity between power window and door lock/unlock switch RH terminals.

Power window and door lock/unlock switch RH state	Terminals	Continuity
Lock	2 - 3	Yes
Unlock	1 - 3	Yes
Neutral/Unlock	2 - 3	No
Neutral/Lock	1 - 3	No

Is the inspection result normal?



YES >> GO TO 4

NO >> Replace power window and door lock/unlock switch RH.

4. CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.
2. Check continuity between BCM connector and power window and door lock/unlock switch RH connector.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
A: M18	36	B: D115	2	Yes
	39		1	Yes



3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	36	Ground
	39	

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

KEY SLOT

[COUPE]

< COMPONENT DIAGNOSIS >

KEY SLOT

Description

INFOID:000000005428964

Detect whether Intelligent Key is inserted.
Immobilizer antenna amp checks Intelligent Key transponder.

Component Function Check

INFOID:000000005428965

1. CHECK FUNCTION

 **With CONSULT-III**
Check KEY SW -SLOT in Data Monitor mode with CONSULT-III.

Monitor item	Condition
KEY SW-SLOT	Key is inserted in key slot: ON
	Key is removed from key slot: OFF

Is the inspection result normal?

- YES >> Key slot is OK.
NO >> Refer to [DLK-77, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005428966

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1. CHECK KEY SLOT POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect key slot connector.
- Check voltage between key slot connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Key slot connector	Terminal	Ground
M40	1	
	5	Battery voltage



Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace key slot power supply circuit.


2. CHECK KEY SLOT GROUND CIRCUIT

Check continuity between key slot connector and ground.

Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace key slot ground circuit.



3. CHECK KEY SLOT CIRCUIT

- Disconnect BCM connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

KEY SLOT

[COUPE]

< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M18	29	C: M40	11	Yes
B: M19	68		2	Yes
	69		3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	29	Ground
B: M19	68	
	69	

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness between BCM and key slot.

4. CHECK KEY SLOT

Refer to [DLK-78, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace key slot.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005428967

1. CHECK KEY SLOT



Check key slot.

Terminal		Condition	Continuity
Key slot			
1	11	Intelligent Key inserted	Yes
		Intelligent Key removed	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace key slot. Refer to [SEC-184, "Removal and Installation"](#).



KEY CYLINDER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

KEY CYLINDER SWITCH

Description

INFOID:000000005428968

For vehicles equipped with LH and RH anti-pinch system, the main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

For vehicles equipped with LH anti-pinch system only, the door lock assembly LH (key cylinder switch) transmits the LOCK or UNLOCK signal directly to the BCM.

Component Function Check

INFOID:000000005428969

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check KEY CYL UN-SW, KEY CYL UN-SW in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-11, "Work Flow"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> With LH and RH anti-pinch, refer to [DLK-79, "Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [DLK-80, "Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

Diagnosis Procedure (With LH and RH Anti-Pinch)


INFOID:000000005428970

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch ON.
- Check voltage between main power window and door lock/unlock switch connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector D28	Terminal 6	Lock	0
		Neutral / Unlock	5
	Terminal 7	Unlock	0
		Neutral / Lock	5



Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [DLK-220, "FRONT DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2

2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Turn ignition switch OFF.


KEY CYLINDER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

- Disconnect main power window and door lock/unlock switch connector and door lock assembly LH (key cylinder switch) connector.
- Check continuity between main power window and door lock/unlock switch connector and door lock assembly LH (key cylinder switch) connector.

Main power window and door lock/unlock switch connector	Terminal	Door lock assembly LH (key cylinder switch) connector	Terminal	Continuity
A: D28	6	B: D26	6	Yes
	7		5	



- Check continuity between main power window and door lock/unlock switch connector and ground.

Power window main switch connector	Terminal	Ground	Continuity
A: D28	6	Ground	No
	7		

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.


3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between door lock assembly LH connector and ground.

Door lock assembly LH connector	Terminal	Ground	Continuity
D26	4	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.



4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-82. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
 NO >> Replace door lock assembly LH (key cylinder switch). Refer to [DLK-220. "FRONT DOOR LOCK: Removal and Installation"](#).

Diagnosis Procedure (With LH Anti-Pinch Only)

INFOID:000000005428971

Regarding Wiring Diagram information, refer to [DLK-156. "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch ON.


KEY CYLINDER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

2. Check voltage between BCM connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	56	Lock	0
		Neutral / Unlock	5
	34	Unlock	0
		Neutral / Lock	5



Is the inspection result normal?


YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-78, "Removal and Installation"](#).

NO >> GO TO 2

2.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect door lock assembly LH (key cylinder switch) connector.
- Check continuity between door lock assembly LH (key cylinder switch) connector and ground.

Door lock assembly LH connector	Terminal	Ground	Continuity
D25	4		Yes



Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Disconnect BCM connector M18.
- Check continuity between door lock assembly LH (key cylinder switch) connector and BCM connector M18.

Door lock assembly LH connector	Terminal	BCM connector	Terminal	Continuity
A: D25	5	B: M18	34	Yes
	6		56	



- Check continuity between door lock assembly LH (key cylinder switch) connector and ground.

Door lock assembly LH connector	Terminal	Ground	Continuity
A: D25	5		No
	6		

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-82, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

KEY CYLINDER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

NO >> Replace door lock assembly LH (key cylinder switch). Refer to [DLK-220. "FRONT DOOR LOCK : Removal and Installation"](#).

Component Inspection


INFOID:000000005428972

COMPONENT INSPECTION

1.CHECK DOOR KEY CYLINDER SWITCH

Check door lock assembly LH (key cylinder switch).

Terminal		Key position	Continuity
Door lock assembly LH (key cylinder switch)			
5	4	Unlock	Yes
		Neutral / Lock	No
6		Lock	Yes
		Neutral / Unlock	No



Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace door lock assembly LH (key cylinder switch). Refer to [DLK-220. "FRONT DOOR LOCK : Removal and Installation"](#).

UNLOCK SENSOR

[COUPE]

< COMPONENT DIAGNOSIS >

UNLOCK SENSOR

Description

INFOID:000000005428973

Detects door lock condition of driver door.

Component Function Check

INFOID:000000005428974

1.CHECK FUNCTION

 **With CONSULT-III**

Check unlock sensor UNLK SEN –DR in “Data Monitor” mode.

Monitor item	Condition
UNLK SEN –DR	Door lock (driver side) LOCK : ON
	Door lock (driver side) UNLOCK : OFF

Is the inspection result normal?

YES >> Unlock sensor is OK.

NO >> Refer to [DLK-83, "Diagnosis Procedure"](#).


Diagnosis Procedure


INFOID:000000005428975

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1.CHECK UNLOCK SENSOR POWER SUPPLY

Check signal between BCM connector and ground with oscilloscope.

Terminals		Door lock assembly LH condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	27	Locked	 <p>JPMA0011GB</p>
		Unlocked	0



Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 2

2.CHECK UNLOCK SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and door lock assembly LH connector.

UNLOCK SENSOR

[COUPE]


< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and door lock assembly LH connector.

BCM connector	Terminal	Door lock assembly LH connector	Terminal	Continuity
A: M18	27	B: D25	3	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	27		No



Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and door lock assembly LH.

3. CHECK UNLOCK SENSOR GROUND CIRCUIT


Check continuity between door lock assembly LH connector and ground.

Door lock assembly LH connector	Terminal	Ground	Continuity
D25	4		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.




4. CHECK BCM OUTPUT SIGNAL

- Connect BCM harness connector.
- Check signal between BCM connector and ground with oscilloscope.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M18	27	Ground

JPMIA0011GB



Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

5. CHECK UNLOCK SENSOR

Refer to [DLK-85. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace door lock assembly LH. Refer to [DLK-220. "FRONT DOOR LOCK : Removal and Installation"](#).

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

UNLOCK SENSOR

[COUPE]

< COMPONENT DIAGNOSIS >

>> Inspection End.

Component Inspection

INFOID:000000005428976

1.CHECK UNLOCK SENSOR


Check unlock sensor.

Terminal		Door lock assembly LH condition	Continuity
Door lock assembly LH			
3	4	Unlock	Yes
	4	Lock	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door lock assembly LH. Refer to [DLK-220](#).
["FRONT DOOR LOCK : Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK LID OPENER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER SWITCH

Description

INFOID:000000005428977

Transmits trunk lid open signal to BCM.

Component Function Check

INFOID:000000005428978

1.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Does trunk lid opener cancel switch turn ON (CANCEL)?

- Yes >> Turn off trunk lid opener cancel switch.
- No >> GO TO 2

2.CHECK FUNCTION

 **With CONSULT-III**

Check trunk lid opener switch TR/BD OPEN SW in "Data Monitor mode with CONSULT-III."

- When trunk lid opener switch is turned to "ON".

Monitor item	Condition
TR/BD OPEN SW	Trunk lid opener switch is pressed: ON
	Trunk lid opener switch is released: OFF

Is the inspection result normal?

- YES >> Trunk lid opener switch is OK.
- NO >> Refer to [DLK-86, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428979


Regarding Wiring Diagram information, refer to [DLK-182, "Wiring Diagram"](#).

1.CHECK TRUNK LID OPEN INPUT SIGNAL

1. Remove Intelligent Key from key slot.
2. Turn on trunk lid opener cancel switch.
3. Check voltage between BCM connector and ground.

Terminals		Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	ON (press and hold)	0
M21	147	OFF (release)	

JPMIA0011GB



Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

TRUNK LID OPENER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

2. CHECK TRUNK LID OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and trunk lid opener switch connector.

BCM connector	Terminal	Trunk lid opener switch connector	Terminal	Continuity
A: M21	147	B: M75	1	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	147		No

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair harness or connector.

3. CHECK TRUNK LID OPENER SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener switch	Terminal	Ground	Continuity
M75	2		Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.

4. CHECK TRUNK LID OPENER SWITCH

Refer to [DLK-87, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Replace trunk lid opener switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).



>> Inspection End.

Component Inspection

INFOID:000000005428980

1. CHECK TRUNK LID OPENER SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener switch connector.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

TRUNK LID OPENER SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

3. Check continuity between trunk lid opener switch connector.



Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON (press and hold)	Yes
		OFF (release)	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trunk lid opener switch.

TRUNK LID OPENER CANCEL SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER CANCEL SWITCH

Description

INFOID:000000005428981

Cancels trunk lid open operation.

Component Function Check

INFOID:000000005428982

1.CHECK FUNCTION

With CONSULT-III

Check trunk lid opener cancel switch TR CANCEL SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TR CANCEL SW	Trunk lid opener cancel switch is turned to "ON": ON
	Trunk lid opener cancel switch is turned to "OFF": OFF

Is the inspection result normal?

- YES >> Trunk lid opener cancel switch is OK.
- NO >> Refer to [DLK-89, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428983


Regarding Wiring Diagram information, refer to [DLK-182, "Wiring Diagram"](#).

1.CHECK TRUNK LID OPENER CANCEL SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of trunk lid opener cancel switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	ON	0
M18	37	OFF	

JPMIA0012GB



Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

2.CHECK TRUNK LID OPENER CANCEL SWITCH CIRCUIT

1. Disconnect BCM connector.

TRUNK LID OPENER CANCEL SWITCH

[COUPE]


< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lid opener cancel switch connector.

BCM connector	Terminal	Trunk lid opener cancel switch connector	Terminal	Continuity
A: M18	37	B: M74	1	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	37		No




Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair harness or connector.

3.CHECK TRUNK LID OPENER CANCEL SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener cancel switch	Terminal	Ground	Continuity
M74	2		Yes



Is the inspection result normal?

- YES >> GO TO 4
NO >> Repair or replace harness.

4.CHECK TRUNK LID OPENER CANCEL SWITCH

Refer to [DLK-90, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
NO >> Replace trunk lid opener cancel switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).


>> Inspection End.

Component Inspection

INFOID:000000005428984

1.CHECK TRUNK LID OPENER CANCEL SWITCH

- Disconnect trunk lid opener cancel switch connector.
- Check continuity between trunk lid opener cancel switch terminals.



TRUNK LID OPENER CANCEL SWITCH

< COMPONENT DIAGNOSIS >

[COUPE]

Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON	Yes
		OFF (cancel)	No

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace trunk lid opener cancel switch.

DLK

TRUNK ROOM LAMP SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

TRUNK ROOM LAMP SWITCH

Description

INFOID:000000005428985

Detects trunk open/close condition.

Component Function Check

INFOID:000000005428986

1.CHECK FUNCTION

With CONSULT-III

Check TRNK/HAT MNTR in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TRNK/HAT MNTR	OPEN : ON
	CLOSE : OFF

Is the inspection result normal?

- YES >> Trunk room lamp switch is OK.
 NO >> Refer to [DLK-92, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428987


Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1.CHECK TRUNK LAMP SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between BCM connector and ground.

Terminals		Trunk condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	OPEN	0
M21	130	CLOSE	

JPMIA0011GB



Is the inspection result normal?

- YES >> GO TO 4
 NO >> GO TO 2

2.CHECK TRUNK LAMP SWITCH CIRCUIT

- Disconnect BCM and trunk lamp switch and trunk release solenoid connectors.

TRUNK ROOM LAMP SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M21	130	B: T4	1	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	130		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and trunk lamp switch and trunk release solenoid.

3.CHECK TRUNK LAMP SWITCH GROUND CIRCUIT

Check continuity between trunk lid lock assembly connector and ground.

Trunk lamp switch and trunk release solenoid connector	Terminal	Ground	Continuity
T4	2		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace trunk lamp switch and trunk release solenoid ground circuit.

4.CHECK BCM OUTPUT SIGNAL

- Insure trunk remains closed during this step.
- Connect BCM connector.
- Check voltage between BCM connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	130	Ground

JPMIA0011GB

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5.CHECK TRUNK ROOM LAMP SWITCH




Refer to [DLK-94, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace trunk lamp switch and trunk release solenoid.

6.CHECK INTERMITTENT INCIDENT



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK ROOM LAMP SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005428988


1. CHECK TRUNK LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check trunk lamp switch.

Terminal		Trunk condition	Continuity
Trunk lamp switch and trunk release solenoid			
1	2	OPEN	Yes
		CLOSE	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace trunk lamp switch and trunk release solenoid.



DOOR REQUEST SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

DOOR REQUEST SWITCH

Description

INFOID:000000005428989

Transmits lock/unlock operation to BCM.

Component Function Check

INFOID:000000005428990

1.CHECK FUNCTION

With CONSULT-III

Check door request switch REQ SW-DR, REQ SW-AS in Data Monitor mode.

Monitor item	Condition
REQ SW-DR	Door request switch is pressed : ON
REQ SW-AS	Door request switch is released : OFF

Is the inspection result normal?

- YES >> Door request switch is OK.
- NO >> Refer to [DLK-95, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428991

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1.CHECK DOOR REQUEST SWITCH OUTPUT SIGNAL



1. Turn ignition switch OFF.
2. Check voltage between BCM harness connector and ground.



DOOR REQUEST SWITCH

< COMPONENT DIAGNOSIS >

[COUPE]

Terminals			Door request switch Condition	Voltage (V) (Approx.)
(+)		(-)		
BCM connector	Terminal			
M19	Door request switch (driver side)	89	Pressed	0
			Released	 <small>JMKIA0059GB</small>
	Door request switch (passenger side)	88	Pressed	0
			Released	 <small>JMKIA0059GB</small>
		Ground		

Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

2. CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM and front outside handle connector.
2. Check continuity between BCM connector and front outside handle connector.

BCM connector	Terminal	Front outside handle connector	Terminal	Continuity
A: M19	89	B: D17 (driver side)	3	Yes
	88	B: D116 (passenger side)		


3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	89		
	88		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and front outside handle.

3. CHECK DOOR REQUEST SWITCH GROUND CIRCUIT



DOOR REQUEST SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

Check continuity between front outside handle connector and ground.

Front outside handle connector	Terminal	Ground	Continuity
D17 (driver side)	4		Yes
D116 (passenger side)			


Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace front outside handle ground circuit.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M19	89 88	
		Ground

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5. CHECK DOOR REQUEST SWITCH

Refer to [DLK-97, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace malfunctioning front outside handle.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005428992




1. CHECK DOOR REQUEST SWITCH

Check front outside handle (request switch).

Terminal		Door request switch condition	Continuity
Front outside handle (request switch)			
3	4	Pressed	Yes
		Released	No

Is the inspection result normal?

YES >> Inspection End.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR REQUEST SWITCH

< COMPONENT DIAGNOSIS >

[COUPE]

NO >> Replace malfunction front outside handle.

TRUNK OPENER REQUEST SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

TRUNK OPENER REQUEST SWITCH

Description

INFOID:000000005428993

Performs trunk lid open request when it is pressed.

Component Function Check

INFOID:000000005428994

1.CHECK FUNCTION

With CONSULT-III

Check trunk opener request switch REQ SW -BD/TR in Data Monitor mode.

Monitor item	Condition
REQ SW -BD/TR	Trunk opener request switch is pressed : ON
	Trunk opener request switch is released : OFF

Is the inspection result normal?

- YES >> Trunk opener request switch is OK.
- NO >> Refer to [DLK-99, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005428995


Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1.CHECK TRUNK OPENER REQUEST SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector and ground.

Terminals		Trunk lid opener request switch condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	Pressed	0
M21	141	Released	

JPMIA0016GB



Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

2.CHECK TRUNK OPENER REQUEST SWITCH CIRCUIT

1. Disconnect BCM and trunk opener request switch connector.

TRUNK OPENER REQUEST SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk opener request switch connector.

BCM connector	Terminal	Trunk opener request switch connector	Terminal	Continuity
A: M21	141	B: T2	1	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	141		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and trunk opener request switch.

3.CHECK TRUNK OPENER REQUEST SWITCH GROUND CIRCUIT

Check continuity between trunk opener request switch connector and ground.

Trunk opener request switch connector	Terminal	Ground	Continuity
T2	2		Yes

Is the inspection result normal?


YES >> GO TO 4

NO >> Repair or replace trunk opener request switch ground circuit.

4.CHECK BCM OUTPUT SIGNAL

- Connect BCM connector.
- Check voltage between BCM connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	141	Ground



(V)
15
10
5
0

10 ms

JPMIA0016GB

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

5.CHECK TRUNK OPENER REQUEST SWITCH

Refer to [DLK-101. "Component Inspection"](#).




Is the inspection result normal?

YES >> GO TO 6

NO >> Replace trunk opener request switch.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).



TRUNK OPENER REQUEST SWITCH

[COUPE]

< COMPONENT DIAGNOSIS >

>> Inspection End.

Component Inspection

INFOID:000000005428996

1.CHECK TRUNK OPENER REQUEST SWITCH


Check trunk opener request switch.

Terminal		Trunk opener request switch condition	Continuity
Trunk opener request switch			
1	2	Pressed	Yes
		Released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trunk opener request switch.



A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

DOOR LOCK ACTUATOR

[COUPE]

< COMPONENT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005428997

Locks/unlocks the door with the signal from BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005428998

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-102, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005428999

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).


1.CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	9	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3
 NO >> GO TO 2




2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and door lock actuator driver side connector.
3. Check continuity between BCM connector and door lock actuator driver side connector.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D25 (with LH anti-pinch only) D26 (with LH and RH anti-pinch))	1	Yes
	9		2	

4. Check continuity between BCM connector and ground.



BCM connector	Terminal	Continuity
A: M17	8	Ground
	9	

Is the inspection result normal?

- YES >> Replace door lock actuator LH.

DOOR LOCK ACTUATOR

[COUPE]

< COMPONENT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005429000

Locks/unlocks the door with the signal from BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005429001

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-103, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005429002

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	Ground	Lock 0 → Battery voltage → 0
M17	8		
	5	Unlock 0 → Battery voltage → 0	

Is the inspection result normal?

YES >> GO TO 3

NO >> GO TO 2


2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and door lock actuator RH connectors.
2. Check continuity between BCM connector and door lock actuator RH.


BCM connector	Terminal	Door lock actuator RH connector	Terminal	Continuity
A: M17	8	B: D112	5	Yes
	5		6	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	No
	5	



DLK



N

O

P

DOOR LOCK ACTUATOR

[COUPE]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace door lock actuator RH.

NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

TRUNK LID OPENER ACTUATOR

[COUPE]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER ACTUATOR

Description

INFOID:000000005429003

Performs trunk lid open with signal from BCM.

Component Function Check

INFOID:000000005429004

1.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Is trunk lid opener cancel switch turned OFF (CANCEL)?

- Yes >> Turn on trunk lid opener cancel switch.
- No >> GO TO 2

2.CHECK FUNCTION

1. Perform Active Test TRUNK/GLASS HATCH with CONSULT-III.
2. Touch "OPEN" and check that trunk lid opens.

Is the inspection result normal?

- YES >> Trunk lid opener actuator is OK.
- NO >> Refer to [DLK-105. "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429005

Regarding Wiring Diagram information, refer to [DLK-182. "Wiring Diagram"](#).

1.CHECK OUTPUT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check voltage between trunk lamp switch and trunk release solenoid connector and ground.

Terminals		(-)	Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)	Terminal			
Trunk lamp switch and trunk release solenoid connector				
T4	3	Ground	DEPRESSED → RELEASED	0 → Battery voltage → 0




Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2.CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals		(-)	Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector				
M20	103	Ground	DEPRESSED → RELEASED	0 → Battery voltage → 0



Is the inspection result normal?

- YES >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK LID OPENER ACTUATOR

[COUPE]

< COMPONENT DIAGNOSIS >

NO >> GO TO 3


3. CHECK TRUNK LID OPENER ACTUATOR CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M20	103	B: T4	3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M20	103 Ground	No



Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).
 NO >> Repair or replace harness.


4. CHECK TRUNK LID OPENER GROUND CIRCUIT

Check continuity between trunk lamp switch and trunk release solenoid connector and ground.

trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
T4	4 Ground	Yes

Is the inspection result normal?

- YES >> Replace trunk lamp switch and trunk release solenoid.
 NO >> Repair or replace harness.



INTELLIGENT KEY WARNING BUZZER

[COUPE]

< COMPONENT DIAGNOSIS >

INTELLIGENT KEY WARNING BUZZER

Description

INFOID:000000005429006

Answers back and warns for an inappropriate operation.

Component Function Check

INFOID:000000005429007

1.CHECK FUNCTION

With CONSULT-III

Check Intelligent Key warning buzzer OUTSIDE BUZZER in Active Test mode.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer (engine room) is OK.
- NO >> Refer to [DLK-107, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429008

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).


1.CHECK INTELLIGENT KEY WARNING BUZZER

Check voltage between BCM connector and ground.

Terminals		Warning buzzer operation condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	ON	0
M21	144	OFF	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2




2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Check voltage between Intelligent Key warning buzzer connector and ground.

Terminals		Warning buzzer operation condition	Voltage (V) (Approx.)
(+)	(-)		
Intelligent Key warning buzzer connector	Terminal	ON	0
E74	1	OFF	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace Intelligent Key warning buzzer power supply circuit.



3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

[COUPE]

< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and Intelligent Key warning buzzer connector.

BCM connector	Terminal	Intelligent Key warning buzzer connector	Terminal	Continuity
A: M21	144	B: E74	3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	144		No

Is the inspection result normal?

OK >> GO TO 4

NG >> Repair or replace harness between BCM and Intelligent Key warning buzzer.

4. CHECK INTELLIGENT KEY WARNING BUZZER

Check [DLK-108. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace Intelligent Key warning buzzer.

5. CHECK INTERMITTENT INCIDENT

Check [GI-41. "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429009

1. CHECK INTELLIGENT KEY WARNING BUZZER



Connect battery power supply to Intelligent Key warning buzzer terminals 1 and 3, and check the operation.

1 (BAT+) - 3 (BAT-) : the buzzer sounds

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace Intelligent Key warning buzzer.



OUTSIDE KEY ANTENNA

[COUPE]

< COMPONENT DIAGNOSIS >

OUTSIDE KEY ANTENNA

Description

INFOID:000000005429010

Detects whether Intelligent Key is outside the vehicle.
Integrated in front outside handle (driver side, passenger side) and installed in rear bumper.

Component Function Check

INFOID:000000005429011

1.CHECK DOOR REQUEST SWITCH

Check that door request switch operates normally.

Is the inspection result normal?

YES >> GO TO 2

NO >> Inspect door request switch. Refer to [DLK-95. "Component Function Check"](#).

2.CHECK FUNCTION

Be sure that Intelligent Key is in each outside key antenna detection range.

Does door lock/unlock when each request switch is pressed?

YES >> Outside key antenna is OK.

NO >> Refer to [DLK-109. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429012

Regarding Wiring Diagram information, refer to [DLK-166. "Wiring Diagram"](#).

1.CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



OUTSIDE KEY ANTENNA

< COMPONENT DIAGNOSIS >

[COUPE]

Terminals			(-)	Condition	Signal (Reference value.)
(+)		Terminal			
BCM connector	Terminal				
A: M19	Driver side	65	Ground	Request switch is pushed	<p style="text-align: right; font-size: small;">JMKIA0061GB</p>
	Passenger side	63			
B: M21	Rear bumper	119		When Intelligent Key is not in the antenna detection area.	<p style="text-align: right; font-size: small;">JMKIA0060GB</p>

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM and front outside handle connector.
2. Check continuity between BCM connector and outside key antenna connector.

BCM connector	Terminal	Outside key antenna connector	Terminal	Continuity
A: M19	65	D17 (driver side)	1	Yes
	64		2	
	63	D116 (passenger side)	1	
	62		2	
B: M21	119	B46 (rear bumper)	1	
	118		2	

3. Check continuity between BCM connector and ground.


BCM connector	Terminal	Ground	Continuity
A: M19	62		Ground
	63		
	64		
	65		
B: M21	118	Ground	No
	119		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and outside key antenna.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna. (New antenna or other antenna)
2. Connect BCM and outside key antenna connector.




OUTSIDE KEY ANTENNA

[COUPE]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals			(-)	Condition	Signal (Reference value.)
(+)		Terminal			
BCM connector					
A: M19	Driver side	65	Ground	Door request switch is pushed	
	Passenger side	63			
B: M21	Rear bumper	119			

Is the inspection result normal?

YES >> Replace outside key antenna.

NO >> GO TO 4

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

[COUPE]

< COMPONENT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Description

INFOID:000000005429013

Receives Intelligent Key operation and transmits to BCM.

Component Function Check

INFOID:000000005429014

1.CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating Intelligent Key.

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
 NO >> Refer to [DLK-112, "Diagnosis Procedure"](#).



Diagnosis Procedure


INFOID:000000005429015

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1.CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

- Turn ignition switch OFF.
- Check signal between remote keyless entry receiver connector and ground with oscilloscope.

Terminals		Condition	Signal (Reference value)
(+)	(-)		
Remote keyless entry receiver connector	Terminal		
M27	2	Ground	 <p>JMKIA0064GB</p>
		When signal is received (All doors closed)	 <p>JMKIA0065GB</p>



Is the inspection result normal?

- YES >> GO TO 7
 NO >> GO TO 2


REMOTE KEYLESS ENTRY RECEIVER


[COUPE]

< COMPONENT DIAGNOSIS >

2. CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Disconnect remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver connector and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Remote keyless entry receiver connector	Terminal	
M27	4	 <p>(V) 15 10 5 0</p> <p>1 ms</p> <p>JMKIA0064GB</p>



Is the inspection result normal?

- YES >> GO TO 4
NO >> GO TO 3


3. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	91	B: M27	4	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	91		No



Is the inspection result normal?

- YES >> Reconnect BCM, GO TO 4
NO >> Repair or replace harness between BCM and remote keyless entry receiver.


4. CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

Check continuity between remote keyless entry receiver connector and ground.

Remote keyless entry receiver connector	Terminal	Ground	Continuity
M27	1		Yes

Is the inspection result normal?

- YES >> GO TO 6
NO >> GO TO 5



5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 2

REMOTE KEYLESS ENTRY RECEIVER

[COUPE]

< COMPONENT DIAGNOSIS >

Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M18	45	B: M27	1	Yes

Is the inspection result normal?

YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry receiver.

6. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 3

1. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	71	B: M27	2	Yes

2. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	71		No

Is the inspection result normal?



YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry.

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.



INTELLIGENT KEY BATTERY AND FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

INTELLIGENT KEY BATTERY AND FUNCTION

Description

INFOID:000000005429016

The following functions are available when having and carrying electronic ID.

- Door lock/unlock
- Trunk open

Remote control entry function and panic alarm function are available when operating the remote buttons.

Component Function Check

INFOID:000000005429017

1. CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating on the Intelligent Key.

Is the inspection result normal?

- YES >> Intelligent Key is OK.
NO >> Refer to [DLK-115, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429018

1. CHECK INTELLIGENT KEY FUNCTION

Check Intelligent Key function using Remote Keyless Entry Tester J-43241.

Does the test pass?

- YES >> Intelligent Key is OK.
NO >> GO TO 2



2. CHECK INTELLIGENT KEY COMPONENTS

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.
2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:


- Do not touch the circuit board or battery terminal.
- The Intelligent Key is water-resistant. However, if it does get wet, immediately wipe it dry.

3. Remove the Intelligent Key battery.

CAUTION:

- Keep dirt, grease, and other foreign materials off the electrode contact area.

4. Visually inspect Intelligent Key internal components.



Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace malfunctioning parts.

3. CHECK INTELLIGENT KEY BATTERY

INTELLIGENT KEY BATTERY AND FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA.


Standard : **Approx. 2.5 - 3.0V**

Is the measurement value within specification?

YES >> Intelligent Key battery is OK. Check remote keyless entry receiver. Refer to [DLK-112](#).

["Component Function Check"](#).

NO >> GO TO 4



4. REPLACE INTELLIGENT KEY BATTERY

1. Replace the Intelligent Key battery.
2. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:


- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.

3. After replacing the battery, check that all Intelligent Key functions work properly.

Is the inspection result normal?

YES >> Intelligent Key is OK.

NO >> Check remote keyless entry receiver. Refer to [DLK-112](#).
["Component Function Check"](#).



KEY SLOT ILLUMINATION

[COUPE]

< COMPONENT DIAGNOSIS >

KEY SLOT ILLUMINATION

Description

INFOID:000000005429019

Blinks when Intelligent Key insertion is required.

Component Function Check

INFOID:000000005429020

1.CHECK FUNCTION

With CONSULT-III

Check key slot illumination KEY SLOT ILLUMI in Active Test mode.

Is the inspection result normal?

- YES >> Key slot function is OK.
- NO >> Refer to [DLK-117, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429021

Regarding Wiring Diagram information, refer to [DLK-166, "Wiring Diagram"](#).

1.CHECK KEY SLOT ILLUMINATION OUTPUT SIGNAL

Check voltage between key slot connector and ground.

Terminals			Condition	Key slot illumination	Voltage (V) (Approx.)
(+)		(-)			
Key slot connector	Terminal				
M40	6	Ground	Intelligent Key inserted	OFF	Battery voltage
			Intelligent Key removed	ON	0




Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

2.CHECK KEY SLOT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect key slot connector.
3. Check voltage between slot connector and ground.

Terminals			Voltage (V) (Approx.)
(+)		(-)	
Key slot connector	Terminal		
M40	1	Ground	Battery voltage
	5		



Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace key slot power supply circuit.

3.CHECK KEY SLOT GROUND CIRCUIT

KEY SLOT ILLUMINATION

[COUPE]


< COMPONENT DIAGNOSIS >

Check continuity between key slot connector and ground.

Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace key slot ground circuit.



4. CHECK KEY SLOT CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM and key slot connector.
- Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M19	80	B: M40	6	Yes

4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	80		No

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Repair or replace harness between BCM and key slot.

5. CHECK KEY SLOT

Refer to [DLK-78, "Component Inspection"](#).


Is the inspection result normal?

- YES >> GO TO 6
 NO >> Replace key slot.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.



HORN FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

HORN FUNCTION

Description

INFOID:000000005429022

Perform answer-back for each operation with horn.

Component Function Check

INFOID:000000005429023

1.CHECK FUNCTION

1. Select HORN in "ACTIVE TEST" mode with CONSULT-III.
2. Check the horn (high/low) operation.

Test item		Description	
HORN	ON	Horn relay	ON (for 20 ms)

Is the operation normal?

- YES >> Inspection End.
 NO >> Refer to [DLK-119, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429024

Regarding Wiring Diagram information, refer to [DLK-156, "Wiring Diagram"](#).

1.CHECK HORN FUNCTION

Check horn function with horn switch

Do the horns sound?

- YES >> GO TO 2
 NO >> Refer to [HRN-3, "COUPE : Wiring Diagram"](#).

2.CHECK HORN RELAY POWER SUPPLY

1. Turn ignition switch ON.
2. Perform "ACTIVE TEST" ("HORN") with CONSULT-III.
3. Using an oscilloscope or analog voltmeter, check voltage between IPDM E/R harness connector and ground.


IPDM E/R		Ground	Test item	Voltage (V) (Approx.)
Connector	Terminal			
E17	44	Ground	HORN	Battery voltage → 0 → Battery voltage
			Other than above	Battery voltage

Is the inspection result normal?

- YES >> Repair or replace open harness between IPDM E/R and horn relay.
 NO >> GO TO 3

3.CHECK HORN RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay connector.



HORN FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

3. Check continuity between IPDM E/R harness connector and horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
A: E17	44	B: H-1	1	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
A: E17	44	Ground	No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.


4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.



COMBINATION METER DISPLAY FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

COMBINATION METER DISPLAY FUNCTION

Description

INFOID:000000005429025

Displays each operation method guide and warning for system malfunction.

Component Function Check

INFOID:000000005429026

1.CHECK FUNCTION

With CONSULT-III

Check the operation with ("LCD") in the Active Test.

Is each warning displayed on meter display?

Is the inspection result normal?

YES >> Meter display is OK.

NO >> Refer to [DLK-121, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429027

1.CHECK COMBINATION METER

Refer to [MWI-62, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check combination meter. Refer to [MWI-42, "Diagnosis Description"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING CHIME FUNCTION

< COMPONENT DIAGNOSIS >

[COUPE]

WARNING CHIME FUNCTION

Description

INFOID:000000005429028

Performs operation method guide and warning with buzzer.

Component Function Check

INFOID:000000005429029

1.CHECK FUNCTION

With CONSULT-III

1. Check the operation with "INSIDE BUZZER" in the Active Test.
2. Touch "TAKE OUT", "KNOB" or "KEY" on screen.

Is the inspection result normal?

- YES >> Warning buzzer into combination meter is OK.
NO >> Refer to [DLK-122, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429030

1.CHECK METER BUZZER CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Replace combination meter. Refer to [MWI-153, "Removal and Installation"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

HAZARD FUNCTION

[COUPE]

< COMPONENT DIAGNOSIS >

HAZARD FUNCTION

Description

INFOID:000000005429031

Perform answer-back for each operation with number of blinks.

Component Function Check

INFOID:000000005429032

1.CHECK FUNCTION

Check hazard warning lamp ("FLASHER") in Active Test.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [DLK-123, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429033

1.CHECK HAZARD SWITCH CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace hazard warning switch circuit. Refer to [EXL-4, "Work Flow"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER

[COUPE]

< COMPONENT DIAGNOSIS >

HOMELINK UNIVERSAL TRANSCEIVER

Description

INFOID:000000005429035

Homelink universal transceiver can store and transmit a maximum of 3 radio signals. Allows operation of garage doors, gates, home and office lighting, entry door locks and security system, etc. Homelink universal transceiver power supply uses vehicle battery, which enables it to maintain every program in case battery is discharged or removed.

Component Function Check

INFOID:000000005429036

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn ignition switch "OFF".
2. Press each of the transmitter buttons and watch for the red light to illuminate with each button.

Is the inspection result normal?

- YES >> GO TO 3
NO >> Refer to [DLK-124, "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

- YES >> Receiver or hand-held transmitter malfunction, not vehicle related.
NO >> Replace auto anti-dazzling inside mirror (homelink universal transceiver). Refer to [MIR-18, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000005429037

Regarding Wiring Diagram information, refer to [DLK-154, "Wiring Diagram"](#).

1.CHECK POWER SUPPLY


1. Disconnect auto anti-dazzling inside mirror (homelink universal transceiver) connector.
2. Check voltage between auto anti-dazzling inside mirror (homelink universal transceiver) harness connector and ground.

Auto anti-dazzling inside mirror (homelink universal transceiver) connector	Terminal		Condition	Voltage (V) (Approx.)
R4	10	Ground	Ignition switch position: LOCK	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2
NO >> Check the following.
- 10A fuse [No. 6 located in the fuse block (J/B)]
 - Harness for open or short between fuse and auto anti-dazzling inside mirror (homelink universal transceiver).

2.CHECK GROUND CIRCUIT




HOMELINK UNIVERSAL TRANSCEIVER

[COUPE]

< COMPONENT DIAGNOSIS >

Check continuity between auto anti-dazzling inside mirror (homelink universal transceiver) harness connector and ground.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

Auto anti-dazzling inside mirror (Homelink universal transceiver) connector	Terminal	Ground	Continuity
R4	8		Yes

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000005783580

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Other than front wiper switch LO	OFF
	Front wiper switch LO	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER INT	Other than front wiper switch INT	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Front wiper is not in STOP position	OFF
	Front wiper is in STOP position	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Other than turn signal switch LH	OFF
	Turn signal switch LH	ON
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	OFF
	Lighting switch 1ST or 2ND	ON
HI BEAM SW	Other than lighting switch HI	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
AUTO LIGHT SW	Other than lighting switch AUTO	OFF
	Lighting switch AUTO	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
DOOR SW-DR	Driver door closed	OFF
	Driver door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear door RH closed	OFF
	Rear door RH opened	ON
DOOR SW-RL	Rear door LH closed	OFF
	Rear door LH opened	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Monitor Item	Condition	Value/Status	
CDL LOCK SW	Other than power door lock switch LOCK	OFF	A
	Power door lock switch LOCK	ON	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	OFF	B
	Power door lock switch UNLOCK	ON	
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF	C
	Driver door key cylinder LOCK position	ON	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF	D
	Driver door key cylinder UNLOCK position	ON	
HAZARD SW	When hazard switch is not pressed	OFF	
	When hazard switch is pressed	ON	
REAR DEF SW	When rear window defogger switch is pressed	ON	E
TR CANCEL SW	Trunk lid opener cancel switch OFF	OFF	
	Trunk lid opener cancel switch ON	ON	
TR/BD OPEN SW	Trunk lid opener switch OFF	OFF	F
	While the trunk lid opener switch is turned ON	ON	
TRNK/HAT MNTR	Trunk lid closed	OFF	G
	Trunk lid opened	ON	
RKE-LOCK	When LOCK button of Intelligent Key is not pressed	OFF	H
	When LOCK button of Intelligent Key is pressed	ON	
RKE-UNLOCK	When UNLOCK button of Intelligent Key is not pressed	OFF	I
	When UNLOCK button of Intelligent Key is pressed	ON	
RKE-TR/BD	When TRUNK OPEN button of Intelligent Key is not pressed	OFF	J
	When TRUNK OPEN button of Intelligent Key is pressed	ON	
RKE-PANIC	When PANIC button of Intelligent Key is not pressed	OFF	
	When PANIC button of Intelligent Key is pressed	ON	
RKE-P/W OPEN	When UNLOCK button of Intelligent Key is not pressed and held	OFF	DLK
	When UNLOCK button of Intelligent Key is pressed and held	ON	
RKE-MODE CHG	When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	OFF	L
	When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	ON	
OPTICAL SENSOR	When outside of the vehicle is bright	Close to 5 V	M
	When outside of the vehicle is dark	Close to 0 V	
REQ SW-DR	When driver door request switch is not pressed	OFF	N
	When driver door request switch is pressed	ON	
REQ SW-AS	When passenger door request switch is not pressed	OFF	O
	When passenger door request switch is pressed	ON	
REQ SW-BD/TR	When trunk request switch is not pressed	OFF	P
	When trunk request switch is pressed	ON	
PUSH SW	When engine switch (push switch) is not pressed	OFF	
	When engine switch (push switch) is pressed	ON	
IGN RLY2-F/B	Ignition switch OFF or ACC	OFF	
	Ignition switch ON	ON	
ACC RLY-F/B	Ignition switch OFF	OFF	
	Ignition switch ACC or ON	ON	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Monitor Item	Condition	Value/Status
CLUTCH SW	When the clutch pedal is not depressed	OFF
	When the clutch pedal is depressed	ON
BRAKE SW 1	When the brake pedal is not depressed	ON
	When the brake pedal is depressed	OFF
DETE/CANCL SW	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN/N SW	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
UNLK SEN-DR	Driver door UNLOCK status	OFF
	Driver door LOCK status	ON
PUSH SW-IPDM	When engine switch (push switch) is not pressed	OFF
	When engine switch (push switch) is pressed	ON
IGN RLY1 F/B	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
DETE SW -IPDM	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN -IPDM	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
SFT P-MET	When selector lever is in any position other than P	OFF
	When selector lever is in P position	ON
SFT N-MET	When selector lever is in any position other than N	OFF
	When selector lever is in N position	ON
ENGINE STATE	Engine stopped	STOP
	While the engine stalls	STALL
	At engine cranking	CRANK
	Engine running	RUN
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door UNLOCK status	UNLK
DOOR STAT-AS	Passenger door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door UNLOCK status	UNLK
ID OK FLAG	Ignition switch ACC or ON	RESET
	Ignition switch OFF	SET
PRMT ENG STAT	When the engine start is prohibited	RESET
	When the engine start is permitted	SET
KEY SW -SLOT	When Intelligent Key is not inserted into key slot	OFF
	When Intelligent Key is inserted into key slot	ON
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	YET
	The key ID that the key slot receives accords with any key ID registered to BCM.	DONE

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Monitor Item	Condition	Value/Status	
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	YET	A
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	DONE	B
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	YET	C
	The key ID that the key slot receives accords with the third key ID registered to BCM.	DONE	
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	YET	D
	The key ID that the key slot receives accords with the second key ID registered to BCM.	DONE	
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	YET	E
	The key ID that the key slot receives accords with the first key ID registered to BCM.	DONE	F
TP 4	The ID of fourth key is not registered to BCM	YET	
	The ID of fourth key is registered to BCM	DONE	G
TP 3	The ID of third key is not registered to BCM	YET	
	The ID of third key is registered to BCM	DONE	H
TP 2	The ID of second key is not registered to BCM	YET	
	The ID of second key is registered to BCM	DONE	I
TP 1	The ID of first key is not registered to BCM	YET	
	The ID of first key is registered to BCM	DONE	J
AIR PRESS FL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front LH tire	
AIR PRESS FR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front RH tire	
AIR PRESS RR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear RH tire	DLK
AIR PRESS RL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear LH tire	
ID REGST FL1	When ID of front LH tire transmitter is registered	DONE	L
	When ID of front LH tire transmitter is not registered	YET	
ID REGST FR1	When ID of front RH tire transmitter is registered	DONE	M
	When ID of front RH tire transmitter is not registered	YET	
ID REGST RR1	When ID of rear RH tire transmitter is registered	DONE	N
	When ID of rear RH tire transmitter is not registered	YET	
ID REGST RL1	When ID of rear LH tire transmitter is registered	DONE	O
	When ID of rear LH tire transmitter is not registered	YET	
WARNING LAMP	Tire pressure indicator OFF	OFF	
	Tire pressure indicator ON	ON	
BUZZER	Tire pressure warning alarm is not sounding	OFF	P
	Tire pressure warning alarm is sounding	ON	


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Terminal Layout

INFOID:000000005783581




Physical Values

INFOID:000000005783582

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]




Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
1 (W/B)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (R/Y)	Ground	Battery power supply output	Output	Ignition switch OFF	Battery voltage
3 (L/W)	Ground	Ignition power supply output	Output	Ignition switch ON	Battery voltage
4 (P/W)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time	0V
				Any other time after passing the interior room lamp battery saver operation time	Battery voltage
5 (G/Y)	Ground	Front door RH UNLOCK	Output	Front door RH	UNLOCK (actuator is activated) Battery voltage
					Other than UNLOCK (actuator is not activated) 0V
7 (R/W)	Ground	Step lamp	Output	Step lamp	ON 0V
					OFF Battery voltage
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (actuator is activated) Battery voltage
					Other than LOCK (actuator is not activated) 0V
9 (G)	Ground	Front door LH UNLOCK	Output	Front door LH	UNLOCK (actuator is activated) Battery voltage
					Other than UNLOCK (actuator is not activated) 0V
10 ¹ (G/Y)	Ground	Rear door RH and rear door LH UNLOCK	Output	Rear door RH and rear door LH	UNLOCK (actuator is activated) Battery voltage
					Other than UNLOCK (actuator is not activated) 0V
11 (Y/R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0V
14 ⁶ (R/Y)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp	OFF 0V
					ON NOTE: When the illumination brightening/dimming level is in the neutral position  JSNIA0010GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




[COUPE]

Terminal No. (Wire color)		Description			Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
14 ¹ (O/W)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp	OFF	0V
					ON	NOTE: When the illumination brightening/dimming level is in the neutral position  <p style="text-align: right; font-size: small;">JSNIA0010GB</p>
15 (Y/L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF	Battery voltage
					ACC or ON	0V
17 (G/B)	Ground	Turn signal (RH)	Output	Ignition switch ON	Turn signal switch OFF	0V
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">PKID0926E</p>
18 (G/Y)	Ground	Turn signal (LH)	Output	Ignition switch ON	Turn signal switch OFF	0V
					Turn signal switch LH	 <p style="text-align: right; font-size: small;">PKID0926E</p>
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0V
21 (P/B)	Ground	Optical sensor signal	Input	Ignition switch ON	When outside of the vehicle is bright	Close to 5V
					When outside of the vehicle is dark	Close to 0V
22 (R/Y)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (clutch pedal is not depressed)	0V
					ON (clutch pedal is depressed)	Battery voltage
24 (R/W)	Ground	Stop lamp switch 1	Input	—	Battery voltage	
26 (O/L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (brake pedal is not depressed)	0V
					ON (brake pedal is depressed)	Battery voltage

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
27 (G/W)	Ground	Front door lock assembly LH (unlock sensor)	Input	Front door LH	LOCK status	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					UNLOCK status	0V
29 (Y)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	Battery voltage	
				When Intelligent Key is not inserted into key slot	0V	
30 (V/Y)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0
				ACC or ON	Battery voltage	
31 (G)	Ground	Rear window defogger feedback signal	Input	Rear window defogger switch	OFF	0V
					ON	Battery voltage
32 (R/B)	Ground	Front door RH switch	Input	Front door RH switch	OFF (when front door RH closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (when front door RH opens)	0V
33 (SB)	Ground	Compressor ON signal	Input	A/C switch	OFF	9.0 - 12.0V
					ON	0V
34 ² (L/R)	Ground	Front door lock assembly LH (key cylinder switch) (unlock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (unlock)	0V
36 ² (GR)	Ground	Lock switch signal	Input	Door lock/unlock switch	Lock	Battery voltage
					Unlock	0V
37 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	CANCEL	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>
					ON	0V
38 (GR/W)	Ground	Rear window defogger ON signal	Input	Rear window defogger switch	OFF	5V
					ON	0V
39 ² (GR/R)	Ground	Unlock switch signal	Input	Door lock/unlock switch	Unlock	Battery voltage
					Lock	0V





A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >






[COUPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
40 ³ (Y/G)	Ground	Power window serial link	Input/ Output	Ignition switch ON		 10.2V
				Ignition switch OFF or ACC		0V
41 (W)	Ground	Engine switch (push switch) illumination	Output	Engine switch (push switch) illumination	ON	5.5V
					OFF	0V
42 (R)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	ON	0V
					OFF	Battery voltage
45 (P)	Ground	Receiver & sensor ground	Input	Ignition switch ON		0V
46 (V/W)	Ground	Receiver & sensor power supply output	Output	Ignition switch	OFF	0V
					ACC or ON	5.0V
47 (G/O)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
48 (R/G)	Ground	Selector lever P/N position signal	Input	Selector lever	P or N position	12.0V
					Except P and N positions	0V
49 (L/O)	Ground	Security indicator signal	Output	Security indicator	ON	0V
					Blinking	 11.3V
					OFF	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
50 (LG/ B)	Ground	Combination switch OUTPUT 5	Output	All switch OFF	0V
				Lighting switch 1ST	
				Lighting switch high-beam	
				Lighting switch 2ND	
				Turn signal switch RH	10.7V
51 (L/W)	Ground	Combination switch OUTPUT 1	Output	All switch OFF (Wiper intermittent dial 4)	0V
				Front wiper switch HI (Wiper intermittent dial 4)	
				Any of the conditions below with all switch OFF	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	
52 (G/B)	Ground	Combination switch OUTPUT 2	Output	All switch OFF (Wiper intermittent dial 4)	0V
				Front washer switch ON (Wiper intermittent dial 4)	
				Any of the conditions below with all switch OFF	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	
53 (LG/ R)	Ground	Combination switch OUTPUT 3	Output	All switch OFF	0V
				Front wiper switch INT	
				Front wiper switch LO	
				Lighting switch AUTO	
				10.7V	
54 (G/Y)	Ground	Combination switch OUTPUT 4	Output	All switch OFF	0V
				Front fog lamp switch ON	
				Lighting switch 2ND	
				Lighting switch flash-to-pass	
				Turn signal switch LH	10.7V
55 (BR/ W)	Ground	Front blower monitor	Input	ON	Battery voltage
				OFF	0V






A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
56 ² (L/B)	Ground	Front door lock assembly LH (key cylinder switch) (lock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (lock)	0V
57 (W)	Ground	Tire pressure warning check switch	Input	—	—	5V
58 (SB)	Ground	Front door LH switch	Input	Front door LH switch	OFF (front door LH CLOSE)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					ON (front door LH OPEN)	0V
59 (G/R)	Ground	Rear window defogger relay	Output	Rear window defogger	Active	Battery voltage
					Not activated	0V
60 (B/R)	Ground	Front console antenna 2 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
61 (W/R)	Ground	Center console antenna 2 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
62 ⁴ (B/Y)	Ground	Front outside handle RH antenna (-)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	
63 ⁴ (LG)	Ground	Front outside handle RH antenna (+)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	
64 ⁴ (V)	Ground	Front outside handle LH antenna (-)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	





A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[COUPE]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
65 ⁴ (P)	Ground	Front outside handle LH antenna (+)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
68 (G/O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
69 (O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
70 (R/B)	Ground	Ignition relay-2 con- trol	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
71 (L/O)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting		 <p style="text-align: right; font-size: small;">JMKIA0064GB</p>
				When operating either button on Intelligent Key	 <p style="text-align: right; font-size: small;">JMKIA0065GB</p>	

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
75 (R/Y)	Ground	Combination switch INPUT 5	Input	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
				Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
				Any of the conditions below with all switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3V</p>






A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



[COUPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
76 (R/G)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4V
					Lighting switch high-beam (Wiper intermittent dial 4)	 <small>JPMIA0036GB</small> 1.3V
					Lighting switch 2ND (Wiper intermittent dial 4)	 <small>JPMIA0037GB</small> 1.3V
					Any of the conditions below with all switch OFF	 <small>JPMIA0040GB</small> 1.3V
78 (P)	Ground	CAN-L	Input/ Output	—	—	
79 (L)	Ground	CAN-H	Input/ Output	—	—	
80 (R/L)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF	0V
					Blinking	 <small>JPMIA0015GB</small> 6.5V
81 (LG)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
83 (L)	Ground	ACC relay control	Output	Ignition switch	OFF	0V
					ACC or ON	Battery voltage
84 (Y/R)	Ground	CVT shift selector	Output	—		Battery voltage
87 (G/B)	Ground	Selector lever P position switch	Input	Selector lever	P position	0V
					Any position other than P	Battery voltage
88 ⁴ (P/L)	Ground	Front door RH request switch	Input	Front door RH request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
89 ⁴ (B/W)	Ground	Front door LH request switch	Input	Front door LH request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
90 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
91 (L/R)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage






A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





[COUPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
95 (R/W)	Ground	Combination switch INPUT 1	Input	All switch OFF	 <small>JPMIA0041GB</small> 1.4V
				Turn signal switch LH	 <small>JPMIA0037GB</small> 1.3V
				Turn signal switch RH	 <small>JPMIA0036GB</small> 1.3V
				Front wiper switch LO	 <small>JPMIA0038GB</small> 1.3V
				Front washer switch ON	 <small>JPMIA0039GB</small> 1.3V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
96 (P/B)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
				Combination switch	Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
				Combination switch	Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
				Combination switch	Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3V</p>







A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
97 (R/B)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					Lighting switch flash-to-pass	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch INT	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch HI	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3V</p>
					Pressed	0 V
98 (G/O)	Ground	Hazard switch	Input	Hazard switch	Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
(+)	(-)					
103 (V)	Ground	Trunk lid opening	Output	Trunk lid	Open (trunk lid opener actuator is activated)	Battery voltage
					Close (trunk lid opener actuator is not activated)	0V
110 (V/W)	Ground	Trunk room lamp	Output	Trunk room lamp	ON	0V
					OFF	Battery voltage
114 (B)	Ground	Rear parcel shelf antenna 1 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
115 (W)	Ground	Rear parcel shelf antenna 1 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>






A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[COUPE]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
118 ⁴ (L/O)	Ground	Rear bumper antenna (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
119 ⁴ (BR/W)	Ground	Rear bumper antenna (+)	Output	When the trunk lid request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
127 (BR/W)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch OFF or ACC	Battery voltage
				Ignition switch ON	0V
130 (Y/G)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch OFF (trunk is closed)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
				Trunk room lamp switch ON (trunk is open)	0V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
(+)	(-)					
132 (R)	Ground	Starter motor relay control	Output	Ignition switch OFF (M/T vehicle)	When the clutch pedal is depressed	Battery voltage
					When the clutch pedal is not depressed	0V
				Ignition switch ON (other than M/T vehicle)	When selector lever is in P or N position and the brake is depressed	Battery voltage
					When selector lever is in P or N position and the brake is not depressed	0V
140 (BR)	Ground	Engine switch (push switch)	Input	Engine switch (push switch)	Pressed	0V
					Not pressed	Battery voltage
141 (G/R)	Ground	Trunk request switch	Input	Trunk request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
144 ⁴ (GR)	Ground	Intelligent Key warning buzzer	Output	Request switch buzzer	Sounding	0V
					Not sounding	Battery voltage
144 ⁵ (GR)	Ground	Outside warning buzzer	Output	Outside warning buzzer	Sounding	0V
					Not sounding	Battery voltage
147 (L/R)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Pressed	0V
					Not pressed	Battery voltage
148 ¹ (R/W)	Ground	Rear door RH switch	Input	Rear door RH switch	OFF (when rear door RH closes)	 <p style="text-align: center;">11.8V</p>
					ON (when rear door RH opens)	0V
149 ¹ (R/B)	Ground	Rear door LH switch	Input	Rear door LH switch	OFF (when rear door LH closes)	 <p style="text-align: center;">11.8V</p>
					ON (when rear door LH opens)	0V

1: Sedan

2: With LH front window anti-pinch

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[COUPE]

< ECU DIAGNOSIS >

3: With LH and RH front window anti-pinch

4: With Intelligent Key

5: Without Intelligent Key

6: Coupe

Fail Safe

INFOID:000000005783583

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> Starter control relay signal Starter relay status signal
B2562: LO VOLTAGE	Inhibit engine cranking	100 ms after the power supply voltage increases to more than 8.8 V
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> Status 1 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): ON Clutch interlock switch signal: OFF (0 V) Status 2 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): OFF Clutch interlock switch signal: OFF (Battery voltage)

DTC Inspection Priority Chart

INFOID:000000005783584

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

Priority	DTC	
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING 	A B
4	<ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • B26E8: CLUTCH SW • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG 	C D E F G H I
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT 	J DLK L M N O
6	<ul style="list-style-type: none"> • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	P

DTC Index

INFOID:000000005783585

NOTE:

Details of time display

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-38, "Description"
U1010: CONTROL UNIT (CAN)	—	—	—	BCS-39, "DTC Logic"
U0415: VEHICLE SPEED SIG	—	—	—	BCS-40, "Description"
B2190: NATS ANTENNA AMP	×	—	—	SEC-53, "Description" (Coupe) SEC-229, "Description" (Sedan with I-Key) SEC-399, "Description" (Sedan without I-Key)
B2191: DIFFERENCE OF KEY	×	—	—	SEC-56, "Description" (Coupe) SEC-232, "Description" (Sedan with I-Key) SEC-402, "Description" (Sedan without I-Key)
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-57, "Description" (Coupe) SEC-233, "Description" (Sedan with I-Key) SEC-403, "Description" (Sedan without I-Key)
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-58, "Description" (Coupe) SEC-234, "Description" (Sedan with I-Key) SEC-404, "Description" (Sedan without I-Key)
B2195: ANTI SCANNING	×	—	—	SEC-59, "Description" (Coupe) SEC-235, "Description" (Sedan with I-Key) SEC-405, "Description" (Sedan without I-Key)
B2553: IGNITION RELAY	—	—	—	PCS-61, "Description"
B2555: STOP LAMP	—	—	—	SEC-60, "Description" (Coupe) SEC-236, "Description" (Sedan with I-Key) SEC-406, "Description" (Sedan without I-Key)
B2556: PUSH-BTN IGN SW	—	×	—	SEC-63, "Description" (Coupe) SEC-239, "Description" (Sedan with I-Key) SEC-409, "Description" (Sedan without I-Key)
B2557: VEHICLE SPEED	—	×	—	SEC-65, "Description" (Coupe) SEC-241, "Description" (Sedan with I-Key) SEC-411, "Description" (Sedan without I-Key)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2560: STARTER CONT RELAY	×	×	—	SEC-66, "Description" (Coupe) SEC-242, "Description" (Sedan with I-Key) SEC-412, "Description" (Sedan without I-Key)
B2562: LOW VOLTAGE	×	—	—	BCS-41, "DTC Logic"
B2601: SHIFT POSITION	—	×	—	SEC-67, "Description" (Coupe) SEC-243, "Description" (Sedan with I-Key) SEC-413, "Description" (Sedan without I-Key)
B2602: SHIFT POSITION	—	×	—	SEC-71, "Description" (Coupe) SEC-246, "Description" (Sedan with I-Key) SEC-416, "Description" (Sedan without I-Key)
B2603: SHIFT POSI STATUS	—	×	—	SEC-74, "Description" (Coupe) SEC-249, "Description" (Sedan with I-Key) SEC-419, "Description" (Sedan without I-Key)
B2604: PNP SW	—	×	—	SEC-77, "Description" (Coupe) SEC-252, "Description" (Sedan with I-Key) SEC-422, "Description" (Sedan without I-Key)
B2605: PNP SW	—	×	—	SEC-79, "Description" (Coupe) SEC-254, "Description" (Sedan with I-Key) SEC-424, "Description" (Sedan without I-Key)
B2608: STARTER RELAY	×	×	—	SEC-81, "Description" (Coupe) SEC-256, "Description" (Sedan with I-Key) SEC-426, "Description" (Sedan without I-Key)
B260A: IGNITION RELAY	×	×	—	PCS-63, "Description"
B260F: ENG STATE SIG LOST	×	×	—	SEC-83, "Description" (Coupe) SEC-258, "Description" (Sedan with I-Key) SEC-428, "Description" (Sedan without I-Key)
B2614: ACC RELAY CIRC	—	×	—	PCS-66, "Description"
B2615: BLOWER RELAY CIRC	—	×	—	PCS-69, "Description"
B2616: IGN RELAY CIRC	—	×	—	PCS-72, "Description"
B2617: STARTER RELAY CIRC	×	×	—	SEC-87, "Description" (Coupe) SEC-262, "Description" (Sedan with I-Key) SEC-432, "Description" (Sedan without I-Key)
B2618: BCM	×	×	—	PCS-75, "Description"
B261A: PUSH-BTN IGN SW	—	×	—	SEC-90, "Description" (Coupe) SEC-265, "Description" (Sedan with I-Key) SEC-435, "Description" (Sedan without I-Key)

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B261E: VEHICLE TYPE	×	× (Turn ON for 15 seconds)	—	SEC-89, "Description" (Coupe) SEC-264, "Description" (Sedan with I-Key) SEC-434, "Description" (Sedan without I-Key)
B2622: INSIDE ANTENNA	—	—	—	DLK-60, "Description" (Coupe) DLK-283, "Description" (Sedan with I-Key) DLK-484, "Description" (Sedan without I-Key)
B2623: INSIDE ANTENNA	—	—	—	DLK-63, "Description" (Coupe) DLK-286, "Description" (Sedan with I-Key) DLK-487, "Description" (Sedan without I-Key)
B26E1: ENG STATE NO RES	×	×	—	SEC-92, "Description" (Coupe) SEC-267, "Description" (Sedan with I-Key) SEC-437, "Description" (Sedan without I-Key)
B26E8: CLUTCH SW	×	×	—	SEC-84, "Description" (Coupe) SEC-259, "Description" (Sedan with I-Key) SEC-429, "Description" (Sedan without I-Key)
B26EA: KEY REGISTRATION	×	× (Turn ON for 15 seconds)	—	SEC-86, "Description" (Coupe) SEC-261, "Description" (Sedan with I-Key) SEC-431, "Description" (Sedan without I-Key)
C1704: LOW PRESSURE FL	—	—	×	WT-44, "Self-Diagnosis (With CONSULT-III)"
C1705: LOW PRESSURE FR	—	—	×	
C1706: LOW PRESSURE RR	—	—	×	
C1707: LOW PRESSURE RL	—	—	×	
C1708: [NO DATA] FL	—	—	×	WT-14, "Description"
C1709: [NO DATA] FR	—	—	×	
C1710: [NO DATA] RR	—	—	×	
C1711: [NO DATA] RL	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	×	WT-16, "Description"
C1713: [CHECKSUM ERR] FR	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	×	WT-18, "Description"
C1717: [PRESSDATA ERR] FR	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	×	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[COUPE]

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1720: [CODE ERR] FL	—	—	×	WT-16, "Description"
C1721: [CODE ERR] FR	—	—	×	
C1722: [CODE ERR] RR	—	—	×	
C1723: [CODE ERR] RL	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	×	
C1725: [BATT VOLT LOW] FR	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	×	WT-19, "Description"
C1729: VHCL SPEED SIG ERR	—	—	×	
C1734: CONTROL UNIT	—	—	×	WT-20, "Description"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER

< WIRING DIAGRAM >


[COUPE]

WIRING DIAGRAM

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram

INFOID:000000005429034



HOMELINK UNIVERSAL TRANSCEIVER

ABKWA0218GB


HOMELINK UNIVERSAL TRANSCEIVER

< WIRING DIAGRAM >

[COUPE]

HOMELINK UNIVERSAL TRANSCEIVER CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6Q	Y/R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	Y/R	-
15	B	-

Connector No.	M64
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B/Y	-
15	B	-

Connector No.	R4
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	B	GND
10	B/Y	BAT+

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[COUPE]


< WIRING DIAGRAM >

POWER DOOR LOCK SYSTEM

Wiring Diagram

INFOID:000000005429041

POWER DOOR LOCK SYSTEM - COUPE




ABKWA0743GB

POWER DOOR LOCK SYSTEM

[COUPE]

< WIRING DIAGRAM >

◁A6▷ : WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM
 ◁A7▷ : WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


ABKWA0744GB

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]

◇A6◇ : WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM
 ◇A7◇ : WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM




POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]


POWER DOOR LOCK SYSTEM CONNECTORS - COUPE

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7N	Y/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17J	SB	-
25J	Y/G	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	R/B	-


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >


[COUPE]

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G/Y	-
5	B	-
6	V	-
8	Y/G	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-
10	Y/G	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
8	B	-
9	GR/R	-
13	G/W	-
14	V	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	G/Y	CDL_AS
8	V	CDL_COMMON
9	G	CDL_DR/FL
11	Y/R	BAT_BCM_FUSE
13	B	GND1

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-

ABKIA2093GB

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name
27	G/W	DOOR_LOCK_STATUS
32	R/B	AS_DOOR_SW
34	L/R	DOOR_KEY/C_UNLOCK_SW
36	GR	CENTRAL_LOCK_SW
39	GR/R	CENTRAL_UNLOCK_SW
40	Y/G	PW_K-LINE
56	L/B	DOOR_KEY/C_LOCK_SW
58	SB	DR_DOOR_SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
78	P	CAN-L
79	L	CAN-H


Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
130	Y/G	TRUNK_SW

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]


Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	W	-
8	B	-

Terminal No.	Color of Wire	Signal Name
17J	SB	-
25J	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B109
Connector Name	DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	DOOR SW (AS)

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	GR	-

Connector No.	B68
Connector Name	DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

ABKIA2095GB

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	T5
Connector Name	JOINT CONNECTOR-T01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B/Y	-
2	B/Y	-

Connector No.	T4
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	W	-
8	B/Y	-

Connector No.	D25
Connector Name	DOOR LOCK ASSEMBLY LH (WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-
3	P	-
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW
6	L/B	DOOR_KEY/C_LOCK_SW

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-
10	BR	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
8	B	-
9	GR/R	-
13	P	-
14	GR	-

ABKIA2096GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	D28
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (COUPE WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
6	L	LOCK
7	R	UNLOCK
12	BR	COM
15	B	GND

Connector No.	D27
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (COUPE WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
5	GR	LOCK
6	GR/R	UNLOCK
10	B	GND

Connector No.	D26
Connector Name	DOOR LOCK ASSEMBLY LH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GRAY



1	2	3	4	5	6
---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-
3	P	-
4	B	GND
5	L/R	DOOR KEY/C UNLOCK SW
6	L/B	DOOR KEY/C LOCK SW

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
11	B	GND
16	R	COM

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



6	5	4	3	2	1
12	11	10	9	8	7

Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4		
5	6	7	8	9	10

Terminal No.	Color of Wire	Signal Name
1	G	-
5	B	-
6	GR	-
8	R	-


ABKIA2097GB

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >


[COUPE]

Connector No.	D112
Connector Name	DOOR LOCK ACTUATOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	GR	-
6	G	-

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	LOCK
2	GR/R	UNLOCK
3	B	GND

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

ABKIA2098GB

INTELLIGENT KEY SYSTEM


[COUPE]

< WIRING DIAGRAM >

INTELLIGENT KEY SYSTEM

Wiring Diagram

INFOID:000000005429042




ABKWA0751GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]




ABKWA0746GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[COUPE]

< WIRING DIAGRAM >




ABKWA0747GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKWA0748GB


INTELLIGENT KEY SYSTEM CONNECTORS - COUPE

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	BR	-
57G	GR	-
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1N	W/L	-
4N	G/Y	-
7N	Y/R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3Q	O/L	-
9Q	R/W	-


ABKIA2100GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
10	R/B	-

Terminal No.	Color of Wire	Signal Name
4J	B	-
6J	BR/W	-
11J	W	-
13J	L/O	-
17J	SB	-
25J	Y/G	-
27J	G/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
11	V	-
12	B/W	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	B	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


ABKIA2101GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	P/W	ROOM LAMP BAT SAVER
5	G/Y	CDL AS
8	V	CDL COMMON
9	G	CDL DR/FL
10	G/Y	CDL RR RL BACK
11	Y/R	BAT BCM FUSE
13	B	GND1
15	Y/L	ACD LED
17	G/B	FR FLASHER
18	G/Y	FL FLASHER
19	Y	ROOM LAMP OUTPUT

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L


Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	LG	-
9	P/L	-
12	B/Y	-

Terminal No.	Color of Wire	Signal Name
24	R/W	STOP LAMP LOW SW
26	O/L	STOP LAMP HIGH SW
29	Y	FOB IN SW 1
32	R/B	AS DOOR SW
40	Y/G	PW K-LINE
42	R	S/L LOCK LED
45	P	GND RF2 A/L
58	SB	DR DOOR SW

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



ABKIA2102GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
151	150	149	148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132

Terminal No.	Color of Wire	Signal Name
114	B	TRUNK ANT 1 B
115	W	TRUNK ANT 1 A
118	L/O	BACK DOOR ANT B
119	BR/W	BACK DOOR ANT A
130	Y/G	TRUNK SW
140	BR	ENGINE START SW W/O ESCL
141	G/R	TRUNK REQUEST SW
144	GR	BUZZER

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



100	101	102	103	104		
105	106	107	108	109	110	111

Terminal No.	Color of Wire	Signal Name
103	V	CDL_BACK_TRUNK

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60
99	98	97	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80

Terminal No.	Color of Wire	Signal Name
60	B/R	ROOM ANT 2 B
61	W/R	ROOM ANT 2 A
62	B/Y	AS DOOR ANT B
63	LG	AS DOOR ANT A
64	V	DR DOOR ANT B
65	P	DR DOOR ANT A
68	G/O	FOB READER CLOCK
69	O	FOB READER DATA
71	L/O	RF1 TUNER SIGNAL
78	P	CAN-L
79	L	CAN-N
80	R/L	FOB SLOT ILLUMINATION
81	LG	IGN ON LED
88	P/L	AS REQUEST SWITCH
91	L/R	RF1 POWER SUPPLY
98	G/O	HAZARD SW

ABKIA2103GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >


[COUPE]

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	B	GND
4	BR	START_SW
5	R	LOCK
6	Y/L	ACC
7	LG	ON
8	G/Y	B+

Connector No.	M27
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	GND
2	L/O	SIGNAL
3	L/R	12V

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/L	BAT
3	B	GND (POWER)
4	B	GND (ILL)
21	L	CAN-H
22	P	CAN-L
23	B	GND (CIRCUIT)

Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Connector No.	M71
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	M40
Connector Name	KEY SLOT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/Y	B+
2	G/O	CLOCK
3	O	DATA
5	G/Y	LIGHT_BAT+
6	R/L	LIGHT_A
7	B	GND
11	Y	CARE_SW_1


ABKIA2104GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >


[COUPE]

Connector No.	M200
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	M131
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Connector No.	M93
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	O	-

Connector No.	M207
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

Connector No.	M203
Connector Name	FRONT CONSOLE ANTENNA
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W/R	ANT+
2	B/R	ANT-

ABKIA2105GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	E17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
39	P	CAN-L
40	L	CAN-H
41	B	GND (SIGNAL)
44	G/W	HORN_RLY

Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	P	-
8P	R	-
11P	G	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	B	GND (POWER)
28	SB	PUSH START SW

Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	SB	-
57G	R	-
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E22
Connector Name	JOINT CONNECTOR-E03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E74
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
3	R	-

Connector No.	E52
Connector Name	STOP LAMP SWITCH (WITH M/T)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-

Connector No.	E38
Connector Name	STOP LAMP SWITCH (WITH CVT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-

ABKIA2107GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	E216
Connector Name	HORN (HIGH)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E215
Connector Name	HORN (LOW)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-


Connector No.	B20
Connector Name	JOINT CONNECTOR-B05
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	B	-
4	B	-

Terminal No.	Color of Wire	Signal Name
4J	B	-(WITH COUPE)
6J	L	-
11J	W	-
13J	LG	-
17J	SB	-
22J	BR	-
25J	W	-
27J	SB	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABKIA2108GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	SB	-
6	B	-
7	W	-
8	B	-

Connector No.	B46
Connector Name	REAR BUMPER ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L	ANT+
2	LG	ANT-

Connector No.	B29
Connector Name	REAR PARCEL SHELF ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	ANT+
2	B	ANT- (WITH COUPE)

Connector No.	B109
Connector Name	DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	DOOR SW (AS)

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	GR	-
11	B	-

Connector No.	B68
Connector Name	DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

ABKIA2109GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >

[COUPE]

Connector No.	T4
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	T2
Connector Name	TRUNK OPENER REQUEST SWITCH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	BR	-

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	SB	-
6	BR	-
7	W	-
8	B/Y	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
11	V	-
12	GR	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	B	-

Connector No.	T5
Connector Name	JOINT CONNECTOR-T01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/Y	-
2	B/Y	-


ABKIA2110GB

INTELLIGENT KEY SYSTEM

< WIRING DIAGRAM >


[COUPE]

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
9	GR	-
12	L	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B	-


Connector No.	D17
Connector Name	OUTSIDE HANDLE LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	ANT+
2	V	ANT-
3	GR	SW+
4	B	SW-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-
3	G	-

Connector No.	H-1
Connector Name	FUSE AND FUSIBLE LINK BOX (HORN RELAY)
Connector Color	-



Connector No.	D116
Connector Name	OUTSIDE HANDLE RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	ANT+
2	L	ANT-
3	GR	SW+
4	B	SW-

ABKIA2111GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK LID OPENER

[COUPE]


< WIRING DIAGRAM >

TRUNK LID OPENER

Wiring Diagram

INFOID:000000005429043

TRUNK LID OPENER - COUPE



ABKWA0750GB


TRUNK LID OPENER

< WIRING DIAGRAM >

[COUPE]


TRUNK LID OPENER CONNECTORS - COUPE

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21J	V	-

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
37	O	TRUNK_CANCEL_SW

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
103	V	CDL_BACK_TRUNK

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK


ABKIA2113GB

TRUNK LID OPENER

[COUPE]

< WIRING DIAGRAM >

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
147	L/R	BACK_TRUNK_OPENER

Connector No.	M74
Connector Name	TRUNK LID OPENER CANCEL SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-

Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L/R	-
2	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	21J
Color of Wire	V
Signal Name	-

TRUNK LID OPENER

< WIRING DIAGRAM >

[COUPE]

Connector No.	T4
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
4	B	-

Connector No.	T3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKIA2114GB

SYMPTOM DIAGNOSIS

INTELLIGENT KEY SYSTEM SYMPTOMS

Symptom Table

INFOID:000000005429047

ALL FUNCTIONS OF INTELLIGENT KEY SYSTEM DO NOT OPERATE

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” and “LOCK/UNLOCK BY I-KEY” are ON when setting on CONSULT-III.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
All functions of Intelligent Key system do not operate.	1. Check BCM power supply and ground circuit.	DLK-66
	2. Check Intelligent Key function and battery inspection.	DLK-115
	3. Check remote keyless entry receiver.	DLK-112
	4. Check Intermittent Incident.	GI-41

DOOR LOCK FUNCTION SYMPTOMS

[COUPE]

< SYMPTOM DIAGNOSIS >

DOOR LOCK FUNCTION SYMPTOMS

DOOR LOCK AND UNLOCK SWITCH

DOOR LOCK AND UNLOCK SWITCH : Symptom Table

INFOID:000000005429048

DOOR LOCK/UNLOCK FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- "LOCK/UNLOCK BY I-KEY" is ON when setting on CONSULT-III.
- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page	
Power door lock does not operate with door lock and unlock switch.	1. Check BCM Power supply and ground circuit.	DLK-66	
	2. Check door lock and unlock switch.	DLK-70	
	3. Check door lock actuator (driver side)	DLK-102	
	4. Check Intermittent Incident.	GI-41	
Power door lock does not operate with door key cylinder operation. (Power door lock operate properly with door lock and unlock switch.)	1. Check key cylinder switch.	DLK-79	
	2. Replace power window main switch.	INT-11	
Specific door lock actuator does not operate.	1. Check door lock actuator.	Driver side	DLK-102
		Passenger side	DLK-103
	2. Check Intermittent Incident.	GI-41	
Vehicle speed sensing auto door LOCK operation does not operate.	1. Ensure automatic door lock/unlock function (lock operation) is enabled.	DLK-53	
	2. Check combination meter vehicle speed signal.	MWI-46	
	3. Check intermittent incident.	GI-41	
Ignition OFF interlock auto door UNLOCK function does not operate.	1. Ensure automatic door lock/unlock function (unlock operation) is enabled.	DLK-53	
	2. Check BCM for DTCs.	DLK-149	
	3. Check intermittent incident.	GI-41	

DLK

DOOR REQUEST SWITCH

DOOR REQUEST SWITCH : Symptom Table

INFOID:000000005429049

DOOR LOCK/UNLOCK FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- "LOCK/UNLOCK BY I-KEY" is ON when setting on CONSULT-III.
- Intelligent Key is out of key slot.
- All doors are closed.

DOOR LOCK FUNCTION SYMPTOMS

[COUPE]

< SYMPTOM DIAGNOSIS >

Symptom	Diagnosis/service procedure	Reference page
Door lock/unlock do not operate by door request switch.	1. Check BCM power supply and ground circuit.	DLK-66
	2. Check door switch.	DLK-67
	3. Check key slot.	DLK-77
	4. Check Intermittent Incident.	GI-41
Door lock/unlock does not operate by request switch (driver side).	1. Check door request switch (driver side).	DLK-95
	2. Check outside key antenna (driver side).	DLK-109
	3. Check Intermittent Incident.	GI-41
Door lock/unlock does not operate by request switch (passenger side).	1. Check door request switch (passenger side).	DLK-95
	2. Check outside key antenna (passenger side).	DLK-109
	3. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by door request switch (driver side) (other door lock function operate).	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-53
	2. Check selective unlock function with a remote controller or door key cylinder.	DLK-20
	3. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by door request switch (passenger side) (other door lock function operate).	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-53
	2. Check Intermittent Incident.	GI-41
Auto lock function does not operate.	1. Check "AUTO LOCK SET" setting in "WORK SUPPORT".	DLK-53
	2. Check door switch.	DLK-67
	3. Check key slot.	DLK-77
	4. Check Intermittent Incident.	GI-41

INTELLIGENT KEY

INTELLIGENT KEY : Symptom Table

INFOID:000000005429050

REMOTE KEYLESS ENTRY FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms" are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- Ignition switch is in OFF or ACC position.
- All doors are closed.
- Retained power operation does not operate. Refer to [DLK-25, "INTELLIGENT KEY : System Description"](#).

Symptom	Diagnosis/service procedure	Reference page
All of the remote keyless entry functions do not operate.	1. Check Intelligent Key battery inspection.	DLK-115
	2. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by Intelligent Key.	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-53
	2. Check Intelligent Key battery inspection.	DLK-115
	3. Check Intermittent Incident.	GI-41

DOOR LOCK FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[COUPE]

Symptom	Diagnosis/service procedure	Reference page
Auto lock function does not operate normally.	1. Check "AUTO LOCK SET" setting in "WORK SUPPORT".	DLK-53
	2. Check door switch.	DLK-67
	3. Check key slot.	DLK-77
	4. Check Intermittent Incident.	GI-41
Power window down function does not operate.	1. Check "PW DOWN SET" setting in "WORK SUPPORT".	DLK-53
	2. Check Intelligent Key battery inspection.	DLK-115

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK OPEN FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[COUPE]

TRUNK OPEN FUNCTION SYMPTOMS

TRUNK LID OPENER SWITCH

TRUNK LID OPENER SWITCH : Symptom Table

INFOID:000000005429051

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by trunk opener switch.	1. Check trunk opener switch.	DLK-86
	2. Check trunk lid opener cancel switch.	DLK-89
	3. Check Intermittent Incident.	GI-41

TRUNK REQUEST SWITCH

TRUNK REQUEST SWITCH : Symptom Table

INFOID:000000005429052

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following “symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by trunk opener request switch.	1. Check trunk opener request switch.	DLK-99
	2. Check trunk lid opener cancel switch.	DLK-89
	3. Check outside key antenna (trunk room).	DLK-109
	4. Check Intermittent Incident.	GI-41

INTELLIGENT KEY

INTELLIGENT KEY : Symptom Table

INFOID:000000005429053

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

TRUNK OPEN FUNCTION SYMPTOMS

[COUPE]

< SYMPTOM DIAGNOSIS >

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by Intelligent Key.	1. Check "TRUNK OPEN DELAY" setting in "WORK SUPPORT".	DLK-53
	2. Check trunk open function.	DLK-37
	3. Check trunk room lamp switch.	DLK-92
	4. Check Intelligent Key battery inspection.	DLK-115
	5. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[COUPE]

WARNING FUNCTION SYMPTOMS

Symptom Table

INFOID:000000005429054

WARNING FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-11, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following “symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

Warning chime functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation.

Symptom		Diagnosis/service procedure	Reference page
OFF position warning does not operate.	For internal	1. Check push button ignition switch position indicator.	SEC-63
		2. Check door switch.	DLK-67
		3. Check warning chime function.	DLK-122
		4. Check Intermittent Incident.	GI-41
	For external	1. Check push button ignition switch position indicator.	SEC-63
		2. Check door switch.	DLK-67
		3. Check Intelligent Key warning buzzer.	DLK-107
		4. Check Intermittent Incident.	GI-41
P position warning does not operate.	1. Check Park position switch.	SEC-77	
	2. Check door switch.	DLK-67	
	3. Check Intelligent Key warning buzzer.	DLK-107	
	4. Check warning chime function.	DLK-122	
	5. Check combination meter display function.	DLK-121	
	6. Check Intermittent Incident.	GI-41	
ACC warning does not operate	1. Check push button ignition switch position indicator.	SEC-63	
	2. Check warning chime function.	DLK-122	
	3. Check combination meter display function.	DLK-121	
	4. Check Intermittent Incident.	GI-41	

WARNING FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[COUPE]

Symptom		Diagnosis/service procedure		Reference page
Take away warning does not operate.	Door open to close	1. Check door switch.		DLK-67
		2. Check inside key antenna.	Console	DLK-60
			Trunk room	DLK-63
		3. Check Intelligent Key warning buzzer.		DLK-107
		4. Check warning chime function.		DLK-122
		5. Check key slot illumination.		DLK-117
		6. Check combination meter display function.		DLK-121
	7. Check Intermittent Incident.		GI-41	
	Push-button ignition switch operation	1. Check push button ignition switch position indicator.		SEC-63
		2. Check inside key antenna.	Console	DLK-60
			Trunk room	DLK-63
		3. Check warning chime function.		DLK-122
		4. Check key slot illumination.		DLK-117
		5. Check combination meter display function.		DLK-121
	6. Check Intermittent Incident.		GI-41	
	Door is open	1. Check push button ignition switch position indicator.		SEC-63
		2. Check inside key antenna.	Console	DLK-60
			Trunk room	DLK-63
		3. Check combination meter display function.		DLK-121
	4. Check Intermittent Incident.		GI-41	
	Take away through window	1. Check "TAKE OUT FROM WIN WARN" setting in "WORK SUPPORT".		DLK-53
		2. Check inside key antenna.	Console	DLK-60
			Trunk room	DLK-63
		3. Check warning chime function.		DLK-122
4. Check key slot illumination.		DLK-117		
5. Check combination meter display function.		DLK-121		
6. Check Intermittent Incident.		GI-41		
Key warning chime does not operate.	1. Check key slot.		DLK-77	
	2. Check door switch.		DLK-67	
	3. Check warning chime function.		DLK-122	
	4. Check key slot illumination.		DLK-117	
	5. Check combination meter display function.		DLK-121	
	6. Check Intermittent Incident.		GI-41	
Door lock operation warning chime does not operate.	1. Check door switch.		DLK-67	
	2. Check key slot illumination.		DLK-117	
	3. Check Intelligent Key warning buzzer.		DLK-107	
	4. Check inside key antenna.	Console	DLK-60	
		Trunk room	DLK-63	
5. Check Intermittent Incident.		GI-41		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY REMINDER FUNCTION SYMPTOMS

[COUPE]

< SYMPTOM DIAGNOSIS >

KEY REMINDER FUNCTION SYMPTOMS

Symptom Table

INFOID:000000005429055

KEY REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-11, "Work Flow"](#).
- If the following symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “LOCK/UNLOCK BY I-KEY” is ON when setting on CONSULT-III.
- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.
- Intelligent Key is out of key slot.

Symptom	Diagnosis/service procedure	Reference page
Key reminder function does not operate.	1. Check “ANTI KEY LOCK IN FUNCTI”setting in “WORK SUPPORT”.	DLK-77
	2. Check door switch.	DLK-67
	3. Check inside key antenna.	DLK-122
	4. Check unlock sensor.	DLK-117
	5. Check Intelligent Key battery inspection.	DLK-115
	6. Check Intermittent Incident.	GI-41

HAZARD FUNCTION

Symptom Table

INFOID:000000005429056

HAZARD AND BUZZER REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-11, "Work Flow"](#).
- If the following symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “LOCK/UNLOCK BY I-KEY” is ON when setting on CONSULT-III.
- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.
- Intelligent Key is out of key slot.

Symptom	Diagnosis/service procedure	Reference page
Hazard reminder does not operate by request switch. (Buzzer reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-53
	2. Check hazard function.	DLK-123
	3. Check Intermittent incident.	GI-41
Hazard reminder does not operate by Intelligent Key. (Buzzer reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-53
	2. Check hazard function.	DLK-123
	3. Check Intelligent Key battery inspection.	DLK-115
Buzzer reminder does not operate by request switch. (Hazard reminder operate.)	1. Check “ANS BACK I-KEY LOCK” or “ANS BACK I-KEY UNLOCK” setting in “WORK SUPPORT”.	DLK-53
	2. Check Intelligent Key warning buzzer.	DLK-107
	3. Check Intermittent incident.	GI-41
Buzzer reminder does not operate by trunk opener request switch.	1. Check “TRUNK OPEN DELAY” setting in “WORK SUPPORT”.	DLK-53
	2. Check Intelligent Key warning buzzer.	DLK-107
	3. Check trunk open function.	DLK-32
	4. Check Intermittent incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HORN FUNCTION

[COUPE]

< SYMPTOM DIAGNOSIS >

HORN FUNCTION

Symptom Table

INFOID:000000005429057

HAZARD AND HORN REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-11, "Work Flow"](#).
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Hazard reminder does not operate by request switch. (Horn reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-53
	2. Check hazard function.	DLK-123
	3. Check Intermittent Incident.	GI-41
Hazard reminder does not operate by Intelligent Key. (Horn reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-53
	2. Check hazard function.	DLK-123
	3. Check Intelligent Key battery inspection.	DLK-115
Horn reminder does not operate by request switch. (Hazard reminder operate.)	1. Check “ANSWER BACK WITH I-KEY LOCK” or “ANSWER BACK WITH I-KEY UNLOCK” setting in “WORK SUPPORT”.	DLK-53
	2. Check Intelligent Key warning buzzer.	DLK-107
	3. Check Intermittent Incident.	GI-41
Horn reminder does not operate by Intelligent Key. (Hazard reminder operate.)	1. Check “HORN WITH KEYLESS LOCK” setting in “WORK SUPPORT”.	DLK-53
	2. Check horn function.	DLK-119
	3. Check Intermittent Incident.	GI-41

INTEGRATED HOMELINK TRANSMITTER

< SYMPTOM DIAGNOSIS >

[COUPE]

INTEGRATED HOMELINK TRANSMITTER

Symptom Table

INFOID:000000005429058

HOMELINK UNIVERSAL TRANSCEIVER MALFUNCTION


Symptom	Diagnosis/service procedure	Reference page
Homelink universal transceiver does not operate properly.	1. Check homelink universal transceiver function.	DLK-124
	2. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005429059



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [DLK-202, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak — (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak — (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle — (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock — (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick — (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump — (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz — (Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[COUPE]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [DLK-200, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[COUPE]

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000005429060

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[COUPE]

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[COUPE]

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000005429061





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[COUPE]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|-------------------------------------------------------|--------------------------------------------------------|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI0071E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005786768

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Procedure without Cowl Top Cover

INFOID:000000005429063

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for work

INFOID:000000005429064

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

PREPARATION

[COUPE]

< PREPARATION >




PREPARATION

PREPARATION

Special Service Tools

INFOID:000000005429065



The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise
— (J-43241) Remote Keyless Entry Tester  LEL946A	Used to test keyfobs

A
B
C
D
E
F
G
H
I
J
DLK

Commercial Service Tools

INFOID:000000005429066

Tool name	Description
Engine ear  SIIA0995E	Locating the noise
Power tool  PIIB1407E	

L
M
N
O
P

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

HOOD

HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation


INFOID:000000005429067

REMOVAL

1. Remove the hinge nuts (a) and the hood assembly (1).

CAUTION:

Remove using two workers, to avoid damaging the hood assembly.



INSTALLATION

Installation is in the reverse order of removal.

Hood hinge nuts : 14 N·m (1.4 kg·m, 10 ft·lb)

NOTE:

After installing, perform hood fitting adjustment. Refer to [DLK-207, "HOOD ASSEMBLY : Adjustment"](#).

HOOD



[COUPE]

< ON-VEHICLE REPAIR >

HOOD ASSEMBLY : Adjustment

INFOID:000000005429068

SEC. 650



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

- 1. Hood assembly
- 2. Front grille
- 3. Front fascia
- 4. Headlamp assembly
- 5. Front fender

FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT

HOOD

< ON-VEHICLE REPAIR >


[COUPE]

Unit: mm (in)


Section	Item	Measurement	Standard	Parallelism	Equality
A – A	E	Clearance	5.0 ± 2.5 (0.20 ± 0.10)	≤ 2.0 (0.079)	—
B – B	F	Clearance	5.0 ± 2.0 (0.20 ± 0.079)	≤ 2.0 (0.079)	≤ 2.0 (0.079)
	G	Surface height	0.8 ± 2.0 (0.03 ± 0.079)	≤ 2.0 (0.079)	≤ 2.0 (0.079)
C – C	H	Clearance	5.0 ± 2.0 (0.20 ± 0.079)	≤ 2.0 (0.079)	2.0 (0.079)
	J	Surface height	1.0 ± 2.0 (0.04 ± 0.079)	—	< 2.0 (0.079)
D – D	K	Clearance	4.0 ± 1.0 (0.16 ± 0.04)	1.0 (0.04)	1.0 (0.04)
	M	Surface height	0.2 ± 1.0 (0.01 ± 0.04)	1.0 (0.04)	1.0 (0.04)

Front End Height Adjustment

1. Check the surface height between the hood and each part by visual and tactile feeling.
2. Remove the front grille. Refer to [EXT-18, "Removal and Installation"](#).
3. Remove the hood lock.
4. Adjust the surface level difference of the hood, fender and head lamp by rotating the hood bumpers until the hood becomes 1 to 1.5 mm (0.04 to 0.059 in) lower than the fender.



5. Install and align the hood lock center with the center of the hood striker. Engage the lock with the striker and check for looseness.
6. Adjust A and B as shown to the following value with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing the hood closed lightly [approx. 29 N (3 kg)].



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.27 in) |

7. After adjustment tighten the hood lock bolts to the specified torque.

Lateral/Longitudinal Clearance Adjustment

1. Check the clearance between the hood and each part by visual and tactile feeling.
2. Loosen the hood hinge bolts.

NOTE:

The anticorrosive agent applied between the hoodledge and the hood hinges also acts as an adhesive. This seal must be broken before the hinges will move.

3. Move the hood so that the clearance measurements are within specifications.
4. Tighten the hood hinge bolts.

Hood hinge bolts : 14 N-m (1.4 kg-m, 10 ft-lb)

NOTE:


After installation apply touch-up paint onto the hinge bolts and around the base of the hinge.

- If the clearance measurements between the hood and fender cannot be corrected by moving the hood, the fender must be adjusted. Refer to [DLK-214, "Removal and Installation"](#).

HOOD LOCK CONTROL

HOOD LOCK CONTROL : Component Parts Location

INFOID:000000005429069




- | | | |
|-----------------------|-----------------------------|----------------------------|
| 1. Hood lock assembly | 2. Hood lock cable | 3. Hoodledge reinforcement |
| 4. Clip | 5. Hood lock release handle | |

HOOD LOCK CONTROL : Removal and Installation

INFOID:000000005429070

REMOVAL

- Remove the front grill. Refer to [EXT-18, "Removal and Installation"](#).
- Remove the LH fender protector. Refer to [EXT-20, "Removal and Installation"](#).
- Remove the hood lock assembly bolts.



- Disconnect the hood lock cable from the hood lock, and unclip it from the hoodledge.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

HOOD

[COUPE]

< ON-VEHICLE REPAIR >


5. Remove the screws (a) with power tool, and separate the hood lock release handle (1) from the hood lock release cable (2).




6. Remove the grommet from the upper dash, and pull the hood lock cable into the passenger compartment.
CAUTION:
While pulling, be careful not to damage (peel) the outside of the hood lock cable.

INSTALLATION


1. Pull the hood lock cable through the upper dash into the engine compartment.
CAUTION:
Be careful not to bend the cable too much, keep the radius 100 mm (3.94 in) or more.
2. Attach the hood lock cable (2) to the hood lock release handle (1) and install the hood lock release handle screws (a).



3. Check that the cable is not offset from the center of the grommet, and seat the grommet into the upper dash hole.
4. Apply the sealant around the grommet at * mark.



5. Position the hood lock cable and clip it into place.
6. Connect the hood lock cable to the hood lock assembly.
7. Loosely install the hood lock assembly.
8. Perform hood fitting adjustment. Refer to [DLK-207, "HOOD ASSEMBLY : Adjustment"](#).
9. Check the hood lock control operation.



HOOD

< ON-VEHICLE REPAIR >


[COUPE]

INSPECTION

CAUTION:


If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary latch is properly engaged with the secondary striker (B: 6.8 mm (0.268 in) shown in the figure) with hood's own weight.



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.268 in) |

2. While operating the hood opener, carefully check that the front end of the hood is raised by approx. 20 mm (0.79 in). Also check that the hood opener returns to the original position.
3. Check that the hood lock release handle operating force is 49 N (5.0 kg, 11 lb).
4. Install so the static closing force of the hood is 343 – 490 N (35 – 44 kg-f, 77.1 - 110.2 lb-f).
5. Check the hood lock lubrication condition. If necessary, apply "body grease" as shown.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

RADIATOR CORE SUPPORT


< ON-VEHICLE REPAIR >

[COUPE]

RADIATOR CORE SUPPORT

Removal and Installation

INFOID:000000005429071



1. Radiator core support

a. Bolts

REMOVAL

1. Remove front bumper reinforcement. Refer to [EXT-14, "Removal and Installation"](#).
2. Remove head lamps (LH/RH). Refer to [EXL-228, "Headlamp"](#).
3. Remove air duct. Refer to QR25DE, [EM-25, "Removal and Installation"](#) VQ35DE [EM-129, "Removal and Installation"](#).
4. Remove the radiator cooling fans. Refer to QR25DE [CO-17, "Removal and Installation"](#), VQ35DE [CO-39, "Removal and Installation"](#).
5. Remove the radiator. Refer to QR25DE [CO-15, "Removal and Installation"](#), VQ35DE [CO-37, "Removal and Installation"](#).
6. Remove the hood lock control. Refer to [DLK-209, "HOOD LOCK CONTROL : Removal and Installation"](#).
7. Remove ambient sensor. Refer to [HA-37, "Removal and Installation"](#).
8. Remove crash zone sensor. Refer to [SR-13, "Removal and Installation"](#).
9. Remove air guides (LH/RH).
10. Remove power steering fluid cooler. Refer to QR25DE [ST-21, "QR25DE : Removal and Installation"](#), VQ35DE [ST-21, "VQ35DE : With 17 Inch Tire"](#) or [ST-23, "VQ35DE : With 18 Inch Tire"](#).

RADIATOR CORE SUPPORT

[COUPE]

< ON-VEHICLE REPAIR >

11. Remove horn (High/Low). Refer to [HRN-11, "Removal and Installation"](#).
12. Remove the harness clips from the radiator core support assembly and position the harness aside.
13. Remove the hood support rod.
14. Remove the bolts and the radiator core support.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

FRONT FENDER

Removal and Installation

INFOID:000000005429072

REMOVAL

1. Remove the head lamp. Refer to [EXL-217, "Removal and Installation"](#).
2. Remove the inner fender bolt cover.
3. Remove the center mudguard. Refer to [EXT-21, "Removal and Installation"](#).
4. Remove the bolts and the front fender.

CAUTION:

- While removing, use a shop cloth to protect the body from damage.
- Use care when removing the front fender. The front fender baffle foam adheres the front fender to the body side outer. Carefully release the foam or damage to the fender may occur.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the front fender bolts.


ADJUSTMENT

FRONT FENDER

< ON-VEHICLE REPAIR >

[COUPE]

SEC. 630



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

- 1. Hood assembly
- 4. Body side outer
- ↔ Front

- 2. Front fender
- 5. Front fascia bracket

- 3. Front fascia
- 6. Front door assembly

AWKIA0447GB

FRONT FENDER

< ON-VEHICLE REPAIR >

[COUPE]

Unit: mm (in)

Section	Item	Measurement	Standard	Parallelism	Equality
A-A	E	Clearance	4.0 ± 1.0 (0.16 ± 0.04)	1.0 (0.04)	1.0 (0.04)
	F	Surface height	0.2 ± 1.0 (0.01 ± 0.04)	1.0 (0.04)	1.0 (0.04)
B-B	G	Clearance	$0.0 + 0.8$ (0.0 + 0.031)	—	—
	H	Surface height	0.7 ± 1.0 (0.028 ± 0.04)	1.0 (0.04)	1.0 (0.04)
C-C	J	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—
	K	Clearance	3.6 ± 1.0 (0.14 ± 0.04)	1.0 (0.04)	—
D-D	M	Clearance	2.3 ± 1.0 (0.09 ± 0.04)	1.0 (0.04)	—
	N	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—

1. Remove the inner fender bolt cover.
2. Remove the front fender protector. Refer to [EXT-20, "Removal and Installation"](#).
3. Remove the center mudguard. Refer to [EXT-21, "Removal and Installation"](#).
4. Loosen the front fender bolts and screws.
5. Adjust the clearance (J) and surface height (K) between the front fender and the front door.
6. Tighten the rear upper and lower front fender bolts.
7. Adjust the clearance (E) and surface height (F) between the front fender and the hood.
8. Adjust the clearance (M) and surface height (N) between the front fender and the body side outer.
9. Tighten the inner front fender bolts.
10. Adjust the clearance (G) and the surface height (H) between the front fender and the front fascia.
11. Tighten the front fender to front fascia and bracket screws.
12. Apply touch-up paint (the body color) onto the head of the front fender bolts.
13. Install the center mudguard. Refer to [EXT-21, "Removal and Installation"](#).
14. Install the front fender protector. Refer to [EXT-20, "Removal and Installation"](#).
15. Install the inner fender bolt cover.

DOOR

FRONT DOOR

FRONT DOOR : Removal and Installation


INFOID:000000005429073

CAUTION:

- When removing and installing the front door assembly, support the door with a jack and cloth to protect the door and body.
- When removing and installing front door assembly, be sure to carry out the fitting adjustment. Refer to [DLK-218, "FRONT DOOR : Adjustment"](#).
- After installing, apply touch-up paint (the body color) onto the head of the hinge nuts.
- Check the hinge rotating parts for lubrication. If necessary, apply "body grease".
- Operate with two workers, because of its heavy weight.
- Check front door open/close operation after installation.

REMOVAL

1. Pull the grommet and wire harness out of the front pillar until the harness connectors are accessible. Then disconnect the wire harness connectors.
2. Remove the check link bolt from the front pillar.
3. Remove the door-side hinge nuts (a) and the door assembly (1).



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

Adjust the door. Refer to [DLK-218, "FRONT DOOR : Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR







[COUPE]

< ON-VEHICLE REPAIR >

FRONT DOOR : Adjustment

INFOID:000000005429074

SEC.800



AWKIA0448GB

- 1. Front fender
- 2. Front door assembly
- 3. Body side outer
- 4. Center mudguard

DOOR

< ON-VEHICLE REPAIR >

[COUPE]

Unit: mm (in)

Section	Item	Measurement	Standard
A-A	F	Clearance	6.1 ± 1.5 (0.24 ± 0.06)
	G	Surface height	2.9 ± 1.5 (0.11 ± 0.06)
B-B	H	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	J	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
C-C	K	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	M	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
D-D	N	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	P	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
E-E	Q	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	R	Surface height	0.0 ± 1.0 (0.0 ± 0.04)

LONGITUDINAL CLEARANCE

1. Remove the front fender. Refer to [DLK-214, "Removal and Installation"](#).
2. Loosen the hinge bolts. Raise or lower the front door at rear edge to adjust.
3. Install the front fender. Refer to [DLK-214, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the front door hinge nuts.
2. Move the top and or bottom in or out as necessary until it is within specifications.
3. Tighten the hinge nuts to specifications.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK


< ON-VEHICLE REPAIR >

[COUPE]

DOOR LOCK FRONT DOOR LOCK

FRONT DOOR LOCK : Component Parts Location

INFOID:000000005429075




- | | | |
|----------------------------|----------------------------------------|---------------------------------------------------------------------------------------------|
| 1. Outside handle assembly | 2. Outside handle grip | 3. Door key cylinder escutcheon (Driver side)
Outside handle escutcheon (Passenger side) |
| 4. Front gasket | 5. Rear gasket | 6. Key cylinder assembly (Driver side only) |
| 7. Outside handle bracket | 8. Key cylinder rod (Driver side only) | 9. Door lock assembly |
| 10. Front door striker | 11. Grommet | 12. Inside door handle assembly |
| 13. Cap | | |

FRONT DOOR LOCK : Removal and Installation

INFOID:000000005429076

REMOVAL

1. Remove the front door finisher. Refer to [INT-11. "Removal and Installation"](#).
2. Disconnect the inside handle knob cable and lock knob cable from the back side of the front door finisher.




DOOR LOCK


[COUPE]

< ON-VEHICLE REPAIR >


3. Remove the front door window and front door module assembly. Refer to [GW-16. "Removal and Installation"](#).
4. Remove door side grommet, and remove door key cylinder assembly (driver side) and outside handle escutcheon (passenger side) bolts (TORX T30) from grommet hole.




5. Disconnect door antenna and door request switch connector and remove harness clamp.



6. Disconnect the key cylinder rod.
7. Disconnect door key cylinder switch harness connector.
8. While pulling the outside handle (1), remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side) (2).



9. Disconnect front door request switch harness connector.
10. While pulling outside handle (1), slide toward rear of vehicle (2) to remove outside handle.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

DOOR LOCK


[COUPE]

< ON-VEHICLE REPAIR >


11. Remove the front gasket and rear gasket.




12. Remove the TORX bolts (T30), remove the door lock assembly.



13. Remove the TORX bolt (T30) (A) from the outside handle bracket.



14. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.




15. Disconnect the door lock actuator connector and remove the door lock assembly.

DOOR LOCK

[COUPE]

< ON-VEHICLE REPAIR >

16. Disconnect the outside handle cable from the outside handle bracket connection.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing the key cylinder rod be sure to rotate the key cylinder rod holder until a click is felt.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK LID

TRUNK LID ASSEMBLY

TRUNK LID ASSEMBLY : Removal and Installation

INFOID:000000005429077

REMOVAL

1. Remove the trunk lid lock. Refer to [DLK-226, "TRUNK LID LOCK : Removal and Installation"](#).
2. Disconnect the harness clips and pull the harness out of the trunk lid.
3. Remove the bolts and the trunk lid assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the hinge bolts.
- After installing, check operation.
- After installing, perform fitting adjustment. Refer to [DLK-225, "TRUNK LID ASSEMBLY : Adjustment"](#).

TRUNK LID



[COUPE]

< ON-VEHICLE REPAIR >


TRUNK LID ASSEMBLY : Adjustment

INFOID:000000005429078


SEC. 843




A-A




B-B



C-C



D-D



AWKIA0449GB

- 1. Trunk lid assembly
- 4. Rear bumper fascia

- 2. Body side outer
- 3. Rear combination lamp
- 5. Trunk lid hinge assembly
- 6. Trunk lid latch assembly

- 1. Trunk lid assembly
- 4. Rear bumper fascia

↩ Front

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

TRUNK LID

< ON-VEHICLE REPAIR >

[COUPE]

Unit: mm (in)

Section	Item	Measurement	Standard	Parallelism	Right/Left Difference
A – A	E	Clearance	$4.0 \pm 1.6 (0.16 \pm 0.06)$	1.5 (0.06) MAX	2.0 (0.08) MAX
	F	Surface height	$-0.5 \pm 1.5 (-0.02 \pm 0.06)$	1.5 (0.06) MAX	2.0 (0.08) MAX
B – B	G	Clearance	$4.0 \pm 1.5 (0.16 \pm 0.06)$	1.5 (0.06) MAX	2.0 (0.08) MAX
	H	Surface height	$-0.5 \pm 1.5 (-0.02 \pm 0.06)$	1.5 (0.06) MAX	2.0 (0.08) MAX
C – C	J	Clearance	$4.0 \pm 2.0 (0.16 \pm 0.08)$	1.5 (0.06) MAX	2.0 (0.08) MAX
D – D	K	Clearance	$7.5 \pm 2.3 (0.30 \pm 0.09)$	2.3 (0.09) MAX	—

LONGITUDINAL CLEARANCE

1. Check the clearance and the evenness between the trunk lid and each part by visual and tactile feeling.
2. Loosen the trunk lid to hinge bolts.
3. Move the trunk lid so that the clearance measurements are within specifications.
4. Tighten the trunk lid to hinge bolts.

SURFACE HEIGHT ADJUSTMENT

1. Loosen the striker bolts.
2. Lift up the trunk lid approx. 100 - 150 mm (3.94 - 5.91 in) height then close it lightly. Make sure it engages firmly with the trunk lid closed.
3. Finally tighten the trunk lid striker.

TRUNK LID LOCK

TRUNK LID LOCK : Removal and Installation

INFOID:000000005429079

LOCK

Removal

1. Remove the trunk lid inner trim panel (if equipped). Refer to [INT-21, "Removal and Installation"](#).
2. Remove the bolts, disconnect the electrical connector, separate the emergency release handle, and remove the trunk lid lock.

Installation

Installation is in the reverse order of removal.

Striker

Removal

1. Remove the trunk end finisher. Refer to [INT-21, "Removal and Installation"](#).
2. Remove the bolts and the striker.

Installation

Installation is in the reverse order of removal.

NOTE:

Align the trunk lid lock. Refer to [DLK-225, "TRUNK LID ASSEMBLY : Adjustment"](#).

FUEL FILLER LID


< ON-VEHICLE REPAIR >

[COUPE]

FUEL FILLER LID

Exploded View

INFOID:000000005429080



- 1. Fuel door latch
 - 2. Cable protector
 - 3. Fuel door opener cable
 - 4. Fuel door opener handle
- ⇐ Front

Removal and Installation

INFOID:000000005429081

DLK

REMOVAL

1. Remove the front LH kicking plate. Refer to [INT-13, "Exploded View"](#).
2. Remove the rear seat. Refer to [SE-29, "Removal and Installation"](#).
3. Remove the LH front seat belt anchor. Refer to [SB-6, "Exploded View"](#).
4. Remove the LH rear lower finisher. Refer to [INT-13, "Exploded View"](#).
5. Position the carpet aside.
6. Remove the LH trunk side finisher. Refer to [INT-20, "Exploded View"](#).
7. Remove the fuel door opener handle and disconnect the fuel door opener cable.
8. Remove the fuel door latch and disconnect the fuel door opener cable.
9. Remove the fuel door opener cable.

INSTALLATION

Installation is in the reverse order of removal.

REMOTE KEYLESS ENTRY RECEIVER

< ON-VEHICLE REPAIR >

[COUPE]


REMOTE KEYLESS ENTRY RECEIVER

Removal

INFOID:000000005429082

REMOVAL

1. Remove glove compartment. Refer to [IP-11, "Removal and Installation"](#).
2. Remove the screw (a), lower the bracket and remote keyless entry receiver (1), then disconnect the harness and remove the receiver.



Installation

INFOID:000000005429083

Installation is in the reverse order of removal.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[SEDAN WITH INTELLIGENT KEY]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005429084

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DETAILED FLOW

JMKIA2270GB

DIAGNOSIS AND REPAIR WORKFLOW

[SEDAN WITH INTELLIGENT KEY]

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT-III.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3

Symptom is described, DTC is not displayed>>GO TO 4

Symptom is not described, DTC is displayed>>GO TO 5

3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5

4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [DLK-372. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check. If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

Yes >> GO TO 7

No >> Refer to [GI-41. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to SYMPTOM TABLE based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

[SEDAN WITH INTELLIGENT KEY]

< BASIC INSPECTION >

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

Is malfunctioning part detected?

YES >> GO TO 8

NO >> Check voltage of related BCM terminals using CONSULT-III.

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9

9. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is the inspection result normal?

NO (DTC is detected)>>GO TO 7

NO (Symptom remains)>>GO TO 6

YES >> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[SEDAN WITH INTELLIGENT KEY]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005429085

Perform the system initialization when replacing BCM, replacing Intelligent Key or registering an additional Intelligent Key.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005429086

Refer to the CONSULT-III Operation Manual for the initialization procedure.

AUTOMATIC DOOR LOCKS


< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

FUNCTION DIAGNOSIS

AUTOMATIC DOOR LOCKS

System Diagram



System Description

INFOID:000000005429088

Input	Single	Function	Actuator
Door lock/unlock switch	Door lock/unlock signal	Door lock function	• Each door lock actuator
Door key cylinder switch			
Each door switch	Door open/close signal	Key reminder function	
Key slot	Key insert/remove signal		
Combination meter	Warning buzzer signal	Automatic door lock/unlock function	
	Vehicle speed signal		

DOOR LOCK FUNCTION

- The door lock and unlock switch (driver side) is build into power window main switch.
- The door lock and unlock switch (passenger side) is on door trim.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Door Key Cylinder

- With the door key inserted in the door key cylinder on driver side, turning it to "LOCK", will lock door lock actuator of all doors.
- With the door key inserted in the door key cylinder on driver side, turning it to "UNLOCK" once unlocks the driver side door lock actuator; turning it to "UNLOCK" again within 60 seconds after the first unlock operation unlocks all of the other doors. - (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using "DOOR LOCK-UNLOCK SET" mode in "WORK SUPPORT". Refer to [DLK-276. "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

AUTOMATIC DOOR LOCKS (LOCK OPERATION)

The automatic door locks function is the function that locks all doors linked with the vehicle speed or shift position.

Vehicle Speed Sensing Auto Door Lock*1

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

AUTOMATIC DOOR LOCKS

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

If a door is opened and closed at any time during one ignition cycle (OFF → ON), even after initial auto door lock operation has taken place, the BCM will relock all doors when the vehicle speed reaches 24 km/h (15 MPH) or more again.

Setting change of Automatic Door Locks (LOCK) Function

The LOCK operation setting of the automatic door locks function can be changed.

With CONSULT-III

The ON/OFF switching of the automatic door locks (LOCK) function and the type selection of the automatic door locks (LOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-276, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (LOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the ignition switch ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

AUTOMATIC DOOR LOCKS (UNLOCK OPERATION)

The automatic door locks (UNLOCK) function is the function that unlocks all doors linked with the key position or shift position.

IGN OFF Interlock Door Unlock*1

All doors are unlocked when the power supply position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

Setting change of Automatic Door Locks (UNLOCK) Function

The UNLOCK operation setting of the automatic door locks function can be changed.

With CONSULT- III

The ON/OFF switching of the automatic door locks (UNLOCK) function and the type selection of the automatic door locks (UNLOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-276, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (UNLOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power supply position ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

*1: This function is set to ON before delivery.


AUTOMATIC DOOR LOCKS

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Component Parts Location

INFOID:000000005429089



- | | | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. BCM M16, M17, M18, M21
(view with instrument panel removed)</p> <p>4. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108</p> <p>7. Rear door lock actuator LH D205
Rear door lock actuator RH D305</p> | <p>2. Main power window and door lock/unlock switch D8, D12 (with left front only power window anti-pinch system)
Main power window and door lock/unlock switch D7, D8 (with left and right front power window anti-pinch system)</p> <p>5. Front door switch LH B8
Front door switch RH B108</p> <p>8. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28</p> | <p>3. Power window and door lock/unlock switch RH D110 (with left front only power window anti-pinch system)
Power window and door lock/unlock switch RH D105 (with left and right front power window anti-pinch system)</p> <p>6. Rear door switch LH B18
Rear door switch RH B116</p> <p>9. Combination meter M24</p> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

ALKIA1733ZZ

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTOMATIC DOOR LOCKS

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Component Description

INFOID:000000005429090

Item	Function
BCM	Controls the door lock function and fuel lid door lock actuator function.
Door lock and unlock switch	Input lock or unlock signal to BCM.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Door key cylinder switch	<ul style="list-style-type: none">• Input lock or unlock signal to power window main switch.• Power window main switch transmits door lock/unlock signal to BCM.
Key slot	Input key insert/remove signal to BCM.
Combination meter	<ul style="list-style-type: none">• Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer.• Transmits vehicle speed signal to CAN communication line.
Push-button ignition switch	Input push-button ignition switch ON/OFF condition to BCM.

DOOR LOCK FUNCTION


< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

DOOR LOCK FUNCTION

DOOR LOCK AND UNLOCK SWITCH

DOOR LOCK AND UNLOCK SWITCH : System Diagram



DOOR LOCK AND UNLOCK SWITCH : System Description

INFOID:0000000005429092

Switch	Input/output signal to BCM	BCM function	Actuator
Main power window and door lock/unlock switch	Door lock/unlock signal	Door lock/unlock control	Door lock actuator
Power window and door lock/unlock switch			
Door key cylinder switch			

DOOR LOCK FUNCTION

Functions Available by Operating the Door Lock and Unlock Switches on Driver Door and Passenger Door

- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all door lock actuators are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all door lock actuators are unlocked.

Functions Available by Operating the Key Cylinder Switch on Driver Door

- Interlocked with the locking operation of door key cylinder, door lock actuators of all door lock actuators are locked.

Selective Unlock Operation

- When door key cylinder is unlocked, door lock actuator driver side is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

Select unlock operation mode can be changed using DOOR LOCK-UNLOCK SET mode in "WORK SUPPORT". Refer to [DLK-276, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Key Reminder System

Refer to [DLK-270, "System Description"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

DOOR LOCK AND UNLOCK SWITCH : Component Parts Location

INFOID:000000005429093



ALKIA0079ZZ

- | | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. BCM M16, M17, M18, M21
(view with instrument panel removed)</p> | <p>2. Main power window and door lock/unlock switch D8, D12 (with left front only power window anti-pinch system)
Main power window and door lock/unlock switch D7, D8 (with left and right front power window anti-pinch system)</p> | <p>3. Power window and door lock/unlock switch RH D110 (with left front only power window anti-pinch system)
Power window and door lock/unlock switch RH D105 (with left and right front power window anti-pinch system)</p> |
| <p>4. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108</p> | <p>5. Front door switch LH B8
Front door switch RH B108</p> | <p>6. Rear door switch LH B18
Rear door switch RH B116</p> |
| <p>7. Rear door lock actuator LH D205
Rear door lock actuator RH D305</p> | <p>8. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28</p> | |

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

DOOR LOCK AND UNLOCK SWITCH : Component Description


INFOID:000000005429094

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Transmits lock or unlock signal to BCM.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Transmits door open/close condition to BCM.

DOOR REQUEST SWITCH

DOOR REQUEST SWITCH : System Diagram

INFOID:000000005429095



DOOR REQUEST SWITCH : System Description

INFOID:000000005429096

Only when pressing the request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communications between the Intelligent Key and the vehicle (BCM).

CAUTION:

The driver should always carry the Intelligent Key

- If an action that does not meet the operating conditions of the Intelligent Key system is taken, the buzzer goes off to inform the driver (Warning chime function).
- When a door lock is locked, unlocked or trunk open with request switch or remote controller button operation, the hazard lamps flash and the Intelligent Key warning buzzer or horn sounds (Hazard and buzzer/horn reminder function).
- The settings for each function can be changed with the CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with the CONSULT-III.

OPERATION DESCRIPTION/DOOR LOCK/UNLOCK

- When the BCM detects that each door request switch is pressed, it starts the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM sends the door lock/unlock signal and sounds Intelligent Key buzzer warning (lock: 2 time, unlock: 1 times) at the same time as a reminder.

OPERATION CONDITION

A
B
C
D
E
F
G
H
I
J
DLK

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >


If the following conditions are not satisfied, door lock/unlock operation is not performed even if the request switch is operated.

Each request switch operation	Operation condition
Lock operation	<ul style="list-style-type: none"> • All doors are closed • Ignition switch is in OFF position • Intelligent Key is out of key slot • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area
Unlock Operation	<ul style="list-style-type: none"> • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area *

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver and passenger door handles (1).



SELECTIVE UNLOCK FUNCTION

When an LOCK signal is sent from door request switch (driver side or passenger side), all doors will be locked. When an UNLOCK signal is sent from door request switch (driver side or passenger side) once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from door request switch (driver side and passenger side) again within 5 seconds, all other door will be unlocked.

HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, or trunk opening operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, IPDM E/R honks Intelligent Key warning buzzer as a reminder and transmits hazard request signal to BCM via CAN communication line.

BCM flashes hazard warning lamps as a reminder.

Operating function of hazard warning lamps and buzzer reminder

Operation	Hazard warning lamps flash	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice
Trunk open	—	Four times

How to change hazard and buzzer reminder mode

Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

AUTO DOOR LOCK FUNCTION

When all doors are locked, ignition switch is in OFF position and key switch is OFF (Intelligent Key is not inserted in key slot), doors are unlocked with door request switch

When BCM does not receive the following signals within 60 seconds, all doors are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON (ignition switch is pressed)
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by "AUTO LOCK SET" mode in "WORK SUPPORT". Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

ROOM LAMP OPERATION

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

When the following conditions are met:

- Condition of interior lamp switch is in DOOR position
- Door switch OFF (all the doors are closed)

Intelligent Key system turns on interior lamp (for up to 30 seconds maximum) by receiving UNLOCK signal from door request switch. For detailed description, refer to [DLK-237, "DOOR LOCK AND UNLOCK SWITCH : System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Door lock function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Door request switch (Driver, Passenger)	Door lock actuator	Inside key antenna	Outside key antenna (Driver, Passenger)	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamp	Push-button ignition switch
Door lock/unlock function by request switch	×	×	×	×	×	×	×	×		×	×		
Hazard and buzzer reminder function for door lock/unlock operation									×	×	×	×	
Key reminder function	×	×	×	×	×	×	×	×	×	×	×	×	
Selective unlock function by request switch (Driver side)	×				×	×	×	×		×	×		
Selective unlock function by request switch (Passenger side)	×				×	×	×	×		×	×		
Auto door lock function	×	×		×	×	×				×	×		×

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK



DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

DOOR REQUEST SWITCH : Component Parts Location

INFOID:000000005429097




ABK1A2282Z

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABK1A2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

- 19. Rear parcel shelf antenna B29
- 20. Trunk opener request switch B33
- 21. Rear bumper antenna B46
- 22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28

DOOR REQUEST SWITCH : Component Description


INFOID:000000005429098

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Transmits lock or unlock signal to BCM.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Transmits door open/close condition to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Request switch	Transmits lock/unlock operation to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

INTELLIGENT KEY

INTELLIGENT KEY : System Diagram

INFOID:000000005429099



INTELLIGENT KEY : System Description

INFOID:000000005429100

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION DESCRIPTION/DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal is transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- When BCM receives the door lock/unlock signal, it operates door lock actuator, flashes the hazard lamp (lock: 2 time, unlock: 1 times) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 time) as a reminder

OPERATION CONDITION

Remote controller operation	Operation condition	Operation
Lock	<ul style="list-style-type: none"> • All doors closed 	All doors lock
Unlock	<ul style="list-style-type: none"> • Intelligent Key is out of key slot 	All doors unlock

OPERATION AREA

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

- Operating Range
- To ensure the Intelligent Key works effectively, use within 80 cm range of each doors, however the operable range may differ according to surroundings. The remote control operation range is greater than that of the Intelligent Key. Refer to Owner's Manual for more details.

SELECTIVE UNLOCK FUNCTION

When a LOCK signal is transmitted from Intelligent Key, all doors will be locked.

When an UNLOCK signal is transmitted from Intelligent Key once, driver's door will be unlocked.

Then, if an UNLOCK signal is transmitted from Intelligent Key again within 5 seconds, all other doors will be unlocked.

HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM flashes hazard warning lamps as a reminder and sends horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating function of hazard and horn reminder

	C mode			S mode		
	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Intelligent Key operation	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Hazard warning lamp flash	Twice	Once	—	Twice	—	—
Horns sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if any door switch is ON (any door is OPEN).

How to change hazard and horn reminder mode

With CONSULT-III

Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Without CONSULT-III

Refer to Owner's Manual for instructions.

AUTO DOOR LOCK FUNCTION

Auto Door Lock Function

When all doors are locked, ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), doors are unlocked with Intelligent Key button. When BCM does not receive the following signals within 60 seconds, all doors are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by DOOR LOCK-UNLOCK SET mode in "WORK SUPPORT". Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

PANIC ALARM FUNCTION

When ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), BCM receives PANIC ALARM signal from Intelligent Key.

BCM turns on and off headlamp intermittently and transmits theft warning horn signal to IPDM E/R. Then, IPDM E/R turns on and off horn intermittently.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off:

- After 25 seconds
- When BCM receives any signal from Intelligent Key

Panic alarm function mode can be changed by PANIC ALARM SET mode in "WORK SUPPORT". Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

KEYLESS POWER WINDOW DOWN (OPEN) FUNCTION

Front power windows (with left and right front power window anti-pinch system) open when the unlock button on Intelligent Key is activated and kept pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, Keyless power window down (open) function cannot be operated.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Keyless power window down operation mode can be changed by PW DOWN SET mode in "WORK SUPPORT". Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

ROOM LAMP ILLUMINATION OPERATION

When the following conditions are met:

- Condition of interior lamp switch is in DOOR position
- Door switch OFF (all the doors are closed)

Intelligent Key system turns on interior lamp (for 15 seconds) by receiving UNLOCK signal from Intelligent Key. For detailed description, refer to [DLK-244, "INTELLIGENT KEY : System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Key slot	Door request switch (Driver, Passenger)	Door switch	Door lock actuator	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	Horn	IPDM E/R	Head lamp
Door lock/unlock function by remote control button	×	×		×	×		×	×					
Hazard and horn reminder function	×					×	×	×	×	×	×	×	
Selective unlock function	×			×	×		×	×					
Keyless power window down (open) function	×	×					×	×					
Auto door lock function	×	×		×			×	×					
Panic alarm function	×	×	×				×	×	×		×	×	×



DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

INTELLIGENT KEY : Component Parts Location

INFOID:000000005783199




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABKIA2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

DOOR LOCK FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

- 19. Rear parcel shelf antenna B29
- 20. Trunk opener request switch B33
- 21. Rear bumper antenna B46
- 22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28

INTELLIGENT KEY : Component Description

INFOID:000000005429102

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Intelligent key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK OPEN FUNCTION


< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK OPEN FUNCTION TRUNK LID OPENER SWITCH

TRUNK LID OPENER SWITCH : System Diagram

INFOID:000000005429103



ALKIA0180GB

TRUNK LID OPENER SWITCH : System Description

INFOID:000000005429104

Switch	Input/output signal to BCM	BCM function	Actuator
Trunk lid opener switch	Trunk open signal	Trunk open control	Trunk lid opener actuator
Trunk lid opener cancel switch			

TRUNK LID OPENER OPERATION

When trunk lid opener switch is ON, BCM opens trunk opener actuator.

BCM can open trunk lid opener actuator when

- vehicle speed is less than 5 km/h (3MPH)
- vehicle security system is disarmed or pre-armed phase

BCM does not open trunk lid opener actuator when

- trunk lid opener cancel switch is OFF (CANCEL)
- vehicle speed is more than 5 km/h (3MPH)
- vehicle security system is armed or alarm phase
- Within 3 seconds of removing the Intelligent Key from the key slot


TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK LID OPENER SWITCH : Component Parts Location

INFOID:000000005429105



- 1. BCM M16, M17, M18, M20, M21
- 2. Trunk lid opener switch M75
- 3. Trunk lid opener cancel switch M74
- 4. Trunk lamp switch and trunk release solenoid (trunk release solenoid) B28

TRUNK LID OPENER SWITCH : Component Description

INFOID:000000005429106

Item	Function
BCM	Transmits trunk open operation to BCM.
Trunk lid opener switch	Transmits trunk open operation to BCM.
Trunk release solenoid	Opens the trunk with the open signal from BCM
Trunk lid opener cancel switch	Cancels the trunk open operation.

TRUNK REQUEST SWITCH

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK


TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK REQUEST SWITCH : System Diagram

INFOID:000000005429107



ALKIA0181GB

TRUNK REQUEST SWITCH : System Description

INFOID:000000005429108

Only when pressing the request switch, it is possible to open the trunk by carrying the Intelligent Key.

- The Intelligent Key system is a system that makes it possible to open the trunk (trunk open function) by carrying the Intelligent Key which operates based on the results of electronic ID verification using two-way communications between the Intelligent Key and the vehicle (BCM).

CAUTION:

The driver should always carry the Intelligent Key

- If an action that does not meet the operating conditions of the Intelligent Key system is taken, the buzzer goes off to inform the driver (warning chime functions).
- When trunk is opened with request switch or remote controller button operation, the hazard lamps flash and the Intelligent Key warning buzzer or horns sound (hazard and buzzer/horn reminder function).
- The settings for each function can be changed with the CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with the CONSULT-III.

OPERATION DESCRIPTION/TRUNK OPEN

- When the BCM detects that trunk open request switch is pressed, it starts the outside key antenna (trunk room) and inside key antenna corresponding to the pressed trunk open request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the trunk.
- If the Intelligent Key is within the outside key antenna (trunk room) detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM transmits the trunk open request signal and sounds Intelligent Key warning buzzer 4 consecutive times.
- When BCM receives the trunk open request signal, it operates the trunk release solenoid and opens the trunk.

OPERATION CONDITION

If the following conditions are not satisfied, trunk open operation is not performed even if the request switch is operated.

Each request switch operation	Operation condition
Trunk open operation	<ul style="list-style-type: none"> • Intelligent Key is within outside key antenna (trunk room) detection area* • Trunk cancel switch is ON • Key reminder functions operate (trunk)

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.


OUTSIDE KEY ANTENNA DETECTION AREA

TRUNK OPEN FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

The outside key antenna detection area of trunk open function is in the range of approximately 80 cm (31.50 in) surrounding trunk opener request switch (1). However, this operating range depends on the ambient conditions.



KEY REMINDER FUNCTION

Key reminder function	Operation condition	Operation
Trunk is closed	Right after trunk is closed under the following conditions <ul style="list-style-type: none"> • Intelligent Key is inside trunk room • All doors are closed • All doors are locked 	<ul style="list-style-type: none"> • Trunk open • Sound Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob, it might activate the door locks accidentally but unlock operation will be performed at these cases.

CAUTION:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function will not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.
- The key reminder function is operated when the trunk is opened/closed and the buzzers sound. If the following operations are performed, the key reminder function is cleared and buzzer sounds are stopped.
 - Remote controller door lock button operation of Intelligent Key
 - Remote controller door unlock button operation of Intelligent Key
 - When the trunk is closed, the Intelligent Key is not inside the vehicle
 - When any door is open

HAZARD AND BUZZER REMINDER FUNCTION

During trunk opening operation by request switch, the hazard warning lamps and Intelligent Key warning buzzer will flash or sound as a reminder.

When trunk open by each request switch, IPDM E/R sounds Intelligent Key warning buzzer as a reminder and transmits hazard request signal to BCM via CAN communication line.

BCM flashes hazard warning lamps as a reminder.

Operating function of hazard and buzzer reminder

Operation	Hazard warning lamp flash	Intelligent Key warning buzzer sounds
Trunk open	—	Four times

How to change hazard and buzzer reminder mode

🔑 With CONSULT-III

Refer to [DLK-276. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Trunk open function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Trunk room lamp switch	Trunk opener request switch	Trunk release solenoid	Inside key antenna	Outside key antenna (Trunk)	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamps	Trunk lid opener cancel switch
Trunk open function by the trunk opener request switch	×		×		×	×	×	×	×		×	×		×
Hazard and buzzer reminder function for door lock/unlock operation										×	×	×	×	
Buzzer reminder for trunk open operation										×	×	×		
Key reminder function	×	×	×	×				×	×	×	×	×	×	



TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK REQUEST SWITCH : Component Parts Location

INFOID:000000005783198




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKTA2282Z

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABKIA2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

TRUNK OPEN FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

- 19. Rear parcel shelf antenna B29
- 20. Trunk opener request switch B33
- 21. Rear bumper antenna B46
- 22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28

TRUNK REQUEST SWITCH : Component Description


INFOID:000000005429110

Item	Function
BCM	Controls trunk open function.
Trunk release solenoid	Transmits trunk open operation to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Trunk opener request switch	Transmits trunk open operation to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

INTELLIGENT KEY

INTELLIGENT KEY : System Diagram

INFOID:000000005429111



INTELLIGENT KEY : System Description

INFOID:000000005429112

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the trunk open button.

OPERATION DESCRIPTION/TRUNK OPEN FUNCTION

- When trunk button of the Intelligent Key is pressed, the trunk open signal is transmitted from the Intelligent Key to the BCM via remote keyless entry receiver.
- When BCM receives the trunk open request signal, it operates the trunk lid opener actuator and opens the trunk.

OPERATION CONDITION

Remote controller operation	Operation condition	Operation
Trunk open	• Press and hold the trunk open button for 0.5 second or more	Trunk open

OPERATION AREA

- To ensure the Intelligent Key works effectively, use within 80 cm (31.50 inches) range of each door, however the operable range may differ according to surroundings.

HAZARD AND HORN REMINDER FUNCTION

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

When doors are locked or unlocked by Intelligent Key, BCM flashes hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sound horns as a reminder.
The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating function of hazard and horn reminder

	C mode			S mode		
	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Intelligent Key operation	Twice	Once	—	Twice	—	—
Hazard warning lamp flash	Twice	Once	—	Twice	—	—
Horn sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if any door switch is ON (any door is OPEN).

How to change hazard and horn reminder mode

Ⓟ With CONSULT-III

Refer to [DLK-276, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

ⓧ Without CONSULT-III

Refer to Owner's Manual for instructions.

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Key slot	Trunk room lamp switch	Trunk release solenoid	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamps	Horns	IPDM E/R
Trunk open function by remote control button	×	×	×	×		×	×				
Hazard and horn reminder function	×				×	×	×	×	×	×	×



TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

INTELLIGENT KEY : Component Parts Location

INFOID:000000005783197




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABKIA2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

19. Rear parcel shelf antenna B29 20. Trunk opener request switch B33 21. Rear bumper antenna B46
22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28

A

INTELLIGENT KEY : Component Description

INFOID:000000005429114

B

Item	Function
BCM	Controls trunk open function.
Trunk release solenoid	Opens the trunk with the open signal from BCM.
Remote keyless entry receiver	Receives trunk open signal from the Intelligent Key, and then transmits to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with a buzzer sound.

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

WARNING FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

WARNING FUNCTION

System Description

INFOID:000000005429115

OPERATION DESCRIPTION

The warning functions are as follows and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, KEY warning lamp, key slot illumination and combination meter display in combination meter.

- Intelligent Key system malfunction
- OFF position warning
- P position warning
- ACC warning
- Take away warning
- Door lock operation warning
- Key warning
- Intelligent Key insert information
- Engine start information
- Intelligent key low battery warning
- Key ID warning

OPERATION CONDITION

Once the following condition from below is established, alert or warning will be executed.

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM, "KEY" warning lamp will illuminate.
OFF position warning	For internal	<ul style="list-style-type: none"> • Ignition switch: ACC position. • Door switch (driver side): ON (Door is open).
	For external	<p>OFF position warning (For internal) is in active mode, driver side door has been closed.</p> <p>NOTE: OFF position (For external) active only when each of the sequence has occurred as below: P position warning → ACC warning → OFF position warning (For internal) → OFF position warning (For internal)</p>
P position warning		<ul style="list-style-type: none"> • Shift position: Except P position • Engine is running to stopped (Ignition switch is ON to OFF)
ACC warning		<ul style="list-style-type: none"> • During P position warning is in active mode, shift position has changed P position. • Ignition switch: Except OFF position.
Take away warning	Door is open to close	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Door switch: ON to OFF (Door is open to close). • Intelligent Key can not be detected inside the vehicle.
	Door is open	<ul style="list-style-type: none"> • Door switch: ON (Door is open) • Key ID verification every 5 seconds when registered Intelligent Key can not be detected inside the vehicle.
	Push-ignition switch operation	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Press ignition switch. • Intelligent Key can not be detected inside the vehicle.
	Take away through window	<ul style="list-style-type: none"> • Engine is running. • Key ID verification every 30 seconds when registered Intelligent Key can not be detected inside the vehicle. • After vehicle speed verification, the registered Intelligent Key can not be detected inside the vehicle.
	Intelligent Key is removed from key slot	<ul style="list-style-type: none"> • When Intelligent Key is removed from key slot, Intelligent Key can not be detected inside the vehicle.

WARNING FUNCTION

< FUNCTION DIAGNOSIS >



[SEDAN WITH INTELLIGENT KEY]

Warning/Information functions		Operation procedure
Door lock operation warning	Request switch operation	When request switch is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • Door switch: ON (Any door is open). • Intelligent Key is inside vehicle.
	Intelligent Key button operation	When Intelligent Key button is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • Door switch: ON (Any door is open). • For 3 seconds after Intelligent Key is removed from key slot.
Key warning		<ul style="list-style-type: none"> • Ignition switch is OFF position. • Driver side door switch: ON (Driver side door is open). • Intelligent Key is inserted in key slot.
Intelligent Key insert information		<ul style="list-style-type: none"> • Door switch: ON to OFF (Door is open to close). • Ignition switch: OFF to ON position. • Intelligent Key is out of key slot. • Intelligent Key can not be detected inside the vehicle.
Engine start information	Ignition switch is ON position	<ul style="list-style-type: none"> • Ignition switch: ON position. • Shift position: P position • Engine is stopped
	Ignition switch is except ON position	<ul style="list-style-type: none"> • Ignition switch: Except ON position. • Shift position: P position • Intelligent Key is inserted in key slot. • Intelligent Key can be detected inside the vehicle.
Intelligent Key low battery warning		When Intelligent Key has low battery, it is detected by BCM after ignition switch is turned ON.
Key ID warning		When registered intelligent Key cannot be detected inside the vehicle after ignition switch is turned ON.

WARNING METHOD

The following table shows the alarm or warning methods with chime.





Meter display, "KEY" indicator or key slot illumination when the warning conditions are met.

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction		Illuminate	—	—	—	—
OFF position warning	For internal	—	—	—	Activate	—
	For external	—	—	—	—	Activate
P position warning		—	 <small>JMKIA0037GB</small>	—	Activate	—
ACC warning		—	 <small>JMKIA0047GB</small>	—	Activate	—

WARNING FUNCTION

< FUNCTION DIAGNOSIS >




[SEDAN WITH INTELLIGENT KEY]

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Take away warning	Door is open to close	—	 <small>JMKIA0036GB</small>	Flash	Activate	Activate
	Door is open	—		Flash	—	—
	Push-ignition switch operation	—		Flash	Activate	—
	Take away through window	—		Flash	Activate	—
	Intelligent Key is removed from key slot	—		Flash	—	—
Door lock operation warning	Request switch operation	—	—	—	—	Activate
	Intelligent Key operation	—	—	—	—	Activate
Key ID warning		—	 <small>JMKIA0036GB</small>	—	—	—
Key warning		—	 <small>JMKIA0035GB</small>	Flash	Activate	—
Intelligent Key insert information		—	 <small>JMKIA0034GB</small>	Flash	—	—

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Warning/Information functions		"KEY" warning lamp	Combination meter display	Key slot illumination	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Engine start information	Automatic transmission models	—	 <small>JMKIA0032GB</small>	—	—	—
	Manual transmission models	—	 <small>ALKIA1326GB</small>	—	—	—
Intelligent Key low battery warning		—	 <small>JMKIA0048GB</small>	—	—	—

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Park position switch	"KEY" warning lamp
		Intelligent Key system malfunction											×	×		
OFF position warning	For internal				×					×	×	×				
	For external				×				×		×	×				
P position warning				×						×	×	×	×		×	
ACC warning				×						×	×	×	×		×	
Take away warning	Door is open or close	×			×		×		×	×	×	×	×	×		
	Door is open	×			×		×				×	×	×	×		
	Push-ignition switch operation	×		×			×		×	×	×	×	×	×		
	Take away through window	×					×		×	×	×	×	×	×		
Intelligent Key is removed from key slot		×	×				×				×	×	×	×		

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Warning function		Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Park position switch	"KEY" warning lamp
Door lock operation warning		×	×		×	×	×	×	×		×	×				
Key ID warning		×	×	×			×				×	×	×			
Key warning		×	×		×					×	×	×	×	×		
Intelligent Key insert information		×	×	×	×		×				×	×	×	×		
Engine start information	Ignition switch is ON position	×	×	×			×				×	×	×		×	
	Ignition switch is except ON position	×	×	×			×				×	×	×			
Intelligent Key low battery warning		×					×				×	×	×			



WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Component Parts Location

INFOID:000000005783196




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABKIA2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

WARNING FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

- | | | |
|--------------------------------------------------------------------------|-------------------------------------|-----------------------------|
| 19. Rear parcel shelf antenna B29 | 20. Trunk opener request switch B33 | 21. Rear bumper antenna B46 |
| 22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28 | | |

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

KEY REMINDER FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

KEY REMINDER FUNCTION

System Description

INFOID:000000005429117

Key reminder is the function that prevents the key from being left in the vehicle. Key reminder has the following 3 functions.

Key reminder function	Operation condition	Operation
Driver door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none">• Door lock operation is performed• Driver side door is opened• Driver side door is in unlock state	All doors unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none">• Intelligent Key is inside the vehicle• Any door is opened• All doors are locked by door lock and unlock switch or door lock knob	<ul style="list-style-type: none">• All doors unlock• Sounds Intelligent Key warning buzzer
Trunk is closed	Right after trunk is closed under the following conditions <ul style="list-style-type: none">• Intelligent Key is inside trunk room• All doors are closed• All doors are locked	<ul style="list-style-type: none">• Trunk open• Sounds Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob, it might activate the door locks accidentally but unlock operation will be performed in these cases.

CAUTION:

- **The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function will not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.**
- **The key reminder function is operated when the trunk is open/closed and the buzzers sound. If the following operations are performed, the key reminder function is cleared and buzzers sounds are stopped.**
 - Remote controller door lock button operation of Intelligent Key
 - Remote controller door unlock button operation of Intelligent Key
 - When the trunk is closed, and the Intelligent Key is not inside the vehicle
 - When any door is open



KEY REMINDER FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Component Parts Location

INFOID:000000005783195




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

KEY REMINDER FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]



ABKIA2284ZZ

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| 1. Horn (low) E215
(view with front fender protector LH removed) | 2. Horn (high) E216
(view with front fender protector LH removed) | 3. IPDM E/R E17, E18 |
| 4. Fuse and fusible link box (horn relay H-1) | 5. Intelligent Key warning buzzer E74 | 6. Remote keyless entry receiver M27
(view with instrument panel removed) |
| 7. Trunk lid opener cancel switch M74 | 8. Combination meter M24 | 9. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) |
| 10. Stop lamp switch E38 (with CVT)
Stop lamp switch E52 (with M/T) | 11. Push button ignition switch M38 | 12. Key slot M40 |
| 13. Front console antenna M203
(view with center console assembly removed) | 14. Front outside handle LH (outside key antenna) D6
Front outside handle RH (outside key antenna) D106 | 15. Front outside handle LH (request switch) D6
Front outside handle RH (request switch) D106 |
| 16. Front door lock assembly LH D14 (with left front only power window anti-pinch system)
Front door lock assembly LH D10 (with left and right front power window anti-pinch system)
Front door lock actuator RH D108 | 17. Front door switch LH B8
Front door switch RH B108 | 18. Rear door switch LH B18
Rear door switch RH B116 |

KEY REMINDER FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

- | | | |
|--------------------------------------------------------------------------|-------------------------------------|-----------------------------|
| 19. Rear parcel shelf antenna B29 | 20. Trunk opener request switch B33 | 21. Rear bumper antenna B46 |
| 22. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28 | | |

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

HOMELINK UNIVERSAL TRANSCEIVER

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

HOMELINK UNIVERSAL TRANSCEIVER

Component Description

INFOID:000000005429119

Item	Function	Reference page
Homelink universal transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.	Refer to Owner's Manual

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : Diagnosis Description

INFOID:000000005783609

BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF DIAGNOSTIC RESULT	Displays the diagnosis results judged by BCM.
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system ¹	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioner	AIR CONDITONER		×	
Intelligent Key system ²	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
BCM	BCM	×		
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

1 : With remote keyless entry system

2: With intelligent Key system

COMMON ITEM : CONSULT-III Function

INFOID:000000005783610

ECU IDENTIFICATION

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Displays the BCM part No.

SELF-DIAG RESULT

Refer to [BCS-70, "DTC Index"](#).

DOOR LOCK

DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)

INFOID:000000005783611

WORK SUPPORT

Work Item	Description
DOOR LOCK-UNLOCK SET	<ul style="list-style-type: none">• ON• OFF
AUTOMATIC DOOR LOCK SELECT	<ul style="list-style-type: none">• P RANGE• VH SPD
AUTOMATIC DOOR UNLOCK SELECT	<ul style="list-style-type: none">• MODE1• MODE2• MODE3• MODE4
AUTOMATIC LOCK/UNLOCK SELECT	<ul style="list-style-type: none">• LOCK/UNLOCK• LOCK ONLY• UNLOCK ONLY• OFF

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW-DR [ON/OFF]	Indicates condition of door request switch LH
REQ SW-AS [ON/OFF]	Indicates condition of door request switch RH
REQ SW-BD/TR [ON/OFF]	Indicates condition of back door request switch
DOOR SW-DR [ON/OFF]	Indicates condition of front door switch LH
DOOR SW-AS [ON/OFF]	Indicates condition of front door switch RH
DOOR SW-RR [ON/OFF]	Indicates condition of rear door switch RH
DOOR SW-RL [ON/OFF]	Indicates condition of rear door switch LH
DOOR SW-BK [ON/OFF]	Indicates condition of back door switch
KEY CYL LK-SW [ON/OFF]	Indicates condition of lock signal from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Indicates condition of unlock signal from door key cylinder switch
CDL LOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [OTR ULK / AS UNLK / DR UNLK / ALL UNLK / ALL LCK].

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY)

INFOID:000000005783615

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Monitor item	Description
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode.
AUTO LOCK SET	Auto door lock time can be changed in this mode. <ul style="list-style-type: none"> • MODE1: 1 minute • MODE2: 5 minutes • MODE3: 30 seconds • MODE4: 2 minutes
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operate (ON) or not operate (OFF) in this mode.
ENGINE START BY I-KEY	Engine start function mode can be changed to operate (ON) or not operate (OFF) with this mode.
TRUNK/GLASS HATCH OPEN	Buzzer reminder function mode by back door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
PANIC ALARM SET	Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 0.5 sec. • MODE2: Non-operation • MODE3: 1.5 sec.
PW DOWN SET	Unlock button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 3 sec. • MODE2: Non-operation • MODE3: 5 sec.
TRUNK OPEN DELAY	Trunk button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE1: 0.5 sec. • MODE2: 1.5 sec. • MODE3: OFF: No delay
LO- BATT OF KEY FOB WARN	Intelligent Key low battery warning mode can be changed to operate (ON) or not operate (OFF) with this mode.
ANTI KEY LOCK IN FUNCTI	Key reminder function mode can be changed to operate (ON) or not operate (OFF) with this mode.
HAZARD ANSWER BACK	Hazard reminder function mode can be selected from the following with this mode. <ul style="list-style-type: none"> • LOCK ONLY: Door lock operation only • UNLOCK ONLY: Door unlock operation only • LOCK/UNLOCK: Lock/unlock operation • OFF: Non-operation
ANS BACK I-KEY LOCK	Buzzer reminder function (lock operation) mode by door request switch (driver side and passenger side) can be selected from the following with this mode. <ul style="list-style-type: none"> • Horn chirp: Sound horn • Buzzer: Sound Intelligent Key warning buzzer • OFF: Non-operation
ANS BACK I-KEY UNLOCK	Buzzer reminder function (unlock operation) mode by door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
SHORT CRANKING OUTPUT	Starter motor can be forcibly activated.
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis.
HORN WITH KEYLESS LOCK	Horn reminder function mode by Intelligent Key button can be changed to operate (ON) or not operate (OFF) with this mode.

SELF-DIAG RESULT

Refer to [DLK-373, "DTC Index"](#).

DATA MONITOR

Monitor Item	Condition
REQ SW -DR	Indicates [ON/OFF] condition of door request switch (driver side).
REQ SW -AS	Indicates [ON/OFF] condition of door request switch (passenger side).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Monitor Item	Condition
REQ SW -BD/TR	Indicates [ON/OFF] condition of back door request switch.
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY2 -F/B	Indicates [ON/OFF] condition of ignition relay 2.
ACC RLY-F/B	Indicates [ON/OFF] condition of accessory relay.
CLUCH SW*1	Indicates [ON/OFF] condition of clutch switch.
BRAKE SW 1	Indicates [ON/OFF]*2 condition of brake switch power supply.
BRAKE SW 2	Indicates [ON/OFF] condition of brake switch.
DETE/CANCL SW	Indicates [ON/OFF] condition of P position.
SFT PN/N SW	Indicates [ON/OFF] condition of P or N position.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
PUSH SW -IPDM	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY1 -F/B	Indicates [ON/OFF] condition of ignition relay 1.
DETE SW -IPDM	Indicates [ON/OFF] condition of P position.
SFT PN -IPDM	Indicates [ON/OFF] condition of P or N position.
SFT P -MET	Indicates [ON/OFF] condition of P position.
SFT N -MET	Indicates [ON/OFF] condition of N position.
ENGINE STATE	Indicates [STOP/STALL/CRANK/RUN] condition of engine states.
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [mph].
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [mph].
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver side door status.
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger side door status.
ID OK FLAG	Indicates [SET/RESET] condition of key ID.
PRMT ENG STRT	Indicates [SET/RESET] condition of engine start possibility.
KEY SW -SLOT	Indicates [ON/OFF] condition of key slot.
TRNK/HAT MNTR	Indicates [ON/OFF] condition of trunk lid.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from Intelligent Key.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key.
RKE-PANIC	Indicates [ON/OFF] condition of PANIC button of Intelligent Key.
RKE-P/W OPEN	Indicates [ON/OFF] condition of P/W DOWN signal from Intelligent Key.
RKE-MODE CHG	Indicates [ON/OFF] condition of MODE CHANGE signal from Intelligent Key.
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
REVERSE SW	Indicates [ON/OFF] condition of R position.

*1: It is displayed but does not operate on M/T models.

*2: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT-III screen is touched.
PW REMOTO DOWN SET	This test is able to check power window down operation. The power window down is activated after "ON" on CONSULT-III screen is touched.
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation. The Intelligent Key warning buzzer is activated after "ON" on CONSULT-III screen is touched.

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Test item	Description
INSIDE BUZZER	This test is able to check warning chime in combination meter operation. <ul style="list-style-type: none"> Take away warning chime sounds when "TAKE OUT" on CONSULT-III screen is touched. Key warning chime sounds when "KEY" on CONSULT-III screen is touched. OFF position warning chime sounds when "KNOB" on CONSULT-III screen is touched.
INDICATOR	This test is able to check warning lamp operation. <ul style="list-style-type: none"> "KEY" Warning lamp illuminates when "KEY ON" on CONSULT-III screen is touched. "KEY" Warning lamp blinks when "KEY IND" on CONSULT-III screen is touched.
INT LAMP	This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT-III screen is touched.
LCD	This test is able to check meter display information <ul style="list-style-type: none"> Engine start information displays when "BP N" on CONSULT-III screen is touched. Engine start information displays when "BP I" on CONSULT-III screen is touched. Key ID warning displays when "ID NG" on CONSULT-III screen is touched. P position warning displays when "SFT P" on CONSULT-III screen is touched. Intelligent Key insert information displays when "INSRT" on CONSULT-III screen is touched. Intelligent Key low battery warning displays when "BATT" on CONSULT-III screen is touched. Take away through window warning displays when "NO KY" on CONSULT-III screen is touched. Take away warning display when "OUTKEY" on CONSULT-III screen is touched. OFF position warning display when "LK WN" on CONSULT-III screen is touched.
FLASHER	This test is able to check hazard warning lamp operation. The hazard warning lamps are activated after "LH/RH/OFF" on CONSULT-III screen is touched.
HORN	This test is able to check horn operation. The horn is activated after "ON" on CONSULT-III screen is touched.
P RANGE	This test is able to check CVT shift selector power supply CVT shift selector power is supplied when "ON" on CONSULT-III screen is touched.
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation. Push-ignition switch illumination illuminates when "ON" on CONSULT-III screen is touched.
LOCK INDICATOR	This test is able to check LOCK indicator in push-ignition switch operation. LOCK indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.
ACC INDICATOR	This test is able to check ACC indicator in push-ignition switch operation. ACC indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.
IGNITION ON IND	This test is able to check ON indicator in push-ignition switch operation. ON indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.
KEY SLOT ILLUMI	This test is able to check key slot illumination operation. Key slot illumination blinks when "ON" on CONSULT-III screen is touched.
TRUNK/BACK DOOR	This test is able to check back door opener actuator open operation. This actuator opens when "OPEN" on CONSULT-III screen is touched.

A
B
C
D
E
F
G
H
I
J
K
L
M

DLK

TRUNK

TRUNK : CONSULT-III Function (BCM - TRUNK)

INFOID:0000000005783616

DATA MONITOR

Monitor Item	Contents
PUSH SW	Indicates [ON/OFF] condition of push button ignition switch.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
VEH SPEED 1	Indicates [mph] condition of vehicle speed signal from combination meter.
TR CANCEL SW	Indicates [ON/OFF] condition of trunk cancel switch.
TR/BD OPEN SW	Indicates [ON/OFF] condition of trunk opener switch.

N
O
P

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITH INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Monitor Item	Contents
TRNK/HAT MNTR	Indicates [ON/OFF] condition of trunk lid.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
TRUNK/GLASS HATCH	This test is able to check trunk open operation. Trunk opens when "OPEN" on CONSULT-III screen is touched.

U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000005429125

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-26, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:0000000005429126

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1000	CAN COMM CIRCUIT	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none">• Transmission• Receiving (ECM)• Receiving (VDC/TCS/ABS)• Receiving (METER/M&A)• Receiving (TCM)• Receiving (MULTI AV)• Receiving (IPDM E/R)

Diagnosis Procedure

INFOID:0000000005429127

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-8, "CAN Communication Control Circuit"](#).
NO >> Refer to [GI-41, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000005429128

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1010	CONTROL UNIT (CAN)	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:000000005429129

1. REPLACE BCM

When DTC [U1010] is detected, replace BCM.

>> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000005429130

1. REQUIRED WORK WHEN REPLACING BCM

Initialize NVIS by CONSULT-III. For the details of initialization refer to CONSULT-III Operation Manual.

>> Work End.

B2622 INSIDE KEY ANTENNA 2

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

B2622 INSIDE KEY ANTENNA 2

Description

INFOID:000000005429134

Detects whether Intelligent Key is inside the vehicle.
Installed in the console.

DTC Logic

INFOID:000000005429135

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none">• Front console antenna• Between BCM and front console antenna.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-III

1. Perform front console antenna INSIDE ANT DIAGNOSIS on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is front console antenna DTC detected?

- YES >> Refer to [DLK-283, "Diagnosis Procedure"](#).
NO >> Front console antenna is OK.


Diagnosis Procedure

INFOID:000000005429136

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



B2622 INSIDE KEY ANTENNA 2

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M19	Front console antenna	61	Ground	Place Intelligent Key inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
			Ground	Place Intelligent Key outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
 NO >> GO TO 2

2. CHECK FRONT CONSOLE ANTENNA CIRCUIT

1. Disconnect BCM and front console antenna connector.
2. Check continuity between BCM connector and front console antenna connector.

BCM connector	Terminal	Front console antenna connector		Terminal	Continuity
A: M19	60	B: M41	Console	2	Yes
	61			1	

3. Check continuity between BCM connector and ground.


BCM connector	Terminal	Ground	Continuity
A: M19	Console		60 61

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness between BCM and front console antenna.

3. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 2

1. Replace front console antenna (new antenna or other antenna).
2. Connect BCM and front console antenna connector.




B2622 INSIDE KEY ANTENNA 2

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M19	Front console antenna	61	Ground	Place Intelligent Key inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Place Intelligent Key outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Replace front console antenna. Refer to [IP-17. "Disassembly and Assembly"](#).
 NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2623 INSIDE KEY ANTENNA 3

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

B2623 INSIDE KEY ANTENNA 3

Description

INFOID:000000005429137

Detects whether Intelligent Key is inside the vehicle.
Installed in the trunk room.

DTC Logic

INFOID:000000005429138

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3 CIRCUIT	An excessive high or low voltage from rear parcel shelf antenna is sent to BCM.	<ul style="list-style-type: none">rear parcel shelf antennaBetween BCM and rear parcel shelf antenna

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-III

1. Perform rear parcel shelf antenna INSIDE ANT DIAGNOSIS on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is rear parcel shelf antenna DTC detected?

- YES >> Refer to [DLK-286, "Diagnosis Procedure"](#).
NO >> Rear parcel shelf antenna is OK.


Diagnosis Procedure

INFOID:000000005429139

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



B2623 INSIDE KEY ANTENNA 3

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M21	Rear parcel shelf antenna	115	Ground	Place Intelligent Key inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Place Intelligent Key outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
 NO >> GO TO 2


2. CHECK REAR PARCEL SHELF ANTENNA CIRCUIT

1. Disconnect BCM and rear parcel shelf antenna connector.
2. Check continuity between BCM connector and rear parcel shelf antenna connector.

BCM connector	Terminal	Rear parcel shelf antenna connector		Terminal	Continuity
A: M21	114	B: B29	Trunk room	2	Yes
	115			1	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	Trunk room		114 115



Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness between BCM and rear parcel shelf antenna.

3. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 2


1. Replace rear parcel shelf antenna (new antenna or other antenna).
2. Connect BCM and rear parcel shelf antenna connector.

B2623 INSIDE KEY ANTENNA 3

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals			Condition	Signal (Reference value.)	
(+)		(-)			
BCM connector	Terminal				
M21	Trunk room	115	Ground	Place Intelligent Key inside the vehicle.	
				Place Intelligent Key outside the vehicle.	

Is the inspection result normal?

- YES >> Replace rear parcel shelf antenna. Refer to [INT-39, "Removal and Installation"](#).
- NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000005783599

Regarding Wiring Diagram information, refer to [BCS-75, "COUPE : Wiring Diagram"](#) or [BCS-84, "SEDAN : Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check if the following BCM fuse or fusible link are blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	H
11		10


Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
 NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground
Connector	Terminal	
M16	1	
M17	11	
		Battery voltage



Is the measurement normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	13		Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



Special Repair Requirement

INFOID:000000005783600

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-6, "CONFIGURATION \(BCM\) : Special Repair Requirement"](#).

>> Work End.

DOOR SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR SWITCH

Description

INFOID:000000005429142

Detects door open/close condition.

Component Function Check

INFOID:000000005429143

1.CHECK FUNCTION

With CONSULT-III

Check door switches DOOR SW-DR, DOOR SW-AS, DOOR SW-RL, DOOR SW-RR in Data Monitor mode with CONSULT-III.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	
DOOR SW-RL	
DOOR SW-RR	

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [DLK-290. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429144

Regarding Wiring Diagram information, refer to [DLK-380. "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



DOOR SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminals		(-)	Door condition		Voltage (V) (Approx.)
(+)					
BCM connector	Terminal				
A: M18	58	Ground	Driver side	OPEN	0
				CLOSE	
	32		Passenger side	OPEN	0
				CLOSE	
B: M21	148		Rear RH	OPEN	0
				CLOSE	
	149		Rear LH	OPEN	0
				CLOSE	

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


DOOR SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
A: M18	58	C: B8 (Driver side)	2	Yes
	32	C: B108 (Passenger side)		
B: M21	148	C: B116 (Rear RH)		
	149	C: B18 (Rear LH)		



- Check continuity between BCM connector and ground.

BCM connector	Terminal		Continuity
A: M18	58	Ground	No
	32		
B: M21	148		
	149		

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness between BCM and door switch.

3.CHECK DOOR SWITCH

Refer to [DLK-292, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Replace malfunctioning door switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429145


1.CHECK DOOR SWITCH

- Turn ignition switch OFF.
- Disconnect door switch connector.
- Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
2	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace malfunctioning door switch.



WIIA0644E

DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005429146

Transmits door lock/unlock operation to BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005429147

1. CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> With LH and RH anti-pinch, refer to [DLK-293, "DRIVER SIDE : Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [DLK-295, "DRIVER SIDE : Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).


DRIVER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:000000005429148

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Read voltage signal between BCM connector and ground with oscilloscope when door lock and unlock switch (driver side) is turned "LOCK" or "UNLOCK".



2. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (driver side) is turned "LOCK" or "UNLOCK".


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK AND UNLOCK SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminal (+)		Terminal (-)	Condition	Signal (Reference value)
BCM connector	Terminal			
M18	40	Ground	Door is closed	 <p>P1IA1297E</p>

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
D8	17	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and main power window and door lock/unlock switch connector.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
A: M18	40	B: D8	14	Yes

3. Check continuity between BCM connector and ground.



BCM connector	Terminals		Continuity
A: M18	40	Ground	No

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).



DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

>> Inspection End.

DRIVER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)


INFOID:000000005429149

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage at the main power window and door lock/unlock switch connector when the switch (driver side) is turned to "LOCK" or "UNLOCK".

Connector	Main power window and door lock/unlock switch state	Terminal	Voltage
D8	Neutral → Lock	18	Battery voltage → 0
D12	Neutral → Unlock	6	




Is the inspection result normal?

- YES >> GO TO 5
NO >> GO TO 2

2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Continuity
D8	17 Ground	Yes




Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK POWER WINDOW SWITCH

Check continuity between main power window and door lock/unlock switch terminals.

Main power window and door lock/unlock switch state	Terminals	Continuity
Lock	17 - 18	Yes
Unlock	6 - 17	
Neutral/Lock	6 - 17	No
Neutral/Unlock	17 - 18	



Is the inspection result normal?

- YES >> GO TO 4
NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-163, "Removal and Installation"](#).

4. CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.


DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and main power window and door lock/unlock switch connector.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
A: M18	36	B: D8	18	Yes
	39	C: D12	6	



- Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	36	No
	39	

Is the inspection result normal?

- YES >> GO TO 5
- NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005429150

Transmits door lock/unlock operation to BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005429151

1.CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.
- NO >> With LH and RH anti-pinch, refer to [DLK-296, "PASSENGER SIDE : Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).
- NO >> With LH anti-pinch only, refer to [DLK-298, "PASSENGER SIDE : Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

PASSENGER SIDE : Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:000000005429152

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

DOOR LOCK AND UNLOCK SWITCH


[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Read voltage signal between BCM connector and ground with oscilloscope when door lock and unlock switch (passenger side) is turned "LOCK" or "UNLOCK".
2. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (passenger side) is turned "LOCK" or "UNLOCK".

Terminal		Condition	Signal (Reference value)
(+)	(-)		
BCM connector	Terminal		
M18	40	Door is closed	



Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2


2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between front power window switch (passenger side) connector and ground.

Power window and door lock/unlock switch RH connector	Terminal	Continuity
D105	11	Ground
		Yes

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.



3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and front power window switch (passenger side) connector.


BCM connector	Terminal	Front power window switch (passenger side) connector	Terminal	Continuity
A: M18	40	B: D105	16	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminals	Continuity
A: M18	40	Ground
		No

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.



DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

YES >> Inspection End.

PASSENGER SIDE : Diagnosis Procedure (With LH Anti-Pinch Only)


INFOID:000000005429153

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage at the power window and door lock/unlock switch RH connector when the switch (passenger side) is turned to "LOCK" or "UNLOCK".

Connector	Power window and door lock/unlock switch RH state	Terminal	Voltage
D110	Neutral → Lock	2	Battery voltage → 0
	Neutral → Unlock	1	



Is the inspection result normal?


YES >> GO TO 5

NO >> GO TO 2

2. CHECK POWER WINDOW SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between power window and door lock/unlock switch RH connector and ground.

Power window and door lock/unlock switch RH connector	Terminal	Continuity
D110	3 Ground	Yes



Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK POWER WINDOW SWITCH

Check continuity between power window and door lock/unlock switch RH terminals.

Power window and door lock/unlock switch RH state	Terminals	Continuity
Lock	2 - 3	Yes
Unlock	1 - 3	
Neutral/Unlock	2 - 3	No
Neutral/Lock	1 - 3	



Is the inspection result normal?

YES >> GO TO 4

NO >> Replace power window and door lock/unlock switch RH.

DOOR LOCK AND UNLOCK SWITCH


[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

4. CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.
2. Check continuity between BCM connector and power window and door lock/unlock switch RH connector.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
A: M18	36	B: D110	1	Yes
	39		2	



3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	36	No
	39	

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

KEY SLOT

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

KEY SLOT

Description

INFOID:000000005429154

Detects whether Intelligent Key is inserted.
Immobilizer antenna amp checks Intelligent Key transponder.

Component Function Check

INFOID:000000005429155

1. CHECK FUNCTION

With CONSULT-III

Check KEY SW -SLOT in Data Monitor mode with CONSULT-III.

Monitor item	Condition
KEY SW-SLOT	Key is inserted in key slot: ON
	Key is removed from key slot: OFF

Is the inspection result normal?

- YES >> Key slot is OK.
NO >> Refer to [DLK-300, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429156

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK KEY SLOT POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect key slot connector.
- Check voltage between key slot connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Key slot connector	Terminal	Ground
M40	1	
	5	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace key slot power supply circuit.

2. CHECK KEY SLOT GROUND CIRCUIT

Check continuity between key slot connector and ground.



Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace key slot ground circuit.

3. CHECK KEY SLOT CIRCUIT

- Disconnect BCM connector.



KEY SLOT

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

2. Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M18	29	C: M40	11	Yes
B: M19	68		2	
	69		3	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	29	No
B: M19	68	
	69	

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness between BCM and key slot.

4.CHECK KEY SLOT

Refer to [DLK-301, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace key slot.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429157

1.CHECK KEY SLOT



Check key slot.

Terminal		Condition	Continuity
Key slot			
1	11	Intelligent Key inserted	Yes
		Intelligent Key removed	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace key slot. Refer to [SEC-362, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY CYLINDER SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

KEY CYLINDER SWITCH

Description

INFOID:000000005429158

For vehicles equipped with LH and RH anti-pinch system, the main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

For vehicles equipped with LH anti-pinch system only, the front door lock assembly LH (key cylinder switch) transmits the LOCK or UNLOCK signal directly to the BCM.

Component Function Check

INFOID:000000005429159

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check KEY CYL UN-SW, KEY CYL UN-SW in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-229. "Work Flow"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> With LH and RH anti-pinch, refer to [DLK-302. "Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [DLK-303. "Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

Diagnosis Procedure (With LH and RH Anti-Pinch)


INFOID:000000005429160

Regarding Wiring Diagram information, refer to [DLK-380. "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal 4	Lock	0
		Neutral / Unlock	5
	Terminal 6	Unlock	0
		Neutral / Lock	5



Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [DLK-449. "FRONT DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2

2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT


KEY CYLINDER SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector and front door lock assembly LH (key cylinder switch) connector.
3. Check continuity between main power window and door lock/unlock switch connector and front door lock assembly LH (key cylinder switch) connector.

Main power window and door lock/unlock switch connector	Terminal	Front door lock assembly LH (key cylinder switch) connector	Terminal	Continuity
A: D7	4	B: D10	6	Yes
	6		5	



4. Check continuity between main power window and door lock/unlock switch connector and ground.

Power window main switch connector	Terminal	Ground	Continuity
A: D7	4	Ground	No
	6		

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.


3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D10	4	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.



4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.
 Refer to [DLK-305, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
 NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-449, "FRONT DOOR LOCK : Removal and Installation"](#).

Diagnosis Procedure (With LH Anti-Pinch Only)

INFOID:000000005429161

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.


KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

2. Check voltage between BCM connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	56	Lock	0
		Neutral / Unlock	5
	34	Unlock	0
		Neutral / Lock	5



Is the inspection result normal?


YES >> Replace main power window and door lock/unlock switch. Refer to [DLK-449, "FRONT DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2

2.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect front door lock assembly LH (key cylinder switch) connector.
- Check continuity between front door lock assembly LH (key cylinder switch) connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	4		Yes



Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Disconnect BCM connector M18.
- Check continuity between front door lock assembly LH (key cylinder switch) connector and BCM connector M18.

Front door lock assembly LH connector	Terminal	BCM connector	Terminal	Continuity
A: D14	5	B: M18	34	Yes
	6		56	



3. Check continuity between front door lock assembly LH (key cylinder switch) connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
A: D14	5		No
	6		

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-305, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

KEY CYLINDER SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-449. "FRONT DOOR LOCK : Removal and Installation"](#).

Component Inspection


INFOID:000000005429162

COMPONENT INSPECTION

1. CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly LH (key cylinder switch).

Terminal		Key position	Continuity
Front door lock assembly LH (key cylinder switch) connector			
5	4	Unlock	Yes
		Neutral / Lock	No
6		Lock	Yes
		Neutral / Unlock	No



Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-449. "FRONT DOOR LOCK : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

UNLOCK SENSOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

UNLOCK SENSOR

Description

INFOID:000000005429163

Detects door lock condition of driver door.

Component Function Check

INFOID:000000005429164

1.CHECK FUNCTION

With CONSULT-III

Check unlock sensor UNLK SEN –DR in “Data Monitor” mode.

Monitor item	Condition
UNLK SEN –DR	Front door lock (driver side) LOCK : ON
	Front door lock (driver side) UNLOCK : OFF

Is the inspection result normal?

YES >> Unlock sensor is OK.

NO >> Refer to [DLK-306, "Diagnosis Procedure"](#).


Diagnosis Procedure


INFOID:000000005429165

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1.CHECK UNLOCK SENSOR POWER SUPPLY

Check signal between BCM connector and ground with oscilloscope.



Terminals		(-)	Front door lock assembly LH condition	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector				
M18	27	Ground	Locked	
			Unlocked	0

JPMIA0011GB

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 2

UNLOCK SENSOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. CHECK UNLOCK SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and front door lock assembly LH connector.
3. Check continuity between BCM connector and front door lock assembly LH connector.

BCM connector	Terminal	Front door lock assembly LH connector	Terminal	Continuity
A: M18	27	B: D10 (with LH and RH front anti-pinch) D14 (with LH front anti-pinch)	3	Yes

4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	27		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and front door lock assembly LH.

3. CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D10 (with LH and RH front anti-pinch) D14 (with LH front anti-pinch)	4		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM harness connector.
2. Check signal between BCM connector and ground with oscilloscope.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M18	27	Ground

(V) 15, 10, 5, 0

10 ms




JPMIA0011GB

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#)

5. CHECK UNLOCK SENSOR



UNLOCK SENSOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Refer to [DLK-308. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace front door lock assembly LH. Refer to [DLK-449. "FRONT DOOR LOCK : Removal and Installation"](#).

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429166

1.CHECK UNLOCK SENSOR


Check unlock sensor.

Terminal		Front door lock assembly LH condition	Continuity
Front door lock assembly LH			
3	4	Unlock	Yes
		Lock	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front lock assembly LH. Refer to [DLK-449. "FRONT DOOR LOCK : Removal and Installation"](#).



TRUNK LID OPENER SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK LID OPENER SWITCH

Description

INFOID:000000005429167

Transmits trunk lid open signal to BCM.

Component Function Check

INFOID:000000005429168

1.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Does trunk lid opener cancel switch turn ON (CANCEL)?

- Yes >> Turn off trunk lid opener cancel switch.
- No >> GO TO 2

2.CHECK FUNCTION

With CONSULT-III

Check trunk lid opener switch TR/BD OPEN SW in Data Monitor mode with CONSULT-III.

- When trunk lid opener switch is turned to "ON".

Monitor item	Condition
TR/BD OPEN SW	Trunk lid opener switch is pressed: ON
	Trunk lid opener switch is released: OFF

Is the inspection result normal?

- YES >> Trunk lid opener switch is OK.
- NO >> Refer to [DLK-309. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429169

Regarding Wiring Diagram information, refer to [DLK-407. "Wiring Diagram"](#).

1.CHECK TRUNK LID OPEN INPUT SIGNAL

1. Remove Intelligent Key from key slot.
2. Turn on trunk lid opener cancel switch.
3. Check voltage between BCM connector and ground.


Terminals		Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	ON (press and hold)	0
M21	147		
	Ground	OFF (release)	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

2.CHECK TRUNK LID OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK LID OPENER SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lid opener switch connector.

BCM connector	Terminal	Trunk lid opener switch connector	Terminal	Continuity
A: M21	147	B: M75	1	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	147		No

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair harness or connector.

3. CHECK TRUNK LID OPENER SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener switch	Terminal	Ground	Continuity
M75	2		Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.

4. CHECK TRUNK LID OPENER SWITCH

Refer to [DLK-310, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Replace trunk lid opener switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429170




1. CHECK TRUNK LID OPENER SWITCH

- Turn ignition switch OFF.
- Disconnect trunk lid opener switch connector.
- Check continuity between trunk lid opener switch connector.

Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON (press and hold)	Yes
		OFF (release)	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace trunk lid opener switch.



TRUNK LID OPENER CANCEL SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK LID OPENER CANCEL SWITCH

Description

INFOID:000000005429171

Cancels trunk lid open operation.

Component Function Check

INFOID:000000005429172

1.CHECK FUNCTION

With CONSULT-III

Check trunk lid opener cancel switch TR CANCEL SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TR CANCEL SW	Trunk lid opener cancel switch is turned to "ON": ON
	Trunk lid opener cancel switch is turned to "OFF": OFF

Is the inspection result normal?

- YES >> Trunk lid opener cancel switch is OK.
- NO >> Refer to [DLK-311, "Diagnosis Procedure"](#).


Diagnosis Procedure


INFOID:000000005429173

Regarding Wiring Diagram information, refer to [DLK-407, "Wiring Diagram"](#).

1.CHECK TRUNK LID OPENER CANCEL SIGNAL

Check voltage between BCM connector and ground.



Terminals		(-)	Condition of trunk lid opener cancel switch	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector		Ground	ON	0
M18	37		OFF	

JPMIA0012GB

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK LID OPENER CANCEL SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. CHECK TRUNK LID OPENER CANCEL SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and trunk lid opener cancel switch connector.

BCM connector	Terminal	Trunk lid opener cancel switch connector	Terminal	Continuity
A: M18	37	B: M74	1	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	37		No

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair harness or connector.

3. CHECK TRUNK LID OPENER CANCEL SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener cancel switch	Terminal	Ground	Continuity
M74	2		Yes

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.

4. CHECK TRUNK LID OPENER CANCEL SWITCH

Refer to [DLK-312, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Replace trunk lid opener cancel switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429174




1. CHECK TRUNK LID OPENER CANCEL SWITCH

1. Disconnect trunk lid opener cancel switch connector.
2. Check continuity between trunk lid opener cancel switch terminals.

Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON	Yes
		OFF (cancel)	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace trunk lid opener cancel switch.



TRUNK ROOM LAMP SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK ROOM LAMP SWITCH

Description

INFOID:000000005429175

Detects trunk open/close condition.

Component Function Check

INFOID:000000005429176

1.CHECK FUNCTION

With CONSULT-III

Check TRNK/HAT MNTR in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TRNK/HAT MNTR	OPEN : ON
	CLOSE : OFF

Is the inspection result normal?

- YES >> Trunk room lamp switch is OK.
 NO >> Refer to [DLK-313, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429177


Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1.CHECK TRUNK LAMP SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between BCM connector and ground.

Terminals		Trunk condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M21	130	OPEN	0
		CLOSE	

JPMIA0011GB



Is the inspection result normal?

- YES >> GO TO 4
 NO >> GO TO 2

2.CHECK TRUNK LAMP SWITCH CIRCUIT

- Disconnect BCM and trunk lamp switch and trunk release solenoid connectors.

TRUNK ROOM LAMP SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M21	130	B: B28	2	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	130		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and trunk lamp switch and trunk release solenoid.

3. CHECK TRUNK LAMP SWITCH GROUND CIRCUIT

Check continuity between trunk lid lock assembly connector and ground.

Trunk lamp switch and trunk release solenoid connector	Terminal	Ground	Continuity
B28	3		Yes




Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace trunk lamp switch and trunk release solenoid ground circuit.

4. CHECK BCM OUTPUT SIGNAL

- Insure trunk remains closed during this step.
- Connect BCM connector.
- Check voltage between BCM connector and ground.



Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	130	Ground

JFMI0011GB

TRUNK ROOM LAMP SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5. CHECK TRUNK ROOM LAMP SWITCH

Refer to [DLK-315, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace trunk lamp switch and trunk release solenoid.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429178

1. CHECK TRUNK LAMP SWITCH


1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check trunk lamp switch.

Terminal		Trunk condition	Continuity
Trunk lamp switch and trunk release solenoid			
2	3	OPEN	Yes
		CLOSE	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trunk lamp switch and trunk release solenoid.



WIIA1180E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR REQUEST SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR REQUEST SWITCH

Description

INFOID:000000005429179

Transmits door lock/unlock operation to BCM.

Component Function Check

INFOID:000000005429180

1.CHECK FUNCTION

With CONSULT-III

Check door request switch REQ SW-DR, REQ SW-AS in Data Monitor mode.

Monitor item	Condition
REQ SW-DR	Door request switch is pressed : ON
REQ SW-AS	Door request switch is released : OFF

Is the inspection result normal?

- YES >> Door request switch is OK.
- NO >> Refer to [DLK-316, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429181

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1.CHECK DOOR REQUEST SWITCH OUTPUT SIGNAL



1. Turn ignition switch OFF.
2. Check voltage between BCM harness connector and ground.



DOOR REQUEST SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminals			Door request switch Condition	Voltage (V) (Approx.)
(+)		(-)		
BCM connector	Terminal			
M19	Door request switch (driver side)	89	Pressed	0
			Released	
	Door request switch (passenger side)	88	Pressed	0
			Released	

Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

2. CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM and front outside handle connector.
2. Check continuity between BCM connector and front outside handle connector.

BCM connector	Terminal	Front outside handle connector	Terminal	Continuity
A: M19	89	B: D6 (driver side)	3	Yes
	88	B: D106 (passenger side)		


3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	89		
	88		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and front outside handle.

3. CHECK DOOR REQUEST SWITCH GROUND CIRCUIT



DOOR REQUEST SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Check continuity between front outside handle connector and ground.


Front outside handle connector	Terminal	Ground	Continuity
D6 (driver side)	4		Ground
D106 (passenger side)			

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace front outside handle ground circuit.

4.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M19	89 88	
	Ground	

Is the inspection result normal?

- YES >> GO TO 5
- NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5.CHECK DOOR REQUEST SWITCH

Refer to [DLK-318, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6
- NO >> Replace malfunctioning front outside handle.



6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

1.CHECK DOOR REQUEST SWITCH



INFOID:000000005429182

DOOR REQUEST SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]


Check front outside handle (request switch).

Terminal		Door request switch condition	Continuity
Front outside handle (request switch)			
3	4	Pressed	Yes
		Released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunction front outside handle.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK OPENER REQUEST SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

TRUNK OPENER REQUEST SWITCH

Description

INFOID:000000005429183

Performs trunk lid open request when it is pressed.

Component Function Check

INFOID:000000005429184

1. CHECK FUNCTION

With CONSULT-III

Check trunk opener request switch REQ SW -BD/TR in Data Monitor mode.

Monitor item	Condition
REQ SW -BD/TR	Trunk opener request switch is pressed : ON
	Trunk opener request switch is released : OFF

Is the inspection result normal?

- YES >> Trunk opener request switch is OK.
- NO >> Refer to [DLK-320, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429185

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK TRUNK OPENER REQUEST SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector and ground.



Terminals		Trunk lid opener request switch condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	Pressed	0
M21	141	Released	

JPMIA0016GB

Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

TRUNK OPENER REQUEST SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. CHECK TRUNK OPENER REQUEST SWITCH CIRCUIT

1. Disconnect BCM and trunk opener request switch connector.
2. Check continuity between BCM connector and trunk opener request switch connector.

BCM connector	Terminal	Trunk opener request switch connector	Terminal	Continuity
A: M21	141	B: B33	1	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	141		No



Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and trunk opener request switch.

3. CHECK TRUNK OPENER REQUEST SWITCH GROUND CIRCUIT

Check continuity between trunk opener request switch connector and ground.



Trunk opener request switch connector	Terminal	Ground	Continuity
B33	2		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace trunk opener request switch ground circuit.


4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	141	Ground

JPMIA0016GB

Is the inspection result normal?



TRUNK OPENER REQUEST SWITCH

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- YES >> GO TO 5
- NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5. CHECK TRUNK OPENER REQUEST SWITCH

Refer to [DLK-322, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6
- NO >> Replace trunk opener request switch.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429186


1. CHECK TRUNK OPENER REQUEST SWITCH

Check trunk opener request switch.

Terminal		Trunk opener request switch condition	Continuity
Trunk opener request switch			
1	2	Pressed	Yes
		Released	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace trunk opener request switch.



DOOR LOCK ACTUATOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005429187

Locks/unlocks the door with the signal from BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005429188

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-323, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005429189

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1.CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	9	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3
 NO >> GO TO 2

2.CHECK DOOR LOCK ACTUATOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM and front door lock actuator driver side connector.
3. Check continuity between BCM connector and front door lock actuator driver side connector.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D10 (with LH and RH anti-pinch) D14 (with LH anti-pinch)	1	Yes
	9		2	


4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	Ground
	9	

Is the inspection result normal?



DLK



DOOR LOCK ACTUATOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- YES >> Replace front door lock actuator LH.
- NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005429190

Locks/unlocks the door with the signal from BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005429191

1. CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
- NO >> Refer to [DLK-324, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005429192

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1. CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.

Terminals		(-)	Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	BCM connector			
	8	Ground	Lock	0 → Battery voltage → 0
	5		Unlock	0 → Battery voltage → 0

Is the inspection result normal?



- YES >> GO TO 3
- NO >> GO TO 2

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and front door lock actuator RH connectors.
2. Check continuity between BCM connector and front door lock actuator RH.

BCM connector	Terminal	Front door lock actuator RH connector	Terminal	Continuity
A: M17	8	B: D108	5	Yes
	5		6	

3. Check continuity between BCM connector and ground.



DOOR LOCK ACTUATOR

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

BCM connector	Terminal		Continuity
A: M17	8	Ground	No
	5		

Is the inspection result normal?

- YES >> Replace front door lock actuator RH.
- NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

REAR LH

REAR LH : Description

INFOID:000000005429193

Locks/unlocks the door with the signal from BCM.

REAR LH : Component Function Check

INFOID:000000005429194

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
- NO >> Refer to [DLK-325, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000005429195

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.


Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)			
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	10	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3
- NO >> GO TO 2

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and rear door lock actuator LH connectors.



ALKIA0405Z2

DOOR LOCK ACTUATOR

[SEDAN WITH INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and rear door lock actuator LH connectors.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D205	1	Yes
	10		2	

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	Ground
	10	



Is the inspection result normal?

- YES >> Replace rear door lock actuator LH.
 NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

REAR RH

REAR RH : Description

INFOID:000000005429196

Locks/unlocks the door with the signal from BCM.

REAR RH : Component Function Check

INFOID:000000005429197

1. CHECK FUNCTION

- Use CONSULT-III to perform Active Test ("DOOR LOCK").
- Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-326. "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000005429198

Regarding Wiring Diagram information, refer to [DLK-380. "Wiring Diagram"](#).


1. CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	10	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3



DOOR LOCK ACTUATOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

NO >> GO TO 2

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and rear door lock actuator RH connectors.
2. Check continuity between BCM connector and rear door lock actuator RH connectors.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D305	5	Yes
	10		6	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	No
	10	


Is the inspection result normal?

- YES >> Replace rear door lock actuator RH.
 NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK LID OPENER ACTUATOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER ACTUATOR

Description

INFOID:000000005429199

Performs trunk lid open with signal from BCM.

Component Function Check

INFOID:000000005429200

1. CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Is trunk lid opener cancel switch turned OFF (CANCEL)?

- Yes >> Turn on trunk lid opener cancel switch.
- No >> GO TO 2.

2. CHECK FUNCTION

1. Perform Active Test TRUNK/GLASS HATCH with CONSULT-III.
2. Touch "OPEN" and check that trunk lid opens.

Is the inspection result normal?

- YES >> Trunk lid opener actuator is OK.
- NO >> Refer to [DLK-328. "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429201

Regarding Wiring Diagram information, refer to [DLK-407. "Wiring Diagram"](#).

1. CHECK OUTPUT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check voltage between trunk lamp switch and trunk release solenoid connector and ground.

Terminals			Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)		(-)		
Trunk lamp switch and trunk release solenoid connector	Terminal			
B28	3	Ground	OFF → ON	0 → Battery voltage → 0




Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals			Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)		(-)		
BCM connector	Terminal			
M20	103	Ground	OFF → ON	0 → Battery voltage → 0



Is the inspection result normal?

- YES >> Repair or replace harness.
- NO >> GO TO 3

TRUNK LID OPENER ACTUATOR

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. CHECK TRUNK LID OPENER ACTUATOR CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M20	103	B: B28	3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M20	103	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).
 NO >> Repair or replace harness.



4. CHECK TRUNK LID OPENER GROUND CIRCUIT

Check continuity between trunk lamp switch and trunk release solenoid connector and ground.

Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
B28	4	Ground

Is the inspection result normal?

- YES >> Replace trunk lamp switch and trunk release solenoid.
 NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

INTELLIGENT KEY WARNING BUZZER

Description

INFOID:000000005429202

Answers back and warns for an inappropriate operation.

Component Function Check

INFOID:000000005429203

1. CHECK FUNCTION

With CONSULT-III

Check Intelligent Key warning buzzer OUTSIDE BUZZER in Active Test mode.

Is the inspection result normal?

YES >> Intelligent Key warning buzzer (engine room) is OK.

NO >> Refer to [DLK-330, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429204

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK INTELLIGENT KEY WARNING BUZZER


Check voltage between BCM connector and ground.

Terminals		Warning buzzer operation condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M21	144	ON	0
		OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2



2. CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Check voltage between Intelligent Key warning buzzer connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Intelligent Key warning buzzer connector	Terminal	
E74	1	Battery voltage

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace Intelligent Key warning buzzer power supply circuit.



3. CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.

INTELLIGENT KEY WARNING BUZZER

[SEDAN WITH INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and Intelligent Key warning buzzer connector.

A: BCM connector	Terminal	Intelligent Key warning buzzer connector	Terminal	Continuity
M21	144	B: E74	3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	144		No



Is the inspection result normal?

OK >> GO TO 4

NG >> Repair or replace harness between BCM and Intelligent Key warning buzzer.

4. CHECK INTELLIGENT KEY WARNING BUZZER

Check [DLK-331, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace Intelligent Key warning buzzer.

5. CHECK INTERMITTENT INCIDENT

Check [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429205

1. CHECK INTELLIGENT KEY WARNING BUZZER


Connect battery power supply to Intelligent Key warning buzzer terminals 1 and 3, and check the operation.

1 (BAT+) - 3 (BAT-) : the buzzer sounds

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace Intelligent Key warning buzzer.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

OUTSIDE KEY ANTENNA

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

OUTSIDE KEY ANTENNA

Description

INFOID:000000005429206

Detects whether Intelligent Key is outside the vehicle.
Integrated in front outside handle (driver side, passenger side) and installed in rear bumper.

Component Function Check

INFOID:000000005429207

1. CHECK DOOR REQUEST SWITCH

Check that door request switch operates normally.

Is the inspection result normal?

YES >> GO TO 2

NO >> Inspect door request switch. Refer to [DLK-316, "Component Function Check"](#).

2. CHECK FUNCTION

Be sure that Intelligent Key is in each outside key antenna detection range.

Does door lock/unlock when each request switch is pressed?

YES >> Outside key antenna is OK.

NO >> Refer to [DLK-332, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429208

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



OUTSIDE KEY ANTENNA

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Terminals			(-)	Condition	Signal (Reference value.)
(+)		Terminal			
BCM connector	Terminal				
A: M19	Driver side	65	Ground	Request switch is pushed	<p>JMKIA0061GB</p>
	Passenger side	63			
B: M21	Rear bumper	119		Request switch is not pushed	<p>JMKIA0060GB</p>

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

- Disconnect BCM and front outside handle connector.
- Check continuity between BCM connector and outside key antenna connector.

BCM connector	Terminal	Outside key antenna connector	Terminal	Continuity
A: M19	65	C: D6 (driver side)	1	Yes
	64		2	
	63	C: D106 (passenger side)	1	
	62		2	
B: M21	119	D: B46 (rear bumper)	1	
	118		2	

3. Check continuity between BCM connector and ground.


BCM connector	Terminal	Ground	Continuity
A: M19	62		Ground
	63		
	64		
	65		
B: M21	118	Ground	No
	119		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and outside key antenna.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

- Replace outside key antenna. (new antenna or other antenna)
- Connect BCM and outside key antenna connector.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

OUTSIDE KEY ANTENNA

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals			(-)	Condition	Signal (Reference value.)
(+)		Terminal			
BCM connector					
A: M19	Driver side	65	Ground	Door request switch is pushed	
	Passenger side	63			
B: M21	Rear bumper	119		When Intelligent Key is not in the antenna detection area.	

Is the inspection result normal?

YES >> Replace outside key antenna.

NO >> GO TO 4

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Description

INFOID:000000005429209

Receives Intelligent Key operation and transmits to BCM.

Component Function Check

INFOID:000000005429210

1. CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating Intelligent Key.

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
- NO >> Refer to [DLK-335, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429211

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1. CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL



1. Turn ignition switch OFF.
2. Check signal between remote keyless entry receiver connector and ground with oscilloscope.



REMOTE KEYLESS ENTRY RECEIVER

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]


Terminals			Condition	Signal (Reference value)
(+)		(-)		
Remote keyless entry receiver connector	Terminal			
M27	2	Ground	Waiting (All doors closed)	 <p style="text-align: right;">JMKIA0064GB</p>
			When signal is received (All doors closed)	 <p style="text-align: right;">JMKIA0065GB</p>


Is the inspection result normal?

- YES >> GO TO 7
- NO >> GO TO 2

2. CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Disconnect remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver connector and ground with oscilloscope.

Terminals			Signal (Reference value)
(+)		(-)	
Remote keyless entry receiver connector	Terminal		
M27	4	Ground	 <p style="text-align: right;">JMKIA0064GB</p>



Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 3

3. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 1

1. Disconnect BCM connector.

REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	91	B: M27	4	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	91		No

Is the inspection result normal?

YES >> Reconnect BCM, GO TO 4

NO >> Repair or replace harness between BCM and remote keyless entry receiver.

4. CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

Check continuity between remote keyless entry receiver connector and ground.

Remote keyless entry receiver connector	Terminal	Ground	Continuity
M27	1		Yes

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 5

5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 2

Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M18	45	B: M27	1	Yes

Is the inspection result normal?

YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry receiver.

6. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 3





1. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	71	B: M27	2	Yes

2. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	71		No

Is the inspection result normal?



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry.

7.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

INTELLIGENT KEY BATTERY AND FUNCTION

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

INTELLIGENT KEY BATTERY AND FUNCTION

Description

INFOID:000000005429212

The following functions are available when having and carrying the Intelligent Key.

- Door lock/unlock
- Trunk open

Remote control entry function and panic alarm function are available when operating the remote buttons.

Component Function Check

INFOID:000000005429213

1. CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating with the Intelligent Key.

Is the inspection result normal?

- YES >> Intelligent Key is OK.
NO >> Refer to [DLK-339, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429214

1. CHECK INTELLIGENT KEY FUNCTION

Check Intelligent Key function using Remote Keyless Entry Tester J-43241.

Does the test pass?

- YES >> Intelligent Key is OK.
NO >> GO TO 2



2. CHECK INTELLIGENT KEY COMPONENTS

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.
2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:


- Do not touch the circuit board or battery terminal.
- The Intelligent Key is water-resistant. However, if it does get wet, immediately wipe it dry.

3. Remove the Intelligent Key battery.

CAUTION:

- Keep dirt, grease, and other foreign materials off the electrode contact area.

4. Visually inspect Intelligent Key internal components.



Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace malfunctioning parts.

3. CHECK INTELLIGENT KEY BATTERY

INTELLIGENT KEY BATTERY AND FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA.


Standard : Approx. 2.5 - 3.0V

Is the measurement value within specification?

YES >> Intelligent Key battery is OK. Check remote keyless entry receiver. Refer to [DLK-112](#).

["Component Function Check"](#).

NO >> GO TO 4



4. REPLACE INTELLIGENT KEY BATTERY

1. Replace the Intelligent Key battery.
2. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:


- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.

3. After replacing the battery, check that all Intelligent Key functions work properly.

Is the inspection result normal?

YES >> Intelligent Key is OK.

NO >> Check remote keyless entry receiver. Refer to [DLK-112](#).
["Component Function Check"](#).



KEY SLOT ILLUMINATION

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

KEY SLOT ILLUMINATION

Description

INFOID:000000005429215

Blinks when Intelligent Key insertion is required.

Component Function Check

INFOID:000000005429216

1.CHECK FUNCTION

With CONSULT-III

Check key slot illumination KEY SLOT ILLUMI in Active Test mode.

Is the inspection result normal?

- YES >> Key slot function is OK.
- NO >> Refer to [DLK-341, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429217

Regarding Wiring Diagram information, refer to [DLK-391, "Wiring Diagram"](#).

1.CHECK KEY SLOT ILLUMINATION OUTPUT SIGNAL

Check voltage between key slot connector and ground.

Terminals			Condition	Key slot illumination	Voltage (V) (Approx.)
(+)		(-)			
Key slot connector	Terminal				
M40	6	Ground	Intelligent Key inserted	OFF	Battery voltage
			Intelligent Key removed	ON	0



DLK


Is the inspection result normal?

- YES >> GO TO 6
- NO >> GO TO 2

2.CHECK KEY SLOT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect key slot connector.
3. Check voltage between slot connector and ground.

Terminals			Voltage (V) (Approx.)
(+)		(-)	
Key slot connector	Terminal		
M40	1	Ground	Battery voltage
	5		



Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace key slot power supply circuit.

3.CHECK KEY SLOT GROUND CIRCUIT

KEY SLOT ILLUMINATION

[SEDAN WITH INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

Check continuity between key slot connector and ground.

Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace key slot ground circuit.



4. CHECK KEY SLOT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and key slot connector.
3. Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M19	80	B: M40	6	Yes

4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	80		No

Is the inspection result normal?

- YES >> GO TO 5
- NO >> Repair or replace harness between BCM and key slot.

5. CHECK KEY SLOT

Refer to [DLK-301, "Component Inspection"](#).


Is the inspection result normal?

- YES >> GO TO 6
- NO >> Replace key slot.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.



HORN FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

HORN FUNCTION

Description

INFOID:000000005429218

Perform answer-back for each operation with horn.

Component Function Check

INFOID:000000005429219

1.CHECK FUNCTION

1. Select HORN in "ACTIVE TEST" mode with CONSULT-III.
2. Check the horn (high/low) operation.

Test item		Description	
HORN	ON	Horn relay	ON (for 20 ms)

Is the operation normal?

- YES >> Inspection End.
 NO >> Refer to [DLK-343, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429220

Regarding Wiring Diagram information, refer to [DLK-380, "Wiring Diagram"](#).

1.CHECK HORN FUNCTION


Check horn function with horn switch

Does the horn sound?

- YES >> GO TO 2
 NO >> Refer to [HRN-7, "SEDAN : Wiring Diagram"](#).

2.CHECK HORN RELAY POWER SUPPLY

1. Turn ignition switch ON.
2. Perform "ACTIVE TEST" ("HORN") with CONSULT-III.
3. Using an oscilloscope or analog voltmeter, check voltage between IPDM E/R connector and ground.



DLK

IPDM E/R		Ground	Test item	Voltage (V) (Approx.)
Connector	Terminal			
E17	44	Ground	HORN	Battery voltage → 0 → Battery voltage
			Other than above	Battery voltage

Is the inspection result normal?

- YES >> Repair or replace open harness between IPDM E/R and horn relay.
 NO >> GO TO 3

3.CHECK HORN RELAY CIRCUIT

HORN FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay connector.
3. Check continuity between IPDM E/R harness connector and horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
A: E17	44	B: H-1	1	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
A: E17	44	Ground	No

Is the inspection result normal?


- YES >> GO TO 4
 NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).
 NO >> Repair or replace the malfunctioning part.



COMBINATION METER DISPLAY FUNCTION

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

COMBINATION METER DISPLAY FUNCTION

Description

INFOID:000000005429221

Displays each operation method guide and warning for system malfunction.

Component Function Check

INFOID:000000005429222

1.CHECK FUNCTION

With CONSULT-III

Check the operation with ("LCD") in the Active Test.

Is each warning displayed on meter display?

Is the inspection result normal?

YES >> Meter display is OK.

NO >> Refer to [DLK-345. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429223

1.CHECK COMBINATION METER

Refer to [MWI-62. "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check combination meter. Refer to [MWI-42. "Diagnosis Description"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING CHIME FUNCTION

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

WARNING CHIME FUNCTION

Description

INFOID:000000005429224

Performs operation method guide and warning with buzzer.

Component Function Check

INFOID:000000005429225

1.CHECK FUNCTION

With CONSULT-III

1. Check the operation with "INSIDE BUZZER" in the Active Test.
2. Touch "TAKE OUT", "KNOB" or "KEY" on screen.

Is the inspection result normal?

- YES >> Warning buzzer into combination meter is OK.
NO >> Refer to [DLK-346, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429226

1.CHECK METER BUZZER CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Replace combination meter. Refer to [MWI-153, "Removal and Installation"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

HAZARD FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

HAZARD FUNCTION

Description

INFOID:000000005429227

Perform answer-back for each operation with number of blinks.

Component Function Check

INFOID:000000005429228

1.CHECK FUNCTION

Check hazard warning lamp ("FLASHER") in Active Test.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [EXL-163, "SEDAN : Wiring Diagram"](#).

Diagnosis Procedure

INFOID:000000005429229

1.CHECK HAZARD SWITCH CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace hazard warning switch circuit. Refer to [EXL-4, "Work Flow"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER

< COMPONENT DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

HOMELINK UNIVERSAL TRANSCEIVER

Description

INFOID:000000005429231

Homelink universal transceiver can store and transmit a maximum of 3 radio signals. Allows operation of garage doors, gates, home and office lighting, entry door locks and security system, etc. Homelink universal transceiver power supply uses vehicle battery, which enables it to maintain every program in case battery is discharged or removed.

Component Function Check

INFOID:000000005429232

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn ignition switch "OFF".
2. Press each of the transmitter buttons and watch for the red light to illuminate with each button.

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Refer to [DLK-348. "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

- YES >> Receiver or hand-held transmitter malfunction, not vehicle related.
- NO >> Replace auto anti-dazzling inside mirror (homelink universal transceiver). Refer to [MIR-18. "Removal and Installation"](#).


Diagnosis Procedure

INFOID:000000005429233

Regarding Wiring Diagram information, refer to [DLK-154. "Wiring Diagram"](#).

1.CHECK POWER SUPPLY

1. Disconnect auto anti-dazzling inside mirror (homelink universal transceiver) connector.
2. Check voltage between auto anti-dazzling inside mirror (homelink universal transceiver) harness connector and ground.



Auto anti-dazzling inside mirror (Homelink universal transceiver) connector	Terminal		Condition	Voltage (V) (Approx.)
R4	10	Ground	Ignition switch position: LOCK	Battery voltage

HOMELINK UNIVERSAL TRANSCEIVER

[SEDAN WITH INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2

NO >> Check the following.

- 10A fuse [No. 6 located in the fuse block (J/B)]
- Harness for open or short between fuse and auto anti-dazzling inside mirror (homelink universal transceiver).

2.CHECK GROUND CIRCUIT

Check continuity between auto anti-dazzling inside mirror (homelink universal transceiver) harness connector and ground.

Auto anti-dazzling inside mirror (Homelink universal transceiver) connector	Terminal	Ground	Continuity
R4	8		Yes

Is the inspection result normal?


YES >> GO TO 3

NO >> Repair harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000005783587

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Other than front wiper switch LO	OFF
	Front wiper switch LO	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER INT	Other than front wiper switch INT	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Front wiper is not in STOP position	OFF
	Front wiper is in STOP position	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Other than turn signal switch LH	OFF
	Turn signal switch LH	ON
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	OFF
	Lighting switch 1ST or 2ND	ON
HI BEAM SW	Other than lighting switch HI	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
AUTO LIGHT SW	Other than lighting switch AUTO	OFF
	Lighting switch AUTO	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
DOOR SW-DR	Driver door closed	OFF
	Driver door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear door RH closed	OFF
	Rear door RH opened	ON
DOOR SW-RL	Rear door LH closed	OFF
	Rear door LH opened	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Monitor Item	Condition	Value/Status	
CDL LOCK SW	Other than power door lock switch LOCK	OFF	A
	Power door lock switch LOCK	ON	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	OFF	B
	Power door lock switch UNLOCK	ON	
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF	C
	Driver door key cylinder LOCK position	ON	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF	D
	Driver door key cylinder UNLOCK position	ON	
HAZARD SW	When hazard switch is not pressed	OFF	
	When hazard switch is pressed	ON	
REAR DEF SW	When rear window defogger switch is pressed	ON	E
TR CANCEL SW	Trunk lid opener cancel switch OFF	OFF	
	Trunk lid opener cancel switch ON	ON	
TR/BD OPEN SW	Trunk lid opener switch OFF	OFF	F
	While the trunk lid opener switch is turned ON	ON	
TRNK/HAT MNTR	Trunk lid closed	OFF	G
	Trunk lid opened	ON	
RKE-LOCK	When LOCK button of Intelligent Key is not pressed	OFF	H
	When LOCK button of Intelligent Key is pressed	ON	
RKE-UNLOCK	When UNLOCK button of Intelligent Key is not pressed	OFF	I
	When UNLOCK button of Intelligent Key is pressed	ON	
RKE-TR/BD	When TRUNK OPEN button of Intelligent Key is not pressed	OFF	J
	When TRUNK OPEN button of Intelligent Key is pressed	ON	
RKE-PANIC	When PANIC button of Intelligent Key is not pressed	OFF	
	When PANIC button of Intelligent Key is pressed	ON	
RKE-P/W OPEN	When UNLOCK button of Intelligent Key is not pressed and held	OFF	DLK
	When UNLOCK button of Intelligent Key is pressed and held	ON	
RKE-MODE CHG	When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	OFF	L
	When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	ON	
OPTICAL SENSOR	When outside of the vehicle is bright	Close to 5 V	M
	When outside of the vehicle is dark	Close to 0 V	
REQ SW-DR	When driver door request switch is not pressed	OFF	N
	When driver door request switch is pressed	ON	
REQ SW-AS	When passenger door request switch is not pressed	OFF	O
	When passenger door request switch is pressed	ON	
REQ SW-BD/TR	When trunk request switch is not pressed	OFF	P
	When trunk request switch is pressed	ON	
PUSH SW	When engine switch (push switch) is not pressed	OFF	
	When engine switch (push switch) is pressed	ON	
IGN RLY2-F/B	Ignition switch OFF or ACC	OFF	
	Ignition switch ON	ON	
ACC RLY-F/B	Ignition switch OFF	OFF	
	Ignition switch ACC or ON	ON	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Monitor Item	Condition	Value/Status
CLUTCH SW	When the clutch pedal is not depressed	OFF
	When the clutch pedal is depressed	ON
BRAKE SW 1	When the brake pedal is not depressed	ON
	When the brake pedal is depressed	OFF
DETE/CANCL SW	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN/N SW	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
UNLK SEN-DR	Driver door UNLOCK status	OFF
	Driver door LOCK status	ON
PUSH SW-IPDM	When engine switch (push switch) is not pressed	OFF
	When engine switch (push switch) is pressed	ON
IGN RLY1 F/B	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
DETE SW -IPDM	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN -IPDM	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
SFT P-MET	When selector lever is in any position other than P	OFF
	When selector lever is in P position	ON
SFT N-MET	When selector lever is in any position other than N	OFF
	When selector lever is in N position	ON
ENGINE STATE	Engine stopped	STOP
	While the engine stalls	STALL
	At engine cranking	CRANK
	Engine running	RUN
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door UNLOCK status	UNLK
DOOR STAT-AS	Passenger door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door UNLOCK status	UNLK
ID OK FLAG	Ignition switch ACC or ON	RESET
	Ignition switch OFF	SET
PRMT ENG STAT	When the engine start is prohibited	RESET
	When the engine start is permitted	SET
KEY SW -SLOT	When Intelligent Key is not inserted into key slot	OFF
	When Intelligent Key is inserted into key slot	ON
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	YET
	The key ID that the key slot receives accords with any key ID registered to BCM.	DONE

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Monitor Item	Condition	Value/Status	
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	YET	A
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	DONE	B
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	YET	C
	The key ID that the key slot receives accords with the third key ID registered to BCM.	DONE	
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	YET	D
	The key ID that the key slot receives accords with the second key ID registered to BCM.	DONE	
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	YET	E
	The key ID that the key slot receives accords with the first key ID registered to BCM.	DONE	F
TP 4	The ID of fourth key is not registered to BCM	YET	
	The ID of fourth key is registered to BCM	DONE	G
TP 3	The ID of third key is not registered to BCM	YET	
	The ID of third key is registered to BCM	DONE	H
TP 2	The ID of second key is not registered to BCM	YET	
	The ID of second key is registered to BCM	DONE	I
TP 1	The ID of first key is not registered to BCM	YET	
	The ID of first key is registered to BCM	DONE	J
AIR PRESS FL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front LH tire	
AIR PRESS FR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front RH tire	
AIR PRESS RR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear RH tire	DLK
AIR PRESS RL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear LH tire	
ID REGST FL1	When ID of front LH tire transmitter is registered	DONE	L
	When ID of front LH tire transmitter is not registered	YET	
ID REGST FR1	When ID of front RH tire transmitter is registered	DONE	M
	When ID of front RH tire transmitter is not registered	YET	
ID REGST RR1	When ID of rear RH tire transmitter is registered	DONE	N
	When ID of rear RH tire transmitter is not registered	YET	
ID REGST RL1	When ID of rear LH tire transmitter is registered	DONE	O
	When ID of rear LH tire transmitter is not registered	YET	
WARNING LAMP	Tire pressure indicator OFF	OFF	
	Tire pressure indicator ON	ON	
BUZZER	Tire pressure warning alarm is not sounding	OFF	P
	Tire pressure warning alarm is sounding	ON	


BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005783588



Physical Values

INFOID:000000005783589

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
1 (W/B)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (R/Y)	Ground	Battery power supply output	Output	Ignition switch OFF	Battery voltage
3 (L/W)	Ground	Ignition power supply output	Output	Ignition switch ON	Battery voltage
4 (P/W)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time	0V
				Any other time after passing the interior room lamp battery saver operation time	Battery voltage
5 (G/Y)	Ground	Front door RH UNLOCK	Output	Front door RH	UNLOCK (actuator is activated)
					Other than UNLOCK (actuator is not activated)
7 (R/W)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (actuator is activated)
					Other than LOCK (actuator is not activated)
9 (G)	Ground	Front door LH UNLOCK	Output	Front door LH	UNLOCK (actuator is activated)
					Other than UNLOCK (actuator is not activated)
10 ¹ (G/Y)	Ground	Rear door RH and rear door LH UNLOCK	Output	Rear door RH and rear door LH	UNLOCK (actuator is activated)
					Other than UNLOCK (actuator is not activated)
11 (Y/R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0V
14 ⁶ (R/Y)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp	OFF
					ON

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
14 ¹ (O/W)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp	OFF	0V
				ON	NOTE: When the illumination brightening/dimming level is in the neutral position  <small>JSNIA0010GB</small>	
15 (Y/L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF	Battery voltage
				ACC or ON	0V	
17 (G/B)	Ground	Turn signal (RH)	Output	Ignition switch ON	Turn signal switch OFF	0V
				Turn signal switch RH	 <small>PKID0926E</small>	
18 (G/Y)	Ground	Turn signal (LH)	Output	Ignition switch ON	Turn signal switch OFF	0V
				Turn signal switch LH	 <small>PKID0926E</small>	
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
				ON	0V	
21 (P/B)	Ground	Optical sensor signal	Input	Ignition switch ON	When outside of the vehicle is bright	Close to 5V
				When outside of the vehicle is dark	Close to 0V	
22 (R/Y)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (clutch pedal is not depressed)	0V
				ON (clutch pedal is depressed)	Battery voltage	
24 (R/W)	Ground	Stop lamp switch 1	Input	—	Battery voltage	
26 (O/L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (brake pedal is not depressed)	0V
				ON (brake pedal is depressed)	Battery voltage	

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
27 (G/W)	Ground	Front door lock assembly LH (unlock sensor)	Input	Front door LH	LOCK status	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					UNLOCK status	0V
29 (Y)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	Battery voltage	
				When Intelligent Key is not inserted into key slot	0V	
30 (V/Y)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0
					ACC or ON	Battery voltage
31 (G)	Ground	Rear window defogger feedback signal	Input	Rear window defogger switch	OFF	0V
					ON	Battery voltage
32 (R/B)	Ground	Front door RH switch	Input	Front door RH switch	OFF (when front door RH closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (when front door RH opens)	0V
33 (SB)	Ground	Compressor ON signal	Input	A/C switch	OFF	9.0 - 12.0V
					ON	0V
34 ² (L/R)	Ground	Front door lock assembly LH (key cylinder switch) (unlock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (unlock)	0V
36 ² (GR)	Ground	Lock switch signal	Input	Door lock/unlock switch	Lock	Battery voltage
					Unlock	0V
37 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	CANCEL	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>
					ON	0V
38 (GR/W)	Ground	Rear window defogger ON signal	Input	Rear window defogger switch	OFF	5V
					ON	0V
39 ² (GR/R)	Ground	Unlock switch signal	Input	Door lock/unlock switch	Unlock	Battery voltage
					Lock	0V





A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
40 ³ (Y/G)	Ground	Power window serial link	Input/ Output	Ignition switch ON		 <small>JPMIA0013GB</small> 10.2V
				Ignition switch OFF or ACC		0V
41 (W)	Ground	Engine switch (push switch) illumination	Output	Engine switch (push switch) illumination	ON	5.5V
					OFF	0V
42 (R)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	ON	0V
					OFF	Battery voltage
45 (P)	Ground	Receiver & sensor ground	Input	Ignition switch ON		0V
46 (V/W)	Ground	Receiver & sensor power supply output	Output	Ignition switch	OFF	0V
					ACC or ON	5.0V
47 (G/O)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	Standby state	 <small>OCC3881D</small>
					When receiving the signal from the transmitter	 <small>OCC3880D</small>
48 (R/G)	Ground	Selector lever P/N position signal	Input	Selector lever	P or N position	12.0V
					Except P and N positions	0V
49 (L/O)	Ground	Security indicator signal	Output	Security indicator	ON	0V
					Blinking	 <small>JPMIA0014GB</small> 11.3V
					OFF	Battery voltage

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
50 (LG/ B)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0V
				Lighting switch 1ST	<p>JPMIA0031GB</p>	
				Lighting switch high-beam		
				Lighting switch 2ND		
				Turn signal switch RH	10.7V	
51 (L/W)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0V
				Any of the conditions below with all switch OFF	<p>JPMIA0032GB</p>	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 		10.7V
52 (G/B)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0V
				Any of the conditions below with all switch OFF	<p>JPMIA0033GB</p>	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 		10.7V
53 (LG/ R)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0V
				Lighting switch AUTO	<p>JPMIA0034GB</p>	
				Front wiper switch INT		
				Front wiper switch LO	10.7V	
54 (G/Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0V
				Turn signal switch LH	<p>JPMIA0035GB</p>	
				Lighting switch flash-to-pass		
				Lighting switch 2ND		
				Front fog lamp switch ON	10.7V	
55 (BR/ W)	Ground	Front blower monitor	Input	Front blower motor switch	ON	Battery voltage
					OFF	0V






A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
56 ² (L/B)	Ground	Front door lock assembly LH (key cylinder switch) (lock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (lock)	0V
57 (W)	Ground	Tire pressure warning check switch	Input	—	—	5V
58 (SB)	Ground	Front door LH switch	Input	Front door LH switch	OFF (front door LH CLOSE)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					ON (front door LH OPEN)	0V
59 (G/R)	Ground	Rear window defogger relay	Output	Rear window defogger	Active	Battery voltage
					Not activated	0V
60 (B/R)	Ground	Front console antenna 2 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
61 (W/R)	Ground	Center console antenna 2 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
62 ⁴ (B/Y)	Ground	Front outside handle RH antenna (-)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is not in the antenna detection area	
63 ⁴ (LG)	Ground	Front outside handle RH antenna (+)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is not in the antenna detection area	
64 ⁴ (V)	Ground	Front outside handle LH antenna (-)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is not in the antenna detection area	





A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
65 ⁴ (P)	Ground	Front outside handle LH antenna (+)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>	
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
68 (G/O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
69 (O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
70 (R/B)	Ground	Ignition relay-2 con- trol	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
71 (L/O)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting		 <p style="text-align: right; font-size: small;">JMKIA0064GB</p>
				When operating either button on Intelligent Key		 <p style="text-align: right; font-size: small;">JMKIA0065GB</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
75 (R/Y)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)  <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
					Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7  <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3V</p>

A
B
C
D
E
F
G
H
I
J






DLK

L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]



< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
76 (R/G)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4V
					Lighting switch high-beam (Wiper intermittent dial 4)	 <small>JPMIA0036GB</small> 1.3V
					Lighting switch 2ND (Wiper intermittent dial 4)	 <small>JPMIA0037GB</small> 1.3V
					Any of the conditions below with all switch OFF	 <small>JPMIA0040GB</small> 1.3V
78 (P)	Ground	CAN-L	Input/ Output	—	—	
79 (L)	Ground	CAN-H	Input/ Output	—	—	
80 (R/L)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF	0V
					Blinking	 <small>JPMIA0015GB</small> 6.5V
81 (LG)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
(+)	(-)					
83 (L)	Ground	ACC relay control	Output	Ignition switch	OFF	0V
					ACC or ON	Battery voltage
84 (Y/R)	Ground	CVT shift selector	Output	—		Battery voltage
87 (G/B)	Ground	Selector lever P position switch	Input	Selector lever	P position	0V
					Any position other than P	Battery voltage
88 ⁴ (P/L)	Ground	Front door RH request switch	Input	Front door RH request switch	ON (pressed)	0V
					OFF (not pressed)	
89 ⁴ (B/W)	Ground	Front door LH request switch	Input	Front door LH request switch	ON (pressed)	0V
					OFF (not pressed)	
90 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
91 (L/R)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage






A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]





< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
95 (R/W)	Ground	Combination switch INPUT 1	Input	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
				Turn signal switch LH	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
				Turn signal switch RH	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
				Front wiper switch LO	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
				Front washer switch ON	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3V</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
96 (P/B)	Ground	Combination switch INPUT 4	Input	Combination switch	<p>All switch OFF (Wiper intermittent dial 4)</p>  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					<p>Lighting switch AUTO (Wiper intermittent dial 4)</p>  <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
					<p>Lighting switch 1ST (Wiper intermittent dial 4)</p>  <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
					<p>Any of the conditions below with all switch OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6  <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3V</p>







A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
97 (R/B)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					Lighting switch flash-to-pass	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch INT	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch HI	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3V</p>
					Pressed	0 V
98 (G/O)	Ground	Hazard switch	Input	Hazard switch	Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
(+)	(-)					
103 (V)	Ground	Trunk lid opening	Output	Trunk lid	Open (trunk lid opener actuator is activated)	Battery voltage
					Close (trunk lid opener actuator is not activated)	0V
110 (V/W)	Ground	Trunk room lamp	Output	Trunk room lamp	ON	0V
					OFF	Battery voltage
114 (B)	Ground	Rear parcel shelf antenna 1 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	
					When Intelligent Key is not in the passenger compartment	
115 (W)	Ground	Rear parcel shelf antenna 1 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	
					When Intelligent Key is not in the passenger compartment	






A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
118 ⁴ (L/O)	Ground	Rear bumper antenna (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
119 ⁴ (BR/W)	Ground	Rear bumper antenna (+)	Output	When the trunk lid request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
127 (BR/W)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0V
130 (Y/G)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	OFF (trunk is closed)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					ON (trunk is open)	0V

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
(+)	(-)					
132 (R)	Ground	Starter motor relay control	Output	Ignition switch OFF (M/T vehicle)	When the clutch pedal is depressed	Battery voltage
					When the clutch pedal is not depressed	0V
				Ignition switch ON (other than M/T vehicle)	When selector lever is in P or N position and the brake is depressed	Battery voltage
					When selector lever is in P or N position and the brake is not depressed	0V
140 (BR)	Ground	Engine switch (push switch)	Input	Engine switch (push switch)	Pressed	0V
					Not pressed	Battery voltage
141 (G/R)	Ground	Trunk request switch	Input	Trunk request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
144 ⁴ (GR)	Ground	Intelligent Key warning buzzer	Output	Request switch buzzer	Sounding	0V
					Not sounding	Battery voltage
144 ⁵ (GR)	Ground	Outside warning buzzer	Output	Outside warning buzzer	Sounding	0V
					Not sounding	Battery voltage
147 (L/R)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Pressed	0V
					Not pressed	Battery voltage
148 ¹ (R/W)	Ground	Rear door RH switch	Input	Rear door RH switch	OFF (when rear door RH closes)	 <p style="text-align: center;">11.8V</p>
					ON (when rear door RH opens)	0V
149 ¹ (R/B)	Ground	Rear door LH switch	Input	Rear door LH switch	OFF (when rear door LH closes)	 <p style="text-align: center;">11.8V</p>
					ON (when rear door LH opens)	0V

1: Sedan

2: With LH front window anti-pinch

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

3: With LH and RH front window anti-pinch

4: With Intelligent Key

5: Without Intelligent Key

6: Coupe

Fail Safe

INFOID:000000005783590

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> Starter control relay signal Starter relay status signal
B2562: LO VOLTAGE	Inhibit engine cranking	100 ms after the power supply voltage increases to more than 8.8 V
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> Status 1 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): ON Clutch interlock switch signal: OFF (0 V) Status 2 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): OFF Clutch interlock switch signal: OFF (Battery voltage)

DTC Inspection Priority Chart

INFOID:000000005783591

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

Priority	DTC	
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING 	A B
4	<ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • B26E8: CLUTCH SW • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG 	C D E F G H I
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT 	J DLK L M N O
6	<ul style="list-style-type: none"> • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	P

DTC Index

INFOID:000000005783592

NOTE:

Details of time display

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-38, "Description"
U1010: CONTROL UNIT (CAN)	—	—	—	BCS-39, "DTC Logic"
U0415: VEHICLE SPEED SIG	—	—	—	BCS-40, "Description"
B2190: NATS ANTENNA AMP	×	—	—	SEC-53, "Description" (Coupe) SEC-229, "Description" (Sedan with I-Key) SEC-399, "Description" (Sedan without I-Key)
B2191: DIFFERENCE OF KEY	×	—	—	SEC-56, "Description" (Coupe) SEC-232, "Description" (Sedan with I-Key) SEC-402, "Description" (Sedan without I-Key)
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-57, "Description" (Coupe) SEC-233, "Description" (Sedan with I-Key) SEC-403, "Description" (Sedan without I-Key)
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-58, "Description" (Coupe) SEC-234, "Description" (Sedan with I-Key) SEC-404, "Description" (Sedan without I-Key)
B2195: ANTI SCANNING	×	—	—	SEC-59, "Description" (Coupe) SEC-235, "Description" (Sedan with I-Key) SEC-405, "Description" (Sedan without I-Key)
B2553: IGNITION RELAY	—	—	—	PCS-61, "Description"
B2555: STOP LAMP	—	—	—	SEC-60, "Description" (Coupe) SEC-236, "Description" (Sedan with I-Key) SEC-406, "Description" (Sedan without I-Key)
B2556: PUSH-BTN IGN SW	—	×	—	SEC-63, "Description" (Coupe) SEC-239, "Description" (Sedan with I-Key) SEC-409, "Description" (Sedan without I-Key)
B2557: VEHICLE SPEED	—	×	—	SEC-65, "Description" (Coupe) SEC-241, "Description" (Sedan with I-Key) SEC-411, "Description" (Sedan without I-Key)

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2560: STARTER CONT RELAY	×	×	—	SEC-66, "Description" (Coupe) SEC-242, "Description" (Sedan with I-Key) SEC-412, "Description" (Sedan without I-Key)
B2562: LOW VOLTAGE	×	—	—	BCS-41, "DTC Logic"
B2601: SHIFT POSITION	—	×	—	SEC-67, "Description" (Coupe) SEC-243, "Description" (Sedan with I-Key) SEC-413, "Description" (Sedan without I-Key)
B2602: SHIFT POSITION	—	×	—	SEC-71, "Description" (Coupe) SEC-246, "Description" (Sedan with I-Key) SEC-416, "Description" (Sedan without I-Key)
B2603: SHIFT POSI STATUS	—	×	—	SEC-74, "Description" (Coupe) SEC-249, "Description" (Sedan with I-Key) SEC-419, "Description" (Sedan without I-Key)
B2604: PNP SW	—	×	—	SEC-77, "Description" (Coupe) SEC-252, "Description" (Sedan with I-Key) SEC-422, "Description" (Sedan without I-Key)
B2605: PNP SW	—	×	—	SEC-79, "Description" (Coupe) SEC-254, "Description" (Sedan with I-Key) SEC-424, "Description" (Sedan without I-Key)
B2608: STARTER RELAY	×	×	—	SEC-81, "Description" (Coupe) SEC-256, "Description" (Sedan with I-Key) SEC-426, "Description" (Sedan without I-Key)
B260A: IGNITION RELAY	×	×	—	PCS-63, "Description"
B260F: ENG STATE SIG LOST	×	×	—	SEC-83, "Description" (Coupe) SEC-258, "Description" (Sedan with I-Key) SEC-428, "Description" (Sedan without I-Key)
B2614: ACC RELAY CIRC	—	×	—	PCS-66, "Description"
B2615: BLOWER RELAY CIRC	—	×	—	PCS-69, "Description"
B2616: IGN RELAY CIRC	—	×	—	PCS-72, "Description"
B2617: STARTER RELAY CIRC	×	×	—	SEC-87, "Description" (Coupe) SEC-262, "Description" (Sedan with I-Key) SEC-432, "Description" (Sedan without I-Key)
B2618: BCM	×	×	—	PCS-75, "Description"
B261A: PUSH-BTN IGN SW	—	×	—	SEC-90, "Description" (Coupe) SEC-265, "Description" (Sedan with I-Key) SEC-435, "Description" (Sedan without I-Key)

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B261E: VEHICLE TYPE	×	× (Turn ON for 15 seconds)	—	SEC-89, "Description" (Coupe) SEC-264, "Description" (Sedan with I-Key) SEC-434, "Description" (Sedan without I-Key)
B2622: INSIDE ANTENNA	—	—	—	DLK-60, "Description" (Coupe) DLK-283, "Description" (Sedan with I-Key) DLK-484, "Description" (Sedan without I-Key)
B2623: INSIDE ANTENNA	—	—	—	DLK-63, "Description" (Coupe) DLK-286, "Description" (Sedan with I-Key) DLK-487, "Description" (Sedan without I-Key)
B26E1: ENG STATE NO RES	×	×	—	SEC-92, "Description" (Coupe) SEC-267, "Description" (Sedan with I-Key) SEC-437, "Description" (Sedan without I-Key)
B26E8: CLUTCH SW	×	×	—	SEC-84, "Description" (Coupe) SEC-259, "Description" (Sedan with I-Key) SEC-429, "Description" (Sedan without I-Key)
B26EA: KEY REGISTRATION	×	× (Turn ON for 15 seconds)	—	SEC-86, "Description" (Coupe) SEC-261, "Description" (Sedan with I-Key) SEC-431, "Description" (Sedan without I-Key)
C1704: LOW PRESSURE FL	—	—	×	WT-44, "Self-Diagnosis (With CONSULT-III)"
C1705: LOW PRESSURE FR	—	—	×	
C1706: LOW PRESSURE RR	—	—	×	
C1707: LOW PRESSURE RL	—	—	×	
C1708: [NO DATA] FL	—	—	×	WT-14, "Description"
C1709: [NO DATA] FR	—	—	×	
C1710: [NO DATA] RR	—	—	×	
C1711: [NO DATA] RL	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	×	WT-16, "Description"
C1713: [CHECKSUM ERR] FR	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	×	WT-18, "Description"
C1717: [PRESSDATA ERR] FR	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	×	

BCM (BODY CONTROL MODULE)

[SEDAN WITH INTELLIGENT KEY]

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1720: [CODE ERR] FL	—	—	×	WT-16, "Description"
C1721: [CODE ERR] FR	—	—	×	
C1722: [CODE ERR] RR	—	—	×	
C1723: [CODE ERR] RL	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	×	
C1725: [BATT VOLT LOW] FR	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	×	WT-19, "Description"
C1734: CONTROL UNIT	—	—	×	WT-20, "Description"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

WIRING DIAGRAM

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram

INFOID:000000005803213



HOMELINK UNIVERSAL TRANSCEIVER

ABKWA0218GB


HOMELINK UNIVERSAL TRANSCEIVER

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

HOMELINK UNIVERSAL TRANSCEIVER CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6Q	Y/R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	Y/R	-
15	B	-

Connector No.	M64
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B/Y	-
15	B	-

Connector No.	R4
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	B	GND
10	B/Y	BAT+

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

POWER DOOR LOCK SYSTEM

Wiring Diagram

INFOID:000000005429237

POWER DOOR LOCK SYSTEM - SEDAN WITH INTELLIGENT KEY SYSTEM




ABKWA0729GB

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

- : WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM
- : WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM



ABKWA0730GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

- ◁A1▷ : WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM
- ◁A2▷ : WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM



ABKWA0731GB


POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

POWER DOOR LOCK SYSTEM CONNECTORS - SEDAN WITH INTELLIGENT KEY SYSTEM


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Terminal No.	Color of Wire	Signal Name
7N	Y/R	-

Terminal No.	Color of Wire	Signal Name
17J	SB	-
22J	R/B	-
25J	Y/G	-
98J	V	-
99J	G/Y	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	V	-
6	G/Y	-
10	R/B	-
11	R/W	-

ABKIA2053GB

A B C D E F G H I J L M N O P


DLK

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
8	B	-
9	GR/R	-
13	G/W	-
14	V	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-
10	Y/G	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/Y	-
5	B	-
6	V	-
8	Y/G	-

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_FL

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G/Y	CDL_AS
8	V	CDL_COMMON
9	G	CDL_DR/FL
10	G/Y	CDL_RR_RL_BACK
11	Y/R	BAT_BCM_FUSE
13	B	GND1

ABKIA2054GB

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60
99	98	97	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80

Terminal No.	Color of Wire	Signal Name
78	P	CAN-L
79	L	CAN-H

Terminal No.	Color of Wire	Signal Name
34	L/R	DOOR_KEY/C_UNLOCK_SW
36	GR	CENTRAL_LOCK_SW
39	GR/R	CENTRAL_UNLOCK_SW
40	Y/G	PW_K-LINE
56	L/B	DOOR_KEY/C_LOCK_SW
58	SB	DR_DOOR_SW


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20
59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40

Terminal No.	Color of Wire	Signal Name
27	G/W	DOOR_LOCK_STATUS
32	R/B	AS_DOOR_SW

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
151	150	149	148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132

Terminal No.	Color of Wire	Signal Name
130	Y/G	TRUNK_SW
148	R/W	RR_DOOR_SW
149	R/B	RL_DOOR_SW


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >


[SEDAN WITH INTELLIGENT KEY]

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17J	SB	-
22J	BR	-
25J	W	-
98J	GR	-
99J	G	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	DOOR SW (RL)

Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	DOOR SW (AS)

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	-
7	L	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	-
6	G	-
10	GR	-
11	B	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-
10	BR	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
8	B	-
9	GR/R	-
13	P	-
14	GR	-

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	DOOR SW (RR)

ABKIA2057GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	D10
Connector Name	FRONT DOOR LOCK ASSEMBLY LH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-
3	P	-
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW
6	L/B	DOOR_KEY/C_LOCK_SW

Connector No.	D8
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	GND
18	GR	LOCK

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L/B	LOCK
6	L/R	UNLOCK
14	Y/G	COM

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
5	B	-
6	GR	-
8	R	-

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-
3	P	-
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW
6	L/B	DOOR_KEY/C_LOCK_SW

Connector No.	D12
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	GR/R	UNLOCK


ABKIA2058GB

POWER DOOR LOCK SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	D108
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	GR	-
6	G	-

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	B	GND
16	R	COM

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-

Connector No.	D205
Connector Name	REAR DOOR LOCK ACTUATOR LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	LOCK
2	GR/R	UNLOCK
3	B	GND

ABKIA2059GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< WIRING DIAGRAM >


[SEDAN WITH INTELLIGENT KEY]

Connector No.	D305
Connector Name	REAR DOOR LOCK ACTUATOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	GR	-
6	G	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

ABKIA2060GB

INTELLIGENT KEY SYSTEM


[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

INTELLIGENT KEY SYSTEM

Wiring Diagram

INFOID:000000005429238



ABKWA0734GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >




ABKWA0735GB

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >




ABKWA0736GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >



ABKWA0737GB


INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >


INTELLIGENT KEY SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	BR	-
57G	GR	-
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1N	W/L	-
4N	G/Y	-
7N	Y/R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3Q	O/L	-
9Q	R/W	-

ABKIA2069GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	R/B	-
11	R/W	-

Terminal No.	Color of Wire	Signal Name
4J	B	-
6J	BR/W	-
11J	W	-
13J	L/O	-
17J	SB	-
22J	R/B	-
25J	Y/G	-
27J	G/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	5	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	3	Color of Wire	P	Signal Name	-
11	V	-	-	-	-
12	B/W	-	-	-	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---


ABKIA2070GB

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	P/W	ROOM_LAMP_BAT_SAVER
5	G/Y	CDL_AS
8	V	CDL_COMMON
9	G	CDL_DR/FL
10	G/Y	CDL_RR_RL_BACK
11	Y/R	BAT_BCM_FUSE
13	B	GND1
15	Y/L	ACC_LED
17	G/B	FR_FLASHER
18	G/Y	FL_FLASHER
19	Y	ROOM_LAMP_OUTPUT

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L


Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	LG	-
9	P/L	-
12	B/Y	-

Terminal No.	Color of Wire	Signal Name
24	R/W	STOP_LAMP_LOW_SW
26	O/L	STOP_LAMP_HIGH_SW
29	Y	FOB_IN_SW_1
32	R/B	AS_DOOR_SW
40	Y/G	PW K-LINE
42	R	S/L_LOCK_LED
45	P	GND_RF2_A/L
58	SB	DR_DOOR_SW

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
78	P	CAN-L
79	L	CAN-H
80	R/L	FOB SLOT ILLUMINATION
81	LG	IGN ON LED
88	P/L	AS REQUEST SWITCH
89	B/W	DR REQUEST SWITCH
91	L/R	RF1 POWER SUPPLY
98	G/O	HAZARD SW

Terminal No.	Color of Wire	Signal Name
60	B/R	ROOM ANT 2 B
61	W/R	ROOM ANT 2 A
62	B/Y	AS DOOR ANT B
63	LG	AS DOOR ANT A
64	V	DR DOOR ANT B
65	P	DR DOOR ANT A
68	G/O	FOB READER CLOCK
69	O	FOB READER DATA
71	L/O	RF1 TUNER SIGNAL

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60
59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40

Terminal No.	Color of Wire	Signal Name
114	B	TRUNK ANT 1 B
115	W	TRUNK ANT 1 A
118	L/O	BACK DOOR ANT B
119	BR/W	BACK DOOR ANT A
130	Y/G	TRUNK SW
140	BR	ENG START SW W/O ESCL
141	G/R	TRUNK REQUEST SW
144	GR	BUZZER
148	R/W	RR DOOR SW
149	R/B	RL DOOR SW

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
151	150	149	148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



100	101	102	103	104		
105	106	107	108	109	110	111

Terminal No.	Color of Wire	Signal Name
103	V	CDL_BACK_TRUNK


ABKIA2072GB

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	B	GND
4	BR	START SW
5	R	LOCK
6	Y/L	ACC
7	LG	ON
8	G/Y	B+

Connector No.	M27
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	GND
2	L/O	SIGNAL
4	L/R	12V

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/L	BAT
3	B	GND (POWER)
4	B	GND (ILL)
21	L	CAN-H
22	P	CAN-L
23	B	GND (CIRCUIT)


Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Terminal No.	Color of Wire	Signal Name
1	G/Y	B+
2	G/O	CLOCK
3	O	DATA
5	G/Y	LIGHT_BAT+
6	R/L	LIGHT_A
7	B	GND
11	Y	CARD_SW_1

Connector No.	M40
Connector Name	KEY SLOT
Connector Color	WHITE



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M203
Connector Name	FRONT CONSOLE ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W/R	ANT+
2	B/R	ANT-

Connector No.	M131
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Connector No.	M93
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	P	-
8P	R	-
11P	G	-

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-

Connector No.	M207
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

ABKIA2074GB


INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
12	B	GND (POWER)
28	SB	PUSH START SW

Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
39	P	CAN-L
40	L	CAN-H
41	B	GND (SIGNAL)
44	G/W	HORN RLY

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABKIA2075GB

A B C D E F G H I J L M N O P

DLK

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	E38
Connector Name	STOP LAMP SWITCH (WITH CVT)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-

Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	SB	-
57G	R	-
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-

Connector No.	E74
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
3	R	-

Connector No.	E52
Connector Name	STOP LAMP SWITCH (WITH M/T)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	E215
Connector Name	HORN (LOW)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E216
Connector Name	HORN (HIGH)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4J	V	- (WITH SEDAN)
6J	L	-
11J	W	-
13J	LG	-
17J	SB	-
22J	BR	-
25J	W	-
27J	SB	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

ABKIA2077GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	B29
Connector Name	REAR PARCEL-SHELF ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	ANT+
2	V	ANT- (WITH SEDAN)

Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	DOOR SW (RL)

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	GR	-
11	B	-

Connector No.	B46
Connector Name	REAR BUMPER ANTENNA
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	ANT+
2	LG	ANT-

Connector No.	B33
Connector Name	TRUNK OPENER REQUEST SWITCH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B	-


ABKIA2078GB

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	8	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	1	Color of Wire	B	Signal Name	DOOR SW (RR)
--------------	---	---------------	---	-------------	--------------

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	1	Color of Wire	GR	Signal Name	DOOR SW (AS)
--------------	---	---------------	----	-------------	--------------

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	5	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	D6
Connector Name	FRONT OUTSIDE HANDLE LH
Connector Color	BLACK



Terminal No.	1	Color of Wire	P	Signal Name	ANT+
2	V	ANT-			
3	GR	SW+			
4	B	SW-			

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	3	Color of Wire	P	Signal Name	-
11	V	-			
12	GR	-			

ABKIA2079GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

[SEDAN WITH INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	H-1
Connector Name	FUSE AND FUSIBLE LINK BOX (HORN RELAY)
Connector Color	-




Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-
3	O	-

Connector No.	D106
Connector Name	FRONT OUTSIDE HANDLE RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	ANT+
2	L	ANT-
3	GR	SW+
4	B	SW-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	-
9	GR	-
12	L	-

ABKIA2115GB

TRUNK LID OPENER


[SEDAN WITH INTELLIGENT KEY]

< WIRING DIAGRAM >

TRUNK LID OPENER

Wiring Diagram

INFOID:000000005429239



TRUNK LID OPENER - SEDAN

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKWA0741GB


TRUNK LID OPENER

< WIRING DIAGRAM >

[SEDAN WITH INTELLIGENT KEY]


TRUNK LID OPENER CONNECTORS - SEDAN

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	82G	Color of Wire	W/B	Signal Name	-
--------------	-----	---------------	-----	-------------	---

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	1	Color of Wire	W/B	Signal Name	BAT_POWER_F/L
--------------	---	---------------	-----	-------------	---------------




Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	13	Color of Wire	B	Signal Name	GND1
--------------	----	---------------	---	-------------	------

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	37	Color of Wire	O	Signal Name	TRUNK_CANCEL_SW
--------------	----	---------------	---	-------------	-----------------

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	103	Color of Wire	V	Signal Name	CDL_BACK_TRUNK
--------------	-----	---------------	---	-------------	----------------

TRUNK LID OPENER

< WIRING DIAGRAM >

[SEDAN WITH INTELLIGENT KEY]

Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L/R	-
2	B	-

Connector No.	M74
Connector Name	TRUNK LID OPENER CANCEL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-


Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
147	L/R	BACK_TRUNK_OPENER_

Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABKIA0613GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TRUNK LID OPENER

< WIRING DIAGRAM >

[SEDAN WITH INTELLIGENT KEY]


Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
4	B	-

Terminal No.	Color of Wire	Signal Name
21J	V	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AAKIA0154GB

INTELLIGENT KEY SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

SYMPTOM DIAGNOSIS

INTELLIGENT KEY SYSTEM SYMPTOMS

Symptom Table

INFOID:000000005429243

ALL FUNCTIONS OF INTELLIGENT KEY SYSTEM DO NOT OPERATE

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- "ENGINE START BY I-KEY" and "LOCK/UNLOCK BY I-KEY" are ON when setting on CONSULT-III.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
All functions of Intelligent Key system do not operate.	1. Check BCM power supply and ground circuit.	DLK-289
	2. Check Intelligent Key function and battery inspection.	DLK-339
	3. Check remote keyless entry receiver.	DLK-335
	4. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

DOOR LOCK FUNCTION SYMPTOMS

DOOR LOCK AND UNLOCK SWITCH

DOOR LOCK AND UNLOCK SWITCH : Symptom Table

INFOID:000000005429244

DOOR LOCK/UNLOCK FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “LOCK/UNLOCK BY I-KEY” is ON when setting on CONSULT-III.
- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page	
Power door locks do not operate with door lock and unlock switch.	1. Check BCM Power supply and ground circuit.	DLK-289	
	2. Check door lock and unlock switch.	DLK-293	
	3. Check door lock actuator (driver side)	DLK-323	
	4. Check Intermittent Incident.	GI-41	
Power door locks do not operate with door key cylinder operation. (Power door locks operate properly with door lock and unlock switch.)	1. Check key cylinder switch.	DLK-302	
	2. Replace power window main switch.	PWC-163 (LH only anti-pinch) or PWC-355 (LH & RH front anti-pinch).	
Specific door lock actuator does not operate.	1. Check door lock actuator.	Driver side	DLK-323
		Passenger side	DLK-324
		Rear LH	DLK-325
		Rear RH	DLK-326
	2. Check Intermittent Incident.	GI-41	
Vehicle speed sensing auto door LOCK operation does not operate.	1. Ensure automatic door lock/unlock function (lock operation) is enabled.	DLK-276	
	2. Check combination meter vehicle speed signal.	MWI-46	
	3. Check intermittent incident.	GI-41	
Ignition OFF interlock auto door UNLOCK function does not operate.	1. Ensure automatic door lock/unlock function (unlock operation) is enabled.	DLK-276	
	2. Check BCM for DTCs.	DLK-373	
	3. Check intermittent incident.	GI-41	

DOOR REQUEST SWITCH

DOOR REQUEST SWITCH : Symptom Table

INFOID:000000005429245

DOOR LOCK/UNLOCK FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

DOOR LOCK FUNCTION SYMPTOMS

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- "LOCK/UNLOCK BY I-KEY" is ON when setting on CONSULT-III.
- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Door lock/unlock system does not operate by door request switch.	1. Check BCM power supply and ground circuit.	DLK-289
	2. Check door switch.	DLK-290
	3. Check key slot.	DLK-300
	4. Check Intermittent Incident.	GI-41
Door lock/unlock system does not operate by request switch (driver side).	1. Check door request switch (driver side).	DLK-316
	2. Check outside key antenna (driver side).	DLK-332
	3. Check Intermittent Incident.	GI-41
Door lock/unlock system does not operate by request switch (passenger side).	1. Check door request switch (passenger side).	DLK-316
	2. Check outside key antenna (passenger side).	DLK-332
	3. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by door request switch (driver side) (other door lock function operate).	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-276
	2. Check selective unlock function with a remote controller or door key cylinder.	DLK-239
	3. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by door request switch (passenger side) (other door lock functions operate).	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-276
	2. Check Intermittent Incident.	GI-41
Auto lock function does not operate.	1. Check "AUTO LOCK SET" setting in "WORK SUPPORT".	DLK-276
	2. Check door switch.	DLK-290
	3. Check key slot.	DLK-300
	4. Check Intermittent Incident.	GI-41

INTELLIGENT KEY

INTELLIGENT KEY : Symptom Table

INFOID:000000005429246

REMOTE KEYLESS ENTRY FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- Ignition switch is in OFF or ACC position.
- All doors are closed.
- Retained power operation does not operate. Refer to [DLK-244, "INTELLIGENT KEY : System Description"](#).

DOOR LOCK FUNCTION SYMPTOMS

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Symptom	Diagnosis/service procedure	Reference page
All of the remote keyless entry functions do not operate.	1. Check Intelligent Key battery inspection.	DLK-339
	2. Check Intermittent Incident.	GI-41
Selective unlock function does not operate by Intelligent Key.	1. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".	DLK-276
	2. Check Intelligent Key battery inspection.	DLK-339
	3. Check Intermittent Incident.	GI-41
Auto lock function does not operate normally.	1. Check "AUTO LOCK SET" setting in "WORK SUPPORT".	DLK-276
	2. Check door switch.	DLK-290
	3. Check key slot.	DLK-300
	4. Check Intermittent Incident.	GI-41
Power window down function does not operate.	1. Check "PW DOWN SET" setting in "WORK SUPPORT".	DLK-276
	2. Check Intelligent Key battery inspection.	DLK-339

TRUNK OPEN FUNCTION SYMPTOMS

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

TRUNK OPEN FUNCTION SYMPTOMS

TRUNK LID OPENER SWITCH

TRUNK LID OPENER SWITCH : Symptom Table

INFOID:000000005429247

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by trunk opener switch.	1. Check trunk opener switch.	DLK-309
	2. Check trunk lid opener cancel switch.	DLK-311
	3. Check Intermittent Incident.	GI-41

TRUNK REQUEST SWITCH

TRUNK REQUEST SWITCH : Symptom Table

INFOID:000000005429248

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by trunk opener request switch.	1. Check trunk opener request switch.	DLK-320
	2. Check trunk lid opener cancel switch.	DLK-311
	3. Check outside key antenna (trunk room).	DLK-332
	4. Check Intermittent Incident.	GI-41

INTELLIGENT KEY

INTELLIGENT KEY : Symptom Table

INFOID:000000005429249

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms” are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

TRUNK OPEN FUNCTION SYMPTOMS

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Conditions of Vehicle (Operating Conditions)

- Intelligent Key is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by Intelligent Key.	1. Check "TRUNK OPEN DELAY" setting in "WORK SUPPORT".	DLK-276
	2. Check trunk open function.	DLK-257
	3. Check trunk room lamp switch.	DLK-313
	4. Check Intelligent Key battery inspection.	DLK-339
	5. Check Intermittent Incident.	GI-41

WARNING FUNCTION SYMPTOMS

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

WARNING FUNCTION SYMPTOMS

Symptom Table

INFOID:000000005429250

WARNING FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check "WORK FLOW". Refer to [DLK-229, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

Conditions of Vehicle (Operating Conditions)

Warning chime functions operating condition is extremely complicated. During operating confirmations, reconfirm the list above twice in order to ensure proper operation.

Symptom		Diagnosis/service procedure	Reference page
OFF position warning does not operate.	For internal	1. Check push-button ignition switch position indicator.	SEC-265
		2. Check door switch.	DLK-290
		3. Check warning chime function.	DLK-346
		4. Check Intermittent Incident.	GI-41
	For external	1. Check push-button ignition switch position indicator.	SEC-265
		2. Check door switch.	DLK-290
		3. Check Intelligent Key warning buzzer.	DLK-330
		4. Check Intermittent Incident.	GI-41
P position warning does not operate.	1. Check Park position switch.	SEC-252	
	2. Check door switch.	DLK-290	
	3. Check Intelligent Key warning buzzer.	DLK-330	
	4. Check warning chime function.	DLK-346	
	5. Check combination meter display function.	DLK-345	
	6. Check Intermittent Incident.	GI-41	
ACC warning does not operate	1. Check push-button ignition switch position indicator.	SEC-265	
	2. Check warning chime function.	DLK-346	
	3. Check combination meter display function.	DLK-345	
	4. Check Intermittent Incident.	GI-41	

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Symptom	Diagnosis/service procedure		Reference page	
Take away warning does not operate.	Door open to close	1. Check door switch.	DLK-290	
		2. Check inside key antenna.	Console	DLK-283
			Trunk room	DLK-286
		3. Check Intelligent Key warning buzzer.		DLK-330
		4. Check warning chime function.		DLK-346
		5. Check key slot illumination.		DLK-341
		6. Check combination meter display function.		DLK-345
	7. Check Intermittent Incident.		GI-41	
	Push-button ignition switch operation	1. Check push-button ignition switch position indicator.		SEC-265
		2. Check inside key antenna.	Console	DLK-283
			Trunk room	DLK-286
		3. Check warning chime function.		DLK-346
		4. Check key slot illumination.		DLK-341
		5. Check combination meter display function.		DLK-345
	6. Check Intermittent Incident.		GI-41	
	Door is open	1. Check push-button ignition switch position indicator.		SEC-265
		2. Check inside key antenna.	Console	DLK-283
			Trunk room	DLK-286
		3. Check combination meter display function.		DLK-345
	4. Check Intermittent Incident.		GI-41	
	Take away through window	1. Check "TAKE OUT FROM WIN WARN" setting in "WORK SUPPORT".		DLK-276
		2. Check inside key antenna.	Console	DLK-283
			Trunk room	DLK-286
		3. Check warning chime function.		DLK-346
4. Check key slot illumination.			DLK-341	
5. Check combination meter display function.			DLK-345	
6. Check Intermittent Incident.		GI-41		
Key warning chime does not operate.	1. Check key slot.		DLK-300	
	2. Check door switch.		DLK-290	
	3. Check warning chime function.		DLK-346	
	4. Check key slot illumination.		DLK-341	
	5. Check combination meter display function.		DLK-345	
	6. Check Intermittent Incident.		GI-41	
Door lock operation warning chime does not operate.	1. Check door switch.		DLK-290	
	2. Check key slot illumination.		DLK-341	
	3. Check Intelligent Key warning buzzer.		DLK-330	
	4. Check inside key antenna.	Console	DLK-283	
		Trunk room	DLK-286	
5. Check Intermittent Incident.		GI-41		

KEY REMINDER FUNCTION SYMPTOMS

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

KEY REMINDER FUNCTION SYMPTOMS

Symptom Table

INFOID:000000005429251

KEY REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-229, "Work Flow"](#).
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “LOCK/UNLOCK BY I-KEY” is ON when setting on CONSULT-III.
- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.
- Intelligent Key is out of key slot.

Symptom	Diagnosis/service procedure	Reference page
Key reminder function does not operate.	1. Check “ANTI KEY LOCK IN FUNCTI”setting in “WORK SUPPORT”.	DLK-276
	2. Check door switch.	DLK-290
	3. Check inside key antenna.	DLK-346
	4. Check unlock sensor.	DLK-341
	5. Check Intelligent Key battery inspection.	DLK-339
	6. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HAZARD FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

HAZARD FUNCTION

Symptom Table

INFOID:000000005429252

HAZARD AND BUZZER REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-229, "Work Flow"](#).
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “LOCK/UNLOCK BY I-KEY” is ON when setting on CONSULT-III.
- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.
- Intelligent Key is out of key slot.

Symptom	Diagnosis/service procedure	Reference page
Hazard reminder does not operate by request switch. (Buzzer reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-276
	2. Check hazard function.	DLK-347
	3. Check Intermittent incident.	GI-41
Hazard reminder does not operate by Intelligent Key. (Buzzer reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-276
	2. Check hazard function.	DLK-347
	3. Check Intelligent Key battery inspection.	DLK-339
Buzzer reminder does not operate by request switch. (Hazard reminder operate.)	1. Check “ANS BACK I-KEY LOCK” or “ANS BACK I-KEY UNLOCK” setting in “WORK SUPPORT”.	DLK-276
	2. Check Intelligent Key warning buzzer.	DLK-330
	3. Check Intermittent incident.	GI-41
Buzzer reminder does not operate by trunk opener request switch.	1. Check “TRUNK OPEN DELAY” setting in “WORK SUPPORT”.	DLK-276
	2. Check Intelligent Key warning buzzer.	DLK-330
	3. Check trunk open function.	DLK-252
	4. Check Intermittent incident.	GI-41

HORN FUNCTION

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

HORN FUNCTION

Symptom Table

INFOID:000000005429253

HAZARD AND HORN REMINDER FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “Work flow”. Refer to [DLK-229, "Work Flow"](#).
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- “ANSWER BACK FUNCTION” is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Hazard reminder does not operate by request switch. (Horn reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-276
	2. Check hazard function.	DLK-347
	3. Check Intermittent Incident.	GI-41
Hazard reminder does not operate by Intelligent Key. (Horn reminder operate.)	1. Check “HAZARD ANSWER BACK” setting in “WORK SUPPORT”.	DLK-276
	2. Check hazard function.	DLK-347
	3. Check Intelligent Key battery inspection.	DLK-339
Horn reminder does not operate by request switch. (Hazard reminder operate.)	1. Check “ANSWER BACK WITH I-KEY LOCK” or “ANSWER BACK WITH I-KEY UNLOCK” setting in “WORK SUPPORT”.	DLK-276
	2. Check Intelligent Key warning buzzer.	DLK-330
	3. Check Intermittent Incident.	GI-41
Horn reminder does not operate by Intelligent Key. (Hazard reminder operate.)	1. Check “HORN WITH KEYLESS LOCK” setting in “WORK SUPPORT”.	DLK-276
	2. Check horn function.	DLK-343
	3. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTEGRATED HOMELINK TRANSMITTER

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

INTEGRATED HOMELINK TRANSMITTER

Symptom Table

INFOID:000000005429254

HOMELINK UNIVERSAL TRANSCEIVER MALFUNCTION

Symptom	Diagnosis/service procedure	Reference page
Homelink universal transceiver does not operate properly.	1. Check homelink universal transceiver function.	DLK-348
	2. Check Intermittent Incident.	GI-41

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005786771



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [DLK-427, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.

• Squeak — (Like tennis shoes on a clean floor)

Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping

• Creak — (Like walking on an old wooden floor)

Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.

• Rattle — (Like shaking a baby rattle)

Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.

• Knock — (Like a knock on a door)

Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.

• Tick — (Like a clock second hand)

Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.

• Thump — (Heavy, muffled knock noise)

Thump characteristics include softer knock/dead sound often brought on by activity.

• Buzz — (Like a bumble bee)

Buzz characteristics include high frequency rattle/firm contact.

- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.

- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [DLK-425. "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-

71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000005786772

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[SEDAN WITH INTELLIGENT KEY]

Diagnostic Worksheet

INFOID:000000005786773





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[SEDAN WITH INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|-------------------------------------------------------|--------------------------------------------------------|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LATA0071E

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005786769

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005429258

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

PRECAUTIONS


< PRECAUTION >

[SEDAN WITH INTELLIGENT KEY]

Procedure without Cowl Top Cover

INFOID:000000005429259

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for work

INFOID:000000005429260

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

PREPARATION

[SEDAN WITH INTELLIGENT KEY]

< PREPARATION >




PREPARATION

PREPARATION

Special Service Tools

INFOID:000000005429261



The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise
— (J-43241) Remote Keyless Entry Tester  LEL946A	Used to test keyfobs

A
B
C
D
E
F
G
H
I
J
DLK

Commercial Service Tools

INFOID:000000005429262

Tool name	Description
Engine ear  SIIA0995E	Locating the noise
Power tool  PIIB1407E	

L
M
N
O
P

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

HOOD


HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation

INFOID:000000005429263

REMOVAL

1. Remove the hinge nuts (a) and the hood assembly (1).

CAUTION:**Operate with two workers, because of its large size.**

INSTALLATION

Installation is in the reverse order of removal.

Hood hinge nuts **14 N·m (1.4 kg·m, 10 ft·lb)**

NOTE:

After installing, perform hood fitting adjustment. Refer to [DLK-433, "HOOD ASSEMBLY : Adjustment"](#).

HOOD



< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

HOOD ASSEMBLY : Adjustment

INFOID:000000005429264

SEC. 650



- 1. Hood assembly
- 2. Front grille
- 3. Front fascia
- 4. Headlamp assembly
- 5. Front fender

FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDUNAL CLEARANCE ADJUSTMENT

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

HOOD

< ON-VEHICLE REPAIR >


[SEDAN WITH INTELLIGENT KEY]

Unit: mm (in)


Section	Item	Measurement	Standard	Parallelism	Equality
A - A	E	Clearance	5.0 ± 2.0 (0.20 \pm 0.079)	≤ 2.0 (0.079)	—
B - B	F	Clearance	5.0 ± 2.0 (0.20 \pm 0.079)	≤ 2.0 (0.079)	≤ 2.2 (0.087)
	G	Surface height	1.0 ± 2.0 (0.04 \pm 0.079)	≤ 2.0 (0.079)	≤ 2.0 (0.079)
C - C	H	Clearance	4.5 ± 2.0 (0.18 \pm 0.079)	—	2.1 (0.083)
	J	Surface height	1.0 ± 2.1 (0.04 \pm 0.083)	—	< 2.0 (0.079)
D - D	K	Clearance	4.0 ± 1.0 (0.16 \pm 0.04)	1.0 (0.04)	1.0 (0.04)
	M	Surface height	0.2 ± 1.0 (0.01 \pm 0.04)	1.0 (0.04)	1.0 (0.04)

FRONT END HEIGHT ADJUSTMENT

1. Check the surface height between the hood and each part by visual and tactile feeling.
2. Remove the front grille. Refer to [EXT-40, "Removal and Installation"](#).
3. Remove the hood lock.
4. Adjust the surface level difference of the hood, fender and head lamp by rotating the hood bumpers until the hood becomes 1 to 1.5 mm (0.04 to 0.059 in) lower than the fender.



5. Install and align the hood lock center with the center of the hood striker. Engage the lock with the striker and check for looseness.
6. Adjust A and B shown in the figure to the following value with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing the hood closed lightly [approx. 29 N (3 kg)].



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.27 in) |

7. After adjustment tighten the hood lock bolts to the specified torque.

LATERAL/LONGITUDUNAL CLEARANCE ADJUSTMENT

1. Check the clearance between the hood and each part by visual and tactile feeling.
2. Loosen the hood hinge bolts.

NOTE:

The anticorrosive agent applied between the hoodledge and the hood hinges also acts as an adhesive. This seal must be broken before the hinges will move.

3. Move the hood so that the clearance measurements are within specifications.
4. Tighten the hood hinge bolts.

HOOD

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

Hood hinge bolts : 14 N-m (1.4 kg-m, 10 ft-lb)

NOTE:


After installation apply touch-up paint onto the hinge bolts and around the base of the hinge.

5. If the clearance measurements between the hood and fender cannot be corrected by moving the hood, the fender must be adjusted. Refer to [DLK-440, "Removal and Installation"](#).

HOOD LOCK CONTROL

HOOD LOCK CONTROL : Component Parts Location

INFOID:000000005429265




- | | | |
|-----------------------|-----------------------------|---------------------------|
| 1. Hood lock assembly | 2. Hood lock cable | 3. Hoodedge reinforcement |
| 4. Clip | 5. Hood lock release handle | |

HOOD LOCK CONTROL : Removal and Installation

INFOID:000000005429266

REMOVAL

1. Remove the front grill. Refer to [EXT-40, "Removal and Installation"](#).
2. Remove the LH fender protector. Refer to [EXT-42, "Removal and Installation"](#).
3. Remove the hood lock assembly bolts.



4. Disconnect the hood lock cable from the hood lock, and unclip it from the hoodedge.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

HOOD

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


5. Remove the screws (a) with power tool, and separate the hood lock release handle (1) from the hood lock release cable (2).




6. Remove the grommet from the upper dash, and pull the hood lock cable into the passenger compartment.
CAUTION:
While pulling, be careful not to damage (peel) the outside of the hood lock cable.

INSTALLATION


1. Pull the hood lock cable through the upper dash into the engine compartment.
CAUTION:
Be careful not to bend the cable too much, keep the radius 100 mm (3.94 in) or more.
2. Attach the hood lock release cable (2) to the hood lock release handle (1) and install the hood lock release handle screws (a).



3. Check that the cable is not offset from the center of the grommet, and seat the grommet into the upper dash hole.
4. Apply the sealant around the grommet at * mark.



5. Position the hood lock cable and clip it into place.
6. Connect the hood lock cable to the hood lock assembly.
7. Loosely install the hood lock assembly.
8. Perform hood fitting adjustment. Refer to [DLK-433, "HOOD ASSEMBLY : Adjustment"](#).
9. Check the hood lock control operation.



HOOD

< ON-VEHICLE REPAIR >


[SEDAN WITH INTELLIGENT KEY]

INSPECTION

CAUTION:


If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary latch is properly engaged with the secondary striker (B: 6.8 mm (0.268 in) shown in the figure) with hood's own weight.



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.268 in) |

2. While operating the hood opener, carefully check that the front end of the hood is raised by approx. 20 mm (0.79 in). Also check that the hood opener returns to the original position.
3. Check that the hood lock release handle operating force is 49 N (5.0 kg-f, 11 ft-lb) or less.
4. Install so the static closing force of the hood is 343 – 490 N (35– 44 kg-f, 77.1 - 110.2 lb-f).
5. Check the hood lock lubrication condition. If necessary, apply "body grease" as shown.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

RADIATOR CORE SUPPORT


< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

RADIATOR CORE SUPPORT

Removal and Installation

INFOID:000000005429267



1. Radiator core support

a. Bolts

REMOVAL

1. Remove front bumper reinforcement. Refer to [EXT-36, "Removal and Installation"](#).
2. Remove head lamps (LH/RH). Refer to [EXL-217, "Removal and Installation"](#).
3. Remove air duct. Refer to [EM-19, "Removal and Installation"](#) QR25DE, [EM-123, "Removal and Installation"](#) VQ35DE.
4. Remove the radiator cooling fans. Refer to [CO-17, "Removal and Installation"](#) QR25DE, [CO-39, "Removal and Installation"](#) VQ35DE.
5. Remove the radiator. Refer to [CO-15, "Removal and Installation"](#) QR25DE, [CO-37, "Removal and Installation"](#) VQ35DE.
6. Remove the hood lock control. Refer to [DLK-435, "HOOD LOCK CONTROL : Removal and Installation"](#).
7. Remove ambient sensor. Refer to [HA-37, "Removal and Installation"](#).
8. Remove crash zone sensor. Refer to [SR-13, "Removal and Installation"](#).
9. Remove air guides (LH/RH).
10. Remove power steering fluid cooler. Refer to [ST-21, "QR25DE : Removal and Installation"](#) QR25DE, [ST-21, "VQ35DE : With 17 Inch Tire"](#) or [ST-23, "VQ35DE : With 18 Inch Tire"](#) VQ35DE.

RADIATOR CORE SUPPORT

[SEDAN WITH INTELLIGENT KEY]

< ON-VEHICLE REPAIR >

11. Remove horn (High/Low). Refer to [HRN-11, "Removal and Installation"](#).
12. Remove the harness clips from the radiator core support assembly, the harness is separate.
13. Remove the hood support rod.
14. Remove the bolts and the radiator core support.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

FRONT FENDER

Removal and Installation

INFOID:000000005429268

REMOVAL

1. Remove the head lamp. Refer to [EXL-217, "Removal and Installation"](#).
2. Remove the inner fender bolt cover.
3. Remove the center mudguard. Refer to [EXT-43, "Removal and Installation"](#).
4. Remove the bolts and the front fender.

CAUTION:

- While removing use a shop cloth to protect body from damaging.
- Use care when removing the front fender. The front fender baffle foam adheres the front fender to the body side outer. Carefully release the foam or damage to the fender may occur.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the front fender bolts.


ADJUSTMENT

FRONT FENDER

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

SEC. 630



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

- 1. Hood assembly
 - 2. Front fender
 - 3. Front fascia
 - 4. Body side outer
 - 5. Front fascia bracket
 - 6. Front door assembly
- ↶ Front

AWKIA0447GB

FRONT FENDER

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

Unit: mm (in)

Section	Item	Measurement	Standard	Parallelism	Equality
A-A	E	Clearance	4.0 ± 1.0 (0.16 ± 0.04)	1.0 (0.04)	1.0 (0.04)
	F	Surface height	0.2 ± 1.0 (0.01 ± 0.04)	1.0 (0.04)	1.0 (0.04)
B-B	G	Clearance	0.0 + 0.8 (0.0 +0.031)	—	—
	H	Surface height	0.7 ± 1.0 (0.028 ± 0.04)	1.0 (0.04)	1.0 (0.04)
C-C	J	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—
	K	Clearance	3.6 ± 1.0 (0.14 ± 0.04)	1.0 (0.04)	—
D-D	M	Clearance	2.3 ± 1.0 (0.09 ± 0.04)	1.0 (0.04)	—
	N	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—

1. Remove the inner fender bolt cover.
2. Remove the front fender protector. Refer to [EXT-42. "Removal and Installation"](#).
3. Remove the center mud guard. Refer to [EXT-43. "Removal and Installation"](#).
4. Loosen the front fender bolts and screws.
5. Adjust the clearance (J) and surface height (K) between the front fender and the front door.
6. Tighten the rear upper and lower front fender bolts.
7. Adjust the clearance (E) and surface height (F) between the front fender and the hood.
8. Adjust the clearance (M) and surface height (N) between the front fender and the body side outer.
9. Tighten the inner front fender bolts.
10. Adjust the clearance (G) and the surface height (H) between the front fender and the front fascia.
11. Tighten the front fender to front fascia and bracket screws.
12. Apply touch-up paint (the body color) onto the head of the front fender bolts.
13. Install the center mud guard. Refer to [EXT-43. "Removal and Installation"](#).
14. Install the front fender protector. Refer to [EXT-42. "Removal and Installation"](#).
15. Install the inner fender bolt cover.

DOOR

FRONT DOOR

FRONT DOOR : Removal and Installation


INFOID:000000005429269

CAUTION:

- When removing and installing the front door assembly, support the door with a jack and cloth to protect the door and body.
- When removing and installing front door assembly, be sure to carry out the fitting adjustment. Refer to [DLK-444, "FRONT DOOR : Adjustment"](#).
- After installing, apply touch-up paint (the body color) onto the head of the hinge nuts.
- Check the hinge rotating parts for lubrication. If necessary, apply "body grease".
- Operate with two workers, because of its heavy weight.
- Check front door open/close operation after installation.

REMOVAL

1. Pull the grommet and wire harness out of the front pillar until the harness connectors are accessible. Then disconnect the wire harness connectors.
2. Remove the check link bolt from the front pillar.
3. Remove the door-side hinge nuts (a) and the door assembly (1).



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

Adjust the door. Refer to [DLK-444, "FRONT DOOR : Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR







< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

FRONT DOOR : Adjustment

INFOID:000000005429270

SEC.800



AWKIA0450GB

- | | | |
|---------------------|------------------------|-----------------------|
| 1. Front fender | 2. Front door assembly | 3. Rear door assembly |
| 4. Center mud guard | 5. Center pillar | 6. Outer sill |
- ↔ Front

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

Unit: mm (in)

Section	Item	Measurement	Standard
A-A	F	Clearance	$4.5 \pm 1.5 (0.18 \pm 0.06)$
	G	Surface height	$0.0 \pm 1.5 (0.0 \pm 0.06)$
B-B	H	Clearance	$4.2 \pm 1.0 (0.17 \pm 0.04)$
	J	Surface height	$0.0 \pm 1.0 (0.0 \pm 0.04)$
C-C	K	Clearance	$4.2 \pm 1.0 (0.17 \pm 0.04)$
	M	Surface height	$0.0 \pm 1.0 (0.0 \pm 0.04)$
D-D	N	Clearance	$5.1 \pm 1.7 (0.20 \pm 0.07)$
E-E	P	Clearance	$3.6 \pm 1.0 (0.14 \pm 0.04)$
	Q	Surface height	$0.0 \pm 1.0 (0.0 \pm 0.04)$

LONGITUDINAL CLEARANCE

1. Confirm the back door adjustments and adjust if necessary. Refer to [DLK-445, "BACK DOOR : Removal and Installation"](#).
2. Remove the front fender. Refer to [DLK-440, "Removal and Installation"](#).
3. Loosen the hinge bolts. Raise or lower the front door at rear edge to adjust.
4. Install the front fender. Refer to [DLK-440, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the front door hinge nuts.
2. Move the top and or bottom in or out as necessary until it is within specifications.
3. Tighten the hinge nuts to specifications.

BACK DOOR

BACK DOOR : Removal and Installation

INFOID:000000005429271

CAUTION:

- When removing and installing the rear door assembly, support the door with a jack and cloth to protect the door and body.
- When removing and installing rear door assembly, be sure to carry out the fitting adjustment.
- Check the hinge rotating parts for poor lubrication. If necessary, apply "body grease".
- After installing, apply touch-up paint (the body color) onto the head of the hinge nuts.
- Operate with two workers, because of its heavy weight.
- Check rear door open/close operation after installation.

REMOVAL


1. Pull out grommet and disconnect rear door harness connector.
2. Remove the check link bolt from the center pillar.

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

3. Remove the door-side hinge nuts (a) and the door assembly (1).



INSTALLATION

Installation is in the reverse order of removal.

BACK DOOR : Adjustment

INFOID:000000005429272



ADJUSTMENT

DOOR


< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


SEC. 820




A-A



B-B



C-C



AWKIA0451GB

1. Rear door assembly

2. Center mud guard

3. Body side outer

Unit: mm (in)

Section	Item	Measurement	Standard
A-A	D	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	E	Surface height	0.0 ± 1.0 (0.0 ± 0.04)

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


Section	Item	Measurement	Standard
B-B	F	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	G	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
C-C	H	Clearance	5.3 ± 1.7 (0.21 ± 0.07)

LONGITUDINAL CLEARANCE

1. Remove the center pillar upper and lower trim. Refer to [INT-37, "Removal and Installation"](#).
2. Loosen the upper pillar hinge nuts.
3. Loosen the lower pillar hinge bolts.
4. Raise or lower the door at the rear edge to adjust.
5. Tighten the lower pillar hinge bolts.
6. Tighten the upper pillar hinge nuts.
7. Install the center pillar upper and lower trim. Refer to [INT-37, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the hinge nuts.
2. Move the top and or the bottom in or out as necessary until it is within specification.
3. Tighten the hinge nuts to specification.



DOOR LOCK


[SEDAN WITH INTELLIGENT KEY]

< ON-VEHICLE REPAIR >

DOOR LOCK FRONT DOOR LOCK

FRONT DOOR LOCK : Component Parts Location

INFOID:0000000005429273




- | | | |
|----------------------------|----------------------------------------|---------------------------------------------------------------------------------------------|
| 1. Outside handle assembly | 2. Front gasket | 3. Door key cylinder escutcheon (Driver side)
Outside handle escutcheon (Passenger side) |
| 4. Front gasket | 5. Rear gasket | 6. Key cylinder assembly (Driver side only) |
| 7. Outside handle bracket | 8. Key cylinder rod (Driver side only) | 9. Front door striker |
| 10. Door lock assembly | 11. Cap | 12. Inside door handle assembly |
| 13. Grommet | 14. Front door assembly | |

FRONT DOOR LOCK : Removal and Installation

INFOID:0000000005429274

REMOVAL

1. Remove the front door finisher. Refer to [INT-31, "Removal and Installation"](#).
2. Disconnect the inside handle knob cable and lock knob cable from the back side of the front door finisher.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK


[SEDAN WITH INTELLIGENT KEY]

< ON-VEHICLE REPAIR >


3. Remove the front door window and front door module assembly. Refer to [GW-16. "Removal and Installation"](#).
4. Remove door side grommet, and remove door key cylinder assembly (driver side) and outside handle escutcheon (passenger side) bolts (TORX T30) from grommet hole.




5. Disconnect door antenna and door request switch connector and remove harness clamp.



6. Disconnect the key cylinder rod.
7. Disconnect door key cylinder switch harness connector.
8. While pulling the outside handle (1), remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side) (2).



9. Disconnect front door request switch harness connector.
10. While pulling outside handle (1), slide toward rear of vehicle (2) to remove outside handle.




DOOR LOCK


< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


11. Remove the front gasket and rear gasket.




12. Remove the TORX bolts (T30), remove the door lock assembly.



13. Remove the TORX bolt (T30) (A) of the outside handle bracket.



14. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



15. Disconnect the door lock actuator connector and remove the door lock assembly.


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

16. Disconnect the outside handle cable from the outside handle bracket connection.



INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

When installing the key cylinder rod be sure to rotate the rod holder until a click is felt.

BACK DOOR LOCK

BACK DOOR LOCK : Component Parts Location

INFOID:000000005429275



- | | | |
|------------------------------|----------------------------|----------------------------|
| 1. Outside handle escutcheon | 2. Outside handle | 3. Front gasket |
| 4. Outside handle bracket | 5. Rear gasket | 6. Outside handle assembly |
| 7. Hole plug | 8. Rear door striker | 9. Rear door lock assembly |
| 10. Cap | 11. Inside handle assembly | 12. Grommet |
| 13. Rear door assembly | | |

BACK DOOR LOCK : Removal and Installation

INFOID:000000005429276

REMOVAL


1. Remove the rear door finisher. Refer to [INT-31, "Removal and Installation"](#).

DOOR LOCK


[SEDAN WITH INTELLIGENT KEY]

< ON-VEHICLE REPAIR >


2. Disconnect the inside handle knob cable and lock knob cable from the back side of the inside door handle.




3. Remove the rear door sash. Refer to [EXT-45, "Removal and Installation"](#).
4. Remove the rear door window and rear door screen assembly.
5. Remove door side grommet, and remove outside handle escutcheon bolt (TORX T30) from grommet hole.



6. While pulling the outside handle (1), remove outside handle escutcheon (2).



7. While pulling outside handle (1), slide toward rear of vehicle (2) to remove outside handle.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK


< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


8. Remove the front gasket and rear gasket.




9. Remove the TORX bolts (T30), remove the door lock assembly.



10. Remove the TORX bolt (T30) (A) from the outside handle bracket.



11. While pulling outside handle, slide toward rear of vehicle to remove outside handle.




12. Disconnect the door lock actuator connector and remove the door lock assembly.

DOOR LOCK

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

13. Disconnect the outside handle cable from the outside handle bracket.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INSTALLATION

Installation is in the reverse order of removal.

TRUNK LID

TRUNK LID ASSEMBLY

TRUNK LID ASSEMBLY : Removal and Installation

INFOID:000000005429277

REMOVAL

1. Remove trunk lid finisher. Refer to [JNT-47, "Removal and Installation"](#).
2. Disconnect the connectors in the trunk lid, and remove the harness clips to pull the harness out of the trunk lid.
3. Remove the bolts, and remove the trunk lid assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the hinge bolts.
- After installing, check operation.
- After installing, perform fitting adjustment. Refer to [DLK-457, "TRUNK LID ASSEMBLY : Adjustment"](#).

TRUNK LID




< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

TRUNK LID ASSEMBLY : Adjustment

INFOID:000000005429278

SEC. 843



- 1. Trunk lid assembly
- 2. Body side outer
- 3. Rear combination lamp
- 4. Rear bumper fascia
- 5. Trunk lid hinge assembly
- 6. Trunk lid latch assembly

↔ Front

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

AWKIA0452GB

TRUNK LID

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

Unit: mm (in)

Parts		Standard	Right/left clearance (MAX)
A – A	E	$4.0 \pm 1.0 (0.16 \pm 0.04)$	2.0 (0.08)
	F	$-0.5 \pm 1.0 (-0.02 \pm 0.04)$	2.0 (0.08)
B – B	G	$4.0 \pm 1.5 (0.16 \pm 0.06)$	2.0 (0.08)
	H	$-0.5 \pm 1.5 (-0.02 \pm 0.06)$	2.0 (0.08)
C – C	J	$4.0 \pm 2.0 (0.16 \pm 0.08)$	—
	K	$5.9 \pm 2.0 (0.23 \pm 0.08)$	—
D – D	K	$5.9 \pm 2.0 (0.23 \pm 0.08)$	—

LONGITUDINAL CLEARANCE

Trunk Lid Removed From Hinge

1. Check the clearance and the evenness between the trunk lid and each part by visual and tactile feeling.
2. Loosen the trunk lid to hinge bolts.
3. Move the trunk lid so that the clearance measurements are within specifications.
4. Tighten the trunk lid to hinge bolts.

Trunk Lid Hinge Removed From Vehicle

1. Remove the parcel shelf trim. Refer to [INT-39, "Removal and Installation"](#).
2. Loosen the hinge to parcel shelf bolts.
3. Move the trunk lid so that the clearance measurements are within specifications.
4. Tighten the hinge to parcel shelf bolts.
5. Install the parcel shelf trim. Refer to [INT-39, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the bumper rubber.
2. Loosen the striker bolts.
3. Lift up the trunk lid approx. 100 - 150 mm (3.94 - 5.91 in) height then close it lightly. Make sure it engages firmly with the trunk lid closed.
4. Finally tighten the trunk lid striker.

TRUNK LID LOCK

TRUNK LID LOCK : Removal and Installation

INFOID:000000005429279

LOCK

Removal

1. Remove the trunk lid inner trim panel. Refer to [INT-47, "Removal and Installation"](#).
2. Remove the bolts, disconnect the electrical connector, separate the emergency release handle, and remove the trunk lid lock

Installation

Installation is in the reverse order of removal.

Striker

Removal

1. Remove the trunk end finisher. Refer to [INT-47, "Removal and Installation"](#).
2. Remove the bolts and the striker.

Installation

Installation is in the reverse order of removal.

NOTE:

Align the trunk lid lock. Refer to [DLK-457, "TRUNK LID ASSEMBLY : Adjustment"](#).

FUEL FILLER LID


< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]

FUEL FILLER LID

Exploded View

INFOID:000000005429280



1. Fuel door latch
 2. Cable protector
 3. Fuel door opener cable
 4. Fuel door opener handle
- ⇐ Front

Removal and Installation

INFOID:000000005429281

DLK

REMOVAL

1. Remove the front and rear LH kicking plates. Refer to [INT-37, "Removal and Installation"](#).
2. Remove the rear seat. Refer to [SE-60, "Removal and Installation"](#).
3. Remove the LH front seat belt anchor. Refer to [SB-6, "Exploded View"](#).
4. Remove the LH center pillar lower finisher. Refer to [INT-36, "Exploded View"](#).
5. Position the carpet aside.
6. Remove the LH trunk side finisher. Refer to [INT-46, "Exploded View"](#).
7. Remove the fuel door opener handle and disconnect the fuel door opener cable.
8. Remove the fuel door latch and disconnect the fuel door opener cable.
9. Remove the fuel door opener cable.

INSTALLATION

Installation is in the reverse order of removal.

REMOTE KEYLESS ENTRY RECEIVER

< ON-VEHICLE REPAIR >

[SEDAN WITH INTELLIGENT KEY]


REMOTE KEYLESS ENTRY RECEIVER

Removal

INFOID:000000005429282

REMOVAL

1. Remove glove compartment. Refer to [IP-11, "Removal and Installation"](#).
2. Remove the screw (a), lower the bracket and remote keyless entry receiver (1), then disconnect the harness and remove the receiver.



Installation

INFOID:000000005429283

Installation is in the reverse order of removal.

DIAGNOSIS AND REPAIR WORKFLOW

[SEDAN WITHOUT INTELLIGENT KEY]

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005429284

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DETAILED FLOW

JMKIA2270GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[SEDAN WITHOUT INTELLIGENT KEY]

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT-III.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3

Symptom is described, DTC is not displayed>>GO TO 4

Symptom is not described, DTC is displayed>>GO TO 5

3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5

4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [DLK-554. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check. If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

Yes >> GO TO 7

No >> Refer to [GI-41. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to SYMPTOM TABLE based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

[SEDAN WITHOUT INTELLIGENT KEY]

< BASIC INSPECTION >

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

Is malfunctioning part detected?

YES >> GO TO 8

NO >> Check voltage of related BCM terminals using CONSULT-III.

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9

9. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is the inspection result normal?

NO (DTC is detected)>>GO TO 7

NO (Symptom remains)>>GO TO 6

YES >> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[SEDAN WITHOUT INTELLIGENT KEY]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005429285

Perform the system initialization when replacing BCM, replacing keyfob or registering an additional keyfob.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005429286

Refer to the CONSULT-III Operation Manual for the initialization procedure.

AUTOMATIC DOOR LOCKS


[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

AUTOMATIC DOOR LOCKS

System Diagram



System Description

INFOID:000000005429288

Input	Single	Function	Actuator
Door lock/unlock switch	Door lock/unlock signal	Door lock function	• Each door lock actuator
Door key cylinder switch			
Each door switch	Door open/close signal	Key reminder function	
Key slot	Key insert/remove signal		
Combination meter	Warning buzzer signal	Automatic door lock/unlock function	
	Vehicle speed signal		

DOOR LOCK FUNCTION

- The door lock and unlock switch (driver side) is build into power window main switch.
- The door lock and unlock switch (passenger side) is on door trim.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Door Key Cylinder

- With the door key inserted in the door key cylinder on driver side, turning it to "LOCK", will lock door lock actuator of all doors.
- With the door key inserted in the door key cylinder on driver side, turning it to "UNLOCK" once unlocks the driver side door lock actuator; turning it to "UNLOCK" again within 60 seconds after the first unlock operation unlocks all of the other doors. - (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using "DOOR LOCK-UNLOCK SET" mode in "WORK SUPPORT". Refer to [DLK-479. "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

AUTOMATIC DOOR LOCKS (LOCK OPERATION)

The automatic door locks function is the function that locks all doors linked with the vehicle speed or shift position.

Vehicle Speed Sensing Auto Door Lock*1

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

AUTOMATIC DOOR LOCKS

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

If a door is opened and closed at any time during one ignition cycle (OFF → ON), even after initial auto door lock operation has taken place, the BCM will relock all doors when the vehicle speed reaches 24 km/h (15 MPH) or more again.

Setting change of Automatic Door Locks (LOCK) Function

The LOCK operation setting of the automatic door locks function can be changed.

With CONSULT-III

The ON/OFF switching of the automatic door locks (LOCK) function and the type selection of the automatic door locks (LOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-479, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (LOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the ignition switch ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

AUTOMATIC DOOR LOCKS (UNLOCK OPERATION)

The automatic door locks (UNLOCK) function is the function that unlocks all doors linked with the key position or shift position.

IGN OFF Interlock Door Unlock*1

All doors are unlocked when the power supply position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

Setting change of Automatic Door Locks (UNLOCK) Function

The UNLOCK operation setting of the automatic door locks function can be changed.

With CONSULT- III

The ON/OFF switching of the automatic door locks (UNLOCK) function and the type selection of the automatic door locks (UNLOCK) function can be performed at the WORK SUPPORT setting of CONSULT-III. Refer to [DLK-479, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Without CONSULT- III

The automatic door locks (UNLOCK) function can be switched ON/OFF by performing the following operation.

1. Close all doors (door switch OFF)
2. Push the ignition switch to the ON position
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power supply position ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

5. The ignition switch must be turned OFF and ON again between each setting change.

*1: This function is set to ON before delivery.


AUTOMATIC DOOR LOCKS

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000005429289



- | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. BCM M16, M17, M18, M21
(view with instrument panel removed)</p> <p>4. Front door lock assembly LH D14
Front door lock actuator RH D108</p> <p>7. Rear door lock actuator LH D205
Rear door lock actuator RH D305</p> | <p>2. Main power window and door lock/unlock switch D8, D12</p> <p>5. Front door switch LH B8
Front door switch RH B108</p> <p>8. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28</p> | <p>3. Power window and door lock/unlock switch RH D110</p> <p>6. Rear door switch LH B18
Rear door switch RH B116</p> <p>9. Combination meter M24</p> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|

ALKIA1739Z2

Component Description

INFOID:000000005429290

Item	Function
BCM	Controls the door lock function and fuel lid door lock actuator function.
Door lock and unlock switch	Input lock or unlock signal to BCM.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Door key cylinder switch	<ul style="list-style-type: none"> Input lock or unlock signal to power window main switch. Power window main switch transmits door lock/unlock signal to BCM.
Key slot	Input key insert/remove signal to BCM.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTOMATIC DOOR LOCKS

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Item	Function
Combination meter	<ul style="list-style-type: none">• Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer.• Transmits vehicle speed signal to CAN communication line.
Push-button ignition switch	Input push-button ignition switch ON/OFF condition to BCM.


DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

DOOR LOCK FUNCTION

System Diagram



System Description

INFOID:000000005429292

Switch	Input/output signal to BCM	BCM function	Actuator
Main power window and door lock/unlock switch	Door lock/unlock signal	Door lock/unlock control	Door lock actuator
Power window and door lock/unlock switch			
Door key cylinder switch			

DOOR LOCK FUNCTION

Functions Available by Operating the Door Lock and Unlock Switches on Driver Door and Passenger Door

- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all door lock actuators are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all door lock actuators are unlocked.

Functions Available by Operating the Key Cylinder Switch on Driver Door

- Interlocked with the locking operation of door key cylinder, door lock actuators of all door lock actuators are locked.

Selective Unlock Operation

- When door key cylinder is unlocked, door lock actuator driver side is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

Select unlock operation mode can be changed using DOOR LOCK-UNLOCK SET mode in "WORK SUPPORT". Refer to [DLK-479, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).


DOOR LOCK FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Component Parts Location

INFOID:000000005429293



ALKIA1740ZZ

- | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| <p>1. BCM M16, M17, M18, M21
(view with instrument panel removed)</p> <p>4. Front door lock assembly LH D14
Front door lock actuator RH D108</p> <p>7. Rear door lock actuator LH D205
Rear door lock actuator RH D305</p> | <p>2. Main power window and door lock/unlock switch D8, D12</p> <p>5. Front door switch LH B8
Front door switch RH B108</p> <p>8. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28</p> | <p>3. Power window and door lock/unlock switch RH D110</p> <p>6. Rear door switch LH B18
Rear door switch RH B116</p> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|

Component Description

INFOID:000000005429294

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Transmits lock or unlock signal to BCM.
Door lock actuator	Receives lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Transmits door open/close condition to BCM.


REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

REMOTE KEYLESS ENTRY SYSTEM

System Diagram



System Description

The remote keyless entry system can be locked and unlocked by pressing door lock and unlock button of keyfob.

DOOR LOCK AND UNLOCK OPERATION

- When door lock and unlock button of keyfob is pressed, door lock and unlock signal transmits from keyfob to BCM via remote keyless entry receiver.
- When BCM receives the door lock and unlock signal, it operates door lock actuator, flashes the hazard lamp (lock: 2 times, unlock: 1 time) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 time) as a reminder.

OPERATION CONDITION

Remote controller operation	Operation condition
Lock/unlock	Key switch is OFF (keyfob is removed from key slot).

OPERATION AREA

To ensure that the keyfob works effectively, use within 100 cm (3ft) range of each door, however the operable range may differ according to surroundings.

SELECTIVE UNLOCK OPERATION

When door lock is unlocked, pressing LOCK button on keyfob once will lock all doors. When door lock is locked, pressing UNLOCK button on keyfob will unlock driver side door. Pressing UNLOCK button on keyfob second time within 5 seconds from the first time will unlock all doors.

HAZARD AND HORN REMINDER

When the doors are locked or unlocked by keyfob, power is supplied to sound horn and flash hazard warning lamps as a reminder

The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

How to Change Hazard and Horn Reminder Modes

Ⓟ With CONSULT-III

Hazard and horn reminders can be changed using "WORK SUPPORT" mode in "MULTI ANSWER BACK SET".

REMOTE KEYLESS ENTRY SYSTEM

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Hazard reminder setting	Mode 1		Mode 2		Mode 3		Mode 4	
Keyfob operation	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Hazard warning lamp blink	—	—	—	Once	Twice	—	Twice	Once

Horn reminder setting	ON			OFF		
Keyfob operation	Lock		Unlock	Lock		Unlock
Horns sound	Once		—	—		—

Hazard and horn reminders do not operate if any door switch is ON (any door is OPEN).

Hazard reminder can be changed using "HAZARD LAMP SET" mode in "WORK SUPPORT".

Horn reminder can be changed using "HORN CHIRP SET" mode in "WORK SUPPORT".

Refer to [DLK-479, "MULTI REMOTE ENT : CONSULT-III Function \(BCM - MULTIREMOTE ENT\)"](#).

⊗ Without CONSULT-III

Refer to Owner's Manual for instructions.

AUTO DOOR LOCK OPERATION

When all doors are locked, ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (keyfob is not inserted in key slot), doors are unlocked with keyfob button. When BCM does not receive the following signals within 1 minute, all doors are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON
- Key switch is ON (keyfob is inserted in key slot)

Auto door lock mode can be changed by "AUTO LOCK SET" mode in "WORK SUPPORT". Refer to [DLK-479, "MULTI REMOTE ENT : CONSULT-III Function \(BCM - MULTIREMOTE ENT\)"](#).

PANIC ALARM OPERATION

When key switch is OFF (when keyfob is not inserted in key slot), BCM turns ON and OFF horn intermittently with input of PANIC ALARM signal from keyfob.

BCM outputs to IPDM E/R for panic alarm signal (horn signal) via CAN communication lines.

The alarm automatically turns OFF after 25 seconds or when BCM receives any signal from keyfob.

Panic alarm operation mode can be changed using "PANIC ALARM SET" mode in "WORK SUPPORT".

Refer to [DLK-479, "MULTI REMOTE ENT : CONSULT-III Function \(BCM - MULTIREMOTE ENT\)"](#).

INTERIOR LAMP TIMER OPERATION

When the following conditions occur, remote keyless entry system turns on interior lamp with input of UNLOCK signal from keyfob. For detailed description, refer to [INL-6, "System Description"](#).

- Interior room lamp switch is in the DOOR position
- Door switch OFF (when all the doors are closed)

DOOR LOCK OPERATION WARNING

Outside warning buzzer will sound, when keyfob LOCK button is pressed with either one of the following conditions.

- Any door is open
- For 3 seconds after keyfob is removed from key slot

KEYFOB LOW BATTERY WARNING

Warning lamp is illuminated; when BCM detects keyfob low battery after ignition switch is turned ON.



REMOTE KEYLESS ENTRY SYSTEM

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Component Parts Location

INFOID:000000005429297




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKTA22937Z

REMOTE KEYLESS ENTRY SYSTEM

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]



ABKIA2294ZZ

- | | | |
|-----------------------------------------------------------------------------|-------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| 1. Horn (high) E216
(view with front fender protector LH removed) | 2. IPDM E/R E17, E18 | 3. Fuse and fusible link box (horn relay H-1) |
| 4. Outside warning buzzer E73 | 5. Remote keyless entry receiver M27
(view with instrument panel removed) | 6. Combination meter M24 |
| 7. BCM M16, M17, M18, M19, M20, M21
(view with instrument panel removed) | 8. Stop lamp switch E38 | 9. Push button ignition switch M38 |
| 10. Key slot M40 | 11. Front console antenna M203
(view with center console assembly removed) | 12. Front door switch LH B8
Front door switch RH B108 |
| 13. Rear door switch LH B18
Rear door switch RH B116 | 14. Rear parcel shelf antenna B29 | 15. Trunk lamp switch and trunk release solenoid (trunk lamp switch) B28 |

Component Description

INFOID:0000000005429298

Item	Function
BCM	Controls the door lock and unlock function.
Key slot	Detects that keyfob is inserted into key slot.
Door lock actuator	Output lock / unlock signal from BCM and locks and unlocks each door.
Remote keyless entry receiver	Receives lock/unlock signal from the keyfob, and then transmits to BCM.
Keyfob	Transmits button operation to remote keyless entry receiver.


TRUNK OPEN FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

TRUNK OPEN FUNCTION

System Diagram



System Description

INFOID:000000005429300

Switch	Input/output signal to BCM	BCM function	Actuator
Trunk lid opener switch	Trunk open signal	Trunk open control	Trunk lid opener actuator
Trunk lid opener cancel switch			

TRUNK LID OPENER OPERATION

When trunk lid opener switch is ON, BCM opens trunk opener actuator.

BCM can open trunk lid opener actuator when

- vehicle speed is less than 5 km/h (3MPH)
- vehicle security system is disarmed or pre-armed phase

BCM does not open trunk lid opener actuator when

- trunk lid opener cancel switch is OFF (CANCEL)
- vehicle speed is more than 5 km/h (3MPH)
- vehicle security system is armed or alarm phase
- Within 3 seconds of removing the keyfob from the key slot

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


TRUNK OPEN FUNCTION

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Component Parts Location

INFOID:000000005429301



- 1. BCM M16, M17, M18, M20, M21
- 2. Trunk lid opener switch M75
- 3. Trunk lid opener cancel switch M74
- 4. Trunk lamp switch and trunk release solenoid (trunk release solenoid) B28

Component Description

INFOID:000000005429302

Item	Function
BCM	Transmits trunk open operation to BCM.
Trunk lid opener switch	Transmits trunk open operation to BCM.
Trunk release solenoid	Opens the trunk with the open signal from BCM
Trunk lid opener cancel switch	Cancels the trunk open operation.

HOMELINK UNIVERSAL TRANSCEIVER

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

HOMELINK UNIVERSAL TRANSCEIVER

Component Description

INFOID:000000005429303

Item	Function	Reference page
Homelink universal transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.	Refer to Owner's Manual

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : Diagnosis Description

INFOID:000000005783612

BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF DIAGNOSTIC RESULT	Displays the diagnosis results judged by BCM.
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none">Read and save the vehicle specification.Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system ¹	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioner	AIR CONDITONER		×	
Intelligent Key system ²	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
BCM	BCM	×		
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

1 : With remote keyless entry system

2: With intelligent Key system

COMMON ITEM : CONSULT-III Function

INFOID:000000005783613

ECU IDENTIFICATION

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Displays the BCM part No.

SELF-DIAG RESULT

Refer to [BCS-70, "DTC Index"](#).

DOOR LOCK

DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)

INFOID:000000005783614

WORK SUPPORT

Work Item	Description
DOOR LOCK-UNLOCK SET	<ul style="list-style-type: none">• ON• OFF
AUTOMATIC DOOR LOCK SELECT	<ul style="list-style-type: none">• P RANGE• VH SPD
AUTOMATIC DOOR UNLOCK SELECT	<ul style="list-style-type: none">• MODE1• MODE2• MODE3• MODE4
AUTOMATIC LOCK/UNLOCK SELECT	<ul style="list-style-type: none">• LOCK/UNLOCK• LOCK ONLY• UNLOCK ONLY• OFF

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW-DR [ON/OFF]	Indicates condition of door request switch LH
REQ SW-AS [ON/OFF]	Indicates condition of door request switch RH
REQ SW-BD/TR [ON/OFF]	Indicates condition of back door request switch
DOOR SW-DR [ON/OFF]	Indicates condition of front door switch LH
DOOR SW-AS [ON/OFF]	Indicates condition of front door switch RH
DOOR SW-RR [ON/OFF]	Indicates condition of rear door switch RH
DOOR SW-RL [ON/OFF]	Indicates condition of rear door switch LH
DOOR SW-BK [ON/OFF]	Indicates condition of back door switch
KEY CYL LK-SW [ON/OFF]	Indicates condition of lock signal from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Indicates condition of unlock signal from door key cylinder switch
CDL LOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Indicates condition of door lock and unlock switch

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [OTR ULK / AS UNLK / DR UNLK / ALL UNLK / ALL LCK].

MULTI REMOTE ENT

MULTI REMOTE ENT : CONSULT-III Function (BCM - MULTIREMOTE ENT)

INFOID:000000005783614

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Monitor Item	Condition
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
CDL LOCK SW	Indicates [ON/OFF] condition of door lock and unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of door lock and unlock switch.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from keyfob.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from keyfob.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from keyfob.
RKE-PANIC	Indicates [ON/OFF] condition of PANIC button of keyfob.
RKE-P/W OPEN	Indicates [ON/OFF] condition of P/W DOWN signal from keyfob.
RKE-MODE CHG	Indicates [ON/OFF] condition of MODE CHANGE signal from keyfob.
KEY CYL LK-SW	Indicated [ON/OFF] condition of lock signal from door key cylinder.
KEY CYL UN-SW	Indicated [ON/OFF] condition of unlock signal from door key cylinder.

ACTIVE TEST

Test item	Description
INT LAMP	This test is able to check interior room lamp operation. The interior room lamp will be activated after "ON" on CONSULT-III screen is touched.
DOOR LOCK	This test is able to check door lock/unlock operation. <ul style="list-style-type: none">• The all door lock actuators are locked when "ALL LCK" on CONSULT-III screen is touched.• The all door lock actuators are unlocked when "ALL UNLK" on CONSULT-III screen is touched.• The door lock actuator (driver side) is unlocked when "DR UNLK" on CONSULT-III screen is touched.• The door lock actuator (passenger side) is unlocked when "AS UNLK" on CONSULT- III screen is touched.• The door lock actuator (rear LH and RH) is unlocked when "OTR ULK" on CONSULT-III screen is touched.
FLASHER	This test is able to check flasher operation [LH/RH/OFF].
HORN	This test is able to check horn operation [ON/OFF].
TRUNK/GLASS HATCH	This test is able to check trunk lid opener actuator open operation. This actuator opens when "ON" on CONSULT-III screen is touched.

WORK SUPPORT

Test item	Description
DOOR LOCK-UNLOCK SET	Selective unlock function mode can be changed to operate (WITH) or not operate (WITHOUT) with this mode.
HORN CHIRP SET	Answer back function (horn) mode can be changed in this mode. For the detail of the setting.
HAZARD LAMP SET	Answer back function (hazard) mode can be changed in this mode. <ul style="list-style-type: none">• MODE1: Non-operation• MODE2: Lock (non-operation) Unlock (blink once)• MODE3: Lock (blink twice) Unlock (non-operation)• MODE4: Lock (blink twice) Unlock (blink once)
AUTO LOCK SET	Auto door lock time can be changed in this mode. <ul style="list-style-type: none">• MODE 1: 1 minute• MODE 2: 5 minutes

DIAGNOSIS SYSTEM (BCM)

[SEDAN WITHOUT INTELLIGENT KEY]

< FUNCTION DIAGNOSIS >

Test item	Description
PANIC ALARM SET	Panic alarm button pressing time on keyfob remote control button can be selected from the following with this mode. <ul style="list-style-type: none">• MODE1: 0.5 sec.• MODE2: 1.5 sec.• MODE3: Non-operation
PW DOWN SET	Unlock button pressing time on keyfob button can be selected from the following with this mode. <ul style="list-style-type: none">• MODE 1: 3 sec.• MODE 2: Non-operation• MODE 3: 5 se

TRUNK

TRUNK : CONSULT-III Function (BCM - TRUNK)

INFOID:000000005783618

DATA MONITOR

Monitor Item	Contents
PUSH SW	Indicates [ON/OFF] condition of push button ignition switch.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
VEH SPEED 1	Indicates [mph] condition of vehicle speed signal from combination meter.
TR CANCEL SW	Indicates [ON/OFF] condition of trunk cancel switch.
TR/BD OPEN SW	Indicates [ON/OFF] condition of trunk opener switch.
TRNK/HAT MNTR	Indicates [ON/OFF] condition of trunk lid.
RKE-TR/BD	Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
TRUNK/GLASS HATCH	This test is able to check trunk open operation. Trunk opens when "OPEN" on CONSULT-III screen is touched.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000005429309

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-26, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000005429310

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1000	CAN COMM CIRCUIT	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none">• Transmission• Receiving (ECM)• Receiving (VDC/TCS/ABS)• Receiving (METER/M&A)• Receiving (TCM)• Receiving (MULTI AV)• Receiving (IPDM E/R)

Diagnosis Procedure

INFOID:000000005429311

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-8, "CAN Communication Control Circuit"](#).
NO >> Refer to [GI-41, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000005429312

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1010	CONTROL UNIT (CAN)	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:000000005429313

1. REPLACE BCM

When DTC [U1010] is detected, replace BCM.

>> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000005429314

1. REQUIRED WORK WHEN REPLACING BCM

Initialize NVIS by CONSULT-III. For the details of initialization refer to CONSULT-III Operation Manual.

>> Work End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2622 INSIDE KEY ANTENNA 2

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

B2622 INSIDE KEY ANTENNA 2

Description

INFOID:000000005429318

Detects whether keyfob is inside the vehicle.
Installed in the console.

DTC Logic

INFOID:000000005429319

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none">• Front console antenna• Between BCM and front console antenna.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT-III

1. Perform front console antenna INSIDE ANT DIAGNOSIS on "Work Support" of "MULTI REMOTE ENTRY".
2. Perform "MULTI REMOTE ENTRY" Self Diagnostic Result.

Is front console antenna DTC detected?

- YES >> Refer to [DLK-484, "Diagnosis Procedure"](#).
NO >> Front console antenna is OK.


Diagnosis Procedure

INFOID:000000005429320

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).

1. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



B2622 INSIDE KEY ANTENNA 2

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M19	Front console antenna	61	Ground	Place keyfob inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
			Ground	Place keyfob outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
- NO >> GO TO 2


2. CHECK FRONT CONSOLE ANTENNA CIRCUIT

1. Disconnect BCM and front console antenna connector.
2. Check continuity between BCM connector and front console antenna connector.

BCM connector	Terminal	Front console antenna connector		Terminal	Continuity
A: M19	60	B: M41	Console	2	Yes
	61			1	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	Console		60
		61	



Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and front console antenna.

3. CHECK FRONT CONSOLE ANTENNA INPUT SIGNAL 2


1. Replace front console antenna (new antenna or other antenna).
2. Connect BCM and front console antenna connector.

B2622 INSIDE KEY ANTENNA 2

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M19	Front console antenna	61	Ground	Place keyfob inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Place keyfob outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Replace front console antenna. Refer to [IP-17. "Disassembly and Assembly"](#).
 NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

B2623 INSIDE KEY ANTENNA 3

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

B2623 INSIDE KEY ANTENNA 3

Description

INFOID:000000005429321

Detects whether keyfob is inside the vehicle.
Installed in the trunk room.

DTC Logic

INFOID:000000005429322

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3 CIRCUIT	An excessive high or low voltage from rear parcel shelf antenna is sent to BCM.	<ul style="list-style-type: none">rear parcel shelf antennaBetween BCM and rear parcel shelf antenna

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-III

- Perform rear parcel shelf antenna INSIDE ANT DIAGNOSIS on "Work Support" of "MULTI REMOTE ENTRY".
- Perform "MULTI REMOTE ENTRY" Self Diagnostic Result.

Is rear parcel shelf antenna DTC detected?

- YES >> Refer to [DLK-487, "Diagnosis Procedure"](#).
NO >> Rear parcel shelf antenna is OK.


Diagnosis Procedure

INFOID:000000005429323

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).

1. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 1

- Turn ignition switch OFF.
- Check signal between BCM connector and ground with oscilloscope.



B2623 INSIDE KEY ANTENNA 3

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Terminals				Condition	Signal (Reference value.)
(+)		(-)			
BCM connector	Terminal				
M21	Rear parcel shelf antenna	115	Ground	Place keyfob inside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Place keyfob outside the vehicle.	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

Is the inspection result normal?

- YES >> Check the condition of harness and connector.
- NO >> GO TO 2


2. CHECK REAR PARCEL SHELF ANTENNA CIRCUIT

1. Disconnect BCM and rear parcel shelf antenna connector.
2. Check continuity between BCM connector and rear parcel shelf antenna connector.

BCM connector	Terminal	Rear parcel shelf antenna connector		Terminal	Continuity
A: M21	114	B: B29	Trunk room	2	Yes
	115			1	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	Trunk room		114 115



Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness between BCM and rear parcel shelf antenna.

3. CHECK REAR PARCEL SHELF ANTENNA INPUT SIGNAL 2


1. Replace rear parcel shelf antenna (new antenna or other antenna).
2. Connect BCM and rear parcel shelf antenna connector.

B2623 INSIDE KEY ANTENNA 3

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

3. Check signal between BCM connector and ground with oscilloscope.



Terminals			Condition	Signal (Reference value.)	
(+)		(-)			
BCM connector	Terminal				
M21	Trunk room	115	Ground	Place keyfob inside the vehicle.	
				Place keyfob outside the vehicle.	

Is the inspection result normal?

- YES >> Replace rear parcel shelf antenna. Refer to [INT-39. "Removal and Installation"](#).
- NO >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000005783601

Regarding Wiring Diagram information, refer to [BCS-75, "COUPE : Wiring Diagram"](#) or [BCS-84, "SEDAN : Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check if the following BCM fuse or fusible link are blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	H
11		10


Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
 NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground
Connector	Terminal	
M16	1	
M17	11	
		Battery voltage



Is the measurement normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	13		Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



Special Repair Requirement

INFOID:000000005783602

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-6, "CONFIGURATION \(BCM\) : Special Repair Requirement"](#).

>> Work End.

DOOR SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR SWITCH

Description

INFOID:000000005429326

Detects door open/close condition.

Component Function Check

INFOID:000000005429327

1. CHECK FUNCTION

With CONSULT-III

Check door switches DOOR SW-DR, DOOR SW-AS, DOOR SW-RL, DOOR SW-RR in Data Monitor mode with CONSULT-III.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	
DOOR SW-RL	
DOOR SW-RR	

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [DLK-491](#). "Diagnosis Procedure".


Diagnosis Procedure

INFOID:000000005429328

Regarding Wiring Diagram information, refer to [DLK-562](#). "Wiring Diagram".

1. CHECK DOOR SWITCH INPUT SIGNAL





1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.



DOOR SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Terminals		(-)	Door condition		Voltage (V) (Approx.)
(+)					
BCM connector	Terminal				
A: M18	58	Ground	Driver side	OPEN	0
				CLOSE	
	32		Passenger side	OPEN	0
				CLOSE	
B: M21	148	Ground	Rear RH	OPEN	0
				CLOSE	
	149		Rear LH	OPEN	0
				CLOSE	

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.


DOOR SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

- Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
A: M18	58	C: B8 (Driver side)	2	Yes
	32	C: B108 (Passenger side)		
B: M21	148	C: B116 (Rear RH)		
	149	C: B18 (Rear LH)		



- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	58	Ground	No
	32		
B: M21	148		
	149		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and door switch.

3.CHECK DOOR SWITCH

Refer to [DLK-493, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace malfunctioning door switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429329

1.CHECK DOOR SWITCH


- Turn ignition switch OFF.
- Disconnect door switch connector.
- Check door switch.

Terminal	Door switch condition	Continuity
2	Pressed	No
	Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning door switch.



DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005429330

Transmits door lock/unlock operation to BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005429331

1.CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.
 NO >> Refer to [DLK-494, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005429332

Regarding Wiring Diagram information, refer to [DLK-562, "Wiring Diagram"](#).

1.CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

- Turn ignition switch ON.
- Check voltage at the main power window and door lock/unlock switch connector when the switch (driver side) is turned to "LOCK" or "UNLOCK".


Connector	Main power window and door lock/unlock switch state	Terminal	Voltage
D8	Neutral → Lock	18	Ground Battery voltage → 0
D12	Neutral → Unlock	6	

Is the inspection result normal?

- YES >> GO TO 5
 NO >> GO TO 2

2.CHECK POWER WINDOW SWITCH GROUND

- Turn ignition switch OFF.
- Disconnect main power window and door lock/unlock switch connector.



ALKIA0335Z2

DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
	D8	17	
	17	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.




3.CHECK POWER WINDOW SWITCH

Check continuity between main power window and door lock/unlock switch terminals.

Main power window and door lock/unlock switch state	Terminals	Continuity
Lock	17 - 18	Yes
Unlock	6 - 17	
Neutral/Lock	6 - 17	No
Neutral/Unlock	17 - 18	

Is the inspection result normal?


- YES >> GO TO 4
NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-163, "Removal and Installation"](#) (LH only anti-pinch) or [PWC-355, "Removal and Installation"](#) (LH & RH front anti-pinch).



4.CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.
2. Check continuity between BCM connector and main power window and door lock/unlock switch connector.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
A: M18	36	B: D8	18	Yes
	39	C: D12	6	



3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	36	No
	39	

Is the inspection result normal?

- YES >> GO TO 5
NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005429333

Transmits door lock/unlock operation to BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005429334

1. CHECK FUNCTION

With CONSULT-III

Check CDL LOCK SW, CDL UNLOCK SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-496. "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure


INFOID:000000005429335

Regarding Wiring Diagram information, refer to [DLK-562. "Wiring Diagram"](#).

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

- Turn ignition switch ON.
- Check voltage at the power window and door lock/unlock switch RH connector when the switch (passenger side) is turned to "LOCK" or "UNLOCK".

Connector	Power window and door lock/unlock switch RH state	Terminal		Voltage
D110	Neutral → Lock	2	Ground	Battery voltage → 0
	Neutral → Unlock	1		



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK POWER WINDOW SWITCH GROUND

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH connector.

DOOR LOCK AND UNLOCK SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

3. Check continuity between power window and door lock/unlock switch RH connector and ground.

Power window and door lock/unlock switch RH connector	Terminal		Continuity
D110	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.




3.CHECK POWER WINDOW SWITCH

Check continuity between power window and door lock/unlock switch RH terminals.

Power window and door lock/unlock switch RH state	Terminals	Continuity
Lock	2 - 3	Yes
Unlock	1 - 3	
Neutral/Unlock	2 - 3	No
Neutral/Lock	1 - 3	

Is the inspection result normal?


- YES >> GO TO 4
 NO >> Replace power window and door lock/unlock switch RH.



4.CHECK POWER WINDOW SWITCH CIRCUITS

1. Disconnect BCM connector.
2. Check continuity between BCM connector and power window and door lock/unlock switch RH connector.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
A: M18	36	B: D110	1	Yes
	39		2	



3. Check continuity between BCM connector and ground.

BCM connector	Terminal		Continuity
A: M18	36	Ground	No
	39		

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

KEY SLOT

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

KEY SLOT

Description

INFOID:000000005429336

Detects whether keyfob is inserted.
Immobilizer antenna amp checks keyfob transponder.

Component Function Check

INFOID:000000005429337

1. CHECK FUNCTION

With CONSULT-III

Check KEY SW -SLOT in Data Monitor mode with CONSULT-III.

Monitor item	Condition
KEY SW-SLOT	Key is inserted in key slot: ON
	Key is removed from key slot: OFF

Is the inspection result normal?

- YES >> Key slot is OK.
NO >> Refer to [DLK-498, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429338

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).

1. CHECK KEY SLOT POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect key slot connector.
- Check voltage between key slot connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Key slot connector	Terminal	Ground
M40	1	
	5	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace key slot power supply circuit.

2. CHECK KEY SLOT GROUND CIRCUIT

Check continuity between key slot connector and ground.



Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace key slot ground circuit.

3. CHECK KEY SLOT CIRCUIT

- Disconnect BCM connector.



KEY SLOT

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

2. Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M18	29	C: M40	11	Yes
B: M19	68		2	
	69		3	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M18	29	No
B: M19	68	
	69	

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness between BCM and key slot.

4. CHECK KEY SLOT

Refer to [DLK-499, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace key slot.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429339

1. CHECK KEY SLOT



Check key slot.

Terminal		Condition	Continuity
Key slot			
1	11	Keyfob inserted	Yes
		Keyfob removed	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace key slot. Refer to [SEC-362, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

KEY CYLINDER SWITCH

Description

INFOID:000000005429340

For vehicles equipped with LH and RH anti-pinch system, the main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

For vehicles equipped with LH anti-pinch system only, the front door lock assembly LH (key cylinder switch) transmits the LOCK or UNLOCK signal directly to the BCM.

Component Function Check

INFOID:000000005429341

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check KEY CYL UN-SW, KEY CYL UN-SW in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-461. "Work Flow"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

- YES >> Key cylinder switch is OK.
 NO >> Refer to [DLK-500. "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429342

Regarding Wiring Diagram information, refer to [DLK-562. "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch ON.
- Check voltage between BCM connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	56	Lock	0
		Neutral / Unlock	5
	34	Unlock	0
		Neutral / Lock	5



Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [DLK-619. "FRONT DOOR LOCK : Removal and Installation"](#).
 NO >> GO TO 2

2. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect front door lock assembly LH (key cylinder switch) connector.

KEY CYLINDER SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

- Check continuity between front door lock assembly LH (key cylinder switch) connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	4		Yes

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.



3. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Disconnect BCM connector M18.
- Check continuity between front door lock assembly LH (key cylinder switch) connector and BCM connector M18.


Front door lock assembly LH connector	Terminal	BCM connector	Terminal	Continuity
A: D14	5	B: M18	34	Yes
	6		56	

- Check continuity between front door lock assembly LH (key cylinder switch) connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
A: D14	5		No
	6	No	

Is the inspection result normal?

- YES >> GO TO 4
NO >> Repair or replace harness.



4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-501. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-619. "FRONT DOOR LOCK : Removal and Installation"](#).

Component Inspection


INFOID:000000005429343

COMPONENT INSPECTION

1. CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly LH (key cylinder switch).

Terminal	Key position	Continuity
Front door lock assembly LH (key cylinder switch) connector		
5	Unlock	Yes
	Neutral / Lock	No
6	Lock	Yes
	Neutral / Unlock	No



A
B
C
D
E
F
G
H
I
J

DLK

L
M

N
O
P

KEY CYLINDER SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-619, "FRONT DOOR LOCK : Removal and Installation"](#).

TRUNK LID OPENER SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER SWITCH

Description

INFOID:000000005429344

Transmits trunk lid open signal to BCM.

Component Function Check

INFOID:000000005429345

1.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Does trunk lid opener cancel switch turn ON (CANCEL)?

- Yes >> Turn off trunk lid opener cancel switch.
- No >> GO TO 2

2.CHECK FUNCTION

With CONSULT-III

Check trunk lid opener switch TR/BD OPEN SW in Data Monitor mode with CONSULT-III.

- When trunk lid opener switch is turned to "ON".

Monitor item	Condition
TR/BD OPEN SW	Trunk lid opener switch is pressed: ON
	Trunk lid opener switch is released: OFF

Is the inspection result normal?

- YES >> Trunk lid opener switch is OK.
- NO >> Refer to [DLK-503. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429346

Regarding Wiring Diagram information, refer to [DLK-560. "Wiring Diagram"](#).

1.CHECK TRUNK LID OPEN INPUT SIGNAL

1. Remove keyfob from key slot.
2. Turn on trunk lid opener cancel switch.
3. Check voltage between BCM connector and ground.


Terminals		Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	ON (press and hold)	0
M21	147		
	Ground	OFF (release)	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

2.CHECK TRUNK LID OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TRUNK LID OPENER SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lid opener switch connector.

BCM connector	Terminal	Trunk lid opener switch connector	Terminal	Continuity
A: M21	147	B: M75	1	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	147		No

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair harness or connector.

3. CHECK TRUNK LID OPENER SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener switch	Terminal	Ground	Continuity
M75	2		Yes

Is the inspection result normal?

- YES >> GO TO 4
NO >> Repair or replace harness.

4. CHECK TRUNK LID OPENER SWITCH

Refer to [DLK-504, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
NO >> Replace trunk lid opener switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429347




1. CHECK TRUNK LID OPENER SWITCH

- Turn ignition switch OFF.
- Disconnect trunk lid opener switch connector.
- Check continuity between trunk lid opener switch connector.

Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON (press and hold)	Yes
		OFF (release)	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace trunk lid opener switch.



TRUNK LID OPENER CANCEL SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER CANCEL SWITCH

Description

INFOID:000000005429348

Cancels trunk lid open operation.

Component Function Check

INFOID:000000005429349

1.CHECK FUNCTION

With CONSULT-III

Check trunk lid opener cancel switch TR CANCEL SW in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TR CANCEL SW	Trunk lid opener cancel switch is turned to "ON": ON
	Trunk lid opener cancel switch is turned to "OFF": OFF

Is the inspection result normal?

- YES >> Trunk lid opener cancel switch is OK.
- NO >> Refer to [DLK-505, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429350


Regarding Wiring Diagram information, refer to [DLK-560, "Wiring Diagram"](#).

1.CHECK TRUNK LID OPENER CANCEL SIGNAL

Check voltage between BCM connector and ground.



DLK

Terminals		(-)	Condition of trunk lid opener cancel switch	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector		Ground	ON	0
M18	37		OFF	

JPMIA0012GB

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2

TRUNK LID OPENER CANCEL SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. CHECK TRUNK LID OPENER CANCEL SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and trunk lid opener cancel switch connector.

BCM connector	Terminal	Trunk lid opener cancel switch connector	Terminal	Continuity
A: M18	37	B: M74	1	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M18	37		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair harness or connector.

3. CHECK TRUNK LID OPENER CANCEL SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch connector and ground.

Trunk lid opener cancel switch	Terminal	Ground	Continuity
M74	2		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4. CHECK TRUNK LID OPENER CANCEL SWITCH

Refer to [DLK-506, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace trunk lid opener cancel switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429351

1. CHECK TRUNK LID OPENER CANCEL SWITCH




1. Disconnect trunk lid opener cancel switch connector.
2. Check continuity between trunk lid opener cancel switch terminals.

Terminal		Condition	Continuity
Trunk lid opener switch			
1	2	ON	Yes
		OFF (cancel)	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trunk lid opener cancel switch.



TRUNK ROOM LAMP SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK ROOM LAMP SWITCH

Description

INFOID:000000005429352

Detects trunk open/close condition.

Component Function Check

INFOID:000000005429353

1. CHECK FUNCTION

With CONSULT-III

Check TRNK/HAT MNTR in Data Monitor mode with CONSULT-III.

Monitor item	Condition
TRNK/HAT MNTR	OPEN : ON
	CLOSE : OFF

Is the inspection result normal?

- YES >> Trunk room lamp switch is OK.
- NO >> Refer to [DLK-507, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429354


Regarding Wiring Diagram information, refer to [DLK-562, "Wiring Diagram"](#).

1. CHECK TRUNK LAMP SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector and ground.

Terminals		Trunk condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal	OPEN	0
M21	130	CLOSE	

JPMIA0011GB



Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2. CHECK TRUNK LAMP SWITCH CIRCUIT

1. Disconnect BCM and trunk lamp switch and trunk release solenoid connectors.

TRUNK ROOM LAMP SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M21	130	B: B28	2	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	130		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and trunk lamp switch and trunk release solenoid.

3. CHECK TRUNK LAMP SWITCH GROUND CIRCUIT

Check continuity between trunk lid lock assembly connector and ground.

Trunk lamp switch and trunk release solenoid connector	Terminal	Ground	Continuity
B28	3		Yes




Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace trunk lamp switch and trunk release solenoid ground circuit.

4. CHECK BCM OUTPUT SIGNAL

- Insure trunk remains closed during this step.
- Connect BCM connector.
- Check voltage between BCM connector and ground.



Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	130	Ground

JFMI A0011GB

TRUNK ROOM LAMP SWITCH

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).

5. CHECK TRUNK ROOM LAMP SWITCH

Refer to [DLK-509, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace trunk lamp switch and trunk release solenoid.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429355

1. CHECK TRUNK LAMP SWITCH


1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check trunk lamp switch.

Terminal		Trunk condition	Continuity
Trunk lamp switch and trunk release solenoid			
2	3	OPEN	Yes
		CLOSE	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trunk lamp switch and trunk release solenoid.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005429356

Locks/unlocks the door with the signal from BCM.

DRIVER SIDE : Component Function Check

INFOID:000000005429357

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-510, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005429358

Regarding Wiring Diagram information, refer to [DLK-562, "Wiring Diagram"](#).

1.CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	9	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3
 NO >> GO TO 2

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and front door lock actuator driver side connector.
3. Check continuity between BCM connector and front door lock actuator driver side connector.



BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D14	1	Yes
	9		2	

4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	No
	9	

Is the inspection result normal?

- YES >> Replace front door lock actuator LH.



DOOR LOCK ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005429359

Locks/unlocks the door with the signal from BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000005429360

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-511, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005429361

Regarding Wiring Diagram information, refer to [DLK-562, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.

Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	5	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

YES >> GO TO 3

NO >> GO TO 2



2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and front door lock actuator RH connectors.
2. Check continuity between BCM connector and front door lock actuator RH.

BCM connector	Terminal	Front door lock actuator RH connector	Terminal	Continuity
A: M17	8	B: D108	5	Yes
	5		6	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity



DOOR LOCK ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

A: M17	8	Ground	No
	5		

Is the inspection result normal?

- YES >> Replace front door lock actuator RH.
- NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

REAR LH

REAR LH : Description

INFOID:000000005429362

Locks/unlocks the door with the signal from BCM.

REAR LH : Component Function Check

INFOID:000000005429363

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
- NO >> Refer to [DLK-512. "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000005429364

Regarding Wiring Diagram information, refer to [DLK-562. "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.


Terminals		Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M17	8	Lock	0 → Battery voltage → 0
	10	Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3
- NO >> GO TO 2

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and rear door lock actuator LH connectors.



ALKIA0405Z2

DOOR LOCK ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and rear door lock actuator LH connectors.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D205	1	Yes
	10		2	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	Ground
	10	



Is the inspection result normal?

- YES >> Replace rear door lock actuator LH.
- NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

REAR RH

REAR RH : Description

INFOID:000000005429365

Locks/unlocks the door with the signal from BCM.

REAR RH : Component Function Check

INFOID:000000005429366

1. CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
- NO >> Refer to [DLK-513. "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000005429367

Regarding Wiring Diagram information, refer to [DLK-562. "Wiring Diagram"](#).


1. CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector and ground.

Terminals		(-)	Condition of door lock and unlock switch	Voltage (V) (Approx.)
(+)				
BCM connector	Terminal			
M17	8	Ground	Lock	0 → Battery voltage → 0
	10		Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3



ALKIA040522

DOOR LOCK ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

NO >> GO TO 2

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM and rear door lock actuator RH connectors.
2. Check continuity between BCM connector and rear door lock actuator RH connectors.

BCM connector	Terminal	Door lock actuator connector	Terminal	Continuity
A: M17	8	B: D305	5	Yes
	10		6	

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M17	8	No
	10	


Is the inspection result normal?

- YES >> Replace rear door lock actuator RH.
 NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.



TRUNK LID OPENER ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

TRUNK LID OPENER ACTUATOR

Description

INFOID:000000005429368

Performs trunk lid open with signal from BCM.

Component Function Check

INFOID:000000005429369

1.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch position.

Is trunk lid opener cancel switch turned OFF (CANCEL)?

- Yes >> Turn on trunk lid opener cancel switch.
- No >> GO TO 2.

2.CHECK FUNCTION

1. Perform Active Test TRUNK/GLASS HATCH with CONSULT-III.
2. Touch "OPEN" and check that trunk lid opens.

Is the inspection result normal?

- YES >> Trunk lid opener actuator is OK.
- NO >> Refer to [DLK-515. "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429370

Regarding Wiring Diagram information, refer to [DLK-560. "Wiring Diagram"](#).

1.CHECK OUTPUT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid connector.
3. Check voltage between trunk lamp switch and trunk release solenoid connector and ground.

Terminals			Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)		(-)		
Trunk lamp switch and trunk release solenoid connector	Terminal			
B28	3	Ground	OFF → ON	0 → Battery voltage → 0




Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

2.CHECK OUTPUT SIGNAL

Check voltage between BCM connector and ground.

Terminals			Condition of trunk lid opener switch	Voltage (V) (Approx.)
(+)		(-)		
BCM connector	Terminal			
M20	103	Ground	OFF → ON	0 → Battery voltage → 0



Is the inspection result normal?

- YES >> Repair or replace harness.
- NO >> GO TO 3

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

TRUNK LID OPENER ACTUATOR

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >


3. CHECK TRUNK LID OPENER ACTUATOR CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector and trunk lamp switch and trunk release solenoid connector.

BCM connector	Terminal	Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
A: M20	103	B: B28	3	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Continuity
A: M20	103	No



Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-96. "Removal and Installation"](#).
 NO >> Repair or replace harness.


4. CHECK TRUNK LID OPENER GROUND CIRCUIT

Check continuity between trunk lamp switch and trunk release solenoid connector and ground.

Trunk lamp switch and trunk release solenoid connector	Terminal	Continuity
B28	4	Ground

Is the inspection result normal?

- YES >> Replace trunk lamp switch and trunk release solenoid.
 NO >> Repair or replace harness.



OUTSIDE WARNING BUZZER

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

OUTSIDE WARNING BUZZER

Description

INFOID:000000005429371

Answers back and warns for an inappropriate operation.

Component Function Check

INFOID:000000005429372

1.CHECK FUNCTION

With CONSULT-III

Check outside warning buzzer OUTSIDE BUZZER in Active Test mode.

Is the inspection result normal?

- YES >> Outside warning buzzer (engine room) is OK.
- NO >> Refer to [DLK-517, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429373

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).


1.CHECK OUTSIDE WARNING BUZZER

Check voltage between BCM connector and ground.

Terminals		Warning buzzer operation condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M21	144	ON	0
		OFF	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5
- NO >> GO TO 2




2.CHECK OUTSIDE WARNING BUZZER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect outside warning buzzer connector.
3. Check voltage between outside warning buzzer connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Outside warning buzzer connector	Terminal	
E74	1	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace outside warning buzzer power supply circuit.



3.CHECK OUTSIDE WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.

OUTSIDE WARNING BUZZER

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

- Check continuity between BCM connector and outside warning buzzer connector.

A: BCM connector	Terminal	Outside warning buzzer connector	Terminal	Continuity
M21	144	B: E74	3	Yes

- Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M21	144		No



Is the inspection result normal?

OK >> GO TO 4

NG >> Repair or replace harness between BCM and outside warning buzzer.

4.CHECK OUTSIDE WARNING BUZZER

Check [DLK-518. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace outside warning buzzer.

5.CHECK INTERMITTENT INCIDENT

Check [GI-41. "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000005429374

1.CHECK OUTSIDE WARNING BUZZER


Connect battery power supply to outside warning buzzer terminals 1 and 3, and check the operation.

1 (BAT+) - 3 (BAT-) : the buzzer sounds

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace outside warning buzzer.



REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Description

INFOID:000000005429375

Receives keyfob operation and transmits to BCM.

Component Function Check

INFOID:000000005429376

1. CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating keyfob.

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
- NO >> Refer to [DLK-519, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000005429377

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).

1. CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL



1. Turn ignition switch OFF.
2. Check signal between remote keyless entry receiver connector and ground with oscilloscope.



REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >


Terminals			Condition	Signal (Reference value)
(+)		(-)		
Remote keyless entry receiver connector	Terminal			
M27	2	Ground	Waiting (All doors closed)	 <p style="text-align: right;">JMKIA0064GB</p>
			When signal is received (All doors closed)	 <p style="text-align: right;">JMKIA0065GB</p>


Is the inspection result normal?

- YES >> GO TO 7
- NO >> GO TO 2

2. CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Disconnect remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver connector and ground with oscilloscope.

Terminals			Signal (Reference value)
(+)		(-)	
Remote keyless entry receiver connector	Terminal		
M27	4	Ground	 <p style="text-align: right;">JMKIA0064GB</p>



Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 3

3. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 1

1. Disconnect BCM connector.

REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

2. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	91	B: M27	4	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	91		No

Is the inspection result normal?

YES >> Reconnect BCM, GO TO 4

NO >> Repair or replace harness between BCM and remote keyless entry receiver.

4. CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

Check continuity between remote keyless entry receiver connector and ground.

Remote keyless entry receiver connector	Terminal	Ground	Continuity
M27	1		Yes

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 5

5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 2

Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M18	45	B: M27	1	Yes

Is the inspection result normal?

YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry receiver.

6. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 3





1. Check continuity between BCM connector and remote keyless entry receiver connector.

BCM connector	Terminal	Remote keyless entry receiver connector	Terminal	Continuity
A: M19	71	B: M27	2	Yes

2. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	71		No

Is the inspection result normal?



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

YES >> GO TO 7

NO >> Repair or replace harness between BCM and remote keyless entry.

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

KEYFOB BATTERY AND FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

KEYFOB BATTERY AND FUNCTION

Description

INFOID:000000005429378

The following functions are available when having and carrying the keyfob.

- Door lock/unlock
- Trunk open

Remote control entry function and panic alarm function are available when operating the remote buttons.

Component Function Check

INFOID:000000005429379

1. CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver RKE OPE COUN1 in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating with the keyfob.

Is the inspection result normal?

- YES >> Keyfob is OK.
NO >> Refer to [DLK-523, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000005429380

1. CHECK KEYFOB FUNCTION

Check keyfob function using Remote Keyless Entry Tester J-43241.

Does the test pass?

- YES >> Keyfob is OK.
NO >> GO TO 2



2. CHECK KEYFOB COMPONENTS

1. Release the lock knob at the back of the keyfob and remove the mechanical key.
2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:


- Do not touch the circuit board or battery terminal.
- The keyfob is water-resistant. However, if it does get wet, immediately wipe it dry.

3. Remove the keyfob battery.

CAUTION:

- Keep dirt, grease, and other foreign materials off the electrode contact area.

4. Visually inspect keyfob internal components.



Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace malfunctioning parts.

3. CHECK KEYFOB BATTERY

KEYFOB BATTERY AND FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA.


Standard : Approx. 2.5 - 3.0V

Is the measurement value within specification?

YES >> Keyfob battery is OK. Check remote keyless entry receiver. Refer to [DLK-112](#).

["Component Function Check"](#).

NO >> GO TO 4



4. REPLACE KEYFOB BATTERY

1. Replace the keyfob battery.
2. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:


- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.

3. After replacing the battery, check that all keyfob functions work properly.

Is the inspection result normal?

YES >> Keyfob is OK.

NO >> Check remote keyless entry receiver. Refer to [DLK-112](#).
["Component Function Check"](#).



KEY SLOT ILLUMINATION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

KEY SLOT ILLUMINATION

Description

INFOID:000000005429381

Blinks when keyfob insertion is required.

Component Function Check

INFOID:000000005429382

1.CHECK FUNCTION

With CONSULT-III

Check key slot illumination KEY SLOT ILLUMI in Active Test mode.

Is the inspection result normal?

YES >> Key slot function is OK.

NO >> Refer to [DLK-525, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429383

Regarding Wiring Diagram information, refer to [DLK-572, "Wiring Diagram"](#).

1.CHECK KEY SLOT ILLUMINATION OUTPUT SIGNAL


Check voltage between key slot connector and ground.

Terminals		Condition	Key slot illumination	Voltage (V) (Approx.)	
(+)					(-)
Key slot connector	Terminal				
M40	6	Ground	Keyfob inserted	OFF	Battery voltage
			Keyfob removed	ON	0

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 2



DLK

2.CHECK KEY SLOT POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect key slot connector.
3. Check voltage between slot connector and ground.

Terminals		Condition	Voltage (V) (Approx.)
(+)			
Key slot connector	Terminal		
M40	1	Ground	Battery voltage
	5		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace key slot power supply circuit.



3.CHECK KEY SLOT GROUND CIRCUIT

KEY SLOT ILLUMINATION

[SEDAN WITHOUT INTELLIGENT KEY]


< COMPONENT DIAGNOSIS >

Check continuity between key slot connector and ground.

Key slot connector	Terminal	Ground	Continuity
M40	7		Yes

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace key slot ground circuit.



4. CHECK KEY SLOT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and key slot connector.
3. Check continuity between BCM connector and key slot connector.

BCM connector	Terminal	Key slot connector	Terminal	Continuity
A: M19	80	B: M40	6	Yes

4. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
A: M19	80		No

Is the inspection result normal?

- YES >> GO TO 5
- NO >> Repair or replace harness between BCM and key slot.

5. CHECK KEY SLOT

Refer to [DLK-499, "Component Inspection"](#).


Is the inspection result normal?

- YES >> GO TO 6
- NO >> Replace key slot.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.



HORN FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

HORN FUNCTION

Description

INFOID:000000005429384

Perform answer-back for each operation with horn.

Component Function Check

INFOID:000000005429385

1.CHECK FUNCTION

1. Select HORN in "ACTIVE TEST" mode with CONSULT-III.
2. Check the horn (high/low) operation.

Test item		Description	
HORN	ON	Horn relay	ON (for 20 ms)

Is the operation normal?

- YES >> Inspection End.
 NO >> Refer to [DLK-527, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429386

Regarding Wiring Diagram information, refer to [DLK-562, "Wiring Diagram"](#).

1.CHECK HORN FUNCTION


Check horn function with horn switch

Does the horn sound?

- YES >> GO TO 2
 NO >> Refer to [HRN-7, "SEDAN : Wiring Diagram"](#).

2.CHECK HORN RELAY POWER SUPPLY

1. Turn ignition switch ON.
2. Perform "ACTIVE TEST" ("HORN") with CONSULT-III.
3. Using an oscilloscope or analog voltmeter, check voltage between IPDM E/R connector and ground.



DLK

IPDM E/R		Ground	Test item	Voltage (V) (Approx.)	
Connector	Terminal				
E17	44	Ground	HORN	ON	Battery voltage → 0 → Battery voltage
			Other than above		Battery voltage

Is the inspection result normal?

- YES >> Repair or replace open harness between IPDM E/R and horn relay.
 NO >> GO TO 3

3.CHECK HORN RELAY CIRCUIT

HORN FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay connector.
3. Check continuity between IPDM E/R harness connector and horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
A: E17	44	B: H-1	1	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
A: E17	44	Ground	No

Is the inspection result normal?


- YES >> GO TO 4
 NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).
 NO >> Repair or replace the malfunctioning part.



COMBINATION METER DISPLAY FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

COMBINATION METER DISPLAY FUNCTION

Description

INFOID:000000005429387

Displays each operation method guide and warning for system malfunction.

Component Function Check

INFOID:000000005429388

1.CHECK FUNCTION

With CONSULT-III

Check the operation with ("LCD") in the Active Test.

Is each warning displayed on meter display?

Is the inspection result normal?

YES >> Meter display is OK.

NO >> Refer to [DLK-529. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429389

1.CHECK COMBINATION METER

Refer to [MWI-62. "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check combination meter. Refer to [MWI-42. "Diagnosis Description"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING CHIME FUNCTION

< COMPONENT DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

WARNING CHIME FUNCTION

Description

INFOID:000000005429390

Performs operation method guide and warning with buzzer.

Component Function Check

INFOID:000000005429391

1.CHECK FUNCTION

With CONSULT-III

1. Check the operation with "INSIDE BUZZER" in the Active Test.
2. Touch "TAKE OUT", "KNOB" or "KEY" on screen.

Is the inspection result normal?

- YES >> Warning buzzer into combination meter is OK.
NO >> Refer to [DLK-530, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005429392

1.CHECK METER BUZZER CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Replace combination meter. Refer to [MWI-153, "Removal and Installation"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

HAZARD FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< COMPONENT DIAGNOSIS >

HAZARD FUNCTION

Description

INFOID:000000005429393

Perform answer-back for each operation with number of blinks.

Component Function Check

INFOID:000000005429394

1.CHECK FUNCTION

Check hazard warning lamp ("FLASHER") in Active Test.

Is the inspection result normal?

- YES >> Hazard warning lamp circuit is OK.
- NO >> Refer to [EXL-163, "SEDAN : Wiring Diagram"](#).

Diagnosis Procedure

INFOID:000000005429395

1.CHECK HAZARD SWITCH CIRCUIT

Operate the hazard lights by turning ON the hazard warning switch.

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair or replace hazard warning switch circuit. Refer to [EXL-4, "Work Flow"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000005783593

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Other than front wiper switch LO	OFF
	Front wiper switch LO	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER INT	Other than front wiper switch INT	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Front wiper is not in STOP position	OFF
	Front wiper is in STOP position	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Other than turn signal switch LH	OFF
	Turn signal switch LH	ON
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	OFF
	Lighting switch 1ST or 2ND	ON
HI BEAM SW	Other than lighting switch HI	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
AUTO LIGHT SW	Other than lighting switch AUTO	OFF
	Lighting switch AUTO	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
DOOR SW-DR	Driver door closed	OFF
	Driver door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear door RH closed	OFF
	Rear door RH opened	ON
DOOR SW-RL	Rear door LH closed	OFF
	Rear door LH opened	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Monitor Item	Condition	Value/Status
CDL LOCK SW	Other than power door lock switch LOCK	OFF
	Power door lock switch LOCK	ON
CDL UNLOCK SW	Other than power door lock switch UNLOCK	OFF
	Power door lock switch UNLOCK	ON
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
HAZARD SW	When hazard switch is not pressed	OFF
	When hazard switch is pressed	ON
REAR DEF SW	When rear window defogger switch is pressed	ON
TR CANCEL SW	Trunk lid opener cancel switch OFF	OFF
	Trunk lid opener cancel switch ON	ON
TR/BD OPEN SW	Trunk lid opener switch OFF	OFF
	While the trunk lid opener switch is turned ON	ON
TRNK/HAT MNTR	Trunk lid closed	OFF
	Trunk lid opened	ON
RKE-LOCK	When LOCK button of Intelligent Key is not pressed	OFF
	When LOCK button of Intelligent Key is pressed	ON
RKE-UNLOCK	When UNLOCK button of Intelligent Key is not pressed	OFF
	When UNLOCK button of Intelligent Key is pressed	ON
RKE-TR/BD	When TRUNK OPEN button of Intelligent Key is not pressed	OFF
	When TRUNK OPEN button of Intelligent Key is pressed	ON
RKE-PANIC	When PANIC button of Intelligent Key is not pressed	OFF
	When PANIC button of Intelligent Key is pressed	ON
RKE-P/W OPEN	When UNLOCK button of Intelligent Key is not pressed and held	OFF
	When UNLOCK button of Intelligent Key is pressed and held	ON
RKE-MODE CHG	When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	OFF
	When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	ON
OPTICAL SENSOR	When outside of the vehicle is bright	Close to 5 V
	When outside of the vehicle is dark	Close to 0 V
REQ SW-DR	When driver door request switch is not pressed	OFF
	When driver door request switch is pressed	ON
REQ SW-AS	When passenger door request switch is not pressed	OFF
	When passenger door request switch is pressed	ON
REQ SW-BD/TR	When trunk request switch is not pressed	OFF
	When trunk request switch is pressed	ON
PUSH SW	When engine switch (push switch) is not pressed	OFF
	When engine switch (push switch) is pressed	ON
IGN RLY2-F/B	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
ACC RLY-F/B	Ignition switch OFF	OFF
	Ignition switch ACC or ON	ON

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Monitor Item	Condition	Value/Status
CLUTCH SW	When the clutch pedal is not depressed	OFF
	When the clutch pedal is depressed	ON
BRAKE SW 1	When the brake pedal is not depressed	ON
	When the brake pedal is depressed	OFF
DETE/CANCL SW	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN/N SW	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
UNLK SEN-DR	Driver door UNLOCK status	OFF
	Driver door LOCK status	ON
PUSH SW-IPDM	When engine switch (push switch) is not pressed	OFF
	When engine switch (push switch) is pressed	ON
IGN RLY1 F/B	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
DETE SW -IPDM	When selector lever is in P position	OFF
	When selector lever is in any position other than P	ON
SFT PN -IPDM	When selector lever is in any position other than P or N	OFF
	When selector lever is in P or N position	ON
SFT P-MET	When selector lever is in any position other than P	OFF
	When selector lever is in P position	ON
SFT N-MET	When selector lever is in any position other than N	OFF
	When selector lever is in N position	ON
ENGINE STATE	Engine stopped	STOP
	While the engine stalls	STALL
	At engine cranking	CRANK
	Engine running	RUN
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door UNLOCK status	UNLK
DOOR STAT-AS	Passenger door LOCK status	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door UNLOCK status	UNLK
ID OK FLAG	Ignition switch ACC or ON	RESET
	Ignition switch OFF	SET
PRMT ENG STAT	When the engine start is prohibited	RESET
	When the engine start is permitted	SET
KEY SW -SLOT	When Intelligent Key is not inserted into key slot	OFF
	When Intelligent Key is inserted into key slot	ON
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	YET
	The key ID that the key slot receives accords with any key ID registered to BCM.	DONE

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Monitor Item	Condition	Value/Status	
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	YET	A
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	DONE	B
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	YET	C
	The key ID that the key slot receives accords with the third key ID registered to BCM.	DONE	
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	YET	D
	The key ID that the key slot receives accords with the second key ID registered to BCM.	DONE	
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	YET	E
	The key ID that the key slot receives accords with the first key ID registered to BCM.	DONE	F
TP 4	The ID of fourth key is not registered to BCM	YET	
	The ID of fourth key is registered to BCM	DONE	G
TP 3	The ID of third key is not registered to BCM	YET	
	The ID of third key is registered to BCM	DONE	H
TP 2	The ID of second key is not registered to BCM	YET	
	The ID of second key is registered to BCM	DONE	I
TP 1	The ID of first key is not registered to BCM	YET	
	The ID of first key is registered to BCM	DONE	J
AIR PRESS FL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front LH tire	
AIR PRESS FR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of front RH tire	
AIR PRESS RR	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear RH tire	DLK
AIR PRESS RL	Ignition switch ON (only when the signal from the transmitter is received)	Air pressure of rear LH tire	
ID REGST FL1	When ID of front LH tire transmitter is registered	DONE	L
	When ID of front LH tire transmitter is not registered	YET	
ID REGST FR1	When ID of front RH tire transmitter is registered	DONE	M
	When ID of front RH tire transmitter is not registered	YET	
ID REGST RR1	When ID of rear RH tire transmitter is registered	DONE	N
	When ID of rear RH tire transmitter is not registered	YET	
ID REGST RL1	When ID of rear LH tire transmitter is registered	DONE	O
	When ID of rear LH tire transmitter is not registered	YET	
WARNING LAMP	Tire pressure indicator OFF	OFF	
	Tire pressure indicator ON	ON	
BUZZER	Tire pressure warning alarm is not sounding	OFF	P
	Tire pressure warning alarm is sounding	ON	


BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005783594




Physical Values

INFOID:000000005783595

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
1 (W/B)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (R/Y)	Ground	Battery power supply output	Output	Ignition switch OFF	Battery voltage
3 (L/W)	Ground	Ignition power supply output	Output	Ignition switch ON	Battery voltage
4 (P/W)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time	0V
				Any other time after passing the interior room lamp battery saver operation time	Battery voltage
5 (G/Y)	Ground	Front door RH UNLOCK	Output	Front door RH UNLOCK (actuator is activated)	Battery voltage
				Other than UNLOCK (actuator is not activated)	0V
7 (R/W)	Ground	Step lamp	Output	Step lamp ON	0V
				OFF	Battery voltage
8 (V)	Ground	All doors LOCK	Output	All doors LOCK (actuator is activated)	Battery voltage
				Other than LOCK (actuator is not activated)	0V
9 (G)	Ground	Front door LH UNLOCK	Output	Front door LH UNLOCK (actuator is activated)	Battery voltage
				Other than UNLOCK (actuator is not activated)	0V
10 ¹ (G/Y)	Ground	Rear door RH and rear door LH UNLOCK	Output	Rear door RH and rear door LH UNLOCK (actuator is activated)	Battery voltage
				Other than UNLOCK (actuator is not activated)	0V
11 (Y/R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0V
14 ⁶ (R/Y)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp OFF	0V
				ON	<p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right;"><small>JSN1A0010GB</small></p>

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
14 ¹ (O/W)	Ground	Engine switch (push switch) illumination ground	Input	Tail lamp	OFF	0V
				ON	NOTE: When the illumination brightening/dimming level is in the neutral position  <small>JSNIA0010GB</small>	
15 (Y/L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF	Battery voltage
				ACC or ON	0V	
17 (G/B)	Ground	Turn signal (RH)	Output	Ignition switch ON	Turn signal switch OFF	0V
				Turn signal switch RH	 <small>PKID0926E</small>	
18 (G/Y)	Ground	Turn signal (LH)	Output	Ignition switch ON	Turn signal switch OFF	0V
				Turn signal switch LH	 <small>PKID0926E</small>	
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
				ON	0V	
21 (P/B)	Ground	Optical sensor signal	Input	Ignition switch ON	When outside of the vehicle is bright	Close to 5V
				When outside of the vehicle is dark	Close to 0V	
22 (R/Y)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (clutch pedal is not depressed)	0V
				ON (clutch pedal is depressed)	Battery voltage	
24 (R/W)	Ground	Stop lamp switch 1	Input	—	Battery voltage	
26 (O/L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (brake pedal is not depressed)	0V
				ON (brake pedal is depressed)	Battery voltage	

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
27 (G/W)	Ground	Front door lock assembly LH (unlock sensor)	Input	Front door LH	LOCK status	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					UNLOCK status	0V
29 (Y)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	Battery voltage	
				When Intelligent Key is not inserted into key slot	0V	
30 (V/Y)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0
				ACC or ON	Battery voltage	
31 (G)	Ground	Rear window defogger feedback signal	Input	Rear window defogger switch	OFF	0V
					ON	Battery voltage
32 (R/B)	Ground	Front door RH switch	Input	Front door RH switch	OFF (when front door RH closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (when front door RH opens)	0V
33 (SB)	Ground	Compressor ON signal	Input	A/C switch	OFF	9.0 - 12.0V
					ON	0V
34 ² (L/R)	Ground	Front door lock assembly LH (key cylinder switch) (unlock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (unlock)	0V
36 ² (GR)	Ground	Lock switch signal	Input	Door lock/unlock switch	Lock	Battery voltage
					Unlock	0V
37 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	CANCEL	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>
					ON	0V
38 (GR/W)	Ground	Rear window defogger ON signal	Input	Rear window defogger switch	OFF	5V
					ON	0V
39 ² (GR/R)	Ground	Unlock switch signal	Input	Door lock/unlock switch	Unlock	Battery voltage
					Lock	0V





A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]






< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
40 ³ (Y/G)	Ground	Power window serial link	Input/ Output	Ignition switch ON	 10.2V	
				Ignition switch OFF or ACC	0V	
41 (W)	Ground	Engine switch (push switch) illumination	Output	Engine switch (push switch) illumination ON	5.5V	
				OFF	0V	
42 (R)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp ON	0V	
				OFF	Battery voltage	
45 (P)	Ground	Receiver & sensor ground	Input	Ignition switch ON	0V	
46 (V/W)	Ground	Receiver & sensor power supply output	Output	Ignition switch OFF	0V	
				ACC or ON	5.0V	
47 (G/O)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	 Standby state	
				When receiving the signal from the transmitter	 When receiving the signal from the transmitter	
48 (R/G)	Ground	Selector lever P/N position signal	Input	Selector lever P or N position	12.0V	
				Except P and N positions	0V	
49 (L/O)	Ground	Security indicator signal	Output	Security indicator ON	0V	
				Security indicator Blinking	 11.3V	
				OFF	Battery voltage	

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
50 (LG/ B)	Ground	Combination switch OUTPUT 5	Output	All switch OFF	0V
				Lighting switch 1ST	
				Lighting switch high-beam	
				Lighting switch 2ND	
				Turn signal switch RH	10.7V
51 (L/W)	Ground	Combination switch OUTPUT 1	Output	All switch OFF (Wiper intermittent dial 4)	0V
				Front wiper switch HI (Wiper intermittent dial 4)	
				Any of the conditions below with all switch OFF	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	
52 (G/B)	Ground	Combination switch OUTPUT 2	Output	All switch OFF (Wiper intermittent dial 4)	0V
				Front washer switch ON (Wiper intermittent dial 4)	
				Any of the conditions below with all switch OFF	
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	
53 (LG/ R)	Ground	Combination switch OUTPUT 3	Output	All switch OFF	0V
				Front wiper switch INT	
				Front wiper switch LO	
				Lighting switch AUTO	
					10.7V
54 (G/Y)	Ground	Combination switch OUTPUT 4	Output	All switch OFF	0V
				Front fog lamp switch ON	
				Lighting switch 2ND	
				Lighting switch flash-to-pass	
				Turn signal switch LH	10.7V
55 (BR/ W)	Ground	Front blower monitor	Input	Front blower motor switch	ON
					OFF






A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
(+)	(-)	Signal name	Input/ Output			
56 ² (L/B)	Ground	Front door lock assembly LH (key cylinder switch) (lock)	Input	Front door lock assembly LH (key cylinder switch)	OFF (neutral)	5V
					ON (lock)	0V
57 (W)	Ground	Tire pressure warning check switch	Input	—	—	5V
58 (SB)	Ground	Front door LH switch	Input	Front door LH switch	OFF (front door LH CLOSE)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>
					ON (front door LH OPEN)	0V
59 (G/R)	Ground	Rear window defogger relay	Output	Rear window defogger	Active	Battery voltage
					Not activated	0V
60 (B/R)	Ground	Front console antenna 2 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
61 (W/R)	Ground	Center console antenna 2 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
62 ⁴ (B/Y)	Ground	Front outside handle RH antenna (-)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	
63 ⁴ (LG)	Ground	Front outside handle RH antenna (+)	Output	When the front door RH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	
64 ⁴ (V)	Ground	Front outside handle LH antenna (-)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	
				When Intelligent Key is in the antenna detection area	





A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
65 ⁴ (P)	Ground	Front outside handle LH antenna (+)	Output	When the front door LH request switch is operat- ed with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>	
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
68 (G/O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
69 (O)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
70 (R/B)	Ground	Ignition relay-2 con- trol	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
71 (L/O)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting		 <p style="text-align: right; font-size: small;">JMKIA0064GB</p>
				When operating either button on Intelligent Key		 <p style="text-align: right; font-size: small;">JMKIA0065GB</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
75 (R/Y)	Ground	Combination switch INPUT 5	Input	Combination switch	<p>1.4V</p>
				Front fog lamp switch ON (Wiper intermittent dial 4)	<p>1.3V</p>
				Any of the conditions below with all switch OFF	<p>1.3V</p>
				<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	

A
B
C
D
E
F
G
H
I
J






DLK

L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]



< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
(+)	(-)				
76 (R/G)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMIA0041GB</p> </div>
					Lighting switch high-beam (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMIA0036GB</p> </div>
					Lighting switch 2ND (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMIA0037GB</p> </div>
					Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMIA0040GB</p> </div>
78 (P)	Ground	CAN-L	Input/ Output	—	—
79 (L)	Ground	CAN-H	Input/ Output	—	—
80 (R/L)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF <div style="text-align: right;">0V</div>
				Blinking	<div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMIA0015GB</p> </div>
81 (LG)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC <div style="text-align: right;">0V</div>
					ON <div style="text-align: right;">Battery voltage</div>

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
(+)	(-)					
83 (L)	Ground	ACC relay control	Output	Ignition switch	OFF	0V
					ACC or ON	Battery voltage
84 (Y/R)	Ground	CVT shift selector	Output	—		Battery voltage
87 (G/B)	Ground	Selector lever P position switch	Input	Selector lever	P position	0V
					Any position other than P	Battery voltage
88 ⁴ (P/L)	Ground	Front door RH request switch	Input	Front door RH request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
89 ⁴ (B/W)	Ground	Front door LH request switch	Input	Front door LH request switch	ON (pressed)	0V
					OFF (not pressed)	 <p style="text-align: center;">1.0V</p>
90 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0V
					ON	Battery voltage
91 (L/R)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage






A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]





< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
95 (R/W)	Ground	Combination switch INPUT 1	Input	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p>
				Turn signal switch LH	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p>
				Turn signal switch RH	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p>
				Front wiper switch LO	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p>
				Front washer switch ON	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
96 (P/B)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)  <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)  <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
					Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6  <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3V</p>







A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
(+)	(-)	Signal name	Input/ Output			
97 (R/B)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4V</p>
					Lighting switch flash-to-pass	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch INT	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3V</p>
					Front wiper switch HI	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3V</p>
					Pressed	0 V
98 (G/O)	Ground	Hazard switch	Input	Hazard switch	Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1V</p>

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
(+)	(-)	Signal name	Input/ Output		
103 (V)	Ground	Trunk lid opening	Output	Trunk lid	Open (trunk lid opener actuator is activated) Battery voltage
					Close (trunk lid opener actuator is not activated) 0V
110 (V/W)	Ground	Trunk room lamp	Output	Trunk room lamp	ON 0V
					OFF Battery voltage
114 (B)	Ground	Rear parcel shelf antenna 1 (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment JMKIA0062GB
					When Intelligent Key is not in the passenger compartment JMKIA0063GB
115 (W)	Ground	Rear parcel shelf antenna 1 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment JMKIA0062GB
					When Intelligent Key is not in the passenger compartment JMKIA0063GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]




< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
(+)	(-)					
118 ⁴ (L/O)	Ground	Rear bumper antenna (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>	
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
119 ⁴ (BR/W)	Ground	Rear bumper antenna (+)	Output	When the trunk lid request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>	
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
127 (BR/W)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	
				ON	Battery voltage	
130 (Y/G)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	OFF (trunk is closed)	
				ON (trunk is open)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8V</p>	
					ON (trunk is open)	0V

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
(+)	(-)					
132 (R)	Ground	Starter motor relay control	Output	Ignition switch OFF (M/T vehicle)	When the clutch pedal is depressed	Battery voltage
					When the clutch pedal is not depressed	0V
				Ignition switch ON (other than M/T vehicle)	When selector lever is in P or N position and the brake is depressed	Battery voltage
					When selector lever is in P or N position and the brake is not depressed	0V
140 (BR)	Ground	Engine switch (push switch)	Input	Engine switch (push switch)	Pressed	0V
					Not pressed	Battery voltage
141 (G/R)	Ground	Trunk request switch	Input	Trunk request switch	ON (pressed)	0V
					OFF (not pressed)	
144 ⁴ (GR)	Ground	Intelligent Key warning buzzer	Output	Request switch buzzer	Sounding	0V
					Not sounding	Battery voltage
144 ⁵ (GR)	Ground	Outside warning buzzer	Output	Outside warning buzzer	Sounding	0V
					Not sounding	Battery voltage
147 (L/R)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Pressed	0V
					Not pressed	Battery voltage
148 ¹ (R/W)	Ground	Rear door RH switch	Input	Rear door RH switch	OFF (when rear door RH closes)	
					ON (when rear door RH opens)	0V
149 ¹ (R/B)	Ground	Rear door LH switch	Input	Rear door LH switch	OFF (when rear door LH closes)	
					ON (when rear door LH opens)	0V

1: Sedan

2: With LH front window anti-pinch

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

3: With LH and RH front window anti-pinch

4: With Intelligent Key

5: Without Intelligent Key

6: Coupe

Fail Safe

INFOID:000000005783596

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> Starter control relay signal Starter relay status signal
B2562: LO VOLTAGE	Inhibit engine cranking	100 ms after the power supply voltage increases to more than 8.8 V
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> Status 1 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): ON Clutch interlock switch signal: OFF (0 V) Status 2 <ul style="list-style-type: none"> Clutch switch signal (CAN from ECM): OFF Clutch interlock switch signal: OFF (Battery voltage)

DTC Inspection Priority Chart

INFOID:000000005783597

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

Priority	DTC	
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING 	A B
4	<ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • B26E8: CLUTCH SW • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG 	C D E F G H I
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT 	J DLK L M N O
6	<ul style="list-style-type: none"> • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	P

DTC Index

INFOID:000000005783598

NOTE:

Details of time display

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-38, "Description"
U1010: CONTROL UNIT (CAN)	—	—	—	BCS-39, "DTC Logic"
U0415: VEHICLE SPEED SIG	—	—	—	BCS-40, "Description"
B2190: NATS ANTENNA AMP	×	—	—	SEC-53, "Description" (Coupe) SEC-229, "Description" (Sedan with I-Key) SEC-399, "Description" (Sedan without I-Key)
B2191: DIFFERENCE OF KEY	×	—	—	SEC-56, "Description" (Coupe) SEC-232, "Description" (Sedan with I-Key) SEC-402, "Description" (Sedan without I-Key)
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-57, "Description" (Coupe) SEC-233, "Description" (Sedan with I-Key) SEC-403, "Description" (Sedan without I-Key)
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-58, "Description" (Coupe) SEC-234, "Description" (Sedan with I-Key) SEC-404, "Description" (Sedan without I-Key)
B2195: ANTI SCANNING	×	—	—	SEC-59, "Description" (Coupe) SEC-235, "Description" (Sedan with I-Key) SEC-405, "Description" (Sedan without I-Key)
B2553: IGNITION RELAY	—	—	—	PCS-61, "Description"
B2555: STOP LAMP	—	—	—	SEC-60, "Description" (Coupe) SEC-236, "Description" (Sedan with I-Key) SEC-406, "Description" (Sedan without I-Key)
B2556: PUSH-BTN IGN SW	—	×	—	SEC-63, "Description" (Coupe) SEC-239, "Description" (Sedan with I-Key) SEC-409, "Description" (Sedan without I-Key)
B2557: VEHICLE SPEED	—	×	—	SEC-65, "Description" (Coupe) SEC-241, "Description" (Sedan with I-Key) SEC-411, "Description" (Sedan without I-Key)

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2560: STARTER CONT RELAY	×	×	—	SEC-66, "Description" (Coupe) SEC-242, "Description" (Sedan with I-Key) SEC-412, "Description" (Sedan without I-Key)
B2562: LOW VOLTAGE	×	—	—	BCS-41, "DTC Logic"
B2601: SHIFT POSITION	—	×	—	SEC-67, "Description" (Coupe) SEC-243, "Description" (Sedan with I-Key) SEC-413, "Description" (Sedan without I-Key)
B2602: SHIFT POSITION	—	×	—	SEC-71, "Description" (Coupe) SEC-246, "Description" (Sedan with I-Key) SEC-416, "Description" (Sedan without I-Key)
B2603: SHIFT POSI STATUS	—	×	—	SEC-74, "Description" (Coupe) SEC-249, "Description" (Sedan with I-Key) SEC-419, "Description" (Sedan without I-Key)
B2604: PNP SW	—	×	—	SEC-77, "Description" (Coupe) SEC-252, "Description" (Sedan with I-Key) SEC-422, "Description" (Sedan without I-Key)
B2605: PNP SW	—	×	—	SEC-79, "Description" (Coupe) SEC-254, "Description" (Sedan with I-Key) SEC-424, "Description" (Sedan without I-Key)
B2608: STARTER RELAY	×	×	—	SEC-81, "Description" (Coupe) SEC-256, "Description" (Sedan with I-Key) SEC-426, "Description" (Sedan without I-Key)
B260A: IGNITION RELAY	×	×	—	PCS-63, "Description"
B260F: ENG STATE SIG LOST	×	×	—	SEC-83, "Description" (Coupe) SEC-258, "Description" (Sedan with I-Key) SEC-428, "Description" (Sedan without I-Key)
B2614: ACC RELAY CIRC	—	×	—	PCS-66, "Description"
B2615: BLOWER RELAY CIRC	—	×	—	PCS-69, "Description"
B2616: IGN RELAY CIRC	—	×	—	PCS-72, "Description"
B2617: STARTER RELAY CIRC	×	×	—	SEC-87, "Description" (Coupe) SEC-262, "Description" (Sedan with I-Key) SEC-432, "Description" (Sedan without I-Key)
B2618: BCM	×	×	—	PCS-75, "Description"
B261A: PUSH-BTN IGN SW	—	×	—	SEC-90, "Description" (Coupe) SEC-265, "Description" (Sedan with I-Key) SEC-435, "Description" (Sedan without I-Key)

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B261E: VEHICLE TYPE	×	× (Turn ON for 15 seconds)	—	SEC-89, "Description" (Coupe) SEC-264, "Description" (Sedan with I-Key) SEC-434, "Description" (Sedan without I-Key)
B2622: INSIDE ANTENNA	—	—	—	DLK-60, "Description" (Coupe) DLK-283, "Description" (Sedan with I-Key) DLK-484, "Description" (Sedan without I-Key)
B2623: INSIDE ANTENNA	—	—	—	DLK-63, "Description" (Coupe) DLK-286, "Description" (Sedan with I-Key) DLK-487, "Description" (Sedan without I-Key)
B26E1: ENG STATE NO RES	×	×	—	SEC-92, "Description" (Coupe) SEC-267, "Description" (Sedan with I-Key) SEC-437, "Description" (Sedan without I-Key)
B26E8: CLUTCH SW	×	×	—	SEC-84, "Description" (Coupe) SEC-259, "Description" (Sedan with I-Key) SEC-429, "Description" (Sedan without I-Key)
B26EA: KEY REGISTRATION	×	× (Turn ON for 15 seconds)	—	SEC-86, "Description" (Coupe) SEC-261, "Description" (Sedan with I-Key) SEC-431, "Description" (Sedan without I-Key)
C1704: LOW PRESSURE FL	—	—	×	WT-44, "Self-Diagnosis (With CONSULT-III)"
C1705: LOW PRESSURE FR	—	—	×	
C1706: LOW PRESSURE RR	—	—	×	
C1707: LOW PRESSURE RL	—	—	×	
C1708: [NO DATA] FL	—	—	×	WT-14, "Description"
C1709: [NO DATA] FR	—	—	×	
C1710: [NO DATA] RR	—	—	×	
C1711: [NO DATA] RL	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	×	WT-16, "Description"
C1713: [CHECKSUM ERR] FR	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	×	WT-18, "Description"
C1717: [PRESSDATA ERR] FR	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	×	

BCM (BODY CONTROL MODULE)

[SEDAN WITHOUT INTELLIGENT KEY]

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1720: [CODE ERR] FL	—	—	×	WT-16, "Description"
C1721: [CODE ERR] FR	—	—	×	
C1722: [CODE ERR] RR	—	—	×	
C1723: [CODE ERR] RL	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	×	
C1725: [BATT VOLT LOW] FR	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	×	WT-19, "Description"
C1734: CONTROL UNIT	—	—	×	WT-20, "Description"

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

WIRING DIAGRAM

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram

INFOID:000000005429401



HOMELINK UNIVERSAL TRANSCEIVER

ABKWA0218GB

HOMELINK UNIVERSAL TRANSCEIVER

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


HOMELINK UNIVERSAL TRANSCEIVER CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6Q	Y/R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	Y/R	-
15	B	-

Connector No.	M64
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B/Y	-
15	B	-

Connector No.	R4
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	B	GND
10	B/Y	BAT+

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >




ABKWA0732GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >



ABKWA0733GB


POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


POWER DOOR LOCK SYSTEM CONNECTORS - SEDAN WITH REMOTE KEYLESS ENTRY

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7N	Y/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17J	SB	-
22J	R/B	-
25J	Y/G	-
98J	V	-
99J	G/Y	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	V	-
6	G/Y	-
10	R/B	-
11	R/W	-

ABKIA2062GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


DLK

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
8	B	-
9	GR/R	-
13	G/W	-
14	V	-


Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4
5	6	7	8
9	10		

Terminal No.	Color of Wire	Signal Name
1	G/Y	-
5	B	-
6	V	-

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-


Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



1	3
2	

Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19					

Terminal No.	Color of Wire	Signal Name
5	G/Y	CDL_AS
8	V	CDL_COMMON
9	G	CDL_DR/FL
10	G/Y	CDL_RR_RL_BACK
11	Y/R	BAT_BCM_FUSE
13	B	GND1

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60
99	98	97	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80

Terminal No.	Color of Wire	Signal Name
78	P	CAN-L
79	L	CAN-H

Terminal No.	Color of Wire	Signal Name
34	L/R	DOOR_KEY/C_UNLOCK_SW
36	GR	CENTRAL_LOCK_SW
39	GR/R	CENTRAL_UNLOCK_SW
56	L/B	DOOR_KEY/C_LOCK_SW
58	SB	DR_DOOR_SW


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20
59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40

Terminal No.	Color of Wire	Signal Name
27	G/W	DOOR_LOCK_STATUS
32	R/B	AS_DOOR_SW

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
151	150	149	148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132

Terminal No.	Color of Wire	Signal Name
130	Y/G	TRUNK_SW
148	R/W	RR_DOOR_SW
149	R/B	RL_DOOR_SW

ABKIA2064GB

A B C D E F G H I J L M N O P


DLK

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

Terminal No.	Color of Wire	Signal Name
17J	SB	-
22J	BR	-
25J	W	-
98J	GR	-
99J	G	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	DOOR SW (RL)

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

ABKIA2065GB

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name
2	GR	DOOR SW (AS)

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3
4	5	6
7	8	

Terminal No.	Color of Wire	Signal Name
3	G	-
7	L	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
2	L	-
6	G	-
10	GR	-
11	B	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



8	7	6	5	4	3	2	1
16	15	14	13	12	11	10	9

Terminal No.	Color of Wire	Signal Name
2	L/B	-
9	L/R	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8					

Terminal No.	Color of Wire	Signal Name
1	GR	-
4	G	-
9	GR/R	-
13	P	-
14	GR	-

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name
2	B	DOOR SW (RR)

ABKIA2066GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


DLK

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-
3	P	-
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW
6	L/B	DOOR_KEY/C_LOCK_SW

Connector No.	D12
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	GR/R	UNLOCK

Connector No.	D8
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	B	GND
18	GR	LOCK

Connector No.	D108
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	GR	-
6	G	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
7	GR/R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
6	GR	-


ABKIA2067GB

POWER DOOR LOCK SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	D205
Connector Name	REAR DOOR LOCK ACTUATOR LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	LOCK
2	GR/R	UNLOCK
3	B	GND

Connector No.	D305
Connector Name	REAR DOOR LOCK ACTUATOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	GR	-
6	G	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
7	GR	-

ABKIA2068GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram

INFOID:000000005429400

REMOTE KEYLESS ENTRY SYSTEM - SEDAN




ABKWA0738GB

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >



ABKWA0740GB


REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


REMOTE KEYLESS ENTRY SYSTEM CONNECTORS - SEDAN

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	BR	-
57G	GR	-
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1N	W/L	-
4N	G/Y	-
7N	Y/R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3Q	O/L	-
9Q	R/W	-


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4J	B	-
11J	W	-
17J	SB	-
22J	R/B	-
25J	Y/G	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
10	R/B	-
11	R/W	-

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	P/W	ROOM LAMP BAT SAVER
5	G/Y	CDL_AS
8	V	CDL_COMMON
9	G	CDL_DR/FL
10	G/Y	CDL_RR_RL_BACK
11	Y/R	BAT_BCM_FUSE
13	B	GND1
15	Y/L	ACC_LED
17	G/B	FR_FLASHER
18	G/Y	FL_FLASHER
19	Y	ROOM_LAMP_OUTPUT

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
24	R/W	STOP_LAMP_LOW_SW
26	O/L	STOP_LAMP_HIGH_SW
29	Y	FOB_IN_SW_1
32	R/B	AS_DOOR_SW
42	R	S/L_LOCK_LED
45	P	GND_RF2_A/L
58	SB	DR_DOOR_SW

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	---

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



100	101	102	103	104	105	106	107	108	109	110	111
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name
103	V	CDL_BACK_TRUNK

Terminal No.	Color of Wire	Signal Name
60	B/R	ROOM_ANT_2_B
61	W/R	ROOM_ANT_2_A
68	G/O	FOB_READER_CLOCK
69	O	FOB_READER_DATA
71	L/O	RF1_TUNER_SIGNAL
78	P	CAN-L
79	L	CAN-H
80	R/L	FOB_SLOT_ILLUMINATION
81	LG	IGN_ON_LED
91	L/R	RF1_POWER_SUPPLY
98	G/O	HAZARD SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


ABKIA2082GB

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M27
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	GND
2	L/O	SIGNAL
4	L/R	12V

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/L	BAT
3	B	GND (POWER)
4	B	GND (ILL)
21	L	CAN-H
22	P	CAN-L
23	B	GND (CIRCUIT)

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
114	B	TRUNK_ANT_1_B
115	W	TRUNK_ANT_1_A
130	Y/G	TRUNK_SW
140	BR	ENG START SW W/O ESCL
144	GR	BUZZER
148	R/W	RR_DOOR_SW
149	R/B	RL_DOOR_SW

Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Connector No.	M40
Connector Name	KEY SLOT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/Y	B+
2	G/O	CLOCK
3	O	DATA
5	G/Y	LIGHT_BAT+
6	R/L	LIGHT_A
7	B	GND
11	Y	CARD_SW_1

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	GND
4	BR	START_SW
5	R	LOCK
6	Y/L	ACC
7	LG	ON
8	G/Y	B+

ABKIA2083GB

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]


< WIRING DIAGRAM >

Connector No.	M203
Connector Name	FRONT CONSOLE ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W/R	ANT+
2	B/R	ANT-

Connector No.	M131
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	BR	-

Connector No.	M93
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	P	-
8P	R	-
11P	G	-

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-

Connector No.	M207
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
7	W/R	-

ABKIA2084GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
12	B	GND (POWER)
28	SB	PUSH_START_SW

Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Connector No.	E17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
39	P	CAN-L
40	L	CAN-H
41	B	GND (SIGNAL)
44	G/W	HORN RLY

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABKIA2085GB

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	E38
Connector Name	STOP LAMP SWITCH (WITH CVT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-

Terminal No.	Color of Wire	Signal Name
8G	P	-
15G	L	-
29G	SB	-
57G	R	-
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E216
Connector Name	HORN (HIGH)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-

Connector No.	E73
Connector Name	OUTSIDE WARNING BUZZER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
3	R	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


ABKIA2086GB

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >


Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW (DR)

Terminal No.	Color of Wire	Signal Name
4J	V	-
11J	W	-
17J	SB	-
22J	BR	-
25J	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B29
Connector Name	REAR PARCEL SHELF ANTENNA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	ANT+
2	V	ANT- (WITH SEDAN)

Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	DOOR SW (RL)

ABKIA2087GB


TRUNK LID OPENER

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

TRUNK LID OPENER CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21J	V	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
37	O	TRUNK_CANCEL_SW

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
103	V	CDL_BACK_TRUNK

A B C D E F G H I J K L M N O P

DLK


ABKIA0771GB

TRUNK LID OPENER

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
147	L/R	BACK_TRUNK_OPENER

Connector No.	M74
Connector Name	TRUNK LID OPENER CANCEL SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-

Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L/R	-
2	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21J	V	-

ABKIA0766GB

TRUNK LID OPENER

[SEDAN WITHOUT INTELLIGENT KEY]

< WIRING DIAGRAM >

Connector No.	T4
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
4	B	-

Connector No.	T3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

ABKIA0767GB

DOOR LOCK FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR LOCK FUNCTION

Symptom Table

INFOID:000000005429405

DOOR LOCK/UNLOCK FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-461, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Symptom	Diagnosis/service procedure	Reference page	
Power door locks do not operate with door lock and unlock switch.	1. Check BCM Power supply and ground circuit.	DLK-490	
	2. Check door lock and unlock switch.	DLK-494	
	3. Check door lock actuator (driver side)	DLK-510	
	4. Check Intermittent Incident.	GI-41	
Power door locks do not operate with door key cylinder operation. (Power door locks operate properly with door lock and unlock switch.)	1. Check key cylinder switch.	DLK-500	
	2. Replace power window main switch.	PWC-163 (LH only anti-pinch) or PWC-355 (LH & RH front anti-pinch)	
Specific door lock actuator does not operate.	1. Check door lock actuator.	Driver side	DLK-510
		Passenger side	DLK-511
		Rear LH	DLK-512
		Rear RH	DLK-513
	2. Check Intermittent Incident.	GI-41	
Vehicle speed sensing auto door LOCK operation does not operate.	1. Ensure automatic door lock/unlock function (lock operation) is enabled.	DLK-479	
	2. Check combination meter vehicle speed signal.	MWI-46	
	3. Check intermittent incident.	GI-41	
Ignition OFF interlock auto door UNLOCK function does not operate.	1. Ensure automatic door lock/unlock function (unlock operation) is enabled.	DLK-479	
	2. Check BCM for DTCs.	DLK-555	
	3. Check intermittent incident.	GI-41	

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

REMOTE KEYLESS ENTRY SYSTEM

Symptom Table

INFOID:000000005429406

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page
All functions of remote keyless entry system do not operate.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	DLK-523
	2. Check BCM and remote keyless entry receiver.	DLK-519
The new ID of keyfob cannot be entered.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	DLK-523
	2. Door switch check	DLK-491
	3. ACC power check	DLK-490
	4. Replace BCM.	BCS-96
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system)	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	DLK-523
	2. Replace BCM.	BCS-96
Hazard and horn reminder does not activate properly when pressing lock or unlock button of keyfob.	1. Check hazard and horn reminder mode with CONSULT-III NOTE: Hazard and horn reminder mode can be changed. First check the hazard and horn reminder mode setting.	PCS-17
	2. Door switch check	DLK-491
	3. Replace BCM.	BCS-96
Hazard reminder does not activate properly when pressing lock or unlock button of keyfob. (Horn reminder OK)	1. Check hazard reminder mode with CONSULT-III NOTE: Hazard reminder mode can be changed. First check the hazard reminder mode setting.	PCS-17
	2. Check hazard function with hazard switch	—
	3. Replace BCM.	BCS-96
Horn reminder does not activate properly when pressing lock or unlock button of keyfob. (Hazard reminder OK)	1. Check horn reminder mode with CONSULT-III NOTE: Horn reminder mode can be changed. First check the horn reminder mode setting.	PCS-17
	2. Check horn function with horn switch	—
	3. IPDM E/R operation check	DLK-527
	4. Replace BCM.	BCS-96
Room lamp illumination does not operate properly.	1. Room lamp operation check	INL-3
	2. Door switch check	DLK-491
	3. Replace BCM.	BCS-96

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

REMOTE KEYLESS ENTRY SYSTEM

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Symptom	Diagnoses/service procedure	Reference page
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	DLK-523
	2. ACC power check	DLK-490
	3. Replace BCM.	BCS-96
Auto door lock operation does not activate properly. (All other remote keyless entry functions OK.)	1. Check auto door lock operation mode with CONSULT-III NOTE: Auto door lock operation mode can be changed. First check the auto door lock operation mode setting.	DLK-479
	2. Replace BCM.	BCS-96

TRUNK OPEN FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

TRUNK OPEN FUNCTION

Symptom Table

INFOID:000000005429407

TRUNK OPEN FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-461, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

- Keyfob is out of key slot.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Trunk open function does not operate by trunk opener switch.	1. Check trunk opener switch.	DLK-503
	2. Check trunk lid opener cancel switch.	DLK-505
	3. Check Intermittent Incident.	GI-41

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

WARNING FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

WARNING FUNCTION

Symptom Table

INFOID:000000005429408

WARNING FUNCTION MALFUNCTION

NOTE:

- Before performing the diagnosis in the following table, check “WORK FLOW”. Refer to [DLK-461, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

Conditions of Vehicle (Operating Conditions)

Warning chime functions operating condition is extremely complicated. During operating confirmations, reconfirm the list above twice in order to ensure proper operation.

Symptom		Diagnosis/service procedure	Reference page
OFF position warning does not operate.	For internal	1. Check push-button ignition switch position indicator.	SEC-265
		2. Check door switch.	DLK-491
		3. Check warning chime function.	DLK-530
		4. Check Intermittent Incident.	GI-41
	For external	1. Check push-button ignition switch position indicator.	SEC-265
		2. Check door switch.	DLK-491
		3. Check outside warning buzzer.	DLK-517
		4. Check Intermittent Incident.	GI-41
P position warning does not operate.	1. Check Park position switch.	SEC-252	
	2. Check door switch.	DLK-491	
	3. Check outside warning buzzer.	DLK-517	
	4. Check warning chime function.	DLK-530	
	5. Check combination meter display function.	DLK-529	
	6. Check Intermittent Incident.	GI-41	
ACC warning does not operate	1. Check push-button ignition switch position indicator.	SEC-265	
	2. Check warning chime function.	DLK-530	
	3. Check combination meter display function.	DLK-529	
	4. Check Intermittent Incident.	GI-41	

WARNING FUNCTION

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

Symptom		Diagnosis/service procedure		Reference page
Take away warning does not operate.	Door open to close	1. Check door switch.		DLK-491
		2. Check inside key antenna.	Console	DLK-484
			Trunk room	DLK-487
		3. Check outside warning buzzer.		DLK-517
		4. Check warning chime function.		DLK-530
		5. Check key slot illumination.		DLK-525
		6. Check combination meter display function.		DLK-529
	7. Check Intermittent Incident.		GI-41	
	Push-button ignition switch operation	1. Check push-button ignition switch position indicator.		SEC-265
		2. Check inside key antenna.	Console	DLK-484
			Trunk room	DLK-487
		3. Check warning chime function.		DLK-530
		4. Check key slot illumination.		DLK-525
		5. Check combination meter display function.		DLK-529
	6. Check Intermittent Incident.		GI-41	
	Door is open	1. Check push-button ignition switch position indicator.		SEC-265
		2. Check inside key antenna.	Console	DLK-484
			Trunk room	DLK-487
		3. Check combination meter display function.		DLK-529
	4. Check Intermittent Incident.		GI-41	
Take away through window	1. Check inside key antenna.	Console	DLK-484	
		Trunk room	DLK-487	
	2. Check warning chime function.		DLK-530	
	3. Check key slot illumination.		DLK-525	
	4. Check combination meter display function.		DLK-529	
5. Check Intermittent Incident.		GI-41		
Key warning chime does not operate.	1. Check key slot.		DLK-498	
	2. Check door switch.		DLK-491	
	3. Check warning chime function.		DLK-530	
	4. Check key slot illumination.		DLK-525	
	5. Check combination meter display function.		DLK-529	
	6. Check Intermittent Incident.		GI-41	
Door lock operation warning chime does not operate.	1. Check door switch.		DLK-491	
	2. Check key slot illumination.		DLK-525	
	3. Check outside warning buzzer.		DLK-517	
	4. Check inside key antenna.	Console	DLK-484	
		Trunk room	DLK-487	
5. Check Intermittent Incident.		GI-41		

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005429409



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [DLK-598, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [DLK-596, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000005429410

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

A

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

B

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

C

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

D

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

E

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

F

G

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

H

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

I

J

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

DLK

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[SEDAN WITHOUT INTELLIGENT KEY]

Diagnostic Worksheet

INFOID:000000005429411





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[SEDAN WITHOUT INTELLIGENT KEY]

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|-------------------------------------------------------|--------------------------------------------------------|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI0071E

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005786770

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Procedure without Cowl Top Cover

INFOID:000000005429413

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for work

INFOID:000000005429414

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

PREPARATION

[SEDAN WITHOUT INTELLIGENT KEY]

< PREPARATION >




PREPARATION

PREPARATION

Special Service Tools



INFOID:000000005429415

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise
— (J-43241) Remote Keyless Entry Tester  LEL946A	Used to test keyfobs

Commercial Service Tools

INFOID:000000005429416

Tool name	Description
Engine ear  SIIA0995E	Locating the noise
Power tool  PIIB1407E	

HOOD

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

ON-VEHICLE REPAIR

HOOD


HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation

INFOID:000000005429417

REMOVAL

1. Remove the hinge nuts (a) and the hood assembly (1).
CAUTION:
Operate with two workers, because of its large size.



INSTALLATION

Installation is in the reverse order of removal.

Hood hinge nuts

14 N·m (1.4 kg·m, 10 ft·lb)

NOTE:

After installing, perform hood fitting adjustment. Refer to [DLK-603, "HOOD ASSEMBLY : Adjustment"](#).

HOOD




< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

HOOD ASSEMBLY : Adjustment

INFOID:000000005429418

SEC. 650



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

- 1. Hood assembly
- 2. Front grille
- 3. Front fascia
- 4. Headlamp assembly
- 5. Front fender

AWKIA1229GB

FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDUNAL CLEARANCE ADJUSTMENT

HOOD

< ON-VEHICLE REPAIR >


[SEDAN WITHOUT INTELLIGENT KEY]

Unit: mm (in)


Section	Item	Measurement	Standard	Parallelism	Equality
A - A	E	Clearance	5.0 ± 2.0 (0.20 \pm 0.079)	≤ 2.0 (0.079)	—
B - B	F	Clearance	5.0 ± 2.0 (0.20 \pm 0.079)	≤ 2.0 (0.079)	≤ 2.2 (0.087)
	G	Surface height	1.0 ± 2.0 (0.04 \pm 0.079)	≤ 2.0 (0.079)	≤ 2.0 (0.079)
C - C	H	Clearance	4.5 ± 2.0 (0.18 \pm 0.079)	—	2.1 (0.083)
	J	Surface height	1.0 ± 2.1 (0.04 \pm 0.083)	—	< 2.0 (0.079)
D - D	K	Clearance	4.0 ± 1.0 (0.16 \pm 0.04)	1.0 (0.04)	1.0 (0.04)
	M	Surface height	0.2 ± 1.0 (0.01 \pm 0.04)	1.0 (0.04)	1.0 (0.04)

FRONT END HEIGHT ADJUSTMENT

1. Check the surface height between the hood and each part by visual and tactile feeling.
2. Remove the front grille. Refer to [EXT-40, "Removal and Installation"](#).
3. Remove the hood lock.
4. Adjust the surface level difference of the hood, fender and head lamp by rotating the hood bumpers until the hood becomes 1 to 1.5 mm (0.04 to 0.059 in) lower than the fender.



5. Install and align the hood lock center with the center of the hood striker. Engage the lock with the striker and check for looseness.
6. Adjust A and B shown in the figure to the following value with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing the hood closed lightly [approx. 29 N (3 kg)].



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.27 in) |

7. After adjustment tighten the hood lock bolts to the specified torque.

LATERAL/LONGITUDUNAL CLEARANCE ADJUSTMENT

1. Check the clearance between the hood and each part by visual and tactile feeling.
2. Loosen the hood hinge bolts.

NOTE:

The anticorrosive agent applied between the hoodledge and the hood hinges also acts as an adhesive. This seal must be broken before the hinges will move.

3. Move the hood so that the clearance measurements are within specifications.
4. Tighten the hood hinge bolts.

HOOD

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

Hood hinge bolts : 14 N-m (1.4 kg-m, 10 ft-lb)

NOTE:


After installation apply touch-up paint onto the hinge bolts and around the base of the hinge.

5. If the clearance measurements between the hood and fender cannot be corrected by moving the hood, the fender must be adjusted. Refer to [DLK-610, "Removal and Installation"](#).

HOOD LOCK CONTROL

HOOD LOCK CONTROL : Component Parts Location

INFOID:000000005429419




- | | | |
|-----------------------|-----------------------------|----------------------------|
| 1. Hood lock assembly | 2. Hood lock cable | 3. Hoodledge reinforcement |
| 4. Clip | 5. Hood lock release handle | |

HOOD LOCK CONTROL : Removal and Installation

INFOID:000000005429420

REMOVAL

1. Remove the front grill. Refer to [EXT-40, "Removal and Installation"](#).
2. Remove the LH fender protector. Refer to [EXT-42, "Removal and Installation"](#).
3. Remove the hood lock assembly bolts.



4. Disconnect the hood lock cable from the hood lock, and unclip it from the hoodledge.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

HOOD

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]


5. Remove the screws (a) with power tool, and separate the hood lock release handle (1) from the hood lock release cable (2).




6. Remove the grommet from the upper dash, and pull the hood lock cable into the passenger compartment.
CAUTION:
While pulling, be careful not to damage (peel) the outside of the hood lock cable.

INSTALLATION


1. Pull the hood lock cable through the upper dash into the engine compartment.
CAUTION:
Be careful not to bend the cable too much, keep the radius 100 mm (3.94 in) or more.
2. Attach the hood lock release cable (2) to the hood lock release handle (1) and install the hood lock release handle screws (a).



3. Check that the cable is not offset from the center of the grommet, and seat the grommet into the upper dash hole.
4. Apply the sealant around the grommet at * mark.



5. Position the hood lock cable and clip it into place.
6. Connect the hood lock cable to the hood lock assembly.
7. Loosely install the hood lock assembly.
8. Perform hood fitting adjustment. Refer to [DLK-603, "HOOD ASSEMBLY : Adjustment"](#).
9. Check the hood lock control operation.



HOOD

< ON-VEHICLE REPAIR >


[SEDAN WITHOUT INTELLIGENT KEY]

INSPECTION

CAUTION:


If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary latch is properly engaged with the secondary striker (B: 6.8 mm (0.268 in) shown in the figure) with hood's own weight.



- | | | |
|--------------------|--------------------|----------------------|
| 1. Hood striker | 2. Primary latch | 3. Secondary striker |
| 4. Secondary latch | A. 20 mm (0.79 in) | B. 6.8 mm (0.268 in) |

2. While operating the hood opener, carefully check that the front end of the hood is raised by approx. 20 mm (0.79 in). Also check that the hood opener returns to the original position.
3. Check that the hood lock release handle operating force is 49 N (5.0 kg-f, 11 ft-lb) or less.
4. Install so the static closing force of the hood is 343 – 490 N (35– 44 kg-f, 77.1 - 110.2 lb-f).
5. Check the hood lock lubrication condition. If necessary, apply “body grease” as shown.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

RADIATOR CORE SUPPORT


< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

RADIATOR CORE SUPPORT

Removal and Installation

INFOID:000000005786774



1. Radiator core support

a. Bolts

REMOVAL

1. Remove front bumper reinforcement. Refer to [EXT-36, "Removal and Installation"](#).
2. Remove head lamps (LH/RH). Refer to [EXL-217, "Removal and Installation"](#).
3. Remove air duct. Refer to [EM-19, "Removal and Installation"](#) QR25DE, [EM-123, "Removal and Installation"](#) VQ35DE.
4. Remove the radiator cooling fans. Refer to [CO-17, "Removal and Installation"](#) QR25DE, [CO-39, "Removal and Installation"](#) VQ35DE.
5. Remove the radiator. Refer to [CO-15, "Removal and Installation"](#) QR25DE, [CO-37, "Removal and Installation"](#) VQ35DE.
6. Remove the hood lock control. Refer to [DLK-435, "HOOD LOCK CONTROL : Removal and Installation"](#).
7. Remove ambient sensor. Refer to [HA-37, "Removal and Installation"](#).
8. Remove crash zone sensor. Refer to [SR-13, "Removal and Installation"](#).
9. Remove air guides (LH/RH).
10. Remove power steering fluid cooler. Refer to [ST-21, "QR25DE : Removal and Installation"](#) QR25DE, [ST-21, "VQ35DE : With 17 Inch Tire"](#) or [ST-23, "VQ35DE : With 18 Inch Tire"](#) VQ35DE.

RADIATOR CORE SUPPORT

[SEDAN WITHOUT INTELLIGENT KEY]

< ON-VEHICLE REPAIR >

11. Remove horn (High/Low). Refer to [HRN-11, "Removal and Installation"](#).
12. Remove the harness clips from the radiator core support assembly, the harness is separate.
13. Remove the hood support rod.
14. Remove the bolts and the radiator core support.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

FRONT FENDER

Removal and Installation

INFOID:000000005786775

REMOVAL

1. Remove the head lamp. Refer to [EXL-217, "Removal and Installation"](#).
2. Remove the inner fender bolt cover.
3. Remove the center mudguard. Refer to [EXT-43, "Removal and Installation"](#).
4. Remove the bolts and the front fender.

CAUTION:

- While removing use a shop cloth to protect body from damaging.
- Use care when removing the front fender. The front fender baffle foam adheres the front fender to the body side outer. Carefully release the foam or damage to the fender may occur.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the front fender bolts.


ADJUSTMENT

FRONT FENDER

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

SEC. 630



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

- 1. Hood assembly
- 4. Body side outer
- ↔ Front

- 2. Front fender
- 5. Front fascia bracket

- 3. Front fascia
- 6. Front door assembly

AWKIA0447GB

FRONT FENDER

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

Unit: mm (in)

Section	Item	Measurement	Standard	Parallelism	Equality
A-A	E	Clearance	4.0 ± 1.0 (0.16 ± 0.04)	1.0 (0.04)	1.0 (0.04)
	F	Surface height	0.2 ± 1.0 (0.01 ± 0.04)	1.0 (0.04)	1.0 (0.04)
B-B	G	Clearance	0.0 + 0.8 (0.0 +0.031)	—	—
	H	Surface height	0.7 ± 1.0 (0.028 ± 0.04)	1.0 (0.04)	1.0 (0.04)
C-C	J	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—
	K	Clearance	3.6 ± 1.0 (0.14 ± 0.04)	1.0 (0.04)	—
D-D	M	Clearance	2.3 ± 1.0 (0.09 ± 0.04)	1.0 (0.04)	—
	N	Surface height	0.0 ± 1.0 (0.0 ± 0.04)	—	—

1. Remove the inner fender bolt cover.
2. Remove the front fender protector. Refer to [EXT-42. "Removal and Installation"](#).
3. Remove the center mud guard. Refer to [EXT-43. "Removal and Installation"](#).
4. Loosen the front fender bolts and screws.
5. Adjust the clearance (J) and surface height (K) between the front fender and the front door.
6. Tighten the rear upper and lower front fender bolts.
7. Adjust the clearance (E) and surface height (F) between the front fender and the hood.
8. Adjust the clearance (M) and surface height (N) between the front fender and the body side outer.
9. Tighten the inner front fender bolts.
10. Adjust the clearance (G) and the surface height (H) between the front fender and the front fascia.
11. Tighten the front fender to front fascia and bracket screws.
12. Apply touch-up paint (the body color) onto the head of the front fender bolts.
13. Install the center mud guard. Refer to [EXT-43. "Removal and Installation"](#).
14. Install the front fender protector. Refer to [EXT-42. "Removal and Installation"](#).
15. Install the inner fender bolt cover.

DOOR

FRONT DOOR

FRONT DOOR : Removal and Installation


INFOID:000000005429423

CAUTION:

- When removing and installing the front door assembly, support the door with a jack and cloth to protect the door and body.
- When removing and installing front door assembly, be sure to carry out the fitting adjustment. Refer to [DLK-614, "FRONT DOOR : Adjustment"](#).
- After installing, apply touch-up paint (the body color) onto the head of the hinge nuts.
- Check the hinge rotating parts for lubrication. If necessary, apply "body grease".
- Operate with two workers, because of its heavy weight.
- Check front door open/close operation after installation.

REMOVAL

1. Pull the grommet and wire harness out of the front pillar until the harness connectors are accessible. Then disconnect the wire harness connectors.
2. Remove the check link bolt from the front pillar.
3. Remove the door-side hinge nuts (a) and the door assembly (1).



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

Adjust the door. Refer to [DLK-614, "FRONT DOOR : Adjustment"](#).

DOOR







< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

FRONT DOOR : Adjustment

INFOID:000000005429424

SEC.800



AWKIA0450GB

- 1. Front fender
 - 2. Front door assembly
 - 3. Rear door assembly
 - 4. Center mud guard
 - 5. Center pillar
 - 6. Outer sill
- ↔ Front

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

Unit: mm (in)

Section	Item	Measurement	Standard
A-A	F	Clearance	4.5 ± 1.5 (0.18 ± 0.06)
	G	Surface height	0.0 ± 1.5 (0.0 ± 0.06)
B-B	H	Clearance	4.2 ± 1.0 (0.17 ± 0.04)
	J	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
C-C	K	Clearance	4.2 ± 1.0 (0.17 ± 0.04)
	M	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
D-D	N	Clearance	5.1 ± 1.7 (0.20 ± 0.07)
E-E	P	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	Q	Surface height	0.0 ± 1.0 (0.0 ± 0.04)

LONGITUDINAL CLEARANCE

1. Confirm the back door adjustments and adjust if necessary. Refer to [DLK-615, "BACK DOOR : Removal and Installation"](#).
2. Remove the front fender. Refer to [DLK-610, "Removal and Installation"](#).
3. Loosen the hinge bolts. Raise or lower the front door at rear edge to adjust.
4. Install the front fender. Refer to [DLK-610, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the front door hinge nuts.
2. Move the top and or bottom in or out as necessary until it is within specifications.
3. Tighten the hinge nuts to specifications.

BACK DOOR

BACK DOOR : Removal and Installation

INFOID:000000005429425

CAUTION:

- When removing and installing the rear door assembly, support the door with a jack and cloth to protect the door and body.
- When removing and installing rear door assembly, be sure to carry out the fitting adjustment. Refer to [DLK-446, "BACK DOOR : Adjustment"](#).
- Check the hinge rotating parts for poor lubrication. If necessary, apply "body grease".
- After installing, apply touch-up paint (the body color) onto the head of the hinge nuts.
- Operate with two workers, because of its heavy weight.
- Check rear door open/close operation after installation.

REMOVAL


1. Pull out grommet and disconnect rear door harness connector.
2. Remove the check link bolt from the center pillar.

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

3. Remove the door-side hinge nuts (a) and the door assembly (1).



INSTALLATION

Installation is in the reverse order of removal.

BACK DOOR : Adjustment

INFOID:000000005429426



ADJUSTMENT

DOOR


< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]


SEC. 820




A-A



B-B



C-C



1. Rear door assembly

2. Center mud guard

3. Body side outer

Unit: mm (in)

Section	Item	Measurement	Standard
A-A	D	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	E	Surface height	0.0 ± 1.0 (0.0 ± 0.04)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

AWKIA0451GB

DOOR

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]


Section	Item	Measurement	Standard
B-B	F	Clearance	3.6 ± 1.0 (0.14 ± 0.04)
	G	Surface height	0.0 ± 1.0 (0.0 ± 0.04)
C-C	H	Clearance	5.3 ± 1.7 (0.21 ± 0.07)

LONGITUDINAL CLEARANCE

1. Remove the center pillar upper and lower trim. Refer to [INT-37, "Removal and Installation"](#).
2. Loosen the upper pillar hinge nuts.
3. Loosen the lower pillar hinge bolts.
4. Raise or lower the door at the rear edge to adjust.
5. Tighten the lower pillar hinge bolts.
6. Tighten the upper pillar hinge nuts.
7. Install the center pillar upper and lower trim. Refer to [INT-37, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the hinge nuts.
2. Move the top and or the bottom in or out as necessary until it is within specification.
3. Tighten the hinge nuts to specification.



DOOR LOCK


[SEDAN WITHOUT INTELLIGENT KEY]

< ON-VEHICLE REPAIR >

DOOR LOCK FRONT DOOR LOCK

FRONT DOOR LOCK : Component Parts Location

INFOID:000000005429427




- | | | |
|----------------------------|----------------------------------------|---------------------------------------------------------------------------------------------|
| 1. Outside handle assembly | 2. Front gasket | 3. Door key cylinder escutcheon (Driver side)
Outside handle escutcheon (Passenger side) |
| 4. Front gasket | 5. Rear gasket | 6. Key cylinder assembly (Driver side only) |
| 7. Outside handle bracket | 8. Key cylinder rod (Driver side only) | 9. Front door striker |
| 10. Door lock assembly | 11. Cap | 12. Inside door handle assembly |
| 13. Grommet | 14. Front door assembly | |

FRONT DOOR LOCK : Removal and Installation

INFOID:000000005429428

REMOVAL

1. Remove the front door finisher. Refer to [INT-31, "Removal and Installation"](#).
2. Disconnect the inside handle knob cable and lock knob cable from the back side of the front door finisher.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK


< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]


3. Remove the front door window and front door module assembly. Refer to [GW-16, "Removal and Installation"](#).
4. Remove door side grommet, and remove door key cylinder assembly (driver side) and outside handle escutcheon (passenger side) bolts (TORX T30) from grommet hole.




5. Disconnect the key cylinder rod.
6. Disconnect door key cylinder switch harness connector.
7. While pulling the outside handle (1), remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side) (2).



8. Disconnect front door request switch harness connector.
9. While pulling outside handle (1), slide toward rear of vehicle (2) to remove outside handle.



10. Remove the front gasket and rear gasket.




DOOR LOCK

[SEDAN WITHOUT INTELLIGENT KEY]


< ON-VEHICLE REPAIR >

11. Remove the TORX bolts (T30), remove the door lock assembly.




A
B
C

12. Remove the TORX bolt (T30) (A) of the outside handle bracket.



D
E
F


13. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



G
H
I

14. Disconnect the door lock actuator connector and remove the door lock assembly.

15. Disconnect the outside handle cable from the outside handle bracket connection.



J
DLK

L
M
N

O
P

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing the key cylinder rod be sure to rotate the rod holder until a click is felt.

BACK DOOR LOCK


DOOR LOCK

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

BACK DOOR LOCK : Component Parts Location

INFOID:000000005429429




- | | | |
|------------------------------|----------------------------|----------------------------|
| 1. Outside handle escutcheon | 2. Outside handle | 3. Front gasket |
| 4. Outside handle bracket | 5. Rear gasket | 6. Outside handle assembly |
| 7. Hole plug | 8. Rear door striker | 9. Rear door lock assembly |
| 10. Cap | 11. Inside handle assembly | 12. Grommet |
| 13. Rear door assembly | | |

BACK DOOR LOCK : Removal and Installation

INFOID:000000005429430

REMOVAL

1. Remove the rear door finisher. Refer to [INT-31, "Removal and Installation"](#).
2. Disconnect the inside handle knob cable and lock knob cable from the back side of the inside door handle.




3. Remove the rear door sash. Refer to [EXT-45, "Removal and Installation"](#).
4. Remove the rear door window and rear door screen assembly.

DOOR LOCK


[SEDAN WITHOUT INTELLIGENT KEY]

< ON-VEHICLE REPAIR >


5. Remove door side grommet, and remove outside handle escutcheon bolt (TORX T30) from grommet hole.




6. While pulling the outside handle (1), remove outside handle escutcheon (2).




7. While pulling outside handle (1), slide toward rear of vehicle (2) to remove outside handle.



8. Remove the front gasket and rear gasket.



9. Remove the TORX bolts (T30), remove the door lock assembly.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK


< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]


10. Remove the TORX bolt (T30) (A) from the outside handle bracket.



11. While pulling outside handle, slide toward rear of vehicle to remove outside handle.



12. Disconnect the door lock actuator connector and remove the door lock assembly.
13. Disconnect the outside handle cable from the outside handle bracket.



INSTALLATION

Installation is in the reverse order of removal.

TRUNK LID

TRUNK LID ASSEMBLY

TRUNK LID ASSEMBLY : Removal and Installation

INFOID:000000005429431

REMOVAL

1. Remove trunk lid finisher. Refer to [INT-47, "Removal and Installation"](#).
2. Disconnect the connectors in the trunk lid, and remove the harness clips to pull the harness out of the trunk lid.
3. Remove the bolts, and remove the trunk lid assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the hinge bolts.
- After installing, check operation.
- After installing, perform fitting adjustment. Refer to [DLK-626, "TRUNK LID ASSEMBLY : Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

TRUNK LID




< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

TRUNK LID ASSEMBLY : Adjustment

INFOID:000000005429432

SEC. 843



AWKIA0452GB

- 1. Trunk lid assembly
- 4. Rear bumper fascia

- 2. Body side outer
- 5. Trunk lid hinge assembly

- 3. Rear combination lamp
- 6. Trunk lid latch assembly

↔ Front

TRUNK LID

< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

Unit: mm (in)

Parts		Standard	Right/left clearance (MAX)
A – A	E	4.0 ± 1.0 (0.16 ± 0.04)	2.0 (0.08)
	F	-0.5 ± 1.0 (-0.02 ± 0.04)	2.0 (0.08)
B – B	G	4.0 ± 1.5 (0.16 ± 0.06)	2.0 (0.08)
	H	-0.5 ± 1.5 (-0.02 ± 0.06)	2.0 (0.08)
C – C	J	4.0 ± 2.0 (0.16 ± 0.08)	—
	K	5.9 ± 2.0 (0.23 ± 0.08)	—
D – D	K	5.9 ± 2.0 (0.23 ± 0.08)	—

LONGITUDINAL CLEARANCE

Trunk Lid Removed From Hinge

1. Check the clearance and the evenness between the trunk lid and each part by visual and tactile feeling.
2. Loosen the trunk lid to hinge bolts.
3. Move the trunk lid so that the clearance measurements are within specifications.
4. Tighten the trunk lid to hinge bolts.

Trunk Lid Hinge Removed From Vehicle

1. Remove the parcel shelf trim. Refer to [INT-39, "Removal and Installation"](#).
2. Loosen the hinge to parcel shelf bolts.
3. Move the trunk lid so that the clearance measurements are within specifications.
4. Tighten the hinge to parcel shelf bolts.
5. Install the parcel shelf trim. Refer to [INT-39, "Removal and Installation"](#).

SURFACE HEIGHT ADJUSTMENT

1. Loosen the bumper rubber.
2. Loosen the striker bolts.
3. Lift up the trunk lid approx. 100 - 150 mm (3.94 - 5.91 in) height then close it lightly. Make sure it engages firmly with the trunk lid closed.
4. Finally tighten the trunk lid striker.

TRUNK LID LOCK

TRUNK LID LOCK : Removal and Installation

INFOID:000000005429433

LOCK

Removal

1. Remove the trunk lid inner trim panel. Refer to [INT-47, "Removal and Installation"](#).
2. Remove the bolts, disconnect the electrical connector, separate the emergency release handle, and remove the trunk lid lock

Installation

Installation is in the reverse order of removal

Striker

Removal

1. Remove the trunk end finisher. Refer to [INT-47, "Removal and Installation"](#).
2. Remove the bolts and the striker.

Installation

Installation is in the reverse order of removal.

NOTE:

Align the trunk lid lock. Refer to [DLK-626, "TRUNK LID ASSEMBLY : Adjustment"](#).

FUEL FILLER LID


< ON-VEHICLE REPAIR >

[SEDAN WITHOUT INTELLIGENT KEY]

FUEL FILLER LID

Exploded View

INFOID:000000005429434



- 1. Fuel door latch
 - 2. Cable protector
 - 3. Fuel door opener cable
 - 4. Fuel door opener handle
- ↶ Front

Removal and Installation

INFOID:000000005429435

REMOVAL

1. Remove the front and rear LH kicking plates. Refer to [INT-37, "Removal and Installation"](#).
2. Remove the rear seat. Refer to [SE-60, "Removal and Installation"](#).
3. Remove the LH front seat belt anchor. Refer to [SB-6, "Exploded View"](#).
4. Remove the LH center pillar lower finisher. Refer to [INT-36, "Exploded View"](#).
5. Position the carpet aside.
6. Remove the LH trunk side finisher. Refer to [INT-46, "Exploded View"](#).
7. Remove the fuel door opener handle and disconnect the fuel door opener cable.
8. Remove the fuel door latch and disconnect the fuel door opener cable.
9. Remove the fuel door opener cable.

INSTALLATION

Installation is in the reverse order of removal.

REMOTE KEYLESS ENTRY RECEIVER

[SEDAN WITHOUT INTELLIGENT KEY]

< ON-VEHICLE REPAIR >


REMOTE KEYLESS ENTRY RECEIVER

Removal

INFOID:000000005429436

REMOVAL

1. Remove glove compartment. Refer to [IP-11, "Removal and Installation"](#).
2. Remove the screw (a), lower the bracket and remote keyless entry receiver (1), then disconnect the harness and remove the receiver.



Installation

INFOID:000000005429437

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P