

ST
 SECTION
STEERING SYSTEM

A
 B
 C
 D
 E
 F
ST
 H
 I
 J
 K
 L
 M
 N
 O
 P

CONTENTS

| | |
|--|----|
| PRECAUTION | 3 |
| PRECAUTIONS | 3 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 |
| General Precautions | 3 |
| SYMPTOM DIAGNOSIS | 4 |
| NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING | 4 |
| NVH Troubleshooting Chart | 4 |
| PREPARATION | 5 |
| PREPARATION | 5 |
| Special Service Tool | 5 |
| Commercial Service Tool | 6 |
| ON-VEHICLE MAINTENANCE | 7 |
| POWER STEERING FLUID | 7 |
| Inspection | 7 |
| Draining | 7 |
| Refilling | 7 |
| STEERING WHEEL | 9 |
| Inspection | 9 |
| POWER STEERING OIL PUMP | 11 |
| Inspection | 11 |
| ON-VEHICLE REPAIR | 12 |
| STEERING WHEEL | 12 |
| Removal and Installation | 12 |
| STEERING COLUMN | 13 |
| Exploded View | 13 |
| Removal and Installation | 13 |
| STEERING GEAR AND LINKAGE | 16 |
| Exploded View | 16 |
| Removal and Installation | 16 |
| POWER STEERING OIL PUMP | 18 |
| QR25DE | 18 |
| QR25DE : Exploded View | 18 |
| QR25DE : Removal and Installation | 18 |
| VQ35DE | 18 |
| VQ35DE : Exploded View | 19 |
| VQ35DE : Removal and Installation | 19 |
| HYDRAULIC LINE | 20 |
| QR25DE | 20 |
| QR25DE : Exploded View | 20 |
| QR25DE : Removal and Installation | 21 |
| VQ35DE | 21 |
| VQ35DE : With 17 Inch Tire | 21 |
| VQ35DE : With 18 Inch Tire | 23 |
| DISASSEMBLY AND ASSEMBLY | 26 |
| STEERING COLUMN | 26 |
| Disassembly and Assembly | 26 |
| STEERING GEAR AND LINKAGE | 27 |
| Exploded View | 27 |
| Disassembly | 27 |
| Inspection | 27 |
| Assembly | 28 |
| POWER STEERING OIL PUMP | 30 |
| QR25DE | 30 |
| QR25DE : Disassembly and Assembly | 30 |
| VQ35DE | 30 |
| VQ35DE : Disassembly and Assembly | 30 |
| SERVICE DATA AND SPECIFICATIONS (SDS) | 31 |

SERVICE DATA AND SPECIFICATIONS

| | |
|----------------------|-----------|
| (SDS) | 31 |
| Steering Wheel | 31 |
| Steering Angle | 31 |

| | |
|-----------------------|----|
| Steering Column | 31 |
| Steering Gear | 32 |
| Oil Pump | 33 |
| Steering Fluid | 33 |

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005789624

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

General Precautions

INFOID:0000000005432705

- In case of removing steering gear assembly, make the final tightening with grounded and unloaded vehicle condition, and then check wheel alignment.
- Observe the following precautions when disassembling.
 - Before disassembly, thoroughly clean the outside of the unit.
 - Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
 - For easier and proper assembly, place disassembled parts in order on a parts rack.
 - Use nylon cloth or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
 - Do not reuse non-reusable parts.
 - Before assembling, apply the specified grease to the directed parts.

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000005432701

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom | | Possible cause and SUSPECTED PARTS | Reference page | | | | | | | | | | | | | | | | | | | |
|----------|-----------|------------------------------------|----------------|-------------------------|--|---|----------------------------------|------------------------|---------------------|----------------------------------|----------------------|-------------------------|-------------------------------|---------------------------------------|---|----------------------------|-----------|---------------------|-------|------------|-------------|--------|
| | | | Fluid level | Air in hydraulic system | Outer socket ball joint swinging force | Outer socket ball joint rotating torque | Outer socket ball joint end play | Steering fluid leakage | Steering wheel play | Steering gear rack sliding force | Drive belt looseness | Improper steering wheel | Mounting rubber deterioration | Steering column deformation or damage | Improper installation or looseness of steering column | Steering linkage looseness | WHEEL HUB | AXLE and SUSPENSION | TIRES | ROAD WHEEL | DRIVE SHAFT | BRAKES |
| Steering | Noise | | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| | Shake | | | | | | | | | | | | | | | | | | | | | |
| | Vibration | | | | | | | | | | | | | | | | | | | | | |
| | Shimmy | | | | | | | | | | | | | | | | | | | | | |
| | Shudder | | | | | | | | | | | | | | | | | | | | | |

x: Applicable

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Special Service Tool

INFOID:000000005432706



The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|---|--|
| ST27180001 (J-25726-A) Steering wheel puller <div data-bbox="606 556 901 724" style="text-align: center;"> <p>M10 x 1.25 pitch M8 x 1.25 pitch 29 mm (1.14 in) S-NT544</p> </div> | Removing steering wheel |
| ST3127S000 (See J-25765-A) Preload gauge 1. GG9103000 (J-25765-A) Torque wrench 2. HT62940000 (-) Socket adapter 3. HT62900000 (-) Socket adapter <div data-bbox="598 861 917 1029" style="text-align: center;"> <p>1 1/4" 2 1/4" to 3/8" 3 3/8" to 1/2" Torque wrench with range of 2.9 N·m (30 kg·cm, 26 in·lb) S-NT541</p> </div> | Inspecting of rotating torque for ball joint |
| KV48103500 (J-26357) Pressure gauge <div data-bbox="598 1155 917 1323" style="text-align: center;"> <p>To oil pump outlet PF3/8" (female) To control valve PF3/8" (male) Shut-off valve S-NT547</p> </div> | Measuring oil pump relief pressure |
| KV48102500 (J-33914) Pressure gauge adapter <div data-bbox="606 1407 909 1575" style="text-align: center;"> <p>PF3/8" PF3/8" M16 x 1.5 pitch M16 x 1.5 pitch S-NT542</p> </div> | Measuring oil pump relief pressure |

A
B
C
D
E
F
ST
H
I
J
K
L
M
N
O
P


PREPARATION

< PREPARATION >

| Tool number (Kent-Moore No.) Tool name | Description |
|--|---|
| <p style="text-align: center;">— (J-44372) Spring gauge</p> <div style="text-align: center;">  <p>LST024</p> </div> | <p>Measuring steering wheel turning force or rack sliding force</p> |
| <p>HT72520000 (J-25730-A) Ball joint remover</p> <div style="text-align: center;">  <p>NT146</p> </div> | <p>Removing ball joint</p> |

Commercial Service Tool

INFOID:000000005432707

| Tool number Tool name | Description |
|--|--|
| <p>Power tool</p> <div style="text-align: center;">  <p>PBIC0190E</p> </div> | <ul style="list-style-type: none"> • Removing wheel nuts • Removing undercover |

POWER STEERING FLUID

< ON-VEHICLE MAINTENANCE >

ON-VEHICLE MAINTENANCE

POWER STEERING FLUID

Inspection

INFOID:000000005432708

FLUID LEVEL


- Check fluid level with engine stopped.
- Make sure that fluid level is between MIN and MAX.
- Fluid levels at HOT (A) and COLD (B) are different. Do not confuse them.

HOT (A) : Fluid temperature 50 - 80 °C (122 - 176°F)

COLD (B) : Fluid temperature 0 - 30°C (32 - 86°F)

CAUTION:

- The fluid level should not exceed the MAX line. Excessive fluid will cause fluid leakage from the cap.
- Do not reuse drained power steering fluid.
- Recommended fluid is Genuine Nissan PSF or equivalent.



FLUID LEAKAGE


Check hydraulic connections for fluid leakage, cracks, damage, looseness, or wear.

1. Run engine until the fluid temperature reaches 50 to 80° C (122 to 176°F) in reservoir tank, and keep engine speed idle.
2. Turn steering wheel several times from full left stop to full right stop.
3. Hold steering wheel at each lock position for five seconds and carefully, check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 10 seconds. (There is the possibility that oil pump may be damaged.)

4. If fluid leakage at connections is noticed, then loosen flare nut and then retighten. Do not overtighten connector as this can damage O-ring, washer and connector.
5. If fluid leakage from oil pump is noticed, check oil pump. Refer to [ST-30 \(QR25DE\)](#), [ST-30 \(VQ35DE\)](#).
6. Check steering gear boots for accumulation of fluid indicating from steering gear.



Draining

INFOID:000000005432709

1. Disconnect both high and low pressure lines from power steering gear.
2. Drain into a suitable container.

Refilling

INFOID:000000005432710

FILLING HYDRAULIC SYSTEM

1. Fill power steering reservoir while checking fluid level.
2. Bleed air from hydraulic system.
3. Check for fluid leaks.

AIR BLEEDING HYDRAULIC SYSTEM

If air bleeding is not complete, the following symptoms can be observed.

- Bubbles are created in reservoir tank.
- Clicking noise can be heard from oil pump.
- Excessive buzzing in the oil pump.

NOTE:

POWER STEERING FLUID

< ON-VEHICLE MAINTENANCE >

Fluid noise may occur in the steering gear or oil pump. This does not affect performance or durability of the system.

1. Turn steering wheel several times from full left stop to full right stop with engine off.

CAUTION:

Turn steering wheel while filling reservoir tank with fluid so as not to lower fluid level below the MIN line.

2. Start engine and hold steering wheel at each lock position for 3 seconds at idle to check for fluid leakage.
3. Repeat step 2 above several times at approximately 3 second intervals.

CAUTION:

Do not hold the steering wheel in a locked position for more than 10 seconds. (There is the possibility that oil pump may be damaged.)

4. Check fluid for bubbles and white contamination.
5. Stop engine if bubbles and white contamination do not drain out. Perform step 2 and 3 above after waiting until bubbles and white contamination drain out.
6. Stop the engine, and then check fluid level.

STEERING WHEEL

< ON-VEHICLE MAINTENANCE >

STEERING WHEEL

Inspection

INFOID:000000005432711

INSTALLATION CONDITION

- Check installation conditions of steering gear assembly, front suspension assembly, axle and steering column assembly.
- Check if movement exists when steering wheel is moved up and down, to the left and right and to the axial direction.

Steering wheel axial end play : Refer to [ST-31, "Steering Wheel"](#).

- Check steering gear assembly bolts and nut for looseness. Refer to [ST-16, "Exploded View"](#).

STEERING WHEEL PLAY

- Turn steering wheel so that front wheels come to the straight-ahead position. Start engine and lightly turn steering wheel to the left and right until front wheels start to move. Measure steering wheel movement on the outer circumference.

Steering wheel play : Refer to [ST-31, "Steering Wheel"](#).

- When the measurement value is outside the standard value, check backlash for each joint of steering column assembly and installation condition of steering gear assembly.

NEUTRAL POSITION OF STEERING WHEEL

- Make sure that steering gear assembly, steering column assembly and steering wheel are installed in the correct position.
- Perform neutral position inspection after wheel alignment. Refer to [FSU-6, "Inspection and Adjustment"](#).
- Set vehicle to the straight-ahead position and confirm steering wheel is in the neutral position.
- Loosen outer socket lock nut and turn inner socket to left and right equally to make fine adjustments if steering wheel is not in the neutral position.


STEERING WHEEL TURNING FORCE

1. Park vehicle on a level, dry surface and set parking brake.
2. Start engine.
3. Bring power steering fluid up to adequate operating temperature. Make sure the fluid temperature is approximately 60° to 80°C (140° to 176°F).
Tires need to be inflated to normal pressure.
4. Check steering wheel turning force using tool when steering wheel has been turned 360° from the neutral position.

Tool number : — (J-44372)

Steering wheel turning force : Refer to [ST-31, "Steering Wheel"](#).

5. If steering wheel turning force is out of specification, check rack sliding force. Refer to [ST-27, "Inspection"](#).
6. If rack sliding force is not within specifications, adjust rack sliding force. Refer to [ST-27, "Inspection"](#).
7. If rack sliding force is OK, inspect steering column. Refer to [ST-13, "Removal and Installation"](#).




FRONT WHEEL TURNING ANGLE

STEERING WHEEL


< ON-VEHICLE MAINTENANCE >

- Check front wheel turning angle after toe-in inspection. Place front wheels on turning radius gauges and rear wheels on stands. Check the maximum inner and outer wheel turning angles for LH and RH road wheels.




- With the engine at idle, turn steering wheel from full left stop to full right stop and measure the steering angles.

Steering angles : Refer to [ST-31, "Steering Angle"](#).



- Measure rack stroke if angles are outside the specified value.

Rack stroke (L) : Refer to [ST-32, "Steering Gear"](#).



POWER STEERING OIL PUMP

< ON-VEHICLE MAINTENANCE >

POWER STEERING OIL PUMP

Inspection

INFOID:000000005432712

RELIEF OIL PRESSURE

CAUTION:

Make sure that belt tension is normal before starting the following procedure.

1. Connect the Tool between oil pump discharge connector and high-pressure hose. Bleed air from the hydraulic circuit while opening valve fully. Refer to [ST-7, "Inspection"](#).

Tool numbers : KV48103500 (J-26357),
KV48102500 (J-33914)

2. Start engine. Run engine until oil temperature reaches 50° to 80°C (122° to 176°F).

CAUTION:


- Leave the valve of the hydraulic pressure gauge [SST] fully open while starting and running engine. If engine is started with the valve closed, the hydraulic pressure in oil pump goes up to the relief pressure along with unusual increase of oil temperature.
 - Be sure to keep hose clear of belts and other parts when engine is started.
3. Fully close the Tool valve with engine at idle and measure the relief oil pressure.

Relief oil pressure: Refer to [ST-33, "Oil Pump"](#).

CAUTION:

Never keep valve closed for 10 seconds or longer.

4. Open the valve slowly after measuring. Replace oil pump is the relief oil pressure is outside the standard.
5. After inspection, disconnect the Tool from hydraulic circuit, then add fluid and bleed air. Refer to [ST-7, "Inspection"](#).



STEERING WHEEL

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

STEERING WHEEL

Removal and Installation

INFOID:000000005432713


REMOVAL

NOTE:

When reconnecting spiral cable, fix cable with a tape so that fixing case and rotating part keep aligned. This will omit neutral position alignment procedure during spiral cable installation.

1. Set vehicle to the straight-ahead position.
2. Remove driver air bag module. Refer to [SR-4, "Removal and Installation"](#).
3. Remove steering wheel lock nut after steering is locked.
4. Remove steering wheel using Tool (A).

Tool number (A) : ST27180001 (J-25726-A)



INSTALLATION

Installation is in the reverse order of removal. Tighten steering wheel nut to specification.

NOTE:

Align the spiral cable. Refer to [SR-7, "Removal and Installation"](#).

Steering wheel nut : Refer to [ST-13, "Exploded View"](#).


STEERING COLUMN

< ON-VEHICLE REPAIR >

STEERING COLUMN

Exploded View

INFOID:000000005432714



- | | | |
|--|--------------------------|--|
| 1-4. Steering column assembly nut tightening order | 5. Steering wheel | 6. Combination switch and spiral cable |
| 7. Steering column assembly | 8. Hole cover seal | 9. Herbie clip |
| 10. Hole cover | 11. Lower shaft assembly | |


Removal and Installation

INFOID:000000005432715

REMOVAL

Hole Cover Seal, Hole Cover and Lower Shaft Assembly


1. Set wheels to the straight-ahead position.
 - Steering gear (2)
2. Remove lower side bolt (A) of lower shaft assembly (1).



STEERING COLUMN

< ON-VEHICLE REPAIR >

3. Remove bolt (A) and nut (B) of column upper joint (2), then remove lower shaft assembly (1).
4. Loosen herbie clip, then remove hole cover seal from hole cover.
5. Remove nuts of hole cover, and then remove clamp and hole cover from dash panel.




Steering Column Assembly

1. Set wheels to the straight-ahead position.
2. Remove instrument lower cover (LH). Refer to [IP-10, "Exploded View"](#).
3. Remove steering column cover (upper and lower). Refer to [IP-10, "Exploded View"](#).
4. Disconnect each switch connector installed to steering column assembly, and then disconnect harness from steering column assembly.

• Lower shaft assembly (1)

5. Remove bolt (A) and nut (B) of column upper joint (2).



6. Remove steering column assembly and nuts, then remove steering column assembly.
7. If replacing steering column, remove the following:
 - Remove driver air bag module. Refer to [SR-4, "Removal and Installation"](#).
 - Remove steering wheel. Refer to [ST-12, "Removal and Installation"](#).
 - Remove combination switch and spiral cable. Refer to [SR-7, "Removal and Installation"](#).

INSPECTION AFTER REMOVAL


Hole Cover Seal, Hole Cover and Lower Shaft Assembly

Check each part of hole cover seal, hole cover and steering column and lower shaft assembly for damage or other malfunctions. Replace if necessary.

Steering Column Assembly

- Check each part of steering column assembly for damage or other malfunctions. Replace entire steering column assembly if any parts are damaged.
- Measure the length (L) as shown if vehicle has been involved in a minor collision. Replace steering column assembly if outside the specifications.

Steering column length (L) : Refer to [ST-31, "Steering Column"](#)



- Measure steering column rotating torque using Tool. Replace steering column assembly if outside the standard.

STEERING COLUMN

< ON-VEHICLE REPAIR >


Tool number : ST3127S000 (J-25765-A)

Rotating torque : Refer to [ST-31. "Steering Column"](#)

- Check tilt and telescopic mechanism operating range (L¹), (L²) as shown.

Tilt operating range (L¹) : Refer to [ST-31. "Steering Column"](#)

Telescopic operating range (L²) : Refer to [ST-31. "Steering Column"](#)



INSTALLATION

Steering Column Assembly

CAUTION:

- Any time the ignition switch has been disconnected, removed or installed, the keys must be re-registered in the BCM. Refer to Consult-III operations IVIS/NVIS.

Installation is in the reverse order of removal.

Hole Cover Seal, Hole Cover and Lower Shaft Assembly


Installation is in the reverse order of removal.

- When installing lower shaft assembly to steering gear assembly, follow the procedure listed below.
- Set rack of steering gear in the neutral position.

NOTE:

To get the neutral position of rack, turn gear sub-assembly and measure the distance of inner socket, and then measure the intermediate position of the distance.

- Align rear cover cap projection (A) with the marking position (B) of gear housing assembly.
- Install slit part of lower shaft assembly (C) aligning with the projection (A) of rear cover cap (1). Make sure that the slit part of lower shaft assembly (C) is aligned with both the projection (A) of rear cover cap (1) and the marking position (B) of gear housing assembly.
- Perform final tightening of nuts and bolts on each part under unladen conditions with tires on level ground when removing steering gear assembly. Check wheel alignment. Refer to [FSU-17. "Wheel Alignment \(Unladen*\)"](#).




STEERING GEAR AND LINKAGE

< ON-VEHICLE REPAIR >

STEERING GEAR AND LINKAGE

Exploded View

INFOID:000000005432716



1. Cotter pin

2. Steering gear assembly

← Front

Removal and Installation

INFOID:000000005432717


REMOVAL

1. Remove the front tires.
2. Disconnect stabilizer connecting rods at steering knuckles and reposition. Refer to [FSU-12, "Exploded View"](#).
3. Remove cotter pin (1), and then loosen the nut.
4. Remove steering outer socket (2) from steering knuckle (3) so as not to damage ball joint boot (4) using the Tool.


CAUTION:

Temporarily tighten the nut to prevent damage to threads and to prevent the Tool from suddenly coming off.

Tool number : HT72520000 (J-25730-A)



5. Remove lower side bolt of lower joint.



6. Remove front exhaust tube. Refer to [EX-5, "Exploded View"](#) (QR25DE), [EX-11, "Exploded View"](#) (VQ35DE).

STEERING GEAR AND LINKAGE

< ON-VEHICLE REPAIR >

Tool number : HT72520000 (J-25730-A)

7. Remove high and low pressure piping of hydraulic piping, and then drain power steering fluid. Refer to [ST-7, "Draining"](#).
8. Remove steering hydraulic piping bracket from front suspension member.
9. Remove SSPS valve harness connector. Refer to [ST-27, "Exploded View"](#).
10. Remove bolts and nuts of steering gear assembly, and then remove steering gear assembly from vehicle.

INSPECTION AFTER REMOVAL

Check for fluid leaks or damage to steering gear. If any exist, replace steering gear as an assembly.


INSTALLATION

Installation is in the reverse order of removal. For tightening specifications, refer to [ST-16, "Exploded View"](#).

- When installing lower joint to steering gear assembly, follow the procedure listed below.
- Set rack of steering gear in the neutral position.

NOTE:

- To get the neutral position of rack, turn gear-sub assembly and measure the distance of inner socket, and then measure the intermediate position of the distance.
- Align rear cover cap projection (A) with the marking position (B) of gear housing assembly.
- Install slit part of lower joint (C) aligning with the projection (A) of rear cover cap (1). Make sure that the slit part of lower joint (C) is aligned with both the projection (A) of rear cover cap (1) and the marking position (B) of gear housing assembly.
- After installation, bleed air from the steering hydraulic system. Refer to [ST-7, "Inspection"](#).
- Perform final tightening of nuts and bolts on each part under unladen conditions with tires on level ground when removing steering gear assembly.
- Check wheel alignment. Refer to [FSU-6, "Inspection and Adjustment"](#).
- On models equipped with VDC, perform neutral position steering angle adjustment. Refer to [BRC-66, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).



INSPECTION AFTER INSTALLATION

Make sure that steering wheel operates smoothly by turning several times from full left stop to full right stop.

POWER STEERING OIL PUMP


< ON-VEHICLE REPAIR >

POWER STEERING OIL PUMP

QR25DE

QR25DE : Exploded View

INFOID:000000005432718



1. Rear bracket

2. Pump assembly

3. Front bracket

QR25DE : Removal and Installation

INFOID:000000005432719

REMOVAL

1. Drain power steering fluid from reservoir tank.
2. Remove undercover using power tool.
3. Loosen drive belt. Refer to [EM-16, "Removal and Installation"](#).
4. Remove drive belt from oil pump pulley.
5. Remove piping of high pressure and low pressure (drain fluid from pipings). Refer to [ST-20, "QR25DE : Exploded View"](#).
6. Remove oil pump bolts, and then remove power steering oil pump. Refer to [ST-18, "QR25DE : Exploded View"](#).

INSPECTION AFTER REMOVAL

INSTALLATION

Installation is in the reverse order of removal. For tightening specifications, refer to [ST-18, "QR25DE : Exploded View"](#).

- Perform the following procedure after installing.
 - For the installation of drive belt, refer to [EM-16, "Tension Adjustment"](#).
 - Bleed air. Refer to [ST-7, "Inspection"](#).


VQ35DE

POWER STEERING OIL PUMP

< ON-VEHICLE REPAIR >

VQ35DE : Exploded View

INFOID:000000005432720



1. Rear bracket

2. Pump assembly

3. Front bracket

ST

VQ35DE : Removal and Installation

INFOID:000000005432721

REMOVAL

1. Drain power steering fluid from reservoir tank.
2. Remove undercover using power tool.
3. Loosen drive belt. Refer to [EM-120, "Removal and Installation"](#).
4. Remove drive belt from oil pump pulley.
5. Remove piping of high pressure and low pressure (drain fluid from pipings). Refer to [ST-21, "VQ35DE : With 17 Inch Tire"](#) or [ST-23, "VQ35DE : With 18 Inch Tire"](#).
6. Remove oil pump bolts, and then remove power steering oil pump. Refer to [ST-19, "VQ35DE : Exploded View"](#).

INSPECTION AFTER REMOVAL

INSTALLATION

Installation is in the reverse order of removal.

- When installing power steering oil pump, install all bolts by hand initially, then tighten bolts to specification.
- Perform the following procedure after installing.
 - Adjust belt tension. Refer to [EM-120, "Tension Adjustment"](#).
 - Bleed air. Refer to [ST-7, "Inspection"](#).

HYDRAULIC LINE

< ON-VEHICLE REPAIR >

HYDRAULIC LINE

QR25DE



QR25DE : Exploded View

INFOID:000000005432722

CAUTION:

Securely insert harness connector to pressure sensor.

SEC. 497



AWGIA0007GB

- 1. Reservoir tank
- 2. Reservoir tank bracket
- 3. Suction hose
- 4. High-pressure hose
- 5. Oil pump assembly
- 6. Steering gear assembly
- 7. Low pressure piping
- 8. High pressure piping
- 9. O-ring

- 10. High pressure piping
- 11. O-ring
- 12. O-ring
- 13. O-ring
- 14. Steering gear assembly

- 15. O-ring
- 16. O-ring
- 17. O-ring
- 18. O-ring
- 19. O-ring
- 20. O-ring
- 21. O-ring
- 22. O-ring
- 23. O-ring
- 24. O-ring
- 25. O-ring
- 26. O-ring
- 27. O-ring
- 28. O-ring
- 29. O-ring
- 30. O-ring
- 31. O-ring
- 32. O-ring
- 33. O-ring
- 34. O-ring
- 35. O-ring
- 36. O-ring
- 37. O-ring
- 38. O-ring
- 39. O-ring
- 40. O-ring
- 41. O-ring
- 42. O-ring
- 43. O-ring
- 44. O-ring
- 45. O-ring
- 46. O-ring
- 47. O-ring
- 48. O-ring
- 49. O-ring
- 50. O-ring

HYDRAULIC LINE

< ON-VEHICLE REPAIR >

- | | | |
|---------------------|---|--|
| 10. Eye-bolt | 11. Copper washer | 12. Eye-joint (assembled to high-pressure side hose) |
| 13. Pressure sensor | 14. Oil pump bracket to engine block mounting point |  Apply Genuine Nissan PSF or equivalent |

QR25DE : Removal and Installation

INFOID:000000005432723

REMOVAL


Refer to [ST-20. "QR25DE : Exploded View"](#) for removal procedure.

INSTALLATION


- Insert hose securely until it contacts tube spool.

CAUTION:

Do not apply fluid.



- Install eye-bolt with eye-joint (assembled to high-pressure hose) protrusion facing with pump side cutout, and then tighten it to the specified torque after tightening by hand.



VQ35DE

VQ35DE : With 17 Inch Tire

INFOID:000000005432724

EXPLODED VIEW



CAUTION:

Securely insert harness connector to pressure sensor.

HYDRAULIC LINE

< ON-VEHICLE REPAIR >

SEC. 497



AWGIA0008GB

- | | | |
|------------------------|---|--|
| 1. Reservoir tank | 2. Reservoir tank bracket | 3. Suction hose |
| 4. High pressure hose | 5. Oil pump assembly | 6. Steering gear assembly |
| 7. Low pressure piping | 8. High pressure piping | 9. O-ring |
| 10. Eye-bolt | 11. Copper washer | 12. Eye-joint (assembled to high-pressure side hose) |
| 13. Pressure sensor | 14. Oil pump bracket to engine mounting point | : Genuine Nissan PSF or equivalent |

REMOVAL AND INSTALLATION

Removal

Refer to [ST-21, "VQ35DE : With 17 Inch Tire"](#) for removal procedure.

HYDRAULIC LINE


< ON-VEHICLE REPAIR >

Installation


- Insert hose securely until it contacts tube spool.

CAUTION:

Do not apply fluid.



- Install eye-bolt with eye-joint (assembled to high-pressure hose) protrusion facing with pump side cutout, and then tighten it to the specified torque after tightening by hand.



VQ35DE : With 18 Inch Tire

INFOID:000000005432725

EXPLODED VIEW



CAUTION:

Securely insert harness connector to pressure sensor.

HYDRAULIC LINE

< ON-VEHICLE REPAIR >

SEC. 497



ALGIA0046GB

- | | | |
|--|---------------------------|--------------------------------|
| 1. High pressure hose | 2. Suction hose | 3. Reservoir tank bracket |
| 4. Reservoir tank | 5. Oil pump assembly | 6. Power steering fluid cooler |
| 7. Power steering fluid cooler brackets | 8. Steering gear assembly | 9. Low pressure piping |
| 10. Eye-bolt | 11. High pressure piping | 12. Copper washer |
| 13. eye bolt | 14. Copper washer | 15. Pressure sensor |
| 16. Eye-joint (assembled to high-pressure side hose) | | |

REMOVAL AND INSTALLATION

Removal

Refer to [ST-23. "VQ35DE : With 18 Inch Tire"](#) for removal procedure.

HYDRAULIC LINE


< ON-VEHICLE REPAIR >

Installation

CAUTION:

Do not apply fluid.


- Install eye-bolt with eye-joint (assembled to high-pressure hose) protrusion facing with pump side cutout, and then tighten it to the specified torque after tightening by hand.



- Install check valve with eye-joint (assembled to high pressure tube) protrusion facing gear side and tighten it to the specified torque after tightening by hand.

CAUTION:

Do not reuse copper washers.



A
B
C
D
E
F
ST
H
I
J
K
L
M
N
O
P

STEERING COLUMN

< DISASSEMBLY AND ASSEMBLY >

DISASSEMBLY AND ASSEMBLY

STEERING COLUMN

Disassembly and Assembly

INFOID:000000005432726

CAUTION:

- Any time the ignition switch has been disconnected, removed or installed, the keys must be re-registered in the BCM. Refer to Consult-III operations IVIS/NVIS.

The steering column assembly is not serviceable and must be replaced as an assembly.


STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >

STEERING GEAR AND LINKAGE

Exploded View

INFOID:000000005432727



- | | | |
|------------------|---------------|---------------------------------------|
| 1. Outer socket | 2. Boot clamp | 3. Boot |
| 4. Inner socket | 5. Boot clamp | 6. SSPS valve (part of gear assembly) |
| 7. Gear assembly | ↩ Front | ☑ Three Bound TB1111 or equivalent |

Disassembly

INFOID:000000005432728

1. Remove outer socket locknut and outer socket
2. Remove boot clamps and boot.
3. Remove inner socket.

Inspection

INFOID:000000005432729

INSPECTION AFTER DISASSEMBLY

Boot

Check boot for cracks. Replace if there are.

Outer Socket and Inner Socket


1. Ball joint swinging torque

STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >

- Hook a tool at the point shown in the figure and pull the spring balance. Make sure that the spring balance reads the specified value when ball stud and inner socket start to move. Replace outer socket and steering gear assembly if they are outside the standard.

Tool number : — (J-44372)




| Items | Outer socket | Inner socket |
|-----------------------------------|---|---|
| Measuring point of spring balance | Stud cotter pin mounting hole | Measuring point at * mark shown in the figure |
| Swinging torque | Refer to ST-32, "Steering Gear" . | |
| Spring balance measurement | | |

2. Ball joint rotating torque

- Make sure that the reading is within the following specified range using Tool. Replace outer socket if the reading is outside the specified value.

Tool number : ST31227S000 (J-25765-A)


| | |
|-------------------------------------|---|
| Outer socket rotating torque | : Refer to ST-32, "Steering Gear" . |
|-------------------------------------|---|



3. Ball joint axial end play

- Apply an axial load of 490 N (50 kg-f, 111 lb-f) to ball stud using a dial gauge. Measure amount of stud movement, and then make sure that the value is within the following specified range. Replace outer socket and inner socket if the measured value is outside the standard.

| | |
|---------------------|---|
| Outer socket | : Refer to ST-32, "Steering Gear" . |
| Inner socket | |



Assembly


INFOID:000000005432730

- Apply Three Bound TB1111 or equivalent to inner socket and turn pinion fully to left with inner socket installed to gear housing assembly.


STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >

2. Install large end of boot to gear housing assembly.
3. Install small end of boot to inner socket boot mounting groove.



4. Install boot clamp to boot small end.
5. Install boot clamp to boot large end.




6. Adjust inner socket to standard length (L), and then tighten lock nut to the specified torque. Refer to [ST-27, "Exploded View"](#). Check length of inner socket (L) again after tightening lock nut. Make sure that the length is the standard.

Inner socket length (L) : Refer to [ST-32, "Steering Gear"](#).

CAUTION:

Adjust toe-in after this procedure. Length achieved after toe-in adjustment should not be more than 98.3 mm max.



A
B
C
D
E
F
ST
H
I
J
K
L
M
N
O
P

POWER STEERING OIL PUMP

< DISASSEMBLY AND ASSEMBLY >

POWER STEERING OIL PUMP

QR25DE

QR25DE : Disassembly and Assembly

INFOID:000000005432731

The power steering oil pump and pulley is not serviceable and should be replaced as an assembly. For front and rear bracket removal, refer to [ST-18. "QR25DE : Removal and Installation"](#).

VQ35DE

VQ35DE : Disassembly and Assembly

INFOID:000000005432732

The power steering oil pump and pulley is not serviceable and should be replaced as an assembly. For front and rear bracket removal, refer to [ST-19. "VQ35DE : Removal and Installation"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Steering Wheel


INFOID:0000000005432733

| | |
|-------------------------------|-------------------------------|
| Steering wheel axial end play | 0 mm (0 in) |
| Steering wheel play | 0 - 35 mm (0 - 1.38 in) |
| Steering wheel turning force | 39 N (4 kg-f, 9 lb-f) or less |

Steering Angle

INFOID:0000000005432734

Unit: Degree minute (Decimal Degree)




SGIA0055E

| Tire size | | P215/60R16 | P215/55R17 | P235/45R18 |
|------------------------|---------|-----------------|-----------------|-----------------|
| Inner wheel (Angle: A) | Minimum | 35° 30' (35.5°) | 33° 30' (33.5°) | 32° (32.0°) |
| | Nominal | 38° 30' (38.5°) | 36° 30' (36.5°) | 35° (35.0°) |
| | Maximum | 39° 30' (39.5°) | 37° 30' (37.5°) | 36° (36.0°) |
| Outer wheel (Angle: B) | Nominal | 31° 30' (31.5°) | 30° 30' (30.5°) | 29° 30' (29.5°) |

Steering Column

INFOID:0000000005432735

STEERING COLUMN LENGTH



SGIA1177E


| | | |
|----------------------------|--------------------|---------------------------------|
| Steering column length (L) | Telescopic maximum | 513 - 543 mm (20.20 - 21.38 in) |
| | Telescopic minimum | 503 - 513 mm (19.80 - 20.20 in) |

TILT MECHANISM OPERATING RANGE

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

Unit: mm (in)




SGIA1179E

| | |
|--|-----------|
| Tilt operating range (L ¹) | 41 (1.61) |
| Telescopic operating range (L ²) | 40 (1.57) |

Steering Gear


INFOID:000000005432736

STEERING OUTER SOCKET AND INNER SOCKET



SGIA0896E

| Steering gear type | | PR26AF |
|--------------------|--|--|
| Outer socket | Swinging torque | 0.1 - 2.9 N·m (0.01 - 0.29 kg·m, 1.0 - 25 in·lb) |
| | Measurement on spring balance Measuring point: cotter pin hole of stud | 1.4 - 42.7 N (0.14 - 4.4 kg, 12 - 31 lb) |
| | Rotating torque | 0.3 - 2.9 N·m (0.03 - 0.29 kg·m, 3.0 - 25 in·lb) |
| | Axial end play | 0.5 mm (0.020 in) or less |
| Inner socket | Swinging torque | 0.1 - 7.8 N·m (0.01 - 0.79 kg·m, 1.0 - 69 in·lb) |
| | <ul style="list-style-type: none"> Measurement on spring balance Measuring point at (* mark shown) | 0.8 - 64 N (0.082 - 6.5 kg, 0.18 - 14.4 lb) |
| | Axial end play | 0.2 mm (0.008 in) or less |




SGIA0167E

| | | |
|-------------------------|---------|--------------------|
| Inner socket length (L) | Nominal | 93.3 mm (3.673 in) |
| | Maximum | 98.3 mm (3.870 in) |

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

RACK STROKE



AWGIA0003GB

| | | | |
|---|--------------------|--------------------|--------------------|
| Steering gear model | PR26AF | | |
| Tire size | P215/60R16 | P215/55R17 | P235/45R18 |
| Rack neutral position, dimension (L) (rack stroke) | 71.5 mm (2.815 in) | 69.0 mm (2.717 in) | 66.5 mm (2.167 in) |

Oil Pump

INFOID:000000005432737

| | |
|------------------------------------|--|
| Oil pump relief hydraulic pressure | 8,520 - 9,320 kPa (86.9 - 95.1 kg/cm ² , 1,235 - 1,351 psi) |
|------------------------------------|--|

Steering Fluid

INFOID:000000005432738

| | |
|-------------------------|--|
| Fluid type and capacity | Refer to MA-15, "FOR USA AND CANADA : Fluids and Lubricants" . |
|-------------------------|--|

A
B
C
D
E
F
ST
H
I
J
K
L
M
N
O
P