



SECTION **BR**

BRAKE SYSTEM

CONTENTS

SERVICE BRAKE	BR- 2	BLEEDING HYDRAULIC SYSTEM	BR-14
BRAKE PEDAL	BR- 2	PARKING BRAKE	BR-15
MASTER CYLINDER	BR- 2	PARKING BRAKE	BR-15
BRAKE FLUID LEVEL GAUGE	BR- 4	SERVICE DATA AND	
BRAKE LINE	BR- 4	SPECIFICATIONS	BR-16
NP-VALVE	BR- 4	GENERAL SPECIFICATIONS	BR-16
FRONT DISC BRAKE	BR- 5	INSPECTION AND ADJUSTMENT	BR-16
FRONT DISC ROTOR	BR- 7	TIGHTENING TORQUE	BR-17
REAR DISC BRAKE	BR- 8	TROUBLE DIAGNOSES AND	
REAR DISC ROTOR	BR-12	CORRECTIONS	BR-18
BRAKE BOOSTER	BR-13	SPECIAL SERVICE TOOL	BR-20

REMOVAL

1. Remove foot brake plate.
2. Disconnect spring from brake fluid gauge.
3. Disconnect front and rear brake tubes from master cylinder.

Refer to Section MA (Brake System) for:

- CHECKING FOOT BRAKE
- CHECKING PARKING BRAKE

CAUTION

When removing brake tubes, be sure to use a container to receive draining brake fluid. Use of rags is also suggested to help absorb parts and seal.

Note: When disconnecting brake tubes, be sure to use a container to receive draining brake fluid. Use of rags is also suggested to help absorb parts and seal.

INSPECTION

Thoroughly inspect all components for wear and damage. Replace any parts that are faulty.


CAUTION

When removing the master cylinder, be sure to use a container to receive draining brake fluid. Use of rags is also suggested to help absorb parts and seal.



SERVICE BRAKE

BRAKE PEDAL



- 1 Collar
- 2 Brake pedal
- 3 Fulcrum bolt
- 4 Return spring
- 5 Clevis pin
- 6 Snap pin

SBR242

REMOVAL

1. Remove instrument lower cover and floor assist nozzle.
2. Remove snap pin and clevis pin and then separate Brake Booster operating rod from pedal.
3. Remove fulcrum bolt.

INSPECTION

Check brake pedal for the following items, servicing as necessary.


1. Check pedal bushing for wear, deformation or damage.
2. Check for bent brake pedal.
3. Check for fatigued return spring.

INSTALLATION

Install brake pedal in reverse order of removal, paying attention to the following:

- ⊕ : Fulcrum bolt
34 - 39 N·m
(3.5 - 4.0 kg-m,
25 - 29 ft-lb)

1. Apply sufficient amount of recommended multi-purpose grease to sliding contact surface and hook of return spring.





BR730

2. Adjust brake pedal, referring to Section MA.

MASTER CYLINDER


TOKICO Make



⊕ : N·m (kg-m, ft-lb)

SBR240

NABCO Make



SRB241

REMOVAL

1. Remove heat shield plate.
2. Disconnect wiring to brake fluid level gauge.
3. Disconnect front and rear brake tubes from master cylinder.

CAUTION:

When removing brake tubes, use suitable tube wrench.
Never use open end or adjustable wrench.

Note: When disconnecting brake tubes, be sure to use a container to receive draining brake fluid. Use of rags is also suggested to keep adjacent parts and area clean.

4. Remove master cylinder securing nut. Master cylinder can then be taken out.

DISASSEMBLY

1. Remove reservoir caps and filters and drain out brake fluid.
2. Pry off stopper ring, using a screwdriver.
3. Remove stopper screw and take out stopper, primary piston assembly, spring, and secondary piston assembly, in the order shown.

Note: Discard caps if they are removed from piston assemblies and use new ones.

4. Unscrew plugs to gain access to check valve for disassembling.

Note: Do not remove or disassemble brake fluid level gauge.

INSPECTION

Thoroughly clean all parts in a suitable solvent and check them for wear or damage. Replace any part that is faulty.

CAUTION:

Use brake fluid to clean. Never use mineral oil.

1. Check cylinder and pistons for evidence of abnormal wear or damage. Replace if found faulty.
2. Check piston-to-cylinder clearance. If it exceeds the specified value, replace either piston or cylinder.

Piston-to-cylinder clearance:

Less than 0.15 mm (0.0059 in)

3. Check springs for weakness, fatigue or damage. Replace if necessary.
4. When master cylinder is disassembled, be sure to discard caps and valves. Replace any other parts which show evidence of deformation, wear or other damage.
5. Replace damaged oil reservoirs and caps.

ASSEMBLY

Assemble master cylinder following the reverse procedure of disassembly, paying particular attention to the following note:

Note:

- a. Replace gaskets and packing with new ones.
- b. Apply brake fluid or rubber grease to sliding contact surface of parts to facilitate assembly of master cylinder.
- c. The brake master cylinder is available in both NABCO make and TOKICO make. There is no interchangeability of repair kits or component parts between NABCO and TOKICO makes.
When replacing the repair kit or component parts, ascertain the brand of the brake master cylinder body. Be sure to use parts of the same make as the former ones.

INSTALLATION

Install master cylinder following the reverse procedure of removal.

After installation, bleed brake system.

CAUTION:

When installing brake tubes, use Flare Nut Torque Wrench GG94310000.

⊕ : Brake master cylinder securing nut

7.8 - 10.8 N·m
(0.8 - 1.1 kg·m,
5.8 - 8.0 ft·lb)

Brake tube flare nut
15 - 18 N·m
(1.5 - 1.8 kg·m,
11 - 13 ft·lb)

BRAKE FLUID LEVEL GAUGE

INSPECTION

1. Disengage hand brake control lever.
2. Raise cap and make sure that brake warning lamp goes on when float comes into contact with stopper.

BRAKE LINE

REMOVAL

1. Remove flare nuts on both ends, and remove retainers and clips.

CAUTION:

When removing brake tubes and hoses, use suitable tube wrench. Never use open end or adjustable wrench.

2. To remove brake hose, first remove flare nut securing brake tube to brake hose and withdraw lock spring. End of hose can then be removed from bracket. Next remove brake hose. Do not twist brake hose.

INSPECTION

Check brake lines (tubes and hoses) for evidence of cracks, deterioration or other damage. Replace any faulty parts.

If leakage occurs at end around joints, re-tighten or, if necessary, replace faulty parts.

INSTALLATION

Pay particular attention to following instructions when installing brake lines.


1. Leave a sufficient space between brake lines and adjacent parts so that brake lines are completely free from vibration during driving.
2. Be careful not to warp or twist.
3. When installing brake tube, keep a certain distance between tube and adjacent parts as follows:

- Tube to rotating parts
More than 10 mm (0.39 in)
- Tube to other parts
More than 5 mm (0.20 in)

4. Always fasten brake tubes with mounting clips where necessary.

On rear suspension arm, there are two double clips which should be used to secure brake tubes in manner described below.

Bend short clip straight up. With brake tube on long clip, bend clip up and around tube. Finally, wrap short clip around tube to secure the installation.



BR141

5. Do not tighten brake line mounting flare nut excessively.

CAUTION:

When installing brake tubes, use Flare Nut Torque Wrench GG94310000.

⊕ : Brake tube flare nut


15 - 18 N·m
(1.5 - 1.8 kg·m,
11 - 13 ft·lb)

Brake hose connector

17 - 20 N·m
(1.7 - 2.0 kg·m,
12 - 14 ft·lb)

6. Upon completion of installation of brake lines, bleed air out of brake lines.

NP-VALVE



BR163A

REMOVAL AND INSTALLATION

1. Remove flare nuts.

CAUTION:

When removing brake tube, use suitable tube wrench. Never use open end or adjustable wrench.

2. Remove NP-valve retaining bolts, and remove NP-valve.

Note: Do not disassemble NP-valve.

3. Installation is in the reverse order of removal.

CAUTION:

When installing brake tube, use Flare Nut Torque Wrench GG94310000.


 : Flared nut

15 - 18 N·m
(1.5 - 1.8 kg·m,
11 - 13 ft·lb)

NP-valve attaching bolt


5.9 - 6.9 N·m
(0.6 - 0.7 kg·m,
4.3 - 5.1 ft·lb)

FRONT DISC BRAKE



- 1 Torque member
- 2 Pad retainer
- 3 Outer shim
- 4 Pad
- 5 Inner shim
- 6 Pin bolt
- 7 Cylinder body
- 8 Main pin
- 9 Dust seal
- 10 Piston seal
- 11 Piston
- 12 Sub pin
- 13 Rubber seal

Tightening torque N·m (kg·m, ft·lb)


 : 22 - 31 (2.2 - 3.2, 16 - 23)

BR164A




PAD REPLACEMENT

Removal

1. Jack up front of car, and support it on safety stands. Remove wheel.
2. Remove lower pin bolt.




165A

3. Open cylinder body upward and remove pad retainer , and inner and outer shims  & .

Note: Do not pull out cylinder body in axial direction (direction of pin guide).

4. Detach pads.



- 1 Inner shim
- 2 Pad retainer
- 3 Outer shim
- 4 Pads

BR166A

CAUTION:

After removing pads, do not depress brake pedal, or pistons will jump out.

Brake System

Inspection

1. When pads are heavily fouled with oil or grease or when pad is deteriorated or deformed, replace it.
2. If pad is worn to less than the specified value, replace.

Pad wear limit
 (Minimum thickness):
 2 mm (0.08 in)

Note: Always replace pads in pad kit (four pads).

3. Check rotor, referring to Rotor for inspection.


Installation

1. Clean piston end and surroundings of pin bolts.

CAUTION:
 Use brake fluid to clean. Never use mineral oil.


Note: Be careful not to get oil on rotor.

2. Install new pad (inner side).
 Insert lever into opening in cylinder body as shown below and push piston by catching torque member.



3. Coat the following point with recommended brake grease.
 - Torque member-to-pad clearance


Note: Do not grease friction face of pad.



➔, [hatched box] : Greasing point

BR167A

4. Install new pad (outer side), and inner and outer shims.
5. After installing pads, install pad retainer, being careful not to fit it upside down.



6. Install cylinder body and then tighten lower pin bolt.

⊕ : Pin bolt
 22 - 31 N·m
 (2.2 - 3.2 kg·m,
 16 - 23 ft·lb)

7. Depress brake pedal several times, and pads will settle into proper position.
8. Install wheels and lower car to ground.

REMOVAL


1. Jack up front of car, and support it on safety stands. Remove wheel.
2. Remove front brake hose.

CAUTION:

When removing brake tube, use suitable tube wrench. Never use open-end or adjustable wrench.


Note: Plug up hole in caliper and brake tube so that brake fluid does not flow out.

3. Remove caliper assembly from knuckle spindle.



DISASSEMBLY

1. Drain brake fluid from cylinder body.
2. Wipe off dust and mud from caliper assembly.
3. Remove pin bolts.



4. Separate cylinder body and torque member.
5. Remove pad retainers and pads.
6. Force out pistons with dust seal from cylinder by feeding compressed air gradually.

WARNING:

Gradually increase air pressure so that piston does not pop out.

7. Remove piston seals.

CAUTION:

Be careful not to damage seals and cylinder body.

8. If necessary, remove sub pin, main pin and dust seals.

INSPECTION

Clean all parts and check as follows:

CAUTION:

Use brake fluid to clean. Never use mineral oil.

Cylinder body

1. Check inside surface of cylinder for score, rust, wear, damage or presence of foreign substances. If any surface fault is detected, replace cylinder body.
2. Minor damage from rust of foreign substances may be eliminated by polishing surface with a fine emery cloth. If damage is major, cylinder assembly must be replaced.

Torque member

Check for wear, cracks or other damage. Replace if any fault is detected.

Piston

Check piston for score, rust, wear, damage or presence of foreign substances. Replace if any fault is detected.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign matter is stuck on sliding surface.

Piston seal and dust seal

Replace piston seal and dust seal at each disassembly.

Main pin, sub pin and rubber bushing


Check for wear, cracks or other damage. Replace if any fault is detected.

ASSEMBLY

Assemble front brake in reverse order of disassembly, closely observing the following:

1. Install piston seals, taking care not to damage them.
2. Apply brake fluid to sliding portions of piston, inside of cylinder body.
3. With dust seal fitted to piston, insert dust seal into groove in cylinder body and install piston. Then securely fit dust seal.

Note: Apply rubber grease to inside of dust seal.



BR171A

4. Coat the following part with recommended brake grease.
 - Torque member-to-pad clearance.
5. Apply a coat of recommended multi-purpose grease to main pin rubber bushing and to sub pin.

6. Tighten pin bolts.

Ⓣ : Pin bolts

22 - 31 N·m
(2.2 - 3.2 kg·m,
16 - 23 ft·lb)

INSTALLATION

1. Install caliper assembly without pads and pad retainer to knuckle spindle.

Ⓣ : Caliper mounting bolt

72 - 97 N·m
(7.3 - 9.9 kg·m,
53 - 72 ft·lb)

2. Install pads and pad retainer. Refer to Pad Replacement.
3. Install front brake hose and bleed brake system.

CAUTION:

When installing brake tubes, use Flare Nut Torque Wrench GG94310000.

Ⓣ : Brake tube flare nut

15 - 18 N·m
(1.5 - 1.8 kg·m,
11 - 13 ft·lb)

Air bleeder

6.9 - 8.8 N·m
(0.7 - 0.9 kg·m,
5.1 - 6.5 ft·lb)

4. After installing, see if there is no leak by depressing brake pedal several times.

Note: Turn rotor to make sure it does not drag excessively.

FRONT DISC ROTOR

REMOVAL

Refer to Removal (Section FA).

INSPECTION

Check the following items and, if necessary, replace. Checks can be made by removing only wheel.

Brake System

1. Sliding surface

If there are cracks or considerable chips, replace.

2. Runout

Adjust wheel bearing correctly. Using a dial gauge, measure runout.


Runout limit:

Total indicator reading

Less than 0.10 mm (0.0039 in)

at center of rotor pad

contact surface



BR025A

3. Parallelism

Measure thickness of rotor in circumferential direction, using a micrometer.


Parallelism:

Circumferential direction

Less than

0.03 mm (0.0012 in)

Note: As this value increases (wear occurs progressively), vibration corresponding to revolution of tire may often be transmitted to interior of car.



BR061

4. Thickness

If rotor thickness is beyond wear limit, replace rotor. When correcting thickness, be sure that the thickness after correction does not exceed the limit.

Standard thickness:

20.0 mm (0.787 in)

Wear limit (Minimum thickness):

18.0 mm (0.709 in)

INSTALLATION

Install rotor in reverse order of removal. Adjust wheel bearing preload correctly. Refer to Adjustment (Section MA).

Ⓣ : Rotor to wheel hub


54 - 74 N·m

(5.5 - 7.5 kg-m,

40 - 54 ft-lb)

REAR DISC BRAKE

- | | |
|----------------------|-----------------|
| 1 Yoke | 20 Spring cover |
| 2 Yoke spring | 21 Spring |
| 3 Clip | 22 Spring seat |
| 4 Pad pin | 23 Snap ring C |
| 5 Anti-squeal spring | 24 Key plate |
| 6 Pad | 25 Push rod |
| 7 Retaining ring | 26 O-ring |
| 8 Dust seal | 27 Strut |
| 9 Outer piston | 28 Inner piston |
| 10 Oil seal | 29 Cam |
| 11 Adjusting nut | 30 Toggle lever |
| 12 Bearing | 31 Spring |
| 13 Spacer | 32 Washer |
| 14 Wave washer | 33 Nut |
| 15 Snap ring B | |
| 16 Piston seal | |
| 17 Cylinder body | |
| 18 Retainer | |
| 19 Snap ring A | |




BR172A

Brake System

PAD REPLACEMENT

Removal

1. Jack up rear of car, and support it on safety stands. Remove wheel.
2. Remove clip ①.
3. Remove pad pins ② holding anti-squeal springs ③ with finger.
4. Detach pads.



BR094A

CAUTION:

After removing pads, do not depress brake pedal, or pistons will jump out.

Inspection

1. Clean pads with cleaning solvent.
2. When pads are heavily fouled with oil or grease or when pad is deteriorated or deformed, replace it.
3. If pad is worn to less than the specified value, replace.

Pad wear limit

(Minimum thickness):
2 mm (0.08 in)

Note: Always replace pads in pad kit (four pads).

4. Check rotor, referring to Rotor for inspection.

Installation

1. Clean piston end.

CAUTION:


Use brake fluid to clean. Never use mineral oil.

Note: Be careful not to get oil on rotor.

2. (1) Coat the following points with recommended brake grease.

- Cylinder body-to-pad clearance
- Yoke-to-pad clearance
- Pad pin-to-pad clearance
- Pad pin-to-bracket clearance

Note: Do not grease friction face of pad.



BR095A
Greasing Points

- (2) Check that the following points are coated with silicone based grease. Nissan silicone based grease or equivalent.


Silicone based greasing points:

- Friction surface of yoke and cylinder body.
 - Cylinder body pad pin hole.
3. When installing new pad, bring piston and yoke into position determined by wear on old pad as follows:
 - Turn outer piston clockwise with a suitable driver until it retracts into cylinder body.

CAUTION:

Turn outer piston, being careful not to damage dust seal.

Note: While pushing outer piston, turn it clockwise.




BR173A

- With a lever placed between rotor and yoke, move yoke until clearances to install brake pads are equal.

4. After installing pads, install anti-squeal spring and pad pin, and fix with clip.

Note: Position outer piston so that portion of cutout is level and install pad by aligning this portion with protrusion at back of pad.



BR191A

5. Depress brake pedal few times to adjust brake pad-to-rotor clearance. Clearance is correct if brake pedal stroke is constant.

Add brake fluid to reservoir tank of master cylinder.

6. Install wheels and lower car to ground.

REMOVAL

1. Disconnect brake tube from caliper assembly.

CAUTION:


When removing brake tube, use suitable tube wrench. Never use open-end or adjustable wrench.

Note: Plug up hole in caliper and brake tube so that brake fluid does not flow out.

2. Disconnect hand brake cable.

Brake System


3. Remove caliper mounting bolts and caliper assembly.



BR175A


DISASSEMBLY

1. Drain brake fluid from cylinder body.
2. Wipe off dust and mud from caliper assembly.
3. Remove pads. Refer to Pad Replacement.
4. Stand yoke on a work bench. Push in cylinder body to separate it and yoke.



BR176A

5. Remove retaining rings and dust seals from end of both pistons.
6. Push in outer piston to drive out piston assembly.




BR177A

7. Remove piston seals.

CAUTION:

Be careful not to damage cylinder body.

8. Remove yoke spring from yoke.
9. Disengage piston assembly by turning inner and outer pistons counterclockwise.



BR178A

10. Disassemble outer piston.
 - (1) Remove snap ring B.
 - (2) Disassemble adjusting nut, ball bearing, spacers and wave washer.
11. Disassemble inner piston.
 - (1) Remove snap ring A and then disassemble spring cover, spring and spring seat.
 - (2) Remove snap ring C and then disassemble key plate, push rod and strut.
 - (3) While holding hand brake toggle lever in a vise, remove return spring and nut, and then remove lever.
 - (4) Remove dust seal and cam.

INSPECTION

Clean all parts and check as follows:

CAUTION:

Use brake fluid to clean. Never use mineral oil.

Cylinder body

1. Check inside surface of cylinder for score, rust, wear, damage or presence of foreign substances. If any surface fault is detected, replace cylinder body.
2. Minor damage from rust of foreign substances may be eliminated by polishing surface with a fine emery cloth. If damage is major, cylinder assembly must be replaced.

Piston

Check piston for score, rust, wear, damage or presence of foreign substances. Replace if any fault is detected.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign matter is stuck on sliding surface.

Yoke

Check for wear, cracks or other damage. Replace if any fault is detected.

Piston seal and dust seal

Replace piston seal and dust seal at each disassembly.


Adjusting nut oil seal and push rod O-ring

Replace at each disassembly.

ASSEMBLY

Piston assembly

- | | | | |
|------------------|-----------------|-----------------|-----------|
| 1 Retaining ring | 13 Spring cover | 20 Strut | 24 Spring |
| 2 Dust seal | 14 Spring | 21 Inner piston | 25 Washer |
| 3 Outer piston | 15 Spring seat | 22 Cam | 26 Nut |
| 4 Oil seal | 16 Snap ring C | 23 Toggle lever | |
| 5 Adjusting nut | 17 Key plate | | |
| 6 Bearing | 18 Push rod | | |
| 7 Spacer | 19 O-ring | | |
| 8 Wave washer | | | |
| 9 Snap ring B | | | |
| 10 Piston seal | | | |
| 11 Cylinder body | | | |
| 12 Snap ring A | | | |




Assemble piston assembly in the reverse procedure of disassembly, paying particular attention to the following:

1. Before assembling, apply thin coat of rubber grease to the following:
 - Groove in push rod and new O-ring
 - Strut ends
 - Oil seal
 - Piston seal
 - Inside of dust seal
 - Cam

CAUTION:

- Securely install oil seal in specified direction.
- Be careful not to excessively open or twist O-ring.

Note: Replace oil seals and dust seal with new ones.




2. Securely fit strut in hole in cam.
3. Engage square hole in key plate with push rod. Also engage convex in key plate in concave in piston.
4. Fit snap ring in groove securely.

5. Install spring seat, spring, spring cover and snap ring A with suitable press and drift.

CAUTION:

- Be careful not to deform spring cover.
- Take care not to push spring cover excessively.




BR190A

6. When installing hand brake toggle lever after assembling piston, turn cam in direction hand brake operates.

⌘ : Toggle lever nut

25 - 29 N·m
 (2.5 - 3.0 kg-m,
 18 - 22 ft-lb)

Caliper assembly



BR191A

1. Install piston seals, taking care not to damage them.
2. Apply rubber grease or brake fluid to sliding portions of piston, and inside of cylinder.
3. Insert outer and inner pistons into cylinder body.


Note: Insert inner piston and outer piston assembly in direction shown by arrow Q1.

Brake System

4. Clamp dust seals with retainer rings.

Note: Replace dust seals with new ones.

5. Install yoke spring on yoke.




BR181A

6. Coat the following points with silicone based grease.

- Frictional surfaces of yoke and cylinder body
- Cylinder body pad pin hole

Note: Silicone based grease is contained in seal kit of disc brake.



BR182A

Silicone Based Greasing Points

- : Silicone based greasing point
- 1 Yoke
- 2 Cylinder body
- 3 Pad pin

7. Assemble yoke and cylinder with retainer.

Note:

- a. Engage cutout portion of inner piston with yoke.
- b. Securely fit retainer into groove in piston.

8. Coat the following points with recommended brake grease.

- Cylinder body-to-pad clearance
 - Yoke-to-pad clearance
 - Pad pin-to-pad clearance
 - Pad pin-to-bracket clearance
9. Install pads, anti-squeal springs, pad pins and fix with clip.

INSTALLATION

1. Install caliper assembly to rear suspension arm.

- Ⓣ : Caliper mounting bolt
 38 - 52 N·m
 (3.9 - 5.3 kg·m,
 28 - 38 ft·lb)

2. Connect hand brake cable.
3. Connect brake tube and bleed brake system.

CAUTION:

When installing brake tubes, use Flare Nut Torque Wrench GG94310000.

- Ⓣ : Brake tube flare nut
 15 - 18 N·m
 (1.5 - 1.8 kg·m,
 11 - 13 ft·lb)
- Air bleeder
 6.9 - 8.8 N·m
 (0.7 - 0.9 kg·m,
 5.1 - 6.5 ft·lb)

4. After installation, depress brake pedal few times to properly adjust brake pad-to-rotor clearance, and check for oil leakage. When brake pedal stroke is constant, brake pad-to-rotor clearance is properly adjusted. It will automatically be adjusted by depressing brake pedal.

Note: Turn rotor to make sure it does not excessively drag.

REAR DISC ROTOR

REMOVAL

Remove caliper and rotor can be taken out.

Refer to Rear Disc Brake for removal.

INSPECTION


Check the following items and, if necessary, replace. Checks can be made by removing only wheel.

1. Sliding surface
 If there are cracks or considerable chips, replace.

2. Runout
 Adjust wheel bearing correctly. Using a dial gauge, measure runout.

Runout limit:

Total indicator reading;
 Less than 0.15 mm (0.0059 in)
 at center of rotor pad
 contact surface



BR104A

3. Parallelism
 Measure thickness of rotor in circumferential direction, using a micrometer.

Parallelism:

Circumferential direction;
 Less than 0.03 mm (0.0012 in)

Note: As this value increases (wear occurs progressively), vibration corresponding to revolution of tire may often be transmitted to interior of car.

Brake System

4. Thickness

If rotor thickness is beyond wear limit, replace rotor. When correcting thickness, be sure that the thickness after correction does not exceed the limit.

Standard thickness:

9.6 mm (0.378 in)

Wear limit (Minimum thickness):

8.6 mm (0.339 in)

INSTALLATION


Install rotor in reverse order of removal.

BRAKE BOOSTER

INSPECTION OF OPERATION

Checking vacuum pressure

1. Connect a vacuum gauge, in the line, between check valve and Brake Booster.



- 1 Check valve
- 2 Vacuum gauge

2. Start engine and increase engine speed. Stop engine when vacuum gauge indicates 66.7 kPa (500 mmHg, 19.69 inHg).

Air tight test (No load)

Fifteen seconds after engine is stopped, observe the rate of drop in air pressure registered by vacuum gauge. If vacuum pressure drops more than the specified value, refer to the following chart to determine the cause of failure.


Maximum vacuum leakage:

3.3 kPa

(25 mmHg, 0.98 inHg)

Inspecting check valve

1. Remove clip and disconnect hoses at connections. The check valve can now be removed.




2. Using a Brake Booster tester, apply a vacuum pressure of 26.7 kPa (200 mmHg, 7.87 inHg) to the port of check valve on the Brake Booster side. If vacuum pressure drops more than the specified value in 15 seconds, replace check valve with a new one.

Maximum vacuum leakage of check valve:

1.3 kPa

(10 mmHg, 0.39 inHg)

3. When vacuum pressure is applied to the Brake Booster side of check valve and valve does not open, replace check valve with a new one.



- 1 Spring
- 2 Valve

BR953

Air tight test (Under load)

Fifteen seconds after engine is stopped and brake fully applied, observe the rate of drop in air pressure registered by vacuum gauge. If vacuum

pressure drops more than the specified value, refer to the following chart to determine the cause of failure.

Maximum vacuum leakage:

3.3 kPa

(25 mmHg, 0.98 inHg)

Probable cause	Corrective action
1. Air leakage at check valve.	Replace check valve.
2. Damaged diaphragm.	Replace Brake Booster as an assembly.
3. Reaction disc dropped off. (Brake Booster)	
4. Air leakage at poppet assembly seat and valve body.	

4. When installing check valve, be careful to avoid incorrect connections.

Operating test

1. Connect an oil pressure gauge to brake line, at connection on master cylinder.
2. Install a pedal force gauge on brake pedal.


Brake System

3. Start engine, and increase engine speed until a vacuum pressure of 66.7 kPa (500 mmHg, 19.69 inHg) is registered on vacuum pressure gauge. With a steady vacuum pressure of 66.7 kPa (500 mmHg, 19.69 inHg), measure oil pressure with respect to each pedal operating force.

Relationship between oil pressure and pedal operating force is illustrated in following chart. If test results are not as specified in following chart, check Brake Booster for condition in manner described under "Inspection" before removal of this unit.

Also check brake line for evidence of fluid leakage.


Note: Determine whether source of problem is in Brake Booster or check valve. Before you reach a final conclusion, always inspect check valve first.



BR184A

REMOVAL

Remove parts in numerical order enumerated.




BR185A


ADJUSTMENT

1. Adjust the length of push rod to the value indicated below. Length adjustment of push rod is made at the tip of push rod.

Length "A":
9.5 - 10.5 mm
(0.374 - 0.413 in)




BR109A



BR288

2. Install clevis. Adjust length of operating rod to specified value.

Length "B":
143 mm (5.63 in)



BR110A

INSTALLATION

Install in the reverse sequence of removal.

⤴ : Master cylinder to Brake Booster

7.8 - 10.8 N·m
(0.8 - 1.1 kg·m,
5.8 - 8.0 ft·lb)

Brake Booster to body

7.8 - 10.8 N·m
(0.8 - 1.1 kg·m,
5.8 - 8.0 ft·lb)

Note: After Brake Booster is properly installed in car, conduct an air-tight and operational tests as previously described.

BLEEDING HYDRAULIC SYSTEM

Hydraulic brake system must be bled whenever any line has been disconnected or air has in some way entered system.

"Spongy" pedal action is an indication that air has entered brake system.

Bleeding hydraulic system deserves much attention as it is an essential element in regular brake servicing.

1. Clean all dirt around master cylinder reservoir, remove cylinder cover and top up reservoir with recommended brake fluid.

Note: Do not mix two different brand oils.

2. Thoroughly clean mud or dust from bleeder valve so that outlet hole is free from foreign material. Install a bleeder hose on bleeder valve.

Dip other end of hose into brake fluid bled in a container.

3. Depress brake pedal two or three times and then keep pedal fully depressed.

4. With brake pedal fully depressed, open bleeder valve to exhaust air.

Note:

a. Carefully monitor brake fluid level at master cylinder during bleeding operation.

b. Do not re-use brake fluid drained during bleeding operation.

c. Bleed air in the following sequence.

Master cylinder →

Rear wheel → Front wheel

d. Be careful not to splash brake fluid on painted areas.

5. Close bleeder valve quickly as brake pedal is on down stroke.

6. Allow brake pedal to return slowly with bleeder screw closed.

7. Repeat bleeding operations until no air bubbles show in hose.

Note:


a. Brake fluid containing air is white and contains air bubbles.

b. Brake fluid containing no air runs out of bleeder valve in a solid stream free of air bubbles.

8. Repeat steps above on remaining brake line to expel air.

PARKING BRAKE

PARKING BRAKE




- 1 Control lever
- 2 Brake warning switch
- 3 Front cable
- 4 Equalizer
- 5 Rear cable
- 6 Lock plate

← : Lubricate with multi-purpose grease

REMOVAL

Control lever and front cable

1. Remove front assistant's seat.
2. Disconnect terminal from parking brake warning switch.
3. Remove bolts securing parking brake control lever to floor.



BR188A

4. Remove lock plate, adjusting nut and lock nut.
5. Pull front cable out into driver's compartment and remove it together with control assembly.

CAUTION:

Be careful not to deform or damage control lever.

Note: Front cable, clevis pin and cotter pin are available as service parts.

Rear cable

1. Disconnect rear cable at equalizer.
2. Remove cable lock plate from rear suspension and rear disc brake.
3. Remove clevis pin and clevis from rear disc brake.
4. Disconnect rear cable from suspension arm and then remove rear cable.

INSPECTION

1. Check control lever for wear or other damage. Replace if necessary.

2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Replace malfunctioning warning light or switch.
4. Check parts at each connection and, if found deformed or damaged, replace.

INSTALLATION

Install parking brake assembly following the reverse procedure of removal. Closely observing the following items:

1. When installing, apply a coating of grease to sliding contact surfaces.
2. Upon completion of installation of parking brake assembly, adjust the entire system as described in Section MA.
3. Make sure that adjacent parts do not interfere with cable.

Do not apply an undue stress to cable.

SERVICE DATA AND SPECIFICATIONS

GENERAL SPECIFICATIONS

SERVICE BRAKE

Unit: mm (in)

	Front	Rear
Type	Disc-CL28V	Disc-AN14H
Pad dimension Width x thickness x length	49 x 11 x 118 (1.93 x 0.43 x 4.65)	42 x 10.3 x 56.8 (1.65 x 0.406 x 2.236)
Rotor outer diameter	252 (9.92)	269 (10.59)
Caliper inner diameter	60.6 (2.386)	42.8 (1.685)


Master cylinder inner diameter mm (in)	23.81 (15/16)
Brake Booster Type	M90
Diaphragm diameter mm (in)	228.6 (9)
NP-valve Split point kPa (kg/cm ² , psi)	3.923 (40, 569)
Reducing ratio	0.4

INSPECTION AND ADJUSTMENT

BRAKE PEDAL

Unit: mm (in)

	M/T	A/T
Pedal play "a"	1 - 5 (0.04 - 0.20)	
Depressed height "d"	More than 80 (3.15)	More than 90 (3.54)
Pedal height "h"	181 - 187 (7.13 - 7.36)	190 - 196 (7.48 - 7.72)
Full stroke "s"	125 (4.92)	134 (5.28)



PARKING BRAKE


Pulling force	N (kg, lb)	265 (27, 60)
Stroke	mm (in)	86 - 109 (3.39 - 4.29)
Number of notches		4 - 6

MASTER CYLINDER


Allowable clearance between cylinder and piston mm (in)	Less than 0.15 (0.0059)
--	-------------------------

BRAKE BOOSTER

Maximum vacuum leakage (15 seconds after engine is stopped) kPa (mmHg, inHg)	3.3 (25, 0.98)
Push rod length "A" mm (in)	9.5 - 10.5 (0.374 - 0.413)
Operating rod length "B" mm (in)	143 (5.63)



BR109A



BR947

Brake System

CHECK VALVE

Maximum vacuum leakage [15 seconds after 26.7 kPa (200 mmHg, 7.87 inHg) pressure is applied] kPa (mmHg, inHg)	1.3 (10, 0.39)
--	----------------

TIGHTENING TORQUE

Unit		N-m	kg-m	ft-lb
Master cylinder to Brake Booster		7.8 - 10.8	0.8 - 1.1	5.8 - 8.0
Brake tube flare nut		15 - 18	1.5 - 1.8	11 - 13
Brake hose connector		17 - 20	1.7 - 2.0	12 - 14
Air bleeder valve		6.9 - 8.8	0.7 - 0.9	5.1 - 6.5
Connector mounting bolt	6 mm dia. bolt	4.9 - 6.9	0.5 - 0.7	3.6 - 5.1
	8 mm dia. bolt	7.8 - 10.8	0.8 - 1.1	5.8 - 8.0
NP-valve		5.9 - 6.9	0.6 - 0.7	4.3 - 5.1
Fulcrum bolt of brake pedal		34 - 39	3.5 - 4.0	25 - 29
Brake warning lamp switch lock nut		12 - 15	1.2 - 1.5	9 - 11
Caliper fixing bolt	Front	72 - 97	7.3 - 9.9	53 - 72
	Rear	38 - 52	3.9 - 5.3	28 - 38
Rotor fixing bolt		54 - 74	5.5 - 7.5	40 - 54
Front brake baffle plate fixing bolts		3.1 - 4.3	0.32 - 0.44	2.3 - 3.2
Rear brake baffle plate fixing bolts		3.1 - 4.3	0.32 - 0.44	2.3 - 3.2
Brake booster				
Brake booster to body		7.8 - 10.8	0.8 - 1.1	5.8 - 8.0
Operating rod lock nut		16 - 22	1.6 - 2.2	12 - 16
Flange to shell cover		7.8 - 10.8	0.8 - 1.1	5.8 - 8.0
Push rod adjusting nut		16 - 22	1.6 - 2.2	12 - 16

DISC BRAKE

Unit: mm (in)

Item	Front	Rear
	CL2BV	AN14H
Pad wear limit (Minimum thickness)	2 (0.08)	
Rotor repair limit Maximum runout	0.10 (0.0039)	0.15 (0.0059)
Maximum parallelism circumferential direction	0.03 (0.0012)	
Minimum thickness	18.0 (0.709)	8.6 (0.339)

Brake System

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Excessive pedal travel	<p>Low brake fluid level or empty master cylinder reservoir.</p> <p>Leakage in master cylinder.</p> <p>Deteriorated check valve.</p> <p>Air in system.</p> <p>Faulty brake adjustment.</p> <p>Excessive lateral play on disc caused by loose or worn wheel bearings or steering parts.</p>	<p>Fill and bleed as necessary. Test for source of leakage by examining all lines, connections and wheel cylinder.</p> <p>Overhaul master cylinder.</p> <p>Replace check valve and bleed system.</p> <p>Bleed system.</p> <p>Adjust pad-to-rotor clearance. Inspect auto-adjuster operation.</p> <p>Replace or adjust faulty parts.</p>
Spongy pedal	<p>Low fluid level in master cylinder.</p> <p>Air in system.</p> <p>Faulty brake adjustment.</p> <p>Reservoir filler cap vent hole clogged.</p> <p>Swollen hose due to deterioration or use of poor quality hose.</p> <p>Distorted brake shoes, or excessively worn or cracked brake drum.</p> <p>Soft or swollen caliper seals.</p> <p>Use of a brake fluid with too low boiling point.</p>	<p>Top with fluid and inspect for leakage.</p> <p>Correct as necessary.</p> <p>Adjust pad-to-rotor clearance. Inspect auto-adjuster operation.</p> <p>Clean and bleed system.</p> <p>Replace hose and bleed system.</p> <p>Replace faulty parts.</p> <p>Drain hydraulic system, flush with alcohol and replace all seals.</p> <p>Replace with specified brake fluid and bleed system.</p>
Poor braking effect	<p>Fluid leakage in brake lines.</p> <p>Low brake fluid level or empty master cylinder reservoir.</p> <p>Air in brake lines.</p> <p>Grease, oil, mud or water on pads.</p> <p>Deterioration of pads.</p> <p>Local fit of pads.</p> <p>Pads excessively worn.</p> <p>Master cylinder or caliper assembly in poor condition.</p> <p>Frozen or seized caliper pistons on disc brakes.</p> <p>Binding mechanical linkage at brake pedal.</p>	<p>Check master cylinder, pipng and caliper for leaks, and repair.</p> <p>Fill and bleed as necessary.</p> <p>Bleed system.</p> <p>Clean brake mechanism and check for cause of problem. Replace pads.</p> <p>Replace.</p> <p>Shave or replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Disassemble caliper and free up as required.</p> <p>Free up as required.</p>


Brake System

Condition	Probable cause	Corrective action
Unbalanced brakes	<p>Improper tire inflation.</p> <p>Improper auto adjustment of pad-to-rotor clearance.</p> <p>Grease, oil, mud or water on pads.</p> <p>Mud in rotor.</p> <p>Deterioration of pads.</p> <p>Excessive wear of pads.</p> <p>Caliper cylinder in poor condition.</p> <p>Looseness of caliper assembly securing bolts.</p> <p>Scored or out-of-round rotor.</p> <p>Incorrect adjustment of wheel bearings.</p> <p>Incorrect adjustment of wheel alignment.</p>	<p>Inflate to correct pressure.</p> <p>Readjust.</p> <p>Clean brake mechanism and check for cause of problem. Replace pads.</p> <p>Clean.</p> <p>Replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Fasten or replace.</p> <p>Recondition or replace rotor as required. Check for improper pad contact with rotor and grind pad if necessary.</p> <p>Adjust or replace.</p> <p>Adjust.</p>
Brakes fade	<p>Brake fluid has too low boiling point.</p> <p>Use of improper pads.</p> <p>Brake rotor is out-of-round.</p> <p>Hydraulic connections, master cylinder and caliper cylinders are corroded or damaged.</p> <p>Bleed screw is open.</p>	<p>Drain and fill system with approved fluid.</p> <p>Replace.</p> <p>Repair or replace as necessary.</p> <p>Repair as necessary.</p> <p>Close screw and bleed system.</p>
Brakes drag	<p>Pedal linkage is binding or push rod adjustment is too long.</p> <p>Master cylinder compensator port is obstructed.</p> <p>Seized master cylinder piston.</p> <p>Poor pad condition.</p> <p>Poor caliper cylinder condition.</p> <p>Deformation of piston cups.</p> <p>Poor condition of caliper because of faulty piston seals.</p> <p>Excessive runout of rotor.</p> <p>Hand brake will not return.</p> <p>Clogged master cylinder return port.</p> <p>Clogged brake lines.</p> <p>Incorrect adjustment of wheel bearings.</p> <p>Improper pad-to-rotor clearance.</p> <p>No free travel in brake pedal return.</p>	<p>Lubricate linkage, check pedal return spring for condition and adjust push rod as necessary.</p> <p>Blow out foreign matter with compressed air.</p> <p>Disassemble master cylinder and replace piston. Bleed system.</p> <p>Clean and repair.</p> <p>Repair or replace.</p> <p>Replace.</p> <p>Replace piston seals.</p> <p>Turn rotor on lathe or replace.</p> <p>Check and repair.</p> <p>Clean.</p> <p>Check and clean.</p> <p>Adjust or repair.</p> <p>Adjust.</p> <p>Adjust pedal height.</p>

Brake System

Condition	Probable cause	Corrective action
Brake chatters	Groove or out-of round rotor. Loose or bent support plate. Distorted pads. Grease or brake fluid on pads.	Grind or replace as required. Tighten support plate bolts to specified torque, or replace plate. Replace as necessary. Replace pads.
Brake squeals	Dirty or scored rotor. Bent support plate. Glazed or contaminated pads.	Blow out assembly with compressed air or refinish rotor. Replace faulty unit. Grind pad to eliminate glaze. If it doesn't, replace pad.
Pedal pulsates	Lateral runout of brake rotor is excessive. Excessive variation in thickness of brake rotor surfaces.	Check with dial indicator, turning disc by hand. If runout exceeds specifications, replace disc. Measure around disc face with micrometer. Replace disc as required.
Rear lock (under light brake pedal force)	Improper tire pressures. Excessive wear of tires. Faulty NP-valve.	Check and adjust. Check and replace. Replace.
Rear lock (under heavy brake pedal force)	Improper tire pressures. Excessive wear of tires. Poor front braking effect. <ul style="list-style-type: none"> ● Grease oil, mud or water on pads. ● Excessive wear pads. ● Local fit pads. ● Master cylinder or caliper cylinder in poor condition. 	Check and adjust. Check and replace. Clean or replace. Replace. Shave or replace. Repair or replace.

SPECIAL SERVICE TOOL

Tool number & tool name	Kent-Moore No.	Tool number & tool name	Kent-Moore No.
	Reference page		Reference page
GG94310000 Flare nut torque wrench	—		
	Page BR-4 Page BR-5 Page BR-7 Page BR-12		