

# ENGINE FUEL & EMISSION CONTROL SYSTEM



# SECTION EF & EC

EF & EC

## CONTENTS

PRECAUTIONS .....	EF & EC- 3
ENGINE AND EMISSION CONTROL PARTS LOCATION .....	EF & EC- 4
E.C.C.S. DIAGRAM .....	EF & EC- 5
E.C.C.S. CHART .....	EF & EC- 7
FUEL FLOW SYSTEM DESCRIPTION .....	EF & EC- 9
AIR FLOW SYSTEM DESCRIPTION .....	EF & EC- 10
E.C.C.S. CIRCUIT DIAGRAM .....	EF & EC- 11
E.C.C.S. WIRING DIAGRAM .....	EF & EC- 12
E.C.C.S. DESCRIPTION .....	EF & EC- 14
DIAGNOSTIC PROCEDURE .....	EF & EC- 31
SELF-DIAGNOSIS .....	EF & EC- 61
ELECTRONIC CONTROL SYSTEM INSPECTION .....	EF & EC- 82
CRANK ANGLE SENSOR .....	EF & EC- 84
AIR FLOW METER .....	EF & EC- 86
CYLINDER HEAD TEMPERATURE SENSOR .....	EF & EC- 88
VEHICLE SPEED SENSOR .....	EF & EC- 90
IGNITION SIGNAL .....	EF & EC- 92
FUEL PUMP .....	EF & EC- 94
IDLE SWITCH .....	EF & EC- 96
ENGINE CONTROL UNIT .....	EF & EC- 98
E.G.R. FUNCTION .....	EF & EC-100
EXHAUST GAS SENSOR .....	EF & EC-104
DETONATION SENSOR .....	EF & EC-106
EXHAUST GAS TEMPERATURE SENSOR .....	EF & EC-108
FUEL TEMPERATURE SENSOR .....	EF & EC-112
THROTTLE SENSOR .....	EF & EC-114
INJECTOR LEAK .....	EF & EC-116
START SIGNAL .....	EF & EC-118
INJECTOR .....	EF & EC-120
POWER SOURCE & GROUND CIRCUIT FOR E.C.U. ....	EF & EC-122

## Contents (Cont'd)

A.I.V. CONTROL SOLENOID VALVE .....	EF & EC-124
E.G.R. CONTROL SOLENOID VALVE .....	EF & EC-126
IDLE-UP SOLENOID VALVE .....	EF & EC-128
A.A.C. VALVE .....	EF & EC-130
NEUTRAL/INHIBITOR SWITCH .....	EF & EC-132
P.R. CONTROL SOLENOID VALVE .....	EF & EC-134
AIR REGULATOR .....	EF & EC-136
E.C.U. INPUT/OUTPUT SIGNAL INSPECTION .....	EF & EC-138
MIXTURE RATIO FEEDBACK SYSTEM INSPECTION .....	EF & EC-143
FUEL SYSTEM INSPECTION .....	EF & EC-148
TURBOCHARGER INSPECTION .....	EF & EC-151
EVAPORATIVE EMISSION CONTROL SYSTEM .....	EF & EC-153
E.G.R. SYSTEM INSPECTION .....	EF & EC-155
CRANKCASE EMISSION CONTROL SYSTEM .....	EF & EC-156
A.I.V. SYSTEM INSPECTION .....	EF & EC-157
SERVICE DATA AND SPECIFICATIONS (S.D.S.) .....	EF & EC-159

**When you read wiring diagrams:**

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.



**BATTERY**

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

**INJECTOR**

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors.

**E.C.C.S. PARTS HANDLING**

- Handle air flow meter carefully to avoid damage.
- Do not disassemble air flow meter.
- Do not clean air flow meter with any type of detergent.
- Do not disassemble auxiliary air control valve (VG30ET engine).
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the crank angle sensor.

**E.C.U.**

- Do not disassemble E.C.C.S. control unit.
- Do not turn diagnosis mode selector forcibly.
- Do not disassemble the E.C.U. (the E.C.C.S. control unit).
- If a battery terminal is disconnected, the memory will return to the ROM value. The E.C.C.S. will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

**WHEN STARTING**

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

**WIRELESS EQUIPMENT**


- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
  - 1) Keep the antenna as far as possible away from the electronic control units.
  - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
  - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
  - 4) Be sure to ground the radio to vehicle body.

**FUEL PUMP**

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.


**E.C.C.S. PARTS HANDLING**

- Securely connect E.C.C.S. harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep E.C.C.S. harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an E.C.C.S. system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep E.C.C.S. parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.





# ENGINE AND EMISSION CONTROL PARTS LOCATION






# E.C.C.S. DIAGRAM

(VG30ET engine (With turbocharger))

VG30E engine (Without turbocharger)



08R2182


SEF358G



# ENGINE AND E.C.C.S. DIAGRAM PARTS LOCATION

VG30ET engine (With turbocharger)


(With turbocharger) engine 30GV





# FUEL FLOW E.C.C.S. CHART

## VG30E Engine (Without turbocharger)






# E.C.C.S. CHART


## VG30ET Engine (With turbocharger)

## (VG30E Engine (Without turbocharger))




# FUEL FLOW SYSTEM DESCRIPTION

VG30E engine (Without turbocharger)



SEF937F



VG30ET engine (With turbocharger)




SEF284F



# AIR FLOW SYSTEM DESCRIPTION




# E.C.C.S. CIRCUIT DIAGRAM






# E.C.C.S. WIRING DIAGRAM






# E.C.C.S. WIRING DIAGRAM








**Components**

**E.C.U. (E.C.C.S. control unit)**


The E.C.U. consists of a microcomputer, inspection lamps, a diagnostic mode selector, and connectors for signal input and output, and for power supply. The unit has control of the engine.




**CRANK ANGLE SENSOR**

The crank angle sensor is a basic component of the entire E.C.C.S. It monitors engine speed and piston position, and sends to the E.C.U. signals on which the controls of fuel injection, ignition timing and other functions are based.

The crank angle sensor has a rotor plate and a wave forming circuit. The rotor plate has 360 slits for 1° signal (crank angle signal) and 6 slits for 120° signal (engine speed signal). Light Emitting Diodes (L.E.D.) and Photo Diodes are built in the wave forming circuit.




When the rotor plate passes the space between the L.E.D. and the Photo Diode, the slits of the rotor plate continually cut the light which is sent to the photo diode from the L.E.D. This causes generating rough-shaped pulses. They are then converted into on-off pulses by the wave forming circuit, which are sent to the E.C.U.



**AIR FLOW METER**

The air flow meter measures the mass flow rate of intake air. Measurements are made in such a manner that the control circuit emits an electrical output signal in relation to the amount of heat dissipated from the hot wire placed in the stream of intake air.

The air flowing around the hot wire removes the heat from the hot wire. The temperature of the hot wire is very sensitive to the mass flow rate of the air. The higher the temperature of the hot wire, the higher its resistance value. This change in the temperature (or: resistance) is determined by the mass flow rate of the air. The control circuit accurately regulates current (I) in relation to the varying resistance value ( $R_H$ ) so that  $V_A$  always equals  $V_B$ . The air flow meter transmits an output for voltage  $V_A$  to the control unit where the output is converted into an intake air signal.



Also, this air flow meter has self-burning off system in order to make hot wire clean.




## E.C.C.S. DESCRIPTION

### Components (Cont'd)

#### CYLINDER HEAD TEMPERATURE SENSOR

The cylinder head temperature sensor, built into the cylinder head, monitors changes in cylinder head temperature and transmits a signal to the E.C.U.


The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



#### IDLE SWITCH


The idle switch is attached to the throttle chamber and actuates in response to accelerator pedal movement.

This switch has idle contact and full throttle contact. The idle contact is used for engine control. It closes when the throttle valve is positioned at idle, and opens when it is at any other position.



#### FUEL INJECTOR


The fuel injector is a small, precision solenoid valve. As the E.C.U. outputs an injection signal to each fuel injector, the coil built into the injector pulls the needle valve back, and fuel is injected through the nozzle to intake manifold. The amount of fuel injected is controlled by the E.C.U. as an injection pulse duration.



#### FUEL TEMPERATURE SENSOR


The fuel temperature sensor is built into the pressure regulator, and senses fuel temperature. When the fuel temperature is higher than the specified level, the E.C.U. enriches fuel injected.

Do not remove fuel temperature sensor from pressure regulator. Always replace as an assembly.



#### FUEL PUMP

The fuel pump with a fuel damper is an in-tank type, that is the pump and damper are located in the fuel tank. The vane rollers are directly coupled to a motor which is cooled by fuel.






## E.C.C.S. DESCRIPTION

### Components (Cont'd)


#### IDLE-UP SOLENOID VALVE [VG30E]

The idle-up solenoid valve is attached to the intake collector. The solenoid valve actuates to stabilize idle speed when engine load is heavy because of electric load, power steering oil pump, etc.





#### A.A.C. (AUXILIARY AIR CONTROL) VALVE [VG30ET]

The A.A.C. valve is attached to the intake collector. The E.C.U. actuates the A.A.C. valve by an ON/OFF pulse of approximately 160 Hz. The longer that ON duty is left on, the larger the amount of air that will flow through the A.A.C. valve.



#### DETONATION SENSOR [VG30ET]



The detonation sensor is attached to the cylinder block and senses engine knocking conditions. A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output.



#### AIR REGULATOR



The air regulator provides an air by-pass when the engine is cold for the purpose of a fast idle during warm-up.

A bimetal, heater and rotary shutter are built into the air regulator. When the bimetal temperature is low, the air by-pass port is open. As the engine starts and electric current flows through a heater, the bimetal begins to rotate the shutter to close off the by-pass port. The air passage remains closed until the engine is stopped and the bimetal temperature drops.



#### A.I.V. (AIR INDUCTION VALVE)

The air induction valve sends secondary air to the exhaust manifold, utilizing a vacuum caused by exhaust pulsation in the exhaust manifold. When the exhaust pressure is below atmospheric pressure (negative pressure), secondary air is sent to the exhaust manifold. When the exhaust pressure is above atmospheric pressure, the reed valves prevent secondary air from being sent back to the air cleaner.





# E.C.C.S. DESCRIPTION


## (b) Components (Cont'd)

### EXHAUST GAS SENSOR (Titania type) [VG30ET]




The exhaust gas sensor, which is placed in the exhaust tube, monitors the amount of oxygen in the exhaust gas.

This sensor is made of ceramic titania which electric resistance drastically changes at the ideal air-fuel ratio.

The E.C.U. supplies the sensor with approximately 1V and takes an output voltage of the sensor depending on its resistance. In order to activate the sensor element, it is equipped with a heater.



SEF716D




SEF285D


### EXHAUST GAS SENSOR (Zirconia type) [VG30E]

The exhaust gas sensor, which is placed into the exhaust manifold, monitors the amount of oxygen in the exhaust gas.

The sensor has a closed-end tube made of ceramic zirconia. The outer surface of the tube is exposed to exhaust gas, and the inner surface to atmosphere. The zirconia of the tube compares the oxygen density of exhaust gas with that of atmosphere, and generates electricity. In order to improve generating power of the zirconia, its tube is coated with platinum. The voltage is approximately 1V in a richer condition of the mixture ratio than the ideal air-fuel ratio, while approximately 0V in leaner conditions. The radical change from 1V to 0V occurs at around the ideal mixture ratio. In this way, the exhaust gas sensor detects the amount of oxygen in the exhaust gas and sends the signal of approximately 1V or 0V to the E.C.U.




SEF336A



SEF288D

### POWER TRANSISTOR AND IGNITION COIL

The ignition signal from the E.C.U. is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit.



SEF025E



## E.C.C.S. DESCRIPTION


### Components (Cont'd)

#### VEHICLE SPEED SENSOR

The vehicle speed sensor provides a vehicle speed signal to the E.C.U.


- **Needle type speedometer models**

The speed sensor consists of a reed switch, which is installed in the speed meter unit and transforms vehicle speed into a pulse signal.




- **Digital type speedometer models**

The speed sensor consists of an L.E.D., photo diode, shutter and wave forming circuit. Its principle is the same as that of the crank angle sensor.




#### A.I.V. CONTROL SOLENOID VALVE (TYPE B)

The A.I.V. control solenoid valve cuts intake manifold vacuum signal for A.I.V. control. The solenoid valve actuates in response to the ON/OFF signal from the E.C.U. When the solenoid is off, the vacuum signal from the intake manifold is cut. As the control unit outputs an ON signal, the coil pulls the plunger downward, and feeds the vacuum signal to the A.I.V. control valve.




#### E.G.R. CONTROL SOLENOID VALVE (TYPE A)

The E.G.R. system is controlled only by the E.C.U. At both low and high speed revolution of engine, the solenoid valve turns on and accordingly the E.G.R. valve cuts the exhaust gas leading to the intake manifold.



#### P.R. (PRESSURE REGULATOR) CONTROL SOLENOID VALVE (VG30E: TYPE A, VG30ET: TYPE B)

The solenoid valve actuates in response to the ON/OFF signal from the E.C.U. When it is off, a vacuum signal from the intake manifold is fed into the pressure regulator. As the control unit outputs an ON signal, the coil pulls the plunger downward, and cuts the vacuum signal.



#### SAFETY RELAY

Safety relay, which is located behind the right side of hoodledge, prevents any damage to the E.C.U. and injectors when battery terminals are connected in reverse.


# E.C.C.S. DESCRIPTION

## Components (Cont'd)

### EXHAUST GAS TEMPERATURE SENSOR




[California model]

The exhaust gas temperature sensor is located near E.G.R. valve, detects exhaust gas temperature and emits signals to the E.C.U. This part employs a thermistor which is sensitive to changes in temperature. The electric resistance of a thermistor decreases in response to a temperature rise.



SEF072G



### Fuel Injection Control





## E.C.C.S. DESCRIPTION

### Fuel Injection Control (Cont'd)



The E.C.U. calculates the basic injection pulse width by processing signals from crank angle sensor and air flow meter. Receiving signals from each sensor which detects various engine conditions, the E.C.U. adds various enrichments, which are pre-programmed in the control unit, to the basic injection amount. Thus, the optimum amount of fuel is injected through the injectors.

#### 1) Fuel enrichment

In each of the following conditions, fuel is enriched.

- During warm-up
- When starting
- After idle
- With heavy load
- When cylinder head temperature is high.

The enrichment rate for "when accelerating" and "with heavy load" are pre-programmed for engine speed and basic injection pulse width.

#### 2) Mixture ratio feedback control

The mixture ratio feedback system is designed to control the mixture ratio precisely to the stoichiometric point so that the three-way catalyst can minimize CO, HC and NOx emissions simultaneously. This system uses an exhaust gas sensor located in the exhaust manifold to give an indication of whether the air-fuel ratio is richer or leaner than the stoichiometric point. The control unit adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the narrow window around the stoichiometric air fuel ratio.

However, this system will open under the following conditions:


- When starting.
- When engine and exhaust gas sensor is cold.
- When driving at high speeds or under heavy load.
- At idle
- When exhaust gas sensor monitors a too lean condition for more than 10 seconds.
- When fuel shut-off is in operation.
- When exhaust gas sensor is malfunctioning.
- When pressure regulator control system is in operation.

#### SAFETY RELAY


Safety relay, which is interlocked with the battery, prevents any damage to the battery and injectors when battery terminals are connected in reverse.

## Fuel Injection Control (Cont'd)

### • Group injection



### • Simultaneous injection



SEF640B

### 3) Injection timing

Two types of fuel injection systems are used – simultaneous injection and group injection. In the former, fuel is injected into all six cylinders simultaneously twice each engine cycle.


In other words, pulse signals of the same width are simultaneously transmitted from the E.C.U. to the six injectors two times for each engine cycle.

In the group injection system, six injectors are divided into two groups – No. 1, No. 2, No. 3 and No. 4, No. 5, No. 6. And fuel is injected into each group separately once each engine cycle.

When any of the following conditions are met, fuel injection shifts to simultaneous injection from group injection.

- Engine speed is more than 3,000 rpm.
- Cylinder head temperature is below 60°C (140°F).
- When starting.

## Ignition Timing Control



Ignition timing is controlled, corresponding to the engine operating conditions, by the E.C.U.: that is, as the optimum ignition timing in each driving condition has been pre-programmed in the control unit, the ignition timing is determined by electrical signals processed in the unit.

The signal from the E.C.U. is transmitted to power transistor, and controls ignition timing.




# E.C.C.S. DESCRIPTION

## (Cont'd) Ignition Timing Control (Cont'd)


### Detonation feedback operation

The retard system by detonation sensor is designed only for emergencies on VG30ET engines. The basic ignition timing is pre-programmed within the anti-knocking zone, even if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the detonation sensor monitors the knocking condition and the signal is transmitted to the E.C.U. After receiving it, the control unit retards the ignition timing to avoid the knocking condition.



## Idle-up Control (VG30E engine)




The idle speed is compensated by the E.C.U. to prevent rough idle when any of the following conditions are met.

The control unit senses the idle condition, and determines ON/OFF signal. The signal from the control unit is transmitted to the idle-up solenoid valve to stabilize idle speed.

### Operation



Condition	Idle-up solenoid operation
During engine start	ON
20 seconds after engine start	
Battery voltage is below 12V	
Headlamp switch ON	
Cooling fan switch ON	
Power steering oil pressure switch ON	OFF
Except above	

## Idle Speed Control (VG30ET engine)



The idle speed is controlled by the E.C.U., corresponding to the engine operating conditions. The E.C.U. senses the engine condition and determines the best idle speed at each cylinder head

temperature and gear position. The control unit then sends an electronic signal corresponding to the difference between the best idle speed and the actual idle speed to the A.A.C. valve.





Except above OFF Operates

The signal from the E.C.U. is sent to the E.G.R. control solenoid valve which cuts the vacuum line for the E.G.R. control valve when any of the following conditions are met.



# E.C.C.S. DESCRIPTION

## Exhaust Gas Recirculation (E.G.R.) Control



### OPERATION

In the exhaust gas recirculation system, some of the exhaust gas is returned to the combustion chamber to lower the flame temperature during combustion. This results in a reduction of the nitrogen oxide density in the exhaust gas.



When the E.G.R. control valve is open, some of the exhaust gas is led from the exhaust manifold to the E.G.R. tube. The exhaust gas is then regulated by E.G.R. valve, and is introduced into the intake manifold.

The signal from the E.C.U. is sent to the E.G.R. control solenoid valve, which cuts the vacuum line for the E.G.R. control valve when any of the following conditions are met.

Condition	E.G.R. control solenoid	E.G.R. system
Engine starting		
Idle switch "ON"		
Under heavy load driving	ON	Does not operate
Low engine temperature		
High engine temperature		
Engine speed above 2,700 rpm		
Except above	OFF	Operates

# E.C.C.S. DESCRIPTION

## Fuel Pump Control



### 2) Fuel pump relay ON-OFF control (terminal ②0)

Condition	Fuel pump relay operation	Fuel pump operation
Ignition switch is turned to ON	ON for 5 seconds	Operates for 5 seconds
When engine is starting [Engine temp.: above 100°C (212°F)]	ON	Operates
After started [Engine temp.: above 100°C (212°F)]	ON for 30 seconds	Operates
When engine stalls and except as shown above	OFF	Stops

### Description

The fuel pump is controlled by the E.C.U. adjusting the output voltage supplied to the fuel pump.

### Fuel pump ON-OFF control

#### 1) Fuel pump ON-OFF control (terminal ①08)

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops


### Fuel pump voltage control

Conditions	Voltage
5 seconds after ignition switch is turned to ON	0.1 - 0.3 V
Engine cranking	
30 seconds after engine start [above 50°C (122°F)]	
Engine temp. above 90°C (194°F) [Idle switch "OFF"]	
Engine temp. below 10°C (50°F)	
Except above	9 - 14 V



# E.C.C.S. DESCRIPTION

## Air Induction Valve (A.I.V.) Control



The air induction system is designed to send secondary air to the exhaust manifold, utilizing a vacuum caused by exhaust pulsation in the exhaust manifold.

The exhaust pressure in the exhaust manifold usually pulsates in response to the opening and closing of the exhaust valve and it decreases below atmospheric pressure periodically.

If a secondary air intake pipe is opened to the atmosphere under vacuum conditions, secondary air can be drawn into the exhaust manifold in proportion to the vacuum.


The air induction valve is controlled by the E.C.U., corresponding to the engine temperature. When the engine is cold, the A.I.V. control system operates to activate the 3-way catalytic converter quickly. This system also operates during deceleration for the purpose of blowing off water around the air induction valve.

Condition	A.I.V. control solenoid	A.I.V. control system
Low engine temp.	ON	Operates
During deceleration		
Except above*	OFF	Does not operate

\*: Including cylinder head temperature sensor circuit malfunctioning


### OPERATION

**Fuel pump voltage control**  
 To the exhaust manifold, secondary air is drawn in proportion to the vacuum. This results in a rich mixture and the engine cranks. When the E.G.R. control valve is closed, the exhaust gas is drawn into the exhaust manifold. The signal from the E.C.U. to the A.I.V. control valve, which cuts the air for the E.G.R. control valve when any of the following conditions are met:



Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates 30 seconds after engine start (above 80°C (172°F))
When engine is stopped	Stops in 1 second
Except as shown above	Stops engine


## Pressure Regulator Control



This system improves the startability in hot condition by cutting off the intake manifold vacuum and increasing the fuel pressure.

For VG30ET engine, the fuel line is imparted with high pressure which has been stored in the surge tank while the engine was running with turbocharger.

### Operation




Condition	Operation
ON	<ul style="list-style-type: none"> <li>• Engine speed is less than 2,800 rpm.</li> <li>• Except under heavy load</li> </ul>
OFF	Except as shown above



# E.C.C.S. DESCRIPTION

## Air Regulator Control



### Description


The air regulator is controlled by the E.C.U. at the same time as fuel pump ON-OFF control.

### Operation (Air regulator-ON-OFF control)

Condition	Air regulator operation
Ignition switch is turned to ON	Operates for 5 seconds
While engine is running and cranking	Operates
When engine is stopped	OFF in 1 second
Except as shown above	OFF



## Exhaust Gas Sensor Heater Control [VG30E]






The E.C.U. controls the heater operation in the following way.

### Operation

Condition	Exhaust gas sensor heater
<ul style="list-style-type: none"> <li>Engine speed is less than 2,800 rpm.</li> <li>Except under heavy load</li> </ul>	ON
Except as shown above	OFF

## Air Flow Meter Self-cleaning Control




### Description

After the engine is stopped, the E.C.U. heats up the hot wire to approximately 1,000°C (1,832°F) to burn out dust which adhered to the hot wire.

### Operation

Condition	Self-cleaning system
<ul style="list-style-type: none"> <li>Engine speed has not exceeded 1,500 rpm before key off.</li> <li>Vehicle speed has not exceeded 20 km/h (12 MPH) before key off.</li> <li>Cylinder head temperature is higher than 115°C (239°F) when key off.</li> <li>Engine stall with key in ON position.</li> </ul>	Does not operate
Except as shown above	Operates





# E.C.C.S. DESCRIPTION

## Fail-safe System

### AIR FLOW METER

#### Description

When the output voltage of air flow meter is lower than the preprogrammed value, the E.C.U. judges it as a malfunctioning of air flow meter. The E.C.U. fixes the systems in the following condition.

#### Operation

System	Fixed condition
E.G.R. control system	OFF
Idle speed control system	A duty ratio is fixed at the preprogrammed value.
Fuel injection control system	Fuel is shut off above 2,000 rpm. (Engine speed does not exceed 2,000 rpm.)

### CYLINDER HEAD TEMPERATURE SENSOR

#### Description

When the output signal of cylinder head temperature sensor is abnormal the E.C.U. judges it as a malfunctioning of cylinder head temperature sensor.

The E.C.U. decides the cylinder head temperature according to the time from ignition switch ON.

#### Operation

Condition	Cylinder head temperature decided
While engine is running and just as ignition switch is turned ON or Start	20°C (68°F)
More than 6 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)

After the engine is stopped, the E.C.U. heats up the hot wire to approximately 1,000°C (1,832°F) to burn out dust which adhered to the hot wire.

#### Operation

Condition	Exhaust Gas Sensor Heater Control [VG30E]
Engine speed has not exceeded 2,000 rpm before key off.	ON
Vehicle speed has not exceeded 30 km/h (12 MPH) before key off.	ON
Cylinder head temperature is higher than 115°C (239°F) when key off.	ON
Engine still with key in ON position.	ON
Except as shown above	OFF



Condition	Exhaust Gas Sensor Heater
Engine speed is less than 2,000 rpm.	ON
Except under heavy load	ON
Except as shown above	OFF

## Introduction




The engine has an electronic control unit to control major systems such as fuel control, ignition control, idle speed control, etc. The control unit accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problems. A road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.



## Work Flow





# DIAGNOSTIC PROCEDURE

## Diagnostic Worksheet

KEY POINTS	
WHAT	Vehicle & engine model
WHEN	Date, Frequencies
WHERE	Road conditions
HOW	Operating conditions, Weather conditions, Symptoms

There are many kinds of operating conditions that lead to malfunctions on engine components.

A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, feelings for a problem depend on each customer. It is important to fully understand the symptoms or under what conditions a customer complains.

Make good use of a diagnostic worksheet such as the one shown below in order to utilize all the complaints for troubleshooting.

### WORKSHEET SAMPLE

Customer name		MR/MS	Model & Year	VIN
Engine #			Trans.	Mileage
Incident Date			Manuf. Date	In Service Date
Symptoms	<input type="checkbox"/> Startability		<input type="checkbox"/> Impossible to start <input type="checkbox"/> No combustion <input type="checkbox"/> Partial combustion <input type="checkbox"/> Partial combustion affected by throttle position <input type="checkbox"/> Partial combustion NOT affected by throttle position <input type="checkbox"/> Possible but hard to start <input type="checkbox"/> Others [    ]	
	<input type="checkbox"/> Idling		<input type="checkbox"/> No fast idle <input type="checkbox"/> Unstable <input type="checkbox"/> High idle <input type="checkbox"/> Low idle <input type="checkbox"/> Others [    ]	
	<input type="checkbox"/> Driveability		<input type="checkbox"/> Stumble <input type="checkbox"/> Surge <input type="checkbox"/> Detonation <input type="checkbox"/> Lack of power <input type="checkbox"/> Intake backfire <input type="checkbox"/> Exhaust backfire <input type="checkbox"/> Others [    ]	
	<input type="checkbox"/> Engine stall		<input type="checkbox"/> At the time of start <input type="checkbox"/> While idling <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating <input type="checkbox"/> Just after stopping <input type="checkbox"/> While loading	
Incident occurrence		<input type="checkbox"/> Just after delivery <input type="checkbox"/> Recently <input type="checkbox"/> In the morning <input type="checkbox"/> At night <input type="checkbox"/> In the daytime		
Frequency		<input type="checkbox"/> All the time <input type="checkbox"/> Under certain conditions <input type="checkbox"/> Sometimes		
Weather conditions		<input type="checkbox"/> Not effected		
Weather		<input type="checkbox"/> Fine <input type="checkbox"/> Raining <input type="checkbox"/> Snowing <input type="checkbox"/> Others [    ]		
Temperature		<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Humid    °F		
Engine conditions		<input type="checkbox"/> Cold <input type="checkbox"/> During warm-up <input type="checkbox"/> After warm-up		
		Engine speed <span style="display: inline-block; width: 100%; border-bottom: 1px solid black; position: relative; margin-left: 50px;"> <span style="position: absolute; left: 0; top: -10px;">0</span> <span style="position: absolute; left: 20%; top: -10px;">2,000</span> <span style="position: absolute; left: 40%; top: -10px;">4,000</span> <span style="position: absolute; left: 60%; top: -10px;">6,000</span> <span style="position: absolute; left: 80%; top: -10px;">8,000 rpm</span> </span>		
Road conditions		<input type="checkbox"/> In town <input type="checkbox"/> In suburbs <input type="checkbox"/> Highway <input type="checkbox"/> Off road (up/down)		
Driving conditions		<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
		Vehicle speed <span style="display: inline-block; width: 100%; border-bottom: 1px solid black; position: relative; margin-left: 50px;"> <span style="position: absolute; left: 0; top: -10px;">0</span> <span style="position: absolute; left: 10%; top: -10px;">10</span> <span style="position: absolute; left: 20%; top: -10px;">20</span> <span style="position: absolute; left: 30%; top: -10px;">30</span> <span style="position: absolute; left: 40%; top: -10px;">40</span> <span style="position: absolute; left: 50%; top: -10px;">50</span> <span style="position: absolute; left: 60%; top: -10px;">60 MPH</span> </span>		
Check engine light		<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on		

CHECK-OUT

# DIAGNOSTIC PROCEDURE



## Intermittent Problem Simulation

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under Service procedure and note the result.


	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Distributor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feedback control	Exhaust gas sensor	Suspended	Disconnect exhaust gas sensor harness connector.
		Control unit	Operation check	Perform self-diagnosis (Mode I/II) at 2,000 rpm.
4	Idle speed	I.A.A. unit	Raised	Turn idle adjust screw counterclockwise.
			Lowered	Turn idle adjust screw clockwise.
5	Electric connection (Electric continuity)	Harness connectors and wires	Poor electric connection or faulty wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
			Cooled	Cool with an icing spray or similar device.
6	Temperature	Control unit	Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
			Damp	Wet [WARNING: Do not directly pour water on components. Use a mist sprayer.]
7	Moisture	Electric parts	Loaded	Turn on head lights, air conditioner, rear defogger, etc.
8	Electric loads	Load switches	ON-OFF switching	Perform self-diagnosis (Mode IV).
9	Idle switch condition	Control unit	Spark power check	Try to flash timing light for each cylinder.
10	Ignition spark	Timing light		

In the following pages, the numbers such as ①, ② in the above chart correspond to those in the service procedure described below.

Possible causes can be checked through the service procedure shown by the mark "O".



# DIAGNOSTIC PROCEDURE



## Specifications

- 1) Idle speed
  - VG30E (M/T & A/T in "D" position):
    - 700±50 rpm at sea level
    - 650±50 rpm at high altitudes
  - VG30ET:
    - M/T; 700±50 rpm
    - A/T; 650±50 rpm (in "D" position)
- 2) Ignition timing
  - VG30E:
    - M/T; 15°±2° B.T.D.C.
    - A/T; 20°±2° B.T.D.C.
  - VG30ET:
    - M/T; 10°±2° B.T.D.C.
    - A/T; 15°±2° B.T.D.C.

- 3) Idle CO
  - 0.2 - 8.0% (in tail pipe)
    - Throttle valve switch harness connector disconnected (No A.I.V. controlled condition)
    - Cylinder head temperature sensor harness connector disconnected and then 2.5 kΩ resistor connected.
    - Exhaust gas sensor harness connector disconnected.
  - Flashes of E.C.U. red inspection lamp in mode II (If flashes, O.K.)
- 4) Mixture ratio at approximately 2,000 rpm of engine speed.
  - Number of flashes of E.C.U. inspection green lamp in mode I:
    - 5 times or more/10 seconds
- 5) Engine speed of idle switch OFF → ON
  - M/T: Idle speed + 250±150 rpm
  - A/T: Engine speed (In "N" position) + 250±150 rpm

Driving condition	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating	<input type="checkbox"/> While idling <input type="checkbox"/> While cranking <input type="checkbox"/> While turning (RH/LH)
Vehicle speed	<input type="checkbox"/> 0 <input type="checkbox"/> 20 <input type="checkbox"/> 40 <input type="checkbox"/> 60 <input type="checkbox"/> 80	<input type="checkbox"/> 0 <input type="checkbox"/> 20 <input type="checkbox"/> 40 <input type="checkbox"/> 60 <input type="checkbox"/> 80
Check engine light	<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on	<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on

# DIAGNOSTIC PROCEDURE

(b'tnoC) Diagnosis Table (Cont'd)

## Diagnostic Table

To assist with your troubleshooting, some typical diagnostic procedures for the following symptoms are described.

SYMPTOM & CONDITION	POSSIBLE CAUSES	SPECIFICATIONS
1. Impossible to start	— no combustion	EF & EC-36
2. Impossible to start	— partial combustion	EF & EC-37
3. Impossible to start	— partial combustion (not affected by throttle position)	EF & EC-38
4. Impossible to start	— partial combustion (throttle position changes combustion quality)	EF & EC-39
5. Hard to start	— before warm-up	EF & EC-40
6. Hard to start	— after warm-up	EF & EC-41
7. Hard to start	— every time	EF & EC-42
8. Hard to start	— morning after a rainy day	EF & EC-43
9. Abnormal idling	— no fast idle	EF & EC-44
10. Abnormal idling	— low idle (after warm-up)	EF & EC-45
11. Abnormal idling	— high idle (after warm-up)	EF & EC-46
12. Unstable idling	— before warm-up	EF & EC-47
13. Unstable idling	— after warm-up	EF & EC-48
14. Poor driveability	— stumble (while accelerating)	EF & EC-49
15. Poor driveability	— surge (while cruising)	EF & EC-50
16. Poor driveability	— lack of power	EF & EC-51
17. Poor driveability	— detonation	EF & EC-52
18. Engine stall	— during start-up	EF & EC-53
19. Engine stall	— while idling	EF & EC-54
20. Engine stall	— while accelerating	EF & EC-55
21. Engine stall	— while cruising	EF & EC-56
22. Engine stall	— while decelerating/just after stopping	EF & EC-57
23. Engine stall	— while loading (power steering, air conditioner, headlamps, etc.)	EF & EC-58
24. Backfire	— through the intake	EF & EC-59
25. Backfire	— through the exhaust	EF & EC-60

### REMARKS

In the following pages, the numbers such as ①, ② in the above chart correspond to those in the service procedure described below.  
Possible causes can be checked through the service procedure shown by the mark "○".



# DIAGNOSTIC PROCEDURE


## Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 1** Impossible to start – no combustion

POSSIBLE CAUSES		1	2	3	4	5	6	7	8
SPECIFICATIONS	Mixture ratio (too lean)	○	○						
	Ignition sparks (weak, missing)				○	○	○		
	Ignition timing							○	
FUEL SYSTEM	Fuel pump (no operation)	○	○						
	Fuel pump relay (open circuited)	○	○						
	Injectors (no operation, clogged)		○						
IGNITION SYSTEM	Ignition switch	○	○	○	○	○	○	○	○
	Main relay	○	○	○	○	○	○	○	○
	Power transistor		○	○	○	○	○	○	○
	Ignition coil				○	○	○	○	○
	Center cable (ignition leaks)				○	○	○	○	○
	Ignition wires (ignition leaks)				○	○	○	○	○
	Spark plugs						○	○	○
CONTROL SYSTEM	Crank angle sensor	○	○	○	○	○	○	○	○

### SERVICE PROCEDURE

**1 LISTEN**




Fuel pump  
SEF279G

Listen for fuel pump operating sound.

N.G. → Check fuel pump and/or related circuits. [See page EF & EC-94.]

**2 LISTEN**




Injector  
SEF280G

Listen for injector operating sound.

N.G. → Check injector circuit. [See page EF & EC-120.]

**3 CHECK**




Tachometer  
Ignition switch  
SEF281G

Make sure tachometer needle moves when cranking.

N.G. →

**4 CHECK**




Timing light  
Distributor  
SEF283G

Check flashes of timing light for weakness.

N.G. →

**5 MEASURE**




Ignition wire  
SEF315G

Measure resistance of suspect wires.

N.G. → Replace the wire.

O.K. →


**6 CHECK**



Ignition wire  
Spark plug  
SEF282G

Remove spark plugs and check their ignition sparks.

**7 CHECK**




Timing light  
SEF284G

Check ignition-timing.

N.G. → Adjust ignition timing. [See page EF & EC-34.]

**8 PERFORM**



Self-diagnosis Mode III  
SEF285G

Perform self-diagnosis Mode III (for crank angle sensor).

N.G. → Check crank angle sensor and/or related circuits. [See page EF & EC-84.]


# DIAGNOSTIC PROCEDURE

## (b) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION** 2 Impossible to start – partial combustion

POSSIBLE CAUSES		1	2	3	4	5
INTAKE SYSTEM	Mixture ratio	○	○	○		
	Fuel pressure (too low)				○	
	Ignition timing					○
FUEL SYSTEM	Fuel pump	○	○	○		
	Fuel pump relay (open circuited)	○				
CONTROL SYSTEM	Injectors (clogged)		○			

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 3** Impossible to start – partial combustion (not affected by throttle position)

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9	10	11	12
SPECIFICATIONS	Mixture ratio		○	○	○								
	Fuel pressure (too low)			○	○	○							
	Ignition timing						○						
FUEL SYSTEM	Fuel filter (clogged)					○							
	Fuel line (clogged)					○							
	Injectors (clogged)	○											
	Pressure regulator			○									
	Pressure regulator vacuum hose (clogged)			○									
IGNITION SYSTEM	Ignition wires (ignition leaks)							○	○				
	Spark plugs (wet with fuel)									○			
	Ignition switch	○						○		○			
INTAKE SYSTEM	Throttle chamber (with ports clogged)		○										
	Throttle valve (clogged)		○										
CONTROL SYSTEM	Cylinder head temperature sensor										○	○	
	Crank angle sensor	○						○				○	

### SERVICE PROCEDURE



# DIAGNOSTIC PROCEDURE


## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION** 4

Impossible to start — partial combustion (throttle position changes combustion quality)

SPECIFICATIONS	POSSIBLE CAUSES	1	2	3	4
<b>INTAKE SYSTEM</b> FUEL SYSTEM	Throttle chamber (with ports clogged)	○			
	Throttle valve (clogged)		○		
	Air regulator (stuck closed)			○	
	Idle speed control valve				○
<b>CONTROL SYSTEM</b>	Cylinder head temperature sensor				○
	Idle switch				○
	Neutral switch				○
<b>IGNITION SYSTEM</b>	Ignition switch (no start signal)				
<b>CONTROL SYSTEM</b>	Cylinder head temperature sensor				
<b>OTHERS</b>	Air flow sensor				
	Starter (idle speed too slow)				
	Battery (voltage too low)				

### SERVICE PROCEDURE





# DIAGNOSTIC PROCEDURE


## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION** 5 **Hard to start – before warm-up**

POSSIBLE CAUSES		1	2	3	4	5	6
<b>SPECIFICATIONS</b>	Mixture ratio			○			○
<b>IGNITION SYSTEM</b>	Ignition switch (no start signal)	○			○		
<b>INTAKE SYSTEM</b>	Air regulator			○			
<b>CONTROL SYSTEM</b>	Cylinder head temperature sensor					○	○
	Idle switch				○		
	Neutral switch	○					
<b>OTHERS</b>	Starter (operation too slow)	○					
	Battery (voltage too low)	○	○				

### SERVICE PROCEDURE

#### SERVICE PROCEDURE



# DIAGNOSTIC PROCEDURE


## Diagnostic Table (Cont'd)

SYMPTOM & CONDITION 6

Hard to start — after warm-up

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9
SPECIFICATIONS	Mixture ratio			○			○	○		
	Fuel pressure			○			○	○	○	
FUEL SYSTEM	Fuel line (hot fuel)			○						
	Pressure regulator (low fuel pressure)						○			
	Pressure regulator vacuum hose (clogged)									
	Pressure regulator control solenoid								○	○
	Pressure regulator control solenoid vacuum hose							○		
	Surge tank (cracks)								○	
	Fuel temperature sensor (open circuited)					○				
IGNITION SYSTEM	Ignition switch (no start signal)	○				○				
CONTROL SYSTEM	Cylinder head temperature sensor				○					
	Air flow meter				○					
OTHERS	Starter (operation too slow)	○								
	Battery (voltage too low)	○	○							

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 7 Hard to start — every time**

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9	10	11	12
SPECIFICATIONS	Mixture ratio												
	Fuel pressure												
	Ignition sparks (missing)												
IGNITION SYSTEM	Ignition timing												
	Ignition timing												
FUEL SYSTEM	Fuel pump (improper operation)												
	Fuel line (clogged)												
	Canister (air leaks)												
OTHERS	Pressure regulator (low fuel pressure)												
	Pressure regulator (low fuel pressure)												
IGNITION SYSTEM	Ignition wires (ignition leaks)												
	Spark plugs (improper gap)												
CONTROL SYSTEM	Crank angle sensor												
	Cylinder head temperature sensor												
	Idle switch												
	Neutral switch												
OTHERS	Starter (operation too slow)												
	Battery (voltage too low)												
	Battery (voltage too low)												

## SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## (b) Diagnostic Table (Cont'd)

SYMPTOM & CONDITION 8 Hard to start — morning after a rainy day

POSSIBLE CAUSES		1	2	3	4	5
SPECIFICATIONS	Ignition sparks (weak)	○	○			○
IGNITION SYSTEM	Power transistor	○				○
INTAKE SYSTEM	Ignition coil	○		○		
	Center cable (ignition leaks)	○			○	
CONTROL SYSTEM	Ignition wires (ignition leaks)	○	○			○
	Distributor cap (ignition leaks)	○		○		○
	Spark plugs (improper gap)				○	○

### SERVICE PROCEDURE





# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

SYMPTOM & CONDITION


9 Abnormal idling -- no fast idle

SYMPTOM & CONDITION

SPECIFICATIONS	POSSIBLE CAUSES	TESTS					
		1	2	3	4	5	6
SPECIFICATIONS	Mixture ratio	○	○		○		
	Ignition timing			○			
INTAKE SYSTEM	Blow-by hose (clogged)		○				
FUEL SYSTEM	Air regulator (stuck closed)	○					
CONTROL SYSTEM	Cylinder head temperature sensor					○	○

### SERVICE PROCEDURE

### SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## (b) Diagnostic Table (Cont'd)

### SYMPTOM & CONDITION 10 Abnormal idling – low idle (after warm-up)

POSSIBLE CAUSES		1	2	3	4	5	6	7
SPECIFICATIONS	Mixture ratio		○			○		
	Ignition timing (too retarded)	○						
INTAKE SYSTEM	Throttle chamber (with ports clogged)			○				
	Throttle valve (clogged)				○			
CONTROL SYSTEM	Crank angle sensor						○	
	Air flow meter						○	
	Cylinder head temperature sensor						○	○
	Load switches (remaining OFF)							○
OTHERS								

### SERVICE PROCEDURE





# DIAGNOSTIC PROCEDURE


## (b'nd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 11 Abnormal idling – high idle (after warm-up)**

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9	10	11
SPECIFICATIONS	Mixture ratio		○	○		○	○			○		
	Ignition timing (too advanced)	○										
INTAKE SYSTEM	Air duct (leaks)		○									
	Throttle chamber (air leaks)				○							
	Throttle valve (stuck control wire)				○							
CONTROL SYSTEM	Intake manifold (gasket) (air leaks)		○									
	Air regulator (stuck open)			○								
	Idle speed control valve (remaining ON)							○				
	F.I.C.D. solenoid (remaining ON)								○			
CONTROL SYSTEM	Crank angle sensor										○	
	Air flow meter										○	
	Cylinder head temperature sensor										○	○
	Idle switch (remaining OFF)								○	○		
	Load switches (remaining ON)								○	○		
	Battery (voltage too low)											

### SERVICE PROCEDURE

### SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 12 Unstable idling — before warm-up**

POSSIBLE CAUSES		1	2	3	4	5	6	7	8
SPECIFICATIONS	Mixture ratio		○	○					
	Ignition timing	○							
INTAKE SYSTEM	Air regulator (not open enough)		○						
	Idle speed control valve (remaining OFF)				○				
CONTROL SYSTEM	Cylinder head temperature sensor							○	○
E.G.R. SYSTEM	E.G.R. control valve (stuck open)					○			
	E.G.R. solenoid (remaining OFF)					○	○		

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 13 Unstable idling — after warm-up**

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9	10	11	12
SPECIFICATIONS	Mixture ratio	○	○	○	○								
	Ignition sparks					○	○	○					
INTAKE SYSTEM	Ignition timing								○				
	Compression pressure									○			
FUEL SYSTEM	Fuel line (clogged)												
	Canister (air leaks)			○									
	Pressure regulator control solenoid				○								
IGNITION SYSTEM	Power transistor					○		○					
	Ignition coil					○		○					
	Ignition wires					○	○	○					
INTAKE SYSTEM	Blow-by hose (leaks)	○											
	Air duct (leaks)		○										
CONTROL SYSTEM	Idle switch											○	
	Load switches												
E.G.R. SYSTEM	E.G.R. control valve										○		
	E.G.R. solenoid										○	○	

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

### SYMPTOM & CONDITION 14 Poor driveability – stumble (while accelerating)

POSSIBLE CAUSES		POSSIBLE CAUSES								
		1	2	3	4	5	6	7	8	9
SPECIFICATIONS	Mixture ratio				○		○	○		○
	Fuel pressure						○	○		
FUEL SYSTEM	Fuel filter (clogged)							○		
	Fuel line (clogged)							○		
	Injectors (clogged)							○		
IGNITION SYSTEM	Power transistor	○		○						
	Ignition coil	○		○						
	Ignition wires (ignition leaks)	○	○	○						
	Spark plugs (ignition leaks, improper gap)			○						
INTAKE SYSTEM	Air duct (leaks)				○					
CONTROL SYSTEM	Crank angle sensor	○							○	
	Air flow meter								○	
	Cylinder head temperature sensor	○							○	
	Exhaust gas sensor								○	○
OTHERS	Idle switch (remaining OFF)							○		
	Fuel (poor quality)							○		

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 15** Poor driveability — surge (while cruising)

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9
SPECIFICATIONS	Mixture ratio (too lean)									
	Fuel pressure (low)									
	Ignition timing									
IGNITION SYSTEM	(missing)									
INTAKE SYSTEM	Air duct (leaks)									
	Throttle chamber (air leaks)									
	Intake manifold (gasket) (air leaks)									
CONTROL SYSTEM	Crank angle sensor									
	Air flow meter									
	Exhaust gas sensor									
E.G.R. SYSTEM	E.G.R. control valve (stuck open)									
	E.G.R. solenoid (remaining OFF)									
	E.G.R. vacuum hose (removed)									

## SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## (b) Diagnostic Table (Cont'd)

### SYMPTOM & CONDITION 16 Poor driveability — lack of power

POSSIBLE CAUSES		1	2	3	4	5	6	7	8	9	10	11
SPECIFICATIONS	Fuel pressure											
	Ignition timing		○									
	Compression pressure (too low)											
FUEL SYSTEM	Fuel pump (low fuel output)									○		
	Fuel filter (clogged)									○		
	Fuel line (clogged)									○		
	Injectors (clogged)									○		
IGNITION SYSTEM	Ignition wires (ignition leaks)				○	○	○					
	Spark plugs (improper gap)							○				
INTAKE SYSTEM	Air cleaner element (clogged)	○										
	Throttle chamber (clogged)			○								
	Throttle valve (not open enough)			○								
CONTROL SYSTEM	Air flow meter										○	
	Exhaust gas sensor											○

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

### SYMPTOM & CONDITION 17 Poor driveability — detonation

	POSSIBLE CAUSES	1	2	3	4	5	6
SPECIFICATIONS	Mixture ratio (too lean)						
	Fuel pressure (low)						
	Ignition timing (too advanced)						
FUEL SYSTEM	Fuel filter (clogged)						
	Fuel line (clogged)						
	Injectors (clogged)						
INTAKE SYSTEM	Turbocharger (too high pressure)						
CONTROL SYSTEM	Crank angle sensor (improper 1°-signals)						
	Air flow meter						
	Cylinder head temperature sensor						
OTHERS	Water temperature (too high)						
	Fuel (low octane rating, poor quality)						

### SERVICE PROCEDURE



# DIAGNOSTIC PROCEDURE


## (b) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 18 Engine stall — during start-up**

	POSSIBLE CAUSES									
		1	2	3	4	5	6	7	8	9
<b>SPECIFICATIONS</b>	Mixture ratio (too rich/too lean)									
	Ignition sparks (weak)									
	Ignition timing									
<b>CONTROL SYSTEM</b>	Compression pressure (too low)									
<b>FUEL SYSTEM</b>	Canister (too much evaporation to intake)									
<b>IGNITION SYSTEM</b>	Ignition wires (ignition leaks)									
	Spark plugs (wet with fuel, improper gap)									
<b>INTAKE SYSTEM</b>	Throttle valve (not open enough)									

INDEPENDENT HONDA SERVICE INC.  
3519 E. Boulder  
Colorado Springs, Colorado 80909

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 19 Engine stall — while idling**

	POSSIBLE CAUSES	①	②	③	④	⑤	⑥	⑦	⑧	⑨
SPECIFICATIONS	Mixture ratio (too rich/too lean)	○	○							
	Fuel pressure (low)	○	○							
	Ignition sparks (weak, missing)			○	○					
FUEL SYSTEM	Idle speed (low)			○						
FUEL SYSTEM	Fuel line (clogged)		○							
IGNITION SYSTEM	Spark plugs (wet with fuel, improper gap)				○	○				
INTAKE SYSTEM	Idle speed control valve (improper operation)			○				○		
INTAKE SYSTEM	F.I.C.D. solenoid (improper operation)				○					
CONTROL SYSTEM	Idle switch (remaining OFF)									○
CONTROL SYSTEM	Neutral switch (remaining OFF)			○						
OTHERS	Load switches (remaining OFF)	○						○	○	

### SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

SYMPTOM & CONDITION 20 Engine stall — while accelerating

SPECIFICATIONS	POSSIBLE CAUSES							
		1	2	3	4	5	6	7
SPECIFICATIONS	Mixture ratio						○	○
	Ignition sparks (weak, missing)	○	○	○				
	Compression pressure (low)				○			
CONTROL SYSTEM	Crank angle sensor	○						○
INTAKE SYSTEM	Air flow meter (malfunctioning feedback control)					○		○
CONTROL SYSTEM	Exhaust gas sensor (malfunctioning feedback control)						○	○
	Crank angle sensor							
	Air flow meter							
	Exhaust gas sensor							

## SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 21 Engine stall — while cruising**

SPECIFICATIONS		POSSIBLE CAUSES						SPECIFICATIONS
		1	2	3	4	5	6	
Mixture ratio								Mixture ratio
Ignition sparks (weak, missing)								Ignition sparks (weak, missing)
CONTROL SYSTEM		Crank angle sensor						Crank angle sensor
		Air flow meter						Air flow meter
FUEL SYSTEM		Fuel (injection)						Fuel (injection)
IGNITION SYSTEM		Spark plug						Spark plug
INTAKE SYSTEM		Idle speed control valve (improper operation)						Idle speed control valve (improper operation)
		F.I.C.D. solenoid (improper operation)						F.I.C.D. solenoid (improper operation)
CONTROL SYSTEM		Idle switch (remaining OFF)						Idle switch (remaining OFF)
		Neutral switch (remaining OFF)						Neutral switch (remaining OFF)
		Load switches (remaining OFF)						Load switches (remaining OFF)

### SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)

### SYMPTOM & CONDITION 22 Engine stall -- while decelerating/just after stopping

POSSIBLE CAUSES		1	2	3	4	5	6
SPECIFICATIONS	Mixture ratio					○	○
	Ignition sparks (missing)	○					
FUEL SYSTEM	Idle speed (too low)			○			
IGNITION SYSTEM	(missing)	○	○				
INTAKE SYSTEM	Idle speed control valve (remaining OFF)			○	○		
CONTROL SYSTEM	Exhaust gas sensor (malfunctioning feedback control)					○	○
	Crank angle sensor		○				
	Idle switch (remaining OFF)			○			
	Load switches (remaining OFF)			○	○		

### SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

**SYMPTOM & CONDITION 23 Engine stall — while loading**

POSSIBLE CAUSES		1	2	3	4	5
SPECIFICATIONS	Ignition timing		○			
	Idle speed (too low)	○	○	○	○	○
INTAKE SYSTEM	Idle speed control valve (remaining OFF)	○		○		
	F.I.C.D. solenoid (remaining OFF)	○			○	
CONTROL SYSTEM	Idle switch (remaining OFF)	○				○
	Load switches (remaining OFF)	○		○	○	○

### SERVICE PROCEDURE




# DIAGNOSTIC PROCEDURE

## (Cont'd) Diagnostic Table (Cont'd)

SYMPTOM & CONDITION 24 Backfire – through the intake

	POSSIBLE CAUSES	1	2	3	4	5	6	7
SPECIFICATIONS	Mixture ratio (too lean)	○		○		○	○	
	Ignition timing (too retarded)		○					
FUEL SYSTEM	Injectors (clogged)				○			
INTAKE SYSTEM	Air duct (air leaks)	○						
	Intake manifold (gaskets) (air leaks)	○						
CONTROL SYSTEM	Air flow meter							○
	Exhaust gas sensor						○	○

## SERVICE PROCEDURE






# DIAGNOSTIC PROCEDURE

## Diagnostic Table (Cont'd)


**SYMPTOM & CONDITION 25** Backfire – through the exhaust

POSSIBLE CAUSES		1	2	3	4	5	6
<b>SPECIFICATIONS</b>	Mixture ratio (too rich)	○	○				
<b>FUEL SYSTEM</b>	Injectors (fuel leaks)		○				
<b>IGNITION SYSTEM</b>	(missing)			○			
<b>INTAKE SYSTEM</b>	Air cleaner element (clogged)	○					
	A.I.V. (always operating)					○	
	A.I.V. solenoid (remaining ON)					○	
<b>CONTROL SYSTEM</b>	Idle switch (remaining OFF)						○

### SERVICE PROCEDURE



# SELF-DIAGNOSIS



## Description

The self-diagnosis is useful to diagnose malfunctions in major sensors and actuators of the E.C.C.S. system. There are 5 modes in the self-diagnosis system.

### 1. Mode I – Mixture ratio feedback control monitor A

- During closed loop condition:

The green inspection lamp turns ON when lean condition is detected and goes OFF by rich condition.

- During open loop condition:

The green inspection lamp remains ON or OFF.

### 2. Mode II – Mixture ratio feedback control monitor B

The green inspection lamp function is the same as Mode I.

- During closed loop condition:

The red inspection lamp turns ON and OFF simultaneously with the green inspection lamp when the mixture ratio is controlled within the specified value.

- During open loop condition:

The red inspection lamp remains ON or OFF.

### 3. Mode III – Self-diagnosis

This mode is the same as the former self-diagnosis in self-diagnosis mode.


### 4. Mode IV – Switches ON/OFF diagnosis

During this mode, the inspection lamps monitor the switch ON-OFF condition.

- Idle switch
- Starter switch
- Vehicle speed sensor

### 5. Mode V – Real time diagnosis

The moment the malfunction is detected, the display will be presented immediately. That is, the condition at which the malfunction occurs can be found by observing the inspection lamps during driving test.



Each time the self-diagnosis is turned off during diagnosis, in each mode, and then turned back on again after the power to the E.C.U. has dropped off completely, the diagnosis will automatically return to Mode I.

The stored memory would be lost if:  
1. Battery terminal is disconnected.

2. After selecting Mode III, Mode IV is selected.  
However, if the diagnostic mode selector is kept turned fully clockwise, it will continue to change in the order of Mode I → II → III → IV → V → I ... etc., and in this state the stored memory will not be erased.



• Methods of erasing memory differ with systems. Read the manual before erasing system.






# SELF-DIAGNOSIS

## Description (Cont'd)


### SWITCHING THE MODES

1. Turn ignition switch "ON".
2. Turn diagnostic mode selector on E.C.U. fully clockwise and wait the inspection lamps flash.
3. Count the number of the flashing time, and after the inspection lamps have flashed the number of the required mode, turn diagnostic mode selector fully counterclockwise immediately.



Mode N

SEF872D



SEF989D

When the ignition switch is turned off during diagnosis, in each mode, and then turned back on again after the power to the E.C.U. has dropped off completely, the diagnosis will automatically return to Mode I.

The stored memory would be lost if:

1. Battery terminal is disconnected.
2. After selecting Mode III, Mode IV is selected.

However, if the diagnostic mode selector is kept turned fully clockwise, it will continue to change in the order of Mode I → II → III → IV → V → I ... etc., and in this state the stored memory will not be erased.


## SELF-DIAGNOSIS

### (b) Description (Cont'd)

#### CHECK ENGINE LIGHT (For California only)

This vehicle has a check engine light on instrument panel. This light comes ON under the following conditions:

- 1) When ignition switch is turned "ON" (for bulb check).
  - 2) When systems related to emission performance malfunction in Mode I (with engine running).
- This check engine light always illuminates and is synchronous with red L.E.D.
  - Malfunction systems related to emission performance can be detected by self-diagnosis, and they are clarified as self-diagnostic codes in Mode III.




CHECK ENGINE LIGHT

SEF924P

Code No.	Malfunction
12	Air flow meter circuit
14	Vehicle speed sensor circuit
23	Idle switch circuit
31	E.C.U. (E.C.C.S. control unit)
32	E.G.R. function
33	Exhaust gas sensor circuit
45	Injector leak

Use the following diagnostic flowchart to check and repair a malfunctioning system.



- Methods of erasing memories differ with systems. Read the manual before diagnosing systems.





# SELF-DIAGNOSIS

## Description (Cont'd)

Perform driving test.  
Make sure that check engine light does not come "ON" during this test.

- After repairs, test drive to check that check engine light does not come on.
- Test driving modes differ with systems. Read the manual before test driving.

DIAGNOSIS END



• Methods of erasing memories differ with systems. Read the manual before diagnosing systems.

# SELF-DIAGNOSIS

## Modes I & II — Mixture Ratio Feedback Control Monitors A & B

In these modes, the control unit provides the Air-fuel ratio monitor presentation and the Air-fuel ratio feedback coefficient monitor presentation.

Mode	LED	Engine stopped (Ignition switch "ON")		Engine running		
		Open loop condition	Closed loop condition			
Mode I (Monitor A)	Green	ON	* Remains ON or OFF	Blinks		
	Red	ON	Except for California model • OFF	For California model • ON: when the CHECK ENGINE LIGHT ITEMS are stored in the E.C.U. • OFF: except for the above condition		
Mode II (Monitor B)	Green	ON	* Remains ON or OFF	Blinks		
	Red	OFF	* Remains ON or OFF (synchronous with green LED)	Compensating mixture ratio		
				More than 5% rich	Between 5% lean and 5% rich	More
				OFF	Synchronized with green LED	Remains ON

\*: Maintains conditions just before switching to open loop

### DISPLAY CODE TABLE

Code No.	Detected Item	California	Non-California
11	Crank angle sensor circuit	X	X
12	Air flow meter circuit	X	X
13	Cylinder head temperature sensor circuit	X	X
14	Vehicle speed sensor circuit	X	X
21	Ignition signal missing in primary coil	X	X
22	Fuel pump circuit	X	X
23	Idle switch circuit	X	X
31	E.C.U. (E.C.S. control unit)	X	X
32	E.G.R. function	X	-
33	Exhaust gas sensor circuit	X	X
34	Detonation sensor circuit (V30BT)	X	X
35	Exhaust gas temperature circuit	X	-
42	Fuel temperature sensor circuit	X	X
43	Throttle sensor circuit	X	-
45	Injector leak	X	-
55	No malfunction in the above circuit	X	X

X: Available —: Not available



## SELF-DIAGNOSIS

### Mode III — Self-diagnostic System

The E.C.U. constantly monitors the function of these sensors and actuators, regardless of ignition key position. If a malfunction occurs, the information is stored in the E.C.U. and can be retrieved from the memory by turning on the diagnostic mode selector, located on the side of the E.C.U. When activated, the malfunction is indicated by flashing a red and a green L.E.D. (Light Emitting Diode), also located on the E.C.U. Since all the self-diagnostic results are stored in the E.C.U.'s memory even intermittent malfunctions can be diagnosed.

A malfunctioning part's group is indicated by the number of both the red and the green L.E.D.s flashing. First, the red L.E.D. flashes and the green flashes follow. The red L.E.D. refers to the number of tens while the green one refers to the number of units. For example, when the red L.E.D. flashes once and then the green one flashes twice, this means the number "12" showing the air flow meter signal is malfunctioning. In this way, all the problems are classified by the code numbers.

- When engine fails to start, crank engine more than two seconds before starting self-diagnosis.
- Before starting self-diagnosis, do not erase stored memory. If doing so, self-diagnosis function for intermittent malfunctions would be lost.

The stored memory would be lost if:

1. Battery terminal is disconnected.
2. After selecting Mode III, Mode IV is selected.

#### DISPLAY CODE TABLE

Code No.	Detected items	California	Non-California
11	Crank angle sensor circuit	X	X
12	Air flow meter circuit	X	X
13	Cylinder head temperature sensor circuit	X	X
14	Vehicle speed sensor circuit	X	X
21	Ignition signal missing in primary coil	X	X
22	Fuel pump circuit	X	X
23	Idle switch circuit	X	X
31	E.C.U. (E.C.C.S. control unit)	X	X
32	E.G.R. function	X	—
33	Exhaust gas sensor circuit	X	X
34	Detonation sensor circuit (VG30ET)	X	X
35	Exhaust gas temperature circuit	X	—
42	Fuel temperature sensor circuit	X	X
43	Throttle sensor circuit	X	—
45	Injector leak	X	—
55	No malfunction in the above circuit	X	X

X: Available —: Not available


# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)



### RETENTION OF DIAGNOSTIC RESULTS

The diagnostic result is retained in E.C.U. memory until the starter is operated fifty times after a diagnostic item is judged to be malfunctioning. The diagnostic result will then be cancelled automatically. If a diagnostic item which has been judged to be malfunctioning and stored in memory is again judged to be malfunctioning before the starter is operated fifty times, the second result will replace the previous one. It will be stored in E.C.U. memory until the starter is operated fifty times more.

RETENTION TERM CHART (Example)



If the same diagnostic item is judged to be malfunctioning before the starter is operated fifty times, it will be stored in E.C.U. memory until the starter is operated fifty times from this point in time.




CAUTION: During flashing code for self-diagnostic mode (mode III), in the other diagnostic mode should be done, make sure to write down the malfunctioning code for before turning diagnostic mode selector on E.C.U. fully clockwise, select the diagnostic mode after turning ignition OFF. Otherwise self-diagnostic information stored in E.C.U. memory until now would be lost.



# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)

### SELF-DIAGNOSTIC PROCEDURE



#### CAUTION:

During displaying code No. in self-diagnosis mode (mode III), if the other diagnostic mode should be done, make sure to write down the malfunctioning code No. before turning diagnostic mode selector on E.C.U. fully clockwise, or select the diagnostic mode after turning switch "OFF". Otherwise self-diagnosis information stored in E.C.U. memory until now would be lost.

# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)

### DECODING CHART


Display code malfunction following conditions are detected

Malfunctioning circuit or parts


Control unit shows a malfunction signal when the following conditions are detected.

#### CRANK ANGLE SENSOR

Code No. 11



Crank angle sensor circuit is malfunctioning.




- Either 1° or 120° signal is not entered for the first few seconds during engine cranking.
- Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm.

SYSTEM INSPECTION  
See page EF & EC-84.

SEF990D

#### AIR FLOW METER

Code No. 12



Air flow meter circuit is malfunctioning.



- The air flow meter circuit is open or shorted. (An abnormally high or low voltage is entered.)

SYSTEM INSPECTION  
See page EF & EC-86.

SEF280E

#### CYLINDER HEAD TEMPERATURE SENSOR

Code No. 13



Cylinder head temperature sensor circuit.



- The cylinder head temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.)

SYSTEM INSPECTION  
See page EF & EC-88.

SEF833C

SYSTEM INSPECTION  
See page EF & EC-84.

SEF990D




# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)

Display code

Malfunctioning circuit or parts

Control unit shows a malfunction signal when the following conditions are detected



### CAUTION

During displaying code No. in self diagnosis mode (mode III), if the other diagnostic mode should be done, make sure to write down the malfunctioning code No. before turning diagnostic mode selector on E.C.U. fully clockwise or select the diagnostic mode after turning switch "OFF". Otherwise self-diagnosis information stored in E.C.U. memory will now would be lost.


# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)


Display code  
Control unit shows a malfunction signal when the following conditions are detected.

Malfunctioning circuit or parts


Control unit shows a malfunction signal when the following conditions are detected

**IDLE SWITCH** 

**Code No. 23**



**Throttle valve switch circuit**




- Signal circuit is open.


**SYSTEM INSPECTION**  
See page EF & EC-96.

**E.C.U. (E.C.C.S. CONTROL UNIT)** 

**Code No. 31**



**E.C.U. calculation function**




- Signal is beyond "normal" range.


**SYSTEM INSPECTION**  
See page EF & EC-98.

**E.G.R. (California model only)** 

**Code No. 32**




**E.G.R. circuit**




- E.G.R. valve does not operate; (E.G.R. valve spring does not lift.)

**SYSTEM INSPECTION**  
See page EF & EC-100/155.

**Code No. 55**



**E.C.C.S. (California model only)**



- Signal circuit is open.

**SYSTEM INSPECTION**  
See page EF & EC-108.




# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)

Display code  
Control unit shows a malfunction signal when the following conditions are detected

Malfunctioning circuit or parts

Control unit shows a malfunction signal when the following conditions are detected.



# SELF-DIAGNOSIS

## Mode III — Self-diagnostic System (Cont'd)


Display code

Malfunctioning circuit or parts

Control unit shows a malfunction signal when the following conditions are detected

### FUEL TEMPERATURE SENSOR

Code No. 42



Fuel temperature sensor circuit is malfunctioning.

Fuel temperature sensor




- Fuel temperature circuit is open or short. (An abnormally high or low voltage has entered.)

SYSTEM INSPECTION  
See page EF & EC-112.


SEF945F

### THROTTLE SENSOR (California model only)

Code No. 43



Throttle sensor circuit




- Throttle sensor circuit is open or short. (Output voltage is too high or too low.)

SYSTEM INSPECTION  
See page EF & EC-114.


SEF980F

### INJECTOR LEAK (California model only)

Code No. 45



Fuel leak




Fuel leak from injector

SYSTEM INSPECTION  
See page EF & EC-116.

SEF364G

Code No. 55



E.C.C.S.  
normal  
operation.

DIAGNOSIS END

SEF946F

### CAUTION:

- For safety, do not drive rear wheels at higher speed than required.



# SELF-DIAGNOSIS

## Mode IV — Switches ON/OFF Diagnostic System

In switches ON/OFF diagnosis system, ON/OFF operation of the following switches can be detected continuously.


- Idle switch
- Starter switch
- Vehicle speed sensor

### (1) Idle switch & Starter switch

The switches ON/OFF status at the point when mode IV is selected is stored in E.C.U. memory. When either switch is turned from "ON" to "OFF" or "OFF" to "ON", the red L.E.D. on E.C.U. alternately comes on and goes off each time switching is detected.

### (2) Vehicle Speed Sensor


The switches ON/OFF status at the point when mode IV is selected is stored in E.C.U. memory. When vehicle speed is 20 km/h (12 MPH) or slower, the green L.E.D. on E.C.U. is off. When vehicle speed exceeds 20 km/h (12 MPH), the green L.E.D. on E.C.U. comes "ON".



# SELF-DIAGNOSIS

## Mode IV — Switches ON/OFF Diagnostic System (Cont'd)

### SELF-DIAGNOSTIC PROCEDURE



**CAUTION:**

- For safety, do not drive rear wheels at higher speed than required.



# SELF-DIAGNOSIS


## Mode V — Real Time Diagnostic System

In real time diagnosis, if any of the following items are judged to be faulty, a malfunction is indicated immediately.

- Crank angle sensor (120°-signal & 1° signal)
- Ignition signal
- Air flow meter output signal
- Fuel pump

Consequently, this diagnosis is a very effective measure to diagnose whether the above systems cause the malfunction or not, during driving test. Compared with self-diagnosis, real time diagnosis is very sensitive, and can detect malfunctioning conditions in a moment. Further, items regarded to be malfunctions in this diagnosis are not stored in E.C.U. memory.

### SELF-DIAGNOSTIC PROCEDURE



#### CAUTION:

In real time diagnosis, pay attention to inspection lamp flashing. E.C.U. displays the malfunction code only once, and does not memorize the inspection.

# SELF-DIAGNOSIS

## Mode V — Real Time Diagnostic System (Cont'd)

### DECODING CHART

Display presentation


Air Flow Meter

Malfunction circuit or parts


Control unit shows a malfunction signal when the following conditions are detected.

(Compare with Self Diagnosis — Mode III.)

#### CRANK ANGLE SENSOR




Crank angle sensor circuit is malfunctioning.




The 1° or 120° signal is momentarily missing, or, multiple, momentary noise signals enter.

REAL TIME DIAGNOSTIC INSPECTION  
See page EF & EC-78.

#### AIR FLOW METER




Air flow meter circuit is malfunctioning.




Abnormal, momentary increase in air flow meter output signal.

REAL TIME DIAGNOSTIC INSPECTION  
See page EF & EC-79.

#### IGNITION SIGNAL




Ignition signal is malfunctioning.



Signal from the primary ignition coil momentarily drops off.

REAL TIME DIAGNOSTIC INSPECTION  
See page EF & EC-80.

#### FUEL PUMP



Fuel pump circuit is malfunctioning.



Fuel pump circuit is momentarily open or shorted.

REAL TIME DIAGNOSTIC INSPECTION  
See page EF & EC-81.




# SELF-DIAGNOSIS

## Mode V — Real Time Diagnostic System (Cont'd)

### REAL TIME DIAGNOSTIC INSPECTION

#### Crank Angle Sensor

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Crank angle sensor harness connector	Sensor & actuator	E.C.U. 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	○	X	X	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	○	X	○	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	X	X	○	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	○	X	X	Replace terminal.
6	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal.






# SELF-DIAGNOSIS

## Mode V — Real Time Diagnostic System (Cont'd)

### Air Flow Meter

Ignition 2

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Air flow meter harness connector	Sensor & actuator	E.C.U. 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	○	X	X	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	○	X	○	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	X	X	○	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	○	X	X	Replace terminal.
6	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal.






# SELF-DIAGNOSIS

## Mode V — Real Time Diagnostic System (Cont'd)

### Ignition Signal

Air Flow Meter

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Ignition signal harness connector	Sensor & actuator	E.C.U. 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	○	X	X	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	○	X	○	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	X	X	○	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	○	X	X	Replace terminal.
6	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal.




# SELF-DIAGNOSIS

## Mode V — Real Time Diagnostic System (Cont'd)






### Fuel pump

Check sequence	Check items	Check conditions	Check parts			If malfunction, perform the following items.
			Fuel pump harness connector	Sensor & actuator	E.C.U. 20- & 16-pin connector	
1	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	Go to check item 2.
2	Check harness continuity at connector.	Engine stopped	○	X	X	Go to check item 3.
3	Disconnect harness connector, and then check dust adhesion to harness connector.	Engine stopped	○	X	○	Clean terminal surface.
4	Check pin terminal bend.	Engine stopped	X	X	○	Take out bend.
5	Reconnect harness connector and then recheck harness continuity at connector.	Engine stopped	○	X	X	Replace terminal.
6	Tap and wiggle harness connector or component during real time diagnosis.	During real time diagnosis	○	○	○	If malfunction codes are displayed during real time diagnosis, replace terminal.





# ELECTRONIC CONTROL SYSTEM INSPECTION




## CAUTION:

1. Before connecting or disconnecting E.C.U. harness connector to or from any E.C.U., be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage E.C.U. as battery voltage is applied to E.C.U. even if ignition switch is turned off. Otherwise, there may be damage to the E.C.U.
2. When performing E.C.U. input/output signal inspection, remove pin terminal retainer from 20- and 16-pin connector to make it easier to insert tester probe into connector.
3. When connecting pin connectors into E.C.U. or disconnecting them from E.C.U., take care not to damage pin terminal of E.C.U. (Bend or break).
4. Make sure that there are not any bends or breaks on E.C.U. pin terminal, when connecting pin connectors into E.C.U.
5. Before replacing E.C.U., perform E.C.U. input/output signal inspection and make sure whether E.C.U. functions properly or not. (See page EF & EC-138.)
6. After performing this "ELECTRONIC CONTROL SYSTEM INSPECTION", perform E.C.C.S. self-diagnosis and driving test.

# ELECTRONIC CONTROL SYSTEM INSPECTION

CRANK ANGLE SENSOR (Code No. 11)



7. When measuring supply voltage of E.C.U. controlled components with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the power transistor of the control unit.



## 8. Keys to symbols



DISCONNECT : Check after disconnecting the connector to be measured.



CONNECT : Check after connecting the connector to be measured.

9. When measuring voltage or resistance at connector with tester probes, there are two methods of measurement; one is done from terminal side and the other from harness side. Before measuring, confirm symbol mark again.




H.S. : Inspection should be done from harness side.



T.S. : Inspection should be done from terminal side.

Refer to GI section.


10. As for continuity check of joint connector, refer to EL section.







# ELECTRONIC CONTROL SYSTEM INSPECTION

## CRANK ANGLE SENSOR (Code No. 11)



SEF157G



### INSPECTION START

**A** CHECK POWER SOURCE.

- 1) Turn ignition switch "ON".
- 2) Check voltage between terminal (b) and ground. Battery voltage should exist.

N.G. Check the following items.

- 1) Harness continuity between crank angle sensor and battery.
- 2) Main relay (Refer to EL section.)
- 3) "BR" fusible link
- 4) Power source for E.C.U. (See page EF & EC-122.)

**B** CHECK GROUND CIRCUIT.


- 1) Turn ignition switch "OFF".
- 2) Disconnect crank angle sensor harness connector.
- 3) Check resistance between terminal (d) and ground. Resistance: Approximately  $0\Omega$

N.G. Check the following items.

- 1) Harness continuity between crank angle sensor and ground
- 2) Ground circuit for E.C.U. (See page EF & EC-122.)

# ELECTRONIC CONTROL SYSTEM INSPECTION

## CRANK ANGLE SENSOR (Code No. 11)



**C**

**CHECK E.C.U. INPUT SIGNALS.**

- 1) Reconnect crank angle sensor harness connector.
- 2) Start engine.
- 3) Check that pulse signals exist in E.C.U. terminals ⑧ and ⑰ with logic probe.

**Pulse signals should exist.**

⑧ : 1° signal

⑰ : 120° signal

**D**

N.G. Check harness continuity between crank angle sensor and E.C.U.

- Stop engine.
- Disconnect crank angle sensor harness connector.
- Disconnect E.C.U. 20-pin connector from E.C.U.

1° signal circuit


Continuity between terminals ③ and ⑧

120° signal circuit

Continuity between terminals ③ and ⑰

**Resistance:**

Approximately 0Ω



O.K.

Stop engine and check interference between crank angle sensor harness and high-tension cable.

N.G. Separate them.

O.K.

**E**

Visually check rotor plate for damage or dust.

N.G. Clean or replace crank angle sensor.

O.K.

Reinstall any part removed.


Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode-III) again.

N.G. 1) Perform E.C.U. input/output signal inspection test.  
2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.

O.K.




**INSPECTION END**





# ELECTRONIC CONTROL SYSTEM INSPECTION

## AIR FLOW METER (Code No. 12) (CHECK ENGINE LIGHT ITEM)



### INSPECTION START

**A** CHECK POWER SOURCE.  
 1) Turn ignition switch "ON".  
 2) Check voltage between terminal **E** and ground. Battery voltage should exist.

N.G. Check the following items.  
 1) Harness continuity between air flow meter and battery  
 2) Main relay (Refer to EL section.)  
 3) "BR" fusible link  
 4) Power source for E.C.U. (See page EF & EC-122.)



O.K.  
**B** CHECK GROUND CIRCUIT.  
 1) Turn ignition switch "OFF".  
 2) Disconnect air flow meter harness connector.  
 3) Check resistance between terminals **C**, **D** and ground.  
 4) Shield wire and ground.  
 Resistance:  
 Approximately  $0\Omega$

N.G. Check engine ground and harness connection between air flow meter and ground.

O.K.

# ELECTRONIC CONTROL SYSTEM INSPECTION

## AIR FLOW METER (Code No. 12) (CHECK ENGINE LIGHT ITEM)



**C**

**CHECK E.C.U. INPUT SIGNAL**

- 1) Reconnect air flow meter harness connector.
- 2) Start engine and warm it up sufficiently.
- 3) Make sure that voltage between E.C.U. terminal ③ and ground changes under the following conditions. **Output voltage should change.**
  - When racing engine with accelerator pedal  
Approximately 2 - 4V
  - Idling condition  
2 - 3V

**D**

N.G. →

Check harness continuity between E.C.U. and air flow meter.

- Stop engine.
- Disconnect air flow meter harness connector.
- Disconnect E.C.U. 16-pin harness connector.
- Check resistance between terminal ② and E.C.U. terminal ③.

Resistance:  
Approximately 0Ω

If O.K., replace air flow meter.

O.K. ↓

Reinstall any part removed.

↓

Erase the self-diagnosis memory.

↓

Perform driving test and then perform self-diagnosis (Mode-III) again.

N.G. →

- 1) Perform E.C.U. input/output signal inspection test.
- 2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.

O.K. ↓

**INSPECTION END**

O.K. ↓

Reinstall any part removed.

↓

Erase the self-diagnosis memory.

↓

Perform driving test and then perform self-diagnosis (Mode-III) again.

O.K. ↓

**INSPECTION END**

N.G. →



Check harness connection between cylinder head temperature sensor and ground.








# ELECTRONIC CONTROL SYSTEM INSPECTION

CYLINDER HEAD TEMPERATURE SENSOR (Code No. 13) (CHECK ENGINE LIGHT ITEM)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## CYLINDER HEAD TEMPERATURE SENSOR (Code No. 13)



INSPECTION START

**A**  
**CHECK INPUT SIGNAL.**  
 1) Start engine.  
 2) Make sure that voltage between E.C.U. terminal ②③ and ground changes during engine warm up.  
**Cold → Hot:** 12 MPH  
**Approximately 5 - 0V**

N.G.

**B** 1) Check cylinder head temperature sensor resistance.

- Stop engine.
- Disconnect cylinder head temperature sensor harness connector.
- Check resistance between terminals.

20°C (68°F)	2.3 - 2.7 kΩ
50°C (122°F)	0.77 - 0.87 kΩ
80°C (176°F)	0.30 - 0.33 kΩ

If no continuity, replace cylinder head temperature sensor.  
 2) Check power source for E.C.U. (See page EF & EC-122.)

O.K.  
**B** CHECK CONTINUITY BETWEEN E.C.U. AND VEHICLE SPEED SENSOR  
 1) Turn ignition switch "OFF".  
 2) Disconnect E.C.U. 16-pin harness connector.  
 3) Check resistance between E.C.U. terminal ② and ground by rotating rear wheel by hand.  
 Continuity should exist, and go O.K.

**C** 3) Check harness continuity between E.C.U. and cylinder head temperature sensor.

- Disconnect 16-pin connector from E.C.U.
- Disconnect cylinder head temperature sensor connector.

**D**  
**CHECK GROUND CIRCUIT.**  
 1) Stop engine and disconnect 16-pin connector from E.C.U.  
 2) Disconnect cylinder head temperature sensor harness connector.  
 3) Check resistance between terminal ① and E.C.U. terminal ②⑥.  
**Resistance:**  
**Approximately 0Ω**

N.G.

Check harness connection between cylinder head temperature sensor and ground.

Reinstall any part removed.

Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode-III) again.

N.G.

1) Perform E.C.U. in-output signal inspection test.  
 2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.


O.K.

INSPECTION END



# ELECTRONIC CONTROL SYSTEM INSPECTION

**VEHICLE SPEED SENSOR (Switch ON/OFF diagnosis) (Code No. 14) (CHECK ENGINE LIGHT ITEM)**



The following is necessary to perform this inspection.

1. Pull out E.C.U. from passenger's dash side.
2. Jack up rear wheels.




# ELECTRONIC CONTROL SYSTEM INSPECTION

VEHICLE SPEED SENSOR (Switch ON/OFF diagnosis) (Code No. 14)



(CHECK ENGINE LIGHT ITEM)




INSPECTION START

**A CHECK INPUT SIGNAL**

- 1) Perform switch ON/OFF diagnosis (in Mode IV).
- 2) Make sure green L.E.D. on E.C.U. comes "ON" when vehicle speed reaches 20 km/h (12 MPH).

O.K.

INSPECTION END



N.G.

**B CHECK CONTINUITY BETWEEN E.C.U. AND VEHICLE SPEED SENSOR**

- 1) Turn ignition switch "OFF".
- 2) Disconnect E.C.U. 16-pin harness connector.
- 3) Check resistance between E.C.U. terminal 29 and ground by rotating rear wheel by hand.

Continuity should come and go.

N.G.

- 1) Repair or replace harness.
- 2) Check middle harness connector for proper connection.
- 3) Check S.M.J.

O.K.

CHECK VEHICLE SPEED SENSOR  
See EL section.

Reinstall any part removed.

Perform self-diagnosis Mode IV.

N.G.

- 1) Perform E.C.U. input/output signal inspection test.
- 2) If N.G., recheck E.C.U. pin terminal damage or the connection of E.C.U. harness connector.

O.K.

INSPECTION END

Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode III) again.





O.K.

INSPECTION END







# ELECTRONIC CONTROL SYSTEM INSPECTION

## IGNITION SIGNAL (Code No. 21)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## IGNITION SIGNAL (Code No. 21)



**D** CHECK INPUT SIGNAL.  
1) Start engine.  
2) Make sure that pulse signals exist between terminal ⑤ and ground with logic probe.  
Pulse signal should exist.

O.K.

**E** CHECK INPUT SIGNAL.  
1) Stop engine.  
2) Turn ignition switch "ON".  
3) Check voltage between terminal ③ and ground.  
Battery voltage should exist.

O.K.

**F** CHECK GROUND CIRCUIT.  
1) Turn ignition switch "OFF".  
2) Disconnect power transistor harness connector.  
3) Check resistance between terminal ③ and ground.  
Resistance:  
Approximately 0Ω

O.K.

Reinstall any part removed.

Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode-III) again.

O.K.

INSPECTION END

N.G.

1) Stop engine and check harness continuity between power transistor and E.C.U.  
**B** 2) Check power transistor with circuit tester.  
• Disconnect harness connector for power transistor.  
① : To ignition coil (+) side  
② : To E.C.U.  
③ : To engine ground

Terminal No.	Tester polarity	Continuity
①	+	No continuity
③	-	No continuity
①	-	Continuity should exist.
③	+	Continuity should exist.
①	+	No continuity
②	-	No continuity
①	-	Continuity should exist.
②	+	Continuity should exist.

If N.G., replace power transistor.

**C** 3) Check resistance of ignition coil.

Terminal No.	Resistance
① - ②	1Ω
① - ③	10 kΩ

If N.G., replace ignition coil.

Check harness continuity between E.C.U. and battery.

N.G.

Check the following items.  
1) Harness connection between power transistor and ground  
2) Engine ground

N.G.







1) Perform E.C.U. input/output signal inspection test.  
2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.



# ELECTRONIC CONTROL SYSTEM INSPECTION






IGNITION SIGNAL (Code No. 21)

## FUEL PUMP (Code No. 22)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## FUEL PUMP (Code No. 22)






# ELECTRONIC CONTROL SYSTEM INSPECTION

FUEL PUMP (Code No. 23)

## IDLE SWITCH (Switch ON/OFF diagnosis) (Code No. 23) (CHECK ENGINE LIGHT ITEM)





The following is necessary to perform this inspection.  
Pull out E.C.U. from passenger's dash side.



# ELECTRONIC CONTROL SYSTEM INSPECTION

IDLE SWITCH (Switch ON/OFF diagnosis) (Code No. 23) (CHECK ENGINE LIGHT ITEM)



INSPECTION START

**A** CHECK INPUT SIGNAL:  
 1) Turn ignition switch "ON".  
 2) Check voltage between E.C.U. terminal ⑱ and ground.

Accelerator pedal condition	Voltage
Fully closed	9 - 10V
Open	0V

O.K.

Reinstall any part removed.

Erase the self-diagnosis memory.  
 Make sure Code No. 55 is displayed in Mode III.

Perform self-diagnosis (Mode IV).

INSPECTION END


- Check the following items.
- 1) Harness continuity between E.C.U. and throttle valve switch.
  - 2) Ignition switch
  - 3) "BR" fusible link
  - 4) Continuity of throttle valve switch
  - Disconnect throttle valve switch harness connector.
  - B** • Make sure that continuity exists when fully closed.
  - 5) E.F.I. main relay
  - 6) Power source for E.C.U. & ground circuit for E.C.U. (See page EF & EC-122.)

- N.G.
- 1) Perform E.C.U. input/output signal inspection test.
  - 2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.



# ELECTRONIC CONTROL SYSTEM INSPECTION




## ENGINE CONTROL UNIT (Code No. 31) (CHECK ENGINE LIGHT ITEM)



# ELECTRONIC CONTROL SYSTEM INSPECTION

E.G.R. FUNCTION (Code No. 55) (CHECK ENGINE LIGHT ITEM) (NOTIFY) (CALIFORNIA MODEL ONLY)

**NOTE**



**1** CHECK VACUUM SOURCE TO E.G.R. CONTROL VALVE

- 1) Disconnect vacuum hose connected to E.G.R. control valve.
- 2) Make sure vacuum exists when cranking engine.

O.K. → Perform CHECK 2

**2** CHECK VACUUM HOSE CONNECTION

- 1) Check vacuum hose for proper connection.

N.G. → If necessary, replace vacuum hose and reconnect vacuum firmly.

**3** CHECK E.C.U. OUTPUT SIGNAL

- 1) Check voltage between E.C.U. terminal 4 and ground.


Engine Condition	Voltage
Idle	Approximately 1.0V
Running	Battery voltage

**4** CHECK POWER SOURCE TO E.G.R. CONTROL SOLENOID VALVE

- 1) Stop engine.
- 2) Turn ignition switch "OFF".
- 3) Check voltage between terminal 3 and ground. Battery voltage should exist.

**5** CHECK GROUND CIRCUIT

- 1) Turn ignition switch "OFF".
- 2) Disconnect E.C.U. terminal 4.
- 3) Disconnect E.G.R. valve and check voltage between terminal 3 and ground. Battery voltage should exist.
- 4) Check voltage between E.C.U. terminal 12 and ground. Battery voltage should exist.




O.K.



# ELECTRONIC CONTROL SYSTEM INSPECTION

**E.G.R. FUNCTION (Code No. 32) (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY**

NOTE



(CAL): For California






SEF313H

The following is necessary to perform this inspection.

1. Pull out E.C.U. from passanger's dash side.
2. Warm up engine sufficiently.

# ELECTRONIC CONTROL SYSTEM INSPECTION




**E.G.R. FUNCTION (Code No. 32) (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY**





# ELECTRONIC CONTROL SYSTEM INSPECTION

**E.G.R. FUNCTION (Code No. 32) (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY**



**G CHECK E.G.R. CONTROL SOLENOID VALVE**

- 1) Stop engine.
- 2) Remove E.G.R. control solenoid valve from vehicle.
- 3) Check the port continuity.

Solenoid valve	Continuity
When current flows	A - B
When current does not flow	B - C

N.G. → Replace E.G.R. control solenoid valve.

**H CHECK E.G.R. CONTROL VALVE**

- 1) Remove E.G.R. control valve from vehicle.
- 2) Apply vacuum to E.G.R. vacuum port with a hand vacuum pump. E.G.R. control valve spring should lift.

N.G. → Valve spring may be stuck. Clean if necessary. If this does not correct trouble, replace E.G.R. control valve.

O.K. → Reinstall any part removed.

Erase the self-diagnosis memory. Make sure Code No. 55 is displayed in Mode III.


- I Perform driving test under the following conditions:**
- 1) Warm up engine sufficiently.
  - 2) Use test driving modes indicated in figure 1.

**J Make sure check engine light does not come "ON" during driving test.**

Comes "ON" → Perform self-diagnosis and find malfunction code. According to displayed code No., perform electronic control system inspection.

Does not come "ON" → INSPECTION END


# ELECTRONIC CONTROL SYSTEM INSPECTION

E.G.R. FUNCTION (Code No. 32)  (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY

**I**

**Driving mode**

(A) : Test condition  
(B) : 17 seconds or more



Vehicle driving  
Idling  
Ignition switch;  
OFF

Time

Until green and red LEDs go off.

- 1 Start engine and warm it up sufficiently.
- 2 Turn off ignition switch and keep it off until green and red LEDs go off.
- 3 Start engine.
- 4 Shift to suitable gear position and drive in "Test condition" for at least 17 seconds.
- 5 Decrease engine revolution to less than 1,000 rpm.
- 6 Repeat steps 4 through 5 at least 4 times.


**Test condition**

Keep the following condition.

- 1) Engine revolution:  
VG30E; 2,300±300 rpm  
VG30ET; 2,200±200 rpm
- 2) Intake manifold vacuum:  
VG30E; -36.0±12.0 kPa  
(-270±90 mmHg,  
-10.63±3.54 inHg)  
VG30ET; -13.3±13.3 kPa  
(-100±100 mmHg,  
-3.94±3.94 inHg)

SEF387G

**U**



CHECK ENGINE LIGHT

SEF924F

**CHECK INPUT SIGNAL**

1) Stop engine.  
2) Start engine and make sure that engine has warmed up sufficiently.  
3) Check voltage between E.C.U. terminal 25 and ground.  
Voltage: 0 - 1.0V

If not, warm it up and repeat steps 2 and 3.

If O.K., go to INSPECTION END.

If N.G., go to CHECK INPUT SIGNAL.

**Check harness between E.C.U. and ground.**

Stop engine.  
Disconnect the gas sensor harness connector, and connect main harness side terminal for sensor signal to ground with a jumper wire.

Disconnect T6 pin connector from E.C.U.

Check resistance between E.C.U. terminal 25 and ground.  
Resistance:  
Approximately 0Ω.

Perform MIXTURE RATIO FEEDBACK SYSTEM INSPECTION (See page EF & EC 14)

**WARM UP ENGINE SUFFICIENTLY**


1) Warm up engine sufficiently.  
2) Make sure that green inspection lamp goes on and off 5 times or more during 10 seconds at 2,000 rpm.

**INSPECTION END**

**INSPECTION END**

**INSPECTION END**

Legend:  
Ⓡ : VG30E engine  
ⓔ : VG30ET engine






# ELECTRONIC CONTROL SYSTEM INSPECTION

E.G.R. FUNCTION (Code No. 82) CHECK ENGINE LIGHT ITEM, CALIFORNIA MODEL 0.3

## EXHAUST GAS SENSOR (Code No. 33) (CHECK ENGINE LIGHT ITEM)






The following is necessary to perform this inspection.

1. Pull out E.C.U. from passenger's dash side.
2. Warm up engine sufficiently.



# ELECTRONIC CONTROL SYSTEM INSPECTION

## EXHAUST GAS SENSOR (Code No. 33) (CHECK ENGINE LIGHT ITEM)



INSPECTION START

**CHECK FLASHES OF INSPECTION LAMPS ON E.C.U.**

- 1) Warm up engine sufficiently.
- A** 2) Make sure that green inspection lamp goes on and off 5 times or more during 10 seconds at 2,000 rpm.

O.K. → INSPECTION END

**B** N.G. →

**CHECK INPUT SIGNAL.**

- 1) Stop engine.
- 2) Start engine and make sure that engine has warmed up sufficiently. If not, warm it up.
- 3) Check voltage between E.C.U. terminal 24 and ground.  
**Voltage: 0 - 1.0V**

N.G. →

1) Insulation between ground and harness connecting E.C.U. with detonation sensor.

**B** 2) Detonation sensor. Continuity should not exist.

If N.G., replace detonation sensor.

**C** N.G. →

Check harness continuity between E.C.U. and ground.

- Stop engine.
- Disconnect exhaust gas sensor harness connector, and connect main harness side terminal for sensor signal to ground with a jumper wire.
- Disconnect 16-pin connector from E.C.U.
- Check resistance between E.C.U. terminal 24 and ground.  
**Resistance: Approximately 0Ω**

N.G. → Replace exhaust gas sensor.

→ Reinstall any part removed.

→ Erase the self-diagnosis memory. Make sure Code No. 55 is displayed in Mode III.

Perform MIXTURE RATIO FEEDBACK SYSTEM INSPECTION. (See page EF & EC-143.)

N.G. →

- 1) Warm up engine sufficiently.
- 2) Set diagnosis mode to Mode I.
- 3) Make sure that inspection lamp (Green) on E.C.U. goes on and off periodically more than 5 times during 10 seconds at 2,000 rpm.


O.K. → INSPECTION END



# ELECTRONIC CONTROL SYSTEM INSPECTION





EXHAUST GAS SENSOR (Code No. 33) (CHECK ENGINE LIGHT ITEM)

## DETONATION SENSOR (Code No. 34); VG30ET



# ELECTRONIC CONTROL SYSTEM INSPECTION


## DETONATION SENSOR (Code No. 34); VG30ET





# ELECTRONIC CONTROL SYSTEM INSPECTION

## EXHAUST GAS TEMPERATURE SENSOR (Code No. 35); CALIFORNIA MODEL ONLY




The following is necessary to perform this inspection.

1. Pull out E.C.U. installed passenger's dash side.
2.
  - Disconnect vacuum hose connected to E.G.R. control valve.
  - Connect a hand vacuum pump to E.G.R. control valve.
3. Warm up engine sufficiently.

# ELECTRONIC CONTROL SYSTEM INSPECTION


## EXHAUST GAS TEMPERATURE SENSOR (Code No. 35); CALIFORNIA MODEL ONLY





# ELECTRONIC CONTROL SYSTEM INSPECTION

## EXHAUST GAS TEMPERATURE SENSOR (Code No. 35); CALIFORNIA MODEL ONLY



# ELECTRONIC CONTROL SYSTEM INSPECTION

FUEL TEMPERATURE SENSOR (Code No. 42)

NOTE

INSPECTION START



**CHECK INPUT SIGNAL**

- 1) Check voltage.
- 2) Make sure that voltage between E.C.U. terminal (5) and ground changes during engine warm up.

Cold → Hot:  
Approximately 5 - 0V

FUEL TEMPERATURE SENSOR

- 1) Check fuel temperature sensor connection.
  - Stop engine.
  - Disconnect fuel temperature sensor connector.
  - Check continuity between terminal (5) and ground.

OK

2) Check fuel temperature sensor resistance.

3) Check ground wire to E.C.U. connector.

4) Check ground wire to E.C.U. connector.



OK

Start the engine and observe the fuel temperature sensor.

Check the fuel temperature sensor.

Check the fuel temperature sensor and perform as diagnosis (Mode III) again.

OK

N.G.

- 1) Check E.C.U. input output signal.
- 2) If N.G., check the E.C.U. pin terminals damage or the connection of E.C.U. main connector.


INSPECTION END

DC 16732




# ELECTRONIC CONTROL SYSTEM INSPECTION

EXHAUST GAS TEMPERATURE SENSOR (Code No. 35); CALIFORNIA MODEL ONLY  
 FUEL TEMPERATURE SENSOR (Code No. 42) 3TON



# ELECTRONIC CONTROL SYSTEM INSPECTION

## FUEL TEMPERATURE SENSOR (Code No. 42)



**INSPECTION START**

**A**

**CHECK INPUT SIGNAL.**

1) Start engine.

2) Make sure that voltage between E.C.U. terminal (15) and ground changes during engine warm up.

**Cold → Hot:**  
**Approximately 5 - 0V**

**N.G.**


**B** 1) Check fuel temperature sensor resistance.

- Stop engine.
- Disconnect fuel temperature sensor harness connector.
- Check resistance between terminal and ground.

20° C (68° F)	2.3 - 2.7 kΩ
50° C (122° F)	0.77 - 0.87 kΩ
80° C (176° F)	0.30 - 0.33 kΩ

If no continuity, replace fuel temperature sensor.

2) Check power source for E.C.U. & ground circuit for E.C.U. (See page EF & EC-122.)



**O.K.**

Reinstall any part removed.

Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode III) again.

**N.G.**

1) Perform E.C.U. input/output signal inspection test.

2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.

**O.K.**

**INSPECTION END**



**N.G.**

Check the following items:

- Turn ignition switch "OFF".
- Disconnect throttle sensor harness connector.
- Disconnect 18-pin connector from E.C.U.
- Check resistance between terminal 15 and ground.

Approximately 0Ω

2) Power source for E.C.U. (Refer to page EF & EC-122.)

3) "BR" fuel link

**INSPECTION END**

Erase the self-diagnosis memory.

Perform driving test and then perform self-diagnosis (Mode III) again.

**O.K.**

**INSPECTION END**

**N.G.**



1) Perform E.C.U. input/output signal inspection test.

2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.




# ELECTRONIC CONTROL SYSTEM INSPECTION

**THROTTLE SENSOR (Code No. 43); FOR CALIFORNIA MODEL/(Not self-diagnostic item);  
FOR NON-CALIFORNIA A/T MODEL (Only control for automatic transmission)**



# ELECTRONIC CONTROL SYSTEM INSPECTION




**THROTTLE SENSOR (Code No. 43); FOR CALIFORNIA MODEL/(Not self-diagnostic item);**






# ELECTRONIC CONTROL SYSTEM INSPECTION

**INJECTOR LEAK (Code No. 45)  (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL ONLY**



# ELECTRONIC CONTROL SYSTEM INSPECTION

**INJECTOR LEAK (Code No. 45) (CHECK ENGINE LIGHT ITEM); CALIFORNIA MODEL**








# ELECTRONIC CONTROL SYSTEM INSPECTION

## START SIGNAL (Switch ON/OFF diagnosis)



INSPECTION START

**A**  
**CHECK INPUT SIGNAL.**  
 1) Turn ignition switch to "START".  
 2) Check voltage between terminal ⑨ and ground.  
**Battery voltage should exist.**




N.G. → Turn ignition switch "OFF" and check the following items.  
 1) Ignition switch  
 2) Harness continuity between ignition switch and E.C.U.

O.K. → Reinstall any part removed.

Perform self-diagnosis (Mode-IV) again.

N.G. → 1) Perform E.C.U. input/output signal inspection test.  
 2) If N.G., recheck the E.C.U. pin terminals damage or the connection of E.C.U. harness connector.

O.K. → INSPECTION END




**B**  
**CHECK GROUND CIRCUIT**  
 1) Disconnect 15-pin connector from E.C.U.  
 2) Check resistance between terminals ⑩, ⑪, ⑫, ⑬ and ground.  
 Resistance:  
 Approximately 0Ω

N.G. → Check resistance of individual injectors.  
 • Disconnect injector harness connector.  
 Resistance:  
 Approximately 1.5Ω

O.K. → Reinstall any part removed.

N.G. → Replace injector.



INSPECTION END









# ELECTRONIC CONTROL SYSTEM INSPECTION

## INJECTOR (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## INJECTOR (Not self-diagnostic item)



**INSPECTION START**

**CHECK POWER SOURCE.**

1) Disconnect 15-pin connector.

**A** 2) Check voltage between terminals (101), (102), (103), (104), (105), (106), (114) and ground. Battery voltage should exist.

N.G. →

Check the following items.

1) Harness continuity between E.C.U. and battery

- Disconnect fusible link connector.

**C** • Check resistance between fusible link connector and E.C.U.

Resistance between terminals (101), (102), (103), (104), (105), (106) and fusible link connector

Resistance: Battery Approximately  $1.5\Omega$

Resistance between terminal (114) and fusible link connector

Resistance: Approximately  $0\Omega$

2) Harness connector for injector

3) "BR" fusible link

**D** 4) Safety relay

12V direct current is applied between terminals (1) and (2)		Continuity between terminals (2) and (3)
(1)	(2)	
-	+	Yes
+	-	No

O.K. ↓

**CHECK GROUND CIRCUIT.**

1) Disconnect 15-pin connector from E.C.U.

2) Check resistance between terminals (107), (109), (112), (113) and ground.

Resistance: Approximately  $0\Omega$

**B**

**CHECK GROUND CIRCUIT.**

1) Disconnect 15-pin connector from E.C.U.

2) Check resistance between terminals (107), (109), (112), (113) and ground.

Resistance: Approximately  $0\Omega$

N.G. ↓

**E**

Check resistance of individual injectors.

- Disconnect injector harness connector.

Resistance: Approximately  $1.5\Omega$

N.G. ↓

Replace injector.

N.G. →

Check engine ground and harness continuity between E.C.U. and engine ground.

O.K. ↓

Reinstall any part removed.


**INSPECTION END**



# ELECTRONIC CONTROL SYSTEM INSPECTION

INJECTOR (Not self-diagnostic item)

## POWER SOURCE & GROUND CIRCUIT FOR E.C.U. (Not self-diagnostic item)



Check resistance of individual injectors  
 Disconnect injector harness connector  
 Resistance: Approximately 1.5Ω  
 N.G.



Replace injector.

Check engine ground and harness continuity between E.C.U. and engine ground

**CHECK GROUND CIRCUIT.**  
 1) Disconnect 18-pin connector from E.C.U.  
 2) Check resistance between terminals (107, 109, 112) and ground.  
 Resistance: Approximately 0Ω  
 O.K.





Reinstall any part removed.

**INSPECTION END**



# ELECTRONIC CONTROL SYSTEM INSPECTION

## POWER SOURCE & GROUND CIRCUIT FOR E.C.U. (Not self-diagnostic item)






# ELECTRONIC CONTROL SYSTEM INSPECTION

POWER SOURCE & GROUND CIRCUIT FOR E.C.U. (Not self-diagnostic item)




## A.I.V. CONTROL SOLENOID VALVE (Not self-diagnostic item)



SEF170G

# ELECTRONIC CONTROL SYSTEM INSPECTION

## A.I.V. CONTROL SOLENOID VALVE (Not self-diagnostic item)



INSPECTION START

**A**  
**CHECK POWER SOURCE.**  
 1) Turn ignition switch "ON".  
 2) Check voltage terminal (b) and ground.  
**Battery voltage should exist.**

N.G. → Check the following items.  
 1) Harness continuity between A.I.V. solenoid valve and battery  
 2) "BR" fusible link  
 3) Main relay (Refer to EL section.)

O.K. ↓

**B**  
 1) Start engine and warm it up sufficiently.  
 2) Check voltage between E.C.U. terminal (14) and ground.

N.G. → Check the following items.  
**C** 1) Harness continuity between E.C.U. terminal (14) and A.I.V. solenoid valve harness connector.  
 2) Stop engine.  
 3) Disconnect A.I.V. solenoid valve harness connector.  
 4) Disconnect 20-pin connector from E.C.U.  
 5) Check resistance between terminal (a) and E.C.U. terminal (14).  
**Resistance:**  
**Approximately 0Ω**  
 6) A.I.V. solenoid valve  
**Check resistance:**  
**Approximately 40Ω**  
 7) Ground circuit of E.C.U. (See page EF & EC-122.)

Accelerator pedal position	Voltage
Released	Approximately 0.8V
Depressed	Battery voltage

O.K. ↓

**CHECK GROUND CIRCUIT.**  
 Check ground circuit for E.C.U. (See page EF & EC-122.)


Reinstall any part removed.

INSPECTION END






# ELECTRONIC CONTROL SYSTEM INSPECTION

## E.G.R. CONTROL SOLENOID VALVE (Not self-diagnostic item); NON-CALIFORNIA MODEL







- Check the following items.
- 1) Start engine and warm it up sufficiently.
  - 2) Check voltage between E.C.U. terminal (18) and ground.
  - 3) Check voltage between E.C.U. terminal (7) and E.C.U. terminal (8).
- Approximately 0.2Ω
- Approximately 40Ω
- Approximately 40Ω
- Stop engine.
  - Disconnect A.I.V. solenoid valve harness connector.
  - Disconnect 20-pin connector from E.C.U.
  - Check resistance between terminal (18) and E.C.U. terminal (8).
  - Check resistance between terminal (7) and E.C.U. terminal (8).



# ELECTRONIC CONTROL SYSTEM INSPECTION

## E.G.R. CONTROL SOLENOID VALVE (Not self-diagnostic item); NON-CALIFORNIA MODEL






# ELECTRONIC CONTROL SYSTEM INSPECTION





E.G.R. CONTROL SOLENOID VALVE (Not self-diagnostic item); NON-CALIFORNIA MODEL

## IDLE-UP SOLENOID VALVE (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION


## IDLE-UP SOLENOID VALVE (Not self-diagnostic item)






# ELECTRONIC CONTROL SYSTEM INSPECTION

## A.A.C. VALVE (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## A.A.C. VALVE (Not self-diagnostic item)



INSPECTION START

**A**

**CHECK POWER SOURCE.**


- 1) Disconnect A.A.C. valve harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal ① and ground.

**Voltage: Battery voltage**

N.G.

Check the following items.

- 1) Harness continuity between battery and A.A.C. valve.
- 2) "BR" fusible link
- 3) Main relay (Refer to EL section.)



**B**

**CHECK GROUND CIRCUIT.**


- 1) Turn ignition switch "OFF" and disconnect E.C.U. 20-pin connector.
- 2) Check resistance between terminal ① and E.C.U. terminal ②.

**Resistance: Approximately 0Ω**

N.G.

Repair harness.

Resistance: Approximately 0Ω



**C**


**CHECK INPUT SIGNAL.**

- 1) Reconnect E.C.U. 20-pin connector and A.A.C. valve harness connector.
- 2) Start engine and warm it up sufficiently.
- 3) Check voltage between E.C.U. terminal ② and ground.

**Voltage: Approximately 6 - 8V (at idle)**

N.G.

Check A.A.C. valve. Check resistance of A.A.C. valve. Continuity should exist.




O.K.

INSPECTION END





# ELECTRONIC CONTROL SYSTEM INSPECTION

## NEUTRAL/INHIBITOR SWITCH (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## NEUTRAL/INHIBITOR SWITCH (Not self-diagnostic item)



INSPECTION START

**A** CHECK INPUT SIGNAL.

- 1) Turn ignition switch "ON".
- 2) Check voltage between E.C.U. terminal ⑩ and ground.

Gear position	Voltage
Neutral/Park	0V
Others	Battery voltage

O.K.

INSPECTION END

- 1) Turn ignition switch to "OFF".
- 2) Connect pressure regulator control solenoid.
- 3) Turn ignition switch to "START".
- 4) Check voltage between E.C.U. terminal ⑬ and ground.  
Voltage: Approximately 0.9V

O.K.

CHECK GROUND CIRCUIT.  
Check ground circuit for E.C.U.  
(See page EF & EC-122.)

Reinstall any part removed.

INSPECTION END

N.G.

Check the following items.

- 1) Power source & ground circuit for E.C.U.  
(See page EF & EC-122.)
- 2) Main relay  
(Refer to EL section.)
- 3) Harness continuity between battery and E.C.U.
- 4) Harness continuity between E.C.U. and Neutral switch.

**B** 5) Check resistance Neutral/Inhibitor switch and ground.

**Resistance:**  
Approximately 0Ω

- Disconnect pressure regulator control solenoid valve harness connector.
- Disconnect 20-pin connector from E.C.U.
- Check resistance between terminal ⑫ and E.C.U. terminal ⑬.  
**Resistance:**  
Approximately 0Ω

2) Pressure regulator control solenoid valve  
Check resistance.  
Approximately 40Ω


- 3) Ground circuit for E.C.U.  
(See page EF & EC-122.)



# ELECTRONIC CONTROL SYSTEM INSPECTION





NEUTRAL INHIBITOR SWITCH (Not self-diagnostic item)

## P.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION


## P.R. CONTROL SOLENOID VALVE (Not self-diagnostic item)








# ELECTRONIC CONTROL SYSTEM INSPECTION

## AIR REGULATOR (Not self-diagnostic item)



# ELECTRONIC CONTROL SYSTEM INSPECTION

## AIR REGULATOR (Not self-diagnostic item)



INSPECTION START

**A**  
**CHECK POWER SOURCE.**  
 1) Disconnect air regulator harness connector.  
 2) Turn ignition switch "ON".  
 3) Check voltage between terminal **b** and ground.  
**Battery voltage should exist.**

N.G.  
 Check the following items.  
 1) Harness continuity between battery and air regulator.  
 2) Fuse



O.K.  
**B**  
**CHECK OUTPUT SIGNAL.**  
 1) Turn ignition switch "OFF".  
 2) Connect air regulator harness connector.  
 3) Turn ignition switch "START".  
 4) Check voltage between E.C.U. terminal **16** and ground.  
**0.6 to 0.9V should appear for 5 seconds after turning ignition switch "START".**

N.G.  
 1) Check harness continuity between E.C.U. and air regulator.  
**C** 2) Check air regulator.  
 • Disconnect air regulator harness connector.  
 • Check resistance between terminals **a** and **b**.  
**Resistance:**  
**Approximately 70Ω**  
 3) Check power source for E.C.U.

O.K.  
**CHECK GROUND CIRCUIT.**  
 Check ground circuit for E.C.U.  
 (See page EF & EC-122.)





Reinstall any part removed.

INSPECTION END





# E.C.U. INPUT/OUTPUT SIGNAL INSPECTION



## MEASUREMENT VOLTAGE OR RESISTANCE OF E.C.U.

1. Disconnect battery ground cable.
2. Disconnect 20- and 16-pin connectors from E.C.U.
3. Remove pin terminal retainer from 20- and 16-pin connectors to make it easier to insert tester probes.
4. Connect 20- and 16-pin connectors to E.C.U. carefully.
5. Connect battery ground cable.
6. Measure the voltage at each terminal by following "E.C.U. inspection table".

## CAUTION:

- a. Perform all voltage measurements with the connectors connected.
- b. Perform all resistance measurements with the connectors disconnected.
- c. Make sure that there is not any bend or break on E.C.U. pin terminal before measurements.
- d. Do not touch tester probes between terminals ⑳ and ㉘, ㉙ and ㉚.

# E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

E.C.U. inspection table

\*Data are reference values.

TERMI- NAL NO.	ATAQ*ITEM ITEM	NOITION CONDITION	ATAQ ITEM *DATA	JAL NO.
1	Throttle valve switch	Engine is running and gear position is in P or N (A/T).	0.1 - 0.4V	8
2	Idle-up solenoid valve (VG30E)	<ul style="list-style-type: none"> <li>— For about 20-seconds after starting engine</li> <li>— Steering wheel is turned.</li> <li>— Blower and air conditioner switches are "ON".</li> <li>— Lighting switch is "ON".</li> </ul>	0.1 - 0.4V	9
10	BATTERY VOLTAGE	<ul style="list-style-type: none"> <li>Engine is running.</li> <li>— Except the conditions shown above</li> </ul>	BATTERY VOLTAGE (11 - 14V)	10
20	A.A.C. valve (VG30ET)	<ul style="list-style-type: none"> <li>Engine is running.</li> <li>— Idle speed (after warm-up)</li> </ul>	6.0 - 8.0V	11
3	Ignition check	<ul style="list-style-type: none"> <li>Engine is running.</li> <li>— Idle speed</li> </ul>	9 - 12V (Decreases as engine is revved up.)	12
22	E.G.R. control solenoid valve	<ul style="list-style-type: none"> <li>Engine is running after being warmed up.</li> <li>— High engine revolution</li> <li>— Idle speed (Throttle valve switch "ON".)</li> </ul>	Approximately 1.0V	13
23	Ignition signal	<ul style="list-style-type: none"> <li>Engine is running.</li> <li>— Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)	14
24	Exhaust gas sensor	<ul style="list-style-type: none"> <li>Engine is running.</li> <li>— Engine speed is 2,000 rpm.</li> </ul>	0.4 - 0.6V	15
25	Idle switch (-) side	<ul style="list-style-type: none"> <li>Engine is running.</li> </ul>	1.2 - 1.5V	16
26	Power source for E.C.C.S. relay-1 (Main relay)	<ul style="list-style-type: none"> <li>Ignition switch "OFF"</li> <li>— For approximately 8 seconds after turning ignition switch "OFF"</li> </ul>	0.7 - 0.9V	17
27	E.C.C.S. relay-1 (Main relay)	<ul style="list-style-type: none"> <li>Ignition switch "OFF"</li> <li>— Within approximately 8 seconds after turning ignition switch "OFF"</li> </ul>	BATTERY VOLTAGE (11 - 14V)	18



## E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

\*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA	TERMI- NAL NO.
8	Crank angle sensor (Position signal)	Engine is running. Do not run engine at high speed under no-load.	2.5 - 2.7V	
9	Start signal	Cranking	8 - 12V	
10	Neutral switch (M/T) Inhibitor switch (A/T)	Ignition switch "ON" └ Gear position is in Neutral or Parking.	0V	3
		Ignition switch "ON" └ Any gear position except Neutral or Parking	BATTERY VOLTAGE (11 - 14V)	
12	Air flow meter burn-off signal	Engine revolution is above 1,500 rpm and vehicle speed is more than 20 km/h (12MPH). ↓ Ignition switch "OFF" └ For 6 seconds after turning ignition switch "OFF"	0V	4
		Engine revolution is above 1,500 rpm and vehicle speed is more than 20 km/h (12 MPH). ↓ Ignition switch "OFF" └ For 1 second after the above 6 seconds have passed.	9.0 - 10.0V	
14	A.I.V. control solenoid valve	Ignition switch "ON" └ Release accelerator pedal, (Throttle valve switch "ON")	0.7 - 0.9V	5
		Ignition switch "ON" └ Depress accelerator pedal, (Throttle valve switch "OFF")	BATTERY VOLTAGE (11 - 14V)	
15	Fuel temperature sensor	Engine is running. └ Idle speed	0.5V Output voltage varies with engine temperature.	8
16	Air regulator	Engine is running.	0.6 - 0.9V	
17	Crank angle sensor (Reference signal)	Engine is running. Do not run engine at high speed under no-load.	0.2 - 0.4V	

# E.C.U. INPUT/OUTPUT SIGNAL INSPECTION

\*Data are reference values.




TERMI- NAL NO.	ATAQ ITEM	CONDITION	*DATA
18	Throttle valve switch (⊖ side)	Ignition switch "ON" — Release accelerator pedal. (Throttle valve switch "OFF")	9.0 - 10.0V
		Ignition switch "ON" — Depress accelerator pedal. (Throttle valve switch "ON")	0V
19	Pressure regulator control solenoid valve	Stop and restart engine after warming it up. — For 30 seconds	0.8 - 1.0V
		Stop and restart engine after warming it up. — After 3 minutes	BATTERY VOLTAGE (11 - 14V)
20	Fuel pump relay	Engine is running.	BATTERY VOLTAGE (11 - 14V)
22	Load signal	Engine is running and gear position is in P or N (A/T). — Steering wheel is turned. — Blower and air conditioner switches are "ON". — Lighting switch is "ON".	BATTERY VOLTAGE (11 - 14V)
		Engine is running. — Except conditions shown above	0V
23	Cylinder head temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine temperature.
24	Exhaust gas sensor	Engine is running. — After warming up sufficiently	0 - Approximately 1.0V
25	Idle switch (⊕ side)	Ignition switch "ON"	9.0 - 10.0V
27 35	Power source for E.C.U.	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
29	Vehicle speed sensor	Ignition switch "ON" — While rotating rear wheel slowly	0 or 7.4V

INSPECTION END



TERMI- NAL NO.	ATAQ* ITEM	CONDITION	MEITI* DATA	TERMI- NAL NO.
8 30	Exhaust gas temperature sensor (Only for California model)	Engine is running. Idle speed	1.0V or more	
9	Start signal	Engine is running. E.G.R. system is operating.	0 - 1.0V	
31	Air flow meter	Engine is running. Do not run engine at high speed under no-load.	2.0 - 4.0V Output voltage varies with engine re- volution and throttle valve movement.	
34	Ignition switch signal	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	
101 102 103 104 105 106 114	Injector	Engine is running.	BATTERY VOLTAGE (11 - 14V)	
108	Fuel pump	Ignition switch "ON" For 5 seconds after turning ignition switch "ON".	0.1 - 0.3V	
		Ignition switch "ON" After 5 seconds have passed	9 - 14V	
110	Throttle sensor (Only for California model)	Ignition switch "ON"	0.4 - 4.0V	
115	Exhaust gas sensor heater	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	

**VG30 PIN CONNECTOR TERMINAL LAYOUT**



# MIXTURE RATIO FEEDBACK SYSTEM INSPECTION

## PREPARATION

1. Make sure that the following parts are in good order.

- Battery
- Ignition system
- Engine oil and coolant levels
- Fuses
- E.C.U. harness connectors
- Vacuum hoses
- Air intake system (oil filler cap, oil level gauge, etc.)
- Fuel pressure
- A.I.V. hose
- Engine compression
- E.G.R. valve operation
- Throttle valve

2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".

3. On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "D" position.

4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.

5. Turn off headlamps, heater blower, rear defogger (if equipped).

6. Keep front wheels pointed straight ahead (if equipped with power steering).

7. Make the check after the radiator cooling fan has stopped.


### WARNING:

a. When selector lever is shifted to "D" position, apply parking brake and block both front and rear wheels with chocks.

b. Depress brake pedal while racing the engine to prevent forward surge of vehicle.

c. After the adjustment has been made, shift the lever to the "N" or "P" position and remove wheel chocks.

## Overall inspection sequence






## Idle Check and Set Procedure

INSPECTION START

Visually check the following:

- Air cleaner clogging
- Hoses and ducts for leaks
- E.G.R. valve operation
- Electrical connectors
- Gaskets
- Idle switch operation
- A.I.V. hose




Start engine and warm up until water temperature indicator points to the middle of gauge.

Run engine at about 2,000 rpm for about 2 minutes under no-load.



Perform E.C.C.S. self-diagnosis.



O.K.

N.G.


Repair or replace components as necessary.

Does engine run smoothly?

Yes

No

Clean injectors.



SEF644B

VG30E only  
Stop engine and disconnect idle-up solenoid valve harness connector. Start engine.

Race engine two or three times under no-load and run engine for about one minute at idle speed.



Check ignition timing.

VG30E:  $20^{\circ} \pm 2^{\circ}$  B.T.D.C.  
VG30ET:  $15^{\circ} \pm 2^{\circ}$  B.T.D.C.

O.K.


N.G.

Adjust ignition timing by turning distributor after loosening bolt which secures distributor.

A


B

# MIXTURE RATIO FEEDBACK SYSTEM INSPECTION





Idle Check and Set Procedure



Check whether green and red inspection lamps on E.C.U. flash simultaneously.

N.G. O.K.

Connect idle switch harness connector.

INSPECTION END

Check exhaust gas sensor harness:

- 1) Turn off engine and disconnect battery ground cable.
- 2) Disconnect 16-pin connector from E.C.U.
- 3) Disconnect exhaust gas sensor harness connector and connect main harness side terminal for exhaust gas sensor to ground with a jumper wire.
- 4) Check for continuity between terminal No. 24 of 16-pin connector and body ground.

Continuity exists ..... O.K.  
Continuity does not exist ..... N.G.

Repair or replace harness.





Connect 16-pin connector to E.C.U.

- Disconnect cylinder head temperature sensor harness connector.
- Connect a resistor (2.5 kΩ) between terminals of cylinder head temperature sensor harness connector.


Connect battery ground cable, start engine and warm it up until water temperature indicator points to middle of gauge.

Race engine two or three times under no-load, then run engine at idle.

# MIXTURE RATIO FEEDBACK SYSTEM INSPECTION







## Releasing Fuel Pressure

### WARNING:

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


1. Remove fuse for fuel pump.

2. Start engine.

3. After engine stalls, crank engine two or three times to make sure that pressure is released.

4. Turn ignition switch off and install the fuse.


Erase the memory (Code No. 22) of the self-diagnosis in E.C.C.S. control unit.



## Fuel Pressure Check

a. Tighten the clamp so its end is 3 mm (0.12 in) from the hose end.

b. Make sure that the screw of the clamp does not contact with any adjacent parts.



 : Fuel hose clamps

1.0 - 1.5 N·m

(0.10 - 0.15 kg·m, 0.7 - 1.1 ft·lb)

c. Disconnect pressure regulator control solenoid valve harness connector.

d. Use Pressure Gauge to check fuel pressure.



1. Release fuel pressure to zero.

2. Disconnect fuel hose between fuel filter and fuel tube (engine side).

3. Install pressure gauge between fuel filter and fuel tube.

# FUEL SYSTEM INSPECTION

## Fuel Pressure Check (Cont'd)

- Start engine and check for fuel leakage.
- Read the indication of fuel pressure gauge.

**At idling:**

Approximately 206 kPa  
(2.1 kg/cm<sup>2</sup>, 30 psi)

**The moment accelerator pedal is fully depressed:**

[VG30E]


Approximately 255 kPa  
(2.6 kg/cm<sup>2</sup>, 37 psi)

[VG30ET]


Approximately 304 kPa  
(3.1 kg/cm<sup>2</sup>, 44 psi)

- Stop engine and disconnect fuel pressure regulator vacuum hose from intake collector.
- Plug intake collector with a rubber cap.
- Connect a handy vacuum pump to fuel pressure regulator.

- Jump No. 108 connector of E.C.U. to body ground.



- Turn ignition switch to "ON" and read the indication of fuel pressure gauge as vacuum is changed.




Vacuum kPa (mmHg, inHg)	Fuel pressure kPa (kg/cm <sup>2</sup> , psi)
0 (0, 0)	248.1 - 255.0 (2.53 - 2.60, 36.0 - 37.0)
16.9 (127, 5.00)	227.5 - 241.3 (2.32 - 2.46, 33.0 - 35.0)
33.9 (254, 10.00)	213.8 - 220.7 (2.18 - 2.25, 31.0 - 32.0)
50.8 (381, 15.00)	200.1 - 206.9 (2.04 - 2.11, 29.0 - 30.0)
67.7 (508, 20.00)	179.5 - 193.2 (1.83 - 1.97, 26.0 - 28.0)

- Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.





# FUEL SYSTEM INSPECTION

## Fuel Pressure Check (Cont'd)





## Injector Removal and Installation


1. Release fuel pressure to zero.
2. Disconnect the following from intake collector, from fuel line
  - Air duct
  - Accelerator wire
  - Blow-by hoses
  - Air regulator hose
  - E.G.R. tube
  - Harness clamps
  - Harness connectors
  - Intake collector cover
  - Water hoses
3. Disconnect fuel hoses.
4. Remove intake collector.



5. Remove bolts securing fuel tube.
6. Remove bolts securing injectors and remove injectors, fuel tubes and pressure regulator as an assembly.



7. Remove fuel hose.
  - 1) Heat sharp knife for 15 minutes. Cut into hose braided reinforcement from mark to socket end and fuel tube end. **Do not allow sharp knife to cut all the way through the hose and touch injector tail piece.**
  - 2) Then pull rubber hose out with hand. **Never place injector in a vise when disconnecting rubber hose.**



8. Install fuel hose as follows:
  - 1) Clean exterior of injector tail piece and fuel tube end.
  - 2) Wet inside of new rubber hose with fuel.
  - 3) Push end of rubber hose with hose sockets onto injector tail piece and fuel tube end by hand as far as they will go.

Clamp is not necessary at the connections.


### CAUTION:

After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage.

Inspection (Cont'd)

Disassembly and Assembly

- Turbocharger should not be disassembled.
- Turbocharger should be removed after engine removal.
- Always replace turbocharger as an assembly if damaged.



Inspection

Condition 1: Low engine power

Probable cause

Corrective action

Air leak at the connection of compressor housing and suction hose/inlet tube, or inlet tube and intake manifold.	Correct the connection.
Exhaust gas leak at the connection of turbine housing and exhaust manifold, connecting tube or exhaust outlet	Correct the connection or replace gasket.
By-pass valve is stuck open.	Replace turbocharger assembly.
Stuck or worn journal or bearing	
Broken shaft	
Sludge on back of turbine wheel	
Broken turbine wheel	



# TURBOCHARGER INSPECTION

## Inspection (Cont'd)

Condition 2: Excessively high engine power

Probable cause

Corrective action

Disconnected or cracked rubber hose on by-pass valve.

Correct or replace rubber hose.

By-pass valve is stuck closed.

Replace turbocharger assembly.

Controller diaphragm is broken.

Condition 3: Excessively high oil consumption or exhaust shows pale blue smoke

Probable cause

Corrective action

Oil leak at the connection of lubricating oil passage


Correct the connection.

Oil leak at oil seal of turbine

Replace turbocharger assembly.

Oil leak at oil seal of compressor

Worn journal or bearing




1. Inspect turbine and compressor wheel as follows:

- Visually check for cracks, clogging, deformity or other damage.
- Revolve wheels to make sure that they turn freely without any abnormal noise or friction.
- Measure play in axial direction.

Play (axial direction):

0.013 - 0.091 mm (0.0005 - 0.0036 in)



2. Check operation of by-pass valve controller.

- Move by-pass valve to make sure that it is not sticking or scratched.
  - Measure rod end play of the by-pass valve controller.
- Do not apply more than 66.7 kPa (500 mmHg, 19.69 inHg) pressure to controller diaphragm.


By-pass valve controller stroke/pressure:

0.38 mm (0.0150 in)/35.2 - 40.5 kPa

(264 - 304 mmHg, 10.39 - 11.97 inHg)

# EVAPORATIVE EMISSION CONTROL SYSTEM

## Description



SEF370G

The evaporative emission control system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.


The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.

## Inspection CARBON CANISTER

Check carbon canister as follows.

- (A) : Blow air and ensure that there is no leakage.
- (B) : Blow air and ensure that there is leakage.



SEF371G




# EVAPORATIVE EMISSION CONTROL SYSTEM

## Inspection (Cont'd)


### FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.
2. Inhale air through the cap. A slight resistance accompanied by valve clicks indicates that valve is in good mechanical condition. Note also that, by further inhaling air, the resistance should be disappeared with valve clicks.
3. If valve is clogged, or if no resistance is felt, replace cap as an assembly.



### FUEL CHECK VALVE


1. Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow be directed toward the canister.
2. Blow air through connector on the canister side. Air flow should be smoothly directed toward fuel tank.
3. If fuel check valve is suspected of not being properly functioning in steps 1 and 2 above, replace it.



### VAPOR VENT LINE


1. Check hoses and fuel tank filler cap.
2. Disconnect the vapor vent line connecting carbon canister to fuel tank.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running. The canister retains the fuel vapor until the canister is purged by the fresh air that flows into the intake manifold.





3. Connect a 3-way connector, a manometer and a cock (or an equivalent 3-way charge cock) to the end of the vent line.
4. Supply fresh air into the vapor vent line through the cock little by little until pressure becomes 3.923 kPa (400 mmH<sub>2</sub>O, 15.75 inH<sub>2</sub>O).
5. Shut the cock completely and leave it unattended.
6. After 2.5 minutes, measure the height of the liquid in the manometer.
7. Variation in height should remain at 0.245 kPa (25 mmH<sub>2</sub>O, 0.98 inH<sub>2</sub>O).
8. When filler cap does not close completely, the height should drop to zero in a short time.
9. If the height does not drop to zero in a short time when filler cap is removed, the cause is a blocked hose or a clogged fuel check valve.


In case the vent line is blocked, the fuel tank is not vented properly causing insufficient deliver of fuel to engine, or vapor lock. It must, therefore, be repaired.




SEC711



SEF698B



SEF792B




SEC327

## E.G.R. SYSTEM

Ensure that E.G.R. system is functioning properly by placing your finger on E.G.R. control valve diaphragm. Make sure that E.G.R. control valve operates as follows.

Conditions	E.G.R. control solenoid	E.G.R. system
① Engine starting		
② Throttle valve switch "ON"		
③ Low engine temperature	ON	Does not operate
④ High engine temperature		
⑤ High engine speed		
⑥ With heavy load		
Except above	OFF	Operates



## E.G.R. CONTROL SOLENOID VALVE

1. Check the solenoid valve for electric continuity, after disconnecting the harness connector.

Resistance: 30 - 40Ω

2. Check the solenoid valve for normal operation as shown.

### CAUTION:

- Be sure to connect ⊕ terminal of battery with white harness of solenoid valve.
- Perform E.G.R. circuit test. (See pages EF & EC-100, 126.)
- Perform E.C.U. input/output test. (See page EF & EC-138.)

## E.G.R. CONTROL VALVE





1. Supply the E.G.R. control valve with vacuum using a handy vacuum pump.
2. Place a finger on the diaphragm of the valve, and make sure that the diaphragm lifts up and down in response to the vacuum leading to the valve.

Full open of E.G.R. valve:

Over -16.0 kPa  
(-120 mmHg, -4.72 inHg)



# CRANKCASE EMISSION CONTROL SYSTEM



## Inspection (Cont'd)

### Description

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon. The vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the purge line to the intake manifold when the engine is running. When the engine is at idle, the purge control valve is closed.

Only a small amount of purged air flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher the purge control valve opens and the vapor is drawn into the intake manifold through both the purge orifice and the constant purge orifice.




## Inspection

### P.C.V. VALVE

With engine running at idle, remove ventilation hose from P.C.V. valve; if valve is working properly a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.

### VENTILATION HOSE


1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



**VISUAL CHECK**

Check the hoses and tubes for loosening, flattening damage or faulty connections, and each part for proper installation.

- Replace, if necessary.





**A.I.V. CONTROL SOLENOID**

Subject the solenoid valve to independent inspection, after disconnecting the harness connector and all the vacuum hoses.

- 1) Check it for electric continuity.

**Resistance: Approximately 40Ω**




- 2) Check the solenoid valve for normal operation. Supply it with battery voltage, and check whether there is continuity between ports A, B and C.

		Solenoid valve	
		OFF	ON
Item	Continuity	B-C	A-B

**CAUTION: Torque**

- Be sure to connect ⊕ terminal of battery with white harness of solenoid valve.
- Perform A.I.V. circuit test. (See page EF & EC-124.)
- Perform E.C.U. input/output test. (See page EF & EC-138.)







**A.I.V. UNIT**

1. Disconnect vacuum hose leading to vacuum motor and set a handy vacuum pump there.
2. Disconnect hose between A.I.V. unit and air cleaner.
3. Subject A.I.V. unit to inspection in the following way.  
Connect suitable hose to A.I.V. unit and try to blow A.I.V. unit through the hose, when vacuum is lead to vacuum motor and when no vacuum exists.

	Vacuum	No vacuum	Parts condition
Can you blow?	Yes	No	O.K.
	No	Yes	N.G.



4. If the inspection shows N.G., disassemble the A.I.V. case and check such parts as the reed valve, the vacuum motor, and the connecting hoses.



# SERVICE DATA AND SPECIFICATIONS (S.D.S.)

## General Specifications

<b>Fuel pump</b>	
Cut-off discharge pressure kPa (kg/cm <sup>2</sup> , psi)	422 - 490 (4.3 - 5.0, 61 - 71)
<b>Pressure regulator</b>	
Regulated pressure kPa (kg/cm <sup>2</sup> , psi)	250 (2.55, 36.3)
<b>Air regulator</b>	
Air flow amount [at 20°C (68°F)] m <sup>3</sup> (cu ft)/hr	14.5 (512)

## Inspection and Adjustment

Item	
<b>Fuel pressure</b>	
At idle kPa (kg/cm <sup>2</sup> , psi)	Approximately 206 (2.1, 30)
The moment accelerator pedal is fully depressed kPa (kg/cm <sup>2</sup> , psi)	
VG30E	Approximately 255 (2.6, 37)
VG30ET	Approximately 304 (3.1, 44)
<b>Air flow meter</b>	
Voltage between terminals B and D	2 - 4V

Item	
<b>Cylinder head temperature sensor and fuel temperature sensor</b>	
Thermistor resistance at 20°C (68°F)	2.3 - 2.7 kΩ
at 50°C (122°F)	0.77 - 0.87Ω
at 80°C (176°F)	0.30 - 0.33Ω
<b>Idle switch</b>	
Engine speed when idle switch is turned from "OFF" to "ON"	Idle speed + 250 rpm allowance: ±150 rpm
<b>Dash pot</b> rpm	
Touch speed	VG30E: 2,200 - 2,800 VG30ET (M/T model only): 2,200 - 2,800

## Tightening Torque

Unit	N·m	kg·m	ft·lb
Throttle chamber securing bolt	18 - 22	1.8 - 2.2	13 - 16
Intake collector cover bolt	6 - 8	0.6 - 0.8	4.3 - 5.8
Intake collector bolt	18 - 22	1.8 - 2.2	13 - 16
Cylinder head temperature sensor	12 - 16	1.2 - 1.6	9 - 12
<b>Exhaust gas sensor</b>			
(VG30E)	40 - 50	4.1 - 5.1	30 - 37
(VG30ET)	18 - 24	1.8 - 2.4	13 - 17
E.G.R. control valve	18 - 23	1.8 - 2.3	13 - 17
E.G.R. tube	34 - 44	3.5 - 4.5	25 - 33
Fuel hose clamp	1.0 - 1.5	0.10 - 0.15	0.7 - 1.1