

STEERING SYSTEM



SECTION ST

CONTENTS

STEERING SYSTEM	ST- 2
STEERING COLUMN	ST- 4
POWER STEERING SYSTEM — Checking	ST- 6
POWER STEERING GEAR AND LINKAGE	ST- 8
POWER STEERING OIL PUMP	ST-18
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	ST-21
SPECIAL SERVICE TOOLS	ST-24


Refer to section MA for:

CHECKING WHEEL ALIGNMENT

- Toe-in
- Front wheel turning angle

BASIC MECHANICAL SYSTEM

- Checking drive belts





ST

STEERING SYSTEM

- Fully turn steering wheel to the right and disconnect whole hydraulic line to steering gear assembly, then remove steering gear.
- Whenever disconnecting hydraulic lines, cover openings to prevent foreign material from entering.
- Be careful not to damage hydraulic line connection.
- Do not reuse O-ring in hydraulic system.
- When connecting hydraulic line, apply a coat of automatic transmission fluid "Dexron Type" to O-rings.
- If disconnecting hydraulic line, always perform leak test and bleed air from line after filling it with oil.
- After properly installing steering gear and linkage, check wheel alignment. Refer to section MA.


49 - 59
(5.0 - 6.0,
36 - 43)



Remove steering wheel using Tool.
Install steering wheel on column shaft in a straight-ahead position.

⊗ : N·m (kg·m, ft·lb)

STEERING SYSTEM



SFA372

- Detach tie-rod ball-studs from knuckle arms with Tool.

54 · 98
(5.5 · 10.0, 40 · 72)

Cylinder tube flare nut

20 · 26
(2.0 · 2.7, 14 · 20)

27 · 39
(2.8 · 4.0, 20 · 29) *



39 · 49
(4.0 · 5.0, 29 · 36)

(A)

Cylinder tube flare nut
 20 · 26
(2.0 · 2.7, 14 · 20)

High-pressure pipe to steering gear

15 · 25 (1.5 · 2.5, 11 · 18) *

Toe-in adjustment

- When adjusting toe-in, be careful not to twist boots.
- Toe-in: Refer to MA section.

Steering gear (PR24S)

Retainer adjusting screw

78 · 98
(8.0 · 10.0, 58 · 72)

Oil pressure switch
(Non-turbocharged model)

16 · 24
(1.6 · 2.4, 12 · 17) *

When hydraulic line pressure is above 1,961 · 2,550 kPa (20 · 26 kg/cm², 284 · 370 psi), switch is conductive.

: N·m (kg-m, ft-lb)

: Grease-up points

: Do NOT reuse.


: O-ring type connector

SST078B

STEERING COLUMN


- Fully turn steering wheel to the right and disconnect whole hydraulic line to steering gear assembly, then remove steering column.
- Never in any case should undue stress be applied to steering column in axial direction.
- When installing, do not apply bending force to steering column.
- Be careful not to lose sliding plate.
- When the vehicle comes into light collision, check dimension "L", between steering column upper end and jacket tube crashable area.
- Column length "L" = 478.7 mm - 480.3 mm (18.85 - 18.91 in)
(Measure "L" at neutral position of steering column if equipped with tilt mechanism)
- Check steering column for smooth rotation without binding and noise. If it does not rotate smoothly, check as follows:

Non-tilt Type Column




STEERING COLUMN

Tilt Type Column



- : N·m (kg·m, ft·lb)
- : Grease-up points
- (A) : Do not reuse.



POWER STEERING SYSTEM — Checking

Fluid Level Check

Check the fluid level when the fluid is cold.
Refer to MA section.

Power Steering Pump Belt Tension

Refer to MA section.

Fluid Leakage Check

1. Run engine at idle speed or 1,000 rpm.
Make sure temperature of fluid in tank rises to 60 to 80°C (140 to 176°F).
2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each "lock" position for five seconds and carefully check for fluid leakage.

CAUTION:

- Do not hold steering wheel at "lock" position for more than 15 seconds at a time.
- If fluid leaks at connectors, replace O-ring (if equipped). Do not overtighten connector as this can damage O-ring and connector.


Bleeding Hydraulic System

1. Raise front end of vehicle until wheels clear ground.
2. While adding fluid, quickly turn steering wheel fully to right and left and lightly touch steering stoppers.
Repeat steering wheel operation until fluid level no longer decreases.
3. Start engine.
Repeat step 2 above.

Hydraulic System Check

Before starting, check belt tension, driving pulley and tire pressure. (Refer to MA section.)

1. Set Tool. Open shut off valve. Then bleed air. (See "Bleeding Hydraulic System".)



2. Run engine.
Make sure temperature of fluid in tank rises to 60 to 80°C (140 to 176°F).
3. Check pressure with steering wheel fully turned to left and right position.

CAUTION:

Do not hold steering wheel at lock position for more than 15 seconds.

Oil pump maximum pressure:

6,669 - 7,257 kPa

(68 - 74 kg/cm², 967 - 1,052 psi) at idling

4. If oil pressure is below the standard, slowly close shut-off valve and check pressure.
 - If pressure raises to standard, gear is damaged.
 - If pressure remains below standard, pump is damaged.
Gear may be damaged.
5. If oil pressure is above the standard, pump may be damaged.

CAUTION:

Do not close shut-off valve for more than fifteen seconds.

6. After checking hydraulic system, remove Tool and add fluid as necessary, then completely bleed air out of system.


POWER STEERING SYSTEM — Checking

Turning Force Check

1. Park vehicle on a level, dry surface and set parking brake.
2. Bring power steering fluid up to adequate operating temperature. [Temperature of fluid is approximately 60 to 80°C (140 to 176°F)].
 - Tires must be inflated to normal pressure.
3. Check steering wheel turning force when steering wheel has been turned 360° from neutral position with engine running.

Steering wheel turning force:

39.2 N (4.0 kg, 8.8 lb) or less



Steering Wheel Play Adjustment

Steering wheel axial play:

0 mm (0 in)

Steering wheel play:


35 mm (1.38 in) or less

If steering wheel play is not within specifications, check condition of column shaft and tie-rod ball joints. If they are in good order, adjust rack retainer.

Rack retainer adjustment:

- a) Adjust only when steering wheel play does not meet specifications.
- b) Prior to adjustment, completely loosen adjustment screw, clean old locking sealer and apply new locking sealer.

Tighten the screw to approximately 3 N·m (0.3 kg·m, 2.2 ft·lb) and back off by 20° to 25°. Measure steering wheel play to make sure it is within specifications. Then tighten lock nut.




- c) After adjustment, drive vehicle at low speeds to check for proper operation of steering system.

POWER STEERING GEAR AND LINKAGE

Disassembly and Assembly

- Do not disassemble unless repairing to stop oil leak, replacing tie-rod and tie-rod inner socket ball joint, or for various adjustments.
- Do not reuse O-rings or oil seals.
- When assembling, apply a coat of oil to mating surfaces of O-rings and oil seals.
- When assembling, be careful not to damage oil seals.
- Before starting work, thoroughly clean all parts in cleaning solvent or automatic transmission fluid "Dexron Type" and blow dry with compressed air, if available.
- After assembling tie-rod inner socket to rack & housing assembly, check rack stroke (refer to "Rack stroke").



POWER STEERING GEAR AND LINKAGE

Disassembly and Assembly (Cont'd)


1. Insert rack packing.
2. Remove retainer.
3. Place plastic film on surfaces of pinion gear to prevent damage by rack teeth.
4. Always remove plastic film after rack oil seal is properly lubricated.

3. CAUTION:
 - The parts which can be disassembled are strictly limited, and some disassemble parts other than the specified ones.
 - Disassembly should be performed in a place as clean as possible.
 - Hands should be washed before disassembly.
 - Do not use any oil or grease to use any parts.
 - When disassembling and reassembling, allow any foreign matter to enter or contact the gear.

Rear housing cover installation

- With retainer adjusting screw fully loosened, tighten rear housing cover so that pinion starting force settles at the specified value, then lock it with lock nut.

For details, refer to "PINION PRELOAD AND RACK STARTING FORCE".



8490782

AST125

Refer to "Tie-rod installation".

6. Set rack gear in neutral position.

SST056B


POWER STEERING GEAR AND LINKAGE

Disassembly


CAUTION:

- The parts which can be disassembled are strictly limited, and never disassemble parts other than the specified ones.
- Disassembly should be performed in a place as clean as possible.
- Hands should be cleaned before disassembly.
- Do not use a rag. Be sure to use nylon or paper cloth.
- When disassembling and reassembling, do not allow any foreign matter to enter or contact any parts of steering gear.

1. Remove tie-rod assembly.




2. Remove retainer.
3. Remove pinion assembly.



SST094B


4. Remove end cover assembly with Tool.



SST844A

5. Draw out rack assembly.
6. Remove rack packing and back-up collar with socket and extension bar.

Do not scratch inner surfaces of cylinder.




SST472A

POWER STEERING GEAR AND LINKAGE


Assembly

1. Insert rack packing.
 - Place plastic film on inner side of rack packing to prevent damage by rack teeth.
 - Always remove plastic film after rack oil seal is positioned properly.




2. Install center bushing and rack oil seal with rack assembly.


Coat rack teeth with multi-purpose grease.




3. Install back-up washer and rack oil seal to cylinder assembly.



4. Tighten end cover assembly with Tool.



5. Fasten end cover assembly to cylinder assembly by staking.




6. Set rack gear in neutral position.


POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)


7. Coat seal lip of oil seal with multi-purpose grease and install new pinion oil seal to pinion housing with suitable tool.




8. Install rear oil seal using suitable tool.




9. Install rear housing cover assembly to pinion. Wrap vinyl tape around pinion serrations to prevent oil seal from being damaged.



10. Install pinion assembly to pinion housing. Be careful not to damage pinion teflon ring.




When installing pinion assembly, use suitable tool.




POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)

11. Install tie-rod inner socket. Then punch arrowed portions of lock plate.




12. Install tie-rod.



- Standard dimension L = 42.9 mm (1.689 in)
- When installing tie-rod or adjusting toe-in, be careful not to twist boots.
- Toe-in: Refer to MA section.


13. Measure rack stroke.



Unit: mm (in)

1. Retainer adjusting screw and lock nut
2. Apply new locking sealer to the threads.

3. If pinion and rack preload are within specified ranges, apply lock nut securely. (Check rack for smooth movement over its entire stroke.)



4. Retainer adjusting screw lock nut

Retainer adjustment (VG30ET engine model)

1. Remove retainer adjusting screw and lock nut.
2. Apply new locking sealer to the threads.
3. Tighten the screw to approximately 3 N·m (30 kg·cm, 2.2 ft·lb) and back it off 20° to 25°.
4. If pinion and rack preloads are within specified ranges, tighten lock nut securely. (Check rack for smooth movement over its entire stroke.)

Pinion rotating torque
 1.9 N·m (19 kg·cm, 16 in·lb) or less
 Rack sliding force (F₁):
 245 N (25 kg, 55 lb) or less
 in neutral position


4. Check rack sliding force (F₁) when installing steering gear assembly on vehicle and starting engine.

5. After checking rack sliding force (F₁), make sure that the handle returns smoothly when driving.

POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)

14. Apply a coat of sealant to contact surfaces between boot and cylinder before installing boot housing with suitable tool.




SST967A

15. Install boot clamps.


- To install, wrap boot clamp around boot groove twice. Tighten clamp by twisting rings at both ends four or four and a half turns with screwdriver while pulling with a force of approx. 98 N (10 kg, 22 lb).

Boot clamp length: ℓ_1, ℓ_2
 $\ell_1 = 390 \text{ mm (15.35 in)}$
 ... at pinion gear side
 $\ell_2 = 430 \text{ mm (16.93 in)}$
 ... at opposite pinion gear side




SST438A

- Install boot clamp so that it is to the rear of the vehicle when gear housing is attached to the body. (This will avoid interference with other parts.)



SST642A


- Twist boot clamp in the direction shown in figure at left.



A88C922

- After twisting boot clamp four or four and a half turns, bend twisted end diagonally so it does not contact boot.

From rear view



SST842A



POWER STEERING GEAR AND LINKAGE

Inspection and Adjustment

PINION PRELOAD AND RACK STARTING FORCE

- After disconnecting hydraulic line and draining fluid, measure them.

Pinion rotating torque:
1.9 N·m (19 kg·cm, 16 in·lb) or less



- If they are not within specifications, adjust retainer adjusting screw.
- If retainer adjustment cannot be made properly, fully loosen retainer adjusting screw, and then adjust pinion preload. Then readjust retainer adjusting screw.
- If pinion preload adjustment cannot be made properly, replace steering gear assembly.

Retainer adjustment (VG30E engine model)

- Remove retainer adjusting screw and clean old locking sealer off the threads.
- Apply new locking sealer to the threads. Tighten the screw to approximately 3 N·m (0.3 kg·m, 2.2 ft·lb) and back it off by 20° to 25°.

- If pinion and rack preloads are within specified ranges, tighten lock nut securely. (Check rack for smooth movement over its entire stroke.)

Pinion rotating torque:

1.9 N·m (19 kg·cm, 16 in·lb) or less

Rack sliding force:

245 N (25 kg, 55 lb) or less

in neutral position

- Retainer adjusting screw lock nut:

39 - 59 N·m

(4.0 - 6.0 kg·m, 29 - 43 ft·lb)

Retainer adjustment (VG30ET engine model)

- Remove retainer adjusting screw and clean old locking sealer off the threads.
- Apply new locking sealer to the threads. Tighten the screw to approximately 3 N·m (0.3 kg·m, 2.2 ft·lb) and back it off by 20° to 25°.
- If pinion and rack preloads are within specified ranges, tighten lock nut securely. (Check rack for smooth movement over its entire stroke.)

Pinion rotating torque:

1.9 N·m (19 kg·cm, 16 in·lb) or less

Rack sliding force (F₁):

245 N (25 kg, 55 lb) or less

in neutral position

- Retainer adjusting screw lock nut

39 - 59 N·m

(4.0 - 6.0 kg·m, 29 - 43 ft·lb)

- Check rack sliding force (F₂), when installing steering gear assembly on vehicle and starting engine.

Rack sliding force (F₂):

245 N (25 kg, 55 lb) or more

- After checking rack sliding force (F₂), make sure that the handle returns smoothly when driving.

POWER STEERING GEAR AND LINKAGE

Inspection and Adjustment (Cont'd)


CAUTION:
When changing retainer spring, use the same part number retainer spring as the former retainer spring.

Part number	Set load N (kg, lb)	Identification (Color)
48237-F6100	127 (13, 29)	Brown
48237-F6101	157 (16, 35)	Pink
48237-W1000	186 (19, 42)	Unpainted
48237-F6102	216 (22, 49)	Green
48237-F6103	245 (25, 55)	Purple

Pinion preload adjustment

Before making pinion preload adjustment, make sure retainer adjusting screw is loosened completely.

1. Screw in rear housing cover completely and back it off by 180° to 360°. Then turn pinion a few rotations and then measure pinion starting torque.




Pinion starting torque T_1 :
0.7 N-m (7 kg-cm, 6.1 in-lb) or less
Free play should not be allowed for pinion.

2. Screw in rear housing cover until pinion starting torque reaches " T_2 "; then tighten lock nut.

$$T_2 = T_1 + 0.5 \text{ N-m (5 kg-cm, 4.3 in-lb)}$$

: Lock nut

78 - 137 N-m
(8.0 - 14.0 kg-m, 58 - 101 ft-lb)



3. Measure pinion starting torque T_3 to make sure it is within specified range.


T_3 :

0.8 N-m (8 kg-cm, 6.9 in-lb) or less and
 $T_1 + [0.10 - 0.25 \text{ N-m (1.0 - 2.5 kg-cm, 0.87 - 2.17 in-lb)}]$

4. If T_3 does not meet the above two values, repeat step 2 and re-adjust pinion preload.

TIE-ROD OUTER SOCKET

1. Check ball joint for swinging torque.



POWER STEERING GEAR AND LINKAGE

— Inspection and Adjustment (Cont'd) —

CAUTION Tie-rod outer socket:

- The **Swinging torque** must be disassembled or restricted by limits of other parts other than the specified parts.
- **Swinging torque**
0.15 - 2.94 N·m
(1.5 - 30 kg-cm, 1.3 - 26.0 in-lb)


2. Check condition of dust cover. If it is cracked excessively, replace.

TIE-ROD INNER SOCKET

Check inner socket for swinging torque and axial play. If ball stud is worn and play in axial direction is excessive or joint is hard to swing, replace as a complete unit.

Tie-rod inner socket:

- **Swinging torque**
0.1 - 7.8 N·m
(1 - 80 kg-cm, 0.9 - 69.4 in-lb)
- **Axial play**
0 mm (0 in)



BOOT

Check condition of boot. If it is cracked, replace boot.


CYLINDER TUBES AND BREATHER HOSE

Check cylinder tubes and breather hose for scratches or other damage.

Replace if necessary.

STEERING GEAR COMPONENT PARTS

Thoroughly examine steering gear component parts. If those parts are damaged, cracked or worn, replace steering gear as an assembly.




INSIDE PARTS

If there are any cracks or flaws, replace pump.

Pre-disassembly Inspection

The power steering oil pump should be disassembled only if any of the following conditions are observed:

- Oil leak at the following points:
- Oil leak around observed around the pump housing.
- Oil leak at the following points:
- Oil leak at the following points:
- Oil leak at the following points:




Address "Hydraulic System Check" in "POWER STEERING SYSTEMS".

- Deformed or damaged pulley

POWER STEERING OIL PUMP

CAUTION:

When changing retainer spring, use the number retainer spring as the reference spring.



Pinion preload adjustment

Before making pinion

sure retainer adjusting

pletely.


1. Screw in rear housing

back it off by 180° to 360°. Then turn pinion a few rotations and then measure pinion starting torque.

Pre-disassembly Inspection

The power steering oil pump should be disassembled only if any of the following conditions are observed.


- Oil leak at the following points



SST984A

- Deformed or damaged pulley

Oil Pump Installation



⊗ : N·m (kg·m, ft·lb)

SST221A

- After installing oil pump, adjust belt tension. Refer to MA section.


SERVIC POWER STEERING OIL PUMP (S.D.S.)

Disassembly


CAUTION:

- The parts which can be disassembled are strictly limited. Never disassemble parts other than the specified ones.
- Disassembly should be performed in a place as clean as possible.
- Do not use a rag. Be sure to use nylon or paper cloth.
- When disassembling and reassembling, do not allow any foreign material to enter or contact any parts.

1. Remove rear cover upward.
 - Be careful not to lose the 2 pins as they often stick to rear cover.
2. Carefully remove cam ring, rotor and vanes.
3. Remove snap ring, then draw pulley shaft out.
 - Be careful not to drop pulley shaft.
 - Be careful not to damage rotor. If damaged, replace as a pump assembly.
4. Remove front side plate.
 - Do not damage inside of front housing.
5. Remove oil seal from front housing.
 - Be careful not to damage front housing.



6. Remove connector bolt.
7. Remove connector.
 - Be careful not to drop spool valve.



8. Remove suction pipe, then remove O-ring.

Inspection

Clean all disassembled parts (inside pump) with suitable cleaning solvent.

INSIDE PARTS

If there are any cracks or flaws, replace pump assembly.

PULLEY AND PULLEY SHAFT

- If pulley is cracked or deformed, replace it.
- If an oil leak is observed around pulley shaft oil seal, replace it.
- If serration of pulley or pulley shaft is deformed or worn, replace it.

OIL PRESSURE SWITCH (Non-turbocharged model)

High-pressure side hydraulic line pressure kPa (kg/cm ² , psi)	Operation
Increasing to 1,961 - 2,942 (20 - 30, 284 - 427)	Turn ON
Decreasing to Approx. 981 - 2,942 (10 - 30, 142 - 427)	Turn OFF


Refer to "Hydraulic System Check" in "POWER STEERING SYSTEM - Checking".

POWER STEERING OIL PUMP


Assembly

Assemble oil pump in the reverse order of disassembly, noting the following instructions.


- Before installing O-rings and oil seal, apply a thin coat of A.T.F. (Automatic Transmission Fluid) to them.
- Make certain that O-rings and oil seal are installed properly.
- Always install new O-rings and an oil seal.
- Be careful of oil seal direction.




- Pay attention to the direction of rotor.




- Install vanes the correct way round.



- Apply A.T.F.* to O-rings and front side plate.
- *: Automatic Transmission Fluid
- Take care to fit front side plate the correct way round and do not scratch inside front housing when installing.





- Insert pins ② into pin grooves ① of front housing and rotor. Then install cam ring ③ as shown below taking care to fit it the correct way round.



- After installing oil pump, adjust belt tension. Refer to MA section.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Steering gear type	PR24S [Power steering]
Steering column	
Type	Collapsible
Column length: L	
Non-tilt type	
Column length "L"	
	
Tilt type	
	
Turn of steering wheel (Lock to lock)	2.8
Steering overall gear ratio	15.3
Power steering fluid	
Type	Automatic transmission fluid "DEXRON type"
Capacity	ℓ (US pt, Imp pt) Approx. 0.9 (1-7/8, 1-5/8)
Normal operating temperature	°C (°F) 60 - 80 (140 - 176)


Inspection and Adjustment

GENERAL

Steering wheel axial play	mm (in)	0 (0)
Steering wheel play	mm (in)	35 (1.38) or less
Power steering system		
Steering wheel turning force at 360° position from Neutral	N (kg, lb)	39.2 (4.0, 8.8) or less
		New: 10 - 13 (0.39 - 0.51) Used: 13 - 16 (0.51 - 0.63) Limit: 21 (0.83) - Replace belt to new one.
Oil pump belt deflection (Measured when engine is cold)	mm (in)/98 N (10 kg, 22 lb)	
Oil pump maximum pressure	kPa (kg/cm ² , psi)	6,669 - 7,257 (68 - 74, 967 - 1,052)

Oil pressure switch operation

Hydraulic line pressure kPa (kg/cm ² , psi)	Operation
Increasing to 1,961 - 2,942 (20 - 30, 284 - 427)	Turn ON
Decreasing to 981 - 2,942 (10 - 30, 142 - 427)	Turn OFF



- Standard dimension L = 429 mm (1.689 in)
- When installing tie-rod or adjusting toe-in, be careful not to twist boots.
- Toe-in: Refer to MA section.

Pinion rotating torque (Pinion and rack gear assembly without fluid)	N·m (kg-cm, in-lb)	1.9 (19, 18) or less
Rack sliding force in neutral position (Pinion and rack gear assembly without fluid)	N (kg, lb)	348 (35, 88) or less

SERVICE DATA AND SPECIFICATIONS (S.D.S.)


Inspection and Adjustment

(Cont'd)

STEERING GEAR AND LINKAGE (PR24S)

Tie-rod outer ball joint	0.15 - 2.94
Swinging torque N·m (kg-cm, in-lb)	(1.5 - 30, 1.3 - 26.0)
Tie-rod inner ball joint	0.1 - 7.8
Swinging torque N·m (kg-cm, in-lb)	(1 - 80, 0.9 - 69.4)
Axial play	mm (in)
	0 (0)


Rack stroke



Unit: mm (in)

SST841A

Tie-rod standard length



- Standard dimension L = 42.9 mm (1.689 in)
- When installing tie-rod or adjusting toe-in, be careful not to twist boots.
- Toe-in: Refer to MA section.

SST936A

Pinion rotating torque (Pinion and rack gear assembly without fluid)	1.9 (19, 16) or less
N·m (kg-cm, in-lb)	
Rack sliding force in neutral position (Pinion and rack gear assembly without fluid)	245 (25, 55) or less
N (kg, lb)	

Tightening Torque

STEERING COLUMN

Unit	N·m	kg-m	ft-lb
Steering wheel nut	49 - 59	5.0 - 6.0	36 - 43
Steering column to body	13 - 18	1.3 - 1.8	9 - 13
Hole cover to dash panel	3 - 5	0.3 - 0.5	2.2 - 3.6
Column joint fixing bolt (Lower joint, column set)	24 - 29	2.4 - 3.0	17 - 22
Jacket lower tube to steering column clamp	16 - 21	1.6 - 2.1	12 - 15

STEERING GEAR & LINKAGE (PR24S)

Unit	N·m	kg-m	ft-lb
Tie-rod lock nut	78 - 98	8.0 - 10.0	58 - 72
Tie-rod inner socket to rack (With sealant)	78 - 98	8.0 - 10.0	58 - 72
Cylinder end cover	39 - 49	4.0 - 5.0	29 - 36
Rear housing cover lock nut	78 - 137	8.0 - 14.0	58 - 101
Retainer lock nut	39 - 59	4.0 - 6.0	29 - 43
Cylinder tube flare nut	20 - 26	2.0 - 2.7	14 - 20
Gear & linkage mounting	39 - 49	4.0 - 5.0	29 - 36
Tie-rod to knuckle arm	54 - 98	5.5 - 10.0	40 - 72

OIL PUMP

Unit	N·m	kg-m	ft-lb
Mounting bracket to engine	14 - 18	1.4 - 1.8	10 - 13
Oil pump to mounting bracket (Through bolt)	31 - 42	3.2 - 4.3	23 - 31
Oil pump front housing sub bracket	27 - 35	2.8 - 3.6	20 - 26
Adjusting bar bracket to mounting bracket	16 - 21	1.6 - 2.1	12 - 15
Sub bracket to adjusting bar	16 - 21	1.6 - 2.1	12 - 15
Pulley lock nut	54 - 68	5.5 - 6.9	40 - 50
Rear cover fixing bolt	31 - 42	3.2 - 4.3	23 - 31
Connector (Spool cover)	69 - 78	7.0 - 8.0	51 - 58
Connector (to flexible hose)	49 - 69	5.0 - 7.0	36 - 51
Suction pipe to casing	14 - 18	1.4 - 1.8	10 - 13

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque (Cont'd)








HYDRAULIC LINE AND OIL PRESSURE SWITCH

Unit	Tool name		
	N·m	kg·m	ft·lb
Low-pressure pipe to steering gear	27 - 39	2.8 - 4.0	20 - 29
High-pressure pipe to steering gear	16 - 25	1.5 - 2.5	11 - 18
High-pressure pipe connector bolt (At oil pump)	49 - 69	5.0 - 7.0	36 - 51
Oil pressure switch	16 - 24	1.6 - 2.4	12 - 17

Tool name	Tool number (Kent-Moore No.)
Steering wheel puller	ST27180001 (128278-A)
Ball joint remover	HT12820000 (128230-A)
Pressure gauge	ST27091000 (128287)
Rear housing lock nut wrench	KV48101800 (128818)
Rear cover wrench	KV48101700 (128819)
Power steering stand	KV48102100 (128817)
Torque adaptor	KV48100700 (128884)

SPECIAL SERVICE TOOLS

(Cont'd)

Tool number (Kent-Moore No.)	Tool name	
ST27180001 (J25726-A)	Steering wheel puller	
HT72520000 (J25730-A)	Ball joint remover	
ST27091000 (J26357)	Pressure gauge	
KV48101600 (J28818)	Rear housing lock nut wrench	
KV48101700 (J28819)	Rear cover wrench	
KV48102100 (J28817)	Power steering stand	
KV48100700 (J26364)	Torque adapter	





- Standard dimension L = 42.0 mm (1.693 in.)
- When installing tapered drive shaft to form, be careful not to twist bolts.
- Tip-in: Refer to J25726-1.

Final rotating torque (Pinion and rack gear assembly without fluid) N·m (kg·cm, in·lb)

Final rotating torque in neutral position (Pinion and rack gear assembly without fluid) N·m (kg·cm, in·lb)

Pulley lock nut	89-98	8.0-10.0	58-72
Rear cover fixing bolt	20-26	2.0-2.1	14-20
Connector (Spool cover)	89-98	8.0-10.0	58-72
Connector (to torque)	89-98	8.0-10.0	58-72
Pinion	89-98	8.0-10.0	58-72
Substituted torque	24-18	2.4-1.8	17-13

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.)	Tool name
ST3127S000 (See J25765-A) ① GG91030000 (J25765-A) ② HT62940000 (-) ③ HT62900000 (-)	Preload gauge Torque wrench ①  Socket adapter ②  Socket adapter ③ 
KV48102000 (J28822)	End cover socket wrench 

INSTRUMENT (Including "Center console")	BF-10
SEAT (Including "Power seat" and wiring diagram)	BF-17
SEAT BELT	BF-28
INTERIOR AND EXTERIOR	BF-29
WINDSHIELD AND WINDOWS	BF-30
T-BAR ROOF	BF-41
MIRROR (Including wiring diagram)	BF-42
REAR AIR SPOILER	BF-43
REAR COMBINATION LAMP	BF-44
BODY ALIGNMENT — Engine compartment & Underbody (Including the actual dimensions between the points and the coordinates of the points)	BF-45

- * For theft warning system, refer to EL section.
- * For seat belts, refer to MA section.
- * Method of reading electrical diagram in BF section is basically the same as in the EL section. So refer to "HOW TO READ DIAGRAM" in EL section.
- * For power supply routing, refer to "POWER SUPPLY" in EL section.
- * Black box internal circuits in BF section are a summary of actual circuit. Use only for studying the operation.
- * "Remarks" and "Connections" in electrical diagram show the terminal meaning and actual electrical flow.
- * For connector Nos. in wiring diagrams in this section, refer to Harness Layout in EL section.