


# SECTION CL

## CONTENTS

<p><b>PRECAUTIONS AND PREPARATION</b>.....2</p> <p>    Precautions .....2</p> <p>    Special Service Tools .....2</p> <p>    Commercial Service Tools .....3</p> <p><b>CLUTCH SYSTEM</b>.....4</p> <p><b>INSPECTION AND ADJUSTMENT</b> .....6</p> <p>    Adjusting Clutch Pedal .....6</p> <p>    Bleeding Procedure .....7</p> <p><b>HYDRAULIC CLUTCH CONTROL</b> .....8</p> <p>    Clutch Master Cylinder .....8</p>	<p>    Operating Cylinder .....9</p> <p>    Clutch Booster .....10</p> <p><b>CLUTCH RELEASE MECHANISM</b> .....12</p> <p><b>CLUTCH DISC AND CLUTCH COVER</b> .....14</p> <p>    Clutch Disc.....14</p> <p>    Clutch Cover and Flywheel .....15</p> <p><b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....16</p> <p>    General Specifications .....16</p> <p>    Inspection and Adjustment .....16</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



## PRECAUTIONS AND PREPARATION



### Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.

### WARNING:




After cleaning the clutch disc, wipe it with a dust collector. Do not use compressed air.

### Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description
GG94310000 ( — ) Flare nut torque wrench	<p style="text-align: center;">NT406</p> <p style="text-align: right;"><b>a: 10 mm (0.39 in)</b></p>
ST20600000 (J26366) Clutch aligning bar	<p style="text-align: center;">NT405</p> <p style="text-align: right;"><b>a: 15.9 mm (0.626 in) dia.</b> <b>b: 22.8 mm (0.898 in) dia.</b> <b>c: 55 mm (2.17 in)</b></p>
ST20050240 ( — ) Diaphragm spring adjusting wrench	<p style="text-align: center;">NT404</p> <p style="text-align: right;"><b>a: 150 mm (5.91 in)</b> <b>b: 25 mm (0.98 in)</b></p>

# PRECAUTIONS AND PREPARATION

## Commercial Service Tools

Tool name	Description	GI
Bearing puller	<div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Removing release bearing</p> <p>NT077</p> </div> </div>	MA
Bearing drift	<div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Installing release bearing</p> <p>NT065</p> <p>a: 50 mm (1.97 in) dia. b: 45 mm (1.77 in) dia.</p> </div> </div>	EM
<p>① Flare nut crows foot</p> <p>② Torque wrench</p>	<div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Installing release bearing</p> <p>NT223</p> </div> </div>	LC

EF &  
EC

FE

**CL**

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

# CLUTCH SYSTEM

## VG30DE engine model



: N·m (kg-m, ft-lb)


L : Apply lithium-based grease including molybdenum disulphide.

SCL641

- |                           |                 |                          |
|---------------------------|-----------------|--------------------------|
| ① Clutch master cylinder  | ⑦ Clevis pin    | ⑬ Air bleeder screw      |
| ② Pedal bracket           | ⑧ Clutch pedal  | ⑭ Release bearing        |
| ③ Assist spring           | ⑨ Clutch switch | ⑮ Release bearing sleeve |
| ④ ASCD cancel switch      | ⑩ Snap pin      | ⑯ Withdrawal lever       |
| ⑤ Fulcrum pin             | ⑪ Clutch disc   | ⑰ Dust cover             |
| ⑥ Clutch interlock switch | ⑫ Clutch cover  | ⑱ Operating cylinder     |

# CLUTCH SYSTEM

VG30DETT engine model



- ① Clutch master cylinder
- ② Pedal bracket
- ③ Clutch booster
- ④ Check valve
- ⑤ Fulcrum pin
- ⑥ Vacuum tank
- ⑦ Lock nut

- ⑧ ASCD cancel switch
- ⑨ HICAS clutch switch
- ⑩ Clutch interlock switch
- ⑪ Return spring
- ⑫ Clevis pin
- ⑬ Clutch pedal
- ⑭ Snap pin

- ⑮ Clutch disc
- ⑯ Clutch cover
- ⑰ Air bleeder screw
- ⑱ Release bearing
- ⑲ Release bearing sleeve
- ⑳ Withdrawal lever
- ㉑ Dust cover
- ㉒ Operating cylinder

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
**CL**  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## Adjusting Clutch Pedal

- Adjust pedal height with ASCD cancel switch and HICAS clutch switch or clutch switch.



**Pedal height "H":**

**VG30DE engine**

197 - 207 mm (7.76 - 8.15 in)

**VG30DETT engine**

183 - 193 mm (7.20 - 7.60 in)



- Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

**Pedal free play "A":**

1.0 - 3.0 mm (0.039 - 0.118 in)

**Pedal free play means the following measured at position of pedal pad:**

- Play due to clevis pin and clevis pin hole in clutch pedal.
- Make sure that clevis pin can be rotated smoothly.  
If not, readjust pedal free play with master cylinder push rod.

# INSPECTION AND ADJUSTMENT




## Adjusting Clutch Pedal (Cont'd)

— U.S.A. model only —

4. Adjust clearance "C" shown in the figure while fully depressing clutch pedal.

**Clearance C:**

**1.0 - 2.0 mm (0.039 - 0.079 in)**



## Bleeding Procedure

1. Bleed air from clutch operating cylinder according to the following procedure.

**Carefully monitor fluid level at master cylinder during bleeding operation.**

- a. Top up reservoir with recommended brake fluid.
  - b. Connect a transparent vinyl tube to air bleeder valve.
  - c. Fully depress clutch pedal several times.
  - d. With clutch pedal depressed, open bleeder valve to release air.
  - e. Close bleeder valve.
  - f. Repeat steps c through e above until brake fluid flows from air bleeder valve without air bubbles.
2. Bleed air from clutch piping connector according to the above same procedure.
  3. Repeat the above bleeding procedures 1 and 2 several times.

GI

MA

EM

LC

EF &  
EC

FE

**CL**

MT

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

# HYDRAULIC CLUTCH CONTROL

## Clutch Master Cylinder




### DISASSEMBLY AND ASSEMBLY

- Push piston into cylinder body with screwdriver when removing and installing valve stopper.



# HYDRAULIC CLUTCH CONTROL

## Clutch Master Cylinder (Cont'd)



- Align groove of piston assembly and valve stopper when installing valve stopper.
- Check direction of piston cups.

GI

MA

EM

LC

## INSPECTION

- Check cylinder and piston rubbing surface for uneven wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check return spring for wear or damage. Replace if necessary.
- Check reservoir for deformation or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.


EF &  
EC

FE

CL

## Operating Cylinder

MT



AT

PD

FA

RA

BR

ST

RS

BT

## INSPECTION

- Check rubbing surface of cylinder for wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check piston spring for wear or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.


HA

EL

IDX

# HYDRAULIC CLUTCH CONTROL


## Clutch Booster



### INSPECTION


#### Hoses and connectors

- Check condition of vacuum hoses and connections.
- Check vacuum hoses and check valve for air tightness.



#### Check valve

- Install check valve properly paying attention to its direction.
- When pressure is applied to the clutch booster side of check valve and valve does not open, replace check valve with a new one.



### ADJUSTMENT

Output rod length "A":

13.35 - 13.60 mm (0.5256 - 0.5354 in)

# HYDRAULIC CLUTCH CONTROL

## Clutch Booster (Cont'd)

If amount of adjustment required exceeds 0.5 mm (0.020 in), reaction disc may have either been dislocated or fallen off. Replace clutch booster assembly.

GI

MA

EM

LC

EF &  
EC

FE

**CL**

MT

AT

PD

FA

RA

BR

ST



RS

BT

HA



EL

IDX




Input rod length "B":  
113 mm (4.45 in)

# CLUTCH RELEASE MECHANISM




## REMOVAL AND INSTALLATION

- Install retainer spring and holder spring.



- Remove release bearing.



- Install release bearing with suitable drift.

# CLUTCH RELEASE MECHANISM

## INSPECTION

- Check release bearing to see that it rolls freely and is free from noise, cracks, pitting or wear. Replace if necessary.
- Check release bearing sleeve and withdrawal lever rubbing surface for wear, rust or damage. Replace if necessary.

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX





## LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.

**Too much lubricant might damage clutch disc facing.**


# CLUTCH DISC AND CLUTCH COVER



## Clutch Disc

### INSPECTION

- Check clutch disc for wear of facing.  
**Wear limit of facing surface to rivet head:**  
**Model 240 and 250**  
**0.3 mm (0.012 in)**




- Check clutch disc for spline backlash and facing runout.  
**Maximum spline backlash (at outer edge of disc):**  
**Model 240 and 250**  
**1.0 mm (0.039 in)**  
**Runout limit:**  
**Model 240 and 250**  
**1.0 mm (0.039 in)**  
**Distance of runout check point (from hub center):**  
**Model 240**  
**115 mm (4.53 in)**  
**Model 250**  
**120 mm (4.72 in)**
- Check clutch disc for burns, discoloration or oil or grease leakage. Replace if necessary.

### INSTALLATION

- Apply recommended grease to contact surface of spring portion.
- Too much lubricant might damage clutch disc facing.**

# CLUTCH DISC AND CLUTCH COVER



## Clutch Cover and Flywheel

### INSPECTION AND ADJUSTMENT

- Check clutch cover installed on vehicle for unevenness of diaphragm spring toe height.

**Uneven limit:**


**Model 240**

**0.5 mm (0.020 in)**

**Model 250**

**0.7 mm (0.028 in)**

- If out of limit, adjust the height with Tool.




### FLYWHEEL INSPECTION

- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.
- Check flywheel runout.

**Maximum allowable runout:**

**Refer to EM section ("Inspection", "CYLINDER BLOCK").**



### INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.
- Tighten bolts in numerical order.
- Be careful not to allow grease to contaminate clutch facing.

GI

MA

EM

LC

EF &  
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# SERVICE DATA AND SPECIFICATIONS (SDS)

## General Specifications

### CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

### CLUTCH MASTER CYLINDER

Inner diameter	mm (in)	15.87 (5/8)
----------------	---------	-------------

### CLUTCH OPERATING CYLINDER

Inner diameter	mm (in)	19.05 (3/4)
----------------	---------	-------------

### CLUTCH DISC

Model	240	250
Engine	VG30DE	VG30DETT
Facing size (Outer dia. x inner dia. x thickness) mm (in)	240 x 160 x 3.5 (9.45 x 6.30 x 0.138)	250 x 160 x 3.5 (9.84 x 6.30 x 0.138)
Thickness of disc assembly With load mm (in)	8.1 - 8.5 (0.319 - 0.335) with 4,904 N (500 kg, 1,103 lb)	

## Inspection and Adjustment

### CLUTCH PEDAL

	Unit: mm (in)	
Engine	VG30DE	VG30DETT
Pedal height "H"	197 - 207 (7.76 - 8.15)	183 - 193 (7.20 - 7.60)
Pedal free play "A" (at pedal pad)	1.0 - 3.0 (0.039 - 0.118)	
Clearance "C" (between pedal stopper rubber and threaded end of clutch interlock)	1.0 - 2.0 (0.039 - 0.079)	

\*: Measured from surface of dash lower panel to pedal pad

### CLUTCH DISC

	Unit: mm (in)	
Model	240	250
Wear limit of facing surface to rivet head	0.3 (0.012)	
Runout limit of facing	1.0 (0.039)	
Distance of runout check point (from the hub center)	115 (4.53)	120 (4.72)
Maximum backlash of spline (at outer edge of disc)	1.0 (0.039)	

### CLUTCH COVER

Model	240	250
Engine	VG30DE	VG30DETT
Full-load N (kg, lb)	5,688 (580, 1,279)	7,846 (800, 1,764)

### CLUTCH BOOSTER (VG30DETT engine model)

Model	M45	
Diaphragm diameter	mm (in)	114.3 (4.50)

### CLUTCH COVER

	Unit: mm (in)	
Model	240	250
Uneven limit of diaphragm spring toe height	0.5 (0.020)	0.7 (0.028)

### CLUTCH BOOSTER

	Unit: mm (in)	
Output rod length "A"	13.35 - 13.60 (0.5256 - 0.5354)	
Input rod length "B"	113 (4.45)	