

A  
B  
AT

# SECTION **AT**

## AUTOMATIC TRANSMISSION

### CONTENTS

|   |   |    |
|---|---|----|
| <b>SERVICE INFORMATION</b> .....                | <b>Malfunction Indicator Lamp (MIL)</b> .....     | F  |
| <b>INDEX FOR DTC</b> .....                      | <b>TROUBLE DIAGNOSIS</b> .....                    | 40 |
| Alphabetical Index .....                        | DTC Inspection Priority Chart .....               | 40 |
| DTC No. Index .....                             | Fail-Safe .....                                   | 40 |
| <b>PRECAUTIONS</b> .....                        | How to Perform Trouble Diagnosis for Quick and    |    |
| Precaution for Supplemental Restraint System    | Accurate Repair .....                             | 41 |
| (SRS) "AIR BAG" and "SEAT BELT PRE-TEN-         | A/T Electrical Parts Location .....               | 46 |
| SIONER" .....                                   | Circuit Diagram .....                             | 47 |
| Precaution for Battery Service .....            | Inspections Before Trouble Diagnosis .....        | 47 |
| Precaution for On Board Diagnosis (OBD) System  | Road Test .....                                   | 51 |
| of A/T and Engine .....                         | Vehicle Speed at When Gears Shifting Occurs ..... | 56 |
| Precaution .....                                | Vehicle Speed at Which Lock-up Occurs/Releas-     | 56 |
| Service Notice or Precaution .....              | es .....  | 56 |
| <b>PREPARATION</b> .....                        | Symptom Chart .....                               | 56 |
| Special Service Tool .....                      | TCM Input/Output Signal Reference Value .....     | 80 |
| Commercial Service Tool .....                   | CONSULT-III Function (TRANSMISSION) .....         | 81 |
| <b>A/T FLUID</b> .....                          | Diagnosis Procedure without CONSULT-III .....     | 88 |
| Changing A/T Fluid .....                        | <b>U1000 CAN COMM CIRCUIT</b> .....               | 90 |
| Checking A/T Fluid .....                        | Description .....                                 | 90 |
| A/T Fluid Cooler Cleaning .....                 | On Board Diagnosis Logic .....                    | 90 |
| <b>A/T CONTROL SYSTEM</b> .....                 | Possible Cause .....                              | 90 |
| Cross-Sectional View .....                      | DTC Confirmation Procedure .....                  | 90 |
| Shift Mechanism .....                           | Wiring Diagram - AT - CAN .....                   | 91 |
| TCM Function .....                              | Diagnosis Procedure .....                         | 92 |
| CAN Communication .....                         | <b>P0615 STARTER RELAY</b> .....                  | 93 |
| Input/Output Signal of TCM .....                | Description .....                                 | 93 |
| Line Pressure Control .....                     | CONSULT-III Reference Value .....                 | 93 |
| Shift Control .....                             | On Board Diagnosis Logic .....                    | 93 |
| Lock-up Control .....                           | Possible Cause .....                              | 93 |
| Engine Brake Control .....                      | DTC Confirmation Procedure .....                  | 93 |
| Control Valve .....                             | Wiring Diagram - AT - STSIG .....                 | 94 |
| <b>ON BOARD DIAGNOSTIC (OBD) SYSTEM</b> .....   | Diagnosis Procedure .....                         | 95 |
| Introduction .....                              | <b>P0700 TRANSMISSION CONTROL</b> .....           | 97 |
| OBD-II Function for A/T System .....            | Description .....                                 | 97 |
| One or Two Trip Detection Logic of OBD-II ..... | On Board Diagnosis Logic .....                    | 97 |
| OBD-II Diagnostic Trouble Code (DTC) .....      | Possible Cause .....                              | 97 |
|   | DTC Confirmation Procedure .....                  | 97 |

|  |            |   |            |
|--|------------|---|------------|
| Diagnosis Procedure .....                    | 97         | DTC Confirmation Procedure .....          | 116        |
| <b>P0705 TRANSMISSION RANGE SWITCH A ...</b> | <b>98</b>  | Diagnosis Procedure .....                 | 117        |
| Description .....                            | 98         | <b>P0735 5GR INCORRECT RATIO .....</b>    | <b>118</b> |
| CONSULT-III Reference Value .....            | 98         | Description .....                         | 118        |
| On Board Diagnosis Logic .....               | 98         | On Board Diagnosis Logic .....            | 118        |
| Possible Cause .....                         | 98         | Possible Cause .....                      | 118        |
| DTC Confirmation Procedure .....             | 98         | DTC Confirmation Procedure .....          | 118        |
| Wiring Diagram - AT - TR/SW .....            | 99         | Diagnosis Procedure .....                 | 119        |
| Diagnosis Procedure .....                    | 99         | <b>P0740 TORQUE CONVERTER .....</b>       | <b>120</b> |
| <b>P0717 INPUT SPEED SENSOR A .....</b>      | <b>101</b> | Description .....                         | 120        |
| Description .....                            | 101        | CONSULT-III Reference Value .....         | 120        |
| CONSULT-III Reference Value .....            | 101        | On Board Diagnosis Logic .....            | 120        |
| On Board Diagnosis Logic .....               | 101        | Possible Cause .....                      | 120        |
| Possible Cause .....                         | 101        | DTC Confirmation Procedure .....          | 120        |
| DTC Confirmation Procedure .....             | 101        | Diagnosis Procedure .....                 | 120        |
| Diagnosis Procedure .....                    | 101        | <b>P0744 TORQUE CONVERTER .....</b>       | <b>122</b> |
| <b>P0720 OUTPUT SPEED SENSOR .....</b>       | <b>103</b> | Description .....                         | 122        |
| Description .....                            | 103        | CONSULT-III Reference Value .....         | 122        |
| CONSULT-III Reference Value .....            | 103        | On Board Diagnosis Logic .....            | 122        |
| On Board Diagnosis Logic .....               | 103        | Possible Cause .....                      | 122        |
| Possible Cause .....                         | 103        | DTC Confirmation Procedure .....          | 122        |
| DTC Confirmation Procedure .....             | 103        | Diagnosis Procedure .....                 | 122        |
| Wiring Diagram - AT - VSSA/T .....           | 105        | <b>P0745 PRESSURE CONTROL SOLENOID A.</b> | <b>124</b> |
| Diagnosis Procedure .....                    | 105        | Description .....                         | 124        |
| <b>P0725 ENGINE SPEED .....</b>              | <b>108</b> | CONSULT-III Reference Value .....         | 124        |
| Description .....                            | 108        | On Board Diagnosis Logic .....            | 124        |
| CONSULT-III Reference Value .....            | 108        | Possible Cause .....                      | 124        |
| On Board Diagnosis Logic .....               | 108        | DTC Confirmation Procedure .....          | 124        |
| Possible Cause .....                         | 108        | Diagnosis Procedure .....                 | 124        |
| DTC Confirmation Procedure .....             | 108        | <b>P1705 TP SENSOR .....</b>              | <b>126</b> |
| Diagnosis Procedure .....                    | 108        | Description .....                         | 126        |
| <b>P0731 1GR INCORRECT RATIO .....</b>       | <b>110</b> | CONSULT-III Reference Value .....         | 126        |
| Description .....                            | 110        | On Board Diagnosis Logic .....            | 126        |
| On Board Diagnosis Logic .....               | 110        | Possible Cause .....                      | 126        |
| Possible Cause .....                         | 110        | DTC Confirmation Procedure .....          | 126        |
| DTC Confirmation Procedure .....             | 110        | Diagnosis Procedure .....                 | 126        |
| Diagnosis Procedure .....                    | 111        | <b>P1710 TRANSMISSION FLUID TEMPERA-</b>  | <b>128</b> |
| <b>P0732 2GR INCORRECT RATIO .....</b>       | <b>112</b> | <b>TURE SENSOR .....</b>                  | <b>128</b> |
| Description .....                            | 112        | Description .....                         | 128        |
| On Board Diagnosis Logic .....               | 112        | CONSULT-III Reference Value .....         | 128        |
| Possible Cause .....                         | 112        | On Board Diagnosis Logic .....            | 128        |
| DTC Confirmation Procedure .....             | 112        | Possible Cause .....                      | 128        |
| Diagnosis Procedure .....                    | 113        | DTC Confirmation Procedure .....          | 128        |
| <b>P0733 3GR INCORRECT RATIO .....</b>       | <b>114</b> | Wiring Diagram - AT - FTS .....           | 129        |
| Description .....                            | 114        | Diagnosis Procedure .....                 | 129        |
| On Board Diagnosis Logic .....               | 114        | Component Inspection .....                | 131        |
| Possible Cause .....                         | 114        | <b>P1721 VEHICLE SPEED SIGNAL .....</b>   | <b>133</b> |
| DTC Confirmation Procedure .....             | 114        | Description .....                         | 133        |
| Diagnosis Procedure .....                    | 115        | CONSULT-III Reference Value .....         | 133        |
| <b>P0734 4GR INCORRECT RATIO .....</b>       | <b>116</b> | On Board Diagnosis Logic .....            | 133        |
| Description .....                            | 116        | Possible Cause .....                      | 133        |
| On Board Diagnosis Logic .....               | 116        | DTC Confirmation Procedure .....          | 133        |
| Possible Cause .....                         | 116        | Diagnosis Procedure .....                 | 133        |

|   |            |  |            |    |
|---|------------|--|------------|----|
| <b>P1730 INTERLOCK</b> .....                | <b>135</b> | On Board Diagnosis Logic .....                     | 149        |    |
| Description .....                           | 135        | Possible Cause .....                               | 149        | A  |
| On Board Diagnosis Logic .....              | 135        | DTC Confirmation Procedure .....                   | 149        |    |
| Possible Cause .....                        | 135        | Diagnosis Procedure .....                          | 150        |    |
| DTC Confirmation Procedure .....            | 135        |  |            |    |
| Judgment of Interlock .....                 | 135        | <b>P1815 M-MODE SWITCH</b> .....                   | <b>151</b> | B  |
| Diagnosis Procedure .....                   | 135        | Description .....                                  | 151        |    |
|   |            | CONSULT-III Reference Value in Data Monitor        |            |    |
| <b>P1731 1ST ENGINE BRAKING</b> .....       | <b>137</b> | Mode .....   | 151        | AT |
| Description .....                           | 137        | On Board Diagnosis Logic .....                     | 151        |    |
| CONSULT-III Reference Value .....           | 137        | Possible Cause .....                               | 151        |    |
| On Board Diagnosis Logic .....              | 137        | DTC Confirmation Procedure .....                   | 151        | D  |
| Possible Cause .....                        | 137        | Wiring Diagram - AT - MMSW .....                   | 152        |    |
| DTC Confirmation Procedure .....            | 137        | Diagnosis Procedure .....                          | 154        |    |
| Diagnosis Procedure .....                   | 137        | Component Inspection .....                         | 155        | E  |
|   |            |  |            |    |
| <b>P1752 INPUT CLUTCH SOLENOID</b> .....    | <b>139</b> | <b>MAIN POWER SUPPLY AND GROUND CIR-</b>           |            |    |
| Description .....                           | 139        | <b>CUIT</b> .....                                  | <b>156</b> |    |
| CONSULT-III Reference Value .....           | 139        | Wiring Diagram - AT - MAIN .....                   | 156        | F  |
| On Board Diagnosis Logic .....              | 139        | Diagnosis Procedure .....                          | 157        |    |
| Possible Cause .....                        | 139        |  |            |    |
| DTC Confirmation Procedure .....            | 139        | <b>CLOSED THROTTLE POSITION AND WIDE</b>           |            |    |
| Diagnosis Procedure .....                   | 139        | <b>OPEN THROTTLE POSITION CIRCUIT</b> .....        | <b>160</b> | G  |
|   |            | CONSULT-III Reference Value .....                  | 160        |    |
| <b>P1757 FRONT BRAKE SOLENOID</b> .....     | <b>141</b> | Diagnosis Procedure .....                          | 160        |    |
| Description .....                           | 141        |  |            |    |
| CONSULT-III Reference Value .....           | 141        | <b>BRAKE SIGNAL CIRCUIT</b> .....                  | <b>161</b> | H  |
| On Board Diagnosis Logic .....              | 141        | CONSULT-III Reference Value .....                  | 161        |    |
| Possible Cause .....                        | 141        | Diagnosis Procedure .....                          | 161        | I  |
| DTC Confirmation Procedure .....            | 141        |  |            |    |
| Diagnosis Procedure .....                   | 141        | <b>A/T INDICATOR CIRCUIT</b> .....                 | <b>162</b> |    |
|   |            | Description .....                                  | 162        |    |
| <b>P1762 DIRECT CLUTCH SOLENOID</b> .....   | <b>143</b> | CONSULT-III Reference Value .....                  | 162        | J  |
| Description .....                           | 143        | Diagnosis Procedure .....                          | 162        |    |
| CONSULT-III Reference Value .....           | 143        |  |            |    |
| On Board Diagnosis Logic .....              | 143        | <b>TROUBLE DIAGNOSIS FOR SYMPTOMS</b> ....         | <b>163</b> | K  |
| Possible Cause .....                        | 143        | Wiring Diagram - AT - NONDTC .....                 | 163        |    |
| DTC Confirmation Procedure .....            | 143        | A/T Check Indicator Lamp Does Not Come On ....     | 166        |    |
| Diagnosis Procedure .....                   | 143        | Engine Cannot Be Started in "P" or "N" Position .. | 166        |    |
|   |            | In "P" Position, Vehicle Moves When Pushed .....   | 167        | L  |
| <b>P1767 HIGH AND LOW REVERSE CLUTCH</b>    |            | In "N" Position, Vehicle Moves .....               | 167        |    |
| <b>SOLENOID</b> .....                       | <b>145</b> | Large Shock ("N" to "D" Position) .....            | 168        |    |
| Description .....                           | 145        | Vehicle Does Not Creep Backward in "R" Position.   | 169        | M  |
| CONSULT-III Reference Value .....           | 145        | Vehicle Does Not Creep Forward in "D" Position ..  | 171        |    |
| On Board Diagnosis Logic .....              | 145        | Vehicle Cannot Be Started from D1 .....            | 173        |    |
| Possible Cause .....                        | 145        | A/T Does Not Shift: D1→ D2 .....                   | 175        |    |
| DTC Confirmation Procedure .....            | 145        | A/T Does Not Shift: D2→ D3 .....                   | 176        | N  |
| Diagnosis Procedure .....                   | 145        | A/T Does Not Shift: D3→ D4 .....                   | 178        |    |
|   |            | A/T Does Not Shift: D4→ D5 .....                   | 180        |    |
| <b>P1772 LOW COAST BRAKE SOLENOID</b> ..... | <b>147</b> | A/T Does Not Lock-up .....                         | 181        | O  |
| Description .....                           | 147        | A/T Does Not Hold Lock-up Condition .....          | 183        |    |
| CONSULT-III Reference Value .....           | 147        | Lock-up Is Not Released .....                      | 184        |    |
| On Board Diagnosis Logic .....              | 147        | Engine Speed Does Not Return to Idle .....         | 184        | P  |
| Possible Cause .....                        | 147        | Cannot Be Changed to Manual Mode .....             | 185        |    |
| DTC Confirmation Procedure .....            | 147        | A/T Does Not Shift: 5GR → 4GR .....                | 186        |    |
| Diagnosis Procedure .....                   | 147        | A/T Does Not Shift: 4GR → 3GR .....                | 187        |    |
|   |            | A/T Does Not Shift: 3GR → 2GR .....                | 188        |    |
| <b>P1774 LOW COAST BRAKE SOLENOID</b> ..... | <b>149</b> | A/T Does Not Shift: 2GR → 1GR .....                | 189        |    |
| Description .....                           | 149        | Vehicle Does Not Decelerate by Engine Brake ....   | 191        |    |
| CONSULT-III Reference Value .....           | 149        |  |            |    |

|  |            |  |            |
|--|------------|--|------------|
| <b>SHIFT CONTROL SYSTEM</b> .....                                    | <b>193</b> | Location of Adjusting Shims, Needle Bearings,<br>Thrust Washers and Snap Rings ..... | 238        |
| A/T Shift Selector Removal and Installation .....                    | 193        |  |            |
| Control Rod Removal and Installation .....                           | 194        |  |            |
| Adjustment of A/T Position .....                                     | 195        |  |            |
| Checking of A/T Position .....                                       | 195        |  |            |
| <b>A/T SHIFT LOCK SYSTEM</b> .....                                   | <b>196</b> | <b>DISASSEMBLY</b> .....   | <b>239</b> |
| Description .....  | 196        | Disassembly .....  | 239        |
| Shift Lock System Electrical Parts Location .....                    | 196        | <b>REPAIR FOR COMPONENT PARTS</b> .....  | <b>255</b> |
| Wiring Diagram - AT - SHIFT .....                                    | 197        | Oil Pump .....   | 255        |
| Diagnosis Procedure .....  | 197        | Front Sun Gear, 3rd One-Way Clutch .....   | 257        |
| <b>KEY INTERLOCK CABLE</b> .....                                     | <b>201</b> | Front Carrier, Input Clutch, Rear Internal Gear ....                                 | 259        |
| Component .....  | 201        | Mid Sun Gear, Rear Sun Gear, High and Low Re-<br>verse Clutch Hub .....              | 264        |
| Removal and Installation .....                                       | 201        | High and Low Reverse Clutch .....  | 269        |
| <b>ON-VEHICLE SERVICE</b> .....                                      | <b>204</b> | Direct Clutch .....  | 270        |
| Control Valve with TCM and A/T Fluid Tempera-<br>ture Sensor 2 ..... | 204        | <b>ASSEMBLY</b> .....  | <b>273</b> |
| Parking Component .....  | 215        | Assembly (1) .....   | 273        |
| Rear Oil Seal .....  | 222        | Adjustment .....   | 285        |
| Output Speed Sensor .....  | 222        | Assembly (2) .....   | 287        |
| <b>AIR BREATHER HOSE</b> .....                                       | <b>228</b> | <b>SERVICE DATA AND SPECIFICATIONS</b>   |            |
| Removal and Installation .....                                       | 228        | <b>(SDS)</b> .....   | <b>294</b> |
| <b>TRANSMISSION ASSEMBLY</b> .....                                   | <b>229</b> | General Specification .....  | 294        |
| Removal and Installation .....                                       | 229        | Vehicle Speed at Which Gear Shifting Occurs ....                                     | 294        |
| <b>OVERHAUL</b> .....  | <b>232</b> | Vehicle Speed at Which Lock-up Occurs/Releas-<br>es .....                            | 294        |
| Component .....  | 232        | Stall Speed .....  | 294        |
| Oil Channel .....  | 237        | Line Pressure .....  | 295        |
|  |            | A/T Fluid Temperature Sensor .....   | 295        |
|  |            | Input Speed Sensor .....   | 295        |
|  |            | Output Speed Sensor .....  | 295        |
|  |            | Reverse Brake .....  | 295        |
|  |            | Total End Play .....   | 295        |

# INDEX FOR DTC

< SERVICE INFORMATION >

## SERVICE INFORMATION

### INDEX FOR DTC

#### Alphabetical Index

INFOID:000000004656774

**NOTE:**

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMM CIRCUIT”. Refer to [AT-90](#).

| Items<br>(CONSULT-III screen terms) | DTC   |   | Reference page         |
|-------------------------------------|---|---|------------------------|
|                                     | OBD-II  | Except OBD-II                           |                        |
|                                     | MIL*1, “ENGINE” with<br>CONSULT-III or<br>GST*2 | CONSULT-III<br>only “TRANSMIS-<br>SION” |                        |
| 1ST E/BRAKING                       | —   | P1731                                   | <a href="#">AT-137</a> |
| 1GR INCORRECT RATIO                 | P0731   | P0731                                   | <a href="#">AT-110</a> |
| 2GR INCORRECT RATIO                 | P0732   | P0732                                   | <a href="#">AT-112</a> |
| 3GR INCORRECT RATIO                 | P0733   | P0733                                   | <a href="#">AT-114</a> |
| 4GR INCORRECT RATIO                 | P0734   | P0734                                   | <a href="#">AT-116</a> |
| 5GR INCORRECT RATIO                 | P0735   | P0735                                   | <a href="#">AT-118</a> |
| INTERLOCK                           | P1730   | P1730                                   | <a href="#">AT-135</a> |
| TORQUE CONVERTER                    | P0744*3   | P0744                                   | <a href="#">AT-122</a> |
| TRANS FLUID TEMP SEN                | P0710   | P1710                                   | <a href="#">AT-128</a> |
| CAN COMM CIRCUIT                    | U1000   | U1000                                   | <a href="#">AT-90</a>  |
| DRCT CLUTCH SOL                     | P1762   | P1762                                   | <a href="#">AT-143</a> |
| ENGINE SPEED                        | P0725   | P0725                                   | <a href="#">AT-108</a> |
| FR BRAKE SOLENOID                   | P1757   | P1757                                   | <a href="#">AT-141</a> |
| HLR CLUTCH SOLENOID                 | P1767   | P1767                                   | <a href="#">AT-145</a> |
| INPUT CLUTCH SOL                    | P1752   | P1752                                   | <a href="#">AT-139</a> |
| PC SOLENOID A                       | P0745   | P0745                                   | <a href="#">AT-124</a> |
| L C BRAKE SOLENOID                  | P1772   | P1772                                   | <a href="#">AT-147</a> |
| L C BRAKE SOLENOID                  | P1774*3   | P1774                                   | <a href="#">AT-149</a> |
| M-MODE SWITCH                       | —   | P1815                                   | <a href="#">AT-151</a> |
| T/M RANGE SWITCH A                  | P0705   | P0705                                   | <a href="#">AT-98</a>  |
| STARTER RELAY                       | —   | P0615                                   | <a href="#">AT-93</a>  |
| TORQUE CONVERTER                    | P0740   | P0740                                   | <a href="#">AT-120</a> |
| TRANSMISSION CONT                   | P0700   | P0700                                   | <a href="#">AT-97</a>  |
| TP SENSOR                           | —   | P1705                                   | <a href="#">AT-126</a> |
| INPUT SPEED SENSOR A                | P0717   | P0717                                   | <a href="#">AT-101</a> |
| VEHICLE SPEED SIGNAL                | —   | P1721                                   | <a href="#">AT-133</a> |
| OUTPUT SPEED SENSOR                 | P0720   | P0720                                   | <a href="#">AT-103</a> |

\*1: Refer to [AT-38, "Malfunction Indicator Lamp \(MIL\)"](#).

\*2: These numbers are prescribed by SAE J2012.

\*3: These malfunctions cannot be displayed MIL if another malfunction is assigned to MIL.

#### DTC No. Index

INFOID:000000004656775

**NOTE:**

# INDEX FOR DTC

## < SERVICE INFORMATION >

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMM CIRCUIT”. Refer to [AT-90](#).

| DTC                                       |                                 | Items<br>(CONSULT-III screen terms) | Reference page         |
|---|---------------------------------|-------------------------------------|------------------------|
| OBD-II                                    | Except OBD-II                   |                                     |                        |
| MIL*1, “ENGINE” with CONSULT-III or GST*2 | CONSULT-III only “TRANSMISSION” |                                     |                        |
| —   | P0615                           | STARTER RELAY                       | <a href="#">AT-93</a>  |
| P0700                                     | P0700                           | TRANSMISSION CONT                   | <a href="#">AT-97</a>  |
| P0705                                     | P0705                           | T/M RANGE SWITCH A                  | <a href="#">AT-98</a>  |
| P0710                                     | P1710                           | TRANS FLUID TEMP SEN                | <a href="#">AT-128</a> |
| P0717                                     | P0717                           | INPUT SPEED SENSOR A                | <a href="#">AT-101</a> |
| P0720                                     | P0720                           | OUTPUT SPEED SENSOR                 | <a href="#">AT-103</a> |
| P0725                                     | P0725                           | ENGINE SPEED                        | <a href="#">AT-108</a> |
| P0731                                     | P0731                           | 1GR INCORRECT RATIO                 | <a href="#">AT-110</a> |
| P0732                                     | P0732                           | 2GR INCORRECT RATIO                 | <a href="#">AT-112</a> |
| P0733                                     | P0733                           | 3GR INCORRECT RATIO                 | <a href="#">AT-114</a> |
| P0734                                     | P0734                           | 4GR INCORRECT RATIO                 | <a href="#">AT-116</a> |
| P0735                                     | P0735                           | 5GR INCORRECT RATIO                 | <a href="#">AT-118</a> |
| P0740                                     | P0740                           | TORQUE CONVERTER                    | <a href="#">AT-120</a> |
| P0744*2                                   | P0744                           | TORUQE CONVERTER                    | <a href="#">AT-122</a> |
| P0745                                     | P0745                           | PC SOLENOID A                       | <a href="#">AT-124</a> |
| —   | P1705                           | TP SENSOR                           | <a href="#">AT-126</a> |
| —   | P1721                           | VEHICLE SPEED SIGNAL                | <a href="#">AT-133</a> |
| P1730                                     | P1730                           | INTERLOCK                           | <a href="#">AT-135</a> |
| —   | P1731                           | 1ST E/BRAKING                       | <a href="#">AT-137</a> |
| P1752                                     | P1752                           | INPUT CLUTCH SOL                    | <a href="#">AT-139</a> |
| P1757                                     | P1757                           | FR BRAKE SOLENOID                   | <a href="#">AT-141</a> |
| P1762                                     | P1762                           | DRCT CLUTCH SOL                     | <a href="#">AT-143</a> |
| P1767                                     | P1767                           | HLR CLUTCH SOLENOID                 | <a href="#">AT-145</a> |
| P1772                                     | P1772                           | L C BRAKE SOLENOID                  | <a href="#">AT-147</a> |
| P1774*2                                   | P1774                           | L C BRAKE SOLENOID                  | <a href="#">AT-149</a> |
| —   | P1815                           | M-MODE SWITCH                       | <a href="#">AT-151</a> |
| U1000                                     | U1000                           | CAN COMM CIRCUIT                    | <a href="#">AT-90</a>  |

\*1: Refer to [AT-38](#), “Malfunction Indicator Lamp (MIL)”.

\*2: These numbers are prescribed by SAE J2012.

\*3: These malfunctions cannot be displayed MIL if another malfunction is assigned to MIL.

# PRECAUTIONS

< SERVICE INFORMATION >

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005874501

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SUPPLEMENTAL RESTRAINT SYSTEM" and "SEAT BELTS" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SUPPLEMENTAL RESTRAINT SYSTEM".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution for Battery Service

INFOID:000000004656777

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

### Precaution for On Board Diagnosis (OBD) System of A/T and Engine

INFOID:000000004656778

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

#### **CAUTION:**

- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. Will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. May cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EVAP system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.


# PRECAUTIONS

< SERVICE INFORMATION >


## Precaution

INFOID:000000004656779

- Before connecting or disconnecting the A/T assembly harness connector, turn ignition switch OFF and disconnect the battery cable from the negative terminal. Because battery voltage is applied to TCM even if ignition switch is turned OFF.



- After performing each TROUBLE DIAGNOSIS, perform "DTC Confirmation Procedure". If the repair is completed the DTC should not be displayed in the "DTC Confirmation Procedure".



- Always use the specified brand of ATF. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use lint-free paper not cloth rags during work.
- After replacing the ATF, dispose of the waste oil using the methods prescribed by law, ordinance, etc.
- Before proceeding with disassembly, thoroughly clean the outside of the A/T. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free paper or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the A/T.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the A/T is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place disassembled valve body parts in order for easier and proper assembly. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, or hold bearings and washers in place during assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- Clean or replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer. Refer to [AT-8, "Service Notice or Precaution"](#).
- After overhaul, refill the A/T with new ATF.
- When the A/T drain plug is removed, only some of the ATF is drained. Old ATF will remain in torque converter and ATF cooling system. Always follow the procedures under "Changing A/T Fluid" in the AT section when changing A/T fluid. Refer to [AT-12, "Changing A/T Fluid"](#), [AT-12, "Checking A/T Fluid"](#).

## Service Notice or Precaution

INFOID:000000004656780

### ATF COOLER SERVICE

If ATF contains frictional material (clutches, bands, etc.), or if an A/T is repaired, overhauled, or replaced, inspect and clean the A/T fluid cooler mounted in the radiator or replace the radiator. Flush cooler lines using



# PRECAUTIONS

## < SERVICE INFORMATION >

cleaning solvent and compressed air after repair. For A/T fluid cooler cleaning procedure, refer to [AT-14, "A/T Fluid Cooler Cleaning"](#). For radiator replacement, refer to [CO-12](#).

### OBD-II SELF-DIAGNOSIS

- A/T self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the A/T CHECK indicator or the malfunction indicator lamp (MIL). Refer to the table on [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#) for the indicator used to display each self-diagnostic result.

- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.

**Always perform the procedure on [AT-37, "OBD-II Diagnostic Trouble Code \(DTC\)"](#) to complete the repair and avoid unnecessary blinking of the MIL.**

For details of OBD-II, refer to [EC-45](#).

- **Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-74](#).**

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION






< SERVICE INFORMATION >

## PREPARATION

### Special Service Tool

INFOID:000000004656781

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |
|---|---|
| ST2505S001<br>(J-34301-C)<br>Oil pressure gauge set<br>1. ST25051001<br>( — )<br>Oil pressure gauge<br>2. ST25052000<br>( — )<br>Hose<br>3. ST25053000<br>( — )<br>Joint pipe<br>4. ST25054000<br>( — )<br>Adapter<br>5. ST25055000<br>( — )<br>Adapter | Measuring line pressure    |
| KV31103600<br>(J-45674)<br>Joint pipe adapter<br>(With ST25054000)  | Measuring line pressure  <p style="text-align: center;">ZZA1227D</p>  |
| ST33400001<br>(J-26082)<br>Drift<br>a: 60 mm (2.36 in) dia.<br>b: 47 mm (1.85 in) dia.  | <ul style="list-style-type: none"> <li>• Installing rear oil seal</li> <li>• Installing oil pump housing oil seal</li> </ul>  <p style="text-align: center;">NT086</p> |
| KV31102400<br>(J-34285 and J-34285-87)<br>Clutch spring compressor<br>a: 320 mm (12.60 in)<br>b: 174 mm (6.85 in)   | Installing reverse brake return spring retainer  <p style="text-align: center;">NT423</p>  |
| ST25850000<br>(J-25721-A)<br>Sliding hammer<br>a: 179 mm (7.05 in)<br>b: 70 mm (2.76 in)<br>c: 40 mm (1.57 in)<br>d: M12X1.75P  | Remove oil pump assembly  <p style="text-align: center;">NT422</p>   |

### Commercial Service Tool

INFOID:000000004656782

# PREPARATION

## < SERVICE INFORMATION >

| Tool name   | Description                              |
|---|--|
| <p>Power tool</p>  <p style="text-align: right; margin-right: 50px;">PBIC0190E</p>                       | <p>Loosening bolts and nuts</p>          |
| <p>Drift<br/>a: 22 mm (0.87 in) dia.</p>  <p style="text-align: right; margin-right: 50px;">NT083</p>    | <p>Installing manual shaft oil seals</p> |
| <p>Pin punch<br/>a: 4 mm (0.16 in) dia.</p>  <p style="text-align: right; margin-right: 50px;">NT410</p> | <p>Removing retaining pin</p>            |

A

B

**AT**

D

E

F

G

H

I

J

K

L

M

N

O

P

# A/T FLUID


< SERVICE INFORMATION >

## A/T FLUID

### Changing A/T Fluid

INFOID:000000004656783

1. Warm up ATF.
2. Stop the engine.
3. Loosen the level gauge bolt.
4. Drain ATF from drain plug and refill with new ATF. Always refill same volume with drained ATF.
  - To replace the ATF, pour in new ATF at the A/T fluid charging pipe with the engine idling and at the same time drain the old ATF from the radiator cooler hose return side.
  - When the color of the ATF coming out is about the same as the color of the new ATF, the replacement is complete. The amount of new ATF to use should be 30 to 50% increase of the stipulated amount.



**ATF:** **Genuine NISSAN Matic J ATF**  
**Fluid capacity:** **10.3 ℓ (10-7/8 US qt, 9-1/8 Imp qt)**

#### CAUTION:

- Use only Genuine NISSAN Matic J ATF. Do not mix with other ATF.
- Using ATF other than Genuine NISSAN Matic J ATF will cause deterioration in driveability and A/T durability, and may damage the A/T, which is not covered by the NISSAN new vehicle limited warranty.
- When filling ATF, take care not to splash heat generating parts such as exhaust with ATF.
- Do not reuse drain plug gasket.

#### Drain plug:

 : **34 N·m (3.5 kg-m, 25 ft-lb)**

5. Run engine at idle speed for 5 minutes.
6. Check A/T fluid level and condition. Refer to [AT-12, "Checking A/T Fluid"](#). If ATF is still dirty, repeat step 2. through 5.
7. Install the removed A/T fluid level gauge in the A/T fluid charging pipe.
8. Tighten the level gauge bolt.

#### Level gauge bolt:


 : **5.1 N·m (0.52 kg-m, 45 in-lb)**

### Checking A/T Fluid

INFOID:000000004656784

1. Warm up engine.
2. Check for A/T fluid leakage.
3. Loosen the level gauge bolt.
4. Before driving, A/T fluid level can be checked at A/T fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on A/T fluid level gauge as follows.
  - a. Park vehicle on level surface and set parking brake.
  - b. Start the engine and move selector lever through each gear position. Leave selector lever in "P" position.
  - c. Check A/T fluid level with engine idling.
  - d. Remove A/T fluid level gauge and wipe clean with lint-free paper.

#### CAUTION:



# A/T FLUID

## < SERVICE INFORMATION >

**When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.**

- e. Re-insert A/T fluid level gauge into A/T fluid charging pipe as far as it will go.

**CAUTION:**

**To check A/T fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the A/T fluid level gauge reversed from the normal attachment conditions.**

- f. Remove A/T fluid level gauge and note reading. If reading is at low side of range, add ATF to the A/T fluid charging pipe.


**CAUTION:**

**Do not overfill.**

5. Drive vehicle for approximately 5 minutes in urban areas.
6. Make the A/T fluid temperature approximately 65°C (149°F).

**NOTE:**

**A/T fluid level will be greatly affected by temperature as shown in the figure. Therefore, be certain to perform operation while checking data with CONSULT-III.**




- a. Select "DATA MONITOR".
- b. Read out the value of "ATF TEMP 1".
7. Re-check A/T fluid level at A/T fluid temperatures of approximately 65°C (149°F) using "HOT" range on A/T fluid level gauge.

**CAUTION:**

- **When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.**
- **To check A/T fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the A/T fluid level gauge rotated from the normal attachment conditions as shown.**

8. Check A/T fluid condition.
  - If ATF is very dark or smells burned, check operation of A/T. Flush cooling system after repair of A/T.
  - If ATF contains frictional material (clutches, bands, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of A/T. Refer to [CO-12](#) and [AT-14, "A/T Fluid Cooler Cleaning"](#).



9. Install the removed A/T fluid level gauge in the A/T fluid charging pipe.

# A/T FLUID


## < SERVICE INFORMATION >

10. Tighten level gauge bolt.

### Level gauge bolt:



: 5.1 N·m (0.52 kg·m, 45 in·lb)



## A/T Fluid Cooler Cleaning

INFOID:000000004656785

Whenever an A/T is replaced, the A/T fluid cooler mounted in the radiator must be inspected and cleaned. Metal debris and friction material, if present, can become trapped in the A/T fluid cooler. This debris can contaminate the newly serviced A/T or, in severe cases, can block or restrict the flow of ATF. In either case, malfunction of the newly serviced A/T may result.

Debris, if present, may build up as ATF enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


### A/T FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the A/T inlet and outlet cooler hoses.
2. Identify the inlet and outlet A/T fluid cooler hoses.
3. Disconnect the A/T fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

#### NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any ATF that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

#### CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.


6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until ATF flows out of the cooler inlet hose for 5 seconds.



## A/T FLUID

### < SERVICE INFORMATION >

7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and of the cooler outlet hose.
9. Blow compressed air regulated to 5 to 9 kg/cm<sup>2</sup> (71 to 128 psi) through the cooler outlet hose for 10 seconds to force out any remaining ATF.
10. Repeat steps 5 through 9 three additional times.
11. Position an oil pan under the banjo bolts that connect the A/T fluid cooler steel lines to the A/T.
12. Remove the banjo bolts.
13. Flush each steel line from the cooler side back toward the A/T by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.
14. Blow compressed air regulated to 5 to 9 kg/cm<sup>2</sup> (71 to 128 psi) through each steel line from the cooler side back toward the A/T for 10 seconds to force out any remaining ATF.
15. Ensure all debris is removed from the steel cooler lines.
16. Ensure all debris is removed from the banjo bolts and fittings.
17. Perform "A/T FLUID COOLER DIAGNOSIS PROCEDURE".



### A/T FLUID COOLER DIAGNOSIS PROCEDURE



#### NOTE:

Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.

1. Position an oil pan under the A/T inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

#### CAUTION:


- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
  - Spray Transmission Cooler Cleaner only with adequate ventilation.
  - Avoid contact with eyes and skin.
  - Do not breath vapors or spray mist.
4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until ATF flows out of the cooler inlet hose for 5 seconds.
  5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.



## A/T FLUID



### < SERVICE INFORMATION >

6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm<sup>2</sup> (71 to 128 psi) through the cooler outlet hose to force any remaining ATF into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform "A/T FLUID COOLER INSPECTION PROCEDURE".



### A/T FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
  - a. If small metal debris less than 1 mm (0.04 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the A/T fluid cooler/radiator can be re-used and the procedure is ended.
  - b. If one or more pieces of debris are found that are over 1 mm (0.04 in) in size and/or peeled clutch facing material is found in the coffee filter, the A/T fluid cooler is not serviceable. The A/T fluid cooler/radiator must be replaced and the inspection procedure is ended. Refer to [CO-12](#) and [CO-16](#).



### A/T FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.




# A/T CONTROL SYSTEM

< SERVICE INFORMATION >

## A/T CONTROL SYSTEM

### Cross-Sectional View

INFOID:000000004656786



SCIA5262E

- |                         |                                |                            |
|-------------------------|--------------------------------|----------------------------|
| 1. Front planetary gear | 2. Mid planetary gear          | 3. Rear planetary gear     |
| 4. Direct clutch        | 5. High and low reverse clutch | 6. Reverse brake           |
| 7. Drum support         | 8. Forward brake               | 9. Low coast brake         |
| 10. Input shaft         | 11. Torque converter           | 12. Oil pump               |
| 13. Front brake         | 14. 3rd one-way clutch         | 15. Input clutch           |
| 16. 1st one-way clutch  | 17. Control valve with TCM     | 18. Forward one-way clutch |
| 19. Rear extension      | 20. Output shaft               |                            |

### Shift Mechanism

INFOID:000000004656787


The A/T uses compact triple planetary gear systems to improve power transmission efficiency, simplify construction and reduce weight.

It also employs an optimum shift control and super wide gear ratios. They improve starting performance and acceleration during medium and high-speed operation.

### CONSTRUCTION

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

## FUNCTION OF CLUTCH AND BRAKE

| Name of the Part                | Abbreviation | Function  |
|---------------------------------|--------------|---|
| Front brake (1)                 | FR/B         | Fastens the front sun gear (11).  |
| Input clutch (2)                | I/C          | Connects the input shaft (12), the front internal gear (14) and the mid internal gear (13).                                 |
| Direct clutch (3)               | D/C          | Connects the rear carrier (15) and the rear sun gear (16).  |
| High and low reverse clutch (4) | HLR/C        | Connects the mid sun gear (17) and the rear sun gear (16).  |
| Reverse brake (5)               | R/B          | Fastens the rear carrier (15).  |
| Forward brake (6)               | Fwd/B        | Fastens the mid sun gear (17).  |
| Low coast brake (7)             | LC/B         | Fastens the mid sun gear (17).  |
| 1st one-way clutch (8)          | 1st OWC      | Allows the rear sun gear (16) to turn freely forward relative to the mid sun gear (17) but fastens it for reverse rotation. |
| Forward one-way clutch (9)      | Fwd OWC      | Allows the mid sun gear (17) to turn freely in the forward direction but fastens it for reverse rotation.                   |
| 3rd one-way clutch (10)         | 3rd OWC      | Allows the front sun gear (11) to turn freely in the forward direction but fastens it for reverse rotation.                 |


# A/T CONTROL SYSTEM

< SERVICE INFORMATION >

## CLUTCH AND BAND CHART

| Shift position | I/C | HLR/C | D/C | R/B | FR/B | LC/B | Fwd/B | 1st OWC | Fwd OWC | 3rd OWC | Remarks                              |
|----------------|-----|-------|-----|-----|------|------|-------|---------|---------|---------|--------------------------------------|
| P              |     | △     |     |     | △    |      |       |         |         |         | PARK POSITION                        |
| R              |     | ○     |     | ○   | ○    |      |       | ◎       |         | ◎       | REVERSE POSITION                     |
| N              |     | △     |     |     | △    |      |       |         |         |         | NEUTRAL POSITION                     |
| D              | 1st |       | △ * |     | △    | △ ** | ○     | ◎       | ◎       | ◎       | Automatic shift<br>1→2→3→4→5         |
|                | 2nd |       |     | ○   | △    |      | ○     |         | ◎       | ◎       |                                      |
|                | 3rd |       | ○   | ○   |      | ○    | △     | ◇       |         | ◎       |                                      |
|                | 4th | ○     | ○   | ○   |      |      | △     | ◇       |         |         |                                      |
|                | 5th | ○     | ○   |     |      | ○    | △     | ◇       |         | ◇       |                                      |
| M5             |     | ○     | ○   |     | ○    |      | △     | ◇       |         | ◇       | Locks* (held stationary) in 5th gear |
| M4             |     | ○     | ○   | ○   |      |      | △     | ◇       |         |         | Locks* (held stationary) in 4th gear |
| M3             |     |       | ○   | ○   |      | ○    | △     | ◇       |         | ◎       | Locks* (held stationary) in 3rd gear |
| M2             |     |       |     | ○   |      | ○    | ○     |         | ◎       | ◎       | Locks* (held stationary) in 2nd gear |
| M1             |     |       |     |     | ○    | ○    | ○     | ◎       | ◎       | ◎       | Locks* (held stationary) in 1st gear |

- — Operates
- ◎ — Operates during "progressive" acceleration.
- ◇ — Operates and affects power transmission while coasting.
- △ — Line pressure is applied but does not affect power transmission.
- △ \* — Operates under conditions shown in illustration ①.
- △ \*\* — Operates under conditions shown in illustration ②. Delay control is applied during D (4,3,2,1) → N shift.



SCIA6962E

## POWER TRANSMISSION

“N” Position


Since both the forward brake and the reverse brake are released, torque from the input shaft drive is not transmitted to the output shaft.

“P” Position

# A/T CONTROL SYSTEM

## < SERVICE INFORMATION >

- The same as for the “N” position, both the forward brake and the reverse brake are released, so torque from the input shaft drive is not transmitted to the output shaft.
- The parking pawl linked with the selector lever meshes with the parking gear and fastens the output shaft mechanically.




- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

### “D1” Position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 1st one-way clutch regulates reverse rotation of the rear sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and the engine brake is not activated.

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |


## "M1" Position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- High and low reverse clutch connects the rear sun gear and the mid sun gear.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >




- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

## "D2" Position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and engine brake is not activated.

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >




- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

## "M2" Position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |


## “D3” and “M3” Positions

- The front brake fastens the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.



# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |


## “D4” and “M4” Positions

- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The drive power is conveyed to the front internal gear, mid internal gear, and rear carrier and the three planetary gears rotate forward as one unit.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >




- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

## "D5" and "M5" Positions

- The front brake fastens the front sun gear.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |


## "R" Position

- The front brake fastens the front sun gear.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The reverse brake fastens the rear carrier.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >



- |                                |                         |                           |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake                 | 2. Input clutch         | 3. Direct clutch          |
| 4. High and low reverse clutch | 5. Reverse brake        | 6. Forward brake          |
| 7. Low coast brake             | 8. 1st one-way clutch   | 9. Forward one-way clutch |
| 10. 3rd one-way clutch         | 11. Front sun gear      | 12. Input shaft           |
| 13. Mid internal gear          | 14. Front internal gear | 15. Rear carrier          |
| 16. Rear sun gear              | 17. Mid sun gear        | 18. Front carrier         |
| 19. Mid carrier                | 20. Rear internal gear  | 21. Output shaft          |
| 22. Parking gear               | 23. Parking pawl        |                           |

## TCM Function

INFOID:000000004656788

The function of the TCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

## CONTROL SYSTEM OUTLINE


The A/T senses vehicle operating conditions through various sensors or signals. It always controls the optimum shift position and reduces shifting and lock-up shocks.

| SENSORS (or SIGNALS)   |   | TCM   |   | ACTUATORS  |
|--|---|---|---|--|
| Transmission range switch<br>Accelerator pedal position signal<br>Closed throttle position signal<br>Wide open throttle position signal<br>Engine speed signal<br>A/T fluid temperature sensor<br>Output speed sensor<br>Vehicle speed signal<br>Manual mode switch signal<br>Stop lamp switch signal<br>Input speed sensor<br>ATF pressure switch | ⇒ | Shift control<br>Line pressure control<br>Lock-up control<br>Engine brake control<br>Timing control<br>Fail-safe control<br>Self-diagnosis<br>CONSULT-III communication line<br>Duet-EA control<br>CAN system | ⇒ | Input clutch solenoid valve<br>Direct clutch solenoid valve<br>Front brake solenoid valve<br>High and low reverse clutch solenoid valve<br>Low coast brake solenoid valve<br>Torque converter clutch solenoid valve<br>Line pressure solenoid valve<br>A/T CHECK indicator lamp<br>Starter relay<br>Back-up lamp relay |

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >

## CONTROL SYSTEM DIAGRAM



## CAN Communication

INFOID:000000004656789

## SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. For details, refer to [LAN-41](#), "[CAN System Specification Chart](#)".

# A/T CONTROL SYSTEM

< SERVICE INFORMATION >

## Input/Output Signal of TCM

INFOID:000000004656790

| Control item |  | Line pressure control                   | Vehicle speed control | Shift control | Lock-up control | Engine brake control | Fail-safe function <sup>(*3)</sup> | Self-diagnostics function |  |
|--------------|--|---|-----------------------|---------------|-----------------|----------------------|------------------------------------|---------------------------|--|
| Input        | Accelerator pedal position signal <sup>(*5)</sup>        | X                                       | X                     | X             | X               | X                    | X                                  | X                         |  |
|              | Vehicle speed sensor A/T (revolution sensor)             | X                                       | X                     | X             | X               | X                    | X                                  | X                         |  |
|              | Vehicle speed sensor MTR <sup>(*1)</sup> <sup>(*5)</sup> |   |                       |               |                 |                      | X                                  |                           |  |
|              | Closed throttle position signal <sup>(*5)</sup>          |   | X <sup>(*2)</sup>     | X             | X               |                      | X                                  | X <sup>(*4)</sup>         |  |
|              | Wide open throttle position signal <sup>(*5)</sup>       |   |                       |               |                 |                      | X                                  | X <sup>(*4)</sup>         |  |
|              | Turbine revolution sensor 1                              |   | X                     |               | X               | X                    | X                                  | X                         |  |
|              | Turbine revolution sensor 2 (for 4th speed only)         |   | X                     |               | X               | X                    | X                                  | X                         |  |
|              | Engine speed signals <sup>(*5)</sup>                     | X                                       | X                     | X             | X               | X                    | X                                  | X                         |  |
|              | Stop lamp switch signal <sup>(*5)</sup>                  |   | X                     | X             | X               |                      |                                    | X <sup>(*4)</sup>         |  |
|              | A/T fluid temperature sensors 1, 2                       | X                                       | X                     | X             | X               |                      | X                                  | X                         |  |
|              | ASCD   | Operation signal <sup>(*5)</sup>        |                       | X             | X               | X                    |                                    |                           |  |
|              |  | Overdrive cancel signal <sup>(*5)</sup> |                       | X             |                 |                      |                                    |                           |  |
| Output       | Direct clutch solenoid                                   |   | X                     | X             |                 |                      | X                                  | X                         |  |
|              | Input clutch solenoid                                    |   | X                     | X             |                 |                      | X                                  | X                         |  |
|              | High and low reverse clutch solenoid                     |   | X                     | X             |                 |                      | X                                  | X                         |  |
|              | Front brake solenoid                                     |   | X                     | X             |                 |                      | X                                  | X                         |  |
|              | Low coast brake solenoid (ATF pressure switch 2)         |   | X                     | X             |                 | X                    | X                                  | X                         |  |
|              | Line pressure solenoid                                   | X                                       | X                     | X             | X               | X                    | X                                  | X                         |  |
|              | TCC solenoid   |   |                       |               | X               |                      | X                                  | X                         |  |
|              | Self-diagnostics table <sup>(*6)</sup>                   |   |                       |               |                 |                      |                                    | X                         |  |
|              | Starter relay  |   |                       |               |                 |                      | X                                  | X                         |  |

\*1: Spare for vehicle speed sensor A/T (revolution sensor)

\*2: Spare for accelerator pedal position signal

\*3: If these input and output signals are different, the TCM triggers the fail-safe function.

\*4: Used as a condition for starting self-diagnostics; if self-diagnostics are not started, it is judged that there is some kind of error.

\*5: Input by CAN communications

\*6: Output by CAN communications

## Line Pressure Control


INFOID:000000004656791

- When an input torque signal equivalent to the engine drive force is sent from the ECM to the TCM, the TCM controls the line pressure solenoid.

# A/T CONTROL SYSTEM

## < SERVICE INFORMATION >

- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving state.




### LINE PRESSURE CONTROL IS BASED ON THE TCM LINE PRESSURE CHARACTERISTIC PATTERN

- The TCM has stored in memory a number of patterns for the optimum line pressure characteristic for the driving state.
- In order to obtain the most appropriate line pressure characteristic to meet the current driving state, the TCM controls the line pressure solenoid current valve and thus controls the line pressure.


#### Normal Control

Each clutch is adjusted to the necessary pressure to match the engine drive force.



#### Back-up Control (Engine Brake)

When the select operation is performed during driving and the A/T is shifted down, the line pressure is set according to the vehicle speed.




#### During Shift Change

# A/T CONTROL SYSTEM


## < SERVICE INFORMATION >

The necessary and adequate line pressure for shift change is set. For this reason, line pressure pattern setting corresponds to input torque and gearshift selection. Also, line pressure characteristic is set according to engine speed, during engine brake operation.



### At Low Fluid Temperature


When the A/T fluid temperature drops below the prescribed temperature, in order to speed up the action of each friction element, the line pressure is set higher than the normal line pressure characteristic.



## Shift Control

INFOID:000000004656792

The clutch pressure control solenoid is controlled by the signals from the switches and sensors. Thus, the clutch pressure is adjusted to be appropriate to the engine load state and vehicle driving state. It becomes possible to finely control the clutch hydraulic pressure with high precision and a smoother shift change characteristic is attained.



### NORMAL SHIFT CONTROL


The clutch is controlled with the optimum timing and oil pressure by the engine speed, engine torque information, etc.

### Shift Change System Diagram



# A/T CONTROL SYSTEM

## < SERVICE INFORMATION >




\*1: Full phase real-time feedback control monitors movement of gear ratio at gear change, and controls oil pressure at real-time to achieve the best gear ratio.

### BLIPPING CONTROL

This system makes transmission clutch engage readily by controlling (synchronizing) engine revolution according to the (calculation of) engine revolution after shifting down.

- “BLIPPING CONTROL” functions.
  - When downshifting by accelerator pedal depression at “D” position.
  - When downshifting under the manual mode.
- TCM selects “BLIPPING CONTROL” or “NORMAL SHIFT CONTROL” according to the gear position, the select lever position, the engine torque and the speed when accelerating by pedal depression.
- Revolution control demand signal is transmitted from TCM to ECM under “BLIPPING CONTROL”.
- TCM synchronizes engine revolution according to the revolution control demand signal.

### Shift Change System Diagram



### Lock-up Control

INFOID:000000004656793

The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.

The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM, and the torque converter clutch control valve engages or releases the torque converter clutch piston.

# A/T CONTROL SYSTEM


## < SERVICE INFORMATION >

Lock-up operation condition table

| selector lever | "D" position |   | "M" position |   |   |   |
|----------------|--------------|---|--------------|---|---|---|
|                | 5            | 4 | 5            | 4 | 3 | 2 |
| Gear position  | 5            | 4 | 5            | 4 | 3 | 2 |
| Lock-up        | ×            | — | ×            | × | × | × |
| Slip lock-up   | ×            | × | —            | — | — | — |

## TORQUE CONVERTER CLUTCH CONTROL VALVE CONTROL

Lock-up Control System Diagram



### Lock-up Released

In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid and the lock-up apply pressure is drained.

In this way, the torque converter clutch piston is not coupled.

### Lock-up Applied

In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid and lock-up apply pressure is generated.

In this way, the torque converter clutch piston is pressed and coupled.

## SMOOTH LOCK-UP CONTROL

When shifting from the lock-up released state to the lock-up applied state, the current output to the torque converter clutch solenoid is controlled with the TCM. In this way, when shifting to the lock-up applied state, the torque converter clutch is temporarily set to the half-clutched state to reduce the shock.

### Half-clutched State

The current output from the TCM to the torque converter clutch solenoid is varied to gradually increase the torque converter clutch solenoid pressure.

In this way, the lock-up apply pressure gradually rises and while the torque converter clutch piston is put into half-clutched status, the torque converter clutch piston operating pressure is increased and the coupling is completed smoothly.

### Slip Lock-up Control

In the slip region, the torque converter clutch solenoid current is controlled with the TCM to put it into the half-clutched state. This absorbs the engine torque fluctuation and lock-up operates from low speed.

This raises the fuel efficiency for 4GR and 5GR at both low speed and when the accelerator has a low degree of opening.

## Engine Brake Control


INFOID:000000004656794

- The forward one-way clutch transmits the drive force from the engine to the rear wheels. But the reverse drive from the rear wheels is not transmitted to the engine because the one-way clutch is idling.

# A/T CONTROL SYSTEM

## < SERVICE INFORMATION >

Therefore, the low coast brake solenoid is operated to prevent the forward one-way clutch from idling and the engine brake is operated in the same manner as conventionally.



- The operation of the low coast brake solenoid switches the low coast brake switching valve and controls the coupling and releasing of the low coast brake. The low coast brake reducing valve controls the low coast brake coupling force.

## Control Valve

INFOID:000000004656795

### FUNCTION OF CONTROL VALVE

| Name   | Function   |
|--|--|
| Torque converter regulator valve   | In order to prevent the pressure supplied to the torque converter from being excessive, the line pressure is adjusted to the optimum pressure (torque converter operating pressure).   |
| Pressure regulator valve<br>Pressure regulator plug<br>Pressure regulator sleeve | Adjusts the oil discharged from the oil pump to the optimum pressure (line pressure) for the driving state.  |
| Front brake control valve  | When the front brake is coupled, adjusts the line pressure to the optimum pressure (front brake pressure) and supplies it to the front brake. (In 1GR, 2GR, 3GR, and 5GR gears, adjusts the clutch pressure.)  |
| Accumulator control valve  | Adjusts the pressure (accumulator control pressure) acting on the accumulator piston and low coast reducing valve to the pressure appropriate to the driving state.  |
| Pilot valve A  | Adjusts the line pressure and produces the constant pressure (pilot pressure) required for line pressure control, shift change control, and lock-up control.   |
| Pilot valve B  | Adjusts the line pressure and produces the constant pressure (pilot pressure) required for shift change control.   |
| Low coast brake switching valve  | During engine braking, supplies the line pressure to the low coast brake reducing valve.   |
| Low coast brake reducing valve   | When the low coast brake is coupled, adjusts the line pressure to the optimum pressure (low coast brake pressure) and supplies it to the low coast brake.  |
| N-R accumulator  | Produces the stabilizing pressure for when N-R is selected.  |
| Direct clutch piston switching valve   | Operates in 4GR and switches the direct clutch coupling capacity.  |
| High and low reverse clutch control valve  | When the high and low reverse clutch is coupled, adjusts the line pressure to the optimum pressure (high and low reverse clutch pressure) and supplies it to the high and low reverse clutch. (In 1GR, 3GR, 4GR and 5GR, adjusts the clutch pressure.) |
| Input clutch control valve   | When the input clutch is coupled, adjusts the line pressure to the optimum pressure (input clutch pressure) and supplies it to the input clutch. (In 4GR and 5GR, adjusts the clutch pressure.)  |
| Direct clutch control valve  | When the direct clutch is coupled, adjusts the line pressure to the optimum pressure (direct clutch pressure) and supplies it to the direct clutch. (In 2GR, 3GR, and 4GR, adjusts the clutch pressure.)   |

## A/T CONTROL SYSTEM

### < SERVICE INFORMATION >

| Name  | Function   |
|---|--|
| TCC control valve<br>TCC control plug<br>TCC control sleeve | Switches the lock-up to operating or released. Also, by performing the lock-up operation transiently, lock-up smoothly.          |
| Torque converter lubrication valve                          | Operates during lock-up to switch the torque converter, cooling, and lubrication system oil passage.                             |
| Cool bypass valve   | Allows excess oil to bypass cooler circuit without being fed into it.  |
| Line pressure relief valve                                  | Discharges excess oil from line pressure circuit.  |
| N-D accumulator   | Produces the stabilizing pressure for when N-D is selected.  |
| Manual valve  | Sends line pressure to each circuit according to the select position. The circuits to which the line pressure is not sent drain. |

### FUNCTION OF ATF PRESSURE SWITCH

| Name                         | Function  |
|------------------------------|---|
| ATF pressure switch 2 (LC/B) | Detects any malfunction in the low coast brake hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode. |

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SERVICE INFORMATION >

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

### Introduction

INFOID:000000004656796

The A/T system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory but not the TCM memory.

The second is the TCM original self-diagnosis indicated by the A/T CHECK indicator lamp. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).

### OBD-II Function for A/T System

INFOID:000000004656797

The ECM provides emission-related on board diagnostic (OBD-II) functions for the A/T system. One function is to receive a signal from the TCM used with OBD-related parts of the A/T system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in "One or Two Trip Detection Logic" when a malfunction is sensed in relation to A/T system parts.

### One or Two Trip Detection Logic of OBD-II

INFOID:000000004656798

#### ONE TRIP DETECTION LOGIC

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

#### TWO TRIP DETECTION LOGIC

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — 1st trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — 2nd trip



The "Trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

### OBD-II Diagnostic Trouble Code (DTC)

INFOID:000000004656799

#### HOW TO READ DTC AND 1ST TRIP DTC

DTC and 1st trip DTC can be read by the following methods.

( with **CONSULT-III** or ( **GST**) CONSULT-III or GST (Generic Scan Tool) Examples: P0705, P0720 etc.

These DTC are prescribed by SAE J2012.

(CONSULT-III also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**  
**CONSULT-III can identify them as shown below, therefore, CONSULT-III (if available) is recommended.**

#### Freeze Frame Data and 1st Trip Freeze Frame Data

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-III or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-III screen, not on the GST. For detail, refer to [EC-111, "CONSULT-III Function \(ENGINE\)"](#).

Only one set of freeze frame data (either 1st trip freeze frame data of freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

## < SERVICE INFORMATION >

longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items                      |  |
|----------|----------------------------|--|
| 1        | Freeze frame data          | Misfire — DTC: P0300 - P0306<br>Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175 |
| 2        |                            | Except the above items (Includes A/T related items)  |
| 3        | 1st trip freeze frame data |  |

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

### HOW TO ERASE DTC

The diagnostic trouble code can be erased by CONSULT-III, GST or ECM DIAGNOSTIC TEST MODE as described following.

- **If the battery cable is disconnected, the diagnostic trouble code will be lost within 24 hours.**
- **When you erase the DTC, using CONSULT-III or GST is easier and quicker than switching the mode selector on the ECM.**

The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-46. "Emission-related Diagnostic Information"](#).

- **Diagnostic trouble codes (DTC)**
- **1st trip diagnostic trouble codes (1st trip DTC)**
- **Freeze frame data**
- **1st trip freeze frame data**
- **System readiness test (SRT) codes**
- **Test values**

#### HOW TO ERASE DTC (WITH CONSULT-III)

1. The emission related diagnostic information in the TCM and ECM can be erased by selecting "All Erase" in the "Description" of "FINAL CHECK" mode with CONSULT-III.

#### HOW TO ERASE DTC (WITH GST)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Perform "Erase Self-diagnosis". Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).
3. Select Mode 4 with GST (Generic Scan Tool). For details, refer to [EC-120. "Generic Scan Tool \(GST\) Function"](#).

#### HOW TO ERASE DTC (NO TOOLS)

The A/T CHECK indicator lamp is located on the instrument panel.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Perform "Erase Self-diagnosis". Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).
3. Perform "OBD-II SELF-DIAGNOSTIC PROCEDURE (No tools)". Refer to [EC-46. "Emission-related Diagnostic Information"](#).

### Malfunction Indicator Lamp (MIL)

INFOID:000000004656800


### DESCRIPTION

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

### < SERVICE INFORMATION >

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
  - If the MIL does not light up, refer to [DI-53](#), or see [EC-662](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



A

B

AT

D

E

F

G

H

I

J

K

L

M

N

O

P

# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## TROUBLE DIAGNOSIS

### DTC Inspection Priority Chart

INFOID:000000004656801

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

**NOTE:**

**If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMM CIRCUIT”. Refer to [AT-90](#).**

| Priority | Detected items (DTC)   |
|----------|------------------------|
| 1        | U1000 CAN COMM CIRCUIT |
| 2        | Except above           |

### Fail-Safe

INFOID:000000004656802

The TCM has an electrical fail-safe mode. This mode makes it possible to operate even if there is an error in a main electronic control input/output signal circuit.

In fail-safe mode, even if the selector lever is “D” or “M” mode, the A/T is fixed in 2nd, 4th or 5th (depending on the breakdown position), so the customer should feel “slipping” or “poor acceleration”.

Even when the electronic circuits are normal, under special conditions (for example, when slamming on the brake with the wheels spinning drastically and stopping the tire rotation), the A/T can go into fail-safe mode. If this happens, switch OFF the ignition switch for 10 seconds, then switch it ON again to return to the normal shift pattern. Therefore, the customer's vehicle has returned to normal, so handle according to the “WORK FLOW” (Refer to [AT-41](#)).

#### FAIL-SAFE FUNCTION

If any malfunction occurs in a sensor or solenoid, this function controls the A/T to mark driving possible.

##### Vehicle Speed Sensor A/T

Signals are input from two systems - from output speed sensor A/T (revolution sensor) installed on the A/T and from unified meter and A/C amp. so normal driving is possible even if there is a malfunction in one of the systems. And if output speed sensor A/T (revolution sensor) has unusual cases, 5GR and manual mode are prohibited.

##### Accelerator Pedal Position Sensor

If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the engine speed is fixed by ECM to a pre-determined engine speed to make driving possible.

##### Throttle Position Sensor

If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the accelerator opening angle is controlled by the idle signal sent from the ECM which is based on input indicating either idle condition or off-idle condition (pre-determined accelerator opening) in order to make driving possible.

##### Transmission Range Switch

In the unlikely event that a malfunction signal enters the TCM, the position indicator is switched OFF, the starter relay is switched OFF (starter starting is disabled), the back-up lamp relay switched OFF (back-up lamp is OFF) and the position is fixed to the “D” position to make driving possible.

##### Starter Relay

The starter relay is switched OFF. (Starter starting is disabled.)

##### Interlock

- If there is an interlock judgment malfunction, the transmission is fixed in 2GR to make driving possible.

**NOTE:**

**When the vehicle is driven fixed in 2GR a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.**

- When interlock is detected at the 3GR or more, it is locked at the 2GR.

##### A/T 1st Engine Braking



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

When there is an 1st engine brake judgment malfunction, the low coast brake solenoid is switched OFF to avoid the engine brake operation.

### Line Pressure Solenoid

The solenoid is switched OFF and the line pressure is set to the maximum hydraulic pressure to make driving possible.

### Torque Converter Clutch Solenoid

The solenoid is switched OFF to release the lock-up.

### Low Coast Brake Solenoid

When a malfunction (electrical or functional) occurs, in order to make driving possible, if the solenoid is ON, the A/T is held in 2GR; if the solenoid is OFF, the A/T is held in 4GR. (Engine brake is not applied in 1GR and 2GR.)

### Input Clutch Solenoid

If a malfunction (electrical or functional) occurs with the solenoid either ON or OFF, the A/T is held in 4GR to make driving possible.

### Direct Clutch Solenoid

If a malfunction (electrical or functional) occurs with the solenoid either ON or OFF, the A/T is held in 4GR to make driving possible.

### Front Brake Solenoid

If a malfunction (electrical or functional) occurs with the solenoid ON, in order to make driving possible, the A/T is held in 5GR; if the solenoid is OFF, 4GR.

### High and Low Reverse Clutch Solenoid

If a malfunction (electrical or functional) occurs with the solenoid either ON or OFF, the A/T is held in 4GR to make driving possible.

### Input Speed Sensor 1 or 2

The control is the same as if there were no turbine revolution sensors, 5GR and manual mode are prohibited.

## How to Perform Trouble Diagnosis for Quick and Accurate Repair


INFOID:000000004656803

### INTRODUCTION

The TCM receives a signal from the output speed sensor, accelerator pedal position sensor (throttle position sensor) or transmission range switch and provides shift control or lock-up control via A/T solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the A/T system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose an error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the errors. A road test with CONSULT-III (or GST) or a circuit tester connected should be performed. Follow the "WORK FLOW".




# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "DIAGNOSTIC WORKSHEET" as shown on the example (Refer to "Diagnostic Worksheet Chart") should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.



SEF234G


## WORK FLOW

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a malfunction. It is important to fully understand the symptoms or conditions for a customer complaint.

Make good use of the two sheets provided, "Information From Customer" and "Diagnostic Worksheet Chart", to perform the best troubleshooting possible.

## Work Flow Chart



SCIA8466E

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

- |                                 |                                  |                             |
|---------------------------------|----------------------------------|-----------------------------|
| *1. "Information From Customer" | *2. "Diagnostic Worksheet Chart" | *3. <a href="#">AT-40</a>   |
| *4. <a href="#">AT-47</a>       | *5. <a href="#">AT-47</a>        | *6. <a href="#">AT-47</a>   |
| *7. <a href="#">AT-81</a>       | *8. <a href="#">AT-37</a>        | *9. <a href="#">AT-40</a>   |
| *10. <a href="#">AT-90</a>      | *11. <a href="#">AT-151</a>      | *12. <a href="#">AT-163</a> |
| *13. <a href="#">AT-56</a>      | *14. <a href="#">AT-37</a>       | *15. <a href="#">AT-90</a>  |
| *16. <a href="#">AT-151</a>     | *17. <a href="#">EC-46</a>       |                             |

## DIAGNOSTIC WORKSHEET

### Information from Customer

#### KEY POINTS

- **WHAT**..... Vehicle & A/T model
- **WHEN**..... Date, Frequencies
- **WHERE**..... Road conditions
- **HOW**..... Operating conditions, Symptoms

|  |   |                                  |
|--|---|----------------------------------|
| Customer name MR/MS                    | Model & Year  | VIN                              |
| Trans. Model                           | Engine  | Mileage                          |
| Incident Date                          | Manuf. Date   | In Service Date                  |
| Frequency                              | <input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent ( times a day)  |                                  |
| Symptoms                               | <input type="checkbox"/> Vehicle does not move. ( <input type="checkbox"/> Any position <input type="checkbox"/> Particular position)   |                                  |
|  | <input type="checkbox"/> No up-shift ( <input type="checkbox"/> 1st → 2nd <input type="checkbox"/> 2nd → 3rd <input type="checkbox"/> 3rd → 4th <input type="checkbox"/> 4th → 5th)   |                                  |
|  | <input type="checkbox"/> No down-shift ( <input type="checkbox"/> 5th → 4th <input type="checkbox"/> 4th → 3rd <input type="checkbox"/> 3rd → 2nd <input type="checkbox"/> 2nd → 1st) |                                  |
|  | <input type="checkbox"/> Lock-up malfunction  |                                  |
|  | <input type="checkbox"/> Shift point too high or too low.   |                                  |
|  | <input type="checkbox"/> Shift shock or slip ( <input type="checkbox"/> N → D <input type="checkbox"/> Lock-up <input type="checkbox"/> Any drive position)                           |                                  |
|  | <input type="checkbox"/> Noise or vibration   |                                  |
|  | <input type="checkbox"/> No kick down   |                                  |
|  | <input type="checkbox"/> No pattern select  |                                  |
| <input type="checkbox"/> Others<br>( ) |   |                                  |
| A/T CHECK indicator lamp               | <input type="checkbox"/> Continuously lit   | <input type="checkbox"/> Not lit |
| Malfunction indicator lamp (MIL)       | <input type="checkbox"/> Continuously lit   | <input type="checkbox"/> Not lit |

### Diagnostic Worksheet Chart

|   |   |   |   |
|---|---|---|---|
| 1   | <input type="checkbox"/> Read the item on cautions concerning fail-safe and understand the customer's complaint.  | <a href="#">AT-40</a>   |   |
| 2   | <input type="checkbox"/> A/T fluid inspection   | <a href="#">AT-47</a>   |   |
|   | <input type="checkbox"/> Leak (Repair leak location.)<br><input type="checkbox"/> State<br><input type="checkbox"/> Amount  |   |   |
| 3   | <input type="checkbox"/> Stall test and line pressure test  | <a href="#">AT-47</a>   |   |
|   | <input type="checkbox"/> Stall test   |   |   |
|   | <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;"> <input type="checkbox"/> Torque converter one-way clutch<br/> <input type="checkbox"/> Front brake<br/> <input type="checkbox"/> High and low reverse clutch<br/> <input type="checkbox"/> Low coast brake<br/> <input type="checkbox"/> Forward brake<br/> <input type="checkbox"/> Reverse brake<br/> <input type="checkbox"/> Forward one-way clutch                 </td> <td style="width: 50%;"> <input type="checkbox"/> 1st one-way clutch<br/> <input type="checkbox"/> 3rd one-way clutch<br/> <input type="checkbox"/> Engine<br/> <input type="checkbox"/> Line pressure low<br/> <input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK                 </td> </tr> </table> | <input type="checkbox"/> Torque converter one-way clutch<br><input type="checkbox"/> Front brake<br><input type="checkbox"/> High and low reverse clutch<br><input type="checkbox"/> Low coast brake<br><input type="checkbox"/> Forward brake<br><input type="checkbox"/> Reverse brake<br><input type="checkbox"/> Forward one-way clutch | <input type="checkbox"/> 1st one-way clutch<br><input type="checkbox"/> 3rd one-way clutch<br><input type="checkbox"/> Engine<br><input type="checkbox"/> Line pressure low<br><input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK |
| <input type="checkbox"/> Torque converter one-way clutch<br><input type="checkbox"/> Front brake<br><input type="checkbox"/> High and low reverse clutch<br><input type="checkbox"/> Low coast brake<br><input type="checkbox"/> Forward brake<br><input type="checkbox"/> Reverse brake<br><input type="checkbox"/> Forward one-way clutch | <input type="checkbox"/> 1st one-way clutch<br><input type="checkbox"/> 3rd one-way clutch<br><input type="checkbox"/> Engine<br><input type="checkbox"/> Line pressure low<br><input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK   |   |   |
| <input type="checkbox"/> Line pressure inspection - Suspected part:   |   |   |   |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

|   |   |                       |
|---|---|-----------------------|
|   | <input type="checkbox"/> Perform all road tests and enter checks in required inspection items.  | <a href="#">AT-51</a> |
| 4 | 4-1. Check before engine is started   | <a href="#">AT-51</a> |
|   | <input type="checkbox"/> <a href="#">AT-166. "A/T Check Indicator Lamp Does Not Come On"</a><br><input type="checkbox"/> Perform self-diagnostics. Enter checks for detected items. <a href="#">AT-81</a> , <a href="#">AT-88</a>   |                       |
|   | <input type="checkbox"/> DTC U1000 CAN COMM CIRCUIT <a href="#">AT-90</a><br><input type="checkbox"/> DTC P0615 STARTER RELAY <a href="#">AT-93</a><br><input type="checkbox"/> DTC P0700 TRANSMISSION CONTROL <a href="#">AT-97</a><br><input type="checkbox"/> DTC P0705 TRANSMISSION RANGE SWITCH A <a href="#">AT-98</a><br><input type="checkbox"/> DTC P0717 INPUT SPEED SENSOR A <a href="#">AT-101</a><br><input type="checkbox"/> DTC P0720 OUTPUT SPEED SENSOR <a href="#">AT-103</a><br><input type="checkbox"/> DTC P0725 ENGINE SPEED <a href="#">AT-108</a><br><input type="checkbox"/> DTC P0731 1GR INCORRECT RATIO <a href="#">AT-110</a><br><input type="checkbox"/> DTC P0732 2GR INCORRECT RATIO <a href="#">AT-112</a><br><input type="checkbox"/> DTC P0733 3GR INCORRECT RATIO <a href="#">AT-114</a><br><input type="checkbox"/> DTC P0734 4GR INCORRECT RATIO <a href="#">AT-116</a><br><input type="checkbox"/> DTC P0735 5GR INCORRECT RATIO <a href="#">AT-118</a><br><input type="checkbox"/> DTC P0740 TORQUE CONVERTER <a href="#">AT-120</a><br><input type="checkbox"/> DTC P0744 TORQUE CONVERTER <a href="#">AT-122</a><br><input type="checkbox"/> DTC P0745 PRESSURE CONTROL SOLENOID <a href="#">AT-124</a><br><input type="checkbox"/> DTC P1705 TP SENSOR <a href="#">AT-126</a><br><input type="checkbox"/> DTC P1710 TRANSMISSION FLUIDTEMPERATURE SENSOR <a href="#">AT-128</a><br><input type="checkbox"/> DTC P1721 VEHICLE SPEED SIGNAL <a href="#">AT-133</a><br><input type="checkbox"/> DTC P1730 INTERLOCK <a href="#">AT-135</a><br><input type="checkbox"/> DTC P1731 1ST ENGINE BRAKING <a href="#">AT-137</a><br><input type="checkbox"/> DTC P1752 INPUT CLUTCH SOLENOID <a href="#">AT-139</a><br><input type="checkbox"/> DTC P1757 FRONT BRAKE SOLENOID <a href="#">AT-141</a><br><input type="checkbox"/> DTC P1762 DIRECT CLUTCH SOLENOID <a href="#">AT-143</a><br><input type="checkbox"/> DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID <a href="#">AT-145</a><br><input type="checkbox"/> DTC P1772 LOW COAST BRAKE SOLENOID <a href="#">AT-147</a><br><input type="checkbox"/> DTC P1774 LOW COAST BRAKE SOLENOID <a href="#">AT-149</a><br><input type="checkbox"/> DTC P1815 M-MODE SWITCH <a href="#">AT-151</a> |                       |
| 4 | 4-2. Check at Idle  | <a href="#">AT-51</a> |
|   | <input type="checkbox"/> <a href="#">AT-166. "Engine Cannot Be Started in "P" or "N" Position"</a><br><input type="checkbox"/> <a href="#">AT-167. "In "P" Position, Vehicle Moves When Pushed"</a><br><input type="checkbox"/> <a href="#">AT-167. "In "N" Position, Vehicle Moves"</a><br><input type="checkbox"/> <a href="#">AT-168. "Large Shock ("N" to "D" Position)"</a><br><input type="checkbox"/> <a href="#">AT-169. "Vehicle Does Not Creep Backward in "R" Position"</a><br><input type="checkbox"/> <a href="#">AT-171. "Vehicle Does Not Creep Forward in "D" Position"</a>   |                       |
| 4 | 4-3. Cruise test  | <a href="#">AT-51</a> |
|   | Part 1<br><input type="checkbox"/> <a href="#">AT-173. "Vehicle Cannot Be Started from D1"</a><br><input type="checkbox"/> <a href="#">AT-175. "A/T Does Not Shift: D1→ D2"</a><br><input type="checkbox"/> <a href="#">AT-176. "A/T Does Not Shift: D2→ D3"</a><br><input type="checkbox"/> <a href="#">AT-178. "A/T Does Not Shift: D3→ D4"</a><br><input type="checkbox"/> <a href="#">AT-180. "A/T Does Not Shift: D4→ D5"</a><br><input type="checkbox"/> <a href="#">AT-181. "A/T Does Not Lock-up"</a><br><input type="checkbox"/> <a href="#">AT-183. "A/T Does Not Hold Lock-up Condition"</a><br><input type="checkbox"/> <a href="#">AT-184. "Lock-up Is Not Released"</a><br><input type="checkbox"/> <a href="#">AT-184. "Engine Speed Does Not Return to Idle"</a>  |                       |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >


|   |  |   |  |                                 |
|---|--|---|--|---------------------------------|
| 4 | 4-3.   | Part 2  | <a href="#">AT-51</a>                            | A                               |
|   |  | <input type="checkbox"/> <a href="#">AT-173. "Vehicle Cannot Be Started from D1"</a><br><input type="checkbox"/> <a href="#">AT-175. "A/T Does Not Shift: D1→ D2"</a><br><input type="checkbox"/> <a href="#">AT-176. "A/T Does Not Shift: D2→ D3"</a><br><input type="checkbox"/> <a href="#">AT-178. "A/T Does Not Shift: D3→ D4"</a>   |  | B                               |
|   |  | Part 3  | <a href="#">AT-51</a>                            | AT                              |
|   |  | <input type="checkbox"/> <a href="#">AT-185. "Cannot Be Changed to Manual Mode"</a><br><input type="checkbox"/> <a href="#">AT-186. "A/T Does Not Shift: 5GR → 4GR"</a><br><input type="checkbox"/> <a href="#">AT-187. "A/T Does Not Shift: 4GR → 3GR"</a><br><input type="checkbox"/> <a href="#">AT-188. "A/T Does Not Shift: 3GR → 2GR"</a><br><input type="checkbox"/> <a href="#">AT-189. "A/T Does Not Shift: 2GR → 1GR"</a><br><input type="checkbox"/> <a href="#">AT-191. "Vehicle Does Not Decelerate by Engine Brake"</a><br><input type="checkbox"/> Perform self-diagnostics. Enter checks for detected items. <a href="#">AT-81</a> , <a href="#">AT-88</a>  |  | D                               |
|   |  | <input type="checkbox"/> DTC U1000 CAN COMM CIRCUIT <a href="#">AT-90</a><br><input type="checkbox"/> DTC P0615 STARTER RELAY <a href="#">AT-93</a><br><input type="checkbox"/> DTC P0700 TRANSMISSION CONTROL <a href="#">AT-97</a><br><input type="checkbox"/> DTC P0705 TRANSMISSION RANGE SWITCH A <a href="#">AT-98</a><br><input type="checkbox"/> DTC P0717 INPUT SPEED SENSOR A <a href="#">AT-101</a><br><input type="checkbox"/> DTC P0720 OUTPUT SPEED SENSOR <a href="#">AT-103</a><br><input type="checkbox"/> DTC P0725 ENGINE SPEED <a href="#">AT-108</a><br><input type="checkbox"/> DTC P0731 1GR INCORRECT RATIO <a href="#">AT-110</a><br><input type="checkbox"/> DTC P0732 2GR INCORRECT RATIO <a href="#">AT-112</a><br><input type="checkbox"/> DTC P0733 3GR INCORRECT RATIO <a href="#">AT-114</a><br><input type="checkbox"/> DTC P0734 4GR INCORRECT RATIO <a href="#">AT-116</a><br><input type="checkbox"/> DTC P0735 5GR INCORRECT RATIO <a href="#">AT-118</a><br><input type="checkbox"/> DTC P0740 TORQUE CONVERTER <a href="#">AT-120</a><br><input type="checkbox"/> DTC P0744 TORQUE CONVERTER <a href="#">AT-122</a><br><input type="checkbox"/> DTC P0745 PRESSURE CONTROL SOLENOID <a href="#">AT-124</a><br><input type="checkbox"/> DTC P1705 TP SENSOR <a href="#">AT-126</a><br><input type="checkbox"/> DTC P1710 TRANSMISSION FLUIDTEMPERATURE SENSOR <a href="#">AT-128</a><br><input type="checkbox"/> DTC P1721 VEHICLE SPEED SIGNAL <a href="#">AT-133</a><br><input type="checkbox"/> DTC P1730 INTERLOCK <a href="#">AT-135</a><br><input type="checkbox"/> DTC P1731 1ST ENGINE BRAKING <a href="#">AT-137</a><br><input type="checkbox"/> DTC P1752 INPUT CLUTCH SOLENOID <a href="#">AT-139</a><br><input type="checkbox"/> DTC P1757 FRONT BRAKE SOLENOID <a href="#">AT-141</a><br><input type="checkbox"/> DTC P1762 DIRECT CLUTCH SOLENOID <a href="#">AT-143</a><br><input type="checkbox"/> DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID <a href="#">AT-145</a><br><input type="checkbox"/> DTC P1772 LOW COAST BRAKE SOLENOID <a href="#">AT-147</a><br><input type="checkbox"/> DTC P1774 LOW COAST BRAKE SOLENOID <a href="#">AT-149</a><br><input type="checkbox"/> DTC P1815 M-MODE SWITCH <a href="#">AT-151</a> |  | E<br>F<br>G<br>H<br>I<br>J<br>K |
| 5 | <input type="checkbox"/> Inspect each system for items found to be NG in the self-diagnostics and repair or replace the malfunctioning parts.  |   |  | L                               |
| 6 | <input type="checkbox"/> Perform all road tests and enter the checks again for the required items.   |   | <a href="#">AT-47</a>                            |                                 |
| 7 | <input type="checkbox"/> For any remaining NG items, perform the "diagnostics procedure" and repair or replace the malfunctioning parts. See the chart for diagnostics by symptoms. (This chart also contains other symptoms and inspection procedures.) |   | <a href="#">AT-56</a>                            | M                               |
| 8 | <input type="checkbox"/> Erase the results of the self-diagnostics from TCM and ECM.   |   | <a href="#">AT-88</a> ,<br><a href="#">AT-37</a> | N                               |

# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## A/T Electrical Parts Location

INFOID:000000004656804




JSDIA1390GB

# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## Circuit Diagram

INFOID:000000004656805



## Inspections Before Trouble Diagnosis

INFOID:000000004656806

### A/T FLUID CHECK

A/T Fluid Leakage and A/T Fluid Level Check


Inspect for A/T fluid leakage and check the A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

A/T Fluid Condition Check  
Inspect the A/T fluid condition.

| Fluid condition                       | Conceivable Cause                        | Required Operation  |
|---------------------------------------|--|---|
| Varnished (viscous varnish state)     | Clutch, brake scorched                   | Replace the ATF and check the A/T main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.) |
| Milky white or cloudy                 | Water in the fluid                       | Replace the ATF and check for places where water is getting in.   |
| Large amount of metal powder mixed in | Unusual wear of sliding parts within A/T | Replace the ATF and check for improper operation of the A/T.  |




SAT638A

## STALL TEST


### Stall Test Procedure

1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the A/T fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of ATF. Replenish if necessary.



SAT647B

3. Securely engage the parking brake so that the tires do not turn.
4. Engine start, apply foot brake, and place selector lever in "D" position.




SAT513G

5. While holding down the foot brake, gradually press down accelerator pedal.
6. Quickly read off the stall speed, then quickly remove your foot from accelerator pedal.

**CAUTION:**

**Do not hold down accelerator pedal for more than 5 seconds during this test.**

**Stall speed: 2,700 – 3,000 rpm**



SAT514G

7. Move selector lever to "N" position.
8. Cool down the ATF.  
**CAUTION:**  
**Run the engine at idle for at least one minute.**



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

9. Repeat steps 5 through 8 with selector lever in "R" position.

### Judgment Stall Test

|             | Selector lever position |     | Expected problem location   |
|-------------|-------------------------|-----|---|
|             | "D" and "M"             | "R" |   |
| Stall speed | H                       | O   | <ul style="list-style-type: none"> <li>• Forward brake</li> <li>• Forward one-way clutch</li> <li>• 1st one-way clutch</li> <li>• 3rd one-way clutch</li> </ul> |
|             | O                       | H   | <ul style="list-style-type: none"> <li>• Reverse brake</li> </ul>   |
|             | L                       | L   | <ul style="list-style-type: none"> <li>• Engine and torque converter one-way clutch</li> </ul>  |
|             | H                       | H   | <ul style="list-style-type: none"> <li>• Line pressure low</li> </ul>   |

O: Stall speed within standard value position

H: Stall speed higher than standard value


L: Stall speed lower than standard value

### Stall Test Standard Value Position

|   |                             |                                      |
|---|-----------------------------|--------------------------------------|
| Does not shift-up "D" or "M" position 1 → 2 | Slipping in 2GR, 3GR or 4GR | Direct clutch slippage               |
| Does not shift-up "D" or "M" position 2 → 3 | Slipping in 3GR, 4GR or 5GR | High and low reverse clutch slippage |
| Does not shift-up "D" or "M" position 3 → 4 | Slipping in 4GR or 5GR      | Input clutch slippage                |
| Does not shift-up "D" or "M" position 4 → 5 | Slipping in 5GR             | Front brake slippage                 |

## LINE PRESSURE TEST

### Line Pressure Test Port



### Line Pressure Test Procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the ATF reaches in range of 50 to 80°C (122 to 176°F), then inspect the amount of ATF and replenish if necessary.


#### NOTE:

**The A/T fluid temperature rises in range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.**

3. After warming up remove the oil pressure detection plug and install the oil pressure gauge [ST2505S001(J-34301-C)].

#### CAUTION:


**When using the oil pressure gauge, be sure to use O-ring attached to the oil pressure detection plug.**



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

4. Securely engage the parking brake so that the tires do not turn.



5. Start the engine, then measure the line pressure at both idle and the stall speed.


**CAUTION:**

- Keep brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to "STALL TEST".

6. After the measurements are complete, install the oil pressure detection plug and tighten to the specified torque. Refer to [AT-232. "Component"](#).

**CAUTION:**

- Do not reuse O-ring.
- Apply ATF to O-ring.



### Line Pressure

| Engine speed   | Line pressure kPa (kg/cm <sup>2</sup> , psi) |  |
|----------------|--|--|
|                | "R" position                                 | "D" and "M" positions                  |
| At idle speed  | 425 – 465 (4.3 – 4.7, 62 – 67)               | 379 – 428 (3.9 – 4.4, 55 – 62)         |
| At stall speed | 1,605 – 1,950 (16.4 – 19.9, 233 – 283)       | 1,310 – 1,500 (13.4 – 15.3, 190 – 218) |

### Judgment of Line Pressure Test

| Judgment   |   | Possible cause   |
|------------|---|--|
| Idle speed | Low for all positions ("P", "R", "N", "D", "M") | Possible causes include malfunctions in the pressure supply system and low oil pump output.<br>For example <ul style="list-style-type: none"> <li>• Oil pump wear</li> <li>• Pressure regulator valve or plug sticking or spring fatigue</li> <li>• Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak</li> <li>• Engine idle speed too low</li> </ul>  |
|            | Only low for a specific position                | Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.   |
|            | High  | Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function.<br>For example <ul style="list-style-type: none"> <li>• Accelerator pedal position signal malfunction</li> <li>• A/T fluid temperature sensor malfunction</li> <li>• Line pressure solenoid malfunction (sticking in OFF state, filter clog, cut line)</li> <li>• Pressure regulator valve or plug sticking</li> </ul> |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Judgment    |   | Possible cause   |
|-------------|---|--|
| Stall speed | Line pressure does not rise higher than the line pressure for idle. | Possible causes include a sensor malfunction or malfunction in the pressure adjustment function.<br>For example <ul style="list-style-type: none"> <li>• Accelerator pedal position signal malfunction</li> <li>• TCM breakdown</li> <li>• Line pressure solenoid malfunction (shorting, sticking in ON state)</li> <li>• Pressure regulator valve or plug sticking</li> <li>• Pilot valve sticking or pilot filter clogged</li> </ul> |
|             | The pressure rises, but does not enter the standard position.       | Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function.<br>For example <ul style="list-style-type: none"> <li>• Accelerator pedal position signal malfunction</li> <li>• Line pressure solenoid malfunction (sticking, filter clog)</li> <li>• Pressure regulator valve or plug sticking</li> <li>• Pilot valve sticking or pilot filter clogged</li> </ul>            |
|             | Only low for a specific position                                    | Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.   |

## Road Test

INFOID:000000004656807

## ROAD TEST

### DESCRIPTION

- The road test inspects overall performance of A/T and analyzes possible malfunction causes.
- The road test is performed in the following three stages.
  1. Check before engine is started.
  2. Check at idle.
  3. Cruise test
- Inspect all the items from Part 1 to Part 3.
- Before beginning the road test, check the test procedure and inspection items.
- Test all inspection items until the symptom is uncovered. Include NG items in "Diagnostic Worksheet Chart" (Refer to [AT-41](#)). Perform a diagnosis of the NG items after the completion of all the road tests.

### CHECK BEFORE ENGINE IS STARTED

#### 1. CHECK A/T CHECK INDICATOR LAMP

1. Park vehicle on level surface.
2. Shift selector lever to "P" position.
3. Turn ignition switch OFF and wait for at least 10 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Does A/T CHECK indicator lamp light up for about 2 seconds?

YES-1 >>  With CONSULT-III

1. Turn ignition switch OFF.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III and record all NG items on "Diagnostic Worksheet Chart".
3. Go to "CHECK AT IDLE".

YES-2 >>  Without CONSULT-III

1. Turn ignition switch OFF.
2. Perform the self-diagnosis and record all NG items on the "Diagnostic Worksheet Chart". Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).
3. Go to "CHECK AT IDLE".

NO >> Stop the road test and go to [AT-166, "A/T Check Indicator Lamp Does Not Come On"](#).

### CHECK AT IDLE

#### 1. CHECK STARTING THE ENGINE

1. Park vehicle on level surface.
2. Shift selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Start the engine.

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

---

### Does the engine start?

YES >> GO TO 2.

NO >> Stop the road test and go to [AT-166, "Engine Cannot Be Started in "P" or "N" Position"](#).

## 2.CHECK STARTING THE ENGINE

---

1. Turn ignition switch ON. (Do not start engine.)
2. Shift selector lever in "D", "M" or "R" position.
3. Start the engine.

### Does the engine start in each position?

YES >> Stop the road test and go to [AT-166, "Engine Cannot Be Started in "P" or "N" Position"](#).

NO >> GO TO 3.

## 3.CHECK "P" POSITION FUNCTIONS

---

1. Shift selector lever to "P" position.
2. Turn ignition switch OFF.
3. Release the parking brake.
4. Push the vehicle forward or backward.
5. Engage the parking brake.

### When you push the vehicle with disengaging the parking brake, does it move?

YES >> Enter a check mark at [AT-167, "In "P" Position, Vehicle Moves When Pushed"](#) on the "Diagnostic Worksheet Chart", GO TO 4.

NO >> GO TO 4.

## 4.CHECK "N" POSITION FUNCTIONS

---

1. Start the engine.
2. Shift selector lever to "N" position.
3. Release the parking brake.

### Does vehicle move forward or backward?

YES >> Enter a check mark at [AT-167, "In "N" Position, Vehicle Moves"](#) on the "Diagnostic Worksheet Chart", GO TO 5.

NO >> GO TO 5.

## 5.CHECK SHIFT SHOCK

---

1. Engage the brake.
2. Move selector lever to "D" position.

### When the A/T is shifted from "N" to "D", is there an excessive shock?

YES >> Enter a check mark at [AT-168, "Large Shock \("N" to "D" Position\)"](#) on the "Diagnostic Worksheet Chart", GO TO 6.

NO >> GO TO 6.

## 6.CHECK "R" POSITION FUNCTIONS

---

1. Engage the brake.
2. Move selector lever to "R" position.
3. Release the brake for 4 to 5 seconds.

### Does the vehicle creep backward?

YES >> GO TO 7.

NO >> Enter a check mark at [AT-169, "Vehicle Does Not Creep Backward in "R" Position"](#) on the "Diagnostic Worksheet Chart", GO TO 7.

## 7.CHECK "D" POSITION FUNCTIONS

---

Inspect whether the vehicle creep forward when the A/T is put into the "D" position.

### Does the vehicle creep forward in the "D" position?

YES >> Go to "CRUISE TEST-PART 1".

NO >> Enter a check mark at [AT-171, "Vehicle Does Not Creep Forward in "D" Position"](#) on the "Diagnostic Worksheet Chart", then continue the road test. Go to "CRUISE TEST-PART 1".

## CRUISE TEST-PART 1

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

### 1. CHECK STARTING OUT FROM D1

1. Drive the vehicle for about 10 minutes to warm up the engine oil and ATF.  
Appropriate temperature for the ATF: 50 to 80°C (122 to 176°F)
2. Park the vehicle on a level surface.
3. Shift selector lever to "P" position.
4. Start the engine.
5. Shift selector lever to "D" position.
6. Press the accelerator pedal about half-way down to accelerate the vehicle.

#### With CONSULT-III

Read the value of "GEAR" with "DATA MONITOR" mode.

#### Starts from D1?

YES >> GO TO 2.

NO >> Enter a check mark at [AT-173, "Vehicle Cannot Be Started from D1"](#) on the "Diagnostic Worksheet Chart", GO TO 2.

### 2. CHECK SHIFT-UP D1 → D2

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D1 → D2) at the appropriate speed. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

#### With CONSULT-III

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

#### Does the A/T shift-up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at [AT-175, "A/T Does Not Shift: D1→D2"](#) on the "Diagnostic Worksheet Chart", GO TO 3.

### 3. CHECK SHIFT-UP D2 → D3

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D2 → D3) at the appropriate speed. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

#### With CONSULT-III

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

#### Does the A/T shift-up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at [AT-176, "A/T Does Not Shift: D2→D3"](#) on the "Diagnostic Worksheet Chart", GO TO 4.

### 4. CHECK SHIFT-UP D3 → D4

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D3 → D4) at the appropriate speed. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

#### With CONSULT-III

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

#### Does the A/T shift-up D3 → D4 at the correct speed?

YES >> GO TO 5.

NO >> Enter a check mark at [AT-178, "A/T Does Not Shift: D3→D4"](#) on the "Diagnostic Worksheet Chart", GO TO 5.

### 5. CHECK SHIFT-UP D4 → D5

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D4 → D5) at the appropriate speed. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

#### With CONSULT-III

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

#### Does the A/T shift-up D4 → D5 at the correct speed?

YES >> GO TO 6.

NO >> Enter a check mark at [AT-180, "A/T Does Not Shift: D4→D5"](#) on the "Diagnostic Worksheet Chart", GO TO 6.

### 6. CHECK LOCK-UP

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

When releasing accelerator pedal (closed throttle position signal: OFF) from D5, check lock-up from D5 to L/U. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

### With CONSULT-III

Read the value of "TCC SOLENOID" with "DATA MONITOR" mode. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).

Does it lock-up?

YES >> GO TO 7.

NO >> Enter a check mark at [AT-181, "A/T Does Not Lock-up"](#) on the "Diagnostic Worksheet Chart", GO TO 7.

## 7.CHECK LOCK-UP HOLD

Check hold lock-up.

### With CONSULT-III

Read the value of "TCC SOLENOID" with "DATA MONITOR" mode. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).

Does it maintain lock-up status?

YES >> GO TO 8.

NO >> Enter a check mark at [AT-183, "A/T Does Not Hold Lock-up Condition"](#) on the "Diagnostic Worksheet Chart", GO TO 8.

## 8.CHECK LOCK-UP RELEASE

Check lock-up cancellation by depressing brake pedal lightly to decelerate.

### With CONSULT-III

Read the value of "TCC SOLENOID" with "DATA MONITOR" mode. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).

Does lock-up cancel?

YES >> GO TO 9.

NO >> Enter a check mark at [AT-184, "Lock-up Is Not Released"](#) on the "Diagnostic Worksheet Chart", GO TO 9

## 9.CHECK SHIFT-DOWN D5 → D4

Decelerate by pressing lightly on the brake pedal.

### With CONSULT-III

Read the value of "GEAR" and "ENGINE SPEED" with "DATA MONITOR" mode.

When the A/T shift-down D5 → D4, does the engine speed drop smoothly back to idle?

YES >> 1. Stop the vehicle.  
2. Go to CRUISE TEST-PART 2.

NO >> Enter a check mark at [AT-184, "Engine Speed Does Not Return to Idle"](#) on the "Diagnostic Worksheet Chart", then continue the road test. Go to CRUISE TEST-PART 2.

## CRUISE TEST-PART 2

### 1.CHECK STARTING FROM D1

1. Shift selector lever into "D" position.
2. Accelerate at half throttle.

### With CONSULT-III

Read the value of "GEAR" with "DATA MONITOR" mode.

Does it start from D1?

YES >> GO TO 2.

NO >> Enter a check mark at [AT-173, "Vehicle Cannot Be Started from D1"](#) on the "Diagnostic Worksheet Chart", GO TO 2.

### 2.CHECK SHIFT-UP D1 → D2

Press the accelerator pedal down all the way and inspect whether or not the A/T shifts up (D1 → D2) at the correct speed. Refer to [AT-56, "Vehicle Speed at When Gears Shifting Occurs"](#).

### With CONSULT-III

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

Does the A/T shift-up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at [AT-175. "A/T Does Not Shift: D1→ D2"](#) on the "Diagnostic Worksheet Chart", GO TO 3.

### 3.CHECK SHIFT UP D2 → D3

Press the accelerator pedal down all the way and inspect whether or not the A/T shifts up (D2 → D3) at the correct speed. Refer to [AT-56. "Vehicle Speed at When Gears Shifting Occurs"](#).

With **CONSULT-III**

Read the value of "GEAR", "ACCELE POSI" and "VEHICLE SPEED" with "DATA MONITOR" mode.

Does the A/T shift-up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at [AT-176. "A/T Does Not Shift: D2→ D3"](#) on the "Diagnostic Worksheet Chart", GO TO 4.

### 4.CHECK SHIFT-UP D3 → D4 AND ENGINE BRAKE

When the A/T changes speed D3 → D4, return the accelerator pedal.

With **CONSULT-III**

Read the value of "GEAR" with "DATA MONITOR" mode.

Does the A/T shift-up D3 → D4 and apply the engine brake?

YES >> 1. Stop the vehicle.

2. Go to "CRUISE TEST-PART 3".

NO >> Enter a check mark at [AT-178. "A/T Does Not Shift: D3→ D4"](#) on the "Diagnostic Worksheet Chart", then continue the road test. Go to "CRUISE TEST-PART 3".

## CRUISE TEST-PART 3

### 1.MANUAL MODE FUNCTION

Move to manual mode from "D" position.

Does it switch to manual mode?

YES >> GO TO 2.

NO >> Enter a check mark at [AT-185. "Cannot Be Changed to Manual Mode"](#) on the "Diagnostic Worksheet Chart", GO TO 2.

### 2.CHECK SHIFT-DOWN

During manual mode driving, is downshift from M5 → M4 → M3 → M2 → M1 performed?

With **CONSULT-III**

Read the value of "GEAR" with "DATA MONITOR" mode.

Is downshifting correctly performed?

YES >> GO TO 3.

NO >> Enter a check mark at "A/T Does Not Shift" at the corresponding position (5th → 4th, 4th → 3rd, 3rd → 2nd, 2nd → 1st) on the "Diagnostic Worksheet Chart", GO TO 3.

### 3.CHECK ENGINE BRAKE

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

YES-1 >>  With **CONSULT-III**

1. Turn ignition switch OFF.

2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III and record all NG items on "Diagnostic Worksheet Chart".

YES-2 >>  Without **CONSULT-III**

1. Turn ignition switch OFF.

2. Perform the self-diagnosis and record all NG items on the "Diagnostic Worksheet Chart". Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

NO >> Enter a check mark at [AT-191. "Vehicle Does Not Decelerate by Engine Brake"](#) on the "Diagnostic Worksheet Chart", then continue trouble diagnosis.



# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## Vehicle Speed at When Gears Shifting Occurs

INFOID:000000004656808

| Throttle position | Vehicle speed km/h (MPH) |                        |                         |                          |                          |                        |                      |                      |
|-------------------|--------------------------|------------------------|-------------------------|--------------------------|--------------------------|------------------------|----------------------|----------------------|
|                   | D1→D2                    | D2→D3                  | D3→D4                   | D4→D5                    | D5→D4                    | D4→D3                  | D3→D2                | D2→D1                |
| Full throttle     | 64 – 68<br>(40 – 42)     | 103 – 111<br>(64 – 69) | 156 – 166<br>(97 – 103) | 224 – 234<br>(139 – 145) | 220 – 230<br>(137 – 143) | 146 – 156<br>(91 – 97) | 86 – 94<br>(53 – 58) | 40 – 44<br>(25 – 27) |
| Half throttle     | 47 – 51<br>(29 – 32)     | 76 – 82<br>(47 – 51)   | 108 – 116<br>(67 – 72)  | 136 – 144<br>(85 – 89)   | 88 – 96<br>(55 – 60)     | 64 – 72<br>(40 – 45)   | 28 – 34<br>(17 – 21) | 8 – 12<br>(5 – 7)    |

- At half throttle, the accelerator opening is 4/8 of the full opening.

## Vehicle Speed at Which Lock-up Occurs/Releases

INFOID:000000004656809

| Throttle position | Vehicle speed km/h (MPH) |                   |
|-------------------|--------------------------|-------------------|
|                   | Lock-up ON               | Lock-up OFF       |
| Closed throttle   | 62 – 70 (39 – 44)        | 59 – 67 (37 – 42) |
| Half throttle     | 136 – 144 (85 – 89)      | 88 – 96 (55 – 60) |

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

## Symptom Chart

INFOID:000000004656810

- **The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.**
- **Overhaul and inspect inside the A/T only if A/T fluid condition is NG. Refer to [AT-47. "Inspections Before Trouble Diagnosis"](#).**



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items       | Symptom   | Condition   | Diagnostic Item  | Reference page                                     |
|-----|-------------|---|-------------|--|--|
| 1   |             | Large shock. ("N" → "D" position)<br>Refer to <a href="#">AT-168</a> , " <a href="#">Large Shock ("N" to "D" Position)</a> ". | ON vehicle  | 1. Engine idle speed   | <a href="#">EC-75</a>                              |
|     |             |   |             | 2. Engine speed signal   | <a href="#">AT-108</a>                             |
|     |             |   |             | 3. Accelerator pedal position sensor   | <a href="#">AT-126</a>                             |
|     |             |   |             | 4. A/T position  | <a href="#">AT-195</a>                             |
|     |             |   |             | 5. A/T fluid temperature sensor  | <a href="#">AT-128</a>                             |
|     |             |   |             | 6. Front brake solenoid valve  | <a href="#">AT-141</a>                             |
|     |             |   |             | 7. CAN communication line  | <a href="#">AT-90</a>                              |
|     |             |   |             | 8. A/T fluid level and state   | <a href="#">AT-47</a>                              |
|     |             |   |             | 9. Line pressure test  | <a href="#">AT-47</a>                              |
|     |             |   |             | 10. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |             |   | OFF vehicle | 11. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>                             |
| 2   | Shift Shock | Shock is too large when changing D1 → D2 or M1 → M2.  | ON vehicle  | 1. Accelerator pedal position sensor   | <a href="#">AT-126</a>                             |
|     |             |   |             | 2. A/T position  | <a href="#">AT-195</a>                             |
|     |             |   |             | 3. Direct clutch solenoid valve  | <a href="#">AT-143</a>                             |
|     |             |   |             | 4. CAN communication line  | <a href="#">AT-90</a>                              |
|     |             |   |             | 5. Engine speed signal   | <a href="#">AT-108</a>                             |
|     |             |   |             | 6. Input speed sensor  | <a href="#">AT-101</a>                             |
|     |             |   |             | 7. Output speed sensor and vehicle speed signal  | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |             |   |             | 8. A/T fluid level and state   | <a href="#">AT-47</a>                              |
|     |             |   |             | 9. Control valve with TCM  | <a href="#">AT-204</a>                             |
|     |             |   | OFF vehicle | 10. Direct clutch  | <a href="#">AT-270</a>                             |
| 3   |             | Shock is too large when changing D2 → D3 or M2 → M3.  | ON vehicle  | 1. Accelerator pedal position sensor   | <a href="#">AT-126</a>                             |
|     |             |   |             | 2. A/T position  | <a href="#">AT-195</a>                             |
|     |             |   |             | 3. High and low reverse clutch solenoid valve  | <a href="#">AT-145</a>                             |
|     |             |   |             | 4. CAN communication line  | <a href="#">AT-90</a>                              |
|     |             |   |             | 5. Engine speed signal   | <a href="#">AT-108</a>                             |
|     |             |   |             | 6. Input speed sensor  | <a href="#">AT-101</a>                             |
|     |             |   |             | 7. Output speed sensor and vehicle speed signal  | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |             |   |             | 8. A/T fluid level and state   | <a href="#">AT-47</a>                              |
|     |             |   |             | 9. Control valve with TCM  | <a href="#">AT-204</a>                             |
|     |             |   | OFF vehicle | 10. High and low reverse clutch  | <a href="#">AT-269</a>                             |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items       | Symptom   | Condition   | Diagnostic Item                                 | Reference page                 |
|-----|-------------|---|-------------|---|--------------------------------|
| 4   |             | Shock is too large when changing D3 → D4 or M3 → M4.                | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |   |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |   |             | 3. Input clutch solenoid valve                  | <a href="#">AT-139</a>         |
|     |             |   |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |   |             | 5. Engine speed signal                          | <a href="#">AT-108</a>         |
|     |             |   |             | 6. Input speed sensor                           | <a href="#">AT-101</a>         |
|     |             |   |             | 7. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |             |   |             | 8. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |   |             | 9. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |   | OFF vehicle | 10. Input clutch                                | <a href="#">AT-259</a>         |
| 5   | Shift Shock | Shock is too large when changing D4 → D5 or M4 → M5.                | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |   |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |   |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>         |
|     |             |   |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |   |             | 5. Engine speed signal                          | <a href="#">AT-108</a>         |
|     |             |   |             | 6. Input speed sensor                           | <a href="#">AT-101</a>         |
|     |             |   |             | 7. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |             |   |             | 8. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |   |             | 9. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |   | OFF vehicle | 10. Front brake (brake band)                    | <a href="#">AT-239</a>         |
|     |             |   |             | 11. Input clutch                                | <a href="#">AT-259</a>         |
| 6   |             | Shock is too large for downshift when accelerator pedal is pressed. | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |   |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |   |             | 3. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |   |             | 4. Engine speed signal                          | <a href="#">AT-108</a>         |
|     |             |   |             | 5. Input speed sensor                           | <a href="#">AT-101</a>         |
|     |             |   |             | 6. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |             |   |             | 7. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |   |             | 8. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |   | OFF vehicle | 9. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|     |             |   |             | 10. Input clutch                                | <a href="#">AT-259</a>         |
|     |             |   |             | 11. High and low reverse clutch                 | <a href="#">AT-269</a>         |
|     |             |   |             | 12. Direct clutch                               | <a href="#">AT-270</a>         |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items       | Symptom  | Condition   | Diagnostic Item                                 | Reference page                 |
|-----|-------------|--|-------------|---|--------------------------------|
| 7   |             | Shock is too large for upshift when accelerator pedal is released. | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |  |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |  |             | 3. Engine speed signal                          | <a href="#">AT-108</a>         |
|     |             |  |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |  |             | 5. Input speed sensor                           | <a href="#">AT-101</a>         |
|     |             |  |             | 6. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |             |  |             | 7. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |  |             | 8. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |  | OFF vehicle | 9. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|     |             |  |             | 10. Input clutch                                | <a href="#">AT-259</a>         |
|     |             |  |             | 11. High and low reverse clutch                 | <a href="#">AT-269</a>         |
|     |             |  |             | 12. Direct clutch                               | <a href="#">AT-270</a>         |
| 8   | Shift Shock | Shock is too large for lock-up.                                    | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |  |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |  |             | 3. Engine speed signal                          | <a href="#">AT-108</a>         |
|     |             |  |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |  |             | 5. Input speed sensor                           | <a href="#">AT-101</a>         |
|     |             |  |             | 6. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |             |  |             | 7. Torque converter clutch solenoid valve       | <a href="#">AT-120</a>         |
|     |             |  |             | 8. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |  |             | 9. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |  | OFF vehicle | 10. Torque converter                            | <a href="#">AT-239</a>         |
| 9   |             | Shock is too large during engine brake.                            | ON vehicle  | 1. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |             |  |             | 2. A/T position                                 | <a href="#">AT-195</a>         |
|     |             |  |             | 3. CAN communication line                       | <a href="#">AT-90</a>          |
|     |             |  |             | 4. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |             |  |             | 5. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |             |  | OFF vehicle | 6. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|     |             |  |             | 7. Input clutch                                 | <a href="#">AT-259</a>         |
|     |             |  |             | 8. High and low reverse clutch                  | <a href="#">AT-269</a>         |
|     |             |  |             | 9. Direct clutch                                | <a href="#">AT-270</a>         |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No.         | Items           | Symptom  | Condition   | Diagnostic Item                                 | Reference page                 |
|-------------|-----------------|--|-------------|---|--------------------------------|
| 10          |                 | Gear does not change from D1 → D2 or from M1 → M2.<br>Refer to <a href="#">AT-175, "A/T Does Not Shift: D1→D2"</a> . | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|             |                 |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|             |                 |  |             | 3. Direct clutch solenoid valve                 | <a href="#">AT-143</a>         |
|             |                 |  |             | 4. Line pressure test                           | <a href="#">AT-47</a>          |
|             |                 |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|             |                 |  |             | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|             |                 |  | OFF vehicle | 7. Direct clutch                                | <a href="#">AT-270</a>         |
| 11          |                 | Gear does not change from D2 → D3 or from M2 → M3.<br>Refer to <a href="#">AT-176, "A/T Does Not Shift: D2→D3"</a> . | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|             |                 |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|             |                 |  |             | 3. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a>         |
|             |                 |  |             | 4. Line pressure test                           | <a href="#">AT-47</a>          |
|             |                 |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|             |                 |  |             | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|             |                 |  | OFF vehicle | 7. High and low reverse clutch                  | <a href="#">AT-269</a>         |
| 12          | No Up Shift     | Gear does not change from D3 → D4 or from M3 → M4.<br>Refer to <a href="#">AT-178, "A/T Does Not Shift: D3→D4"</a> . | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|             |                 |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|             |                 |  |             | 3. Input clutch solenoid valve                  | <a href="#">AT-139</a>         |
|             |                 |  |             | 4. Front brake solenoid valve                   | <a href="#">AT-141</a>         |
|             |                 |  |             | 5. Line pressure test                           | <a href="#">AT-47</a>          |
|             |                 |  |             | 6. CAN communication line                       | <a href="#">AT-90</a>          |
|             |                 |  |             | 7. Control valve with TCM                       | <a href="#">AT-204</a>         |
| OFF vehicle | 8. Input clutch | <a href="#">AT-259</a>   |             |   |                                |
| 13          |                 | Gear does not change from D4 → D5 or from M4 → M5.<br>Refer to <a href="#">AT-180, "A/T Does Not Shift: D4→D5"</a> . | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|             |                 |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|             |                 |  |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>         |
|             |                 |  |             | 4. Direct clutch solenoid valve                 | <a href="#">AT-143</a>         |
|             |                 |  |             | 5. Input speed sensor                           | <a href="#">AT-101</a>         |
|             |                 |  |             | 6. Line pressure test                           | <a href="#">AT-47</a>          |
|             |                 |  |             | 7. CAN communication line                       | <a href="#">AT-90</a>          |
|             |                 |  |             | 8. Control valve with TCM                       | <a href="#">AT-204</a>         |
|             |                 |  | OFF vehicle | 9. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|             |                 |  |             | 10. Input clutch                                | <a href="#">AT-259</a>         |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items         | Symptom  | Condition   | Diagnostic Item                                 | Reference page                 |
|-----|---------------|--|-------------|---|--------------------------------|
| 14  | No Down Shift | In "D" or "M" position, does not downshift to 4GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |               |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |               |  |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>         |
|     |               |  |             | 4. Direct clutch solenoid valve                 | <a href="#">AT-143</a>         |
|     |               |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|     |               |  |             | 6. Line pressure test                           | <a href="#">AT-47</a>          |
|     |               |  |             | 7. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |               |  | OFF vehicle | 8. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|     |               |  |             | 9. Input clutch                                 | <a href="#">AT-259</a>         |
| 15  | No Down Shift | In "D" or "M" position, does not downshift to 3GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |               |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |               |  |             | 3. Input clutch solenoid valve                  | <a href="#">AT-139</a>         |
|     |               |  |             | 4. Front brake solenoid valve                   | <a href="#">AT-141</a>         |
|     |               |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|     |               |  |             | 6. Line pressure test                           | <a href="#">AT-47</a>          |
|     |               |  |             | 7. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |               |  | OFF vehicle | 8. Input clutch                                 | <a href="#">AT-259</a>         |
| 16  | No Down Shift | In "D" or "M" position, does not downshift to 2GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |               |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |               |  |             | 3. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a>         |
|     |               |  |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |               |  |             | 5. Line pressure test                           | <a href="#">AT-47</a>          |
|     |               |  |             | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |               |  | OFF vehicle | 7. High and low reverse clutch                  | <a href="#">AT-269</a>         |
| 17  | No Down Shift | In "D" or "M" position, does not downshift to 1GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |               |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |               |  |             | 3. Direct clutch solenoid valve                 | <a href="#">AT-143</a>         |
|     |               |  |             | 4. CAN communication line                       | <a href="#">AT-90</a>          |
|     |               |  |             | 5. Line pressure test                           | <a href="#">AT-47</a>          |
|     |               |  |             | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |               |  | OFF vehicle | 7. Direct clutch                                | <a href="#">AT-270</a>         |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No.  | Items                  | Symptom                                   | Condition   | Diagnostic Item   | Reference page                 |
|--|------------------------|---|-------------|---|--------------------------------|
| 18   |                        | When "D" or "M" position, remains in 1GR. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|  |                        |   |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103, AT-133</a> |
|  |                        |   |             | 3. Direct clutch solenoid valve   | <a href="#">AT-143</a>         |
|  |                        |   |             | 4. Line pressure test   | <a href="#">AT-47</a>          |
|  |                        |   |             | 5. CAN communication line   | <a href="#">AT-90</a>          |
|  |                        |   |             | 6. Control valve with TCM   | <a href="#">AT-204</a>         |
|  |                        |   | OFF vehicle | 7. 3rd one-way clutch   | <a href="#">AT-257</a>         |
|  |                        |   |             | 8. 1st one-way clutch   | <a href="#">AT-264</a>         |
|  |                        |   |             | 9. Gear system  | <a href="#">AT-232</a>         |
|  |                        |   |             | 10. Reverse brake   | <a href="#">AT-239</a>         |
|  |                        |   |             | 11. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> ) | <a href="#">AT-239</a>         |
| 12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> ) | <a href="#">AT-239</a> |   |             |   |                                |
| 19   | Slips/Will Not Engage  | When "D" or "M" position, remains in 2GR. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|  |                        |   |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103, AT-133</a> |
|  |                        |   |             | 3. Low coast brake solenoid valve   | <a href="#">AT-147</a>         |
|  |                        |   |             | 4. Line pressure test   | <a href="#">AT-47</a>          |
|  |                        |   |             | 5. CAN communication line   | <a href="#">AT-90</a>          |
|  |                        |   |             | 6. Control valve with TCM   | <a href="#">AT-204</a>         |
|  |                        |   | OFF vehicle | 7. 3rd one-way clutch   | <a href="#">AT-257</a>         |
|  |                        |   |             | 8. Gear system  | <a href="#">AT-232</a>         |
|  |                        |   |             | 9. Direct clutch  | <a href="#">AT-270</a>         |
|  |                        |   |             | 10. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> )          | <a href="#">AT-239</a>         |
|  |                        |   |             |   |                                |
| 20   |                        | When "D" or "M" position, remains in 3GR. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|  |                        |   |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103, AT-133</a> |
|  |                        |   |             | 3. Line pressure test   | <a href="#">AT-47</a>          |
|  |                        |   |             | 4. CAN communication line   | <a href="#">AT-90</a>          |
|  |                        |   |             | 5. Control valve with TCM   | <a href="#">AT-204</a>         |
|  |                        |   | OFF vehicle | 6. 3rd one-way clutch   | <a href="#">AT-257</a>         |
|  |                        |   |             | 7. Gear system  | <a href="#">AT-232</a>         |
|  |                        |   |             | 8. High and low reverse clutch  | <a href="#">AT-269</a>         |
|  |                        |   |             | 9. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> )  | <a href="#">AT-239</a>         |
|  |                        |   |             | 10. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> )          | <a href="#">AT-239</a>         |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom                                   | Condition   | Diagnostic Item                                 | Reference page                                     |    |
|-----|-----------------------|---|-------------|---|--|----|
| 21  | Slips/Will Not Engage | When "D" or "M" position, remains in 4GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>                              | A  |
|     |                       |   |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> | B  |
|     |                       |   |             | 3. Input clutch solenoid valve                  | <a href="#">AT-139</a>                             | AT |
|     |                       |   |             | 4. Direct clutch solenoid valve                 | <a href="#">AT-143</a>                             |    |
|     |                       |   |             | 5. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a>                             |    |
|     |                       |   |             | 6. Low coast brake solenoid valve               | <a href="#">AT-147</a>                             |    |
|     |                       |   |             | 7. Front brake solenoid valve                   | <a href="#">AT-141</a>                             | D  |
|     |                       |   |             | 8. Line pressure test                           | <a href="#">AT-47</a>                              |    |
|     |                       |   |             | 9. CAN communication line                       | <a href="#">AT-90</a>                              | E  |
|     |                       |   |             | 10. Control valve with TCM                      | <a href="#">AT-204</a>                             |    |
|     |                       |   | OFF vehicle | 11. Input clutch                                | <a href="#">AT-259</a>                             |    |
|     |                       |   |             | 12. Gear system                                 | <a href="#">AT-232</a>                             | F  |
|     |                       |   |             | 13. High and low reverse clutch                 | <a href="#">AT-269</a>                             |    |
|     |                       |   |             | 14. Direct clutch                               | <a href="#">AT-270</a>                             | G  |
| 22  |                       | When "D" or "M" position, remains in 5GR. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>                              | H  |
|     |                       |   |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> | H  |
|     |                       |   |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>                             |    |
|     |                       |   |             | 4. Line pressure test                           | <a href="#">AT-47</a>                              |    |
|     |                       |   |             | 5. CAN communication line                       | <a href="#">AT-90</a>                              | I  |
|     |                       |   |             | 6. Control valve with TCM                       | <a href="#">AT-204</a>                             |    |
|     |                       |   | OFF vehicle | 7. Front brake (brake band)                     | <a href="#">AT-239</a>                             | J  |
|     |                       |   |             | 8. Input clutch                                 | <a href="#">AT-259</a>                             |    |
|     |                       |   |             | 9. Gear system                                  | <a href="#">AT-232</a>                             |    |
|     |                       |   |             | 10. High and low reverse clutch                 | <a href="#">AT-269</a>                             | K  |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No.                                       | Items                  | Symptom   | Condition   | Diagnostic Item   | Reference page         |   |            |                              |                        |
|---|------------------------|---|-------------|---|------------------------|---|------------|------------------------------|------------------------|
| 23  |                        | Vehicle cannot be started from D1. Refer to <a href="#">AT-173, "Vehicle Cannot Be Started from D1"</a> . | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |   |            |                              |                        |
|   |                        |   |             | 2. Accelerator pedal position sensor  | <a href="#">AT-126</a> |   |            |                              |                        |
|   |                        |   |             | 3. Line pressure test   | <a href="#">AT-47</a>  |   |            |                              |                        |
|   |                        |   |             | 4. CAN communication line   | <a href="#">AT-90</a>  |   |            |                              |                        |
|   |                        |   |             | 5. Control valve with TCM   | <a href="#">AT-204</a> |   |            |                              |                        |
|   |                        |   | OFF vehicle | 6. Torque converter   | <a href="#">AT-239</a> |   |            |                              |                        |
|   |                        |   |             | 7. Oil pump assembly  | <a href="#">AT-255</a> |   |            |                              |                        |
|   |                        |   |             | 8. 3rd one-way clutch   | <a href="#">AT-257</a> |   |            |                              |                        |
|   |                        |   |             | 9. 1st one-way clutch   | <a href="#">AT-264</a> |   |            |                              |                        |
|   |                        |   |             | 10. Gear system   | <a href="#">AT-232</a> |   |            |                              |                        |
|   |                        |   |             | 11. Reverse brake   | <a href="#">AT-239</a> |   |            |                              |                        |
|   |                        |   |             | 12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View"</a> .) | <a href="#">AT-239</a> |   |            |                              |                        |
|   |                        |   |             | 13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View"</a> .)          | <a href="#">AT-239</a> |   |            |                              |                        |
| 24  | Slips/Will Not Engage  | Does not lock-up. Refer to <a href="#">AT-181, "A/T Does Not Lock-up"</a> .                               | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |   |            |                              |                        |
|   |                        |   |             | 2. Line pressure test   | <a href="#">AT-47</a>  |   |            |                              |                        |
|   |                        |   |             | 3. Engine speed signal  | <a href="#">AT-108</a> |   |            |                              |                        |
|   |                        |   |             | 4. Input speed sensor   | <a href="#">AT-101</a> |   |            |                              |                        |
|   |                        |   |             | 5. Torque converter clutch solenoid valve   | <a href="#">AT-120</a> |   |            |                              |                        |
|   |                        |   |             | 6. CAN communication line   | <a href="#">AT-90</a>  |   |            |                              |                        |
|   |                        |   |             | 7. Control valve with TCM   | <a href="#">AT-204</a> |   |            |                              |                        |
|   |                        |   | OFF vehicle | 8. Torque converter   | <a href="#">AT-239</a> |   |            |                              |                        |
|   |                        |   |             | 9. Oil pump assembly  | <a href="#">AT-255</a> |   |            |                              |                        |
|   |                        |   |             | 25  |                        | Does not hold lock-up condition. Refer to <a href="#">AT-183, "A/T Does Not Hold Lock-up Condition"</a> . | ON vehicle | 1. A/T fluid level and state | <a href="#">AT-47</a>  |
|   |                        |   |             |   |                        |   |            | 2. Line pressure test        | <a href="#">AT-47</a>  |
|   |                        |   |             |   |                        |   |            | 3. Engine speed signal       | <a href="#">AT-108</a> |
|   |                        |   |             |   |                        |   |            | 4. Input speed sensor        | <a href="#">AT-101</a> |
| 5. Torque converter clutch solenoid valve | <a href="#">AT-120</a> |   |             |   |                        |   |            |                              |                        |
| 6. CAN communication line                 | <a href="#">AT-90</a>  |   |             |   |                        |   |            |                              |                        |
| 7. Control valve with TCM                 | <a href="#">AT-204</a> |   |             |   |                        |   |            |                              |                        |
| OFF vehicle                               | 8. Torque converter    | <a href="#">AT-239</a>  |             |   |                        |   |            |                              |                        |
|   | 9. Oil pump assembly   | <a href="#">AT-255</a>  |             |   |                        |   |            |                              |                        |



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom  | Condition   | Diagnostic Item  | Reference page                                     |
|-----|-----------------------|--|-------------|--|--|
| 26  |                       | Lock-up is not released.<br>Refer to <a href="#">AT-184</a> , " <a href="#">Lock-up Is Not Released</a> ". | ON vehicle  | 1. A/T fluid level and state   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Line pressure test  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 3. Engine speed signal   | <a href="#">AT-108</a>                             |
|     |                       |  |             | 4. Input speed sensor  | <a href="#">AT-101</a>                             |
|     |                       |  |             | 5. Torque converter clutch solenoid valve  | <a href="#">AT-120</a>                             |
|     |                       |  |             | 6. CAN communication line  | <a href="#">AT-90</a>                              |
|     |                       |  |             | 7. Control valve with TCM  | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter  | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly   | <a href="#">AT-255</a>                             |
| 27  | Slips/Will Not Engage | No shock at all or the clutch slips when vehicle changes speed D1 → D2 or M1 → M2.                         | ON vehicle  | 1. A/T fluid level and state   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal  | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. Direct clutch solenoid valve  | <a href="#">AT-143</a>                             |
|     |                       |  |             | 4. CAN communication line  | <a href="#">AT-90</a>                              |
|     |                       |  |             | 5. Line pressure test  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 6. Control valve with TCM  | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 7. Torque converter  | <a href="#">AT-239</a>                             |
|     |                       |  |             | 8. Oil pump assembly   | <a href="#">AT-255</a>                             |
|     |                       |  |             | 9. 3rd one-way clutch  | <a href="#">AT-257</a>                             |
|     |                       |  |             | 10. Gear system  | <a href="#">AT-232</a>                             |
|     |                       |  |             | 11. Direct clutch  | <a href="#">AT-270</a>                             |
|     |                       |  |             | 12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>                             |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom  | Condition   | Diagnostic Item   | Reference page                                     |
|-----|-----------------------|--|-------------|---|--|
| 28  | Slips/Will Not Engage | No shock at all or the clutch slips when vehicle changes speed D2 → D3 or M2 → M3. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a>                             |
|     |                       |  |             | 4. CAN communication line   | <a href="#">AT-90</a>                              |
|     |                       |  |             | 5. Line pressure test   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 6. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 7. Torque converter   | <a href="#">AT-239</a>                             |
|     |                       |  |             | 8. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |                       |  |             | 9. 3rd one-way clutch   | <a href="#">AT-257</a>                             |
|     |                       |  |             | 10. Gear system   | <a href="#">AT-232</a>                             |
|     |                       |  |             | 11. High and low reverse clutch   | <a href="#">AT-269</a>                             |
|     |                       |  |             | 12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>                             |
|     |                       |  |             | 13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a>                             |
| 29  | Slips/Will Not Engage | No shock at all or the clutch slips when vehicle changes speed D3 → D4 or M3 → M4. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. Input clutch solenoid valve  | <a href="#">AT-139</a>                             |
|     |                       |  |             | 4. Front brake solenoid valve   | <a href="#">AT-141</a>                             |
|     |                       |  |             | 5. CAN communication line   | <a href="#">AT-90</a>                              |
|     |                       |  |             | 6. Line pressure test   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 7. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter   | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |                       |  |             | 10. Input clutch  | <a href="#">AT-259</a>                             |
|     |                       |  |             | 11. Gear system   | <a href="#">AT-232</a>                             |
|     |                       |  |             | 12. High and low reverse clutch   | <a href="#">AT-269</a>                             |
|     |                       |  |             | 13. Direct clutch   | <a href="#">AT-270</a>                             |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom  | Condition   | Diagnostic Item                                 | Reference page                                     |
|-----|-----------------------|--|-------------|---|--|
| 30  | Slips/Will Not Engage | No shock at all or the clutch slips when vehicle changes speed D4 → D5 or M4 → M5.                         | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>                             |
|     |                       |  |             | 4. Direct clutch solenoid valve                 | <a href="#">AT-143</a>                             |
|     |                       |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>                              |
|     |                       |  |             | 6. Line pressure test                           | <a href="#">AT-47</a>                              |
|     |                       |  |             | 7. Control valve with TCM                       | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter                             | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly                            | <a href="#">AT-255</a>                             |
|     |                       |  |             | 10. Front brake (brake band)                    | <a href="#">AT-239</a>                             |
|     |                       |  |             | 11. Input clutch                                | <a href="#">AT-259</a>                             |
|     |                       |  |             | 12. Gear system                                 | <a href="#">AT-232</a>                             |
|     |                       |  |             | 13. High and low reverse clutch                 | <a href="#">AT-269</a>                             |
| 31  | Slips/Will Not Engage | When you press the accelerator pedal and shift speed D5 → D4 or M5 → M4 the engine idles or the A/T slips. | ON vehicle  | 1. A/T fluid level and state                    | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>                             |
|     |                       |  |             | 4. Direct clutch solenoid valve                 | <a href="#">AT-143</a>                             |
|     |                       |  |             | 5. CAN communication line                       | <a href="#">AT-90</a>                              |
|     |                       |  |             | 6. Line pressure test                           | <a href="#">AT-47</a>                              |
|     |                       |  |             | 7. Control valve with TCM                       | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter                             | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly                            | <a href="#">AT-255</a>                             |
|     |                       |  |             | 10. Input clutch                                | <a href="#">AT-259</a>                             |
|     |                       |  |             | 11. Gear system                                 | <a href="#">AT-232</a>                             |
|     |                       |  |             | 12. High and low reverse clutch                 | <a href="#">AT-269</a>                             |
|     |                       |  |             | 13. Direct clutch                               | <a href="#">AT-270</a>                             |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom  | Condition   | Diagnostic Item   | Reference page                                     |
|-----|-----------------------|--|-------------|---|--|
| 32  | Slips/Will Not Engage | When you press the accelerator pedal and shift speed D4 → D3 or M4 → M3 the engine idles or the A/T slips. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. Input clutch solenoid valve  | <a href="#">AT-139</a>                             |
|     |                       |  |             | 4. Front brake solenoid valve   | <a href="#">AT-141</a>                             |
|     |                       |  |             | 5. CAN communication line   | <a href="#">AT-90</a>                              |
|     |                       |  |             | 6. Line pressure test   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 7. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter   | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |                       |  |             | 10. 3rd one-way clutch  | <a href="#">AT-257</a>                             |
|     |                       |  |             | 11. Gear system   | <a href="#">AT-232</a>                             |
|     |                       |  |             | 12. High and low reverse clutch   | <a href="#">AT-269</a>                             |
|     |                       |  |             | 13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> . "Cross-Sectional View".) | <a href="#">AT-239</a>                             |
|     |                       |  |             | 14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> . "Cross-Sectional View".)          | <a href="#">AT-239</a>                             |
| 33  |                       | When you press the accelerator pedal and shift speed D3 → D2 or M3 → M2 the engine idles or the A/T slips. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |                       |  |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |                       |  |             | 3. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a>                             |
|     |                       |  |             | 4. Direct clutch solenoid valve   | <a href="#">AT-143</a>                             |
|     |                       |  |             | 5. CAN communication line   | <a href="#">AT-90</a>                              |
|     |                       |  |             | 6. Line pressure test   | <a href="#">AT-47</a>                              |
|     |                       |  |             | 7. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |                       |  | OFF vehicle | 8. Torque converter   | <a href="#">AT-239</a>                             |
|     |                       |  |             | 9. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |                       |  |             | 10. 3rd one-way clutch  | <a href="#">AT-257</a>                             |
|     |                       |  |             | 11. Gear system   | <a href="#">AT-232</a>                             |
|     |                       |  |             | 12. Direct clutch   | <a href="#">AT-270</a>                             |
|     |                       |  |             | 13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> . "Cross-Sectional View".)          | <a href="#">AT-239</a>                             |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items  | Symptom  | Condition   | Diagnostic Item   | Reference page                                     |
|-----|--|--|-------------|---|--|
| 34  | Slips/Will Not Engage  | When you press the accelerator pedal and shift speed D2 → D1 or M2 → M1 the engine idles or the A/T slips. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |  |  |             | 2. Output speed sensor and vehicle speed signal   | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |  |  |             | 3. Direct clutch solenoid valve   | <a href="#">AT-143</a>                             |
|     |  |  |             | 4. CAN communication line   | <a href="#">AT-90</a>                              |
|     |  |  |             | 5. Line pressure test   | <a href="#">AT-47</a>                              |
|     |  |  |             | 6. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |  |  | OFF vehicle | 7. Torque converter   | <a href="#">AT-239</a>                             |
|     |  |  |             | 8. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |  |  |             | 9. 3rd one-way clutch   | <a href="#">AT-257</a>                             |
|     |  |  |             | 10. 1st one-way clutch  | <a href="#">AT-264</a>                             |
|     |  |  |             | 11. Gear system   | <a href="#">AT-232</a>                             |
|     |  |  |             | 12. Reverse brake   | <a href="#">AT-239</a>                             |
|     |  |  |             | 13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>                             |
|     |  |  |             | 14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a>                             |
| 35  | With selector lever in "D" position, acceleration is extremely poor. |  | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>                              |
|     |  |  |             | 2. Line pressure test   | <a href="#">AT-47</a>                              |
|     |  |  |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a>                             |
|     |  |  |             | 4. CAN communication line   | <a href="#">AT-90</a>                              |
|     |  |  |             | 5. Transmission range switch  | <a href="#">AT-98</a>                              |
|     |  |  |             | 6. A/T position   | <a href="#">AT-195</a>                             |
|     |  |  |             | 7. Control valve with TCM   | <a href="#">AT-204</a>                             |
|     |  |  | OFF vehicle | 8. Torque converter   | <a href="#">AT-239</a>                             |
|     |  |  |             | 9. Oil pump assembly  | <a href="#">AT-255</a>                             |
|     |  |  |             | 10. 1st one-way clutch  | <a href="#">AT-264</a>                             |
|     |  |  |             | 11. Gear system   | <a href="#">AT-232</a>                             |
|     |  |  |             | 12. Reverse brake   | <a href="#">AT-239</a>                             |
|     |  |  |             | 13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>                             |
|     |  |  |             | 14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a>                             |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom   | Condition   | Diagnostic Item   | Reference page         |
|-----|-----------------------|---|-------------|---|------------------------|
| 36  |                       | With selector lever in "R" position, acceleration is extremely poor.        | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |                       |   |             | 4. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a> |
|     |                       |   |             | 5. CAN communication line   | <a href="#">AT-90</a>  |
|     |                       |   |             | 6. Transmission range switch  | <a href="#">AT-98</a>  |
|     |                       |   |             | 7. A/T position   | <a href="#">AT-195</a> |
|     |                       |   |             | 8. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 9. Gear system  | <a href="#">AT-232</a> |
|     |                       |   |             | 10. Output shaft  | <a href="#">AT-239</a> |
|     |                       |   |             | 11. Reverse brake   | <a href="#">AT-239</a> |
| 37  | Slips/Will Not Engage | While starting off by accelerating in 1st, engine races or slippage occurs. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |                       |   |             | 4. CAN communication line   | <a href="#">AT-90</a>  |
|     |                       |   |             | 5. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 6. Torque converter   | <a href="#">AT-239</a> |
|     |                       |   |             | 7. Oil pump assembly  | <a href="#">AT-255</a> |
|     |                       |   |             | 8. 3rd one-way clutch   | <a href="#">AT-257</a> |
|     |                       |   |             | 9. 1st one-way clutch   | <a href="#">AT-264</a> |
|     |                       |   |             | 10. Gear system   | <a href="#">AT-232</a> |
|     |                       |   |             | 11. Reverse brake   | <a href="#">AT-239</a> |
|     |                       |   |             | 12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a> |
|     |                       |   |             | 13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a> |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom   | Condition   | Diagnostic Item   | Reference page         |
|-----|-----------------------|---|-------------|---|------------------------|
| 38  |                       | While accelerating in 2GR, engine races or slippage occurs. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |                       |   |             | 4. CAN communication line   | <a href="#">AT-90</a>  |
|     |                       |   |             | 5. Direct clutch solenoid valve   | <a href="#">AT-143</a> |
|     |                       |   |             | 6. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 7. Torque converter   | <a href="#">AT-239</a> |
|     |                       |   |             | 8. Oil pump assembly  | <a href="#">AT-255</a> |
|     |                       |   |             | 9. 3rd one-way clutch   | <a href="#">AT-257</a> |
|     |                       |   |             | 10. Gear system   | <a href="#">AT-232</a> |
|     |                       |   |             | 11. Direct clutch   | <a href="#">AT-270</a> |
|     |                       |   |             | 12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> )          | <a href="#">AT-239</a> |
| 39  | Slips/Will Not Engage | While accelerating in 3GR, engine races or slippage occurs. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |                       |   |             | 4. CAN communication line   | <a href="#">AT-90</a>  |
|     |                       |   |             | 5. High and low reverse clutch solenoid valve   | <a href="#">AT-145</a> |
|     |                       |   |             | 6. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 7. Torque converter   | <a href="#">AT-239</a> |
|     |                       |   |             | 8. Oil pump assembly  | <a href="#">AT-255</a> |
|     |                       |   |             | 9. 3rd one-way clutch   | <a href="#">AT-257</a> |
|     |                       |   |             | 10. Gear system   | <a href="#">AT-232</a> |
|     |                       |   |             | 11. High and low reverse clutch   | <a href="#">AT-269</a> |
|     |                       |   |             | 12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> ) | <a href="#">AT-239</a> |
|     |                       |   |             | 13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> )          | <a href="#">AT-239</a> |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                 | Symptom   | Condition   | Diagnostic Item                           | Reference page         |
|-----|-----------------------|---|-------------|---|------------------------|
| 40  |                       | While accelerating in 4th, engine races or slippage occurs. | ON vehicle  | 1. A/T fluid level and state              | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test                     | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor      | <a href="#">AT-126</a> |
|     |                       |   |             | 4. CAN communication line                 | <a href="#">AT-90</a>  |
|     |                       |   |             | 5. Input clutch solenoid valve            | <a href="#">AT-139</a> |
|     |                       |   |             | 6. Control valve with TCM                 | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 7. Torque converter                       | <a href="#">AT-239</a> |
|     |                       |   |             | 8. Oil pump assembly                      | <a href="#">AT-255</a> |
|     |                       |   |             | 9. Input clutch                           | <a href="#">AT-259</a> |
|     |                       |   |             | 10. Gear system                           | <a href="#">AT-232</a> |
|     |                       |   |             | 11. High and low reverse clutch           | <a href="#">AT-269</a> |
|     |                       |   |             | 12. Direct clutch                         | <a href="#">AT-270</a> |
| 41  | Slips/Will Not Engage | While accelerating in 5th, engine races or slippage occurs. | ON vehicle  | 1. A/T fluid level and state              | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test                     | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Accelerator pedal position sensor      | <a href="#">AT-126</a> |
|     |                       |   |             | 4. CAN communication line                 | <a href="#">AT-90</a>  |
|     |                       |   |             | 5. Front brake solenoid valve             | <a href="#">AT-141</a> |
|     |                       |   |             | 6. Control valve with TCM                 | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 7. Torque converter                       | <a href="#">AT-239</a> |
|     |                       |   |             | 8. Oil pump assembly                      | <a href="#">AT-255</a> |
|     |                       |   |             | 9. Front brake (brake band)               | <a href="#">AT-239</a> |
|     |                       |   |             | 10. Input clutch                          | <a href="#">AT-259</a> |
|     |                       |   |             | 11. Gear system                           | <a href="#">AT-232</a> |
|     |                       |   |             | 12. High and low reverse clutch           | <a href="#">AT-269</a> |
| 42  |                       | Slips at lock-up.   | ON vehicle  | 1. A/T fluid level and state              | <a href="#">AT-47</a>  |
|     |                       |   |             | 2. Line pressure test                     | <a href="#">AT-47</a>  |
|     |                       |   |             | 3. Engine speed signal                    | <a href="#">AT-108</a> |
|     |                       |   |             | 4. Input speed sensor                     | <a href="#">AT-101</a> |
|     |                       |   |             | 5. Torque converter clutch solenoid valve | <a href="#">AT-120</a> |
|     |                       |   |             | 6. CAN communication line                 | <a href="#">AT-90</a>  |
|     |                       |   |             | 7. Control valve with TCM                 | <a href="#">AT-204</a> |
|     |                       |   | OFF vehicle | 8. Torque converter                       | <a href="#">AT-239</a> |
|     |                       |   |             | 9. Oil pump assembly                      | <a href="#">AT-255</a> |



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items                                | Symptom  | Condition   | Diagnostic Item   | Reference page         |
|-----|--------------------------------------|--|-------------|---|------------------------|
| 43  | Slips/Will Not Engage                | No creep at all. Refer to <a href="#">AT-169</a> , " <a href="#">Vehicle Does Not Creep Backward in "R" Position</a> ", <a href="#">AT-171</a> , " <a href="#">Vehicle Does Not Creep Forward in "D" Position</a> ". | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                                      |  |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                                      |  |             | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |                                      |  |             | 4. Direct clutch solenoid valve   | <a href="#">AT-143</a> |
|     |                                      |  |             | 5. Transmission range switch  | <a href="#">AT-98</a>  |
|     |                                      |  |             | 6. CAN communication line   | <a href="#">AT-90</a>  |
|     |                                      |  |             | 7. A/T position   | <a href="#">AT-195</a> |
|     |                                      |  |             | 8. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                                      |  | OFF vehicle | 9. Torque converter   | <a href="#">AT-239</a> |
|     |                                      |  |             | 10. Oil pump assembly   | <a href="#">AT-255</a> |
|     |                                      |  |             | 11. 1st one-way clutch  | <a href="#">AT-264</a> |
|     |                                      |  |             | 12. Gear system   | <a href="#">AT-232</a> |
|     |                                      |  |             | 13. Reverse brake   | <a href="#">AT-239</a> |
|     |                                      |  |             | 14. Direct clutch   | <a href="#">AT-270</a> |
|     |                                      |  |             | 15. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a> |
|     |                                      |  |             | 16. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a> |
| 44  | Vehicle cannot run in all positions. |  | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |                                      |  |             | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |                                      |  |             | 3. Transmission range switch  | <a href="#">AT-98</a>  |
|     |                                      |  |             | 4. A/T position   | <a href="#">AT-195</a> |
|     |                                      |  | OFF vehicle | 5. Control valve with TCM   | <a href="#">AT-204</a> |
|     |                                      |  |             | 6. Oil pump assembly  | <a href="#">AT-255</a> |
|     |                                      |  |             | 7. Gear system  | <a href="#">AT-232</a> |
|     |                                      |  |             | 8. Output shaft   | <a href="#">AT-239</a> |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No.                       | Items                       | Symptom  | Condition   | Diagnostic Item   | Reference page   |            |                              |                        |
|---------------------------|-----------------------------|--|-------------|---|--|------------|------------------------------|------------------------|
| 45                        | Slips/Will Not Engage       | With selector lever in "D" position, driving is not possible.  | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |            |                              |                        |
|                           |                             |  |             | 2. Line pressure test   | <a href="#">AT-47</a>  |            |                              |                        |
|                           |                             |  |             | 3. Transmission range switch  | <a href="#">AT-98</a>  |            |                              |                        |
|                           |                             |  |             | 4. A/T position   | <a href="#">AT-195</a>   |            |                              |                        |
|                           |                             |  |             | 5. Control valve with TCM   | <a href="#">AT-204</a>   |            |                              |                        |
|                           |                             |  | OFF vehicle | 6. Torque converter   | <a href="#">AT-239</a>   |            |                              |                        |
|                           |                             |  |             | 7. Oil pump assembly  | <a href="#">AT-255</a>   |            |                              |                        |
|                           |                             |  |             | 8. 1st one-way clutch   | <a href="#">AT-264</a>   |            |                              |                        |
|                           |                             |  |             | 9. Gear system  | <a href="#">AT-232</a>   |            |                              |                        |
|                           |                             |  |             | 10. Reverse brake   | <a href="#">AT-239</a>   |            |                              |                        |
|                           |                             |  |             | 11. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a>   |            |                              |                        |
|                           |                             |  |             | 12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a>   |            |                              |                        |
| 46                        |                             | With selector lever in "R" position, driving is not possible.  | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |            |                              |                        |
|                           |                             |  |             | 2. Line pressure test   | <a href="#">AT-47</a>  |            |                              |                        |
|                           |                             |  |             | 3. Transmission range switch  | <a href="#">AT-98</a>  |            |                              |                        |
|                           |                             |  |             | 4. A/T position   | <a href="#">AT-195</a>   |            |                              |                        |
|                           |                             |  |             | 5. Control valve with TCM   | <a href="#">AT-204</a>   |            |                              |                        |
|                           |                             |  | OFF vehicle | 6. Gear system  | <a href="#">AT-232</a>   |            |                              |                        |
|                           |                             |  |             | 7. Output shaft   | <a href="#">AT-239</a>   |            |                              |                        |
|                           |                             |  |             | 8. Reverse brake  | <a href="#">AT-239</a>   |            |                              |                        |
| 47                        | Does Not Change             | Does not change M5 → M4.<br>Refer to <a href="#">AT-186</a> , " <a href="#">A/T Does Not Shift: 5GR → 4GR</a> ". | ON vehicle  | 1. Transmission range switch  | <a href="#">AT-98</a>  |            |                              |                        |
|                           |                             |  |             | 2. A/T fluid level and state  | <a href="#">AT-47</a>  |            |                              |                        |
|                           |                             |  |             | 3. A/T position   | <a href="#">AT-195</a>   |            |                              |                        |
|                           |                             |  |             | 4. Manual mode switch   | <a href="#">AT-151</a>   |            |                              |                        |
|                           |                             |  |             | 5. CAN communication line   | <a href="#">AT-90</a>  |            |                              |                        |
|                           |                             |  |             | 6. Control valve with TCM   | <a href="#">AT-204</a>   |            |                              |                        |
|                           |                             |  | OFF vehicle | 7. Front brake (brake band)   | <a href="#">AT-239</a>   |            |                              |                        |
|                           |                             |  | 48          |   | Does not change M4 → M3.<br>Refer to <a href="#">AT-187</a> , " <a href="#">A/T Does Not Shift: 4GR → 3GR</a> ". | ON vehicle | 1. Transmission range switch | <a href="#">AT-98</a>  |
|                           |                             |  |             |   |  |            | 2. A/T fluid level and state | <a href="#">AT-47</a>  |
|                           |                             |  |             |   |  |            | 3. A/T position              | <a href="#">AT-195</a> |
| 4. Manual mode switch     | <a href="#">AT-151</a>      |  |             |   |  |            |                              |                        |
| 5. CAN communication line | <a href="#">AT-90</a>       |  |             |   |  |            |                              |                        |
| 6. Control valve with TCM | <a href="#">AT-204</a>      |  |             |   |  |            |                              |                        |
| OFF vehicle               | 7. Front brake (brake band) | <a href="#">AT-239</a>   |             |   |  |            |                              |                        |
| 8. Input clutch           | <a href="#">AT-259</a>      |  |             |   |  |            |                              |                        |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items  | Symptom  | Condition                 | Diagnostic Item                                 | Reference page                 |
|-----|--|--|---------------------------|---|--------------------------------|
| 49  | Does Not Change  | Does not change M3 → M2.<br>Refer to <a href="#">AT-188, "A/T Does Not Shift: 3GR → 2GR"</a> . | ON vehicle                | 1. Transmission range switch                    | <a href="#">AT-98</a>          |
|     |  |  |                           | 2. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |  |  |                           | 3. A/T position                                 | <a href="#">AT-195</a>         |
|     |  |  |                           | 4. Manual mode switch                           | <a href="#">AT-151</a>         |
|     |  |  |                           | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|     |  |  |                           | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |  |  | OFF vehicle               | 7. Front brake (brake band)                     | <a href="#">AT-239</a>         |
|     |  |  |                           | 8. Input clutch                                 | <a href="#">AT-259</a>         |
|     |  |  |                           | 9. High and low reverse clutch                  | <a href="#">AT-269</a>         |
| 50  | Does Not Change  | Does not change M2 → M1.<br>Refer to <a href="#">AT-189, "A/T Does Not Shift: 2GR → 1GR"</a> . | ON vehicle                | 1. Transmission range switch                    | <a href="#">AT-98</a>          |
|     |  |  |                           | 2. A/T fluid level and state                    | <a href="#">AT-47</a>          |
|     |  |  |                           | 3. A/T position                                 | <a href="#">AT-195</a>         |
|     |  |  |                           | 4. Manual mode switch                           | <a href="#">AT-151</a>         |
|     |  |  |                           | 5. CAN communication line                       | <a href="#">AT-90</a>          |
|     |  |  |                           | 6. Control valve with TCM                       | <a href="#">AT-204</a>         |
|     |  |  | OFF vehicle               | 7. Input clutch                                 | <a href="#">AT-259</a>         |
|     |  |  |                           | 8. High and low reverse clutch                  | <a href="#">AT-269</a>         |
|     |  |  |                           | 9. Direct clutch                                | <a href="#">AT-270</a>         |
| 51  | Cannot be changed to manual mode.<br>Refer to <a href="#">AT-185, "Cannot Be Changed to Manual Mode"</a> . | ON vehicle   | 1. Manual mode switch     | <a href="#">AT-151</a>                          |                                |
|     |  |  | 2. Input speed sensor     | <a href="#">AT-101</a>                          |                                |
|     |  |  | 3. CAN communication line | <a href="#">AT-90</a>                           |                                |
| 52  | Others   | Shift point is high in "D" position.   | ON vehicle                | 1. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |  |  |                           | 2. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |  |  |                           | 3. CAN communication line                       | <a href="#">AT-90</a>          |
|     |  |  |                           | 4. A/T fluid temperature sensor                 | <a href="#">AT-128</a>         |
|     |  |  |                           | 5. Control valve with TCM                       | <a href="#">AT-204</a>         |
| 53  | Others   | Shift point is low in "D" position.  | ON vehicle                | 1. Output speed sensor and vehicle speed signal | <a href="#">AT-103, AT-133</a> |
|     |  |  |                           | 2. Accelerator pedal position sensor            | <a href="#">AT-126</a>         |
|     |  |  |                           | 3. CAN communication line                       | <a href="#">AT-90</a>          |
|     |  |  |                           | 4. Control valve with TCM                       | <a href="#">AT-204</a>         |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items  | Symptom                        | Condition   | Diagnostic Item   | Reference page                 |
|-----|--------|--------------------------------|-------------|---|--------------------------------|
| 54  |        | Judder occurs during lock-up.  | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|     |        |                                |             | 2. Engine speed signal  | <a href="#">AT-108</a>         |
|     |        |                                |             | 3. Input speed sensor   | <a href="#">AT-101</a>         |
|     |        |                                |             | 4. Output speed sensor and vehicle speed signal   | <a href="#">AT-103, AT-133</a> |
|     |        |                                |             | 5. Accelerator pedal position sensor  | <a href="#">AT-126</a>         |
|     |        |                                |             | 6. CAN communication line   | <a href="#">AT-90</a>          |
|     |        |                                |             | 7. Torque converter clutch solenoid valve   | <a href="#">AT-120</a>         |
|     |        |                                |             | 8. Control valve with TCM   | <a href="#">AT-204</a>         |
|     |        |                                | OFF vehicle | 9. Torque converter   | <a href="#">AT-239</a>         |
| 55  | Others | Strange noise in "R" position. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|     |        |                                |             | 2. Engine speed signal  | <a href="#">AT-108</a>         |
|     |        |                                |             | 3. CAN communication line   | <a href="#">AT-90</a>          |
|     |        |                                |             | 4. Control valve with TCM   | <a href="#">AT-204</a>         |
|     |        |                                | OFF vehicle | 5. Torque converter   | <a href="#">AT-239</a>         |
|     |        |                                |             | 6. Oil pump assembly  | <a href="#">AT-255</a>         |
|     |        |                                |             | 7. Gear system  | <a href="#">AT-232</a>         |
|     |        |                                |             | 8. High and low reverse clutch  | <a href="#">AT-269</a>         |
|     |        |                                |             | 9. Reverse brake  | <a href="#">AT-239</a>         |
| 56  |        | Strange noise in "N" position. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|     |        |                                |             | 2. Engine speed signal  | <a href="#">AT-108</a>         |
|     |        |                                |             | 3. CAN communication line   | <a href="#">AT-90</a>          |
|     |        |                                |             | 4. Control valve with TCM   | <a href="#">AT-204</a>         |
|     |        |                                | OFF vehicle | 5. Torque converter   | <a href="#">AT-239</a>         |
|     |        |                                |             | 6. Oil pump assembly  | <a href="#">AT-255</a>         |
|     |        |                                |             | 7. Gear system  | <a href="#">AT-232</a>         |
| 57  |        | Strange noise in "D" position. | ON vehicle  | 1. A/T fluid level and state  | <a href="#">AT-47</a>          |
|     |        |                                |             | 2. Engine speed signal  | <a href="#">AT-108</a>         |
|     |        |                                |             | 3. CAN communication line   | <a href="#">AT-90</a>          |
|     |        |                                |             | 4. Control valve with TCM   | <a href="#">AT-204</a>         |
|     |        |                                | OFF vehicle | 5. Torque converter   | <a href="#">AT-239</a>         |
|     |        |                                |             | 6. Oil pump assembly  | <a href="#">AT-255</a>         |
|     |        |                                |             | 7. Gear system  | <a href="#">AT-232</a>         |
|     |        |                                |             | 8. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View".</a> ) | <a href="#">AT-239</a>         |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No.                       | Items                          | Symptom  | Condition   | Diagnostic Item                | Reference page         |            |                              |                       |
|---------------------------|--------------------------------|--|-------------|--------------------------------|------------------------|------------|------------------------------|-----------------------|
| 58                        |                                | Vehicle does not decelerate by engine brake.<br>Refer to <a href="#">AT-191</a> , " <a href="#">Vehicle Does Not Decelerate by Engine Brake</a> ". | ON vehicle  | 1. Transmission range switch   | <a href="#">AT-98</a>  |            |                              |                       |
|                           |                                |  |             | 2. A/T fluid level and state   | <a href="#">AT-47</a>  |            |                              |                       |
|                           |                                |  |             | 3. A/T position                | <a href="#">AT-195</a> |            |                              |                       |
|                           |                                |  |             | 4. Manual mode switch          | <a href="#">AT-151</a> |            |                              |                       |
|                           |                                |  |             | 5. CAN communication line      | <a href="#">AT-90</a>  |            |                              |                       |
|                           |                                |  |             | 6. Control valve with TCM      | <a href="#">AT-204</a> |            |                              |                       |
|                           |                                |  | OFF vehicle | 7. Input clutch                | <a href="#">AT-259</a> |            |                              |                       |
|                           |                                |  |             | 8. High and low reverse clutch | <a href="#">AT-269</a> |            |                              |                       |
|                           |                                |  |             | 9. Direct clutch               | <a href="#">AT-270</a> |            |                              |                       |
| 59                        |                                | Engine brake does not work M5 → M4.  | ON vehicle  | 1. Transmission range switch   | <a href="#">AT-98</a>  |            |                              |                       |
|                           |                                |  |             | 2. A/T fluid level and state   | <a href="#">AT-47</a>  |            |                              |                       |
|                           |                                |  |             | 3. A/T position                | <a href="#">AT-195</a> |            |                              |                       |
|                           |                                |  |             | 4. Manual mode switch          | <a href="#">AT-151</a> |            |                              |                       |
|                           |                                |  |             | 5. CAN communication line      | <a href="#">AT-90</a>  |            |                              |                       |
|                           |                                |  |             | 6. Control valve with TCM      | <a href="#">AT-204</a> |            |                              |                       |
|                           |                                |  | OFF vehicle | 7. Front brake (brake band)    | <a href="#">AT-239</a> |            |                              |                       |
| 60                        | Others                         | Engine brake does not work M4 → M3.  | ON vehicle  | 1. Transmission range switch   | <a href="#">AT-98</a>  |            |                              |                       |
|                           |                                |  |             | 2. A/T fluid level and state   | <a href="#">AT-47</a>  |            |                              |                       |
|                           |                                |  |             | 3. A/T position                | <a href="#">AT-195</a> |            |                              |                       |
|                           |                                |  |             | 4. Manual mode switch          | <a href="#">AT-151</a> |            |                              |                       |
|                           |                                |  |             | 5. CAN communication line      | <a href="#">AT-90</a>  |            |                              |                       |
|                           |                                |  |             | 6. Control valve with TCM      | <a href="#">AT-204</a> |            |                              |                       |
|                           |                                |  | OFF vehicle | 7. Front brake (brake band)    | <a href="#">AT-239</a> |            |                              |                       |
|                           |                                |  |             | 8. Input clutch                | <a href="#">AT-259</a> |            |                              |                       |
|                           |                                |  |             | 61                             |                        | ON vehicle | 1. Transmission range switch | <a href="#">AT-98</a> |
|                           |                                |  |             |                                |                        |            | 2. A/T fluid level and state | <a href="#">AT-47</a> |
| 3. A/T position           | <a href="#">AT-195</a>         |  |             |                                |                        |            |                              |                       |
| 4. Manual mode switch     | <a href="#">AT-151</a>         |  |             |                                |                        |            |                              |                       |
| 5. CAN communication line | <a href="#">AT-90</a>          |  |             |                                |                        |            |                              |                       |
| 6. Control valve with TCM | <a href="#">AT-204</a>         |  |             |                                |                        |            |                              |                       |
| OFF vehicle               | 7. Front brake (brake band)    | <a href="#">AT-239</a>   |             |                                |                        |            |                              |                       |
|                           | 8. Input clutch                | <a href="#">AT-259</a>   |             |                                |                        |            |                              |                       |
|                           | 9. High and low reverse clutch | <a href="#">AT-269</a>   |             |                                |                        |            |                              |                       |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items  | Symptom  | Condition           | Diagnostic Item   | Reference page         |
|-----|--------|--|---------------------|---|------------------------|
| 62  | Others | Engine brake does not work M2 → M1.  | ON vehicle          | 1. Transmission range switch  | <a href="#">AT-98</a>  |
|     |        |  |                     | 2. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |        |  |                     | 3. A/T position   | <a href="#">AT-195</a> |
|     |        |  |                     | 4. Manual mode switch   | <a href="#">AT-151</a> |
|     |        |  |                     | 5. CAN communication line   | <a href="#">AT-90</a>  |
|     |        |  |                     | 6. Control valve with TCM   | <a href="#">AT-204</a> |
|     |        |  | OFF vehicle         | 7. Input clutch   | <a href="#">AT-259</a> |
|     |        |  |                     | 8. High and low reverse clutch  | <a href="#">AT-269</a> |
|     |        |  |                     | 9. Direct clutch  | <a href="#">AT-270</a> |
| 63  | Others | Maximum speed low.   | ON vehicle          | 1. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |        |  |                     | 2. Line pressure test   | <a href="#">AT-47</a>  |
|     |        |  |                     | 3. Accelerator pedal position sensor  | <a href="#">AT-126</a> |
|     |        |  |                     | 4. CAN communication line   | <a href="#">AT-90</a>  |
|     |        |  |                     | 5. Direct clutch solenoid valve   | <a href="#">AT-143</a> |
|     |        |  |                     | 6. Control valve with TCM   | <a href="#">AT-204</a> |
|     |        |  | OFF vehicle         | 7. Torque converter   | <a href="#">AT-239</a> |
|     |        |  |                     | 8. Oil pump assembly  | <a href="#">AT-255</a> |
|     |        |  |                     | 9. Input clutch   | <a href="#">AT-259</a> |
|     |        |  |                     | 10. Gear system   | <a href="#">AT-232</a> |
|     |        |  |                     | 11. High and low reverse clutch   | <a href="#">AT-269</a> |
|     |        |  |                     | 12. Direct clutch   | <a href="#">AT-270</a> |
|     |        |  |                     | 13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".) | <a href="#">AT-239</a> |
|     |        |  |                     | 14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17</a> , " <a href="#">Cross-Sectional View</a> ".)          | <a href="#">AT-239</a> |
| 64  | Others | Extremely large creep.   | ON vehicle          | 1. Engine idle speed  | <a href="#">EC-75</a>  |
|     |        |  | OFF vehicle         | 2. CAN communication line   | <a href="#">AT-90</a>  |
|     |        |  | 3. Torque converter | <a href="#">AT-239</a>  |                        |
| 65  | Others | With selector lever in "P" position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled. | ON vehicle          | 1. Transmission range switch  | <a href="#">AT-98</a>  |
|     |        |  |                     | 2. A/T position   | <a href="#">AT-195</a> |
|     |        |  |                     | 3. Parking pawl components  | <a href="#">AT-232</a> |
| 66  | Others | Vehicle runs with A/T in "P" position.   | ON vehicle          | 1. Transmission range switch  | <a href="#">AT-98</a>  |
|     |        |  |                     | 2. A/T fluid level and state  | <a href="#">AT-47</a>  |
|     |        |  |                     | 3. A/T position   | <a href="#">AT-195</a> |
|     |        |  |                     | 4. Control valve with TCM   | <a href="#">AT-204</a> |
|     |        |  |                     | 5. Parking pawl components  | <a href="#">AT-232</a> |
|     |        |  | OFF vehicle         | 6. Gear system  | <a href="#">AT-232</a> |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Items  | Symptom  | Condition   | Diagnostic Item  | Reference page             |
|-----|--------|--|-------------|--|----------------------------|
| 67  |        | Vehicle runs with A/T in "N" position. Refer to <a href="#">AT-167, "In "N" Position, Vehicle Moves"</a> .                         | ON vehicle  | 1. Transmission range switch   | <a href="#">AT-98</a>      |
|     |        |  |             | 2. A/T fluid level and state   | <a href="#">AT-47</a>      |
|     |        |  |             | 3. A/T position  | <a href="#">AT-195</a>     |
|     |        |  |             | 4. Control valve with TCM  | <a href="#">AT-204</a>     |
|     |        |  | OFF vehicle | 5. Input clutch  | <a href="#">AT-259</a>     |
|     |        |  |             | 6. Gear system   | <a href="#">AT-232</a>     |
|     |        |  |             | 7. Direct clutch   | <a href="#">AT-270</a>     |
|     |        |  |             | 8. Reverse brake   | <a href="#">AT-239</a>     |
|     |        |  |             | 9. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View"</a> .) | <a href="#">AT-239</a>     |
|     |        |  |             | 10. Low coast brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to <a href="#">AT-17, "Cross-Sectional View"</a> .)       | <a href="#">AT-239</a>     |
| 68  | Others | Engine does not start in "N" or "P" position. Refer to <a href="#">AT-166, "Engine Cannot Be Started in "P" or "N" Position"</a> . | ON vehicle  | 1. Ignition switch and starter   | <a href="#">PG-4, SC-8</a> |
|     |        |  |             | 2. A/T position  | <a href="#">AT-195</a>     |
|     |        |  |             | 3. Transmission range switch   | <a href="#">AT-98</a>      |
| 69  | Others | Engine starts in positions other than "N" or "P".  | ON vehicle  | 1. Ignition switch and starter   | <a href="#">PG-4, SC-8</a> |
|     |        |  |             | 2. A/T position  | <a href="#">AT-195</a>     |
|     |        |  |             | 3. Transmission range switch   | <a href="#">AT-98</a>      |
| 70  |        | Engine stall.  | ON vehicle  | 1. A/T fluid level and state   | <a href="#">AT-47</a>      |
|     |        |  |             | 2. Engine speed signal   | <a href="#">AT-108</a>     |
|     |        |  |             | 3. Input speed sensor  | <a href="#">AT-101</a>     |
|     |        |  |             | 4. Torque converter clutch solenoid valve  | <a href="#">AT-120</a>     |
|     |        |  |             | 5. CAN communication line  | <a href="#">AT-90</a>      |
|     |        |  |             | 6. Control valve with TCM  | <a href="#">AT-204</a>     |
|     |        |  | OFF vehicle | 7. Torque converter  | <a href="#">AT-239</a>     |
| 71  |        | Engine stalls when selector lever shifted "N" → "D", "R".  | ON vehicle  | 1. A/T fluid level and state   | <a href="#">AT-47</a>      |
|     |        |  |             | 2. Engine speed signal   | <a href="#">AT-108</a>     |
|     |        |  |             | 3. Input speed sensor  | <a href="#">AT-101</a>     |
|     |        |  |             | 4. Torque converter clutch solenoid valve  | <a href="#">AT-120</a>     |
|     |        |  |             | 5. CAN communication line  | <a href="#">AT-90</a>      |
|     |        |  |             | 6. Control valve with TCM  | <a href="#">AT-204</a>     |
|     |        |  | OFF vehicle | 7. Torque converter  | <a href="#">AT-239</a>     |

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TROUBLE DIAGNOSIS


## < SERVICE INFORMATION >

| No. | Items  | Symptom   | Condition        | Diagnostic Item                                 | Reference page                                     |
|-----|--------|---|------------------|---|--|
| 72  | Others | Engine speed does not return to idle. Refer to <a href="#">AT-184</a> , " <a href="#">Engine Speed Does Not Return to Idle</a> ". | ON vehicle       | 1. A/T fluid level and state                    | <a href="#">AT-47</a>                              |
|     |        |   |                  | 2. Direct clutch solenoid valve                 | <a href="#">AT-143</a>                             |
|     |        |   |                  | 3. Front brake solenoid valve                   | <a href="#">AT-141</a>                             |
|     |        |   |                  | 4. Accelerator pedal position sensor            | <a href="#">AT-126</a>                             |
|     |        |   |                  | 5. Output speed sensor and vehicle speed signal | <a href="#">AT-103</a> ,<br><a href="#">AT-133</a> |
|     |        |   |                  | 6. CAN communication line                       | <a href="#">AT-90</a>                              |
|     |        |   |                  | 7. Control valve with TCM                       | <a href="#">AT-204</a>                             |
|     |        |   | OFF vehicle      | 8. Front brake (brake band)                     | <a href="#">AT-239</a>                             |
|     |        |   | 9. Direct clutch | <a href="#">AT-270</a>                          |  |

## TCM Input/Output Signal Reference Value

INFOID:000000004656811





### A/T ASSEMBLY HARNESS CONNECTOR TERMINAL LAYOUT



SCIA1658E

## TCM INSPECTION TABLE

Data are reference value and are measured between each terminal and ground.

| Terminal | Wire color | Item                          | Condition   | Data (Approx.)                           |                 |
|----------|------------|-------------------------------|---|--|-----------------|
| 1        | G          | Power supply (Memory back-up) | Always  | Battery voltage                          |                 |
| 2        | G          | Power supply (Memory back-up) | Always  | Battery voltage                          |                 |
| 3        | L          | CAN-H                         | —   | —  |                 |
| 4        | PU/W       | K-line (CONSULT-III signal)   | The terminal is connected to the data link connector for CONSULT-III.               |  |                 |
| 5        | B          | Ground                        | Always  | 0 V                                      |                 |
| 6        | Y/R        | Power supply                  |  | —  | Battery voltage |
|          |            |                               |  | —  | 0 V             |
| 7        | Y          | Back-up lamp relay            |  | Selector lever in "R" position.          | 0 V             |
|          |            |                               |   | Selector lever in other positions.       | Battery voltage |
| 8        | P          | CAN-L                         | —   | —  |                 |
| 9        | GY/R       | Starter relay                 |  | Selector lever in "N" and "P" positions. | Battery voltage |
|          |            |                               |   | Selector lever in other positions.       | 0 V             |
| 10       | B          | Ground                        | Always  | 0 V                                      |                 |



# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## CONSULT-III Function (TRANSMISSION)

INFOID:000000004656812

CONSULT-III can display each diagnostic item using the diagnostic test mode shown following.

### FUNCTION

| Diagnostic test mode           | Function  |
|--------------------------------|---|
| Self Diagnostic Results        | Retrieve DTC from ECU and display diagnostic items.   |
| Data Monitor                   | Monitor the input/output signal of the control unit in real time.   |
| CAN Diagnosis                  | This mode displays a network diagnosis result about CAN by a diagram.   |
| CAN Diagnostic Support Monitor | It monitors the starts of CAN communication.  |
| DTC & SRT confirmation         | The status of system monitoring tests and the self-diagnosis status/result can be confirmed.  |
| ECU Identification             | Display the ECU identification number (part number etc.) of the selected system.  |
| Function Test*                 | This mode can show results of self-diagnosis of ECU with either "OK" or "NG". For engine, more practical tests regarding sensors/switches and/or actuators are available. |

\*: Although "Function Test" is selectable, do not use its.

### CONSULT-III REFERENCE VALUE

#### NOTICE:

- The CONSULT-III electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).  
Check for time difference between actual shift timing and the CONSULT-III display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- Shift schedule (which implies gear position) displayed on CONSULT-III and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
  - Actual shift schedule has more or less tolerance or allowance,
  - Shift schedule indicated in Service Manual refers to the point where shifts start, and
  - Gear position displayed on CONSULT-III indicates the point where shifts are completed.
- Display of solenoid valves on CONSULT-III changes at the start of shifting, while gear position is displayed upon completion of shifting (which is computed by TCM).

| Item name     | Condition                                | Display value (Approx.)                         |
|---------------|--|---|
| ATF TEMP SE 1 | 0°C (32° F) – 20°C (68°F) – 80°C (176°F) | 3.3 – 2.7 – 0.9 V                               |
| ATF TEMP SE 2 |  | 3.3 – 2.5 – 0.7 V                               |
| ATF TEMP 1    | Ignition switch ON                       | Temperature of ATF in the oil pan is indicated. |
| TCC SOLENOID  | Lock-up is active                        | 0.4 – 0.6 A                                     |
| SLCT LVR POSI | Selector lever in "N" and "P" positions. | N/P   |
|               | Selector lever in "R" position.          | R   |
|               | Selector lever in "D" position.          | D   |
| VHCL/S SE-A/T | During driving                           | Approximately matches the speedometer reading.  |
| VEHICLE SPEED | During driving                           | Approximately matches the speedometer reading.  |
| ENGINE SPEED  | Engine running                           | Closely matches the tachometer reading.         |
| LINE PRES SOL | During driving                           | 0.2 – 0.6 A                                     |
| INPUT SPEED   | During driving (lock-up ON)              | Approximately matches the engine speed.         |
| VHCL/S SE-MTR | During driving                           | Approximately matches the speedometer reading.  |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Item name     | Condition  | Display value (Approx.) |
|---------------|--|-------------------------|
| ATF PRES SW 2 | Low coast brake engaged. Refer to <a href="#">AT-17</a> .                | ON                      |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> .             | OFF                     |
| I/C SOLENOID  | Input clutch disengaged. Refer to <a href="#">AT-17</a> .                | 0.6 – 0.8 A             |
|               | Input clutch engaged. Refer to <a href="#">AT-17</a> .                   | 0 – 0.05 A              |
| FR/B SOLENOID | Front brake engaged. Refer to <a href="#">AT-17</a> .                    | 0.6 – 0.8 A             |
|               | Front brake disengaged. Refer to <a href="#">AT-17</a> .                 | 0 – 0.05 A              |
| D/C SOLENOID  | Direct clutch disengaged. Refer to <a href="#">AT-17</a> .               | 0.6 – 0.8 A             |
|               | Direct clutch engaged. Refer to <a href="#">AT-17</a> .                  | 0 – 0.05 A              |
| HLR/C SOL     | High and low reverse clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|               | High and low reverse clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |
| ON OFF SOL    | Low coast brake engaged. Refer to <a href="#">AT-17</a> .                | ON                      |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> .             | OFF                     |
| MANU MODE SW  | Manual shift gate position (neutral)                                     | ON                      |
|               | Other than the above   | OFF                     |
| NON M-MODE SW | Manual shift gate position   | OFF                     |
|               | Other than the above   | ON                      |
| UP SW LEVER   | Selector lever: + side   | ON                      |
|               | Other than the above   | OFF                     |
| DOWN SW LEVER | Selector lever: - side   | ON                      |
|               | Other than the above   | OFF                     |
| STARTER RELAY | Selector lever in “N” and “P” positions.                                 | ON                      |
|               | Selector lever in other positions.                                       | OFF                     |
| ACCELE POSI   | Released accelerator pedal.  | 0.0/8                   |
|               | Fully depressed accelerator pedal.                                       | 8.0/8                   |
| CLSD THL POS  | Released accelerator pedal.  | ON                      |
|               | Fully depressed accelerator pedal.                                       | OFF                     |
| W/O THL POS   | Fully depressed accelerator pedal.                                       | ON                      |
|               | Released accelerator pedal.  | OFF                     |
| BRAKE SW      | Depressed brake pedal.   | ON                      |
|               | Released brake pedal.  | OFF                     |
| GEAR          | During driving   | 1, 2, 3, 4, 5           |

## SELF-DIAGNOSTIC RESULT MODE

### Display Items List

X: Applicable, —: Not applicable

| Items (CONSULT-III screen terms) | Malfunction is detected when...   | TCM self-diagnosis              | OBD-II (DTC)                              | Reference page        |
|----------------------------------|---|---------------------------------|---|-----------------------|
|                                  |   | “TRANSMISSION” with CONSULT-III | MIL*1, “ENGINE” with CONSULT-III or GST*2 |                       |
| CAN COMM CIRCUIT                 | When TCM is not transmitting or receiving CAN communication signal for 2 seconds or more.   | U1000                           | U1000                                     | <a href="#">AT-90</a> |
| STARTER RELAY                    | If this signal is ON other than in “P” or “N” position, this is judged to be a malfunction.<br>(And if it is OFF in “P” or “N” position, this too is judged to be a malfunction.) | P0615                           | —   | <a href="#">AT-93</a> |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Items (CONSULT-III screen terms) | Malfunction is detected when...   | TCM self-diagnosis              | OBD-II (DTC)                              | Reference page         |         |
|----------------------------------|---|---------------------------------|---|------------------------|---------|
|                                  |   | "TRANSMISSION" with CONSULT-III | MIL*1, "ENGINE" with CONSULT-III or GST*2 |                        |         |
| TRANSMISSION CONT                | TCM is malfunctioning   | P0700                           | P0700                                     | <a href="#">AT-97</a>  | A       |
| T/M RANGE SWITCH A               | <ul style="list-style-type: none"> <li>Transmission range switch 1–4 signals input with impossible pattern.</li> <li>"P" position is detected from "N" position without any other position being detected in between.</li> </ul>  | P0705                           | P0705                                     | <a href="#">AT-98</a>  | B<br>AT |
| INPUT SPEED SENSOR A             | <ul style="list-style-type: none"> <li>TCM does not receive the proper voltage signal from the sensor.</li> <li>TCM detects an irregularity only at position of 4GR for input speed sensor 2.</li> </ul>  | P0717                           | P0717                                     | <a href="#">AT-101</a> | D<br>E  |
| OUTPUT SPEED SENSOR              | <ul style="list-style-type: none"> <li>Signal from vehicle speed sensor A/T (Revolution sensor) not input due to cut line or the like.</li> <li>Unexpected signal input during running.</li> <li>After ignition switch is turned ON, unexpected signal input from vehicle speed signal before the vehicle starts moving.</li> </ul> | P0720                           | P0720                                     | <a href="#">AT-103</a> | F       |
| ENGINE SPEED                     | TCM does not receive the CAN communication signal from the ECM.   | P0725                           | P0725                                     | <a href="#">AT-108</a> | G       |
| 1GR INCORRECT RATIO              | A/T cannot shift to 1GR   | P0731                           | P0731                                     | <a href="#">AT-110</a> | H       |
| 2GR INCORRECT RATIO              | A/T cannot shift to 2GR   | P0732                           | P0732                                     | <a href="#">AT-112</a> | I       |
| 3GR INCORRECT RATIO              | A/T cannot shift to 3GR   | P0733                           | P0733                                     | <a href="#">AT-114</a> | I       |
| 4GR INCORRECT RATIO              | A/T cannot shift to 4GR   | P0734                           | P0734                                     | <a href="#">AT-116</a> | J       |
| 5GR INCORRECT RATIO              | A/T cannot shift to 5GR   | P0735                           | P0735                                     | <a href="#">AT-118</a> | J       |
| TORQUE CONVERTER                 | Normal voltage not applied to solenoid due to cut line, short, or the like.   | P0740                           | P0740                                     | <a href="#">AT-120</a> | K       |
| TORQUE CONVERTER                 | <ul style="list-style-type: none"> <li>A/T cannot perform lock-up even if electrical circuit is good.</li> <li>TCM detects as irregular by comparing difference value with slip rotation.</li> </ul>  | P0744                           | P0744*3                                   | <a href="#">AT-122</a> | L       |
| PC SOLENOID A                    | <ul style="list-style-type: none"> <li>Normal voltage not applied to solenoid due to cut line, short, or the like.</li> <li>TCM detects as irregular by comparing target value with monitor value.</li> </ul>   | P0745                           | P0745                                     | <a href="#">AT-124</a> | M       |
| TP SENSOR                        | TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.   | P1705                           | —   | <a href="#">AT-126</a> | N       |
| TRANS FLUID TEMP SEN             | During running, the A/T fluid temperature sensor signal voltage is excessively high or low.   | P1710                           | P0710                                     | <a href="#">AT-128</a> | N       |
| VEHICLE SPEED SIGNAL             | <ul style="list-style-type: none"> <li>Signal (CAN communication) from vehicle speed signal not input due to cut line or the like.</li> <li>Unexpected signal input during running.</li> </ul>  | P1721                           | —   | <a href="#">AT-133</a> | O       |
| INTERLOCK                        | Except during shift change, the gear position and ATF pressure switch states are monitored and comparative judgment made.   | P1730                           | P1730                                     | <a href="#">AT-135</a> | P       |
| 1ST E/BRAKING                    | Each ATF pressure switch and solenoid current is monitored and if a pattern is detected having engine braking 1GR other than in the M1 position, a malfunction is detected.   | P1731                           | —   | <a href="#">AT-137</a> |         |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Items (CONSULT-III screen terms)                   | Malfunction is detected when...   | TCM self-diagnosis              | OBD-II (DTC)                              | Reference page         |
|--|---|---------------------------------|---|------------------------|
|  |   | "TRANSMISSION" with CONSULT-III | MIL*1, "ENGINE" with CONSULT-III or GST*2 |                        |
| INPUT CLUTCH SOL                                   | <ul style="list-style-type: none"> <li>Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like.</li> <li>TCM detects as irregular by comparing target value with monitor value.</li> </ul>   | P1752                           | P1752                                     | <a href="#">AT-139</a> |
| FR BRAKE SOLENOID                                  | <ul style="list-style-type: none"> <li>Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like.</li> <li>TCM detects as irregular by comparing target value with monitor value.</li> </ul>   | P1757                           | P1757                                     | <a href="#">AT-141</a> |
| DRCT CLUTCH SOL                                    | <ul style="list-style-type: none"> <li>Normal voltage not applied to solenoid due to cut line, short, or the like.</li> <li>TCM detects as irregular by comparing target value with monitor value.</li> </ul>   | P1762                           | P1762                                     | <a href="#">AT-143</a> |
| HLR CLUTCH SOLENOID                                | <ul style="list-style-type: none"> <li>Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like.</li> <li>TCM detects as irregular by comparing target value with monitor value.</li> </ul>   | P1767                           | P1767                                     | <a href="#">AT-145</a> |
| L C BRAKE SOLENOID                                 | Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like.   | P1772                           | P1772                                     | <a href="#">AT-147</a> |
| L C BRAKE SOLENOID                                 | <ul style="list-style-type: none"> <li>TCM detects an improper voltage drop when it tries to operate the solenoid valve.</li> <li>Condition of ATF pressure switch 2 is different from monitor value, and relation between gear position and actual gear ratio is irregular.</li> </ul> | P1774                           | P1774*3                                   | <a href="#">AT-149</a> |
| M-MODE SWITCH                                      | When an impossible pattern of switch signals is detected, a malfunction is detected.  | P1815                           | —   | <a href="#">AT-151</a> |
| NO DTC IS DETECTED FURTHER TESTING MAY BE REQUIRED | No NG item has been detected.   | X                               | X   | —                      |

\*1: Refer to [AT-38, "Malfunction Indicator Lamp \(MIL\)"](#).

\*2: These numbers are prescribed by SAE J2012.

\*3: These malfunctions cannot be displayed MIL if another malfunction is assigned to MIL.

## DATA MONITOR MODE

### Display Items List

X: Standard, —: Not applicable, ▼: Option

| Monitored item (Unit) | Monitor Item Selection |              |                     | Remarks  |
|-----------------------|------------------------|--------------|---------------------|--|
|                       | ECU INPUT SIGNALS      | MAIN SIGNALS | SELECTION FROM MENU |  |
| VHCL/S SE-A/T (km/h)  | X                      | X            | ▼                   | Output speed sensor  |
| VHCL/S SE-MTR (km/h)  | X                      | —            | ▼                   |  |
| ACCELE POSI (0.0/8)   | X                      | —            | ▼                   | Accelerator pedal position signal  |
| THROTTLE POSI (0.0/8) | X                      | X            | ▼                   | Degree of opening for accelerator recognized by the TCM.<br>For fail-safe operation, the specific value used for control is displayed. |
| CLSD THL POS (ON/OFF) | X                      | —            | ▼                   | Signal input with CAN communications.  |
| W/O THL POS (ON/OFF)  | X                      | —            | ▼                   |  |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Monitored item (Unit)  | Monitor Item Selection |              |                     | Remarks  |    |
|------------------------|------------------------|--------------|---------------------|--|----|
|                        | ECU INPUT SIGNALS      | MAIN SIGNALS | SELECTION FROM MENU |  |    |
| BRAKE SW (ON/OFF)      | X                      | —            | ▼                   | Stop lamp switch   | A  |
| GEAR                   | —                      | X            | ▼                   | Gear position recognized by the TCM updated after gear-shifting.   | B  |
| ENGINE SPEED (rpm)     | X                      | X            | ▼                   |  | AT |
| INPUT SPEED (rpm)      | X                      | X            | ▼                   |  |    |
| OUTPUT REV (rpm)       | X                      | X            | ▼                   |  | D  |
| GEAR RATIO             | —                      | X            | ▼                   |  |    |
| TC SLIP SPEED (rpm)    | —                      | X            | ▼                   | Difference between engine speed and torque converter input shaft speed.  | E  |
| F SUN GR REV (rpm)     | —                      | —            | ▼                   |  |    |
| F CARR GR REV (rpm)    | —                      | —            | ▼                   |  | F  |
| ATF TEMP SE 1 (V)      | X                      | —            | ▼                   |  |    |
| ATF TEMP SE 2 (V)      | X                      | —            | ▼                   |  | G  |
| ATF TEMP 1 (°C)        | —                      | X            | ▼                   | Temperature of ATF in the oil pan.   |    |
| ATF TEMP 2 (°C)        | —                      | X            | ▼                   | Temperature of ATF at the exit of torque converter.  | H  |
| BATTERY VOLT (V)       | X                      | —            | ▼                   |  |    |
| ATF PRES SW 1 (ON/OFF) | X                      | X            | ▼                   | (for FR/B solenoid)  | I  |
| ATF PRES SW 2 (ON/OFF) | X                      | X            | ▼                   | (for LC/B solenoid)  |    |
| ATF PRES SW 3 (ON/OFF) | X                      | X            | ▼                   | (for I/C solenoid)   | J  |
| ATF PRES SW 5 (ON/OFF) | X                      | X            | ▼                   | (for D/C solenoid)   |    |
| ATF PRES SW 6 (ON/OFF) | X                      | X            | ▼                   | (for HLR/C solenoid)   | K  |
| RANGE SW 1 (ON/OFF)    | X                      | —            | ▼                   |  |    |
| RANGE SW 2 (ON/OFF)    | X                      | —            | ▼                   |  | L  |
| RANGE SW 3 (ON/OFF)    | X                      | —            | ▼                   |  |    |
| RANGE SW 4 (ON/OFF)    | X                      | —            | ▼                   |  |    |
| 1 POSITION SW (ON/OFF) | X                      | —            | ▼                   |  | M  |
| SLCT LVR POSI          | —                      | X            | ▼                   | Selector lever position is recognized by the TCM. For fail-safe operation, the specific value used for control is displayed. | N  |
| OD CONT SW (ON/OFF)    | X                      | —            | ▼                   | Not mounted but displayed.   |    |
| POWERSHIFT SW (ON/OFF) | X                      | —            | ▼                   |  | O  |
| HOLD SW (ON/OFF)       | X                      | —            | ▼                   |  |    |
| MANU MODE SW (ON/OFF)  | X                      | —            | ▼                   |  | P  |
| NON M-MODE SW (ON/OFF) | X                      | —            | ▼                   |  |    |
| UP SW LEVER (ON/OFF)   | X                      | —            | ▼                   |  |    |
| DOWN SW LEVER (ON/OFF) | X                      | —            | ▼                   |  |    |
| SFT UP ST SW (ON/OFF)  | —                      | —            | ▼                   | Not mounted but displayed.   |    |
| SFT DWN ST SW (ON/OFF) | —                      | —            | ▼                   |  |    |

## TROUBLE DIAGNOSIS

### < SERVICE INFORMATION >

| Monitored item (Unit)   | Monitor Item Selection |              |                     | Remarks                    |
|-------------------------|------------------------|--------------|---------------------|----------------------------|
|                         | ECU INPUT SIGNALS      | MAIN SIGNALS | SELECTION FROM MENU |                            |
| ASCD-OD CUT (ON/OFF)    | —                      | —            | ▼                   |                            |
| ASCD-CRUISE (ON/OFF)    | —                      | —            | ▼                   |                            |
| ABS SIGNAL (ON/OFF)     | —                      | —            | ▼                   |                            |
| ACC OD CUT (ON/OFF)     | —                      | —            | ▼                   | Not mounted but displayed  |
| ACC SIGNAL (ON/OFF)     | —                      | —            | ▼                   |                            |
| TCS GR/P KEEP (ON/OFF)  | —                      | —            | ▼                   |                            |
| TCS SIGNAL 2 (ON/OFF)   | —                      | —            | ▼                   |                            |
| TCS SIGNAL 1 (ON/OFF)   | —                      | —            | ▼                   |                            |
| TCC SOLENOID (A)        | —                      | X            | ▼                   |                            |
| LINE PRES SOL (A)       | —                      | X            | ▼                   |                            |
| I/C SOLENOID (A)        | —                      | X            | ▼                   |                            |
| FR/B SOLENOID (A)       | —                      | X            | ▼                   |                            |
| D/C SOLENOID (A)        | —                      | X            | ▼                   |                            |
| HLR/C SOL (A)           | —                      | X            | ▼                   |                            |
| ON OFF SOL (ON/OFF)     | —                      | —            | ▼                   | LC/B solenoid              |
| TCC SOL MON (A)         | —                      | —            | ▼                   |                            |
| L/P SOL MON (A)         | —                      | —            | ▼                   |                            |
| I/C SL MON (A)          | —                      | —            | ▼                   |                            |
| FR/B SOL MON (A)        | —                      | —            | ▼                   |                            |
| D/C SOL MON (A)         | —                      | —            | ▼                   |                            |
| HLR/C SOL MON (A)       | —                      | —            | ▼                   |                            |
| ON OFF SOL MON (ON/OFF) | —                      | —            | ▼                   | LC/B solenoid              |
| P POSI IND (ON/OFF)     | —                      | —            | ▼                   |                            |
| R POSI IND (ON/OFF)     | —                      | —            | ▼                   |                            |
| N POSI IND (ON/OFF)     | —                      | —            | ▼                   |                            |
| D POSI IND (ON/OFF)     | —                      | —            | ▼                   |                            |
| 4TH POSI IND (ON/OFF)   | —                      | —            | ▼                   |                            |
| 3RD POSI IND (ON/OFF)   | —                      | —            | ▼                   |                            |
| 2ND POSI IND (ON/OFF)   | —                      | —            | ▼                   |                            |
| 1ST POSI IND (ON/OFF)   | —                      | —            | ▼                   |                            |
| MANU MODE IND (ON/OFF)  | —                      | —            | ▼                   |                            |
| POWER M LAMP (ON/OFF)   | —                      | —            | ▼                   |                            |
| F-SAFE IND/L (ON/OFF)   | —                      | —            | ▼                   |                            |
| ATF WARN LAMP (ON/OFF)  | —                      | —            | ▼                   | Not mounted but displayed. |
| BACK-UP LAMP (ON/OFF)   | —                      | —            | ▼                   |                            |

# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| Monitored item (Unit)  | Monitor Item Selection |              |                     | Remarks                              |    |
|------------------------|------------------------|--------------|---------------------|--------------------------------------|----|
|                        | ECU INPUT SIGNALS      | MAIN SIGNALS | SELECTION FROM MENU |                                      |    |
| STARTER RELAY (ON/OFF) | —                      | —            | ▼                   |                                      | A  |
| RANGE SW 3M (ON/OFF)   | —                      | —            | ▼                   |                                      | B  |
| C/V CLB ID1            | —                      | —            | ▼                   |                                      | AT |
| C/V CLB ID2            | —                      | —            | ▼                   |                                      |    |
| C/V CLB ID3            | —                      | —            | ▼                   |                                      | D  |
| UNIT CLB ID1           | —                      | —            | ▼                   |                                      |    |
| UNIT CLB ID2           | —                      | —            | ▼                   |                                      | E  |
| UNIT CLB ID3           | —                      | —            | ▼                   |                                      |    |
| TRGT GR RATIO          | —                      | —            | ▼                   |                                      | F  |
| TRGT PRES TCC (kPa)    | —                      | —            | ▼                   |                                      |    |
| TRGT PRES L/P (kPa)    | —                      | —            | ▼                   |                                      | G  |
| TRGT PRES I/C (kPa)    | —                      | —            | ▼                   |                                      |    |
| TRGT PRE FR/B (kPa)    | —                      | —            | ▼                   |                                      | H  |
| TRGT PRES D/C (kPa)    | —                      | —            | ▼                   |                                      |    |
| TRG PRE HLR/C (kPa)    | —                      | —            | ▼                   |                                      | I  |
| SHIFT PATTERN          | —                      | —            | ▼                   |                                      |    |
| DRV CST JUDGE          | —                      | —            | ▼                   |                                      | J  |
| START RLY MON          | —                      | —            | ▼                   |                                      |    |
| NEXT GR POSI           | —                      | —            | ▼                   |                                      | K  |
| SHIFT MODE             | —                      | —            | ▼                   |                                      |    |
| MANU GR POSI           | —                      | —            | ▼                   |                                      | L  |
| VEHICLE SPEED (km/h)   | —                      | X            | ▼                   | Vehicle speed recognized by the TCM. |    |

## DTC WORK SUPPORT MODE

### Display Items List

| DTC work support item | Description  | Check item  |   |
|-----------------------|--|---|---|
| 1ST GR FNCTN P0731    | Following items for "1GR function ratio" can be confirmed. <ul style="list-style-type: none"> <li>• Self-diagnosis status (whether the diagnosis is being performed or not)</li> <li>• Self-diagnostic results (OK or NG)</li> </ul> | <ul style="list-style-type: none"> <li>• Input clutch solenoid valve</li> <li>• Front brake solenoid valve</li> <li>• Direct clutch solenoid valve</li> <li>• High and low reverse clutch solenoid valve</li> <li>• Each clutch</li> <li>• Hydraulic control circuit</li> </ul> | N |
| 2ND GR FNCTN P0732    | Following items for "2GR function ratio" can be confirmed. <ul style="list-style-type: none"> <li>• Self-diagnosis status (whether the diagnosis is being performed or not)</li> <li>• Self-diagnostic results (OK or NG)</li> </ul> |   | O |
| 3RD GR FNCTN P0733    | Following items for "3GR function ratio" can be confirmed. <ul style="list-style-type: none"> <li>• Self-diagnosis status (whether the diagnosis is being performed or not)</li> <li>• Self-diagnostic results (OK or NG)</li> </ul> |   | P |
| 4TH GR FNCTN P0734    | Following items for "4GR function ratio" can be confirmed. <ul style="list-style-type: none"> <li>• Self-diagnosis status (whether the diagnosis is being performed or not)</li> <li>• Self-diagnostic results (OK or NG)</li> </ul> |   |   |
| 5TH GR FNCTN P0735    | Following items for "5GR function ratio" can be confirmed. <ul style="list-style-type: none"> <li>• Self-diagnosis status (whether the diagnosis is being performed or not)</li> <li>• Self-diagnostic results (OK or NG)</li> </ul> |   |   |

# TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

## Diagnosis Procedure without CONSULT-III

INFOID:000000004656813

### OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

Refer to [EC-120, "Generic Scan Tool \(GST\) Function"](#).

### OBD-II SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Refer to [EC-62, "Malfunction Indicator Lamp \(MIL\)"](#).

### TCM SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

#### Description

When the ignition switch is turned ON, the indicator lamp lights up 2 seconds. As a method for locating the suspect circuit, when the self-diagnostics start signal is input, the memory for the malfunction location is output and A/T CHECK indicator lamp flashes to display the corresponding DTC.

#### Diagnostic Procedure

### 1. CHECK A/T CHECK INDICATOR LAMP

1. Start the engine with selector lever in "P" position. Warm engine to normal operating temperature.
2. Turn ignition switch ON and OFF at least twice, then leave it in the OFF position.
3. Wait 10 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Does A/T CHECK indicator lamp come on for about 2 seconds?

YES >> GO TO 2.

NO >> Go to [AT-166, "A/T Check Indicator Lamp Does Not Come On"](#).

### 2. JUDGMENT PROCEDURE

1. Turn ignition switch OFF.
2. Keep pressing shift lock release button.
3. Move selector lever from "P" to "D" position.
4. Release accelerator pedal. (Set the closed throttle position signal ON.)
5. Depress brake pedal. (Stop lamp switch signal ON.)
6. Turn ignition switch ON. (Do not start engine.)
7. Wait 3 seconds.
8. Move the selector lever to the manual shift gate side. (Manual mode switch ON.)
9. Release brake pedal. (Stop lamp switch signal OFF.)
10. Move the selector lever to "D" position. (Manual mode switch OFF.)
11. Depress brake pedal. (Stop lamp switch signal ON.)
12. Release brake pedal. (Stop lamp switch signal OFF.)
13. Depress accelerator pedal fully and release it.

>> GO TO 3.

### 3. CHECK SELF-DIAGNOSIS CODE

Check A/T CHECK indicator lamp. Refer to "Judgment Self-diagnosis Code".

If the system does not go into self-diagnostics. Refer to [AT-98](#), [AT-151](#), [AT-160](#), [AT-161](#).

>> **DIAGNOSIS END**

#### Judgment Self-diagnosis Code

If there is a malfunction, the lamp lights up for the time corresponding to the suspect circuit.


| No. | Malfunctioning item                           | No. | Malfunctioning item                                      |
|-----|---|-----|--|
| 1   | Output speed sensor <a href="#">AT-103</a>    | 12  | Interlock <a href="#">AT-135</a>                         |
| 2   | Direct clutch solenoid <a href="#">AT-143</a> | 13  | 1st engine braking <a href="#">AT-137</a>                |
| 3   | Torque converter <a href="#">AT-120</a>       | 14  | Starter relay <a href="#">AT-93</a>                      |
| 4   | Line pressure solenoid <a href="#">AT-124</a> | 15  | Accelerator pedal position sensor <a href="#">AT-126</a> |
| 5   | Input clutch solenoid <a href="#">AT-139</a>  | 16  | Engine speed <a href="#">AT-108</a>                      |



# TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

| No. | Malfunctioning item  | No. | Malfunctioning item                          |
|-----|--|-----|--|
| 6   | Front brake solenoid <a href="#">AT-141</a>                              | 17  | CAN communication line <a href="#">AT-90</a> |
| 7   | Low coast brake solenoid <a href="#">AT-147</a> , <a href="#">AT-149</a> | 18  | 1GR incorrect ratio <a href="#">AT-110</a>   |
| 8   | High and low reverse clutch solenoid <a href="#">AT-145</a>              | 19  | 2GR incorrect ratio <a href="#">AT-112</a>   |
| 9   | Transmission range switch <a href="#">AT-98</a>                          | 20  | 3GR incorrect ratio <a href="#">AT-114</a>   |
| 10  | A/T fluid temperature sensor <a href="#">AT-128</a>                      | 21  | 4GR incorrect ratio <a href="#">AT-116</a>   |
| 11  | Input speed sensor <a href="#">AT-101</a>                                | 22  | 5GR incorrect ratio <a href="#">AT-118</a>   |



### Erase Self-diagnosis

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned ON and OFF.
- However, this information is erased by turning ignition switch OFF after performing self-diagnostics or by erasing the memory using the CONSULT-III.

# U1000 CAN COMM CIRCUIT

< SERVICE INFORMATION >

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000004656814

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### On Board Diagnosis Logic

INFOID:000000004656815

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "U1000" with CONSULT-III or 17th judgment flicker without CONSULT-III is detected when TCM cannot communicate to other control units.

### Possible Cause

INFOID:000000004656816

Harness or connectors  
(CAN communication line is open or shorted.)

### DTC Confirmation Procedure

INFOID:000000004656817

#### NOTE:

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine and wait for at least 6 seconds.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
3. If DTC is detected, go to [AT-92. "Diagnosis Procedure"](#).

#### Ⓢ WITH GST

Follow the procedure "WITH CONSULT-III".




# U1000 CAN COMM CIRCUIT



< SERVICE INFORMATION >

## Wiring Diagram - AT - CAN

INFOID:000000004656818

### AT-CAN-01

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWM0259E

# U1000 CAN COMM CIRCUIT

## < SERVICE INFORMATION >

TCM terminals and data are reference value. Measured between each terminal and ground.

| Terminal | Wire color | Item  | Condition | Data (Approx.) |
|----------|------------|-------|-----------|----------------|
| 3        | L          | CAN-H | —         | —              |
| 8        | P          | CAN-L | —         | —              |

## Diagnosis Procedure

INFOID:000000004656819

### 1. CHECK CAN COMMUNICATION CIRCUIT

#### With CONSULT-III

1. Start the engine.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Is the "U1000" indicated?

- YES >> Go to LAN section. Refer to [LAN-41, "CAN System Specification Chart"](#).  
NO >> **INSPECTION END**

# P0615 STARTER RELAY

< SERVICE INFORMATION >

## P0615 STARTER RELAY

### Description

INFOID:000000004656820

Prohibits cranking other at "P" or "N" position.

### CONSULT-III Reference Value

INFOID:000000004656821

| Item name     | Condition                                | Display value |
|---------------|--|---------------|
| STARTER RELAY | Selector lever in "N" and "P" positions. | ON            |
|               | Selector lever in other positions.       | OFF           |

### On Board Diagnosis Logic

INFOID:000000004656822

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0615" with CONSULT-III or 14th judgment flicker without CONSULT-III is detected when starter relay is switched ON other than at "P" or "N" position. (Or when switched OFF at "P" or "N" position.)

### Possible Cause

INFOID:000000004656823

- Harness or connectors  
(Starter relay and TCM circuit is open or shorted.)
- Starter relay circuit

### DTC Confirmation Procedure

INFOID:000000004656824

#### NOTE:

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### ④ WITH CONSULT-III

1. Shift selector lever to "P" or "N" position.
2. Turn ignition switch ON and wait for at least 2 consecutive seconds.
3. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
4. If DTC is detected, go to [AT-95. "Diagnosis Procedure"](#).

# P0615 STARTER RELAY



< SERVICE INFORMATION >

## Wiring Diagram - AT - STSIG

INFOID:000000004656825

### AT-STSIG-01


- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ◊NT** : WITH VDC SYSTEM, NAVIGATION SYSTEM OR TELEPHONE
- ◊OT** : WITHOUT VDC SYSTEM, NAVIGATION SYSTEM AND TELEPHONE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWM0678E

TCM terminals and data are reference value. Measured between each terminal and ground.

| Terminal | Wire color | Item          | Condition  | Data (Approx.)  |
|----------|------------|---------------|--|-----------------|
| 9        | GY/R       | Starter relay |  Selector lever in "N" and "P" positions. | Battery voltage |
|          |            |               | Selector lever in other positions.   | 0 V             |

# P0615 STARTER RELAY

< SERVICE INFORMATION >

## Diagnosis Procedure

INFOID:000000004656826

### 1. CHECK STARTER RELAY

#### With CONSULT-III

- Turn ignition switch ON.
- Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III and check monitor item "STARTER RELAY" ON/OFF.

| Item name     | Condition                                | Display value |
|---------------|--|---------------|
| STARTER RELAY | Selector lever in "N" and "P" positions. | ON            |
|               | Selector lever in other positions.       | OFF           |


#### Without CONSULT-III

- Turn ignition switch ON.
- Check voltage between the IPDM E/R connector and ground.

| Item          | Connector | Terminal    | Shift position  | Voltage (Approx.) |
|---------------|-----------|-------------|-----------------|-------------------|
| Starter relay | E9        | 53 – Ground | "N", "P"        | Battery voltage   |
|               |           |             | Other positions | 0 V               |

#### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 2.



### 2. CHECK HARNESS BETWEEN A/T ASSEMBLY HARNESS CONNECTOR AND IPDM E/R CONNECTOR


- Turn ignition switch OFF.
- Disconnect A/T assembly harness connector and IPDM E/R connector.
- Check continuity between A/T assembly harness connector and IPDM E/R connector.

| Item                           | Connector | Terminal | Continuity |
|--------------------------------|-----------|----------|------------|
| A/T assembly harness connector | F6        | 9        | Yes        |
| IPDM E/R connector             | E9        | 53       |            |

- If OK, check harness for short to ground and short to power.
- Reinstall any part removed.

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.




### 3. CHECK TERMINAL CORD ASSEMBLY

- Remove control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- Disconnect A/T assembly harness connector and TCM connector.
- Check continuity between A/T assembly harness connector terminal and TCM connector terminal.

| Item                           | Connector | Terminal | Continuity |
|--------------------------------|-----------|----------|------------|
| A/T assembly harness connector | F6        | 9        | Yes        |
| TCM connector                  | F502      | 8        |            |

- If OK, check harness for short to ground and short to power.
- Reinstall any part removed.

#### OK or NG



## P0615 STARTER RELAY

### < SERVICE INFORMATION >

---

OK >> GO TO 4.

NG >> Replace open circuit or short to ground and short to power in harness or connectors.

### 4. DETECT MALFUNCTIONING ITEM

---

Check the following.

- Starter relay, Refer to [SC-8](#).
- IPDM E/R, Refer to [PG-16](#).

#### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

### 5. CHECK DTC

---

Perform [AT-93, "DTC Confirmation Procedure"](#).

#### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.



# P0700 TRANSMISSION CONTROL

< SERVICE INFORMATION >

## P0700 TRANSMISSION CONTROL

### Description

INFOID:000000004656827

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The TCM controls A/T.

### On Board Diagnosis Logic

INFOID:000000004656828

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0700" with CONSULT-III is detected when TCM is malfunctioning.

### Possible Cause

INFOID:000000004656829

TCM.

### DTC Confirmation Procedure

INFOID:000000004656830

#### NOTE:

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and wait for at least 2 consecutive seconds at idle speed.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
3. If DTC is detected, go to [AT-97, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure "WITH CONSULT-III".

### Diagnosis Procedure

INFOID:000000004656831

#### 1. CHECK DTC

##### With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
3. Touch "ERASE".
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Perform [AT-97, "DTC Confirmation Procedure"](#).

Is the "P7000" displayed again?

YES >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NO >> **INSPECTION END**

# P0705 TRANSMISSION RANGE SWITCH A

< SERVICE INFORMATION >

## P0705 TRANSMISSION RANGE SWITCH A

### Description

INFOID:000000004656832

The transmission range switch detects the selector lever position and sends a signal to the TCM.

### CONSULT-III Reference Value

INFOID:000000004656833

| Item name     | Condition                                | Display value |
|---------------|--|---------------|
| SLCT LVR POSI | Selector lever in "N" and "P" positions. | N/P           |
|               | Selector lever in "R" position.          | R             |
|               | Selector lever in "D" position.          | D             |

### On Board Diagnosis Logic

INFOID:000000004656834

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0705" with CONSULT-III or 9th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM does not receive the correct voltage signal from transmission range switch 1, 2, 3 and 4 based on the gear position.
  - When no other position but "P" position is detected from "N" position.

### Possible Cause

INFOID:000000004656835

- Harness or connectors  
Transmission range switch 1, 2, 3, 4 and TCM circuit is open or shorted.
- Transmission range switch 1, 2, 3 and 4

### DTC Confirmation Procedure

INFOID:000000004656836

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

ACCELE POSI : More than 1.0/8

4. If DTC is detected, go to [AT-99. "Diagnosis Procedure"](#).

#### Ⓟ WITH GST

Follow the procedure "WITH CONSULT-III".

# P0705 TRANSMISSION RANGE SWITCH A



< SERVICE INFORMATION >

## Wiring Diagram - AT - TR/SW

INFOID:000000004656837

### AT-PNP/SW-01

— : DETECTABLE LINE FOR DTC  
 - - - : NON-DETECTABLE LINE FOR DTC



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

## Diagnosis Procedure

### 1. CHECK TRANSMISSION RANGE SWITCH CIRCUIT

Ⓜ With CONSULT-III

1. Turn ignition switch ON.

TCWM0679E

INFOID:000000004656838

# P0705 TRANSMISSION RANGE SWITCH A

## < SERVICE INFORMATION >

2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Check if correct selector lever position (N/P, R or D) is displayed as selector lever is moved into each position.

| Item name     | Condition                                | Display value |
|---------------|--|---------------|
| SLCT LVR POSI | Selector lever in "N" and "P" positions. | N/P           |
|               | Selector lever in "R" position.          | R             |
|               | Selector lever in "D" position.          | D             |

### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 2.

## 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace damaged parts.

## 3.DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.


### OK or NG

- OK >> GO TO 4.  
 NG >> Repair or replace damaged parts.

## 4.CHECK SUB-HARNESS

1. Remove control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disconnect transmission range switch connector and TCM connector.
3. Check continuity between transmission range switch connector (A) terminals and TCM connector (B) terminals.

| Item                                | Connector | Terminal | Continuity |
|-------------------------------------|-----------|----------|------------|
| Transmission range switch connector | F505      | 1        | Yes        |
| TCM connector                       | F503      | 13       |            |
| Transmission range switch connector | F505      | 2        | Yes        |
| TCM connector                       | F503      | 11       |            |
| Transmission range switch connector | F505      | 3        | Yes        |
| TCM connector                       | F503      | 12       |            |
| Transmission range switch connector | F505      | 5        | Yes        |
| TCM connector                       | F503      | 14       |            |



4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
 NG >> Replace open circuit or short to ground and short to power in harness or connectors.

## 5.CHECK DTC

Perform [AT-98. "DTC Confirmation Procedure"](#).

### OK or NG

- OK >> **INSPECTION END**  
 NG >> GO TO 2.

# P0717 INPUT SPEED SENSOR A

< SERVICE INFORMATION >

## P0717 INPUT SPEED SENSOR A

### Description

INFOID:000000004656839

The input speed sensor detects input shaft rpm (revolutions per minute). It is located on the input side of the A/T. Monitors revolution of sensor 1 and sensor 2 for non-standard conditions.

### CONSULT-III Reference Value

INFOID:000000004656840

| Item name   | Condition                   | Display value                           |
|-------------|-----------------------------|---|
| INPUT SPEED | During driving (lock-up ON) | Approximately matches the engine speed. |

### On Board Diagnosis Logic

INFOID:000000004656841

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0717" with CONSULT-III or 11th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM does not receive the proper voltage signal from the sensor.
  - When TCM detects an irregularity only at position of 4GR for input speed sensor 2.

### Possible Cause

INFOID:000000004656842

- Harness or connectors (Sensor circuit is open or shorted.)
- Input speed sensor 1 and/or 2

### DTC Confirmation Procedure

INFOID:000000004656843

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

VHCL/S SE-A/T : 40 km/h (25 MPH) or more

ACCELE POSI : More than 0.5/8

ENGINE SPEED : 1,500 rpm or more

SLCT LVR POSI : "D" position

GEAR (Input speed sensor 1) : "4" or "5" position

GEAR (Input speed sensor 2) : All positions

Driving location : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

4. If DTC is detected, go to [AT-101. "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure "WITH CONSULT-III".

### Diagnosis Procedure

INFOID:000000004656844

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.

## P0717 INPUT SPEED SENSOR A

### < SERVICE INFORMATION >

---

3. Vehicle start and read out the value of "INPUT SPEED".

| Item name   | Condition                      | Display value                           |
|-------------|--------------------------------|---|
| INPUT SPEED | During driving<br>(lock-up ON) | Approximately matches the engine speed. |

#### OK or NG

OK >> GO TO 4.  
NG >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
NG >> Repair or replace damaged parts.

### 4.CHECK DTC

---

Perform [AT-101, "DTC Confirmation Procedure"](#).

#### OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 2.

# P0720 OUTPUT SPEED SENSOR

< SERVICE INFORMATION >

## P0720 OUTPUT SPEED SENSOR

### Description

INFOID:000000004656845

The output speed sensor detects the revolution of the parking gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

### CONSULT-III Reference Value

INFOID:000000004656846

| Item name     | Condition      | Display value                                  |
|---------------|----------------|--|
| VHCL/S SE-A/T | During driving | Approximately matches the speedometer reading. |

### On Board Diagnosis Logic

INFOID:000000004656847

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0720" with CONSULT-III or 1st judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM does not receive the proper voltage signal from the sensor.
  - After ignition switch is turned ON, irregular signal input from vehicle speed signal before the vehicle starts moving.

### Possible Cause

INFOID:000000004656848

- Harness or connectors  
(Sensor circuit is open or shorted.)
- Output speed sensor
- Vehicle speed signal

### DTC Confirmation Procedure

INFOID:000000004656849

#### CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

#### NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and check for an increase of "VHCL/S SE-A/T" value in response to "VHCL/S SE-MTR" value.  
If the check result is NG, go to [AT-105, "Diagnosis Procedure"](#).  
If the check result is OK, go to following step.
4. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                  |  |
|------------------|--|
| VHCL/S SE-A/T    | : 30 km/h (19 MPH) or more   |
| ACCELE POSI      | : More than 1.0/8  |
| SLCT LVR POSI    | : "D" position   |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

If DTC is detected, go to [AT-105, "Diagnosis Procedure"](#).

If the check result is OK, go to following step.

6. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|              |                     |
|--------------|---------------------|
| ENGINE SPEED | : 3,500 rpm or more |
| ACCELE POSI  | : More than 1.0/8   |

## P0720 OUTPUT SPEED SENSOR

### < SERVICE INFORMATION >

---

SLCT LVR POSI : "D" position

Driving location : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

7. If DTC is detected, go to [AT-105, "Diagnosis Procedure"](#).

 WITH GST

Follow the procedure "WITH CONSULT-III".



# P0720 OUTPUT SPEED SENSOR



< SERVICE INFORMATION >

## Wiring Diagram - AT - VSSA/T

INFOID:000000004656850

### AT-VSSA/T-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

## Diagnosis Procedure

### 1. CHECK INPUT SIGNAL

With CONSULT-III

1. Start the engine.

TCWM0680E

INFOID:000000004656851

## P0720 OUTPUT SPEED SENSOR

### < SERVICE INFORMATION >

2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed.

| Item name     | Condition      | Display value                                  |
|---------------|----------------|--|
| VHCL/S SE-A/T | During driving | Approximately matches the speedometer reading. |

#### OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.


#### OK or NG

- OK >> GO TO 4.  
 NG >> Repair or replace damaged parts.

### 4.CHECK SUB-HARNESS

1. Remove control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disconnect transmission range switch connector and TCM connector.
3. Check continuity between transmission range switch connector (A) terminals and TCM connector (B) terminals.

| Item                                | Connector | Terminal | Continuity |
|-------------------------------------|-----------|----------|------------|
| Transmission range switch connector | F505      | 8        | Yes        |
| TCM connector                       | F503      | 20       |            |
| Transmission range switch connector | F505      | 9        | Yes        |
| TCM connector                       | F503      | 17       |            |
| Transmission range switch connector | F505      | 10       | Yes        |
| TCM connector                       | F503      | 16       |            |



4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

#### OK or NG

- OK >> GO TO 5.  
 NG >> Replace open circuit or short to ground and short to power in harness or connectors.

### 5.REPLACE THE OUTPUT SPEED SENSOR AND CHECK DTC

1. Replace output speed sensor. Refer to [AT-222, "Output Speed Sensor"](#).
2. Perform [AT-103, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
 NG >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

### 6.CHECK DTC

Perform [AT-103, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**

# P0720 OUTPUT SPEED SENSOR

< SERVICE INFORMATION >

---

NG >> GO TO 2.

A

B

**AT**

D

E

F

G

H

I

J

K

L

M

N

O

P

# P0725 ENGINE SPEED

< SERVICE INFORMATION >

## P0725 ENGINE SPEED

### Description

INFOID:000000004656852

The engine speed signal is sent from the ECM to the TCM.

### CONSULT-III Reference Value

INFOID:000000004656853

| Item name    | Condition      | Display value                           |
|--------------|----------------|---|
| ENGINE SPEED | Engine running | Closely matches the tachometer reading. |

### On Board Diagnosis Logic

INFOID:000000004656854

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0725" with CONSULT-III or 16th judgment flicker without CONSULT-III is detected when TCM does not receive the ignition signal from ECM during engine cranking or running.

### Possible Cause

INFOID:000000004656855

Harness or connectors  
(ECM to TCM circuit is open or shorted.)

### DTC Confirmation Procedure

INFOID:000000004656856

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 10 consecutive seconds.

VHCL/S SE-A/T : 10 km/h (6 MPH) or more  
ACCELE POSI : More than 1.0/8  
SLCT LVR POSI : "D" position

4. If DTC is detected, go to [AT-108. "Diagnosis Procedure"](#).

#### Ⓟ WITH GST

Follow the procedure "WITH CONSULT-III".

### Diagnosis Procedure

INFOID:000000004656857

#### 1. CHECK CAN COMMUNICATION LINE

##### Ⓟ With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

##### ⊗ Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).  
NO >> GO TO 2.

#### 2. CHECK DTC WITH TCM

##### Ⓟ With CONSULT-III

1. Start the engine.

## P0725 ENGINE SPEED

### < SERVICE INFORMATION >

2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. While monitoring engine speed, check for engine speed change corresponding to wide-open throttle position signal.

| Item name    | Condition      | Display value                           |
|--------------|----------------|---|
| ENGINE SPEED | Engine running | Closely matches the tachometer reading. |

#### OK or NG

- OK >> GO TO 3.  
NG >> Check the ignition signal circuit. Refer to [EC-645](#).

### 3.CHECK DTC

Perform [AT-108, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 4.

### 4.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 5.  
NG >> Repair or replace damaged parts.

### 5.DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
NG >> Repair or replace damaged parts.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# P0731 1GR INCORRECT RATIO

< SERVICE INFORMATION >

## P0731 1GR INCORRECT RATIO

### Description

INFOID:000000004656858

This malfunction is detected when the A/T does not shift into 1GR position as instructed by TCM. This is not only caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### On Board Diagnosis Logic

INFOID:000000004656859

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0731" with CONSULT-III or 18th judgment flicker without CONSULT-III is detected when TCM detects any inconsistency in the actual gear ratio.

### Possible Cause

INFOID:000000004656860

- Input clutch solenoid valve
- Front brake solenoid valve
- Direct clutch solenoid valve
- High and low reverse clutch solenoid valve
- Each clutch
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656861

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
2. Make sure that "ATF TEMP 1" is within the following range.

ATF TEMP 1 : 20°C – 140°C

If out of range, drive vehicle to warm ATF or stop engine to cool ATF.

3. Select "1ST GR FNCTN P0731" of "DTC WORK SUPPORT" mode for "TRANSMISSION" with CONSULT-III.
4. Drive vehicle and maintain the following conditions.

|               |                                |
|---------------|--------------------------------|
| MANU MODE SW  | : ON                           |
| GEAR          | : "1" position                 |
| ACCELE POSI   | : 0.6/8 or more                |
| VEHICLE SPEED | : 10 km/h (6 MPH) or more      |
| ENGINE SPEED  | : INPUT SPEED – 50 rpm or more |
| INPUT SPEED   | : 300 rpm or more              |

5. Keep the current driving status for at least 5 consecutive seconds if CONSULT-III screen changes from "OUT OF CONDITION" to "TESTING".

#### **CAUTION:**

**If "TESTING" does not appear on CONSULT-III for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than "P0731" is shown, refer to ["AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).**

If "COMPLETED RESULT NG" is detected, go to [AT-111, "Diagnosis Procedure"](#).

If "STOP VEHICLE" is detected, go to the following step.

6. Stop vehicle.
7. Drive vehicle in "D" position allowing it to shift from 1GR to 5GR and check shift timing and shift shock.
  - Touch "OK" to complete the inspection when normally shifted from the 1GR to 5GR.

# P0731 1GR INCORRECT RATIO

## < SERVICE INFORMATION >

- Touch "NG" when an unusual shift shock, etc. occurs in spite of shifting from the 1GR to 5GR. Go to [AT-47, "Inspections Before Trouble Diagnosis"](#).
- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III when not shifted from the 1GR to 5GR. (Neither "OK" nor "NG" are indicated.)

### WITH GST

1. Start the engine.
2. Drive vehicle for approximately 5 minutes in urban areas.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                     |                           |
|---------------------|---------------------------|
| Manual mode switch  | : ON                      |
| Gear position       | : "1" position            |
| Accelerator opening | : 0.6/8 or more           |
| Vehicle speed       | : 10 km/h (6 MPH) or more |

4. Check DTC. If DTC is detected, go to [AT-111, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000004656862

### 1.CHECK CAN COMMUNICATION LINE

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-90](#).  
NO >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTION ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> GO TO 4.  
NG >> Repair or replace damaged parts.

### 4.REPLACE CONTROL VALVE WITH TCM

1. Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Perform [AT-110, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> Confirm malfunction phenomena by "ROAD TEST" to repair malfunctioning part. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# P0732 2GR INCORRECT RATIO

< SERVICE INFORMATION >

## P0732 2GR INCORRECT RATIO

### Description

INFOID:000000004656863

This malfunction is detected when the A/T does not shift into 2GR position as instructed by TCM. This is not only caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### On Board Diagnosis Logic

INFOID:000000004656864

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0732" with CONSULT-III or 19th judgment flicker without CONSULT-III is detected when TCM detects any inconsistency in the actual gear ratio.

### Possible Cause

INFOID:000000004656865

- Input clutch solenoid valve
- Front brake solenoid valve
- Direct clutch solenoid valve
- High and low reverse clutch solenoid valve
- Each clutch
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656866

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
2. Make sure that "ATF TEMP 1" is within the following range.

ATF TEMP 1 : 20°C – 140°C

If out of range, drive vehicle to warm ATF or stop engine to cool ATF.

3. Select "2ND GR FNCTN P0732" of "DTC WORK SUPPORT" mode for "TRANSMISSION" with CONSULT-III.
4. Drive vehicle and maintain the following conditions.

|               |                                |
|---------------|--------------------------------|
| MANU MODE SW  | : ON                           |
| GEAR          | : "2" position                 |
| ACCELE POSI   | : 0.6/8 or more                |
| VEHICLE SPEED | : 10 km/h (6 MPH) or more      |
| ENGINE SPEED  | : INPUT SPEED – 50 rpm or more |
| INPUT SPEED   | : 300 rpm or more              |

5. Keep the current driving status for at least 5 consecutive seconds if CONSULT-III screen changes from "OUT OF CONDITION" to "TESTING".

#### **CAUTION:**

**If "TESTING" does not appear on CONSULT-III for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than "P0732" is shown, refer to ["AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).**

If "COMPLETED RESULT NG" is detected, go to [AT-113, "Diagnosis Procedure"](#).

If "STOP VEHICLE" is detected, go to the following step.

6. Stop vehicle.
7. Drive vehicle in "D" position allowing it to shift from 1GR to 5GR and check shift timing and shift shock.
  - Touch "OK" to complete the inspection when normally shifted from the 1GR to 5GR.



# P0732 2GR INCORRECT RATIO

## < SERVICE INFORMATION >

- Touch "NG" when an unusual shift shock, etc. occurs in spite of shifting from the 1GR to 5GR. Go to [AT-47, "Inspections Before Trouble Diagnosis"](#).
- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III when not shifted from the 1GR to 5GR. (Neither "OK" nor "NG" are indicated.)

### WITH GST

1. Start the engine.
2. Drive vehicle for approximately 5 minutes in urban areas.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                     |                           |
|---------------------|---------------------------|
| Manual mode switch  | : ON                      |
| Gear position       | : "2" position            |
| Accelerator opening | : 0.6/8 or more           |
| Vehicle speed       | : 10 km/h (6 MPH) or more |

4. Check DTC. If DTC is detected, go to [AT-113, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000004656867

### 1.CHECK CAN COMMUNICATION LINE

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-90](#).  
NO >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTION ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> GO TO 4.  
NG >> Repair or replace damaged parts.

### 4.REPLACE CONTROL VALVE WITH TCM

1. Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Perform [AT-112, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> Confirm malfunction phenomena by "ROAD TEST" to repair malfunctioning part. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# P0733 3GR INCORRECT RATIO

< SERVICE INFORMATION >

## P0733 3GR INCORRECT RATIO

### Description

INFOID:000000004656868

This malfunction is detected when the A/T does not shift into 3GR position as instructed by TCM. This is not only caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### On Board Diagnosis Logic

INFOID:000000004656869

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0733" with CONSULT-III or 20th judgment flicker without CONSULT-III is detected when TCM detects any inconsistency in the actual gear ratio.

### Possible Cause

INFOID:000000004656870

- Input clutch solenoid valve
- Front brake solenoid valve
- Direct clutch solenoid valve
- High and low reverse clutch solenoid valve
- Each clutch
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656871

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
2. Make sure that "ATF TEMP 1" is within the following range.

ATF TEMP 1 : 20°C – 140°C

If out of range, drive vehicle to warm ATF or stop engine to cool ATF.

3. Select "3RD GR FNCTN P0733" of "DTC WORK SUPPORT" mode for "TRANSMISSION" with CONSULT-III.
4. Drive vehicle and maintain the following conditions.

|               |                                |
|---------------|--------------------------------|
| MANU MODE SW  | : ON                           |
| GEAR          | : "3" position                 |
| ACCELE POSI   | : 0.6/8 or more                |
| VEHICLE SPEED | : 10 km/h (6 MPH) or more      |
| ENGINE SPEED  | : INPUT SPEED – 50 rpm or more |
| INPUT SPEED   | : 300 rpm or more              |

5. Keep the current driving status for at least 5 consecutive seconds if CONSULT-III screen changes from "OUT OF CONDITION" to "TESTING".

#### **CAUTION:**

**If "TESTING" does not appear on CONSULT-III for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than "P0733" is shown, refer to ["AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).**

If "COMPLETED RESULT NG" is detected, go to [AT-115, "Diagnosis Procedure"](#).

If "STOP VEHICLE" is detected, go to the following step.

6. Stop vehicle.
7. Drive vehicle in "D" position allowing it to shift from 1GR to 5GR and check shift timing and shift shock.
  - Touch "OK" to complete the inspection when normally shifted from the 1GR to 5GR.

# P0733 3GR INCORRECT RATIO

## < SERVICE INFORMATION >

- Touch "NG" when an unusual shift shock, etc. occurs in spite of shifting from the 1GR to 5GR. Go to [AT-47, "Inspections Before Trouble Diagnosis"](#).
- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III when not shifted from the 1GR to 5GR. (Neither "OK" nor "NG" are indicated.)

### WITH GST

1. Start the engine.
2. Drive vehicle for approximately 5 minutes in urban areas.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                     |                           |
|---------------------|---------------------------|
| Manual mode switch  | : ON                      |
| Gear position       | : "3" position            |
| Accelerator opening | : 0.6/8 or more           |
| Vehicle speed       | : 10 km/h (6 MPH) or more |

4. Check DTC. If DTC is detected, go to [AT-115, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000004656872

### 1.CHECK CAN COMMUNICATION LINE

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-90](#).
- NO >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTION ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace damaged parts.

### 4.REPLACE CONTROL VALVE WITH TCM

1. Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Perform [AT-114, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**
- NG >> Confirm malfunction phenomena by "ROAD TEST" to repair malfunctioning part. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# P0734 4GR INCORRECT RATIO

< SERVICE INFORMATION >

## P0734 4GR INCORRECT RATIO

### Description

INFOID:000000004656873

This malfunction is detected when the A/T does not shift into 4GR position as instructed by TCM. This is not only caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### On Board Diagnosis Logic

INFOID:000000004656874

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0734" with CONSULT-III or 21st judgment flicker without CONSULT-III is detected when TCM detects any inconsistency in the actual gear ratio.

### Possible Cause

INFOID:000000004656875

- Input clutch solenoid valve
- Front brake solenoid valve
- Direct clutch solenoid valve
- High and low reverse clutch solenoid valve
- Each clutch
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656876

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
2. Make sure that "ATF TEMP 1" is within the following range.

ATF TEMP 1 : 20°C – 140°C

If out of range, drive vehicle to warm ATF or stop engine to cool ATF.

3. Select "4TH GR FNCTN P0734" of "DTC WORK SUPPORT" mode for "TRANSMISSION" with CONSULT-III.
4. Drive vehicle and maintain the following conditions.

|               |                                |
|---------------|--------------------------------|
| MANU MODE SW  | : ON                           |
| GEAR          | : "4" position                 |
| ACCELE POSI   | : 0.6/8 or more                |
| VEHICLE SPEED | : 10 km/h (6 MPH) or more      |
| ENGINE SPEED  | : INPUT SPEED – 50 rpm or more |
| INPUT SPEED   | : 300 rpm or more              |

5. Keep the current driving status for at least 5 consecutive seconds if CONSULT-III screen changes from "OUT OF CONDITION" to "TESTING".

#### **CAUTION:**

**If "TESTING" does not appear on CONSULT-III for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than "P0734" is shown, refer to ["AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).**

If "COMPLETED RESULT NG" is detected, go to [AT-117, "Diagnosis Procedure"](#).

If "STOP VEHICLE" is detected, go to the following step.

6. Stop vehicle.
7. Drive vehicle in "D" position allowing it to shift from 1GR to 5GR and check shift timing and shift shock.
- Touch "OK" to complete the inspection when normally shifted from the 1GR to 5GR.

# P0734 4GR INCORRECT RATIO

## < SERVICE INFORMATION >

- Touch "NG" when an unusual shift shock, etc. occurs in spite of shifting from the 1GR to 5GR. Go to [AT-47, "Inspections Before Trouble Diagnosis"](#).
- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III when not shifted from the 1GR to 5GR. (Neither "OK" nor "NG" are indicated.)

### WITH GST

1. Start the engine.
2. Drive vehicle for approximately 5 minutes in urban areas.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                     |                           |
|---------------------|---------------------------|
| Manual mode switch  | : ON                      |
| Gear position       | : "4" position            |
| Accelerator opening | : 0.6/8 or more           |
| Vehicle speed       | : 10 km/h (6 MPH) or more |

4. Check DTC. If DTC is detected, go to [AT-117, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000004656877

### 1.CHECK CAN COMMUNICATION LINE

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-90](#).  
NO >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTION ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> GO TO 4.  
NG >> Repair or replace damaged parts.

### 4.REPLACE CONTROL VALVE WITH TCM

1. Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Perform [AT-116, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> Confirm malfunction phenomena by "ROAD TEST" to repair malfunctioning part. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# P0735 5GR INCORRECT RATIO

< SERVICE INFORMATION >

## P0735 5GR INCORRECT RATIO

### Description

INFOID:000000004656878

This malfunction is detected when the A/T does not shift into 5GR position as instructed by TCM. This is not only caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### On Board Diagnosis Logic

INFOID:000000004656879

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0735" with CONSULT-III or 22nd judgment flicker without CONSULT-III is detected when TCM detects any inconsistency in the actual gear ratio.

### Possible Cause

INFOID:000000004656880

- Input clutch solenoid valve
- Front brake solenoid valve
- Direct clutch solenoid valve
- High and low reverse clutch solenoid valve
- Each clutch
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656881

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
2. Make sure that "ATF TEMP 1" is within the following range.

ATF TEMP 1 : 20°C – 140°C

If out of range, drive vehicle to warm ATF or stop engine to cool ATF.

3. Select "5TH GR FNCTN P0735" of "DTC WORK SUPPORT" mode for "TRANSMISSION" with CONSULT-III.
4. Drive vehicle and maintain the following conditions.

|               |                                |
|---------------|--------------------------------|
| MANU MODE SW  | : ON                           |
| GEAR          | : "5" position                 |
| ACCELE POSI   | : 0.6/8 or more                |
| VEHICLE SPEED | : 10 km/h (6 MPH) or more      |
| ENGINE SPEED  | : INPUT SPEED – 50 rpm or more |
| INPUT SPEED   | : 300 rpm or more              |

5. Keep the current driving status for at least 5 consecutive seconds if CONSULT-III screen changes from "OUT OF CONDITION" to "TESTING".

#### **CAUTION:**

**If "TESTING" does not appear on CONSULT-III for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than "P0735" is shown, refer to ["AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#).**

If "COMPLETED RESULT NG" is detected, go to [AT-119, "Diagnosis Procedure"](#).

If "STOP VEHICLE" is detected, go to the following step.

6. Stop vehicle.
7. Drive vehicle in "D" position allowing it to shift from 1GR to 5GR and check shift timing and shift shock.
  - Touch "OK" to complete the inspection when normally shifted from the 1GR to 5GR.

# P0735 5GR INCORRECT RATIO

## < SERVICE INFORMATION >

- Touch "NG" when an unusual shift shock, etc. occurs in spite of shifting from the 1GR to 5GR. Go to [AT-47, "Inspections Before Trouble Diagnosis"](#).
- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III when not shifted from the 1GR to 5GR. (Neither "OK" nor "NG" are indicated.)

### WITH GST

1. Start the engine.
2. Drive vehicle for approximately 5 minutes in urban areas.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                     |                           |
|---------------------|---------------------------|
| Manual mode switch  | : ON                      |
| Gear position       | : "5" position            |
| Accelerator opening | : 0.6/8 or more           |
| Vehicle speed       | : 10 km/h (6 MPH) or more |

4. Check DTC. If DTC is detected, go to [AT-119, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000004656882

### 1.CHECK CAN COMMUNICATION LINE

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-90](#).  
NO >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTION ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> GO TO 4.  
NG >> Repair or replace damaged parts.

### 4.REPLACE CONTROL VALVE WITH TCM

1. Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Perform [AT-118, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> Confirm malfunction phenomena by "ROAD TEST" to repair malfunctioning part. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).



# P0740 TORQUE CONVERTER

< SERVICE INFORMATION >

## P0740 TORQUE CONVERTER

### Description

INFOID:000000004656883

- Torque converter clutch solenoid valve is activated, with the gear in D4, D5, M2, M3, M4 and M5 by the TCM in response to signals sent from the output speed sensor and accelerator pedal position sensor (throttle position sensor). Torque converter clutch piston operation will then be controlled.
- Lock-up operation, however, is prohibited when A/T fluid temperature is too low.
- When the accelerator pedal is depressed (less than 1.0/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

### CONSULT-III Reference Value

INFOID:000000004656884

| Item name    | Condition         | Display value (Approx.) |
|--------------|-------------------|-------------------------|
| TCC SOLENOID | Lock-up is active | 0.4 – 0.6 A             |

### On Board Diagnosis Logic

INFOID:000000004656885

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0740” with CONSULT-III or 3rd judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656886

- Torque converter clutch solenoid valve
- Harness or connectors  
(Solenoid circuit is open or shorted.)

### DTC Confirmation Procedure

INFOID:000000004656887

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

VHCL/S SE-A/T : 80 km/h (50 MPH) or more

ACCELE POSI : 0.5/8 – 1.0/8

SLCT LVR POSI : “D” position

Driving location : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

4. If DTC is detected go to [AT-120. "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656888

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.



# P0740 TORQUE CONVERTER

## < SERVICE INFORMATION >

3. Read out the value of "TCC SOLENOID" while driving.

| Item name    | Condition         | Display value (Approx.) |
|--------------|-------------------|-------------------------|
| TCC SOLENOID | Lock-up is active | 0.4 – 0.6 A             |

### OK or NG

OK >> GO TO 4.

NG >> GO TO 2.

## 2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

## 3. DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

## 4. CHECK DTC

Perform [AT-120. "DTC Confirmation Procedure"](#).

### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# P0744 TORQUE CONVERTER

< SERVICE INFORMATION >

## P0744 TORQUE CONVERTER

### Description

INFOID:000000004656889

This malfunction is detected when the A/T does not shift into 5GR position or the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### CONSULT-III Reference Value

INFOID:000000004656890

| Item name    | Condition         | Display value (Approx.) |
|--------------|-------------------|-------------------------|
| TCC SOLENOID | Lock-up is active | 0.4 – 0.6 A             |

### On Board Diagnosis Logic

INFOID:000000004656891

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0744” with CONSULT-III or 3rd judgment flicker without CONSULT-III is detected under the following conditions.
  - When A/T cannot perform lock-up even if electrical circuit is good.
  - When TCM detects as irregular by comparing difference value with slip rotation.

### Possible Cause

INFOID:000000004656892

- Harness or connectors  
(Solenoid circuit is open or shorted.)
- Torque converter clutch solenoid valve
- Hydraulic control circuit

### DTC Confirmation Procedure

INFOID:000000004656893

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 30 consecutive seconds.

|                  |  |
|------------------|--|
| ACCELE POSI      | : More than 1.0/8  |
| SLCT LVR POSI    | : “D” position   |
| TCC SOLENOID     | : 0.4 – 0.6 A  |
| VEHICLE SPEED    | : 80 km/h (50 MPH) or more   |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected, go to [AT-122, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656894

#### 1. CHECK INPUT SIGNAL

#### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.

## P0744 TORQUE CONVERTER

### < SERVICE INFORMATION >

3. Read out the value of "TCC SOLENOID" while driving.

| Item name    | Condition         | Display value (Approx.) |
|--------------|-------------------|-------------------------|
| TCC SOLENOID | Lock-up is active | 0.4 – 0.6 A             |

#### OK or NG

OK >> GO TO 4.

NG >> GO TO 2.

### 2.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

### 4.CHECK DTC

Perform [AT-122. "DTC Confirmation Procedure"](#).

#### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# P0745 PRESSURE CONTROL SOLENOID A

< SERVICE INFORMATION >

## P0745 PRESSURE CONTROL SOLENOID A

### Description

INFOID:000000004656895

The line pressure solenoid valve regulates oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

### CONSULT-III Reference Value

INFOID:000000004656896

| Item name     | Condition      | Display value (Approx.) |
|---------------|----------------|-------------------------|
| LINE PRES SOL | During driving | 0.2 – 0.6 A             |

### On Board Diagnosis Logic

INFOID:000000004656897

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0745” with CONSULT-III or 4th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656898

- Harness or connectors  
(Solenoid circuit is open or shorted.)
- Line pressure solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656899

#### NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine and wait for at least 5 seconds.
2. Select “SELF-DIAG RESULTS” mode for “TRANSMISSION” with CONSULT-III.
3. If DTC is detected, go to [“AT-124, "Diagnosis Procedure"”](#).

#### Ⓞ WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656900

#### 1. CHECK INPUT SIGNAL

##### Ⓟ With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Read out the value of “LINE PRES SOL” while driving.

| Item name     | Condition      | Display value (Approx.) |
|---------------|----------------|-------------------------|
| LINE PRES SOL | During driving | 0.2 – 0.6 A             |

#### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

#### 2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

## P0745 PRESSURE CONTROL SOLENOID A

### < SERVICE INFORMATION >

---

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

### 3.DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector

#### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

### 4.CHECK DTC

---

Perform [AT-124, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# P1705 TP SENSOR

< SERVICE INFORMATION >

## P1705 TP SENSOR

### Description

INFOID:000000004656901

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor, etc. The actuator sends a signal to the ECM, and ECM sends signals to TCM with CAN communication.

### CONSULT-III Reference Value

INFOID:000000004656902

| Item name   | Condition                          | Display value (Approx.) |
|-------------|------------------------------------|-------------------------|
| ACCELE POSI | Released accelerator pedal.        | 0.0/8                   |
|             | Fully depressed accelerator pedal. | 8.0/8                   |

### On Board Diagnosis Logic

INFOID:000000004656903

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1705" with CONSULT-III or 15th judgment flicker without CONSULT-III is detected when TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.

### Possible Cause

INFOID:000000004656904

Harness or connectors  
(Sensor circuit is open or shorted.)

### DTC Confirmation Procedure

INFOID:000000004656905

#### NOTE:

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine and let it idle for 1 second.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
3. If DTC is detected, go to [AT-126. "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure "WITH CONSULT-III".

### Diagnosis Procedure

INFOID:000000004656906

#### 1. CHECK CAN COMMUNICATION LINE

##### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

##### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

#### 2. CHECK DTC WITH TCM

##### With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Depress accelerator pedal and read out the value of "ACCELE POSI".

# P1705 TP SENSOR

## < SERVICE INFORMATION >

| Item name   | Condition                          | Display value (Approx.) |
|-------------|------------------------------------|-------------------------|
| ACCELE POSI | Released accelerator pedal.        | 0.0/8                   |
|             | Fully depressed accelerator pedal. | 8.0/8                   |

4. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-III. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#)

### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 3.

## 3.CHECK DTC WITH ECM

### With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-111, "CONSULT-III Function \(ENGINE\)"](#).

### OK or NG

- OK >> GO TO 4.  
NG >> Check the DTC detected item. Refer to [EC-111, "CONSULT-III Function \(ENGINE\)"](#).  
• If CAN communication line is detected, go to [AT-90](#).

## 4.CHECK DTC

Perform [AT-126, "DTC Confirmation Procedure"](#).

### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 5.

## 5.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

- OK >> GO TO 6.  
NG >> Repair or replace damaged parts.

## 6.DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
NG >> Repair or replace damaged parts.

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# P1710 TRANSMISSION FLUID TEMPERATURE SENSOR

< SERVICE INFORMATION >

## P1710 TRANSMISSION FLUID TEMPERATURE SENSOR

### Description

INFOID:000000004656907

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.

### CONSULT-III Reference Value

INFOID:000000004656908

| Item name     | Condition °C (°F)           | Display value (Approx.) |
|---------------|-----------------------------|-------------------------|
| ATF TEMP SE 1 | 0 (32) – 20 (68) – 80 (176) | 3.3 – 2.7 – 0.9 V       |
| ATF TEMP SE 2 |                             | 3.3 – 2.5 – 0.7 V       |

### On Board Diagnosis Logic

INFOID:000000004656909

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1710 (A/T), P0710 (ENGINE)” with CONSULT-III or 10th judgment flicker without CONSULT-III is detected when TCM receives an excessively low or high voltage from the sensor.

### Possible Cause

INFOID:000000004656910

- Harness or connectors  
(Sensor circuit is open or shorted.)
- A/T fluid temperature sensors 1 and/or 2

### DTC Confirmation Procedure

INFOID:000000004656911

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)

VHCL/S SE-A/T : 10 km/h (6 MPH) or more

ACCELE POSI : More than 1.0/8

SLCT LVR POSI : “D” position

4. If DTC is detected, go to [AT-129, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.



# P1710 TRANSMISSION FLUID TEMPERATURE SENSOR


< SERVICE INFORMATION >

## Wiring Diagram - AT - FTS


INFOID:000000004656912

AT-FTS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



A/T ASSEMBLY



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

## Diagnosis Procedure

### 1. CHECK A/T FLUID TEMPERATURE SENSOR 1 SIGNAL

**With CONSULT-III**

1. Start the engine.

TCWM0681E

INFOID:000000004656913

# P1710 TRANSMISSION FLUID TEMPERATURE SENSOR

## < SERVICE INFORMATION >

2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out the value of "ATF TEMP SE 1".

| Item name     | Condition °C (°F)           | Display value (Approx.) |
|---------------|-----------------------------|-------------------------|
| ATF TEMP SE 1 | 0 (32) – 20 (68) – 80 (176) | 3.3 – 2.7 – 0.9 V       |

### OK or NG

- OK >> GO TO 2.  
 NG >> GO TO 3.

## 2.CHECK A/T FLUID TEMPERATURE SENSOR 2 SIGNAL

### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out the value of "ATF TEMP SE 2".

| Item name     | Condition °C (°F)           | Display value (Approx.) |
|---------------|-----------------------------|-------------------------|
| ATF TEMP SE 2 | 0 (32) – 20 (68) – 80 (176) | 3.3 – 2.5 – 0.7 V       |

### OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 5.

## 3.CHECK A/T FLUID TEMPERATURE SENSOR 1

Check A/T fluid temperature sensor 1. Refer to [AT-131, "Component Inspection"](#).

### OK or NG

- OK >> GO TO 4.  
 NG >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

## 4.CHECK SUB-HARNESS

1. Disconnect transmission range switch connector and TCM connector.
2. Check continuity between transmission range switch connector terminals (A) and TCM connector (B) terminals.

| Item                                | Connector | Terminal | Continuity |
|-------------------------------------|-----------|----------|------------|
| Transmission range switch connector | F505      | 6        | Yes        |
| TCM connector                       | F503      | 19       |            |
| Transmission range switch connector | F505      | 7        | Yes        |
| TCM connector                       | F503      | 18       |            |

3. If OK, check harness for short to ground and short to power.

### OK or NG

- OK >> GO TO 7.  
 NG >> Replace open circuit or short to ground and short to power in harness or connectors.

## 5.CHECK A/T FLUID TEMPERATURE SENSOR 2


Check A/T fluid temperature sensor 2. Refer to [AT-131, "Component Inspection"](#).

### OK or NG

- OK >> GO TO 6.  
 NG >> Replace A/T fluid temperature sensor 2. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

## 6.CHECK TERMINAL CORD ASSEMBLY

1. Disconnect A/T fluid temperature sensor 2 connector and TCM connector.



# P1710 TRANSMISSION FLUID TEMPERATURE SENSOR

## < SERVICE INFORMATION >

- Check continuity between A/T fluid temperature sensor 2 connector terminals and TCM connector terminals.

| Item                                     | Connector | Terminal | Continuity |
|--|-----------|----------|------------|
| A/T fluid temperature sensor 2 connector | F507      | 1        | Yes        |
| TCM connector                            | F502      | 3        |            |
| A/T fluid temperature sensor 2 connector | F507      | 2        | Yes        |
| TCM connector                            | F502      | 5        |            |

- If OK, check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 7.

NG >> Replace open circuit or short to ground and short to power in harness or connectors.

## 7. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

- Check TCM power supply and ground circuit. Refer to [AT-156](#).
- Reinstall any part removed.

### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

## 8. CHECK DTC

Perform [AT-128, "DTC Confirmation Procedure"](#).

### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 1.

## Component Inspection

INFOID:000000004656914

### A/T FLUID TEMPERATURE SENSOR 1



- Remove control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- Check resistance between transmission range switch connector (A) terminals.

| Name                           | Connector | Terminal | Temperature<br>°C (°F) | Resistance<br>(Approx.) |
|--------------------------------|-----------|----------|------------------------|-------------------------|
| A/T fluid temperature sensor 1 | F505      | 6 - 7    | 0 (32)                 | 15 kΩ                   |
|                                |           |          | 20 (68)                | 6.5 kΩ                  |
|                                |           |          | 80 (176)               | 0.9 kΩ                  |

- If NG, replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

### A/T FLUID TEMPERATURE SENSOR 2

- Remove A/T fluid temperature sensor 2. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).




# P1710 TRANSMISSION FLUID TEMPERATURE SENSOR

## < SERVICE INFORMATION >

2. Check resistance between terminals.

| Name                              | Connector | Terminal | Temperature<br>°C (°F) | Resistance<br>(Approx.) |
|-----------------------------------|-----------|----------|------------------------|-------------------------|
| A/T fluid temperature<br>sensor 2 | F507      | 1 - 2    | 0 (32)                 | 10 kΩ                   |
|                                   |           |          | 20 (68)                | 4 kΩ                    |
|                                   |           |          | 80 (176)               | 0.5 kΩ                  |

3. If NG, replace A/T fluid temperature sensor 2. Refer to [AT-204](#), "[Control Valve with TCM and A/T Fluid Temperature Sensor 2](#)".



# P1721 VEHICLE SPEED SIGNAL

< SERVICE INFORMATION >

## P1721 VEHICLE SPEED SIGNAL

### Description

INFOID:000000004656915

The vehicle speed signal is transmitted from combination meter to TCM by CAN communication line. The signal functions as an auxiliary device to the output speed sensor when it is malfunctioning. The TCM will then use the vehicle speed signal.

### CONSULT-III Reference Value

INFOID:000000004656916

| Item name     | Condition      | Display value                                  |
|---------------|----------------|--|
| VHCL/S SE-MTR | During driving | Approximately matches the speedometer reading. |

### On Board Diagnosis Logic

INFOID:000000004656917

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1721" with CONSULT-III is detected when TCM does not receive the proper vehicle speed signal (input by CAN communication) from unified meter and A/C amp.

### Possible Cause

INFOID:000000004656918

Harness or connectors  
(Sensor circuit is open or shorted.)

### DTC Confirmation Procedure

INFOID:000000004656919

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

VHCL/S SE-MTR : 30 km/h (19 MPH) or more  
ACCELE POSI : 1.0/8 or less

4. If DTC is detected, go to [AT-133. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004656920

#### 1.CHECK CAN COMMUNICATION LINE

##### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

##### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is malfunction in the CAN communication indicated in the result?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

#### 2.CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and read out the value of "VHCL/S SE-MTR".

## P1721 VEHICLE SPEED SIGNAL

### < SERVICE INFORMATION >

---

| Item name     | Condition      | Display value                                  |
|---------------|----------------|--|
| VHCL/S SE-MTR | During driving | Approximately matches the speedometer reading. |

---

#### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

### **3.**CHECK UNIFIED METER AND A/C AMP.

---

Check unified meter and A/C amp. Refer to [DI-42](#).

#### OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace damaged parts.

### **4.**CHECK DTC

---

Perform [AT-133, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

### **5.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

### **6.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

# P1730 INTERLOCK

< SERVICE INFORMATION >

## P1730 INTERLOCK

### Description

INFOID:000000004656921

Fail-safe function to detect interlock conditions.

### On Board Diagnosis Logic

INFOID:000000004656922

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1730" with CONSULT-III or 12th judgment flicker without CONSULT-III is detected when TCM does not receive the proper voltage signal from the sensor and switch.
- TCM monitors and compares gear position and conditions of each ATF pressure switch when gear is steady.

### Possible Cause

INFOID:000000004656923

- Harness or connectors  
(Solenoid and switch circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

### DTC Confirmation Procedure

INFOID:000000004656924

#### NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

SLCT LVR POSI : "D" position

4. If DTC is detected, go to [AT-135. "Diagnosis Procedure"](#).

#### Ⓞ WITH GST

Follow the procedure "WITH CONSULT-III".

### Judgment of Interlock

INFOID:000000004656925

- When Interlock is judged to be malfunctioning, the vehicle should be fixed in 2GR, and should be set in a condition in which it can travel.

#### NOTE:

**When the vehicle is driven fixed in 2GR, a input speed sensor malfunction is displayed, but this is not a input speed sensor malfunction.**

- When interlock is detected at the 3GR or more, it is locked at the 2GR.

### Diagnosis Procedure

INFOID:000000004656926

## 1.SELF-DIAGNOSIS

#### Ⓟ With CONSULT-III

1. Drive vehicle.
2. Stop vehicle and turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Ⓞ Without CONSULT-III

1. Drive vehicle.
2. Stop vehicle and turn ignition switch OFF.
3. Turn ignition switch ON.
4. Perform self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

OK or NG

# P1730 INTERLOCK

## < SERVICE INFORMATION >

---

OK >> GO TO 2.

NG >> Check low coast brake solenoid valve circuit and function. Refer to [AT-147](#), [AT-149](#).

### 2.CHECK DTC

---

Perform [AT-135, "DTC Confirmation Procedure"](#).

#### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 3.

### 3.CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

### 4.DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.



# P1731 1ST ENGINE BRAKING

< SERVICE INFORMATION >

## P1731 1ST ENGINE BRAKING

### Description

INFOID:000000004656927

Fail-safe function to prevent sudden decrease in speed by engine brake other than at M1 position.

### CONSULT-III Reference Value

INFOID:000000004656928

| Item name     | Condition  | Display value |
|---------------|--|---------------|
| ON OFF SOL    | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |
| ATF PRES SW 2 | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

### On Board Diagnosis Logic

INFOID:000000004656929

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1731" with CONSULT-III or 13th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM does not receive the proper voltage signal from the sensor.
  - When TCM monitors each ATF pressure switch and solenoid monitor value, and detects as irregular when engine brake of 1GR acts other than at M1 position.

### Possible Cause

INFOID:000000004656930

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

### DTC Confirmation Procedure

INFOID:000000004656931

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

ENGINE SPEED : 1,200 rpm  
MANU MODE SW : ON  
GEAR : "1" position

4. If DTC is detected, go to [AT-137. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004656932

#### 1. CHECK INPUT SIGNALS

##### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle in the "M" position (1GR), and confirm the ON/OFF actuation of "ATF PRES SW 2" and "ON OFF SOL".

# P1731 1ST ENGINE BRAKING

## < SERVICE INFORMATION >

---

| Item name     | Condition  | Display value |
|---------------|--|---------------|
| ON OFF SOL    | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |
| ATF PRES SW 2 | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

## **2.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

## **3.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

## **4.**CHECK DTC

---

Perform [AT-137, "DTC Confirmation Procedure"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

# P1752 INPUT CLUTCH SOLENOID

< SERVICE INFORMATION >

## P1752 INPUT CLUTCH SOLENOID

### Description

INFOID:000000004656933

Input clutch solenoid valve is controlled by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

### CONSULT-III Reference Value

INFOID:000000004656934

| Item name    | Condition   | Display value (Approx.) |
|--------------|---|-------------------------|
| I/C SOLENOID | Input clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|              | Input clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

### On Board Diagnosis Logic

INFOID:000000004656935

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1752” with CONSULT-III or 5th judgment flicker CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656936

- Harness or connectors  
(Solenoid circuit is open or shorted.)
- Input clutch solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656937

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                  |  |
|------------------|--|
| ACCELE POSI      | : 1.5/8 – 2.0/8  |
| SLCT LVR POSI    | : “D” position   |
| GEAR             | : “3” ⇒ “4” (I/C ON/OFF)   |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected go to [“AT-139, “Diagnosis Procedure”](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656938

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Read out the value of “I/C SOLENOID” while driving.

# P1752 INPUT CLUTCH SOLENOID

## < SERVICE INFORMATION >

---

| Item name    | Condition   | Display value (Approx.) |
|--------------|---|-------------------------|
| I/C SOLENOID | Input clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|              | Input clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

### OK or NG

OK >> GO TO 4.

NG >> GO TO 2.

## **2.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

## **3.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

## **4.**CHECK DTC

---

Perform [AT-139, "DTC Confirmation Procedure"](#).

### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

# P1757 FRONT BRAKE SOLENOID

< SERVICE INFORMATION >

## P1757 FRONT BRAKE SOLENOID

### Description

INFOID:000000004656939

Front brake solenoid valve is controlled by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

### CONSULT-III Reference Value

INFOID:000000004656940

| Item name     | Condition  | Display value (Approx.) |
|---------------|--|-------------------------|
| FR/B SOLENOID | Front brake engaged. Refer to <a href="#">AT-17</a> .    | 0.6 – 0.8 A             |
|               | Front brake disengaged. Refer to <a href="#">AT-17</a> . | 0 – 0.05 A              |

### On Board Diagnosis Logic

INFOID:000000004656941

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1757” with CONSULT-III or 6th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656942

- Harness or connectors (Solenoid circuit is open or shorted.)
- Front brake solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656943

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                  |  |
|------------------|--|
| ACCELE POSI      | : 1.5/8 – 2.0/8  |
| SLCT LVR POSI    | : “D” position   |
| GEAR             | : “3” ⇒ “4” (FR/B ON/OFF)  |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected go to [AT-141, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656944

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Read out the value of “FR/B SOLENOID” while driving.

# P1757 FRONT BRAKE SOLENOID

## < SERVICE INFORMATION >

---

| Item name     | Condition  | Display value (Approx.) |
|---------------|--|-------------------------|
| FR/B SOLENOID | Front brake engaged. Refer to <a href="#">AT-17</a> .    | 0.6 – 0.8 A             |
|               | Front brake disengaged. Refer to <a href="#">AT-17</a> . | 0 – 0.05 A              |

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

## **2.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

## **3.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

## **4.**CHECK DTC

---

Perform [AT-141, "DTC Confirmation Procedure"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

# P1762 DIRECT CLUTCH SOLENOID

< SERVICE INFORMATION >

## P1762 DIRECT CLUTCH SOLENOID

### Description

INFOID:000000004656945

Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

### CONSULT-III Reference Value

INFOID:000000004656946

| Item name    | Condition  | Display value (Approx.) |
|--------------|--|-------------------------|
| D/C SOLENOID | Direct clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|              | Direct clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

### On Board Diagnosis Logic

INFOID:000000004656947

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1762” with CONSULT-III or 2nd judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656948

- Harness or connectors (Solenoid circuit is open or shorted.)
- Direct clutch solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656949

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                  |  |
|------------------|--|
| ACCELE POSI      | : 1.5/8 – 2.0/8  |
| SLCT LVR POSI    | : “D” position   |
| GEAR             | : “1” ⇒ “2” (D/C ON/OFF)   |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected, go to [AT-143, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656950

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Read out the value of “D/C SOLENOID” while driving.

# P1762 DIRECT CLUTCH SOLENOID

## < SERVICE INFORMATION >

---

| Item name    | Condition  | Display value (Approx.) |
|--------------|--|-------------------------|
| D/C SOLENOID | Direct clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|              | Direct clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

### OK or NG

OK >> GO TO 4.

NG >> GO TO 2.

## **2.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

## **3.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

NG >> Repair or replace damaged parts.

## **4.**CHECK DTC

---

Perform [AT-143, "DTC Confirmation Procedure"](#).

### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.



# P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID

< SERVICE INFORMATION >

## P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID

### Description

INFOID:000000004656951

High and low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

### CONSULT-III Reference Value

INFOID:000000004656952

| Item name | Condition  | Display value (Approx.) |
|-----------|--|-------------------------|
| HLR/C SOL | High and low reverse clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|           | High and low reverse clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

### On Board Diagnosis Logic

INFOID:000000004656953

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1767” with CONSULT-III or 8th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
  - When TCM detects as irregular by comparing target value with monitor value.

### Possible Cause

INFOID:000000004656954

- Harness or connectors (Solenoid circuit is open or shorted.)
- High and low reverse clutch solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656955

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

|                  |  |
|------------------|--|
| ACCELE POSI      | : 1.5/8 – 2.0/8  |
| SLCT LVR POSI    | : “D” position   |
| GEAR             | : “2” ⇒ “3” (HLR/C ON/OFF)   |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected, go to [AT-145, "Diagnosis Procedure"](#).

#### WITH GST

Follow the procedure “WITH CONSULT-III”.

### Diagnosis Procedure

INFOID:000000004656956

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select “DATA MONITOR” mode for “TRANSMISSION” with CONSULT-III.
3. Read out the value of “HLR/C SOL” while driving.

# P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID

## < SERVICE INFORMATION >

---

| Item name | Condition  | Display value (Approx.) |
|-----------|--|-------------------------|
| HLR/C SOL | High and low reverse clutch disengaged. Refer to <a href="#">AT-17</a> . | 0.6 – 0.8 A             |
|           | High and low reverse clutch engaged. Refer to <a href="#">AT-17</a> .    | 0 – 0.05 A              |

---

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

## **2.**CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

## **3.**DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

## **4.**CHECK TCM

---

Perform [AT-145, "DTC Confirmation Procedure"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

# P1772 LOW COAST BRAKE SOLENOID

< SERVICE INFORMATION >

## P1772 LOW COAST BRAKE SOLENOID

### Description

INFOID:000000004656957

Low coast brake solenoid valve is turned ON or OFF by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

### CONSULT-III Reference Value

INFOID:000000004656958

| Item name  | Condition  | Display value |
|------------|--|---------------|
| ON OFF SOL | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|            | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

### On Board Diagnosis Logic

INFOID:000000004656959

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1772" with CONSULT-III or 7th judgment flicker without CONSULT-III is detected when TCM detects an improper voltage drop when it tries to operate the solenoid valve.

### Possible Cause

INFOID:000000004656960

- Harness or connectors (Solenoid circuit is open or shorted.)
- Low coast brake solenoid valve

### DTC Confirmation Procedure

INFOID:000000004656961

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

MANU MODE SW : ON  
GEAR : "1" or "2" (LC/B ON/OFF)

4. If DTC is detected, go to [AT-147](#), "[Diagnosis Procedure](#)".

#### WITH GST

Follow the procedure "WITH CONSULT-III".

### Diagnosis Procedure

INFOID:000000004656962

#### 1. CHECK INPUT SIGNAL

##### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out the value of "ON OFF SOL" while driving.

| Item name  | Condition  | Display value |
|------------|--|---------------|
| ON OFF SOL | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|            | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

## P1772 LOW COAST BRAKE SOLENOID

< SERVICE INFORMATION >

---

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

### 2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

---

Check TCM power supply and ground circuit. Refer to [AT-156](#).

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace damaged parts.

### 3. DETECT MALFUNCTIONING ITEM

---

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

### 4. CHECK DTC

---

Perform [AT-147, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

# P1774 LOW COAST BRAKE SOLENOID

< SERVICE INFORMATION >

## P1774 LOW COAST BRAKE SOLENOID

### Description

INFOID:000000004656963

- Low coast brake solenoid valve is turned ON or OFF by the TCM in response to signals sent from the transmission range switch, output speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

### CONSULT-III Reference Value

INFOID:000000004656964

| Item name     | Condition  | Display value |
|---------------|--|---------------|
| ON OFF SOL    | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |
| ATF PRES SW 2 | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

### On Board Diagnosis Logic

INFOID:000000004656965

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1774" with CONSULT-III or 7th judgment flicker without CONSULT-III is detected under the following conditions.
  - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 2 is irregular during depressing accelerator pedal (Other than during shift change)
  - When TCM detects that relation between gear position and condition of ATF pressure switch 2 is irregular during releasing accelerator pedal (Other than during shift change).

### Possible Cause

INFOID:000000004656966

- Harness or connectors  
(The solenoid and switch circuits are open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

### DTC Confirmation Procedure

INFOID:000000004656967

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### Ⓟ WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Accelerate vehicle to maintain the following conditions.

MANU MODE SW : ON  
GEAR : "1" or "2" (LC/B ON/OFF)

4. Perform step 3 again.
5. Turn ignition switch OFF, then perform step 1 to 4 again.
6. Check "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.
  - If DTC (P1774) is detected, refer to [AT-150, "Diagnosis Procedure"](#).
  - If DTC (P1772) is detected, go to [AT-147, "Diagnosis Procedure"](#).

#### Ⓟ WITH GST

Follow the procedure "WITH CONSULT-III".

# P1774 LOW COAST BRAKE SOLENOID

< SERVICE INFORMATION >

## Diagnosis Procedure

INFOID:000000004656968

### 1. CHECK INPUT SIGNALS

#### With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Drive vehicle in the manual mode (1GR or 2GR), and confirm the ON/OFF actuation of the "ATF PRES SW 2" and "ON OFF SOL".

| Item name     | Condition  | Display value |
|---------------|--|---------------|
| ON OFF SOL    | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |
| ATF PRES SW 2 | Low coast brake engaged. Refer to <a href="#">AT-17</a> .    | ON            |
|               | Low coast brake disengaged. Refer to <a href="#">AT-17</a> . | OFF           |

#### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 2.

### 2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair or replace damaged parts.

### 3. DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
NG >> Repair or replace damaged parts.

### 4. CHECK DTC

Perform [AT-149, "DTC Confirmation Procedure"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 2.

# P1815 M-MODE SWITCH

< SERVICE INFORMATION >

## P1815 M-MODE SWITCH

### Description

INFOID:000000004656969

Manual mode switch is installed in A/T shift selector. It sends manual mode switch, shift up and shift down switch signals to TCM.

TCM sends the switch signals to unified meter and A/C amp. by CAN communication line. Then manual mode switch position is indicated on the A/T position indicator. For inspection, refer to [AT-162](#).

### CONSULT-III Reference Value in Data Monitor Mode

INFOID:000000004656970

| Item name     | Condition                            | Display Value |
|---------------|--------------------------------------|---------------|
| MANU MODE SW  | Manual shift gate position (neutral) | ON            |
|               | Other than the above                 | OFF           |
| NON M-MODE SW | Manual shift gate position           | OFF           |
|               | Other than the above                 | ON            |
| UP SW LEVER   | Selector lever: + side               | ON            |
|               | Other than the above                 | OFF           |
| DOWN SW LEVER | Selector lever: - side               | ON            |
|               | Other than the above                 | OFF           |

### On Board Diagnosis Logic

INFOID:000000004656971

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1815" with CONSULT-III is detected when TCM monitors Manual mode, Non manual mode, Up or Down switch signal, and detects as irregular when impossible input pattern occurs 1 second or more.

### Possible Cause

INFOID:000000004656972

- Harness or connectors  
(These switches circuit is open or shorted.)
- Manual mode select switch (Into A/T shift selector)
- Manual mode position select switch (Into A/T shift selector)

### DTC Confirmation Procedure

INFOID:000000004656973

#### **CAUTION:**

**Always drive vehicle at a safe speed.**

#### **NOTE:**

**If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.**

After the repair, perform the following procedure to confirm the malfunction is eliminated.

#### WITH CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Move selector lever to "M" position.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

MANU MODE SW : ON






5. If DTC is detected, go to [AT-154, "Diagnosis Procedure"](#).

# P1815 M-MODE SWITCH

< SERVICE INFORMATION >

## Wiring Diagram - AT - MMSW

INFOID:000000004656974



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)




TCWT0439E



# P1815 M-MODE SWITCH

< SERVICE INFORMATION >

## AT-MMSW-02



REFER TO THE FOLLOWING.  
 (M4) - FUSE BLOCK-JUNCTION BOX (J/B)

TCM terminals and data are reference value. Measured between each terminal and ground.

TCWM0263E

| Terminal | Wire color | Item  | Condition | Data (Approx.) |
|----------|------------|-------|-----------|----------------|
| 3        | L          | CAN-H | —         | —              |
| 8        | P          | CAN-L | —         | —              |

# P1815 M-MODE SWITCH

< SERVICE INFORMATION >

## Diagnosis Procedure

INFOID:000000004656975

### 1. CHECK CAN COMMUNICATION LINE

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

### 2. CHECK MANUAL MODE SWITCH CIRCUIT

With CONSULT-III

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out ON/OFF switching action of "MANU MODE SW", "NON M-MODE SW", "UP SW LEVER", "DOWN SW LEVER".

| Item name     | Condition                            | Display Value |
|---------------|--------------------------------------|---------------|
| MANU MODE SW  | Manual shift gate position (neutral) | ON            |
|               | Other than the above                 | OFF           |
| NON M-MODE SW | Manual shift gate position           | OFF           |
|               | Other than the above                 | ON            |
| UP SW LEVER   | selector lever: +side                | ON            |
|               | Other than the above                 | OFF           |
| DOWN SW LEVER | selector lever: -side                | ON            |
|               | Other than the above                 | OFF           |

Without CONSULT-III

Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+" (up) or "-" (down) side (1GR ⇔ 5GR).

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

### 3. DETECT MALFUNCTIONING ITEM

Check the following.

- Manual mode switch. Refer to [AT-155. "Component Inspection"](#).
- Pin terminals for damage or loose connection with harness connector.
- Open circuit or short to ground or short to power in harness or connector for A/T shift selector (manual mode switch).
- Unified meter and A/C amp. Refer to [DI-42](#).

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

### 4. CHECK DTC

Perform [AT-151. "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 5.

### 5. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

# P1815 M-MODE SWITCH

## < SERVICE INFORMATION >

### OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

## 6. DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.


## Component Inspection

INFOID:000000004656976

## MANUAL MODE SWITCH

Check continuity between A/T shift selector connector terminals.

| Item                               | Position | Connector | Terminal | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Manual mode select switch          | Auto     | M47       | 9 – 10   | Yes        |
|                                    | Manual   |           | 6 – 9    |            |
| Manual mode position select switch | UP       |           | 8 – 9    |            |
|                                    | DOWN     |           | 7 – 9    |            |



# MAIN POWER SUPPLY AND GROUND CIRCUIT

< SERVICE INFORMATION >






## MAIN POWER SUPPLY AND GROUND CIRCUIT

Wiring Diagram - AT - MAIN

INFOID:000000004656977

### AT-MAIN-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC





\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0440E

# MAIN POWER SUPPLY AND GROUND CIRCUIT

## < SERVICE INFORMATION >

TCM terminals and data are reference value. Measured between each terminal and ground.

| Terminal | Wire color | Item                          | Condition   | Data (Approx.)  |
|----------|------------|-------------------------------|---|-----------------|
| 1        | G          | Power supply (Memory back-up) | Always  | Battery voltage |
| 2        | G          | Power supply (Memory back-up) | Always  | Battery voltage |
| 5        | B          | Ground                        | Always  | 0 V             |
| 6        | Y/R        | Power supply                  |  | Battery voltage |
|          |            |                               |  | 0 V             |
| 10       | B          | Ground                        | Always  | 0 V             |


## Diagnosis Procedure

INFOID:000000004656978

### 1. CHECK TCM POWER SOURCE STEP 1

- Turn ignition switch OFF.
- Disconnect A/T assembly harness connector.
- Check voltage between A/T assembly harness connector and ground.

| Item | Connector | Terminal   | Voltage (Approx.) |
|------|-----------|------------|-------------------|
| TCM  | F6        | 1 – Ground | Battery voltage   |
|      |           | 2 – Ground | Battery voltage   |
|      |           | 6 – Ground | 0 V               |




#### OK or NG

- OK >> GO TO 2.  
NG >> GO TO 3.

### 2. CHECK TCM POWER SOURCE STEP 2

- Disconnect A/T assembly harness connector.
- Turn ignition switch ON.
- Check voltage between A/T assembly harness connector and ground.

| Item | Connector | Terminal   | Voltage (Approx.) |
|------|-----------|------------|-------------------|
| TCM  | F6        | 1 – Ground | Battery voltage   |
|      |           | 2 – Ground | Battery voltage   |
|      |           | 6 – Ground | 0 V               |



#### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 3.

### 3. DETECT MALFUNCTIONING ITEM

Check the following.

- Harness for short or open between battery and A/T assembly harness connector terminals 1, 2
- Harness for short or open between ignition switch and A/T assembly harness connector terminal 6
- 10 A fuse (No. 32, located in the fuse and fusible link block) and 10 A fuse (No. 83, located in the IPDM E/R)
- Ignition switch, Refer to [PG-4](#).

#### OK or NG

- OK >> GO TO 4.

# MAIN POWER SUPPLY AND GROUND CIRCUIT

## < SERVICE INFORMATION >

NG >> Repair or replace damaged parts.

### 4. CHECK TCM GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/T assembly harness connector.
3. Check continuity between A/T assembly harness connector terminals and ground.


| Item | Connector | Terminal       | Continuity |
|------|-----------|----------------|------------|
| TCM  | F6        | 5, 10 – Ground | Yes        |

If OK, check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 5. DETECT MALFUNCTIONING ITEM

Check A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> GO TO 6.

NG >> Repair or replace damaged parts.

### 6. PERFORM SELF-DIAGNOSIS

Ⓟ With CONSULT-III

Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### OK or NG

OK >> **INSPECTION END**


NG-1 >> Self-diagnosis does not activate: GO TO 7.

NG-2 >> DTC is displayed: Check the malfunctioning system. Refer to [AT-81. "CONSULT-III Function \(TRANSMISSION\)"](#).

### 7. CHECK TERMINAL CORD ASSEMBLY

1. Remove control valve with TCM. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disconnect A/T assembly harness connector and TCM connector.
3. Check continuity between A/T assembly harness connector terminals and TCM connector terminals.

| Item                           | Connector | Terminal | Continuity |
|--------------------------------|-----------|----------|------------|
| A/T assembly harness connector | F6        | 1        | Yes        |
| TCM connector                  | F502      | 9        |            |
| A/T assembly harness connector | F6        | 2        | Yes        |
| TCM connector                  | F502      | 10       |            |
| A/T assembly harness connector | F6        | 6        | Yes        |
| TCM connector                  | F502      | 4        |            |



# MAIN POWER SUPPLY AND GROUND CIRCUIT

## < SERVICE INFORMATION >


4. Check continuity between A/T assembly harness connector terminals and TCM connector terminals.

| Item                           | Connector | Terminal | Continuity |
|--------------------------------|-----------|----------|------------|
| A/T assembly harness connector | F6        | 5        | Yes        |
| TCM connector                  | F504      | 21       |            |
| A/T assembly harness connector | F6        | 10       | Yes        |
| TCM connector                  | F504      | 22       |            |

5. If OK, check harness for short to ground and short to power.

### OK or NG

- OK >> Replace control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Replace open circuit or short to ground and short to power in harness or connectors.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

< SERVICE INFORMATION >

## CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

CONSULT-III Reference Value

INFOID:000000004656979

| Item name    | Condition                          | Display value |
|--------------|------------------------------------|---------------|
| CLSD THL POS | Released accelerator pedal.        | ON            |
|              | Fully depressed accelerator pedal. | OFF           |
| W/O THL POS  | Fully depressed accelerator pedal. | ON            |
|              | Released accelerator pedal.        | OFF           |

### Diagnosis Procedure

INFOID:000000004656980

#### 1. CHECK CAN COMMUNICATION LINE

Ⓟ With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

ⓧ Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

#### 2. CHECK THROTTLE POSITION SIGNAL CIRCUIT

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Depress accelerator pedal and read out the value of "CLSD THL POS" and "W/O THL POS".

| Accelerator Pedal Operation | Monitor Item |             |
|-----------------------------|--------------|-------------|
|                             | CLSD THL POS | W/O THL POS |
| Released                    | ON           | OFF         |
| Fully depressed             | OFF          | ON          |

OK or NG

OK >> **INSPECTION END**

NG >> Check the following. If NG, repair or replace damaged parts.

- Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-111, "CONSULT-III Function \(ENGINE\)"](#).
- Open circuit or short to ground or short to power in harness or connectors.
- Pin terminals for damage or loose connection with harness connector.



# BRAKE SIGNAL CIRCUIT

< SERVICE INFORMATION >

## BRAKE SIGNAL CIRCUIT

CONSULT-III Reference Value

INFOID:000000004656981

| Item name | Condition              | Display value |
|-----------|------------------------|---------------|
| BRAKE SW  | Depressed brake pedal. | ON            |
|           | Released brake pedal.  | OFF           |

### Diagnosis Procedure

INFOID:000000004656982

#### 1. CHECK CAN COMMUNICATION LINE

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

#### 2. CHECK STOP LAMP SWITCH CIRCUIT

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III.
3. Read out ON/OFF switching action of the "BRAKE SW".

| Item name | Condition              | Display value |
|-----------|------------------------|---------------|
| BRAKE SW  | Depressed brake pedal. | ON            |
|           | Released brake pedal.  | OFF           |

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 3.

#### 3. CHECK STOP LAMP SWITCH

Check continuity between stop lamp switch harness connector E111 terminals 3 and 4. Refer to [AT-163, "Wiring Diagram - AT - NON-DTC"](#).


| Condition                     | Continuity |
|-------------------------------|------------|
| When brake pedal is depressed | Yes        |
| When brake pedal is released  | No         |

Check stop lamp switch after adjusting brake pedal — refer to [BR-7](#).

OK or NG

- OK >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
  - Harness for short or open between stop lamp switch and unified meter and A/C amp.
  - 10 A fuse (No. 20, located in fuse block).

NG >> Repair or replace the stop lamp switch.



# A/T INDICATOR CIRCUIT

< SERVICE INFORMATION >

## A/T INDICATOR CIRCUIT

### Description

INFOID:000000004656983

The TCM sends the switch signals to unified meter and A/C amp. by CAN communication line. Then manual mode switch position is indicated on the A/T position indicator.

### CONSULT-III Reference Value

INFOID:000000004656984

| Item name | Condition      | Display value |
|-----------|----------------|---------------|
| GEAR      | During driving | 1, 2, 3, 4, 5 |

### Diagnosis Procedure

INFOID:000000004656985

#### 1. CHECK INPUT SIGNALS

##### Ⓟ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-III and read out the value of "GEAR".
3. Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1GR ↔ 5GR).

##### OK or NG

OK >> **INSPECTION END**

NG >> Check the following.

### A/T INDICATOR SYMPTOM CHART

| Items  | Presumed Location of Trouble  |
|--|---|
| The actual gear position does not change, or shifting into the manual mode is not possible (no gear shifting in the manual mode possible).<br>The A/T position indicator is not indicated. | Manual mode switch<br>Refer to <a href="#">AT-151</a> .<br>A/T main system (Fail-safe function actuated)<br>• Refer to <a href="#">AT-81, "CONSULT-III Function (TRANSMISSION)"</a> . |
| The actual gear position changes, but the A/T position indicator is not indicated.   | Perform the self-diagnosis function.<br>• Refer to <a href="#">AT-81, "CONSULT-III Function (TRANSMISSION)"</a> .   |
| The actual gear position and the indication on the A/T position indicator do not coincide.   | Perform the self-diagnosis function.<br>• Refer to <a href="#">AT-81, "CONSULT-III Function (TRANSMISSION)"</a> .   |
| Only a specific position or positions is/are not indicated on the A/T position indicator.  | Check the unified meter and A/C amp.<br>• Refer to <a href="#">DI-5</a> .   |

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## TROUBLE DIAGNOSIS FOR SYMPTOMS

### Wiring Diagram - AT - NONDTC

INFOID:000000004656986

A

B

AT

D

E

F

G

H

I

J

K




L

M

N

O

P



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.







REFER TO THE FOLLOWING.

- (F102) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TCWT0441E

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >



REFER TO THE FOLLOWING.  
 (E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M4) -FUSE BLOCK-JUNCTION BOX (J/B)


\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0442E

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

AT-NONDTC-03



REFER TO THE FOLLOWING.  
 (E108) -SUPER MULTIPLE JUNCTION (SMJ)  
 (E101) -FUSE BLOCK-JUNCTION BOX (J/B)


TCM terminals and data are reference value. Measured between each terminal and ground.

TCWT0378E

| Terminal | Wire color | Item                        | Condition   | Data (Approx.) |
|----------|------------|-----------------------------|---|----------------|
| 3        | L          | CAN-H                       | —   | —              |
| 4        | PU/W       | K-line (CONSULT-III signal) | The terminal is connected to the data link connector for CONSULT-III. | —              |

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

| Terminal | Wire color | Item               | Condition   | Data (Approx.)  |
|----------|------------|--------------------|---|-----------------|
| 7        | Y          | Back-up lamp relay |  Selector lever in "R" position. | 0 V             |
|          |            |                    | Selector lever in other positions.  | Battery voltage |
| 8        | P          | CAN-L              | —   | —               |

### A/T Check Indicator Lamp Does Not Come On

INFOID:000000004656987

#### SYMPTOM:

**A/T CHECK indicator lamp does not come on for about 2 seconds when turning ignition switch to ON.**

#### DIAGNOSTIC PROCEDURE

##### 1. CHECK CAN COMMUNICATION LINE

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-90](#).

NO >> GO TO 2.

##### 2. CHECK A/T CHECK INDICATOR LAMP CIRCUIT

Check combination meter. Refer to [DI-5](#).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

##### 3. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-156](#).

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

### Engine Cannot Be Started in "P" or "N" Position

INFOID:000000004656988

#### SYMPTOM:

- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D" or "R" position.

#### DIAGNOSTIC PROCEDURE

##### 1. CHECK TRANSMISSION RANGE SWITCH CIRCUIT

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Do the self-diagnostic results indicate transmission range switch?

YES >> Check the malfunctioning system. Refer to [AT-98](#).

NO >> GO TO 2.

##### 2. CHECK A/T POSITION

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## 3.CHECK STARTING SYSTEM

Check starting system. Refer to [SC-8](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

In "P" Position, Vehicle Moves When Pushed

INFOID:000000004656989

SYMPTOM:

**Even though the selector lever is set in the "P" position, the parking mechanism is not actuated, allowing the vehicle to be moved when it is pushed.**

DIAGNOSTIC PROCEDURE

### 1.CHECK A/T POSITION

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

### 2.CHECK PARKING COMPONENTS

Check parking components. Refer to [AT-215, "Parking Component"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

In "N" Position, Vehicle Moves

INFOID:000000004656990

SYMPTOM:

**Vehicle moves forward or backward when selecting "N" position.**

DIAGNOSTIC PROCEDURE

### 1.CHECK PNP SWITCH CIRCUIT

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Do the self-diagnostic results indicate PNP switch?

- YES >> Check the malfunctioning system. Refer to [AT-98](#).
- NO >> GO TO 2.

### 2.CHECK A/T POSITION

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

### 3.CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

### 4.CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

OK >> GO TO 5.

NG >> Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 67).

---

## 5.CHECK SYMPTOM

---

Check again. Refer to [AT-51. "Road Test"](#).

### OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

---

## 6.CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80. "TCM Input/Output Signal Reference Value"](#).

2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

---

## Large Shock ("N" to "D" Position)

INFOID:000000004656991

### SYMPTOM:

**A noticeable shock occurs when the selector lever is shifted from the "N" to "D" position.**

### DIAGNOSTIC PROCEDURE

## 1.CHECK SELF-DIAGNOSTIC RESULTS

---

With CONSULT-III

• Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

• Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81. "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 2.

---

## 2.ENGINE IDLE SPEED

---

Check engine idle speed. Refer to [EC-75. "Idle Speed and Ignition Timing Check"](#).

### OK or NG

OK >> GO TO 3.

NG >> Adjust engine idle speed. Refer to [EC-75. "Idle Speed and Ignition Timing Check"](#).

---

## 3.CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195. "Checking of A/T Position"](#).

### OK or NG

OK >> GO TO 4.

NG >> Adjust A/T position. Refer to [AT-195. "Adjustment of A/T Position"](#).

---

## 4.CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).

### OK or NG

OK >> GO TO 5.

NG >> Refill ATF.

---

## 5.CHECK LINE PRESSURE

---

Check line pressure at idle with selector lever in "D" position. Refer to [AT-47. "Inspections Before Trouble Diagnosis"](#).

### OK or NG



# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

- OK >> GO TO 8.
- NG - 1 >> Line pressure high: GO TO 6.
- NG - 2 >> Line pressure low: GO TO 7.

## 6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

### OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

## 7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

### OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

## 8. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

## 9. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 1).

### OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace damaged parts.

## 10. CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 11.

## 11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## Vehicle Does Not Creep Backward in "R" Position

INFOID:000000004656992

### SYMPTOM:

**The vehicle does not creep in the "R" position. Or an extreme lack of acceleration is observed.**

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

---

## DIAGNOSTIC PROCEDURE

### 1. CHECK SELF-DIAGNOSTIC RESULTS

---

Ⓟ With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

ⓧ Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#),  
[AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 2.

### 2. CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

### 3. CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

### 4. CHECK STALL TEST

---

Check stall revolution with selector lever in "M" and "R" positions.

Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 6.

OK in "M" position, NG in "R" position >> GO TO 5.

NG in both "M" and "R" positions >> GO TO 8.

### 5. DETECT MALFUNCTIONING ITEM

---

1. Disassemble A/T. Refer to [AT-239](#).

2. Check the following.

- Reverse brake. Refer to [AT-239, "Disassembly"](#).

OK or NG

OK >> GO TO 9.

NG >> Repair or replace damaged parts.

### 6. CHECK LINE PRESSURE

---

Check line pressure with the engine idling. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 9.

NG - 1 >> Line pressure high. GO TO 7.

NG - 2 >> Line pressure low. GO TO 8.

### 7. DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

OK or NG

OK >> GO TO 9.

NG >> Repair or replace damaged parts.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## 8. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace damaged parts.

## 9. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 10.  
NG >> GO TO 13.

## 10. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 43).

OK or NG

- OK >> GO TO 11.  
NG >> Repair or replace damaged parts.

## 11. CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).

OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 12.

## 12. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**  
NG >> Repair or replace damaged parts.

## 13. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 43).

OK or NG

- OK >> GO TO 11.  
NG >> Repair or replace damaged parts.

## Vehicle Does Not Creep Forward in "D" Position

INFOID:000000004656993

SYMPTOM:

**Vehicle does not creep forward when selecting "D" position.**

DIAGNOSTIC PROCEDURE

### 1. CHECK SELF-DIAGNOSTIC RESULTS

 With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

⊗ Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#),  
[AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 2.

## 2.CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

## 3.CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

## 4.CHECK STALL TEST

---

Check stall revolution with selector lever in "D" position. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 5.

NG >> GO TO 7.

## 5.CHECK LINE PRESSURE

---

Check line pressure at idle with selector lever in "D" position. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 8.

NG - 1 >> Line pressure high. GO TO 6.

NG - 2 >> Line pressure low. GO TO 7.

## 6.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

OK or NG

OK >> GO TO 8.

NG >> Repair or replace damaged parts.

## 7.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
- Power train system. Refer to [AT-239](#).
- Transmission case. Refer to [AT-239](#).

OK or NG

OK >> GO TO 8.

NG >> Repair or replace damaged parts.

## 8.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 9.
- NG >> GO TO 12.

## 9. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 43).

### OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace damaged parts.

## 10. CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 11.

## 11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 12. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 43).

### OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace damaged parts.

## Vehicle Cannot Be Started from D1

INFOID:000000004656994

### SYMPTOM:

**Vehicle cannot be started from D1 on cruise test - Part 1.**

### DIAGNOSTIC PROCEDURE

## 1. CHECK SYMPTOM

Check if vehicle creeps in "R" position.

### OK or NG

- OK >> GO TO 2.
- NG >> Refer to [AT-169, "Vehicle Does Not Creep Backward in "R" Position"](#).

## 2. CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).
- NO >> GO TO 3.

## 3. CHECK ACCELERATOR POSITION SENSOR

Check accelerator pedal position sensor. Refer to [AT-126](#)

## TROUBLE DIAGNOSIS FOR SYMPTOMS

### < SERVICE INFORMATION >

---

#### OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace accelerator pedal position sensor.

### 4.CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

#### OK or NG

- OK >> GO TO 5.
- NG >> Refill ATF.

### 5.CHECK LINE PRESSURE

---

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

- OK >> GO TO 8.
- NG - 1 >> Line pressure high. GO TO 6.
- NG - 2 >> Line pressure low. GO TO 7.

### 6.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

#### OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

### 7.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

#### OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

### 8.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

- OK >> GO TO 9.
- NG >> GO TO 12.

### 9.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 23).

#### OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace damaged parts.

### 10.CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

#### OK or NG

- OK >> **INSPECTION END**

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

NG >> GO TO 11.

### 11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> **INSPECTION END**  
NG >> Repair or replace damaged parts.

### 12. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 23).

#### OK or NG

OK >> GO TO 10.  
NG >> Repair or replace damaged parts.

## A/T Does Not Shift: D1→D2

INFOID:000000004656995

### SYMPTOM:

**The vehicle does not shift-up from the D1 to D2 gear at the specified speed.**

### DIAGNOSTIC PROCEDURE

#### 1. CHECK SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1.

#### OK or NG

OK >> GO TO 2.  
NG >> Refer to [AT-171, "Vehicle Does Not Creep Forward in "D" Position"](#), [AT-173, "Vehicle Cannot Be Started from D1"](#).

#### 2. CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 3.

#### 3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

#### OK or NG

OK >> GO TO 4.  
NG >> Refill ATF.

#### 4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

OK >> GO TO 7.  
NG - 1 >> Line pressure high. GO TO 5.  
NG - 2 >> Line pressure low. GO TO 6.

#### 5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).

## TROUBLE DIAGNOSIS FOR SYMPTOMS

### < SERVICE INFORMATION >

---

3. Check the following items:
- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

#### OK or NG

- OK >> GO TO 7.  
NG >> Repair or replace damaged parts.

### 6. DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

#### OK or NG

- OK >> GO TO 7.  
NG >> Repair or replace damaged parts.

### 7. CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

- OK >> GO TO 8.  
NG >> GO TO 11.

### 8. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 10).

#### OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace damaged parts.

### 9. CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

#### OK or NG

- OK >> **INSPECTION END**  
NG >> GO TO 10.

### 10. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

#### OK or NG

- OK >> **INSPECTION END**  
NG >> Repair or replace damaged parts.

### 11. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 10).

#### OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace damaged parts.

A/T Does Not Shift: D2→ D3

INFOID:000000004656996

SYMPTOM:

**The vehicle does not shift-up from D2 to D3 gear at the specified speed.**



# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## DIAGNOSTIC PROCEDURE

### 1. CHECK SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1.

#### OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-171, "Vehicle Does Not Creep Forward in "D" Position"](#), [AT-173, "Vehicle Cannot Be Started from D1"](#).

### 2. CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

• Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

• Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 3.

### 3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

#### OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

### 4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

OK >> GO TO 7.

NG - 1 >> Line pressure high. GO TO 5.

NG - 2 >> Line pressure low. GO TO 6.

### 5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

#### OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

### 6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

- Power train system. Refer to [AT-239](#).

- Transmission case. Refer to [AT-239](#).

#### OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

### 7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

- OK >> GO TO 8.
- NG >> GO TO 11.

## 8. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 11).

### OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

## 9. CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.

## 10. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 11. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 11).

### OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

## A/T Does Not Shift: D3→D4

INFOID:000000004656997

### SYMPTOM:

**The vehicle does not shift-up from the D3 to D4 gear at the specified speed.**

### DIAGNOSTIC PROCEDURE

## 1. CHECK SYMPTOM

---

Check if vehicle creeps forward in "D" position and vehicle can be started from D1.

### OK or NG

- OK >> GO TO 2.
- NG >> Refer to [AT-171, "Vehicle Does Not Creep Forward in "D" Position"](#), [AT-173, "Vehicle Cannot Be Started from D1"](#).

## 2. CHECK SELF-DIAGNOSTIC RESULTS

---

### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).
- NO >> GO TO 3.

## 3. CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

## 4.CHECK LINE PRESSURE

---

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 7.
- NG - 1 >> Line pressure high. GO TO 5.
- NG - 2 >> Line pressure low. GO TO 6.

## 5.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 6.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 7.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 8.
- NG >> GO TO 11.

## 8.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 12).

### OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

## 9.CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.

## 10.CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

- OK >> **INSPECTION END**  
NG >> Repair or replace damaged parts.

### 11. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 12).

#### OK or NG

- OK >> GO TO 9.  
NG >> Repair or replace damaged parts.

### A/T Does Not Shift: D4→D5

INFOID:000000004656998

#### SYMPTOM:

- The vehicle does not shift-up from the D4 to D5 gear at the specified speed.
- The vehicle does not shift-up from the D4 to D5 gear unless A/T is warmed up.

#### DIAGNOSTIC PROCEDURE

### 1. CHECK SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1.

#### OK or NG

- OK >> GO TO 2.  
NG >> Refer to [AT-171, "Vehicle Does Not Creep Forward in "D" Position"](#), [AT-173, "Vehicle Cannot Be Started from D1"](#).

### 2. CHECK SELF-DIAGNOSTIC RESULTS

#### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

#### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

#### Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 3.

### 3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

#### OK or NG

- OK >> GO TO 4.  
NG >> Refill ATF.

### 4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

#### OK or NG

- OK >> GO TO 7.  
NG - 1 >> Line pressure high. GO TO 5.  
NG - 2 >> Line pressure low. GO TO 6.

### 5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

#### OK or NG

- OK >> GO TO 7.  
NG >> Repair or replace damaged parts.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## 6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Disassemble A/T. Refer to [AT-239](#).
3. Check the following.
  - Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
  - Power train system. Refer to [AT-239](#).
  - Transmission case. Refer to [AT-239](#).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 11.

## 8. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 13).

OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

## 9. CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 10.

## 10. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 11. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 13).

OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

## A/T Does Not Lock-up

INFOID:000000004656999

SYMPTOM:

**A/T does not lock-up at the specified speed.**

DIAGNOSTIC PROCEDURE

### 1. CHECK SELF-DIAGNOSTIC RESULTS

④ With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

⊗ Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#),  
[AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 2.

## 2.CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

## 3.CHECK LINE PRESSURE

---

Check line pressure at the engine stall point. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 6.

NG - 1 >> Line pressure high. GO TO 4.

NG - 2 >> Line pressure low. GO TO 5.

## 4.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).

OK or NG

OK >> GO TO 6.

NG >> Repair or replace damaged parts.

## 5.DETECT MALFUNCTIONING ITEM

---

1. Check control valve with TCM. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Disassemble A/T. Refer to [AT-239](#).

3. Check the following.

- Oil pump assembly. Refer to [AT-255, "Oil Pump"](#).
- Power train system. Refer to [AT-239](#).
- Transmission case. Refer to [AT-239](#).

OK or NG

OK >> GO TO 6.

NG >> Repair or replace damaged parts.

## 6.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 10.

## 7.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 24).

OK or NG

OK >> GO TO 8.

NG >> Repair or replace damaged parts.

## 8.CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 9.

## 9.CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 10.DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 24).

### OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

## A/T Does Not Hold Lock-up Condition

INFOID:000000004657000

### SYMPTOM:

**The lock-up condition cannot be maintained for more than 30 seconds.**

### DIAGNOSTIC PROCEDURE

## 1.CHECK SELF-DIAGNOSTIC RESULTS

### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

### Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 2.

## 2.CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

## 3.CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 7.

## 4.DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 25).

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## 5.CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).



# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

### 6. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80. "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

### 7. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 25).

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## Lock-up Is Not Released

INFOID:000000004657001

### SYMPTOM:

**The lock-up condition cannot be cancelled even after releasing the accelerator pedal.**

### DIAGNOSTIC PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULTS

---

##### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

##### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

#### Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81. "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 2.

#### 2. CHECK SYMPTOM

---

Check again. Refer to [AT-51. "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 3.

#### 3. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80. "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## Engine Speed Does Not Return to Idle

INFOID:000000004657002

### SYMPTOM:

**When a shift-down is performed, the engine speed does not smoothly return to the idling speed.**

### DIAGNOSTIC PROCEDURE

#### 1. CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).



# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

### OK or NG

- OK >> GO TO 2.
- NG >> Refill ATF.

## 2.CHECK SELF-DIAGNOSTIC RESULTS

### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

### Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).
- NO >> GO TO 3.

## 3.CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 7.

## 4.DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 72).

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## 5.CHECK SYMPTOM

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

## 6.CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 7.DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 72).

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## Cannot Be Changed to Manual Mode

INFOID:000000004657003

### SYMPTOM:

**Does not change to manual mode when manual shift gate is used.**

### DIAGNOSTIC PROCEDURE

#### 1.MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-151](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

---

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace damaged parts.

## 2.CHECK SELF-DIAGNOSIS RESULTS

---

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

- NO >> **INSPECTION END**

A/T Does Not Shift: 5GR → 4GR

INFOID:000000004657004

SYMPTOM:

**When shifted from M5 to M4 position in manual mode, does not downshift from 5GR to 4GR.**

DIAGNOSTIC PROCEDURE

## 1.CHECK SELF-DIAGNOSTIC RESULTS

---

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 2.

## 2.CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

## 3.CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

## 4.MANUAL MODE SWITCH

---

Check manual mode switch. Refer to [AT-151](#).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## 5.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

## 6.DETECT MALFUNCTIONING ITEM

---

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 47).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 7. CHECK SYMPTOM

Check again. Refer to [AT-51. "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

## 8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-80. "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 9. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 47).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## A/T Does Not Shift: 4GR → 3GR

INFOID:000000004657005

### SYMPTOM:

**When shifted from M4 to M3 position in manual mode, does not downshift from 4GR to 3GR.**

### DIAGNOSTIC PROCEDURE

## 1. CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81. "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 2.

## 2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

## 3. CHECK A/T POSITION

Check A/T position. Refer to [AT-195. "Checking of A/T Position"](#).

### OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-195. "Adjustment of A/T Position"](#).

## 4. MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-151](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## 5. CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

## 6. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 48).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 7. CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

## 8. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

## 9. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 48).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## A/T Does Not Shift: 3GR → 2GR

INFOID:000000004657006

### SYMPTOM:

**When shifted from M3 to M2 position in manual mode, does not downshift from 3GR to 2GR.**

### DIAGNOSTIC PROCEDURE

## 1. CHECK SELF-DIAGNOSTIC RESULTS

---

### With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

### Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88, "Diagnosis Procedure without CONSULT-III"](#).
- NO >> GO TO 2.

## 2. CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## < SERVICE INFORMATION >

---

### OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

### 3.CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

### OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

### 4.MANUAL MODE SWITCH

---

Check manual mode switch. Refer to [AT-151](#).

### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

### 5.CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

### OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

### 6.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 49).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

### 7.CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

### OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

### 8.CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

### OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

### 9.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 49).

### OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## A/T Does Not Shift: 2GR → 1GR

INFOID:000000004657007

### SYMPTOM:

**When shifted from M2 to M1 position in manual mode, does not downshift from 2GR to 1GR.**

### DIAGNOSTIC PROCEDURE

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

---

## 1. CHECK SELF-DIAGNOSTIC RESULTS

---

④ With CONSULT-III

• Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

⊗ Without CONSULT-III

• Perform the self-diagnosis. Refer to [AT-88, "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

YES >> Check the malfunctioning system. Refer to [AT-81, "CONSULT-III Function \(TRANSMISSION\)"](#),  
[AT-88, "Diagnosis Procedure without CONSULT-III"](#).

NO >> GO TO 2.

---

## 2. CHECK A/T FLUID LEVEL

---

Check A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

---

## 3. CHECK A/T POSITION

---

Check A/T position. Refer to [AT-195, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 4.

NG >> Adjust A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#).

---

## 4. MANUAL MODE SWITCH

---

Check manual mode switch. Refer to [AT-151](#).

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

---

## 5. CHECK A/T FLUID CONDITION

---

1. Remove oil pan. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

2. Check A/T fluid condition. Refer to [AT-47, "Inspections Before Trouble Diagnosis"](#).

OK or NG

OK >> GO TO 6.

NG >> GO TO 9.

---

## 6. DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 50).

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

---

## 7. CHECK SYMPTOM

---

Check again. Refer to [AT-51, "Road Test"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 8.

---

## 8. CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).

2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

---

# TROUBLE DIAGNOSIS FOR SYMPTOMS

< SERVICE INFORMATION >

## 9. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 50).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

### Vehicle Does Not Decelerate by Engine Brake

INFOID:000000004657008

SYMPTOM:

**No engine brake is applied when the gear is shifted from the 2GR to 1GR.**

DIAGNOSTIC PROCEDURE

## 1. CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

- Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III.

Without CONSULT-III

- Perform the self-diagnosis. Refer to [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

Is any malfunction detected by self-diagnostic results?

- YES >> Check the malfunctioning system. Refer to [AT-81. "CONSULT-III Function \(TRANSMISSION\)"](#), [AT-88. "Diagnosis Procedure without CONSULT-III"](#).

- NO >> GO TO 2.

## 2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

## 3. CHECK A/T POSITION

Check A/T position. Refer to [AT-195. "Checking of A/T Position"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-195. "Adjustment of A/T Position"](#).

## 4. MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-151](#).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

## 5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-204. "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).
2. Check A/T fluid condition. Refer to [AT-47. "Inspections Before Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

## 6. DETECT MALFUNCTIONING ITEM

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56. "Symptom Chart"](#) (Symptom No. 58).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

## 7. CHECK SYMPTOM

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## TROUBLE DIAGNOSIS FOR SYMPTOMS

### < SERVICE INFORMATION >

---

Check again. Refer to [AT-51, "Road Test"](#).

#### OK or NG

OK >> **INSPECTION END**  
NG >> GO TO 8.

### 8.CHECK TCM

---

1. Check TCM input/output signals. Refer to [AT-80, "TCM Input/Output Signal Reference Value"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

#### OK or NG

OK >> **INSPECTION END**  
NG >> Repair or replace damaged parts.

### 9.DETECT MALFUNCTIONING ITEM

---

Check the malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-56, "Symptom Chart"](#) (Symptom No. 58).

#### OK or NG

OK >> GO TO 7.  
NG >> Repair or replace damaged parts.




# SHIFT CONTROL SYSTEM

< SERVICE INFORMATION >

## SHIFT CONTROL SYSTEM

### A/T Shift Selector Removal and Installation

INFOID:000000004657009



- |  |   |                             |
|--|---|-----------------------------|
| 1. Selector lever knob                                   | 2. Knob cover                           | 3. Lock pin                 |
| 4. A/T shift selector assembly                           | 5. A/T shift selector harness connector | 6. Position indicator plate |
| 7. Shift lock solenoid and park position switch assembly | 8. Snap pin                             | 9. Conical washer           |
| 10. Plain washer   | 11. Bracket                             | 12. Control rod             |
| 13. Dust cover   | 14. Dust cover plate                    | 15. Bulb case               |
| 16. Position lamp  |   |                             |

#### REMOVAL

#### **CAUTION:**


**Make sure that parking brake is applied before removal/installation.**

1. Disconnect lower lever of A/T shift selector and control rod.

# SHIFT CONTROL SYSTEM

## < SERVICE INFORMATION >

2. Remove knob cover below selector lever downward.
3. Pull lock pin out of selector lever knob.
4. Remove selector lever knob.
5. Remove console finisher (A/T ring) and console finisher (A/T). Refer to [IP-12, "Component Parts Drawing"](#).
6. Remove center console. Refer to [IP-12, "Component Parts Drawing"](#).
7. Remove key interlock cable from A/T shift selector. Refer to [AT-201, "Removal and Installation"](#).
8. Disconnect A/T shift selector harness connector.
9. Remove A/T shift selector assembly.



### **CAUTION:**

**Do not impact, or damage propeller shaft tube.**

## INSTALLATION


Note the following, and install in the reverse order of removal.

- After installation is completed, adjust and check A/T position. Refer to [AT-195, "Adjustment of A/T Position"](#), [AT-195, "Checking of A/T Position"](#).

## Control Rod Removal and Installation

INFOID:000000004657010

## CONTROL ROD COMPONENTS




- |                                |                |                 |
|--------------------------------|----------------|-----------------|
| 1. A/T shift selector assembly | 2. A/T         | 3. Manual lever |
| 4. Control rod                 | 5. Lower lever |                 |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

## REMOVAL

1. Disconnect lower lever of A/T shift selector and control rod.
2. Remove manual lever from A/T.
3. Remove control rod from vehicle.



# SHIFT CONTROL SYSTEM

## < SERVICE INFORMATION >

### INSTALLATION


Note the following, and install in the reverse order of removal.

- After installation is completed, adjust and check A/T position. Refer to [AT-195. "Adjustment of A/T Position"](#) and [AT-195. "Checking of A/T Position"](#).

### Adjustment of A/T Position

INFOID:000000004657011


1. Loosen nut of control rod.
2. Place transmission range switch and selector lever in "P" position.
3. While pressing lower lever toward rear of vehicle (in "P" position direction), tighten nut to the specified torque. Refer to [AT-194. "Control Rod Removal and Installation"](#)



### Checking of A/T Position

INFOID:000000004657012

1. Place selector lever in "P" position, and turn ignition switch ON.
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check whether or not the actual position the selector lever is in matches the position shown by the shift position indicator and the transmission body.
5. The method of operating the lever to individual positions correctly should be as shown in the figure.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when lever is placed in the "R" position. Confirm the back-up lamps does not illuminate when selector lever is pushed against "R" position in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions. (With selector lever in the "P" position, engine can be started even when selector lever is moved forward and backward.)
9. Make sure that transmission is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.  
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



# A/T SHIFT LOCK SYSTEM

< SERVICE INFORMATION >

## A/T SHIFT LOCK SYSTEM


### Description

INFOID:000000004657013

- The mechanical key interlock mechanism also operates as a shift lock:  
With the ignition switch turned to ON, the selector lever cannot be shifted from "P" position to any other position unless the brake pedal is depressed.  
With the key removed, the selector lever cannot be shifted from "P" position to any other position.  
The key cannot be removed unless the selector lever is placed in "P" position.
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder.

### Shift Lock System Electrical Parts Location

INFOID:000000004657014




- |   |                                      |                         |
|---|--------------------------------------|-------------------------|
| 1. A/T shift selector harness connector | 2. Key inter lock cable              | 3. Shift lock solenoid  |
| 4. Shift lock relay                     | 5. Stop lamp switch                  | 6. Brake pedal          |
| A. A/T shift selector assembly          | B. Shift lock solenoid, reverse side | C. Park position switch |
| D. Fuse, fusible link and relay box     | E. Brake pedal, upper                | F. A/T console finisher |
| G. Shift lock release button            |                                      |                         |

# A/T SHIFT LOCK SYSTEM

< SERVICE INFORMATION >

## Wiring Diagram - AT - SHIFT


INFOID:000000004657015



AT-SHIFT-01

REFER TO PG-POWER.

- ⬠NT⬠ : WITH VDC SYSTEM, NAVIGATION SYSTEM OR TELEPHONE
- ⬠OT⬠ : WITHOUT VDC SYSTEM, NAVIGATION SYSTEM AND TELEPHONE



TCW70443E

## Diagnosis Procedure

INFOID:000000004657016

### SYMPTOM 1:

- Selector lever cannot be moved from “P” position with key in ON position and brake pedal applied.
- Selector lever can be moved from “P” position with key in ON position and brake pedal released.
- Selector lever can be moved from “P” position when key is removed from key cylinder.

### SYMPTOM 2:

# A/T SHIFT LOCK SYSTEM

## < SERVICE INFORMATION >

- Ignition key cannot be removed when selector lever is set to “P” position.
- Ignition key can be removed when selector lever is set to any position except “P” position.

### 1. CHECK KEY INTERLOCK CABLE

Check the key interlock cable for damage.

#### OK or NG

- OK >> GO TO 2.
- NG >> Replace key interlock cable. Refer to [AT-201](#).

### 2. CHECK SELECTOR LEVER POSITION

Check the selector lever position for damage. Refer to [AT-195, "Checking of A/T Position"](#).

#### OK or NG

- OK >> GO TO 3.
- NG >> Check selector lever. Refer to [AT-195, "Adjustment of A/T Position"](#).

### 3. CHECK POWER SOURCE

1. Turn ignition switch OFF.
2. Disconnect shift lock relay.
3. Check voltage between shift lock relay E19 terminal 2 and ground.


#### Voltage

Brake pedal depressed: **Battery voltage**

Brake pedal released: **0 V**

#### OK or NG


- OK >> GO TO 5.
- NG >> GO TO 4.



### 4. DETECT MALFUNCTIONING ITEM

Check the following.

- Harness for short or open between battery and stop lamp switch harness connector E111 terminal 3.
- Harness for short or open between stop lamp switch harness connector E111 terminal 4 and shift lock relay E19 terminal 2.
- 10 A fuse [No. 20, located in the fuse block (J/B)].
- Stop lamp switch.
- Check continuity between stop lamp switch harness connector E111 terminals 3 and 4.



Check stop lamp switch after adjusting brake pedal — refer to [BR-7](#).

#### OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

### 5. CHECK GROUND CIRCUIT

# A/T SHIFT LOCK SYSTEM

## < SERVICE INFORMATION >

1. Turn ignition switch OFF.
2. Disconnect shift lock relay.
3. Check continuity between shift lock relay E19 terminal 1 and ground.

**CAUTION:**

Connect test probe (BLACK) to shift lock relay, and test probe (RED) to ground.


**Continuity should exist.**

If OK, check harness for short to ground and short to power.

**OK or NG**

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 6. CHECK INPUT SIGNAL A/T SHIFT SELECTOR

1. Turn ignition switch ON.
2. A/T shift selector is set in "P" position.
3. Check voltage between A/T shift selector harness connector M47 terminal 1 and ground.

**Voltage**


**Brake pedal depressed: Battery voltage**

**Brake pedal released: 0 V**

**OK or NG**

OK >> GO TO 8.

NG >> GO TO 7.



## 7. DETECT MALFUNCTIONING ITEM

Check the following.


- Harness for short or open between ignition switch and shift lock relay E19 terminal 5.
- Harness for short or open between shift lock relay E19 terminal 3 and A/T shift selector harness connector M47 terminal 1.
- 10 A fuse [No. 12, located in the fuse block (J/B)].
- Ignition switch (Refer to [PG-4](#)).
- Shift lock relay.
- Check continuity between shift lock relay E19 terminal 3 and 5.

| Condition  | Continuity |
|--|------------|
| 12V direct current supply between terminal 1 and 2 | Yes        |
| OFF  | No         |

**OK or NG**

OK >> GO TO 8.

NG >> Repair or replace damaged parts.



## 8. CHECK GROUND CIRCUIT

# A/T SHIFT LOCK SYSTEM

## < SERVICE INFORMATION >

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector harness connector.
3. Check continuity between A/T shift selector harness connector M47 terminal 2 and ground.


**Continuity should exist.**

If OK, check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



## 9. CHECK SHIFT LOCK SOLENOID AND PARK POSITION SWITCH

1. Connect A/T shift selector harness connector.
2. Turn ignition switch ON.
3. Selector lever is set in "P" position.
4. Check operation.

| Condition  | Brake pedal | Operation |
|--|-------------|-----------|
| When ignition switch is turned to "ON" position and selector lever is set in "P" position. | Depressed   | Yes       |
|  | Released    | No        |

### OK or NG

OK >> **INSPECTION END.**

NG >> Repair or replace damaged parts.




# KEY INTERLOCK CABLE

< SERVICE INFORMATION >

## KEY INTERLOCK CABLE

### Component

INFOID:000000004657017



### CAUTION:


- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.

### Removal and Installation

INFOID:000000004657018

#### REMOVAL

1. Unlock slider by squeezing lock tabs on slider from adjuster holder.
2. Remove casing cap from bracket of A/T shift selector assembly and remove interlock rod from adjuster holder.



A

B

AT

D

E

F

G

H

I

J

K

L

M

N


O

P

# KEY INTERLOCK CABLE


## < SERVICE INFORMATION >

3. Remove lock plate from key cylinder.
4. Remove holder from key cylinder and remove key interlock cable.



## INSTALLATION

1. Set holder of key interlock cable to key cylinder and install lock plate.  
**CAUTION:**  
**Do not reuse the lock plate**
2. Clamp key interlock cable and fix to key interlock cable with band.
3. Turn ignition key to lock position.
4. Set selector lever to "P" position.




## KEY INTERLOCK CABLE

### < SERVICE INFORMATION >

5. Insert interlock rod into adjuster holder.
6. Install casing cap to bracket.
7. Move slider in order to fix adjuster holder to interlock rod.

**CAUTION:**

**Do not touch any parts except slider. Do not add any force to slider except force toward slider.**



A

B

AT

D

E

F

G

H

I

J

K

L

M

N

O

P

# ON-VEHICLE SERVICE


< SERVICE INFORMATION >

## ON-VEHICLE SERVICE

### Control Valve with TCM and A/T Fluid Temperature Sensor 2

INFOID:000000004657019

#### COMPONENTS



- |                                   |                           |                            |
|-----------------------------------|---------------------------|----------------------------|
| 1. A/T                            | 2. Snap ring              | 3. Sub-harness             |
| 4. Bracket                        | 5. Control valve with TCM | 6. Bracket                 |
| 7. A/T fluid temperature sensor 2 | 8. Oil pan gasket         | 9. Clip                    |
| 10. Oil pan mounting bolt         | 11. Oil pan               | 12. Magnet                 |
| 13. Drain plug                    | 14. Drain plug gasket     | 15. Terminal cord assembly |
| 16. O-ring                        |                           |                            |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

#### CONTROL VALVE WITH TCM ASSEMBLY REMOVAL AND INSTALLATION


##### Removal

1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain hole.
3. Remove exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


4. Disconnect heated oxygen sensor 2 harness connectors (A).
  - ↶: Vehicle front
  - ⬅: Bolt
5. Remove heated oxygen sensor 2 harness (B) from clips (1).
6. Remove bracket (2) from transmission assembly.
7. Disconnect A/T assembly harness connector.




8. Remove snap ring from A/T assembly harness connector.




9. Push A/T assembly harness connector.  
**CAUTION:**  
**Be careful not to damage connector.**



10. Remove clips (1), oil pan (2) and oil pan gasket.
  - ↶: Vehicle front
  - ⬅: Oil pan mounting bolt
  - Drain bolt (3)



11. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.
  - If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

12. Remove magnets from oil pan.




13. Disconnect A/T fluid temperature sensor 2 connector (A).

**CAUTION:**

**Be careful not to damage connector.**

14. Straighten terminal clips (←) to free terminal cord assembly and A/T fluid temperature sensor 2 harness.




15. Straighten terminal clip (←) to free output speed sensor harness.

16. Disconnect output speed sensor connector (1).

**CAUTION:**


**Be careful not to damage connector.**



17. Remove bolts (A), (B) and (C) from control valve with TCM.

• ←: Vehicle front


| Bolt symbol | Length (in) | Number of bolts |
|-------------|-------------|-----------------|
| A           | 42 (1.65)   | 5               |
| B           | 55 (2.17)   | 6               |
| C           | 40 (1.57)   | 1               |



18. Remove control valve with TCM from transmission case.

**CAUTION:**


**When removing, be careful with the manual valve notch and manual plate height. Remove it vertically.**




# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


19. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.



20. Remove bracket from A/T fluid temperature sensor 2.




21. Remove O-ring from A/T assembly harness connector.




22. Disconnect TCM connectors.

**CAUTION:**  
Be careful not to damage connectors.



23. Remove A/T assembly harness connector from control valve with TCM using a flat-bladed screwdriver.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

24. Disconnect TCM connector (1) and transmission range switch connector (2).

**CAUTION:**

**Be careful not to damage connectors.**




### Installation


**CAUTION:**

**After completing installation, check A/T fluid leakage and A/T fluid level. Refer to [AT-12. "Checking A/T Fluid"](#).**


1. Connect TCM connector (1) and transmission range switch connector (2).



2. Install A/T assembly harness connector from control valve with TCM.



3. Connect TCM connectors.






# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


4. Install O-ring in A/T assembly harness connector.

**CAUTION:**

- Do not reuse O-ring.
- Apply ATF to O-ring.




5. Install A/T fluid temperature sensor 2 to bracket.



6. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM, and then tighten A/T fluid temperature sensor 2 bolt to the specified torque. Refer to "COMPONENTS".

**CAUTION:**

Adjust bolt hole of bracket to bolt hole of control valve with TCM.




7. Install control valve with TCM in transmission case.

**CAUTION:**


- Make sure that input speed sensor securely installs input speed sensor hole (B).

A : Brake band

- Hang down output speed sensor harness toward outside so as not to disturb installation of control valve with TCM.
- Adjust A/T assembly harness connector of control valve with TCM to terminal hole of transmission case.



- Assemble it so that manual valve cutout is engaged with manual plate projection.



A  
B  
AT

D  
E  
F  
G

H  
I  
J  
K

L  
M  
N  
O


P

# ON-VEHICLE SERVICE


## < SERVICE INFORMATION >

8. Install bolts (A), (B) and (C) in control valve with TCM.  
 • ⇐: Vehicle front


| Bolt symbol | Length mm (in) | Number of bolts |
|-------------|----------------|-----------------|
| A           | 42 (1.65)      | 5               |
| B           | 55 (2.17)      | 6               |
| C           | 40 (1.57)      | 1               |




9. Tighten bolt 1, 2 and 3 temporarily to prevent dislocation. After that tighten them in order (1 → 2 → 3), and then tighten other bolts, and then tighten control valve with TCM mounting bolts to the specified torque. Refer to "COMPONENTS".  
 • ⇐: Vehicle front




10. Connect A/T fluid temperature sensor 2 connector (A).  
 11. Securely fasten terminal cord assembly and A/T fluid temperature sensor 2 harness with terminal clips (⇐).



12. Connect output speed sensor connector (1).




13. Securely fasten output speed sensor (1) harness with terminal clip.



# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

14. Install magnets in oil pan.



15. Install oil pan to transmission case.

a. Install oil pan gasket to oil pan.

**CAUTION:**


- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.

b. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

- ←: Vehicle front
- ←: Oil pan mounting bolt

**CAUTION:**

- Install it so that drain plug (3) comes to the position as shown in the figure.
- Be careful not to pinch harness.
- Complete remove all moisture, oil and old gasket, etc. from oil pan mounting surface.



c. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to "COMPONENTS".


**CAUTION:**

**Do not reuse oil pan mounting bolts.**

16. Install drain plug gasket and drain plug to oil pan, and then tighten drain plug to the specified torque. Refer to "COMPONENTS".

**CAUTION:**


**Do not reuse drain plug gasket.**



17. Pull up A/T assembly harness connector.

**CAUTION:**

**Be careful not to damage connector.**




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

18. Install snap ring to A/T assembly harness connector.
19. Connect A/T assembly harness connector.




20. Install bracket (2) from transmission assembly. Refer to "COMPONENTS".
  - ⇐: Vehicle front
  - ←: Bolt
21. Install heated oxygen sensor 2 harness (B) from clips (1).
22. Connect heated oxygen sensor 2 harness connectors (A).
23. Install exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).
24. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).
25. Connect the battery cable to the negative terminal.




## A/T FLUID TEMPERATURE SENSOR 2 REMOVAL AND INSTALLATION

### Removal

1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain hole.
3. Remove exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).
4. Disconnect heated oxygen sensor 2 harness connectors (A).
  - ⇐: Vehicle front
  - ←: Bolt
5. Remove heated oxygen sensor 2 harness (B) from clips (1).
6. Remove bracket (2) from transmission assembly.




7. Remove clips (1), oil pan (2) and oil pan gasket.
  - ⇐: Vehicle front
  - ←: Oil pan mounting bolt
  - Drain plug (3)




# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


8. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.
- If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).




9. Disconnect A/T fluid temperature sensor 2 connector (1).  
**CAUTION:**  
**Be careful not to damage connector.**
10. Straighten terminal clip (←) to free A/T fluid temperature sensor 2 harness.



11. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.



12. Remove bracket from A/T fluid temperature sensor 2.



### Installation

#### **CAUTION:**


After completing installation, check A/T fluid leakage and A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


1. Install A/T fluid temperature sensor 2 to bracket.



2. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM, and then tighten A/T fluid temperature sensor 2 bolt to the specified torque. Refer to "COMPONENTS".



3. Connect A/T fluid temperature sensor 2 connector (1).
4. Securely fasten A/T fluid temperature sensor 2 harness with terminal clip (◀).



5. Install oil pan to transmission case.

- a. Install oil pan gasket to oil pan.

**CAUTION:**


- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.

- b. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

- ◀: Vehicle front
- ◀: Oil pan mounting bolt

**CAUTION:**

- Install it so that drain plug (3) comes to the position as shown in the figure.
- Be careful not to pinch harness.
- Complete remove all moisture, oil and old gasket, etc. from oil pan mounting surface.



# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

- c. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to "COMPONENTS".


**CAUTION:**

**Do not reuse oil pan mounting bolts.**

6. Install drain plug gasket and drain plug to oil pan, and then tighten drain plug to the specified torque. Refer to "COMPONENTS".

**CAUTION:**


**Do not reuse drain plug gasket.**



7. Install bracket (2) from transmission assembly. Refer to "COMPONENTS".

- ←: Vehicle front
- ⬅: Bolt


8. Install heated oxygen sensor 2 harness (B) from clips (1).
9. Connect heated oxygen sensor 2 harness connectors (A).
10. Install exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).
11. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).
12. Connect the battery cable to the negative terminal.



## Parking Component

INFOID:000000004657020

## COMPONENTS





# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

- |                      |                   |                             |
|----------------------|-------------------|-----------------------------|
| 1. Rear oil seal     | 2. Rear extension | 3. Parking actuator support |
| 4. Return spring     | 5. Parking pawl   | 6. Pawl shaft               |
| 7. Self-sealing bolt | 8. Seal ring      | 9. Parking gear             |
| 10. Output shaft     | 11. Bearing race  | 12. Needle bearing          |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

However, refer to the following for others.

 : Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42, "Recommended Chemical Product and Sealant"](#).

## REMOVAL

1. Drain ATF through drain hole.
2. Remove exhaust front tube and center muffler with power tool. Refer to [EX-3, "Removal and Installation"](#).
3. Remove rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).

### CAUTION:


**Do not impact or damage propeller shaft tube.**

4. Remove control rod. Refer to [AT-194, "Control Rod Removal and Installation"](#).
5. Support A/T assembly with a transmission jack.


### CAUTION:

**When setting transmission jack, be careful not to allow it to collide against drain plug.**


6. Remove rear engine mounting member with power tool. Refer to [AT-229, "Removal and Installation"](#).
7. Remove tightening bolts for rear extension assembly and transmission case.



8. Tap rear extension assembly with soft hammer.



9. Remove rear extension assembly from transmission case. (With needle bearing.)







# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


10. Remove bearing race from output shaft.




11. Remove output shaft from transmission case by rotating left/right.




12. Remove parking gear from output shaft.



13. Remove seal rings from output shaft.



14. Remove needle bearing (1) from rear extension.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


## ON-VEHICLE SERVICE

### < SERVICE INFORMATION >


15. Remove parking actuator support from rear extension.




16. Remove parking pawl (with return spring) and pawl shaft from rear extension.



17. Remove return spring (1) from parking pawl (2).



18. Remove rear oil seal from rear extension.  
**CAUTION:**  
**Be careful not to scratch rear extension.**





### INSPECTION

# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

- If the contact surface on parking actuator support, parking pawl, etc. has excessive wear, abrasion, bend, or any other damage, replace the components.



## INSTALLATION


### CAUTION:

After completing installation, check A/T position, A/T fluid leakage and A/T fluid level. Refer to [AT-195](#), "[Checking of A/T Position](#)", [AT-12](#), "[Checking A/T Fluid](#)".


1. As shown in the figure, use a drift to drive rear oil seal into the rear extension until it is flush.

### CAUTION:

- Do not reuse rear oil seal.
- Apply ATF to rear oil seal.



2. Install return spring (1) to parking pawl (2).




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

3. Install parking pawl (with return spring) and pawl shaft to rear extension.




4. Install parking actuator support to rear extension.



5. Install needle bearing (1) to rear extension.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




6. Install seal rings in output shaft.

**CAUTION:**

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




7. Install parking gear to output shaft.




# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

8. Install output shaft to transmission case.




9. Install bearing race to output shaft.




10. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42. "Recommended Chemical Product and Sealant"](#).) to rear extension assembly as shown in the figure.

**CAUTION:**  
 Completely remove all moisture, oil and old sealant, etc. from transmission case and rear extension assembly mounting surfaces.




11. Install rear extension assembly to transmission case. (With needle bearing.)

**CAUTION:**  
 Insert the tip of parking rod between parking pawl and parking actuator support when assembling rear extension assembly.



12. Tighten rear extension assembly mounting bolts to the specified torque. Refer to "COMPONENTS".

**CAUTION:**  
 Do not reuse self-sealing bolts.



# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


13. Install rear engine mounting member. Refer to [AT-229, "Removal and Installation"](#).
14. Install control rod. Refer to [AT-194, "Control Rod Removal and Installation"](#).
15. Install rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).  
**CAUTION:**  
**Do not impact or damage propeller shaft tube.**
16. Install exhaust front tube and center muffler. Refer to [EX-3, "Removal and Installation"](#).
17. Install drain plug gasket and drain plug to oil pan, and then tighten drain plug to the specified torque. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).  
**CAUTION:**  
**Do not reuse drain plug gasket.**
18. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).

## Rear Oil Seal

INFOID:000000004657021

### REMOVAL


1. Remove exhaust front tube and center muffler with power tool. Refer to [EX-3, "Removal and Installation"](#).
2. Remove rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).  
**CAUTION:**  
**Do not impact or damage propeller shaft tube.**
3. Remove rear oil seal using a flat-bladed screwdriver.  
**CAUTION:**  
**Be careful not to scratch rear extension assembly.**



### INSTALLATION

**CAUTION:**  
After completing installation, check A/T fluid leakage and A/T fluid level. Refer to [AT-12, "Checking A/T Fluid"](#).

1. As shown in the figure, use the drift to drive rear oil seal into rear extension assembly until it is flush.  
**CAUTION:**
  - Do not reuse rear oil seal.
  - Apply ATF to rear oil seal.
2. Install rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).  
**CAUTION:**  
**Do not impact or damage propeller shaft tube.**
3. Install exhaust front tube and center muffler. Refer to [EX-3, "Removal and Installation"](#).




## Output Speed Sensor

INFOID:000000004657022

### COMPONENTS

# ON-VEHICLE SERVICE

< SERVICE INFORMATION >



- |                         |                       |                          |
|-------------------------|-----------------------|--------------------------|
| 1. Rear extension       | 2. A/T                | 3. Bracket               |
| 4. Oil pan gasket       | 5. Clip               | 6. Oil pan mounting bolt |
| 7. Oil pan              | 8. Drain plug         | 9. Drain plug gasket     |
| 10. Output speed sensor | 11. Self-sealing bolt |                          |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

However, refer to the following for others.

 : Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42, "Recommended Chemical Product and Sealant"](#).


## REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain hole.
3. Remove exhaust front tube and center muffler with power tool. Refer to [EX-3, "Removal and Installation"](#).
4. Remove rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).  
**CAUTION:**  
**Do not impact or damage propeller shaft tube.**
5. Remove control rod. Refer to [AT-194, "Control Rod Removal and Installation"](#).
6. Remove exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).


## ON-VEHICLE SERVICE

### < SERVICE INFORMATION >


7. Disconnect heated oxygen sensor 2 harness connectors (A).
  - ⇐: Vehicle front
  - ←: Bolt
8. Remove heated oxygen sensor 2 harness (B) from clips (1).
9. Remove bracket (2) from transmission assembly.



10. Remove clip (1), oil pan (2) and oil pan gasket.
  - ⇐: Vehicle front
  - ←: Oil pan mounting bolt
  - ●: Drain plug (3)



11. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.
  - **If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14. "A/T Fluid Cooler Cleaning"](#).**




12. Support transmission assembly with a transmission jack.

**CAUTION:**

**When setting transmission jack, place wooden blocks to prevent from damaging control valve with TCM and transmission case.**

13. Remove rear engine mounting member with power tool. Refer to [AT-229. "Removal and Installation"](#).
14. Remove tightening bolts for rear extension assembly and transmission case.







# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

15. Tap rear extension assembly with soft hammer.



16. Remove rear extension assembly from transmission case. (With needle bearing.)




17. Straighten terminal clip (←) to free output speed sensor harness,

18. Disconnect output speed sensor connector (1).

**CAUTION:**

**Be careful not to damage connector.**




19. Remove output speed sensor (1) from transmission case.

← :Bolt

**CAUTION:**

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc. to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.



## INSTALLATION

**CAUTION:**

After completing installation, check A/T position, A/T fluid leakage and A/T fluid level. Refer to [AT-195, "Checking of A/T Position"](#), [AT-12, "Checking A/T Fluid"](#).

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >


1. Install output speed sensor (1) in transmission case, Tighten a necessary bolt (←) for output speed sensor with specified torque. Refer to "COMPONENTS".

**CAUTION:**


- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc. to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.



2. Connect output speed sensor connector (1).




3. Securely fasten output speed sensor (1) harness with clip (←).



4. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42, "Recommended Chemical Product and Sealant"](#).) to rear extension assembly as shown in illustration.

**CAUTION:**


Completely remove all moisture, oil and old sealant, etc. from transmission case and rear extension assembly mounting surfaces.



5. Install rear extension assembly to transmission case. (With needle bearing.)

**CAUTION:**

Insert the tip of parking rod between parking pawl and parking actuator support when assembling rear extension assembly.



# ON-VEHICLE SERVICE

## < SERVICE INFORMATION >

6. Tighten rear extension assembly mounting bolts to the specified torque. Refer to "COMPONENTS".

**CAUTION:**

**Do not reuse self-sealing bolts.**

7. Install rear engine mounting member. Refer to [AT-229, "Removal and Installation"](#).

8. Install oil pan to transmission case.

- a. Install oil pan gasket to oil pan.

**CAUTION:**


- **Do not reuse oil pan gasket.**
- **Install it in the direction to align hole positions.**
- **Completely remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.**

- b. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.


- : Vehicle front
- : Oil pan mounting bolt

**CAUTION:**

- **Install it so that drain plug (3) comes to the position as shown in the figure.**
- **Be careful not to pinch harness.**
- **Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.**



SCIA6941E



SCIA8117E

- c. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to "COMPONENTS".


**CAUTION:**

**Do not reuse oil pan mounting bolts.**

9. Install drain plug gasket and drain plug to oil pan, and then tighten drain plug to the specified torque. Refer to "COMPONENTS".

**CAUTION:**

**Do not reuse drain plug gasket.**



SCIA4113E

10. Install bracket (2) from transmission assembly. Refer to [AT-204, "Control Valve with TCM and A/T Fluid Temperature Sensor 2"](#).

- : Vehicle front
- : Bolt

11. Install heated oxygen sensor 2 harness (B) from clips (1).

12. Connect heated oxygen sensor 2 harness connectors (A).

13. Install exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).

14. Install control rod. Refer to [AT-194, "Control Rod Removal and Installation"](#).

15. Install rear propeller shaft. Refer to [PR-6, "Removal and Installation"](#).


**CAUTION:**

**Do not impact or damage propeller shaft tube.**

16. Install exhaust front tube and center muffler. Refer to [EX-3, "Removal and Installation"](#).

17. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).

18. Connect the battery cable to the negative terminal.



SCIA8269E

# AIR BREATHER HOSE


< SERVICE INFORMATION >

## AIR BREATHER HOSE

### Removal and Installation

INFOID:000000004657023


Refer to the figure below for air breather hose removal and installation procedure.



- |                      |                            |         |
|----------------------|----------------------------|---------|
| 1. Air breather box  | 2. Air breather hose       | 3. Clip |
| 4. Clip              | 5. A/T fluid charging pipe |         |
| A. Air breather tube |                            |         |

#### CAUTION:

- When installing an air breather hose, do not to crush or block by folding or bending the hose.
- When inserting air breather hose to air breather tube, be sure to insert it fully until its end reaches the tube bend R portion.
- Install A/T air breather hose to air breather tube so that the paint mark is facing upward.
- Ensure clips are securely installed to brackets when installing A/T breather hose to brackets.
- When inserting air breather hose to air breather box, be sure to insert it fully until its end reaches the stop.
- Install A/T air breather hose to air breather box so that the paint mark is facing backward.
- Install clip (1) at the paint mark (A).
- Air breather hose (2)
- Harness (3)




# TRANSMISSION ASSEMBLY

< SERVICE INFORMATION >

## TRANSMISSION ASSEMBLY

### Removal and Installation

INFOID:000000004657024



- |                             |                                     |                                |
|-----------------------------|-------------------------------------|--------------------------------|
| 1. O-ring                   | 2. Engine mounting insulator (rear) | 3. Rear engine mounting member |
| 4. Copper washer            | 5. Fluid cooler tube                | 6. Bracket                     |
| 7. Bracket                  | 8. Bracket                          | 9. A/T assembly                |
| 10. A/T fluid charging pipe | 11. A/T fluid level gauge           |                                |

A. For tightening torque, refer to "INSTALLATION".

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

### REMOVAL



#### CAUTION:


- When removing A/T assembly from engine assembly, first remove crankshaft position sensor (POS) from A/T assembly.
- Be careful not to damage sensor edge.

1. Disconnect the battery cable from the negative terminal.
2. Remove tower bar with power tool. Refer to [FSU-18, "Removal and Installation"](#).
3. Remove engine under covers with power tool.
4. Remove exhaust mounting bracket. Refer to [EX-3, "Removal and Installation"](#).

# TRANSMISSION ASSEMBLY

## < SERVICE INFORMATION >

5. Disconnect heated oxygen sensor 2 harness connectors (A).
  - : Vehicle front
  - : Bolt
6. Remove heated oxygen sensor 2 harness (B) from clips (1).
7. Remove bracket (2) from transmission assembly.
8. Remove front cross bar with power tool. Refer to [FSU-7. "Component"](#).
9. Remove exhaust front tube and center muffler with power tool. Refer to [EX-3. "Removal and Installation"](#).
10. Remove three way catalyst (right bank) and three way catalyst (left bank). Refer to [EM-23. "Removal and Installation"](#).
11. Remove crankshaft position sensor (POS) (1). Refer to [EM-27. "Removal and Installation"](#).




- Three way catalyst (right bank) (2)

### CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc. to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.

12. Remove rear propeller shaft. Refer to [PR-6. "Removal and Installation"](#).



### CAUTION:

**Do not impact, or damage propeller shaft tube.**

13. Remove control rod. Refer to [AT-194. "Control Rod Removal and Installation"](#).

14. Disconnect the following:

- A/T assembly harness connector
- S terminal connector (A)
- EPS solenoid valve harness connector (B)

15. Remove starter motor with power tool. Refer to [SC-14. "Removal and Installation"](#).

16. Remove A/T fluid level gauge.

17. Remove A/T fluid charging pipe

18. Remove O-ring from A/T fluid charging pipe.

19. Remove fluid cooler tube according to the following procedure.

- a. Remove mounting nuts of the engine mounting insulator (LH) and engine mounting insulator (RH) on the undersurface of the vehicle. Refer to [EM-101. "Removal and Installation"](#).

- b. Push engine assembly upward from the vehicle with transmission jack to create clearance for removing fluid cooler tube.

### CAUTION:

**Be careful with hoses and harness when pushing up the engine assembly.**

- c. Remove fluid cooler tube.

20. Plug up openings such as A/T fluid charging pipe hole, etc.

21. Remove rear plate cover from converter housing. Refer to [EM-27. "Removal and Installation"](#).

22. Turn crankshaft, and remove the four tightening bolts for drive plate and torque converter.

### CAUTION:

**When turning crankshaft, turn it clockwise as viewed from the front of the engine.**

23. Support A/T assembly with a transmission jack.


### CAUTION:

**When setting the transmission jack, be careful not to allow it to collide against the drain plug.**

24. Remove rear engine mounting member with power tool. Refer to "Removal and Installation".

25. Remove engine mounting insulator (rear) with power tool. Refer to "Removal and Installation".

26. Remove bolts fixing A/T assembly to engine assembly with power tool.






# TRANSMISSION ASSEMBLY

## < SERVICE INFORMATION >

27. Remove A/T assembly from vehicle with a transmission jack.
  - **Secure torque converter to prevent it from dropping.**
  - **Secure A/T assembly to a transmission jack.**
28. Remove air breather hose. Refer to [AT-228, "Removal and Installation"](#).




## INSPECTION

### Installation and Inspection of Torque Converter

- After inserting a torque converter to a A/T, be sure to check distance "A" to ensure it is within the reference value limit.

**Distance "A": 25.0 mm (0.98 in) or more**




## INSTALLATION

Install the removed parts in the reverse order of the removal, while paying attention to the following work.

- When installing A/T assembly to the engine assembly, attach the fixing bolts in accordance with the following standard.
  - ⊗: Engine to transmission
  - ⊙: Transmission to engine

| Bolt symbol                         | A            | B              |
|-------------------------------------|--------------|----------------|
| Number of bolts                     | 8            | 4              |
| Bolt length mm (in)                 | 65 (2.56)    | 35 (1.38)      |
| Tightening torque N·m (kg·m, ft·lb) | 75 (7.7, 55) | 46.6 (4.8, 34) |




- Align the positions of tightening bolts for drive plate with those of the torque converter, and temporarily tighten the bolts. Then tighten the bolts with the specified torque.

 : 51 N·m (5.2 kg·m, 38 ft·lb)

### CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening bolts for torque converter after fixing crankshaft pulley bolts, be sure to confirm the tightening torque of crankshaft pulley mounting bolts. Refer to [EM-53](#).
- After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.
- Install crankshaft position sensor (POS). Refer to [EM-27, "Removal and Installation"](#).
- After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-12, "Checking A/T Fluid"](#), [AT-195, "Checking of A/T Position"](#).




# OVERHAUL

< SERVICE INFORMATION >

## OVERHAUL

Component

INFOID:000000004657025



JPDIA0556GB

- |                      |                              |                     |
|----------------------|------------------------------|---------------------|
| 1. O-ring            | 2. Oil pump cover            | 3. O-ring           |
| 4. Oil pump housing  | 5. Self-sealing bolt         | 6. Torque converter |
| 7. Converter housing | 8. Oil pump housing oil seal | 9. Bearing race     |




# OVERHAUL

## < SERVICE INFORMATION >

- |                           |                        |                                     |
|---------------------------|------------------------|-------------------------------------|
| 10. Needle bearing        | 11. O-ring             | 12. Front carrier assembly          |
| 13. Needle bearing        | 14. Snap ring          | 15. Front sun gear                  |
| 16. 3rd one-way clutch    | 17. Snap ring          | 18. Bearing race                    |
| 19. Needle bearing        | 20. Seal ring          | 21. Input clutch assembly           |
| 22. Needle bearing        | 23. Rear internal gear | 24. Brake band                      |
| 25. Mid carrier assembly  | 26. Needle bearing     | 27. Bearing race                    |
| 28. Rear carrier assembly | 29. Needle bearing     | 30. Mid sun gear                    |
| 31. Seal ring             | 32. Rear sun gear      | 33. 1st one-way clutch              |
| 34. Snap ring             | 35. Needle bearing     | 36. High and low reverse clutch hub |
| 37. Snap ring             | 38. Bearing race       | 39. Needle bearing                  |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8. "Component"](#).

However, refer to the following for others.

 : Apply Genuine RTV silicone sealant or equivalent. Refer to [GI-42. "Recommended Chemical Product and Sealant"](#).

A

B

AT

D

E

F

G

H

I

J

K

L

M


N

O

P

# OVERHAUL

< SERVICE INFORMATION >



- |                               |                                   |   |
|-------------------------------|-----------------------------------|---|
| 1. Needle bearing             | 2. Bearing race                   | 3. High and low reverse clutch assembly |
| 4. Needle bearing             | 5. Direct clutch assembly         | 6. Reverse brake dish plate             |
| 7. Reverse brake dish plate   | 8. Reverse brake driven plate     | 9. N-spring                             |
| 10. Reverse brake drive plate | 11. Reverse brake retaining plate | 12. Snap ring                           |
| 13. D-ring                    | 14. D-ring                        | 15. Reverse brake piston                |

# OVERHAUL


## < SERVICE INFORMATION >

16. Return spring

17. Spring retainer

18. Snap ring

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).



- 1. Self-sealing bolt
- 4. Parking pawl
- 7. Rear oil seal
- 10. Output speed sensor

- 2. Rear extension
- 5. Return spring
- 8. Seal ring
- 11. Parking gear

- 3. Parking actuator support
- 6. Pawl shaft
- 9. Needle bearing
- 12. Output shaft

# OVERHAUL

## < SERVICE INFORMATION >

---

- |                            |                                    |                            |
|----------------------------|------------------------------------|----------------------------|
| 13. Bearing race           | 14. Needle bearing                 | 15. Manual plate           |
| 16. Parking rod            | 17. Manual shaft oil seal          | 18. Manual shaft           |
| 19. O-ring                 | 20. Band servo anchor end pin      | 21. Detent spring          |
| 22. Spacer                 | 23. Seal ring                      | 24. Snap ring              |
| 25. Return spring          | 26. O-ring                         | 27. Servo assembly         |
| 28. Snap ring              | 29. Sub-harness                    | 30. Control valve with TCM |
| 31. Bracket                | 32. A/T fluid temperature sensor 2 | 33. Clip                   |
| 34. Oil pan mounting bolt  | 35. Oil pan                        | 36. Magnet                 |
| 37. Drain plug             | 38. Drain plug gasket              | 39. Oil pan gasket         |
| 40. Terminal cord assembly | 41. O-ring                         | 42. Retaining pin          |
| 43. Transmission case      |                                    |                            |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

However, refer to the following for others.



: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42, "Recommended Chemical Product and Sealant"](#).


# OVERHAUL

< SERVICE INFORMATION >

## Oil Channel

INFOID:000000004657026

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# OVERHAUL

< SERVICE INFORMATION >

## Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings

INFOID:000000004657027



| Snap ring   |                        | Needle bearing |                        |
|-------------|------------------------|----------------|------------------------|
| Item number | Outer diameter mm (in) | Item number    | Outer diameter mm (in) |
| 1           | 67.5 (2.657)           | 10             | 80 (3.15)              |
| 2           | 182.4 (7.181)          | 11             | 77 (3.03)              |
| 3           | 171.5 (6.751)          | 12             | 77 (3.03)              |
| 4           | 70.5 (2.775)           | 13             | 47 (1.85)              |
| 5           | 169 (6.653)            | 14             | 84 (3.31)              |
| 6           | 134.3 (5.287)          | 15             | 84 (3.31)              |
| 7           | 180.5 (7.106)          | 16             | 92 (3.62)              |
| 8           | 181 (7.125)            | 17             | 60 (2.36)              |
| 9           | 48.4 (1.905)           | 18             | 63 (2.48)              |
| —           | —                      | 19             | 92 (3.62)              |
| —           | —                      | 20             | 65 (2.56)              |
| —           | —                      | 21             | 60 (2.36)              |

# DISASSEMBLY

< SERVICE INFORMATION >

## DISASSEMBLY


### Disassembly

INFOID:000000004657028


#### CAUTION:

Do not disassemble parts behind Drum Support. Refer to [AT-17, "Cross-Sectional View"](#).


1. Drain ATF through drain hole.
2. Remove torque converter by holding it firmly and turning while pulling straight out.



3. Check torque converter one-way clutch using check tool as shown at figure.
  - a. Insert check tool into the groove of bearing support built into one-way clutch outer race.
  - b. When fixing bearing support with check tool, rotate one-way clutch spline using screwdriver.
  - c. Check that inner race rotates clockwise only. If not, replace torque converter assembly.



4. Remove tightening bolts (←) for converter housing and transmission case.
5. Remove converter housing from transmission case.  
**CAUTION:**  
Be careful not to scratch converter housing.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# DISASSEMBLY

## < SERVICE INFORMATION >

6. Remove O-ring from input clutch assembly.




7. Remove tightening bolts for oil pump assembly and transmission case.




8. Attach the sliding hammers to oil pump assembly and extract it evenly from transmission case.

**CAUTION:**

- Fully tighten sliding hammer screw.
- Make sure that bearing race is installed to the oil pump assembly edge surface.



9. Remove O-ring from oil pump assembly.







# DISASSEMBLY

## < SERVICE INFORMATION >

10. Remove bearing race from oil pump assembly.




11. Remove needle bearing from front sun gear.




12. Remove front sun gear assembly from front carrier assembly.

**NOTE:**

Remove front sun gear by rotating left/right.




13. Remove seal rings from input clutch assembly.



14. Remove front carrier assembly from rear carrier assembly. (With input clutch assembly and rear internal gear.)

**CAUTION:**

Be careful to remove it with needle bearing.



A

B

AT

D

E

F

G

H

I

J

K

L

M

N


O

P


# DISASSEMBLY

## < SERVICE INFORMATION >


15. Loosen lock nut and remove band servo anchor end pin from transmission case.




16. Remove brake band from transmission case.




- To prevent brake linings from cracking or peeling, do not stretch the flexible band unnecessarily. When removing the brake band, always secure it with a clip as shown in the figure at right. Leave the clip in position after removing the brake band.
- Check brake band facing for damage, cracks, wear or burns.



17. Remove mid carrier assembly and rear carrier assembly as a unit.




18. Remove mid carrier assembly from rear carrier assembly.




# DISASSEMBLY

## < SERVICE INFORMATION >


19. Remove needle bearing (front side) from mid carrier assembly.




20. Remove needle bearing (rear side) from mid carrier assembly.



21. Remove bearing race from rear carrier assembly.




22. Remove needle bearing from rear carrier assembly.



23. Remove mid sun gear assembly, rear sun gear assembly and high and low reverse clutch hub as a unit.

**CAUTION:**

**Be careful to remove them with bearing race and needle bearing.**



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# DISASSEMBLY

## < SERVICE INFORMATION >


24. Remove high and low reverse clutch assembly from direct clutch assembly.

**CAUTION:**


Make sure that needle bearing is installed to high and low reverse clutch assembly edge surface.




25. Remove direct clutch assembly from reverse brake.



26. Remove needle bearing from drum support.




27. Remove snap ring from A/T assembly harness connector.



28. Push A/T assembly harness connector.

**CAUTION:**

Be careful not to damage connector.




# DISASSEMBLY

## < SERVICE INFORMATION >


29. Remove clips (1), oil pan (2) and oil pan gasket.

- ⇐: Front
- ←: Oil pan mounting bolt
- Drain bolt (3)




30. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.

- **If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).**




31. Remove magnets from oil pan.



32. Disconnect A/T fluid temperature sensor 2 connector (A).


- **CAUTION:**  
**Be careful not to damage connector.**

33. Straighten terminal clips (←) to free terminal cord assembly and A/T fluid temperature sensor 2 harness.



34. Disconnect output speed sensor connector (1).

- **CAUTION:**  
**Be careful not to damage connector.**




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DISASSEMBLY


## < SERVICE INFORMATION >

35. Straighten terminal clip (↔) to free output speed sensor harness.




36. Remove bolts (A), (B) and (C) from control valve with TCM.  
 • ↔: Front


| Bolt symbol | Length mm (in) | Number of bolts |
|-------------|----------------|-----------------|
| A           | 42 (1.65)      | 5               |
| B           | 55 (2.17)      | 6               |
| C           | 40 (1.57)      | 1               |




37. Remove control valve with TCM from transmission case.  
**CAUTION:**  
 When removing, be careful with the manual valve notch and manual plate height. Remove it vertically.



38. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.




39. Remove bracket from A/T fluid temperature sensor 2.



# DISASSEMBLY


## < SERVICE INFORMATION >

40. Remove O-ring from A/T assembly harness connector.




41. Disconnect TCM connectors.

**CAUTION:**  
Be careful not to damage connectors.




42. Remove A/T assembly harness connector from control valve with TCM using a flat-bladed screwdriver.




43. Disconnect TCM connector (1) and transmission range switch connector (2).

**CAUTION:**  
Be careful not to damage connectors.



44. Remove tightening bolts for rear extension assembly and transmission case.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# DISASSEMBLY

## < SERVICE INFORMATION >


45. Tap rear extension assembly with soft hammer.




46. Remove rear extension assembly from transmission case. (With needle bearing)




47. Remove bearing race from output shaft.



48. Remove output shaft from transmission case by rotating left/right.



49. Remove parking gear from output shaft.







# DISASSEMBLY

## < SERVICE INFORMATION >

50. Remove seal rings from output shaft.



51. Remove needle bearing from transmission case.




52. Remove output speed sensor (1) from transmission case.

← : Bolt

### CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc. to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.




53. Remove reverse brake snap ring (fixing plate) using 2 flat-bladed screwdrivers.

### NOTE:

Press out snap ring from transmission case oil pan side gap using a flat-bladed screwdriver, and remove it using another screwdriver.

54. Remove reverse brake retaining plate from transmission case.

- Check facing for burns, cracks or damage. If necessary, replace the plate.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DISASSEMBLY

## < SERVICE INFORMATION >


55. Remove N-spring from transmission case.




56. Remove reverse brake drive plates, driven plates and dish plates from transmission case.

**CAUTION:**


**Be careful to remove it with N-spring.**




57. Remove snap ring (fixing spring retainer) using a flat-bladed screwdriver.



58. Remove spring retainer and return spring from transmission case.




59. Remove seal rings from drum support.



# DISASSEMBLY

## < SERVICE INFORMATION >


60. Remove needle bearing from drum support edge surface.




61. Remove reverse brake piston from transmission case with compressed air. Refer to [AT-237, "Oil Channel"](#).

**CAUTION:**


Care should be taken not to abruptly blow air. It makes pistons incline, as the result, it becomes hard to disassemble the pistons.



62. Remove D-rings from reverse brake piston.



63. Use a pin punch [4 mm (0.16 in) dia. commercial service tool] to knock out retaining pin.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# DISASSEMBLY

## < SERVICE INFORMATION >


64. Remove manual shaft retaining pin using pair of nippers.




65. Remove manual plate (with parking rod) from manual shaft.




66. Remove parking rod from manual plate.



67. Remove manual shaft from transmission case.




68. Remove manual shaft oil seals using a flat-bladed screwdriver.  
**CAUTION:**  
Be careful not to scratch transmission case.




# DISASSEMBLY

## < SERVICE INFORMATION >


69. Remove detent spring and spacer from transmission case.




70. Remove snap ring from transmission case using pair of snap ring pliers.




71. Remove servo assembly (with return spring) from transmission case.



72. Remove return spring from servo assembly.



73. Remove O-rings from servo assembly.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# DISASSEMBLY

## < SERVICE INFORMATION >


74. Remove needle bearing (1) from rear extension.




75. Remove parking actuator support from rear extension.




76. Remove parking pawl (with return spring) and pawl shaft from rear extension.



77. Remove return spring (1) from parking pawl (2).



78. Remove rear oil seal from rear extension.  
**CAUTION:**  
Be careful not to scratch rear extension.



# REPAIR FOR COMPONENT PARTS


< SERVICE INFORMATION >

## REPAIR FOR COMPONENT PARTS

### Oil Pump

INFOID:000000004657029


### COMPONENTS



- |                     |                              |           |
|---------------------|------------------------------|-----------|
| 1. O-ring           | 2. Oil pump cover            | 3. O-ring |
| 4. Oil pump housing | 5. Oil pump housing oil seal |           |

### DISASSEMBLY


- Remove oil pump housing from oil pump cover.



- Remove oil pump housing oil seal using a flat-bladed screwdriver.

**CAUTION:**


**Be careful not to scratch oil pump housing.**




# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

3. Remove O-ring from oil pump housing.



4. Remove O-ring from oil pump cover.




## ASSEMBLY

1. Install O-ring to oil pump cover.

### CAUTION:


- Do not reuse O-ring.
- Apply ATF to O-ring.



2. Install O-ring to oil pump housing.

### CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.






# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >


3. Install oil pump housing oil seal to the oil pump housing until it is flush using the drift.

**CAUTION:**

- Do not reuse oil seal.
- Apply ATF to oil seal.




4. Install oil pump housing to oil pump cover.
5. Tighten bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to "COMPONENTS".



## Front Sun Gear, 3rd One-Way Clutch

INFOID:000000004657030

### COMPONENTS



1. Front sun gear
2. 3rd one-way clutch
3. Snap ring


### DISASSEMBLY

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

1. Remove snap ring from front sun gear using a flat-bladed screwdriver.



2. Remove 3rd one-way clutch from front sun gear.



## INSPECTION

### 3rd One-way Clutch

- Check frictional surface for wear or damage.

**CAUTION:**

**If necessary, replace 3rd one-way clutch.**

### Front Sun Gear Snap Ring

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace snap ring.**

### Front Sun Gear

- Check for deformation, fatigue or damage.

**CAUTION:**


**If necessary, replace front sun gear.**

## ASSEMBLY

1. Install 3rd one-way clutch in front sun gear.

**CAUTION:**


**Apply ATF to 3rd one-way clutch.**



## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >


2. Install snap ring in front sun gear using a flat-bladed screwdriver.



3. Check operation of 3rd one-way clutch.
  - a. Hold oil pump assembly and turn front sun gear.
  - b. Check 3rd one-way clutch for correct locking and unlocking directions.

**CAUTION:**

**If not as shown in the figure, check installation direction of 3rd one-way clutch.**



Front Carrier, Input Clutch, Rear Internal Gear


COMPONENTS

INFOID:000000004657031

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# REPAIR FOR COMPONENT PARTS

< SERVICE INFORMATION >



- |                  |                           |                    |
|------------------|---------------------------|--------------------|
| 1. Seal ring     | 2. O-ring                 | 3. Needle bearing  |
| 4. Bearing race  | 5. Front carrier assembly | 6. Needle bearing  |
| 7. Snap ring     | 8. Snap ring              | 9. Retaining plate |
| 10. Driven plate | 11. Input clutch drum     | 12. Dish plate     |
| 13. Drive plate  | 14. Rear internal gear    |                    |


Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-8, "Component"](#).

## DISASSEMBLY


# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >


1. Compress snap ring using 2 flat-bladed screwdrivers.
2. Remove front carrier assembly and input clutch assembly from rear internal gear.
3. Remove front carrier assembly from input clutch assembly.




- a. Remove bearing race from front carrier assembly.




- b. Remove needle bearing from front carrier assembly.



- c. Remove snap ring from front carrier assembly.  
**CAUTION:**  
**Do not expand snap ring excessively.**



4. Disassemble input clutch assembly.
- a. Remove O-ring and seal rings from input clutch assembly.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >

- b. Remove needle bearing from input clutch assembly.



- c. Remove snap ring from input clutch drum using a flat-bladed screwdriver.
- d. Remove retaining plate, drive plates and driven plates from input clutch drum.



### INSPECTION

#### Front Carrier Snap Ring

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace snap ring.**

#### Input Clutch Snap Ring

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace input clutch assembly.**

#### Input Clutch Drum

- Check for deformation, fatigue or damage or burns.

**CAUTION:**

**If necessary, replace input clutch assembly.**

#### Input Clutch Drive Plates

- Check facing for burns, cracks or damage.

**CAUTION:**

**If necessary, replace input clutch assembly.**

#### Input Clutch Retaining Plate and Driven Plates

- Check facing for burns, cracks or damage.

**CAUTION:**

**If necessary, replace input clutch assembly.**

#### Front Carrier

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace front carrier assembly.**

#### Rear Internal Gear

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace rear internal gear.**

### ASSEMBLY

1. Install input clutch.


# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >


- a. Install driven plates, drive plates and retaining plate in input clutch drum.
- Snap ring (1)
  - Retaining plate (2)
  - Drive plate (3)
  - Driven plate (4)
  - Dish plate (5)
  - Drive plate/Driven plate: 7/7

**CAUTION:**

Take care with order of plates.




- b. Install snap ring in input clutch drum using a flat-bladed screwdriver.



- c. Install needle bearing in input clutch assembly.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.



- d. Install O-ring and seal rings in input clutch assembly.

**CAUTION:**

- Do not reuse O-ring and seal rings.
- Apply ATF to O-ring.
- Apply petroleum jelly to seal rings.




2. Install front carrier assembly.

- a. Install snap ring to front carrier assembly.

**CAUTION:**

Do not expand snap ring excessively.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

b. Install needle bearing in front carrier assembly.

**CAUTION:**

- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




c. Install bearing race in front carrier assembly.

**CAUTION:**


**Apply petroleum jelly to bearing race.**

d. Install front carrier assembly to input clutch assembly.



3. Compress snap ring using 2 flat-bladed screwdrivers.


4. Install front carrier assembly and input clutch assembly to rear internal gear.



## Mid Sun Gear, Rear Sun Gear, High and Low Reverse Clutch Hub

INFOID:000000004657032

## COMPONENTS






# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

- |                                    |                   |              |
|------------------------------------|-------------------|--------------|
| 1. Needle bearing                  | 2. Bearing race   | 3. Snap ring |
| 4. High and low reverse clutch hub | 5. Needle bearing | 6. Snap ring |
| 7. 1st one-way clutch              | 8. Rear sun gear  | 9. Seal ring |
| 10. Mid sun gear                   |                   |              |

### DISASSEMBLY


1. Remove needle bearing and bearing race from high and low reverse clutch hub.




2. Remove snap ring from mid sun gear assembly using pair of snap ring pliers.

**CAUTION:**


**Do not expand snap ring excessively.**



3. Remove high and low reverse clutch hub from mid sun gear assembly.



- a. Remove needle bearing from high and low reverse clutch hub.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >


4. Remove rear sun gear assembly (1) from mid sun gear assembly.




- a. Remove snap ring from rear sun gear using a flat-bladed screwdriver.



- b. Remove 1st one-way clutch from rear sun gear.



5. Remove seal rings from mid sun gear.



### INSPECTION

High and Low Reverse Clutch Hub Snap Ring, Rear Sun Gear Snap Ring

- Check for deformation, fatigue or damage.

#### **CAUTION:**

**If necessary, replace snap ring.**

1st One-way Clutch

- Check frictional surface for wear or damage.

#### **CAUTION:**

**If necessary, replace 1st one-way clutch.**

Mid Sun Gear

# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace mid sun gear.**

### Rear Sun Gear

- Check for deformation, fatigue or damage.

**CAUTION:**

**If necessary, replace rear sun gear.**

### High and Low Reverse Clutch Hub

- Check for deformation, fatigue or damage.

**CAUTION:**


**If necessary, replace high and low reverse clutch hub.**

## ASSEMBLY

1. Install seal rings to mid sun gear.

**CAUTION:**


- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




2. Install 1st one-way clutch to rear sun gear.

**CAUTION:**

**Apply petroleum jelly to 1st one-way clutch.**



3. Install snap ring to rear sun gear using a flat-bladed screwdriver.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >


4. Install rear sun gear assembly (1) to mid sun gear assembly.




5. Install needle bearing to high and low reverse clutch hub.

**CAUTION:**

- Take care with the direction of needle bearing. Refer to [AT-238. "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




6. Install high and low reverse clutch hub to mid sun gear assembly.



7. Install snap ring to mid sun gear assembly using pair of snap ring pliers.

**CAUTION:**

**Do not expand snap ring excessively.**




8. Check operation of 1st one-way clutch.

- a. Hold mid sun gear and turn rear sun gear.  
b. Check 1st one-way clutch for correct locking and unlocking directions.

**CAUTION:**

**If not as shown in illustration, check installation direction of 1st one-way clutch.**




# REPAIR FOR COMPONENT PARTS

## < SERVICE INFORMATION >

9. Install bearing race and needle bearing to high and low reverse clutch hub.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.



## High and Low Reverse Clutch

INFOID:000000004657033


## COMPONENTS



- |                                     |                 |                    |
|-------------------------------------|-----------------|--------------------|
| 1. High and low reverse clutch drum | 2. Driven plate | 3. Retaining plate |
| 4. Snap ring                        | 5. Drive plate  | 6. Bearing race    |

## DISASSEMBLY


1. Remove bearing race from high and low reverse clutch drum.



## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >

2. Remove snap ring from high and low reverse clutch drum using a flat-bladed screwdriver.
3. Remove retaining plate, drive plates and driven plates from high and low reverse clutch drum.



### INSPECTION

**Check the following, and replace high and low reverse clutch assembly if necessary.**

High and Low Reverse Clutch Snap Ring

- Check for deformation, fatigue or damage.

High and Low Reverse Clutch Drive Plates

- Check facing for burns, cracks or damage.

High and Low Reverse Clutch Retaining Plate and Driven Plates

- Check facing for burns, cracks or damage.


### ASSEMBLY

1. Install driven plates, drive plates and retaining plate in high and low reverse clutch drum.

**CAUTION:**

**Take care with order of plates.**


2. Install snap ring in high and low reverse clutch drum using a flat-bladed screwdriver.



3. Install bearing race to high and low reverse clutch drum.

**CAUTION:**

**Apply petroleum jelly to bearing race.**




Direct Clutch

COMPONENTS

INFOID:000000004657034

# REPAIR FOR COMPONENT PARTS


< SERVICE INFORMATION >



- |                       |                    |                    |
|-----------------------|--------------------|--------------------|
| 1. Direct clutch drum | 2. Dish plate      | 3. Retaining plate |
| 4. Driven plate       | 5. Retaining plate | 6. Snap ring       |
| 7. Drive plate        |                    |                    |

## DISASSEMBLY

1. Remove snap ring from direct clutch drum using a flat-bladed screwdriver.
2. Remove retaining plates, drive plates, driven plates and dish plate from direct clutch drum.



## INSPECTION

**Check the following, and replace direct clutch assembly if necessary.**

### Direct Clutch Snap Ring

- Check for deformation, fatigue or damage.

### Direct Clutch Drive Plates

- Check facing for burns, cracks or damage.

### Direct Clutch Retaining Plate, Driven Plates and Dish Plate


- Check facing for burns, cracks or damage.

## ASSEMBLY

1. Install dish plate, retaining plates, driven plates and drive plates in direct clutch drum.
  - Snap ring (1)
  - Retaining plate (2)
  - Drive plate (3)
  - Driven plate (4)
  - Dish plate (5)
  - Drive plate/Driven plate: 5/4

**CAUTION:**

**Take care with order of plates.**




SCIA6952E

A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## REPAIR FOR COMPONENT PARTS

### < SERVICE INFORMATION >

2. Install snap ring in direct clutch drum using a flat-bladed screwdriver.





# ASSEMBLY

< SERVICE INFORMATION >

## ASSEMBLY


### Assembly (1)

INFOID:000000004657035


1. As shown in the right figure, use a drift [commercial service tool: 22 mm (0.87 in) dia.] to drive manual shaft oil seals into transmission case until it is flush.

**CAUTION:**


- Do not reuse manual shaft oil seals.
- Apply ATF to manual shaft oil seals.




2. Install detent spring and spacer to transmission case, and then tighten mounting bolt to the specified torque. Refer to [AT-232](#), "[Component](#)".



3. Install manual shaft to transmission case.



4. Install parking rod to manual plate.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ASSEMBLY

## < SERVICE INFORMATION >


5. Install manual plate (with parking rod) to manual shaft.



6. Install retaining pin into manual plate and manual shaft.
- Fit pinhole of manual plate to pinhole of manual shaft with a pin punch.
  - Tap retaining pin into manual plate using a hammer.

**CAUTION:**


- Do not reuse retaining pin.
- Drive retaining pin to  $2 \pm 0.5$  mm ( $0.08 \pm 0.020$  in) over manual plate.



7. Install retaining pin into transmission case and manual shaft.
- Fit pinhole of transmission case to pinhole of manual shaft with a pin punch.
  - Tap the retaining pin into transmission case using a hammer.

**CAUTION:**


- Do not reuse retaining pin.
- Drive retaining pin to  $5 \pm 1$  mm ( $0.20 \pm 0.04$  in) over transmission case.



8. Install O-rings to servo assembly.

**CAUTION:**


- Do not reuse O-rings.
- Apply petroleum jelly to O-rings.




# ASSEMBLY

## < SERVICE INFORMATION >


9. Install return spring to servo assembly.



10. Install servo assembly in transmission case.




11. Install snap ring to transmission case using pair of snap ring pliers.




12. Install D-rings in reverse brake piston.

**CAUTION:**

- Do not reuse D-rings.
- Apply ATF to D-rings.



13. Install reverse brake piston in transmission case.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ASSEMBLY

## < SERVICE INFORMATION >

14. Install needle bearing to drum support edge surface.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




15. Install seal rings to drum support.

**CAUTION:**

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




16. Install return spring and spring retainer in transmission case.



17. Set the SST on spring retainer and install snap ring (fixing spring retainer) in transmission case while compressing return spring.

**CAUTION:**

- Securely assemble them using a flat-bladed screwdriver so that snap ring tension is slightly weak.



# ASSEMBLY


## < SERVICE INFORMATION >

18. Install reverse brake retaining plate, drive plates, driven plates and dish plates in transmission case.

- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Dish plate (5)
- Drive plate/Driven plate: 6/6


**CAUTION:**

Take care with order of plates.




19. Assemble N-spring.

20. Install reverse brake retaining plate in transmission case.



21. Install snap ring in transmission case.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ASSEMBLY

## < SERVICE INFORMATION >

22. Measure clearance between retaining plate and snap ring. If not within specified clearance, select proper retaining plate. Refer to "Parts Information" for retaining plate selection.

**Specified clearance "A":**


Refer to [AT-295, "Reverse Brake"](#).



23. Install needle bearing to transmission case.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.



24. Install output speed sensor (1) to transmission case, Tighten bolt (⬅) to the specified torque. Refer to [AT-232, "Component"](#).

**CAUTION:**


- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc. to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.




25. As shown in the figure, drive rear oil seal into rear extension until it is flush using a drift.

**CAUTION:**

- Do not reuse rear oil seal.
- Apply ATF to rear oil seal.




26. Install return spring (1) to parking pawl (2).




# ASSEMBLY

## < SERVICE INFORMATION >

27. Install parking pawl (with return spring) and pawl shaft to rear extension.




28. Install parking actuator support to rear extension.



29. Install needle bearing (1) to rear extension.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




30. Install seal rings to output shaft.

**CAUTION:**

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.



31. Install parking gear to output shaft.



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ASSEMBLY

## < SERVICE INFORMATION >


32. Install output shaft in transmission case.

**CAUTION:**

Be careful not to mistake front for rear because both sides looks similar. (Thinner end is front side.)




33. Install bearing race to output shaft.



34. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-42. "Recommended Chemical Product and Sealant"](#).) to rear extension assembly as shown in the figure.

**CAUTION:**


Completely remove all moisture, oil and old sealant, etc. from transmission case and rear extension assembly mounting surfaces.



35. Install rear extension assembly to transmission case.

**CAUTION:**


Insert the tip of parking rod between parking pawl and the parking actuator support when assembling rear extension assembly.



36. Tighten rear extension assembly mounting bolts to the specified torque. Refer to [AT-232. "Component"](#).

**CAUTION:**

Do not reuse self-sealing bolts.






# ASSEMBLY

## < SERVICE INFORMATION >

37. Install needle bearing in drum support.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




38. Install direct clutch assembly in reverse brake.

**CAUTION:**


- Make sure that drum support edge surface and direct clutch inner boss edge surface come to almost same place.




39. Install high and low reverse clutch assembly in direct clutch.



40. Align drive plate using a flat-bladed screwdriver.



41. Install high and low reverse clutch hub, mid sun gear assembly and rear sun gear assembly as a unit.



A

B

AT

D

E

F

G

H

I

J

K

L

M

N

O


P

# ASSEMBLY

## < SERVICE INFORMATION >

### CAUTION:


Make sure that portion "A" of high and low reverse clutch drum protrudes approximately 2 mm (0.08 in) beyond portion "B" of rear sun gear.



42. Install needle bearing in rear carrier assembly.

### CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




43. Install bearing race in rear carrier assembly.

### CAUTION:

Apply petroleum jelly to bearing race.



44. Install rear carrier assembly in direct clutch drum.




# ASSEMBLY

## < SERVICE INFORMATION >

45. Install needle bearing (rear side) to mid carrier assembly.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




46. Install needle bearing (front side) to mid carrier assembly.

**CAUTION:**


- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.



47. Install mid carrier assembly in rear carrier assembly.




48. Install front carrier assembly, input clutch assembly and rear internal gear as a unit.



49. Install seal rings in input clutch assembly.

**CAUTION:**

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.



A

B

AT

D

E

F

G

H

I

J

K

L

M

N

O

P


# ASSEMBLY

## < SERVICE INFORMATION >

50. Install band servo anchor end pin and lock nut in transmission case.

**CAUTION:**


Do not reuse band servo anchor end pin.



51. Install brake band in transmission case.

**CAUTION:**


Assemble it so that identification to avoid incorrect installation faces servo side.



52. Install front sun gear to front carrier assembly.

**CAUTION:**


Apply ATF to front sun gear bearing and 3rd one-way clutch end bearing.




53. Install needle bearing to front sun gear.

**CAUTION:**

- Take care with the direction of needle bearing. Refer to [AT-238, "Location of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.



54. Adjust brake band tilting using a clip so that brake band contacts front sun gear drum evenly.



# ASSEMBLY

## < SERVICE INFORMATION >


55. Adjust brake band.

- a. Loosen lock nut.
- b. Tighten band servo anchor end pin to the specified torque.



**: 5.0 N·m (0.51 kg·m, 44 in·lb)**

- c. Back of band servo anchor end pin three turns.
- d. Holding band servo anchor end pin, tighten lock nut to the specified torque. Refer to [AT-232. "Component"](#).




INFOID:000000004657036


## Adjustment

### TOTAL END PLAY


- Measure clearance between front sun gear and bearing race for oil pump cover.
- Select proper thickness of bearing race so that end play is within specifications.



1. Measure dimensions "K" and "L" and then calculate dimension "J".



- a. Measure dimension "K".



# ASSEMBLY


## < SERVICE INFORMATION >

- b. Measure dimension "L".
- c. Calculate dimension "J".


**"J": Distance between oil pump fitting surface of transmission case and needle bearing mating surface of front sun gear.**

$$J = K - L$$


- 2. Measure dimensions "M1" and "M2" and then calculate dimension "M".





- a. Place bearing race and needle bearing on oil pump assembly.



- b. Measure dimension "M1".



- c. Measure dimension "M2".



# ASSEMBLY

## < SERVICE INFORMATION >

d. Calculate dimension "M".

**"M": Distance between transmission case fitting surface of oil pump and needle bearing on oil pump.**

$$M = M_1 - M_2$$

3. Adjust total end play "T1".

$$T_1 = J - M$$

**Total end play "T1":**

**Refer to [AT-295, "Total End Play"](#).**

- Select proper thickness of bearing race so that total end play is within specifications. Refer to "Parts Information" for bearing race selection.

## Assembly (2)

1. Install O-ring to oil pump assembly.



**CAUTION:**

- Do not reuse O-ring.
- Apply ATF to O-ring.



2. Install bearing race to oil pump assembly.

**CAUTION:**

**Apply petroleum jelly to bearing race.**



INFOID:000000004657037



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# ASSEMBLY

## < SERVICE INFORMATION >

3. Install oil pump assembly in transmission case.

**CAUTION:**


Apply ATF to oil pump bearing.



4. Apply recommended sealant (Genuine RTV Silicone Sealant or equivalent. Refer to [GI-42, "Recommended Chemical Product and Sealant"](#).) to oil pump assembly as shown in the figure.

**CAUTION:**


Completely remove all moisture, oil and old sealant, etc. from the oil pump mounting bolts and oil pump mounting bolt mounting surfaces.



5. Tighten oil pump mounting bolts to the specified torque. Refer to [AT-232, "Component"](#).

**CAUTION:**


Apply ATF to oil pump bushing.



6. Install O-ring to input clutch assembly.

**CAUTION:**


- Do not reuse O-ring.
- Apply ATF to O-ring.



7. Install converter housing to transmission case, and then tighten converter housing bolts (A) and self-sealing bolts (B) to the specified torque. Refer to [AT-232, "Component"](#).

**CAUTION:**

Do not reuse self-sealing bolts (B).







# ASSEMBLY

## < SERVICE INFORMATION >


8. Make sure that brake band (1) does not close input speed sensor hole (A).




9. Install control valve with TCM.  
 a. Connect TCM connector (1) and transmission range switch connector (2).



- b. Install A/T assembly harness connector from control valve with TCM.




- c. Connect TCM connectors.



- d. Install O-ring to A/T assembly harness connector.

**CAUTION:**

- Do not reuse O-ring.
- Apply ATF to O-ring.




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ASSEMBLY

## < SERVICE INFORMATION >


e. Install A/T fluid temperature sensor 2 to bracket.



f. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM, and then tighten mounting bolt to the specified torque. Refer to [AT-232. "Component"](#).

**CAUTION:**

**Adjust bolt hole of bracket to bolt hole of control valve with TCM.**




g. Install control valve with TCM in transmission case.


← : Brake band

**CAUTION:**

- Make sure that input speed sensor securely installs input speed sensor hole (A).
- Hang down output speed sensor harness toward outside so as not to disturb installation of control valve with TCM.
- Adjust A/T assembly harness connector of control valve with TCM to terminal hole of transmission case.



- Assemble it so that manual valve cutout is engaged with manual plate projection.




# ASSEMBLY

## < SERVICE INFORMATION >

h. Install bolts (A), (B) and (C) to control valve with TCM.


- ←: Front

| Bolt symbol | Length mm (in) | Number of bolts |
|-------------|----------------|-----------------|
| A           | 42 (1.65)      | 5               |
| B           | 55 (2.17)      | 6               |
| C           | 40 (1.57)      | 1               |




i. Tighten bolt 1, 2 and 3 temporarily to prevent dislocation. After that tighten them in order (1 → 2 → 3), and then tighten other bolts to the specified torque. Refer to [AT-232. "Component"](#).

- ←: Front




10. Connect A/T fluid temperature sensor 2 connector (A).

11. Securely fasten terminal cord assembly and A/T fluid temperature sensor 2 harness with terminal clips (←).



12. Connect output speed sensor connector (1).




A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ASSEMBLY

## < SERVICE INFORMATION >


13. Securely fasten output speed sensor harness with terminal clip (←).




14. Pull down A/T assembly harness connector.  
**CAUTION:**  
**Be careful not to damage connector.**



15. Install snap ring to A/T assembly harness connector.



16. Install magnets in oil pan.



17. Install oil pan to transmission case.

- a. Install oil pan gasket to oil pan.


**CAUTION:**

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Completely remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


# ASSEMBLY

## < SERVICE INFORMATION >


- b. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.
- ◀: Front
  - ⬆: Oil pan mounting bolt
- CAUTION:**
- Install it so that drain plug (3) comes to the position as shown in the figure.
  - Be careful not to pinch harnesses.
  - Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.




- c. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to [AT-232. "Component"](#).
- CAUTION:**  
Do not reuse oil pan mounting bolts.
18. Install drain plug to oil pan, and then tighten drain plug to the specified torque. Refer to [AT-232. "Component"](#).
- CAUTION:**  
Do not reuse drain plug gasket.



19. Install torque converter.
- a. Pour ATF into torque converter.
- Approximately 2 liter (2-1/8 US qt, 1-3/4 Imp qt) of ATF is required for a new torque converter.
  - When reusing old torque converter, add the same amount of ATF as was drained.




- b. Install torque converter while aligning notches of torque converter with notches of oil pump.
- CAUTION:**  
Install torque converter while rotating it.



- c. Measure distance "A" to check that torque converter is in proper position.

**Distance "A": 25.0 mm (0.98 in) or more**



A  
B  
AT  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE INFORMATION >

## SERVICE DATA AND SPECIFICATIONS (SDS)

### General Specification

INFOID:000000004657038

|                                |   |       |
|--------------------------------|---|-------|
| Applied model                  | VQ35HR engine   |       |
| Automatic transmission model   | RE5R05A   |       |
| Transmission model code number | 99X5B   |       |
| Stall torque ratio             | 1.74 : 1  |       |
| Transmission gear ratio        | 1st   | 3.842 |
|                                | 2nd   | 2.353 |
|                                | 3rd   | 1.529 |
|                                | 4th   | 1.000 |
|                                | 5th   | 0.839 |
|                                | Reverse   | 2.765 |
| Recommended fluid              | Genuine NISSAN Matic J ATF* <sup>1</sup>              |       |
| Fluid capacity                 | 10.3 liter (10-7/8 US qt, 9-1/8 Imp qt)* <sup>2</sup> |       |

**CAUTION:**

- Use only Genuine NISSAN Matic J ATF. Do not mix with other fluid.
- Using A/T fluid other than Genuine NISSAN Matic J ATF will cause deterioration driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

\*<sup>1</sup>: Refer to [MA-10, "Fluids and Lubricants"](#).

\*<sup>2</sup>: The fluid capacity is the reference value. Check the fluid level with A/T fluid level gauge.

### Vehicle Speed at Which Gear Shifting Occurs

INFOID:000000004657039

| Throttle position | Vehicle speed km/h (MPH) |                        |                         |                          |                          |                        |                      |                      |
|-------------------|--------------------------|------------------------|-------------------------|--------------------------|--------------------------|------------------------|----------------------|----------------------|
|                   | D1→D2                    | D2→D3                  | D3→D4                   | D4→D5                    | D5→D4                    | D4→D3                  | D3→D2                | D2→D1                |
| Full throttle     | 64 – 68<br>(40 – 42)     | 103 – 111<br>(64 – 69) | 156 – 166<br>(97 – 103) | 224 – 234<br>(139 – 145) | 220 – 230<br>(137 – 143) | 146 – 156<br>(91 – 97) | 86 – 94<br>(53 – 58) | 40 – 44<br>(25 – 27) |
| Half throttle     | 47 – 51<br>(29 – 32)     | 76 – 82<br>(47 – 51)   | 108 – 116<br>(67 – 72)  | 136 – 144<br>(85 – 89)   | 88 – 96<br>(55 – 60)     | 64 – 72<br>(40 – 45)   | 28 – 34<br>(17 – 21) | 8 – 12<br>(5 – 7)    |

- At half throttle, the accelerator opening is 4/8 of the full opening.

### Vehicle Speed at Which Lock-up Occurs/Releases

INFOID:000000004657040

| Throttle position | Vehicle speed km/h (MPH) |                   |
|-------------------|--------------------------|-------------------|
|                   | Lock-up ON               | Lock-up OFF       |
| Closed throttle   | 62 – 70 (39 – 44)        | 59 – 67 (37 – 42) |
| Half throttle     | 136 – 144 (85 – 89)      | 88 – 96 (55 – 60) |

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

### Stall Speed

INFOID:000000004657041

|             |                   |
|-------------|-------------------|
| Stall speed | 2,700 – 3,000 rpm |
|-------------|-------------------|

# SERVICE DATA AND SPECIFICATIONS (SDS)

## < SERVICE INFORMATION >

### Line Pressure

INFOID:000000004657042

| Engine speed   | Line pressure kPa (kg/cm <sup>2</sup> , psi) |  |
|----------------|--|--|
|                | "R" position                                 | "D" and "M" positions                  |
| At idle speed  | 425 – 465 (4.3 – 4.7, 62 – 67)               | 379 – 428 (3.9 – 4.4, 55 – 62)         |
| At stall speed | 1,605 – 1,950 (16.4 – 19.9, 233 – 283)       | 1,310 – 1,500 (13.4 – 15.3, 190 – 218) |

### A/T Fluid Temperature Sensor

INFOID:000000004657043

| Name                           | Condition    | CONSULT-III "DATA MONITOR" (Approx.) | Resistance (Approx.) |
|--------------------------------|--------------|--------------------------------------|----------------------|
| A/T fluid temperature sensor 1 | 0°C (32°F)   | 3.3 V                                | 15 kΩ                |
|                                | 20°C (68°F)  | 2.7 V                                | 6.5 kΩ               |
|                                | 80°C (176°F) | 0.9 V                                | 0.9 kΩ               |
| A/T fluid temperature sensor 2 | 0°C (32°F)   | 3.3 V                                | 10 kΩ                |
|                                | 20°C (68°F)  | 2.5 V                                | 4 kΩ                 |
|                                | 80°C (176°F) | 0.7 V                                | 0.5 kΩ               |

### Input Speed Sensor

INFOID:000000004657044

| Name                 | Condition   | Data (Approx.) |
|----------------------|---|----------------|
| Input speed sensor 1 | When running at 50 km/h (31 MPH) in 4th speed with the closed throttle position signal OFF. | 1.3 kHz        |
| Input speed sensor 2 | When moving at 20 km/h (12 MPH) in 1st speed with the closed throttle position signal OFF.  |                |

### Output Speed Sensor

INFOID:000000004657045

| Name                | Condition                        | Data (Approx.) |
|---------------------|----------------------------------|----------------|
| Output speed sensor | When moving at 20 km/h (12 MPH). | 185 Hz         |

### Reverse Brake

INFOID:000000004657046

|                         |          |                           |
|-------------------------|----------|---------------------------|
| Model code number       | 99X5B    |                           |
| Number of drive plates  | 6        |                           |
| Number of driven plates | 6        |                           |
| Clearance mm (in)       | Standard | 0.7 – 1.1 (0.028 – 0.043) |

### Total End Play

INFOID:000000004657047

|                        |                               |
|------------------------|-------------------------------|
| Total end play mm (in) | 0.25 – 0.55 (0.0098 – 0.0217) |
|------------------------|-------------------------------|