

SECTION HRN
HORNA
B
C
D
E**CONTENTS**

DTC/CIRCUIT DIAGNOSIS	2	FOR MEXICO	5
HORN	2	FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5
Wiring Diagram - HORN -	2	FOR MEXICO : Precautions for Removing Battery Terminal	6
PRECAUTION	5	REMOVAL AND INSTALLATION	7
PRECAUTIONS	5	HORN	7
EXCEPT FOR MEXICO	5	Exploded View	7
EXCEPT FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	Removal and Installation	7
EXCEPT FOR MEXICO : Precautions for Removing Battery Terminal	5		

J

K

HRN

M

N

O

P

HORN


< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

HORN

Wiring Diagram - HORN -

INFOID:0000000011737241



* : This connector is not shown in "Harness Layout".

HORN

HORN

< DTC/CIRCUIT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HORN		
Connector No.	65	Signal Name [Specification]
Connector Name	POWER/INTelligent Power Distribution Module (DC/DC)	HORN (HIGH)
Connector Type	THDFW-CS12.2-M4-TV	
Connector No.	61	Signal Name [Specification]
Connector Name	HORN (HIGH)	
Connector Type	P01FB-BKA	
Connector No.	670	Signal Name [Specification]
Connector Name	HORN (LOW)	
Connector Type	P01FB-A	
Connector No.	E11	Signal Name [Specification]
Connector Name	HORN RELAY 1	
Connector Type	24381-7950A	
Connector No.	652	Signal Name [Specification]
Connector Name	HORN (HIGH)	
Connector Type	P01FB-A	
Connector No.	E106	Signal Name [Specification]
Connector Name	WIRE TO WIRE	
Connector Type	TH85HW-CS16-TMM	
Connector No.	138	Signal Name [Specification]
Connector Name	HORN RELAY 2	
Connector Type	IMOFN-RCC	
Connector No.	659	Signal Name [Specification]
Connector Name	POWER/INTelligent Power Distribution Module (DC/DC)	HORN (LOW)
Connector Type	THDFW-WHN	
Connector No.	42	Signal Name [Specification]
Connector Name	-	
Connector Type	-	
Connector No.	1	Signal Name [Specification]
Connector Name	P	
Connector Type	P01FB-BKA	
Connector No.	2	Signal Name [Specification]
Connector Name	Y	
Connector Type	P01FB-BKA	
Connector No.	3	Signal Name [Specification]
Connector Name	G	
Connector Type	P01FB-BKA	
Connector No.	39	Signal Name [Specification]
Connector Name	P	
Connector Type	-	
Connector No.	40	Signal Name [Specification]
Connector Name	L	
Connector Type	-	
Connector No.	43	Signal Name [Specification]
Connector Name	ROW	
Connector Type	-	
Connector No.	43	Signal Name [Specification]
Connector Name	Y	
Connector Type	-	
Connector No.	43	Signal Name [Specification]
Connector Name	S8	
Connector Type	-	
Connector No.	44	Signal Name [Specification]
Connector Name	W	
Connector Type	-	

JRLWE8492GB

HORN

< DTC/CIRCUIT DIAGNOSIS >

HORN

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	[Coupe models] - (Roadster models)	1	Y	
2	BR	WIRE TO WHITE	2	Y	
3	G		3	BR	
4	L		4	BR	
5	Y		5	Y	
6	GR		6	P	
7	R		7	P	
8	R		8	P	
9	B		9	P	
10	W		10	P	
11	IG		11	P	
12	SB		12	O	
13	G		13	O	
14	GR		14	Y	
15	R	- Except for roadster models with M/T1 [Roadster models with M/T1]	15	Y	
16	BR		16	Y	
17	P		17	BR	
18	SHIELD		18	BR	
19	L		19	BR	
20	P		20	GR	
21	W		21	R	
22	P		22	R	
23	Y		23	R	
24	S		24	R	
25	V		25	R	
26	W		26	SB	
27	Y		27	SB	
28	LG		28	SB	
29	Y		29	SB	
30	GR		30	W	
31	LG		31	W	
32	W		32	V	
33	L		33	SB	
34	G		34	SB	
35	Y		35	SB	
36	GR		36	SB	
37	LG		37	Y	
38	Y		38	LG	
39	SB		39	LG	
40	W		40	LG	
41	LG		41	LG	
42	R		42	R	
43	G		43	G	- (With A/T)
44	G		44	R	- (With M/T)
45	O		45	O	- (With M/T)
46	G		46	G	-
47	BR		47	BR	-
48	SHIELD		48	SHIELD	-
49	L		49	L	-
50	R		50	R	-
51	LG		51	LG	-
52	GR		52	GR	-
53	V		53	V	-

JRLWE8493GB

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

EXCEPT FOR MEXICO

EXCEPT FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011737242

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

EXCEPT FOR MEXICO : Precautions for Removing Battery Terminal

INFOID:000000011737243

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.


- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and



SEF289H

HRN

M

N

O

P

PRECAUTIONS

< PRECAUTION >

"SEAT BELT PRE-TENSIONER"

INFOID:000000011737244

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precautions for Removing Battery Terminal

INFOID:000000011737245

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

HORN


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

HORN

Exploded View

INFOID:0000000011737246



1. Horn (LOW)

2. Horn (HIGH)

Removal and Installation

INFOID:0000000011737247

REMOVAL

Horn (LOW)

1. Remove the bumper center upper finisher. Refer to [EXT-16, "Removal and Installation"](#).
2. Disconnect the horn (LOW) connector.
3. Remove the horn mounting nut, and remove the horn (LOW) from the vehicle.

Horn (HIGH)

1. Remove the fender protector LH (front). Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation"](#).
2. Disconnect the horn (HIGH) connector.
3. Remove the horn mounting bolt, and remove the horn (HIGH) from the vehicle.

HRN

INSTALLATION

Install in the reverse order of removal.

M

N

O

P