

# EXL

## SECTION EXL

### EXTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## CONTENTS

<p style="text-align: center;"><b>XENON TYPE</b></p> <p><b>PRECAUTION</b> ..... 5</p> <p><b>PRECAUTIONS</b> ..... 5</p> <p><b>FOR USA AND CANADA</b> .....5</p> <p style="padding-left: 20px;">FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....5</p> <p style="padding-left: 20px;">FOR USA AND CANADA : Precautions For Xenon Headlamp Service .....5</p> <p style="padding-left: 20px;">FOR USA AND CANADA : Precaution for Battery Service .....5</p> <p><b>FOR MEXICO</b> .....6</p> <p style="padding-left: 20px;">FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....6</p> <p style="padding-left: 20px;">FOR MEXICO : Precautions For Xenon Headlamp Service .....6</p> <p style="padding-left: 20px;">FOR MEXICO : Precaution for Battery Service .....6</p> <p><b>SYSTEM DESCRIPTION</b> ..... 7</p> <p><b>COMPONENT PARTS</b> ..... 7</p> <p><b>HEADLAMP SYSTEM</b> .....7</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : Component Parts Location .....7</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : Component Description.....7</p> <p><b>AUTO LIGHT SYSTEM</b> .....7</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : Component Parts Location .....8</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : Component Description.....8</p> <p><b>DAYTIME RUNNING LIGHT SYSTEM</b> .....8</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : Component Parts Location .....9</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : Component Description .....9</p>	<p><b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> ..... 9</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Parts Location ..... 9</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Description .....10</p> <p><b>PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL)</b> .....10</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Component Parts Location .....10</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Component Description .....11</p> <p><b>PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL)</b> .....12</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Component Parts Location .....12</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Component Description .....12</p> <p><b>REAR FOG LAMP SYSTEM</b> .....12</p> <p style="padding-left: 20px;">REAR FOG LAMP SYSTEM : Component Parts Location .....13</p> <p style="padding-left: 20px;">REAR FOG LAMP SYSTEM : Component Description .....13</p> <p><b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> .....13</p> <p style="padding-left: 20px;">EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Parts Location .....14</p> <p style="padding-left: 20px;">EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Description .....14</p> <p><b>SYSTEM</b> ..... 15</p> <p><b>HEADLAMP SYSTEM</b> .....15</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Diagram .....15</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Description .....15</p>
---	--

<b>AUTO LIGHT SYSTEM</b> .....	16	List of ECU Reference .....	33
AUTO LIGHT SYSTEM : System Diagram .....	16	<b>WIRING DIAGRAM</b> .....	34
AUTO LIGHT SYSTEM : System Description .....	16	<b>HEADLAMP SYSTEM</b> .....	34
<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	17	Wiring Diagram .....	34
DAYTIME RUNNING LIGHT SYSTEM : System		<b>AUTO LIGHT SYSTEM</b> .....	39
Diagram .....	17	Wiring Diagram .....	39
DAYTIME RUNNING LIGHT SYSTEM : System		<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	46
Description .....	17	Wiring Diagram .....	46
<b>TURN SIGNAL AND HAZARD WARNING LAMP</b>		<b>TURN SIGNAL AND HAZARD WARNING</b>	
<b>SYSTEM</b> .....	18	<b>LAMP SYSTEM</b> .....	54
TURN SIGNAL AND HAZARD WARNING LAMP		Wiring Diagram .....	54
SYSTEM : System Diagram .....	18	<b>PARKING, LICENSE PLATE AND TAIL</b>	
TURN SIGNAL AND HAZARD WARNING LAMP		<b>LAMPS SYSTEM</b> .....	60
SYSTEM : System Description .....	18	Wiring Diagram .....	60
<b>PARKING, LICENSE PLATE AND TAIL LAMP</b>		<b>STOP LAMP</b> .....	66
<b>SYSTEM (WITH DTRL)</b> .....	19	Wiring Diagram .....	66
PARKING, LICENSE PLATE AND TAIL LAMP		<b>BACK-UP LAMP</b> .....	68
SYSTEM (WITH DTRL) : System Diagram .....	19	Wiring Diagram .....	68
PARKING, LICENSE PLATE AND TAIL LAMP		<b>REAR FOG LAMP SYSTEM</b> .....	72
SYSTEM (WITH DTRL) : System Description .....	19	Wiring Diagram .....	72
<b>PARKING, LICENSE PLATE AND TAIL LAMP</b>		<b>BASIC INSPECTION</b> .....	77
<b>SYSTEM (WITHOUT DTRL)</b> .....	19	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	77
PARKING, LICENSE PLATE AND TAIL LAMP		Work Flow .....	77
SYSTEM (WITHOUT DTRL) : System Diagram ....	19	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	79
PARKING, LICENSE PLATE AND TAIL LAMP		<b>EXTERIOR LAMP FUSE</b> .....	79
SYSTEM (WITHOUT DTRL) : System Description		<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM</b> ...	79
... 20		WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
<b>REAR FOG LAMP SYSTEM</b> .....	20	: Description .....	79
REAR FOG LAMP SYSTEM : System Diagram ....	20	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
REAR FOG LAMP SYSTEM : System Description..	20	: Diagnosis Procedure .....	79
<b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> .....	21	<b>WITH DAYTIME RUNNING LIGHT SYSTEM</b> .....	79
EXTERIOR LAMP BATTERY SAVER SYSTEM :		WITH DAYTIME RUNNING LIGHT SYSTEM : De-	
System Diagram .....	21	scription .....	79
EXTERIOR LAMP BATTERY SAVER SYSTEM :		WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	
System Description .....	21	agnosis Procedure .....	80
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	23	<b>HEADLAMP (HI) CIRCUIT</b> .....	81
<b>COMMON ITEM</b> .....	23	Description .....	81
COMMON ITEM : CONSULT-III Function (BCM -		Component Function Check .....	81
COMMON ITEM) .....	23	Diagnosis Procedure .....	81
<b>HEADLAMP</b> .....	24	<b>HEADLAMP (LO) CIRCUIT</b> .....	83
HEADLAMP : CONSULT-III Function (BCM -		Description .....	83
HEAD LAMP) .....	24	Component Function Check .....	83
<b>FLASHER</b> .....	26	Diagnosis Procedure .....	83
FLASHER : CONSULT-III Function (BCM -		<b>XENON HEADLAMP</b> .....	85
FLASHER) .....	26	Description .....	85
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	28		
Diagnosis Description .....	28		
CONSULT-III Function (IPDM E/R) .....	30		
<b>ECU DIAGNOSIS INFORMATION</b> .....	33		
<b>BCM, IPDM E/R</b> .....	33		

Diagnosis Procedure .....	85	WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	
		agnosis Procedure .....	106
<b>DAYTIME RUNNING LIGHT RELAY CIRCUIT</b>	<b>....87</b>	<b>REAR FOG LAMP CIRCUIT .....</b>	<b>108</b>
Component Function Check .....	87	Component Function Check .....	108
Diagnosis Procedure .....	87	Diagnosis Procedure .....	108
Component Inspection .....	88	<b>SYMPTOM DIAGNOSIS .....</b>	<b>110</b>
<b>PARKING LAMP CIRCUIT .....</b>	<b>90</b>	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS.</b>	<b>110</b>
<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM....90</b>		<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM ..110</b>	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
: Component Function Check .....	90	: Symptom Table .....	110
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		<b>WITH DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>111</b>
: Diagnosis Procedure .....	90	WITH DAYTIME RUNNING LIGHT SYSTEM :	
<b>WITH DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>91</b>	Symptom Table .....	111
WITH DAYTIME RUNNING LIGHT SYSTEM :		<b>NORMAL OPERATING CONDITION .....</b>	<b>114</b>
Component Function Check .....	91	Description .....	114
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-		<b>BOTH SIDE HEADLAMPS DO NOT SWITCH</b>	
agnosis Procedure .....	92	<b>TO HIGH BEAM .....</b>	<b>115</b>
<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>93</b>	Description .....	115
Description .....	93	Diagnosis Procedure .....	115
Component Function Check .....	93	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT</b>	
Diagnosis Procedure .....	93	<b>TURNED ON .....</b>	<b>116</b>
<b>OPTICAL SENSOR .....</b>	<b>97</b>	Description .....	116
Description .....	97	Diagnosis Procedure .....	116
Component Function Check .....	97	<b>PARKING, LICENSE PLATE, SIDE MARKER</b>	
Diagnosis Procedure .....	97	<b>AND TAIL LAMPS ARE NOT TURNED ON ...</b>	<b>117</b>
<b>HAZARD SWITCH .....</b>	<b>100</b>	<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM ..117</b>	
Component Function Check .....	100	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
Diagnosis Procedure .....	100	: Description .....	117
<b>TAIL LAMP CIRCUIT .....</b>	<b>102</b>	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM.. 102</b>		: Diagnosis Procedure .....	117
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		<b>WITH DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>117</b>
: Component Function Check .....	102	WITH DAYTIME RUNNING LIGHT SYSTEM : De-	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		scription .....	117
: Diagnosis Procedure .....	102	WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	
<b>WITH DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>103</b>	agnosis Procedure .....	117
WITH DAYTIME RUNNING LIGHT SYSTEM :		<b>PERIODIC MAINTENANCE .....</b>	<b>119</b>
Component Function Check .....	103	<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>119</b>
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-		Description .....	119
agnosis Procedure .....	103	Aiming Adjustment Procedure .....	120
<b>LICENSE PLATE LAMP CIRCUIT .....</b>	<b>105</b>	<b>REMOVAL AND INSTALLATION .....</b>	<b>121</b>
<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM.. 105</b>		<b>FRONT COMBINATION LAMP .....</b>	<b>121</b>
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		Exploded View .....	121
: Component Function Check .....	105	Removal and Installation .....	122
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		Replacement .....	122
: Diagnosis Procedure .....	105	Disassembly and Assembly .....	123
<b>WITH DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>106</b>	Inspection After Installation (HID Control Unit) .....	123
WITH DAYTIME RUNNING LIGHT SYSTEM :		<b>OPTICAL SENSOR .....</b>	
Component Function Check .....	106		

Exploded View .....	125	<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>131</b>
Removal and Installation .....	125	Exploded View .....	131
<b>LIGHTING &amp; TURN SIGNAL SWITCH .....</b>	<b>126</b>	Removal and Installation .....	131
Exploded View .....	126	<b>LICENSE PLATE LAMP .....</b>	<b>132</b>
<b>HAZARD SWITCH .....</b>	<b>127</b>	Exploded View .....	132
Exploded View .....	127	Removal and Installation .....	132
Removal and Installation .....	127	Replacement .....	132
<b>SIDE TURN SIGNAL LAMP .....</b>	<b>128</b>	<b>REAR FOG LAMP .....</b>	<b>134</b>
Exploded View .....	128	Exploded View .....	134
Removal and Installation .....	128	Removal and Installation .....	134
Replacement .....	128	Replacement .....	134
<b>REAR COMBINATION LAMP .....</b>	<b>129</b>	<b>SERVICE DATA AND SPECIFICATIONS</b>	
Exploded View .....	129	<b>(SDS) .....</b>	<b>136</b>
Removal and Installation .....	129	<b>SERVICE DATA AND SPECIFICATIONS</b>	
Replacement .....	130	<b>(SDS) .....</b>	<b>136</b>
		Bulb Specifications .....	136

PRECAUTION

PRECAUTIONS  
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005568562

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions For Xenon Headlamp Service

INFOID:000000005568564

**WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

**CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

FOR USA AND CANADA : Precaution for Battery Service

INFOID:000000005568566

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# PRECAUTIONS

< PRECAUTION >

[XENON TYPE]

window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

## FOR MEXICO

### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005683409

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### FOR MEXICO : Precautions For Xenon Headlamp Service

INFOID:00000000568565

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

#### **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

### FOR MEXICO : Precaution for Battery Service

INFOID:00000000568567

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.


SYSTEM DESCRIPTION

COMPONENT PARTS

HEADLAMP SYSTEM

HEADLAMP SYSTEM : Component Parts Location

INFOID:000000005233692



- 1. BCM  
Refer to [BCS-9, "Component Parts Location"](#).
- 2. IPDM E/R  
Refer to [PCS-6, "Component Parts Location"](#).
- 3. Headlamp
- 4. Combination meter  
(High beam indicator lamp)
- 5. Combination switch

HEADLAMP SYSTEM : Component Description

INFOID:000000005233693

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges that the headlamp is turned ON according to the vehicle condition.</li> <li>- Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication).</li> <li>- Requests the high beam indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM (with CAN communication).
Headlamp assembly	<ul style="list-style-type: none"> <li>• HID control unit</li> <li>• Xenon bulb</li> </ul>
	High beam solenoid

AUTO LIGHT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

## AUTO LIGHT SYSTEM : Component Parts Location

INFOID:000000005233696



- |   |                      |  |
|---|----------------------|--|
| 1. Door switch  | 2. Optical sensor    | 3. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . |
| 4. IPDM E/R<br>Refer to <a href="#">PCS-6, "Component Parts Location"</a> . | 5. Combination meter | 6. Combination switch  |
| 7. Daytime running light relay  |                      |  |
| A. Engine room (LH)   |                      |  |

## AUTO LIGHT SYSTEM : Component Description

INFOID:000000005233697

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the outside brightness from the optical sensor signal.</li> <li>• Judges the OFF timing according to the vehicle condition.</li> <li>• Judges the ON/OFF status of the exterior lamp and each illumination according to the outside brightness and the vehicle condition.</li> <li>- Requests ON/OFF of each relay to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
Optical sensor	Refer to <a href="#">EXL-97, "Description"</a> .

## DAYTIME RUNNING LIGHT SYSTEM




# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM : Component Parts Location

INFOID:000000005233700



- |  |   |  |
|--|---|--|
| 1. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 2. IPDM E/R<br>Refer to <a href="#">PCS-6, "Component Parts Location"</a> . | 3. ECM<br>Refer to <a href="#">EC-27, "Component Parts Location"</a> . |
| 4. Parking lamp  | 5. Front side marker lamp   | 6. Combination meter   |
| 7. Combination switch  | 8. Rear side marker lamp  | 9. Tail lamp   |
| 10. License plate lamp   | 11. Daytime running light relay   |  |
| A. Engine room (LH)  |   |  |

## DAYTIME RUNNING LIGHT SYSTEM : Component Description

INFOID:000000005233701

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition with the combination switch reading function.</li> <li>• Judges each lamps ON/OFF condition according to the vehicle condition.</li> <li>- Requests the each relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
ECM	Transmits the engine status signal to BCM with CAN communication.
Combination meter	Transmits the parking brake switch signal to BCM with CAN communication.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Parts Location


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

tion

INFOID:000000005233704



JPLIA1561ZZ

- |                          |  |                           |
|--------------------------|--|---------------------------|
| 1. Hazard switch         | 2. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 3. Front turn signal lamp |
| 4. Side turn signal lamp | 5. Combination meter<br>(Turn signal indicator lamp)                   | 6. Combination switch     |
| 7. Rear turn signal lamp |  |                           |

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Description

INFOID:000000005233705

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks.</li> <li>- Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (with CAN communication).

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL)

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Component


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

## Parts Location

INFOID:000000005233712



- |  |   |  |
|--|---|--|
| 1. BCM<br>Refer to <a href="#">BCS-9. "Component Parts Location"</a> . | 2. IPDM E/R<br>Refer to <a href="#">PCS-6. "Component Parts Location"</a> . | 3. ECM<br>Refer to <a href="#">EC-27. "Component Parts Location"</a> . |
| 4. Parking lamp  | 5. Front side marker lamp   | 6. Combination meter<br>(Tail lamp indicator lamp)                     |
| 7. Combination switch  | 8. Rear side marker lamp  | 9. Tail lamp   |
| 10. License plate lamp   | 11. Daytime running light relay   |  |
| A. Engine room (LH)  |   |  |

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Component Description

INFOID:000000005233713

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the ON/OFF status of the parking, license plate, tail and side marker lamps according to the vehicle condition.</li> <li>- Requests the daytime running light relay and tail lamp relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>• Controls the daytime running light relay and supplies voltage to the load according to the request from BCM (with CAN communication).</li> <li>• Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).</li> </ul>

## COMPONENT PARTS

< SYSTEM DESCRIPTION >


[XENON TYPE]

Part	Description
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).

### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL)

#### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Component Parts Location

INFOID:000000005233708



JPLIA1568ZZ

- |  |   |                       |
|--|---|-----------------------|
| 1. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 2. IPDM E/R<br>Refer to <a href="#">PCS-6, "Component Parts Location"</a> . | 3. Parking lamp       |
| 4. Front side marker lamp  | 5. Combination meter<br>(Tail lamp indicator lamp)                          | 6. Combination switch |
| 7. Rear side marker lamp   | 8. Tail lamp  | 9. License plate lamp |

#### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Component Description

INFOID:000000005233709

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges the ON/OFF status of the parking, license plate, tail and side marker lamps according to the vehicle condition.</li> <li>Requests the tail lamp relay ON to IPDM E/R (with CAN communication).</li> <li>Requests the tail lamp indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).

### REAR FOG LAMP SYSTEM


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

## REAR FOG LAMP SYSTEM : Component Parts Location

INFOID:000000005233716



1. BCM  
Refer to [BCS-9. "Component Parts Location"](#).
2. Combination meter  
(Rear fog lamp indicator lamp)
3. Combination switch
4. Rear fog lamp

## REAR FOG LAMP SYSTEM : Component Description

INFOID:000000005233717

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges that the rear fog lamp is turned ON according to the vehicle status</li> <li>- Supplies voltage to the rear fog lamp</li> <li>- Requests the rear fog lamp indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10. "System Diagram"</a> .
Combination meter (Rear fog lamp indicator lamp)	Turns the rear fog lamp indicator lamp ON according to the request from BCM (with CAN communication).

## EXTERIOR LAMP BATTERY SAVER SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Parts Location

INFOID:000000005233720



- |  |   |                      |
|--|---|----------------------|
| 1. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 2. IPDM E/R<br>Refer to <a href="#">PCS-6, "Component Parts Location"</a> . | 3. Combination meter |
| 4. Combination switch  | 5. Daytime running light relay  |                      |
| A. Engine room (LH)  |   |                      |

## EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Description


INFOID:000000005233721

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the exterior lamp OFF according to the vehicle condition.</li> <li>- Requests each relay OFF to IPDM E/R (with CAN communication).</li> <li>- Turn rear fog lamp OFF.</li> </ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .

SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Diagram



HEADLAMP SYSTEM : System Description

INFOID:000000005233691

OUTLINE

- Mobile valve shade type is adopted. Xenon headlamp switches the high beam and the low beam with one xenon bulb each on right and left.
- Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP BASIC OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp ON condition.

Headlamp ON condition

- Lighting switch 2ND
- Lighting switch PASS
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

HEADLAMP HI/LO SWITCHING OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the high beam switching condition.

High beam switching condition

- Lighting switch HI with the headlamp ON
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# SYSTEM

[XENON TYPE]

## < SYSTEM DESCRIPTION >


- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (3) is switched to the high beam position through the actuator rod (2).
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.



## AUTO LIGHT SYSTEM

### AUTO LIGHT SYSTEM : System Diagram

INFOID:000000005233694



### AUTO LIGHT SYSTEM : System Description

INFOID:000000005233695

#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function

#### Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function and the delay timer function.



# SYSTEM

## < SYSTEM DESCRIPTION >

[XENON TYPE]

- Auto light function turns the exterior lamps\* and each illumination ON/OFF automatically according to the outside brightness.
- When auto light system turns the exterior lamps ON with the ignition switch OFF, delay timer function turns the exterior lamps OFF depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), parking lamp, side marker lamp and tail lamp (Headlamp HI depend on the combination switch condition.)

### AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the ignition switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R with CAN communication according to ON/OFF condition by the auto light function.

#### NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT-III. Refer to [EXL-24, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#).

### DELAY TIMER FUNCTION

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens (Door switch ON).
- Turns the exterior lamp OFF a certain period of time\* after closing all doors (Door switch ON→OFF).
- Turns the exterior lamp OFF with the ignition switch ACC or the light switch OFF.


\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT-III. Refer to [EXL-24, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#).

#### NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

## DAYTIME RUNNING LIGHT SYSTEM

### DAYTIME RUNNING LIGHT SYSTEM : System Diagram



### DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000005233699

#### OUTLINE

- Turns the following exterior lamps ON as the daytime running light.
  - Headlamp (LO)
  - Parking, tail, license plate and side marker lamps.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

#### DAYTIME RUNNING LIGHT OPERATION

# SYSTEM

## < SYSTEM DESCRIPTION >

[XENON TYPE]


- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine condition signal (received from ECM with CAN communication).
  - Parking brake switch signal (received from combination meter with CAN communication)
- BCM transmits the daytime running light request signal and low beam request signal to IPDM E/R with CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- While the engine running with the parking brake released.
- Lighting switch OFF
- IPDM E/R turns the integrated headlamp low relay and daytime running light relay ON according to the daytime running light request signal and low beam request signal. And it turns each lamps ON.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram



### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000005233703

#### OUTLINE

Turn signal and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

#### TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

#### HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

#### TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter with CAN communication while the turn signal lamp and the hazard warning lamp operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

#### HIGH FLASHER OPERATION (FAIL-SAFE)

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.


# SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL)

### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Diagram



### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Description

INFOID:000000005233711

#### OUTLINE

Parking, license plate, tail and side marker lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

#### PARKING, LICENSE PLATE, TAIL AND SIDE MARKER LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the daytime running light request signal or position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate, tail and side marker lamps.


Parking, license plate, tail and side marker lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Daytime running light ON judgment
- IPDM E/R turns the daytime running light relay and tail lamp relay ON according to the daytime running light request signal or position light request signal. And turns the parking, license plate, tail, side marker lamps and illuminations ON.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL)

### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System

## Diagram



INFOID:000000005233706

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System Description

INFOID:000000005233707

### OUTLINE

Parking, license plate, tail and side marker lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

### PARKING, LICENSE PLATE, TAIL AND SIDE MARKER LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate, tail and side marker lamps.


Parking, license plate, tail and side marker lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate, tail and side marker lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

## REAR FOG LAMP SYSTEM

### REAR FOG LAMP SYSTEM : System Diagram

INFOID:000000005233714



### REAR FOG LAMP SYSTEM : System Description

INFOID:000000005233715

### OUTLINE

# SYSTEM

## < SYSTEM DESCRIPTION >

[XENON TYPE]

Rear fog lamp is controlled with the combination switch reading function and the rear fog lamp control function of BCM.

### REAR FOG LAMP OPERATION

- BCM detects the condition of the combination switch by the combination switch reading function.
- BCM supplies voltage to rear fog lamp according to the rear fog lamp ON condition.

Rear fog lamp ON condition

- When rear fog lamp switch signal is input (OFF → ON) with headlamp ON and rear fog lamp OFF

Rear fog lamp OFF condition (satisfied any condition as follows)


- When rear fog lamp switch signal is input (OFF → ON) with rear fog lamp ON
- Headlamp OFF

- BCM transmits the rear fog lamp status signal to the combination meter with CAN communication.
- Combination meter turns the rear fog lamp indicator lamp ON according to the rear fog lamp status signal.

### EXTERIOR LAMP BATTERY SAVER SYSTEM

#### EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000005233718



#### EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000005233719

##### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Control by IPDM E/R

- Relay control function

- BCM turns the exterior lamp\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.

\*: Headlamp (LO/Hi), parking lamp, tail lamp, license plate lamp, side marker lamp and rear fog lamp.

##### NOTE:

When the lighting switch is turned AUTO, the exterior lamp battery saver switches to the auto light system. Refer to [EXL-16, "AUTO LIGHT SYSTEM : System Diagram"](#).

##### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the ignition switch is turned from ON → OFF with the exterior lamps ON.

##### NOTE:

- Headlamp control function turns the exterior lamps ON normally when the ignition switch is turned ACC or the engine started (both before and after the exterior lamp battery saver is turned OFF).

## SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamp OFF.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005588097

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>• Read and save the vehicle specification.</li> <li>• Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITONER*			
<ul style="list-style-type: none"> <li>• Intelligent Key system</li> <li>• Engine start system</li> </ul>	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door/Trunk lid open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)		
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## HEADLAMP

### HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000005233723

### WORK SUPPORT

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function



# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Service item	Setting item	Setting	
ILL DELAY SET	MODE 1*	45 sec.	Sets delay timer function timer operation time. (All doors closed)
	MODE 2	Without the function	
	MODE 3	30 sec.	
	MODE 4	60 sec.	
	MODE 5	90 sec.	
	MODE 6	120 sec.	
	MODE 7	150 sec.	
	MODE 8	180 sec.	
CUSTOM A/LIGHT SETTING	MODE 1*	Normal	
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation.)	
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2.)	
	MODE 4	Less sensitive setting than normal setting (Turns ON later than normal operation.)	

\*: Factory setting

## DATA MONITOR

Monitor item [Unit]	Description	
PUSH SW [On/Off]	The switch status input from push-button ignition switch	
ENGINE STATE [Stop/Stall/Crank/Run]	The engine status received from ECM with CAN communication	
VEH SPEED 1 [km/h]	The value of the vehicle speed received from combination meter with CAN communication	
KEY SW-SLOT [On/Off]	Key switch status input from key slot	
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function	
TURN SIGNAL L [On/Off]		
TAIL LAMP SW [On/Off]		
HI BEAM SW [On/Off]		
HEAD LAMP SW1 [On/Off]		
HEAD LAMP SW2 [On/Off]		
PASSING SW [On/Off]		
AUTO LIGHT SW [On/Off]		
FR FOG SW [On/Off]		<b>NOTE:</b> The item is indicated, but not monitored.
RR FOG SW [On/Off]		Each switch status that BCM judges from the combination switch reading function
DOOR SW-DR [On/Off]	The switch status input from driver side door switch	
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch	

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	
DOOR SW-BK [On/Off]	
OPTICAL SENSOR [V]	The value of exterior brightness voltage input from the optical sensor

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the position light request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	Low	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
	Off	
RR FOG LAMP	On	<ul style="list-style-type: none"> <li>• Outputs the voltage to turn the rear fog lamp ON.</li> <li>• Transmits the rear fog lamp status signal to the combination meter with CAN communication to turn the rear fog lamp indicator lamp ON.</li> </ul>
	Off	<ul style="list-style-type: none"> <li>• Stops the voltage to turn the rear fog lamp OFF.</li> <li>• Stops the rear fog lamp status signal transmission.</li> </ul>
DAYTIME RUNNING LIGHT	On	Transmits the low beam request signal and the daytime running light request signal with CAN communication to turn the headlamp (LO), parking, license plate, tail and side marker lamps ON.
	Off	Stops the low beam request signal and the daytime running light request signal transmission.
CORNERING LAMP	RH	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	Off	
ILL DIM SIGNAL	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
	Off	

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000005233724

## WORK SUPPORT

Service item	Setting item	Setting
HAZARD ANSWER BACK	Lock Only*	With locking only
	Unlk Only	With unlocking only
	Lock/Unlk	With locking/unlocking
	Off	Without the function
		Sets the hazard warning lamp answer back function when the door is lock/unlock with the request switch or the key fob.

\*: Factory setting

## DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from the request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from the request switch (passenger side)
PUSH SW [On/Off]	The switch status input from the push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Lock signal status received from the remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from the remote keyless entry receiver
RKE-PANIC [On/Off]	Panic alarm signal status received from the remote keyless entry receiver

## ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to blink the right side turn signal lamps.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	Off	Stops the voltage to turn the turn signal lamps OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000005588098

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side maker lamps
- Tail lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)  
**NOTE:**  
 When auto active test is performed with hood opened, sprinkle water on windshield beforehand.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.  
**CAUTION:**  
**Close passenger door.**
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-88](#), "[Component Function Check](#)".
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Side maker lamps</li> <li>• Tail lamps</li> </ul>	10 seconds
4	Headlamps	LO for 10 seconds → HI ON ⇔ OFF 5 times
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6*	Cooling fan	MID for 5 seconds → HI for 5 seconds


\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Side maker lamps</li> <li>• Tail lamps</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• Unified meter and A/C amp. signal input circuit</li> <li>• CAN communication signal between unified meter and A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and unified meter and A/C amp.</li> <li>• Combination meter</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	<p style="text-align: center;">YES</p> <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		<p style="text-align: center;">NO</p> <ul style="list-style-type: none"> <li>• Cooling fan</li> <li>• Harness or connector between cooling fan and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connector between IPDM E/R and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000005588099

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-32, "DTC Index"](#).

### DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIG- NALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	<b>NOTE:</b> The item is indicated, but not monitored.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor Item [Unit]	MAIN SIG- NALS	Description
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the clutch interlock switch (M/T models) or shift position (A/T models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay request received from BCM via CAN communication.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with daytime running light system.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

Test item

Test item	Operation	Description
CORNERING LAMP	Off	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay 1 and horn relay 2 for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.

## DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation	Description
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and daytime running light relay. <b>NOTE:</b> Daytime running light relay is with daytime running light system only.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	<b>NOTE:</b> The item is indicated, but cannot be tested.



# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000005402599

ECU	Reference
BCM	<a href="#">BCS-51, "Reference Value"</a>
	<a href="#">BCS-82, "Fail-safe"</a>
	<a href="#">BCS-85, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-86, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-20, "Reference Value"</a>
	<a href="#">PCS-30, "Fail-safe"</a>
	<a href="#">PCS-32, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP SYSTEM

[XENON TYPE]


< WIRING DIAGRAM >

## WIRING DIAGRAM

### HEADLAMP SYSTEM

Wiring Diagram

INFOID:000000005233766




# HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


## HEADLAMP

Connector No.	E5
Connector Name	SWAYLE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20PW-CS12-M4-TV



45	G	-
46	V	-

Connector No.	E8
Connector Name	SWAYLE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	INS09PW-OS




Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
16	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-

Connector No.	E58
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	P	-
6	GR	-
7	LG	-
8	EG	-
8	O	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH60PW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	-
9	B	-
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-

Terminal No.	Color of Wire	Signal Name [Specification]
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	R	-
44	GR	- [Roadster models with M/T]
45	EG	- [Coupe models]
45	O	- [Roadster models]
46	W	-
47	P	-
58	SHIELD	-
59	L	-
70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	EG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

JCLWM4050GB

# HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## HEADLAMP

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-MZ




Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
8C	R	-
9C	O	-
10C	L	-
11C	LG	-
12C	O	-


Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH8GMH-CS (6-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	-
9	B	-
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	-
21	R	-
31	L	-
31	BR	-
32	Y	-
32	V	-
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	G	-
44	R	-
45	O	-
46	G	-
47	BR	-
58	SHIELD	-


59	L	-
70	R	-
80	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	Y	-
87	V	-
87	G	-
89	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	-
7	V	-
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	SB	-
5	L	-
6	B	-
7	V	-
8	O	-
9	Y	-
10	R	-
11	LG	-
12	P	-
13	BR	-
14	G	-

# HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## HEADLAMP

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH4FV-NH



1	2	3	4	5	6	8	9	10	12
15	16	17	18	19	20	21	22	23	24

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PUL SE)
4	Y	VEHICLE SPEED SIGNAL (8-PUL SE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
8	BR	COMMUNICATION SIGNAL (METER->TRIPLE METER)
9	ER	COMMUNICATION SIGNAL (TRIPLE METER->METER)
10	L	S-MODE SWITCH SIGNAL
12	G	ACC POWER SUPPLY
15	L	AIR BAG SIGNAL
16	R	GROUND
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL
19	G	A.C. AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	GROUND
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M54
Connector Name	COMBINATION METER
Connector Type	TH16FV-NH



25	26	27	28	29	32		
33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
25	W	ALTERNATOR SIGNAL
26	O	PARKING BRAKE SWITCH SIGNAL
27	LG	BRAKE FLUID LEVEL SWITCH SIGNAL

28	Y	SECURITY SIGNAL
29	GR	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER DOWN SIGNAL
33	O	PADDLE SHIFTER UP SIGNAL
34	BR	FUEL LEVEL SENSOR SIGNAL
35	L	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	L	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) [Except for Mexico]
37	G	NON-MANUAL MODE SIGNAL
38	V	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL

Connector No.	M68
Connector Name	PARKING BRAKE SWITCH
Connector Type	PH1FB-A



1
---

Terminal No.	1	O
Color of Wire		
Signal Name [Specification]		

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



1	2	3
---	---	---

Terminal No.	1	W
Color of Wire		
Signal Name [Specification]		
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS16FH-CS



4	5	8	9	11	13	14	15	17	18	19
---	---	---	---	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Cause models]
8	V	SUPER LOCK OUTPUT [Reader models]
9	G	ALL DOOR FUEL LID LOCK OUTPUT
11	BR	DRIVER DOOR FUEL LID UNLOCK OUTPUT
13	B	BAT (USE)
14	R	IGND
15	Y	PUSH-BUTTON IGNITION SW ILL POWER
17	W	ACC IND
18	O	TURN SIGNAL RH (FRONT SIDE)
19	P	TURN SIGNAL LH (FRONT SIDE)
19	V	ROOM LAMP TIMER CONTROL [Cause models]
19	V	ROOM LAMP TIMER CONTROL [Reader models]

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



61	63	65	67	68	69	70	71	72	73	74	75	76	77	78
81	83	85	87	88	89	90	91	92	93	94	95	96	97	98

Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Reader models with M/T]
72	L	ROOM ANT 2- [Except for reader models with M/T]
73	G	ROOM ANT 2+ [Reader models with M/T]
73	P	ROOM ANT 2+ [Except for reader models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	W	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]

78	Y	ROOM ANT 1- [With M/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	MATS ANT AMP-
81	W	MATS ANT AMP+
82	R	IGN RELAY (F/B) CONT
83	Y	KYLS ENT RECEIVER (FRONT) [Reader models with M/T]
84	GR	KYLS ENT RECEIVER (REAR) [Reader models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A.T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Cause models with M/T]
99	R	CLUTCH PEDAL POS SW [Reader models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Reader models with M/T]
100	GR	DRIVER DOOR REQUEST SW [Reader models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Except for reader models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Except for reader models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Reader models with M/T]
110	P	HAZARD SW [Except for reader models with M/T]
111	Y	S/L UNIT COMM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## HEADLAMP

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4DFG-IN1



123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COMM [Couple models]
132	V	P/W SW & SOFT TOP C/U COMM [Resistor models]
133	R	PUSH BUTTON OPERATION SW (L POWER) [Resistor models with M/T]
133	G	PUSH BUTTON OPERATION SW (R POWER) [Resistor models with M/T]
134	GR	LOCK IND
137	O	RECEIVER/SENSOR GND [Resistor models with M/T]
137	P	RECEIVER/SENSOR GND [Except for resistor models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./K/LS ENT (REAR) RECEIV COMM
140	G	SHFT N/P (With A/T)
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

JCLWM4053GB

# AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

## AUTO LIGHT SYSTEM

### Wiring Diagram

INFOID:000000005233767



2009/07/10

JCLWM4062GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## AUTO LIGHT SYSTEM


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THB07V-C516-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	- [Coupe models]
3	O	- [Roadster models]
4	Y	-
5	W	-
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	- [Coupe models]
33	W	- [Roadster models]
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	SB	-
47	V	-
48	SHIELD	-


51	W	-
52	R	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	- [Coupe models]
84	L	- [Roadster models]
85	LG	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	- [Coupe models]
94	G	- [Roadster models]
95	GR	- [Coupe models]
95	LG	- [Roadster models]
96	L	-
97	Y	-
98	W	- [Coupe models]
98	Y/B	- [Roadster models]
99	LG	-
100	B	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B63
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-
3	B	-

JCLWM4063GB




# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


## AUTO LIGHT SYSTEM

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH03FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	- [Coupe models]
3	R	- [Roadster models]
4	G	- [Coupe models]
7	R	- [Roadster models]
7	Y	- [Coupe models]
8	LG	- [Roadster models]
9	Y	- [Coupe models]
11	R	- [Roadster models]
20	G	- [Coupe models]
21	R	- [Roadster models]
30	B	- [Coupe models]
40	W	- [Roadster models]
41	V	- [Coupe models]
42	G	- [Roadster models]
43	L	- [Coupe models]
51	P	- [Roadster models]
52	L	- [Coupe models]
53	SHIELD	- [Roadster models]
54	BR	- [Coupe models]
55	Y	- [Roadster models]
56	SHIELD	- [Coupe models]
57	G	- [Roadster models]
58	R	- [Coupe models]
58	L	- [Roadster models]
59	B	- [Coupe models]
60	W	- [Roadster models]
61	GR	- [Coupe models]
62	B	- [Roadster models]
63	Y	- [Coupe models]
64	V	- [Roadster models]
65	SB	- [Coupe models]
66	BG	- [Roadster models]
66	O	- [Coupe models]
67	Y	- [Roadster models]

Connector No.	B216
Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-

Connector No.	E5
Connector Name	POWER IN INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH03FW-CS12-MM-1V



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
18	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-

Connector No.	E6
Connector Name	POWER IN INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH03FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	Y	-
43	SB	-
44	W	-
45	G	-
46	V	-

Connector No.	E6
Connector Name	POWER IN INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS03FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
83	R	-
84	P	-
88	G	-
89	BR	-
90	LG	-

JCLWM4064GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## AUTO LIGHT SYSTEM

Connector No.	E9
Connector Name	IGNITION RELAY POWER DISTRIBUTION MODULE
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
91	P	—
92	BG	— [Coupe models]
93	O	— [Roadster models]
97	V	—
104	LG	—
105	SB	—

Connector No.	E13
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS02FL-M2-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	—
2	SB	—
3	R	—
5	BG	— [Coupe models]
	O	— [Roadster models]

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH8CFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	—
3	L	—
4	L	—
7	B	—
8	P	—
9	L	— [Coupe models]
	B	— [Roadster models]
11	V	—
12	R	—
13	L	—
14	GR	—
15	P	—
16	W	—
17	SB	—
20	LG	—
21	BR	— [Coupe models]
	G	— [Roadster models]
31	L	—
32	Y	—
33	P	—
34	L	—
35	BR	—
36	V	—
37	Y	—
38	R	—
39	B	—
40	W	—
41	LG	—
42	SB	—
43	G	—
44	R	— [Roadster models with M/T]
	GR	— [Except for roadster models with M/T]
45	BG	— [Coupe models]
	O	— [Roadster models]
46	W	—
47	P	—
58	SHIELD	—
59	L	—

70	P	—
80	W	—
81	B	—
82	G	—
83	V	—
84	L	—
85	BG	— [Coupe models]
	O	— [Roadster models]
88	LG	—
87	R	—
89	P	—
91	W	—
92	L	—
93	G	—
94	Y	—
96	Y	—
97	BR	—
98	GR	—
99	LG	—
100	BG	— [Coupe models]
	O	— [Roadster models]

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	—
2A	G	—
3A	L	—
4A	P	—
5A	L	—
6A	Y	—
7A	BR	—
8A	L	—


# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## AUTO LIGHT SYSTEM


Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
11	GR	- [Roadster models]
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	- [Roadster models with M/T]
31	BR	- [Except for roadster models with M/T]
32	Y	- [Roadster models with M/T]
32	V	- [Except for roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	R	- [With A/T]
44	V	- [With M/T]
45	O	-
46	G	-
47	BR	-
58	SHIELD	-

59	L	-
70	R	-
80	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	Y	-
87	G	- [Roadster models with M/T]
87	V	- [Except for roadster models with M/T]
89	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	O	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-

21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	-
47	V	- [With M/T]
48	SHIELD	-
51	V	-
52	R	-
57	SHIELD	-
59	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	-
63	BR	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	V	- [Roadster models]
68	SHIELD	-
69	LG	- [Coupe models]
69	P	- [Roadster models]
67	V	- [Coupe models]
67	L	- [Roadster models]
69	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-

81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
93	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
88	RG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	IM24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models]
7	V	- [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## AUTO LIGHT SYSTEM

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M94
Connector Name	OPTICAL SENSOR
Connector Type	TK03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	POWER
2	O	OUTPUT
3	P	GND

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH8GMV-CS (6-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	- [Coupe models]
3	LG	- [Coupe models]
4	O	- [Coupe models]
5	B	- [Coupe models]
6	W	- [Coupe models]
7	LG	- [Coupe models]
8	Y	- [Coupe models]
9	Y	- [Coupe models]
11	R	- [Coupe models]
20	G	- [Coupe models]
21	R	- [Coupe models]
30	B	- [Coupe models]
40	O	- [Coupe models]
41	Y	- [Coupe models]
42	G	- [Coupe models]
43	L	- [Coupe models]
44	SB	- [Coupe models]
51	R	- [Coupe models]
52	G	- [Coupe models]
53	SHIELD	- [Coupe models]
54	LG	- [Coupe models]
54	BR	- [Roadster models]
55	V	- [Coupe models]
55	Y	- [Roadster models]
56	SHIELD	- [Coupe models]
57	G	- [Roadster models]
57	P	- [Coupe models]
58	R	- [Roadster models]
58	L	- [Coupe models]
59	B	- [Roadster models]
60	W	- [Coupe models]
61	GR	- [Roadster models]
62	B	- [Coupe models]
63	Y	- [Roadster models]
64	L	- [Coupe models]
65	G	- [Roadster models]

66	O	- [Coupe models]
66	G	- [Roadster models]
67	V	- [Coupe models]
68	P	- [Roadster models]
68	GR	- [Coupe models]
69	L	- [Roadster models]
69	P	- [Coupe models]
70	O	- [Roadster models]
70	L	- [Coupe models]
80	W	- [Roadster models]
80	L	- [Coupe models]
81	Y	- [Roadster models]
82	W	- [Coupe models]
83	B	- [Roadster models]
84	R	- [Coupe models]
85	G	- [Roadster models]
86	SHIELD	- [Coupe models]
87	G	- [Roadster models]
88	L	- [Coupe models]
88	P	- [Roadster models]
90	SHIELD	- [Coupe models]
92	G	- [Roadster models]
92	LG	- [Coupe models]
93	R	- [Roadster models]
93	V	- [Coupe models]
94	SHIELD	- [Roadster models]
94	G	- [Coupe models]
95	SB	- [Roadster models]
95	LG	- [Coupe models]
97	LG	- [Roadster models]
97	Y	- [Coupe models]
98	Y/B	- [Roadster models]
98	G	- [Coupe models]
100	BR	- [Roadster models]
100	Y	- [Coupe models]

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03PF-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	- [Coupe models]
13	V	- [Roadster models]
2	V	- [Coupe models]

1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
8	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (FUSE)
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE)
18	O	TURN SIGNAL LH (FRONT, SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## AUTO LIGHT SYSTEM

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [W/wh A/T]
78	Y	ROOM ANT 1- [W/wh M/T]
79	R	ROOM ANT 1+ [W/wh A/T]
79	BR	ROOM ANT 1+ [W/wh M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F: B) CONT
83	Y	KYLS ENT RECEIVER (FRONT) [Roadster models with M/T]
83	GR	KYLS ENT RECEIVER (FRONT) [Except for roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-H
91	L	CAN-L
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	SHIFT P [W/wh A/T]
98	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	V	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY

106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FC-NH



137	138	139	140	141	142	143	144	145	146	147	148	149
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COM1 [Coupe models]
132	V	P/W SW & SOFT TOP C/L COM1 [Roadster models]
133	R	POWER WINDOW SW COM2 [Coupe models]
133	G	POWER WINDOW SW COM2 [Roadster models with M/T]
133	GR	POWER WINDOW SW COM2 [Except for roadster models with M/T]
134	GR	LOCK IND
137	O	RECEIVER/SENSOR/OND [Roadster models with M/T]
137	P	RECEIVER/SENSOR AND [Except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS KYLS ENT (REAR) RECEIVE COMM
140	G	SHIFT N/P [W/wh A/T]
140	G	P/N POSITION SW [W/wh M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SR	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW

150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

JCLWM4068GB

# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Wiring Diagram

INFOID:000000005233768

### DAYTIME RUNNING LIGHT SYSTEM



2009/07/10


JCLWM4054GB

# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

CP : Coupe models  
RS : Roadster models



JCLWM4055GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	B89
Connector Name	WIRE TO WIRE
Connector Type	RS08FY-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	R	- [Coupe models]
3	V	- [Roadster models]
4	GR	-
5	EG	- [Coupe models]
6	BR	- [Roadster models]
7	LG	-
8	R	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS06FY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	- [Coupe models]
3	B	- [Roadster models]
4	LG	-
6	O	- [Roadster models]

Connector No.	B64
Connector Name	WIRE TO WIRE
Connector Type	RS04FE-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	W	- [Coupe models]
3	GR	- [Roadster models]
4	B	-

Connector No.	B67
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS06FY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	B	-
4	V	-
6	O	- [Roadster models]

Connector No.	B151
Connector Name	WIRE TO WIRE
Connector Type	RSG4MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-

Connector No.	B152
Connector Name	LICENSE PLATE LAMP LH
Connector Type	RK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-


Connector No.	B153
Connector Name	LICENSE PLATE LAMP RH
Connector Type	RK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]

1	B
2	R

Connector No.	E5
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (PDM) (PDM)
Connector Type	TH20FW-C512-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
16	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-



# DAYTIME RUNNING LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	E6
Connector Name	SPWLE-F-INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FV-NH




Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	Y	-
43	SB	-
44	W	-
45	G	-
46	V	-

Connector No.	E8
Connector Name	SPWLE-F-INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FV-CS



Terminal No.	Color of Wire	Signal Name [Specification]
83	R	-
84	P	-
85	G	-
86	BR	-
87	LG	-
88	-	-
89	-	-

Connector No.	E9
Connector Name	SPWLE-F-INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH16FV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
91	P	-
92	BG	- [Coupe models]
93	O	- [Roadster models]
94	V	-
95	LG	-
96	LG	-
97	LG	-
98	SB	-

Connector No.	E13
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS02FL-M2-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	SB	-
3	R	-
4	P	-
5	BG	- [Coupe models]
	O	- [Roadster models]

Connector No.	E28
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	R	-
6	LG	-
7	BR	-
8	P	-

Connector No.	E58
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	P	-
6	GR	-
7	LG	-
8	BG	- [Coupe models]
	O	- [Roadster models]


# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH807V-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	R	- [Roadster models with M/T]
44	GR	- [Except for roadster models with M/T]
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	W	-
47	P	-
58	SHIELD	-
59	L	-


70	P	-
80	W	-
81	P	-
82	C	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

Connector No.	E117
Connector Name	WIRE TO WIRE
Connector Type	NS08MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	O	- [Roadster models with daytime running light system]
2	R	- [Except for roadster models with daytime running light system]
3	Y	-
4	GR	-
5	BG	- [Coupe models]
5	O	- [Roadster models]
6	BR	-
7	P	-
8	BG	- [Coupe models with daytime running light system]
8	O	- [Roadster models with daytime running light system]
8	R	- [Without daytime running light system]

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9C	R	-
7C	B	-
9C	R	- [Coupe models]
9C	O	- [Roadster models]
10C	L	-
11C	LG	-
12C	O	-

JCLWM4058GB

# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM


Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS(E)-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	L	-
4	L	-
7	B	-
8	P	-
9	B	- [Coupe models] - [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models] - [Roadster models]
31	L	- [Roadster models with M/T]
31	BR	- [Except for roadster models with M/T]
32	Y	- [Roadster models with M/T]
32	V	- [Except for roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	G	- [With A/T] - [With M/T]
44	R	-
45	O	-
46	G	-
47	BR	-
58	SHIELD	-


59	L	-
60	R	-
60	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	Y	-
87	V	- [Roadster models with M/T] - [Except for roadster models with M/T]
89	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models] - [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (METER->TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER->METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY

16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL
19	G	A/C AUTO AIR CONDITION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	GROUND
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M54
Connector Name	COMBINATION METER
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
25	W	ALTERNATOR SIGNAL
26	O	PARKING BRAKE SWITCH SIGNAL
27	LG	BRAKE FLUID LEVEL SWITCH SIGNAL
28	Y	SECURITY SIGNAL
29	GR	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER DOWN SIGNAL
33	O	PADDLE SHIFTER UP SIGNAL
34	BR	FUEL LEVEL SENSOR SIGNAL
35	L	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	L	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) (For Model)
36	P	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) (For Model)
37	G	NON-MANUAL MODE SIGNAL
38	V	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	M68
Connector Name	PARKING BRAKE SWITCH
Connector Type	PO1PE-A



Terminal No.	1	O
Color of Wire		
Signal Name [Specification]		

Connector No.	M107
Connector Name	ECM
Connector Type	RN24FG-R28-R-LH-Z



Terminal No.	Color of Wire	Signal Name [Specification]
97	R	APS 1
98	P	APS 2
99	L	AVCC 1-APS 1
100	W	GND-A-APS 1
101	SB	ASCDSW
102	GR	FTPRS
103	G	AVCC2-APS 2
104	GR	GND-APS 2
105	L	PDPRESS
106	W	TF
107	BR	AVCC 2-FTPRS
108	Y	GND ASCDSW
109	G	NEUT-H
110	R	TACHO
112	SB	GND-A-FTPRS
113	P	VEHCAN-LI
114	L	VEHCAN-HI
117	Y	KLINE [Coupe models]
117	V	KLINE [Roadster models]
121	LG	CDGV
122	P	BRAKE

123	B	GND
124	B	GND
125	R	YBR
126	BR	ENG5W
127	B	GND
128	B	GND



Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)


Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
5	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (R/USE)
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT SIDE)
18	O	TURN SIGNAL LH (FRONT SIDE)

19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH00FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2- [Roadster models with M/T]
73	P	ROOM ANT 2- [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]
78	Y	ROOM ANT 1- [With A/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP.
81	W	NATS ANT AMP.
82	R	IGN RELAY (F/B) CONT
83	Y	KYLE ENT RECEIVER (FRONT COMM) [Roadster models with M/T]
83	GR	KYLE ENT RECEIVER (FRONT COMM) [Except for roadster models with M/T]
87	BR	COMBI SW (INPUT 5)
88	V	COMBI SW (INPUT 3)
88	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	G	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]

101	Y	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLE ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLE ENT RECEIVER (REAR) PWR SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 2
109	Y	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

# DAYTIME RUNNING LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-1M



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	PASSENGER DOOR SW
124	LG	TRUNK LID OPENER CANCEL SW
129	O	REAR DEFOGGER SW
130	L	POWER WINDOW SW COMM [Coupe models]
132	Y	P/W SW & SOFT TOP C/U COMM [Resistor models]
133	R	P/WR INITIATION SW (L POWER [Resistor models with M/T])
133	R	P/WR INITIATION SW (R POWER [Resistor models with M/T])
133	G	LOCK IND
134	GR	RECEIVER/SENSOR GND [Resistor models with M/T]
137	O	RECEIVER/SENSOR GND [Resistor models with M/T]
137	P	RECEIVER/SENSOR GND [Resistor models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./K/L'S ENT (REAR) RECELV COMM
140	G	SHIFT N/UP [With A/T]
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

JCLWM4061GB

EXL

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:000000005233769

## TURN SIGNAL AND HAZARD WARNING LAMPS



◊ : With A/T  
◊ : With M/T

2008/09/12

JCLWA2621GB


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THEOPV-CS1.6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	- [Coupe models] - [Roadster models]
3	O	-
4	W	-
5	Y	-
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	- [Coupe models] - [Roadster models]
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	- [Coupe models] - [Roadster models]
46	O	-
47	V	-
48	SHIELD	-


51	W	-
52	R	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	- [Coupe models] - [Roadster models]
84	L	- [Roadster models]
85	LG	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	- [Coupe models] - [Roadster models]
94	G	- [Roadster models]
95	GR	- [Coupe models] - [Roadster models]
95	LG	- [Roadster models]
96	L	-
97	Y	-
98	W	-
98	Y/B	- [Coupe models] - [Roadster models]
99	LG	-
100	B	-

Connector No.	B60
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	- [Coupe models] - [Roadster models]
3	B	-
4	LG	-
6	BG	- [Coupe models] - [Roadster models]
8	O	-

Connector No.	B67
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS08FGY-PR




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	B	-
4	V	-
6	BG	- [Coupe models] - [Roadster models]

Connector No.	E24
Connector Name	SIDE TURN SIGNAL LAMP RH
Connector Type	FK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	E28
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	R	-
6	LG	-
7	BR	-
8	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	E55
Connector Name	SIDE TURN SIGNAL LAMP LH
Connector Type	RK02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	- [Coupe models] - [Roadster models]
2	B	-

Connector No.	E58
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS0BFGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	P	-
6	GR	-
7	LG	- [Coupe models] - [Roadster models]
8	O	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models] - [Roadster models]
9	B	-
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models] - [Roadster models]
21	G	-
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	R	- [Roadster models with M/T] - [Except for roadster models with M/T]
44	GR	- [Coupe models] - [Roadster models]
45	BG	-
45	O	- [Roadster models]
46	W	-
46	W	-
47	P	-
58	SHIELD	-
59	L	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
9C	R	- [Coupe models] - [Roadster models]
9C	O	-
10C	L	-
11C	LG	-
12C	O	-

70	P	-
80	W	-
81	B	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models] - [Roadster models]
85	O	-
88	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models] - [Roadster models]
100	O	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS09FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-




# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
11	GR	- [Roadster models]
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	- [Roadster models with M/T]
32	Y	- [Except for roadster models with M/T]
32	V	- [Roadster models with M/T]
33	P	- [Except for roadster models with M/T]
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	R	- [With A/T]
44	V	- [With M/T]
45	O	-
46	G	-
47	BR	-
58	SHIELD	-

59	L	-
70	R	-
80	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	Y	-
87	G	- [Roadster models with M/T]
87	V	- [Except for roadster models with M/T]
89	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	O	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-

21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	W	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-
51	V	-
52	R	-
57	SHIELD	-
59	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	V	- [Roadster models]
68	SHIELD	-
69	LG	- [Coupe models]
69	P	- [Roadster models]
67	V	- [Coupe models]
67	L	- [Roadster models]
69	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-

81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
93	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
88	RG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	IM24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models]
7	V	- [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS


Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL
19	C	A/C AUTO AMP CONNECTION (RESISTOR SIGNAL)
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	GROUND
23	B	FUEL LEVEL SENSOR GROUND
24	Y	

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	INPUT 5
13	BR	INPUT 1
14	G	OUTPUT 2


Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (METER->TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER->METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY


2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
3	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (FUSE)
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT SIDE)
18	O	TURN SIGNAL LH (FRONT SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	L	BACK DOOR OPEN OUTPUT [Coupe models]
23	Y	TRUNK LID OPEN OUTPUT [Roadster models]
24	O	REAR FOG OUTPUT
25	LG	TURN SIGNAL LH (REAR)

Connector No.	M88
Connector Name	WIRE TO WIRE
Connector Type	TH08FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	GR	- [Coupe models]
3	B	- [Roadster models]
4	P	- [Coupe models]
4	G	- [Roadster models]
5	B	-
6	L	-
7	B	-
8	G	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

30	R	LUGGAGE ROOM LAMP OUTPUT
----	---	--------------------------


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS


Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4QFB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [W/h A/T]
78	Y	ROOM ANT 1- [W/h M/T]
79	R	ROOM ANT 1+ [W/h A/T]
79	BR	ROOM ANT 1+ [W/h M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F, B) CONT
83	Y	KYLS ENT RECEIVER (FRONT) COM1 [Roadster models with M/T]
83	GR	KYLS ENT RECEIVER (FRONT) COM2 [Roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-H
90	L	CAN-L
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
98	R	SHIFT P [W/h A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Event for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Event for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY

106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4QFC-NH



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	P/W SW & SOFT TOP C/L COM1 [Coupe models]
132	V	P/W SW & SOFT TOP C/L COM2 [Roadster models]
133	R	REAR LID LOCK SW ILL [Roadster models with M/T]
133	G	REAR LID LOCK SW ILL [Event for roadster models with M/T]
134	GR	LOCK IND
137	O	RECEIVER-SENSOR GND [Roadster models with M/T]
137	P	RECEIVER-SENSOR AND EVENT for roadster models with M/T
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS. KYLS ENT (REAR) RECEIVE COMM
140	G	SHIFT N/P [W/h A/T]
140	G	P/N POSITION SW [W/h M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SR	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW

Connector No.	M256
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	G	BCM
3	SR	ILL+
4	BG	ILL- [Coupe models]
4	O	ILL- [Roadster models]


150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Connector No.	M144
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	GND
2	P	BCM
3	R	ILL+
4	B	ILL-

Connector No.	M252
Connector Name	WIPE TO WIRE
Connector Type	TH08MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	- [Coupe models]
1	O	- [Roadster models]
2	SB	-
3	B	-
4	G	-
5	B	-
6	L	-
7	G	-
8	G	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### Wiring Diagram

INFOID:000000005233770




# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	B89
Connector Name	WIRE TO WIRE
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	R	- [Coupe models]
3	V	- [Roadster models]
4	GR	-
5	BG	- [Coupe models]
6	BR	- [Roadster models]
7	LG	-
8	R	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	- [Coupe models]
3	B	- [Roadster models]
4	LG	-
6	BG	- [Coupe models]
	O	- [Roadster models]

Connector No.	B84
Connector Name	WIRE TO WIRE
Connector Type	RS04FE-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	- [Coupe models]
2	W	- [Roadster models]
3	R	-
4	B	-

Connector No.	B87
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	B	-
4	V	- [Coupe models]
6	BG	- [Roadster models]
	O	-

Connector No.	B151
Connector Name	WIRE TO WIRE
Connector Type	RS04MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-

Connector No.	B152
Connector Name	LICENSE PLATE LAMP LH
Connector Type	RK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	B153
Connector Name	LICENSE PLATE LAMP RH
Connector Type	RK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]

1	B
2	R

Connector No.	E5
Connector Name	IPWLEP (INTELLIGENT POWER DISTRIBUTION MODULE) (POWER POSE)
Connector Type	TH20FW-C512-M4-TV



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
16	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	E6
Connector Name	SPW LPI INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH06FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	Y	- [Coupe models]
43	SB	- [Roadster models]
44	W	-
45	O	-
46	V	-

Connector No.	E9
Connector Name	SPW LPI INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
91	P	-
92	BG	- [Coupe models]
93	O	- [Roadster models]
94	V	-
97	L	-
104	LG	-
105	SB	-

Connector No.	E13
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS02FL-M2-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	SB	-
3	R	-
5	BG	- [Coupe models]
5	O	- [Roadster models]

Connector No.	E28
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS06FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	R	-
6	LG	-
7	BR	-
8	P	-

Connector No.	E58
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS06FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	B/W	-
5	P	-
6	GR	-
7	LG	-
8	BG	- [Coupe models]
8	O	- [Roadster models]

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SB	-
2F	W	-
4F	G	- [Coupe models]
6F	BG	- [Roadster models]
8F	L	-
9F	R	- [Coupe models]
9F	V	- [Roadster models]

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS


Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
36	BR	-
36	V	-
37	Y	-
38	R	-
38	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	R	- [Roadster models with M/T]
44	GR	- [Except for roadster models with M/T]
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	W	-
47	P	-
58	SHIELD	-
58	L	-


70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

Connector No.	E117
Connector Name	WIRE TO WIRE
Connector Type	NS00MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	O	- [Roadster models with daytime running light system]
2	R	- [Except for roadster models with daytime running light system]
3	Y	-
4	GR	-
5	BG	- [Coupe models]
5	O	- [Roadster models]
6	BR	-
7	P	-
8	BG	- [Coupe models with daytime running light system]
8	O	- [Roadster models with daytime running light system]
8	R	- [Without daytime running light system]

Connector No.	M1
Connector Name	FUSE BLOCK (U/B)
Connector Type	NS08FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M2
Connector Name	FUSE BLOCK (U/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1B	Y	-
2B	P	-
4B	G	-
5B	O	-
8B	Y	-
8B	R	-
9B	SB	-

JCLWM4087GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS


Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS1E-TIM



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	- [Roadster models with M/T]
31	BR	- [Except for roadster models with M/T]
32	Y	- [Roadster models with M/T]
32	V	- [Except for roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	G	- [With A/T]
44	R	- [With M/T]
45	O	-
46	G	-
47	BR	-
58	SHIELD	-


59	L	-
70	R	-
80	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	Y	-
87	V	- [Roadster models with M/T]
87	G	- [Except for roadster models with M/T]
89	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models]
7	V	- [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (METERS->TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER->METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY

16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL
19	C	A/C AUTO AMP CONVERSION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	GROUND
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M18
Connector Name	ECM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)



# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS16PW-CS



4	5	6	7	8	9
11	13	14	15	17	18
19					

Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
8	V	SUPER LOCK OUTPUT [Roadster models]
9	G	ALL DOOR FUEL LID LOCK OUTPUT
11	BR	DRIVER DOOR FUEL LID UNLOCK OUTPUT
13	B	BAT.(USE)
14	R	GND
15	Y	PUSH-BUTTON IGNITION SW ILL POWER ACC IND
17	W	TURN SIGNAL RH (FRONT SIDE)
18	O	TURN SIGNAL LH (FRONT SIDE)
19	P	ROOM LAMP-TIMER CONTROL [Coupe models]
19	V	ROOM LAMP-TIMER CONTROL [Roadster models]

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78

Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [W/br. A/T]

78	Y	ROOM ANT 1- [W/br. M/T]
79	R	ROOM ANT 1+ [W/br. A/T]
79	BR	ROOM ANT 1+ [W/br. M/T]
80	GR	MAXIS ANT AMP-
81	W	MAXIS ANT AMP+
82	R	IGN RELAY (F/B) CONT
83	Y	KYLS ENT RECEIVER (FRONT) COM1 [Roadster models with M/T]
83	GR	KYLS ENT RECEIVER (FRONT) COM2 [Roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [W/br. A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



103	104	105	106	107	108	109	110	111

Terminal No.	Color of Wire	Signal Name [Specification]
--------------	---------------	-----------------------------

113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	V	POWER WINDOW SW COMM [Coupe models]
132	V	P/W SW & SOFT TOP C/U COMM [Roadster models]
133	R	PUSH-BUTTON IGNITION SW ILL POWER [Roadster models with M/T]
133	G	PUSH-BUTTON IGNITION SW ILL POWER [Except for roadster models with M/T]
134	GR	LOCK IND
137	O	REGENERATOR SENSOR ENG [Roadster models with M/T]
137	P	REGENERATOR SENSOR [Except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
138	L	TIRE PRESS. KYLS ENT (REAR) RECEV COMM
140	G	SHIFT N/P [W/br. A/T]
140	G	P/N POSITION SW [W/br. M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	L	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# STOP LAMP

< WIRING DIAGRAM >


[XENON TYPE]

## STOP LAMP

Wiring Diagram

INFOID:000000005233771

CP : Coupe models  
RS : Roadster models



STOP LAMP

2009/07/10

JCLWM4079GB

# STOP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

## STOP LAMP

Connector No.	B56
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FBR-CS



5G	4G	3G	2G	1G
12G	11G	10G	9G	8G
7G	6G	5G	4G	3G
2G	1G	—	—	—

Terminal No.	Color of Wire	Signal Name [Specification]
5G	LG	—
10G	W	— [Coupe models]
11G	W	— [Roadster models]
12G	Y	— [Roadster models]

Connector No.	B52
Connector Name	WIRE TO WIRE
Connector Type	TH04MV-NH



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
3	L	—
4	LG	—

Connector No.	B50
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS06FGY-PR



3	6	2	4	1
---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	—
2	R	— [Coupe models]
3	B	— [Roadster models]
4	LG	—
6	BG	— [Coupe models]
6	O	— [Roadster models]

Connector No.	B67
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS06FGY-PR



3	6	2	4	1
---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	—
2	R	—
3	B	—
4	V	—
6	BG	— [Coupe models]
6	O	— [Roadster models]

Connector No.	B72
Connector Name	WIRE TO WIRE
Connector Type	NS04MH-CS



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	B	—
3	L	—
4	LG	—

Connector No.	D42
Connector Name	WIRE TO WIRE
Connector Type	MS04FW-CS



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	B	—
3	B	—
4	LG	—

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Type	TH04FW-NH



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
3	B	—
4	LG	—

Connector No.	D104
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Type	TR02FW



2	1
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	—

Terminal No.	Color of Wire	Signal Name [Specification]
2	B	—



7F	6F	5F	4F	3F	2F	1F
6E	5E	4E	3E	2E	1E	—
—	—	—	—	—	—	—

Terminal No.	Color of Wire	Signal Name [Specification]
1F	SR	—
2F	W	—
4F	G	—
6F	BG	— [Coupe models]
6F	O	— [Roadster models]
8F	L	—
9F	R	— [Coupe models]
9F	V	— [Roadster models]

Connector No.	E10
Connector Name	STOP LAMP SWITCH
Connector Type	MS04FW-LC



1	2
3	4

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	—
2	W	—
3	G	—
4	P	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BACK-UP LAMP

< WIRING DIAGRAM >


[XENON TYPE]

## BACK-UP LAMP

### Wiring Diagram

INFOID:000000005233772

### BACK-UP LAMP



\*: This connector is not shown in "Harness Layout".

2008/09/12

JCLWA2627GB


# BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

## BACK-UP LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THEOPV-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	- [Coupe models]
3	O	- [Roadster models]
4	Y	-
5	W	-
6	V	-
7	LG	-
8	GR	-
9	SB	-
10	Y	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	- [Coupe models]
33	W	- [Roadster models]
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	SB	-
47	V	-
48	SHIELD	-

51	W	-
52	P	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	- [Coupe models]
84	L	- [Roadster models]
85	LG	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	- [Coupe models]
94	G	- [Roadster models]
95	GR	- [Coupe models]
95	LG	- [Roadster models]
96	L	-
97	Y	-
98	W	- [Coupe models]
98	Y/B	- [Roadster models]
99	LG	-
100	B	-

Connector No.	B60
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	- [Coupe models]
2	V	- [Roadster models]
3	B	-
4	LG	-
6	BG	- [Coupe models]
6	O	- [Roadster models]

Connector No.	B67
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	B	-
4	V	-
6	BG	- [Coupe models]
6	O	- [Roadster models]

Connector No.	F61
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	BR	-
3	L	-
4	V	-
5	B	-
6	Y	-
7	W	-
8	P	-
9	GR	-
10	B	-

Connector No.	F56
Connector Name	BACK-UP LAMP SWITCH
Connector Type	RK02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	BG	- [Coupe models]
2	O	- [Roadster models]

JCLWM4081GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

## BACK-UP LAMP


Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK26FW-NS10



2	B	BATT
3	R	CAN-H
4	O	K-LINE
5	C	CUID
6	GR	VIGN
7	L	REV LAMP RLY
8	BR	CAN-L
9	Y	STARTER RLY
10	W/B	GND

Terminal No.	Color of Wire	Signal Name [Specification]
2	G	-
3	W	-
4	R	-
5	B	-
8	L	-
9	Y	-
10	GR	-
19	BG	- [Coupe models]
20	O	- [Roadster models]
28	B	-
29	LG	-
30	R	-
31	BG	- [Coupe models]
31	O	- [Roadster models]
39	W	-
42	G	-
43	P	-
44	L	-
45	Y	-
46	V	-


Connector No.	F301
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FG



Terminal No.	1	W	Signal Name [Specification]	VIGN
--------------	---	---	-----------------------------	------


6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	-
47	V	- [With M/T]
48	SHIELD	-
51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	-
61	SB	- [Roadster models]
62	SHIELD	-
63	R	-
63	BR	- [Coupe models]
64	G	- [Coupe models]
64	Y	- [Roadster models]
65	SHIELD	-
66	LG	-
66	L	- [Coupe models]
66	P	- [Roadster models]
67	V	-
67	L	- [Roadster models]

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS1ZFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
9C	R	- [Coupe models]
9C	O	- [Roadster models]
10C	L	-
11C	LG	-
12C	O	-


Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TR60MP-CS16-TM4



Terminal No.	1	BR	Signal Name [Specification]
2	O	-	
3	LG	-	
4	O	-	

68	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
93	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	W	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	M89
Connector Name	BACK-UP LAMP RELAY
Connector Type	MS20FL-M2-LC




Terminal No.	1	W	Signal Name [Specification]
2	G	-	
3	R	-	
5	O	-	

JCLWM4082GB

# BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
3	EG	- [Course models]
3	O	- [Roadster models]
4	W	-
5	B	-
8	L	-
9	Y	-
10	R	-
19	O	-
20	G	-
28	B	-
29	LG	-
30	LG	-
31	O	-
39	G	-
42	G	-
43	P	-
44	L	-
45	BR	-
46	V	-

JCLWM4083GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

## REAR FOG LAMP SYSTEM

### Wiring Diagram

INFOID:000000005233773

### REAR FOG LAMP



2009/07/10

JCLWM4069GB




# REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## REAR FOG LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	
2	BG	- [Coupe models]
3	O	- [Roadster models]
4	W	
5	Y	
6	V	
7	LG	
8	GR	
9	SB	
11	Y	
12	W	
13	BR	
14	LG	
15	B	
16	V	
20	SB	
21	G	
22	GR	
23	V	
24	O	
25	L	
26	P	
31	W	
32	B	
33	P	- [Coupe models]
33	W	- [Roadster models]
34	R	
35	B	
40	Y	
41	L	
42	GR	
43	BR	
44	R	
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	SB	
47	V	
48	SHIELD	


51	W	
52	R	
57	SHIELD	
58	B	
60	V	
61	SB	
62	SHIELD	
63	BR	
64	Y	
65	SHIELD	
66	P	
67	L	
68	SHIELD	
69	R	
70	G	
71	V	
72	P	
73	BR	
74	GR	
75	O	
80	Y	
81	R	
82	B	
83	GR	
84	G	- [Coupe models]
84	L	- [Roadster models]
85	LG	
86	V	
87	BR	
88	GR	
93	Y	
94	L	- [Coupe models]
94	G	- [Roadster models]
95	GR	- [Coupe models]
95	LG	- [Roadster models]
96	L	
97	Y	
97	W	
98	Y/B	- [Coupe models]
98	LG	- [Roadster models]
99	LG	
100	B	

Connector No.	B/10
Connector Name	REAR FOG LAMP
Connector Type	RS2ZFGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	- [Coupe models]
1	O	- [Roadster models]
2	B	

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
3	L	
4	L	
7	B	
8	P	
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	
12	R	
13	L	
14	GR	
15	P	
16	W	
17	SB	
20	LG	
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	
32	Y	

33	P	
34	L	
35	BR	
36	V	
37	Y	
38	R	
39	B	
40	W	
41	LG	
42	SB	
43	G	
44	R	- [Roadster models with M/T]
44	GR	- [Except for roadster models with M/T]
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	W	
47	P	
58	SHIELD	
59	L	
70	B	
80	W	
81	P	
82	G	
83	V	
84	L	
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	
87	R	
89	P	
91	W	
92	L	
93	G	
94	Y	
96	Y	
97	BR	
98	GR	
99	LG	
100	BG	- [Coupe models]
100	O	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


## REAR FOG LAMP

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-MZ




Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
8C	R	-
9C	O	-
10C	L	-
11C	LG	-
12C	O	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	T18GMH-CS (6-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	L	-
4	L	-
5	B	-
6	P	-
7	L	-
8	L	-
9	B	-
10	GR	-
11	R	-
12	L	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
18	GR	-
19	BR	-
20	GR	-
21	R	-
22	L	-
23	BR	-
24	Y	-
25	V	-
26	P	-
27	L	-
28	L	-
29	L	-
30	L	-
31	GR	-
32	BR	-
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	R	-
45	O	-
46	G	-
47	BR	-
48	SHIELD	-

49	L	-
50	R	-
51	LG	-
52	GR	-
53	V	-
54	L	-
55	BR	-
56	Y	-
57	G	-
58	P	-
59	W	-
60	P	-
61	P	-
62	P	-
63	Y	-
64	Y	-
65	GR	-
66	O	-
67	W	-
68	R	-
69	R	-
70	R	-
71	R	-
72	R	-
73	R	-
74	R	-
75	R	-
76	R	-
77	R	-
78	R	-
79	R	-
80	R	-
81	R	-
82	R	-
83	R	-
84	R	-
85	R	-
86	R	-
87	R	-
88	R	-
89	R	-
90	R	-
91	W	-
92	P	-
93	P	-
94	Y	-
95	P	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-


# REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## REAR FOG LAMP


Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS (F-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-


51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	Y	- [Roadster models]
65	SHIELD	-
66	LG	- [Coupe models]
66	P	- [Roadster models]
67	V	- [Coupe models]
67	L	- [Roadster models]
68	SHIELD	-
68	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
89	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	- [Roadster models]
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FN




Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	V	- [Coupe models]
7	V	- [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	INPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M83
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROGE STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (ME-TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER-METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY
16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL
19	G	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	IM8FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## REAR FOG LAMP

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



4	5	6	7	8	9
11	13	14	15	17	18
19					

Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Course models]
5	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (USE)
13	B	GND
14	R	PUSH BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE)
18	O	TURN SIGNAL LH (FRONT, SIDE)
19	P	ROOM LAMP TIMER CONTROL [Course models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



20	23	24
25	26	30

Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	L	BACK DOOR OPEN OUTPUT [Course models]
23	Y	TRUNK LID OPEN OUTPUT [Roadster models]
24	O	REAR FOG OUTPUT
25	LG	TURN SIGNAL LH (REAR)
30	R	LUGGAGE ROOM LAMP OUTPUT

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2 - [Roadster models with M/T]
72	L	ROOM ANT 2 - [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SR	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1 - [With A/T]
78	Y	ROOM ANT 1 - [With M/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F/B) CONT
83	Y	KYLS ENT RECEIVER (FRONT) COMM [Roadster models with M/T]
83	GR	KYLS ENT RECEIVER (FRONT) COMM [Except for roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Course models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY

106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	V	POWER WINDOW SW COMM [Course models]
133	R	POWER WINDOW SW COMM [Roadster models]
133	G	POWER WINDOW SW COMM [Except for roadster models with M/T]
134	GR	LOCK IND
137	O	RECEIVER SENSOR GND [Roadster models with M/T]
137	P	RECEIVER SENSOR ENT [Except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS/KYLS ENT (REAR) RECEV COMM
140	G	SHIFT N/P [With A/T]
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW

150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT


**BASIC INSPECTION**

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005233689

OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

DETAILED FLOW

**1. INTERVIEW FOR MALFUNCTION**

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

[XENON TYPE]

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# EXTERIOR LAMP FUSE

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DTC/CIRCUIT DIAGNOSIS

### EXTERIOR LAMP FUSE

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:0000000005233729

Fuse list

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A
Headlamp LO (RH)	IPDM E/R	#57	15 A
<ul style="list-style-type: none"><li>• Parking lamp</li><li>• Front side marker lamp</li></ul>	IPDM E/R	#52	10 A
<ul style="list-style-type: none"><li>• Tail lamp</li><li>• Rear side marker lamp</li><li>• License plate lamp</li><li>• Each illumination</li></ul>	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:0000000005233730

### 1.CHECK FUSE

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A
Headlamp LO (RH)	IPDM E/R	#57	15 A
<ul style="list-style-type: none"><li>• Parking lamp</li><li>• Front side marker lamp</li></ul>	IPDM E/R	#52	10 A
<ul style="list-style-type: none"><li>• Tail lamp</li><li>• Rear side marker lamp</li><li>• License plate lamp</li><li>• Each illumination</li></ul>	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

#### Is the fuse fusing?

YES >> Repair the applicable circuit. And then replace the fuse.

NO >> The fuse is normal.

#### WITH DAYTIME RUNNING LIGHT SYSTEM

#### WITH DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:0000000005233731

Fuse list

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A

# EXTERIOR LAMP FUSE

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#57	15 A
<ul style="list-style-type: none"><li>• Daytime running light relay</li><li>- Parking lamp</li><li>- Front side marker lamp</li><li>- Tail lamp</li><li>- Rear side marker lamp</li><li>- License plate lamp</li></ul>	IPDM E/R	#59	10 A
Each illumination	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

## WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233732

### 1. CHECK FUSE

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#54	10 A
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp LO (LH)	IPDM E/R	#56	15 A
Headlamp LO (RH)	IPDM E/R	#57	15 A
<ul style="list-style-type: none"><li>• Daytime running light relay</li><li>- Parking lamp</li><li>- Front side marker lamp</li><li>- Tail lamp</li><li>- Rear side marker lamp</li><li>- License plate lamp</li></ul>	IPDM E/R	#59	10 A
Each illumination	IPDM E/R	#53	10 A
Stop lamp	FUSE BLOCK (J/B)	#7	10 A
Back-up lamp	FUSE BLOCK (J/B)	#4	10 A

#### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.  
NO >> The fuse is normal.



# HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]


## HEADLAMP (HI) CIRCUIT

### Description

INFOID:000000005233733

The high beam solenoid drives the mobile valve shade. And the mobile valve shade switches the high beam and low beam of headlamp.

- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (3) is switched to the high beam position through the actuator rod (2).
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.



### Component Function Check

INFOID:000000005233734

#### 1. CHECK HEADLAMP (HI) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp switches to the high beam.

**Hi** : Headlamp switches to the high beam.

**Off** : Headlamp OFF

#### NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Does the headlamp switch to the high beam?

- YES >> Headlamp (HI) circuit is normal.  
NO >> Refer to [EXL-81, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233735

#### 1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

# HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Terminals			Test item	Voltage (Approx.)	
(+)	(-)				
IPDM E/R			EXTERNAL LAMPS	Ground	
Connector	Terminal				
RH	E8	89	Hi		Battery voltage
LH		90	Off		0 V
			Hi	Battery voltage	
			Off	0 V	

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

## 2.CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	E28	7	Existed
LH		90	E58	

Does continuity exist?

YES >> Replace the front combination lamp.

NO >> Repair the harnesses or connectors.

## 3.CHECK HEADLAMP (HI) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp HI (LH)	IPDM E/R	#54	10 A

Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

## 4.CHECK FRONT COMBINATION LAMP (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector terminal and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E8	89	Ground	Not existed
LH		90		

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP (LO) CIRCUIT

### Description

INFOID:000000005233736

Headlamp (LO) circuit is connected to HID control unit integrated in the headlamp. Headlamp (LO) circuit turns xenon headlamp ON.

For the details of HID control unit and the xenon headlamp, refer to [EXL-85, "Description"](#).

### Component Function Check

INFOID:000000005233737

#### 1. CHECK HEADLAMP (LO) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp is turned ON.

**Lo** : Headlamp ON

**Off** : Headlamp OFF

Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-83, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233738

#### 1. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)		
(+)	(-)					
IPDM E/R			EXTERNAL LAMPS	Battery voltage		
Connector	Terminal					
RH	E8	83			Lo	Battery voltage
		84			Off	0 V
LH	E8	83	Lo	Battery voltage		
		84	Off	0 V		

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

# HEADLAMP (LO) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	E28	5	Existed
LH		84	E58	

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 3. CHECK HEADLAMP (LO) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Lotion	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#57	15 A
Headlamp LO (LH)	IPDM E/R	#56	15 A

Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

## 4. CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	83	Not existed
LH		84	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

## 5. CHECK HEADLAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28	3	Existed
LH	E58	3	

Does continuity exist?

YES >> Perform the xenon headlamp diagnosis. Refer to [EXL-85, "Description"](#).

NO >> Repair the harnesses or connectors.

## XENON HEADLAMP

### Description

INFOID:000000005233739

### OUTLINE


- The lamp light source is by the arch discharge by applying high voltage into the xenon gas-filled bulb instead of the halogen bulb filament.
- Sight becomes more natural and brighter because the amount of light are gained adequately and the color of light is sunshine-like white.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

### ILLUMINATION PRINCIPLE

1. Discharging starts in high voltage pulse between bulb electrodes.
2. Xenon gas is activated by current between electrodes. Pale light is emitted.
3. The luminous tube (bulb) temperature elevates. Evaporated halide is activated by discharge. The color of light changes into white.

#### NOTE:

- Brightness and the color of light may change slightly immediately after the headlamp turned ON until the xenon bulb becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.



### PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; “Light does not turn ON”, “Light blinks”, and “Brightness is inadequate”. The cause often be the xenon bulb. Such malfunctions, however, are occurred occasionally by HID control unit malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

#### WARNING:

- **Never touch the harness, HID control unit, the inside and metal part of lamp when turning the headlamp ON or operating the light switch.**
- **Never work with wet hands.**

#### CAUTION:

- **Never perform HID control unit circuit diagnosis with a circuit tester or an equivalent.**
- **Temporarily install the headlamp on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.**
- **Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.**
- **Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.**

#### NOTE:

- Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

### Diagnosis Procedure

INFOID:000000005233740

#### 1. CHECK XENON BULB

Install the normal bulb to the applicable headlamp. Check that the xenon bulb is turned ON.

Is the headlamp turned ON?

- YES >> Replace the xenon bulb.
- NO >> GO TO 2.

#### 2. CHECK HID CONTROL UNIT

Install the normal HID control unit to the applicable headlamp. Check that the lamp is turned ON.

Is the headlamp turned ON?

## XENON HEADLAMP

[XENON TYPE]

### < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> Replace HID control unit.
- NO >> GO TO 3.

### 3.CHECK XENON HEADLAMP HOUSING ASSEMBLY

---

Install the normal xenon headlamp housing assembly to the applicable headlamp. Check that the xenon headlamp is turned ON.

#### Is the headlamp turned ON?

- YES >> Replace the front combination lamp. (Xenon headlamp housing voltage converter malfunctions.)
- NO >> Xenon headlamp is normal. Check the headlamp control system.

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

### Component Function Check

INFOID:000000005233741

#### 1.CHECK DAYTIME RUNNING LIGHT OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the parking lamp and tail lamp are turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test item, check that parking lamp and tail lamp are turned ON.

**TAIL : Parking lamp and tail lamp ON**

**Off : Parking lamp and tail lamp OFF**

#### Are parking lamp and tail lamp turned ON?

- YES >> Daytime running light relay circuit is normal.  
 NO >> Refer to [EXL-87, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233742

#### 1.CHECK DAYTIME RUNNING LIGHT RELAY FUSE

Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Daytime running light relay	IPDM E/R	#59	10 A

#### Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.  
 NO >> GO TO 2.

#### 2.CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove the daytime running light relay.
2. Check voltage between the daytime running light relay harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Daytime running light relay		Battery voltage
Connector	Terminal	
E13	1 3	

#### Is the measurement value normal?

- YES >> GO TO 3.  
 NO >> Repair harnesses or connectors.

#### 3.CHECK DAYTIME RUNNING LIGHT RELAY

Check the daytime running light relay. Refer to [EXL-88, "Component Inspection"](#).

#### Is the daytime running light relay normal?

- YES >> GO TO 4.  
 NO >> Replace the daytime running light relay.

#### 4.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OUTPUT

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Install the daytime running light relay.

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

- Turn the ignition switch ON.
- Select "EXTERNAL LAMPS" of IPDM E/R active test item.
- With operating the test item, check voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	0 V
Connector	Terminal		
E9	105	TAIL	0 V
		Off	Battery voltage

### Is the measurement value normal?

YES >> Check the parking lamp circuit. Refer to [EXL-92, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

Fixed at 0 V >> GO TO 5.

Fixed at battery voltage >> Replace IPDM E/R.

## 5. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OPEN CIRCUIT

- Remove the daytime running light relay.
- Disconnect IPDM E/R harness connector.
- Check continuity between the IPDM E/R harness connector and the daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E9	105	E13	2	Existed

### Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

## 6. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL SHORT CIRCUIT

Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E9	105		Not existed

### Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace IPDM E/R.

## Component Inspection

INFOID:000000005233743

## 1. CHECK DAYTIME RUNNING LIGHT RELAY EXCITATION COIL SIDE

- Turn the ignition switch OFF.
- Remove the daytime running light relay.
- Check continuity of the daytime running light relay excitation coil side.

Daytime running light relay		Continuity
Terminal		
1	2	Existed

### Does continuity exist?

YES >> GO TO 2.

NO >> Replace the daytime running light relay.



# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## 2. CHECK DAYTIME RUNNING LIGHT RELAY CONTACT SIDE

1. Apply battery voltage to the daytime running light relay between the terminals 1 and 2.
2. Check continuity of the daytime running light relay.

Daytime running light relay		Condition	Continuity
Terminal		Voltage	
3	4	Apply	Existed
		Not Apply	Not existed

### Does continuity exist?

- YES >> Daytime running light relay is normal.  
NO >> Replace the daytime running light relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## PARKING LAMP CIRCUIT

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000005233744

#### 1. CHECK PARKING LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**

**Off : Parking lamp OFF**

Is the parking lamp turned ON?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-90, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233745

#### 1. CHECK PARKING LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"><li>• Parking lamp</li><li>• Front side marker lamp</li></ul>	IPDM E/R	#52	10 A

Is the fuse fusing?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front combination lamp connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E9	91	Not existed	
LH		92		

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if fusing is found again.)

#### 3. CHECK PARKING LAMP BULB AND FRONT SIDE MARKER LAMP

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 4.

NO >> Replace the bulb.

#### 4. CHECK PARKING LAMP OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Disconnect the front combination lamp connector.

# PARKING LAMP CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)	(-)			
IPDM E/R			EXTERNAL LAMPS	Battery voltage
Connector	Terminal			
RH	E9	91	TAIL	0 V
LH		92	Off	Battery voltage
			Off	0 V

Is the measurement value normal?

- YES >> GO TO 5.  
 NO >> Replace IPDM E/R.

## 5.CHECK PARKING LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R			Front combination lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E9	91	E28	8	Existed
LH		92	E58	8	

Does continuity exist?

- YES >> GO TO 6.  
 NO >> Repair the harnesses or connectors.

## 6.CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp			Ground	Continuity
Connector	Terminal			
RH	E28	4	Existed	
LH	E58	4		

Does continuity exist?

- YES >> Replace the front combination lamp.  
 NO >> Repair the harnesses or connectors.

## WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000005233746

### NOTE:

Check the daytime running light relay circuit first if the parking lamp, tail lamp, license plate lamp and side marker lamp are not turned ON. Refer to [EXL-87. "Component Function Check"](#).

## 1.CHECK PARKING LAMP OPERATION

### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11. "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

# PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## ⓐCONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.  
NO >> Refer to [EXL-92. "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

## WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233747

### 1.CHECK PARKING LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.  
NO >> Replace the bulb.

### 2.CHECK PARKING LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Remove the daytime running light relay.
3. Disconnect the front combination lamp connector.
4. Check continuity between the daytime running light relay harness connector and the front combination lamp harness connector.

Daytime running light relay		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E13	E28	8	Existed
LH		E58	8	

Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair the harnesses or connectors.

### 3.CHECK PARKING LAMP SHORT CIRCUIT

Check continuity between the daytime running light relay harness connector and the ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		
E13	5		Not existed

Does continuity exist?

- YES >> Repair the harnesses or connectors.  
NO >> GO TO 4.

### 4.CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp			Ground	Continuity
Connector	Terminal			
RH	E28	4		Existed
LH	E58	4		

Does continuity exist?

- YES >> Replace the front combination lamp.  
NO >> Repair the harnesses or connectors.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Description

INFOID:0000000005233748

BCM performs the high flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

#### NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

### Component Function Check

INFOID:0000000005233749

#### 1. CHECK TURN SIGNAL LAMP

##### ⓂCONSULT-III ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

**LH** : Turn signal lamp LH blinking

**RH** : Turn signal lamp RH blinking

**Off** : The turn signal lamp OFF

Does the turn signal lamp blink?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-93. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005233750

#### 1. CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

#### 2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

##### ⓂCONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector, side turn signal lamp connector or the rear combination lamp connector.
3. Turn the ignition switch ON.
4. Select "FLASHER" of BCM (FLASHER) active test item.
5. With operating the turn signal switch, check the voltage between the BCM harness connector and the ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# TURN SIGNAL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Terminals			Test item	Voltage (Approx.)
(+)	(-)			
BCM			FLASHER	
Connector	Terminal			
RH	M119	17	RH	
Off		Ground		0 V
LH	M119	18	LH	
Off		Ground		0 V

Terminals			Test item	Voltage (Approx.)
(+)	(-)			
BCM			FLASHER	
Connector	Terminal			
RH	M120	20	RH	
Off		Ground		0 V
LH	M120	25	LH	
Off		Ground		0 V

Is the measurement value normal?

- YES >> GO TO 3.
- NO >> Replace BCM.

### 3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check the continuity between the BCM harness connector and the front combination lamp, side turn signal lamp or rear combination lamp harness connector.

# TURN SIGNAL LAMP CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

Front turn signal lamp

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M119	17	E28	Existed
LH		18	E58	

Side turn signal lamp

BCM		Side turn signal lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M119	17	E24	Existed
LH		18	E55	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M120	20	B67	Existed
LH		25	B60	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

### 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector and the ground.

Front/side

BCM		Ground	Continuity
Connector	Terminal		
RH	M119	17	Not existed
LH		18	

Rear

BCM		Ground	Continuity
Connector	Terminal		
RH	M120	20	Not existed
LH		25	

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

### 5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check the continuity between the front combination lamp, side turn signal lamp or rear combination lamp and the ground.

Front turn signal lamp

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28	4	Existed
LH	E58	4	

# TURN SIGNAL LAMP CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

### Side turn signal lamp

Side turn signal lamp			Ground	Continuity
Connector		Terminal		Existed
RH	E24	2		
LH	E55	2		

### Rear turn signal lamp

Rear combination lamp			Ground	Continuity
Connector		Terminal		Existed
RH	B67	3		
LH	B60	3		

### Does continuity exist?

- YES >> Replace the front combination lamp, side turn signal lamp or rear combination lamp.
- NO >> Repair the harnesses or connectors.



# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## OPTICAL SENSOR

### Description

INFOID:000000005233751

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.

### Component Function Check

INFOID:000000005233752

#### 1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEADLAMP) data monitor item.
3. Turn the lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTICAL SENSOR	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

##### Is the item status normal?

- YES >> Optical sensor is normal.  
 NO >> Refer to [EXL-97, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233753

#### 1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn the ignition switch ON.
2. Turn the lighting switch AUTO.
3. Check the voltage between the optical sensor harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		5 V
Connector	Ground	
M94		

##### Is the measurement value normal?

- YES >> GO TO 2.  
 NO >> GO TO 4.

#### 2.CHECK OPTICAL SENSOR GROUND INPUT

Check the voltage between the optical sensor harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		0 V
Connector	Ground	
M94		

##### Is the measurement value normal?

- YES >> GO TO 3.  
 NO >> GO TO 6.

#### 3.CHECK OPTICAL SENSOR SIGNAL OUTPUT

# OPTICAL SENSOR

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

With illuminating the optical sensor, check the voltage between the optical sensor harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Optical sensor		Optical sensor	
Connector	Terminal		
M94	2	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

### Is the measurement value normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

## 4.CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	1	M123	138	Existed

### Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 5.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M94	1		Not existed

### Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

## 6.CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	3	M123	137	Existed

### Does continuity exist?

YES >> Replace BCM.

NO >> Repair the harnesses or connectors.

## 7.CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	2	M123	113	Existed

Does continuity exist?

YES >> GO TO 8.

NO >> Repair the harnesses or connectors.

## 8.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M94	2		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HAZARD SWITCH

### Component Function Check

INFOID:000000005233754

#### 1.CHECK HAZARD SWITCH SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the item status normal?


- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-100, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233755

#### 1.CHECK HAZARD SWITCH SIGNAL INPUT

With operating the hazard switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Hazard switch	0 V
Connector	Terminal		
M122	110	ON	
		OFF	
	Ground		

JPMIA0012GB

Is the measurement value normal?

- YES >> Replace BCM.  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the hazard switch connector and BCM connector.
3. Check continuity between the hazard switch harness connector and the BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M144	2	M122	110	Existed

Does continuity exist?

- YES >> GO TO 3.  
 NO >> Repair the harnesses or connectors.

#### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Hazard switch		Ground	Continuity
Connector	Terminal		
M144	2		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 4.

## 4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M144	1		Existed

Does continuity exist?

YES >> Replace the hazard switch.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# TAIL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## TAIL LAMP CIRCUIT

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000005233756

#### 1.CHECK TAIL LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL : Tail lamp ON**

**Off : Tail lamp OFF**

Is the tail lamp turned ON?

YES >> Tail lamp circuit is normal.

NO >> Refer to [EXL-102, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233757

#### 1.CHECK TAIL LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"><li>• Tail lamp</li><li>• Rear side marker lamp</li><li>• License plate lamp</li></ul>	IPDM E/R	#53	10 A

Is the fuse fusing?

YES >> Repair the malfunctioning part before replacing the fuse.

NO >> GO TO 2.

#### 2.CHECK TAIL LAMP OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Disconnect the rear combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	Battery voltage
Connector	Terminal		
E5	7	TAIL	
		Off	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R.

#### 3.CHECK TAIL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.

# TAIL LAMP CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E5	7	B67	2	Existed
LH			B60		

### Does continuity exist?

- YES >> GO TO 4.  
NO >> Repair the harnesses or connectors.

## 4.CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp			Ground	Continuity
Connector	Terminal			
RH	B67	3	Ground	Existed
LH	B60	3		

### Does continuity exist?

- YES >> Replace the rear combination lamp.  
NO >> Repair the harnesses or connectors.

## WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000005233758

### NOTE:

Check the daytime running light relay circuit first if the parking lamp, tail lamp, license plate lamp and side marker lamp are not turned ON. Refer to [EXL-87. "Component Function Check"](#).

## 1.CHECK TAIL LAMP OPERATION

### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11. "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

### Ⓜ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL : Tail lamp ON**

**Off : Tail lamp OFF**

### Is the tail lamp turned ON?

- YES >> Tail lamp circuit is normal.  
NO >> Refer to [EXL-103. "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure INFOID:000000005233759

## 1.CHECK TAIL LAMP BULB

Check the applicable lamp bulb.

### Is the bulb normal?

- YES >> GO TO 2.  
NO >> Replace the bulb.

## 2.CHECK TAIL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.

# TAIL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

2. Remove the daytime running light relay.
3. Disconnect the rear combination lamp connector.
4. Check continuity between the daytime running light relay harness connector and the rear combination lamp harness connector.

Daytime running light relay		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E13	5	B67	Existed
LH			B60	

**Does continuity exist?**

- YES >> GO TO 3.  
 NO >> Repair the harnesses or connectors.

### 3. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp			Ground	Continuity
Connector	Terminal			
RH	B67	3		Existed
LH	B60	3		

**Does continuity exist?**

- YES >> Replace the rear combination lamp.  
 NO >> Repair the harnesses or connectors.



# LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## LICENSE PLATE LAMP CIRCUIT WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000005233760

#### NOTE:

Check the tail lamp circuit if the tail lamp and the license plate lamp are not turned ON.

#### 1.CHECK LICENSE PLATE LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

##### Ⓜ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**  
**Off : License plate lamp OFF**

Is the license plate lamp turned ON?

- YES >> License plate lamp circuit is normal.  
 NO >> Refer to [EXL-105, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233761

#### 1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.  
 NO >> Replace the bulb.

#### 2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector and the license plate lamp connector.
3. Check continuity between the IPDM E/R harness connector and the license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E5	7	B153	Existed
LH			B152	

Does continuity exist?

- YES >> GO TO 3.  
 NO >> Repair the harnesses or connectors.

#### 3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp			Ground	Continuity
Connector	Terminal			
RH	B153	1	Existed	
LH	B152	1		

Does continuity exist?

- YES >> Replace the license plate lamp.

# LICENSE PLATE LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair the harnesses or connectors.  
WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000005233762

## NOTE:

Check the daytime running light relay circuit first if the parking lamp, tail lamp, license plate lamp and side marker lamp are not turned ON. Refer to [EXL-87, "Component Function Check"](#).

### 1.CHECK LICENSE PLATE LAMP OPERATION

#### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

#### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**  
**Off : License plate lamp OFF**

Is the license plate lamp turned ON?

- YES >> License plate lamp circuit is normal.  
NO >> Refer to [EXL-106, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure INFOID:000000005233763

### 1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.  
NO >> Replace the bulb.

### 2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Remove the daytime running light relay.
3. Disconnect the license plate lamp connector.
4. Check continuity between the daytime running light relay harness connector and the license plate lamp harness connector.

Daytime running light relay		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E13	5	B153	Existed
LH			B152	

Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair the harnesses or connectors.

### 3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp			Ground	Continuity
Connector	Terminal			
RH	B153	1	Existed	
LH	B152	1		

Does continuity exist?

# LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

- YES >> Replace the license plate lamp.
- NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N

O

P

# REAR FOG LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## REAR FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000005233764

#### 1. CHECK REAR FOG LAMP OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
2. With operating the test items, check that the rear fog lamp is turned ON.

**On** : Rear fog lamp ON  
**Off** : Rear fog lamp OFF

##### Is rear fog lamp turned ON?

- YES >> Rear fog lamp circuit is normal.  
NO >> Refer to [EXL-108, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233765

#### 1. CHECK REAR FOG LAMP BULB

Check the applicable lamp bulb.

##### Is the bulb normal?

- YES >> GO TO 2.  
NO >> Replace the bulb.

#### 2. CHECK REAR FOG LAMP OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the rear fog lamp connector.
3. Turn the ignition switch ON.
4. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
5. With operating the test items, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (approx.)
(+)	(-)		
BCM		RR FOG LAMP	Battery voltage
Connector	Terminal		
M120	24	On	Battery voltage
		Off	0 V

##### Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Replace BCM.

#### 3. CHECK REAR FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear fog lamp harness connector.

BCM		Rear fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
M120	24	B70	1	Existed

##### Does continuity exist?

- YES >> GO TO 4.  
NO >> Repair the harnesses or connectors.

# REAR FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## 4. CHECK REAR FOG LAMP SHORT CIRCUIT

Check for continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	24		Not existed

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

## 5. CHECK REAR FOG LAMP GROUND OPEN CIRCUIT

Check for continuity between rear fog lamp harness connector and the ground.

Rear fog lamp		Ground	Continuity
Connector	Terminal		
B70	2		Existed

Does continuity exist?

YES >> Replace the rear fog lamp.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS WITHOUT DAYTIME RUNNING LIGHT SYSTEM

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000005233783

**CAUTION:**

**Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.**

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> <li>Fuse</li> <li>Harness between IPDM E/R and the front combination lamp</li> <li>Front combination lamp (High beam solenoid)</li> <li>IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-81</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to <a href="#">EXL-115</a> .	
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		Combination meter	<ul style="list-style-type: none"> <li>Combination meter Data monitor "HI-BEAM IND"</li> <li>BCM (HEAD LAMP) Active test "HEADLAMP"</li> </ul>
Headlamp does not switch to the low beam.	One side	Front combination lamp (High beam solenoid)	—
	Both sides	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between the combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .
		High beam request signal	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>Fuse</li> <li>Xenon bulb</li> <li>Harness between IPDM E/R and the front combination lamp</li> <li>Front combination lamp (xenon headlamp)</li> <li>IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-83</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-116</a> .	
Headlamp is not turned OFF.	When the ignition switch is turned ON	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-116</a> .	
	The ignition switch is turned OFF (After activating the battery saver).	IPDM E/R	—
Headlamp is not turned ON/OFF with the lighting switch AUTO.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between the combination switch and BCM</li> <li>BCM</li> </ul>		Combination switch Refer to <a href="#">BCS-89</a> .
	<ul style="list-style-type: none"> <li>Optical sensor</li> <li>Harness between the optical sensor and BCM</li> <li>BCM</li> </ul>		Optical sensor Refer to <a href="#">EXL-97</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item		
Parking lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-90</a> .	A	
Tail lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• Rear combination lamp</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-102</a> .	B	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Harness between IPDM E/R and the license plate lamp</li> <li>• License plate lamp</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-105</a> .	C	
Tail lamp and license plate lamp are not turned ON.	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-102</a> .	D	
<ul style="list-style-type: none"> <li>• Parking lamp, tail lamp and license plate lamp are not turned ON.</li> <li>• Parking lamp, tail lamp and license plate lamp are not turned OFF.</li> </ul> (Each illumination is turned ON/OFF.)	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-117</a> .		E	
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-93</a> .	F
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .	G
Turn signal indicator lamp does not blink. (The turn signal indicator lamp is normal.)	One side	Combination meter	—	H
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>- Combination meter</li> <li>- BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "TURN IND"</li> <li>• BCM (FLASHER) Active test "FLASHER"</li> </ul>	I
	Both sides (Only when activating the hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply and the ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and the ground circuit Refer to <a href="#">MWI-45</a> .	J
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating.</li> </ul> (Turn signal is normal.)	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between the hazard switch and BCM</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-100</a> .	K	
Rear fog lamp is not turned ON.	Rear fog lamp indicator lamp is normal.	<ul style="list-style-type: none"> <li>• Harness between BCM and rear fog lamp</li> <li>• Rear fog lamp bulb</li> <li>• BCM</li> </ul>	Rear fog lamp circuit Refer to <a href="#">EXL-108</a> .	EXL
	Rear fog lamp indicator lamp is included.	<ul style="list-style-type: none"> <li>• Rear fog lamp indicator lamp is included.</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .	M

## WITH DAYTIME RUNNING LIGHT SYSTEM

### WITH DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000005233784

**CAUTION:**

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

**Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.**

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp (High beam solenoid)</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-81</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to <a href="#">EXL-115</a> .	
High beam indicator lamp is not turned ON. (The headlamp switches to the high beam.)		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "HEADLAMP"</li> </ul>
Headlamp does not switch to the low beam.	One side	Front combination lamp (High beam solenoid)	—
	Both sides	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .
		High beam request signal	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Xenon bulb</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp (xenon headlamp)</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-83</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-116</a> .	
Headlamp is not turned OFF.	When ignition switch is turned ON	Refer to <a href="#">EXL-116</a> .	
	Ignition switch is turned OFF.	IPDM E/R	—
Headlamp is not turned ON/OFF with the lighting switch AUTO.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>		Combination switch Refer to <a href="#">BCS-89</a> .
	<ul style="list-style-type: none"> <li>• Optical sensor</li> <li>• Harness between the optical sensor and BCM</li> <li>• BCM</li> </ul>		Optical sensor Refer to <a href="#">EXL-97</a> .
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Parking lamp bulb</li> <li>• Harness between daytime running light relay and the front combination lamp</li> <li>• Front combination lamp</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-91</a> .
Tail lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Harness between daytime running light relay and the rear combination lamp</li> <li>• Rear combination lamp</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-103</a> .



# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Harness between daytime running light relay and the license plate lamp</li> <li>• License plate lamp</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-106</a> .	
Tail lamp and license plate lamp are not turned ON.	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between daytime running light relay and the rear combination lamp</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-103</a> .	
<ul style="list-style-type: none"> <li>• Parking lamp, tail lamp and license plate lamp are not turned ON.</li> <li>• Parking lamp, tail lamp and license plate lamp are not turned OFF. (Each illumination is turned ON/OFF.)</li> </ul>	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-117</a> .		
Tail lamp indicator lamp is not turned ON. (Parking and tail lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "TAIL LAMP"</li> </ul>	
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-93</a> .
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .
Turn signal indicator lamp does not blink. (The turn signal indicator lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>- combination meter</li> <li>- BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>• Active test "FLASHER"</li> </ul>
	Both sides (Only when activating the hazard warning lamp with the ignition switch OFF.)	<ul style="list-style-type: none"> <li>• Combination meter power supply and the ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and the ground circuit Refer to <a href="#">PCS-19</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between the hazard switch and BCM</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-100</a> .	
Rear fog lamp is not turned ON.	Rear fog lamp indicator lamp is normal.	<ul style="list-style-type: none"> <li>• Harness between BCM and rear fog lamp</li> <li>• Rear fog lamp bulb</li> <li>• BCM</li> </ul>	Rear fog lamp circuit Refer to <a href="#">EXL-108</a> .
	Rear fog lamp indicator lamp is included.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-89</a> .
Rear fog lamp indicator lamp is not turned ON. (Rear fog lamp is turned ON.)	<ul style="list-style-type: none"> <li>• Rear fog lamp status signal</li> <li>- Combination meter.</li> <li>- BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "RR FOG IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "RR FOG LAMP"</li> </ul>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

---

### NORMAL OPERATING CONDITION

#### Description

INFOID:000000005233785

#### XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area etc.) while using the auto light system. This causes for the control difference. This is normal.

# BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

### Description

INFOID:000000005233786

The headlamp (both sides) does not switch to the high beam when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000005233787

#### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-89. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

 CONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		Except for HI or PASS	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-81. "Description"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000005233788

The headlamps (both sides) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000005233789

#### 1. CHECK COMBINATION SWITCH

Check the combination switch. Refer to [BCS-89, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### ⓑ CONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-83, "Description"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000005233790

The parking, license plate, tail, side marker lamps and each illumination are not turned ON in any condition.

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233791

### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-89. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

### 2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

 CONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

### 3.TAIL LAMP CIRCUIT INSPECTION

Check the tail lamp circuit. Refer to [EXL-102. "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

### WITH DAYTIME RUNNING LIGHT SYSTEM

#### WITH DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000005233792

The parking, license plate and tail lamps are not turned ON in any condition.

#### WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000005233793

### 1.SYMPTOM CONFIRMATION

Turn the lighting switch 1ST.

Are each illumination turned ON?

YES >> GO TO 4.

NO >> GO TO 2.

### 2.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-89. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

### 3.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

[XENON TYPE]

< SYMPTOM DIAGNOSIS >

## ⓑCONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the item status normal?

- YES >> Replace IPDM E/R.  
NO >> Replace BCM.

## 4.DAYTIME RUNNING LIGHT RELAY CIRCUIT INSPECTION

Check the daytime running light relay circuit. Refer to [EXL-87. "Component Function Check"](#).

Is the daytime running light relay circuit normal?

- YES >> Check the parking lamp circuit. Refer to [EXL-92. "WITH DAYTIME RUNNING LIGHT SYSTEM: Diagnosis Procedure"](#).  
NO >> Repair or replace the malfunctioning part.

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:000000005233797

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

##### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

##### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW



A. Headlamp (RH) adjustment screw    B. Headlamp (LH) adjustment screw

←: Vehicle center

Adjustment screw	Screw driver rotation	Facing direction
A    Headlamp (RH)	Clockwise	UP
	Counterclockwise	DOWN

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

	Adjustment screw	Screw driver rotation	Facing direction
B	Headlamp (LH)	Clockwise	UP
		Counterclockwise	DOWN

## Aiming Adjustment Procedure

INFOID:000000005233798

- Place the screen.

**NOTE:**

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

- Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.

- Start the engine. Turn the headlamp (LO) ON.

**NOTE:**

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.


**CAUTION:**

**Never cover the lens surface with a tape etc. The lens is made of resin.**

- Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)

Low beam distribution on the screen




- Adjust the cutoff line height with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)



# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]


## REMOVAL AND INSTALLATION

### FRONT COMBINATION LAMP

Exploded View


INFOID:000000005233799

#### REMOVAL



1. Front combination lamp

#### DISASSEMBLY



- |                                |                                       |                               |
|--------------------------------|---------------------------------------|-------------------------------|
| 1. Front turn signal lamp bulb | 2. Front turn signal lamp bulb socket | 3. Parking lamp bulb          |
| 4. Parking lamp bulb socket    | 5. Resin cap                          | 6. Seal packing               |
| 7. Xenon bulb socket           | 8. Xenon bulb                         | 9. Seal packing               |
| 10. HID control unit           | 11. Bumper bracket                    | 12. Headlamp housing assembly |
| 13. Retaining spring           |                                       |                               |

Refer to [GI-4, "Components"](#) for symbols in the figure.

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## Removal and Installation


INFOID:000000005233800

### CAUTION:

Disconnect the battery negative terminal or remove the fuse.

### REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-13, "Exploded View"](#).
2. Remove the headlamp mounting bolts and clip.
3. Remove the holding clip (A)\* and harness clip.  
\*: Left side only
4. Pull out the headlamp assembly forward the vehicle.
5. Disconnect the connector before removing the headlamp housing assembly.



### INSTALLATION

Install in the reverse order of removal.

### NOTE:

- After installation, perform aiming adjustment. Refer to [EXL-119, "Description"](#).
- After installation, check that headlamp lighting. Refer to [EXL-123, "Inspection After Installation \(HID Control Unit\)"](#).

### Replacement

INFOID:000000005233801

### CAUTION:


- Disconnect the battery negative terminal or remove the fuse.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### HEADLAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
2. Rotate the resin cap counterclockwise and unlock it.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Remove the retaining spring lock. Remove the bulb from the headlamp housing assembly.

### CAUTION:

Never break the xenon bulb ceramic tube when replacing the bulb.



### PARKING LAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the bulb socket.

# FRONT COMBINATION LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

## FRONT TURN SIGNAL LAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the bulb socket.

## SIDE MARKER LAMP

Replacement integral with front combination lamp. Refer to [EXL-121, "Exploded View"](#).

## Disassembly and Assembly

INFOID:000000005233802

### DISASSEMBLY


1. Rotate the resin cap counterclockwise and unlock it.
2. Rotate the xenon bulb socket counterclockwise and unlock it.
3. Remove the retaining spring lock. Remove the xenon bulb.
4. Remove the bumper bracket.
5. Remove the HID control unit installation screw.
6. Remove the screw. Disconnect the connector from HID control unit.
7. Pull out the xenon bulb socket from the headlamp housing assembly.
8. Rotate the parking lamp bulb socket counterclockwise and unlock it.
9. Remove the bulb from the parking lamp bulb socket.
10. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
11. Remove the bulb from the front turn signal lamp bulb socket.

### ASSEMBLY

Assemble in the reverse order of disassembly.

#### CAUTION:

- When xenon bulb socket installation, fix xenon bulb socket harness (A) to a protruding portion (B) in a headlamp housing surely.



- Install HID control unit securely.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Seal packing cannot be reused.
- After installation, check that headlamp lighting. Refer to [EXL-123, "Inspection After Installation \(HID Control Unit\)"](#).

## Inspection After Installation (HID Control Unit)

INFOID:000000005233803

#### CAUTION:

Temporarily install the headlamp on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.

### XENON HEADLAMP LIGHTING CHECK

When recycled HID Control Unit, check the following, when there is abnormality replace the HID Control Unit.

1. Xenon bulb is cold condition (turn OFF more than 10 minutes), and repetition does headlamp turned ON/OFF, check that a headlamp illuminated it surely.
2. Headlamp is turn ON until the xenon bulb becomes stable condition (for about 5 minutes) from cold condition, check that there are not on and off light, abnormality such as blinking.

## FRONT COMBINATION LAMP

[XENON TYPE]

### < REMOVAL AND INSTALLATION >

---

3. Xenon bulb is warm condition (turn ON more than 15 minutes and turn OFF for 1 minute), and repetition does headlamp turned ON/OFF, check that a headlamp illuminated it surely.
4. Headlamp is turn ON for about 30 minutes, check that there are not on and off light, abnormality such as blinking whether brightness of right and left does not have a difference.

# OPTICAL SENSOR


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## OPTICAL SENSOR

### Exploded View

INFOID:000000005233804



1. Optical sensor

### Removal and Installation

INFOID:000000005233805

#### REMOVAL

1. Insert an appropriate tool between the optical sensor and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the connector. Remove the optical sensor.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[XENON TYPE]

---

### LIGHTING & TURN SIGNAL SWITCH

#### Exploded View

INFOID:000000005233806

The lighting & turn switch is integrated in the combination switch. Refer to [BCS-93. "Exploded View"](#).

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## HAZARD SWITCH

### Exploded View

INFOID:000000005233807



1. Hazard switch

### Removal and Installation

INFOID:000000005233808

#### REMOVAL

1. Remove the console finisher. Refer to [IP-23. "Exploded View"](#).
2. Remove the hazard switch from the console finisher.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# SIDE TURN SIGNAL LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## SIDE TURN SIGNAL LAMP

Exploded View

INFOID:000000005233809



1. Side turn signal lamp connector
2. Side turn signal lamp

## Removal and Installation

INFOID:000000005233810

### CAUTION:

Disconnect battery negative terminal or remove the fuse.

### REMOVAL


1. Remove the side turn signal lamp in numerical order shown in the figure.

← : Vehicle front

2. Disconnect the side turn signal lamp connector.

### NOTE:

Support the vehicle-side harness of the side turn signal lamp with tape so that it does not drop inside the front fender.



### INSTALLATION

1. Connect the connector.
2. Fix the pawl-side behind the side turn signal lamp housing first, then push the resin clip-side.

## Replacement

INFOID:000000005233811

### SIDE TURN SIGNAL LAMP BULB

Replace the side turn signal lamp as an assembly because it cannot be disassembled.



# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REAR COMBINATION LAMP

### Exploded View

INFOID:000000005233812


### REMOVAL



1. EPT sealer
2. Seal packing
3. Rear combination lamp assembly
4. Rear combination lamp finisher

Refer to [GI-4, "Components"](#) for symbols in the figure.

### DISASSEMBLY



1. Rear turn signal lamp bulb
2. Rear turn signal lamp bulb socket
3. Back-up lamp bulb socket
4. Back-up lamp

### Removal and Installation

INFOID:000000005233813

**CAUTION:**  
Disconnect the battery negative terminal or remove the fuse.

### REMOVAL

1. Remove the rear combination lamp finisher.
2. Remove the luggage side finisher upper / trunk side finisher.  
Coupe models: Refer to [INT-28, "Exploded View"](#).  
Roadster models: Refer to [INT-89, "TRUNK SIDE FINISHER : Exploded View"](#).
3. Remove the rear combination lamp mounting nut and bolts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR COMBINATION LAMP

[XENON TYPE]

## < REMOVAL AND INSTALLATION >

4. Pull the rear combination lamp toward rear of the vehicle.
5. Disconnect the rear combination lamp connector.

### INSTALLATION


Install in the reverse order of removal.

#### **CAUTION:**

**Always replace EPT sealer and seal packing with a new one, if rear combination lamp assembly is reused.**

Installation EPT sealer

1. Remove the EPT sealer from rear combination lamp assembly.
2. Apply new EPT sealer within mark off line (A) surface while following the mark off line (B) as shown in the figure.



INFOID:000000005233814

### Replacement

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### REAR TURN SIGNAL LAMP BULB

1. Remove the rear combination lamp assembly.
2. Turn the rear turn signal lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

### BACK-UP LAMP BULB

1. Remove the rear combination lamp assembly.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

### STOP/TAIL LAMP

Replacement integral with rear combination lamp. Refer to [EXL-129. "Exploded View"](#).

### REAR SIDE MARKER LAMP

Replacement integral with rear combination lamp. Refer to [EXL-129. "Exploded View"](#).

# HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000005233815



1. Seal packing
2. High-mounted stop lamp

⊗ : Metal clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000005233816

### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Wrap the tip of remover tool with a cloth to protect the body from damage.

### REMOVAL

1. Remove the back door trim / trunk lid trim.  
Coupe models: Refer to [INT-30, "Exploded View"](#).  
Roadster models: Refer to [INT-99, "Exploded View"](#).
2. Remove the high-mounted stop lamp mounting nut.
3. Disconnect the high-mounted stop lamp connector.
4. Insert any appropriate tool in high-mounted stop lamp and a gap of the back door. Remove the metal clip.
5. Remove the high-mounted stop lamp from the back door.

### INSTALLATION

Install in the reverse order of removal.

### CAUTION:

Seal packing cannot be reused.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## LICENSE PLATE LAMP

Exploded View

INFOID:000000005233817



1. License plate lamp

## Removal and Installation


INFOID:000000005233818

### CAUTION:

**Disconnect the battery negative terminal or remove the fuse.**

### REMOVAL

1. Remove the license plate lamp in numerical order.
2. Disconnect the license plate lamp connector.
3. Remove the license plate lamp.



### INSTALLATION

1. Connect the license plate lamp connector.
2. Fix the pawl side. And then push the resin clip side.

## Replacement

INFOID:000000005233819

### CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### LICENSE PLATE LAMP BULB


1. Remove the license plate lamp.

# LICENSE PLATE LAMP

## < REMOVAL AND INSTALLATION >

[XENON TYPE]

2. Turn the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR FOG LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## REAR FOG LAMP

Exploded View

INFOID:000000005233820



1. Rear fog lamp bracket

2. Rear fog lamp

## Removal and Installation


INFOID:000000005233821

### CAUTION:

**Disconnect battery negative terminal or remove the fuse.**

### REMOVAL

1. Remove the clip (A), keep a service area.
2. Remove the rear fog lamp mounting nuts.
3. Turn the bulb socket counterclockwise and unlock it.
4. Remove the rear fog lamp from the rear fog lamp bracket.
5. Disconnect the rear fog lamp connector.
6. Remove the rear fog lamp bracket from the rear bumper fascia.



### INSTALLATION

Installation is the reverse order of removal.

### Replacement

INFOID:000000005233822

### CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**


### REAR FOG LAMP BULB

## REAR FOG LAMP

### < REMOVAL AND INSTALLATION >

[XENON TYPE]

1. Turn the bulb socket (1) counterclockwise and unlock it.
2. Remove the bulb (2) from the rear fog lamp bulb socket.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000005233823

Item	Type	Wattage (W)
Front combination lamp	Headlamp (HI/LO)	D2S (Xenon) 35
	Front turn signal lamp	7444NA (Amber) 28/8
	Parking lamp	W5W 5
	Front side marker lamp	LED —
Side turn signal lamp	LED —	
Rear combination lamp	Stop lamp/Tail lamp	LED —
	Rear turn signal lamp	WY21W (Amber) 21
	Rear side marker lamp	LED —
	Back-up lamp	W16W 16
License plate lamp	W5W 5	
High-mounted stop lamp	LED —	
Rear fog lamp	W21W 21	