

# SECTION **INL**

## INTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<p style="text-align: center;"><b>COUPE</b></p> <p><b>PRECAUTION</b> ..... 4</p> <p><b>PRECAUTIONS</b> ..... 4</p> <p><b>FOR USA AND CANADA</b> .....4</p> <p style="padding-left: 20px;">FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....4</p> <p style="padding-left: 20px;">FOR USA AND CANADA : Precaution for Battery Service .....4</p> <p><b>FOR MEXICO</b> .....4</p> <p style="padding-left: 20px;">FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....4</p> <p style="padding-left: 20px;">FOR MEXICO : Precaution for Battery Service .....5</p> <p><b>SYSTEM DESCRIPTION</b> ..... 6</p> <p><b>COMPONENT PARTS</b> ..... 6</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....6</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : Component Parts Location .....6</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : Component Description .....6</p> <p><b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....7</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Parts Location .....7</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Description .....7</p> <p><b>ILLUMINATION CONTROL SYSTEM</b> .....8</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : Component Parts Location .....8</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : Component Description .....8</p> <p><b>SYSTEM</b> ..... 9</p>	<p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> ..... 9</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram ..... 9</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : System Description ..... 9</p> <p><b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....10</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram .....11</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description .....11</p> <p><b>ILLUMINATION CONTROL SYSTEM</b> .....11</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : System Diagram .....12</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : System Description .....12</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> .....13</p> <p><b>COMMON ITEM</b> .....13</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....13</p> <p><b>INT LAMP</b> .....14</p> <p style="padding-left: 20px;">INT LAMP : CONSULT-III Function (BCM - INT LAMP) (Coupe Models) .....15</p> <p><b>BATTERY SAVER</b> .....16</p> <p style="padding-left: 20px;">BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER) (Coupe Models) .....16</p> <p><b>ECU DIAGNOSIS INFORMATION</b> .....19</p> <p><b>BCM, COMBINATION METER</b> .....19</p> <p style="padding-left: 20px;">List of ECU Reference .....19</p> <p><b>WIRING DIAGRAM</b> .....20</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....20</p> <p style="padding-left: 20px;">Wiring Diagram .....20</p>
--	--



<b>ILLUMINATION</b> .....	<b>30</b>	<b>PRECAUTION</b> .....	<b>58</b>
Wiring Diagram .....	30	<b>PRECAUTIONS</b> .....	<b>58</b>
<b>BASIC INSPECTION</b> .....	<b>43</b>	<b>FOR USA AND CANADA</b> .....	<b>58</b>
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>43</b>	FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	58
Work Flow .....	43	FOR USA AND CANADA : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....	58
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>45</b>	FOR USA AND CANADA : Precaution for Battery Service .....	59
<b>INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT</b> .....	<b>45</b>	<b>FOR MEXICO</b> .....	<b>59</b>
Description .....	45	FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	59
Component Function Check .....	45	FOR MEXICO : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....	59
Diagnosis Procedure .....	45	FOR MEXICO : Precaution for Battery Service .....	60
<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b> .....	<b>47</b>	<b>SYSTEM DESCRIPTION</b> .....	<b>61</b>
Description .....	47	<b>COMPONENT PARTS</b> .....	<b>61</b>
Component Function Check .....	47	<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....	<b>61</b>
Diagnosis Procedure .....	47	INTERIOR ROOM LAMP CONTROL SYSTEM : Component Parts Location .....	61
<b>LUGGAGE ROOM LAMP CIRCUIT</b> .....	<b>49</b>	INTERIOR ROOM LAMP CONTROL SYSTEM : Component Description .....	61
Description .....	49	<b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....	<b>61</b>
Component Function Check .....	49	INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Parts Location .....	62
Diagnosis Procedure .....	49	INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Description .....	62
<b>PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT</b> .....	<b>51</b>	<b>ILLUMINATION CONTROL SYSTEM</b> .....	<b>62</b>
Description .....	51	ILLUMINATION CONTROL SYSTEM : Component Parts Location .....	63
Component Function Check .....	51	ILLUMINATION CONTROL SYSTEM : Component Description .....	63
Diagnosis Procedure .....	51	<b>SYSTEM</b> .....	<b>64</b>
<b>SYMPTOM DIAGNOSIS</b> .....	<b>53</b>	<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....	<b>64</b>
<b>INTERIOR LIGHTING SYSTEM SYMPTOMS</b> .....	<b>53</b>	INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram .....	64
Symptom Table .....	53	INTERIOR ROOM LAMP CONTROL SYSTEM : System Description .....	64
<b>REMOVAL AND INSTALLATION</b> .....	<b>54</b>	<b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....	<b>65</b>
<b>MAP LAMP</b> .....	<b>54</b>	INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram .....	66
Exploded View .....	54	INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description .....	66
Removal and Installation .....	54	<b>ILLUMINATION CONTROL SYSTEM</b> .....	<b>66</b>
Replacement .....	54		
<b>VANITY MIRROR LAMP</b> .....	<b>55</b>		
Exploded View .....	55		
Replacement .....	55		
<b>LUGGAGE ROOM LAMP</b> .....	<b>56</b>		
Exploded View .....	56		
Removal and Installation .....	56		
Replacement .....	56		
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>57</b>		
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>57</b>		
Bulb Specifications .....	57		

**ROADSTER**

ILLUMINATION CONTROL SYSTEM : System Diagram .....	67	Diagnosis Procedure .....	109	A
ILLUMINATION CONTROL SYSTEM : System Description .....	67	<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b>	<b>. 111</b>	B
<b>DIAGNOSIS SYSTEM (BCM) .....</b>	<b>68</b>	Description .....	111	
<b>COMMON ITEM .....</b>	<b>68</b>	Component Function Check .....	111	
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	68	Diagnosis Procedure .....	111	C
<b>INT LAMP .....</b>	<b>69</b>	<b>TRUNK ROOM LAMP CIRCUIT .....</b>	<b>113</b>	D
INT LAMP : CONSULT-III Function (BCM - INT LAMP) (Roadster Models) .....	70	Description .....	113	
<b>BATTERY SAVER .....</b>	<b>71</b>	Component Function Check .....	113	
BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER) (Roadster Models) .....	71	Diagnosis Procedure .....	113	E
<b>DIAGNOSIS SYSTEM (SOFT TOP CONTROL UNIT) .....</b>	<b>74</b>	<b>PUSH-BUTTON IGNITION SWITCH ILLUMI- NATION CIRCUIT .....</b>	<b>115</b>	F
CONSULT-III Function .....	74	Description .....	115	
<b>DIAGNOSIS SYSTEM (METER) .....</b>	<b>77</b>	Component Function Check .....	115	
Diagnosis Description .....	77	Diagnosis Procedure .....	115	G
CONSULT-III Function (METER/M&A) .....	78	<b>SYMPTOM DIAGNOSIS .....</b>	<b>117</b>	
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>83</b>	<b>INTERIOR LIGHTING SYSTEM SYMPTOMS .</b>	<b>117</b>	
<b>BCM, COMBINATION METER, SOFT TOP CONTROL UNIT .....</b>	<b>83</b>	Symptom Table .....	117	H
List of ECU Reference .....	83	<b>REMOVAL AND INSTALLATION .....</b>	<b>118</b>	
<b>WIRING DIAGRAM .....</b>	<b>84</b>	<b>MAP LAMP .....</b>	<b>118</b>	I
<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b>	<b>84</b>	Exploded View .....	118	
Wiring Diagram .....	84	Removal and Installation .....	118	J
<b>ILLUMINATION .....</b>	<b>94</b>	Replacement .....	118	
Wiring Diagram .....	94	<b>VANITY MIRROR LAMP .....</b>	<b>119</b>	K
<b>BASIC INSPECTION .....</b>	<b>107</b>	Exploded View .....	119	
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>107</b>	Replacement .....	119	
Work Flow .....	107	<b>CARGO AREA COURTESY LIGHT .....</b>	<b>120</b>	
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>109</b>	Exploded View .....	120	
<b>INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT .....</b>	<b>109</b>	Removal and Installation .....	120	
Description .....	109	Replacement .....	120	
Component Function Check .....	109	<b>TRUNK ROOM LAMP .....</b>	<b>121</b>	
		Exploded View .....	121	
		Removal and Installation .....	121	
		Replacement .....	121	M
		<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>122</b>	N
		<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>122</b>	
		Bulb Specifications .....	122	O
				P

**INL**

## PRECAUTION

### PRECAUTIONS FOR USA AND CANADA

#### FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005568887

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### FOR USA AND CANADA : Precaution for Battery Service

INFOID:000000005568889

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

### FOR MEXICO

#### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005568890

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".

# PRECAUTIONS

[COUPE]

< PRECAUTION >

- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

## PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

## FOR MEXICO : Precaution for Battery Service

INFOID:000000005568892

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[COUPE]


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### INTERIOR ROOM LAMP CONTROL SYSTEM

#### INTERIOR ROOM LAMP CONTROL SYSTEM : Component Parts Location

INFOID:000000005233640



- |   |  |                                |
|---|--|--------------------------------|
| 1. Remote keyless entry receiver<br>Refer to <a href="#">SEC-13, "Component Parts Location"</a> . | 2. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 3. Door switch                 |
| 4. • Key cylinder switch<br>• Request switch  | 5. Map lamp  | 6. Door lock and unlock switch |
| 7. Push-button ignition switch<br>(Push-button ignition switch illumination)                      | 8. Back door switch  | 9. Luggage room lamp           |
| A. Back door lock assembly  | B. Luggage room  |                                |

#### INTERIOR ROOM LAMP CONTROL SYSTEM : Component Description

INFOID:000000005233641

Part	Description
BCM	<ul style="list-style-type: none"> <li>Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamp ON/OFF.</li> <li>Turns the luggage room lamp ON /OFF according to the luggage room lamp switch status.</li> </ul>
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[COUPE]

Part	Description
<ul style="list-style-type: none"> <li>• Door lock and unlock switch</li> <li>• Key cylinder switch</li> </ul>	Transmits a switch signal by power window switch serial link.
<ul style="list-style-type: none"> <li>• Request switch</li> <li>• Door switch</li> </ul>	Inputs a switch signal to BCM.

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

### INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Parts Location

INFOID:000000005233644



- |  |  |                                |
|--|--|--------------------------------|
| 1. Remote keyless entry receiver<br>Refer to <a href="#">DLK-15, "POWER DOOR LOCK SYSTEM : Component Parts Location"</a> . | 2. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> . | 3. Door switch                 |
| 4. <ul style="list-style-type: none"> <li>• Key cylinder switch</li> <li>• Request switch</li> </ul>                       | 5. Map lamp  | 6. Vanity mirror lamp          |
| 7. Door lock and unlock switch   | 8. Key slot  | 9. Push-button ignition switch |
| 10. Back door switch   | 11. Luggage room lamp  |                                |
| A. Back door lock assembly   | B. Luggage room  |                                |

### INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Description

INFOID:000000005233645

Part	Description
BCM	Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply.
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[COUPE]

Part	Description
<ul style="list-style-type: none"> <li>Door lock and unlock switch</li> <li>Key cylinder switch</li> </ul>	Transmits a switch signal by power window switch serial link.
<ul style="list-style-type: none"> <li>Request switch</li> <li>Door switch</li> </ul>	Inputs a switch signal to BCM.
Key slot	Inputs the key switch status to BCM.

## ILLUMINATION CONTROL SYSTEM

### ILLUMINATION CONTROL SYSTEM : Component Parts Location

INFOID:000000005233648



1. BCM  
Refer to [BCS-9, "Component Parts Location"](#).
2. IPDM E/R  
Refer to [PCS-6, "Component Parts Location"](#).
3. Combination switch
4. Combination meter
5. Illumination control switch

### ILLUMINATION CONTROL SYSTEM : Component Description

INFOID:000000005233649

Part	Description
BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination meter	<ul style="list-style-type: none"> <li>Enters in nighttime mode according to the request from BCM (with CAN communication).</li> <li>Controls the each illumination in the nighttime mode. Refer to <a href="#">MWI-6, "METER SYSTEM : System Diagram"</a>.</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .




SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram

INFOID:000000005233638



JPMIA1309GB

INTERIOR ROOM LAMP CONTROL SYSTEM : System Description


INFOID:000000005233639

OUTLINE

- Interior room lamps\* are controlled by interior room lamp timer control function of BCM.
- \*: Map lamp (when map lamp switch is in DOOR position).
- Luggage room lamp is controlled by luggage room lamp control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.

INTERIOR ROOM LAMP TIMER CONTROL

Interior Room Lamp Timer Basic Operation



JPLIA0093GB

- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room timer.
- BCM judges the vehicle condition with the following items. It activates the interior room timer.

## < SYSTEM DESCRIPTION >

- Ignition switch status
- Door switch signal (ALL)
- Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, central door lock/unlock switch)

### NOTE:

Each function of interior room lamp timer can be set by CONSULT-III. Refer to [INL-15, "INT LAMP : CONSULT-III Function \(BCM - INT LAMP\) \(Coupe Models\)"](#).

#### Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- BCM activates the interior room timer in any of the following conditions to turn the interior room lamp ON for a period of time.
  - Any door opens before all doors close.
  - Ignition switch is turned ON → OFF.
  - Any door unlock signal is detected when all doors close with ignition switch OFF.

### NOTE:

Restart the timer if new condition is input during the timer operating time.

#### Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turn the interior room lamp OFF.

- The timer operating time is expired.
- Ignition switch position is other than OFF with all doors close.
- Any door lock operation is detected with all doors close.

## LUGGAGE ROOM LAMP CONTROL

BCM controls the luggage room lamp (ground-side) to turn ON with the luggage room lamp switch ON.

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

#### Push-button Ignition Switch Illumination Basic Operation

- BCM provides the power supply and the ground to turn the push-button ignition switch illumination ON.
- BCM cuts the ground supply while the each illumination (tail lamp) ON. BCM switches to the ground control with the meter illumination control function.

#### Push-button Ignition Switch Illumination ON Operation

BCM turns the push-button ignition switch illumination ON in the following conditions.

- Ignition switch ON
- Each illumination (tail lamp) ON
- Any of the following conditions with ignition switch OFF
  - Engine start permission is entered.
  - Intelligent Key inserted into the key slot.
  - Driver door is LOCK → UNLOCK.
  - Driver door is open.

#### Push-button Ignition Switch Illumination OFF Operation


BCM turns the push-button ignition switch illumination OFF in any of the following conditions.

- The push-button ignition switch illumination ON conditions do not satisfy.
- All of the following conditions with ignition switch OFF
  - Each illumination (tail lamp) OFF
  - The push-button ignition switch illumination ON conditions do not change (15 seconds after the ignition switch OFF) or the driver door is UNLOCK → LOCK.

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000005233642



INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000005233643

OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the battery from over-discharging if the driver neglect turning OFF the any lamps.

Applicable lamps

- Map lamp
- Luggage room lamp
- Vanity mirror lamp

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned OFF, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signals changes while operating the timer.
  - Ignition switch status
  - Door switch signal (ALL)
  - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, central door lock/unlock switch)
  - Back door switch signal
  - Key switch signal (Key slot)
- BCM provides the interior room lamp power supply continuously when the ignition switch position is other than OFF.


**NOTE:**

Each function of interior room lamp battery saver can be set by CONSULT-III. Refer to [INL-16, "BATTERY SAVER : CONSULT-III Function \(BCM - BATTERY SAVER\) \(Coupe Models\)"](#).

ILLUMINATION CONTROL SYSTEM

## ILLUMINATION CONTROL SYSTEM : System Diagram

INFOID:000000005233646



## ILLUMINATION CONTROL SYSTEM : System Description

INFOID:000000005233647

### OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R and combination meter.

#### Control by BCM

- Combination switch reading function
- Headlamp control function

#### Control by IPDM E/R

- Relay control function

#### Control by combination meter

- Meter illumination control function (Refer to [MWI-6, "METER SYSTEM : System Diagram"](#).)

### ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition.

#### Tail lamp ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).

# DIAGNOSIS SYSTEM (BCM)

[COUPE]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005588104

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITONER*			
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door/Trunk lid open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[COUPE]

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## INT LAMP

# DIAGNOSIS SYSTEM (BCM)


< SYSTEM DESCRIPTION >

[COUPE]

## INT LAMP : CONSULT-III Function (BCM - INT LAMP) (Coupe Models)

INFOID:000000005233651

### WORK SUPPORT



Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function	
	OFF	Without the interior room lamp timer function	
ROOM LAMP TIMER SET	MODE 2	7.5 sec.	Sets the interior room lamp ON time. (Timer operating time)
	MODE 3*	15 sec.	
	MODE 4	30 sec.	
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual brightening time.
	MODE 2*	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual dimming time.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4*	3 sec.	
	MODE 5	0 sec.	
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.	
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.	

\*: Factory setting

### DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	

# DIAGNOSIS SYSTEM (BCM)

[COUPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
KEY SW-SLOT [On/Off]	Key switch status input from key slot
DOOR SW-DR [On/Off]	The switch status input from driver side door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	
DOOR SW-BK [On/Off]	The switch status input from back door switch
CDL LOCK SW [On/Off]	Lock switch status received from the door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status received from the door lock and unlock switch
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch
TRNK/HAT MNTR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

## ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs the interior room lamp control signal to turn map lamp ON (Map lamp switch is in DOOR position).
	Off	Stops the interior room lamp control signal to turn map lamp OFF.
STEP LAMP TEST	On	<b>NOTE:</b> The item is displayed, but cannot be tested.
	Off	
LUGGAGE LAMP TEST	On	Outputs the luggage room lamp control signal to turn the luggage room lamp ON.
	Off	Stops the luggage room lamp control signal to turn the luggage room lamp OFF.

## BATTERY SAVER

BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER) (Coupe Models)

INFOID:000000005233652

## WORK SUPPORT



# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[COUPE]

Service item	Setting item	Setting	
BATTERY SAVER SET	On*	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	
ROOM LAMP BAT SAV SET	On*	With the interior room lamp battery saver function	
	Off	Without the interior room lamp battery saver function	
ROOM LAMP TIMER SET	MODE 1*	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	

\*: Factory setting

## DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
KEY SW-SLOT [On/Off]	Key switch status input from key slot
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
DOOR SW-DR [On/Off]	The switch status input driver side front door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	
DOOR SW-BK [On/Off]	The switch status input from back door switch
CDL LOCK SW [On/Off]	Lock switch status received from the door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status received from the door lock and unlock switch
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch
TRNK/HAT MNTR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# DIAGNOSIS SYSTEM (BCM)

[COUPE]

< SYSTEM DESCRIPTION >

## ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamp OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamp ON.*

\*: Each lamp switch is in ON position.

# BCM, COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[COUPE]

## ECU DIAGNOSIS INFORMATION

### BCM, COMBINATION METER

#### List of ECU Reference

INFOID:000000005402647

ECU	Reference
BCM	<a href="#">BCS-51, "Reference Value"</a>
	<a href="#">BCS-82, "Fail-safe"</a>
	<a href="#">BCS-85, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-86, "DTC Index"</a>
COMBINATION METER	<a href="#">MWI-57, "Reference Value"</a>
	<a href="#">MWI-76, "Fail-Safe"</a>
	<a href="#">MWI-77, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


[COUPE]

## WIRING DIAGRAM

### INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:000000005233666



2009/07/10


JCLWM4090GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]

◊CP◊ : Coupe models  
 ◊RS◊ : Roadster models  
 \*2 97 : ◊CP◊  
 92 : ◊RS◊



\*: This connector is not shown in "Harness Layout".

JCLWM4091GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]


## INTERIOR ROOM LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THB07V-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	Y	- [Coupe models]
4	W	- [Roadster models]
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	- [Coupe models]
33	W	- [Roadster models]
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	SB	-
47	V	-
48	SHIELD	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B53
Connector Name	LUGGAGE ROOM LAMP
Connector Type	CJ02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	B55
Connector Name	TRUNK ROOM LAMP
Connector Type	S02FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	B56
Connector Name	WIRE TO WIRE
Connector Type	NSJ2MM-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	R	-
9	V	-
10	LG	-
11	GR	-
12	B	-

Connector No.	B63
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-
3	B	-

JCLWM4092GB


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]

## INTERIOR ROOM LAMP

Connector No.	B66
Connector Name	BACK DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	B	-

Connector No.	B76
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Type	NS38FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	B	-

Connector No.	B61
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-RH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-


5	BR	-
6	B	-
8	Y	-
9	O	-
14	GR	-
15	SB	-
16	V	-
17	G	-
24	LG	-
25	V	-
31	L	-
32	P	-
34	O	-
35	R	-

Connector No.	B66
Connector Name	CARGO AREA COURTESY LIGHT
Connector Type	SS2FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-


Connector No.	B147
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	R	-
9	V	-
10	LG	-

11	GR	-
12	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	- [Coupe models]
2	R	- [Roadster models]
3	B	- [Coupe models]
3	B	- [Roadster models]
4	G	-
7	R	- [Coupe models]
7	Y	- [Roadster models]
8	LG	-
9	Y	-
11	R	-
20	G	-
21	R	-
30	B	-
40	W	-
41	V	-
42	G	-
43	L	-
44	SB	-
51	P	-
52	L	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	G	- [Coupe models]
57	P	- [Roadster models]
58	R	- [Coupe models]
58	L	- [Roadster models]
59	B	-
60	W	-
61	GR	-
62	B	-
63	Y	-
64	V	-

65	SB	- [Coupe models]
66	B	- [Roadster models]
68	V	-
69	P	- [Coupe models]
69	GR	- [Roadster models]
70	L	- [Coupe models]
70	G	- [Roadster models]
70	O	- [Coupe models]
70	O	- [Roadster models]
80	V	-
81	SB	-
82	G	-
83	R	-
84	W	-
85	B	-
86	SHIELD	-
87	O	-
88	BR	-
89	Y	-
90	SHIELD	-
92	SB	- [Coupe models]
92	LG	- [Roadster models]
93	V	- [Coupe models]
93	W	- [Roadster models]
94	SHIELD	- [Coupe models]
94	G	- [Roadster models]
95	GR	- [Coupe models]
95	LG	- [Roadster models]
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	W	- [Coupe models]
98	Y/B	- [Roadster models]
99	G	-
100	BR	- [Coupe models]
100	Y	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]

## INTERIOR ROOM LAMP

Connector No.	B206
Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
3	B	-

Connector No.	B216
Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B301
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	L	-
6	P	-


8	O	-
9	Y	-
14	BR	-
15	BR	-
16	W	-
17	DG	-
24	V	-
25	LG	-
31	BG	-
32	P	-
34	O	-
35	SB	-

Connector No.	B303
Connector Name	SOFT TOP CONTROL UNIT
Connector Type	TH40FEB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	SENSOR POWER SUPPLY (ROOF STRIKER SENSOR LH)
3	DG	ROOF STRIKER SENSOR RH
4	W	ROOF STRIKER SENSOR LH
8	Y	REVERSE SIGNAL
9	SB	POWER CONDITION (POWER WINDOW)
10	O	TRUNK LID OPEN SIGNAL
11	O	ROOF STATUS SIGNAL (INDICATOR)
12	SB	ROOF STATUS SIGNAL (AUDIO)
14	L	ROOF OPEN / CLOSE SWITCH (CLOSE)
15	LG	ROOF OPEN / CLOSE SWITCH (OPEN)
16	V	TRUNK ROOM LAMP SWITCH
17	BG	CAN-H
18	P	CAN-L
19	LG	LOCAL COMMUNICATION (POWER WINDOW)
20	V	LOCAL COMMUNICATION (BCM)
21	BR	SENSOR POWER SUPPLY (ROOF STRIKER SENSOR RH)
29	DG	GND
35	P	ROOF OPEN / CLOSE SWITCH (GND)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	BG	- [Coupe models] - [Roadster models]
11	P	- [Roadster models]
11	V	- [With BOSE system] - [Without BOSE system]
12	L	-
13	B	-
14	SB	- [Coupe models] - [Roadster models]
15	W	-
19	G	-
23	R	-
44	L	-
47	B	-
48	SB	-
49	W	-
50	LG	-
51	R	-
52	V	-
53	BG	- [Coupe models] - [Roadster models]
54	GR	-
55	G	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS36FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
4	Y	-
5	BG	- [Coupe models] - [Roadster models]
6	O	-
7	V	-
8	L	-
9	LG	-
10	Y	-
11	BR	-
12	SB	- [Coupe models] - [Roadster models]
13	R	-
14	G	-
15	B	-

Connector No.	D15
Connector Name	DRIVER SIDE DOOR LOCK ASSEMBLY
Connector Type	EQ6F5Y-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	- [Coupe models] - [Roadster models]
2	G	-
3	SB	-
4	B	-
5	V	-
6	GR	-




# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]


## INTERIOR ROOM LAMP

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
10	V	-
11	LG	-
12	P	- [With BOSE system]
12	LG	- [Without BOSE system]
13	V	- [Coupe models without BOSE system]
13	L	- [Except for coupe models without BOSE system]
14	B	-
15	W	-
19	P	-
23	L	-
44	L	-
50	Y	-
51	Y	-
52	G	-
53	BG	- [Coupe models]
53	O	- [Roadster models]
54	GR	-
55	L	-


Connector No.	D38
Connector Name	POWER WINDOW SUB-SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	BG	- [Coupe models]
4	O	- [Roadster models]
8	L	-

9	BR	-
10	W	- [Roadster models with M/T]
11	B	- [Except for Roadster models with M/T]
12	R	- [Coupe models]
14	Y	-
15	LG	-
16	Y	-


Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-

7A	BR	-
8A	L	-


Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	V	-
11	V	-
12	L	-
13	B	-
14	Y	-
15	W	-
19	Y	-
23	Y/B	-
44	L	-
47	B	-
48	SB	-
49	SB	- [Roadster models with M/T]
49	Y	- [Except for Roadster models with M/T]
50	W	-
51	R	-
52	L	-
53	W	-
54	G	-
55	R	-

43	G	-
44	R	- [Roadster models with M/T]
44	CR	- [Except for Roadster models with M/T]
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	W	-
47	P	-
58	SHIELD	-
59	L	-
70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

Connector No.	M1
Connector Name	FUSE BLOCK (U/B)
Connector Type	NS80FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-

A B C D E F G H I J K M N O P




# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]


## INTERIOR ROOM LAMP

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	- [Roadster models with M/T]
31	BR	- [Except for roadster models with M/T]
32	Y	- [Roadster models with M/T]
32	V	- [Except for roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
38	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	G	- [With A/T]
44	R	- [With M/T]
45	O	-
46	G	-
47	BR	-
47	BR	-
47	SHIELD	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-

21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-
51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	V	- [Roadster models]
65	SHIELD	-
66	LG	- [Coupe models]
66	P	- [Roadster models]
67	V	- [Coupe models]
67	L	- [Roadster models]
68	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-

81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
93	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	-
98	Y/B	- [Coupe models]
99	W	- [Roadster models]
100	B	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]


## INTERIOR ROOM LAMP

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FV-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT [Roadster models with M/T]
2	GR	BAT [Except for roadster models with M/T]
3	W	LOCK
5	Y	DATA
6	LG	ILL BAT
7	B	ILL
11	R	GND
		KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FV




Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	
4	B	
5	B	
6	L	
7	Y	- [Coupe models]
8	G	- [Roadster models]
11	LG	
14	P	
16	Y	

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK03FER



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	R	
3	R	- [Roadster models with M/T]
4	G	- [Except for roadster models with M/T]
5	BR	
6	GR	
7	Y	
8	P	

Connector No.	M106
Connector Name	WIPE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	
5	R	
6	B	
7	P	
8	R	
11	B	
12	Y	
13	G	
14	SHIELD	
15	R	
16	G	

Connector No.	M117
Connector Name	WIPE TO WIRE
Connector Type	TH62MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	- [Coupe models]
3	O	- [Coupe models]
4	B	- [Roadster models]
5	W	- [Coupe models]
6	G	- [Roadster models]
7	LG	- [Coupe models]
8	LG	- [Roadster models]
9	Y	
11	R	
20	G	
21	R	
30	B	
40	O	
41	Y	
42	G	
43	L	
44	SB	
51	R	
52	G	
53	SHIELD	
54	LG	- [Coupe models]
54	BR	- [Roadster models]
55	V	- [Coupe models]
55	Y	- [Roadster models]
56	SHIELD	
57	G	- [Coupe models]
57	P	- [Roadster models]
58	R	- [Coupe models]
58	L	- [Roadster models]
59	B	
60	W	
61	GR	
62	B	
63	Y	
64	L	
65	G	

66	O	- [Coupe models]
66	G	- [Roadster models]
67	V	- [Roadster models]
68	P	- [Coupe models]
68	GR	- [Roadster models]
69	L	- [Coupe models]
69	P	- [Roadster models]
70	L	- [Coupe models]
70	O	- [Roadster models]
80	W	- [Coupe models]
80	L	- [Roadster models]
81	Y	
82	W	
83	B	
84	R	
85	G	
86	SHIELD	
87	G	
88	L	
89	P	
90	SHIELD	
92	G	- [Coupe models]
92	LG	- [Roadster models]
93	R	- [Coupe models]
93	V	- [Roadster models]
94	SHIELD	
94	G	- [Roadster models]
95	SB	- [Coupe models]
95	LG	- [Roadster models]
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	V	- [Coupe models]
98	Y/B	- [Roadster models]
99	G	
100	BR	- [Coupe models]
100	Y	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]


## INTERIOR ROOM LAMP

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MDFPB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
5	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (PUSE)
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE)
18	O	TURN SIGNAL LH (FRONT, SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	L	BACK DOOR OPEN OUTPUT [Coupe models]
23	Y	TRUNK LID OPEN OUTPUT [Roadster models]
24	O	REAR FOG OUTPUT
25	LG	TURN SIGNAL LH (REAR)
30	R	LUGGAGE ROOM LAMP OUTPUT


Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT- [Roadster models with M/T]
34	G	LUGGAGE ROOM ANT- [Coupe models with M/T]
35	V	LUGGAGE ROOM ANT+ [Roadster models with M/T]
35	R	LUGGAGE ROOM ANT+ [Coupe models with M/T]
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (DRIVE E/FR) CONT [Roadster models with M/T]
47	V	IGN RELAY (DRIVE E/FR) CONT [Coupe models with M/T]
52	SB	STARTER RELAY CONT
61	W	BACK DOOR REQUEST SW [Coupe models]
61	W	TRUNK LID REQUEST SW [Roadster models]
64	V	1-KEY WARN BUZZER BING ROOM [Roadster models with M/T]
64	G	1-KEY WARN BUZZER BING ROOM [Coupe models]
66	R	BACK DOOR SW [Coupe models]
66	R	TRUNK ROOM LAMP SW [Roadster models]
67	GR	BACK DOOR OPENER SW [Coupe models]

67	GR	TRUNK LID OPENER SW [Roadster models]
----	----	---------------------------------------

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Coupe models with M/T]
72	G	ROOM ANT 2+ [Roadster models with M/T]
72	B	ROOM ANT 2+ [Coupe models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]
78	Y	ROOM ANT 1- [With M/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F/B) CONT
83	Y	KEYS ENT RECEIVER (FRONT) COMM [Roadster models with M/T]
83	GR	KEYS ENT RECEIVER (FRONT) COMM [Coupe models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	GAN-L
91	L	GAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	CLUTCH PEDAL REQUEST SW [Roadster models with M/T]
100	GR	CLUTCH PEDAL REQUEST SW [Coupe models with M/T]
101	SB	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
101	GR	PASSENGER DOOR REQUEST SW [Coupe models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Coupe models with M/T]

102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KEYS ENT RECEIVER (REAR) PWR SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Coupe models with M/T]
111	Y	S/L UNIT COMM

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[COUPE]

## INTERIOR ROOM LAMP

Connector No.	M123
Connector Name	BCM BODY CONTROL MODULE
Connector Type	TH40FG-NH

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COMM [Coupe models]
132	V	P/W SW & SOFT TOP C/U COMM [Roadster models]
133	R	PWR BATT DISCHARGE SW (Except for roadster models with M/T)
133	G	LOCK IND
134	GR	LOCK IND
137	O	RECEIVER/SENSOR GND [Roadster models with M/T]
137	P	RECEIVER/SENSOR GND [Except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./KYL'S ENT (REAR) RECEIV COMM
140	G	SHIFT N/UP (With A/T)
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MP-CS15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



Terminal No.	Color of Wire	Signal Name [Specification]
10	G	- [Coupe models]
10	V	- [Roadster models]
11	V	- [Coupe models]
11	LG	- [Roadster models]
12	LG	- [Roadster models]
13	V	-
14	B	-
15	W	-
19	Y	-
23	Y/B	-
44	R	- [Coupe models]
44	O	- [Roadster models]
50	Y	-
51	Y	-
52	G	- [Roadster models with M/T]
52	GR	- [Except for roadster models with M/T]
53	W	-
54	G	-
55	R	-

Connector No.	RI
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH

8	7	6	5	4	3	2	1	16	15	14	13	12	11	10	9
---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	---



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-

7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	R2
Connector Name	VANITY MIRROR LAMP LH
Connector Type	MCA02FW

1	2
---	---



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	R3
Connector Name	VANITY MIRROR LAMP RH
Connector Type	MCA02FW

1	2
---	---



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK08FGY



6	5	4	3	2	1
---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	B	-
4	SB	-
5	Y	-
6	GR	-

Connector No.	RI1
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH



6	5	4	3	2	1	12	11	10	9	8	7
---	---	---	---	---	---	----	----	----	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	SS	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-

A B C D E F G H I J K M N O P

INL

# ILLUMINATION


< WIRING DIAGRAM >

[COUPE]

## ILLUMINATION

### Wiring Diagram

INFOID:00000005233667




# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

- ◊ XM > : Except for Mexico
- ◊ RS > : Roadster models
- ◊ ON > : Without NAVI
- ◊ WB > : With BOSE system
- ◊ OB > : Without BOSE system
- ◊ WS > : With climate controlled seat
- ◊ HS > : With heated seat



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


JCLWM4101GB

# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

- ◊ A : With A/T
- ◊ M : With M/T
- ◊ CP : Coupe models
- ◊ RS : Roadster models
- ◊ HS : With heated seat



\*: This connector is not shown in "Harness Layout".

JCLWM4102GB




# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

- ◁MX▷ : For Mexico
- ◁A▷ : With A/T
- ◁MS▷ : With M/T and SynchroRev Match mode
- ◁NV▷ : With NAV



JCLWM4103GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

## ILLUMINATION

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	Y	-
4	W	-
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	-
33	W	-
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	-
45	O	-
46	SB	-
47	V	-
48	SHIELD	-

51	W	-
52	R	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	-
85	L	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	-
94	G	-
95	GR	-
95	LG	-
96	L	-
97	Y	-
98	W	-
98	Y/B	-
99	LG	-
100	B	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B63
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-
3	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-

10	BG	-
10	O	-
11	P	-
11	V	-
12	L	-
13	SB	-
14	SB	-
14	Y	-
15	W	-
19	G	-
23	R	-
44	L	-
47	B	-
48	SB	-
49	W	-
50	LG	-
51	R	-
52	V	-
53	BG	-
53	O	-
54	GR	-
55	G	-

Connector No.	D7
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
7	V	-
8	LG	-
9	R	-
10	Y	-
12	G	-
13	GR	-
14	L	-
15	BG	-
15	O	-
16	BR	-

JCLWM4104GB


# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]


## ILLUMINATION

Connector No.	E5
Connector Name	SMALL INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
16	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-


Connector No.	E6
Connector Name	SMALL INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	Y	-
43	SB	-
44	W	-


45	G	-
46	V	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SB	-
2F	W	-
4F	G	-
6F	EG	- [Coupe models]
8F	O	- [Readerster models]
9F	L	-
10E	R	- [Coupe models]
11E	V	- [Readerster models]

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
11	V	- [Readerster models]
12	R	-
13	L	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1B	Y	-
3B	P	-
4B	G	-
5B	O	-
6B	Y	-
8B	R	-
9B	SB	-

14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
31	L	- [Readerster models]
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	GR	- [Readerster models with M/T]
44	GR	- [except for readerster models with M/T]
45	BG	- [Coupe models]
45	O	- [Readerster models]
46	W	-
47	P	-
59	SHIELD	-
70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Readerster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Readerster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

## ILLUMINATION

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS12FW-CS



5C	AC	8C	2C	1C
12C	11C	10C	9C	8C
7C	6C	5C	4C	3C

Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
9C	R	- [Coupe models]
10C	O	- [Roadster models]
11C	LG	-
12C	O	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
18	17	16	15	14	13	12	11	10	9	8	7	6	5	4
3	2	1	16	15	14	13	12	11	10	9	8	7	6	5
24	23	22	21	20	19	18	17	16	15	14	13	12	11	10

Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	V	-
11	V	-
12	L	-
13	B	-
14	Y	-
15	W	-
19	Y	-
23	Y/B	-
44	L	-
47	B	-
48	SB	-
48	SB	- [Roadster models with M/T]

49	Y	-	-	-
50	W	-	-	-
51	R	-	-	-
52	L	-	-	- [With A/T]
53	W	-	-	- [With M/T]
54	G	-	-	-
55	R	-	-	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS18-TM4



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40	41	42	43	44	45
46	47	48	49	50	51	52	53	54	55	56	57	58	59	60

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	-
31	BR	- [Roadster models with M/T]
32	Y	- [Except for roadster models with M/T]
32	V	- [Roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-

41	LG	-
42	R	-
43	G	-
44	G	- [With A/T]
44	R	- [With M/T]
45	O	-
46	G	-
47	BR	-
58	SHIELD	-
59	L	-
70	R	-
80	LG	-
81	GR	-
82	V	-
83	V	-
84	L	-
85	BR	-
86	V	-
87	V	-
87	G	- [Roadster models with M/T]
87	G	- [Except for roadster models with M/T]
88	P	-
91	W	-
92	P	-
93	P	-
94	Y	-
96	P	-
97	GR	-
98	O	-
99	W	-
100	R	-


# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

## ILLUMINATION

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS (E-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-

51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	Y	- [Roadster models]
65	SHIELD	-
66	LG	- [Coupe models]
66	P	- [Roadster models]
67	V	-
67	L	- [Roadster models]
68	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
89	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	M9
Connector Name	DIODE
Connector Type	2433S CS900




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-

Connector No.	M15
Connector Name	ROOF OPEN / CLOSE SWITCH
Connector Type	TK08FW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
3	V	-
4	BR	-
5	R	-
8	R	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-

Connector No.	M19
Connector Name	VDC OFF SWITCH
Connector Type	TK08FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-
3	R	-
4	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL


**ILLUMINATION**

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FV



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models] - [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FV-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M35
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK0BFY-EX-TV



Terminal No.	Color of Wire	Signal Name [Specification]
23	W	- [Coupe models] - [Roadster models]
28	R	-
29	Y	-
30	Y	-

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK0BFY-TV




Terminal No.	Color of Wire	Signal Name [Specification]
24	P	-
25	SB	-
28	W	- [Coupe models] - [Roadster models]
31	L	-
32	Y	-
33	B	-
34	LG	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK0BFER



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	R	- [Roadster models with M/T] - [Except for roadster models with M/T]
4	BR	-
5	GR	-
8	Y	-
7	V	-
8	P	-


Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (METER->TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER->METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY
16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL

19	G	A.C. AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M64
Connector Name	CLIMATE CONTROLLED RELAY SWITCH (RELAY SOI)
Connector Type	TK10FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	V	-
3	P	-
4	BR	-
5	GR	-
6	B	-
7	R	-
8	R	-

# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]


## ILLUMINATION

Connector No.	M65
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	GND
2	G	-
3	L	-
4	O	-
5	Y	-
6	B	-
7	R	-
8	R	-

Connector No.	M67
Connector Name	A/C CONTROL
Connector Type	TH10FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	IGNITION POWER SUPPLY
2	R	ILL+
3	W	ILL-
4	P	TX (SW>AMP)
5	L	RX (AMP>SW)
6	B	GROUND

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FP-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
3	V	ACC
4	R	ILL
5	R	ILL CONT
6	LG	AV COMM (H) [Coupe models]
8	Y	AV COMM (+) [Roadster models]
8	Y	AV COMM (L) [Coupe models]
8	P	AV COMM (L) [Roadster models]
9	BR	SW GND
14	SB	DISK EJECT SIGNAL

Connector No.	M80
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2




Terminal No.	Color of Wire	Signal Name [Specification]
2	L	SOUND SIGNAL FRONT SPEAKER LH (+)
3	V	SOUND SIGNAL FRONT SPEAKER LH (-)
6	P	STRG SW A
7	L	ACC
8	W	ILL (-)
9	R	ILL (+)
11	V	SOUND SIGNAL FRONT SPEAKER RH (+)
12	LG	SOUND SIGNAL FRONT SPEAKER RH (-)
15	B	STRG SW GND
16	L	BATTERY
19	Y	-

Connector No.	M81
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BOSE AMP ON SIGNAL
2	LG	SOUND SIGNAL FRONT LH (+) [Coupe models]
2	P	SOUND SIGNAL FRONT LH (-) [Roadster models]
3	V	SOUND SIGNAL FRONT LH (-) [Coupe models]
3	L	SOUND SIGNAL FRONT LH (+) [Roadster models]
4	L	SOUND SIGNAL REAR LH (+) [Coupe models]
4	V	SOUND SIGNAL REAR LH (-) [Roadster models]
5	R	SOUND SIGNAL REAR LH (-) [Coupe models]
5	SB	SOUND SIGNAL REAR LH (+) [Roadster models]
6	P	STRG SW A [For Mexico]
6	W	STRG SW A [Except for Mexico]
7	L	ACC
8	W	ILL (-) [Coupe models]
8	O	ILL (-) [Roadster models]
9	R	ILL (+)
10	SHIELD	SHIELD
11	L	SOUND SIGNAL FRONT RH (+) [Coupe models]
11	R	SOUND SIGNAL FRONT RH (-) [Roadster models]
12	P	SOUND SIGNAL FRONT RH (-) [Coupe models]
12	G	SOUND SIGNAL FRONT RH (+) [Roadster models]
13	R	SOUND SIGNAL REAR RH (+) [Coupe models]
13	RR	SOUND SIGNAL REAR RH (-) [Roadster models]
14	G	SOUND SIGNAL REAR RH (+) [Coupe models]
14	V	SOUND SIGNAL REAR RH (-) [Roadster models]
15	B	STRG SW GND
15	B	STRG SW B [For Mexico]
16	L	BATTERY
18	GR	STRG SW B [Except for Mexico]
18	Y	VEHICLE SPEED SIGNAL (8-PULSE)
19	Y	BATTERY
20	SHIELD	SHIELD

Connector No.	M86
Connector Name	AV CONTROL UNIT
Connector Type	TH32FPV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
65	V	PARKING BRAKE SIGNAL
67	B	COMPOSITE IMAGE GND
68	L	COMPOSITE IMAGE SIGNAL
71	SHIELD	SHIELD
72	R	MICROPHONE GND
73	G	COMM (CONT->DISP) [Coupe models]
73	R	COMM (CONT->DISP) [Roadster models]
74	P	CAN-L [Coupe models]
74	L	CAN-L [Roadster models]
75	Y	AV COMM (L)
76	Y	AV COMM (L)
79	R	ILL+
80	G	IGNITION SIGNAL
81	O	REVERSE SIGNAL
82	Y	VEHICLE SPEED SIGNAL (8-PULSE)
83	SHIELD	SHIELD
84	Y	-
87	G	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	R	COMM (DISP->CONT) [Coupe models]
89	G	COMM (DISP->CONT) [Roadster models]
89	L	CAN-H [Coupe models]
89	L	CAN-H [Roadster models]
90	P	CAN-H [Coupe models]
91	LG	AV COMM (H)
92	LG	AV COMM (H)


A B C D E F G H I J K M N O P

INL

# ILLUMINATION


## ILLUMINATION

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	GR	- [Coupe models]
3	B	- [Roadster models]
4	P	- [Coupe models]
4	G	- [Roadster models]
5	B	-
6	L	-
7	B	-
8	G	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-
7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M30FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FY-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
5	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT FUSE
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE)
18	O	TURN SIGNAL LH (FRONT, SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]
79	R	ROOM ANT 1- [With M/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F/B) CONT
83	Y	PULSE ENT RECEIVER (FRONT COMM) [Roadster models with M/T]
83	GR	PULSE ENT RECEIVER (FRONT COMM) [Except for roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
106	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY

106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM



# ILLUMINATION

< WIRING DIAGRAM >

[COUPE]

## ILLUMINATION

Connector No.	M123
Connector Name	BCM BODY CONTROL MODULE
Connector Type	TH40FG-NH



Connector No.	M140
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS08FBR-CS



Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TK10PW



Connector No.	M252
Connector Name	WIRE TO WIRE
Connector Type	TK08MNF-NH



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COMM [Coupe models]
132	V	P/W SW & SOFT TOP C/U COMM [Roadster models]
133	R	P/WR INITIATION SW (L POWER [Roadster models with M/T])
133	G	P/WR INITIATION SW (R POWER [Roadster models with M/T])
134	GR	LOCK IND
137	O	RECEIVER SENSOR GND [Roadster models with M/T]
137	P	RECEIVER SENSOR GND [except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./KYL'S ENT (REAR) RECELV COMM
140	G	SHIFT N/P (With A/T)
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY COINT

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-
3	GR	-
4	B	-
5	R	-
6	W	-

Connector No.	M144
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	[Coupe models]
1	O	-
2	SB	[Roadster models]
3	B	-
4	G	-
5	B	-
6	L	-
7	G	-
8	G	-

Connector No.	M255
Connector Name	S-MODE SWITCH
Connector Type	TK04FCY



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	GND
2	P	ECM
3	R	ILL+
4	B	ILL-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	G	-
3	L	-
4	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	GR	-
3	SB	-
4	B	-
5	R	-
6	W	-



Connector No.	M138
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)
Connector Type	NS08FW-CS



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

JCLWM4111GB

## ILLUMINATION

Connector No.	M296
Connector Name	HAZARD SWITCH
Connector Type	TK08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	G	BCM
3	SB	ILL+
4	EG	ILL- [Coupe models]
4	O	ILL- [Roadster models]

Connector No.	M303
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-
7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	B	-
4	SB	-
5	Y	-
6	GR	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	B	-
5	V	-
6	B	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-


**BASIC INSPECTION**

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005233637

OVERALL SEQUENCE



DETAILED FLOW

**1. INTERVIEW FOR MALFUNCTION**

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

[COUPE]

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

## DTC/CIRCUIT DIAGNOSIS

### INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

#### Description

INFOID:000000005233654

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

#### Component Function Check

INFOID:000000005233655

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

##### CONSULT-III ACTIVE TEST

- Turn the ignition switch ON.
- Turn each interior room lamp ON.
  - Map lamp
  - Vanity mirror lamp
  - Luggage room lamp
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test items, check that each interior room lamp turns ON/OFF.

**Off** : Interior room lamp OFF

**On** : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

- YES >> Interior room lamp power supply circuit is normal.  
 NO >> Refer to [INL-45, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000005233656

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

##### CONSULT-III ACTIVE TEST

- Turn the ignition switch ON.
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test item, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		BATTERY SAVER	0 V
Connector	Terminal		
M119	4	Off	Battery voltage
		On	

Is the measurement value normal?

- YES >> GO TO 2.  
 NO >> Replace BCM.

#### 2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the following connectors.
  - Map lamp
  - Vanity mirror lamp (LH)
  - Vanity mirror lamp (RH)
  - Luggage room lamp
- Check continuity between BCM harness connector and each interior room lamp harness connector.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

BCM		Each interior room lamp			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
M119	4	Map lamp	R4	1	Existed
		Vanity mirror lamp (LH)	R2	2	
		Vanity mirror lamp (RH)	R3	2	
		Luggage room lamp	B53	1	

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

### 3. CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check that each interior room lamp has no internal short circuit.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:000000005233657

Controls each interior room lamp (ground side) by PWM signal.

#### NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

### Component Function Check

INFOID:000000005233658

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb

### 1. CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Switch the map lamp switch to DOOR.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

**On** : Interior room lamp gradual brightening

**Off** : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-47, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233659

### 1. CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove all the bulbs of map lamp.
3. Turn the ignition switch ON.
4. Select "INT LAMP" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		INT LAMP	
M119	19		On	Existed
			Off	Not existed

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON >> GO TO 3.

Fixed OFF >> Replace BCM.

### 2. CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and map lamp connector.
3. Check continuity between BCM harness connector and map lamp harness connector.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

[COUPE]

< DTC/CIRCUIT DIAGNOSIS >

BCM		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M119	19	R4	2	Existed

Does continuity exist?

YES >> Replace the map lamp.

NO >> Repair the harnesses or connectors.

## 3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and map lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	19		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.



# LUGGAGE ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

## LUGGAGE ROOM LAMP CIRCUIT

### Description

INFOID:000000005233660

Controls the luggage room lamp (ground side) to turn the luggage room lamp ON and OFF.

### Component Function Check

INFOID:000000005233661

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Luggage room lamp bulb

### 1.CHECK LUGGAGE ROOM LAMP OPERATION

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that luggage room lamp turns ON/OFF.

**On** : Luggage room lamp ON

**Off** : Luggage room lamp OFF

#### Does the luggage room lamp turn ON/OFF?

- YES >> Luggage room lamp circuit is normal.  
 NO >> Refer to [INL-49, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233662

### 1.CHECK LUGGAGE ROOM LAMP OUTPUT

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove luggage room lamp bulb.
3. Turn the ignition switch ON.
4. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		LUGGAGE LAMP TEST	
M120	30		On	Existed
			Off	Not existed

#### Is the measurement value normal?

- YES >> GO TO 2.  
 Fixed ON>>GO TO 3.  
 Fixed OFF>>Replace BCM.

### 2.CHECK LUGGAGE ROOM LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and luggage room lamp connector.
3. Check continuity between BCM harness connector and luggage room lamp harness connector.

BCM		Luggage room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M120	30	B53	2	Existed

#### Does continuity exist?

- YES >> Replace the luggage room lamp.

# LUGGAGE ROOM LAMP CIRCUIT

[COUPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair the harnesses or connectors.

## 3. CHECK LUGGAGE ROOM LAMP SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and luggage room lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	30		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:000000005233663

Provides the power supply and the ground to control the push-button ignition switch illumination.

### Component Function Check

INFOID:000000005233664

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

**On** : Push-button ignition switch illumination ON

**Off** : Push-button ignition switch illumination OFF

##### Does the push-button ignition switch illumination turn ON/OFF?

- YES >> Push-button ignition switch illumination circuit is normal.  
NO >> Refer to [INL-51, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005233665

#### 1. CHECK ILLUMINATION CONTROL SWITCHING OPERATION

1. Turn the ignition switch ON.
2. With operating the lighting switch, check that the push-button ignition switch illumination turns ON/OFF.

Condition	Push-button ignition switch illumination
<ul style="list-style-type: none"><li>• Ignition switch ON</li><li>• Lighting switch 1ST</li></ul>	ON
<ul style="list-style-type: none"><li>• Ignition switch OFF</li><li>• Lighting switch OFF</li><li>• Driver door LOCK</li></ul>	OFF

##### Does the push-button ignition switch illumination turn ON/OFF?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M119	14	M50	2	Existed

##### Does the continuity exist?

- YES >> Replace BCM.  
NO >> Repair the harness or the connector.

#### 3. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[COUPE]

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		ENGINE SW ILLUMI	5 V
Connector	Terminal		
M123	133	ON	5 V
		OFF	0 V

Is the measurement value normal?

- YES >> GO TO 4.  
NO >> GO TO 5.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	133	M50	3	Existed

Does the continuity exist?

- YES >> Replace the push-button ignition switch.  
NO >> Repair the harness or the connector.

## 5. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	133		Not existed

Does the continuity exist?

- YES >> Repair the harness or the connector.  
NO >> Replace BCM.

# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[COUPE]

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000005233677

**CAUTION:**

**Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.**

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. • Map lamp • Luggage room lamp • Vanity mirror lamp	<ul style="list-style-type: none"> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Interior room lamp power supply circuit Refer to <a href="#">INL-45</a> .
<ul style="list-style-type: none"> <li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li> <li>• Interior room lamp does not turn OFF even though the door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each door switch</li> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-88</a> .
		Interior room lamp control circuit Refer to <a href="#">INL-47</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to <a href="#">INL-15</a> .
<ul style="list-style-type: none"> <li>• Luggage room lamp does not turn ON. (The bulb is normal.)</li> <li>• Luggage room lamp does not turn OFF.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and back door switch</li> <li>• Harness between BCM and luggage room lamp</li> <li>• BCM</li> </ul>	Back door switch circuit Refer to <a href="#">DLK-88</a> .
		Luggage room lamp circuit Refer to <a href="#">INL-49</a> .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none"> <li>• Harness between BCM and push-button ignition switch</li> <li>• BCM</li> </ul>	Push-button ignition switch illumination circuit Refer to <a href="#">INL-51</a> .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to <a href="#">INL-16</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# MAP LAMP

< REMOVAL AND INSTALLATION >


[COUPE]

## REMOVAL AND INSTALLATION

### MAP LAMP

#### Exploded View


INFOID:000000005233680



1. Map lamp assembly

2. Bulb

3. Lens

 : Pawl

### Removal and Installation

INFOID:000000005233681

Refer to [INT-25. "Exploded View"](#) for the map lamp assembly installation/removal.

### Replacement

INFOID:000000005233682

#### **CAUTION:**

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### MAP LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

# VANITY MIRROR LAMP


< REMOVAL AND INSTALLATION >

[COUPE]

## VANITY MIRROR LAMP


Exploded View

INFOID:000000005233683



1. Lens

2. Bulb

 : Pawl

## Replacement

INFOID:000000005233684

### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### VANITY MIRROR LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# LUGGAGE ROOM LAMP


< REMOVAL AND INSTALLATION >

[COUPE]


## LUGGAGE ROOM LAMP

Exploded View

INFOID:000000005233685



1. Luggage room lamp assembly
2. Bulb

 : Pawl

### Removal and Installation

INFOID:000000005233686

#### **CAUTION:**

**Disconnect the battery negative terminal or remove the fuse.**

#### REMOVAL

1. Insert any appropriate tool into the gap between the luggage room lamp assembly and luggage finisher lower. Remove the luggage room lamp assembly.
2. Disconnect the connector.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000005233687

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

#### LUGGAGE ROOM LAMP BULB

1. Remove the luggage room lamp assembly.
2. Remove the bulb.



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[COUPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000005233688

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	Wedge	8
Vanity mirror lamp	—	2
Luggage room lamp	Wedge	5

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

**INL**

&lt; PRECAUTION &gt;

## PRECAUTION

### PRECAUTIONS

#### FOR USA AND CANADA

#### FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005476787

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### FOR USA AND CANADA : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:00000000557284

**NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

**NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

# PRECAUTIONS

[ROADSTER]

< PRECAUTION >

- When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- Perform self-diagnosis check of all control units using CONSULT-III.

## FOR USA AND CANADA : Precaution for Battery Service

INFOID:000000005476788

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

## FOR MEXICO

## FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005664437

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

## PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

### WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

## FOR MEXICO : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000005577285

### NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

## OPERATION PROCEDURE

- Connect both battery cables.

### NOTE:

Supply power using jumper cables if battery is discharged.

- Turn the push-button ignition switch to ACC position.

# PRECAUTIONS

[ROADSTER]

< PRECAUTION >

(At this time, the steering lock will be released.)

3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

## FOR MEXICO : Precaution for Battery Service

INFOID:000000005568595

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.


SYSTEM DESCRIPTION

COMPONENT PARTS

INTERIOR ROOM LAMP CONTROL SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM : Component Parts Location

INFOID:000000005476791



- |   |  |                           |
|---|--|---------------------------|
| 1. Remote keyless entry receiver<br>Refer to <a href="#">SEC-13, "Component Parts Location"</a> . | 2. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> .                 | 3. Door switch            |
| 4. • Key cylinder switch<br>• Request switch  | 5. Soft top control unit<br>Refer to <a href="#">RF-12, "Component Parts Location"</a> | 6. Trunk room lamp switch |
| 7. Trunk room lamp  | 8. Cargo area courtesy light   | 9. Map lamp               |
| 10. Door lock and unlock switch   | 11. Push-button ignition switch<br>(Push-button ignition switch illumination)          |                           |

INTERIOR ROOM LAMP CONTROL SYSTEM : Component Description

INFOID:000000005476792

Part	Description
BCM	<ul style="list-style-type: none"> <li>Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamp ON/OFF.</li> <li>Turns the trunk room lamp ON /OFF according to the trunk room lamp switch status.</li> </ul>
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.
<ul style="list-style-type: none"> <li>Door lock and unlock switch</li> <li>Key cylinder switch</li> </ul>	Transmits a switch signal by power window switch serial link.
<ul style="list-style-type: none"> <li>Request switch</li> <li>Door switch</li> <li>Trunk room lamp switch</li> </ul>	Inputs a switch signal to BCM.
Soft top control unit	Refer to <a href="#">RF-17</a>

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM


## COMPONENT PARTS

< SYSTEM DESCRIPTION >

[ROADSTER]

### INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Parts Location

INFOID:000000005476795



- |   |  |                           |
|---|--|---------------------------|
| 1. Remote keyless entry receiver<br>Refer to <a href="#">DLK-210, "Remote Keyless Entry Receiver"</a> . | 2. BCM<br>Refer to <a href="#">BCS-9, "Component Parts Location"</a> .                 | 3. Door switch            |
| 4. • Key cylinder switch<br>• Request switch  | 5. Soft top control unit<br>Refer to <a href="#">RF-12, "Component Parts Location"</a> | 6. Trunk room lamp switch |
| 7. Trunk room lamp  | 8. Cargo area courtesy light   | 9. Map lamp               |
| 10. Vanity mirror lamp  | 11. Door lock and unlock switch  | 12. Key slot              |
| 13. Push-button ignition switch   |  |                           |

### INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Component Description

INFOID:000000005476796

Part	Description
BCM	Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply.
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.
• Door lock and unlock switch • Key cylinder switch	Transmits a switch signal by power window switch serial link.
• Request switch • Door switch • Trunk room lamp switch	Inputs a switch signal to BCM.
Key slot	Inputs the key switch status to BCM.
Soft top control unit	Refer to <a href="#">RF-17</a>

### ILLUMINATION CONTROL SYSTEM


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[ROADSTER]

## ILLUMINATION CONTROL SYSTEM : Component Parts Location

INFOID:000000005476799



- |   |  |                              |
|---|--|------------------------------|
| <p>1. BCM<br/>Refer to <a href="#">BCS-9, "Component Parts Location"</a>.</p> <p>4. Combination meter</p> | <p>2. IPDM E/R<br/>Refer to <a href="#">PCS-6, "Component Parts Location"</a>.</p> <p>5. Illumination control switch</p> | <p>3. Combination switch</p> |
|---|--|------------------------------|

## ILLUMINATION CONTROL SYSTEM : Component Description

INFOID:000000005476800


Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination meter	<ul style="list-style-type: none"> <li>• Enters in nighttime mode according to the request from BCM (with CAN communication).</li> <li>• Controls the each illumination in the nighttime mode. Refer to <a href="#">MWI-6, "METER SYSTEM : System Diagram"</a>.</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .

SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram

INFOID:000000005476789



INTERIOR ROOM LAMP CONTROL SYSTEM : System Description


INFOID:000000005476790

OUTLINE

- Interior room lamps\* are controlled by interior room lamp timer control function of BCM.  
\*: Map lamp (when map lamp switch is in DOOR position) and cargo area courtesy light (when map lamp switch is in DOOR position).
- Trunk room lamp is controlled by Trunk room lamp control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.

INTERIOR ROOM LAMP TIMER CONTROL

Interior Room Lamp Timer Basic Operation



- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room timer.



# SYSTEM

[ROADSTER]

## < SYSTEM DESCRIPTION >

- BCM judges the vehicle condition with the following items. It activates the interior room timer.
  - Ignition switch status
  - Door switch signal (ALL)
  - Door lock/unlock signal (Remote keyless entry receiver, each door request switch, key cylinder switch, door lock and unlock switch)

### NOTE:

Each function of interior room lamp timer can be set by CONSULT-III. Refer to [INL-70, "INT LAMP : CONSULT-III Function \(BCM - INT LAMP\) \(Roadster Models\)"](#).

### Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- BCM activates the interior room timer in any of the following conditions to turn the interior room lamp ON for a period of time.
  - Any door opens before all doors close.
  - Ignition switch is turned ON → OFF.
  - Any door unlock signal is detected when all doors close with ignition switch OFF.

### NOTE:

Restart the timer if new condition is input during the timer operating time.

### Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turns the interior room lamp OFF.

- The timer operating time is expired.
- Ignition switch position is other than OFF with all doors close.
- Any door lock operation is detected with all doors close.

## TRUNK ROOM LAMP CONTROL

BCM controls the trunk room lamp (ground-side) to turn ON with the trunk room lamp switch ON.

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

### Push-button Ignition Switch Illumination Basic Operation

- BCM provides the power supply and the ground to turn the push-button ignition switch illumination ON.
- BCM cuts the ground supply while the each illumination (tail lamp) ON. BCM switches to the ground control with the meter illumination control function.

### Push-button Ignition Switch Illumination ON Operation

BCM turns the push-button ignition switch illumination ON in the following conditions.

- Ignition switch ON
- Each illumination (tail lamp) ON
- Any of the following conditions with ignition switch OFF
  - Engine start permission is entered.
  - Intelligent Key inserted into the key slot.
  - Driver door is LOCK → UNLOCK.
  - Driver door is open.

### Push-button Ignition Switch Illumination OFF Operation


BCM turns the push-button ignition switch illumination OFF in any of the following conditions.

- The push-button ignition switch illumination ON conditions do not satisfy.
- All of the following conditions with ignition switch OFF
  - Each illumination (tail lamp) OFF
  - The push-button ignition switch illumination ON conditions do not change (15 seconds after the ignition switch OFF) or the driver door is UNLOCK → LOCK.

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000005476793



JMLIA0655GB

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000005476794

OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the battery from over-discharging if the driver neglect turning OFF the any lamps.

Applicable lamps

- Map lamp
- Cargo area coutesy light
- Trunk room lamp
- Vanity mirror lamp

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned OFF, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signals changes while operating the timer.
  - Ignition switch status
  - Door switch signal (ALL)
  - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, central door lock/unlock switch)
  - Trunk room lamp switch signal
  - Key switch signal (Key slot)
- BCM provides the interior room lamp power supply continuously when the ignition switch position is other than OFF.


NOTE:

Each function of interior room lamp battery saver can be set by CONSULT-III. Refer to [INL-71, "BATTERY SAVER : CONSULT-III Function \(BCM - BATTERY SAVER\) \(Roadster Models\)"](#).

ILLUMINATION CONTROL SYSTEM

## ILLUMINATION CONTROL SYSTEM : System Diagram

INFOID:000000005476797



## ILLUMINATION CONTROL SYSTEM : System Description

INFOID:000000005476798

### OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R and combination meter.

#### Control by BCM

- Combination switch reading function
- Headlamp control function

#### Control by IPDM E/R

- Relay control function

#### Control by combination meter

- Meter illumination control function (Refer to [MWI-6, "METER SYSTEM : System Diagram"](#).)

### ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition.

#### Tail lamp ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (BCM)

[ROADSTER]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005588105

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*			
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door/Trunk lid open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[ROADSTER]

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	A
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	B
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")	C
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)	D
	LOCK>ACC	While turning power supply position from "LOCK" to "ACC"	E
	ACC>ON	While turning power supply position from "ACC" to "IGN"	F
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)	G
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)	H
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)	I
	ACC>OFF	While turning power supply position from "ACC" to "OFF"	J
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"	K
	OFF>ACC	While turning power supply position from "OFF" to "ACC"	L
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"	M
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode	N
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode	O
	LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)	P
	OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)	Q
	ACC	Power supply position is "ACC" (Ignition switch ACC)	R
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)	S
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)	T	
CRANKING	Power supply position is "CRANKING" (At engine cranking)	U	
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	V

## INT LAMP


# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[ROADSTER]

## INT LAMP : CONSULT-III Function (BCM - INT LAMP) (Roadster Models) INFOID:000000005476803

### WORK SUPPORT



Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function	
	OFF	Without the interior room lamp timer function	
ROOM LAMP TIMER SET	MODE 2	7.5 sec.	Sets the interior room lamp ON time. (Timer operating time)
	MODE 3*	15 sec.	
	MODE 4	30 sec.	
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual brightening time.
	MODE 2*	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual dimming time.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4*	3 sec.	
	MODE 5	0 sec.	
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.	
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.	

\*: Factory setting

### DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[ROADSTER]

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
KEY SW-SLOT [On/Off]	Key switch status input from key slot
DOOR SW-DR [On/Off]	The switch status input from driver side door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	
DOOR SW-BK [On/Off]	
CDL LOCK SW [On/Off]	Lock switch status received from the door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status received from the door lock and unlock switch
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

## ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs the interior room lamp control signal to turn map lamp and cargo area courtesy light ON (Map lamp switch is in DOOR position).
	Off	Stops the interior room lamp control signal to turn map lamp and cargo area courtesy light OFF.
STEP LAMP TEST	On	<b>NOTE:</b> The item is displayed, but cannot be tested.
	Off	
LUGGAGE LAMP TEST	On	Outputs the trunk room lamp control signal to turn the trunk room lamp ON.
	Off	Stops the trunk room lamp control signal to turn the trunk room lamp OFF.

## BATTERY SAVER

**BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER) (Roadster Models)**

INFOID:000000005476804

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[ROADSTER]

Service item	Setting item	Setting	
BATTERY SAVER SET	On*	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	
ROOM LAMP BAT SAV SET	On*	With the interior room lamp battery saver function	
	Off	Without the interior room lamp battery saver function	
ROOM LAMP TIMER SET	MODE 1*	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	

\*: Factory setting

## DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
KEY SW-SLOT [On/Off]	Key switch status input from key slot
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
DOOR SW-DR [On/Off]	The switch status input driver side front door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	
DOOR SW-BK [On/Off]	
CDL LOCK SW [On/Off]	Lock switch status received from the door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status received from the door lock and unlock switch
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver



# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[ROADSTER]

## ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamp OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamp ON.*

\*: Each lamp switch is in ON position.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

**INL**

# DIAGNOSIS SYSTEM (SOFT TOP CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ROADSTER]

## DIAGNOSIS SYSTEM (SOFT TOP CONTROL UNIT)

### CONSULT-III Function

INFOID:000000005588106

#### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with soft top control unit.

Diagnosis mode	Function Description
ECU Identification	The soft top control unit part number is displayed.
Self Diagnostic Result	Displays the diagnosis results judged by soft top control unit.
Freeze Frame Data	The soft top control unit records the vehicle condition at the time when the DTC is detected, and displays.
Data Monitor	The soft top control unit input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from soft top control unit.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from soft top control unit. Refer to CONSULT-III operation manual.

#### SELF-DIAG RESULT

Refer to [RF-41. "DTC Index"](#).

#### Freeze Frame Data

The soft top control unit records the following vehicle condition at the time when the DTC is detected, and displays on CONSULT-III.

CONSULT-III display		Description
Item	Indication	
ROOF SW (OPEN)	ON/OFF	OPEN input state of roof open/close switch is displayed.
ROOF SW (CLOSE)	ON/OFF	CLOSE input state of roof open/close switch is displayed.
ROOF LATCHED LH	ON/OFF	Input state of roof striker sensor LH is displayed.
ROOF LATCHED RH	ON/OFF	Input state of roof striker sensor RH is displayed.
F/CENTER LOCK	ON/OFF	Input state of roof latch lock sensor is displayed.
R/RAIL RAISED LH	ON/OFF	Input state of roof status sensor LH is displayed.
R/RAIL RAISED RH	ON/OFF	Input state of roof status sensor RH is displayed.
R/RAIL LOWERED	ON/OFF	Input state of roof status sensor LH is displayed.
5BOW LOWERED	ON/OFF	Input state of 5th bow status sensor LH is displayed.
5BOW RAISED	ON/OFF	Input state of 5th bow status sensor RH is displayed.
TRUNK STATUS SEN	ON/OFF	Input state of trunk status sensor is displayed.
S/LID OPEN LH	ON/OFF	Input state of storage lid status sensor LH is displayed.
S/LID OPEN RH	ON/OFF	Input state of storage lid status sensor RH is displayed.
S/LID CLOSE RH	ON/OFF	Input state of storage lid status sensor RH is displayed.
5TH BOW LATCH OP	ON/OFF	Input state of 5th bow latch open sensor is displayed.
5TH BOW LATCH CL	ON/OFF	Input state of 5th bow latch close sensor is displayed.
5BOW STRIK LATCH	ON/OFF	Input state of 5th bow striker sensor is displayed.
FLPD LIMIT SW(DWN)	ON/OFF	Input state of flipper door limit switch (DOWN) is displayed.
SWITCH VALVE 1	ON/OFF	Output state to switching valve 1 is displayed.
SWITCH VALVE 2	ON/OFF	Output state to switching valve 2 is displayed.
SWITCH VALVE 3	ON/OFF	Output state to switching valve 3 is displayed.
SWITCH VALVE 4	ON/OFF	Output state to switching valve 4 is displayed.
SWITCH VALVE 5	ON/OFF	Output state to switching valve 5 is displayed.

# DIAGNOSIS SYSTEM (SOFT TOP CONTROL UNIT)

[ROADSTER]

## < SYSTEM DESCRIPTION >

CONSULT-III display		Description
Item	Indication	
PUMP OUT (LH)	ON/OFF	Right rotation output state to hydraulic motor is displayed.
PUMP OUT (RH)	ON/OFF	Left rotation output state to hydraulic motor is displayed.

## DATA MONITOR

CONSULT-III display		Description
Item	Indication/Unit	
ROOF LATCHED LH	ON/OFF/NG	Input state of roof striker sensor LH is displayed.
ROOF LATCHED RH	ON/OFF/NG	Input state of roof striker sensor RH is displayed.
F/CENTER LOCK	ON/OFF/NG	Input state of roof latch lock sensor is displayed.
R/RAIL RAISED LH	ON/OFF/NG	Input state of roof status sensor LH is displayed.
R/RAIL RAISED RH	ON/OFF/NG	Input state of roof status sensor RH is displayed.
R/RAIL LOWERED	ON/OFF/NG	Input state of roof status sensor LH is displayed.
5TH BOW LOWERED	ON/OFF/NG	Input state of 5th bow status sensor LH is displayed.
5TH BOW RAISED	ON/OFF/NG	Input state of 5th bow status sensor RH is displayed.
S/LID OPEN LH	ON/OFF/NG	Input state of storage lid status sensor LH is displayed.
S/LID OPEN RH	ON/OFF/NG	Input state of storage lid status sensor RH is displayed.
S/LID CLOSE RH	ON/OFF/NG	Input state of storage lid status sensor RH is displayed.
5TH BOW LATCH OP	ON/OFF/NG	Input state of 5th bow latch open sensor is displayed.
SWITCHING VALVE 1	ON/OFF/NG	Output state to switching valve 1 is displayed.
SWITCHING VALVE 2	ON/OFF/NG	Output state to switching valve 2 is displayed.
SWITCHING VALVE 3	ON/OFF/NG	Output state to switching valve 3 is displayed.
SWITCHING VALVE 4	ON/OFF/NG	Output state to switching valve 4 is displayed.
SWITCHING VALVE 5	ON/OFF/NG	Output state to switching valve 5 is displayed.
PUMP OUT (RH)	ON/OFF/NG	Right rotation output state to hydraulic motor is displayed.
PUMP OUT (LH)	ON/OFF/NG	Left rotation output state to hydraulic motor is displayed.
5TH BOW LATCH CL	ON/OFF/NG	Input state of 5th bow latch close sensor is displayed.
ROOF SW (OPEN)	ON/OFF	OPEN input state of roof open/close switch is displayed.
ROOF SW (CLOSE)	ON/OFF	CLOSE input state of roof open/close switch is displayed.
SHIFT R SIGNAL	ON/OFF	Input state of shift position (R position) is displayed.
TRUNK OPEN OUT	ON/OFF	Output state to trunk open signal is displayed.
THER PROTEC PUMP	OK/NG	Non-operation state of thermo protection (hydraulic pump) is displayed.
THER PROTEC RCU	OK/NG	Non-operation state of thermo protection (soft top control unit) is displayed.
PWR COND RCU	OK/NG	Diagnosis result of power supply (soft top control unit) is displayed.
PWR COND P/W	OK/NG	Diagnosis result of power supply (power window) is displayed.
LOCAL COMM 1	NG/SLEEP/NG	State of serial link 1 is displayed.
LOCAL COMM 2	NG/SLEEP/NG	State of serial link 2 is displayed.
REAR DEF OUT	OK/NG	Output state to rear window defogger is displayed.
5BOW STRIK LATCH	ON/OFF/NG	Input state of 5th bow striker sensor is displayed.
P/W OP REQ SW SIG	ON/OFF	Input state of power window open signal from request switch is displayed.
PROHIBIT P/W UP	ON/OFF	Output state to power window operation prohibition signal is displayed.
IGN ON SIG (BCM)	ON/OFF	Receiving state of ignition ON signal from BCM is displayed.
RF OP REQ SW SIG	ON/OFF	Input state of soft top open signal from request switch is displayed.

## ACTIVE TEST

# DIAGNOSIS SYSTEM (SOFT TOP CONTROL UNIT)

[ROADSTER]

< SYSTEM DESCRIPTION >

CONSULT-III display		Description
Item	Indication	
ROOF LATCHED LH/RH	LOCK	Roof lock assembly performs lock operation.
	UNLOCK	Roof lock assembly performs unlock operation.
STORAGE LID	OPEN	Storage lid performs open operation.
	CLOSE	Storage lid performs close operation.
SOFT TOP SYSTEM	UP	Soft top performs close operation.
	DOWN	Soft top performs open operation.
ROOF SYSTEM	OPEN	Soft top system performs open operation.
	CLOSE	Soft top system performs close operation.
5TH BOW SYSTEM	OPEN	1st bow and 5th bow performs fold operation.
	CLOSE	1st bow and 5th bow performs spread operation.
HYDRAULIC PRESSURE RELEASE	ON	Switching valve performs OFF operation.
TRUNK OPENER	ON	Trunk lid opener actuator performs unlock operation.
ROOF STATE OUTPUT (AUDIO)	ON	Full open position signal of roof is transmitted to audio unit.
	OFF	Full close position signal of roof is transmitted to audio unit.
POWER WINDOW (LH/RH)	UP	Power window (LH/RH) performs close operation.
	DOWN	Power window (LH/RH) performs open operation.
REAR WINDOW DEFOGGER	ON	Rear window defogger performs ON operation.
	OFF	Rear window defogger performs OFF operation.

## DIAGNOSIS SYSTEM (METER)

### Diagnosis Description

INFOID:000000005588107

#### SELF-DIAGNOSIS MODE

- LCD segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.


#### OPERATION PROCEDURE

1. Turn ignition switch OFF.
2. While pressing the trip reset switch (1), turn ignition switch ON.
3. Make sure that the trip meter displays "0000.0".


**NOTE:**

If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0". (The same way for "trip B".)


4. Press the trip reset switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)



5. The unified meter control unit is turned to self-diagnosis mode.
  - The segment dots of the information display LCD (1) blink alternately.
  - Speedometer, tachometer, volt meter, and oil temperature gauge return to zero respectively.
  - All the segments of clock, manual mode indicator, S-MODE indicator, odo/trip meter, and shift position indicator illuminate.



- The fuel gauge (1) blink alternately.
- The engine coolant temperature gauge (2) blink alternately.



**NOTE:**


- Check combination meter power supply and ground circuit when the self-diagnosis mode of the combination meter does not start. Replace combination meter if power supply and ground circuit are normal.
- When turning the ignition switch ON, if the triple meter has a malfunction and the self-diagnosis mode for triple meter does not start, check the power supply and ground circuit of the triple meter, and the communication line circuit (METER↔TRIPLE METER). Replace triple meter if power supply and ground circuit and the communication line circuit (METER↔TRIPLE METER) are normal.
- If any of the segments does not illuminate, replace the combination meter or the triple meter (only when the clock of a segment that does not illuminate).

# DIAGNOSIS SYSTEM (METER)

[ROADSTER]

## < SYSTEM DESCRIPTION >

6. Each meter activates by pressing the trip reset switch.



### NOTE:

- If any of the meters or gauges is not activated, replace combination meter or triple meter.
- The figure is reference.

## CONSULT-III Function (METER/M&A)

INFOID:000000005588108

### CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes via CAN communication and the combination meter.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	The combination meter checks the conditions and displays memorized errors.
	Data Monitor	Displays the combination meter input/output data in real time.
	Special function	Lighting history of the warning lamp and indicator lamp can be checked.

### SELF DIAG RESULT

Refer to [MWI-77. "DTC Index"](#).

### DATA MONITOR

#### Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h or mph]		Odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM via CAN communication. <b>NOTE:</b> 8191.875 is displayed when the malfunction signal is received.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°C]	X	Value of engine coolant temperature signal is received from ECM via CAN communication. <b>NOTE:</b> 215 is displayed when the malfunction signal is input.

# DIAGNOSIS SYSTEM (METER)

[ROADSTER]



< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description	
ABS W/L [On/Off]		Status of ABS warning lamp detected from ABS warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.	A
VDC/TCS IND [On/Off]		Status of VDC OFF indicator lamp detected from VDC OFF indicator lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.	B
SLIP IND [On/Off]		Status of SLIP indicator lamp detected from slip indicator lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.	C
BRAKE W/L [On/Off]		Status of brake warning lamp detected from brake warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication. <b>NOTE:</b> Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.	D
DOOR W/L [On/Off]		Status of door warning detected from door switch signal received from BCM via CAN communication.	E
TRUNK/GLAS-H [Off]		This item is displayed, but cannot be monitored.	F
HI-BEAM IND [On/Off]		Status of high beam indicator lamp detected from high beam request signal is received from BCM via CAN communication.	
TURN IND [On/Off]		Status of turn indicator lamp detected from turn indicator signal is received from BCM via CAN communication.	G
RR FOG IND [On/Off]		Status of rear fog lamp indicator lamp detected from rear fog lamp status signal is received from BCM via CAN communication.	H
LIGHT IND [On/Off]		Status of light indicator lamp detected from position light request signal is received from BCM via CAN communication.	
OIL W/L [On/Off]		Status of oil pressure warning lamp detected from oil pressure switch signal is received from BCM via CAN communication.	I
MIL [On/Off]		Status of malfunction indicator lamp detected from malfunctioning indicator lamp signal is received from ECM via CAN communication.	J
CRUISE IND [On/Off]		Status of CRUISE indicator lamp detected from CRUISE indicator lamp signal is received from ECM via CAN communication.	
ATC/T-AMT W/L [On/Off]		A/T CHECK indicator lamp status judged by the transmission check warning lamp signal received from TCM via CAN communication.	K
4WD W/L [Off]		This item is displayed, but cannot be monitored.	INL
4WD LOCK IND [Off]		This item is displayed, but cannot be monitored.	
FUEL W/L [On/Off]		Low-fuel warning lamp status detected by the identified fuel level.	M
WASHER W/L [On/Off]		Status of washer warning lamp judged from washer level switch input to combination meter.	
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp detected from tire pressure signal is received from BCM via CAN communication.	N
KEY G/Y W/L [On/Off]		Status of key warning lamp (yellow) detected from key warning signal is received from BCM via CAN communication.	O
KEY R W/L [Off]		This item is displayed, but cannot be monitored.	
KEY KNOB W/L [Off]		This item is displayed, but cannot be monitored.	P
AFS OFF IND [Off]		This item is displayed, but cannot be monitored.	
MT SYNC REV IND [On/Off]		Status of S-MODE indicator judged from S-MODE indicator signal received from ECM with CAN communication line.	

# DIAGNOSIS SYSTEM (METER)

[ROADSTER]

## < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
LCD [C&P N, C&P I, B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY, OUTKY, LK WN]		Displays status of Intelligent Key system warning detected from meter display signal is received from BCM via CAN communication.
SHIFT IND [P, R, N, D, L, M1, M2, M3, M4, M5, M6, M7]		<ul style="list-style-type: none"> <li>• Status of shift position indicator detected from shift position signal and manual mode indicator signal is received from TCM via CAN communication. (A/T models)</li> <li>• Status of shift position indicator detected from shift position signal is received from ECM via CAN communication. (with SynchroRev Match mode models)</li> </ul>
AT S MODE SW [Off]		This item is displayed, but cannot be monitored.
M RANGE SW [On/Off]		Status of manual mode switch.
NM RANGE SW [On/Off]		Status of non-manual mode switch.
AT SFT UP SW [On/Off]		Status of position select switch (up).
AT SFT DWN SW [On/Off]		Status of position select switch (down).
ST SFT UP SW [On/Off]		Status of paddle shifter up switch.
ST SFT DWN SW [On/Off]		Status of paddle shifter down switch.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch (driver side).
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
AMB POWER [Off]		This item is displayed, but cannot be monitored.
A/C AMP CONN [On/Off]		Status of A/C auto amp. connection recognition signal.
ENTER SW [On/Off]		Status of  (ENTER) switch.
SELECT SW [On/Off]		Status of  (SELECT) switch.
MT SYNC REV SW [On/Off]		Status of S-MODE switch.
DISTANCE [km]		Value of possible driving distance calculated by combination meter.
OUTSIDE TEMP [°C or °F]		<p>Ambient air temperature value converted from ambient sensor signal received from ambient sensor.</p> <p><b>NOTE:</b> This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)</p>
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit via CAN communication.
CRANKING SIG [On/Off]		Cranking status judged by the engine status signal received from ECM via CAN communication.



# DIAGNOSIS SYSTEM (METER)

[ROADSTER]

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
ST CNT SIG [On/Off]		Starter relay status judged by the starter relay status signal received from BCM via CAN communication.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.

**NOTE:**

Some items are not available according to vehicle specification.

## SPECIAL FUNCTION

Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

### W/L ON HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “W/L ON HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is :
  - 0 : The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
  - 1 - 39 : The number of times the engine was restarted after the 0 condition.
  - NO W/L ON HISTORY : Stores NO (0) turning on history of warning/indicator lamp.

**NOTE:**

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

Display Item

Display item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC/TCS IND	Lighting history of VDC OFF indicator lamp.
SLIP IND	Lighting history of SLIP indicator lamp.
BRAKE W/L	Lighting history of brake warning lamp.
DOOR W/L	Lighting history of door warning.
TRUNK/GLAS-H	This item is displayed, but cannot be monitored.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp.
C-ENG2 W/L	This item is displayed, but cannot be monitored.
CRUISE IND	Lighting history of CRUISE indicator lamp.
SET IND	This item is displayed, but cannot be monitored.
CRUISE W/L	This item is displayed, but cannot be monitored.
BA W/L	This item is displayed, but cannot be monitored.
O/D OFF IND	This item is displayed, but cannot be monitored.
ATC/T-AMT W/L	Lighting history of A/T CHECK indicator lamp.
ATF TEMP W/L	This item is displayed, but cannot be monitored.
CVT IND	This item is displayed, but cannot be monitored.
SPORT IND	This item is displayed, but cannot be monitored.
4WD W/L	This item is displayed, but cannot be monitored.
FUEL W/L	Lighting history of low fuel level warning.

# DIAGNOSIS SYSTEM (METER)

[ROADSTER]

< SYSTEM DESCRIPTION >

Display item	Description
WASHER W/L	Lighting history of low washer fluid warning
AIR PRES W/L	Lighting history of low tire pressure warning lamp.
KEY G/Y W/L	Lighting history of key warning lamp (yellow).
KEY R W/L	Lighting history of key warning lamp (red).
KEY KNOB W/L	This item is displayed, but cannot be monitored.
EPS W/L	This item is displayed, but cannot be monitored.
e-4WD W/L	This item is displayed, but cannot be monitored.
AFS OFF IND	This item is displayed, but cannot be monitored.
4WAS/RAS W/L	This item is displayed, but cannot be monitored.
HDC W/L	This item is displayed, but cannot be monitored.
SYS FAIL W/L	This item is displayed, but cannot be monitored.
SFT POSI W/L	This item is displayed, but cannot be monitored.
HV BAT W/L	This item is displayed, but cannot be monitored.
HEV BRAKE W/L	This item is displayed, but cannot be monitored.
SFT OPER W/L	This item is displayed, but cannot be monitored.
LANE W/L	This item is displayed, but cannot be monitored.
CHAGE W/L	Lighting history of charge warning lamp.
OIL LEV LOW	This item is displayed, but cannot be monitored.
DPF W/L	This item is displayed, but cannot be monitored.
TRAILER IND	This item is displayed, but cannot be monitored.
RUN FLAT W/L	This item is displayed, but cannot be monitored.
E-SUS W/L	This item is displayed, but cannot be monitored.
LAUNCH CNT W/L	This item is displayed, but cannot be monitored.
BRAKE PAD W/L	This item is displayed, but cannot be monitored.

# BCM, COMBINATION METER, SOFT TOP CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ROADSTER]

## ECU DIAGNOSIS INFORMATION

BCM, COMBINATION METER, SOFT TOP CONTROL UNIT

List of ECU Reference

INFOID:000000005476805

ECU	Reference
BCM	<a href="#">BCS-51, "Reference Value"</a>
	<a href="#">BCS-82, "Fail-safe"</a>
	<a href="#">BCS-85, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-86, "DTC Index"</a>
COMBINATION METER	<a href="#">MWI-57, "Reference Value"</a>
	<a href="#">MWI-76, "Fail-Safe"</a>
	<a href="#">MWI-77, "DTC Index"</a>
SOFT TOP CONTROL UNIT	<a href="#">RF-32, "Reference Value"</a>
	<a href="#">RF-39, "Fail-safe"</a>
	<a href="#">RF-40, "DTC Inspection Priority Chart"</a>
	<a href="#">RF-41, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


[ROADSTER]

## WIRING DIAGRAM

### INTERIOR ROOM LAMP CONTROL SYSTEM

#### Wiring Diagram

INFOID:000000005612306




# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

◊CP◊ : Coupe models  
 ◊RS◊ : Roadster models  
 \*2 97 : ◊CP◊  
 92 : ◊RS◊



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THB07V-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	Y	- [Coupe models]
4	W	- [Roadster models]
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	- [Coupe models]
33	W	- [Roadster models]
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	SB	-
47	V	-
48	SHIELD	-

51	W	-
52	R	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	- [Coupe models]
84	L	- [Roadster models]
85	LG	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	- [Coupe models]
94	G	- [Roadster models]
95	GR	-
95	LG	- [Roadster models]
96	L	-
97	Y	-
98	W	- [Coupe models]
98	Y/B	- [Roadster models]
99	LG	-
100	B	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B53
Connector Name	LUGGAGE ROOM LAMP
Connector Type	CJ02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	B55
Connector Name	TRUNK ROOM LAMP
Connector Type	S02FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	B56
Connector Name	WIRE TO WIRE
Connector Type	NS12MM-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	R	-
9	V	-
10	LG	-
11	GR	-
12	B	-

Connector No.	B63
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-
3	B	-

JCLWM4092GB


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	B66
Connector Name	BACK DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	B	-

Connector No.	B76
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Type	NS38FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	B	-

Connector No.	B61
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-RH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-


5	BR	-
6	B	-
8	Y	-
9	O	-
14	GR	-
15	SB	-
16	V	-
17	G	-
24	LG	-
25	V	-
31	L	-
32	P	-
34	O	-
35	R	-

Connector No.	B66
Connector Name	CARGO AREA COURTESY LIGHT
Connector Type	SS2FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-


Connector No.	B147
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	R	-
9	V	-
10	LG	-

11	GR	-
12	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	- [Coupe models]
3	R	- [Roadster models]
4	B	- [Coupe models]
7	R	- [Coupe models]
8	LG	- [Roadster models]
9	Y	-
11	R	-
20	G	-
21	R	-
30	B	-
40	W	-
41	V	-
42	G	-
43	L	-
44	SB	-
51	P	-
52	L	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	G	- [Coupe models]
58	R	- [Roadster models]
58	L	- [Coupe models]
59	B	- [Roadster models]
60	W	-
61	GR	-
62	B	-
63	Y	-
64	V	-

65	SB	- [Coupe models]
66	BG	- [Roadster models]
68	V	-
69	P	- [Coupe models]
68	GR	- [Roadster models]
69	L	- [Coupe models]
69	P	- [Roadster models]
70	G	- [Coupe models]
70	O	- [Roadster models]
80	V	-
81	SB	-
82	G	-
83	R	-
84	W	-
85	B	-
86	SHIELD	-
87	O	-
88	BR	-
89	Y	-
90	SHIELD	-
92	SB	- [Coupe models]
92	LG	- [Roadster models]
93	V	- [Coupe models]
93	W	- [Roadster models]
94	SHIELD	- [Coupe models]
94	G	- [Roadster models]
95	GR	- [Coupe models]
95	LG	- [Roadster models]
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	W	- [Coupe models]
98	Y/B	- [Roadster models]
99	G	-
100	BR	- [Coupe models]
100	Y	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	B206
Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
3	B	-

Connector No.	B216
Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B301
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	L	-
6	P	-

8	O	-
9	Y	-
14	BR	-
15	BR	-
16	W	-
17	DG	-
24	V	-
25	LG	-
31	BG	-
32	P	-
34	O	-
35	SB	-

Connector No.	B303
Connector Name	SOFT TOP CONTROL UNIT
Connector Type	TH40FEB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	SENSOR POWER SUPPLY (ROOF STRIKER SENSOR LH)
3	DG	ROOF STRIKER SENSOR RH
4	W	ROOF STRIKER SENSOR LH
8	Y	REVERSE SIGNAL
9	SB	POWER CONDITION (POWER WINDOW)
10	O	TRUNK LID OPEN SIGNAL
11	O	ROOF STATUS SIGNAL (INDICATOR)
12	SB	ROOF STATUS SIGNAL (AUDIO)
14	L	ROOF OPEN / CLOSE SWITCH (CLOSE)
15	LG	ROOF OPEN / CLOSE SWITCH (OPEN)
16	V	TRUNK ROOM LAMP SWITCH
17	BG	CAN-H
18	P	CAN-L
19	LG	LOCAL COMMUNICATION (POWER WINDOW)
20	V	LOCAL COMMUNICATION (BCM)
21	BR	SENSOR POWER SUPPLY (ROOF STRIKER SENSOR RH)
29	DG	GND
35	P	ROOF OPEN / CLOSE SWITCH (GND)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	BG	- [Coupe models] - [Roadster models]
11	P	- [Coupe models] - [Roadster models]
11	V	- [With BOSE system] - [Without BOSE system]
12	L	-
13	B	-
14	SB	- [Coupe models] - [Roadster models]
15	W	-
19	G	-
23	R	-
44	L	-
47	B	-
48	SB	-
49	W	-
50	LG	-
51	R	-
52	V	-
53	BG	- [Coupe models] - [Roadster models]
54	GR	-
55	G	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS36FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
4	Y	-
5	BG	- [Coupe models] - [Roadster models]
6	O	-
7	V	-
8	L	-
9	LG	-
10	Y	-
11	BR	-
12	SB	- [Coupe models] - [Roadster models]
13	R	-
14	G	-
15	B	-

Connector No.	D15
Connector Name	DRIVER SIDE DOOR LOCK ASSEMBLY
Connector Type	EQ6F5Y-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	- [Coupe models] - [Roadster models]
2	G	-
3	SB	-
4	B	-
5	V	-
6	GR	-



# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
10	V	-
11	LG	-
12	P	- [With BOSE system]
12	LG	- [Without BOSE system]
13	V	- [Coupe models without BOSE system]
13	L	- [Except for coupe models without BOSE system]
14	B	-
15	W	-
19	P	-
23	L	-
44	L	-
50	Y	-
51	Y	-
52	G	-
53	BG	- [Coupe models]
53	O	- [Roadster models]
54	GR	-
55	L	-

Connector No.	D38
Connector Name	POWER WINDOW SUB-SWITCH
Connector Type	NS16FW-CS

3	4
8	9
10	11
12	14
15	16

Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	BG	- [Coupe models]
4	O	- [Roadster models]
8	L	-

9	BR	-
10	W	-
11	B	-
12	R	-
14	Y	-
15	LG	-
16	Y	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4

16	17	18	19	20
21	22	23	24	25
26	27	28	29	30

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-

7A	BR	-
8A	L	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	V	-
11	V	-
12	L	-
13	B	-
14	Y	-
15	W	-
19	Y	-
23	Y/B	-
44	L	-
47	B	-
48	SB	-
49	SB	- [Roadster models with M/T]
49	Y	- [Except for roadster models with M/T]
50	W	-
51	R	-
52	L	-
53	W	-
54	G	-
55	R	-

43	G	-
44	R	- [Roadster models with M/T]
44	GR	- [Except for Roadster models with M/T]
45	BG	- [Coupe models]
46	O	- [Roadster models]
47	W	-
47	P	-
58	SHIELD	-
59	L	-
70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

Connector No.	M1
Connector Name	FUSE BLOCK (U/B)
Connector Type	NS80FW-M2

3A	7A
8A	17A
16A	6A
4A	4A

Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	- [Roadster models with M/T]
31	BR	- [Except for roadster models with M/T]
32	Y	- [Roadster models with M/T]
32	V	- [Except for roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
38	SB	-
40	W	-
41	LG	-
42	R	-
43	G	-
44	G	- [With A/T]
44	R	- [With M/T]
45	O	-
46	G	-
47	BR	-
47	BR	-
58	SHIELD	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-

21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	V	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-
51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	V	- [Roadster models]
65	SHIELD	-
66	LG	- [Coupe models]
66	P	- [Roadster models]
67	V	- [Coupe models]
67	L	- [Roadster models]
68	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-

81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
93	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	GR	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	-
98	Y/B	- [Coupe models]
99	W	-
100	B	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FN-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT [Roadster models with M/T]
2	GR	BAT [Except for roadster models with M/T]
3	W	CLOCK
4	Y	DATA
5	Y	ILL. BAT
6	LG	ILL
7	B	GND
11	R	KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FV




Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models]
7	V	- [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK03FER



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	R	- [Roadster models with M/T]
3	G	- [Except for roadster models with M/T]
4	BR	-
5	GR	-
6	Y	-
7	V	-
8	P	-

Connector No.	M106
Connector Name	WIPE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-
7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	M117
Connector Name	WIPE TO WIRE
Connector Type	TH62MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	- [Coupe models]
2	LG	- [Roadster models]
3	O	- [Coupe models]
3	B	- [Roadster models]
4	W	- [Coupe models]
4	G	- [Roadster models]
7	LG	- [Coupe models]
7	Y	- [Roadster models]
8	LG	-
9	Y	-
11	R	-
20	G	-
21	R	-
30	B	-
40	O	-
41	Y	-
42	G	-
43	L	-
44	SB	-
51	R	-
52	G	-
53	SHIELD	-
54	LG	- [Coupe models]
54	BR	- [Roadster models]
55	V	- [Coupe models]
55	Y	- [Roadster models]
56	SHIELD	-
57	G	- [Coupe models]
57	P	- [Roadster models]
58	R	- [Coupe models]
58	L	- [Roadster models]
59	B	-
60	W	-
61	GR	-
62	B	-
63	Y	-
64	L	-
65	G	-

66	O	- [Coupe models]
66	G	- [Roadster models]
67	V	- [Roadster models]
68	P	- [Coupe models]
68	GR	- [Roadster models]
69	L	- [Coupe models]
69	P	- [Roadster models]
70	L	- [Coupe models]
70	O	- [Roadster models]
80	W	- [Coupe models]
80	L	- [Roadster models]
81	Y	-
82	W	-
83	B	-
84	R	-
85	G	-
86	SHIELD	-
87	G	-
88	L	-
89	P	-
90	SHIELD	-
92	G	- [Coupe models]
92	LG	- [Roadster models]
93	R	- [Coupe models]
93	V	- [Roadster models]
94	SHIELD	-
94	G	- [Roadster models]
95	SB	- [Coupe models]
95	LG	- [Roadster models]
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	V	- [Coupe models]
98	Y/B	- [Roadster models]
99	G	-
100	BR	- [Coupe models]
100	Y	- [Roadster models]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS16FW-IC



1	3
2	

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS16FW-CS



4	5	8	9
11	13	14	15
17	18	19	

Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
8	V	SUPER LOCK OUTPUT [Roadster models]
9	G	ALL DOOR FUEL LID LOCK OUTPUT
11	BR	DRIVER DOOR FUEL LID UNLOCK OUTPUT
13	B	IGN (FUSE)
14	R	GND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT SIDE)
18	O	TURN SIGNAL LH (FRONT SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



20	23	24	25	26	28	29	30
21	22	27	31	32	33	34	35

Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	L	BACK DOOR OPEN OUTPUT [Coupe models]
23	Y	TRUNK LID OPEN OUTPUT [Roadster models]
24	O	REAR FOG OUTPUT
25	LG	TURN SIGNAL LH (REAR)
30	R	LUGGAGE ROOM LAMP OUTPUT

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



47	48	49	50	51	52	53	54	55	56	57	58	59	60
----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT- [Roadster models with M/T]
34	G	LUGGAGE ROOM ANT- [Except for roadster models with M/T]
35	V	LUGGAGE ROOM ANT+ [Roadster models with M/T]
35	R	LUGGAGE ROOM ANT+ [Except for roadster models with M/T]
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (FRONT E/F) CONT [Roadster models with M/T]
47	V	IGN RELAY (FRONT E/F) CONT [Except for roadster models with M/T]
52	SB	STARTER RELAY CONT
61	W	BACK DOOR REQUEST SW [Coupe models]
61	W	TRUNK LID REQUEST SW [Roadster models]
64	V	1-KEY WARN BUZZER (ENG ROOM) [Roadster models with M/T]
64	G	1-KEY WARN BUZZER (ENG ROOM) [Except for roadster models with M/T]
66	R	BACK DOOR SW [Coupe models]
66	R	TRUNK ROOM LAMP SW [Roadster models]
67	GR	BACK DOOR OPENER SW [Coupe models]

67	GR	TRUNK LID OPENER SW [Roadster models]
----	----	---------------------------------------

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



36	37	38	39	40	41	42	43	44	45	46
----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	B	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]
78	Y	ROOM ANT 1- [With M/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP.
81	W	NATS ANT AMP.
82	R	IGN RELAY (F/B) CONT
83	Y	KEYS ENT RECEIVER (FRONT) COMM [Roadster models with M/T]
83	GR	KEYS ENT RECEIVER (FRONT) COMM [Except for roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	GAN-L
91	L	GAN-H
92	LG	KEY SLOT TLL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	CLUTCH PEDAL REQUEST SW [Roadster models with M/T]
100	GR	DRIVER DOOR REQUEST SW [Roadster models with M/T]
100	SB	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
101	Y	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]

102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYS ENT RECEIVER (FRONT) PWR SUPPLY
105	GR	KEYS ENT RECEIVER (REAR) PWR SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

[ROADSTER]

## INTERIOR ROOM LAMP

Connector No.	M123
Connector Name	BCM BODY CONTROL MODULE
Connector Type	TH40FG-NH

Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COMM [Coupe models]
133	V	P/W SW & SOFT TOP C/U COMM [Roadster models]
134	R	LOCK IND
137	O	RECEIVER / SENSOR GND [Roadster models with M/T]
137	P	RECEIVER / SENSOR GND [Except for roadster models with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./KYL'S ENT (REAR) RECEIV COMM
140	G	SHIFT N/UP [With M/T]
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MP-CS15

Terminal No.	Color of Wire	Signal Name [Specification]
10	G	- [Coupe models]
10	V	- [Roadster models]
11	V	- [Coupe models]
11	LG	- [Roadster models]
12	LG	- [Roadster models]
13	V	-
14	B	-
15	W	-
19	Y	-
23	Y/B	-
44	R	- [Coupe models]
44	O	- [Roadster models]
50	Y	-
51	Y	-
52	G	- [Roadster models with M/T]
52	GR	- [Except for roadster models with M/T]
53	W	-
54	G	-
55	R	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH

Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-

7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	R2
Connector Name	VANITY MIRROR LAMP LH
Connector Type	MCA02FW

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	R3
Connector Name	VANITY MIRROR LAMP RH
Connector Type	MCA02FW

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK08FGY

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	B	-
4	SB	-
5	Y	-
6	GR	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH

Terminal No.	Color of Wire	Signal Name [Specification]
1	SS	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

INL

## ILLUMINATION

### Wiring Diagram

INFOID:000000005612307



2009/07/10


JCLWM4100GB

# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

- ◊ XM ◊ : Except for Mexico
- ◊ RS ◊ : Roadster models
- ◊ ON ◊ : Without NAVI
- ◊ WB ◊ : With BOSE system
- ◊ OB ◊ : Without BOSE system
- ◊ WS ◊ : With climate controlled seat
- ◊ HS ◊ : With heated seat



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


JCLWM4101GB

# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

- ◊ A : With A/T
- ◊ M : With M/T
- ◊ CP : Coupe models
- ◊ RS : Roadster models
- ◊ HS : With heated seat



\*: This connector is not shown in "Harness Layout".

JCLWM4102GB




# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

<MX> : For Mexico  
<A> : With A/T  
<MS> : With M/T and SynchroRev Match mode  
<NV> : With NAV



JCLWM4103GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

## ILLUMINATION

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	Y	-
4	W	-
6	V	-
7	LG	-
8	GR	-
9	SB	-
11	Y	-
12	W	-
13	BR	-
14	LG	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	O	-
25	L	-
26	P	-
31	W	-
32	B	-
33	P	-
33	W	-
34	R	-
35	B	-
40	Y	-
41	L	-
42	GR	-
43	BR	-
44	R	-
45	BG	-
45	O	-
46	SB	-
47	V	-
48	SHIELD	-


51	W	-
52	R	-
57	SHIELD	-
58	B	-
60	V	-
61	SB	-
62	SHIELD	-
63	BR	-
64	Y	-
65	SHIELD	-
66	P	-
67	L	-
68	SHIELD	-
69	R	-
70	G	-
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	R	-
82	B	-
83	GR	-
84	G	-
85	L	-
85	LG	-
86	V	-
87	BR	-
88	GR	-
93	Y	-
94	L	-
94	G	-
95	GR	-
95	LG	-
96	L	-
97	Y	-
98	W	-
98	Y/B	-
99	LG	-
100	B	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B63
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-
3	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-

10	BG	-
10	O	-
11	P	-
11	V	-
12	L	-
13	B	-
14	SB	-
14	Y	-
15	W	-
19	G	-
23	R	-
44	L	-
47	B	-
48	SB	-
49	W	-
50	LG	-
51	R	-
52	V	-
53	BG	-
53	O	-
54	GR	-
55	G	-

Connector No.	D7
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
7	V	-
8	LG	-
9	R	-
10	Y	-
12	G	-
13	GR	-
14	L	-
15	BG	-
15	O	-
16	BR	-

JCLWM4104GB


# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]


## ILLUMINATION

Connector No.	E5
Connector Name	SMALL INTELLIGENT POWER DISTRIBUTION MODULE (FRONT ROOM)
Connector Type	TH20PW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	R	-
7	R	-
11	BR	-
12	B/W	-
13	Y	-
16	LG	-
19	W	-
25	G	-
27	Y	-
28	L	-
30	GR	-
32	L	-
33	P	-
36	G	-


Connector No.	E6
Connector Name	SMALL INTELLIGENT POWER DISTRIBUTION MODULE (FRONT ROOM)
Connector Type	TH20PW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	Y	-
43	SB	-
44	W	-


45	G	-
46	V	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SB	-
2F	W	-
4F	G	-
6F	EG	- [Coupe models]
8F	O	- [Roadster models]
9F	L	-
9F	R	- [Coupe models]
9F	V	- [Roadster models]

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	V	-
12	R	-
13	L	-


14	GR	-
15	P	-
16	W	-
17	SB	-
20	LG	-
21	BR	- [Coupe models]
21	G	- [Roadster models]
31	L	-
32	Y	-
33	P	-
34	L	-
35	BR	-
36	V	-
37	Y	-
38	R	-
39	B	-
40	W	-
41	LG	-
42	SB	-
43	G	-
44	R	- [Roadster models with M/T]
44	GR	- [except for roadster models with M/T]
45	BG	- [Coupe models]
45	O	- [Roadster models]
46	W	-
47	P	-
59	SHIELD	-
59	L	-
70	P	-
80	W	-
81	P	-
82	G	-
83	V	-
84	L	-
85	BG	- [Coupe models]
85	O	- [Roadster models]
86	LG	-
87	R	-
89	P	-
91	W	-
92	L	-
93	G	-
94	Y	-
96	Y	-
97	BR	-
98	GR	-
99	LG	-
100	BG	- [Coupe models]
100	O	- [Roadster models]

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	BR	-
8A	L	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1B	Y	-
3B	P	-
4B	G	-
5B	O	-
6B	Y	-
8B	R	-
9B	SB	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# ILLUMINATION

## ILLUMINATION

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS12FW-CS



5C	AC	8C	2C	1C
12C	11C	10C	9C	8C
7C	6C	5C	4C	3C

Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	-
7C	B	-
9C	R	- [Coupe models]
10C	O	- [Roadster models]
11C	LG	-
12C	O	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

Terminal No.	Color of Wire	Signal Name [Specification]
7	Y	-
8	Y	-
9	G	-
10	V	-
11	V	-
12	L	-
13	B	-
14	Y	-
15	W	-
23	Y/B	-
44	L	-
47	B	-
48	SB	-
48	SB	- [Roadster models with M/T]

49	Y	-	[Except for roadster models with M/T]
50	W	-	-
51	R	-	-
52	L	-	- [With A/T]
53	W	-	- [With M/T]
54	G	-	-
55	R	-	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS18-TM4




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	L	-
4	L	-
7	B	-
8	P	-
9	L	- [Coupe models]
9	B	- [Roadster models]
11	GR	-
12	R	-
13	L	-
14	G	-
15	P	-
16	W	-
17	BR	-
20	GR	-
21	BR	- [Coupe models]
21	R	- [Roadster models]
31	L	-
31	BR	- [Roadster models with M/T]
32	Y	- [Except for roadster models with M/T]
32	V	- [Roadster models with M/T]
33	P	-
34	L	-
35	BR	-
36	SB	-
37	Y	-
38	LG	-
39	SB	-
40	W	-

41	LG	-	-
42	R	-	-
43	G	-	-
44	R	-	- [With A/T]
44	R	-	- [With M/T]
45	O	-	-
46	G	-	-
47	BR	-	-
58	SHIELD	-	-
59	L	-	-
70	R	-	-
80	LG	-	-
81	GR	-	-
82	V	-	-
83	V	-	-
84	L	-	-
85	BR	-	-
86	V	-	-
87	V	-	- [Roadster models with M/T]
87	G	-	- [Except for roadster models with M/T]
88	P	-	-
91	W	-	-
92	P	-	-
93	P	-	-
94	Y	-	-
96	P	-	-
97	GR	-	-
98	O	-	-
99	W	-	-
100	R	-	-

ILLUMINATION

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS (E-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	O	-
6	V	-
7	LG	-
8	SB	-
9	GR	-
11	Y	-
12	V	-
13	BR	-
14	V	-
15	B	-
16	V	-
20	SB	-
21	G	-
22	GR	-
23	V	-
24	R	-
25	L	-
26	P	-
31	W	-
32	B	-
33	W	-
34	R	-
35	B	-
40	L	-
41	R	-
42	GR	-
43	R	- [Coupe models]
43	V	- [Roadster models]
44	R	-
45	O	-
46	G	- [With A/T]
46	SB	- [With M/T]
47	R	- [With A/T]
47	V	- [With M/T]
48	SHIELD	-

51	V	-
52	R	-
57	SHIELD	-
58	B	-
60	L	- [Coupe models]
60	V	- [Roadster models]
61	R	- [Coupe models]
61	SB	- [Roadster models]
62	SHIELD	-
63	R	- [Coupe models]
63	BR	- [Roadster models]
64	G	- [Coupe models]
64	Y	- [Roadster models]
65	SHIELD	-
66	LG	- [Coupe models]
66	P	- [Roadster models]
67	V	-
67	L	- [Roadster models]
68	SHIELD	-
69	L	- [Coupe models]
69	R	- [Roadster models]
70	P	- [Coupe models]
70	G	- [Roadster models]
71	V	-
72	P	-
73	BR	-
74	GR	-
75	O	-
80	Y	-
81	W	-
82	BR	-
83	GR	-
84	L	-
85	LG	-
86	V	-
87	BR	-
88	SB	-
89	Y	-
94	SB	- [Coupe models]
94	L	- [Roadster models]
95	GR	- [Coupe models]
95	W	- [Roadster models]
96	L	-
97	LG	- [Coupe models]
97	Y	- [Roadster models]
98	BG	- [Coupe models]
98	Y/B	- [Roadster models]
99	W	-
100	B	-

Connector No.	M9
Connector Name	DIODE
Connector Type	2433S CS900




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-

Connector No.	M15
Connector Name	ROOF OPEN / CLOSE SWITCH
Connector Type	TK08FW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
3	V	-
4	BR	-
5	R	-
8	R	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	B	-
5	V	-
6	R	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-

Connector No.	M19
Connector Name	VDC OFF SWITCH
Connector Type	TK08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-
3	R	-
4	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL


# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]


## ILLUMINATION

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FV



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
4	B	-
5	B	-
6	L	-
7	Y	- [Coupe models] - [Roadster models]
8	G	-
11	LG	-
14	P	-
16	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FV-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M35
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK0BFY-EX-TV



Terminal No.	Color of Wire	Signal Name [Specification]
23	W	- [Coupe models] - [Roadster models]
28	R	-
29	Y	-
30	Y	-

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK0BFY-TV




Terminal No.	Color of Wire	Signal Name [Specification]
24	P	-
25	SB	-
28	W	- [Coupe models] - [Roadster models]
31	L	-
32	Y	-
33	B	-
34	LG	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK0BF8R



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	R	- [Roadster models with M/T] - [Except for roadster models with M/T]
4	BR	-
5	GR	-
8	Y	-
7	V	-
8	P	-


Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	O	IGNITION POWER SUPPLY
3	L	VEHICLE SPEED SIGNAL (2-PULSE)
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	R	ROOF STATUS SIGNAL
9	BR	COMMUNICATION SIGNAL (METER->TRIPLE METER)
10	L	COMMUNICATION SIGNAL (TRIPLE METER->METER)
12	G	S-MODE SWITCH SIGNAL
15	L	ACC POWER SUPPLY
16	R	AIR BAG SIGNAL
17	B	GROUND
18	V	AMBIENT SENSOR SIGNAL

19	G	A.C. AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	GR	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	Y	FUEL LEVEL SENSOR GROUND

Connector No.	M64
Connector Name	CLIMATE CONTROLLED RELAY SWITCH (RELAY SOI)
Connector Type	TK10FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	V	-
3	P	-
4	BR	-
5	GR	-
6	B	-
7	R	-
8	R	-

JCLWM4108GB

# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]


## ILLUMINATION

Connector No.	M65
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	GND
2	G	-
3	L	-
4	O	-
5	Y	-
6	B	-
7	R	-
8	R	-

Connector No.	M67
Connector Name	A/C CONTROL
Connector Type	TH10FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	IGNITION POWER SUPPLY
2	R	ILL+
3	W	ILL-
4	P	TX (SW>AMP)
5	L	RX (AMP>SW)
6	B	GROUND

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FP-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
3	V	ACC
4	R	ILL
5	R	ILL CONT
6	LG	AV COMM (H) [Coupe models]
8	Y	AV COMM (H) [Roadster models]
8	Y	AV COMM (L) [Coupe models]
8	P	AV COMM (L) [Roadster models]
9	BR	SW GND
14	SB	DISK EJECT SIGNAL

Connector No.	M80
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
2	L	SOUND SIGNAL FRONT SPEAKER LH (+)
3	V	SOUND SIGNAL FRONT SPEAKER LH (-)
6	P	STRG SW A
7	L	ACC
8	W	ILL (-)
9	R	ILL (+)
11	V	SOUND SIGNAL FRONT SPEAKER RH (+)
12	LG	SOUND SIGNAL FRONT SPEAKER RH (-)
15	B	STRG SW GND
16	L	STRG SW B
19	Y	BATTERY

Connector No.	M81
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BOSE AMP ON SIGNAL
2	LG	SOUND SIGNAL FRONT LH (+) [Coupe models]
2	P	SOUND SIGNAL FRONT LH (-) [Roadster models]
3	V	SOUND SIGNAL FRONT LH (+) [Coupe models]
3	L	SOUND SIGNAL FRONT LH (-) [Roadster models]
4	L	SOUND SIGNAL REAR LH (+) [Coupe models]
4	V	SOUND SIGNAL REAR LH (-) [Roadster models]
5	R	SOUND SIGNAL REAR LH (+) [Coupe models]
5	SB	SOUND SIGNAL REAR LH (-) [Roadster models]
6	P	STRG SW A [For Mexico]
6	W	STRG SW A [Except for Mexico]
7	L	ACC
8	W	ILL (-) [Coupe models]
8	O	ILL (-) [Roadster models]
9	R	ILL (+)
10	SHIELD	SHIELD
11	L	SOUND SIGNAL FRONT RH (+) [Coupe models]
11	R	SOUND SIGNAL FRONT RH (-) [Roadster models]
12	P	SOUND SIGNAL FRONT RH (+) [Coupe models]
12	G	SOUND SIGNAL FRONT RH (-) [Roadster models]
13	R	SOUND SIGNAL REAR RH (+) [Coupe models]
13	RR	SOUND SIGNAL REAR RH (-) [Roadster models]
14	G	SOUND SIGNAL REAR RH (+) [Coupe models]
14	Y	SOUND SIGNAL REAR RH (-) [Roadster models]
15	B	STRG SW GND
15	B	STRG SW B [For Mexico]
16	L	STRG SW B [Except for Mexico]
18	GR	VEHICLE SPEED SIGNAL (8-PULSE)
18	Y	BATTERY
19	Y	BATTERY
20	SHIELD	SHIELD

Connector No.	M86
Connector Name	AV CONTROL UNIT
Connector Type	TH32FPV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
65	V	PARKING BRAKE SIGNAL
67	B	COMPOSITE IMAGE GND
68	L	COMPOSITE IMAGE SIGNAL
71	SHIELD	SHIELD
72	R	MICROPHONE GND
73	G	COMM (CONT->DISP) [Coupe models]
73	R	COMM (CONT->DISP) [Roadster models]
74	P	CAN-L [Coupe models]
74	L	CAN-L [Roadster models]
75	Y	AV COMM (L)
76	Y	AV COMM (L)
79	R	ILL+
80	G	IGNITION SIGNAL
81	O	REVERSE SIGNAL
82	Y	VEHICLE SPEED SIGNAL (8-PULSE)
83	SHIELD	SHIELD
84	Y	-
87	G	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	R	COMM (DISP->CONT) [Coupe models]
89	G	COMM (DISP->CONT) [Roadster models]
89	L	CAN-H [Coupe models]
89	L	CAN-H [Roadster models]
91	LG	AV COMM (H)
92	LG	AV COMM (H)

A B C D E F G H I J K M N O P

INL


### ILLUMINATION

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	GR	- [Coupe models]
3	B	- [Roadster models]
4	P	- [Coupe models]
4	G	- [Roadster models]
5	B	-
6	L	-
7	B	-
8	G	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-
7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (IGN)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FY-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER SUPPLY
5	G	SUPER LOCK OUTPUT [Coupe models]
5	V	SUPER LOCK OUTPUT [Roadster models]
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	BR	BAT (FUSE)
13	B	GND
14	R	PUSH-BUTTON IGNITION SW ILL POWER
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE)
18	O	TURN SIGNAL LH (FRONT, SIDE)
19	P	ROOM LAMP TIMER CONTROL [Coupe models]
19	V	ROOM LAMP TIMER CONTROL [Roadster models]

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH04FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT 2- [Roadster models with M/T]
72	L	ROOM ANT 2- [Except for roadster models with M/T]
73	G	ROOM ANT 2+ [Roadster models with M/T]
73	P	ROOM ANT 2+ [Except for roadster models with M/T]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	L	ROOM ANT 1- [With A/T]
78	Y	ROOM ANT 1- [With M/T]
79	R	ROOM ANT 1+ [With A/T]
79	BR	ROOM ANT 1+ [With M/T]
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IGN RELAY (F/B) CONT
83	Y	PULSE ENT RECEIVER (FRONT COMM) [Roadster models with M/T]
83	GR	PULSE ENT RECEIVER (FRONT COMM) [Except for roadster models with M/T]
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-H
91	L	CAN-L
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	Y	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P [With A/T]
99	BR	CLUTCH PEDAL POS SW [Coupe models with M/T]
99	R	CLUTCH PEDAL POS SW [Roadster models with M/T]
100	G	PASSENGER DOOR REQUEST SW [Roadster models with M/T]
100	GR	PASSENGER DOOR REQUEST SW [Except for roadster models with M/T]
101	SB	DRIVER DOOR REQUEST SW [Roadster models with M/T]
101	Y	DRIVER DOOR REQUEST SW [Except for roadster models with M/T]
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KYLS ENT RECEIVER (FRONT) PWR SUPPLY
106	GR	KYLS ENT RECEIVER (REAR) PWR SUPPLY

106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW [Roadster models with M/T]
110	P	HAZARD SW [Except for roadster models with M/T]
111	Y	S/L UNIT COMM



# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

## ILLUMINATION

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH




Connector No.	M140
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS08FBR-CS



Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TK10PW



Connector No.	M252
Connector Name	WIRE TO WIRE
Connector Type	TK08MNF-NH



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	SHOCK SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	Y	POWER WINDOW SW COMM [Coupe models]
132	V	P/W SW & SOFT TOP C/U COMM [Roadster models]
133	R	P/WR INJECTION POSITION SW (L POWER [Roadster models, with M/T])
133	G	P/WR INJECTION POSITION SW (R POWER [Roadster models, with M/T])
134	GR	LOCK IND
137	O	RECEIVER/SENSOR GND [Roadster models, with M/T]
137	P	RECEIVER/SENSOR GND [except for roadster models, with M/T]
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESS./KYL'S ENT (REAR) RECEIV COMM
140	G	SHIFT N/P (With A/T)
140	G	P/N POSITION SW [With M/T]
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESSURE WARN CHECK SW
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY COINT

Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	[Coupe models]
1	O	[Roadster models]
2	SB	
3	B	
4	G	
5	B	
6	L	
7	G	
8	G	

Connector No.	M255
Connector Name	S-MODE SWITCH
Connector Type	TK04FCY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	
2	O	
3	GR	
4	B	
5	R	
6	W	

Connector No.	M144
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	GND
2	P	BCM
3	R	ILL+
4	B	ILL-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	
2	G	
3	L	
4	B	

JCLWM4111GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# ILLUMINATION

< WIRING DIAGRAM >

[ROADSTER]

## ILLUMINATION

Connector No.	M296
Connector Name	HAZARD SWITCH
Connector Type	TK08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	G	BCM
3	SB	ILL+
4	BG	ILL- [Cruise models]
4	O	ILL- [Roadster models]

Connector No.	M303
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	R	-
6	B	-
7	P	-
8	R	-
11	B	-
12	Y	-
13	G	-
14	SHIELD	-
15	R	-
16	G	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	B	-
4	SB	-
5	Y	-
6	GR	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	B	-
5	V	-
6	B	-
7	SHIELD	-
8	R	-
9	G	-
10	B	-
11	G	-
12	Y	-

JCLWM4112GB


**BASIC INSPECTION**

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005476817

OVERALL SEQUENCE



DETAILED FLOW

**1. INTERVIEW FOR MALFUNCTION**

Interview the symptom to the customer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# DIAGNOSIS AND REPAIR WORKFLOW

[ROADSTER]

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

## DTC/CIRCUIT DIAGNOSIS

### INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

#### Description

INFOID:0000000005476819

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

#### Component Function Check

INFOID:0000000005476820

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

##### CONSULT-III ACTIVE TEST

- Turn the ignition switch ON.
- Turn each interior room lamp ON.
  - Map lamp
  - Vanity mirror lamp
  - Trunk room lamp
  - Cargo area courtesy light
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test items, check that each interior room lamp turns ON/OFF.

**Off** : Interior room lamp OFF

**On** : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-109, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:0000000005476821

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

##### CONSULT-III ACTIVE TEST

- Turn the ignition switch ON.
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test item, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		BATTERY SAVER	0 V
Connector	Terminal		
M119	4	Off	0 V
		On	Battery voltage

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace BCM.

#### 2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the following connectors.
  - Map lamp
  - Vanity mirror lamp (LH)
  - Vanity mirror lamp (RH)
  - Trunk room lamp
  - Cargo area courtesy light
- Check continuity between BCM harness connector and each interior room lamp harness connector.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

BCM		Each interior room lamp			Continuity
Connector	Terminal	Connector		Terminal	
M119	4	Map lamp	R4	1	Existed
		Vanity mirror lamp (LH)	R2	2	
		Vanity mirror lamp (RH)	R3	2	
		Trunk room lamp	B55	1	
		Cargo area courtesy light	B86	1	

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

### 3. CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check that each interior room lamp has no internal short circuit.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:000000005476822

Controls each interior room lamp (ground side) by PWM signal.

#### NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

### Component Function Check

INFOID:000000005476823

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb

### 1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Switch the map lamp switch to DOOR.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

**On** : Interior room lamp gradual brightening

**Off** : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

- YES >> Interior room lamp control circuit is normal.  
 NO >> Refer to [INL-111, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005476824

### 1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove all the bulbs of map lamp.
3. Turn the ignition switch ON.
4. Select "INT LAMP" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		INT LAMP	
M119	19		On	Existed
			Off	Not existed

Is the measurement value normal?

- YES >> GO TO 2.  
 Fixed ON>>GO TO 3.  
 Fixed OFF>>Replace BCM.

### 2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and map lamp connector.
3. Check continuity between BCM harness connector and map lamp harness connector.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

BCM		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M119	19	R4	2	Existed

Does continuity exist?

YES >> Replace the map lamp.

NO >> Repair the harnesses or connectors.

## 3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and map lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	19		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.



# TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

## TRUNK ROOM LAMP CIRCUIT

### Description

INFOID:000000005476825

Controls the trunk room lamp (ground side) to turn the luggage room lamp ON and OFF.

### Component Function Check

INFOID:000000005476826

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Trunk room lamp bulb

### 1.CHECK TRUNK ROOM LAMP OPERATION

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that trunk room lamp turns ON/OFF.

- On** : Trunk room lamp ON  
**Off** : Trunk room lamp OFF

#### Does the Trunk room lamp turn ON/OFF?

- YES >> Trunk room lamp circuit is normal.  
 NO >> Refer to [INL-113, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005476827

### 1.CHECK TRUNK ROOM LAMP OUTPUT

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove trunk room lamp bulb.
3. Turn the ignition switch ON.
4. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		LUGGAGE LAMP TEST	
M120	30		On	Existed
			Off	Not existed

#### Is the measurement value normal?

- YES >> GO TO 2.  
 Fixed ON>>GO TO 3.  
 Fixed OFF>>Replace BCM.

### 2.CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and trunk room lamp harness connector.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M120	30	B55	2	Existed

#### Does continuity exist?

- YES >> Replace the trunk room lamp.

# TRUNK ROOM LAMP CIRCUIT

[ROADSTER]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair the harnesses or connectors.

## 3. CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	30		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:000000005476828

Provides the power supply and the ground to control the push-button ignition switch illumination.

### Component Function Check

INFOID:000000005476829

### 1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

**On : Push-button ignition switch illumination ON**

**Off : Push-button ignition switch illumination OFF**

#### Does the push-button ignition switch illumination turn ON/OFF?

- YES >> Push-button ignition switch illumination circuit is normal.  
NO >> Refer to [INL-115, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005476830

### 1.CHECK ILLUMINATION CONTROL SWITCHING OPERATION

1. Turn the ignition switch ON.
2. With operating the lighting switch, check that the push-button ignition switch illumination turns ON/OFF.

Condition	Push-button ignition switch illumination
<ul style="list-style-type: none"><li>• Ignition switch ON</li><li>• Lighting switch 1ST</li></ul>	ON
<ul style="list-style-type: none"><li>• Ignition switch OFF</li><li>• Lighting switch OFF</li><li>• Driver door LOCK</li></ul>	OFF

#### Does the push-button ignition switch illumination turn ON/OFF?

- YES >> GO TO 2.  
NO >> GO TO 3.

### 2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M119	14	M50	2	Existed

#### Does the continuity exist?

- YES >> Replace BCM. Refer to [BCS-92, "Exploded View"](#)  
NO >> Repair the harness or the connector.

### 3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

#### CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ROADSTER]

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		ENGINE SW ILLUMI	5 V
Connector	Terminal		
M123	133	ON	5 V
		OFF	0 V

Is the measurement value normal?

- YES >> GO TO 4.  
NO >> GO TO 5.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	133	M50	3	Existed

Does the continuity exist?

- YES >> Replace the push-button ignition switch.  
NO >> Repair the harness or the connector.

## 5. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	133		Not existed

Does the continuity exist?

- YES >> Repair the harness or the connector.  
NO >> Replace BCM. Refer to [BCS-92. "Exploded View"](#)

# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[ROADSTER]

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000005476831

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. • Map lamp • Cargo area courtesy light • Trunk room lamp • Vanity mirror lamp	<ul style="list-style-type: none"> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Interior room lamp power supply circuit Refer to <a href="#">INL-109</a> .
<ul style="list-style-type: none"> <li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li> <li>• Interior room lamp does not turn OFF even though the door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each door switch</li> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-285</a> .  Interior room lamp control circuit Refer to <a href="#">INL-111</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to <a href="#">INL-70</a> .
<ul style="list-style-type: none"> <li>• Trunk room lamp does not turn ON. (The bulb is normal.)</li> <li>• Trunk room lamp does not turn OFF.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and trunk room lamp switch</li> <li>• Harness between BCM and trunk room lamp</li> <li>• BCM</li> </ul>	Trunk room lamp switch circuit Refer to <a href="#">DLK-298</a> .  Trunk room lamp circuit Refer to <a href="#">INL-113</a> .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none"> <li>• Harness between BCM and push-button ignition switch</li> <li>• BCM</li> </ul>	Push-button ignition switch illumination circuit Refer to <a href="#">INL-115</a> .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to <a href="#">INL-71</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

INL

M  
N  
O  
P

# MAP LAMP

< REMOVAL AND INSTALLATION >


[ROADSTER]

## REMOVAL AND INSTALLATION

### MAP LAMP

#### Exploded View


INFOID:000000005476832



1. Map lamp assembly

2. Bulb

3. Lens

 : Pawl

### Removal and Installation

INFOID:000000005476833

Refer to [INT-25. "Exploded View"](#) for the map lamp assembly installation/removal.

### Replacement

INFOID:000000005476834

#### **CAUTION:**

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### MAP LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

# VANITY MIRROR LAMP


< REMOVAL AND INSTALLATION >

[ROADSTER]

## VANITY MIRROR LAMP

Exploded View

INFOID:000000005476835



1. Lens

2. Bulb

△ : Pawl

## Replacement

INFOID:000000005476836

### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### VANITY MIRROR LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# CARGO AREA COURTESY LIGHT


< REMOVAL AND INSTALLATION >

[ROADSTER]


## CARGO AREA COURTESY LIGHT

Exploded View

INFOID:000000005524218



1. Bulb
2. Cargo area courtesy light

 : Pawl

### Removal and Installation

INFOID:000000005524219

#### **CAUTION:**

**Disconnect the battery negative terminal or remove the fuse.**

#### REMOVAL

1. Insert any appropriate tool into the gap between cargo area courtesy light and rear parcel shelf assembly. Remove cargo area courtesy light.
2. Disconnect the connector.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000005524220

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

#### CARGO AREA COURTESY LIGHT BULB

1. Remove cargo area courtesy light. Refer to [INL-120, "Removal and Installation"](#).
2. Remove the bulb.



# TRUNK ROOM LAMP


< REMOVAL AND INSTALLATION >

[ROADSTER]

## TRUNK ROOM LAMP

Exploded View

INFOID:000000005476837



- 1. Trunk room lamp
- 2. Bulb
- A : Lens fixing pawl
- B : Trunk room lamp fixing pawl
- △ : Pawl

### Removal and Installation


INFOID:000000005476838

**CAUTION:**  
Disconnect the battery negative terminal or remove the fuse.

#### REMOVAL

1. Disengage lens (1) fixing pawl (A) and open the lens.
2. Remove the bulb.
3. Press trunk room lamp fixing pawl (B) toward the direction of the arrow and pull trunk room lamp down to remove it from the panel.
4. Disconnect the connector and remove trunk room lamp.

△ : Pawl



#### INSTALLATION

Install in the reverse order of removal.

#### Replacement

INFOID:000000005476839

- CAUTION:**
- Disconnect the battery negative terminal or remove the fuse.
  - Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
  - Never touch bulb by hand while it is lit or right after being turned off.
  - Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### TRUNK ROOM LAMP BULB

1. Disengage trunk room lamp lens fixing pawl with a remover tool and open the lens.
2. Remove the bulb.

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[ROADSTER]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000005476840

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	Wedge	8
Vanity mirror lamp	—	2
Trunk room lamp	Wedge	5
Cargo area courtesy light	Wedge	5