

WT

D

CONTENTS

REGULAR GRADE	SYSTEM9
PRECAUTION3	System Description9
	DIAGNOSIS SYSTEM (BCM)10
PRECAUTIONS3	COMMON ITEM10
EXCEPT FOR MEXICO	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)10
"SEAT BELT PRE-TENSIONER"3 EXCEPT FOR MEXICO : Precaution for Battery Service	AIR PRESSURE MONITOR11 AIR PRESSURE MONITOR : CONSULT Function11
EXCEPT FOR MEXICO : Service Notice and Precautions for TPMS	ECU DIAGNOSIS INFORMATION13
EXCEPT FOR MEXICO : Precautions for Removing Battery Terminal4	BCM
FOR MEXICO	WIRING DIAGRAM14
FOR MEXICO: Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	TIRE PRESSURE MONITORING SYSTEM14 Wiring Diagram14
FOR MEXICO : Service Notice and Precautions	BASIC INSPECTION18
for TPMS4 FOR MEXICO : Precautions for Removing Battery Terminal5	DIAGNOSIS AND REPAIR WORK FLOW18 Work Flow18
PREPARATION6	ADDITIONAL SERVICE WHEN REPLACING
PREPARATION	Description 20 Work Procedure 20 TIRE PRESSURE SENSOR WAKE UP OP- (1)
SYSTEM DESCRIPTION7	ERATION21
COMPONENT PARTS 7 Component Parts Location	Description21 Work Procedure21
Component Description7	ID REGISTRATION PROCEDURE22
BCM	Description22
Tire pressure sensor8 Tire pressure receiver8	Work Procedure22
The pressure receiver0	DTC/CIRCUIT DIAGNOSIS 24

C1704, C1705, C1706, C1707 LOW TIRE		Description	42
PRESSURE	24	Diagnosis Procedure	42
Description			
DTC Logic		LOW TIRE PRESSURE WARNING LAMP	
Diagnosis Procedure	24	BLINKS	43
Special Repair Requirement	25	Description	43
Opeolar Regali Regulierierie	20	Diagnosis Procedure	43
C1708, C1709, C1710, C1711 TIRE PRES-			
SURE SENSOR	26	ID REGISTRATION CANNOT BE COMPLET-	
DTC Logic		ED	
Diagnosis Procedure		Description	44
Special Repair Requirement		Diagnosis Procedure	44
Opeda Repair Requirement	20		
C1716, C1717, C1718, C1719 TIRE PRES-		NOISE, VIBRATION AND HARSHNESS	
SURE SENSOR	29	(NVH) TROUBLESHOOTING	45
DTC Logic		NVH Troubleshooting Chart	45
Diagnosis Procedure			
Special Repair Requirement		PERIODIC MAINTENANCE	46
Opeda Repair Requirement	50	DOAD WHEEL	40
C1729 VEHICLE SPEED SIGNAL	31	ROAD WHEEL	
Description		Adjustment	46
DTC Logic		REMOVAL AND INSTALLATION	40
Diagnosis Procedure		REMOVAL AND INSTALLATION	49
Special Repair Requirement		ROAD WHEEL TIRE ASSEMBLY	49
Opoolal Ropali Roquitorioni IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	0 1	Exploded View	
C1734 BCM	33	Removal and Installation	
DTC Logic	33	Inspection	
Diagnosis Procedure		How to Handle Puncture Repair Agent (With	43
Special Repair Requirement		Puncture Repair Kit)	5 0
·		Functure Repair Kit)	50
TIRE PRESSURE RECEIVER	35	TIRE PRESSURE SENSOR	51
Component Function Check	35	Exploded View	
Diagnosis Procedure	35	Removal and Installation	
TIDE DDEGGLIDE WARNING I AMD			
LOW TIRE PRESSURE WARNING LAMP		TIRE PRESSURE RECEIVER	53
Component Function Check		Removal and Installation	53
Diagnosis Procedure	37		
POWER SUPPLY AND GROUND CIRCUIT	20	SERVICE DATA AND SPECIFICATIONS	
		(SDS)	54
Diagnosis Procedure	38		
SYMPTOM DIAGNOSIS	39	SERVICE DATA AND SPECIFICATIONS	
	00	(SDS)	54
TPMS	39	Road Wheel	54
Symptom Table	39	Tire Air Pressure	54
	00	Nismo 370Z	
LOW TIRE PRESSURE WARNING LAMP			
DOES NOT TURN ON	41	SPEC CHANGE INFORMATION	55
Description			
Diagnosis Procedure		ROAD WHEEL TIRE ASSEMBLY	55
-		Road Wheel Tire Assembly	55
LOW TIRE PRESSURE WARNING LAMP		·	
DOES NOT TURN OFF	42		

PRECAUTIONS

[REGULAR GRADE] < PRECAUTION >

PRECAUTION

PRECAUTIONS EXCEPT FOR MEXICO

EXCEPT FOR MEXICO: Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" INFOID:0000000011735681

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

EXCEPT FOR MEXICO: Precaution for Battery Service

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

EXCEPT FOR MEXICO: Service Notice and Precautions for TPMS

- Low tire pressure warning lamp blinks for 1 minute, then turns ON when any malfunction occurs except low tire pressure. Erase the self-diagnosis memories for BCM, or register the ID to turn low tire pressure warning lamp OFF. For ID registration, refer to WT-22, "Description".
- ID registration is required when replacing wheels, replacing tire pressure sensor or BCM. Refer to WT-22. "Description".
- Replace grommet seal, valve core and valve cap of tire pressure sensor in TPMS when replacing each tire by reaching the wear limit. Refer to WT-51, "Exploded View".

WT

Α

INFOID:0000000011735682

INFOID:0000000011735683

Р

WT-3 Revision: 2015 June 2016 370Z < PRECAUTION > [REGULAR GRADE]

EXCEPT FOR MEXICO: Precautions for Removing Battery Terminal

INFOID:0000000011735684

SEF289H

BATTERY

60


 When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.


For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.
 NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected



The removal of 12V battery may cause a DTC detection error.

FOR MEXICO



The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the
 ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with
 a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing
 serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO: Precaution for Battery Service

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

FOR MEXICO: Service Notice and Precautions for TPMS

INFOID:0000000011735687

INFOID:0000000011735686

Low tire pressure warning lamp blinks for 1 minute, then turns ON when any malfunction occurs except low
tire pressure. Erase the self-diagnosis memories for BCM, or register the ID to turn low tire pressure warning
lamp OFF. For ID registration, refer to <a href="https://www.wtr.august.com/w

Revision: 2015 June **WT-4** 2016 370Z

< PRECAUTION > [REGULAR GRADE]

 ID registration is required when replacing wheels, replacing tire pressure sensor or BCM. Refer to <u>WT-22</u>, "Description".

Replace grommet seal, valve core and valve cap of tire pressure sensor in TPMS when replacing each tire
by reaching the wear limit. Refer to <u>WT-51</u>, "Exploded View".

FOR MEXICO: Precautions for Removing Battery Terminal

INFOID:0000000011735688


 When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur

 For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.
 NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.



After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.
 NOTE:

The removal of 12V battery may cause a DTC detection error.

WT

D

Α

В

F

G

Н

. 1

K

L

Ν

0

Р

Revision: 2015 June **WT-5** 2016 370Z

< PREPARATION > [REGULAR GRADE]

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000011735689

The actual shapes of TechMate tools may differ from those of special service tools illustrated here. Tool number (TechMate No.) Description Tool name • Activate and display TPMS tire pressure (J-50190) sensor IDs Signal tech II • Display tire pressure reported by the TPMS tire pressure sensor Read TPMS DTCs • Register TPMS tire pressure sensor IDs • Test remote keyless entry keyfob relative signal strength · Compatible with future sensors ALEIA0131ZZ · Equipped with a display KV48105501 • Activate TPMS tire pressure sensor IDs (J-45295-A) · Compatible with future sensors Tire pressure sensor activation tool • Equipped with a display (KV48105501 only)

Commercial Service Tool

INFOID:0000000011735690

Tool name		Description
Power tool		Loosening wheel nuts
	PBIC0190E	

ALEIA018377

INFOID:0000000011735691

Α


В

D

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location



- 1. Tire pressure sensor
- A. Wheel
 - **BCM**
- D. Refer to BCS-10, "Component Parts Location"
- 2. Tire pressure receiver
- B. Low tire pressure warning lamp (In the combination meter)
- C. Glove box assembly

Component Description

INFOID:0000000011735692

Ν

Р

Component parts	Function	
BCM (Body Control Module)	WT-7, "BCM".	
Tire pressure sensor	WT-8. "Tire pressure sensor".	
Tire pressure receiver	WT-8, "Tire pressure receiver".	
Turn signal lamp	ID registration of each wheel has been completed, turn signal lamp flashes.	
	Transmits the vehicle speed signal via CAN communication to BCM.	
Combination meter	Receives the following signals via CAN communication to BCM. • Low tire pressure warning lamp signal • TPMS malfunction warning lamp signal	

BCM

The BCM reads the tire pressure signal received by the tire pressure receiver, and controls the low tire pressure warning lamp and the buzzer operations. It also has a judgment function to detect a system malfunction.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[REGULAR GRADE]

Tire pressure sensor

INFOID:0000000011735694

The tire pressure sensor integrated with a valve is installed on a wheel, and transmits a detected tire pressure signal by radio wave.

Tire pressure receiver

INFOID:0000000011735695

The tire pressure receiver receives the tire pressure signal transmitted by the tire pressure sensor in each wheel.

SYSTEM

System Description

INFOID:0000000011735696

Α

В

C

D


WT

Н

K

During driving, the TPMS (Tire Pressure Monitoring System) receives the signal transmitted from tire pressure sensor installed in each wheel. The BCM (Body Control Module) of this system has pressure judgment and trouble diagnosis functions. When the tire pressure monitoring system detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL

Revision: 2015 June

The signal transmission/reception between units via a communication line is mainly as listed in the following table.

Component parts	Signal item
BCM	Transmits the following signals via CAN communication to combination meter. Low tire pressure warning lamp signal TPMS malfunction warning lamp signal
Combination meter	Transmits the vehicle speed signal via CAN communication to BCM.

LOW TIRE PRESSURE WARNING LAMP INDICATION CONDITION

Uses CAN communication from the BCM to illuminate the low tire pressure warning lamp on the combination meter.

Condition	Low tire pressure warning lamp	
Ignition switch OFF	OFF	
Ignition switch ON (system normal)	Warning lamp turns on for 1second, then turns off.	
Low tire pressure	ON	
Tire pressure sensor ID not registered in BCM	ON	
Tire pressure monitoring system malfunction (Other diagnostic item)	Warning lamp blinks 1 min, then turns on.	
Tire pressure sensor is in OFF state	Blink (Blinking pattern depends on the positions of non-operational tire pressure sensors.)	

WT-9

2016 370Z

U

Ν

Р

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM: CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000011999699

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	 Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
System	Sub system selection item	Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
_	AIR CONDITONER*			
Intelligent Key system Engine start system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door/Trunk lid open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

NOTE

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

^{*:} This item is displayed, but is not used.

Ν

0

Р

INFOID:0000000011735698

CONSULT screen item	Indication/Unit	Description			
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected			
Odo/Trip Meter	km	Total mileage (Odomete	Total mileage (Odometer value) of the moment a particular DTC is detected		
SLEEP>LOCK SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)			
		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)			
	LOCK>ACC		While turning power supply position from "LOCK"* to "ACC"		
	ACC>ON		While turning power supply position from "ACC" to "IGN"		
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Except emergency stop operation)		
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)		
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)		
	ACC>OFF		While turning power supply position from "ACC" to "OFF"		
	OFF>LOCK	Power supply position status of the moment a	While turning power supply position from "OFF" to "LOCK"*		
Vehicle Condition	OFF>ACC	particular DTC is de-	While turning power supply position from "OFF" to "ACC"		
	ON>CRANK	tected	While turning power supply position from "IGN" to "CRANKING"		
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode		
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode		
	LOCK		Power supply position is "LOCK"*		
	OFF		Power supply position is "OFF" (Ignition switch OFF)		
	ACC		Power supply position is "ACC" (Ignition switch ACC)		
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)		
ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)			
	CRANKING		Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number is 0 where The number increases whenever ignition switches.	at ignition switch is turned ON after DTC is detected in a malfunction is detected now. If the sum of the sum		

NOTE

- *: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (A/T models), and any of the following conditions are met.
- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR: CONSULT Function

FUNCTION

The diagnosis functions (main functions) include the following: "WORK SUPPORT", "SELF DIAGNOSTIC RESULT", "DATA MONITOR" and "ACTIVE TEST".

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[REGULAR GRADE]

Diagnostic test mode	Function
Work support	In this mode, it is possible to make quick and accurate adjustments by following the instructions on the CONSULT display.
Self diagnostic result	Receives self-diagnosis results from the BCM, and indicates DTCs and the number of mal- functions.
Data monitor	Receives input/output signals from the BCM and indicates and stores them to facilitate locating the causes of malfunctions.
Active test	Transmits command to the BCM to change output signals and check operation of output system.

WORK SUPPORT MODE

Refer to WT-22, "Description".

SELF-DIAG RESULTS MODE

Refer to BCS-99, "DTC Index".

DATA MONITOR MODE

Screen of data monitor mode is displayed.

NOTE:

- When malfunction is detected, CONSULT perform REAL-TIME DIAGNOSIS.
 Also, any malfunction detected while in this mode will be displayed at real time.
- The following table includes information(items)inapplicable to this vehicle. For information(items)applicable
 to this vehicle, refer to CONSULT display items.

Monitor item (Unit)	Remark
AIR PRESS FL (kPa), (kg/cm ²), (Psi)	
AIR PRESS FR (kPa), (kg/cm ²), (Psi)	Air pressure of tires
AIR PRESS RR (kPa), (kg/cm ²), (Psi)	All pressure of thes
AIR PRESS RL (kPa), (kg/cm ²), (Psi)	
ID REGST FL1	
ID REGST FR1	ID is registered: Done
ID REGST RR1	ID is not registered: Yet
ID REGST RL1	
WARNING LAMP	Low tire pressure warning lamp ON: On Low tire pressure warning lamp OFF: Off
BUZZER	Combination meter buzzer ON: On Combination meter buzzer OFF: Off

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction location may be different from that displayed on CONSULT.

ACTIVE TEST MODE

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction may be different from that displayed on CONSULT.

TEST ITEM LIST

Test item	Content
WARNING LAMP	This test is able to check to check that the low tire pressure warning lamp turns on.
ID REGIST WARNING	This test is able to check to check that the buzzer sounds or the low tire pressure warning lamp turns on.
FLASHER	This test is able to check to check that each turn signal lamp turns on.
HORN	This test is able to check to check that the horn sounds.

INFOID:0000000011735699

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

ECU	Reference
	BCS-58, "Reference Value"
BCM	BCS-97, "Fail-safe"
BCIVI	BCS-98, "DTC Inspection Priority Chart"
	BCS-99, "DTC Index"

WT

D

Α

В

С

F

G

Н

1

J

Κ

L

M

Ν


0

Р

WIRING DIAGRAM

TIRE PRESSURE MONITORING SYSTEM

Wiring Diagram



TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >

[REGULAR GRADE]

	81	۵	- Connector No. M2		Connector No.	or No. M6	
	82	9	- Connector Name		Connector Name	١,	
	83	^	- Colliector value				
TH80FW-CS16-TM4	84	Н	Connector Type NS10FW-CS		Connector Type	or Type TH80MW-CS16-TM4	
	85	+			Œ		
** 50 83	00 60	2 0			事		8 5
	88	: a	H.S. 48 38		H.S.		05 50
-	91	>		OB 8B GB GB			8 3
7	92	-		JV.		0 0	2 2
	93	9					
	94	>					
Some Name (Specification)	96	^	Terminal Color Of	Control Name Constitution	Terminal	Color Of Signal Name (Specification)	laoites
and Specifications	86	GR	No. Wire	Manue (Specimentori)	No.	Wire John	ration
	66	91	зв р	-	1	λ.	
	100	96	- 48 6		3		
			0 85		4		
			٨ 89		7		
	Connet	Connector No.	M1 88 R		∞		
			No. of the last of		6		
	Conne	Connector Name	FUSE BLOCK (J/B)		11	GR	
	Conne	Connector Type	NS06FW-M2		12		
	C		Connector No. M3		13		
	13	_	(a) 13 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3		14		
	ŧ		[:		15		
	Ż	7	Connector Type NS12FW-CS		16		
			8A 7A 6A 5A 4A		17	- BR	
					20	GR	
- [Coupe models]					21		
padster models]			CH CH]	31	- BR	
	Terminal	nal Color Of	(1)	70 70 00 110	32	^	
	No.	Wire	ognal Name (opecurcation)	,	36	88	
	14	>			37		
	2A	9			38	. 91	
,	3A	_	Terminal Color Of	Control Name Constitution	39	. se	
	4A	Ь	. No. Wire	Name [Specification]	40	· w	
	5A	7	1 100 1		41	- 91	
	6A	Н			42		
-	7.4	BR			43	. 9	
	8A	_	9 ec R		44	G - [With A/T]	
- [Except for roadster models with M/T]			8 2/2		44	R - [With M/T	
- [Roadster models with M/T]			0	- [Roadster models]	45	0	
			œ	- [Coupe models]	46	5	
					47		
					28	Q	
					59		
					02	~	
					2 8		
					8		
						-	

Α

В

С

D

WI

G

Н

ı

Κ

L


 \mathbb{N}

Ν

0

JREWC1793GB

Ρ



JREWC1794GB

Α

В

C

D

١.	٨	Ī	ī
W	Δ٧	,	ш

F

G

Н

ı

J

Κ

_

M

Ν

0

Р

JREWC1795GB

TIRE	PRESS	TIRE PRESSURE MONITORING SYSTEM							
Connector No.	r No.	M119	81	W	NATS ANT AMP.	134	GR	LOCK IND	
Connector Name	r Mama	BOM IBODY CONTROL MODILLE)	82	В	IGN RELAY (F/B) CONT	137	Ь	RECEIVER & SENSOR GND	
COILLECTIO	a lagran	BOWN (BOD) CONTROL MODOLE)	83	GR	KYLS ENT RECEIVER (FRONT) COMM	138	۸	RECEIVER & SENSOR POWER SUPPLY	
Connector Type	r Type	NS16FW-CS	87	BR	COMBI SW INPUT 5	139	7	TIRE PRESS RECEIV COMM	
	_		88	>	COMBI SW INPUT 3	140	IJ	P/N POSITION	
B			06	d	CAN-L	141	٨	SECURITY INDICATOR	
ŧ			91	_	CAN-H	142	0	COMBI SW OUTPUT 5	
2	_	4 5	95	97	KEY SLOT ILL	143	Ь	COMBI SW OUTPUT 1	
		11 13 14 15 17 18 19	93	>	ONIND	144	IJ	COMBI SW OUTPUT 2	
		0 1	95	0	ACC RELAY CONT	145	_	COMBI SW OUTPUT 3	
			96	>	A/T SHIFT SELECTOR POWER SUPPLY	146	SB	COMBI SW OUTPUT 4	
			66	~	SHIFT P/CLUTCH PEDAL POS SW	150	GR.	DRIVER DOOR SW	
Terminal	٥	Signal Name (Specification)	100	GR	PASSENGER DOOR REQUEST SW	151	9	REAR WINDOW DEFOGGER RELAY CONT	
No.	Wire		101	>	DRIVER DOOR REQUEST SW				
4	œ	INTERIOR ROOM LAMP POWER SUPPLY	102	0	BLOWER FAN MOTOR RELAY CONT				
2	ŋ	PASSENGER DOOR UNLOCK OUTPUT	103	91	KYLS ENT RECEIVER (FRONT) PWR SUPPLY				
00	>	ALL DOOR, FUEL LID LOCK OUTPUT	107	P1	COMBI SW INPUT 1				
6	9	DRIVER DOOR, FUEL LID UNLOCK OUTPUT	108	R	COMBI SW INPUT 4				
11	BR	BAT (FUSE)	109	*	COMBI SW INPUT 2				
13	8	GROUND	110	d	HAZARD SW				
14	~	PUSH-BUTTON IGNITION SW ILL GND							
15	>	ACCIND							
17	Α	TURN SIGNAL RH (FRONT, SIDE)	Connector No.	r No.	M123				
18	0	TURN SIGNAL LH (FRONT, SIDE)			The state of the s				
19	а	ROOM LAMP TIMER CONTROL	Connector Name	r Name	BCIM (BODY CONTROL MODULE)				
			Connector Type	r Type	TH40FG-NH				
			4	_					
Connector No.	r No.	M122	ほ						
Connector Name	r Name	BCM (BODY CONTROL MODULE)	H.S.						
Connector Type	r Type	TH40FB:NH			134123				
					कि कि । अस्ति हिस्सि हिन्दी महिन्दी कि कि । अस्ति हिन्दी कि				
E									
Ę									
15			Terminal	Color Of	Signal Name [Specification]				
		110 (10 10 10 10 10 10 10 10 10 10 10 10 10 1	113	0	OPTICAL SENSOR				
			114	~	CLUTCH INTERLOCK SW				
			115	0					
Terminal	Color Of		116	SB	STOP LAMP SW 1				
No.	Wire	Signal Name [Specification]	118	Ь	STOP LAMP SW 2				
7.2	٦	ROOM ANT 2-	119	SB	DR DOOR UNLOCK SENSOR				
73	۵	ROOM ANT 2+	121	В	KEY SLOT SW				
74	88	PASSENGER DOOR ANT-	123	Μ	IGN F/B				
75	BR	PASSENGER DOOR ANT+	124	FIG.	PASSENGER DOOR SW				
76	>	DRIVER DOOR ANT-	129	0	TRUNK LID OPENER CANCEL SW				
77	P1	DRIVER DOOR ANT+	130	_	REAR DEFOGGER SW				
78	1	ROOM ANT 1-	132	> ;	P/W SW & SOFT TOP C/U COMM [Roadster models]				
2	2	* INDENDED			* DOWNED WHEN HE WAS A LIBERT II OUR PROPERTY.				

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

It is also important to clarify customer concerns before starting the inspection. Reproduce the symptom, and understand it fully. Interview the customer about the concerns carefully. In some cases, it is necessary to check the symptoms by driving the vehicle with the customer.

CAUTION:

Customers are not professionals. Never assume "maybe the customer means..." or "maybe the customer mentioned this symptom.

>> GO TO 2.

2.BASIC INSPECTION

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to <u>WT-54, "Tire Air Pressure"</u>.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Inspect or repair the tires or wheels.

3.CHECK LOW TIRE PRESSURE WARNING LAMP

Check low tire pressure warning lamp display.

Does not low tire pressure warning lamp turn OFF?

YES >> GO TO 4.

NO >> INSPECTION END

CRUISE TEST

Start the engine and drive the vehicle.

>> GO TO 5.

5. PERFORM SELF-DIAGNOSIS

(P)With CONSULT

Perform "SELF-DIAG RESULTS".

Is any DTC detected?

YES >> Record or print DTC and freeze frame data (FFD). GO TO 7.

NO >> GO TO 6.

6.CHECK SYMPTOM

Perform trouble diagnosis for the applicable symptom. Refer to WT-39, "Symptom Table".

Is the cause of the malfunction detected?

YES >> GO TO 8. NO >> GO TO 10.

7. CIRCUIT DIAGNOSIS

Inspect the malfunctioning system indicated by the DTC code that is detected during self-diagnosis. Refer to BCS-99, "DTC Index".

>> GO TO 8.

DIAGNOSIS AND REPAIR WORK FLOW

DIAGNOSIS AND REPAIR WORK FLOW	
< BASIC INSPECTION > [REGU	JLAR GRADE]
8. REPAIR WORK	
Repair or replace the malfunctioning part.	
00.70.0	
>> GO TO 9. 9. PERFORM SELF-DIAGNOSIS	
Select "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".	
2. Touch "ERASE" on CONSULT screen to erase memory of the BCM.	
 Drive the vehicle. Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM". 	
Is any DTC detected?	
YES >> GO TO 7.	
NO >> GO TO 10. 10. FINAL CHECK	
Perform a cruise test.	
 Check that the low tire pressure warning lamp turn OFF. 	
Dose the tire pressure warning lamp turn OFF?	
YES >> INSPECTION END NO >> GO TO 2.	
77 00 10 2.	

ADDITIONAL SERVICE WHEN REPLACING BCM

< BASIC INSPECTION > [REGULAR GRADE]

ADDITIONAL SERVICE WHEN REPLACING BCM

Description INFOID:0000000011735702

When replacing BCM, tire pressure sensor ID registration is required. Refer to WT-20, "Work Procedure".

Work Procedure

1. PERFORM TIRE PRESSURE SENSOR ID REGISTRATION

Perform tire pressure sensor ID registration.

>> Refer to WT-22, "Description".

TIRE PRESSURE SENSOR WAKE UP OPERATION

< BASIC INSPECTION > [REGULAR GRADE]

TIRE PRESSURE SENSOR WAKE UP OPERATION

Description INFOID:0000000011735704

This procedure must be done after replacement of a tire pressure sensor, BCM, or rotation of wheels. Refer to WT-21, "Work Procedure".

Work Procedure

1. TIRE PRESSURE SENSOR WAKE-UP PROCEDURE

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

NOTE:

The position of an inactive tire pressure sensor can be identified by checking the blinking timing of the low tire pressure warning lamp.

Low tire pressure warning lamp blinking	timing	Activation tire position
ON a b	a : 0.3 sec. b : 1.0 sec.	Front LH
ON a a b	a : 0.3 sec. b : 1.0 sec.	Front RH
ON a a a a b	a : 0.3 sec. b : 1.0 sec.	Rear RH
ON a a a a a a b	a : 0.3 sec. b : 1.0 sec.	Rear LH
ON a b	a : 2 sec. b : 0.2 sec.	All tires

JPEIC0089GB

- Contact the tire pressure sensor activation tool (J-50190 or J-45295-A) (1) to the side of the tire at the location to the tire pressure sensor.
- 3. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

CAUTION:

Perform the wake-up procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.

- 4. Check that the turn signal lamps blink twice when the tire pressure sensor wake-up procedure for all wheels is completed.
- 5. Check that the low tire pressure warning lamp turns OFF, after the tire pressure sensor wake-up procedure is completed for all wheels and turns OFF.

Is the tire pressure sensor wake-up procedure completed?

YES >> Perform the tire pressure sensor ID registration procedure. Refer to WT-22, "Description".

NO >> Perform trouble diagnosis for the tire pressure sensor. Refer to WT-26, "Diagnosis Procedure".

WT

D

Α

В

G

Н

K

L

M

N

NNEIC0020ZZ

Р

ID REGISTRATION PROCEDURE

Description INFOID:000000011735706

This procedure must be done after replacing or rotating wheels, replacing tire pressure sensor or BCM. Refer to <u>WT-22</u>, "Work <u>Procedure"</u>.

Work Procedure

1. TIRE PRESSURE SENSOR ID REGISTRATION PROCEDURE

CAUTION:

To perform ID registration, observe the following points:

- Never register ID in a place where radio waves are interfered (e.g. radio tower).
- Never register ID in a place close to vehicles including TPMS.

With CONSULT.

1. Display the "WORK SUPPORT" screen and select "ID REGIST".

<u>Is the tire pressure sensor activation tool (J-50190 or J-45295-A) used for the tire pressure sensor ID registration procedure?</u>


YES >> GO TO 2.

NO >> GO TO 3.

2.TIRE PRESSURE SENSOR ID REGISTRATION PROCEDURE (WITH TIRE PRESSURE SENSOR ACTIVATION TOOL)

- Turn the ignition switch ON.
- 2. Select the start button on the "ID REGIST" screen.
- Contact the tire pressure sensor activation tool (J-50190 or J-45295-A) (1) to the side of the tire at the location to the tire pressure sensor.
- 4. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)
 CAUTION:

Perform the ID registration procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



5. When ID registration is completed, check the following pattern at each wheel.

Sequence	ID registration position	Turn signal lamp	CONSULT
1	Front left wheel		
2	Front right wheel	2 blinks	"Red" I
3	Rear right wheel	2 billing	↔ "Green"
4	Rear left wheel		

6. After the ID registration procedure for all wheels is completed, press "END" to end ID registration, and check that ID registration for all wheels is completed.

Is the check result normal?

YES >> ID registration END.

NO >> Refer to WT-44, "Diagnosis Procedure".

3.tire pressure sensor id registration procedure (without tire pressure sensor activation tool)

Adjust the tire pressure for all wheels to match the list below.

ID REGISTRATION PROCEDURE

< BASIC INSPECTION >

[REGULAR GRADE]

Tire position	Tire pressure kPa (kg/cm², psi)
Front LH	240 (2.4, 35)
Front RH	220 (2.2, 31)
Rear RH	200 (2.0, 29)
Rear LH	180 (1.8, 26)

2. Drive the vehicle at a speed at more than 40 km/h (25 MPH) for 3 minutes or more, then perform the tire pressure sensor ID registration procedure.

3. After ID registration for all wheels is completed, press "END" to end ID registration.

ID registration position	CONSULT
Front LH	
Front RH	"Red"
Rear RH "Green"	
Rear LH	

4. Adjust the tire pressures for all wheels to the specified value. Refer to <u>WT-54, "Tire Air Pressure"</u>. <u>Is ID registrations for all wheels completed?</u>

YES >> ID registration END.

NO >> Performs trouble-diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to <u>BCS-99</u>. "<u>DTC Index"</u>.

WT

D

Α

В

Н

<

L

M

Ν

0

Р

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

DTC/CIRCUIT DIAGNOSIS

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

Description

When the tire pressure monitoring system detects low inflation pressure, the low tire pressure warning lamps in the combination meter comes on.

DTC Logic

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1704	LOW PRESSURE FL	Front LH tire pressure drops to * kPa (* kg/cm², * psi) or less. [NOTE]	
C1705	LOW PRESSURE FR	Front RH tire pressure drops to * kPa (* kg/cm², * psi) or less. [NOTE]	Low tire pressureTire Pressure
C1706	LOW PRESSURE RR	Rear RH tire pressure drops to * kPa (* kg/cm², * psi) or less. [NOTE]	Sensor malfunc- tion
C1707	LOW PRESSURE RL	Rear LH tire pressure drops to * kPa (* kg/cm², * psi) or less. [NOTE]	

NOTE:

- 189.6 kPa (1.9 kg/cm², 27 psi): Standard air pressure is for 240 kPa (2.4 kg/cm²,35 psi) vehicles.
- 205.1 kPa (2.1 kg/cm², 30 psi): Standard air pressure is for 260 kPa (2.6 kg/cm², 38 psi) vehicles.

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

(P)With CONSULT

Turn the ignition switch ON.

CAUTION:

Never start the engine.

- Check the tire pressure for all wheels and adjust to the specified value. Refer to <u>WT-54, "Tire Air Pressure"</u>.
- 3. Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".

Is DTC "C1704", "C1705", "C1706", "C1707" detected?

YES >> Perform trouble diagnosis. Refer to <u>WT-24, "Diagnosis Procedure"</u>.

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011735710

1. CHECK TIRE PRESSURE

Check the internal pressure of all wheels. Refer to WT-54, "Tire Air Pressure".

Is the inspection result normal?

YES >> Replace the DTC-detected malfunctioning tire pressure sensor. Refer to <u>WT-51, "Exploded View"</u>.

NO >> After adjusting the air pressure, GO TO 2.

2.CHECK TIRE PRESSURE SIGNAL

(P)With CONSULT

- 1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- Perform "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM".
- 3. Select "BCM" in "DATA MONITOR", and check that the tire pressures match the standard value.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

Monitor item AIR PRESS FL AIR PRESS FR AIR PRESS RR AIR PRESS RR AIR PRESS RL CAUTION: Stop the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS to display the tire pressure for all wheels. s the inspection result normal? YES >> Inspect or repair the tires or wheels and adjust the tire pressure to the NO >> GO TO 1. Special Repair Requirement 1. CHECK TIRE PRESSURE Check all tires for tire pressures. Refer to WT-54. "Tire Air Pressure". Does all tire pressure data meet the specification? YES >> Inspect or repair the tires or wheels and adjust the tire pressure to the Special tire pressure to the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Special tire pressure to the Special tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Special tire pressure to the Special tire pressure to the Special tire pressure. Perform ID registration. Refer to WT-22, "Description". >> END	specification. INFOID:0000000117357
AIR PRESS FL AIR PRESS RR AIR PRESS RR AIR PRESS RL Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes. AUTION: top the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS of display the tire pressure for all wheels. the inspection result normal? YES >> Inspect or repair the tires or wheels and adjust the tire pressure to the NO >> GO TO 1. pecial Repair Requirement CHECK TIRE PRESSURE heck all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". oes all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the pressure to the specification? YES >> GO TO 2. NO Time Air Pressure of the pressure to the pressure or wheels and adjust the tire pressure to the pressure or repair the tires or wheels and adjust the tire pressure to the pressure or repair the tires or wheels and adjust the tire pressure to the pressure or repair the tires or wheels and adjust the tire pressure to the pressure or pressure to the pressure or repair the tires or wheels and adjust the tire pressure to the pressure or pressure to	URE MONITOR" of "BCM specification.
AIR PRESS FR AIR PRESS RR AIR PRESS RL AUTION: op the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS display the tire pressure for all wheels. the inspection result normal? (ES >> Inspect or repair the tires or wheels and adjust the tire pressure to the NO >> GO TO 1. Decial Repair Requirement CHECK TIRE PRESSURE meck all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". Des all tire pressure data meet the specification? (ES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification? (ES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification. PERFORM ID REGISTRATION Perform ID registration. Refer to WT-22, "Description".	URE MONITOR" of "BCM specification.
AIR PRESS RR AIR PRESS RL MOTION: top the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS display the tire pressure for all wheels. the inspection result normal? /ES >> Inspect or repair the tires or wheels and adjust the tire pressure to the >> GO TO 1. pecial Repair Requirement .CHECK TIRE PRESSURE heck all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". pes all tire pressure data meet the specification? /ES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification? /ES >> GO TO 2. NO PERFORM ID REGISTRATION Perform ID registration. Refer to WT-22, "Description".	URE MONITOR" of "BCM specification.
AUTION: top the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS of display the tire pressure for all wheels. The inspection result normal? YES >> Inspect or repair the tires or wheels and adjust the tire pressure to the NO >> GO TO 1. pecial Repair Requirement CHECK TIRE PRESSURE heck all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". oes all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the PREFORM ID REGISTRATION erform ID registration. Refer to WT-22, "Description".	specification. INFOID:0000000117357
AUTION: Itop the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESS of display the tire pressure for all wheels. Is the inspection result normal? YES >> Inspect or repair the tires or wheels and adjust the tire pressure to the NO >> GO TO 1. Special Repair Requirement CHECK TIRE PRESSURE Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". Does all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the PREFORM ID REGISTRATION Perform ID registration. Refer to WT-22, "Description".	specification. INFOID:0000000117357
Special Repair Requirement CHECK TIRE PRESSURE Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". Coes all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the PERFORM ID REGISTRATION Perform ID registration. Refer to WT-22, "Description".	INFOID:0000000117357
Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure". Does all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID registration. Refer to WT-22, "Description".	
Check all tires for tire pressures. Refer to WT-54 , "Tire Air Pressure". Does all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID REGISTRATION Perform ID registration. Refer to WT-22 , "Description".	specification.
Check all tires for tire pressures. Refer to WT-54 , "Tire Air Pressure". Does all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID REGISTRATION Perform ID registration. Refer to WT-22 , "Description".	specification.
Does all tire pressure data meet the specification? YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID registration. Refer to WT-22, "Description".	specification.
YES >> GO TO 2. NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID registration. Refer to WT-22, "Description".	specification.
NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the Perform ID registration. Refer to WT-22, "Description".	specification.
Perform ID registration. Refer to WT-22, "Description".	
Perform ID registration. Refer to WT-22, "Description".	
>> END	

Revision: 2015 June **WT-25** 2016 370Z

C1708, C1709, C1710, C1711 TIRE PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

C1708, C1709, C1710, C1711 TIRE PRESSURE SENSOR

DTC Logic

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1708	[NO DATA] FL	Tire pressure data signal from the front left wheel tire pressure sensor cannot be detected.	
C1709	[NO DATA] FR	Tire pressure data signal from the front right wheel tire pressure sensor cannot be detected.	Harness or connector (Tire pressure receiver, BCM) ID registration is not finished
C1710	[NO DATA] RR	Tire pressure data signal from the rear right wheel tire pressure sensor cannot be detected.	Tire pressure sensor malfunction BCM malfunction
C1711	[NO DATA] RL	Tire pressure data signal from the rear left wheel tire pressure sensor cannot be detected.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

(P)With CONSULT

- 1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- 2. Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".

Is DTC "C1708", "C1709", "C1710", "C1711" detected?

YES >> Perform trouble diagnosis. Refer to <u>WT-26, "Diagnosis Procedure"</u>.

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011735713

1. CHECK TIRE PRESSURE SIGNAL

(P)With CONSULT

- 1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- 2. Perform "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM".
- 3. Select "BCM" in "DATA MONITOR", and check that the tire pressures match the standard value.

Monitor item	Condition	Displayed value
AIR PRESS FL		Internal pressure of tires
AIR PRESS FR	Drive for 3 minutes at a speed of 40 km/h (25 MPH) or	
AIR PRESS RR	more, then drive normally for 10 minutes.	internal pressure of thes
AIR PRESS RL		

CAUTION:

Stop the vehicle and within 5 minutes, use "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM" to display the tire pressure for all wheels.

Is a tire pressure of 0 kPa (0 Psi) displayed for all wheels?

YES >> GO TO 2. NO >> GO TO 5.

2.CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

- Turn the ignition switch OFF.
- Disconnect BCM harness connector and tire pressure receiver harness connector.
- Check the continuity between BCM harness connector and tire pressure receiver harness connector.

C1708, C1709, C1710, C1711 TIRE PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

ВСМ		Tire pressure receiver		Continuit
Connector	Terminal	Connector	Terminal	Continuity
	137		1	
M123	138	M101	4	Existed
	139		2	
Check the contin	uity between BCM har	ness connector and g	ground.	
	BCM			Continuity
Connector	Termina	al	_	Continuity
	137			
M123	138		Ground	Not existed
	139			
s the inspection resu	lt normal?			
YES >> GO TO 3		4_		
·	replace damaged par		. O. III T	
	SSURE RECEIVER F	OWER SUPPLY CIR	CUII	
 Connect the BCN Turn the ignition : 	I harness connector.			
CAUTION:	SWILCH OIN.			
Never start the				
B. Check the voltage	e between the BCM ha	arness connector and	ground.	
	BCM			Voltage
Connector	Termina	al	_	(Approx.)
M123	138		Ground	5 V
s the inspection resu	lt normal?			
YES >> GO TO 4				
. ·	replace damaged par	ts.		
H.CHECK TIRE PRE	SSURE RECEIVER			
=	eceiver. Refer to WT-3	5. "Diagnosis Proced	ure".	
s the inspection resu				
YES >> GO TO 5 NO >> Replace	tire pressure receiver.	Refer to M/T-52 "Por	noval and Installation	\ "
D.CHECK ID REGIS	•	INGIGI IO <u>VV 1-00, INGI</u>	<u>novai anu mstaliatiur</u>	<u>.</u> .
		D-((MT-(00 IID I	
-	n of all tire pressure se		∠∠, "Description".	
	all tire pressure senso	ors de completed?		
YES >> GO TO 6 NO >> Replace	tire pressure sensor. R	efer to WT-51. "Explo	oded View".	
<u>'</u>	SSURE MONITORIN		•	
With CONSULT Drive at a speed	of 40 km/h (25 MPH) o	or more for several m	inutes without stoppir	ng.
2. Perform "DATA M	IONITOR" in "AIR PŔE	SSURE MONITOR"	of "BCM".	
Select "BCM" in "	DATA MONITOR", and			

C1708, C1709, C1710, C1711 TIRE PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

Monitor item	Condition	Displayed value
AIR PRESS FL		Internal pressure of tires
AIR PRESS FR	Drive at a speed of 40 km/h (25 MPH) or more, for several minutes without stopping.	
AIR PRESS RR		internal pressure of thes
AIR PRESS RL		

CAUTION:

Stop the vehicle and within 15 minutes, use "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM" to read the tire pressure for all wheels.

Is the inspection result normal?

YES >> Replace the DTC detected malfunctioning tire pressure sensor. Refer to <u>WT-51, "Exploded View"</u>. NO >> Replace BCM. Refer to <u>BCS-106, "Exploded View"</u>.

Special Repair Requirement

INFOID:0000000011735714

1. CHECK TIRE PRESSURE

Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2. PERFORM ID REGISTRATION

Perform ID registration. Refer to WT-22, "Description".

>> END

C1716, C1717, C1718, C1719 TIRE PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

Α

В

D

WT

C1716, C1717, C1718, C1719 TIRE PRESSURE SENSOR

DTC Logic (INFOID:0000000011735715

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible case
C1716	[PRESSDATA ERR] FL	Malfunction in the tire pressure data from the front left wheel tire pressure sensor.	
C1717	[PRESSDATA ERR] FR	Malfunction in the tire pressure data from the front right wheel tire pressure sensor.	ID registration is not fin- ished
C1718	[PRESSDATA ERR] RR	Malfunction in the tire pressure data from the rear right wheel tire pressure sensor.	tire pressure sensor mal- function
C1719	[PRESSDATA ERR] RL	Malfunction in the tire pressure data from the rear left wheel tire pressure sensor.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

- 2. Check the tire pressure for all wheels and adjust to the specified value. Refer to <u>WT-54, "Tire Air Pressure"</u>.
- 3. Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".

Is DTC "C1716", "C1717", "C1718", "C1719" detected?

YES >> Perform trouble diagnosis. Refer to WT-29, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1.CHECK TIRE PRESSURE

Check the internal pressure of all wheels. Refer to WT-54. "Tire Air Pressure".

Is the inspection result normal?

YES >> Replace the DTC-detected malfunctioning tire pressure sensor. Refer to WT-51, "Exploded View".

NO >> After adjusting the tire pressure, GO TO 2.

2.CHECK TIRE PRESSURE SIGNAL

(P)With CONSULT

- 1. Check and adjust the tire pressure for all wheels. Refer to WT-54, "Tire Air Pressure".
- 2. Perform tire pressure sensor ID registration for all wheels. Refer to WT-22, "Description".
- 3. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- Perform "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM".
- Select "BCM" in "DATA MONITOR", and check that the tire pressures match the standard value. CAUTION:

Stop the vehicle and within 15 minutes, use CONSULT "DATA MONITOR" to display the tire pressure for all wheels.

6. Check that "DATA MONITOR" displays tire pressure of 438.60 kPa (4.47 kg/cm², 63.60 Psi).

Is the inspection 438.60 kPa (4.47 kg/cm², 63.60 Psi)?

YES >> Replace tire pressure sensor the tire pressure 438.60 kPa (4.386 bar, 4.47 kg/cm², 63.60 Psi) displayed. Refer to <u>WT-51</u>, "Exploded View".

NO >> GO TO 1.

M

N

Р

INFOID:0000000011735716

WT-29

C1716, C1717, C1718, C1719 TIRE PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

Special Repair Requirement

INFOID:0000000011735717

1. CHECK TIRE PRESSURE

Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to WT-22, "Description".

>> END

- DTC/CIE	RCUIT DIAGNOSIS >	1729 VEHICLE SPEED SIGNAL	[REGULAR GRADE]
	VEHICLE SPEE	D SIGNAL	[REGOLAR GRADE]
		D SIGIVILE	
Descripti	ION		INFOID:0000000011735718
	cts no vehicle speed sig	ınal.	
DTC Log	gic		INFOID:0000000011735719
DTC DET	ECTION LOGIC		
DTC number	Trouble diagnosis name	DTC detecting condition	Possible case
C1729	VHCL SPEED SIG ERR	Vehicle speed signal not detected.	CAN communication error Combination meter malfunction
4	IFIRMATION PROCE EPRODUCTION PROC		
YES >: NO >:	1729" detected? > Perform trouble diagn > INSPECTION END is Procedure	osis. Refer to <u>WT-31, "Diagnosis Procedure"</u> .	INFOID:0000000011735720
4		ETER SELF-DIAGNOSIS	
(P)With CO		TENGLE Bindingsis	
	ELF-DIAG RESULTS" C detected?	of "METER/M&A".	
_	> Check the DTC. Refe > GO TO 2.	r to BCS-99, "DTC Index".	
	RM SELF-DIAGNOSIS		
With CO		in "AIR PRESSURE MONITOR" of "BCM".	
	1729" detected?	III AIR I REGOORE MONITOR OF BOM.	
	> Replace BCM. Refer ITEM)". > GO TO 3.	to BCS-20, "COMMON ITEM: CONSULT	Function (BCM - COMMON
_	INFORMATION		
──With CO	NSULT		
	"BCM" in "DATA MON	"AIR PRESSURE MONITOR" of "BCM". NITOR", and check the input/output values.	Refer to BCS-58, "Reference
Is the inspe	ection result normal?		

YES >> Check pin terminal and connection of each harness connector for malfunctioning conditions. >> Replace BCM. Refer to BCS-106, "Exploded View".

NO

Special Repair Requirement

INFOID:0000000011735721

Р

1. CHECK TIRE PRESSURE

Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

C1729 VEHICLE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to WT-22, "Description".

>> END

C1734 BCM

DTC Logic INFOID:0000000011735722

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible case
C1734	CONTROL UNIT	Tire pressure monitoring system malfunction in BCM	BCM malfunction

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

(P)With CONSULT

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.

Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".

Perform within 15 minutes after stop the vehicle.

Is DTC "C1734" detected?

>> Perform trouble diagnosis. Refer to WT-33, "Diagnosis Procedure".

NO >> INSPECTION END

Diagnosis Procedure

1. CHECK BCM POWER SUPPLY

- Turn the ignition switch OFF.
- Disconnect BCM harness connector. 2.
- Check voltage between BCM harness connector terminals and ground.

В	CM		Voltage	
Connector	Terminal	_	vollage	
M118	1	Ground	Pattony voltago	
M119	11	Ground	Battery voltage	

Is the power supply normal?

YES >> GO TO 2.

NO

>> Check the following. If any items are damaged, repair or replace damage parts.

- 40A fusible link [No. K located in the fuse block]. Refer to PG-99, "Fuse and Fusible Link Arrangement".
- 10A fuse [No. 10 located in the fuse block (J/B)]. Refer to PG-100, "Fuse, Connector and Terminal Arrangement".
- Harness for short or open between battery and BCM harness connector M118 terminal 1.
- Harness for short or open between battery and BCM harness connector M119 terminal 11.
- Check the Battery voltage.

2.CHECK BCM GROUND

Check the continuity between BCM harness connector and ground.

В	CM	_	Continuity	
Connector	Terminal	_		
M119	13	Ground	Existed	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

- Disconnect tire pressure receiver harness connector.
- Check the continuity between BCM harness connector and tire pressure receiver harness connector.

D

Α

INFOID:0000000011735723

K

M

Ν

Р

WT-33 Revision: 2015 June 2016 370Z

В	ВСМ		Tire pressure receiver	
Connector	Terminal	Connector	Terminal	Continuity
	137		1	
M123	138	M101	4	Existed
	139		2	

3. Check the continuity between BCM harness connector and ground.

В	CM		Continuity	
Connector	Terminal	_	Continuity	
	137			
M123	138	Ground	Not existed	
	139			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK BCM

Check the BCM input/output signal. Refer to BCS-58, "Reference Value".

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK BCM HARNESS CONNECTOR

Check the BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to BCS-106, "Exploded View".

NO >> Check for looseness or damage at the harness connector pins of the BCM. Repair or replace if necessary.

Special Repair Requirement

INFOID:0000000011735724

1. CHECK TIRE PRESSURE

Check all tires for tire pressures. Refer to WT-54, "Tire Air Pressure".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to WT-22, "Description".

>> END

TIRE PRESSURE RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

TIRE PRESSURE RECEIVER

Component Function Check

INFOID:0000000011735725

1. TIRE PRESSURE MONITORING SYSTEM OPERATION

10.0000000011733723

(P)With CONSULT

- 1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- 2. On "DATA MONITOR", select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL", and check that the tire pressures match the standard value.

Monitor item	Condition	Displayed value
AIR PRESS FL		
AIR PRESS FR	Drive for 3 minutes at a speed of 40 km/h (25 MPH) or	Internal pressure of tires
AIR PRESS RR	more, then drive normally for 10 minutes.	internal pressure of thes
AIR PRESS RL		

WT

D

Α

В

CAUTION:

Stop the vehicle and within 5 minutes, use CONSULT "DATA MONITOR" to display the tire pressure for all wheels.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform trouble diagnosis. Refer to <u>WT-35</u>, "<u>Diagnosis Procedure</u>".

Diagnosis Procedure

INFOID:0000000011735726

1. CHECK TIRE PRESSURE RECEIVER SIGNAL

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check tire pressure receiver connector and ground signal with oscilloscope.

Tire pressure receiver			Condition	Voltage (Approx.)
Connector	Terminal	_	Condition	Voltage (Approx.)
M101	M101 2 Ground	Stand by state	(V) 6 4 2 0 • • 0.2s OCC3881D	
WITOT		When receiving the signal from the tire pressure sensor	(V) 6 4 2 0 	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK TIRE PRESSURE RECEIVER INPUT VOLTAGE

- 1. Disconnect tire pressure receiver connector.
- Check voltage between tire pressure receiver connector and ground.

Revision: 2015 June WT-35 2016 370Z

Ν

TIRE PRESSURE RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

Tire pressure receiver			Voltago (Approx.)
Connector	Terminal	_	Voltage (Approx.)
M101	4	Ground	5.0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.check tire pressure receiver ground circuit

- 1. Disconnect BCM harness connector.
- 2. Check continuity between BCM harness connector and tire pressure receiver connector.

BCM		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	Continuity
M123	137	M101	1	Existed

3. Check continuity between BCM harness connector and ground.

BCM			Continuity
Connector	Terminal	_	Continuity
M123	137	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK BCM CIRCUIT

Inspect the BCM circuit. Refer to BCS-53, "Diagnosis Procedure".

Is the BCM circuit normal?

YES >> Replace tire pressure receiver. Refer to WT-53, "Removal and Installation".

NO >> Replace BCM. Refer to BCS-106, "Exploded View".

LOW TIRE PRESSURE WARNING LAMP < DTC/CIRCUIT DIAGNOSIS > [REGULAR GRADE]	
LOW TIRE PRESSURE WARNING LAMP	А
Component Function Check	\wedge
1. CHECK THE ILLUMINATION OF THE LOW TIRE PRESSURE WARNING LAMP	В
Check that the low tire pressure warning lamp is turned OFF after illuminating for approximately 1 second, when the ignition switch is turned ON.	
Is the inspection result normal?	С
YES >> INSPECTION END NO >> Perform trouble diagnosis. Refer to <u>WT-37, "Diagnosis Procedure"</u> .	
Diagnosis Procedure	D
1. POWER SUPPLY AND GROUND CIRCUIT	WT
Check power supply and ground circuit. Refer to WT-38, "Diagnosis Procedure".	
Is the inspection result normal? YES >> GO TO 2.	F
NO >> Repair or replace damaged parts. 2.PERFORM SELF-DIAGNOSIS	
(P)With CONSULT	G
Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".	
Is any DTC detected? YES >> Check the DTC. Refer to BCS-99, "DTC Index".	Н
NO $>>$ GO TO 3. 3.CHECK LOW TIRE PRESSURE WARNING LAMP SIGNAL	
®With CONSULT	I
Turn the ignition switch ON. CAUTION:	J
Never start the engine. 2. Perform "DATA MONITOR" in "AIR PRESSURE MONITOR" of "BCM".	
 Select "BCM" in "DATA MONITOR", and check that the low tire pressure warning lamp is turned OFF after illuminating for approximately 1 second, when the ignition switch is turned ON. 	K
Is the inspection result normal?	
YES >> Check the combination meter. Refer to MWI-45, "COMBINATION METER: Diagnosis Procedure".	ı

- >> Check the combination meter. Refer to MWI-45, "COMBINATION METER: Diagnosis Procedure >> Replace the BCM. Refer to BCS-106, "Exploded View".
- YES NO

WT-37 Revision: 2015 June 2016 370Z

 \mathbb{N}

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[REGULAR GRADE]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011735729

1. POWER SUPPLY SYSTEM CHECK

- 1. Turn the ignition switch OFF.
- 2. Disconnect the BCM harness connector.
- 3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between the BCM harness connector and the ground.

В	CM		Voltage
Connector	Terminal	_	voltage
M118	1	Ground	Battery voltage
M119	11	Ground	Dattery Voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace damaged parts.

2.GROUND SYSTEM INSPECTION

- 1. Turn the ignition switch OFF.
- Check the continuity between the BCM harness connector and the ground.

В	CM	_	Continuity
Connector	Terminal		Continuity
M119	13	Ground	Existed

Is the inspection result normal?

YES >> • Check the 10A fuse [No. 10 in fuse block (J/B)].

• Check the 40A fusible link [No. K in fuse block].

NO >> Repair or replace damaged parts.

[REGULAR GRADE]

SYMPTOM DIAGNOSIS

TPMS

Symptom Table

INFOID:0000000011735730

Α

В

LOW TIRE PRESSURE WARNING LAMP SYMPTOM CHART

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
	The low tire pressure warning lamp illuminates for 1 second, then turns OFF.	ON 1 sec > stays OFF SEIA0592E	Wake-up operation for all tire pressure sensors at wheels is completed.	No system malfunctions
	The low tire pressure warning lamp repeats blinking ON for 2 seconds and OFF for 0.2 seconds.	Blinks: ON 2 sec > OFF 0.2 sec SEIA0593E	Wake-up operation for all tire pressure sensors at wheels is not completed.	Perform the wake-up operation for all tire pressure sensors at wheels. Refer to WT-21, "Description".
Low tire pressure warning lamp	The low tire pressure warning lamp blinks once.	Blinks 1 time ON 0.3 sec > OFF 1.0 sec JPEIC0090GB	The front left tire pressure sensor is not activated.	Perform the wake-up operation for the tire pressure sensor at front left wheel. Refer to WT-21, "Description".
	The low tire pressure warning lamp repeats blinking twice.	Blinks 2 times ON 0.3 sec > OFF 0.3 sec SEIAO595E	The front right tire pressure sensor is not activated.	Perform the wake-up operation for the tire pressure sensor at front right wheel. Refer to WT-21, "Description".
	The low tire pressure warning lamp repeats blinking for 3 times.	Blinks 3 times ON 0.3 sec > OFF 0.3 sec SEIA0596E	The rear right tire pressure sensor is not activated.	Perform the wake-up operation for the tire pressure sensor at rear right wheel. Refer to WT-21, "Description".
	The low tire pressure warning lamp repeats blinking for 4 times.	Blinks 4 times ON 0.3 sec > OFF 0.3 sec SEIADGS97E	The rear left tire pressure sensor is not activated.	Perform the wake-up operation for the tire pressure sensor at rear left wheel. Refer to WT-21. "Description".

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
	The low tire pressure warning lamp turns ON and stays illuminated.	Comes ON and stays ON	Low tire pressure	Check the tire pressure for all wheels and adjust to the specified value. Refer to WT-54, "Tire Air Pressure".
			The combination meter fuse is open or removed (or pulled out).	Check and install the combination meter fuse. If necessary, replace the fuse.
Low tire pres- sure warning lamp	The low tire pressure warning lamp repeats blinking at 0.5-second intervals for 1 minute, and then stays illuminated.		The BCM harness connector is removed.	Check the connection conditions of the BCM harness connector, and repair if necessary.
		Blinks 1 min ON 0.5 sec > OFF 0.5 sec and stays ON SEIA0788E	Tire Pressure Monitoring System (TPMS) mal- function.	Perform CONSULT self-diagnosis. Refer to BCS-20, "COMMON ITEM: CONSULT Function (BCM - COMMON ITEM)". If necessary, perform tire pressure sensor ID registration. Refer to WT-22, "Description".
Turn signal lamp	The turn signal lamps do not blink twice when the tire pressure sensor is activated. Or the buzzer does not sound.		 The tire pressure sensor activation tool (J-50190 or J-45295-A) does not activate. The ignition switch is OFF when the tire pressure sensor wake-up operation is performed. The tire pressure sensor activation tool (J-50190 or J-45295-A) is not used in the correct position. The tire pressure sensor is already waked up. 	 Replace the battery in the tire pressure sensor activation tool (J-50190 or J-45295-A). Turn the ignition switch ON when performing the tire pressure sensor wake-up operation. Operate the tire pressure sensor activation tool (J-50190 or J-45295-A) in the correct position when performing the wake-up operation. No procedure.

NOTE:

If tire pressure sensor wake-up operation is not completed for two or more tire pressure sensors, the applicable low tire pressure warning lamp blinking patterns are displayed continuously.

(Example: Blinks once/OFF/blinks 3 times = Wake-up operation is not completed at the front left wheel and rear right wheel tire pressure sensors.)

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[REGULAR GRADE]

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

Description INFOID:000000011735731

DESCRIPTION

The low tire pressure warning lamp illuminates for approximately 1 second and then turns OFF when the ignition switch is turned ON. This is to check that no abnormal condition is present in the tire pressure monitoring system.

The lamp bulb may be burnt out or the tire pressure monitoring system may be malfunctioning if the low tire pressure warning lamp does not illuminate when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:0000000011735732

1. CHECK LOW TIRE PRESSURE WARNING LAMP

Perform trouble diagnosis of the low tire pressure warning lamp. Refer to <u>WT-37, "Diagnosis Procedure"</u>. <u>Is the inspection result normal?</u>

YES >> Check pin terminal and connection of each connector for damage and loose connection.

NO >> Repair or replace damaged parts.

WT

D

Α

В

F

G

Н

ı

K

L

M

Ν

0

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[REGULAR GRADE]

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

Description INFOID:000000011735733

The low tire pressure warning lamp does not turn OFF after several seconds is passed after engine starts.

Diagnosis Procedure

INFOID:0000000011735734

1. CHECK TIRE PRESSURE

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to WT-54, "Tire Air Pressure".

Is the inspection result normal?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels.

2. CHECK LOW TIRE PRESSURE WARNING LAMP

Check low tire pressure warning lamp display.

Does not low tire pressure warning lamp turn OFF?

YES >> GO TO 3.

NO >> INSPECTION END

3.CHECK BCM

(P)With CONSULT

Perform "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR" of "BCM".

Is any DTC detected?

YES >> Check the DTC. Refer to BCS-99, "DTC Index".

NO >> GO TO 4.

f 4.CHECK BCM POWER SUPPLY AND GROUND

- 1. Turn the ignition switch OFF.
- 2. Disconnect the BCM harness connector.
- 3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between the BCM harness connector and the ground.

В	CM	_	Voltage		
Connector	Terminal	_	vollage		
M118	1	Ground	Rattory voltago		
M119	11	Giouna	Battery voltage		

Is the inspection result normal?

YES >> Replace BCM. Refer to <u>BCS-106</u>. "Exploded View".

NO >> Repair or replace damaged parts.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

[REGULAR GRADE]

LOW TIRE PRESSURE WARNING LAMP BLINKS

Description INFOID:0000000011735735

The low tire pressure warning lamp blinks when the ignition switch is turned ON.

NOTE:

The position of an inactive tire pressure sensor can be identified by checking the blinking timing of the low tire pressure warning lamp.

Low tire pressure warning lamp blinkin	g timing	Activation tire position
ON a b	a : 0.3 sec. b : 1.0 sec.	Front LH
ON a a b	a : 0.3 sec. b : 1.0 sec.	Front RH
ON a a a a b	a : 0.3 sec. b : 1.0 sec.	Rear RH
ON a a a a a b	a : 0.3 sec. b : 1.0 sec.	Rear LH
ON a b	a : 2 sec. b : 0.2 sec.	All tires

JPEIC0089GB

Diagnosis Procedure

1. TIRE PRESSURE SENSOR WAKE-UP OPERATION

Perform the tire pressure sensor wake-up. Refer to WT-21, "Description".

Is the tire pressure sensor wake-up completed?

YES >> GO TO 2.

NO >> Perform trouble diagnosis for the tire pressure sensor. Refer to WT-26, "Diagnosis Procedure".

2. TIRE PRESSURE SENSOR ID REGISTRATION

Perform tire pressure sensor ID registration. Refer to WT-22, "Description".

Is tire pressure sensor ID registration completed?

YES >> INSPECTION END

NO >> Perform the self-diagnosis for "AIR PRESSURE MONITOR". Refer to <u>BCS-99</u>. "<u>DTC Index</u>".

Revision: 2015 June **WT-43** 2016 370Z

WT

D

Α

В

C

INFOID:0000000011735736

Κ

1 \

M

Ν

0

Ρ

ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

[REGULAR GRADE]

ID REGISTRATION CANNOT BE COMPLETED

Description INFOID:0000000011735737

The ID of the tire pressure sensor installed in each wheel cannot be registered in the tire pressure monitoring system. Inspect the tire pressure sensor or the tire pressure monitoring system circuit.

Diagnosis Procedure

INFOID:0000000011735738

1. TIRE PRESSURE SENSOR WAKE-UP

Perform the tire pressure sensor wake-up. Refer to WT-21, "Description".

Is the tire pressure sensor wake-up completed?

YES >> GO TO 3. NO >> GO TO 2.

2.CHECK TIRE PRESSURE SENSOR ACTIVATION TOOL

Check tire pressure sensor activation tool.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the battery of tire pressure sensor activation tool or repair/replace the tire pressure sensor activation tool.

3.tire pressure sensor id registration

Perform tire pressure sensor ID registration. Refer to WT-22, "Description".

CAUTION:

To perform ID registration, observe the following points:

- Never register ID in a place where radio waves are interfered (e.g. radio tower).
- Never register ID in a place close to vehicles including TPMS.

Is tire pressure sensor ID registration completed?

YES >> INSPECTION END

NO >> GO TO 4.

4. CHECK TIRE PRESSURE SIGNAL

Change the work location and perform ID registration again.

NOTE:

Depending on the tire pressure sensor position*, a blind spot exists, and the tire pressure receiver gets a poor reception. If an ID registration is performed under this condition, the registration may not be completed. In such case, follow the instructions below to improve the radio wave receiving environment.

- Rotate tire by 90°, 180°, or 270°. (This Step is to change tire pressure sensor position.)
- Open the door close to the tire of which ID registration is ongoing.
- *: Radio wave reception condition depends on vehicle architecture (e.g. body harness layout, tire wheel design) or environment.

When ID registration is performed, which wheels do not react?

All wheels react and ID registration is possible.>>INSPECTION END

Only certain wheel(s) do not react.>>Replace applicable tire pressure sensor. Refer to WT-51, "Removal and Installation".

All wheels do not react.>>Check the tire pressure receiver. Refer to WT-35, "Component Function Check".

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REGULAR GRADE]

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000011735739

Α

В

C

D

WT

G

Н

J

Κ

L

M

se chart below to find the cause of the symptom. If necessary, repair or replace these parts.																			
Reference	page		ESU-11, FSU-14	WT-49, "Inspection"	WT-46, "Adjustment"	WT-54, "Tire Air Pressure"	WT-46, "Adjustment"	I	ı	WT-54, "Tire Air Pressure"	NVH in DLN section.	NVH in DLN section.	NVH in FAX and FSU sections.	NVH in RAX and RSU sections.	Refer to TIRES in this chart.	Refer to ROAD WHEEL in this chart.	NVH in RAX section.	NVH in BR section.	NVH in ST section.
Possible ca	ause and Sl	USPECTED PARTS	Improper installation, looseness	Out-of-round	unbalance	Incorrect tire pressure	Uneven tire wear	Deformation or damage	Non-uniformity	Incorrect tire size	PROPELLER SHAFT	DIFFERENTIAL	FRONT AXLE AND FRONT SUSPENSION	REAR AXLE AND REAR SUSPENSION	TIRES	ROAD WHEELS	DRIVE SHAFT	ВКАКЕ	STEERING
		Noise	×	×	×	×	×	×	×		×	×	×	×		×	×	×	×
		Shake	×	×	×	×	×	×		×	×		×	×		×	×	×	×
		Vibration				×				×	×		×	×			×		×
	TIRES	Shimmy	×	×	×	×	×	×	×	×			×	×		×		×	×
		Judder	×	×	×	×	×	×		×			×	×		×		×	×
Symptom	Poor quality ride or handling	×	×	×	×	×	×		×			×		×	×				
	Noise	×	×	×			×			×	×	×	×	×		×	×	×	
	ROAD	Shake	×	×	×			×			×		×	×	×		×	×	×
	WHEEL	Shimmy, Judder	×	×	×			×					×	×	×			×	×
		Poor quality ride or handling	×	×	×			×					×	×	×				

×: Applicable

Revision: 2015 June WT-45 2016 370Z

Ν

0

PERIODIC MAINTENANCE

ROAD WHEEL

Adjustment INFOID:0000000011735740

BALANCING WHEELS (BONDING WEIGHT TYPE)

Preparation Before Adjustment

Using releasing agent, remove double-faced adhesive tape from the road wheel.

CAUTION:

- Never scratch the road wheel during removal.
- After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.

Wheel Balance Adjustment

- The details of the adjustment procedure are different for each model of wheel balancer. Therefore, refer to each instruction manual.
- If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for road wheels.
- 1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
- 2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by 5/3 to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install to the designated outer position of, or at the designated angle in relation to the road wheel.

CAUTION

- Do not install the inner balance weight before installing the outer balance weight.
- Before installing the balance weight, be sure to clean the mating surface of the road wheel.
- a. Indicated unbalance value × 5/3 = balance weight to be installed
 Calculation example:


23 g (0.81 oz) \times 5/3 = 38.33 g (1.35 oz) \Rightarrow 37.5 g (1.32 oz) balance weight (closer to calculated balance weight value)

NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

 $36.2 \Rightarrow 35 \text{ g } (1.23 \text{ oz})$ $36.3 \Rightarrow 37.5 \text{ g } (1.32 \text{ oz})$




b. Installed balance weight in the position.

[REGULAR GRADE]

 When installing balance weight (1) to road wheels, set it into the grooved area (A) on the inner wall of the road wheel as shown in the figure so that the balance weight center (B) is aligned with the tire balance machine indication position (angle) (C).

CAUTION:

- Always use genuine NISSAN adhesion balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install three or more sheets of balance weight.



c. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.

CAUTION:

Do not install one balance weight sheet on top of another.

- Start the tire balance machine again.
- 4. Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).

CAUTION:

Do not install three or more balance weight.

Start the tire balance machine. Check that inner and outer residual unbalance values is within the allowable unbalance value.

Adhesion weight Wheel balancer indication position (angle) PEIA0033E

CAUTION:

If either residual unbalance value exceeds limit, repeat installation procedures.

Allowable unbalance value

Dynamic (At flange) : Refer to WT-54, "Road Wheel". Static (At flange) : Refer to WT-54, "Road Wheel".

TIRE ROTATION

 Tire cannot be rotated in vehicle, as front tire are different size from rear tire and the direction of wheel rotation is fixed in each tire.

Wheel nuts tighting torque: Refer to WT-54, "Road Wheel".

CAUTION:

- Never include the T-type spare tire when rotating the tires.
- Use NISSAN genuine wheel nuts for aluminum wheels.

Safety Device Preventing from Being Incorrectly installed

FRONT BRAKE DISC ROTOR AND FRONT WHEEL

Α


В

D

WT


Ν

• Front and rear wheel size for this model differs, therefore special pin (1) is adopted to the front brake disc rotor (2). And a hole (3) that matches to this pin is adopted to the front wheel (4) (the rear wheel does not have this wheel). This structure prevents the rear wheel from being mistakenly installed on the front.



T-TYPE SPARE TIRE WHEEL

Regarding spare tire (for emergency) wheel, wrong assembly protection pin hole (1) has been set in addition to regular bolt holes (2) in order to enable installation to front wheel.



[REGULAR GRADE]

INFOID:0000000011735741

INFOID:0000000011735742

Α

В

D

K


Ν

Р

REMOVAL AND INSTALLATION

ROAD WHEEL TIRE ASSEMBLY

Exploded View



1. Tire assembly

Refer to GI-4. "Components" for symbols in the figure.

Removal and Installation

REMOVAL

- 1. Remove wheel nuts.
- Remove tire assembly.

INSTALLATION

Install in the reverse order of removal.

Inspection INFOID:0000000011735743


ALUMINUM WHEEL

- 1. Check tires for wear and improper inflation.
- Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
- a. Remove tire from aluminum wheel and mount on a tire balance machine.
- Set dial indicator as shown in the figure.
- c. Check runout, If the axial runout (A) or radial runout (B) exceeds the limit, replace aluminum wheel.

Limit

Axial runout (A) : Refer to <u>WT-54, "Road Wheel"</u>.

Radial runout (B) : Refer to <u>WT-54, "Road Wheel"</u>.



STEEL WHEEL

1. Check tires for wear and improper inflation.

ROAD WHEEL TIRE ASSEMBLY

< REMOVAL AND INSTALLATION >

[REGULAR GRADE]

- 2. Check wheels for deformation, clacks and other damage. If deformed, remove wheel and check wheel runout.
- Remove tire from steel wheel and mount wheel on a tire balance machine.
- Set two dial indicators as shown in the illustration.
- Set each dial indicator to "0".
- d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
- e. Calculate runout at each point as shown below.

Axial runout (A) : (1+2)/2 Radial runout (B) : (3+4)/2

f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout.


CAUTION:

In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout.

Limit

(A) : Refer to WT-54, "Road Wheel".(B) : Refer to WT-54, "Road Wheel".

g. If the total runout value exceeds limit, replace steel wheel.



How to Handle Puncture Repair Agent (With Puncture Repair Kit)

INFOID:000000001173574

CAUTION:

- · Never spill the sealant in the tire during repair.
- If the sealant spills, wipe it out with a waste cloth.
- Never reuse the repair kit hose used for a temporary repair of a flat tire because some of the puncture repair agent remains in the hose.
- After using a puncture repair agent, replace valve core with a new one.
- Complete tire blowout repair or tire replacement within two days from the tire removal work start to prevent the hardening of the repair agent which attached to tire pressure sensor
- 1. Remove tires form the vehicle.
- 2. Remove tire from road wheel, using a tire changer.

CAUTION:

- When deflating a tire, cover the valve with a waste cloth to prevent the sealant from splattering.
- Never spill the sealant in the tire during repair.
- 3. Dispose of sealant in the removed tire.

CAUTION:

- Wipe out sealant spilled on the road wheel, tire, tire changer, and floor with a waste cloth.
- Drained sealant or expired sealant returned by the customer must be disposed according to the law and local regulations.
- Fix a tire blowout, if repairable.

NOTE:

Sealant blocks holes caused by blowouts. These holes may not be found and repaired, depending on the level of blowout. Therefore, it is necessary to check tire air pressure frequently and replace tire with a new one, if the air pressure is decreasing.

• Replace tire with a new one, if not repairable.

CAUTION:

Never dispose of tires with the sealant contained.

INFOID:0000000011735745

TIRE PRESSURE SENSOR

Exploded View

1. Tire pressure sensor

2. Grommet seal

Valve nut

Valve core

5. Valve cap

: Parts that are replaced as a set when the tire is replaced.

Refer to GI-4, "Components" for symbols not described above.

Removal and Installation

INFOID:0000000011735746

REMOVAL

Remove tire assembly. Refer to <u>WT-49, "Removal and Installation"</u>.

2. Remove valve cap, valve core and then deflate tire.

NOTE:


If the tire is reused, apply a matching mark to the position of the tire road wheel valve hole for the purpose of wheel balance adjustment after installation.

3. Remove valve nut retaining tire pressure sensor and allow tire pressure sensor to fall into tire.

4. Use the tire changer and disengage the tire beads.

CAUTION:

- Verify that the tire pressure sensor (1) is at the bottom of the tire while performing the above.
- Be sure not to damage the road wheel or tire pressure sensor.
- 5. Apply bead cream or an equivalent to the tire beads.
- Set tire onto the tire changer turntable so that the tire pressure sensor inside the tire is located close to the road wheel valve hole.



В

Α

C

D

WT

G

Н

K

L

M

Ν

0

Ρ

TIRE PRESSURE SENSOR

< REMOVAL AND INSTALLATION >


[REGULAR GRADE]

Turn tire so that valve hole is at bottom and bounce so that tire
pressure sensor (1) is near valve hole. Carefully lift tire onto
turntable and position valve hole (and tire pressure sensor) 270
degree from mounting/dismounting head (2).

CAUTION:

Be sure not to damage the road wheel and tire pressure sensor.

- 8. Remove tire pressure sensor from tire.
- 9. Remove the grommet seal.




INSTALLATION

- 1. Apply bead cream or an equivalent to the tire beads.
- 2. Install the tire inside beads (1) onto the road wheel (2) in the position shown in the figure.
- 3. Install grommet seal to the tire pressure sensor.

CAUTION:


- Never reuse grommet seal.
- Insert grommet seal all the way to the base.



4. Hold tire pressure sensor as shown in the figure, and press the sensor in the direction shown by arrow (←) to bring it into absolute contact with valve hole. After this, tighten valve nut to the specified torque.

CAUTION:

- Never reuse valve core and valve cap.
- Check that grommet seal is free of foreign matter.
- Check that grommet seal contacts horizontally with road wheel.
- Manually tighten valve nut all the way to the wheel. (Never use a power tool to avoid impact.)



5. Set the tire onto the turntable so that the tire changer arm (2) is at a position approximately 270° from the tire pressure sensor (1).

CAUTION:

Be sure that the arm does not contact the tire pressure sensor.

6. Install the tire outer side beads onto the road wheel.

CAUTION:

When installing, check that the tire does not turn together with the road wheel.

7. Check the tire pressure for all wheels and adjust to the specified value. Refer to <u>WT-54</u>, "<u>Tire Air Pressure</u>".

3 270° JPEIC0014GB

NOTE:

Before adding air, align the tire with the position of the matching mark applied at the time of removal.

- 8. Install tire to the vehicle. Refer to WT-49, "Removal and Installation".
- 9. Perform tire pressure sensor ID registration. Refer to WT-22, "Work Procedure".

TIRE PRESSURE RECEIVER

< REMOVAL AND INSTALLATION >

[REGULAR GRADE]

TIRE PRESSURE RECEIVER

Removal and Installation

INFOID:0000000011735747

REMOVAL

- 1. Remove the glove box assembly. Refer to IP-13, "Exploded View".
- 2. Remove the instrument lower panel RH. Refer to IP-13, "Exploded View".
- 3. Disconnect tire pressure receiver harness connector.
- 4. Remove tire pressure receiver mounting screw.
- 5. Remove tire pressure receiver.

INSTALLATION

Install is the reverse order of removal.

WT

Α

В

C

D

Н

J

Κ

L

M

Ν

0

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REGULAR GRADE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Road Wheel

CONVENTIONAL

Item		Limit
Radial runout	Axial runout	Less than 0.3 mm (0.012 in)
Radiai runout	Radial runout	Less than 0.3 min (0.012 m)
Allowable unbalance	Dynamic (At flange)	Less than 5 g (0.17 oz) (one side)
Allowable urbalance	Static (At flange)	Less than 10 g (0.35 oz)

EMERGENCY

Item		Limit
Radial runout	Axial runout	Less than 1.5 mm (0.059 in)
	Radial runout	Less than 1.5 min (0.005 m)

Tire Air Pressure

INFOID:0000000011735749

Unit: kPa (kg/cm², psi)

		Air pressure							
Tire size	Fro	Front							
	Coupe	Roadster	Coupe	Roadster					
225/50R18 95W	240 (2.4, 35)	260 (2.6, 38)		_					
245/45R18 96W	-	- 240 (
245/40R19 94W	220 (2	.2, 32)	-						
275/35R19 96W	-	_	220 (2.2, 32)						
245/40R19 98Y	Y 240 (2.4, 35) –			_					
285/35R19 99Y	-	_ 24							
T145/80D17 107M		420 (4.2, 60)							
T145/70R18 107M									

[Nismo 370Z]

INFOID:0000000011735750


SPEC CHANGE INFORMATION

ROAD WHEEL TIRE ASSEMBLY

Road Wheel Tire Assembly

• Dedicated aluminum wheels adopted.

NISMO models	Item		Data
Aluminum road Size		Front	19 × 9.5J
wheels	s		19 × 10.5J
Offset		Front	+40 mm (+1.57 in)
		Rear	+23 mm (+0.91 in)
Tires	ires Tire size		245/40ZR19 98Y
		Rear	285/35ZR19 99Y



В

Α

D

WT

F

G

Н

J

Κ

L

M

Ν

0