

SECTION **DAS**

DRIVER ASSISTANCE SYSTEM

A
B
C

CONTENTS

D
E

ITS CONTROL UNIT	Inspection Procedure32	F
PRECAUTION 8	ACTION TEST33	
PRECAUTIONS 8	Description33	G
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"8	Inspection Procedure33	
Precautions For Harness Repair8	ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA35	H
SYSTEM DESCRIPTION 9	Description35	
COMPONENT PARTS 9	Work Procedure35	I
Component Parts Location9	REAR VIEW CAMERA CALIBRATION36	
Component Description 10	Description36	J
SYSTEM11	Work Procedure (Preparation)36	
System Description 11	Work Procedure (Target Setting)37	K
Fail-safe (ITS Control Unit) 12	Work Procedure (Rear View Camera Calibration)...38	
DIAGNOSIS SYSTEM (ITS CONTROL UNIT) ...14	DTC/CIRCUIT DIAGNOSIS40	L
CONSULT Function (AVM) 14	C1A03 VEHICLE SPEED SENSOR40	
ECU DIAGNOSIS INFORMATION17	DTC Logic40	M
ITS CONTROL UNIT17	Diagnosis Procedure40	
Reference Value 17	C1A04 ABS/TCS/VDC SYSTEM41	N
Fail-safe 19	DTC Logic41	
DTC Inspection Priority Chart 19	Diagnosis Procedure41	DAS
DTC Index 20	C1A39 STEERING ANGLE SENSOR42	
WIRING DIAGRAM22	DTC Logic42	P
DRIVER ASSISTANCE SYSTEMS22	Diagnosis Procedure42	
Wiring Diagram 22	U0122 VDC P-RUN DIAG43	
BASIC INSPECTION29	DTC Logic43	
DIAGNOSIS AND REPAIR WORK FLOW29	Diagnosis Procedure43	
Work Flow 29	U0416 VDC CHECKSUM DIAG44	
Diagnostic Work Sheet 30	DTC Logic44	
PRE-INSPECTION FOR DIAGNOSIS32	Diagnosis Procedure44	
	U0428 STEERING ANGLE SENSOR45	
	DTC Logic45	
	Diagnosis Procedure45	

PRE-INSPECTION FOR DIAGNOSIS	98	U1305 CAMERA IMAGE CALIB	117	
Inspection Procedure	98	DTC Logic	117	A
ACTION TEST	99	Diagnosis Procedure	117	
Description	99	U1308 CAMERA CONFIG	118	B
Inspection Procedure	99	DTC Logic	118	
ADDITIONAL SERVICE WHEN REPLACING		Diagnosis Procedure	118	
REAR VIEW CAMERA	101	U1309 PUMP UNIT CURRENT	119	C
Description	101	DTC Logic	119	
Work Procedure	101	Diagnosis Procedure	119	
REAR VIEW CAMERA CALIBRATION	102	U130B REAR CAMERA COMM ERROR	122	D
Description	102	DTC Logic	122	
Work Procedure (Preparation)	102	Diagnosis Procedure	122	
Work Procedure (Target Setting)	103	U1310 PUMP UNIT CIRCUIT	123	E
Work Procedure (Rear View Camera Calibration)	104	DTC Logic	123	
DTC/CIRCUIT DIAGNOSIS	106	Diagnosis Procedure	123	F
C1A03 VEHICLE SPEED SENSOR	106	POWER SUPPLY AND GROUND CIRCUIT ..	126	
DTC Logic	106	Diagnosis Procedure	126	G
Diagnosis Procedure	106	WARNING SYSTEMS SWITCH CIRCUIT	127	
C1A04 ABS/TCS/VDC SYSTEM	107	Component Function Check	127	H
DTC Logic	107	Diagnosis Procedure	127	
Diagnosis Procedure	107	Component Inspection	128	
C1A39 STEERING ANGLE SENSOR	108	WARNING SYSTEMS ON INDICATOR CIR-		I
DTC Logic	108	CUIT	129	
Diagnosis Procedure	108	Component Function Check	129	
U0122 VDC P-RUN DIAG	109	Diagnosis Procedure	129	J
DTC Logic	109	Component Inspection	130	
Diagnosis Procedure	109	WARNING BUZZER CIRCUIT	131	
U0416 VDC CHECKSUM DIAG	110	Component Function Check	131	K
DTC Logic	110	Diagnosis Procedure	131	
Diagnosis Procedure	110	SYMPTOM DIAGNOSIS	132	
U0428 STEERING ANGLE SENSOR	111	LDW SYSTEM SYMPTOMS	132	L
DTC Logic	111	Symptom Table	132	
Diagnosis Procedure	111	LANE DEPARTURE WARNING LAMP DOES		M
U1000 CAN COMM CIRCUIT	112	NOT TURN ON	133	
Description	112	Description	133	
DTC Logic	112	Diagnosis Procedure	133	N
Diagnosis Procedure	112	THE SYSTEM OPERATES EVEN WHEN US-		
U1010 CONTROL UNIT (CAN)	113	ING TURN SIGNAL	134	
Description	113	Description	134	
DTC Logic	113	Diagnosis Procedure	134	DAS
Diagnosis Procedure	113	LDW SYSTEM SETTINGS CANNOT BE		
U111A REAR CAMERA IMAGE SIGNAL CIR-		TURNED ON/OFF IN VEHICLE INFORMA-		P
CUIT	114	TION DISPLAY	135	
DTC Logic	114	Description	135	
Diagnosis Procedure	114	Diagnosis Procedure	135	
U1232 STEERING ANGLE SENSOR	116	NORMAL OPERATING CONDITION	136	
DTC Logic	116	Description	136	
Diagnosis Procedure	116			

REMOVAL AND INSTALLATION	137	DRIVER ASSISTANCE SYSTEMS	160
CONTROL UNIT	137	Wiring Diagram	160
Exploded View	137	BASIC INSPECTION	167
Removal and Installation - Rear View Camera		DIAGNOSIS AND REPAIR WORK FLOW	167
Washer Control Unit	137	Work Flow	167
WARNING SYSTEMS SWITCH	138	Diagnostic Work Sheet	168
Removal and Installation	138	PRE-INSPECTION FOR DIAGNOSIS	170
REAR VIEW CAMERA	139	Inspection Procedure	170
Removal and Installation	139	ACTION TEST	171
AIR PUMP	140	Description	171
Exploded View	140	Inspection Procedure	171
Removal and Installation	140	ADDITIONAL SERVICE WHEN REPLACING	
BSW		REAR VIEW CAMERA	173
PRECAUTION	141	Description	173
PRECAUTIONS	141	Work Procedure	173
Precaution for Supplemental Restraint System		REAR VIEW CAMERA CALIBRATION	174
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		Description	174
SIONER"	141	Work Procedure (Preparation)	174
Precaution for Work	141	Work Procedure (Target Setting)	175
Precautions For Harness Repair	141	Work Procedure (Rear View Camera Calibration),	176
Precaution for BSW System Service	142	DTC/CIRCUIT DIAGNOSIS	178
PREPARATION	143	C1A03 VEHICLE SPEED SENSOR	178
PREPARATION	143	DTC Logic	178
Special Service Tool	143	Diagnosis Procedure	178
SYSTEM DESCRIPTION	144	C1A04 ABS/TCS/VDC SYSTEM	179
COMPONENT PARTS	144	DTC Logic	179
Component Parts Location	144	Diagnosis Procedure	179
Component Description	144	C1A39 STEERING ANGLE SENSOR	180
SYSTEM	146	DTC Logic	180
System Description	146	Diagnosis Procedure	180
Fail-safe (ITS Control Unit)	148	U0122 VDC P-RUN DIAG	181
OPERATION	149	DTC Logic	181
Switch Name and Function	149	Diagnosis Procedure	181
System Display and Warning	149	U0416 VDC CHECKSUM DIAG	182
HANDLING PRECAUTION	151	DTC Logic	182
Precautions for Blind Spot Warning	151	Diagnosis Procedure	182
DIAGNOSIS SYSTEM (ITS CONTROL UNIT)	152	U0428 STEERING ANGLE SENSOR	183
CONSULT Function (AVM)	152	DTC Logic	183
ECU DIAGNOSIS INFORMATION	155	Diagnosis Procedure	183
ITS CONTROL UNIT	155	U1000 CAN COMM CIRCUIT	184
Reference Value	155	Description	184
Fail-safe	157	DTC Logic	184
DTC Inspection Priority Chart	157	Diagnosis Procedure	184
DTC Index	158	U1010 CONTROL UNIT (CAN)	185
WIRING DIAGRAM	160	Description	185
		DTC Logic	185
		Diagnosis Procedure	185

DTC Index	230	U1010 CONTROL UNIT (CAN)	256
WIRING DIAGRAM	232	Description	256
DRIVER ASSISTANCE SYSTEMS	232	DTC Logic	256
Wiring Diagram	232	Diagnosis Procedure	256
BASIC INSPECTION	239	U111A REAR CAMERA IMAGE SIGNAL CIR- CUIT	257
DIAGNOSIS AND REPAIR WORK FLOW	239	DTC Logic	257
Work Flow	239	Diagnosis Procedure	257
Diagnostic Work Sheet	240	U1232 STEERING ANGLE SENSOR	259
PRE-INSPECTION FOR DIAGNOSIS	242	DTC Logic	259
Inspection Procedure	242	Diagnosis Procedure	259
ACTION TEST	243	U1305 CAMERA IMAGE CALIB	260
Description	243	DTC Logic	260
Inspection Procedure	243	Diagnosis Procedure	260
ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA	244	U1308 CAMERA CONFIG	261
Description	244	DTC Logic	261
Work Procedure	244	Diagnosis Procedure	261
REAR VIEW CAMERA CALIBRATION	245	U1309 PUMP UNIT CURRENT	262
Description	245	DTC Logic	262
Work Procedure (Preparation)	245	Diagnosis Procedure	262
Work Procedure (Target Setting)	246	U130B REAR CAMERA COMM ERROR	265
Work Procedure (Rear View Camera Calibration)	247	DTC Logic	265
DTC/CIRCUIT DIAGNOSIS	249	Diagnosis Procedure	265
C1A03 VEHICLE SPEED SENSOR	249	U1310 PUMP UNIT CIRCUIT	266
DTC Logic	249	DTC Logic	266
Diagnosis Procedure	249	Diagnosis Procedure	266
C1A04 ABS/TCS/VDC SYSTEM	250	POWER SUPPLY AND GROUND CIRCUIT ...	269
DTC Logic	250	Diagnosis Procedure	269
Diagnosis Procedure	250	WARNING SYSTEMS SWITCH CIRCUIT	270
C1A39 STEERING ANGLE SENSOR	251	Component Function Check	270
DTC Logic	251	Diagnosis Procedure	270
Diagnosis Procedure	251	Component Inspection	271
U0122 VDC P-RUN DIAG	252	WARNING SYSTEMS ON INDICATOR CIR- CUIT	272
DTC Logic	252	Component Function Check	272
Diagnosis Procedure	252	Diagnosis Procedure	272
U0416 VDC CHECKSUM DIAG	253	Component Inspection	273
DTC Logic	253	WARNING BUZZER CIRCUIT	274
Diagnosis Procedure	253	Component Function Check	274
U0428 STEERING ANGLE SENSOR	254	Diagnosis Procedure	274
DTC Logic	254	SYMPTOM DIAGNOSIS	275
Diagnosis Procedure	254	MOD SYSTEM SYMPTOMS	275
U1000 CAN COMM CIRCUIT	255	Symptom Table	275
Description	255	MOD SYSTEM DOES NOT ACTIVATE	276
DTC Logic	255	Description	276
Diagnosis Procedure	255	Diagnosis Procedure	276

MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMA- TION DISPLAY	278	REMOVAL AND INSTALLATION	280
Description	278	CONTROL UNIT	280
Diagnosis Procedure	278	Exploded View	280
NORMAL OPERATING CONDITION	279	Removal and Installation - Rear View Camera	
Description	279	Washer Control Unit	280
		AIR PUMP	281
		Exploded View	281
		Removal and Installation	281

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008726194

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precautions For Harness Repair


INFOID:000000008479417

ITS communication uses a twisted pair line. Be careful when repairing it.

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[ITS CONTROL UNIT]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000008932604



- | | | |
|--|---|--|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit (center display) | 14. ITS control unit (view with center console removed) | 15. Steering angle sensor (view with steering wheel removed) |

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Component Description

INFOID:000000008660088


Component	Description
ITS control unit	<ul style="list-style-type: none"> • Controls each system, based on signals received from the rear view camera and CAN communication signals received from each control unit • Transmits signals necessary for control between CAN communication
Blind Spot Warning indicator LH/ RH	Receives Blind Spot Warning indicator operation signal from rear view camera and turns OFF, turns ON or blinks
Warning systems switch	Inputs the switch signal to ITS control unit
Warning systems ON indicator (On the warning systems switch)	Indicates BSW/LDW system status
Rear view camera	<ul style="list-style-type: none"> • Detects the lane marker by the built-in camera • Transmits detected lane condition signal to ITS control unit
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication
Buzzer (combination meter)	Receives buzzer signal from ITS control unit and sounds buzzer.
Combination meter	<ul style="list-style-type: none"> • Turns the Lane Departure Warning/Blind Spot Warning indicator ON/OFF according to the signals from the ITS control unit via CAN communication • Receives Lane Departure Warning/Blind Spot Warning ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication • Transmits dimmer signal to ITS control unit via CAN communication
ECM	Transmits engine speed signal to ITS control unit via CAN communication
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the center display
Center display	Displays the various system screen signals according to the priority level received via CAN communication
Rear view camera washer control unit	Controls the air pump to drive air to the rear camera lens according to the signals received from the ITS control unit
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the pump control unit

SYSTEM

System Description

INFOID:000000008660089

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name		Description
ECM	CAN communication	Engine speed signal	Receives engine speed
TCM	CAN communication	Input speed signal	Receives the number of revolutions of input shaft
		Current gear position signal	Receives a current gear position
		Shift position signal	Receives a shift selector position
		Output shaft revolution signal	Receives the number of revolutions of output shaft
ABS actuator and electric unit (control unit)	CAN communication	Vehicle speed signal (ABS)	Receives wheel speeds of four wheels
		Yaw rate signal	Receives yaw rate acting on the vehicle
Combination meter	CAN communication	Parking brake switch signal	Receives an operational state of the parking brake
BCM	CAN communication	Front wiper request signal	Receives an operational state of front wiper(s)
		Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp
		Dimmer signal	Receives ON/OFF state of dimmer signal

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

SYSTEM

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Transmit unit	Signal name		Description
Steering angle sensor	CAN communication	Steering angle sensor malfunction signal	Receives a malfunction state of steering angle sensor
		Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel
		Steering angle speed signal	Receives the turning angle speed of the steering wheel
AV control unit	CAN communication	System selection signal	Receives a selection state of each item in "Driver Assistance" selected with the navigation system
Warning systems switch	Warning systems switch signal		Receives an ON/OFF state of the warning systems switch

Output Signal Item

Reception unit	Signal name		Description
Combination meter	CAN communication	Meter display signal Own vehicle indicator signal	Transmits a signal to display a state of the system on the information display
		Blind Spot Warning indicator	Transmits a Blind Spot Warning signal to turn ON the Blind Spot Warning indicator
		Lane Departure Warning lamp signal	Transmits a Lane Departure Warning signal to turn ON the Lane Departure Warning indicator
		Buzzer output signal	Transmits a buzzer output signal to turn ON the buzzer of the following systems: <ul style="list-style-type: none"> • Moving Object Detection (MOD) • Blind Spot Warning (BSW) • Lane Departure Warning (LDW)
Warning buzzer	Warning buzzer signal		Activates the warning buzzer of the following systems: <ul style="list-style-type: none"> • Moving Object Detection (MOD) • Blind Spot Warning (BSW) • Lane Departure Warning (LDW)
Warning systems ON indicator	Warning systems ON indicator signal		Turns ON the warning systems ON indicator

DESCRIPTION

- ITS* control unit controls the following systems, based on ITS communication signals from the rear view camera and a CAN communication signal from each control unit.

NOTE:

*: Intelligent Technology Suite

- Moving Object Detection (MOD)
- Blind Spot Warning (BSW)
- Lane Departure Warning (LDW)

System	Reference
Moving Object Detection (MOD)	DAS-219. "System Description"
Blind Spot Warning (BSW)	DAS-146. "System Description"
Lane Departure Warning (LDW)	DAS-74. "System Description"

Fail-safe (ITS Control Unit)

INFOID:000000008660090

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

SYSTEM

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

System	Buzzer	Warning lamp/Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on camera screen)	Cancel

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000008660092

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit
Data Monitor	Displays ITS control unit input/output data in real time
Work support	Displays causes of automatic system cancellation occurred during system control
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load
ECU identification	Displays ITS control unit part number
Configuration	The vehicle specification can be written when replacing the ITS control unit

SELF DIAGNOSTIC RESULT

Refer to [DAS-20. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication)
REVERSE SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication)
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication]
CAMERA SWITCH SIGNAL [On/Off]	Indicates [On/Off] status of camera switch signal as judged from ITS control unit
CAMERA OFF SIGNAL [On/Off]	Indicates [On/Off] status of camera OFF signal as judged from ITS control unit
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling")
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2)
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD)
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines
WASH SW [ON/OFF]	Indicates the state of the wash switch indicator output
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit
ILL [On/Off]	Indicates [On/Off] status of the illumination signal
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Monitored item [Unit]	Description
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output
Rear Camera Image Output signal [OK/NG]	Indicates the input state of video image from rear camera
ITS SW_2 [ON/OFF/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit
ITS SW_2 IND [ON/OFF/No setting]	Indicates the state of the warning system secondary switch indicator output

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view
REAR CAMERA ITS	Displays and sets camera image calibration values
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description
WASH ACTIVE	ON
	OFF
LED LH	ON
	OFF
LED RH	ON
	OFF
AIR ACTIVE	ON
	OFF
AIR & WASH ACTIVE	ON
	OFF

BSW ON INDICATOR

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Test item	Operation	Description	Blind Spot Warning ON indicator lamp (Yellow)
BSW ON INDICATOR	Off	Stops transmitting the Blind Spot Warning ON indicator signal below to end the test	Off
	On	Transmits the Blind Spot Warning ON indicator signal to the warning lamp on the door	ON
Washer	Off	Stops transmitting activate signal to washer below to end the test	Off
	On	Transmits activate signal to washer	ON
Air pump	Off	Stops transmitting activate signal to air pump below to end the test	Off
	On	Transmits activate signal to air pump	ON

ECU IDENTIFICATION

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:0000000008660093

VALUES ON THE DIAGNOSIS TOOL


Monitor item	Condition		Value/Status
STEERING ANGLE	Ignition switch ON	Steering angle signal is received	On
		Steering angle signal is not received	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse)	On
		Shift selector is not in R (reverse)	Off
VEHICLE SPEED	While driving	Vehicle speed signal is received	On
		Vehicle speed signal is not received	Off
CAMERA SWITCH	Ignition switch ON	Camera switch is pressed	On
		Camera switch is not pressed	Off
CAMERA OFF SWITCH	Ignition switch ON	Purpose switch is pressed	On
		Purpose switch is not pressed	Off
TYPE OF STEER ANGLE SENSOR	Ignition switch ON	Steering angle sensor type is displayed	Absolute
		Steering angle sensor type is not received	Not
TYPE OF STEER GEAR RATIO	Ignition switch ON	Pattern 1 type of steering gear ratio displayed	Pattern 1
		Pattern 2 type of steering gear ratio displayed	Pattern 2
LEFT OR RIGHT STEER	Ignition switch ON	It recognizes steering position is left	LHD
		It recognizes steering position is right	RHD
REAR CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK	OK
		Rear camera serial status is not OK	NG
REAR CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received	OK
		Rear camera serial communication signal is not received	NG
ILL	Ignition switch ON	Illumination is ON	On
		Illumination is OFF	Off
ITS SW_1	Ignition switch ON	ITS switch is pressed	On
		ITS switch is not pressed	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting	On
		Indicator of ITS switch 1 is not lighting	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received	Left
		Turn signal neutral is received	N
		Turn signal right is received	Right
R-CAMERA IMAGE	Ignition switch ON	Camera image signal is received	On
		Camera image signal is not received	Off
ITS SW_2	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
WASH SWITCH SIGNAL	Ignition switch ON	Wash switch signal is pressed	On
		Wash switch signal is not pressed	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received	On
		Pump communication signal is not received	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (Y)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (LG)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN -L	—	—	—	—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (BR)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN -H	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (re- verse)	12 V
					Shift selector not in R (re- verse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—	—	0 V
50, 53	Ground	Shield	—	—	—	0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON	—	0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	

Fail-safe

INFOID:000000008660094

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on camera screen)	Cancel

DTC Inspection Priority Chart

INFOID:000000008660095

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

ITS CONTROL UNIT

[ITS CONTROL UNIT]

< ECU DIAGNOSIS INFORMATION >

INFOID:000000008660096

DTC Index

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010)
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-40
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-41
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-42
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-43
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-44
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-45
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-46
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-47
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-48
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-50
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-51
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-52
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-53
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-56
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-57

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000008660097



AAOWA0012GB

DRIVER ASSISTANCE SYSTEM CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7R	6R	5R	4R	3R	2R	1R		
16R	15R	14R	13R	12R	11R	10R	9R	8R




Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1G	LG	-

Terminal No.	Color of Wire	Signal Name
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-







A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]



AA0IA0041GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[ITS CONTROL UNIT]

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	BG	-
4	B	-
5	G	-
6	P	-
7	-	-
8	B	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA (SHIELD)


AA0IA0043GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	-	-
4	B	-

AA0IA0050GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008840782

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-30, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[ITS CONTROL UNIT]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-32, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform LDW system action test to check the operation status. Refer to [DAS-33, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-20, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-132, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform LDW system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000008840783

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using LDW				
	<input type="checkbox"/> All functions do not operate. <input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator) <input type="checkbox"/> Yawing function does not operate. (Warning function is operated.) <input type="checkbox"/> Functions when changing the course in the turn signal direction. <input type="checkbox"/> Functions are untimely. <input type="checkbox"/> Does not function when driving on lane markers. <input type="checkbox"/> Functions when driving in a lane. <input type="checkbox"/> Functions in a different position from the actual position. <input type="checkbox"/> Others ()				
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000008840784

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-36](#), "[Description](#)".

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26](#), "[Wheelarch Height \(Unladen*1\)](#)".

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[ITS CONTROL UNIT]

ACTION TEST

Description

INFOID:000000008840785

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-79, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000008840786

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-223, "Precautions for Moving Objects Detection"](#).

1. CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR LDW

1. Enable the setting of the LDW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the LDW operation according to the following table.


Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	 White <small>ALO1A0191GB</small>	—

DAS

ACTION TEST

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> • Buzzer sounds • Warning lamp blinks 	ON	 White (Orange) Blink White ALOIA0190GB	Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action	ON	 White ALOIA0191GB	—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-74. "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[ITS CONTROL UNIT]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000008840787

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000008840788

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment with CONSULT. Refer to [DAS-36, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of rear view camera with CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-20, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-33, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform WASH ACTIVE on Active Test using CONSULT.

2. Perform air and washer tube connection check by AIR & WASH ACTIVE on Active Test:

(1) Washer fluid output count on the rear view camera is 3 to 5 times → OK

(2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking

(3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking

(4) No washer fluid output → Check tube with blue marking or check valve

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000008840789

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the CONSULT when performing the calibration. (Rear view camera calibration cannot be operated without CONSULT).

Work Procedure (Preparation)

INFOID:000000008840790

1.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of the ITS control unit.

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-20, "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the ITS control unit by CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-32, "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

>> Refer to [DAS-37. "Work Procedure \(Target Setting\)".](#)


Work Procedure (Target Setting)

INFOID:000000008840791

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



- Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)
 Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)
 Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".

9. Position the center of the target mark to point of "Ct".



PKIB7667E

A
B
C
D
E
F
G
H
I
J
K
L
M
N


DAS

P

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-38. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000008840792


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-36. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" with CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".
4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
 - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-37. "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> • Temporary malfunction in internal processing of the rear view camera. • Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> • A target is not-yet-placed. (The rear view camera cannot detect a target.) • The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-36. "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> • Inappropriate work environment. • Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of ITS control unit with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-20. "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-33. "Description"](#).

>> Work End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000008840729

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-40, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008840730

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000008840733

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-40, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008840734

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
- NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008840749

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-40, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008840750

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-127, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000008840737

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-43, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008840738

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000008840741

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-43, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008840742

1. CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008840724

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U0428	ST ANGLE SENSOR CALIBRATION [U0428]	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000008840725

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When U1232 is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008660102

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:000000008660103

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:000000008660104

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-46, "Description"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1010 CONTROL UNIT (CAN)

Description

INFOID:0000000008660105

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:0000000008660106

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis	ITS control unit

Diagnosis Procedure

INFOID:0000000008660107

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000008840745

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted	Check rear camera image signal circuit between rear camera and around view monitor control unit.

Diagnosis Procedure

INFOID:000000008840746

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK CONTINUITY REAR CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear camera connector.
- Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE REAR CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit			
Connector	Terminal	"CAMERA" switch is ON or shift selector is in R (Reverse)	6.2 V
M59	52		

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

3. CHECK CONTINUITY REAR CAMERA IMAGE SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit connector and rear camera connector.
3. Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK REAR CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008840726

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:000000008840727

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-14, "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" with CONSULT. Refer to [DAS-14, "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Repair or replace malfunctioning parts.

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000008840752

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete	Perform ITS configuration with CONSULT

Diagnosis Procedure

INFOID:000000008840753

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-14, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000008841686

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB [U1308]	ITS control unit calibration is incomplete	Perform ITS calibration with CONSULT

Diagnosis Procedure

INFOID:000000008841687

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-14, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000008660108

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect	<ul style="list-style-type: none"> Rear view camera washer control unit Harness ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform "All DTC Reading" with CONSULT.
- Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-53, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841744

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

- Disconnect the rear view camera washer control unit connector.
- Turn the ignition switch ON.
- Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	12 V
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

- Disconnect the ITS control unit connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000008841691

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-57, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841743

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000008841693

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect	<ul style="list-style-type: none"> Rear view camera washer control unit Harness ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform "All DTC Reading" with CONSULT.
- Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-57, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841694

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

- Disconnect the rear view camera washer control unit connector.
- Turn the ignition switch ON.
- Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

- Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

[ITS CONTROL UNIT]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008660110

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	Ground	OFF	Battery voltage
		Ground	ON	Battery voltage
	39	Ground	OFF	0 V
		Ground	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000008931701

1.CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the DATA MONITOR item "ITS SW 1" of "AVM" with CONSULT.
3. With operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	OFF

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-61. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008931702

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	
Connector	Terminal		
M58	32	Pressed	
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> GO TO 2.

2.CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-62. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-138. "Removal and Installation"](#).

3.CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[ITS CONTROL UNIT]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000008931703

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Component Function Check

INFOID:000000008931704

1. CHECK WARNING SYSTEMS ON INDICATOR

1. Turn the ignition switch ON.
2. Select the active test item "BSW ON INDICATOR" of "AVM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning systems ON indicator illuminates

Off : Warning systems ON indicator is turned OFF

Is the inspection result normal?

- YES >> Inspection End.
NO >> Refer to [DAS-63, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008931705

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1. CHECK WARNING ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground Battery voltage
Connector	Terminal	
M62	5	

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

ITS control unit		Ground	Continuity
Connector	Terminal		
58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-64, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace warning systems switch. [DAS-138, "Removal and Installation"](#).

Component Inspection

INFOID:000000008931706

1.CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

WARNING BUZZER CIRCUIT

Component Function Check

INFOID:000000008931707

1. CHECK WARNING BUZZER

1. Turn the ignition switch ON.
2. Select the active test item "BUZZER" of "BCM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning buzzer is activated.

Off : Warning buzzer is not activated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-65, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008931708

1. CHECK WARNING BUZZER OPERATION

While activating the buzzer with CONSULT, listen for the buzzer sound.

Does warning buzzer sound?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace the combination meter (buzzer).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

CONTROL UNIT

< REMOVAL AND INSTALLATION >


[ITS CONTROL UNIT]

REMOVAL AND INSTALLATION

CONTROL UNIT

Exploded View

INFOID:000000008942903




- 1. Trunk lid - reinforcement
 - 2. Trunk lid - outer
 - 3. Rear view camera air pump motor assembly
 - 4. Rear view camera washer control unit
- ← : Front

Removal and Installation - ITS Control Unit

INFOID:000000008525000

REMOVAL

1. Disconnect the battery negative terminal. Refer to [PG-72. "Removal and Installation \(Battery\)"](#).
2. Remove the center console assembly. Refer to [JP-18. "Removal and Installation"](#).
3. Disconnect the harness connectors (B,C) from the ITS control unit (1).
↔: Front
4. Remove bolts (↔) and plastic screw (A) that retain the ITS control unit (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

Removal and Installation - Rear View Camera Washer Control Unit

INFOID:000000008942904

REMOVAL AND INSTALLATION

Removal


1. Remove the trunk lid finisher. Refer to [INT-33. "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.

CONTROL UNIT

< REMOVAL AND INSTALLATION >

[ITS CONTROL UNIT]

3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

AIR PUMP


< REMOVAL AND INSTALLATION >

[ITS CONTROL UNIT]

AIR PUMP

Exploded View

INFOID:000000008942905



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation

INFOID:000000008942906

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tube from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor assembly (1).



Installation

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008726195

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000008527312

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000008479650

ITS communication uses a twisted pair line. Be careful when repairing it.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



PRECAUTIONS


[LDW]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



Precaution for LDW System Service

INFOID:000000008942899

WARNING:

Be cautious of traffic conditions and other vehicles when performing a road test.

CAUTION:

- Never use the LDW system when driving with free rollers or a chassis dynamometer.
- Never disassemble or alter the rear view camera.
- Do not use the rear view camera when removed from the vehicle.
- Never disable the LDW system without the consent of the customer.

PREPARATION

< PREPARATION >

[LDW]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000008542317

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components



AWJIA04832Z

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LDW]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000008932603



AL01A01522Z

- | | | |
|--|--|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit (center display) | 14. ITS control unit
(view with center console removed) | 15. Steering angle sensor
(view with steering wheel removed) |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LDW]

Component Description

INFOID:000000008479653

Component	Description
ITS control unit	<ul style="list-style-type: none"> • Judges the lane departure depending on the lane detection result and each signal • Controls the warning buzzer and the warning systems ON indicator • Transmits lane departure warning lamp signal to combination meter via CAN communication
Warning systems switch	Inputs the warning systems switch signal to ITS control unit
Warning systems ON indicator (On the warning systems switch)	Turns on the warning systems ON indicator, according to a warning systems ON indicator signal received from the ITS control unit
Rear view camera	<ul style="list-style-type: none"> • Detects the lane marker in travel lane • Transmits the detected lane condition signal to ITS control unit via ITS communication
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication
Buzzer (combination meter)	Activates the warning buzzer, according to a warning buzzer signal received from the ITS control unit
Combination meter	<ul style="list-style-type: none"> • Turns the Lane Departure Warning lamp ON/OFF according to the signals from ITS control unit via CAN communication • Receives Lane Departure Warning ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication • Transmits dimmer signal to ITS control unit via CAN communication
ECM	Transmits engine speed signal to ITS control unit via CAN communication
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the center display
Center display	Displays the various system screen signals according to the priority level received via CAN communication
Rear view camera washer control unit	Controls the air pump to drive air to the rear camera lens according to the signals received from the ITS control unit
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the pump control unit

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

SYSTEM

System Description

INFOID:000000008479656

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name		Description
BCM	CAN communication	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp
Rear view camera	ITS communication	Detected lane condition signal	Receives detection results of lane marker
Warning systems switch	Warning systems switch signal		Receives an ON/OFF state of the warning systems switch

Output Signal Item

Reception unit	Signal name		Description
Combination meter	CAN communication	Lane departure warning lamp signal	Transmits a lane departure warning lamp signal to turn ON the lane departure warning lamp
Rear view camera	ITS communication	Vehicle speed signal	Transmits a vehicle speed calculated by the ITS control unit
		Turn indicator signal	Transmits a turn indicator signal received from BCM
Warning buzzer	Warning buzzer signal		Activates the warning buzzer
Warning systems ON indicator	Warning systems ON indicator signal		Turns ON the warning systems ON indicator

SYSTEM


[LDW]

< SYSTEM DESCRIPTION >

FUNCTION DESCRIPTION

- Lane Departure Warning (LDW) system provides a lane departure warning function when the vehicle is driven at speeds of approximately 70 km/h (45 MPH) or more.
- When the vehicle approaches either the left or the right side of the traveling lane, a warning will sound and the lane departure warning lamp (orange) on the combination meter will blink to alert the driver.
- The warning does not occur during turn signal operation (Lane change side).
- The warning function will stop when the vehicle returns inside of the lane markers.

EXAMPLE



When the vehicle approaches the right lane marker, the driver is alerted by the buzzer and the blinking of lane departure warning lamp (orange).

OPERATION DESCRIPTION

- When the system is turned ON by operating the warning systems switch, ITS control unit turns ON the warning systems ON indicator.
- Rear view camera monitors lane markers of the traveling lane. It transmits the detected lane condition signal to ITS control unit via ITS communication.
- When judging from a lane marker detection signal that the vehicle is approaching the lane marker, the ITS control unit controls the following item to alert the driver.
 - Activates warning buzzer
 - ITS control unit transmits a lane departure warning lamp signal to combination meter via CAN communication and turns ON/OFF the lane departure warning lamp (orange).

OPERATING CONDITION

- Warning systems ON indicator: ON
- Vehicle speed: approximately 70 km/h (45 MPH) or more
- Turn indicator signal: After 2 seconds or more from turned OFF

NOTE:

- When the LDW system setting on the vehicle information display is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH)
- The LDW system may not function properly, depending on the situation. Refer to [DAS-79. "Precautions for Lane Departure Warning"](#)

Bulb Check Action and Fail-safe Indication

DAS

SYSTEM

< SYSTEM DESCRIPTION >

[LDW]

Vehicle condition/ Driver's operation	Warning systems ON indicator	Indication on the combination meter
Ignition switch OFF ⇒ ON (Bulb check)	Approx. 5 sec. ON	ON (white)  <small>AL01A01832Z</small> ON: Operational Blinking: LDW detected
When DTC is detected (Except "U1308")	ON	LDW OFF (orange)
Camera aiming is not completed ("U1308" is detected) NOTE: This is detected while driving the vehicle and the indication remains ON until the ignition switch is turned OFF	ON	 <small>AL01A0159GB</small>
When rear camera needs cleaning	OFF	Unavailable: Clean Rear Camera
Temporary disabled status	OFF	LDW light (white) will blink
When the warning systems switch is pressed (When the settings of LDW system and BSW system on the vehicle information display is "OFF")	Blink	—

Fail-safe (ITS Control Unit)

INFOID:000000008680985

If a malfunction occurs in each system, ITS control unit cancels each control, and turns ON the warning lamp or indicator lamp.

System	Warning lamp/Indicator lamp	Description
Blind Spot Warning (BSW)	Blind Spot Warning lamp	Cancel
Lane Departure Warning (LDW)	Lane Departure Warning indicator	Cancel

Fail-safe (Rear View Camera)

INFOID:000000008479658

FAIL-SAFE CONTROL BY DTC

If a malfunction occurs in the rear view camera, ITS control unit cancels control, and turns ON the lane departure warning lamp in the combination meter.

BSW/LDW TEMPORARY DISABLED STATUS

Under the following condition, the BSW and/or LDW system is turned off temporarily, the BSW light (white) and /or LDW light (white) will blink, and either of the following messages will appear in the vehicle information display:

- "trunk is open"
- "washer fluid is low"

When the above condition no longer exists, the BSW and /or LDW system will resume automatically.

OPERATION


< SYSTEM DESCRIPTION >

[LDW]

OPERATION

Switch Name and Function

INFOID:000000008479662




No.	Switch name	Description
1	Warning systems switch	Turns LDW system ON/OFF (When the setting of LDW system on the navigation system screen is ON)

Menu Displayed by Pressing Each Switch

INFOID:000000008479663

INDICATOR LAMP AND WARNING LAMP



No.	Display item	Description
1	Warning systems ON indicator	Indicates that the LDW and/or BSW system is ON
2	Lane departure warning lamp	<ul style="list-style-type: none"> Blinks when LDW system is activated Turns ON when LDW system has a malfunction Blinks when DTC is detected or system is temporarily disabled Blinks when rear view camera blockage is detected

DISPLAY AND WARNING

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	ON	White	—

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

OPERATION

< SYSTEM DESCRIPTION >

[LDW]

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> • Buzzer sounds • Warning lamp blinks (orange) 	ON	OFF (orange) Blink  <small>AL0IA0185ZZ</small>	Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action	ON	White	—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-74. "System Description"](#).

HANDLING PRECAUTION

< SYSTEM DESCRIPTION >

[LDW]

HANDLING PRECAUTION

Precautions for Lane Departure Warning


INFOID:000000008479666

REAR VIEW CAMERA HANDLING

The rear camera unit "1" for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



LANE DEPARTURE WARNING (LDW)

- LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- The camera unit may not detect properly under the following conditions:
 - When towing a trailer.
 - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
 - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect properly under the following conditions:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt or snow, etc.
 - On roads where the discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
 - On roads where the traveling lane merges or separates.
 - When the vehicle's traveling direction does not align with the lane marker.
 - When the road surface is very dark due to scarce ambient light or impaired tail lamp.
- When driving on a curved road, warning will be late on the outside of the curve due to the nature of the system.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

[LDW]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000008842029

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit
Data Monitor	Displays ITS control unit input/output data in real time
Work support	Displays causes of automatic system cancellation occurred during system control
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load
ECU identification	Displays ITS control unit part number
Configuration	The vehicle specification can be written when replacing the ITS control unit

SELF DIAGNOSTIC RESULT

Refer to [DAS-86. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication)
REVERSE SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication)
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication]
CAMERA SWITCH SIGNAL [On/Off]	Indicates [On/Off] status of camera switch signal as judged from ITS control unit
CAMERA OFF SIGNAL [On/Off]	Indicates [On/Off] status of camera OFF signal as judged from ITS control unit
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling")
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2)
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD)
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines
WASH SW [ON/OFF]	Indicates the state of the wash switch indicator output
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit
ILL [On/Off]	Indicates [On/Off] status of the illumination signal
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LDW]

Monitored item [Unit]	Description
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output
Rear Camera Image Output signal [OK/NG]	Indicates the input state of video image from rear camera
ITS SW_2 [ON/OFF/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit
ITS SW_2 IND [ON/OFF/No setting]	Indicates the state of the warning system secondary switch indicator output

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view
REAR CAMERA ITS	Displays and sets camera image calibration values
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description
WASH ACTIVE	ON
	OFF
LED LH	ON
	OFF
LED RH	ON
	OFF
AIR ACTIVE	ON
	OFF
AIR & WASH ACTIVE	ON
	OFF

BSW ON INDICATOR

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LDW]

Test item	Operation	Description	Blind Spot Warning ON indicator lamp (Yellow)
BSW ON INDICATOR	Off	Stops transmitting the Blind Spot Warning ON indicator signal below to end the test	Off
	On	Transmits the Blind Spot Warning ON indicator signal to the warning lamp on the door	ON
Washer	Off	Stops transmitting activate signal to washer below to end the test	Off
	On	Transmits activate signal to washer	ON
Air pump	Off	Stops transmitting activate signal to air pump below to end the test	Off
	On	Transmits activate signal to air pump	ON

ECU IDENTIFICATION

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:000000008842085

VALUES ON THE DIAGNOSIS TOOL


Monitor item	Condition		Value/Status
STEERING ANGLE	Ignition switch ON	Steering angle signal is received	On
		Steering angle signal is not received	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse)	On
		Shift selector is not in R (reverse)	Off
VEHICLE SPEED	While driving	Vehicle speed signal is received	On
		Vehicle speed signal is not received	Off
CAMERA SWITCH	Ignition switch ON	Camera switch is pressed	On
		Camera switch is not pressed	Off
CAMERA OFF SWITCH	Ignition switch ON	Purpose switch is pressed	On
		Purpose switch is not pressed	Off
TYPE OF STEER ANGLE SENSOR	Ignition switch ON	Steering angle sensor type is displayed	Absolute
		Steering angle sensor type is not received	Not
TYPE OF STEER GEAR RATIO	Ignition switch ON	Pattern 1 type of steering gear ratio displayed	Pattern 1
		Pattern 2 type of steering gear ratio displayed	Pattern 2
LEFT OR RIGHT STEER	Ignition switch ON	It recognizes steering position is left	LHD
		It recognizes steering position is right	RHD
REAR CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK	OK
		Rear camera serial status is not OK	NG
REAR CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received	OK
		Rear camera serial communication signal is not received	NG
ILL	Ignition switch ON	Illumination is ON	On
		Illumination is OFF	Off
ITS SW_1	Ignition switch ON	ITS switch is pressed	On
		ITS switch is not pressed	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting	On
		Indicator of ITS switch 1 is not lighting	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received	Left
		Turn signal neutral is received	N
		Turn signal right is received	Right
R-CAMERA IMAGE	Ignition switch ON	Camera image signal is received	On
		Camera image signal is not received	Off
ITS SW_2	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
WASH SWITCH SIGNAL	Ignition switch ON	Wash switch signal is pressed	On
		Wash switch signal is not pressed	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received	On
		Pump communication signal is not received	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (Y)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (LG)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN -L	—	—	—	—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (BR)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN -H	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (re- verse)	12 V
					Shift selector not in R (re- verse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—	—	0 V
50, 53	Ground	Shield	—	—	—	0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON	—	0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	

Fail-safe

INFOID:000000008842086

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on camera screen)	Cancel

DTC Inspection Priority Chart

INFOID:000000008842087

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

ITS CONTROL UNIT

[LDW]

< ECU DIAGNOSIS INFORMATION >

DTC Index

INFOID:000000008842088

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010)
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-249
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-250
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-251
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-252
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-253
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-254
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-255
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-256
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-257
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-259
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-260
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-261
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-262
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-265
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-266

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- P

DAS


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000008674518



AAOWA0012GB


DRIVER ASSISTANCE SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-



Terminal No.	Color of Wire	Signal Name
1G	LG	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AA0IA0040GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK


Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
2	G	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
4	GR	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
109	G	REVERSE SIGNAL

AA0IA0041GB

DRIVER ASSISTANCE SYSTEMS

[LDW]

< WIRING DIAGRAM >

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[LDW]

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	BG	-
4	B	-
5	G	-
6	P	-
7	-	-
8	B	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA (SHIELD)

AA01A0043GB


DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[LDW]

Terminal No.	Color of Wire	Signal Name
1G	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	–

Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
74	V	WASH MTR

AA0IA0044GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	-	-
4	B	-

AA0IA0050GB

DIAGNOSIS AND REPAIR WORK FLOW

[LDW]

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008842004

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-240, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[LDW]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-242, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform LDW system action test to check the operation status. Refer to [DAS-33, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-20, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-132, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform LDW system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000008842005

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

[LDW]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using LDW <input type="checkbox"/> All functions do not operate. <input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator) <input type="checkbox"/> Yawing function does not operate. (Warning function is operated.) <input type="checkbox"/> Functions when changing the course in the turn signal direction. <input type="checkbox"/> Functions are untimely. <input type="checkbox"/> Does not function when driving on lane markers. <input type="checkbox"/> Functions when driving in a lane. <input type="checkbox"/> Functions in a different position from the actual position. <input type="checkbox"/> Others ()				
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[LDW]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000008842006

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-245. "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26. "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[LDW]

ACTION TEST

Description

INFOID:000000008842007

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-79, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000008842008

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-223, "Precautions for Moving Objects Detection"](#).

1. CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR LDW


1. Enable the setting of the LDW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the LDW operation according to the following table.

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	 White <small>ALO1A0191GB</small>	—

ACTION TEST

< BASIC INSPECTION >

[LDW]

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> • Buzzer sounds • Warning lamp blinks 	ON		Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action	ON		—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-74. "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[LDW]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000008842009

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000008842010

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment with CONSULT. Refer to [DAS-245, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of rear view camera with CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-86, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-99, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform WASH ACTIVE on Active Test using CONSULT.

2. Perform air and washer tube connection check by AIR & WASH ACTIVE on Active Test:

(1) Washer fluid output count on the rear view camera is 3 to 5 times → OK

(2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking

(3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking

(4) No washer fluid output → Check tube with blue marking or check valve

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000008842011

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the **CONSULT** when performing the calibration. (Rear view camera calibration cannot be operated without **CONSULT**).

Work Procedure (Preparation)

INFOID:000000008842012

1.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of the ITS control unit.

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-86. "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the ITS control unit by **CONSULT**.

1. Perform pre-inspection for diagnosis. Refer to [DAS-242. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

REAR VIEW CAMERA CALIBRATION

[LDW]

< BASIC INSPECTION >

>> Refer to [DAS-246. "Work Procedure \(Target Setting\)".](#)


Work Procedure (Target Setting)

INFOID:000000008842013

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".


9. Position the center of the target mark to point of "Ct".



REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-247. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000008842014


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-245. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" with CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".
4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
 - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-246, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> • Temporary malfunction in internal processing of the rear view camera. • Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> • A target is not-yet-placed. (The rear view camera cannot detect a target.) • The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-245, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> • Inappropriate work environment. • Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of ITS control unit with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-20, "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-99, "Description"](#).

>> Work End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000008841799

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841800

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000008841803

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841804

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
- NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841807

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841808

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-127, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000008841811

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841812

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000008841815

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841816

1.CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841818

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U0428	ST ANGLE SENSOR CALIBRATION [U0428]	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000008841819

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When U1232 is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008841820

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:000000008841821

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:000000008841822

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-46, "Description"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000008841823

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000008841824

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis	ITS control unit

Diagnosis Procedure

INFOID:000000008841825

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
- NO >> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000008841827

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted	Check rear camera image signal circuit between rear camera and around view monitor control unit.

Diagnosis Procedure

INFOID:000000008841828

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK CONTINUITY REAR CAMERA POWER SUPPLY AND GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector and rear camera connector.
3. Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK VOLTAGE REAR CAMERA POWER SUPPLY

1. Connect the ITS control unit connector and rear camera connector.
2. Turn the ignition switch ON.
3. Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit			
Connector	Terminal		
M59	52	Ground	"CAMERA" switch is ON or shift selector is in R (Reverse) 6.2 V

Is inspection result normal?

- YES >> GO TO 3.
NO >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK CONTINUITY REAR CAMERA IMAGE SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit connector and rear camera connector.
3. Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		


Is inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK REAR CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

DAS

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841830

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:000000008841831

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-224. "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" with CONSULT. Refer to [DAS-224. "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> Repair or replace malfunctioning parts.

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000008841832

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete	Perform ITS configuration with CONSULT

Diagnosis Procedure

INFOID:000000008841833

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000008841834

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB [U1308]	ITS control unit calibration is incomplete	Perform ITS calibration with CONSULT

Diagnosis Procedure

INFOID:000000008841835

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1309 PUMP UNIT CURRENT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000008841839

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect	<ul style="list-style-type: none"> Rear view camera washer control unit Harness ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform "All DTC Reading" with CONSULT.
- Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-262, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841839

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

- Disconnect the rear view camera washer control unit connector.
- Turn the ignition switch ON.
- Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	12 V
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

- Disconnect the ITS control unit connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000008841842

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841843

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000008841848

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841849

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

- Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

- Disconnect rear view camera air pump connector.
- Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

- Reconnect the ITS control unit connector.
- Turn the ignition switch ON.
- Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008841853

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	Ground	OFF	Battery voltage
		Ground	ON	Battery voltage
	39	Ground	OFF	0 V
		Ground	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

WARNING SYSTEMS SWITCH CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000008932645

1.CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the DATA MONITOR item "ITS SW 1" of "AVM" with CONSULT.
3. With operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	OFF

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
 NO >> Refer to [DAS-127. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932646

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	0 V
Connector	Terminal		
M58	32	Released	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
 NO >> GO TO 2.

2.CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-128. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Replace the warning systems switch. Refer to [DAS-138. "Removal and Installation"](#).

3.CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000008932647

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS ON INDICATOR CIRCUIT

Component Function Check

INFOID:000000008932648

1. CHECK WARNING SYSTEMS ON INDICATOR

1. Turn the ignition switch ON.
2. Select the active test item "BSW ON INDICATOR" of "AVM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning systems ON indicator illuminates

Off : Warning systems ON indicator is turned OFF

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-129, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932649

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1. CHECK WARNING ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground Battery voltage
Connector	Terminal	
M62	5	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

ITS control unit		Ground	Continuity
Connector	Terminal		
58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-130, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace warning systems switch. [DAS-138, "Removal and Installation"](#).

Component Inspection

INFOID:000000008932650

1.CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

WARNING BUZZER CIRCUIT

Component Function Check

INFOID:000000008932651

1.CHECK WARNING BUZZER

1. Turn the ignition switch ON.
2. Select the active test item "BUZZER" of "BCM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning buzzer is activated.

Off : Warning buzzer is not activated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-131, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932652

1.CHECK WARNING BUZZER OPERATION

While activating the buzzer with CONSULT, listen for the buzzer sound.

Does warning buzzer sound?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace the combination meter (buzzer).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

LDW SYSTEM SYMPTOMS

[LDW]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

LDW SYSTEM SYMPTOMS

Symptom Table

INFOID:000000008479783

NOTE:

For the operational conditions of Lane Departure Warning (LDW), refer to the following description.

- LDW: [DAS-74. "System Description"](#)

Symptom	Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON	Lane departure warning lamp (orange) does not illuminate.	<ul style="list-style-type: none"> • Combination meter • ITS control unit Lane departure warning lamp does not turn ON Refer to DAS-133. "Description"
	Warning systems ON indicator does not illuminate.	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch • Warning systems switch • ITS control unit Warning systems ON indicator circuit Refer to DAS-129. "Component Function Check"
	Lane departure warning lamp (orange) ON indicator lamp (white) does not illuminate.	<ul style="list-style-type: none"> • Combination meter • ITS control unit • Lane departure warning lamp does not turn ON Refer to DAS-133. "Description"
	All of indicator/warning lamps does not illuminate; <ul style="list-style-type: none"> • Lane departure warning lamp (orange) • Warning systems ON indicator 	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit • ITS control unit Power supply and ground circuit of ITS control unit Refer to DAS-126. "Diagnosis Procedure"
LDW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON)	Warning systems ON indicator is not turned ON ⇔ OFF when operating warning systems switch	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch • Harness between warning systems switch and ground • Warning systems switch • ITS control unit <ul style="list-style-type: none"> • Warning systems switch circuit Refer to DAS-127. "Component Function Check" • LDW system setting cannot be turned ON/OFF on the navigation screen Refer to DAS-135. "Diagnosis Procedure"
	Warning buzzer is not sounding. (Lane departure warning lamp is activated.)	<ul style="list-style-type: none"> • Warning buzzer • ITS control unit Refer to DAS-131. "Component Function Check"
Warning functions are not timely (Example) <ul style="list-style-type: none"> • Does not function when driving on lane markers • Functions when driving in a lane • Functions in a different position from the actual position. 	<ul style="list-style-type: none"> • Lane camera unit • ITS control unit Camera calibration DAS-102. "Description"	
Functions when changing the course in direction of the turn signal	Turn indicator signal (CAN) <ul style="list-style-type: none"> • BCM • ITS control unit 	System operates even when using turn signal . Refer to DAS-134. "Description"

LANE DEPARTURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[LDW]

LANE DEPARTURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000008479784

The lane departure warning lamp in the combination meter does not turn ON when turning on the ignition switch

Diagnosis Procedure

INFOID:000000008479785

1. CHECK LANE DEPARTURE WARNING LAMP

1. Check that "LANE DEPARTURE W/L" operates normally in "ACTIVE TEST" of "AVM".
2. Operate the test items to check that the lane departure warning lamp blinks

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 2.

2. CHECK COMBINATION METER

Turn the ignition switch from OFF to ON to check that "LANE W/L" included in "DATA MONITOR" in "METER/M&A" operates normally.

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).
- NO >> GO TO 3.

3. CHECK SELF-DIAGNOSIS RESULTS OF COMBINATION METER

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "METER/M&A". Refer to [MWI-27, "DTC Index"](#).

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> GO TO 4.

4. CHECK SELF-DIAGNOSIS RESULTS OF ITS CONTROL UNIT

Check if the DTC is detected in self-diagnosis results of "AVM". Refer to [DAS-20, "DTC Index"](#).

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL

< SYMPTOM DIAGNOSIS >

[LDW]

THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL

Description

INFOID:000000008932671

The warning of Lane Departure Warning (LDW) is activated during the use of a turn signal.

NOTE:

For the operational conditions of Lane Departure Warning (LDW), refer to [DAS-74, "System Description"](#).

Diagnosis Procedure

INFOID:000000008932672

1. CHECK TURN SIGNAL OPERATION

Check that both right and left turn signals are operational.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts. Refer to [DAS-132, "Symptom Table"](#).

2. CHECK SELF-DIAGNOSIS RESULTS

1. Perform "All DTC Reading" with CONSULT.

2. Check if the DTC is detected in self-diagnosis results of "AVM" Refer to [DAS-20, "DTC Index"](#).

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.

NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

LDW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[LDW]

LDW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:000000008479790

- LDW system setting is not selectable on the navigation screen.
- **NOTE:**
 - When the ignition switch is in ACC position, LDW system setting cannot be changed.
 - "Lane Departure Warning" is not indicated on the navigation screen.
 - The switching between ON and OFF cannot be performed by operating the navigation system.
 - The item of "Lane Departure Warning" on the navigation screen is not active.
- After turning ON the ignition switch or starting the engine, LDW setting of the navigation system cannot be selected for several tens of seconds under the following conditions:
 - After replacing AV control unit.
 - After erasing connection history of the navigation system.
 - After erasing self-diagnosis results of AV control unit.
- The LDW or LDP system setting differs from the one set at the previous driving.
 - **NOTE:**
 - Turn OFF the ignition switch and wait for 5 seconds or more.

Diagnosis Procedure

INFOID:000000008479791

1. CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system settings is selectable on the navigation screen.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "AVM", "MULTI AV" and "METER/M&A". Refer to the following.
 - AVM: [DAS-20, "DTC Index"](#)
 - MULTI AV (with BOSE): [AV-309, "DTC Index"](#)
 - MULTI AV (without BOSE): [AV-216, "DTC Index"](#)
 - METER/M&A: [MWI-27, "DTC Index"](#)

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> Inspection End.

3. CHECK DATA MONITOR OF ITS CONTROL UNIT

Check that "LDW SELECT" operates normally in "DATA MONITOR" of "AVM" with CONSULT.

Is the inspection result normal?

- YES >> Refer to [DAS-80, "CONSULT Function \(AVM\)"](#).
- NO >> GO TO 4.

4. CHECK MULTIFUNCTION SWITCH

Operate the multifunction switch to check that the audio, navigation system, and air conditioner operate properly.

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
- NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[LDW]

NORMAL OPERATING CONDITION

Description

INFOID:000000008479792

PRECAUTIONS FOR LANE DEPARTURE WARNING (LDW)

- LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- LDW system will not operate at speeds below approximately 70 km/h (45 MPH) or if it cannot detect lane markers.
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.
- LDW system may not function properly under the following conditions:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt or snow, etc.
 - On roads where the discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
 - On roads where the traveling lane merges or separates.
 - When the vehicle's traveling direction does not align with the lane marker.
 - When traveling close to other vehicle in front of the vehicle, which obstructs the lane camera unit detection range.
 - When rain, snow or dirt adheres to the windshield in front of the lane camera unit.
 - When a sudden change in brightness occurs. (For example, when the vehicle enters or exits a tunnel or under a bridge.)

CONTROL UNIT

< REMOVAL AND INSTALLATION >


[LDW]

REMOVAL AND INSTALLATION

CONTROL UNIT

Exploded View

INFOID:000000008942908



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation - Rear View Camera Washer Control Unit

INFOID:000000008942910

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33. "TRUNK LID FINISHER: Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[LDW]


WARNING SYSTEMS SWITCH

Removal and Installation


INFOID:000000008524993

REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-21. "Removal and Installation"](#).
2. Remove screws (←) that retain the upper switch carrier (1) to the instrument lower panel LH (2).



3. Release upper tab (B) and lower tab (C) using a suitable tool (A), then remove the warning system switch (4) from the upper switch carrier.
 - (1) Trunk opener switch
 - (2) VDC switch
 - (3) Heated steering wheel switch



INSTALLATION

Installation is in the reverse order of removal.

REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

[LDW]


REAR VIEW CAMERA

Removal and Installation

INFOID:000000008527109

REMOVAL

1. Remove trunk lid finisher. Refer to [INT-33, "Exploded View"](#).
2. Disconnect the harness connector (A) from rear view camera.
3. Push the rear view camera (1) in direction shown (←) and pull out to remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

AIR PUMP


< REMOVAL AND INSTALLATION >

[LDW]

AIR PUMP

Exploded View

INFOID:000000008942911



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation

INFOID:000000008942912

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tube from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor assembly (1).



Installation

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008726196

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000008599597

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000008479799

ITS communication uses a twisted pair line. Be careful when repairing it.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



PRECAUTIONS


[BSW]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



Precaution for BSW System Service

INFOID:000000008942898

WARNING:

Be cautious of traffic conditions and other vehicles when performing a road test.

CAUTION:

- Never use the BSW system when driving with free rollers or on a chassis dynamometer.
- Never perform BSW ACTIVE TESTS while driving.
- Never disassemble or alter the rear view camera.
- Do not use the rear view camera when removed from the vehicle.
- Never disable the BSW system without the consent of the customer.

OBSERVE THE FOLLOWING ITEMS IN ORDER TO KEEP THE BSW SYSTEM OPERATING PROPERLY:

Rear view Camera Maintenance

The rear view camera for the BSW system is located in the truck lid. To keep the BSW system operating properly and prevent a malfunction, be sure to observe the following:

- Always keep the camera lens area clean.
- Do not attach bumper stickers (including transparent materials) or install an accessory near the rear view-camera.
- Do not strike or damage the areas around the rear view camera.
- Do not touch the camera lens (except for cleaning) or remove the rear view camera.

PREPARATION

< PREPARATION >

[BSW]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000008542318

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components



AWJIA04832Z

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

COMPONENT PARTS

[BSW]


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000008479801



AL01A01522Z

- | | | |
|--|--|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit (center display) | 14. ITS control unit
(view with center console removed) | 15. Steering angle sensor
(view with steering wheel removed) |

Component Description

INFOID:000000008479802

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[BSW]

Component	Description
ITS control unit	<ul style="list-style-type: none"> • Being connected with rear view camera via ITS communication, receives vehicle detection signal and transmits Blind Spot Warning indicator signal and Blind Spot Warning indicator dimmer signal to the rear view camera • Being connected with lane camera unit via ITS communication, receives detected lane condition signal • Receives steering angle sensor signal from steering angle sensor via CAN communication • Judges a Blind Spot Warning indicator ON/OFF state and an approach state to the lane marker, based on each signal. • Activates the warning buzzer and warning systems ON indicator • Transmits Blind Spot Warning ON indicator signal to combination meter via CAN communication
Blind Spot Warning indicator LH/RH	Receives Blind Spot Warning indicator operation signal from rear view camera and turns OFF, turns ON or blinks
Warning systems switch	Inputs the switch signal to ITS control unit
Warning systems ON indicator (On the warning systems switch)	Indicates BSW system status
Rear view camera	<ul style="list-style-type: none"> • Detects the lane marker by the built-in camera • Transmits detected lane condition signal to ITS control unit
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication
Buzzer (combination meter)	Receives buzzer signal from ITS control unit and sounds buzzer.
Combination meter	<ul style="list-style-type: none"> • Turns the Blind Spot Warning indicator ON/OFF according to the signals from the ITS control unit via CAN communication • Receives Blind Spot Warning ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication • Transmits dimmer signal to ITS control unit via CAN communication
ECM	Transmits engine speed signal to ITS control unit via CAN communication
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the center display
Center display	Displays the various system screen signals according to the priority level received via CAN communication
Rear view camera washer control unit	Controls the air pump to drive air to the rear camera lens according to the signals received from the ITS control unit
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the pump control unit

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

SYSTEM

System Description

INFOID:000000008479803

SYSTEM DIAGRAM



CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Control unit receives signals via CAN communication. It also detects vehicle conditions that are necessary for BSW control.

Input Signal Item

Transmit unit	Signal name	Description
ECM	CAN Communication	Engine status signal Receive engine status
BCM	CAN communication	Door open status signal Receive door open status
		Light status signal Receive light status
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal Receive wheel speed
TCM	CAN communication	Shift selector position signal Receive shift selector position
Combination meter	CAN communication	Moving Object Detection ON/OFF signal Receive the ON/OFF status for Moving Object Detection function
Rear view camera	NTSC	Video signal Receive Rear View Camera image from camera for Moving Object Detection function in ITS controller

Output Signal Item

Reception unit	Signal name	Description
Combination meter	CAN communication	Buzzer request Transmits a buzzer request signal when the moving object is detected
Display	CAN communication	Visual signal request Transmits a visual signal request from ITS Controller to display Rear View while the shift selector is in R (reverse)


SYSTEM

[BSW]

< SYSTEM DESCRIPTION >

FUNCTION DESCRIPTION


- The BSW system can help alert the driver of other vehicles in adjacent lanes when changing lanes.
- The BSW system uses rear view camera near the rear bumper to detect vehicles in an adjacent lane.
- The rear view camera can detect vehicles on either side of vehicle within the detection zone shown as illustrated.
- This detection zone starts from the back of the vehicle and extends approximately 3.0 m (10 ft) behind the rear bumper, and approximately 13.0 m (10 ft) sideways.
- The BSW system operates above approximately 32 km/h (20 MPH).
- If the rear view camera detects vehicles in the detection zone, the Blind Spot Warning indicator illuminates.



- If the driver then activates the turn signal, a buzzer will sound twice and the Blind Spot Warning indicator will blink.

NOTE:

A buzzer sounds if the rear view camera has already detected vehicles when the driver activates the turn signal. If a vehicle comes into the detection zone after the driver activates the turn signal, then only the Blind Spot Warning indicator blinks and no buzzer sounds.



BSW SYSTEM OPERATION DESCRIPTION

- Control unit enables BSW system.
- The control unit turns on the BSW system when the warning systems switch is turned ON.
- Rear view camera detects a vehicle in the adjacent lane, and transmits the vehicle detection signal to control unit.
- Control unit starts the control as follows, based on a vehicle detection signal, turn signal and dimmer signal transmitted from BCM via CAN communication:
 - Blind Spot Warning indicator signal and Blind Spot Warning indicator dimmer signal transmission to rear view camera.
 - Buzzer signal transmission to warning buzzer.
- Rear view camera transmits an indicator operation signal to the Blind Spot Warning indicator according to Blind Spot Warning indicator signal and Blind Spot Warning indicator dimmer signal.

Operation Condition of BSW System

SYSTEM

[BSW]

< SYSTEM DESCRIPTION >

control unit performs the control when the following conditions are satisfied:

- When the warning systems switch is turned ON*.
- When the vehicle drives at 32 km/h (20 MPH) or more in the forward direction.


NOTE:

- *: When the BSW system setting on the vehicle information display screen is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed is reduced below approximately 29 km/h (18 MPH)
- The BSW system may not function properly, depending on the situation.

BULB CHECK ACTION AND FAIL-SAFE INDICATION

Vehicle condition/Driver's operation	Blind Spot Warning/ Blind Spot Intervention indicator	Warning systems ON indicator	Indication on the combination meter
When DTC is detected	OFF	ON	<p style="text-align: center;">OFF → Orange</p>  <p style="text-align: right; font-size: small;">ALOIA0172GB</p>
Temporary disabled status	OFF	ON	BSW light (white) will blink
When rear view camera needs cleaning	OFF	ON	Unavailable: Clean Rear Camera
When the warning systems switch is pressed (When the settings of LDW system and BSW system on the vehicle information screen are "OFF")	OFF	Blink	—

*: Blinking cycle when there is a rear view camera blockage condition or lane camera unit high temperature condition



NOTE:

Time shown in the figure is approximate.

Fail-safe (ITS Control Unit)

INFOID:000000008681903

If a malfunction occurs in each system, ITS control unit cancels each control, and turns ON the warning lamp or indicator lamp.

System	Warning lamp/Indicator lamp	Description
Blind Spot Warning (BSW)	Blind Spot Warning lamp	Cancel
Lane Departure Warning (LDW)	Lane Departure Warning indicator	Cancel

OPERATION


< SYSTEM DESCRIPTION >

[BSW]

OPERATION

Switch Name and Function

INFOID:000000008479811




ALOIA01092Z

No.	Name	Function
1	Warning systems switch	Turns BSW system ON/OFF (When the setting of BSW system on the vehicle information display setting screen is ON)

System Display and Warning

INFOID:000000008479812

INDICATOR AND WARNING LAMP



ALOIA01802Z

No.	Name	Description
1	Warning systems ON indicator	Indicates that the LDW system and/or BSW system is ON
2	Blind Spot Warning lamp (orange)	<ul style="list-style-type: none"> • Turns ON when Blind Spot Warning system is malfunctioning • Blinks during the following conditions: <ul style="list-style-type: none"> - DTC is detected or system is temporarily disabled. - When rear view camera blockage is detected.




DISPLAY AND WARNING OPERATION

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
OFF	—	—	—	OFF	OFF

OPERATION

[BSW]

< SYSTEM DESCRIPTION >

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
ON	Less than approx. 29km/h (18MPH)	—	—	OFF	OFF
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF
		OFF	Vehicle is detected	ON	OFF
		ON (vehicle detected direction)	Before turn signal operates Vehicle is detected	Blink  Indicator ON Indicator OFF 200 ms 200 ms <small>J50IA0251GB</small>	Short continuous beep  Buzzer ON Buzzer OFF 80 ms 550 ms <small>J50IA0252GB</small>
	ON (vehicle detected direction)	Vehicle is detected after turn signal operates	Blink  Indicator ON Indicator OFF 200 ms 200 ms <small>J50IA0251GB</small>	OFF	

NOTE:

- If vehicle speed exceeds approximately 32 km/h (20 MPH), BSW function operates until the vehicle speed becomes lower than approximately 29 km/h (18 MPH).
- Time shown in the figure is approximate.
- Whenever Blind Spot Warning system is turned off, the warning systems ON indicator remains OFF.

HANDLING PRECAUTION

< SYSTEM DESCRIPTION >

[BSW]

HANDLING PRECAUTION

Precautions for Blind Spot Warning


INFOID:000000008681801

REAR VIEW CAMERA HANDLING

The rear camera unit "1" for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



BLIND SPOT WARNING (BSW)

- BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- The camera unit may not detect properly under the following conditions:
 - When towing a trailer.
 - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
 - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - Several types of vehicles such as motorcycles.
 - Oncoming vehicles.
 - A vehicle approaching rapidly from behind
 - A vehicle which your vehicle overtakes rapidly.
- The camera unit may not be able to detect properly when your vehicle travels beside the middle section of a vehicle with a long wheelbase (e.g., trailer truck, semi-trailer, tractor).
- The camera unit is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- The camera unit may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

[BSW]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000008842031

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit
Data Monitor	Displays ITS control unit input/output data in real time
Work support	Displays causes of automatic system cancellation occurred during system control
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load
ECU identification	Displays ITS control unit part number
Configuration	The vehicle specification can be written when replacing the ITS control unit

SELF DIAGNOSTIC RESULT

Refer to [DAS-86. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication)
REVERSE SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication)
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication]
CAMERA SWITCH SIGNAL [On/Off]	Indicates [On/Off] status of camera switch signal as judged from ITS control unit
CAMERA OFF SIGNAL [On/Off]	Indicates [On/Off] status of camera OFF signal as judged from ITS control unit
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling")
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2)
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD)
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines
WASH SW [ON/OFF]	Indicates the state of the wash switch indicator output
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit
ILL [On/Off]	Indicates [On/Off] status of the illumination signal
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

[BSW]

< SYSTEM DESCRIPTION >

Monitored item [Unit]	Description
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output
Rear Camera Image Output signal [OK/NG]	Indicates the input state of video image from rear camera
ITS SW_2 [ON/OFF/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit
ITS SW_2 IND [ON/OFF/No setting]	Indicates the state of the warning system secondary switch indicator output

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view
REAR CAMERA ITS	Displays and sets camera image calibration values
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description
WASH ACTIVE	ON
	OFF
LED LH	ON
	OFF
LED RH	ON
	OFF
AIR ACTIVE	ON
	OFF
AIR & WASH ACTIVE	ON
	OFF

BSW ON INDICATOR

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BSW]

Test item	Operation	Description	Blind Spot Warning ON indicator lamp (Yellow)
BSW ON INDICATOR	Off	Stops transmitting the Blind Spot Warning ON indicator signal below to end the test	Off
	On	Transmits the Blind Spot Warning ON indicator signal to the warning lamp on the door	ON
Washer	Off	Stops transmitting activate signal to washer below to end the test	Off
	On	Transmits activate signal to washer	ON
Air pump	Off	Stops transmitting activate signal to air pump below to end the test	Off
	On	Transmits activate signal to air pump	ON

ECU IDENTIFICATION

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:000000008842081

VALUES ON THE DIAGNOSIS TOOL

Monitor item	Condition		Value/Status
STEERING ANGLE	Ignition switch ON	Steering angle signal is received	On
		Steering angle signal is not received	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse)	On
		Shift selector is not in R (reverse)	Off
VEHICLE SPEED	While driving	Vehicle speed signal is received	On
		Vehicle speed signal is not received	Off
CAMERA SWITCH	Ignition switch ON	Camera switch is pressed	On
		Camera switch is not pressed	Off
CAMERA OFF SWITCH	Ignition switch ON	Purpose switch is pressed	On
		Purpose switch is not pressed	Off
TYPE OF STEER ANGLE SENSOR	Ignition switch ON	Steering angle sensor type is displayed	Absolute
		Steering angle sensor type is not received	Not
TYPE OF STEER GEAR RATIO	Ignition switch ON	Pattern 1 type of steering gear ratio displayed	Pattern 1
		Pattern 2 type of steering gear ratio displayed	Pattern 2
LEFT OR RIGHT STEER	Ignition switch ON	It recognizes steering position is left	LHD
		It recognizes steering position is right	RHD
REAR CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK	OK
		Rear camera serial status is not OK	NG
REAR CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received	OK
		Rear camera serial communication signal is not received	NG
ILL	Ignition switch ON	Illumination is ON	On
		Illumination is OFF	Off
ITS SW_1	Ignition switch ON	ITS switch is pressed	On
		ITS switch is not pressed	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting	On
		Indicator of ITS switch 1 is not lighting	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received	Left
		Turn signal neutral is received	N
		Turn signal right is received	Right
R-CAMERA IMAGE	Ignition switch ON	Camera image signal is received	On
		Camera image signal is not received	Off
ITS SW_2	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
WASH SWITCH SIGNAL	Ignition switch ON	Wash switch signal is pressed	On
		Wash switch signal is not pressed	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received	On
		Pump communication signal is not received	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (Y)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (LG)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN -L	—	—	—	—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (BR)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN -H	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (re- verse)	12 V
					Shift selector not in R (re- verse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—	—	0 V
50, 53	Ground	Shield	—	—	—	0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON	—	0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	

Fail-safe

INFOID:000000008842082

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on camera screen)	Cancel

DTC Inspection Priority Chart

INFOID:000000008842083

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

DTC Index

INFOID:000000008842084

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010)
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-249
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-250
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-251
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-252
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-253
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-254
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-255
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-256
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-257
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-259
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-260
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-261
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-262
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-265
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-266

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000008674519



AAOWA0012GB

DRIVER ASSISTANCE SYSTEM CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7R	6R	5R	4R	3R	2R	1R		
16R	15R	14R	13R	12R	11R	10R	9R	8R



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1G	LG	-

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-


Terminal No.	Color of Wire	Signal Name
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[BSW]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK


Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
2	G	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
4	GR	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
109	G	REVERSE SIGNAL

AA0IA0041GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[BSW]

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AA0IA0042GB

DRIVER ASSISTANCE SYSTEMS

[BSW]


< WIRING DIAGRAM >

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	BG	-
4	B	-
5	G	-
6	P	-
7	-	-
8	B	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA (SHIELD)

AA0IA0043GB


DRIVER ASSISTANCE SYSTEMS

[BSW]


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
1G	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	–

Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
74	V	WASH MTR

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AA0IA0044GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[BSW]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	-	-
4	B	-

AA0IA0050GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008841992

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-240, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[BSW]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-242, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform BSW system action test to check the operation status. Refer to [DAS-171, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-20, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-132, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform BSW system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000008841993

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

[BSW]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using BSW <input type="checkbox"/> All functions do not operate. <input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator) <input type="checkbox"/> Yawing function does not operate. (Warning function is operated.) <input type="checkbox"/> Functions when changing the course in the turn signal direction. <input type="checkbox"/> Functions are untimely. <input type="checkbox"/> Does not function when driving on lane markers. <input type="checkbox"/> Functions when driving in a lane. <input type="checkbox"/> Functions in a different position from the actual position. <input type="checkbox"/> Others ()				
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ALOIA0193GB

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[BSW]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000008841994

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-245. "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26. "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[BSW]

ACTION TEST

Description

INFOID:000000008945582

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
- System description for LDW: Refer to [DAS-74, "System Description"](#).
- System description for BSW: Refer to [DAS-146, "System Description"](#).
- System description for MOD: Refer to [DAS-219, "System Description"](#).
- Handling precaution: Refer to [DAS-79, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000008841996

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
- System description for LDW: Refer to [DAS-74, "System Description"](#).
- System description for BSW: Refer to [DAS-146, "System Description"](#).
- System description for MOD: Refer to [DAS-219, "System Description"](#).
- Handling precaution: Refer to [DAS-79, "Precautions for Lane Departure Warning"](#).

1. CHECK BSW SYSTEM SETTING

1. Start the engine.
2. Check that the BSW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR BSW

1. Enable the setting of the BSW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the BSW operation according to the following table.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

ACTION TEST

[BSW]

< BASIC INSPECTION >

Vehicle condition/Driver's operation						
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the combination meter	Buzzer	
ON	Less than Approx. 29 km/h (18 MPH)	—	—	OFF	OFF	
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF	
		OFF	Vehicle is detected	ON	ON	OFF
		ON (vehicle detected direction)	Before turn signal operates vehicle is detected	Blink	Short continuous beeps	
			Vehicle is detected after turn signal operates	Blink	OFF	



NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-146. "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[BSW]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000008841997

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000008841998

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment with CONSULT. Refer to [DAS-245, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of rear view camera with CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-86, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-171, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform WASH ACTIVE on Active Test using CONSULT.

2. Perform air and washer tube connection check by AIR & WASH ACTIVE on Active Test:

(1) Washer fluid output count on the rear view camera is 3 to 5 times → OK

(2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking

(3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking

(4) No washer fluid output → Check tube with blue marking or check valve

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

[BSW]

< BASIC INSPECTION >

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000008841999

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the CONSULT when performing the calibration. (Rear view camera calibration cannot be operated without CONSULT).

Work Procedure (Preparation)

INFOID:000000008842000

1.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of the ITS control unit.

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-86. "DTC Index"](#).

"U1308" or no DTC>> GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the ITS control unit by CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-242. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

REAR VIEW CAMERA CALIBRATION

[BSW]

< BASIC INSPECTION >

>> Refer to [DAS-246. "Work Procedure \(Target Setting\)".](#)


Work Procedure (Target Setting)

INFOID:000000008842001

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (Sd): "B" – "E" ("D" – "F") : 2125 mm (83.66 in)

:

Left distance (Ld): "Ct" – "Lt" : 1500 mm (59.06 in)

Right distance (Rd): "Ct" – "Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".

9. Position the center of the target mark to point of "Ct".




A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[BSW]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-247. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000008842002


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-245. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" with CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".
4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
 - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

REAR VIEW CAMERA CALIBRATION

[BSW]

< BASIC INSPECTION >

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-246, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> Temporary malfunction in internal processing of the rear view camera. Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> A target is not-yet-placed. (The rear view camera cannot detect a target.) The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-245, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> Inappropriate work environment. Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of ITS control unit with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-20, "DTC Index"](#).

NO >> GO TO 4.

4.ACTION TEST

Test the system operation by action test. Refer to [DAS-171, "Description"](#).

>> Work End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000008841874

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841875

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000008841878

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841879

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
- NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A39 STEERING ANGLE SENSOR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841882

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841883

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-127, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

U0122 VDC P-RUN DIAG

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000008841886

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841887

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2. CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000008841890

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841891

1.CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841893

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U0428	ST ANGLE SENSOR CALIBRATION [U0428]	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000008841894

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When U1232 is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008841895

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:000000008841896

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:000000008841897

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-46, "Description"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000008841898

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000008841899

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis	ITS control unit

Diagnosis Procedure

INFOID:000000008841900

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
- NO >> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000008841902

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted	Check rear camera image signal circuit between rear camera and around view monitor control unit.

Diagnosis Procedure

INFOID:000000008841903

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK CONTINUITY REAR CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear camera connector.
- Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE REAR CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit			
Connector	Terminal		
M59	52	Ground	"CAMERA" switch is ON or shift selector is in R (Reverse) 6.2 V

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK CONTINUITY REAR CAMERA IMAGE SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit connector and rear camera connector.
3. Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK REAR CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

DAS

U1232 STEERING ANGLE SENSOR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841905

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:000000008841906

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-224. "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" with CONSULT. Refer to [DAS-224. "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> Repair or replace malfunctioning parts.

U1305 CAMERA IMAGE CALIB

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000008841907

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete	Perform ITS configuration with CONSULT

Diagnosis Procedure

INFOID:000000008841908

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000008841909

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB [U1308]	ITS control unit calibration is incomplete	Perform ITS calibration with CONSULT

Diagnosis Procedure

INFOID:000000008841910

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000008841913

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-262, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841914

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	12 V
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1309 PUMP UNIT CURRENT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1309 PUMP UNIT CURRENT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U130B REAR CAMERA COMM ERROR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000008841917

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841918

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

U1310 PUMP UNIT CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000008841923

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect	<ul style="list-style-type: none"> Rear view camera washer control unit Harness ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform "All DTC Reading" with CONSULT.
- Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841924

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

- Disconnect the rear view camera washer control unit connector.
- Turn the ignition switch ON.
- Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

- Disconnect the ITS control unit connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1310 PUMP UNIT CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008841928

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	Ground	OFF	Battery voltage
		Ground	ON	Battery voltage
	39	Ground	OFF	0 V
		Ground	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

WARNING SYSTEMS SWITCH CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000008932653

1.CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the DATA MONITOR item "ITS SW 1" of "AVM" with CONSULT.
3. With operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	OFF

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-199. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932654

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	
Connector	Terminal		
M58	32	Pressed	
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> GO TO 2.

2.CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-200. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-138. "Removal and Installation"](#).

3.CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000008932655

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS ON INDICATOR CIRCUIT

Component Function Check

INFOID:000000008932656

1.CHECK WARNING SYSTEMS ON INDICATOR

1. Turn the ignition switch ON.
2. Select the active test item "BSW ON INDICATOR" of "AVM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning systems ON indicator illuminates

Off : Warning systems ON indicator is turned OFF

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-201, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932657

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CHECK WARNING ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M62	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2.CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

ITS control unit		Ground	Continuity
Connector	Terminal		
58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-202, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace warning systems switch. [DAS-138, "Removal and Installation"](#).

Component Inspection

INFOID:000000008932658

1.CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

WARNING BUZZER CIRCUIT

Component Function Check

INFOID:000000008932659

1.CHECK WARNING BUZZER

1. Turn the ignition switch ON.
2. Select the active test item "BUZZER" of "BCM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning buzzer is activated.

Off : Warning buzzer is not activated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-203, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932660

1.CHECK WARNING BUZZER OPERATION

While activating the buzzer with CONSULT, listen for the buzzer sound.

Does warning buzzer sound?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace the combination meter (buzzer).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

SYMPTOM DIAGNOSIS

BSW SYSTEM SYMPTOMS

Symptom Table

INFOID:000000008479991

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

NOTE:

Refer to the following for operating conditions of the Blind Spot Warning system.

- Blind Spot Warning system: [DAS-146, "System Description"](#).

Symptom	Possible cause	Inspection item/Reference page	
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	Blind Spot Warning lamp (orange) does not illuminate	<ul style="list-style-type: none"> • Blind Spot Warning warning lamp signal (CAN) - Combination meter - ITS control unit • Blind Spot Warning lamp (combination meter) 	<ul style="list-style-type: none"> • ITS control unit Active test "BSW WARNING LAMP". Refer to DAS-152, "CONSULT Function (AVM)". • ITS control unit Data monitor "BSW WARN LMP". Refer to DAS-152, "CONSULT Function (AVM)".
	Blind Spot Warning/Backup Collision Warning lamp (orange) do not illuminate	<ul style="list-style-type: none"> • Combination meter • ITS control unit 	<ul style="list-style-type: none"> • Combination meter Data monitor "BSW W/L". Refer to MWI-18, "CONSULT Function (METER/M&A)".
	All of indicator/warning lamps do not illuminate; • Blind Spot Warning lamp • Warning systems ON indicator	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit • ITS control unit • Combination meter 	Power supply and ground circuit of ITS control unit. Refer to DAS-198, "Diagnosis Procedure" .
	Warning systems ON indicator (on the warning systems switch) does not illuminate	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch • Warning systems switch • ITS control unit 	Warning systems ON indicator circuit. Refer to DAS-201, "Diagnosis Procedure" .
	Blind Spot Warning indicator does not turn ON	<ul style="list-style-type: none"> • Harness between ITS control unit and Blind Spot Warning indicator • Blind Spot Warning indicator 	Perform self-diagnosis of Blind Spot Warning indicator. Refer to DAS-152, "CONSULT Function (AVM)" .
BSW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON.)	Warning systems ON indicator is not turned ON ⇔ OFF when operating warning systems switch	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch • Harness between warning systems switch and ground • ITS control unit • Warning systems switch 	<ul style="list-style-type: none"> • Warning systems switch circuit. Refer to DAS-199, "Diagnosis Procedure". • BSW system setting cannot be turned ON/OFF on the navigation screen. Refer to DAS-207, "Description".
	Buzzer is not sounding	<ul style="list-style-type: none"> • Combination meter (warning buzzer) • ITS control unit 	Combination meter. Refer to DAS-203, "Component Function Check" .
Blind Spot Warning functions are not timely (Example) <ul style="list-style-type: none"> • Does not function when approaching a lane marker with a vehicle in the blind spot. • Functions when driving in the middle of lane. 	<ul style="list-style-type: none"> • Camera aiming • Lane camera unit 	Camera aiming. Refer to DAS-174, "Description" .	

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[BSW]

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

Description

INFOID:000000008479992

The switch does not turn ON

- When the Blind Spot Warning system setting is ON, the Blind Spot Warning ON indicator does not illuminate even if the warning system switch is depressed.

The switch does not turn OFF

- The Blind Spot Warning ON indicator does not turn off even if the warning system switch is pressed when the Blind Spot Warning ON indicator illuminates.

Diagnosis Procedure

INFOID:000000008479993

1. CHECK BLIND SPOT WARNING SYSTEM SETTING

1. Start the engine.
2. After starting the engine wait for 5 seconds or more.
3. Check that Blind Spot Warning system setting on the vehicle information display screen is ON.

Is Blind Spot Warning system setting ON?

- YES >> GO TO 2.
NO >> Enable the Blind Spot Warning system setting.

2. WARNING SYSTEM SWITCH INSPECTION

1. Start the engine.
2. Check that warning system switch operates normally in "DATA MONITOR" of "AVM" with CONSULT.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 5.

3. CHECK BLIND SPOT WARNING ON INDICATOR CIRCUIT

1. Start the engine.
2. Select the active test item "BSW ON IND" of "AVM" with CONSULT.
3. Check if the Blind Spot Warning ON indicator illuminates when the test item is operated.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 4.

4. PERFORM THE SELF-DIAGNOSIS OF COMBINATION METER

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "METER/M&A". Refer to [MWI-27, "DTC Index"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5. PERFORM THE SELF-DIAGNOSIS

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "AVM". Refer to [DAS-20, "DTC Index"](#).

Is any DTC detected?

- YES >> GO TO 6.
NO >> GO TO 7.

6. REPAIR OR REPLACE MALFUNCTIONING PARTS.

Repair or replace malfunctioning parts.

>> GO TO 7.

7. CHECK BLIND SPOT WARNING SYSTEM

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[BSW]

1. Erase “self-diagnosis result”, and then perform “All DTC Reading” again after performing the action test.
(Refer to [DAS-171, "Description"](#) for action test.)
2. Check that the Blind Spot Warning system is normal.

>> Inspection End.

BSW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[BSW]

BSW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:000000008479994

- BSW system setting is not selectable on the vehicle information display screen.
 - **NOTE:**
 - When the ignition switch is in ACC position, Blind Spot Warning system setting cannot be changed.
 - "Blind Spot Warning" is not indicated on the vehicle information display screen.
 - The switching between ON and OFF cannot be performed by operating the Setting screen on the vehicle information display system.
 - The item "Blind Spot Warning" on the vehicle information display screen is not active.
 - The Blind Spot Warning system setting differs from the one set at the previous driving.
- NOTE:**
Turn OFF the ignition switch and wait for 5 seconds or more.

Diagnosis Procedure

INFOID:000000008479995

1. CHECK BLIND SPOT WARNING SYSTEM SETTING

1. Start the engine.
 2. Check that the Blind Spot Warning system settings is selectable on the vehicle information display screen.
- Is the inspection result normal?
- YES >> GO TO 3.
NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

1. Perform self-diagnosis with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "AVM", "MULTI AV" and "METER/M&A". Refer to the following:
 - AVM: [DAS-20. "DTC Index"](#)
 - MULTI AV (with BOSE): [AV-309. "DTC Index"](#)
 - MULTI AV (without BOSE): [AV-216. "DTC Index"](#)
 - METER/M&A: [MWI-27. "DTC Index"](#)

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
NO >> Inspection End.

3. CHECK DATA MONITOR OF ITS CONTROL UNIT

Check that "BSW SELECT" operates normally in "DATA MONITOR" of "AVM" with CONSULT.

Is the inspection result normal?

- YES >> Refer to [DAS-152. "CONSULT Function \(AVM\)"](#).
NO >> GO TO 4.

4. CHECK MULTIFUNCTION SWITCH

Operate the multifunction switch to check that the audio, navigation system, and air conditioner operate properly.

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

NORMAL OPERATING CONDITION

Description

INFOID:000000008479996

PRECAUTIONS FOR BLIND SPOT WARNING (BSW)

- The Blind Spot Warning system is not a replacement for proper driving procedure and are not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction driver will move to ensure it is safe to change lanes. Never rely solely on the Blind Spot Warning system.
- The Blind Spot Warning system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Blind Spot Warning system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect and activate Blind Spot Warning when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - Several types of vehicles such as motorcycles.
 - Oncoming vehicles.
 - Vehicles remaining in the detection zone when driver accelerates from a stop.
 - A vehicle merging into an adjacent lane at a speed approximately the same as vehicle.
 - A vehicle approaching rapidly from behind.
 - Another vehicle which overtakes this vehicle rapidly.
- Severe weather or road spray conditions may reduce the ability of the rear view camera to detect other vehicles.
- The rear view camera detection zone is designed based on a standard lane width. When driving in a wider lane, the rear view camera may not detect vehicles in an adjacent lane. When driving in a narrow lane, the rear view camera may detect vehicles driving two lanes away.
- The rear view camera is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.

PRECAUTIONS FOR BLIND SPOT WARNING

- Do not use the Blind Spot Warning system under the following conditions because the system may not function properly:
 - During bad weather (e.g., rain, fog, snow, wind, etc.)
 - When driving on slippery roads, such as on ice or snow, etc.
 - When driving on winding or uneven roads.
 - When there is a lane closure due to road repairs.
 - When driving in a makeshift lane.
 - When driving on roads where the lane width is too narrow.
 - When driving with a tire that is not within normal tire conditions (e.g., tire wear, low tire pressure, installation of spare tire, tire chains, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.
- The rear view camera may not detect lane markers in the following situations and the Blind Spot Warning system may not operate properly:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; nonstandard lane markers; lane markers covered with water, dirt, snow, etc.
 - On roads where discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs.
 - On roads where the traveling lane merges or separates.
 - When the vehicle traveling direction does not align with the lane markers.
 - When rain, snow or dirt adheres to the lens of a the rear view camera unit.
 - When a sudden change in brightness occurs. (e.g., when the vehicle enters or exits a tunnel or under a bridge.)
 - When steering quickly.
 - When the hazard warning flashers are operated.
 - When driving on a curve at a high speed.

CONTROL UNIT

< REMOVAL AND INSTALLATION >


[BSW]

REMOVAL AND INSTALLATION

CONTROL UNIT

Exploded View

INFOID:000000008942913



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation - Rear View Camera Washer Control Unit

INFOID:000000008942915

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33. "TRUNK LID FINISHER: Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[BSW]


WARNING SYSTEMS SWITCH

Removal and Installation


INFOID:000000008527308

REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-21. "Removal and Installation"](#).
2. Remove screws (←) that retain the upper switch carrier (1) to the instrument lower panel LH (2).



3. Release upper tab (B) and lower tab (C) using a suitable tool (A), then remove the warning system switch (4) from the upper switch carrier.
 - (1) Trunk opener switch
 - (2) VDC switch
 - (3) Heated steering wheel switch



INSTALLATION

Installation is in the reverse order of removal.

BSW INDICATOR


< REMOVAL AND INSTALLATION >

[BSW]

BSW INDICATOR

Exploded View

INFOID:000000008479999



1. Blind spot warning indicator 2. Front door 3. Door mirror corner finisher
A. Blind spot warning indicator harness connector ⇐ Front

NOTE:

LH side shown; RH side similar.

Removal and Installation

INFOID:000000008480000

REMOVAL AND INSTALLATION

Removal

1. Remove the front door finisher. Refer to [MIR-20. "Removal and Installation"](#).
2. Remove the door mirror corner finisher using a suitable tool.
3. Remove the blind spot warning indicator screws.
4. Remove the blind spot warning indicator.

Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

[BSW]


REAR VIEW CAMERA

Removal and Installation

INFOID:000000008527309

REMOVAL

1. Remove trunk lid finisher. Refer to [INT-33. "Exploded View"](#).
2. Disconnect the harness connector (A) from rear view camera.
3. Push the rear view camera (1) in direction shown (←) and pull out to remove.



INSTALLATION

Installation is in the reverse order of removal.

AIR PUMP


< REMOVAL AND INSTALLATION >

[BSW]

AIR PUMP

Exploded View

INFOID:000000008942916



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation

INFOID:000000008942917

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tube from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor assembly (1).



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008726197

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000008599598

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000008480007

ITS communication uses a twisted pair line. Be careful when repairing it.

PRECAUTIONS


[MOD]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PREPARATION

< PREPARATION >

[MOD]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000008542323

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components



AWJIA04832Z

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[MOD]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000008932605



AL01A01522Z

- | | | |
|--|---|--|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit (center display) | 14. ITS control unit (view with center console removed) | 15. Steering angle sensor (view with steering wheel removed) |

Component Description

INFOID:000000008660113

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[MOD]

Component	Description
ITS control unit	<ul style="list-style-type: none"> • Being connected with rear view camera via ITS communication, receives vehicle detection signal and transmits Moving Object Detection indicator signal and Moving Object Detection indicator dimmer signal to rear view camera • Being connected with rear view camera unit via ITS communication, receives detected rear condition signal • Receives steering angle sensor signal from steering angle sensor via CAN communication • Judges a Moving Object Detection indicator ON/OFF state and an approach state to the rear proximity of the vehicle. • Activates the warning buzzer and warning systems ON indicator • Transmits Moving Object Detection lamp signal to combination meter via CAN communication
Blind Spot Warning indicator LH/RH	Receives Moving Object Detection indicator operation signal from rear view camera and turns OFF, turns ON or blinks
Warning system switch	Inputs the switch signal to ITS control unit
Warning system switch indicator (on the warning systems switch)	Indicates Moving Object Detection system status
Rear view camera	<ul style="list-style-type: none"> • Detects the lane marker by the built-in camera • Transmits detected lane condition signal to ITS control unit
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication
Buzzer (combination meter)	Receives buzzer signal from ITS control unit via CAN and sounds buzzer.
Combination meter (vehicle information display)	<ul style="list-style-type: none"> • Turns the Moving Object Detection (MOD) warning indicator ON/OFF according to the signals from the ITS control unit via CAN communication • Receives MOD ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication • Transmits dimmer signal to ITS control unit via CAN communication
ECM	Transmits engine speed signal to ITS control unit via CAN communication
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the center display
Center display	Displays the various system screen signals according to the priority level received via CAN communication
Rear view camera washer control unit	Controls the air pump to drive air to the rear camera lens according to the signals received from the ITS control unit
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the pump control unit

SYSTEM

< SYSTEM DESCRIPTION >


[MOD]

SYSTEM

System Description

INFOID:000000008660114

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name	Description
ECM	CAN communication	Engine speed signal Receives engine status
BCM	CAN communication	Door open status signal Receives door open status
		Light status signal Receives light status
		Turn signal Receives turn signal status
Washer level switch	Hard wire	Washer fluid level status
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal Receives wheel speed
TCM	CAN communication	Shift selector position signal Receives shift selector position
Combination meter	CAN communication	Moving Object Detection ON/OFF signal Receives the ON/OFF status for Moving Object Detection function
Rear view camera	NTSC	Video signal Receives the Rear View Camera image from camera for Moving Object Detection function in ITS controller

Output Signal Item

SYSTEM


< SYSTEM DESCRIPTION >

[MOD]


Reception unit	Signal name		Description
Combination meter	CAN communication	Buzzer Request	Transmits a buzzer request signal when a moving object is detected.
Display	CAN communication	Visual signal request	Transmits a visual signal request from the ITS controller to display Rear View while the shift selector is in R (reverse).

FUNCTION DESCRIPTION


- The Moving Object Detection (MOD) system can help alert the driver of approaching vehicles or rear objects when the driver is backing out of a parking space.
- The MOD system comprises of the rear view camera as the main detection system, which is located on the trunk as illustrated.
- The MOD system operates at speeds below 8 km/h (5 MPH) whenever the vehicle is in R (reverse).



- The MOD system uses the rear view camera to detect approaching moving objects from either side.



- The MOD system can detect moving objects on either side as close as rear obstacles of up to approximately 3 m (10 feet).



MOVING OBJECT DETECTION SYSTEM OPERATION DESCRIPTION

- ITS control unit enables Moving Object Detection system.
- Combination meter turns Moving Object Detection ON indicator lamp ON/OFF according to the signals from ITS control unit via CAN communication.
- ITS control unit starts the control as follows, based on a vehicle detection signal.

Operation Condition of Moving Object Detection System

ITS control unit performs the control when the following conditions are satisfied:

- Moving Object Detection ON indicator: ON
- When the vehicle is moving in R (reverse) at 8 km/h (5 MPH) or less.

NOTE:

- When the Moving Object Detection system setting on the Vehicle Information Display is ON.

SYSTEM

< SYSTEM DESCRIPTION >

[MOD]

- Moving Object Detection braking will not operate or will stop operating and only a warning chime will sound under the following conditions:
 - When driving with a tire that is not within normal tire conditions (pressure, wear, chain, spare, etc.)
 - When the vehicle is equipped with non-original brake parts or suspension parts.
- Do not use the MOD system when towing a trailer.
- Excessive noise such as the audio system will interfere with the chime sound, and it may not be heard.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

OPERATION

< SYSTEM DESCRIPTION >

[MOD]

OPERATION

System Display and Warning

INFOID:000000008660118

INDICATOR AND WARNING LAMP

The MOD system can be turned ON or OFF for the current ignition cycle using the warning system switch. When toggled between ON and OFF, the indicator will appear on the right side of the rear view camera screen.

No.	Name	Description
1	MOD indicator (blue)	<ul style="list-style-type: none"> • Turns ON while MOD system is ON • Under the following conditions, the MOD indicator (blue) will blink. <ul style="list-style-type: none"> - When the VDC system (except TCS function) or ABS operates. - When the VDC system is turned off.
	MOD warning lamp (orange)	<ul style="list-style-type: none"> • Turns ON when MOD system is malfunctioning • Blinks under the following conditions: <ul style="list-style-type: none"> - When the component temperature reaches high level. - When rear view camera blockage is detected.

DISPLAY AND WARNING OPERATION

Vehicle condition/Driver's operation				
Moving Object Detection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area	Indication on the Moving Object Detection indicator	Buzzer
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
	Approx. 8 km/h (5 MPH) or more	Vehicle is absent	ON	OFF
		Vehicle is detected	ON	OFF
		Vehicle is not detected	ON	OFF

HANDLING PRECAUTION

Precautions for Moving Objects Detection

INFOID:000000008660119

REAR VIEW CAMERA HANDLING

- The rear view camera which is located on the back of the trunk performs the Moving Object Detection system.
- Always keep the rear view camera lens clean.
- Do not attach a sticker (including transparent material), install an accessory or paint work over the camera lens.
- Do not strike or scratch the lens causing physical damage to the camera or the surrounding area.

MOVING OBJECT DETECTION

- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather conditions could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect and activate Moving Object Detection when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - A vehicle passing at a speed greater than approximately 15 MPH (24km/h).
 - Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- Do not use the MOD system under the following conditions because the system may not function properly:
 - When driving with a tire that is not within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MOD]

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000008842033

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit
Data Monitor	Displays ITS control unit input/output data in real time
Work support	Displays causes of automatic system cancellation occurred during system control
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load
ECU identification	Displays ITS control unit part number
Configuration	The vehicle specification can be written when replacing the ITS control unit

SELF DIAGNOSTIC RESULT

Refer to [DAS-86. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication)
REVERSE SIGNAL [On/Off]	Indicates [On/Off] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication)
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication]
CAMERA SWITCH SIGNAL [On/Off]	Indicates [On/Off] status of camera switch signal as judged from ITS control unit
CAMERA OFF SIGNAL [On/Off]	Indicates [On/Off] status of camera OFF signal as judged from ITS control unit
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling")
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2)
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD)
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines
WASH SW [ON/OFF]	Indicates the state of the wash switch indicator output
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit
ILL [On/Off]	Indicates [On/Off] status of the illumination signal
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MOD]

Monitored item [Unit]	Description
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output
Rear Camera Image Output signal [OK/NG]	Indicates the input state of video image from rear camera
ITS SW_2 [ON/OFF/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit
ITS SW_2 IND [ON/OFF/No setting]	Indicates the state of the warning system secondary switch indicator output

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view
REAR CAMERA ITS	Displays and sets camera image calibration values
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description
WASH ACTIVE	ON
	OFF
LED LH	ON
	OFF
LED RH	ON
	OFF
AIR ACTIVE	ON
	OFF
AIR & WASH ACTIVE	ON
	OFF

BSW ON INDICATOR

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MOD]

Test item	Operation	Description	Blind Spot Warning ON indicator lamp (Yellow)
BSW ON INDICATOR	Off	Stops transmitting the Blind Spot Warning ON indicator signal below to end the test	Off
	On	Transmits the Blind Spot Warning ON indicator signal to the warning lamp on the door	ON
Washer	Off	Stops transmitting activate signal to washer below to end the test	Off
	On	Transmits activate signal to washer	ON
Air pump	Off	Stops transmitting activate signal to air pump below to end the test	Off
	On	Transmits activate signal to air pump	ON

ECU IDENTIFICATION

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:000000008842077

VALUES ON THE DIAGNOSIS TOOL


Monitor item	Condition		Value/Status
STEERING ANGLE	Ignition switch ON	Steering angle signal is received	On
		Steering angle signal is not received	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse)	On
		Shift selector is not in R (reverse)	Off
VEHICLE SPEED	While driving	Vehicle speed signal is received	On
		Vehicle speed signal is not received	Off
CAMERA SWITCH	Ignition switch ON	Camera switch is pressed	On
		Camera switch is not pressed	Off
CAMERA OFF SWITCH	Ignition switch ON	Purpose switch is pressed	On
		Purpose switch is not pressed	Off
TYPE OF STEER ANGLE SENSOR	Ignition switch ON	Steering angle sensor type is displayed	Absolute
		Steering angle sensor type is not received	Not
TYPE OF STEER GEAR RATIO	Ignition switch ON	Pattern 1 type of steering gear ratio displayed	Pattern 1
		Pattern 2 type of steering gear ratio displayed	Pattern 2
LEFT OR RIGHT STEER	Ignition switch ON	It recognizes steering position is left	LHD
		It recognizes steering position is right	RHD
REAR CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK	OK
		Rear camera serial status is not OK	NG
REAR CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received	OK
		Rear camera serial communication signal is not received	NG
ILL	Ignition switch ON	Illumination is ON	On
		Illumination is OFF	Off
ITS SW_1	Ignition switch ON	ITS switch is pressed	On
		ITS switch is not pressed	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting	On
		Indicator of ITS switch 1 is not lighting	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received	Left
		Turn signal neutral is received	N
		Turn signal right is received	Right
R-CAMERA IMAGE	Ignition switch ON	Camera image signal is received	On
		Camera image signal is not received	Off
ITS SW_2	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed	No setting
WASH SWITCH SIGNAL	Ignition switch ON	Wash switch signal is pressed	On
		Wash switch signal is not pressed	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received	On
		Pump communication signal is not received	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (Y)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (LG)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN -L	—	—	—	—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (BR)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN -H	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (re- verse)	12 V
					Shift selector not in R (re- verse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—	—	0 V
50, 53	Ground	Shield	—	—	—	0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON	—	0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	

Fail-safe

INFOID:000000008842078

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on camera screen)	Cancel

DTC Inspection Priority Chart

INFOID:000000008842079

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

DTC Index

INFOID:000000008842080

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010)
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-249
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-250
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-251
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-252
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-253
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-254
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-255
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-256
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-257
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-259
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-260
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-261
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-262
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-265
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-266

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- P

DAS


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000008674517





AAOWA0012GB

DRIVER ASSISTANCE SYSTEM CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-

Terminal No.	Color of Wire	Signal Name
1G	LG	-

Terminal No.	Color of Wire	Signal Name
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AA0IA0040GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK


Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H

Connector No.	M15
Connector Name	WIRE TO WIRE
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
2	G	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
4	GR	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
109	G	REVERSE SIGNAL

AA0IA0041GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AA0IA0042GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	BG	-
4	B	-
5	G	-
6	P	-
7	-	-
8	B	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA (SHIELD)

AA01A0043GB


DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Terminal No.	Color of Wire	Signal Name
1G	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	– (WITH REAR VIEW CAMERA)

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	–

Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
74	V	WASH MTR

AA0IA0044GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	-	-
3	-	-
4	B	-

AA0IA0050GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[MOD]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008842016

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-240, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[MOD]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-242, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform MOD system action test to check the operation status. Refer to [DAS-243, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-20, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-132, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform MOD system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000008842017

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

[MOD]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using MOD				
	<input type="checkbox"/> All functions do not operate.				
	<input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator)				
	<input type="checkbox"/> Yawing function does not operate. (Warning function is operated.)				
	<input type="checkbox"/> Functions when changing the course in the turn signal direction.				
<input type="checkbox"/> Functions are untimely.					
<input type="checkbox"/> Does not function when driving on lane markers.					
<input type="checkbox"/> Functions when driving in a lane.					
<input type="checkbox"/> Functions in a different position from the actual position.					
<input type="checkbox"/> Others ()					
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[MOD]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000008842018

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-245. "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26. "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[MOD]

ACTION TEST

Description

INFOID:000000008945583

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-79, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000008842020

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-70, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-74, "System Description"](#).
 - System description for BSW: Refer to [DAS-146, "System Description"](#).
 - System description for MOD: Refer to [DAS-219, "System Description"](#).
 - Handling precaution: Refer to [DAS-223, "Precautions for Moving Objects Detection"](#).

1. CHECK MOD SYSTEM SETTING

1. Start the engine.
2. Check that the MOD system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR MOD

1. Enable the setting of the MOD system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the MOD operation according to the following table.

Vehicle condition/ Driver's operation			Vehicle response	
Moving Object De- tection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area	Indication on the Moving Object Detection indicator	Buzzer
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
		Vehicle is absent	ON	OFF
	Approx. 8 km/h (5 MPH) or more	Vehicle is detected	ON	OFF
		Vehicle is not detected	ON	OFF

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle reaches a higher speed. Refer to [DAS-74, "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[MOD]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000008842021

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000008842022

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment with CONSULT. Refer to [DAS-245, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of rear view camera with CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-86, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-243, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform WASH ACTIVE on Active Test using CONSULT.

2. Perform air and washer tube connection check by AIR & WASH ACTIVE on Active Test:

- (1) Washer fluid output count on the rear view camera is 3 to 5 times → OK
- (2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking
- (3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking
- (4) No washer fluid output → Check tube with blue marking or check valve

>> Inspection End.

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000008842023

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the **CONSULT** when performing the calibration. (Rear view camera calibration cannot be operated without **CONSULT**).

Work Procedure (Preparation)

INFOID:000000008842024

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of the ITS control unit.

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-86. "DTC Index"](#).

"U1308" or no DTC>> GO TO 2.

2. PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the ITS control unit by CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-242. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3. PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

>> Refer to [DAS-246. "Work Procedure \(Target Setting\)".](#)


Work Procedure (Target Setting)

INFOID:000000008842025

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B" – "E" ("D" – "F") 2125 mm (83.66 in)

:

Left distance (L_d): "Ct" – "Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct" – "Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".


9. Position the center of the target mark to point of "Ct".



REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-247. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000008842026


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-245. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" with CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".
4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
 - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-246, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none">Temporary malfunction in internal processing of the rear view camera.Rear view camera malfunction.	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none">A target is not-yet-placed. (The rear view camera cannot detect a target.)The position of the rear view camera is not correct.	Position the target appropriately again. Perform the aiming again. Refer to DAS-245, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none">Inappropriate work environment.Inappropriate vehicle condition.	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of ITS control unit with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-20, "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-243, "Description"](#).

>> Work End.

C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000008841937

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841938

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000008841941

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841942

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" with CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841945

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-249, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841946

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-44, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" with CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-127, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000008841949

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841950

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000008841953

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-252, "Diagnosis Procedure"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008841954

1. CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-123, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841956

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U0428	ST ANGLE SENSOR CALIBRATION [U0428]	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000008841957

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When U1232 is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008841958

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:000000008841959

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:000000008841960

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-46, "Description"](#).
NO >> Refer to [GI-47, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000008841961

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000008841962

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis	ITS control unit

Diagnosis Procedure

INFOID:000000008841963

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
- NO >> Inspection End.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000008841965

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted	Check rear camera image signal circuit between rear camera and around view monitor control unit.

Diagnosis Procedure

INFOID:000000008841966

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK CONTINUITY REAR CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear camera connector.
- Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE REAR CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit			
Connector	Terminal		
M59	52	Ground	"CAMERA" switch is ON or shift selector is in R (Reverse) 6.2 V

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK CONTINUITY REAR CAMERA IMAGE SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit connector and rear camera connector.
3. Check for continuity between ITS control unit harness connector and rear camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		


Is inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK REAR CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	 <p>(V)</p> <p>1</p> <p>0</p> <p>-1</p> <p>← 40 µs</p> <p>AL01A01792Z</p>

Is inspection result normal?

YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000008841968

DTC	Display contents of CONSULT	DTC detection condition	Possible malfunction factor
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:000000008841969

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" with CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000008841970

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete	Perform ITS configuration with CONSULT

Diagnosis Procedure

INFOID:000000008841971

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000008841972

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB [U1308]	ITS control unit calibration is incomplete	Perform ITS calibration with CONSULT

Diagnosis Procedure

INFOID:000000008841973

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-224, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-47, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000008841976

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-262, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841977

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	12 V
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1309 PUMP UNIT CURRENT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4.CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000008841980

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841981

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
NO >> Replace rear view camera. Refer to [DAS-139, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000008841986

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-266, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008841987

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA AIR PUMP MOTOR POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA AIR PUMP MOTOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

YES >> Replace rear view camera washer control unit.

NO >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008841991

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition switch	Battery voltage
Connector	Terminal		
M58	20	OFF	Battery voltage
		ON	Battery voltage
	39	OFF	0 V
		ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000008932661

1.CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the DATA MONITOR item "ITS SW 1" of "AVM" with CONSULT.
3. With operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	OFF

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-270. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932662

Regarding Wiring Diagram information, refer to [DAS-22. "Wiring Diagram"](#).

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	
Connector	Terminal		
M58	32		
		Pressed	0 V
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66. "Removal and Installation - ITS Control Unit"](#).
NO >> GO TO 2.

2.CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-271. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-138. "Removal and Installation"](#).

3.CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000008932663

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

DAS

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Component Function Check

INFOID:000000008932664

1. CHECK WARNING SYSTEMS ON INDICATOR

1. Turn the ignition switch ON.
2. Select the active test item "BSW ON INDICATOR" of "AVM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning systems ON indicator illuminates

Off : Warning systems ON indicator is turned OFF

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-272, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932665

Regarding Wiring Diagram information, refer to [DAS-22, "Wiring Diagram"](#).

1. CHECK WARNING ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground Battery voltage
Connector	Terminal	
M62	5	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

ITS control unit		Ground	Continuity
Connector	Terminal		
58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-273, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace warning systems switch. [DAS-138, "Removal and Installation"](#).

Component Inspection

INFOID:000000008932666

1.CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-138, "Removal and Installation"](#).

WARNING BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

WARNING BUZZER CIRCUIT

Component Function Check

INFOID:000000008932667

1. CHECK WARNING BUZZER

1. Turn the ignition switch ON.
2. Select the active test item "BUZZER" of "BCM" with CONSULT.
3. With operating the test item, check the operation.

On : Warning buzzer is activated.

Off : Warning buzzer is not activated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-274, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008932668

1. CHECK WARNING BUZZER OPERATION

While activating the buzzer with CONSULT, listen for the buzzer sound.

Does warning buzzer sound?

YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).

NO >> Replace the combination meter (buzzer).

MOD SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[MOD]

SYMPTOM DIAGNOSIS

MOD SYSTEM SYMPTOMS

Symptom Table

INFOID:000000008660302

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

NOTE:

Refer to the following the operation condition of the Moving Object Detection system.

- Moving Object Detection system: [DAS-219, "System Description"](#).

Symptom		Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	All of indicator/warning lamps do not illuminate; <ul style="list-style-type: none">• Moving Object Detection warning lamp• Moving Object Detection ON indicator• Warning systems ON indicator	<ul style="list-style-type: none">• Power supply and ground circuit of ITS control unit• ITS control unit• Combination meter	Power supply and ground circuit of ITS control unit. Refer to DAS-60, "Diagnosis Procedure"
	Buzzer is not sounding	<ul style="list-style-type: none">• Buzzer (combination meter)	Refer to DAS-65, "Component Function Check"

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

MOD SYSTEM DOES NOT ACTIVATE

< SYMPTOM DIAGNOSIS >

[MOD]

MOD SYSTEM DOES NOT ACTIVATE

Description

INFOID:000000008660303

The switch does not turn ON

- When the Moving Object Detection system setting is ON, the Moving Object Detection ON indicator does not illuminate even if the warning system switch is depressed.

The switch does not turn OFF

- The Moving Object Detection ON indicator does not turn off even if the warning system switch is pressed when the Moving Object Detection ON indicator illuminates.

Diagnosis Procedure

INFOID:000000008660304

1. CHECK MOVING OBJECT DETECTION SYSTEM SETTING

1. Start the engine.
2. After starting the engine wait for 5 seconds or more.
3. Check that Moving Object Detection system setting on the navigation screen is ON.

Is Moving Object Detection system setting ON?

- YES >> GO TO 2.
NO >> Enable the Moving Object Detection system setting.

2. MOD SWITCH INSPECTION

1. Start the engine.
2. Check that "mod SW" operates normally in "DATA MONITOR" of "AVM" with CONSULT.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 5.

3. CHECK MOVING OBJECT DETECTION ON INDICATOR CIRCUIT

1. Start the engine.
2. Select the active test item "MOD ON IND" of "AVM" with CONSULT.
3. Check if the Moving Object Detection ON indicator illuminates when the test item is operated.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 4.

4. PERFORM THE SELF-DIAGNOSIS OF COMBINATION METER

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "METER/M&A". Refer to [MWI-27, "DTC Index"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 6.

5. PERFORM THE SELF-DIAGNOSIS

1. Perform "All DTC Reading" with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "AVM". Refer to [DAS-20, "DTC Index"](#).

Is any DTC detected?

- YES >> GO TO 6.
NO >> GO TO 7.

6. REPAIR OR REPLACE MALFUNCTIONING PARTS.

Repair or replace malfunctioning parts.

>> GO TO 7.

7. CHECK MOVING OBJECT DETECTION SYSTEM

MOD SYSTEM DOES NOT ACTIVATE

< SYMPTOM DIAGNOSIS >

[MOD]

1. Erase “self-diagnosis result”, and then perform “All DTC Reading” again after performing the action test.
(Refer to [DAS-243, "Description"](#) for action test.)
2. Check that the Moving Object Detection system is normal.

A

>> Inspection End.

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[MOD]

MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:000000008660305

- Moving Object Detection system setting is not selectable on the vehicle information display screen.

NOTE:

When the ignition switch is in ACC position, Moving Object Detection system settings cannot be changed.

- "Moving Object Detection" is not indicated on the vehicle information display screen.
 - The switching between ON and OFF cannot be performed by operating the vehicle information display setting system selection.
 - The item "Moving Object Detection" on the vehicle information display screen is not active.
- The Moving Object Detection system setting differs from the one set at the previous driving.

NOTE:

Turn OFF the ignition switch and wait for 5 seconds or more.

Diagnosis Procedure

INFOID:000000008660306

1. CHECK MOVING OBJECT DETECTION SYSTEM SETTING

1. Start the engine.
2. Check that the Moving Object Detection system settings is selectable on the vehicle information display screen.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

1. Perform self-diagnosis with CONSULT.
2. Check if the DTC is detected in self-diagnosis results of "AVM", "MULTI AV" and "METER/M&A". Refer to the following.
 - AVM: [DAS-20, "DTC Index"](#)
 - MULTI AV (with BOSE): [AV-309, "DTC Index"](#)
 - MULTI AV (without BOSE): [AV-216, "DTC Index"](#)
 - METER/M&A: [MWI-27, "DTC Index"](#)

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> Inspection End.

3. CHECK DATA MONITOR OF ITS CONTROL UNIT

Check that "MOD SELECT" operates normally in "DATA MONITOR" of "AVM" with CONSULT.

Is the inspection result normal?

- YES >> Refer to [DAS-14, "CONSULT Function \(AVM\)"](#).
- NO >> GO TO 4.

4. CHECK MULTIFUNCTION SWITCH

Operate the multifunction switch to check that the audio, navigation system, and air conditioner operate properly.

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-66, "Removal and Installation - ITS Control Unit"](#).
- NO >> Repair or replace malfunctioning parts.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[MOD]

NORMAL OPERATING CONDITION

Description

INFOID:000000008660307

MOVING OBJECT DETECTION

- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather condition could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
 - Pedestrians, bicycles, animals.
 - A vehicle passing at a speed greater than approximately 24km/h (15 MPH).
- A rear view camera may not detect approaching vehicles in certain situations:
 - When the vehicle parked aside obstruct the beam of the rear view camera.
 - When the vehicle is parked in an angled parking space.
 - When the vehicle is parked on an inclined ground.
 - When the vehicle turns around into your vehicle's aisle.
 - When the angle formed by your vehicle and approaching vehicle is small.
- Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- The rear view camera system may not detect:
 - Small or moving object.
 - Wedge-shaped objects.
 - Object closer to the bumper than 30 cm (10 inch).
 - Thin objects such as rope, wire, chain, etc.
- Do not use the MOD system under the following conditions because the system may not function properly:
 - When driving with a tire that is not the within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

CONTROL UNIT

< REMOVAL AND INSTALLATION >


[MOD]

REMOVAL AND INSTALLATION

CONTROL UNIT

Exploded View

INFOID:000000008942918



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation - Rear View Camera Washer Control Unit

INFOID:000000008942920

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33. "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



Installation

Installation is in the reverse order of removal.

AIR PUMP


< REMOVAL AND INSTALLATION >

[MOD]

AIR PUMP

Exploded View

INFOID:000000008942921



1. Trunk lid - reinforcement

2. Trunk lid - outer

3. Rear view camera air pump motor assembly

4. Rear view camera washer control unit

← : Front


Removal and Installation

INFOID:000000008942922

REMOVAL AND INSTALLATION

Removal

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tube from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor assembly (1).



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS