

NISSAN
STANZA
ALTIMA
MODEL U13 SERIES

QUICK REFERENCE INDEX

GENERAL INFORMATION _____	GI
MAINTENANCE _____	MA
ENGINE MECHANICAL _____	EM
ENGINE LUBRICATION AND COOLING SYSTEMS _____	LC
ENGINE FUEL AND EMISSION CONTROL SYSTEM _____	EF & EC
ACCELERATOR CONTROL, FUEL AND EXHAUST SYSTEMS _____	FE
CLUTCH _____	CL
MANUAL TRANSAXLE _____	MT
AUTOMATIC TRANSAXLE _____	AT
FRONT AXLE & FRONT SUSPENSION _____	FA
REAR AXLE & REAR SUSPENSION _____	RA
BRAKE SYSTEM _____	BR
STEERING SYSTEM _____	ST
BODY _____	BF
HEATER & AIR CONDITIONING _____	HA
ELECTRICAL SYSTEM _____	EL

FOREWORD

This manual contains maintenance and repair procedures for the 1993 Nissan STANZA ALTIMA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN NORTH AMERICA, INC.

Technical Information Department

Torrance, California

GENERAL INFORMATION

SECTION **GI**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

PRECAUTIONS	2	Model Variation	14
Precautions for Supplemental Restraint System		Prefix and suffix designations:.....	14
“AIR BAG”	2	Identification Number	15
General Precautions	2	Vehicle Identification Number Arrangement.....	15
Precautions for Multiport Fuel Injection System		Engine Serial Number	16
or ECM Controlled Engine	4	Manual Transaxle Number	16
Precautions for Three Way Catalytic Converter	4	Automatic Transaxle Number	16
Precautions for Fuel.....	4	Dimensions.....	17
HOW TO USE THIS MANUAL	5	Wheels and Tires	17
HOW TO READ WIRING DIAGRAMS	7	LIFTING POINTS AND TOW TRUCK TOWING	18
Wiring Diagram	7	Preparation	18
Switch Positions.....	7	Special Service Tools.....	18
Connector Symbols	8	Board-on Lift.....	19
Multiple Switch.....	8	Garage Jack and Safety Stand	19
Super Multiple Junction (SMJ).....	9	2-pole Lift.....	20
HOW TO FOLLOW FLOW CHART IN TROUBLE		Tow Truck Towing	20
DIAGNOSES	10	Towing An Automatic Transaxle Model With	
Notice	10	Four Wheels On Ground.....	21
How To Follow This Flow Chart	11	Towing An Automatic Transaxle Model With	
Direction mark	11	Rear Wheels Raised (With front wheels on	
Key to symbols signifying measurements		ground).....	21
or procedures.....	12	Towing Point.....	21
CONSULT CHECKING SYSTEM	13	TIGHTENING TORQUE OF STANDARD BOLTS	22
Function and System Application.....	13	GLOSSARY	23
Lithium Battery Replacement	13	The “Glossary of Acronyms” and the “Glossary	
Checking Equipment.....	13	of Technical Terms and Component Part	
IDENTIFICATION INFORMATION	14	Names” Related to SAE J1930.....	23

PRECAUTIONS

Observe the following precautions to ensure safe and proper servicing. These precautions are not described in each individual section.





Precautions for Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cables. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".






General Precautions

1. Do not operate the engine for an extended period of time without proper exhaust ventilation. Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials. Do not smoke while working on the vehicle.
2. Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting and towing before working on the vehicle. These operations should be done on a level surface.
3. When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.

PRECAUTIONS

General Precautions (Cont'd)



4. Before starting repairs which do not require battery power, always turn off the ignition switch, then disconnect the battery negative cable from the battery to prevent accidental short circuit.
5. To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe and muffler. Do not remove the radiator cap when the engine is hot.
6. Before servicing the vehicle, protect fenders, upholstery and carpeting with appropriate covers. Take caution that keys, buckles or buttons on your person do not scratch the paint.
7. Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
8. Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
9. Replace inner and outer races of tapered roller bearings and needle bearings as a set.
10. Arrange the disassembled parts in accordance with their assembled locations and sequence.
11. Do not touch the terminals of electrical components which use microcomputers (such as electronic control module). Static electricity may damage internal electronic components.
12. After disconnecting vacuum or air hoses, attach a tag to indicate the proper connection.
13. Use only the lubricants specified in MA section.
14. Use approved bonding agent, sealants or their equivalents when required.
15. Use tools and recommended special tools where specified for safe and efficient service repairs.
16. When repairing the fuel, oil, water, vacuum or exhaust systems, check all affected lines for leaks.
17. Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

PRECAUTIONS



Precautions for Multiport Fuel Injection System or ECM Controlled Engine

1. Before connecting or disconnecting multiport fuel injection system or ECM (ECCS control module) harness connector to or from any multiport fuel injection system or ECM, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal. Otherwise, there may be damage to ECM.
2. Before disconnecting pressurized fuel line from fuel pump to injectors, be sure to release fuel pressure to eliminate danger.
3. Be careful not to jar components such as ECM and mass air flow sensor.

Precautions for Three Way Catalytic Converter

If a large amount of unburned fuel flows into the converter, the converter temperature will be excessively high. To prevent this, follow the procedure below:

1. Use unleaded gasoline only. Leaded gasoline will seriously damage the three way catalytic converter.
2. When checking for ignition spark or measuring engine compression, make tests quickly and only when necessary.
3. Do not run engine when the fuel tank level is low, otherwise the engine may misfire causing damage to the converter.
4. Do not place the vehicle on inflammable material. Keep inflammable material off the exhaust pipe.

Precautions for Fuel

Use unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (research octane number 96). If unleaded premium gasoline is not available, unleaded regular gasoline with an octane rating of at least 87 AKI (research octane number 91) can be used.


However, for maximum vehicle performance, the use of unleaded premium gasoline is recommended.

CAUTION:

Do not use leaded gasoline. Using leaded gasoline will damage the three way catalytic converter.

HOW TO USE THIS MANUAL









1. **A QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find each section by mating it to the section's black tabs.
2. **THE CONTENTS** are listed on the first page of each section.
3. **THE TITLE** is indicated on the upper portion of each page and shows the part or system.
4. **THE PAGE NUMBER** of each section consists of two letters which designate the particular section and a number (e.g. "BR-5").
5. **THE LARGE ILLUSTRATIONS** are exploded views (See below) and contain tightening torques, lubrication points and other information necessary to perform repairs. The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.



6. **THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations. Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.

HOW TO USE THIS MANUAL

7. The following **SYMBOLS AND ABBREVIATIONS** are used:

	:	Tightening torque	M/T	:	Manual Transaxle/Transmission
	:	Should be lubricated with grease. Unless otherwise indicated, use recommended multi-purpose grease.	A/T	:	Automatic Transaxle/Transmission
	:	Should be lubricated with oil.	Tool	:	Special Service Tools
	:	Sealing point	LHD	:	Left-Hand Drive
	:	Checking point	RHD	:	Right-Hand Drive
	:	Always replace after every disassembly.	ATF	:	Automatic Transmission Fluid
	:	Apply petroleum jelly.	D ₁	:	Drive range 1st gear
	:	Apply ATF	D ₂	:	Drive range 2nd gear
★	:	Select with proper thickness.	D ₃	:	Drive range 3rd gear
☆	:	Adjustment is required.	D ₄	:	Drive range 4th gear
SDS	:	Service Data and Specifications	OD	:	Overdrive
LH, RH	:	Left-Hand, Right-Hand	2 ₂	:	2nd range 2nd gear
			2 ₁	:	2nd range 1st gear
			1 ₂	:	1st range 2nd gear
			1 ₁	:	1st range 1st gear

8. The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.

“Example”

Tightening torque:

59 - 78 N·m (6.0 - 8.0 kg-m, 43 - 58 ft-lb)

9. **TROUBLE DIAGNOSES** are included in sections dealing with complicated components.


10. **SERVICE DATA AND SPECIFICATIONS** are contained at the end of each section for quick reference of data.

11. The captions **WARNING** and **CAUTION** warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.

- **WARNING** indicates the possibility of personal injury if instructions are not followed.
- **CAUTION** indicates the possibility of component damage if instructions are not followed.
- **BOLD TYPED STATEMENTS** except **WARNING** and **CAUTION** give you helpful information.

HOW TO READ WIRING DIAGRAMS


Example



CONNECTOR SYMBOLS

- All connector symbols in wiring diagrams are shown from the terminal side.

Example




- Male and female terminals
Connector guides for male terminals are shown in black and female terminals in white in wiring diagrams.

MULTIPLE SWITCH

The continuity of the multiple switch is identified in the switch chart in wiring diagrams.

Example



Example: Wiper switch in LO position

Continuity circuit: Red wire - (A) terminal - (③) terminal - Wiper switch (● - ●):
LO) - (⑥) terminal - (F) terminal - Black wire



SGI365

HOW TO READ WIRING DIAGRAMS

SUPER MULTIPLE JUNCTION (SMJ)

- The "SMJ" indicated in wiring diagrams is shown in a simplified form. The terminal arrangement should therefore be referred to in the foldout at the end of the Service Manual.
- The foldout should be spread to read the entire wiring diagram.

Example






AGI012

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

Example



NOTICE

The flow chart indicates work procedures required to diagnose problems effectively. Observe the following instructions before diagnosing.


- 1) Use the flow chart after locating probable causes of a problem following the "Preliminary Check" or the "Symptom Chart".
- 2) After repairs, re-check that the problem has been completely eliminated.
- 3) Refer to Component Parts Location and Harness Layout for the Systems described in each section for identification/ location of components and harness connectors.
- 4) Refer to the Circuit Diagram for Quick Pinpoint Check. If you must check circuit continuity between harness connectors in more detail, such as when a sub-harness is used, refer to Wiring Diagram and Harness Layout in EL section for identification of harness connectors.
- 5) When checking circuit continuity, ignition switch should be "OFF".
- 6) Before checking voltage at connectors, check battery positive voltage.
- 7) After accomplishing the Diagnostic Procedures and Electrical Components Inspection, make sure that all harness connectors are reconnected as they were.

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

HOW TO FOLLOW THIS FLOW CHART

1 Work and diagnostic procedure

Start to diagnose a problem using procedures indicated in enclosed blocks, as shown in the following example.



2 Measurement results

Required results are indicated in bold type in the corresponding block, as shown below:

These have the following meanings:


Battery positive voltage → 11 - 14V or approximately 12V
Voltage: Approximately 0V → Less than 1V

3 Cross reference of work symbols in the text and illustrations

Illustrations are provided as visual aids for work procedures. For example, symbol **A** indicated in the left upper portion of each illustration corresponds with the symbol in the flow chart for easy identification. More precisely, the procedure under the "CHECK POWER SUPPLY" outlined previously is indicated by an illustration **A**.

4 Symbols used in illustrations

Symbols included in illustrations refer to measurements or procedures. Before diagnosing a problem, familiarize yourself with each symbol.



Direction mark

A direction mark is shown to clarify the side of connector (terminal side or harness side).

Direction marks are mainly used in the illustrations indicating terminal inspection.

 : View from terminal side ... T.S.

- All connector symbols shown from the terminal side are enclosed by a single line.

 : View from harness side ... H.S.

- All connector symbols shown from the harness side are enclosed by a double line.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

Key to symbols signifying measurements or procedures

Symbol	Symbol explanation	Symbol	Symbol explanation
	Check after disconnecting the connector to be measured.		Procedure with CONSULT
	Check after connecting the connector to be measured.		Procedure with CONSULT
	Insert key into ignition switch.		A/C switch is "OFF".
	Remove key from ignition switch.		A/C switch is "ON".
	Turn ignition switch to "OFF" position.		REC switch is "ON".
	Turn ignition switch to "ON" position.		REC switch is "OFF".
	Turn ignition switch to "START" position.		DEF switch is "ON".
	Turn ignition switch from "OFF" to "ACC" position.		VENT switch is "ON".
	Turn ignition switch from "ACC" to "OFF" position.		Fan switch is "ON". (At any position except for "OFF" position)
	Turn ignition switch from "OFF" to "ON" position.		Fan switch is "OFF".
	Turn ignition switch from "ON" to "OFF" position.		Apply fused battery positive voltage directly to components.
	Do not start engine, or check with engine stopped.		Drive vehicle.
	Start engine, or check with engine running.		Disconnect battery negative cable.
	Apply parking brake.		Depress brake pedal.
	Release parking brake.		Release brake pedal.
	Check after engine is warmed up sufficiently.		Depress accelerator pedal.
	Voltage should be measured with a voltmeter.		Release accelerator pedal.
	Circuit resistance should be measured with an ohmmeter.	<p>Pin terminal check for SMJ type ECM and TCM connectors. For details regarding the terminal arrangement, refer to the foldout page.</p>	
	Current should be measured with an ammeter.		

CONSULT CHECKING SYSTEM

Function and System Application

Diagnostic test mode	Function	ECCS	A/T	Air bag
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT.	X	—	—
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	X	X	X
Data monitor	Input/Output data in the ECM can be read.	X	X	—
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.	X	—	—
ECM part number	ECM part number can be read.	X	X	—
Function test	ECCS faults can be isolated to a general area, semi-automatically and in a short time, by following the directions on the screen.	X	—	—

X: Applicable

Lithium Battery Replacement

CONSULT contains a lithium battery. When replacing the battery obey the following:


WARNING:

Replace the lithium battery with SANYO Electric Co., Ltd., CR2032 only. Use of another battery may present a risk of fire or explosion. The battery may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble or dispose of in fire.

Keep the battery out of reach of children and discard used battery conforming to the local regulations.

Checking Equipment

When ordering the below equipment, contact your NISSAN distributor.


Tool name	Description
NISSAN CONSULT kit	
① CONSULT unit and accessories	
② Program card (UE920)	
③ Operation manuals	
④ Binder	
⑤ Carrying case	
⑥ Thermal paper (Rolls)	

IDENTIFICATION INFORMATION

Model Variation

Destination	Body	Engine	Grade	Transaxle					
				RS5F50A	RE4F04A				
Non-California, USA	Sedan	KA24DE	XE	BBGALHF-EUA	BBGALHA-EUA				
			XE-L	—	BBGALJA-EUA				
			SE	BBGALYF-EUA	BBGALYA-EUA				
			XE-S	BBGALBF-EUA	BBGALBA-EUA				
California, USA			Sedan	KA24DE	XE	BBGALHF-EVA	BBGALHA-EVA		
					XE-L	—	BBGALJA-EVA		
					SE	BBGALYF-EVA	BBGALYA-EVA		
					XE-S	BBGALBF-EVA	BBGALBA-EVA		
Canada					Sedan	KA24DE	XE	BBGALHF-ENA	BBGALHA-ENA
							XE-L	—	BBGALJA-ENA
							SE	BBGALYF-ENA	BBGALYA-ENA
							XE-S	BBGALBF-ENA	BBGALBA-ENA


Prefix and suffix designations:




IDENTIFICATION INFORMATION

Identification Number (Cont'd)


ENGINE SERIAL NUMBER



MANUAL TRANSAXLE NUMBER



AUTOMATIC TRANSAXLE NUMBER



IDENTIFICATION INFORMATION

Dimensions

Unit: mm (in)

Overall length	4,585 (180.5)
Overall width	1,695 (66.7)
Overall height	1,420 (55.9)
Front tread	1,465 (57.7)
Rear tread	1,455 (57.3)
Wheelbase	2,620 (103.1)

GI

MA

EM

Wheels and Tires

		Conventional	T type
Road wheel			
Steel		15 x 6JJ	15 x 4T
Aluminum		15 x 6JJ	15 x 4T
Offset	mm (in)	45 (1.77)	40 (1.57)
Tire size			
		P205/60R15 90H	T125/70D15 T135/90D15*

LC

EF &
EC

FE

CL

* With viscous L.S.D.

MT

AT

FA

RA

BR

ST

BF



HA

EL


LIFTING POINTS AND TOW TRUCK TOWING

Preparation

SPECIAL SERVICE TOOLS

Tool number Tool name	Description
LM4086-0200 Board-on lift attachment	
LM4519-0000 Safety stand attachment	

LIFTING POINTS AND TOW TRUCK TOWING



Board-on Lift

CAUTION:


Make sure vehicle is empty when lifting.

- The board-on lift attachment (LM4086-0200) set at front end of vehicle should be set on the front of the sill under the front door opening.
- Position attachments at front and rear ends of board-on lift.



Garage Jack and Safety Stand

WARNING:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands when you have to get under the vehicle.
- Place wheel chocks at both front and back of the wheels on the ground.



Use safety stand adapter as shown for stable support.



SGI737

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


LIFTING POINTS AND TOW TRUCK TOWING

2-pole Lift

WARNING:

When lifting the vehicle, open the lift arms as wide as possible and ensure that the front and rear of the vehicle are well balanced.


When setting the lift arm, do not allow the arm to contact the brake tubes and fuel lines.



Tow Truck Towing

CAUTION:

- All applicable local laws regarding the towing operation must be obeyed.
- It is necessary to use proper towing equipment to avoid possible damage to the vehicle during a towing operation.
- When towing with the rear wheels on the ground, release the parking brake and move the gearshift lever to neutral position ("N" position).



NISSAN recommends that vehicle be towed with the driving (front) wheels off the ground as illustrated.

LIFTING POINTS AND TOW TRUCK TOWING

Tow Truck Towing (Cont'd)

TOWING AN AUTOMATIC TRANSAXLE MODEL WITH FOUR WHEELS ON GROUND


Observe the following restricted towing speeds and distances.

Speed: Below 50 km/h (30 MPH)

Distance: Less than 65 km (40 miles)

CAUTION:


Never tow an automatic transaxle model from the rear (i.e., backward) with four wheels on the ground as this may cause serious and expensive damage to the transaxle.



SGI368

TOWING AN AUTOMATIC TRANSAXLE MODEL WITH REAR WHEELS RAISED (With front wheels on ground)

Never tow an automatic transaxle model with rear wheels raised (with front wheels on ground) as this may cause serious and expensive damage to the transaxle. If it is necessary to tow it with rear wheels raised, always use a towing dolly under the front wheels.



SGI739

TOWING POINT

Always pull the cable straight out from the vehicle. Never pull on the hook at a sideways angle.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TIGHTENING TORQUE OF STANDARD BOLTS

Grade	Bolt size	Bolt diameter* mm	Pitch mm	Tightening torque (Without lubricant)					
				Hexagon head bolt			Hexagon flange bolt		
				N•m	kg-m	ft-lb	N•m	kg-m	ft-lb
4T	M6	6.0	1.0	5.1	0.52	3.8	6.1	0.62	4.5
	M8	8.0	1.25	13	1.3	9	15	1.5	11
			1.0	13	1.3	9	16	1.6	12
	M10	10.0	1.5	25	2.5	18	29	3.0	22
			1.25	25	2.6	19	30	3.1	22
	M12	12.0	1.75	42	4.3	31	51	5.2	38
1.25			46	4.7	34	56	5.7	41	
M14	14.0	1.5	74	7.5	54	88	9.0	65	
7T	M6	6.0	1.0	8.4	0.86	6.2	10	1.0	7
	M8	8.0	1.25	21	2.1	15	25	2.5	18
			1.0	22	2.2	16	26	2.7	20
	M10	10.0	1.5	41	4.2	30	48	4.9	35
			1.25	43	4.4	32	51	5.2	38
	M12	12.0	1.75	71	7.2	52	84	8.6	62
1.25			77	7.9	57	92	9.4	68	
M14	14.0	1.5	127	13.0	94	147	15.0	108	
9T	M6	6.0	1.0	12	1.2	9	15	1.5	11
	M8	8.0	1.25	29	3.0	22	35	3.6	26
			1.0	31	3.2	23	37	3.8	27
	M10	10.0	1.5	59	6.0	43	70	7.1	51
			1.25	62	6.3	46	74	7.5	54
	M12	12.0	1.75	98	10.0	72	118	12.0	87
1.25			108	11.0	80	137	14.0	101	
M14	14.0	1.5	177	18.0	130	206	21.0	152	

1. Special parts are excluded.
2. This standard is applicable to bolts having the following marks embossed on the bolt head.

Grade	Mark
4T	4
7T	7
9T	9



GLOSSARY

The “Glossary of Acronyms” and the “Glossary of Technical Terms and Component Part Names” Related to SAE J1930

The glossary is a list comprising the acronyms and technical terms that are described in SAE J1930 and original Nissan technical terms that were described in pre-1993 model year Service Manuals or are described in Parts Catalogs as part names.

This glossary is provided to indicate correspondence between acronyms and two kinds of technical terms. Thus, this glossary is not intended for use as a dictionary of components and their functions.

SAE J1930 ACRONYMS	SAE J1930 TECHNICAL TERMS	NISSAN TECHNICAL TERMS OR COMPONENT PART NAMES
A/C	Air Conditioning	Air Conditioner
ACL	Air Cleaner	Air Cleaner
AIR	Secondary Air Injection	Air Pump
AP	Accelerator Pedal	Accelerator Pedal
BARO	Barometric Pressure	Altitude Compensator & BCDD
B+	Battery Positive Voltage	Battery Voltage
CAC	Charge Air Cooler	Inter Cooler
CARB	Carburetor	Carburetor
CFI	Continuous Fuel Injection	—
CL	Closed Loop	Closed Loop and Closed Loop Control
CKP	Crankshaft Position	Crank Angle Sensor
CMP	Camshaft Position	—
CPP	Clutch Pedal Position	Clutch Switch
CTOX	Continuous Trap Oxidizer	—
CTP	Closed Throttle Position	Idle Switch
DFI	Direct Fuel Injection	—
DI	Distributor Ignition	Ignition Timing Control
DLC	Data Link Connector	Diagnostic Connector for CONSULT or Diagnostic Connector
DTC	Diagnostic Trouble Code	Malfunction code or Code
DTM	Diagnostic Test Mode	Mode
ECM	Engine Control Module	ECCS Control Unit, Control Unit (EF & EC). ECU (ECCS Control Unit) or ECCS Control Unit (ECCS)
ECT	Engine Coolant Temperature	Engine Temperature Sensor, Engine Temperature or Coolant Temperature
EEPROM	Electrically Erasable Programmable Read Only Memory	ROM
EFE	Early Fuel Evaporation	Heat Control Valve Mixture Heater
EGR	Exhaust Gas Recirculation	Exhaust Gas Recirculation, Exhaust Gas Temperature Sensor, EGR System, EGR Valve, EGR Control Valve, BPT Valve or EGR Control Solenoid Valve
EI	Electronic Ignition	Ignition Timing Control
EM	Engine Modification	—
EPROM	Erasable Programmable Read Only Memory	ROM
EVAP	Evaporative Emission	Evaporative Emission Control System
FC	Fan Control	Radiator Fan Control or Condenser Fan Control

GLOSSARY

The “Glossary of Acronyms” and the “Glossary of Technical Terms and Component Part Names” Related to SAE J1930 (Cont’d)

SAE J1930 ACRONYMS	SAE J1930 TECHNICAL TERMS	NISSAN TECHNICAL TERMS OR COMPONENT PART NAMES
FEEPROM	Flash Electrically Erasable Programmable Read Only Memory	ROM
FEPROM	Flash Erasable Programmable Read Only Memory	ROM
FF	Flexible Fuel	—
FP	Fuel Pump	Fuel Pump
GEN	Generator	Alternator
GND	Ground	Ground or Earth
HO2S	Heated Oxygen Sensor	Exhaust Gas Sensor
IAT	Intake Air Temperature	—
ICM	Ignition Control Module	—
IFI	Indirect Fuel Injection	—
IFS	Inertia Fuel Shutoff	—
ISC	Idle Speed Control	FI Pot
KS	Knock Sensor	Detonation Sensor
MAF	Mass Air Flow	Air Flow Meter
MAP	Manifold Absolute Pressure	—
MC	Mixture Control	Air-Fuel Ratio Solenoid Valve
MDP	Manifold Differential Pressure	—
MIL	Malfunction Indicator Lamp	Check Engine Light
MFI	Multiport Fuel Injection	Fuel Injection Control
MST	Manifold Surface Temperature	—
MVZ	Manifold Vacuum Zone	—
NVRAM	Non-Volatile Random Access Memory	—
O2S	Oxygen Sensor	Exhaust Gas Sensor
OBD	On-Board Diagnostic	Self-diagnosis
OC	Oxidation Catalytic Converter	Catalyst
OL	Open Loop	Open Loop
PAIR	Pulsed Secondary Air Injection	AIV (Air Induction Valve)
PCM	Powertrain Control Module	—
PNP	Park/Neutral Position	Neutral Switch
PROM	Programmable Read Only Memory	ROM
PSP	Power Steering Pressure	—
PTOX	Periodic Trap Oxidizer	—
RAM	Random Access Memory	—
RM	Relay Module	—
ROM	Read Only Memory	ROM
RPM	Engine Speed	Engine Revolution or Engine rpm
SC	Supercharger	—
SCB	Supercharger Bypass	—
SFI	Sequential Multiport Fuel Injection	Sequential Injection
SPL	Smoke Puff Limiter	—

GLOSSARY

The "Glossary of Acronyms" and the "Glossary of Technical Terms and Component Part Names" Related to SAE J1930 (Cont'd)

SAE J1930 ACRONYMS	SAE J1930 TECHNICAL TERMS	NISSAN TECHNICAL TERMS OR COMPONENT PART NAMES
SRI	Service Reminder Indicator	—
SRT	System Readiness Test	—
ST	Scan Tool	—
TB	Throttle Body	Throttle Chamber or SPI Body
TBI	Throttle Body Fuel Injection	Fuel Injection Control
TC	Turbocharger	Turbocharger
TCC	Torque Converter Clutch	Lock-up Solenoid or Lock-up Cancel Solenoid
TCM	Transmission Control Module	A/T Control Unit
TP	Throttle Position	Throttle Sensor, Soft/Hard Idle Switch, Throttle Position of Throttle Valve Switch
TR	Transmission Range	—
TW	Thermal Vacuum Valve	Thermal Vacuum Valve (TVV)
TWC	Three Way Catalytic Converter	Catalyst
TWC + OC	Three Way + Oxidation Catalytic Converter	Catalyst
VAF	Volume Air Flow	Air Flow Meter
VR	Voltage Regulator	Voltage Regulator or IC Voltage Regulator
VSS	Vehicle Speed Sensor	Vehicle Speed Sensor
WOT	Wide Open Throttle	Full Switch or Full Throttle Switch
WU-OC	Warm Up Oxidation Catalytic Converter	Catalyst or Pre Cat
WU-TWC	Warm Up Three Way Catalytic Converter	Catalyst or Pre Cat
3GR	Third Gear	—
4GR	Fourth Gear	—

—: Not issued as NISSAN TECHNICAL TERMS OR COMPONENT PART NAMES

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

1000

1000

1000

MAINTENANCE

SECTION MA

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

GENERAL MAINTENANCE	2	Wheel Cylinder	16
PERIODIC MAINTENANCE	4	Drum	17
Schedule 1	5	Lining.....	17
Schedule 2	6	Temporary Method For Checking Lining	
RECOMMENDED FLUIDS AND LUBRICANTS	7	Wear.....	17
Fluids and Lubricants.....	7	Balancing Wheels	17
SAE Viscosity Number.....	7	Tire Rotation.....	17
ENGINE MAINTENANCE	8	Checking Steering Gear and Linkage.....	17
Checking Drive Belts	8	Steering Gear	17
Changing Engine Coolant.....	9	Steering Linkage.....	17
Automatic Air Conditioning.....	9	Checking Power Steering Fluid and Lines.....	18
Manual Air Conditioning	9	Checking Exhaust System.....	18
Checking Fuel Lines	10	CHASSIS AND BODY MAINTENANCE	19
Changing Fuel Filter.....	10	Lubricating Locks, Hinges and Hood Latches	19
Changing Air Cleaner Filter	11	Checking Seat Belts, Buckles, Retractors,	
Changing Engine Oil.....	11	Anchors and Adjusters.....	19
Changing Oil Filter	12	SERVICE DATA AND SPECIFICATIONS (SDS)	20
Changing Spark Plugs.....	13	Engine Maintenance	20
Checking Vapor Lines.....	13	Inspection And Adjustment	20
Checking Valve Clearance	13	Drive belt deflection	20
CHASSIS AND BODY MAINTENANCE	14	Oil capacity (Refill).....	20
Checking Clutch Fluid Level and Leaks	14	Engine coolant level.....	20
Checking M/T Oil	14	Spark plug	20
Changing M/T Oil.....	14	Chassis and Body Maintenance.....	20
Checking A/T Fluid Level.....	15	Inspection And Adjustment	20
Changing A/T Fluid	15	Clutch	20
Checking Brake Fluid Level and Leaks	15	Front axle and front suspension.....	20
Checking Brake Lines and Cables.....	16	Rear axle and rear suspension	20
Checking Disc Brake	16	Brake	20
Rotor	16	Wheel balance	21
Caliper	16	Wheel bearing	21
Pad.....	16	Tightening Torque	21
Checking Drum Brake.....	16		

GENERAL MAINTENANCE

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform the checks and inspections themselves or they can have their NISSAN dealers do them.

Item	Reference page
OUTSIDE THE VEHICLE	
The maintenance items listed here should be performed from time to time, unless otherwise specified.	
Tires Check the pressure with a gauge periodically when at a service station, including the spare, and adjust to the specified pressure if necessary. Check carefully for damage, cuts or excessive wear.	—
Wheel nuts When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	—
Tire rotation Tires should be rotated every 12,000 km (7,500 miles.)	MA-17
Wheel alignment and balance If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	MA-17, FA-6
Windshield wiper blades Check for cracks or wear if they do not wipe properly.	—
Doors and engine hood Check that all doors and the engine hood operate smoothly as well as the trunk lid and back hatch. Also, ensure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-19
INSIDE THE VEHICLE	
The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance-cleaning the vehicle, etc.	
Lamps Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also, check headlamp aim.	—
Warning lamps and buzzers/chimes Make sure that all warning lamps and buzzers/chimes are operating properly.	—
Windshield wiper and washer Check that the wipers and washer operate properly and that the wipers do not streak.	—
Windshield defroster Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioning.	—
Steering wheel Check that it has the specified free play. Be sure to check for changes in the steering condition, such as excessive free play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in)	ST-5
Seats Check seat position controls such as seat adjusters, seatback recliner, etc. to ensure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if so equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seatbacks.	—
Seat belts Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-19
Clutch pedal Make sure the pedal operates smoothly and check that it has the proper free travel.	CL-4
Brakes Check that the brake does not pull the vehicle to one side when applied.	—
Brake pedal and booster Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Be certain to keep the floor mats away from the pedal.	BR-9, 14

GENERAL MAINTENANCE

Item	Reference page	
Parking brake Check that the lever has the proper travel and confirm that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	BR-33	GI
Automatic transmission "Park" mechanism Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that your vehicle is held securely with the selector lever in the "P" position without applying any brakes.	—	MA
UNDER THE HOOD AND VEHICLE		
The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).		EM
Windshield washer fluid Check that there is adequate fluid in the tank.	—	LC
Engine coolant level Check the coolant level when the engine is cold.	MA-20	EF & EC
Radiator and hoses Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, rot or loose connections.	LC-8	FE
Brake and clutch fluid levels Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoir.	MA-14, 15	CL
Battery Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines.	EL-10	MT
Engine drive belts Make sure that no belt is frayed, worn, cracked or oily.	MA-8	AT
Engine oil level Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-11	FA
Power steering fluid level and lines Check the level when the fluid is cold and the engine is turned off. Check the lines for proper attachment, leaks, cracks, etc.	MA-18	RA
Automatic transaxle fluid level Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-15	BR
Exhaust system Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-18	ST
Underbody The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—	BF
Fluid leaks Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioning after use is normal. If you should notice any leaks or if gasoline fumes are evident, check for the cause and correct it immediately.	—	HA
		EL

PERIODIC MAINTENANCE

Two different maintenance schedules are provided, and should be used, depending upon the conditions in which the vehicle is mainly operated. **After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage/time intervals.**

SCHEDULE 1

Follow Periodic Maintenance Schedule 1 if your driving habits frequently include one or more of the following driving conditions:

- Repeated short trips of less than 5 miles (8 km).
- Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing.
- Operating in hot weather in stop-and-go "rush hour" traffic.
- Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use.
- Driving in dusty conditions.
- Driving on rough, muddy, or salt spread roads.
- Towing a trailer, using a camper or a car-top carrier.

SCHEDULE 2

Follow Periodic Maintenance Schedule 2 if none of the driving conditions shown in Schedule 1 apply to your driving habits.

PERIODIC MAINTENANCE

Schedule 1

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION

Perform at number of miles, kilometers or months, whichever comes first.

	3.75 (6)	7.5 (12)	11.25 (18)	15 (24)	18.75 (30)	22.5 (36)	26.25 (42)	30 (48)	33.75 (54)	37.5 (60)	41.25 (66)	45 (72)	48.75 (78)	52.5 (84)	56.25 (90)	60 (96)	Reference page
Miles x 1,000																	
(km x 1,000)																	
Months	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48	

Emission control system maintenance

Drive belts	See NOTE (1)																	I*	MA-8
Air cleaner filter	See NOTE (2)																	[R]	MA-11
Vapor lines																		I*	MA-13
Fuel lines																		I*	MA-10
Fuel filter	See NOTE (3)*																		MA-10
Engine coolant	See NOTE (4)																	R*	MA-9
Engine oil	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	MA-11	
Engine oil filter (Use Nissan PRE-MILUM type or equivalent)	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	MA-12	
Spark plugs	[R]																	[R]	MA-13
Intake & exhaust valve clearance	See NOTE (5)*																		EM-36

Chassis and body maintenance

Brake lines & cables	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	MA-16	
Brake pads, discs, drums & linings	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	MA-16	
Manual & automatic transaxle oil	See NOTE (6)																		MA-14, 15
Steering gear & linkage, axle & suspension parts	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	MA-17, FA-4, FA-4	
Steering linkage ball joints & front suspension ball joints	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	MA-17, FA-5	
Exhaust system	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	MA-18	
Drive shaft boots	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	FA-8	
Air bag system	See NOTE (7)																		BF-85

NOTE: (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.

(2) If operating mainly in dusty conditions, more frequent maintenance may be required.

(3) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.

(4) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.

(5) If valve noise increases, inspect valve clearance.

(6) If towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil at every 30,000 miles (48,000 km) or 24 months.

(7) Inspect the air bag system 10 years after the date of manufacture as noted on the F.M.V.S.S. certification label.

(8) Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

PERIODIC MAINTENANCE

Schedule 2

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. [] : At the mileage intervals only

MAINTENANCE OPERATION Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)		Months		MAINTENANCE INTERVAL				Refer- ence page
	7.5 (12)	15 (24)	22.5 (36)	30 (48)	37.5 (60)	45 (72)	52.5 (84)	60 (96)	
	6	12	18	24	30	36	42	48	

Emission control system maintenance

Drive belts	See NOTE (1)								I*	MA-8
Air cleaner filter				[R]					[R]	MA-11
Vapor lines				I*					I*	MA-13
Fuel lines				I*					I*	MA-10
Fuel filter	See NOTE (2)*									MA-10
Engine coolant	See NOTE (3)								R*	MA-9
Engine oil		R	R	R	R	R	R	R	R	MA-11
Engine oil filter (Use Nissan PREMIUM type or equivalent)		R	R	R	R	R	R	R	R	MA-12
Spark plugs				[R]					[R]	MA-13
Intake & exhaust valve clearance	See NOTE (4)*									EM-36

Chassis and body maintenance

Brake lines & cables		I	I	I	I	I	I	I	I	MA-16
Brake pads, discs, drums & linings		I	I	I	I	I	I	I	I	MA-16
Manual & automatic transaxle oil		I	I	I	I	I	I	I	I	MA-14, 15
Steering gear linkage, axle & suspension parts										MA-17, FA-4, RA-4
Exhaust system										MA-18
Drive shaft boots		I	I	I	I	I	I	I	I	FA-8
Air bag system	See NOTE (5)									BF-85

NOTE: (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.
(2) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.
(3) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.
(4) If valve noise increases, inspect valve clearance.
(5) Inspect the air bag system 10 years after the date of manufacture as noted on the F.M.V.S.S. certification label.
(6) Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

RECOMMENDED FLUIDS AND LUBRICANTS

Fluids and Lubricants

	Capacity (Approximate)			Recommended fluids and lubricants
	US measure	Imp measure	Liter	
Engine oil (Refill)				
With oil filter	4-1/8 qt	3-3/8 qt	3.9	Energy Conserving Oils of API SG*2, *3
Without oil filter	3-3/4 qt	3-1/8 qt	3.5	
Cooling system (Reservoir tank included)	8-1/4 qt	6-7/8 qt	7.8	Anti-freeze coolant (Ethylene glycol base)
Manual transaxle gear oil	10 pt	8-1/4 pt	4.7	API GL-4*2
Automatic transaxle fluid	10 qt	8-1/4 qt	9.4	Genuine Nissan ATF*1 or equivalent type DEXRON II E™
Power steering fluid	1 qt	3/4 qt	0.9	Type DEXRON II™ or equivalent
Brake & Clutch fluid	—	—	—	Genuine Nissan Brake Fluid*1 or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease	—	—	—	NLGI No. 2 (Lithium soap base)


*1: Available in mainland USA through your Nissan dealer.

*2: For further details, see "SAE Viscosity Number".


*3: Energy conserving oils

These oils can be identified by such labels as EC-I, EC-II, energy conserving, energy saving, improved fuel economy, etc.

SAE Viscosity Number




5W-30 is preferable for all ambient temperatures. 20W-40 and 20W-50 are usable for ambient temperatures above 10°C (50°F) for all seasons.



80W-90 is preferable for ambient temperatures below 40°C (104°F).

ENGINE MAINTENANCE

Checking Drive Belts



1. Inspect for cracks, fraying, wear or oil adhesion. If necessary, replace with a new one.
2. Inspect drive belt deflections by pushing on the belt midway between pulleys.


Adjust if belt deflections exceed the limit.

Belt deflection:

Inspect drive belt deflections when engine is cold.

Unit: mm (in)

	Used belt deflection		Deflection of new belt
	Limit	Deflection after adjustment	
Generator & Power steering oil pump	8 (0.31)	6 - 7 (0.24 - 0.28)	5 - 6 (0.20 - 0.24)
Air conditioning compressor	10 (0.39)	7 - 8 (0.28 - 0.31)	6 - 7 (0.24 - 0.28)
Applied pushing force	98 N (10 kg, 22 lb)		



Changing Engine Coolant

WARNING:




To avoid being scalded, never change the coolant when the engine is hot.

AUTOMATIC AIR CONDITIONING

1. Perform self-diagnosis step 4 of Automatic Air Conditioning system, referring to the following notes. Refer to HA section ("Self-diagnosis", "TROUBLE DIAGNOSES — Auto Air Conditioning").
- 1) Turn ignition switch from "OFF" to "ON".
- 2) Within 10 seconds after ignition switch is turned "ON", press **OFF** switch and hold in for at least 5 seconds.
- 3) Press **HOT** switch 3 times.
- 4) Press **DEF** switch 2 times.
- 5) Confirm indication of the A/C display shown at left.
- 6) Wait 10 seconds before turning ignition switch off. This step is necessary to allow heater water cock to open wide.

MANUAL AIR CONDITIONING

1. Turn ignition switch "ON" and set temperature controller to maximum hot position.
2. Open drain plug at the bottom of radiator, and remove radiator cap.



3. Remove drain plug on water pipe.
4. Close radiator drain plug and tighten drain plug on water pipe securely.
- Apply sealant to the thread of drain plug on water pipe.
 - ⌘: 34 - 44 N·m
 - (3.5 - 4.5 kg-m, 25 - 33 ft-lb)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

ENGINE MAINTENANCE

Changing Engine Coolant (Cont'd)



5. Open air relief plug.
6. Fill radiator with water until water spills from the air relief hole, then reinstall air relief plug. fill radiator and reservoir tank with water and reinstall radiator cap.
7. Run engine and warm it up sufficiently.
8. Race engine 2 or 3 times under no-load.
9. Stop engine and wait until it cools down.
10. Drain water.
11. Repeat step 1 through step 10 until clear water begins to drain from radiator.



12. Open radiator cap and air relief plug.
13. Fill radiator with coolant up to specified level following step 1 through step 9.
Follow instructions attached to anti-freeze container for mixing ratio of anti-freeze to water.

Engine coolant level (With reservoir tank):



7.8 l (8-1/4 US qt, 6-7/8 Imp qt)

Reservoir tank:

0.7 l (3/4 US qt, 5/8 Imp qt)


Pour coolant through coolant filler neck slowly to allow air in system to escape.

14. If necessary, add coolant.



Checking Fuel Lines

Inspect fuel lines and tank for improper attachment and for leaks, cracks, damage, loose connections, chafing and deterioration. If necessary, repair or replace faulty parts.



Changing Fuel Filter

CAUTION:

Tighten high-pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end.

Ensure that screw does not contact adjacent parts.

ENGINE MAINTENANCE

Changing Fuel Filter (Cont'd)

WARNING:

Before removing fuel filter, release fuel pressure from fuel line.



1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode to release fuel pressure to zero.
3. After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
4. Turn ignition switch off.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA






BR

ST

BF

HA

EL



1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
4. Turn ignition switch off and install fuse for fuel pump.

5. Loosen fuel hose clamps.

6. Replace fuel filter.

- Be careful not to spill fuel over engine compartment. Place a shop towel to absorb fuel.
- Use a high-pressure type fuel filter. Do not use a synthetic resinous fuel filter.
- When tightening fuel hose clamps, refer to MA-10.

Changing Air Cleaner Filter

The viscous paper type filter does not need cleaning between renewals.

Changing Engine Oil

WARNING:

Be careful not to burn yourself, as the engine oil is hot.

1. Warm up engine, and check for oil leakage from engine components.
2. Remove drain plug and oil filler cap.
3. Drain oil and refill with new engine oil.

Oil grade: API SG

Viscosity: See MA-7.

ENGINE MAINTENANCE


Changing Engine Oil (Cont'd)

Refill oil capacity (Approximately):

With oil filter change	3.9 l (4-1/8 US qt, 3-3/8 Imp qt)
Without oil filter change	3.5 l (3-3/4 US qt, 3-1/8 Imp qt)

CAUTION:

- Be sure to clean drain plug and install with new washer.
Drain plug:
⊙: 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)
- The refill capacity changes depending on the oil temperature and drain time; use these values as a reference and be certain to check with the dipstick when changing the oil.




4. Check oil level.
5. Start engine and check area around drain plug and oil filter for oil leakage.
6. Run engine for a few minutes, then turn it off. After several minutes, check oil level.

Changing Oil Filter


1. Remove oil filter with a suitable tool.

WARNING:

Be careful not to burn yourself, as the engine and the engine oil are hot.







2. Before installing new oil filter, clean the oil filter mounting surface on the cylinder block, and coat the rubber seal of the oil filter with a little engine oil.



3. Screw in the oil filter until a slight resistance is felt, then tighten additionally more than 2/3 turn.
4. Add engine oil.

Refer to MA-11.



Changing Spark Plugs

1. Disconnect ignition wires from spark plugs at boot. Do not pull on the wire.

2. Remove spark plugs with spark plug wrench.

Spark plug:

Standard type

BKR5E-11

Cold type

BKR6E-11

BKR7E-11

3. Check plug gap of each new spark plug.

Gap: 1.0 - 1.1 mm (0.039 - 0.043 in)

4. Install spark plugs. Reconnect ignition wires according to Nos. indicated on them.

Spark plug:

⚙️: 20 - 29 N·m

(2.0 - 3.0 kg-m, 14 - 22 ft-lb)

Checking Vapor Lines

1. Visually inspect vapor lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration.
2. Inspect vacuum relief valve of fuel tank filler cap for clogging, sticking, etc.

Refer to EF & EC section ("Inspection", "EVAPORATIVE EMISSION (EVAP) SYSTEM").

Checking Valve Clearance

If engine runs with unusual mechanical noise, refer to EM section ("Inspection", "CYLINDER HEAD").

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL




Checking Clutch Fluid Level and Leaks

If fluid level is extremely low, check clutch system for leaks.




Checking M/T Oil

1. Check for oil leaks.



2. Check oil level.

Never start engine while checking oil level.



Changing M/T Oil


Oil grade: API GL-4

Oil viscosity:

See MA-7.

Oil capacity:

4.7 liters (10 US pt, 8-1/4 Imp pt)





Checking A/T Fluid Level

1. Check for fluid leakage.
2. Check fluid level.
Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) after vehicle has been driven approximately 5 minutes in urban areas after engine is warmed up. But it can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on dipstick for reference after engine is warmed up and before driving. However, fluid level must be rechecked using "HOT" range.

- 1) Park vehicle on level surface and set parking brake.
- 2) Start engine and then move selector lever through each gear range, ending in "P".
- 3) Check fluid level with engine idling.
- 4) Remove dipstick and wipe it clean with lint-free paper.
- 5) Re-insert dipstick into charging pipe as far as it will go.
- 6) Remove dipstick and note reading. If level is at low side of either range, add fluid to the charging pipe.

Do not overfill.

3. Check fluid condition.
Check fluid for contamination. If fluid is very dark or smells burned, or contains frictional material (clutches, band, etc.), check operation of A/T.
Refer to AT section for checking operation of A/T.



Changing A/T Fluid

Oil grade:

Genuine Nissan ATF or equivalent **DEXRON II E™** type fluid


Oil capacity (With torque converter):

RE4F04A

8.3 liters (8-3/4 US qt, 7-1/4 Imp qt)

RE4F04V

8.5 liters (9 US qt, 7-1/2 Imp qt)



Checking Brake Fluid Level and Leaks

If fluid level is extremely low, check brake system for leaks.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

Checking Brake Lines and Cables

Check brake fluid lines and parking brake cables for improper attachment and for leaks, chafing, abrasions, deterioration, etc.




Checking Disc Brake

ROTOR

Check condition and thickness.


Unit: mm (in)

	CL25VB	CL9HA
Standard	22.0 (0.866)	9.0 (0.354)
Minimum	20.0 (0.787)	8.0 (0.315)



CALIPER

Check operation and for leakage.




PAD

Check for wear or damage.

Unit: mm (in)

	CL25VB	CL9HA
Standard	11.0 (0.433)	10.0 (0.394)
Minimum	2.0 (0.079)	1.5 (0.059)



Checking Drum Brake

WHEEL CYLINDER

Check operation and for leakage.

CHASSIS AND BODY MAINTENANCE

Checking Drum Brake (Cont'd)

DRUM


Check condition of inner surface.

Standard inner diameter:

228.6 mm (9 in)

Maximum diameter:

230.0 mm (9.06 in)



LINING


Check for wear or damage.

Standard thickness:

4.1 mm (0.161 in)


Minimum thickness:

1.5 mm (0.059 in)



TEMPORARY METHOD FOR CHECKING LINING WEAR

Remove inspection hole plug and check for lining wear.




Balancing Wheels

- Adjust wheel balance using road wheel center.

Wheel balance (Maximum allowable unbalance):

Refer to MA-21.



Tire Rotation

- Do not include the T-type spare tire when rotating the tires.

Wheel nuts:

: 98 - 118 N·m

(10 - 12 kg-m, 72 - 87 ft-lb)


Checking Steering Gear and Linkage

STEERING GEAR

- Check gear housing and boots for looseness, damage or grease leakage.
- Check connection with steering column for looseness.

STEERING LINKAGE

- Check ball joint, dust cover and other component parts for looseness, wear, damage or grease leakage.



↶ : Check grease leakage

⬇ : Check tightening torque

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

CHASSIS AND BODY MAINTENANCE




Checking Power Steering Fluid and Lines

Check fluid level.


Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) or using "COLD" range on dipstick at fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is type DEXRON II™ or equivalent.




- Check lines for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.



Checking Exhaust System

Check exhaust pipes, muffler and mounting for proper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

Lubricating Locks, Hinges and Hood Latches



GI

MA

EM

LC

EF &
EC

FE


CL


MT


Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters

CAUTION:

- All seat belt assemblies, including retractors and attaching hardwares such as guide rail set, etc., should be inspected after any collision. Nissan recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Seat belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.
- If the condition of any component of seat belt assembly is questionable, do not have it repaired, but replaced as seat belt assembly.
- If webbing is cut, frayed, or damaged, replace belt assembly.
- Do not spill drinks, oil, etc. on inner lap belt buckle. Never oil tongue and buckle.
- Use a NISSAN genuine seat belt assembly.

 Anchor bolt
43 - 55 (4.4 - 5.6, 32 - 41)

 : N•m (kg-m, ft-lb)



AT

FA

RA

BR

ST

BF

HA

EL

AMA030

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Maintenance

INSPECTION AND ADJUSTMENT

Drive belt deflection

	Used belt deflection		Deflection of new belt
	Limit	Deflection after adjustment	
Generator & Power steering oil pump	8 (0.31)	6 - 7 (0.24 - 0.28)	5 - 6 (0.20 - 0.24)
Air conditioning compressor	10 (0.39)	7 - 8 (0.28 - 0.31)	6 - 7 (0.24 - 0.28)
Applied pushing force	98 N (10 kg, 22 lb)		

Unit: mm (in)

Oil capacity (Refill)

	Unit: ℓ (US qt, Imp qt)
With oil filter	3.9 (4-1/8, 3-3/8)
Without oil filter	3.5 (3-3/4, 3-1/8)

Engine coolant level

	Unit: ℓ (US qt, Imp qt)
With reservoir tank	7.8 (8-1/4, 6-7/8)
Reservoir tank	0.7 (3/4, 5/8)

Spark plug

Standard type	BKR5E-11
	BKR6E-11
Cold type	BKR7E-11
Plug gap	1.0 - 1.1 mm (0.039 - 0.043 in)

INSPECTION AND ADJUSTMENT

Clutch

	Unit: mm (in)
Pedal free height	163 - 173 (6.42 - 6.81)
Pedal free play	1 - 3 (0.04 - 0.12)

Front axle and front suspension (Unladen)*

Camber	degree	-0°50' to 0°40'
Caster	degree	1°55' - 3°25'
Kingpin inclination	degree	13°20' - 14°50'
Toe-in		
A - B	mm (in)	0 - 2 (0 - 0.08)
Front wheel turning angle		
Full turn		31°30' - 35°30' /
Inside/outside	degree	25°36' - 29°36'

*: Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

Rear axle and rear suspension (Unladen)*

Camber	degree	-2°00' to -0°30'
Toe-in		
A - B	mm (in)	1 to 3 (0.04 to 0.12)

*: Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

Chassis and Body Maintenance

Brake

Disc brake	mm (in)	
Pad		
Standard thickness		
CL25VB		11.0 (0.433)
CL9HA		10.0 (0.394)
Minimum thickness		
CL25VB		2.0 (0.079)
CL9HA		1.5 (0.059)
Rotor		
Standard thickness		
CL25VB		22.0 (0.866)
CL9HA		9.0 (0.354)
Minimum thickness		
CL25VB		20.0 (0.787)
CL9HA		8.0 (0.315)

SERVICE DATA AND SPECIFICATIONS (SDS)

Chassis and Body Maintenance (Cont'd)

Drum brake	mm (in)	
Lining		
Standard thickness		4.1 (0.161)
Minimum thickness		1.5 (0.059)
Drum		
Standard diameter		228.6 (9)
Maximum diameter		230.0 (9.06)

Wheel balance

Maximum allowable unbalance	Dynamic (at rim flange)	g (oz)	10 (0.35) (One side)
	Static	g (oz)	20 (0.71)

Wheel bearing

	Front	Rear
Wheel bearing axle end play mm (in)	0.05 (0.0020) or less	
Wheel bearing lock nut		
Tightening torque N•m (kg-m, ft-lb)	235 - 314 (24 - 32, 174 - 231)	186 - 255 (19 - 26, 137 - 188)

TIGHTENING TORQUE

Unit	N•m	kg-m	ft-lb
Clutch			
Pedal stopper lock nut	16 - 22	1.6 - 2.2	12 - 16
Clutch switch lock nut	12 - 15	1.2 - 1.5	9 - 11
Manual transaxle			
Filler plug	25 - 34	2.5 - 3.5	18 - 25
Drain plug	20 - 29	2.0 - 3.0	14 - 22
Automatic transaxle			
Drain plug	29 - 39	3.0 - 4.0	22 - 29
Front axle and front suspension			
Tie-rod lock nut	78 - 98	8.0 - 10.0	58 - 72
Rear axle and rear suspension			
Toe adjusting lock nut	78 - 98	8.0 - 10.0	58 - 72
Brake system			
Air bleed valve	7 - 9	0.7 - 0.9	5.1 - 6.5
Wheel and tire			
Wheel nut	98 - 118	10 - 12	72 - 87

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

PRECAUTIONS	2	Camshaft End Play.....	31
Precautions for Supplemental Restraint System		Camshaft Sprocket Runout.....	32
“AIR BAG”.....	2	Valve Guide Clearance	32
Parts Requiring Angular Tightening	2	Valve Guide Replacement	32
Liquid Gasket Application Procedure	3	Valve Seats.....	33
PREPARATION	4	Replacing Valve Seat For Service Parts.....	34
Special Service Tools.....	4	Valve Dimensions.....	34
Commercial Service Tools	7	Valve Spring	34
OUTER COMPONENT PARTS	8	Squareness	34
COMPRESSION PRESSURE	10	Pressure	35
Measurement of Compression Pressure	10	Valve Lifter And Valve Shim	35
OIL PAN	11	Assembly	35
Removal	11	Valve Clearance.....	36
Installation	13	Checking	36
TIMING CHAIN	16	Adjusting	36
Liquid gasket application places.....	17	ENGINE REMOVAL	38
Removal	18	Removal	39
Upper Timing Chain	18	Installation	40
Lower Timing Chain	21	CYLINDER BLOCK	41
Inspection	21	Disassembly	42
Installation	21	Piston And Crankshaft	42
Lower Timing Chain	21	Inspection	43
Upper Timing Chain	22	Piston And Piston Pin Clearance.....	43
OIL SEAL REPLACEMENT	25	Piston Ring Side Clearance	43
Valve Oil Seal.....	25	Piston Ring End Gap	43
Oil Seal Installing Direction	25	Connecting Rod Bend And Torsion.....	44
Front Oil Seal.....	25	Cylinder Block Distortion And Wear	44
Rear Oil Seal	26	Piston-To-Bore Clearance.....	44
ACCEL-DRUM UNIT	27	Crankshaft.....	45
CYLINDER HEAD	29	Bearing Clearance.....	46
Removal and Installation	30	Method A (Using bore gauge &	
Disassembly	30	micrometer)	46
Inspection	30	Main bearing	46
Cylinder Head Distortion	30	Connecting rod bearing (Big end).....	47
Camshaft Visual Check.....	30	Method B (Using plastigage).....	48
Camshaft Runout.....	31	Connecting Rod Bushing Clearance (Small	
Camshaft Cam Height.....	31	end)	48
Camshaft Journal Clearance	31		

CONTENTS (Cont'd.)

Replacement Of Connecting Rod Bushing			
(Small end)	49		
Flywheel/Drive Plate Runout.....	49		
Assembly	49		
Piston	49		
Crankshaft.....	50		
SERVICE DATA AND SPECIFICATIONS (SDS)	52		
General Specifications	52		
Compression Pressure.....	52		
Inspection and Adjustment	52		
Cylinder Head	52		
Valve	52		
Valve spring.....	52		
Valve lifter.....	53		
Valve guide.....	53		
Valve clearance adjustment	54		
Available shims	54		
Valve seat.....	55		GI
Cylinder Block.....	56		
Camshaft And Camshaft Bearing	57		
Piston, Piston Ring And Piston Pin	58		MA
Piston.....	58		
Piston pin.....	58		
Piston ring	58		EM
Connecting Rod.....	58		
Crankshaft.....	59		
Bearing Clearance.....	59		LC
Available Main Bearing	59		
Standard	59		EF & EC
Undersize (service)	60		
Available Connecting Rod Bearing	60		
Standard	60		FE
Undersize (service)	60		
Miscellaneous Components	60		CL
			MT
			AT
			FA
			RA
			BR
			ST
			BF
			HA
			EL

PRECAUTIONS

Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in **section BF** of this Service Manual.



WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.

Parts Requiring Angular Tightening

- Some important engine parts are tightened using an angular-tightening method rather than a torque setting method.
- If these parts are tightened using a torque setting method, dispersal of the tightening force (axial bolt force) will be two or three times that of the dispersal produced by using the correct angular tightening method.
- Although the torque setting values (described in this manual) are equivalent to those used when bolts and nuts are tightened with an angular-tightening method, they should be used for reference only.
- To assure the satisfactory maintenance of the engine, bolts and nuts must be tightened using an angular tightening method.
- Before tightening the bolts and nuts, ensure that the thread and seating surfaces are clean and then coated with engine oil.
- The bolts and nuts which require the angular-tightening method are as follows:
 - (1) Cylinder head bolts
 - (2) Connecting rod cap nuts.

PRECAUTIONS



Liquid Gasket Application Procedure

- a. Before applying liquid gasket, use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves, and then completely clean any oil stains from these portions.
- b. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- c. Apply liquid gasket to inner surface around hole perimeter area. (Assembly should be done within 5 minutes after coating.)
- d. Wait at least 30 minutes before refilling engine oil and engine coolant.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA







EL

PREPARATION




SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST0501S000 (-) Engine stand assembly ① ST05011000 (-) Engine stand ② ST05012000 (-) Base	 <p style="text-align: right;">Disassembling and assembling</p>
KV10114300 (-) Engine sub-attachment	
KV101065001 (-) Engine stand shaft	
KV101092S0 (-) Valve spring compressor ① KV10109210 (-) Compressor ② KV10109220 (-) Adapter	 <p style="text-align: right;">Disassembling and assembling valve components</p>
KV10116300 (J-38955) Valve oil seal drift	 <p style="text-align: right;">Installing valve oil seal</p>

PREPARATION







Tool number (Kent-Moore No.) Tool name	Description	
KV10110300 (-) Piston pin press stand assembly ① KV10110310 (-) Cap ② KV10110330 (-) Spacer ③ ST13030020 (-) Press stand ④ ST13030030 (-) Spring ⑤ KV10110340 (-) Drift ⑥ KV10110320 (-) Center shaft	 <p style="text-align: right;">Disassembling and assembling piston with connecting rod</p>	GI MA EM LC EF & EC FE CL MT
EM03470000 (J8037) Piston ring compressor	 <p style="text-align: right;">Installing piston assembly into cylinder bore</p>	AT FA
(J36467) Valve oil seal remover	 <p style="text-align: right;">Displacement valve oil seal</p>	RA BR
KV10111100 (J37228) Seal cutter	 <p style="text-align: right;">Removing oil pan</p>	ST BF
WS39930000 (-) Tube presser	 <p style="text-align: right;">Pressing the tube of liquid gasket</p>	HA EL
ST16610001 (J23907) Pilot bushing puller		

PREPARATION


Tool number (Kent-Moore No.) Tool name	Description
ST10120000 (J-24239-01) Cylinder head bolt wrench	 <p>Loosening and tightening cylinder head bolt</p>
KV101151S0 Lifter stopper set ① KV10115110 Camshaft pliers ② KV10115120 Lifter stopper	 <p>Changing shims</p>
KV10112100 Angle wrench	 <p>Tightening bolts for bearing cap, cylinder head, etc.</p>

PREPARATION


COMMERCIAL SERVICE TOOLS

Tool name	Description							
Spark plug wrench	 <p style="text-align: center;">16 mm (0.63 in)</p>	Removing and installing spark plug GI MA EM						
Pulley holder		Holding camshaft pulley while tightening or loosening camshaft bolt LC EF & EC FE						
Valve seat cutter set		Finishing valve seat dimensions CL MT AT FA RA						
Piston ring expander		Removing and installing piston ring MT AT FA RA						
Valve guide drift		Removing and installing valve guide Diameter: _____ mm (in) <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th>Intake & Exhaust</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>10.5 (0.413)</td> </tr> <tr> <td>B</td> <td>6.6 (0.260)</td> </tr> </tbody> </table>		Intake & Exhaust	A	10.5 (0.413)	B	6.6 (0.260)
	Intake & Exhaust							
A	10.5 (0.413)							
B	6.6 (0.260)							
Valve guide reamer		Reaming valve guide (①) or hole for oversize valve guide (②) Diameter: _____ mm (in) <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th>Intake & Exhaust</th> </tr> </thead> <tbody> <tr> <td>D₁</td> <td>7 (0.28)</td> </tr> <tr> <td>D₂</td> <td>11.175 (0.4400)</td> </tr> </tbody> </table>		Intake & Exhaust	D ₁	7 (0.28)	D ₂	11.175 (0.4400)
	Intake & Exhaust							
D ₁	7 (0.28)							
D ₂	11.175 (0.4400)							

OUTER COMPONENT PARTS



OUTER COMPONENT PARTS



GI

MA

EM

LC

EF & EC

FE


CL

MT


AT

FA


Intake manifold tightening procedure




Intake manifold collector tightening procedure



Exhaust manifold tightening procedure



Throttle body tightening procedure



RA

BR



ST

BF

HA

EL

COMPRESSION PRESSURE



Measurement of Compression Pressure

1. Warm up engine.
2. Turn ignition switch off.
3. Release fuel pressure.
Refer to EF & EC section ("Releasing Fuel Pressure", "MULTI-PORT FUEL INJECTION SYSTEM INSPECTION").
4. Remove all spark plugs.
5. Disconnect distributor center cable.

6. Attach a compression tester to No. 1 cylinder.
 7. Depress accelerator pedal fully to keep throttle valve wide open.
 8. Crank engine and record highest gauge indication.
 9. Repeat the measurement on each cylinder as shown above.
- **Always use a fully-charged battery to obtain specified engine speed.**

Compression pressure: kPa (kg/cm², psi)/rpm

Standard

1,226 (12.5, 178)/300

Minimum


1,030 (10.5, 149)/300

Difference limit between cylinders

98 (1.0, 14)/300

10. If cylinder compression in one or more cylinders is low, pour a small amount of engine oil into cylinders through spark plug holes and retest compression.
- **If adding oil helps compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
 - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to SDS) If valve or valve seat is damaged excessively, replace them.**
 - **If compression in any two adjacent cylinders is low and if adding oil does not help compression, there is leakage past the gasket surface. If so, replace cylinder head gasket.**



OIL PAN



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Removal


1. Remove engine under cover.
2. Drain engine oil.
3. Remove steel oil pan bolts.




4. Remove steel oil pan.
 - (1) Insert Tool between aluminum oil pan and steel oil pan.
 - Be careful not to damage aluminum mating surface.
 - Do not insert screwdriver, or oil pan flange will be deformed.

OIL PAN


Removal (Cont'd)




(2) Slide Tool by tapping on the side of the Tool with a hammer.




(3) Remove steel oil pan.
5. Remove baffle plate.
6. Remove oil strainer.



7. Remove front tube.
8. Set a suitable transmission jack under transaxle and hoist engine with engine slinger.
9. Remove center member.



10. Remove compressor gussets.




11. Remove rear cover plate.

OIL PAN

Removal (Cont'd)


12. Remove aluminum oil pan nuts and bolts.




13. Remove aluminum oil pan.

(1) Insert Tool between cylinder block and aluminum oil pan.



- Be careful not to damage aluminum mating surface.
- Do not insert screwdriver, or oil pan flange will be deformed.



(2) Slide Tool by tapping on the side of the Tool with a hammer.



(3) Remove aluminum oil pan.



Installation

1. Install aluminum oil pan.

(1) Before installing aluminum oil pan, remove all traces of liquid gasket from mating surfaces using a scraper.

- Also remove traces of liquid gasket from mating surfaces of cylinder block, front cover and steel oil pan.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


OIL PAN

Installation (Cont'd)




(2) Apply a continuous bead of liquid gasket to mating surface of aluminum oil pan.


- Use Genuine Liquid Gasket or equivalent.



- For areas marked with "★", apply liquid gasket to the outer side of the bolt hole.




- Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide.
- Attaching should be done within 5 minutes after coating.



(3) Install aluminum oil pan.


- Install bolts in the reverse order of removal.



2. Install compressor gussets.
3. Install center member.
4. Install front tube.
Install oil strainer baffle plate.

OIL PAN

Installation (Cont'd)




5. Install steel oil pan.

- (1) Before installing steel oil pan, remove all traces of liquid gasket from mating surfaces using a scraper.
 - Also remove traces of liquid gasket from mating surface of aluminum oil pan.

GI

MA

EM



- (2) Apply a continuous bead of liquid gasket to mating surface of steel oil pan.


- Use Genuine Liquid Gasket or equivalent.

LC

EF &
EC

FE

CL




MT

AT

FA

RA




- Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide.
- Attaching should be done within 5 minutes after coating.

BR

ST

BF



(3) Install steel oil pan.





- Install bolts in the reverse order of removal together with oxygen sensor harness bracket.
- Wait at least 30 minutes before refilling engine oil.

HA

EL

TIMING CHAIN

Liquid gasket application places



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TIMING CHAIN

CAUTION:


- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing sliding parts such as camshafts, chain tensioner and oil seal, be sure to apply new engine oil on their sliding surfaces.
- When tightening cylinder head bolts, camshaft sprocket bolts, crankshaft pulley bolt and camshaft bracket bolts, apply new engine oil to thread portions and seat surfaces of bolts.
- Before disconnecting fuel hose, release fuel pressure from fuel line.
Refer to EF & EC section ("Releasing Fuel Pressure", "MULTIPOINT FUEL INJECTION SYSTEM INSPECTION").



Removal


UPPER TIMING CHAIN

1. Drain coolant from drain plug on water pipe and radiator drain cock. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
2. Remove vacuum hoses, fuel hoses, wires, harness and connectors and so on.
3. Remove the following parts.
 - Generator and bracket
 - Upper radiator hose
 - Air duct
 - Front exhaust tube
4. Remove intake manifold collector supports, intake manifold collector and exhaust manifold.



TIMING CHAIN

Removal (Cont'd)



5. Set No. 1 piston at TDC on its compression stroke.
6. Remove distributor.
7. Set a suitable transmission jack under aluminum oil pan and remove front engine mounting.

GI

MA



EM

LC

EF &
EC

FE

CL




8. Remove rocker cover.

MT

AT

FA

RA




9. Remove cam sprocket.

BR

ST

BF

HA




10. Remove cam brackets and camshafts.
 - These parts should be reassembled in their original positions.

EL


TIMING CHAIN

Removal (Cont'd)



11. Loosen cylinder head bolts.

- A warped or cracked cylinder head could result from removing in incorrect order.
- Cylinder head bolts should be loosened in two or three steps.




12. Remove cam sprocket cover

- Upper timing chain will not be disengaged from idler sprocket. For this reason, a stopper need not be used.


Cast portion of cam sprocket cover is located on lower side of idler sprocket so upper timing chain need not be disengaged from idler sprocket.

13. Remove upper chain tensioner and upper chain guides.




14. Remove upper timing chain.

15. Remove idler sprocket bolt.



16. Remove cylinder head with intake manifold, intake manifold collector and exhaust manifold assembly.

17. Remove cylinder head gasket.



- Lower timing chain will not be disengaged from crankshaft sprocket. For this reason, a stopper need not be used.


Cast portion of front cover is located on lower side of crankshaft sprocket so lower timing chain need not be disengaged from idler sprocket.

TIMING CHAIN


Removal (Cont'd)

LOWER TIMING CHAIN


1. Remove upper timing chain.
Refer to EM-18.



2. Remove oil pan.
Refer to EM-11.
3. Remove crankshaft pulley.
4. Remove front cover




5. Remove the following parts.
 - Lower timing chain tensioner
 - Tension arm
 - Lower timing chain guide
6. Remove lower timing chain and idler sprocket.



Inspection


Check for cracks and excessive wear at roller links. Replace chain if necessary.



Installation

LOWER TIMING CHAIN

1. Install crankshaft sprocket.
 - Make sure that mating marks of crankshaft sprocket face front of engine.
2. Position crankshaft so that No. 1 piston is set at TDC.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

TIMING CHAIN


Installation (Cont'd)




3. Install idler sprocket and lower timing chain.
 - **Set lower timing chain on the sprockets, aligning mating marks.**
 - **Be careful not to damage cylinder head gasket when installing lower timing chain.**
4. Install chain tension arm and chain guide.
5. Install lower timing chain tensioner.



6. Install front cover.
 - **Apply a continuous bead of liquid gasket to front cover.**
 - **Be careful not to damage cylinder head gasket.**
 - **Be sure to install oil seal.**
7. Install the following parts:
 - Crankshaft pulley
 - Oil strainer
 - Oil pan
 - New cylinder head gasket



8. Install cylinder head and temporarily tighten cylinder head bolts when installing front cover.
 - **Temporarily tighten cylinder head bolts. This is necessary to avoid damaging cylinder head gasket.**
 - **Be sure to install washers between bolts and cylinder head.**








UPPER TIMING CHAIN

1. Install lower timing chain. Refer to EM-21.

TIMING CHAIN

Installation (Cont'd)



2. Install upper timing chain, chain tensioner and chain guide.
 - Set upper timing chain on the idler sprockets, aligning mating marks.

3. Install cam sprocket cover.
 - Apply a continuous bead of liquid gasket to front cover.
 - Be careful not to damage cylinder head gasket.
 - Be careful upper timing chain does not slip or jump when installing cam sprocket cover.


4. Tighten cylinder head bolts.
 - **Tightening procedure**
 - (a) Tighten all bolts to 29 N·m (3.0 kg·m, 22 ft·lb).
 - (b) Tighten all bolts to 79 N·m (8.1 kg·m, 59 ft·lb).
 - (c) Loosen all bolts completely
 - (d) Tighten all bolts to 25 to 34 N·m (2.5 to 3.5 kg·m, 18 to 25 ft·lb).
 - (e) Turn all bolts 86 to 91 degrees clockwise, or if an angle wrench is not available, tighten bolts to 75 to 84 N·m (7.6 to 8.6 kg·m, 55 to 62 ft·lb).

5. Install camshafts and camshaft brackets.
 - **Camshaft bracket bolts tightening procedure**
 - (a) Tighten all bolts to 2 N·m (0.2 kg·m, 1.4 ft·lb).
 - (b) Tighten all bolts to 9.0 to 11.8 N·m (0.92 to 1.2 kg·m, 6.7 to 8.7 ft·lb).


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TIMING CHAIN


Installation (Cont'd)





6. Install camshaft sprockets.
7. Install chain guide between both camshaft sprockets.



8. Install rubber plugs as follows.
 - (1) Apply liquid gasket to rubber plugs.
 - (2) Install rubber plugs, then move them by hand to uniformly spread the gasket on cam sprocket cover surface.
- Mating surfaces of liquid gasket should be installed flush.
9. Install chain guide between both camshaft sprockets.



10. Install distributor.
 - Make sure that No. 1 piston is set at TDC and that distributor rotor is set at No. 1 cylinder spark position.



11. Install rocker cover.
 - **Tightening procedure**
 - (a) Tighten nuts ①-⑤-⑥-④ in that order to 4 N·m (0.4 kg-m, 2.9 ft-lb).
 - (b) Tighten nuts ① to ⑪ as indicated in figure to 8 to 11 N·m (0.8 to 1.1 kg-m, 5.8 to 8.0 ft-lb).
12. Install all spark plugs with high-tension cords.
13. Install vacuum hoses, fuel tubes, wires, harness and connectors and so on.




OIL SEAL REPLACEMENT

VALVE OIL SEAL


1. Remove rocker cover.
2. Remove camshaft. Refer to EM-18.
3. Remove valve spring and valve oil seal with Tool or a suitable tool.

Piston concerned should be set at TDC to prevent valve from falling.

4. Apply engine oil to new valve oil seal and install it with Tool.



OIL SEAL INSTALLING DIRECTION



FRONT OIL SEAL

1. Remove radiator shroud and crankshaft pulley.
 2. Remove front oil seal
- **Be careful not to damage crankshaft.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL

OIL SEAL REPLACEMENT




3. Apply engine oil to new oil seal and install it using a suitable tool.




REAR OIL SEAL


1. Remove drive plate or flywheel.
2. Remove rear oil seal retainer.
3. Remove traces of liquid gasket using scraper.



4. Remove rear oil seal from rear oil seal retainer.




5. Apply engine oil to new oil seal and install it using a suitable tool.




6. Apply a continuous bead of liquid gasket to rear oil seal retainer.


ACCEL-DRUM UNIT



SEM205D



SEM148E



SEM207D

Adjust accel-drum unit whenever any of the following parts (new or old) are installed:

- Accel-drum unit
- Throttle body
- Rod (Always replace with a new one after removal.)

1. Install accel-drum unit and throttle body.
2. Apply grease all over the inside of the rod couplings.

Use genuine Nissan grease or equivalent.

3. Insert each one coupling to ball links of throttle body and accel-drum unit.

4. Loosen lock nut.
5. Loosen adjusting screw enough.

6. Manually turn accel-drum until throttle valve is fully open.
- Check that stopper lever is not touching adjusting screw. If it is, loosen adjusting screw to maintain clearance between the two.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL

ACCEL-DRUM UNIT




7. Turn adjusting screw until it touches stopper lever.
8. Back off accel-drum.



9. Turn adjusting screw 3 rotations clockwise.
10. Tighten lock nut.

CYLINDER HEAD



- ① Oil filler cap
- ② Rocker cover
- ③ Camshaft bracket
- ④ Intake camshaft
- ⑤ Exhaust camshaft

- ⑥ Shim
- ⑦ Valve lifter
- ⑧ Valve cotter
- ⑨ Spring retainer
- ⑩ Valve spring

- ⑪ Spring seat
- ⑫ Intake valve
- ⑬ Exhaust valve
- ⑭ Cylinder head
- ⑮ Cylinder head bolt

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SEM149E


CYLINDER HEAD

CAUTION:

- When installing sliding parts such as rocker arms, camshaft and oil seal, be sure to apply new engine oil on their sliding surfaces.
- When tightening cylinder head bolts, intake camshaft sprocket bolts and camshaft bracket bolts, apply new engine oil to thread portions and seat surfaces of bolts.
- Attach tags to valve lifters so as not to mix them up.


Removal and Installation

- Removal and installation procedures are the same as those for timing chain. Refer to EM-18.



Disassembly

1. Remove intake manifold, collector assembly and exhaust manifold. Refer to EM-8.
2. Remove valve components with Tool.
3. Remove valve oil seal with a suitable tool.



Inspection

CYLINDER HEAD DISTORTION

Head surface flatness:

Standard Less than 0.03 mm (0.0012 in)
Limit 0.1 mm (0.004 in)

If beyond the specified limit, replace it or resurface it.

Resurfacing limit:

The resurfacing limit of cylinder head is determined by the cylinder block resurfacing in an engine.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$$A + B = 0.2 \text{ mm (0.008 in)}$$

After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

Nominal cylinder head height:

126.3 - 126.5 mm (4.972 - 4.980 in)

CAMSHAFT VISUAL CHECK


Check camshaft for scratches, seizure and wear.

CYLINDER HEAD

Inspection (Cont'd)


CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.
Runout (Total indicator reading):
Standard
Less than 0.02 mm (0.0008 in)
Limit
0.04 mm (0.0016 in)
2. If it exceeds the limit, replace camshaft.





CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.
Standard cam height:
Intake
42.415 - 42.605 mm (1.6699 - 1.6774 in)
Exhaust
42.415 - 43.005 mm (1.6699 - 1.6931 in)
Cam wear limit:
Intake & Exhaust
0.2 mm (0.008 in)
2. If wear is beyond the limit, replace camshaft.




CAMSHAFT JOURNAL CLEARANCE

1. Install camshaft bracket and tighten bolts to the specified torque.
2. Measure inner diameter of camshaft bearing.
Standard inner diameter:
#1 journal
28.000 - 28.025 mm (1.1024 - 1.1033 in)
#2 to #5 journals
24.000 - 24.025 mm (0.9449 - 0.9459 in)
3. Measure outer diameter of camshaft journal.
Standard outer diameter:
#1 journal
27.935 - 27.955 mm (1.0998 - 1.1006 in)
#2 to #5 journals
23.935 - 23.955 mm (0.9423 - 0.9431 in)
4. If clearance exceeds the limit, replace camshaft and/or cylinder head.
Camshaft journal clearance:
Standard 0.045 - 0.090 mm (0.0018 - 0.0035 in)
Limit 0.12 mm (0.0047 in)



CAMSHAFT END PLAY

1. Install camshaft and thermostat housing in cylinder head.
2. Measure camshaft end play.
Camshaft end play:
Standard
0.070 - 0.15 mm (0.0028 - 0.0059 in)
Limit
0.20 mm (0.0079 in)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

CYLINDER HEAD


Inspection (Cont'd)

CAMSHAFT SPROCKET RUNOUT




1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.
Runout (Total indicator reading):
Limit 0.12 mm (0.0047 in)
3. If it exceeds the limit, replace camshaft sprocket.

VALVE GUIDE CLEARANCE



1. Measure valve deflection in a parallel direction with rocker arm. (Valve and valve guide mostly wear in this direction.)
Valve intake and exhaust deflection limit (Dial gauge reading):
0.2 mm (0.008 in)



2. If it exceeds the limit, check valve to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.


Valve to valve guide clearance:

Unit: mm (in)

	Standard	Limit
Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.08 (0.0031)
Exhaust	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)

- c. If it exceeds the limit, replace valve or valve guide.


VALVE GUIDE REPLACEMENT




1. To remove valve guide, heat cylinder head to 120 to 140°C (248 to 284°F).

CYLINDER HEAD


Inspection (Cont'd)




2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.




3. Ream cylinder head valve guide hole.
**Valve guide hole diameter
(for service parts):
Intake & Exhaust
11.175 - 11.196 mm (0.4400 - 0.4408 in)**



4. Heat cylinder head to 120 to 140°C (230 to 266°F) and press service valve guide onto cylinder head.
**Projection "L":
13.3 - 13.9 mm (0.524 - 0.547 in)**



5. Ream valve guide.
**Finished size:
Intake & Exhaust
7.000 - 7.018 mm (0.2756 - 0.2763 in)**



VALVE SEATS

Check valve seats for any evidence of pitting at valve contact surface, and reset or replace if it has worn out excessively.

- Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.
- Cut with both hands to uniform the cutting surface.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CYLINDER HEAD

Inspection (Cont'd)

REPLACING VALVE SEAT FOR SERVICE PARTS

1. Bore out old seat until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the seat recess in cylinder head.
2. Ream cylinder head recess.


Reaming bore for service valve seat

Oversize [0.5 mm (0.020 in)]:


Intake 38.000 - 38.016 mm (1.4961 - 1.4967 in)

Exhaust 32.700 - 32.716 mm (1.2874 - 1.2880 in)

Reaming should be done in circles concentric to the valve guide center so that valve seat will have the correct fit.




SEM795A



SEM008A

3. Heat cylinder head to 120 to 140°C (248 to 284°F).
4. Press fit valve seat until it seats on the bottom.



SEM892B

5. Cut or grind valve seat using suitable tool at the specified dimensions as shown in SDS.
6. After cutting, lap valve seat with abrasive compound.
7. Check valve seating condition.

Seat face angle "α":

44°53' - 45°07'


Contacting width "W":

Intake

1.48 - 1.63 mm (0.0583 - 0.0642 in)

Exhaust

1.8 - 2.0 mm (0.071 - 0.079 in)




SEM188A

VALVE DIMENSIONS

Check dimensions in each valve. For dimensions, refer to SDS. When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.



SEM288A

VALVE SPRING

Squareness

1. Measure "S" dimension.

Out-of-square:

Less than 2.0 mm (0.079 in)

2. If it exceeds the limit, replace spring.

CYLINDER HEAD

Inspection (Cont'd)

Pressure

Check valve spring pressure.

Pressure: N (kg, lb) at height mm (in)


Standard

471.7 (48.1, 106.1) at 26.06 (1.0260)

Limit


More than 421.31 (42.96, 94.73) at 26.06 (1.0260)

If it exceeds the limit, replace spring.



VALVE LIFTER AND VALVE SHIM


1. Visually check contact and sliding surfaces for wear or scratches.



2. Check diameter of valve lifter and valve lifter guide bore.

Valve lifter diameter:

33.960 - 33.975 mm (1.3370 - 1.3376 in)





Lifter guide bore diameter:

34.000 - 34.021 mm (1.3386 - 1.3394 in)

Valve lifter to valve lifter guide clearance:

0.025 - 0.061 mm (0.0010 - 0.0024 in)



Assembly

1. Install valve component parts.
 - **Always use new valve oil seal. Refer to EM-25.**
 - **Before installing valve oil seal, install valve spring seat.**
 - **Install outer valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side.**
 - **After installing valve component parts, use plastic hammer to lightly tap valve stem tip to assure a proper fit.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

CYLINDER HEAD





Valve Clearance

CHECKING

Check valve clearance while engine is warm but not running.

1. Remove rocker cover and all spark plugs.
2. Set No. 1 cylinder at TDC on its compression stroke.
 - Align pointer with TDC mark on crankshaft pulley.
 - Check that valve lifters on No. 1 cylinder are loose and valve lifters on No. 4 are tight.If not, turn crankshaft one revolution (360°) and align as above.
3. Check only those valves shown in the figure.



- Using a feeler gauge, measure clearance between valve lifter and camshaft.
- Record any valve clearance measurements which are out of specification. They will be used later to determine the required replacement adjusting shim.


Valve clearance (Hot):

Intake

0.31 - 0.39 mm (0.012 - 0.015 in)

Exhaust

0.33 - 0.41 mm (0.013 - 0.016 in)



4. Turn crankshaft one revolution (360°) and align mark on crankshaft pulley with pointer.
5. Check those valves shown in the figure.
 - Use the same procedure as mentioned in step 4.
6. If all valve clearances are within specification, install the following parts.
 - Rocker cover
 - All spark plugs

ADJUSTING


Adjust valve clearance while engine is cold.

1. Turn crankshaft, to position cam lobe on camshaft of valve that must be adjusted upward.
2. Place Tool (A) around camshaft as shown in figure.
3. Rotate Tool (A) so that lifter is pushed down.

Before placing Tool (A), rotate notch toward center of cylinder head (See figure.), to simplify shim removal later.






CAUTION:

Be careful not to damage cam surface with Tool (A).



CYLINDER HEAD

Valve Clearance (Cont'd)



- Place Tool (B) between camshaft and valve lifter to retain valve lifter.

CAUTION:

- Tool (B) must be placed as close to camshaft bracket as possible.
 - Be careful not to damage cam surface with Tool (B).
- Remove Tool (A).

- Remove adjusting shim using a small screwdriver and a magnetic finger.

- Determine replacement adjusting shim size following formula.
- Using a micrometer determine thickness of removed shim.
- Calculate thickness of new adjusting shim so valve clearance comes within specified values.

R = Thickness of removed shim

N = Thickness of new shim

M = Measured valve clearance

Intake: $N = R + [M - 0.35 \text{ mm (0.0138 in)}]$

Exhaust: $N = R + [M - 0.37 \text{ mm (0.0146 in)}]$

Shims are available in 37 sizes from 1.96 mm (0.0772 in) to 2.68 mm (0.1055 in), in steps of 0.02 mm (0.0008 in).

- Select new shim with thickness as close as possible to calculated value.

- Install new shim using a suitable tool.
- Install with the surface on which the thickness is stamped facing down.
- Place Tool (A) as mentioned in steps 2 and 3.
- Remove Tool (B).
- Remove Tool (A).
- Recheck valve clearance. Refer to EM-36.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

ENGINE REMOVAL



ENGINE REMOVAL

WARNING:


- a. Position vehicle on a flat and solid surface.
- b. Place chocks at front and back of rear wheels.
- c. Do not remove engine until exhaust system has completely cooled off.
Otherwise, you may burn yourself and/or fire may break out in fuel line.
- d. For safety during subsequent steps, the tension of wires should be slackened against the engine.
- e. Before disconnecting fuel hose, release fuel pressure from fuel line.
Refer to EF & EC section ("Releasing Fuel Pressure", "MULTI-PORT FUEL INJECTION SYSTEM INSPECTION").
- f. Before removing front axle from transaxle, place safety stands under designated front supporting points. Refer to GI section for lifting points and towing.
- g. Be sure to hoist engine and transaxle in a safe manner.
- h. For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

CAUTION:

- When lifting engine, be careful not to strike adjacent parts, especially accelerator wire casing, brake lines, and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- In removing drive shaft, be careful not to damage grease seal of transaxle.

Removal

1. Remove engine under cover and hood.
2. Drain coolant from drain plug on water pipe, and radiator.
3. Remove vacuum hoses, fuel hoses, wires, harnesses and connectors and so on.
4. Remove front exhaust tube and drive shafts.
5. Remove drive belts.
6. Remove generator, compressor and power steering oil pump from engine.
7. Set a suitable transmission jack under transaxle. Hoist engine with engine slinger.
8. Remove RH and LH engine mountings and center member.
9. Remove front and rear engine mountings.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

ENGINE REMOVAL

Removal (Cont'd)


10. Remove engine with transaxle as shown.



Installation

Installation is in the reverse order of removal.

CYLINDER BLOCK



- | | | |
|--------------------------|--------------------|-----------------------------|
| ① Piston rings | ⑦ Crankshaft | ⑬ Rear plate (A/T) |
| ② Piston | ⑧ Main bearing cap | ⑭ Drive plate (A/T) |
| ③ Piston pin | ⑨ Rear plate (M/T) | ⑮ Drive plate reinforcement |
| ④ Snap ring | ⑩ Flywheel (M/T) | ⑯ Rear oil seal |
| ⑤ Connecting rod | ⑪ Dust cover (A/T) | ⑰ Rear oil seal retainer |
| ⑥ Connecting rod bearing | ⑫ Main bearing | ⑱ Cylinder block |

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

CYLINDER BLOCK

CAUTION:


- When installing sliding parts such as bearings and pistons, be sure to apply engine oil on the sliding surfaces.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When tightening connecting rod bolts and main bearing cap bolts, apply engine oil to thread portion of bolts and seating surface of nuts.



Disassembly

PISTON AND CRANKSHAFT

1. Place engine on a work stand.
2. Remove timing chain.
Refer to EM-18.





3. Remove pistons with connecting rods.

- When disassembling piston and connecting rod, remove snap rings, then heat piston to 60 to 70°C (140 to 158°F) or use piston pin press stand at room temperature.

CAUTION:


- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- When piston rings are being replaced and no punchmark is present, piston rings can be mounted with either side up.




4. Remove main bearing beam and crankshaft.

- Before removing main bearing beam, measure crankshaft end play.
- Bolts should be loosened in two or three steps.


CYLINDER BLOCK




AEM023



AEM024



SEM249C



SEM250C

Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".
Standard diameter "dp":
20.987 - 20.999 mm (0.8263 - 0.8267 in)

2. Measure outer diameter of piston pin "Dp".
Standard diameter "Dp":
20.989 - 21.001 mm (0.8263 - 0.8268 in)
3. Calculate interference fit of piston pin to piston.
dp - Dp = 0 - 0.004 mm (0 - 0.0002 in)
If it exceeds the above value, replace piston assembly with pin.

PISTON RING SIDE CLEARANCE

Side clearance:

Top ring

0.040 - 0.080 mm (0.0016 - 0.0031 in)

2nd ring

0.030 - 0.070 mm (0.0012 - 0.0028 in)

Max. limit of side clearance:

0.1 mm (0.004 in)

If out of specification, replace piston and/or piston ring assembly.

PISTON RING END GAP

End gap:

Top ring

0.28 - 0.52 mm (0.0110 - 0.0205 in)

2nd ring

0.45 - 0.69 mm (0.0177 - 0.0272 in)

Oil ring

0.20 - 0.69 mm (0.0079 - 0.0272 in)

Max. limit of ring gap:

1.0 mm (0.039 in)

If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, rebore cylinder and use oversized piston and piston rings.

Refer to EM-58.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CYLINDER BLOCK

Inspection (Cont'd)

CONNECTING ROD BEND AND TORSION



Bend:

Limit 0.15 mm (0.0059 in)
per 100 mm (3.94 in) length

Torsion:

Limit 0.30 mm (0.0118 in)
per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.



CYLINDER BLOCK DISTORTION AND WEAR

1. Clean upper face of cylinder block and measure the distortion.

Limit:

0.10 mm (0.0039 in)

2. If out of specification, resurface it.
The resurfacing limit is determined by cylinder head resurfacing in engine.

Amount of cylinder head resurfacing is "A"

Amount of cylinder block resurfacing is "B"

The maximum limit is as follows:

$$A + B = 0.2 \text{ mm (0.008 in)}$$

Nominal cylinder block height
from crankshaft center:

246.95 - 247.05 mm (9.7224 - 9.7264 in)

3. If necessary, replace cylinder block.

PISTON-TO-BORE CLEARANCE

1. Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Standard inner diameter:

89.000 - 89.030 mm (3.5039 - 3.5051 in)

Wear limit:

0.2 mm (0.008 in)

Out-of-round (X - Y):


Less than 0.015 mm (0.0006 in)

Taper (A - B):

Less than 0.01 mm (0.0004 in)



If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.

2. Check for scratches and seizure. If seizure is found, hone it.



CYLINDER BLOCK

Inspection (Cont'd)



- If both cylinder block and piston are replaced with new ones, select piston of the same grade number punched on cylinder block upper surface.

3. Measure piston skirt diameter.

Piston diameter "A":

Refer to EM-58.

Measuring point "a" (Distance from the top):

52 mm (2.05 in)

4. Check that piston-to-bore clearance is within specification.

Piston-to-bore clearance "B":

0.020 - 0.040 mm (0.0008 - 0.0016 in)

5. Determine piston oversize according to amount of cylinder wear.

Oversize pistons are available for service. Refer to EM-58.

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation: $D = A + B - C$ where,

D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

7. Install main bearing caps, and tighten to the specified torque to prevent distortion of cylinder bores in final assembly.
8. Cut cylinder bores.


- **When any cylinder needs boring, all other cylinders must also be bored.**

- **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**

9. Hone cylinders to obtain specified piston-to-bore clearance.

10. Measure finished cylinder bore for out-of-round and taper.

- **Measurement should be done after cylinder bore cools down.**



CRANKSHAFT

1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):

Less than 0.005 mm (0.0002 in)

Taper (A - B):

Less than 0.002 mm (0.0001 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


CYLINDER BLOCK

Inspection (Cont'd)



3. Measure crankshaft runout.

Runout (Total indicator reading):
Less than 0.04 mm (0.0016 in)




BEARING CLEARANCE

- Either of the following two methods may be used, however, method "A" gives more reliable results and is preferable.

Method A (Using bore gauge & micrometer)

Main bearing


1. Set main bearings in their proper positions on cylinder block and main bearing cap.



2. Install main bearing cap to cylinder block.

Tighten all bolts in correct order in two or three stages. Refer to EM-50.

3. Measure inner diameter "A" of each main bearing.



4. Measure outer diameter "D_m" of each crankshaft main journal.

5. Calculate main bearing clearance.


Main bearing clearance = A - D_m

Standard:

0.020 - 0.047 mm (0.0008 - 0.0019 in)

Limit: 0.1 mm (0.004 in)

6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.





- a. When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.

"L": 0.1 mm (0.004 in)

- b. Refer to EM-59 for grinding crankshaft and available service parts.

CYLINDER BLOCK

Inspection (Cont'd)



8. If crankshaft is reused, measure main bearing clearance and select thickness of main bearing.
If crankshaft is replaced with a new one, it is necessary to select thickness of main bearings as follows:
 - a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.

- b. Grade number of each crankshaft main journal is punched on crankshaft. These numbers are punched in either Arabic or Roman numerals.

- c. Select main bearing with suitable thickness according to the following table.

Main bearing grade number:


Crankshaft journal grade number	Main journal grade number		
	0	1	2
0	0	1	2
1	1	2	3
2	2	3	4

For example:

Main journal grade number: 1

Crankshaft journal grade number: 2

Main bearing grade number = 1 + 2 = 3



Connecting rod bearing (Big end)

1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of each bearing.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

CYLINDER BLOCK

Inspection (Cont'd)




4. Measure outer diameter "Dp" of each crankshaft pin journal.
5. Calculate connecting rod bearing clearance.

$$\text{Connecting rod bearing clearance} = C - Dp$$

Standard: 0.010 - 0.035 mm (0.0004 - 0.0014 in)
Limit: 0.09 mm (0.0035 in)

6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing. Refer to step 7 on EM-46.




8. If crankshaft is replaced with a new one, select connecting rod bearing according to the following table.

Connecting rod bearing grade number:

These numbers are punched in either Arabic or Roman numerals.


Crank pin grade number	Connecting rod bearing grade number
0	0
1	1
2	2



Method B (Using plastigage)


CAUTION:

- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. Then if excessive bearing clearance exists, use a thicker main bearing or undersized bearing so that the specified bearing clearance is obtained.



CONNECTING ROD BUSHING CLEARANCE (Small end)

1. Measure inner diameter "C" of bushing.



2. Measure outer diameter "Dp" of piston pin.
3. Calculate connecting rod bushing clearance.

$$C - Dp =$$


0.005 - 0.017 mm (0.0002 - 0.0007 in) (Standard)
0.023 mm (0.0009 in) (Limit)

If it exceeds the limit, replace connecting rod assembly and/or piston set with pin.

CYLINDER BLOCK

Inspection (Cont'd)

REPLACEMENT OF CONNECTING ROD BUSHING (Small end)



1. Drive in small end bushing until it is flush with end surface of rod.

Be sure to align the oil holes.

2. After driving in small end bushing, ream the bushing so that clearance between small end bushing and piston pin is specified value.

Clearance between small end bushing and piston pin:
0.005 - 0.017 mm (0.0002 - 0.0007 in)

FLYWHEEL/DRIVE PLATE RUNOUT


Runout (Total indicator reading):

Flywheel (M/T model)

Less than 0.15 mm (0.0059 in)

Drive plate (A/T model)


Less than 0.15 mm (0.0059 in)



Assembly


PISTON

1. Install new snap ring on one side of piston pin hole.



2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.


- **Align the direction of piston and connecting rod.**
- **Numbers stamped on connecting rod and cap correspond to each cylinder.**
- **After assembly, make sure connecting rod swings smoothly.**



3. Set piston rings as shown.

CAUTION:

- **When piston rings are not being replaced, make sure that piston rings are mounted in their original positions.**
- **When piston rings are being replaced and no punchmark is present, piston rings can be mounted with either side up.**



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL

CYLINDER BLOCK

Assembly (Cont'd)



CRANKSHAFT

1. Set main bearings in their proper positions on cylinder block and main bearing beam.

- Confirm that correct main bearings are used. Refer to EM-45.

2. Install crankshaft and main bearing beam and tighten bolts to the specified torque.

- Prior to tightening bearing cap bolts, place bearing cap in its proper position by shifting crankshaft in the axial direction.
- Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward sequentially.
- After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.

3. Measure crankshaft end play.

Crankshaft end play:

Standard

0.05 - 0.18 mm (0.0020 - 0.0071 in)

Limit

0.3 mm (0.012 in)


If beyond the limit, replace bearing with a new one.

4. Install connecting rod bearings in connecting rods and connecting rod caps.

- Confirm that correct bearings are used. Refer to EM-47.
- Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.

CYLINDER BLOCK

Assembly (Cont'd)




5. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - Be careful not to scratch cylinder wall by connecting rod.
 - Arrange so that front mark on piston head faces toward front of engine.

GI

MA

EM



- b. Install connecting rod bearing caps.
Tighten connecting rod bearing cap nuts to the specified torque.

LC


EF &
EC

Connecting rod bearing nut:

- (1) Tighten to 14 to 16 N·m
(1.4 to 1.6 kg-m, 10 to 12 ft-lb).
- (2) Tighten bolts 60 to 65 degrees clockwise with an angle wrench, or if an angle wrench is not available, tighten them to 38 to 44 N·m (3.9 to 4.5 kg-m, 28 to 33 ft-lb).

FE

CL



6. Measure connecting rod side clearance.

Connecting rod side clearance:

- Standard**
0.2 - 0.4 mm (0.008 - 0.016 in)
- Limit**
0.6 mm (0.024 in)

MT

AT

FA

If beyond the limit, replace connecting rod and/or crankshaft.

RA

BR

ST

BF

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Cylinder arrangement	In-line 4	
Displacement	cm ³ (cu in)	2,389 (145.78)
Bore and stroke	mm (in)	89 x 96 (3.50 x 3.78)
Valve arrangement	D.O.H.C.	
Firing order	1-3-4-2	
Number of piston rings		
Compression	2	
Oil	1	
Number of main bearings	5	
Compression ratio	9.2	

COMPRESSION PRESSURE

Unit: kPa (kg/cm², psi)/300 rpm


Compression pressure	
Standard	1,226 (12.5, 178)
Minimum	1,030 (10.5, 149)
Differential limit between cylinders	98 (1.0, 14)

Inspection and Adjustment

CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Head surface distortion	Less than 0.03 (0.0012)	0.1 (0.004)




Nominal cylinder head height:
H = 126.3 - 126.5 (4.972 - 4.980)

SEM956C

VALVE

Unit: mm (in)



SEM188

Valve head diameter "D"

Intake	36.5 - 36.7 (1.437 - 1.445)
Exhaust	31.2 - 31.4 (1.228 - 1.236)

Valve length "L"

Intake	101.02 - 101.62 (3.9772 - 4.0008)
Exhaust	98.52 - 99.72 (3.8787 - 3.9260)

Valve stem diameter "d"

Intake	6.965 - 6.980 (0.2742 - 0.2748)
Exhaust	6.945 - 6.960 (0.2734 - 0.2740)

Valve seat angle "α"

Intake	45°15' - 45°45'
Exhaust	

Valve margin "T"

Intake	0.95 - 1.25 (0.0374 - 0.0492)
Exhaust	1.15 - 1.45 (0.0453 - 0.0571)

Valve margin "T" limit More than 0.5 (0.020)

Valve stem end surface grinding limit Less than 0.2 (0.008)

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Valve spring

Free height	mm (in)	45.79 (1.8028)
Pressure N (kg, lb) at height mm (in)	Standard	471.7 (48.1, 106.1) at 26.06 (1.0260)
		Limit
Out-of-square	mm (in)	Less than 2.0 (0.079)


Valve lifter

Unit: mm (in)

Valve lifter outer diameter	33.960 - 33.975 (1.3370 - 1.3376)
Lifter guide inner diameter	34.000 - 34.021 (1.3386 - 1.3394)
Clearance between lifter and filter guide	0.025 - 0.061 (0.0010 - 0.0024)

Valve guide

Unit: mm (in)



SEM301D

		Standard	Service
Valve guide			
Outer diameter	Intake & Exhaust	11.023 - 11.034 (0.4340 - 0.4344)	11.223 - 11.234 (0.4418 - 0.4423)
	Valve guide		
Inner diameter (Finished size)	Intake	7.000 - 7.018 (0.2756 - 0.2763)	
	Exhaust	7.000 - 7.018 (0.2756 - 0.2763)	
Cylinder head valve guide hole diameter	Intake & Exhaust	10.975 - 10.996 (0.4321 - 0.4329)	11.175 - 11.196 (0.4400 - 0.4408)
	Interference fit of valve guide	0.027 - 0.059 (0.0011 - 0.0023)	
Stem to guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.08 (0.0031)
	Exhaust	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)
Valve deflection limit		0.2 (0.008)	
Projection length "L"		13.3 - 13.9 (0.524 - 0.547)	

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)


Valve clearance adjustment

Unit: mm (in)

Valve clearance	
Intake	0.31 - 0.39 (0.012 - 0.015)
Exhaust	0.33 - 0.41 (0.013 - 0.016)

Available shims

Thickness mm (in)	Identification mark
1.96 (0.0772)	196
1.98 (0.0780)	198
2.00 (0.0787)	200
2.02 (0.0795)	202
2.04 (0.0803)	204
2.06 (0.0811)	206
2.08 (0.0819)	208
2.10 (0.0827)	210
2.12 (0.0835)	212
2.14 (0.0843)	214
2.16 (0.0850)	216
2.18 (0.0858)	218
2.20 (0.0866)	220
2.22 (0.0874)	222
2.24 (0.0882)	224
2.26 (0.0890)	226
2.28 (0.0898)	228
2.30 (0.0906)	230
2.32 (0.0913)	232
2.34 (0.0921)	234
2.36 (0.0929)	236
2.38 (0.0937)	238
2.40 (0.0945)	240
2.42 (0.0953)	242
2.44 (0.0961)	244
2.46 (0.0969)	246
2.48 (0.0976)	248
2.50 (0.0984)	250
2.52 (0.0992)	252
2.54 (0.1000)	254
2.56 (0.1008)	256
2.58 (0.1016)	258
2.60 (0.1024)	260
2.62 (0.1031)	262
2.64 (0.1039)	264
2.66 (0.1047)	266
2.68 (0.1055)	268




SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Valve seat

Unit: mm (in)



SEM179E


		Standard	Service
Cylinder head seat recess diameter (D)	In.	37.500 - 37.516 (1.4764 - 1.4770)	38.000 - 38.016 (1.4961 - 1.4967)
	Ex.	32.200 - 32.216 (1.2677 - 1.2683)	32.700 - 32.716 (1.2874 - 1.2880)
Valve seat interference fit	In.	0.064 - 0.096 (0.0025 - 0.0038)	
	Ex.	0.064 - 0.096 (0.0025 - 0.0038)	
Valve seat outer diameter (d)	In.	37.580 - 37.596 (1.4795 - 1.4802)	38.080 - 38.096 (1.4992 - 1.4998)
	Ex.	32.280 - 32.296 (1.2709 - 1.2715)	32.780 - 32.796 (1.2905 - 1.2912)
Depth (H)	In.	6.19 - 6.21 (0.2437 - 0.2445)	
	Ex.	6.1 - 6.3 (0.240 - 0.248)	
Height (h_1)		5.9 - 6.0 (0.232 - 0.236)	
Height (h_2)	In.	0.44 - 0.64 (0.0173 - 0.0252)	
	Ex.	0.53 - 0.73 (0.0209 - 0.0287)	

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CYLINDER BLOCK



SEM447C

Unit: mm (in)



			Standard	Limit
Distortion			Less than 0.03 (0.0012)	0.1 (0.004)
Cylinder bore	Inner diameter	Grade 1	89.000 - 89.010 (3.5039 - 3.5043)	0.2 (0.008)
		Grade 2	89.010 - 89.020 (3.5043 - 3.5047)	
		Grade 3	89.020 - 89.030 (3.5047 - 3.5051)	
	Out-of-round (X - Y)		Less than 0.015 (0.0006)	—
Taper (A - B)		Less than 0.010 (0.0004)	—	
Difference in inner diameter between cylinders			Less than 0.03 (0.0012)	0.2 (0.008)
Cylinder block height : H (From crankshaft center)			246.95 - 247.05 (9.7224 - 9.7264)	0.2 (0.008)*

* Total amount of cylinder head resurfacing and cylinder block resurfacing

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CAMSHAFT AND CAMSHAFT BEARING



SEM568A

EM120

Unit: mm (in)

		Standard	Limit
Cam height (A)	Intake	42.415 - 42.605 (1.6699 - 1.6774)	—
	Exhaust	42.415 - 43.005 (1.6699 - 1.6931)	—
Wear limit of cam height		—	0.2 (0.008)
Camshaft journal to bearing clearance		0.045 - 0.090 (0.0018 - 0.0035)	0.12 (0.0047)
Inner diameter of camshaft bearing	#1 journal	28.000 - 28.025 (1.1024 - 1.1033)	—
	#2 to #5 journal	24.000 - 24.025 (0.9449 - 0.9459)	
Outer diameter of camshaft journal (D)	#1 journal	27.935 - 27.955 (1.0998 - 1.1006)	—
	#1 to #5 journal	23.935 - 23.955 (0.9423 - 0.9431)	
Camshaft runout*		Less than 0.02 (0.0008)	0.04 (0.0016)
Camshaft end play		0.07 - 0.15 (0.0028 - 0.0059)	0.20 (0.0079)
Valve timing (Degree on crankshaft)	a	248	—
	b	240	—
	c	-1	—
	d	61	—
	e	8	—
	f	60	—

* Total indicator reading

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

PISTON, PISTON RING AND PISTON PIN Piston



SEM444C

Unit: mm (in)

Piston skirt diameter (A)	Standard	Grade No. 1	88.970 - 88.980 (3.5027 - 3.5031)
		Grade No. 2	88.980 - 88.990 (3.5031 - 3.5035)
		Grade No. 3	88.990 - 89.000 (3.5035 - 3.5039)
	Service (Oversize)	0.5 (0.020)	89.470 - 89.500 (3.5224 - 3.5236)
		1.0 (0.039)	89.970 - 90.000 (3.5421 - 3.5433)
Dimension (a)		Approximately 52 (2.05)	
Piston pin hole diameter (d)		20.987 - 20.999 (0.8263 - 0.8267)	
Piston-to-cylinder bore clearance		0.020 - 0.040 (0.0008 - 0.0016)	

Piston pin

Unit: mm (in)


	Standard	Limit
Piston pin outer diameter	20.989 - 21.001 (0.8263 - 0.8268)	—
Interference fit of piston pin to piston pin hole	0 - 0.004 (0 - 0.0002)	—
Piston pin to connecting rod bearing clearance	0.005 - 0.017 (0.0002 - 0.0007)	0.023 (0.0009)

Piston ring

Unit: mm (in)

		Standard	Limit
Side clearance	Top	0.040 - 0.080 (0.0016 - 0.0031)	0.1 (0.004)
	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.1 (0.004)
Ring gap	Top	0.28 - 0.52 (0.0110 - 0.0205)	1.0 (0.039)
	2nd	0.45 - 0.69 (0.0177 - 0.0272)	1.0 (0.039)
	Oil (rail ring)	0.20 - 0.69 (0.0079 - 0.0272)	1.0 (0.039)

CONNECTING ROD



SEM180E

Unit: mm (in)


	Standard	Limit
Center distance (S)	164.95 - 165.05 (6.4941 - 6.4980)	—
Bend [per 100 mm (3.94 in)]	—	0.15 (0.0059)
Torsion [per 100 mm (3.94 in)]	—	0.30 (0.0118)
Piston pin bushing inner diameter (d)*	21.000 - 21.012 (0.8268 - 0.8272)	—
Connecting rod big end inner diameter (D)*	53.000 - 53.013 (2.0866 - 2.0871)	—
Side clearance	0.2 - 0.4 (0.008 - 0.016)	0.6 (0.024)

* Without bearing

SERVICE DATA AND SPECIFICATIONS (SDS)


Inspection and Adjustment (Cont'd)

CRANKSHAFT



SEM394

Out-of-round X - Y
Taper A - B



EM715

Unit: mm (in)

Main journal diameter (Dm)	Grade	No. 0	59.967 - 59.975 (2.3609 - 2.3612)
		No. 1	59.959 - 59.967 (2.3606 - 2.3609)
		No. 2	59.951 - 59.959 (2.3603 - 2.3606)
Pin journal diameter (Dp)	Grade	No. 0	49.968 - 49.974 (1.9672 - 1.9675)
		No. 1	49.962 - 49.968 (1.9670 - 1.9672)
		No. 2	49.956 - 49.962 (1.9668 - 1.9670)
Center distance (r)			47.97 - 48.05 (1.8886 - 1.8917)
		Standard	Limit
Taper of journal and pin [(A) - (B)]		Less than 0.002 (0.0001)	—
Out-of-round of journal and pin [(X) - (Y)]		Less than 0.005 (0.0002)	—
Runout [T.I.R.]*		Less than 0.04 (0.0016)	—
Free end play		0.05 - 0.18 (0.0020 - 0.0071)	0.3 (0.012)
Fillet roil		More than 0.1 (0.004)	

* Total indicator reading

BEARING CLEARANCE

Unit: mm (in)

	Standard	Limit
Main bearing clearance	0.020 - 0.047 (0.0008 - 0.0019)	0.1 (0.004)
Connecting rod bearing clearance	0.010 - 0.035 (0.0004 - 0.0014)	0.09 (0.0035)

AVAILABLE MAIN BEARING

Standard

Grade number	Thickness mm (in)	Identification color
0	1.821 - 1.825 (0.0717 - 0.0719)	Black
1	1.825 - 1.829 (0.0719 - 0.0720)	Brown*
2	1.829 - 1.833 (0.0720 - 0.0722)	Green
3	1.833 - 1.837 (0.0722 - 0.0723)	Yellow
4	1.837 - 1.841 (0.0723 - 0.0725)	Blue

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Undersize (service)

Unit: mm (in)

	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	1.952 - 1.960 (0.0769 - 0.0772)	Grind so that bearing clearance is the specified value.

Undersize (service)

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.08 (0.0031)	1.540 - 1.548 (0.0606 - 0.0609)	Grind so that bearing clearance is the specified value.
0.12 (0.0047)	1.560 - 1.568 (0.0614 - 0.0617)	
0.25 (0.0098)	1.625 - 1.633 (0.0640 - 0.0643)	

AVAILABLE CONNECTING ROD BEARING

Standard

Grade number	Thickness mm (in)	Identification color
0	1.505 - 1.508 (0.0593 - 0.0594)	—
1	1.508 - 1.511 (0.0594 - 0.0595)	Brown
2	1.511 - 1.514 (0.0595 - 0.0596)	Green

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Camshaft sprocket runout [T.I.R.]*	Less than 0.12 (0.0047)
Flywheel runout [T.I.R.]*	Less than 0.15 (0.0059)
Drive plate runout [T.I.R.]*	Less than 0.15 (0.0059)

* Total indicator reading

ENGINE LUBRICATION AND COOLING SYSTEM

SECTION LC

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

PRECAUTIONS	2	Checking Cooling System Hoses	8
Precautions for Supplemental Restraint System		Checking Cooling System For Leaks	9
“AIR BAG”	2	Checking Radiator Cap	9
Liquid Gasket Application Procedure	2	Water Pump	9
PREPARATION	3	Removal	10
Special Service Tools	3	Inspection	10
ENGINE LUBRICATION SYSTEM	4	Installation	10
Lubrication Circuit	4	Thermostat	11
Oil Pressure Check	5	Inspection	11
Oil Pump	5	Radiator	12
Removal	5	SERVICE DATA AND SPECIFICATIONS (SDS)	13
Regulator Valve Inspection	6	Engine Lubrication System	13
Oil Pressure Relief Valve Inspection	7	Oil pressure check	13
Oil Pump Inspection	7	Oil pump	13
ENGINE COOLING SYSTEM	8	Engine Cooling System	13
Cooling Circuit	8	Thermostat	13
System Check	8	Radiator	13



PRECAUTIONS

Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.







Liquid Gasket Application Procedure

- Before applying liquid gasket, use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves, and then completely clean any oil stains from these portions.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- Apply liquid gasket to inner surface around hole perimeter area. (Assembly should be done within 5 minutes after coating.)
- Wait at least 30 minutes before refilling engine oil and engine coolant.

PREPARATION


SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge		GI MA EM
ST25052000 (J25695-2) Hose		LC EF & EC
EG17650301 (J33984-A) Radiator cap tester adapter		FE CL MT
WS39930000 (-) Tube presser		Adapting oil pressure gauge to cylinder block Adapting radiator cap tester to radiator filler neck Pressing the tube of liquid gasket AT FA

RA
BR
ST
BF
HA
EL

ENGINE LUBRICATION SYSTEM

Lubrication Circuit



SLC749A

- | | | |
|--------------------------|--------------------------|--------------------------------|
| ① Connecting rod | ⑥ Oil strainer | ⑩ Idler sprocket |
| ② Connecting rod bearing | ⑦ Oil pump | ⑪ Upper timing chain tensioner |
| ③ Main bearing | ⑧ Piston oil jet | ⑫ Exhaust camshaft |
| ④ Oil filter | ⑨ Timing chain tensioner | ⑬ Intake camshaft |
| ⑤ Oil pan | | |

ENGINE LUBRICATION SYSTEM

Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may hot.
- Oil pressure check should be done in "Neutral" position.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA

EL



1. Check oil level.
2. Remove oil pressure switch.




3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.




Oil Pump

REMOVAL

1. Remove front cover.
Refer to EM section ("Removal", "TIMING CHAIN").
2. Remove oil pump cover.


ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)



- | | |
|------------------|----------------------------|
| ① Front cover | ⑥ Cap |
| ② Outer gear | ⑦ Washer |
| ③ Inner gear | ⑧ Spring |
| ④ Oil pump cover | ⑨ Regulator valve |
| ⑤ Oil strainer | ⑩ Regulator valve assembly |

- Always replace oil seals and gaskets with new ones.
- When installing oil pump, apply engine oil to inner and outer gears.



REGULATOR VALVE INSPECTION





1. Visually inspect components for wear and damage.
 2. Check oil pressure regulator valve sliding surface and valve spring.
 3. Coat regulator valve with engine oil and check that it falls smoothly into the valve hole by its own weight.
- If damaged, replace regulator valve set or oil pump assembly.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)

OIL PRESSURE RELIEF VALVE INSPECTION

Inspect oil pressure relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove valve by prying it out with a suitable tool. Install a new valve in place by tapping it.



SLC741A

OIL PUMP INSPECTION

Using a feeler gauge, check the following clearances.

Standard clearance:


Unit: mm (in)

Body to outer gear clearance ①	0.114 - 0.20 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance ②	0.04 - 0.18 (0.0016 - 0.0071)
Cover to inner gear clearance ③	0.05 - 0.09 (0.0020 - 0.0035)
Cover to outer gear clearance ④	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion clearance ⑤	..	0.045 - 0.091 (0.0018 - 0.0036)

- If the tip clearance (②) exceeds the limit, replace gear set.
- If body to gear clearances (①, ③, ④, ⑤) exceed the limit, replace front cover assembly.

ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the radiator cap when the engine is hot; serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap and carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape and then turn the cap all the way off.

CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

ENGINE COOLING SYSTEM

System Check (Cont'd)



CHECKING COOLING SYSTEM FOR LEAKS

To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:
157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.




CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.

Radiator cap relief pressure:
78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Water Pump



CAUTION:




- When removing water pump assembly, be careful not to get coolant on drive belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.

ENGINE COOLING SYSTEM

Water Pump (Cont'd)


REMOVAL

1. Drain coolant from drain plug on water pipe and radiator.
2. Remove generator and air compressor.
3. Remove water pump.




INSPECTION

1. Check for badly rusted or corroded vanes and body assembly.
2. Check for rough operation due to excessive end play.



INSTALLATION



1. Before installing water pump, remove all traces of liquid gasket from mating surface using a scraper.
 - Also remove traces of liquid gasket from mating surface of cylinder block.



2. Apply a continuous bead of liquid gasket to mating surface of water pump.
 - Use genuine liquid gasket or equivalent.

ENGINE COOLING SYSTEM

Thermostat



INSPECTION

1. Check valve seating condition at ordinary room temperatures. It should seat tightly.
2. Check valve opening temperature and maximum valve lift.


		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Maximum valve lift	mm/°C (in/°F)	10/90 (0.39/194)

3. Then check if valve is closed at 5°C (9°F) below valve opening temperature.
 - Apply a continuous bead of liquid gasket to mating surface of water inlet.
 - After installation, run engine for a few minutes, and check for leaks.
 - Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

ENGINE COOLING SYSTEM

Radiator



CAUTION:
When filling radiator with coolant, refer to MA section (“Changing Engine Coolant”, “ENGINE MAINTENANCE”).

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure check

Engine speed	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

Oil pump

		Unit: mm (in)
Body to outer gear clearance	0.114 - 0.20 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance	0.04 - 0.18 (0.0016 - 0.0071)
Cover to inner gear clearance	0.05 - 0.09 (0.0020 - 0.0035)
Cover to outer gear clearance	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion clearance	0.045 - 0.091 (0.0018 - 0.0036)

GI

MA

EM

LC

EF &
EC

Engine Cooling System

Thermostat

Valve opening temperature	°C (°F)	76.5 (170)
Max. valve lift	mm/°C (in/°F)	10/90 (0.39/194)

Radiator

		Unit: kPa (kg/cm ² , psi)
Cap relief pressure		78 - 98 (0.8 - 1.0, 11 - 14)
Leakage test pressure		157 (1.6, 23)

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

ENGINE FUEL AND EMISSION CONTROL SYSTEM

SECTION EF & EC










GI
MA
EM
LC
EF & EC

CONTENTS

PREPARATION	2	EGR Temperature Sensor (For California models)	16
PRECAUTIONS	3	ENGINE AND EMISSION CONTROL SYSTEM	
ENGINE AND EMISSION CONTROL OVERALL		DESCRIPTION	17
SYSTEM	5	Multiport Fuel Injection (MFI) System	17
ECCS Component Parts Location.....	5	Distributor Ignition (DI) System	20
System Diagram.....	7	Idle Air Control (IAC) System	22
System Chart	8	Exhaust Gas Recirculation (EGR) System	23
Vacuum Hose Drawing.....	9	Fuel Pump Control.....	23
Circuit Diagram	10	Acceleration Cut Control.....	24
ENGINE AND EMISSION CONTROL PARTS		Radiator Fan Control	24
DESCRIPTION	11	Fail-safe System	25
Engine Control Module (ECM)-ECCS Control		IDLE SPEED/IGNITION TIMING/IDLE MIXTURE	
Module.....	11	RATIO INSPECTION	27
Crankshaft Position (CKP) Sensor.....	11	TROUBLE DIAGNOSES	32
Mass Air Flow (MAF) Sensor	11	How to Perform Trouble Diagnoses for Quick	
Engine Coolant Temperature (ECT) Sensor	12	and Accurate Repair	32
Throttle Position (TP) Sensor & Soft/Hard		Introduction	32
Closed Throttle Position (CTP) Switch.....	12	Work Flow.....	33
Fuel Injector.....	13	Diagnostic Worksheet	34
Pressure Regulator	13	Worksheet sample	34
Oxygen Sensor (O2S)	13	Intermittent Problem Simulation.....	35
Fuel Pump.....	13	On-board Diagnostic System.....	36
Ignition Coil with Power Transistor.....	14	On-board Diagnostic System — On-board	
Idle Air Control (IAC) Valve-Air Regulator	14	Diagnostic Test Mode I.....	38
Idle Air Control (IAC) Valve-Fast Idle Control		On-board Diagnostic System — On-board	
Device (FICD) Solenoid Valve.....	14	Diagnostic Test Mode II (Self-diagnostic results) ...	39
Idle Air Control (IAC) Valve-Auxiliary Air Control		How To Erase On-Board Diagnostic Test	
(AAC) Valve.....	14	Mode II (Self-Diagnostic Results)	41
Power Steering Pressure Switch.....	14	On-board Diagnostic System — On-board	
Vehicle Speed Sensor (VSS)	15	Diagnostic Test Mode II (Oxygen sensor	
Knock Sensor (KS)	15	monitor)	41
Fuel Filter	15	How To Check Oxygen Sensor	41
Data Link Connector (DLC) for CONSULT.....	15	CONSULT	42
Exhaust Gas Recirculation (EGR) Valve	15	CONSULT Inspection Procedure.....	42
EGR Control-BPT Valve	16	Function	43
EGR and Canister Control Solenoid Valve.....	16	ECCS Component Parts Application	43
Carbon Canister	16	Work Support Diagnostic Test Mode.....	44

FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS (Cont'd.)

Self-Diagnostic Results Diagnostic Test Mode	45	Self-Diagnosis Codes	
Data Monitor Diagnostic Test Mode	46	Crankshaft Position Sensor (Diagnostic trouble code No. 11).....	94
Active Test Diagnostic Test Mode	48	Mass Air Flow Sensor (Diagnostic trouble code No. 12)  (Malfunction Indicator Lamp Item).....	97
Function Test Diagnostic Test Mode	49	Engine Coolant Temperature Sensor (Diagnostic trouble code No. 13)  (Malfunction Indicator Lamp Item).....	100
Diagnostic Procedure.....	52	Vehicle Speed Sensor (Diagnostic trouble code No. 14)  (Malfunction Indicator Lamp Item).....	103
Basic Inspection	54	Ignition Signal (Diagnostic trouble code No. 21)	106
Diagnostic Procedure 1 — High Idling after Warm-up.....	57	ECM (ECCS Control Module) (Diagnostic trouble code No. 31)  (Malfunction Indicator Lamp Item)	108
Diagnostic Procedure 2 — Hunting.....	57	EGR Function (Diagnostic trouble code No. 32)  (Malfunction Indicator Lamp Item): California Model	
Diagnostic Procedure 3 — Unstable Idle.....	59	EGR Control System (Not self-diagnostic item): Non-California Model	109
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold.....	62	Oxygen Sensor (Diagnostic trouble code No. 33)  (Malfunction Indicator Lamp Item) ..	115
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot	64	Knock Sensor (Diagnostic trouble code No. 34)	118
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions.....	65	EGR Temperature Sensor (Diagnostic trouble code No. 35)  (Malfunction Indicator Lamp Item): California Model Only....	120
Diagnostic Procedure 7 — Hesitation when the Engine is Hot.....	67	Throttle Position Sensor (Diagnostic trouble code No. 43)  (Malfunction Indicator Lamp Item).....	123
Diagnostic Procedure 8 — Hesitation when the Engine is Cold.....	68	Injector Leak (Diagnostic trouble code No. 45)  (Malfunction Indicator Lamp Item); California Model Only.....	126
Diagnostic Procedure 9 — Hesitation under Normal Conditions.....	69	A/T Control (Diagnostic trouble code No. 54) ..	128
Diagnostic Procedure 10 — Engine Stalls when Turning	70	Non-Self-Diagnosis Items	
Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot	72	Start Signal	130
Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold.....	74	Injector	132
Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily.....	76	Fuel Pump	134
Diagnostic Procedure 14 — Engine Stalls after Decelerating	78	IAC Valve-AAC Valve.....	137
Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed	82	Radiator Fan Control.....	140
Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy.....	84	Power Steering Pressure Switch	146
Diagnostic Procedure 17 — Lack of Power and Stumble	86	Neutral Position Switch/Inhibitor Switch	148
Diagnostic Procedure 18 — Knock.....	87	Electrical Components Inspection	154
Diagnostic Procedure 19 — Surge	89	ECM Input/Output Signal Inspection	154
Diagnostic Procedure 20 — Backfire through the Intake.....	90	ECM Harness Connector Terminal Layout	154
Diagnostic Procedure 21 — Backfire through the Exhaust on Deceleration	90	ECM inspection table.....	155
Diagnostic Procedure 22	91	Crankshaft Position Sensor.....	159
Main Power Supply And Ground Circuit (Not self-diagnostic item).....	91		

CONTENTS (Cont'd.)

Mass Air Flow Sensor	159	And Radiator Fan Relay-1	165	
Engine Coolant Temperature Sensor	160	Radiator Fan Relays-2 And -3	165	GI
Power Transistor	160	Power Steering Pressure Switch	165	
Ignition Coil	161	IAC Valve-Air Regulator	166	MA
Fuel Pump	161	IAC Valve-FICD Solenoid Valve	166	
EGR And Canister Control Solenoid Valve.....	161	Radiator Fan Motors-1 And -2	166	EM
EGR Valve	161	Resistor	166	
EGR Control-Bpt Valve	162	MULTIPOINT FUEL INJECTION SYSTEM		
EGR Temperature Sensor	162	INSPECTION	167	LC
Wide Open Throttle Position Switch — A/T		Releasing Fuel Pressure	167	
model only	162	Fuel Pressure Check	167	EF & EC
Closed Throttle Position Switch (Idle		Fuel Pressure Regulator Check	168	
position) — A/T model only.....	163	Injector Removal and Installation	168	
Throttle Position Sensor	163	EVAPORATIVE EMISSION (EVAP) SYSTEM	169	FE
Adjustment.....	163	Description.....	169	
IAC Valve-AAC Valve.....	164	Inspection	169	
Knock Sensor	164	CRANKCASE EMISSION CONTROL SYSTEM	171	CL
Injector	164	Description.....	171	
ECM Relay And Fuel Pump Relay	165	Inspection	171	
Inhibitor Relay (A/T models with ASCD)	165	SERVICE DATA AND SPECIFICATIONS (SDS)	172	MT
Inhibitor Relay (A/T models without ASCD)				

Note: Refer to Foldout page for “ECCS WIRING DIAGRAM”.

When you read wiring diagrams:


- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
- See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.

When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES”.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

PREPARATION

SPECIAL SERVICE TOOL

Tool number (Kent-Moore No.) Tool name	Description
EG11160000 (—) Ignition coil adapter harness	 <p data-bbox="1052 296 1308 323">Measuring engine speed</p>

PRECAUTIONS

Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

PRECAUTIONS

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

INJECTOR

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors.

ECCS PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IAC valve-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the crankshaft position sensor.

ECM


- Do not disassemble ECM (ECCS control module).
- Do not turn on-board diagnostic test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far as possible away from the electronic control units.
 - 2) Keep the antenna feeder line more the 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



FUEL PUMP


- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

ECM HARNESS HANDLING

- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST




BF

HA

EL


ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)



ENGINE AND EMISSION CONTROL OVERALL SYSTEM


System Diagram




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart



Vacuum Hose Drawing



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram




MEF139C



Engine Control Module (ECM)-ECCS Control Module

The ECM consists of a microcomputer, an inspection lamp, an on-board diagnostic test mode selector, and connectors for signal input and output and for power supply. The module controls the engine. For diagnosis, refer to EF & EC-108.





Crankshaft Position (CKP) Sensor

The crankshaft position sensor is a basic component of the entire ECCS. It monitors engine speed and piston position, and sends signals to the ECM to control fuel injection, ignition timing and other functions.

The crankshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 4 slits for 180° signal. Light Emitting Diodes (LED) and photo diodes are built in the wave-forming circuit.

When the rotor plate passes between the LED and the photo diode, the slits in the rotor plate continually cut the light being transmitted to the photo diode from the LED. This generates rough-shaped pulses which are converted into on-off signals by the wave-forming circuit, which are then sent to the ECM. For diagnosis, refer to EF & EC-94.




Mass Air Flow (MAF) Sensor

The mass air flow sensor measures the intake air flow rate by measuring a part of the entire flow. Measurements are made in such a way that the ECM receives electrical output signals varied by the amount of heat emitting from the hot film placed in the stream of the intake air.

When intake air flows into the intake manifold through a route around the hot film, the heat generated from the hot film is taken away by the air. The amount of heat reduction depends on the air flow. The temperature of the hot film is automatically controlled to a certain number of degrees.

Therefore, it is necessary to supply the hot film with more electric current in order to maintain the temperature of the hot film. The ECM detects the air flow by means of this current change. For diagnosis, refer to EF & EC-97.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


ENGINE AND EMISSION CONTROL PARTS DESCRIPTION



Engine Coolant Temperature (ECT) Sensor

The engine coolant temperature sensor detects the engine coolant temperature, which is dependent on engine coolant temperature, and transmits a signal to the ECM.


The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise. For diagnosis, refer to EF & EC-100.




Throttle Position (TP) Sensor & Soft/Hard Closed Throttle Position (CTP) Switch

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This system is called "soft closed throttle position switch" and controls engine operation such as fuel cut. On the other hand, "hard closed throttle position switch", which is built into the throttle position sensor unit on A/T equipped models, is used not for engine control. For diagnosis, refer to EF & EC-123.




ENGINE AND EMISSION CONTROL PARTS DESCRIPTION



Fuel Injector

The fuel injector is a small, elaborate solenoid valve. As the ECM sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The injected fuel is controlled by the ECM in terms of injection pulse duration. For diagnosis, refer to EF & EC-126 or EF & EC-132.


GI
MA
EM



Pressure Regulator

The pressure regulator maintains the fuel pressure at 299.1 kPa (3.05 kg/cm², 43.4 psi). Since the injected fuel amount depends on injection pulse duration, it is necessary to maintain the pressure at the above value. For diagnosis, refer to EF & EC-167.

LC
EF & EC




Oxygen Sensor (O2S)

The oxygen sensor, which is placed into the exhaust manifold, monitors the amount of oxygen in the exhaust gas.

The sensor has a closed-end tube made of ceramic zirconia. The outer surface of the tube is exposed to exhaust gas, and the inner surface to atmosphere. The zirconia of the tube compares the oxygen density of exhaust gas with that of atmosphere, and generates electricity. In order to improve the generating power of the zirconia, its tube is coated with platinum. The voltage is approximately 1V in a richer condition of the mixture ratio than the ideal air-fuel ratio, while approximately 0V in leaner conditions. The radical change from 1V to 0V occurs at around the ideal mixture ratio. In this way, the oxygen sensor detects the amount of oxygen in the exhaust gas and sends the signal of approximately 1V or 0V to the ECM. For diagnosis, refer to EF & EC-115.


FE
CL
MT




Fuel Pump

The fuel pump with a fuel damper is a submersible type, and are located in the fuel tank. For diagnosis, refer to EF & EC-134.

AT
FA
RA
BR
ST
BF
HA
EL




ENGINE AND EMISSION CONTROL PARTS DESCRIPTION



Ignition Coil with Power Transistor

The ignition signal from the ECM is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type. For diagnosis, refer to EF & EC-106.




Idle Air Control (IAC) Valve-Air Regulator

The IAC valve-air regulator provides an air by-pass when the engine is cold for a fast idle during warm-up. Wax, piston and spring are built into the IAC valve-air regulator. When the coolant temperature is low, the air by-pass port opens. When the coolant temperature is high, the wax expands, moving the piston up and closing the air by-pass port, which decreases the idle speed.


Idle Air Control (IAC) Valve-Fast Idle Control Device (FICD) Solenoid Valve

When the air conditioning switch is on, additional air is supplied by the IAC valve-FICD solenoid valve.




Idle Air Control (IAC) Valve-Auxiliary Air Control (AAC) Valve

The ECM actuates the IAC valve-AAC valve by an ON/OFF pulse. The longer that ON pulse is received, the larger the amount of air that will flow through the IAC valve-AAC valve. For diagnosis, refer to EF & EC-137.



Power Steering Pressure Switch

The power steering pressure switch is attached to the power steering high-pressure tube and detects the power steering load, sending the load signal to the ECM. The ECM then sends the idle-up signal to the IAC valve-AAC valve. For diagnosis, refer to EF & EC-146.



Vehicle Speed Sensor (VSS)


The vehicle speed sensor provides a vehicle speed signal to the speedometer and the speedometer sends a signal to the ECM. The speed sensor consists of a pulse generator, which is installed in the transaxle. For diagnosis, refer to EF & EC-103.

GI

MA

EM

LC



Knock Sensor (KS)


The knock sensor is attached to the cylinder block and senses engine knocking conditions.

A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is sent to the ECM. For diagnosis, refer to EF & EC-118.

EF & EC

FE

CL



Fuel Filter


The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

MT

AT

FA

RA



Data Link Connector (DLC) for CONSULT


The data link connector for CONSULT is located beside the fuse lid.

BR

ST

BF

HA




Exhaust Gas Recirculation (EGR) Valve

The EGR valve controls the quantity of exhaust gas to be led to the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum is applied in response to the opening of the throttle valve. For diagnosis, refer to EF & EC-109.


EL

ENGINE AND EMISSION CONTROL PARTS DESCRIPTION




EGR Control-BPT Valve

The EGR control-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation. For diagnosis, refer to EF & EC-109.



EGR and Canister Control Solenoid Valve

The solenoid valve responds to the ON/OFF signal from the ECM. When it is off, a vacuum signal from the throttle body is fed into the EGR valve. When the ECM sends an ON signal, the coil pulls the plunger downward and cuts the vacuum signal. For diagnosis, refer to EF & EC-109.




Carbon Canister

The carbon canister is filled with active charcoal to absorb evaporative gases produced in the fuel tank. These absorbed gases are then delivered to the intake manifold by manifold vacuum for combustion purposes.

The vacuum in the intake passage upstream of the throttle valve increases in response to the amount of the intake air.

When the vacuum of the intake passage is higher than a preset value, the 2nd purge control valve opens and the absorbed gases are sucked into the intake passage for combustion purposes. For diagnosis, refer to EF & EC-169.




EGR Temperature Sensor (For California models)

The EGR temperature sensor monitors in exhaust gas temperature and transmits a signal to the ECM. The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electric resistance of the thermistor decreases in response to the temperature rise. For diagnosis, refer to EF & EC-120.

Multiport Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL LINE



BASIC MULTIPOINT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector, or the length of time the valve remains open, is determined by the ECM. The amount of fuel injected is a program value mapped in the ECM memory. In other words, the program value is preset by engine operating conditions determined by input signals (for engine speed and air intake) from both the crankshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/ DECREASE COMPENSATION

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.

<Fuel increase>

- 1) During warm-up
- 2) When starting the engine
- 3) During acceleration
- 4) Hot-engine operation

<Fuel decrease>

- 1) During deceleration
- 2) During high engine speed operation

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system is used for precise control of the mixture ratio to the stoichiometric point, so that the three way catalytic converter can reduce CO, HC and NOx emissions. This system uses an oxygen sensor in the exhaust manifold to check the air- fuel ratio. The ECM adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the range of the stoichiometric air-fuel ratio.

This stage refers to the closed loop control condition.



OPEN LOOP CONTROL


The open loop system condition refers to when the ECM detects any of the following conditions and feedback control stops in order to maintain stabilized fuel combustion.

- 1) Deceleration and acceleration
- 2) High-load, high-speed operation
- 3) Engine idling
- 4) Malfunction of oxygen sensor or its circuit
- 5) Insufficient activation of oxygen sensor at low engine coolant temperature
- 6) Engine starting
- 7) High-engine coolant temperature
- 8) After shifting from "N" to "D"

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the oxygen sensor. This feedback signal is then sent to the ECM to control the amount of fuel injection to provide a basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing differences (e.g., mass air flow sensor hot film) and changes to the ECCS parts during operation (injector clogging, etc.) which directly affect the mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.




FUEL INJECTION TIMING

Two types of fuel injection systems are used — sequential multiport fuel injection system and simultaneous multiport fuel injection system. In the former, fuel is injected into each cylinder during each engine cycle according to the firing order.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)



In the simultaneous multiport fuel injection system, fuel is injected into all four cylinders simultaneously twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM to the four injectors two times for each engine cycle.

When the engine is being started and/or if the fail-safe system (CPU) is operating, simultaneous multiport fuel injection system is used. When the engine is running sequential multiport fuel injection system is used.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high engine speed.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Distributor Ignition (DI) System

INPUT/OUTPUT SIGNAL LINE



ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Distributor Ignition (DI) System (Cont'd)

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM in order to maintain the best air-fuel ratio for every running condition of the engine.

The ignition timing data is stored in the ECM located in the ECM. This data forms the map shown below.


The ECM detects information such as the injection pulse width and crankshaft position sensor signal which varies every moment. Then responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec
A °B.T.D.C.

In addition to this,

- 1 At starting
- 2 During warm-up
- 3 At idle
- 4 Hot engine operation
- 5 At acceleration

the ignition timing is revised by the ECM according to the other data stored in the ECM.




The knock sensor retard system is designed only for emergencies. The basic ignition timing is pre-programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the knock sensor monitors the condition and the signal is transmitted to the ECM (ECCS control module). After receiving it, the ECM retards the ignition timing to eliminate the knocking condition.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Idle Air Control (IAC) System

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via the IAC valve-AAC valve. The IAC valve-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The crankshaft position sensor detects the actual engine speed and sends a signal to the ECM.

The ECM then controls the ON/OFF time of the IAC valve-AAC valve so that engine speed coincides with the target value memorized in the ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as noise and vibration transmitted to the vehicle interior, fuel consumption, and engine load.

Exhaust Gas Recirculation (EGR) System

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

In addition, a system is provided which precisely cuts and controls port vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM. When the ECM detects any of the following conditions, current flows through the solenoid valve in the EGR control system vacuum line. This causes the port vacuum to be discharged into the atmosphere so that the EGR valve remains closed.

- 1) Low engine coolant temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling
- 5) Excessively high engine coolant temperature

Fuel Pump Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION


The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine start-up. If the ECM receives a 1° signal from the crankshaft position sensor, it knows that the engine is rotating, and causes the pump to activate. If the 1° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents the battery from discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Acceleration Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

When the accelerator pedal is fully depressed or the engine is running at high speed, the air conditioning is turned off for a few seconds.

This system improves acceleration when the air conditioning is used.

Radiator Fan Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The ECM controls the radiator fan corresponding to the vehicle speed, engine coolant temperature,

air conditioning discharge side pressure and air conditioning ON signal. The control system has 3-step control [HIGH/LOW/OFF].

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Radiator Fan Control (Cont'd)


OPERATION

Vehicle speed km/h (MPH)	Air conditioning switch	Air conditioning triple-pressure switch	Engine coolant temperature °C(°F)		
			95 (203)	100 (212)	105 (221)
0 - 20 (0 - 12)	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	LOW		HIGH
		ON	HIGH		
20 - 80 (12 - 50)	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	LOW		HIGH
		ON	LOW		HIGH
80 (50) or more	OFF	OFF	OFF	LOW	HIGH
	ON	OFF	OFF	LOW	HIGH
		ON	OFF	LOW	HIGH

Fail-safe System

CPU MALFUNCTION

Input/output signal line



Outline

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit.

In former models, engine starting was difficult under the previously mentioned conditions. But with the provisions in this fail-safe system, it is possible to start the engine.

Fail-safe system activating condition when ECM is malfunctioning

The fail-safe mode operates when the computing function of the ECM is judged to be malfunctioning. When the fail-safe system activates, i.e. if a malfunction condition is detected in the CPU of the ECM, the MALFUNCTION INDICATOR LAMP on

the instrument panel lights to warn the driver.

Engine control with fail-safe system, operates when ECM is malfunctioning

When the fail-safe system is operating, fuel injection, ignition timing, and so on are controlled under certain limitations.

Cancellation of fail-safe system when ECM is malfunctioning

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from OFF to ON.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fail-safe System (Cont'd)

MASS AIR FLOW SENSOR MALFUNCTION

If the mass air flow sensor output voltage is below the specified value when the starter switch is being turned OFF, the ECM senses a mass air flow sensor malfunction. In the case of a malfunction, the fuel injection operates without the mass air flow sensor signal.

Although the mass air flow sensor is malfunctioning, it is possible to start the engine and drive the vehicle. But engine speed will not rise more than 2,400 rpm in order to inform the driver of fail-safe system operation while driving.

Operation (Mass air flow sensor malfunction)

Engine condition	Starter switch	Fail-safe system	Fail-safe functioning
Stopped	ANY	Does not operate	—
Cranking	ON		
Running	OFF	Operates	Engine speed will not rise above 2,400 rpm

ENGINE COOLANT TEMPERATURE SENSOR MALFUNCTION

When the engine coolant temperature sensor output voltage is below or above the specified value, engine coolant temperature is fixed at the preset value as follows:

Engine condition	Engine coolant temperature preset value °C (°F)
Start	40 (104)
Running	80 (176)

KNOCK SENSOR MALFUNCTION

When the output signal of the knock sensor is abnormal, the ECM judges it to be malfunctioning. When the knock sensor is malfunctioning, ignition timing will retard according to operating conditions.

THROTTLE POSITION SENSOR MALFUNCTION

When the throttle position sensor output voltage is below or above the specified value, the throttle valve opening is fixed at a specified value. In this condition the ECM does not use the throttle position sensor output. The idle position is decided by the mass air flow sensor, crankshaft position sensor output signals.

Operation	Driving condition
While idling	Low engine speed
While accelerating	Poor acceleration

START SIGNAL FOR MALFUNCTION

If the ECM always receives a start signal, the ECM will judge the start signal "OFF" when engine speed is above 1,000 rpm to prevent extra enrichment.

After the engine speed is below 200 rpm, start-up enrichment will be allowed until the engine speed reaches 1,000 rpm.

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION

PREPARATION

1. Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system (Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - EGR valve operation
 - Throttle valve

2. On air conditioning equipped models, checks should be carried out while the air conditioning is "OFF".
3. On automatic transaxle equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the radiator fan has stopped.

GI


MA

EM

LC

EF &
EC

Overall inspection sequence



FE

CL

MT

AT

FA

RA

BR


ST

BF

HA




EL

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION




IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION

IGN TIMING ADJ
 --- CONDITION SETTING ---
 IGN/T FEEDBACK: HOLD
 === MONITOR ===
 CKPS-RPM (REF) 650rpm
 IGN TIMING 20BTDC
 CLOSED TH/POS ON



MONITOR NO FAIL
 CKPS-RPM (REF) 700rpm
 RECORD



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL




IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



*ECM (ECCS control module) may be the cause of a problem, but this is rarely the case.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES



How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.


Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.

1. Verify the complaint.
2. Isolate the cause.
3. Repair.
4. Recheck and be sure no new symptoms have been caused.

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



*1: If the on-board diagnostic system cannot be performed, check main power supply and ground circuit. (Refer to EF & EC-91.)

*2: If the trouble is not duplicated, refer to EF & EC-35.

TROUBLE DIAGNOSES


How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

INTERMITTENT PROBLEM SIMULATION

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under

Service procedure and note the result.




	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Crankshaft position sensor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feedback control	Oxygen sensor	Suspended	Disconnect oxygen sensor harness connector.
		ECM	Operation check	Perform on-board diagnostic system (On-board Diagnostic Test Mode II) at 2,000 rpm.
4	Idle speed	IAC valve-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electrical connection (Electric continuity)	Harness connectors and wires	Poor electrical connection or improper wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	ECM	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioning, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Rotate throttle position sensor body.
10	Ignition spark position	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition coil adapter (SST).

- Select the "Variable factor" when the symptom occurs. Perform the "Service procedure" to try to simulate the intermittent problem.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES



On-board Diagnostic System

MALFUNCTION INDICATOR LAMP (MIL)




A malfunction indicator lamp has been adopted on all models. This lamp blinks simultaneously with the RED LED on the ECM. Malfunction indicator lamp is located on the instrument panel.



ECM LED

The ECM has only one RED LED.


ON-BOARD DIAGNOSTIC SYSTEM MODES

Condition		On-board Diagnostic Test Mode	
		On-board Diagnostic Test Mode I	On-board Diagnostic Test Mode II
Ignition switch in "ON" position 	Engine stopped 	MALFUNCTION INDICATOR LAMP CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	OXYGEN SENSOR MONITOR

TROUBLE DIAGNOSES

On-board Diagnostic System (Cont'd)

HOW TO SWITCH ON-BOARD DIAGNOSTIC TEST MODES (Without CONSULT)



- Turn back on-board diagnostic test mode selector to the fully counterclockwise position whenever vehicle is in use.
- Switching the modes is not possible when the engine is running.
- When the ignition switch is turned off during diagnosis in each mode, and then turned back on again after power to the ECM has dropped off completely, the diagnosis will automatically return to On-board Diagnostic Test Mode I but stored codes will remain in memory unless the erasing procedure has been performed.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

TROUBLE DIAGNOSES



On-board Diagnostic System — On-board Diagnostic Test Mode I

ON-BOARD DIAGNOSTIC TEST MODE I — MALFUNCTION INDICATOR LAMP CHECK

In this mode, the RED LED in the ECM and the MALFUNCTION INDICATOR LAMP in the instrument panel stay "ON". If either remain "OFF", check the bulb in the MALFUNCTION INDICATOR LAMP or the RED LED.

ON-BOARD DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

FOR CALIFORNIA MODELS

MALFUNCTION INDICATOR LAMP and RED LED	Condition
ON	When the following malfunctions (malfunction indicator lamp item) are detected or the ECM's CPU is malfunctioning.
OFF	O.K.

Diagnostic trouble code No.	Malfunction
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
31	ECM (ECCS control module)
32	EGR function
33	Oxygen sensor circuit
35	EGR temperature sensor circuit
43	Throttle position sensor circuit
45	Injector leak

- These Diagnostic trouble code Numbers are clarified in On-board Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS. Refer to EF & EC-39.
- The RED LED and the MALFUNCTION INDICATOR LAMP will turn off when operation returns to normal. But, the On-board Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS memory will hold the diagnostic trouble code until the memory is cleared. To clear SELF-DIAGNOSTIC RESULTS memory, refer to EF & EC-37 (Without CONSULT). To clear SELF-DIAGNOSTIC RESULTS memory (With CONSULT), refer to CONSULT Operation Manual — Engine.

FOR NON-CALIFORNIA MODELS

MALFUNCTION INDICATOR LAMP and RED LED	Condition
ON	When the ECM's CPU is malfunctioning.
OFF	O.K.

TROUBLE DIAGNOSES


On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results)

CAUTION:

The mode selector on the ECM must be returned to the fully counterclockwise position, except when switching the modes.

DESCRIPTION










In this mode, a diagnostic trouble code is indicated by the number of flashes from the RED LED or the MALFUNCTION INDICATOR LAMP as shown below:



Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits. For example, the red LED flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the mass air flow sensor. In this way, all the problems are classified by their diagnostic trouble code numbers.

The diagnostic results will remain in ECM memory.

Display diagnostic trouble code table

Diagnostic trouble code No.	Detected items	California models	Non-California models	Diagnostic Procedure page
11*	Crankshaft position sensor circuit	X	X	EF & EC-94
12 	Mass air flow sensor circuit	X	X	EF & EC-97
13 	Engine coolant temperature sensor circuit	X	X	EF & EC-100
14 	Vehicle speed sensor circuit	X	X	EF & EC-103
21*	Ignition signal circuit	X	X	EF & EC-106
31 	ECM	X	X	EF & EC-108
32 	EGR function	X	—	EF & EC-109
33 	Oxygen sensor circuit	X	X	EF & EC-115
34	Knock sensor circuit	X	X	EF & EC-118
35 	EGR temperature sensor circuit	X	—	EF & EC-120
43 	Throttle position sensor circuit	X	X	EF & EC-123
45 	Injector leak	X	—	EF & EC-126
54	Signal circuit from A/T control module to ECM (A/T only)	X	X	EF & EC-128
55	No malfunction in the above circuits	X	X	EF & EC-33

X: Available —: Not available  : Malfunction indicator lamp item

*: Inspect items causing a malfunction of crankshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

TROUBLE DIAGNOSES

On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)


Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
11*	Crankshaft position sensor circuit	<ul style="list-style-type: none"> ● Either 1° or 180° signal is not entered for the first few seconds during engine cranking. ● Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace crankshaft position sensor.)
12	Mass air flow sensor circuit	<ul style="list-style-type: none"> ● The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
13	Engine coolant temperature sensor circuit	<ul style="list-style-type: none"> ● The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> ● The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor (pulse generator)
21*	Ignition signal circuit	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness and connector ● Power transistor unit
31	ECM	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
32	EGR function	<ul style="list-style-type: none"> ● EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> ● EGR valve ● EGR and canister control solenoid valve
33	Oxygen sensor circuit	<ul style="list-style-type: none"> ● The oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks
34	Knock sensor circuit	<ul style="list-style-type: none"> ● The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Knock sensor
35	EGR temperature sensor circuit	<ul style="list-style-type: none"> ● The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● EGR temperature sensor
43	Throttle position sensor circuit	<ul style="list-style-type: none"> ● The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor
45	Injector leak	<ul style="list-style-type: none"> ● Fuel leaks from injector. 	<ul style="list-style-type: none"> ● Injector
54	Signal circuit from TCM (A/T control module) to ECM (A/T only)	<ul style="list-style-type: none"> ● The A/T communication line is open or shorted. 	<ul style="list-style-type: none"> ● Harness and connector
55	None	<ul style="list-style-type: none"> ● None of the above items detected. 	Refer to EF & EC-33.

*: Inspect items causing a malfunction of crankshaft position sensor circuit first, if both "CRANKSHAFT POSITION SENSOR (No. 11)" and "IGN SIGNAL-PRIMARY (No. 21)" are displayed one after the other.

TROUBLE DIAGNOSES

On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)

HOW TO ERASE ON-BOARD DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS)

-  The diagnostic trouble code is erased from the backup memory on the ECM when the on-board diagnostic test mode is changed from On-board Diagnostic Test Mode II to On-board Diagnostic Test Mode I. Refer to EF & EC-37.
- When the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
 - Before starting On-board Diagnostic Test Mode II (Self-diagnostic results), do not erase the stored memory.
 - Refer to CONSULT Operation Manual — Engine.

On-board Diagnostic System — On-board Diagnostic Test Mode II (Oxygen sensor monitor)

DESCRIPTION

In this mode, the MALFUNCTION INDICATOR LAMP and RED LED display the condition of the fuel mixture (lean or rich) which is monitored by the oxygen sensor.

MALFUNCTION INDICATOR LAMP and RED LED	Fuel mixture condition in the exhaust gas	② Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
① Remains ON or OFF	Any condition	Open loop system


①: Maintains the mixture condition present just before switching to open loop.

②: Refer to EF & EC-18 for description of mixture ratio feedback system and open loop system.

HOW TO CHECK OXYGEN SENSOR

1. Set On-board Diagnostic Test Mode II. Refer to EF & EC-37.
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure RED LED or MALFUNCTION INDICATOR LAMP goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.


TROUBLE DIAGNOSES




Consult

CONSULT INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located beside the fuse lid.)
3. Turn on ignition switch.
4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic test mode according to the inspection sheet as follows:

For further information, see the CONSULT Operation Manual – Engine.



TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION

Diagnostic test mode	Function	Page
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.	EF & EC-44
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	EF & EC-45
Data monitor	Input/Output data in the ECM can be read.	EF & EC-46
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the control modules and also shifts some parameters in a specified range.	EF & EC-48
ECM part number	ECM part number can be read.	—
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".	EF & EC-49

GI

MA

EM

LC

EF & EC

ECCS COMPONENT PARTS APPLICATION

ECCS COMPONENT PARTS		DIAGNOSTIC TEST MODE				
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
INPUT	Crankshaft position sensor (REF)		X	X		
	Mass air flow sensor		X	X		
	Engine coolant temperature sensor		X	X	X	
	Oxygen sensor		X	X		X
	Vehicle speed sensor		X	X		X
	Throttle position sensor	X	X	X		X
	EGR temperature sensor*		X	X		
	Knock sensor		X			
	Ignition switch (start signal)			X		X
	Air conditioning switch			X		
	Neutral position switch (M/T)			X		X
	Inhibitor switch (A/T)			X		X
	Power steering pressure switch			X		X
	Soft closed throttle position switch			X		
Battery			X			
OUT-PUT	Injectors		X	X	X	X
	Power transistor (ignition timing)	X	X (Ignition signal)	X	X	X
	IAC valve-AAC valve	X		X	X	X
	EGR and canister control solenoid valve		X	X	X	X
	Air conditioning relay			X		
	Fuel pump relay	X		X	X	X
	Radiator fan relay			X	X	X

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

: The ECCS component part marked "" is applicable to vehicles for California only. X: Applicable

TROUBLE DIAGNOSES

Consult (Cont'd)

WORK SUPPORT DIAGNOSTIC TEST MODE

WORK ITEM	CONDITION	USAGE
CLOSED TH/SW ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none">● IGN SW "ON"● ENG NOT RUNNING● ACC PEDAL NOT PRESSED	When adjusting throttle position sensor initial position Refer to EF & EC-54.
IGN TIMING ADJ	<ul style="list-style-type: none">● IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR.	When adjusting initial ignition timing Refer to EF & EC-27.
IACV-AAC/V ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none">● ENGINE WARMED UP● NO-LOAD	When adjusting idle speed
FUEL PRES RELEASE	<ul style="list-style-type: none">● FUEL PUMP WILL STOP BY TOUCHING "START" WHEN IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line Refer to EF & EC-167.

TROUBLE DIAGNOSES

Consult (Cont'd)

SELF-DIAGNOSTIC RESULTS DIAGNOSTIC TEST MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CRANKSHAFT POSITION SEN*	<ul style="list-style-type: none"> Either 1° or 180° signal is not entered for the first few seconds during engine cranking. Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> Harness and connector (If harness and connector are normal, replace crankshaft position sensor.)
MASS AIR FLOW SEN	<ul style="list-style-type: none"> The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
COOLANT TEMP SEN	<ul style="list-style-type: none"> The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor
VEHICLE SPEED SEN	<ul style="list-style-type: none"> The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor (pulse generator)
IGN SIGNAL-PRIMARY*	<ul style="list-style-type: none"> The ignition signal in primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> Harness and connector Power transistor unit
ECM	<ul style="list-style-type: none"> ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
EGR SYSTEM**	<ul style="list-style-type: none"> EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> EGR valve EGR and canister control solenoid valve
OXYGEN SEN	<ul style="list-style-type: none"> The oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Oxygen sensor Fuel pressure Injectors Intake air leaks
KNOCK SENSOR	<ul style="list-style-type: none"> The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Knock sensor
EGR TEMP SENSOR**	<ul style="list-style-type: none"> The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector EGR temperature sensor
THROTTLE POSI SEN	<ul style="list-style-type: none"> The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Throttle position sensor
INJECTOR LEAK**	<ul style="list-style-type: none"> Fuel leaks from injector. 	<ul style="list-style-type: none"> Injector

*: Check items causing a malfunction of crankshaft position sensor circuit first, if both "CRANKSHAFT POSITION SENSOR" and "IGN SIGNAL-PRIMARY" come out at the same time.

** : The diagnostic item marked "*" is applicable to vehicles for California only.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Consult (Cont'd)

DATA MONITOR DIAGNOSTIC TEST MODE

- Remarks :
- Specification data are reference values.
 - Specification data are output/input values which are detected or supplied by ECM at the connector.
 - *Specification data may not be directly related to their components signals/values/operations.
 - ie. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing being not adjusted to the specification data. This IGN TIMING monitors the calculated data by ECM according to the input signals from crankshaft position sensor and other ignition timing related sensors.
 - If the real-time diagnosis results are NG and the on-board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.
 - The monitor item marked "★★" is applicable to vehicles for California only.
 - If the A/F ALPHA is below 100, the ECM is compensating for a rich signal from the oxygen sensor. If it is above 100, the ECM is compensating for a lean signal from the oxygen sensor.

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CKPS, RPM (REF)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.	<ul style="list-style-type: none"> ● Harness and connector ● Crankshaft position sensor
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine ● A/C switch "OFF" ● Shift lever "N" 	Idle	0.85 - 1.35V	<ul style="list-style-type: none"> ● Harness and connector ● Mass air flow sensor
		2,000 rpm	1.3 - 1.8V	
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor
O2 SEN	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V	<ul style="list-style-type: none"> ● Harness and connector ● Oxygen sensor ● Intake air leaks ● Injectors
M/R F/C MNT			LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value	<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V	<ul style="list-style-type: none"> ● Battery ● ECM power supply circuit
THRTL POS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Throttle valve fully closed	0.3 - 0.7V	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor ● Throttle position sensor adjustment
		Throttle valve fully opened	Approx. 4.0V	
EGR TEMP SEN★★	<ul style="list-style-type: none"> ● Engine: After warming up 		Less than 5.0V	<ul style="list-style-type: none"> ● Harness and connector ● EGR temperature sensor
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START 		OFF → ON	<ul style="list-style-type: none"> ● Harness and connector ● Starter switch
CLOSED TH/POS	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor ● Throttle position sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	A/C switch "OFF"	OFF	<ul style="list-style-type: none"> ● Harness and connector ● Air conditioning switch
		A/C switch "ON"	ON	
NEUT POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever "P" or "N"	ON	<ul style="list-style-type: none"> ● Harness and connector ● Neutral position/Inhibitor switch
		Except above	OFF	

TROUBLE DIAGNOSES

Consult (Cont'd)

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel in park/neutral position (forward direction)	OFF	<ul style="list-style-type: none"> ● Harness and connector ● Power steering pressure switch
		The steering wheel is turned.	ON	
LOAD SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Rear window defogger is operating.	ON	<ul style="list-style-type: none"> ● Harness and connector ● Rear window defogger system Refer to EL section ("REAR WINDOW DEFOGGER").
		Rear window defogger is not operating.	OFF	
INJ PULSE	<ul style="list-style-type: none"> ● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load 	Idle	2.3 - 3.3 msec.	<ul style="list-style-type: none"> ● Harness and connector ● Injector ● Mass air flow sensor ● Intake air system
		2,000 rpm	2.4 - 3.3 msec.	
IGN TIMING	ditto	Idle	20° B.T.D.C.	<ul style="list-style-type: none"> ● Harness and connector ● Crankshaft position sensor
		2,000 rpm	More than 30° B.T.D.C.	
IACV-AAC/V	ditto	Idle	10 - 40%	<ul style="list-style-type: none"> ● Harness and connector ● IAC valve-AAC valve
		2,000 rpm	—	
A/F ALPHA	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	75 - 125%	<ul style="list-style-type: none"> ● Harness and connector ● Injectors ● Mass air flow sensor ● Oxygen sensor ● Canister purge line ● Intake air system
AIR COND RLY	<ul style="list-style-type: none"> ● Air conditioning switch OFF → ON 		OFF → ON	<ul style="list-style-type: none"> ● Harness and connector ● Air conditioning switch ● Air conditioning relay
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking ● When engine is stopped (stops in 1.5 seconds) 		ON	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
		Except as shown above	OFF	
RADIATOR FAN	<ul style="list-style-type: none"> ● After warming up engine, idle the engine. ● A/C switch "OFF" 	Engine coolant temperature is 94°C (201°F) or less	OFF	<ul style="list-style-type: none"> ● Harness and connector ● Radiator fan relays ● Radiator fan
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F).	LOW	
		Engine coolant temperature is 105°C (221°F) or more	HIGH	
EGRC SOL/V	<ul style="list-style-type: none"> ● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load 	Idle	ON	<ul style="list-style-type: none"> ● Harness and connector ● EGR and canister control solenoid valve
		2,000 rpm	OFF	

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Consult (Cont'd)

ACTIVE TEST DIAGNOSTIC TEST MODE

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL INJECTION TEST	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the amount of fuel injection with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel injectors ● Oxygen sensors
IACV-AAC/V OPENING TEST	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Change the IAC valve-AAC valve opening percent with the CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● IAC valve-AAC valve
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor ● Fuel injectors
IGN TIMING TEST	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Adjust initial ignition timing
POWER BALANCE TEST	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time with the CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connector ● Compression ● Injectors ● Power transistor ● Spark plugs ● Ignition coils
RADIATOR FAN TEST	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn the radiator fan "ON" and "OFF" with the CONSULT. 	Radiator fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connector ● Radiator fan motor
FUEL PUMP RLY TEST	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" with the CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound. 	Each solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
SELF-LEARN CONT TEST	<ul style="list-style-type: none"> ● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION TEST DIAGNOSTIC TEST MODE

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Displays the results of on-board diagnostic system. 	—		Objective system	GI MA
CLOSED THROTTLE POSI (SOFT CLOSED THROTTLE POS SWITCH CIRCUIT)	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Soft closed throttle position switch circuit is tested when throttle is opened and closed fully. ("CLOSED THROTTLE POSI" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> Harness and connector Throttle position sensor (Soft closed throttle position switch) Throttle position sensor (Soft closed throttle position switch) adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	EM LC
		Throttle valve: closed	ON		EF & EC FE
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	CL MT AT
NEUTRAL POSI SW CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Neutral position switch/inhibitor switch circuit is tested when shift lever is manipulated. 	OUT OF N/P-RANGE	OFF	<ul style="list-style-type: none"> Harness and connector Neutral position switch/Inhibitor switch Linkage + Inhibitor switch adjustment 	FA
		IN N-RANGE	ON		RA
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level 	BR ST
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) EGR control-solenoid valve circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector EGR control-solenoid valve 	BF HA
RADIATOR FAN CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Radiator fan circuit is tested by checking radiator fan operation. 	<ul style="list-style-type: none"> The radiator fan rotates and stops every 3 seconds 		<ul style="list-style-type: none"> Harness and connector Radiator fan motor Radiator fan relay 	EL

TROUBLE DIAGNOSES

Consult (Cont'd)






FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
START SIGNAL CKT	<ul style="list-style-type: none"> ● Ignition switch: ON → START ● Start signal circuit is tested when engine is started by operating the starter. Battery positive voltage and water temperature before cranking, and average battery positive voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed. 	Start signal: OFF → ON		<ul style="list-style-type: none"> ● Harness and connector ● Ignition switch
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine running) ● Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> ● Harness and connector ● Power steering pressure switch ● Power steering oil pump
		Neutral position	OFF	
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> ● Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor ● Electric speedometer
IGN TIMING ADJ	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> ● Adjust ignition timing (by moving crankshaft position sensor or distributor) ● Crankshaft position sensor drive mechanism
MIXTURE RATIO TEST	<ul style="list-style-type: none"> ● Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the oxygen sensor output at 2,000 rpm under non-loaded state. 	<ul style="list-style-type: none"> ● OXYGEN SENSOR COUNT: More than 5 times during 10 seconds 		<ul style="list-style-type: none"> ● INJECTION SYS (Injector, fuel pressure regulator, harness or connector) ● IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) ● VACUUM SYS (Intake air leaks) ● Oxygen sensor circuit ● Oxygen sensor operation ● Fuel pressure high or low ● Mass air flow sensor

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)	
POWER BALANCE	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multipoint fuel injection system is used.) 	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.	<ul style="list-style-type: none"> ● Injector circuit (Injector, harness or connector) ● Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) ● Compression ● Valve timing 	GI
				MA
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● IAC valve-AAC valve system is tested by detecting change in engine speed when IAC valve-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% (102 steps) and at 20% (25 steps).	<ul style="list-style-type: none"> ● Harness and connector ● IAC valve-AAC valve ● Air passage restriction between air inlet and IAC valve-AAC valve ● IAS (Idle adjusting screw) adjustment 	EM
				LC
				EF & EC
				FE
				CL
				MT
				AT
				FA
				RA
				BR
				ST
				BF
				HA
				EL

TROUBLE DIAGNOSES



Diagnostic Procedure

CAUTION:


1. Before connecting or disconnecting the ECM harness connector to or from any ECM, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage ECM as battery positive voltage is applied to ECM even if ignition switch is turned off. Failure to do so may damage the ECM.
2. When connecting ECM harness connector, tighten securing bolt until red projection is in line with connector face.
3. When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
5. Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. Refer to EF & EC-154.
6. After reviewing the above items, perform On-board Diagnostic Test Mode II (Self-diagnostic results) and driving test.

TROUBLE DIAGNOSES

Diagnostic Procedure (Cont'd)

7. When measuring ECM controlled components supply voltage with a circuit tester, separate one tester probe from the other.






If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the ECM power transistor.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Basic Inspection



1

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for proper connections
 - Vacuum hoses for splits, kinks, and proper connections
 - Wiring for proper connections, pinches, and cuts

2

CONNECT CONSULT TO THE VEHICLE.
Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. Refer to EF & EC-42.

3

DOES ENGINE START?

No → Go to **6**

Yes →


4

CHECK IGNITION TIMING.

1. Warm up engine sufficiently.
2. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
3. Touch "START".
4. Check ignition timing at idle using timing light.

Ignition timing:
20° ± 2° B.T.D.C.

N.G. → Adjust ignition timing by turning crankshaft position sensor. Refer to EF & EC-27.

 1. Warm up engine sufficiently.

2. Stop engine and disconnect throttle position sensor harness connector.

3. Start engine.

4. Check ignition timing at idle using timing light.

Ignition timing:
20° ± 2° B.T.D.C.

O.K. →

(Go to **A** on next page.)

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)

5

■ IGN TIMING ADJ ■

— CONDITION SETTING —

IGN/T FEEDBACK: HOLD

=== MONITOR ===

CKPS•RPM (REF) 650rpm
IGN TIMING 20BTDC
CLOSED TH/POS ON

SEF221M

6

■ THRTL POS SEN ADJ ■

ADJ MONITOR

THRTL POS SEN 0.44V



=== MONITOR ===


CKPS•RPM (REF) 687rpm
CLOSED TH/POS ON

SEF222M

6

CONNECT




H.S.  



SEF148I


7

DISCONNECT

1 2 3

Closed throttle position switch connector



SEF096M

5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine speed fall to 650 ± 50 rpm (A/T in "N" position)?

OR

When disconnecting throttle position sensor harness connector, does engine speed fall to 650 ± 50 rpm (A/T in "N" position)?

N.G. Adjust engine speed by turning idle adjusting screw.

6

CHECK THROTTLE POSITION SENSOR IDLE POSITION. (MT model only).

1. Perform "THRTL POS SEN. ADJ." in "WORK SUPPORT" mode.

2. Check that output voltage of throttle position sensor is approx. 0.3 to 0.7V. (Throttle valve fully closes.) and "CLOSED TH/POS" stays "ON".

OR

Measure output voltage of throttle position sensor using voltmeter, and check that it is approx. 0.3 to 0.7V. (Throttle valve fully closed.)

N.G. 1. Adjust output voltage by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "CLOSED TH/POS" stays "ON" using CONSULT.

7

CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (AT model only).

Check closed throttle position switch OFF → ON engine speed with circuit tester, closing throttle valve manually.

Closed throttle position switch OFF → ON engine speed 900 ± 150 rpm ("N" position)

N.G. 1. Adjust continuity signal by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "CLOSED TH/POS" stays "ON" using CONSULT.

(Go to **B** on next page.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES


Basic Inspection (Cont'd)

8

☆ MONITOR ☆ NO FAIL	<input type="checkbox"/>
START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON
PW/ST SIGNAL	OFF

RECORD

AEC213





9

■ SELF-DIAG RESULTS ■	<input type="checkbox"/>
FAILURE DETECTED	TIME
NO SELF DIAGNOSTIC FAILURE INDICATED.	
FURTHER TESTING MAY BE REQUIRED. **	

ERASE PRINT

SEF227L



TROUBLE DIAGNOSES

1

■ ACTIVE TEST ■ □	
SELF-LEARN CONTROL	100%
=== MONITOR ===	
CKPS-RPM (REF)	725rpm
COOLAN TEMP/S	84°C
O2 SEN	0.80V
A/F ALPHA	112%
CLEAR	

SEF225M

1

Oxygen sensor

SEF226M

2

SEF082M

1

DISCONNECT

SEF307G

Diagnostic Procedure 1 — High Idling after Warm-up

1

CHECK INTAKE AIR LEAK.

1. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.
2. Clear the self-learning control coefficient by touching "CLEAR".
3. Does the engine speed drop?

OR

1. Disconnect oxygen sensor harness connectors.
2. After racing engine at 2,000 rpm under no load for about 30 seconds, does the engine speed drop?

Yes → Discover air leak location and repair.

No →

2

CHECK THROTTLE LINKAGE.

1. Check that throttle linkage moves smoothly.
2. Confirm that throttle valve both fully opens and fully closes.

N.G. → Repair throttle linkage or sticking of throttle valve.

O.K. →

INSPECTION END

Diagnostic Procedure 2 — Hunting

1

CHECK OXYGEN SENSOR.

When disconnecting oxygen sensor harness connector, is the hunting fixed?

Yes → Check oxygen sensor. Refer to EF & EC-115.

No → (Go to **A** on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL







TROUBLE DIAGNOSES

Diagnostic Procedure 2 — Hunting (Cont'd)



TROUBLE DIAGNOSES






Diagnostic Procedure 3 — Unstable Idle



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL





TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 3 – Unstable Idle (Cont'd)



B

8 **CHECK IDLE ADJ. SCREW CLOGGING.**

1. Perform "IGN TIMING ADJ" in "WORK SUPPORT" mode and touch "START".
2. Can you set engine speed at 650 ± 50 rpm (in "N" position) by turning idle adjusting screw?

No → Check for IAC valve-AAC valve clogging or throttle valve clogging.

OR

1. Disconnect throttle position sensor harness connector.
2. Can you set engine speed at 650 ± 50 rpm (in "N" position) by turning idle adjusting screw?

Yes

9 **CHECK COMPRESSION PRESSURE.**

- Check compression pressure.
- Standard: kPa (kg/cm², psi)/300 rpm**
1,226 (12.5, 178)
- Minimum: kPa (kg/cm², psi)/300 rpm**
1,030 (10.5, 149)
- Difference between each cylinder:**
kPa (kg/cm², psi)/300 rpm
98 (1.0, 14)

N.G. → Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

O.K.

10 **CHECK ECM HARNESS CONNECTOR.**

Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-154.

N.G. → Repair or replace.

O.K.

11 **TRY A KNOWN GOOD ECM***

O.K.


INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES


Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold



1
CHECK BATTERY AND STARTER.
Check battery and starter condition. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("SDS", "STARTING SYSTEM — Starter —").

N.G. Repair or replace.

O.K.




2
CHECK FUEL PRESSURE.
1. Turn ignition switch "ON".
2. Perform "FUEL PUMP RELAY" in "ACTIVE TEST" mode.
3. Pinch fuel feed hose with fingers.
Is fuel pressure pulsation felt on the fuel feed hose?

No Check fuel pump and circuit. Refer to EF & EC-134.

OR

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?


Yes



3
CHECK IAC VALVE-AAC VALVE.
When pressing accelerator pedal 1/4 open, can you start the engine.

Yes Check IAC valve-AAC valve and circuit. Refer to EF & EC-137.

No




4
CHECK IGNITION SPARK.
1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. Check ignition coil, power transistor unit and their circuits. Refer to EF & EC-106.



O.K.

(Go to **A** on next page.)



TROUBLE DIAGNOSES

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)



5 **CHECK SPARK PLUGS.**
Remove the spark plugs and check for fouling, etc.

N.G. → Repair or replace spark plug(s).

O.K.

6 **CHECK INJECTOR.**
1. Remove crankshaft position sensor from engine. (Crankshaft position sensor harness connector should remain connected.)
2. Disconnect ignition coil harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating crankshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s). Refer to EF & EC-132.

Yes

7 **CHECK ECM HARNESS CONNECTOR.**
Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-154.

N.G. → Repair or replace.

O.K.

8 **CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.**
Refer to EF & EC-91.

N.G. → Repair or replace.

O.K.

9 **TRY A KNOWN GOOD ECM***






INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot



1 CHECK FUEL PRESSURE.

1. Turn ignition switch "ON".
 2. Perform "FUEL PUMP RELAY" in "ACTIVE TEST" mode.
 3. Pinch fuel feed hose with fingers.
- Is fuel pressure pulsation felt on the fuel feed hose?

No → Check fuel pump and circuit. Refer to EF & EC-134.

- OR
1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?

2 CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Can you start engine?

Yes → Check fuel properties.

3 CHECK INJECTOR.

- Does each injector sound like it is operating at idling?

No → Check injector(s) and circuit(s). Refer to EF & EC-132.

4 CHECK IGNITION SPARK.

1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

5 CHECK ECM HARNESS CONNECTOR.

- Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-154.

N.G. → Repair or replace.

6 CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

- Refer to EF & EC-91.


N.G. → Repair or replace.

7 TRY A KNOWN GOOD ECM*

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES




Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions

1
CHECK BATTERY AND STARTER.
 Check battery and starter operation. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("SDS", "STARTING SYSTEM — Starter —").

N.G. Repair or replace.

O.K.




2
CHECK FUEL PRESSURE.
 1. Turn ignition switch "ON".
 2. Perform "FUEL PUMP RELAY" in "ACTIVE TEST" mode.
 3. Pinch fuel feed hose with fingers.
Is fuel pressure pulsation felt on the fuel feed hose?

No Check fuel pump and circuit. Refer to EF & EC-134.

OR
 1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?


Yes



3
CHECK IGNITION SPARK.
 1. Disconnect ignition wire from rocker cover.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

N.G. Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

O.K.




4
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.

N.G. Repair or replace spark plug(s).

O.K.





(Go to (A) on next page.)



GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL



TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)




*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES



Diagnostic Procedure 7 — Hesitation when the Engine is Hot



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


TROUBLE DIAGNOSES








Diagnostic Procedure 8 — Hesitation when the Engine is Cold



TROUBLE DIAGNOSES



Diagnostic Procedure 9 — Hesitation under Normal Conditions



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 10 — Engine Stalls when Turning



1

CHECK FUEL LEVEL.

Check to see that there is enough fuel in tank.

N.G. → Fill fuel tank with fuel.

O.K.

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **5**.

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

3

CHECK INJECTOR.

Does each injector sound like it is operating at idle?

No → Check injector(s) and circuit(s). Refer to EF & EC-132.

Yes

4

CHECK IGNITION SPARK.

1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

O.K.

(Go to **A** on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 10 – Engine Stalls when Turning (Cont'd)

5


■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

START



SEF379I




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot




1

CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the engine stall disappear?

Yes → Check fuel properties.



2


PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

No → Go to 5.

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?




3

CHECK INJECTOR.

Does each injector sound like it is operating at idle?

No → Check injector(s) and circuit(s). Refer to EF & EC-132.




4

CHECK IGNITION SPARK.

1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.



N.G. → Check ignition coil, power transistor unit and their circuits. Refer to EF & EC-106.



O.K. → (Go to A on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)







*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold



1

CHECK IAC VALVE-AAC VALVE.

When the engine is cold, can you start the engine when pressing accelerator pedal 1/4 open?

Yes

Check IAC valve-AAC valve and circuits. Refer to EF & EC-137.

No

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

N.G.

Go to **6**

OR

- When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

O.K.

3

CHECK INJECTOR.

Does each injector sound like it is operating at idle?

N.G.





Check injector(s) and circuit(s). Refer to EF & EC-132.

O.K.

(Go to **A** on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF






HA

EL

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Diagnostic Procedure 13 – Engine Stalls when Stepping on the Accelerator Momentarily



1

CHECK IAC VALVE-AAC VALVE.

1) Start engine and warm it up sufficiently.

2) Check idle speed.
700 ± 50 rpm
(A/T in "N" position)

3) Perform "IACV AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.

OR

3) Select "IACV AAC/V OPENING" in "ACTIVE TEST" mode.

4) When touching "Qu" and "Qd", does the engine speed change according to the percent of IAC valve-AAC valve opening?

OR

3) When disconnecting IAC valve-AAC valve harness connector, does the engine speed drop?

No → Check IAC valve-AAC valve and circuit. Refer to EF & EC-137.

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

OR




When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **5**.

Yes → (Go to **A** on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)



3 **CHECK INJECTOR.**
Does each injector sound like it is operating at idle?

No → Check injector(s) and their circuit(s). Refer to EF & EC-132.

Yes

4 **CHECK IGNITION SPARK.**
1. Disconnect ignition wire from rocker cover.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against an ground point with engine cranking.
4. Check for spark.

N.G. → Check ignition coil, power transistor unit and their circuits. Refer to EF & EC-106.

O.K.

5 **CHECK FUEL PRESSURE.**
1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.
2. Install fuel pressure gauge and check fuel pressure.
A few seconds after ignition switch is turned OFF to ON:
Approx.
294 kPa (3.0 kg/cm², 43 psi)
At idle:
Approx.
235 kPa (2.4 kg/cm², 34 psi)
OR
1. Release fuel pressure to zero. Refer to EF & EC-167.
2. Install fuel pressure gauge and check fuel pressure.

N.G. → Check fuel pressure regulator diaphragm. Refer to EF & EC-168.

O.K.

6 **CHECK ECM HARNESS CONNECTOR.**
Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-154.

N.G. → Repair or replace.

O.K.

7 **CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.**
Refer to EF & EC-91.

N.G. → Repair or replace.

O.K.

8 **TRY A KNOWN GOOD ECM***

INSPECTION END

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating

1 ■ IACV-AAC/V SYSTEM ■

LET ENGINE IDLE
THEN
TOUCH START
(A/C SW•LIGHT SW OFF)

NEXT START

SEF249M

1 ■ ACTIVE TEST ■


IACV-AAC/V
OPENING 50%

=== MONITOR ===

CKPS•RPM (REF) 825rpm
MAS AIR/FL SE 1.12V
COOLAN TEMP/S 84°C

Qu UP DWN Qd

SEF250M



2 ■ IGN TIMING ADJ ■


— CONDITION SETTING —

IGN/T FEEDBACK: HOLD

=== MONITOR ===

CKPS•RPM (REF) 650rpm
IGN TIMING 20BTDC
CLOSED TH/POS ON

SEF221M



1

CHECK IAC VALVE-AAC VALVE.

- 1) Start engine and warm it up sufficiently.
- 2) Check idle speed.
700 ± 50 rpm
(A/T in "N" position)
- 3) Perform "IACV-AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.

OR

- 3) Select "IACV-AAC/V OPENING" in "ACTIVE TEST" mode.
- 4) When touching "Qu" and "Qd", does the engine speed change according to the percent of IAC valve-AAC valve opening?

OR

- 3) When disconnecting IAC valve-AAC valve harness connector, does the engine speed drop?

No

Check IAC valve-AAC valve and circuit. Refer to EF & EC-137.

2

CHECK IDLE ADJ. SCREW CLOGGING.

1. Perform "IGN TIMING ADJ" in "WORK SUPPORT" mode and touch "START".
2. Can you set engine speed at 650 ± 50 rpm (in "N" position) by turning idle adjusting screw?

OR

1. Disconnect throttle position sensor harness connector.
2. Can you set engine speed at 650 ± 50 rpm (in "N" position) by turning idle adjusting screw?

No






Check for IAC valve-AAC valve clogging or throttle body passages clogging.

Yes

(Go to (A) on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Diagnostic Procedure 14 – Engine Stalls after Decelerating (Cont'd)


6

■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

START

↓



SEF379I

7

MIXTURE RATIO TEST

ACCELERATE TO 2000 RPM AND HOLD THEN TOUCH START.

2000 2200

NEXT START

SEF115L

7

☆ MONITOR ☆ NO FAIL


CKPS•RPM (REF) 2000rpm

M/R F/C MNT RICH


RECORD

SEF228M

7



RED LED



Malfunction indicator lamp

AEC212

ⓑ

6

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.

2. Install fuel pressure gauge and check fuel pressure.

A few seconds after ignition switch is turned OFF to ON:

Approx.
294 kPa (3.0 kg/cm², 43 psi)

At idle:
Approx.
235 kPa (2.4 kg/cm², 34 psi)

OR

1. Release fuel pressure to zero. Refer to EF & EC-167.

2. Install fuel pressure gauge and check fuel pressure.

N.G. Check fuel pressure regulator diaphragm. Refer to EF & EC-168.

O.K.

7

CHECK OXYGEN SENSOR.

1. Start engine and warm it up sufficiently.

2. Perform "MIXTURE RATIO TEST" in "FUNCTION TEST" mode.

OR

1. See "M/R F/C MNT" in "DATA MONITOR" mode.

2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently.), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →

1 time 2 times

LEAN → RICH.....

OR

1. Set "Oxygen sensor monitor" in the On-board Diagnostic Test Mode II. Refer to EF & EC-37.

2. Maintaining engine at 2,000 rpm under no load, check that malfunction indicator lamp or RED LED on the ECM goes ON and OFF more than 5 times during 10 seconds.


N.G. Replace oxygen sensor.

O.K.

(Go to Ⓒ on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 14 – Engine Stalls after Decelerating (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 15 – Engine Stalls when Accelerating or when Driving at Constant Speed



TROUBLE DIAGNOSES

Diagnostic Procedure 15 – Engine Stalls when Accelerating or when Driving at Constant Speed (Cont'd)


4

■ FUEL PRES RELEASE ■


FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

START

↓



SEF3791




*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy



1
CHECK BATTERY AND GENERATOR.
 Check battery and generator condition. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("Trouble-shooting", "CHARGING SYSTEM").


N.G. Repair or replace.



2
PERFORM POWER BALANCE TEST.
 1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
 2. Is there any cylinder which does not produce a momentary engine speed drop?


No Go to 5.

OR
 When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?




3
CHECK INJECTOR.
 Does each injector sound like it is operating at idle?

No Check injector(s) and circuit(s). Refer to EF & EC-132.



4
CHECK IGNITION SPARK.
 1. Disconnect ignition wire from rocker cover.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

N.G. Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.



O.K.
 (Go to A on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)


5

■ FUEL PRES RELEASE ■


FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

START

↓




SEF3791



*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES



Diagnostic Procedure 17 — Lack of Power and Stumble

1

CHECK FUEL PRESSURE.



1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.
2. Install fuel pressure gauge and check fuel pressure.

A few seconds after ignition switch is turned OFF to ON:

Approx.
294 kPa (3.0 kg/cm², 43 psi)

At idle:

Approx.
235 kPa (2.4 kg/cm², 34 psi)

OR



1. Release fuel pressure to zero. Refer to EF & EC-167.
2. Install fuel pressure gauge and check fuel pressure.

N.G.





Check fuel pressure regulator diaphragm. Refer to EF & EC-168.

O.K.

INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure 18 — Knock



1 **CHECK EGR OPERATION.**

1. Apply vacuum directly to the EGR valve using a handy vacuum pump.
2. Check to see that the engine runs rough or dies.

No → Check EGR valve for sticking.

Yes ↓

2 **CHECK EGR & CANISTER CONTROL SOLENOID VALVE.**

Ⓜ 1. Start engine and warm it up sufficiently.

2. Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode.

— OR —

N.G. → Check solenoid valve and circuit. Refer to EF & EC-109.

Ⓜ 1. Select "EGRC SOL/V" in "ACTIVE TEST" mode.

2. Turn EGR and canister control solenoid valve ON and OFF.
3. Check operating sound.

— OR —

ⓧ 1. Disconnect EGR and canister control solenoid valve harness connector.

2. Supply EGR and canister control solenoid valve terminals with battery current and check operating sound.

O.K. ↓

3 **CHECK VACUUM HOSES.**

Check the following vacuum hoses for clogging, cracks and poor connection.

- a) Vacuum hose between EGR valve and EGR and canister control solenoid valve.
- b) Vacuum hose between EGR and canister control solenoid valve and throttle body port.
- c) Vacuum hose between EGR and canister control solenoid valve and air duct. Refer to EF & EC-9.



N.G. → Repair or replace.

O.K. ↓
(Go to **A** on next page.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL





TROUBLE DIAGNOSES

Diagnostic Procedure 18 — Knock (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 19 – Surge



1

CHECK OXYGEN SENSOR.

1. Start engine and warm it up sufficiently.

2. Perform "MIXTURE RATIO TEST" in "FUNCTION TEST" mode.

OR

N.G. Replace oxygen sensor.

1. See "M/R F/C MNT" in "DATA MONITOR" mode.

2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently.), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH→LEAN→RICH→
1 time 2 times

LEAN→RICH.....

OR

1. Set "Oxygen sensor monitor" in the On-board Diagnostic Test Mode II. Refer to EF & EC- 37.

2. Maintaining engine at 2,000 rpm under no-load, check that malfunction indicator lamp or RED LED on the ECM goes ON and OFF more than 5 times during 10 seconds.

O.K.

2

CHECK EGR VALVE.
Check EGR valve for sticking.

N.G. Repair or replace.

O.K.

3

TRY A KNOWN GOOD ECM*


O.K.

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES



Diagnostic Procedure 20 — Backfire through the Intake

1

CHECK SPARK PLUGS.

Remove the spark plugs and check for fouling, etc.

N.G.

Repair or replace spark plug.

O.K.

2

CHECK FOR INTAKE VALVE DEPOSITS.

If there are deposits on intake valves, remove them.

INSPECTION END

Diagnostic Procedure 21 — Backfire through the Exhaust on Deceleration

CHECK ENGINE COOLANT TEMPERATURE SENSOR.

Check engine coolant temperature sensor and its circuit. Refer to EF & EC-100.

N.G.

Replace or repair.


O.K.

INSPECTION END



TROUBLE DIAGNOSES

Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)








Harness layout



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 22 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Turn ignition switch "ON".
- 2) Check voltage between ECM terminals (38), (47) and ground.

Voltage: Battery positive voltage

B

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminals (6), (13), (107), (108), (116) and engine ground.

Continuity should exist.

If N.G., repair harness or connectors.

Check ECM pin terminals for damage or the connection of ECM harness connector.

C

CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Disconnect ECM relay.
- 4) Check harness continuity between ECM terminals (38), (47) and terminal (3).

Continuity should exist.

Repair harness or connectors.

D

CHECK VOLTAGE BETWEEN ECM RELAY AND GROUND.

- 1) Check voltage between terminals (1), (5) and ground.

Voltage: Battery positive voltage

Check the following.

- Harness connectors (F24), (M50)
- Harness connectors (M7), (E103)
- 25A fusible link
- Harness continuity between ECM relay and battery

If N.G., repair harness or connectors.

E

CHECK VOLTAGE BETWEEN ECM AND GROUND.

- 1) Check voltage between ECM terminal (46) and ground.

Voltage: Battery positive voltage

Check the following.





- Harness connectors (F24), (M50)
- Harness connectors (M7), (E103)
- 25A fusible link
- Harness continuity between ECM and battery

If N.G., repair harness or connectors.

(A)

TROUBLE DIAGNOSES


Diagnostic Procedure 22 (Cont'd)





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11 CRANKSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Disconnect crankshaft position sensor harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal (b) and ground.
Voltage: Battery positive voltage

N.G. Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Check harness continuity between terminal (a) and engine ground.
Continuity should exist.

N.G. Repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
 1) Reconnect crankshaft position sensor harness connector.
 2) Start engine.
 3) Read crankshaft position sensor signals in "DATA MONITOR" mode with CONSULT.
rpm: 700 ± 50

N.G. Repair harness or connectors.

OR
 1) Disconnect ECM harness connector.
 2) Check harness continuity between terminal (c) and ECM terminals (31), (40) (1° signal), terminal (d) and ECM terminals (22), (30) (180° signal).
Continuity should exist.

CHECK COMPONENT
 (Crankshaft position sensor).
 Refer to EF & EC-159.

N.G. Replace crankshaft position sensor.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11 (Cont'd)


Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 12

MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12) (MALFUNCTION INDICATOR LAMP ITEM)







Harness layout



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 12 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Disconnect mass air flow sensor harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal (b) and ground.
Voltage: Battery positive voltage

N.G. Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Disconnect ECM harness connector.
 3) Check harness continuity between terminal (c) and ECM terminal (17).
Continuity should exist.

N.G. Repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
 1) Reconnect mass air flow sensor harness connector and ECM harness connector.
 2) Start engine and warm it up sufficiently.
 3) Read mass air flow sensor signal in "DATA MONITOR" mode with CONSULT.
Voltage: 0.85 - 1.35V (At idle)

N.G. Repair harness or connectors.

OR
 1) Check harness continuity between terminal (d) and ECM terminal (16).
Continuity should exist.

CHECK COMPONENT
 (Mass air flow sensor).
 Refer to EF & EC-159.


N.G. Replace mass air flow sensor.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 12 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 13

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13) (MALFUNCTION INDICATOR LAMP ITEM)






Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 13 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

1) Start engine.
2) Read engine coolant temperature sensor signal in "DATA MONITOR" mode with CONSULT.

Engine coolant temperature should gradually rise and reach more than 70°C (158°F) after engine warm-up.

OR

1) Disconnect engine coolant temperature sensor harness connector.
2) Turn ignition switch "ON".
3) Check voltage between terminal **a** and ground.

Voltage:
Approximately 5V

N.G.

Check the following.

- Harness connectors **(F18), (E205)**
- Harness continuity between ECM and engine coolant temperature sensor

If N.G., repair harness or connectors.

B

CHECK GROUND CIRCUIT.

1) Turn ignition switch "OFF".
2) Check harness continuity between terminal **b** and engine ground.

Continuity should exist.

N.G.

Check the following.

- Harness connectors **(F18), (E205)**
- Harness continuity between ECM and engine coolant temperature sensor

If N.G., repair harness or connectors.

CHECK COMPONENT
(Engine coolant temperature sensor).
Refer to EF & EC-160.

N.G.

Replace engine coolant temperature sensor.

O.K.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 13 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.




TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 14

VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14) (MALFUNCTION INDICATOR LAMP ITEM)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 14 (Cont'd)

A ■ VEHICLE SPEED SEN CKT ■

AFTER TOUCH START,
DRIVE VEHICLE
AT 10 km/h (6 mph) OR
(MORE WITHIN 15 sec.)

NEXT START


SEF233M

A ☆ MONITOR ☆ NO FAIL

VHCL SPEED SE 10mph

RECORD

SEF234M



INSPECTION START

CHECK SPEEDOMETER FUNCTION.
Make sure that speedometer functions properly.

N.G. Check vehicle speed sensor and circuit.
Refer to EL section ("Vehicle Speed Sensor Signal Check", "METER AND GAUGES").

O.K.

A CHECK INPUT SIGNAL CIRCUIT.
Perform "VEHICLE SPEED SEN CKT" in "FUNCTION TEST" mode with CONSULT.

N.G. Check the following.

- Harness connectors **F23**, **M49**
- Harness continuity between ECM and combination meter

If N.G., repair harness or connectors.

OR

1) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT.
CONSULT value should be the same as the speedometer indication.

OR

1) Turn ignition switch "OFF".
2) Disconnect ECM harness connector and combination meter harness connector.
3) Check harness continuity between ECM terminal **32** and terminal **5** (Models without head-up display), **58** (Models with head-up display).
Continuity should exist.


O.K.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

TROUBLE DIAGNOSES


Diagnostic Procedure For Trouble Code 14 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.







TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21 IGNITION SIGNAL (Diagnostic trouble code No. 21)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21 (Cont'd)



INSPECTION START

A CHECK POWER SUPPLY.
 1) Disconnect ignition coil harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal (a) and ground.
Voltage: Battery positive voltage

N.G. Check the following.
 • Harness connectors (F24, M50)
 • Harness connectors (M7, E103)
 • Harness continuity between ignition coil and ignition switch
 If N.G., repair harness or connectors.

O.K.

B CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Disconnect resistor and condenser harness connector.
 3) Disconnect power transistor harness connector.
 4) Check harness continuity between terminal (b) and terminals (d), (i).
Continuity should exist.
 5) Check harness continuity between terminal (h) and engine ground.
Continuity should exist.

N.G. Repair harness or connectors.

O.K.

D CHECK INPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector.
 2) Check harness continuity between terminal (3) and ECM terminal (3).
Continuity should exist.

N.G. Repair harness or connectors.

O.K.

E CHECK OUTPUT SIGNAL CIRCUIT.
 1) Check harness continuity between terminal (g) and ECM terminal (1).
Continuity should exist.

N.G. Repair harness or connectors.

O.K.

CHECK COMPONENTS
 (Ignition coil, resistor and power transistor).
 Refer to EF & EC-160, 161, 166.

N.G. Replace malfunctioning component(s).

O.K.

(A)

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL


TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21 (Cont'd)

(A)


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

Perform FINAL CHECK by the following procedure after repair is completed.




Diagnostic Procedure For Trouble Code 31

ECM (ECCS CONTROL MODULE) (Diagnostic trouble code No. 31)  (MALFUNCTION INDICATOR LAMP ITEM)




TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 32

EGR FUNCTION (Diagnostic trouble code No. 32)  (MALFUNCTION INDICATOR LAMP ITEM): CALIFORNIA MODEL
EGR CONTROL SYSTEM (Not self-diagnostic item): NON-CALIFORNIA MODEL

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)



California model

INSPECTION START

A
CHECK VACUUM SOURCE TO EGR VALVE.
 1) Start engine and warm it up sufficiently.
 2) Perform on-board diagnostic test mode II (Self-diagnostic results). Make sure that none of the diagnostic trouble code No. 12, No. 13, No. 35 or No. 43 are displayed.
 3) Keep engine speed at about 2,000 rpm.
 4) Disconnect vacuum hose to EGR valve.
 5) Make sure that vacuum exists under the following conditions.
At idle:
 Vacuum should not exist.
Engine is racing (2,000 rpm):
 Vacuum should exist.

O.K. → **CHECK COMPONENTS** (EGR valve, EGR control-BPT valve and EGR temperature sensor). Refer to EF & EC-161.

N.G. ↓

Replace malfunctioning component(s).

B
CHECK CONTROL FUNCTION.
 1) Check voltage between ECM terminal (105) and ground under the following conditions.
Voltage:
At idle
 Approximately 0V
Engine is racing (2,000 rpm)
 Battery positive voltage

O.K. → **C**
CHECK VACUUM HOSE.
 1) Check vacuum hose for clogging, cracks and proper connection.

D
CHECK POWER SUPPLY.
 1) Stop engine.
 2) Disconnect EGR & canister control solenoid valve harness connector.
 3) Turn ignition switch "ON".
 4) Check voltage between terminal (b) and ground.
Voltage: Battery positive voltage

N.G. → Check the following.
 • Harness connectors (F24), (M50)
 • 10A fuse
 • Harness continuity between EGR & canister control solenoid valve and fuse
 If N.G., repair harness or connectors.

O.K. ↓
 (A)

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)

F ■ EGRC SOL/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

SEF235M

F ■ ACTIVE TEST ■

EGRC SOL/V OFF

=== MONITOR ===

CKPS•RPM(REF) 0rpm

ON ON/OFF OFF

AEC223

E CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal (105) and terminal (a). **Continuity should exist.**

N.G. Repair harness or connectors.

O.K.

F CHECK COMPONENT (EGR & canister control solenoid valve).

- 1) Reconnect EGR & canister control solenoid valve harness connector and ECM harness connector.
- 2) Turn ignition switch "ON".
- 3) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 3) Turn EGR control-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.

OR

Refer to EF & EC-161.

N.G. Replace EGR & canister control solenoid valve.

O.K.

Check resistance of EGR temperature sensor.






Refer to EF & EC-162.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)



Non-California model

INSPECTION START

I
CHECK OVERALL FUNCTION.
1) Start engine and warm it up sufficiently.
2) Make sure that EGR valve spring is lifted up and down when racing engine (2,000 rpm). (Use your finger.)

Is lifted up and down.
INSPECTION END

Is not lifted up and down.

J
CHECK VACUUM SOURCE TO EGR VALVE.
1) Disconnect vacuum hose to EGR valve.
2) Make sure that vacuum exists under the following conditions.
At idle:
Vacuum should not exist.
Engine is racing (2,000 rpm):
Vacuum should exist.

O.K. CHECK COMPONENTS (EGR valve and EGR control-BPT valve). Refer to EF & EC-161.
N.G.

Replace malfunctioning component(s).

N.G.

K
CHECK CONTROL FUNCTION.
1) Check voltage between ECM terminal (105) and ground under the following conditions.
Voltage:
At idle
Approximately 0V
Engine is racing (2,000 rpm)
Battery positive voltage

O.K. CHECK VACUUM HOSE.
1) Check vacuum hose for clogging, cracks and proper connection.

N.G.

M
CHECK POWER SUPPLY.
1) Stop engine.
2) Disconnect EGR & canister control solenoid valve harness connector.
3) Turn ignition switch "ON".
4) Check voltage between terminal (b) and ground.
Voltage: Battery positive voltage

N.G. Check the following.
• Harness connectors (F24, M50)
• 10A fuse
• Harness continuity between EGR & canister control solenoid valve and fuse
If N.G., repair harness or connectors.

O.K.

(A)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)



N


A

N

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal **105** and terminal **a**. **Continuity should exist.**

N.G. → Repair harness or connectors.




O.K.

O

CHECK COMPONENT (EGR & canister control solenoid valve).

- 1) Reconnect EGR & canister control solenoid valve harness connector and ECM harness connector.
- 2) Turn ignition switch "ON".
- 3) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

N.G. → Replace EGR & canister control solenoid valve.



OR

- 3) Turn EGR control-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.

OR

Refer to EF & EC-161.

O.K.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 33

OXYGEN SENSOR (Diagnostic trouble code No. 33)  (MALFUNCTION INDICATOR LAMP ITEM)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 33 (Cont'd)

A

MIXTURE RATIO TEST

ACCELERATE TO 2000 RPM AND HOLD THEN TOUCH START.

2000 2200

NEXT START

SEF115L

A

☆ MONITOR ☆ NO FAIL

CKPS•RPM(REF) 2087rpm

M/R F/C MNT LEAN

RECORD

SEF237M

A

RED LED

Malfunction indicator lamp

AEC212

B

DISCONNECT


DISCONNECT

ECM CONNECTOR

19 a

OFF


MEF452C



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 33 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 34

KNOCK SENSOR (Diagnostic trouble code No. 34)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 34 (Cont'd)



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector and engine harness No. 2 connector (E205).
 2) Check harness continuity between terminal (g) and ECM terminal (27).
Continuity should exist.

N.G. → Repair harness or connectors.

O.K.

CHECK COMPONENT
 (Knock sensor).
 Refer to EF & EC-118.

N.G. → Replace knock sensor.

O.K.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

Perform FINAL CHECK by the following procedure after repair is completed.

FINAL CHECK

Erase the on-board diagnostic test mode II (Self-diagnostic results) memory. Refer to EF & EC-41.

Perform test drive.

Perform on-board diagnostic test mode II (Self-diagnostic results) again. Refer to EF & EC-36.

N.G. → Recheck ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

O.K.


INSPECTION END

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35

EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35)  (MALFUNCTION INDICATOR LAMP ITEM): CALIFORNIA MODEL ONLY






Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Start engine and warm it up sufficiently.
- 2) Read EGR temperature sensor signal in "DATA MONITOR" mode with CONSULT.

Voltage:
Less than 5V (at idle)

OR

- 2) Stop engine.
- 3) Disconnect EGR temperature sensor connector.
- 4) Turn ignition switch "ON".
- 5) Check voltage between terminal (a) and ground.

Voltage:
Less than 5V (at idle)

N.G. Repair harness or connectors.

O.K.

B

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Check harness continuity between terminal (b) and engine ground.

Continuity should exist.

N.G. Repair harness or connectors.

O.K.

CHECK COMPONENT.
(EGR temperature sensor).
Refer to EF & EC-162.

N.G. Replace EGR temperature sensor.

O.K.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35 (Cont'd)


Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43

THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43) (MALFUNCTION INDICATOR LAMP ITEM)








Harness layout



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Disconnect throttle position sensor harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal (c) and ground.
Voltage: Approximately 5V

N.G. Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Check harness continuity between terminal (a) and engine ground.
Continuity should exist.

N.G. Repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
 1) Reconnect throttle position sensor harness connector.
 2) Turn ignition switch "ON".
 3) Perform "THROTTLE POSI SEN CKT" in "FUNCTION TEST" mode with CONSULT.

N.G. Repair harness or connectors.

OR
 3) Read throttle position sensor output voltage in "WORK SUPPORT" mode with CONSULT.
Throttle valve fully closed:
Approx. 0.3 - 0.7V
Throttle valve fully open:
Approx. 4.0V

OR
 1) Disconnect ECM harness connector.
 2) Check harness continuity between ECM terminal (20) and terminal (b).
Continuity should exist.

O.K.
CHECK COMPONENT
 (Throttle position sensor).
 Refer to EF & EC-163.


N.G. Replace throttle position sensor.

O.K.
 Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

TROUBLE DIAGNOSES




Diagnostic Procedure For Trouble Code 43 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 45 INJECTOR LEAK (Diagnostic trouble code No. 45) (MALFUNCTION INDICATOR LAMP ITEM); CALIFORNIA MODEL ONLY


INSPECTION START

A

Clear the self-learning data

- 1) Start engine and warm it up sufficiently.
- 2) Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT.
- 3) Clear the self-learning control coefficient by touching "CLEAR".

OR

 2) Disconnect mass air flow sensor connector, and restart and run engine for at least 30 seconds at 2,000 rpm.

- 3) Stop engine and reconnect mass air flow sensor connector.
- 4) Make sure diagnostic trouble code No. 12 is displayed in On-board Diagnostic Test Mode II.
- 5) Erase the on-board diagnostic test mode II (Self-diagnostic results) memory. Make sure diagnostic trouble code No. 55 is displayed in On-board Diagnostic Test Mode II.

B

PERFORM ON-BOARD DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS).

O.K. → INSPECTION END

N.G.

Remove injector assembly.
Refer to EF & EC-168.
Keep fuel hose and all injectors connected to injector gallery.

Turn ignition switch "ON".
Make sure fuel does not drip from injector.

Drips → Replace the injectors from which fuel is dripping.


Do not drip

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 45 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 54

A/T CONTROL (Diagnostic trouble code No. 54)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 54 (Cont'd)



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector and A/T control module harness connector.
 2) Check harness continuity between ECM terminal (12) and terminal (12), ECM terminal (42) and terminal (10), ECM terminal (44) and terminal (11).
Continuity should exist.

N.G. Check the following.
 • Harness connectors (F22, M60)
 • Harness continuity between ECM and A/T control module
 If N.G., repair harness or connectors.

O.K.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

Perform FINAL CHECK by the following procedure after repair is completed.

FINAL CHECK

Erase the on-board diagnostic test mode II (Self-diagnostic results) memory. Refer to EF & EC-41.

Perform test drive.

Perform on-board diagnostic test mode II (Self-diagnostic results) again. Refer to EF & EC-36.

N.G. Recheck ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

O.K.

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 23 (Cont'd)

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE, SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY

NEXT
START

SEF191L



A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

SEF241M



INSPECTION START

A

CHECK OVERALL FUNCTION.

- 1) Turn ignition switch "ON".
- 2) Perform "START SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

O.K. → INSPECTION END

- 1) Turn ignition switch "ON".
- 2) Check start signal in "DATA MONITOR" mode with CONSULT.

IGN "ON"	OFF
IGN "START"	ON

OR

- 1) Turn ignition switch to "START".
- 2) Check voltage between ECM terminal (34) and ground.

Voltage:

Ignition switch "START"
Battery positive voltage
Except above
Approximately 0V

N.G.

B

CHECK INPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector and ignition switch harness connector.
- 3) Check harness continuity between ECM terminal (34) and terminal (6).

Continuity should exist.

N.G. → Check the following.

- Harness connectors (F23), (M49)
- Harness connectors (M7), (E103)
- 10A fuse
- Harness continuity between ECM and ignition switch

If N.G., repair harness or connectors.

O.K.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL



TROUBLE DIAGNOSES

Diagnostic Procedure 24

INJECTOR (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 24 (Cont'd)



INSPECTION START

A


CHECK CONTROL FUNCTION.

- 1) Start engine.
- 2) Check voltage between ECM terminals (101), (110), (103), (112) and ground.

Voltage: Battery positive voltage

O.K. → INSPECTION END

N.G. ↓



B

CHECK POWER SUPPLY 1.

- 1) Stop engine.
- 2) Disconnect each injector harness connector.
- 3) Check voltage between terminal (b) and ground.


Voltage: Battery positive voltage

N.G. → Check the following.

- Harness connectors (F23), (M49)
- Harness connectors (M7), (E103)
- 10A fuse
- 75A fusible link
- Harness continuity between injector and battery

If N.G., repair harness or connectors.

O.K. ↓



C

CHECK POWER SUPPLY 2.

- 1) Disconnect ECM harness connector.
- 2) Check voltage between ECM terminal (109) and ground.


Voltage: Battery positive voltage

N.G. → Check the following.

- Harness connectors (F24), (M50)
- Harness connectors (M7), (E103)
- 25A fusible link
- Harness continuity between ECM and battery

If N.G., repair harness or connectors.

O.K. ↓



D

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Check harness continuity between terminal (a) and ECM terminals (101), (110), (103), (112).

Continuity should exist.

N.G. → Repair harness or connectors.

O.K. ↓

CHECK COMPONENT (Injector).

Refer to EF & EC-164.

N.G. → Replace injector.

O.K. ↓

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL




TROUBLE DIAGNOSES

Diagnostic Procedure 25

FUEL PUMP (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)




INSPECTION START

A
CHECK OVERALL FUNCTION.
1) Turn ignition switch "ON".
2) Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt for 5 seconds after ignition switch is turned "ON".

O.K. → INSPECTION END


N.G.



B
CHECK POWER SUPPLY.
1) Turn ignition switch "OFF".
2) Disconnect fuel pump relay.
3) Turn ignition switch "ON".
4) Check voltage between terminals ①, ③ and ground.
Voltage: Battery positive voltage

N.G. → Check the following.
 • Harness connectors **(E103)**, **(M7)**
 • Joint connector **(E3)**
 • 15A fuse
 • Harness continuity between fuse and fuel pump relay
 If N.G., repair harness or connectors.

O.K.



C
CHECK GROUND CIRCUIT.
1) Turn ignition switch "OFF".
2) Disconnect fuel pump harness connector.
3) Check harness continuity between terminal ⑥ and body ground, terminal ⑦ and terminal ⑤.
Continuity should exist.


N.G. → Check the following.
 • Harness connectors **(B1)**, **(M6)**
 • Harness connectors **(M7)**, **(E103)**
 • Harness continuity between fuel pump and body ground
 • Harness continuity between fuel pump and fuel pump relay
 If N.G., repair harness or connectors.

O.K.

D
CHECK OUTPUT SIGNAL CIRCUIT.
1) Disconnect ECM harness connector.
2) Check harness continuity between ECM terminal ⑩ and terminal ②.
Continuity should exist.

N.G. → Check the following.
 • Harness connectors **(M7)**, **(E103)**
 • Harness connectors **(M49)**, **(F23)**
 • Harness continuity between ECM and fuel pump relay
 If N.G., repair harness or connectors.

O.K.



Ⓐ

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)

E

■ FUEL PUMP CIRCUIT ■

PINCH FUEL FEED HOSE WITH FINGERS. IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?
OR
DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT
NO
YES

SEF633L

E

■ ACTIVE TEST ■


FUEL PUMP RELAY ON

=== MONITOR ===

CKPS•RPM(REF) 0rpm

ON
ON/OFF
OFF


AEC227





TROUBLE DIAGNOSES

Diagnostic Procedure 26

IAC VALVE-AAC VALVE (Not self-diagnostic item)









Harness layout



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL





TROUBLE DIAGNOSES

Diagnostic Procedure 27

RADIATOR FAN CONTROL (Not self-diagnostic item)





Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



INSPECTION START

A

CHECK RADIATOR FAN LOW SPEED OPERATION.

With air conditioning

- 1) Start engine.
- 2) Set temperature lever at full cold position.
- 3) Turn air conditioning switch "ON".
- 4) Turn blower fan switch "ON".
- 5) Run engine at idle for a few minutes with air conditioning operating.
- 6) Make sure that radiator fan operates at low speed.

Without air conditioning

- 1) Start engine.
- 2) Keep engine speed at about 2,000 rpm until engine is warmed up sufficiently.
- 3) Make sure that radiator fan begins to operate at low speed during warm-up.

N.G. Check radiator fan low speed control circuit. (Perform PROCEDURE A .)

O.K.

B

CHECK RADIATOR FAN HIGH SPEED OPERATION.

- 1) Turn air conditioning switch "OFF".
- 2) Turn blower fan switch "OFF". (Steps 1) and 2) are only performed for models with air conditioning.)
- 3) Stop engine.
- 4) Disconnect engine coolant temperature sensor harness connector.
- 5) Restart engine and make sure that radiator fan operates at high speed.

N.G. Check radiator fan high speed control circuit. (Perform PROCEDURE B .)



O.K.

INSPECTION END

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



PROCEDURE A

INSPECTION START

C

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect radiator fan relay-1.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ①, ③ and ground.

Voltage: Battery positive voltage

N.G.

Check the following.

- Harness connectors
- M7, E103
- 10A fuse
- 30A fusible link
- 75A fusible link
- Joint connector-2
- Harness continuity between radiator fan relay-1 and fuse
- Harness continuity between radiator fan relay-1 and battery

If N.G., repair harness or connectors.

O.K.

D

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect radiator fan motor-1 harness connector and radiator fan motor-2 harness connector.
- 3) Check harness continuity between terminals a, e and terminal 5, terminals d, h and body ground.

Continuity should exist.

N.G.

Repair harness or connectors.

Check the following.

- Joint connector-1
- Harness continuity between radiator fan relay-1 and radiator fan motor-1, 2.




If N.G., repair harness or connectors.

O.K.

➔ A

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



PROCEDURE B

INSPECTION START

G

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect radiator fan relays-2 and 3.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ①, ③ and ground.


Voltage: Battery positive voltage

N.G. →

Check the following.

- Harness connectors **M7**, **E103**
- 10A fuse
- 30A fusible link
- 75A fusible link
- Joint connector-1
- Joint connector-2
- Harness continuity between radiator fan relays-2 and 3 and fuse
- Harness continuity between radiator fan relays-2 and 3 and battery

If N.G., repair harness or connectors.



O.K. ↓


CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect radiator fan motor harness connector.
- H** 3) Check harness continuity between terminal ⑤ and terminals ②, ④.
- I** 4) Check harness continuity between terminal ⑥ and terminals ③, ⑦, terminal ⑧ and body ground.

Continuity should exist.

N.G. →

Repair harness or connectors.






O.K. ↓

A

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)




GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL



TROUBLE DIAGNOSES

Diagnostic Procedure 28

POWER STEERING PRESSURE SWITCH (Not self-diagnostic item)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 28 (Cont'd)

A

■ PW/ST SIGNAL CIRCUIT ■

HOLD STEERING WHEEL
IN A FULL
LOCKED POSITION
THEN
TOUCH START

NEXT START

SEF200L





A

☆ MONITOR ☆ NO FAIL

PW/ST SIGNAL OFF

RECORD

SEF591I




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES





Diagnostic Procedure 29

NEUTRAL POSITION SWITCH/INHIBITOR SWITCH (Not self-diagnostic item)



MEF242C

Harness layout



EF & EC-148

TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)

A

■ NEUTRAL POSI SW CKT ■

SHIFT
OUT OF N/P-RANGE

THEN
TOUCH START

START

SEF247M




A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

SEF248M



Neutral position switch (M/T)

INSPECTION START

A

CHECK OVERALL FUNCTION.

1) Turn ignition switch "ON".
2) Perform "NEUTRAL POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.

OR

1) Turn ignition switch "ON".
2) Check neutral position switch signal in "DATA MONITOR" mode with CONSULT.

Neutral position: ON
Except above: OFF

O.K. → INSPECTION END

OR

1) Set shift lever to the neutral position.
2) Disconnect ECM harness connector.
3) Check harness continuity between ECM terminal (35) and body ground.
Continuity should exist.

N.G. →

Turn ignition switch "OFF".

B

CHECK GROUND CIRCUIT.

1) Disconnect neutral position switch harness connector.
2) Check harness continuity between terminal (d) and body ground.
Continuity should exist.

N.G. → Check the following.
• Harness connectors (E213, E15)
• Harness continuity between neutral position switch and body ground.
If N.G., repair harness or connectors.

O.K. →

Disconnect ECM harness connector.

C

CHECK INPUT SIGNAL CIRCUIT.

1) Check harness continuity between ECM terminal (35) and terminal (b).
Continuity should exist.

N.G. → Check the following.
• Harness connectors (E213, E15)
• Harness connectors (E103, M7)
• Harness connectors (M49, F23)
• Harness continuity between ECM and neutral position switch
If N.G., repair harness or connectors.

O.K. → A

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)

D ■ NEUTRAL POSI SW CKT ■

SHIFT
OUT OF N/P-RANGE

THEN
TOUCH START

START

SEF247M

D ☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON

RECORD

SEF248M

D

ECM CONNECTOR

35

Ω

P N

MEF460C

Inhibitor switch (A/T)

INSPECTION START

D

CHECK OVERALL FUNCTION.

- 1) Turn ignition switch "ON".
- 2) Perform "NEUTRAL POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.

O.K. → INSPECTION END

OR

- 1) Turn ignition switch "ON".
- 2) Check park/neutral position switch signal in "DATA MONITOR" mode with CONSULT.

"N" or "P": ON
Except above: OFF

OR

- 1) Make sure that inhibitor switch circuit functions properly. Refer to AT section ("INHIBITOR SWITCH, OVERDRIVE SWITCH AND CLOSED THROTTLE POSITION SWITCH CIRCUIT CHECKS", "Self-diagnosis", "TROUBLE DIAGNOSES").
- 2) Disconnect ECM harness connector.
- 3) Shift selector lever to "P" range.
- 4) Turn ignition switch "ON".
- 5) Check harness continuity between ECM terminal (35) and body ground.
Continuity should exist.
- 6) Shift selector lever to "N" range.
- 7) Check harness continuity between ECM terminal (35) and body ground.
Continuity should exist.

N.G.

(A)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST








BF

HA

EL



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



H

ⓑ

H

CHECK GROUND CIRCUIT.

1) Turn ignition switch "OFF".

2) With ASCD:
Check harness continuity between terminals ②, ⑦ and body ground.

Without ASCD:
Check harness continuity between terminals ②, ⑤ and body ground.

N.G. → Repair harness or connectors.

O.K.

I

CHECK INPUT SIGNAL CIRCUIT.

1) With ASCD:
Check harness continuity between ECM terminal ③⑤ and terminal ⑥.

Without ASCD:
Check harness continuity between ECM terminal ③⑤ and terminal ③.

N.G. → Check the following.

- Harness connectors **M7**, **E103**
- Harness connectors **M49**, **F23**
- Harness continuity between ECM and inhibitor relay

If N.G., repair harness or connectors.

O.K.

CHECK COMPONENT (Inhibitor relay). Refer to EF & EC-165.

N.G. → Replace inhibitor relay.

O.K.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-154.

INSPECTION END




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Electrical Components Inspection

ECM INPUT/OUTPUT SIGNAL INSPECTION

- ECM is located behind the center console panel. For this inspection, remove the center console under cover.
- Remove ECM harness protector.
- Perform all voltage measurements with the connectors connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



ECM HARNESS CONNECTOR TERMINAL LAYOUT

101	103	104	105	107	108	1	2	3	4	6	7	15	16	17	18	19	20	21	22	31	32	33	34	35	36	37	38	39
109	110	112	113	116		8	9	10	11	12	13	14	23	24	27	28	29	30	40	41	42	43	44	45	46	47	48	



TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM inspection table

TER-MINAL NO.	ITEM	CONDITION	DATA	
1	Ignition signal	Engine is running. └ Idle speed	0.2 - 0.3V	GI MA
		Engine is running. └ Engine speed is 2,000 rpm.	Approximately 0.8V	EM
3	Ignition check	Engine is running. └ Idle speed	BATTERY POSITIVE VOLTAGE (11 - 14V)	LC
4	ECM relay (Self-shutoff)	Engine is running. Ignition switch "OFF" └ For approximately 1 second after turning ignition switch "OFF"	0 - 1V	EF & EC FE
		Ignition switch "OFF" └ Approximately 1 second after turning ignition switch "OFF"	BATTERY POSITIVE VOLTAGE (11 - 14V)	CL MT
8	EGR temperature sensor	Engine is running. └ EGR system is not operating.	Less than 5V	AT
		Engine is running. └ EGR system is operating.	0 - 1.0V	FA
9	Radiator fan relay (Low speed)	Engine is running. └ Radiator fans are not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	RA
		Engine is running. └ Radiator fans are operating at low speed.	Approximately 0.7V	BR
10	Radiator fan relay (High speed)	Engine is running. └ Radiator fans are not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	ST
		Engine is running. └ Radiator fans are operating at high speed.	Approximately 0.7V	BF
11	Air conditioning relay	Engine is running. └ Both A/C switch and blower switch are "ON".	Approximately 0.7V	HA
		Engine is running. └ A/C switch is "OFF".	BATTERY POSITIVE VOLTAGE (11 - 14V)	EL
16	Mass air flow sensor	Engine is running. └ Idle speed	0.8 - 3.0V Output voltage varies with engine speed.	
18	Engine coolant temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine water temperature.	

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

TER-MINAL NO.	ITEM	CONDITION	DATA
19	Oxygen sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ After warming up sufficiently	0 - Approximately 1.0V
20	Throttle position sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	0.3 - Approximately 4V Output voltage varies with the throttle valve opening angle.
22 30	Crankshaft position sensor (Reference signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Do not run engine at high speed under no-load.	0.1 - 1.3V
24	Malfunction indicator lamp	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 1.5V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div>	BATTERY POSITIVE VOLTAGE (11 - 14V)
27	Knock sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	Approximately 2.5V
31 40	Crankshaft position sensor (Position signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Do not run engine at high speed under no-load.	2.0 - 3.0V
32	Vehicle speed sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Engine stopped and gear position is "Neutral". └ While rotating front wheel by hand	Varies from 0 to 10V
33	Rear window defogger switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Rear window defogger switch is "ON".	BATTERY POSITIVE VOLTAGE (11 - 14V)
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Rear window defogger switch is "OFF".	0V
34	Start signal	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "START"</div>	BATTERY POSITIVE VOLTAGE (11 - 14V)
35	Park/neutral position switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Park/neutral position	0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Except the above gear position	Approximately 6V
36	Ignition switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "OFF"</div>	0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	BATTERY POSITIVE VOLTAGE (11 - 14V)
37	Throttle position sensor power supply	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 5V

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

TER-MINAL NO.	ITEM	CONDITION	DATA	
38 47	Power supply for ECM	Ignition switch "ON"	BATTERY POSITIVE VOLTAGE (11 - 14V)	GI
41	Air conditioning switch	Engine is running. └ Both air conditioning switch and blower switch are "ON".	Approximately 0V	MA EM
		Engine is running. └ Air conditioning switch is "OFF".	BATTERY POSITIVE VOLTAGE (11 - 14V)	LC
43	Power steering pressure switch	Engine is running. └ Steering wheel is being turned.	0V	EF & EC
		Engine is running. └ Steering wheel is not being turned.	Approximately 8V	FE CL
45	Air conditioning triple-pressure switch	Engine is running. └ Air conditioning switch is "ON". └ Air conditioning triple-pressure switch is "ON".	Approximately 0V	MT AT
		Engine is running. └ Air conditioning switch is "ON". └ Air conditioning triple-pressure switch is "OFF".	Approximately 7V	FA RA
46 109	Power supply (Back-up)	Ignition switch "OFF"	BATTERY POSITIVE VOLTAGE (11 - 14V)	BR
101	Injector No. 1	Engine is running.	BATTERY POSITIVE VOLTAGE (11 - 14V)	ST
103	Injector No. 3			
110	Injector No. 2			
112	Injector No. 4			BF
104	Fuel pump relay	Ignition switch "ON" └ For 5 seconds after turning ignition switch "ON"	Approximately 0.8V	HA
		Engine is running. Ignition switch "ON" └ 5 seconds after turning ignition switch "ON"	BATTERY POSITIVE VOLTAGE (11 - 14V)	EL

TROUBLE DIAGNOSES


Electrical Components Inspection (Cont'd)

TER-MINAL NO.	ITEM	CONDITION	DATA
105	EGR & canister control solenoid valve	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> Engine is cold [Water temperature is below 60° (140°F)] 	Approximately 0.7V
		<div style="border: 1px solid black; padding: 2px;">Engine is racing (2,000 rpm)</div> <ul style="list-style-type: none"> After warming up [Water temperature is between 60°F (140°C) and 105°C (221°F)] 	BATTERY POSITIVE VOLTAGE (11 - 14V)
113	IAC valve-AAC valve	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> Idle speed 	9 - 14V
		<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> Steering wheel is being turned. Air conditioning is operating. Rear defogger is "ON". Headlamp are in high position. 	5 - 9V

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

CRANKSHAFT POSITION SENSOR



1. Remove distributor assembly from engine. Disconnect ignition wires and center cable from distributor. (Crankshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON".
3. Rotate crankshaft position sensor shaft slowly by hand and check voltage between terminals ①, ② and ground.

Terminal	Voltage
① (180° signal)	Voltage fluctuates between 5V and 0V.
② (1° signal)	

4. Rotate crankshaft position sensor shaft slowly by hand and check voltage between terminals ①, ② and ground. Measure with circuit tester set in 100 mV range, AC.


Tester pointer deflects: O.K.

Tester pointer does not deflect: N.G.

If N.G., replace crankshaft position sensor.


After this inspection, diagnostic trouble code No. 11 might be displayed though the crankshaft position sensor is functioning properly. In this case erase the stored memory.

MASS AIR FLOW SENSOR



1. Fold back mass air flow sensor harness connector rubber as shown in the figure if the harness connector is connected.
2. Turn ignition switch "ON".
3. Start engine and warm it up sufficiently.
4. Check voltage between terminal ① and ground.

Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Approximately 0.2
Idle (Engine is warmed-up sufficiently.)	Approximately 0.85 - 1.35




5. If N.G., remove mass air flow sensor from air duct. Check hot film for damage or dust.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)


ENGINE COOLANT TEMPERATURE SENSOR

1. Disconnect engine coolant temperature sensor harness connector.
2. Check resistance as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

If N.G., replace engine coolant temperature sensor.



POWER TRANSISTOR

1. Disconnect power transistor harness connector.
 2. Check power transistor continuity between terminals with a digital tester as shown in the figure.
- The digital tester must have a diode check position to perform this test.

⊕ terminal side	⊖ terminal side					
	Terminal (a)		Terminal (b)		Terminal (c)	
	Resistance Ω	Result	Resistance Ω	Result	Resistance Ω	Result
Terminal (a)	—	—	∞	O.K.	∞	O.K.
	—	—	Not ∞ or 0	N.G.	Not ∞ or 0	N.G.
	—	—	0	N.G.	0	N.G.
Terminal (b)	∞	N.G.	—	—	∞	N.G.
	Not ∞ or 0	O.K.	—	—	Not ∞ or 0	O.K.
	0	N.G.	—	—	0	N.G.
Terminal (c)	∞	N.G.	∞	N.G.	—	—
	Not ∞ or 0	O.K.	Not ∞ or 0	O.K.	—	—
	0	N.G.	0	N.G.	—	—


∞ : Infinity resistance

If N.G., replace power transistor.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

IGNITION COIL



1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.

Terminal	Resistance
Ⓐ - Ⓑ	Approximately 1.0Ω

If N.G., replace power transistor.


GI

MA

EM

LC

FUEL PUMP



1. Disconnect fuel pump harness connector.
2. Check resistance between terminals Ⓐ and Ⓑ.

Resistance: Approximately 0.5Ω


If N.G., replace fuel pump.

EF & EC

FE

CL

EGR AND CANISTER CONTROL SOLENOID VALVE



Check air passage continuity.

Condition	Air passage continuity between Ⓐ and Ⓑ	Air passage continuity between Ⓐ and Ⓒ
12V direct current supply between terminals Ⓐ and Ⓑ	Yes	No
No supply	No	Yes

If N.G., replace solenoid valve.

MT

AT

FA

RA


BR

ST

BF

HA

EL



EGR VALVE

Apply vacuum to EGR vacuum port with a hand vacuum pump.

EGR valve spring should lift.


If N.G., replace EGR valve.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

EGR CONTROL-BPT VALVE

Plug one of two ports of EGR control-BPT valve.
Apply a pressure above 0.490 kPa (50 mmH₂O, 1.97 inH₂O) to check for leakage. If a leak is noted, replace valve.



EGR TEMPERATURE SENSOR


Check resistance change and resistance value at 100°C (212°F).

- Resistance should decrease in response to temperature increase.

Resistance: 100°C (212°F)


$85.3 \pm 8.53 \text{ k}\Omega$

If N.G., replace EGR temperature sensor.



WIDE OPEN THROTTLE POSITION SWITCH — AT model only

1. Disconnect wide open throttle position switch harness connector.
2. Check continuity between terminals ② and ③.



Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

If N.G., replace wide open throttle position switch.


TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

CLOSED THROTTLE POSITION SWITCH (Idle position)

— A/T model only

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between terminals ① and ②.




Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

If N.G., replace closed throttle position switch.



THROTTLE POSITION SENSOR

1. Disconnect throttle position sensor harness connector.
2. Make sure that resistance between terminals ② and ③ changes when opening throttle valve manually.



Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 2
Partially released	2 - 10
Completely depressed	Approximately 10

If N.G., replace throttle position sensor.




Adjustment

If throttle position sensor, closed throttle position switch or wide open throttle position switch is replaced or removed, it is necessary to install in proper position, by following the procedure as shown below:


MT model;

1. Install throttle position sensor body in throttle body. Do not tighten bolts. Leave bolts loose.
2. Connect throttle position sensor harness connector.
3. Start engine and warm it up sufficiently.
4. Perform "THRTL POS SEN ADJ" in "WORK SUPPORT" mode.
5. Adjust by rotating throttle position sensor body so that output voltage is 0.3 to 0.7V.
6. Tighten mounting bolts.
7. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.



TROUBLE DIAGNOSES


Electrical Components Inspection (Cont'd)



AT model;

1. Install throttle position sensor in throttle body. Do not tighten bolts. Leave bolts loose.
2. Connect throttle position sensor and closed throttle position switch harness connector.
3. Start engine and warm it up sufficiently.
4. Disconnect closed throttle position switch harness connector.
5. Check closed throttle position switch OFF → ON engine speed with circuit tester, closing throttle valve manually.

Closed throttle position switch continuity OFF → ON engine speed (in "N" position):
900 ± 150 rpm




IAC VALVE-AAC VALVE

- Check IAC valve-AAC valve resistance.

Resistance:

Approximately 10Ω

- Check plunger for seizing or sticking.
- Check for broken spring.



KNOCK SENSOR


1. Disconnect engine harness No. 2 connector (E205).
2. Check continuity between terminal (f) and ground.

Continuity should exist.

- It is necessary to use an ohmmeter which can measure more than 10 MΩ.

CAUTION:

Discard any knock sensor which has been dropped or undergone shocks; use a new one.



INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: Approximately 11Ω [at 20°C (68°F)]


If N.G., replace injector.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM RELAY AND FUEL PUMP RELAY

Check continuity between terminals ③ and ⑤.




SEF054F

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If N.G., replace relay.

INHIBITOR RELAY (A/T models with ASCD)

Check continuity between terminals ⑥ and ⑦.




AEC157

Conditions	Continuity
12V direct current supply between terminals ① and ②.	Yes
No current supply	No

If N.G., replace relay.

INHIBITOR RELAY (A/T models without ASCD) AND RADIATOR FAN RELAY-1

Check continuity between terminals ③ and ⑤.




SEF090M

Conditions	Continuity
12V direct current supply between terminals ① and ②.	Yes
No current supply	No

If N.G., replace relay.

RADIATOR FAN RELAYS-2 AND -3

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.




SEC202B

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If N.G., replace relay.

POWER STEERING PRESSURE SWITCH

1. Disconnect power steering pressure switch harness connector.
2. Check continuity between terminals.



AEC249

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

IAC VALVE-AIR REGULATOR

1. Remove IAC valve unit from engine.
2. Immerse IAC valve unit in cold or hot water as shown, and check air flow.




Water temperature	When blowing from air inlet hole
20°C (68°F)	Air flows
80°C (176°F) or more	Almost no air flows

If N.G., replace IAC valve unit.


IAC VALVE-FICD SOLENOID VALVE

- Check that clicking sound is heard when applying 12V direct current to terminals.
- Check plunger for seizure or sticking.
- Check for broken spring.



RADIATOR FAN MOTORS-1 AND -2

1. Disconnect radiator fan motor harness connectors.
2. Supply radiator fan motor terminals with battery positive voltage and check operation.



	Speed	Terminals	
		(+)	(-)
Radiator fan motor-1	Low	(b)	(c)
	High	(a, b)	(c, d)
Radiator fan motor-2	Low	(b)	(c)
	High	(a, b)	(c, d)

Radiator fan motor should operate.


If N.G., replace radiator fan motor.

RESISTOR




1. Disconnect resistor harness connector (F8).
2. Check resistance between terminals (a) and (b).

Resistance: Approximately 2.2kΩ

If N.G., replace resistor.




MULTIPOINT FUEL INJECTION SYSTEM INSPECTION



Releasing Fuel Pressure

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".

- 
1. Remove fuel pump fuse.
 2. Start engine.
 3. After engine stalls, crank it two or three times to release all fuel pressure.
 4. Turn ignition switch "OFF" and reconnect fuel pump fuse.

Fuel Pressure Check

- a. Make sure that clamp screw does not contact adjacent parts.
 - b. Use a torque driver to tighten clamps.
 - c. Use Pressure Gauge to check fuel pressure.
 - d. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.
 4. Start engine and check for fuel leakage.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

MULTIPOINT FUEL INJECTION SYSTEM INSPECTION

Fuel Pressure Check (Cont'd)

5. Read the indication of fuel pressure gauge.

At idling:


When fuel pressure regulator valve vacuum hose is connected.

Approximately 235 kPa (2.4 kg/cm², 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected.

Approximately 294 kPa (3.0 kg/cm², 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check.




Fuel Pressure Regulator Check

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a rubber cap.
3. Connect variable vacuum source to fuel pressure regulator.

4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.




Injector Removal and Installation

1. Release fuel pressure to zero.
2. Remove injector tube assembly with injectors from intake manifold.
3. Remove injectors from injector tube assembly.
 - Push injector tail piece.
 - Do not pull on the connector.
4. Install injectors as follows:
 - Clean exterior of injector tail piece.
 - Use new O-rings
5. Assemble injectors to injector tube assembly.


CAUTION:

After properly connecting injectors to fuel tube assembly, check connections for fuel leakage.



EVAPORATIVE EMISSION (EVAP) SYSTEM

Description



The evaporative emission (EVAP) system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.


Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.

Inspection

CARBON CANISTER

Check carbon canister as follows:

1. Blow air in port (A) and ensure that there is no leakage.
2. ● Apply vacuum to port (A)
● Cover port (D) with your hand.
● Blow air in port (C) and ensure free flow out of port (B).




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


EVAPORATIVE EMISSION (EVAP) SYSTEM

Inspection (Cont'd)

FUEL TANK VACUUM RELIEF VALVE



1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. If valve is clogged or if no resistance is felt, replace cap as an assembly.



FUEL CHECK VALVE

1. Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow should be directed toward the canister.
2. Blow air through connector on canister side. Air flow should be smoothly directed toward fuel tank.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

CRANKCASE EMISSION CONTROL SYSTEM

Description

This system returns blow-by gas to the intake collector.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.



During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air duct, through the hose connecting air inlet tubes to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the intake collector under all conditions.



Inspection

PCV (Positive Crankcase Ventilation) VALVE

With engine running at idle, remove PCV valve from breather separator; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

PRESSURE REGULATOR	
Fuel pressure at idling kPa (kg/cm ² , psi)	
Vacuum hose is connected	Approximately 235 (2.4, 34)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Inspection and Adjustment

Idle speed*1	rpm	
No-load*2	(in "N" position)	700 ± 50
Air conditioning: ON	(in "N" position)	800 ± 50
Ignition timing		20° ± 2° B.T.D.C.
Throttle position sensor idle position	V	0.3 - 0.7

*1: Feedback controlled and needs no adjustments

*2: Under the following conditions:

- Air conditioning switch: OFF
- Electric load: OFF (Lights, heater, fan & rear defogger)

IGNITION COIL

Primary voltage	V	Battery positive voltage (11 - 14)
Primary resistance [at 20°C (68°F)]	Ω	Approximately 1.0
Secondary resistance [at 20°C (68°F)]	kΩ	Approximately 10.0

ENGINE COOLANT TEMPERATURE SENSOR

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

EGR TEMPERATURE SENSOR

Resistance [at 100°C (212°F)]	kΩ	85.3 ± 8.53
----------------------------------	----	-------------

FUEL PUMP

Resistance	Ω	Approximately 0.5
------------	---	-------------------

IAC VALVE-AAC VALVE

Resistance	Ω	Approximately 10.0
------------	---	--------------------

INJECTOR

Resistance	Ω	Approximately 11
------------	---	------------------

RESISTOR

Resistance	kΩ	Approximately 2.2
------------	----	-------------------

ACCELERATOR CONTROL, FUEL AND EXHAUST SYSTEMS

SECTION FE

CONTENTS

ACCELERATOR CONTROL SYSTEM2	Special Service Tool.....4
Adjusting Accelerator Cable2	Fuel Pump And Gauge4
FUEL SYSTEM3	EXHAUST SYSTEM5
Fuel Tank3	

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

ACCELERATOR CONTROL SYSTEM

CAUTION:

- When removing accelerator cable, make a mark to indicate lock nut's initial position.
- Check that throttle valve opens fully when accelerator pedal is fully depressed and that it returns to idle position when pedal is released.
- Check accelerator control parts for improper contact with any adjacent parts.
- When connecting accelerator cable, be careful not to twist or scratch its inner wire.
- For ASCD cable adjustment, refer to EL section ("ASCW WIRE ADJUSTMENT", "Trouble Diagnoses", "AUTOMATIC SPEED CONTROL DEVICE").



Adjusting Accelerator Cable

1. Loosen lock nut and tighten adjusting nut until throttle drum starts to move.
2. From that position turn back adjusting nut 1.5 to 2 turns, and secure lock nut.

FUEL SYSTEM

Fuel Tank


WARNING:

When replacing fuel line parts, be sure to observe the following:

- Put a "CAUTION: INFLAMMABLE" sign in workshop.
- Be sure to furnish workshop with a CO₂ fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to disconnect battery ground cable before conducting operations.
- Drain fuel from Fuel Tank and put drained fuel in an explosion-proof container and put lid on securely.

CAUTION:

- Before disconnecting fuel hose, release fuel pressure from fuel line. Refer to MA section ("Changing Fuel Filter", "ENGINE MAINTENANCE").
- Do not disconnect any fuel line unless absolutely necessary.
- Plug hose and pipe openings to prevent entry of dust or dirt.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose clamps excessively to avoid damaging hoses.
- When installing fuel check valve, be careful of its designated direction. Refer to EF & EC section ("Inspection", "EVAPORATIVE EMISSION (EVAP) SYSTEM").
- Tighten bolts to specified torque.
- After installation, run engine and check for leaks at connections.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA


EL

FUEL SYSTEM

Fuel Tank (Cont'd)

SPECIAL SERVICE TOOL


Tool number (Kent-Moore No.) Tool name	Description
KV999G0010 (X38879) Fuel tank lock ring socket	




FUEL PUMP AND GAUGE

Removal


1. Release fuel pressure from fuel line. Refer to MA section ("Changing Fuel Filter", "ENGINE MAINTENANCE").
2. Remove inspection hole cover located under rear seat.
3. Disconnect connectors and fuel tubes.
4. Remove lock ring (Use S.S.T. X38879).



5. Remove fuel gauge assembly and disconnect tubes and connector.



6. Remove fuel pump as shown in the figure.




Installation

- Installation procedure is basically the reverse order of removal.

CAUTION:

- Always replace O-ring with a new one.
- Align parts with alignment marks.
- Tighten lock ring to specified torque.
- After installation, run engine and check for leaks at connections.

EXHAUST SYSTEM



CAUTION:

- Always replace exhaust gaskets with new ones when reassembling. If gasket is left on flange surface, scrape off completely as shown at left.
- With engine running, check all tube connections for exhaust gas leaks, and entire system for unusual noises.
- After installation, check to ensure that mounting brackets and mounting insulators are free from undue stress. If any of the above parts are not installed properly, excessive noise or vibration may be transmitted to the vehicle body.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA

EL



AFE003




SECTION CL

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS

<p>PRECAUTIONS AND PREPARATION..... 2</p> <p style="padding-left: 20px;">Precautions..... 2</p> <p style="padding-left: 20px;">Preparation 2</p> <p style="padding-left: 40px;">Special Service Tools..... 2</p> <p>CLUTCH SYSTEM — Hydraulic Type..... 3</p> <p>INSPECTION AND ADJUSTMENT..... 4</p> <p style="padding-left: 20px;">Adjusting Clutch Pedal..... 4</p> <p style="padding-left: 40px;">For USA model only 5</p> <p style="padding-left: 20px;">Bleeding Procedure 5</p> <p>HYDRAULIC CLUTCH CONTROL 6</p> <p style="padding-left: 20px;">Clutch Master Cylinder 6</p> <p style="padding-left: 40px;">Disassembly And Assembly..... 6</p> <p style="padding-left: 20px;">Inspection..... 7</p> <p style="padding-left: 20px;">Operating Cylinder 7</p> <p style="padding-left: 40px;">Inspection..... 7</p> <p>CLUTCH RELEASE MECHANISM..... 8</p> <p style="padding-left: 20px;">Inspection..... 8</p> <p style="padding-left: 20px;">Lubrication 8</p> <p>CLUTCH DISC AND CLUTCH COVER..... 9</p>	<p style="padding-left: 20px;">Clutch Disc 9</p> <p style="padding-left: 40px;">Inspection..... 9</p> <p style="padding-left: 40px;">Installation 9</p> <p style="padding-left: 20px;">Clutch Cover and Flywheel 10</p> <p style="padding-left: 40px;">Inspection And Adjustment 10</p> <p style="padding-left: 40px;">Flywheel Inspection 10</p> <p style="padding-left: 40px;">Installation 10</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS) 11</p> <p style="padding-left: 20px;">General Specifications 11</p> <p style="padding-left: 40px;">Clutch Control System 11</p> <p style="padding-left: 40px;">Clutch Master Cylinder 11</p> <p style="padding-left: 40px;">Clutch Operating Cylinder 11</p> <p style="padding-left: 40px;">Clutch Disc..... 11</p> <p style="padding-left: 40px;">Clutch Cover 11</p> <p style="padding-left: 20px;">Inspection and Adjustment 11</p> <p style="padding-left: 40px;">Clutch Pedal 11</p> <p style="padding-left: 40px;">Clutch Disc..... 11</p> <p style="padding-left: 40px;">Clutch Cover 11</p>
---	--

PRECAUTIONS AND PREPARATION



Precautions

- Recommended fluid is brake fluid “DOT 3”.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.

WARNING:


After cleaning clutch disc, wipe it with a dust collector. Do not use compressed air.

Preparation

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description	
GG94310000 (-) Flare nut torque wrench	Removing and installing clutch piping	
KV30101000 (J33213) Clutch aligning bar	Installing clutch cover and clutch disc	
ST20050010 (-) Base plate	Inspecting diaphragm spring of clutch cover	
ST20050100 (-) Distance piece	Inspecting diaphragm spring of clutch cover	
ST20050240 (-) Diaphragm spring adjusting wrench	Adjusting unevenness of diaphragm spring of clutch cover	

CLUTCH SYSTEM — Hydraulic Type



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

L : Apply lithium-based grease including molybdenum disulphide.


: N•m (kg-m, ft-lb)

INSPECTION AND ADJUSTMENT

Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper or ASCD cancel switch.

Pedal height "H":
165 - 175 mm (6.50 - 6.89 in)




2. Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

Pedal free play "A₁":
1.0 - 3.0 mm (0.039 - 0.118 in)

Pedal free play means the following total, measured at position of pedal pad.

- Play due to clevis pin and clevis pin hole in clutch pedal.



INSPECTION AND ADJUSTMENT




Adjusting Clutch Pedal (Cont'd)

For USA model only

- Adjust clearance "C" between stopper rubber and threaded end of clutch interlock switch while depressing clutch pedal fully.

Clearance C:

0.1 - 1.0 mm (0.004 - 0.039 in)



Bleeding Procedure

Bleed air according to the following procedure.

- Carefully monitor fluid level at master cylinder during bleeding operation.

- Top up reservoir with recommended brake fluid.
- Connect a transparent vinyl tube to air bleeder valve of clutch operating cylinder.
- Fully depress clutch pedal several times.
- With clutch pedal depressed, open bleeder valve to release air.
- Close bleeder valve.
- Repeat steps 3 through 5 above until clear brake fluid comes out of air bleeder valve.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder



DISASSEMBLY AND ASSEMBLY

- Push piston into cylinder body with screwdriver when removing and installing valve stopper.



- Align piston assembly groove and valve stopper when installing valve stopper.
- Check direction of piston cups.

HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder (Cont'd)

INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

Operating Cylinder




INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Piston spring, for wear or damage
- Dust cover, for cracks, deformation or damage


CLUTCH RELEASE MECHANISM



INSPECTION

Check the following items, and replace if necessary.




- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting or wear
- Release sleeve and withdrawal lever rubbing surface, for wear, rust or damage



LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.
- **Too much lubricant might damage clutch disc facing.**

CLUTCH DISC AND CLUTCH COVER



Clutch Disc

INSPECTION

Check the following items, and replace if necessary.

- Clutch disc, for burns, discoloration, oil or grease leakage
- Clutch disc, for wear of facing

Wear limit of facing surface to rivet head:
0.3 mm (0.012 in)

- Check clutch disc for backlash of spline and runout of facing.
Maximum backlash of spline (at outer edge of disc):
0.9 mm (0.035 in)
Runout limit:
1.0 mm (0.039 in)
Distance of runout check point (from hub center):
107.5 mm (4.23 in)

INSTALLATION

- Apply recommended grease to contact surface of spline portion.
- Too much lubricant might damage clutch facing.

CLUTCH DISC AND CLUTCH COVER

Clutch Cover and Flywheel


INSPECTION AND ADJUSTMENT

- Set Tool and check height and unevenness of diaphragm spring.
- Set 0.4 mm (0.016 in) feeler gauges on distance pieces (ST20050100) when checking diaphragm spring height.

Diaphragm spring height "A":

33.0 - 35.0 mm (1.299 - 1.378 in)

- Check thrust rings for wear or damage by shaking cover assembly and listening for chattering noise, or lightly hammering on rivets for a slightly cracked noise. Replace clutch cover assembly if necessary.
- Check pressure plate and clutch disc contact surface for slight burns or discoloration. Clean pressure plate with emery paper.
- Check pressure plate and clutch disc contact surface for deformation or damage. Replace if necessary.




SCL219

- Adjust unevenness of diaphragm spring with Tool.

Uneven limit:

0.7 mm (0.028 in)



SCL512


FLYWHEEL INSPECTION

- Check contact surface of flywheel for slight burns or discoloration. Clean flywheel with emery paper.
- Check flywheel runout.

Runout (Total indicator reading):

Flywheel


Refer to EM section ("Inspection", "CYLINDER BLOCK").



SCL349

INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.
- Tighten bolts in numerical order.
- Be careful not to allow grease to contaminate clutch facing.



SCL511

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

CLUTCH MASTER CYLINDER

Inner diameter	mm (in)	15.87 (5/8)
----------------	---------	-------------

CLUTCH OPERATING CYLINDER

Inner diameter	mm (in)	19.05 (3/4)
----------------	---------	-------------

CLUTCH DISC

Unit: mm (in)

Model	225TBL
Facing size (Outer dia. x inner dia. x thickness)	225 x 150 x 3.5 (8.86 x 5.91 x 0.138)
Thickness of disc assembly With load	7.9 - 8.3 (0.311 - 0.327) with 4,904 N (500 kg, 1,103 lb)

CLUTCH COVER

Model	T225S
Full-load	N (kg, lb) 4,904 (500, 1,103)

Inspection and Adjustment

CLUTCH PEDAL

Unit: mm (in)

Pedal height*	165 - 175 (6.50 - 6.89)
Pedal free play	1.0 - 3.0 (0.039 - 0.118)
Clearance between pedal stopper rubber and clutch interlock switch threaded end while clutch pedal is fully depressed.	0.1 - 1.0 (0.004 - 0.039)

*: Measured from surface of melt sheet to pedal pad

CLUTCH DISC

Unit: mm (in)

Model	225TBL
Wear limit of facing surface to rivet head	0.3 (0.012)
Runout limit of facing	1.0 (0.039)
Distance of runout check point (from the hub center)	107.5 (4.23)
Maximum backlash of spline (at outer edge disc)	0.9 (0.035)

CLUTCH COVER

Unit: mm (in)

Model	C225S
Diaphragm spring height	33.0 - 35.0 (1.299 - 1.378)
Uneven limit of diaphragm spring toe height	0.7 (0.028)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



MANUAL TRANSAXLE

SECTION **MT**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA








EL

CONTENTS








PREPARATION	2	Gear and shaft	22
Special Service Tools.....	2	Synchronizer	23
Commercial Service Tools	4	Bearing	24
ON-VEHICLE SERVICE	5	Assembly	24
Differential Side Oil Seal Replacement.....	5	Final Drive	26
Striking Rod Oil Seal Replacement.....	5	Disassembly.....	26
Position Switch Check	6	Inspection.....	27
Back-Up Lamp Switch And Neutral Position		Assembly	28
Switch.....	6	Shift Control Components	30
Viscous Coupling Check.....	6	Inspection.....	30
REMOVAL AND INSTALLATION	7	Case Components	30
Removal	7	Removal And Installation	30
Installation	8	Mainshaft front bearing outer race	31
TRANSAXLE GEAR CONTROL	9	ADJUSTMENT	32
MAJOR OVERHAUL	10	Input Shaft End Play and Differential Side	
Case Components	10	Bearing Preload	32
Gear Components.....	11	Mainshaft Bearing Preload	33
Shift Control Components	12	ASSEMBLY	36
DISASSEMBLY	13	SERVICE DATA AND SPECIFICATIONS (SDS)	40
REPAIR FOR COMPONENT PARTS	16	General Specifications	40
Input Shaft and Gears	16	Inspection and Adjustment	41
Disassembly.....	16	Gear End Play	41
Inspection.....	17	Clearance Between Baulk Ring And Gear	
Gear and shaft	17	1st, 3rd, 4th, & 5th	41
Synchronizer	17	Reverse Baulk Ring.....	41
Assembly	18	2nd baulk ring	41
Mainshaft and Gears	21	Available Snap Ring.....	41
Disassembly.....	21	Available Washer.....	42
Inspection.....	22	Available Shim.....	42

PREPARATION



SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description	
KV38106500 (J34284) Preload adapter	Measuring turning torque of final drive assembly Measuring total turning torque Measuring clearance between side gear and differential case with washer Selecting differential side bearing adjusting shim	
KV32101000 (J25689-A) Pin punch	Removing and installing retaining pin	
ST22730000 (J25681) Puller	Removing mainshaft front and rear bearing inner race	
ST30031000 (J22912-01) Puller	Removing input shaft front and rear bearing Removing 4th & 5th main gear	
ST30021000 (J22912-01) Puller	Removing 5th synchronizer Removing 3rd & 4th synchronizer Removing 2nd & 3rd main gear	
ST3306S001 (-) Differential side bearing puller set ① ST33051001 (-) Puller ② ST33061000 (J8107-2) Adapter	Removing differential side bearing inner race	 <p>a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.</p>
ST33290001 (J34286) Puller	Removing differential oil seal Removing mainshaft rear bearing outer race Removing differential side bearing outer race	



PREPARATION






Tool number (Kent-Moore No.) Tool name	Description	GI
ST33400001 (J26082) Drift	Installing differential oil seal	MA
		EM
	<p>a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.</p>	LC
ST30600000 (J25863-01) Drift	Installing input shaft front bearing	EF & EC
		FE
	<p>a: 36 mm (1.42 in) dia. b: 31 mm (1.22 in) dia.</p>	CL
ST22452000 (-) Drift	Installing 3rd, 4th and 5th main gear	MT
		AT
	<p>a: 45 mm (1.77 in) dia. b: 36 mm (1.42 in) dia.</p>	FA
ST30621000 (J25742-5) Drift	Installing mainshaft rear bearing outer race (Use with ST30611000.)	RA
		BR
	<p>a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.</p>	ST
ST30611000 (J25742-1) Drift	Installing mainshaft rear bearing outer race (Use with ST30621000.)	BF
		HA
ST307200000 (-) Drift	Installing differential side bearing outer race	EL
		
	<p>a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.</p>	
(J34290) Shim selecting tool set	Selecting differential side bearing adjusting shim	
		

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description	
(J34305) Snap ring remover and installer	Removing and installing stopper ring of shift fork	
(J25407-2)	Measuring reverse baulk ring wear	

COMMERCIAL SERVICE TOOLS

Tool name	Description	
Drift	Installing differential side bearing inner race	 a: 45 mm (1.77 in) dia. b: 41 mm (1.61 in) dia.
Drift	Installing striking rod oil seal	 a: 38 mm (1.50 in) dia. b: 20 mm (0.79 in) dia.



Differential Side Oil Seal Replacement

1. Drain gear oil from transaxle.
2. Remove drive shafts — Refer to FA section (“Removal”, “FRONT AXLE — Drive Shaft”).
3. Remove differential oil seal.

4. Install differential oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts — Refer to FA section (“Installation”, “FRONT AXLE — Drive Shaft”).

Striking Rod Oil Seal Replacement

1. Remove transaxle control rod from yoke.
2. Remove yoke retaining pin.
 - **Be careful not to damage boot.**

3. Remove striking rod oil seal.

4. Install striking rod oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL




Position Switch Check

BACK-UP LAMP SWITCH AND NEUTRAL POSITION SWITCH

- Check continuity.

Gear position	Continuity
Reverse	② – ④
Neutral	① – ③
Except reverse and neutral	No



Viscous Coupling Check

1. Apply parking brake firmly and place shift lever in the neutral position.
2. Jack up front wheels.
3. Rotate one front wheel and check turning direction of the other front wheel.






Turning direction of the two wheels is opposite:

The viscous coupling is not functioning normally.

Turning direction of the two wheels is the same:

If differential side gear and pinion mate gear thrust washers are O.K., viscous coupling is functioning normally.

REMOVAL AND INSTALLATION



Removal

1. Remove battery and bracket.
2. Remove air cleaner box with mass air flow sensor.
3. Remove air duct.
4. Remove clutch operating cylinder from transaxle.
5. Disconnect back-up lamp switch harness connectors.
6. Remove starter motor from transaxle.
7. Remove shift control rod from transaxle.
8. Drain gear oil from transaxle.
9. Draw out drive shafts from transaxle — Refer to FA section ("Removal", "FRONT AXLE — Drive Shaft").

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

REMOVAL AND INSTALLATION



Removal (Cont'd)

10. Support engine by placing a jack under oil pan.


CAUTION:

Do not place jack under oil pan drain plug.

11. Remove rear and LH mounts.




12. Raise jack for access to lower housing bolts. Remove bolts. Lower jack.



13. Remove bolts securing transaxle.

14. Lower transaxle while supporting it with a jack.




Installation

1. Tighten bolts securing transaxle.

Bolt No.	Tightening torque N•m (kg-m, ft-lb)	ℓ mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	45 (1.77)
2	39 - 49 (4.0 - 5.0, 29 - 36)	48 (1.89)
3	30 - 40 (3.1 - 4.1, 22 - 30)	30 (1.18)
4	30 - 40 (3.1 - 4.1, 22 - 30)	40 (1.57)

MAJOR OVERHAUL

Case Components



: N·m (kg·m, ft·lb)


: Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.

Gear Components

Apply gear oil to gears, shafts, synchronizers and bearings when assembling.


: N·m (kg-m, ft-lb)
 ★ : Select proper thickness.

: Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT**
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL


DISASSEMBLY




1. Before removing transmission case, remove bolts and plugs as shown left.
2. Remove transmission case.




3. Remove position switch.



4. Mesh 4th gear, and then remove reverse idler shaft and reverse idler gear.



5. Pull out retaining pin from clutch housing.



6. Remove reverse lever spring and reverse lock spring from reverse lever assembly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY




7. Remove reverse arm shaft while rotating it.



8. Remove reverse lever assembly.




9. Remove 5th & reverse check plug, spring and ball.



10. Remove stopper rings and retaining pins from 5th & reverse and 3rd & 4th fork rods.


11. Remove 5th & reverse and 3rd & 4th fork rods. Then remove forks and brackets.




12. Remove both input and mainshafts with 1st & 2nd fork and fork rod as a set.

13. Remove final drive assembly.



DISASSEMBLY




14. Remove reverse check assembly.



15. Remove retaining pin and detach the selector.



16. Remove drain plug for convenience in removing retaining pin which holds striking lever to striking rod.



17. Remove retaining pin and then withdraw striking lever and striking rod.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears






DISASSEMBLY

1. Before disassembly, check 3rd, 4th and 5th input gear end plays.

Gear end play

Gears	End play mm (in)
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

- If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring and thrust washer — Refer to MT-18.




2. Remove input shaft rear bearing.

3. Remove 5th & reverse synchronizer and 5th input gear.


4. Remove thrust washer ring, thrust washers and 4th input gear.

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)




5. Remove snap ring.



6. Remove 3rd & 4th synchronizer and 3rd input gear.




7. Remove input shaft front bearing.



INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.



Synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



- Measure clearance between baulk ring and gear (4th and 5th).


Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)

Wear limit

0.7 mm (0.028 in)



- Measure wear of reverse baulk ring.

- a. Place reverse baulk ring on Tool and then place reverse synchronizer cone on reverse baulk ring.

- Make sure projection of synchronizer cone is positioned over the recess on Tool.


- b. While holding reverse synchronizer cone against reverse baulk ring as firmly as possible, measure dimension "A" with dial indicator.

Wear limit:

Dimension "A"


1.2 mm (0.047 in)

- c. If dimension "A" is smaller than the wear limit, replace baulk ring.



Bearing






- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.



ASSEMBLY

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



1. Place inserts in three grooves on coupling sleeve (3rd & 4th synchronizer).

2. Install 3rd input gear and 3rd baulk ring.

3. Press on 3rd & 4th synchronizer hub.

• **Pay attention to its direction.**

4. Select proper snap ring of 3rd & 4th synchronizer hub to minimize clearance of groove, and then install it.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Snap ring of 3rd & 4th synchronizer hub:

Refer to MT-41.

5. Install 4th input gear.

6. Select proper thrust washers to minimize clearance of groove.

Then install them and thrust washer ring.

Allowable clearance of groove:

0 - 0.06 mm (0 - 0.0024 in)

Input shaft thrust washer:

Refer to MT-42.

7. Install 5th & reverse synchronizer assembly.

a. Hook insert springs on reverse baulk ring.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)




- b. Install insert springs with reverse baulk ring onto coupling sleeve.
- **Pay attention to position of insert springs.**
- c. Place 5th baulk ring on 5th input gear.
- d. Install reverse synchronizer cone on reverse baulk ring.




- e. Place reverse synchronizer assembly on 5th input gear.
- **Mesh recesses of 5th input gear with projections of reverse synchronizer cone.**
- **Put insert spring mounts on reverse baulk ring upon those on 5th baulk ring.**




- f. Press on 5th & reverse synchronizer assembly with 5th input gear.



8. Install input shaft front and rear bearings.
9. Measure gear end play as the final check — Refer to MT-16.



REPAIR FOR COMPONENT PARTS




Mainshaft and Gears

DISASSEMBLY


1. Before disassembly, check 1st and 2nd main gear end plays.
Gear end play

Gears	End play mm (in)
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)


If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring — Refer to MT-24.



2. Press out mainshaft rear bearing.



3. Remove thrust washer and snap ring.



4. Press out 5th main gear and 4th main gear.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)


5. Press out 3rd main gear and 2nd main gear.




6. Remove snap ring.



7. Remove 1st & 2nd synchronizer and 1st main gear.




8. Remove mainshaft front bearing.



INSPECTION

Gear and shaft


- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.



REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)

Synchronizer




- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for deformation.

GI

MA

EM

LC



- Measure clearance between baulk ring and gear (1st).

Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)

Wear limit

0.7 mm (0.028 in)


EF &

EC

FE

CL

MT



- Measure wear of 2nd baulk rings.
 - a. Place baulk rings in position on synchronizer cone.
 - b. While holding baulk ring against synchronizer cone as far as it will go, measure dimensions "A" and "B".

Standard:

A 0.6 - 0.8 mm (0.024 - 0.031 in)

B 0.6 - 1.1 mm (0.024 - 0.043 in)

Wear limit:

0.2 mm (0.008 in)

- c. If dimension "A" or "B" is smaller than the wear limit, replace baulk ring.

AT

FA

RA

BR

ST



BF

HA

EL


REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing tapered roller bearing, replace outer and inner race as a set.**



ASSEMBLY



1. Press on 1st main gear, 1st baulk ring and 1st & 2nd synchronizer hub.
2. **Pay attention to direction of 1st & 2nd synchronizer hub.**






Select proper snap ring of 1st & 2nd synchronizer hub to minimize clearance of groove and then install it.

Allowable clearance of groove:
 0 - 0.1 mm (0 - 0.004 in)

Snap ring of 1st & 2nd synchronizer hub:
 Refer to MT-41.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



3. Install 2nd synchronizer cone, inner & outer baulk rings. Insert springs and 1st & 2nd coupling sleeve.
4. Install 2nd main gear.
 - Ensure four protrusions of 2nd synchronizer cone are set in 2nd main gear holes.

5. Press on 3rd main gear.

6. Press on 4th main gear.

7. Press on 5th main gear.
8. Select proper snap ring of 5th main gear to minimize clearance of groove and then install it.
 - Allowable clearance of groove:**
0 - 0.15 mm (0 - 0.0059 in)
 - Snap ring of 5th main gear:**
Refer to MT-41.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




9. Press on thrust washer and press on mainshaft rear bearing.



10. Press on mainshaft front bearing.


11. Measure gear end play as the final check — Refer to MT-21.



Final Drive


DISASSEMBLY

1. Remove final gear.
2. Remove speedometer drive gear by cutting it.



3. Press out differential side bearings.


- Be careful not to mix up the right and left bearings.




4. Remove viscous coupling — Models with viscous coupling.

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)




5. Drive out retaining pin and draw out pinion mate shaft.
6. Remove pinion mate gears and side gears.



INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, viscous coupling, side gears and pinion mate gears.
- Check washers for wear.



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing tapered roller bearing, replace outer and inner race as a set.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)




Viscous coupling

- Check case for cracks.
- Check silicone oil for leakage.




ASSEMBLY

1. Attach side gear thrust washers to side gears, then install pinion mate washers and pinion mate gears in place.



2. Insert pinion mate shaft.

- When inserting, be careful not to damage pinion mate thrust washers.



3. Measure clearance between side gear and differential case with washers following the procedure below:

- a. Set Tool and dial indicator on side gear.
- b. Move side gear up and down to measure dial indicator deflection. Always measure indicator deflection on both side gears.

Clearance between side gear and differential case with washers:


0.1 - 0.2 mm (0.004 - 0.008 in)

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)

- c. If not within specification, adjust clearance by changing thickness of side gear thrust washers.

**Side gear thrust washer:
Refer to MT-42.**




SMT631B



SMT630B

- 4. Install retaining pin.
 - Make sure that retaining pin is flush with case.



SMT687B

- 5. Install viscous coupling — Models with viscous coupling.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)



6. Install final gear.
7. Install speedometer drive gear.




8. Press on differential side bearings.



Shift Control Components

INSPECTION


- Check contact surface and sliding surface for wear, scratches, projections or other damage.



Case Components

REMOVAL AND INSTALLATION

Input shaft oil seal



- Apply multi-purpose grease to seal lip of oil seal before installing.


REPAIR FOR COMPONENT PARTS

Case Components (Cont'd)

Mainshaft front bearing outer race

Mainshaft rear bearing outer race — Refer to MT-33.

Differential side bearing outer race — Refer to MT-32.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

ADJUSTMENT


Input Shaft End Play and Differential Side Bearing Preload

If any of the following parts are replaced, adjust input shaft end play.


- Input shaft
- Input shaft bearing
- Clutch housing
- Transmission case

If any of the following parts are replaced, adjust differential side bearing preload.


- Differential case
- Differential side bearing
- Clutch housing
- Transmission case



1. Remove differential side bearing outer race (transmission case side) and shim(s).



2. Reinstall differential side bearing outer race without shim(s).
3. Install input shaft and final drive assembly on clutch housing.
4. Install transmission case without input shaft bearing shim(s). Tighten it to the specified torque.







5. Using the following procedures, measure clearance between bearings and transmission case.

- **Differential side**
 - a. Attach dial indicator. If clamp diameter of dial indicator is too small or too large, attach dial indicator using a magnetic stand.

ADJUSTMENT

Input Shaft End Play and Differential Side Bearing Preload (Cont'd)



- b. Insert Tool all the way into differential side gear. Move Tool up and down and measure dial indicator deflection.

- **Input shaft side**

- Set dial indicator on rear end of input shaft.
 - Move input shaft up and down and measure dial indicator deflection.
- Select shims with proper thickness with SDS table as a guide. Refer to MT-43.
 - Install selected differential side bearing adjusting shim and differential side bearing outer race.

- Check differential side bearing turning torque.

- Install final drive assembly on clutch housing.
- Install transmission case on clutch housing.

- **Tighten transmission case fixing bolts to the specified torque.**

- Measure turning torque of final drive assembly.

**Turning torque of final drive assembly
(New bearing):**

4.9 - 7.8 N·m (50 - 80 kg-cm, 43 - 69 in-lb)

- **When old bearing is used again, turning torque will be slightly less than the above.**
- **Make sure torque is close to the specified range.**

Mainshaft Bearing Preload

If any of the following parts are replaced, adjust mainshaft bearing preload.

- **Mainshaft**
- **Mainshaft bearings**
- **Clutch housing**
- **Transmission case**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST






BF

HA

EL

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)



1. Remove mainshaft rear bearing outer race and shim(s).

2. Reinstall mainshaft rear bearing outer race without shims.
3. Clean mating surfaces of clutch housing and transmission case with solvent.
4. Install mainshaft and mainshaft front bearing outer race into transmission case. Turn mainshaft while holding bearing outer race so that bearings are properly seated.


5. Place Tools (bridge and gauging cylinder) onto machined surface of transmission case, allowing gauging cylinder to rest on surface of mainshaft front bearing outer race. Use proper screw in bridge to lock gauging cylinder in place.

6. Turn bridge over and place Tool (gauging plunger) into gauging cylinder.

7. Place bridge, legs up, onto machined surface of clutch housing and allow gauging plunger to rest upon mating surface where mainshaft front bearing outer race fits.

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)




8. Measure with feeler gauge distance between gauging cylinder and shoulder of gauging plunger.
9. Use feeler gauge reading to select correct mainshaft preload shim(s).

Mainshaft bearing adjusting shim:

Refer to MT-42.

10. Install selected mainshaft bearing adjusting shim and mainshaft bearing outer race.
11. Check total turning torque after assembly — Refer to MT-36.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


ASSEMBLY




1. Install striking lever and striking rod.



2. Install selector and retaining pin.




3. Install reverse gate assembly.



4. Install final drive assembly.


5. Install input shaft and mainshaft with 1st & 2nd shift fork assembly.

- Be careful not to damage input shaft oil seal.





6. Install interlock balls and plunger.


ASSEMBLY




7. Install 3rd & 4th shift fork and bracket, then install 3rd & 4th shift rod, stopper ring and retaining pin.



8. Install interlock balls.



9. Install 5th shift fork and bracket, then install shift rod, stopper ring and retaining pin.



10. Install 5th & reverse check plug, spring and ball.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


ASSEMBLY




11. Install reverse lock spring on 5th & reverse bracket.
 - Pay attention to its direction.




12. Install check ball and reverse lever spring on reverse lever assembly.
 - Apply multi-purpose grease to check ball.
 - Pay attention to direction of reverse lever spring.



13. Install reverse lever assembly on clutch housing.




14. Install reverse arm shaft and retaining pin.




15. Hook reverse lock spring and reverse lever spring on reverse lever assembly.

ASSEMBLY




16. Mesh 4th gear, then install reverse idler gear and shaft.

- Pay attention to direction of tapped hole.



17. Place magnet on clutch housing.




18. If bearing preload was adjusted, install selected shim(s) into transmission case.

- To aid in installation of transmission case, place shift selector in the 1st & 2nd shift bracket or between 1st & 2nd bracket and 3rd & 4th bracket.


19. Apply sealant to mating surface of transmission case and install it.

20. Install position switch.



21. Apply sealant to threads of check plugs. Install balls, springs and plugs.

22. After assembly, check that you can shift into each gear smoothly.



23. Measure total turning torque.

Total turning torque (New bearing):

8.8 - 21.6 N·m (90 - 220 kg·cm, 78 - 191 in·lb)

- When old bearing is used again, preload will be slightly less than the above. Make sure torque is close to the specified range.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

TRANSAXLE

Engine		KA24DE	
Transaxle model		RS5F50A	RS5F50V
Number of speeds		5	
Synchronmesh type		Warner	
Shift pattern			
Gear ratio	1st	3.285	
	2nd	1.850	
	3rd	1.206	
	4th	0.954	
	5th	0.740	
	Rev.	3.428	
Number of teeth	Input gear	1st	14
		2nd	20
		3rd	29
		4th	44
		5th	50
		Rev.	14
	Main gear	1st	46
		2nd	37
		3rd	35
		4th	42
		5th	37
		Rev.	48
Reverse idler gear		29	
Oil capacity ℓ (US pt, Imp pt)		4.7 (10, 8-1/4)	

FINAL GEAR

Transaxle model	RS5F50A	RS5F50V, RS5F50A
Final gear ratio	3.650	3.895
Number of teeth		
Final gear/Pinion	73/20	74/19
Side gear/Pinion	16/10	16/10

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

GEAR END PLAY


Gear	End play mm (in)
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

CLEARANCE BETWEEN BAULK RING AND GEAR 1ST, 3RD, 4TH, & 5TH

Unit: mm (in)

	Standard	Wear limit
1st	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
3rd & 4th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
5th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)

REVERSE BAULK RING




SMT581B

Dimension	Wear limit
A	1.2 mm (0.047 in)

2nd baulk ring

Unit: mm (in)



SMT806B

Dimension	Standard	Wear limit
A	0.6 - 0.8 (0.024 - 0.031)	0.2 (0.008)
B	0.6 - 1.1 (0.024 - 0.043)	

AVAILABLE SNAP RING

3rd & 4th synchronizer hub (At input shaft)

Allowable clearance 0 - 0.1 mm (0 - 0.004 in)

Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

1st & 2nd synchronizer hub

Allowable clearance 0 - 0.1 mm (0 - 0.004 in)

Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

5th main gear

Allowable clearance 0 - 0.15 mm (0 - 0.0059 in)

Thickness mm (in)	Part number
1.95 (0.0768)	32348-05E00
2.05 (0.0807)	32348-05E01
2.15 (0.0846)	32348-05E02
2.55 (0.1004)	32348-05E03

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

AVAILABLE WASHER

Input shaft thrust washer

Allowable clearance		0 - 0.06 mm (0 - 0.0024 in)
Thickness mm (in)	Part number	
4.500 (0.1772)	32278-03E01	
4.525 (0.1781)	32278-03E02	
4.550 (0.1791)	32278-03E03	
4.575 (0.1801)	32278-03E04	

Differential side gear thrust washer — RS5F50A

Allowable clearance between side gear and differential case with washer		0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number	
0.75 (0.0295)	38424-E3020	
0.80 (0.0315)	38424-E3021	
0.85 (0.0335)	38424-E3022	
0.90 (0.0354)	38424-E3023	

Differential side gear thrust washer — RS5F50V

Allowable clearance between side gear and (differential case or viscous coupling) with washer		0.1 - 0.2 mm (0.004 - 0.008 in)
	Thickness mm (in)	Part number
Differential case side	0.75 - 0.80 (0.0295 - 0.0315)	38424-E3000
	0.80 - 0.85 (0.0315 - 0.0335)	38424-E3001
	0.85 - 0.90 (0.0335 - 0.0354)	38424-E3002
	0.90 - 0.95 (0.0354 - 0.0374)	38424-E3003
Viscous coupling side	0.43 - 0.45 (0.0169 - 0.0177)	38424-51E10
	0.52 - 0.54 (0.0205 - 0.0213)	38424-51E11
	0.61 - 0.63 (0.0240 - 0.0248)	38424-51E12
	0.70 - 0.72 (0.0276 - 0.0283)	38424-51E13
	0.79 - 0.81 (0.0311 - 0.0319)	38424-51E14

AVAILABLE SHIM

— INPUT SHAFT END PLAY AND MAINSHAFT AND DIFFERENTIAL SIDE BEARING PRELOAD AND ADJUSTING SHIM

Bearing preload and end play

	Unit: mm (in)
Mainshaft bearing preload	0.25 - 0.30 (0.0098 - 0.0118)
Input shaft end play	0 - 0.06 (0 - 0.0024)
Differential side bearing preload	0.40 - 0.45 (0.0157 - 0.0177)

Turning torque (New bearing)

	Unit: N•m (kg-cm, in-lb)
Final drive only	4.9 - 7.8 (50 - 80, 43 - 69)
Total	8.8 - 21.6 (90 - 220, 78 - 191)

Mainshaft bearing adjusting shim


Thickness mm (in)	Part number
0.40 (0.0157)	32139-03E11
0.44 (0.0173)	32139-03E00
0.48 (0.0189)	32139-03E01
0.52 (0.0205)	32139-03E12
0.56 (0.0220)	32139-03E02
0.60 (0.0236)	32139-03E03
0.64 (0.0252)	32139-03E04
0.68 (0.0268)	32139-03E05
0.72 (0.0283)	32139-03E06
0.76 (0.0299)	32139-03E07
0.80 (0.0315)	32139-03E08
1.20 (0.0472)	32139-03E13

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Table for selecting mainshaft adjusting shim

Unit: mm (in)



SMT467B

Dimension "C"	Suitable shim(s)
0.30 - 0.34 (0.0118 - 0.0134)	0.60 (0.0236)
0.34 - 0.38 (0.0134 - 0.0150)	0.64 (0.0252)
0.38 - 0.42 (0.0150 - 0.0165)	0.68 (0.0268)
0.42 - 0.46 (0.0165 - 0.0181)	0.72 (0.0283)
0.46 - 0.50 (0.0181 - 0.0197)	0.76 (0.0299)
0.50 - 0.54 (0.0197 - 0.0213)	0.80 (0.0315)
0.54 - 0.58 (0.0213 - 0.0228)	0.40 + 0.44 (0.0157 + 0.0173)
0.58 - 0.62 (0.0228 - 0.0244)	0.44 + 0.44 (0.0173 + 0.0173)
0.62 - 0.66 (0.0244 - 0.0260)	0.44 + 0.48 (0.0173 + 0.0189)
0.66 - 0.70 (0.0260 - 0.0276)	0.48 + 0.48 (0.0189 + 0.0189)
0.70 - 0.74 (0.0276 - 0.0291)	0.48 + 0.52 (0.0189 + 0.0205)
0.74 - 0.78 (0.0291 - 0.0307)	0.52 + 0.52 (0.0205 + 0.0205)
0.78 - 0.82 (0.0307 - 0.0323)	0.52 + 0.56 (0.0205 + 0.0220)
0.82 - 0.86 (0.0323 - 0.0339)	0.56 + 0.56 (0.0220 + 0.0220)
0.86 - 0.90 (0.0339 - 0.0354)	0.56 + 0.60 (0.0220 + 0.0236)
0.90 - 0.94 (0.0354 - 0.0370)	0.60 + 0.60 (0.0236 + 0.0236)
0.94 - 0.98 (0.0370 - 0.0386)	0.60 + 0.64 (0.0236 + 0.0252)
0.98 - 1.02 (0.0386 - 0.0402)	0.64 + 0.64 (0.0252 + 0.0252)
1.02 - 1.06 (0.0402 - 0.0417)	0.64 + 0.68 (0.0252 + 0.0268)
1.06 - 1.10 (0.0417 - 0.0433)	0.68 + 0.68 (0.0268 + 0.0268)
1.10 - 1.14 (0.0433 - 0.0449)	0.68 + 0.72 (0.0268 + 0.0283)
1.14 - 1.18 (0.0449 - 0.0465)	0.72 + 0.72 (0.0283 + 0.0283)
1.18 - 1.22 (0.0465 - 0.0480)	0.72 + 0.76 (0.0283 + 0.0299)
1.22 - 1.26 (0.0480 - 0.0496)	0.76 + 0.76 (0.0299 + 0.0299)
1.26 - 1.30 (0.0496 - 0.0512)	0.76 + 0.80 (0.0299 + 0.0315)
1.30 - 1.34 (0.0512 - 0.0528)	0.80 + 0.80 (0.0315 + 0.0315)
1.34 - 1.38 (0.0528 - 0.0543)	0.44 + 1.20 (0.0173 + 0.0472)
1.38 - 1.42 (0.0543 - 0.0559)	0.48 + 1.20 (0.0189 + 0.0472)
1.42 - 1.46 (0.0559 - 0.0575)	0.52 + 1.20 (0.0205 + 0.0472)
1.46 - 1.50 (0.0575 - 0.0591)	0.56 + 1.20 (0.0220 + 0.0472)

Input shaft bearing adjusting shim

Thickness mm (in)	Part number
0.40 (0.0157)	32225-08E00
0.44 (0.0173)	32225-08E01
0.48 (0.0189)	32225-08E02
0.52 (0.0205)	32225-08E03
0.56 (0.0220)	32225-08E04
0.60 (0.0236)	32225-08E05
0.64 (0.0252)	32225-08E06
0.68 (0.0268)	32225-08E07
0.72 (0.0283)	32225-08E08
0.76 (0.0299)	32225-08E09
0.80 (0.0315)	32225-08E10
1.20 (0.0472)	32225-08E11

Table for selecting input shaft bearing adjusting shim

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.65 - 0.69 (0.0256 - 0.0272)	0.64 (0.0252)
0.69 - 0.73 (0.0272 - 0.0287)	0.68 (0.0268)
0.73 - 0.77 (0.0287 - 0.0303)	0.72 (0.0283)
0.77 - 0.81 (0.0303 - 0.0319)	0.76 (0.0299)
0.81 - 0.85 (0.0319 - 0.0335)	0.80 (0.0315)
0.85 - 0.89 (0.0335 - 0.0350)	0.40 + 0.44 (0.0157 + 0.0173)
0.89 - 0.93 (0.0350 - 0.0366)	0.44 + 0.44 (0.0173 + 0.0173)
0.93 - 0.97 (0.0366 - 0.0382)	0.44 + 0.48 (0.0173 + 0.0189)
0.97 - 1.01 (0.0382 - 0.0398)	0.48 + 0.48 (0.0189 + 0.0189)
1.01 - 1.05 (0.0398 - 0.0413)	0.48 + 0.52 (0.0189 + 0.0205)
1.05 - 1.09 (0.0413 - 0.0429)	0.52 + 0.52 (0.0205 + 0.0205)
1.09 - 1.13 (0.0429 - 0.0445)	0.52 + 0.56 (0.0205 + 0.0220)
1.13 - 1.17 (0.0445 - 0.0461)	0.56 + 0.56 (0.0220 + 0.0220)
1.17 - 1.21 (0.0461 - 0.0476)	0.56 + 0.60 (0.0220 + 0.0236)
1.21 - 1.25 (0.0476 - 0.0492)	0.60 + 0.60 (0.0236 + 0.0236)
1.25 - 1.29 (0.0492 - 0.0508)	0.60 + 0.64 (0.0236 + 0.0252)
1.29 - 1.33 (0.0508 - 0.0524)	0.64 + 0.64 (0.0252 + 0.0252)
1.33 - 1.37 (0.0524 - 0.0539)	0.64 + 0.68 (0.0252 + 0.0268)
1.37 - 1.41 (0.0539 - 0.0555)	0.68 + 0.68 (0.0268 + 0.0268)
1.41 - 1.45 (0.0555 - 0.0571)	0.68 + 0.72 (0.0268 + 0.0283)
1.45 - 1.49 (0.0571 - 0.0587)	0.72 + 0.72 (0.0283 + 0.0283)
1.49 - 1.53 (0.0587 - 0.0602)	0.72 + 0.76 (0.0283 + 0.0299)
1.53 - 1.57 (0.0602 - 0.0618)	0.76 + 0.76 (0.0299 + 0.0299)
1.57 - 1.61 (0.0618 - 0.0634)	0.76 + 0.80 (0.0299 + 0.0315)
1.61 - 1.65 (0.0634 - 0.0650)	0.80 + 0.80 (0.0315 + 0.0315)
1.65 - 1.69 (0.0650 - 0.0665)	0.44 + 1.20 (0.0173 + 0.0472)

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Differential side bearing adjusting shim — RS5F50A

Thickness mm (in)	Part number
0.40 (0.0157)	38453-03E11
0.44 (0.0173)	38453-03E00
0.48 (0.0189)	38453-03E01
0.52 (0.0205)	38453-03E12
0.56 (0.0220)	38453-03E02
0.60 (0.0236)	38453-03E03
0.64 (0.0252)	38453-03E04
0.68 (0.0268)	38453-03E05
0.72 (0.0283)	38453-03E06
0.76 (0.0299)	38453-03E07
0.80 (0.0315)	38453-03E08
1.20 (0.0472)	38453-03E13

Differential side bearing adjusting shim — RS5F50V

Thickness mm (in)	Part number
0.36 (0.0142)	38753-56E00
0.40 (0.0157)	38753-56E01
0.44 (0.0173)	38753-56E02
0.48 (0.0189)	38753-56E03
0.52 (0.0205)	38753-56E04
0.56 (0.0220)	38753-56E05
0.60 (0.0236)	38753-56E06
0.64 (0.0252)	38753-56E07
0.68 (0.0268)	38753-56E08
0.72 (0.0283)	38753-56E09
0.76 (0.0299)	38753-56E10
0.80 (0.0315)	38753-56E11
0.84 (0.0331)	38753-56E12
0.88 (0.0346)	38753-56E13
0.92 (0.0362)	38753-56E14

Table for selecting differential side bearing adjusting shim(s) — RS5F50A

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.47 - 0.51 (0.0185 - 0.0201)	0.44 + 0.48 (0.0173 + 0.0189)
0.51 - 0.55 (0.0201 - 0.0217)	0.48 + 0.48 (0.0189 + 0.0189)
0.55 - 0.59 (0.0217 - 0.0232)	0.48 + 0.52 (0.0189 + 0.0205)
0.59 - 0.63 (0.0232 - 0.0248)	0.52 + 0.52 (0.0205 + 0.0205)
0.63 - 0.67 (0.0248 - 0.0264)	0.52 + 0.56 (0.0205 + 0.0220)
0.67 - 0.71 (0.0264 - 0.0280)	0.56 + 0.56 (0.0220 + 0.0220)
0.71 - 0.75 (0.0280 - 0.0295)	0.56 + 0.60 (0.0220 + 0.0236)
0.75 - 0.79 (0.0295 - 0.0311)	0.60 + 0.60 (0.0236 + 0.0236)
0.79 - 0.83 (0.0311 - 0.0327)	0.60 + 0.64 (0.0236 + 0.0252)
0.83 - 0.87 (0.0327 - 0.0343)	0.64 + 0.64 (0.0252 + 0.0252)
0.87 - 0.91 (0.0343 - 0.0358)	0.64 + 0.68 (0.0252 + 0.0268)
0.91 - 0.95 (0.0358 - 0.0374)	0.68 + 0.68 (0.0268 + 0.0268)
0.95 - 0.99 (0.0374 - 0.0390)	0.68 + 0.72 (0.0268 + 0.0283)
0.99 - 1.03 (0.0390 - 0.0406)	0.72 + 0.72 (0.0283 + 0.0283)
1.03 - 1.07 (0.0406 - 0.0421)	0.72 + 0.76 (0.0283 + 0.0299)
1.07 - 1.11 (0.0421 - 0.0437)	0.76 + 0.76 (0.0299 + 0.0299)
1.11 - 1.15 (0.0437 - 0.0453)	0.76 + 0.80 (0.0299 + 0.0315)
1.15 - 1.19 (0.0453 - 0.0469)	0.80 + 0.80 (0.0315 + 0.0315)
1.19 - 1.23 (0.0469 - 0.0484)	0.44 + 1.20 (0.0173 + 0.0472)
1.23 - 1.27 (0.0484 - 0.0500)	0.48 + 1.20 (0.0189 + 0.0472)
1.27 - 1.31 (0.0500 - 0.0516)	0.52 + 1.20 (0.0205 + 0.0472)

Table for selecting differential side bearing adjusting shim(s) — RS5F50V

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.47 - 0.51 (0.0185 - 0.0201)	0.44 + 0.48 (0.0173 + 0.0189)
0.51 - 0.55 (0.0201 - 0.0217)	0.48 + 0.48 (0.0189 + 0.0189)
0.55 - 0.59 (0.0217 - 0.0232)	0.48 + 0.52 (0.0189 + 0.0205)
0.59 - 0.63 (0.0232 - 0.0248)	0.52 + 0.52 (0.0205 + 0.0205)
0.63 - 0.67 (0.0248 - 0.0264)	0.52 + 0.56 (0.0205 + 0.0220)
0.67 - 0.71 (0.0264 - 0.0280)	0.56 + 0.56 (0.0220 + 0.0220)
0.71 - 0.75 (0.0280 - 0.0295)	0.56 + 0.60 (0.0220 + 0.0236)
0.75 - 0.79 (0.0295 - 0.0311)	0.60 + 0.60 (0.0236 + 0.0236)
0.79 - 0.83 (0.0311 - 0.0327)	0.60 + 0.64 (0.0236 + 0.0252)
0.83 - 0.87 (0.0327 - 0.0343)	0.64 + 0.64 (0.0252 + 0.0252)
0.87 - 0.91 (0.0343 - 0.0358)	0.64 + 0.68 (0.0252 + 0.0268)
0.91 - 0.95 (0.0358 - 0.0374)	0.68 + 0.68 (0.0268 + 0.0268)
0.95 - 0.99 (0.0374 - 0.0390)	0.68 + 0.72 (0.0268 + 0.0283)
0.99 - 1.03 (0.0390 - 0.0406)	0.72 + 0.72 (0.0283 + 0.0283)
1.03 - 1.07 (0.0406 - 0.0421)	0.72 + 0.76 (0.0283 + 0.0299)
1.07 - 1.11 (0.0421 - 0.0437)	0.76 + 0.76 (0.0299 + 0.0299)
1.11 - 1.15 (0.0437 - 0.0453)	0.76 + 0.80 (0.0299 + 0.0315)
1.15 - 1.19 (0.0453 - 0.0469)	0.80 + 0.80 (0.0315 + 0.0315)
1.19 - 1.23 (0.0469 - 0.0484)	0.72 + 0.92 (0.0283 + 0.0362)
1.23 - 1.27 (0.0484 - 0.0500)	0.76 + 0.92 (0.0299 + 0.0362)
1.27 - 1.31 (0.0500 - 0.0516)	0.80 + 0.92 (0.0315 + 0.0362)

AUTOMATIC TRANSAXLE

SECTION AT

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

PREPARATION	2	Self-Diagnostic Procedure (Without	
PRECAUTIONS	7	CONSULT).....	37
A/T CONTROL DIAGRAM	8	Judgement Of Self-Diagnosis Code	39
Hydraulic Control Circuits	8	Revolution Sensor Circuit Check	41
Electrical Control Chart	9	Vehicle Speed Sensor Circuit Check	42
Mechanical Operation	9	Throttle Position Sensor Circuit Check.....	43
Cross-Sectional View	10	Shift Solenoid Valve A Circuit Check	44
TROUBLE DIAGNOSES	11	Shift Solenoid Valve B Circuit Check	45
How to Perform Trouble Diagnoses for Quick		Overrun Clutch Solenoid Valve Circuit Check ...	46
and Accurate Repair	11	Torque Converter Clutch Solenoid Valve	
Fail-Safe Remarks	12	Circuit Check	47
Preliminary Check	13	Fluid Temperature Sensor Circuit And TCM	
A/T Fluid Check	13	(A/T Control Module) Power Source Circuit	
Fluid leakage check	13	Checks	48
Fluid condition check	13	Engine Speed Signal Circuit Check	50
Fluid level check	13	Line Pressure Solenoid Valve Circuit Check	51
Road Testing	13	Inhibitor Switch, Overdrive Switch And	
Description.....	13	Closed Throttle Position Switch Circuit	
1. Check before engine is started	14	Checks	52
2. Check at idle	15	Diagnostic Procedure 1	56
3. Cruise test	17	(SYMPTOM: OD OFF indicator lamp does	
With CONSULT.....	17	not come on for about 2 seconds when	
Without CONSULT.....	20	turning ignition switch to "ON".)	
Cruise test — Part 1	20	Diagnostic Procedure 2	57
Cruise test — Part 2	23	(SYMPTOM: Engine cannot be started with	
Cruise test — Part 3	25	selector lever in "P" or "N" position or	
Vehicle speed when shifting gears	26	engine can be started with selector lever in	
Vehicle speed when performing lock-up	26	"D", "2", "1" or "R" position.)	
Shift schedule (Comfort pattern)	27	Diagnostic Procedure 3	57
Shift schedule (Auto power pattern).....	27	(SYMPTOM: Vehicle moves when it is	
Diagnosis by CONSULT	28	pushed forward or backward with selector	
A/T Component Parts Application.....	29	lever in "P" position.)	
Data Analysis.....	30	Diagnostic Procedure 4	58
A/T Electrical Parts Location	31	(SYMPTOM: Vehicle moves forward or	
Circuit Diagram for Quick Pinpoint Check	32	backward when selecting "N" position.)	
Wiring Diagram	34	Diagnostic Procedure 5	59
Self-diagnosis	36	(SYMPTOM: There is large shock when	
Self-Diagnostic Procedure (With CONSULT).....	36	changing from "N" to "R" position.)	

CONTENTS (Cont'd.)

Diagnostic Procedure 6	60	Diagnostic Procedure 18	72
(SYMPTOM: Vehicle does not creep backward when selecting "R" range.)		(SYMPTOM: A/T does not shift from D ₃ to 2 ₂ when changing selector lever from "D" to "2" position.)	
Diagnostic Procedure 7	61	Diagnostic Procedure 19	72
(SYMPTOM: Vehicle does not creep forward when selecting "D", "2" or "1" position.)		(SYMPTOM: A/T does not shift from 2 ₂ to 1 ₁ when changing selector lever from "2" to "1" position.)	
Diagnostic Procedure 8	62	Diagnostic Procedure 20	73
(SYMPTOM: Vehicle cannot be started from D ₁ on Cruise test — Part 1.)		(SYMPTOM: Vehicle does not decelerate by engine brake when shifting from 2 ₂ (1 ₂) to 1 ₁ .)	
Diagnostic Procedure 9	63	Electrical Components Inspection	74
(SYMPTOM: A/T does not shift from D ₁ to D ₂ at the specified speed. A/T does not shift from D ₄ to D ₂ when depressing accelerator pedal fully at the specified speed.)		Inspection Of TCM (A/T Control Module).....	74
Diagnostic Procedure 10	65	TCM (A/T Control Module) Inspection Table	74
(SYMPTOM: A/T does not shift from D ₂ to D ₃ at the specified speed.)		Overdrive Switch	78
Diagnostic Procedure 11	66	Inhibitor Switch	78
(SYMPTOM: A/T does not shift from D ₃ to D ₄ at the specified speed.)		Revolution Sensor	79
Diagnostic Procedure 12	67	Solenoid Valves And Fluid Temperature Sensor	79
(SYMPTOM: A/T does not perform lock-up at the specified speed.)		Dropping Resistor	80
Diagnostic Procedure 13	68	Final Check	80
(SYMPTOM: A/T does not hold lock-up condition for more than 30 seconds.)		Stall Testing	80
Diagnostic Procedure 14	69	Stall test procedure	80
(SYMPTOM: Lock-up is not released when accelerator pedal is released.)		Judgement of stall test.....	82
Diagnostic Procedure 15	70	Pressure Testing	83
(SYMPTOM: Engine speed does not return to idle smoothly when A/T is shifted from D ₄ to D ₃ with accelerator pedal released. Vehicle does not decelerate by engine brake when changing overdrive switch to "OFF" position with accelerator pedal released. Vehicle does not decelerate by engine brake when changing selector lever from "D" to "2" position with accelerator pedal released.)		Line pressure test procedure.....	83
Diagnostic Procedure 16	71	Judgement of line pressure test.....	84
(SYMPTOM: Vehicle does not start from D ₁ on Cruise test — Part 2.)		Symptom Chart	85
Diagnostic Procedure 17	71	ON-VEHICLE SERVICE	88
(SYMPTOM: A/T does not shift from D ₄ to D ₃ when changing overdrive switch to "OFF" position.)		Control Valve Assembly and Accumulator.....	88
		Revolution Sensor Replacement.....	90
		Inhibitor Switch Adjustment	90
		Control Cable Adjustment.....	90
		Differential Side Oil Seal Replacement.....	90
		TROUBLE DIAGNOSES — A/T Shift Lock	
		System	92
		Shift Lock Electrical Parts Location.....	92
		Circuit Diagram for Quick Pinpoint Check	93
		Wiring Diagram	94
		Diagnostic Procedure.....	95
		Key Interlock Cable.....	99
		Shift Lock Control Module Inspection	100
		Shift Lock Control Module Inspection Table	100
		Component Check	101
		REMOVAL AND INSTALLATION	102
		MAJOR OVERHAUL	104
		DISASSEMBLY	107
		REPAIR FOR COMPONENT PARTS	123
		Manual Shaft	123

CONTENTS (Cont'd.)

Oil Pump.....	126	Total End Play	200	GI
Control Valve Assembly.....	130	Assembly	202	
Control Valve Upper Body.....	139	SERVICE DATA AND SPECIFICATIONS (SDS)	209	
Control Valve Lower Body.....	143	General Specifications	209	MA
Reverse Clutch.....	146	Specifications and Adjustments.....	209	
High Clutch.....	150	Vehicle Speed When Shifting Gears	209	EM
Forward Clutch and Overrun Clutch	155	Vehicle Speed When Performing Lock-Up.....	209	EM
Low & Reverse Brake.....	161	Stall Revolution.....	210	
Rear Internal Gear, Forward Clutch Hub and		Line Pressure.....	210	LC
Overrun Clutch Hub	164	Control Valves	210	LC
Output Shaft, Idler Gear, Reduction Gear and		Clutches And Brakes.....	211	EF &
Bearing Retainer	168	Final Drive.....	212	EC
Band Servo Piston Assembly	173	Planetary Carrier And Oil Pump	213	
Final Drive — RE4F04A	178	Input Shaft	213	FE
Final Drive — RE4F04V	182	Reduction Gear	213	FE
ASSEMBLY	188	Reverse Clutch End Play	214	
Adjustment.....	188	Accumulator	214	CL
Differential Side Bearing Preload.....	188	Band Servo	214	CL
Reduction Gear Bearing Preload.....	190	Removal And Installation	214	
Output Shaft End Play	192	Output Shaft.....	214	MT
Assembly	194	Bearing Retainer.....	215	
Adjustment.....	200	Total End Play	215	AT

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST







BF

HA







EL

PREPARATION






SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST33290001 (J34286) Puller	 <p style="text-align: right;">Removing differential side oil seals</p>
ST33400001 (J26082) Drift	 <p style="text-align: right;">Installing differential side oil seal (RH side) Installing oil seal on oil pump housing</p> <p>a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.</p>
ST2505S001 (J25695-A) Oil pressure gauge set ① ST25051001 (J25695-1) Oil pressure gauge ② ST25052000 (J25695-2) Hose ③ ST25053000 (J25695-3) Joint pipe ④ ST25054000 (J25695-4) Adapter ⑤ ST25055000 (J25695-5) Adapter	<p style="text-align: right;">Measuring line pressure.</p> 
KV381054S0 (-) Puller	 <ul style="list-style-type: none"> ● Removing differential side bearing outer race ● Removing idler gear bearing outer race
ST27180001 (-) Puller	 <p style="text-align: right;">Removing idler gear</p>
ST23540000 (-) Pin punch	 <p style="text-align: right;">Removing and installing parking rod plate and manual plate pins.</p>





PREPARATION

Tool number (Kent-Moore No.) Tool name	Description	
ST25710000 (-) Pin punch	 <p>Aligning groove of manual shaft and hole of transmission case.</p>	GI MA EM
KV32101000 (J25689-A) Pin punch	 <p>Installing manual shaft retaining pin</p>	LC EF & EC
KV31102400 (J34285 and J34285-87) Clutch spring compressor	 <ul style="list-style-type: none"> ● Removing and installing clutch return springs ● Installing low and reverse brake piston 	FE CL MT
KV40100630 (-) Drift	 <ul style="list-style-type: none"> ● Installing reduction gear bearing inner race ● Installing idler gear bearing inner race <p>a: 67.5 mm (2.657 in) dia. b: 44 mm (1.73 in) dia. c: 38.5 mm (1.516 in) dia.</p>	<div style="background-color: black; color: white; padding: 2px; text-align: center; font-weight: bold;">AT</div> FA RA BR
ST30720000 (J34331) Drift	 <ul style="list-style-type: none"> ● Installing idler gear bearing outer race <p>a: 55.5 mm (2.185 in) dia. b: 77 mm (3.03 in) dia.</p>	ST BF HA EL
ST35321000 (-) Drift	 <ul style="list-style-type: none"> ● Installing output shaft bearing <p>a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.</p>	

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description
(J34291) Shim setting gauge set	 <ul style="list-style-type: none"> ● Selecting oil pump cover bearing race and oil pump thrust washer ● Selecting side gear thrust washer
KV38100300 (-)	 <p> a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32 mm (1.26 in) dia. </p>
ST30613000 (-)	 <p> a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia. </p>
ST3306S001 (-) Differential side bearing puller set ① ST33051001 (-) Puller ② ST33061000 (J8107-2) Adapter	 <p> a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia. </p>
ST3127S000 (See J25765-A) Preload gauge ① GG91030000 (J25765-A) Torque wrench ② HT62940000 (-) Socket adapter ③ HT62900000 (-) Socket adapter	 <p>Checking differential side bearing preload</p>






PREPARATION

Tool number (Kent-Moore No.) Tool name	Description		
ST33220000 (—) Drift	 <p> a: 37 mm (1.46 in) dia. b: 31 mm (1.22 in) dia. c: 22 mm (0.87 in) dia. </p>	Selecting differential side bearing adjusting shim (F04V)	GI MA EM LC
KV38105210 (—) Preload adapter		<ul style="list-style-type: none"> • Selecting differential side bearing adjusting shim (F04V) • Checking differential side bearing preload (F04V) 	EF & EC FE
ST35271000 (—) Drift	 <p> a: 72 mm (2.83 in) dia. b: 63 mm (2.48 in) dia. </p>	Installing idler gear	CL MT <div style="background-color: black; color: white; padding: 2px; display: inline-block;">AT</div>
(J39713) Preload adapter		<ul style="list-style-type: none"> • Selecting differential side bearing adjusting shim (F04A) • Checking differential side bearing preload (F04A) 	FA RA BR

ST
 BF
 HA
 EL

PREPARATION

COMMERCIAL SERVICE TOOLS

Tool name	Description
Puller	 <ul style="list-style-type: none">● Removing idler gear bearing inner race● Removing and installing band servo piston snap ring
Puller	 <p>Removing reduction gear bearing inner race</p>
Drift	 <p>Installing differential side oil seal (Left side)</p> <p>a: 90 mm (3.54 in) dia.</p>
Drift	 <p>Installing needle bearing on bearing retainer</p> <p>a: 36 mm (1.42 in) dia.</p>
Drift	 <p>Removing needle bearing from bearing retainer</p> <p>a: 33.5 mm (1.319 in) dia.</p>

PRECAUTIONS

Service Notice

- Before proceeding with disassembly, thoroughly clean the outside of the transaxle. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transaxle.
- When disassembling parts, place them in order in a parts rack so that they can be put back into the unit in their proper positions.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transaxle is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- Valve bodies contain precision parts and requires extreme care when parts are removed and serviced. Place removed parts in order on a parts rack so they can be put back in the valve body in the same positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along their bores in the valve bodies under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Petroleum jelly may be applied to O-rings and seals and used to hold small bearings and washers in place during reassembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- After overhaul, refill the transaxle with new ATF.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



- When connecting TCM (A/T control module) harness connector, tighten securing bolt until red projection is in line with connector face.



Precautions for Supplemental Restraint System "AIR BAG"


The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".


AT CONTROL DIAGRAM

Hydraulic Control Circuits



A/T CONTROL DIAGRAM

Electrical Control Chart



AAT003

Mechanical Operation

Shift position	Reverse clutch	High clutch	Forward clutch	Overrun clutch	Band servo			Forward one-way clutch	Low one-way clutch	Low & reverse brake	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK
R	○									○		REVERSE
N												NEUTRAL
D*4	1st		○	*1◎				●	●			Automatic shift 1 ↔ 2 ↔ 3 ↔ 4
	2nd		○	*1◎	○			●				
	3rd		○	*1◎	*2(X)	(X)		●		○		
	4th		○	(X)	*3(X)	(X)	○			○		
2	1st		○	○				●	●			Automatic shift 1 ↔ 2 ↔ 3
	2nd		○	○	○			●				
1	1st		○	○				●		○		Locks (held stationary) in 1st speed
	2nd		○	○	○			●				1 ← 2 ← 3

*1: Operates when overdrive switch is in "OFF" position.

*2: Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

*3: Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

*4: A/T will not shift to 4th when overdrive switch is in "OFF" position.

○: Operates


◎: Operates when throttle position is less than 3/16.

●: Operates during "progressive" acceleration.

(X): Operates but does not affect power transmission.

A/T CONTROL DIAGRAM

Cross-Sectional View




AAT173

- | | | |
|------------------------|--------------------------|--------------------------|
| ① Band servo piston | ⑨ Low one-way clutch | ⑬ Low & reverse brake |
| ② Reverse clutch drum | ⑩ Rear planetary gear | ⑭ Output gear |
| ③ Converter housing | ⑪ Forward clutch | ⑮ Idler gear |
| ④ Oil pump | ⑫ Overrun clutch | ⑯ Forward one-way clutch |
| ⑤ Brake band | ⑬ Low & reverse brake | ⑰ Pinion reduction gear |
| ⑥ Reverse clutch | ⑭ Output gear | ⑱ Differential case |
| ⑦ High clutch | ⑮ Idler gear | ⑳ Input shaft |
| ⑧ Front planetary gear | ⑯ Forward one-way clutch | ㉑ Torque converter |
| | ⑰ Pinion reduction gear | ㉒ Viscous coupling |

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES

Fail-Safe Remarks

The TCM (A/T control module) has an electronic Fail-Safe (limp home mode) to allow the vehicle to be driven even in the event of damage to a major electrical input or output device circuit.

In this condition, the vehicle runs in third gear in positions 1, 2 or D and will not upshift. Customer may say "Sluggish, poor acceleration."

When Fail-Safe operation occurs, the next time the key is turned to the "ON" position the OD OFF lamp will blink for about 8 seconds. For diagnosis, refer to AT-13.

Remarks

If the vehicle is driven under extreme conditions such as excessive wheel spinning and emergency braking suddenly after, Fail-Safe may be activated even if all electrical circuits are undamaged.

In this case, normal shift pattern can be returned by turning the ignition key OFF for 3 seconds and then back ON.

The blinking of the OD OFF lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions by chance.




Always follow the "WORK FLOW" (see the previous page).

The SELF DIAGNOSIS results will be as follows:

The first SELF DIAGNOSIS will indicate the damage of the vehicle speed sensor or the revolution sensor.

During the next SELF DIAGNOSIS performed after checking the sensors, no damages will be indicated.

TROUBLE DIAGNOSES



Preliminary Check

A/T FLUID CHECK

Fluid leakage check

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in “D” position and wait a few minutes.
3. Stop engine.
4. Check for fresh leakage.


Fluid condition check

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling — Overheating

Fluid level check

Refer to MA section (“Checking A/T Fluid Level”, “CHASSIS AND BODY MAINTENANCE”).

ROAD TEST PROCEDURE



SAT786A

ROAD TESTING

Description

- The purpose of this road test is to determine overall performance of automatic transmission and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Check at idle
 3. Cruise test

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL




TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items. Troubleshoot items which check out No Good after road test. Refer to AT-36 and AT-56.

1. Check before engine is started



1

Park vehicle on flat surface.



2

Move selector lever to "P" position.



3

Does OD OFF indicator lamp come on for about 2 seconds?

No

Perform Diagnostic Procedure 1. Refer to AT-56.

Yes

4

Does OD OFF indicator lamp flicker for about 8 seconds?

Yes

Perform self-diagnosis. See SELF-DIAGNOSIS PROCEDURE. Refer to AT-36 with CONSULT. Refer to AT-37 without CONSULT.

No








Perform self-diagnosis.
— Refer to SELF-DIAGNOSIS PROCEDURE and note N.G. items. Refer to AT-36 with CONSULT. Refer to AT-37 without CONSULT.


Perform "ROAD TESTING — 2. Check at idle". Refer to AT-15.

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



2. Check at idle



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST







BF

HA


EL

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



6 Move selector lever to "N" position.



Does vehicle move forward or backward? Yes → Perform Diagnostic Procedure 4. Refer to AT-58.

No
7 Apply foot brake.

8 Move selector lever to "R" position.

Is there large shock when changing from "N" to "R" position? Yes → Perform Diagnostic Procedure 5. Refer to AT-59.

No
9 Release service brake for several seconds.

Does vehicle creep backward when foot brake is released? No → Perform Diagnostic Procedure 6. Refer to AT-60.

Yes
10 Move selector lever to "D", "1" and "2" positions and check if vehicle creeps forward.

Does vehicle creep forward in all three positions? Yes → Perform Cruise test. Refer to AT-17.

No
Perform Diagnostic Procedure 7. Refer to AT-61.

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

3. Cruise test

- Check all items listed in Parts 1 through 3.



With CONSULT

- Using CONSULT, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per "Shift Schedule."

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF



HA

EL




CONSULT setting procedure

1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located in left dash side panel.)




3. Turn on ignition switch.
4. Touch "START".




5. Touch "A/T".

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)




6. Touch "DATA MONITOR".



7. Touch "SETTING" to set recording condition.




8. Touch "LONG TIME" and "ENTER" key.



9. Go back to SELECT MONITOR ITEM and touch "MAIN SIGNALS".

10. Touch "START".




11. When performing cruise test, touch "RECORD".


TROUBLE DIAGNOSES

Preliminary Check (Cont'd)


12. After finishing cruise test part 1, touch "STOP".




13. Touch "DISPLAY".



14. Touch "PRINT".




15. Touch "PRINT" again.



16. Check the monitor data printed out.

17. Continue cruise test part 2 and 3.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)



Without CONSULT

- Throttle position can be controlled by voltage across terminals ③④ and ③⑤ of TCM (A/T control module).


Cruise test — Part 1



1

Warm up engine until engine oil and ATF reach operating temperature after vehicle has been driven approx. 10 minutes.

ATF operating temperature:
50 - 80°C (122 - 176°F)




2

Set overdrive switch to "ON" position.

3

Move selector lever to "P" position.




4

Move selector lever to "D" position.

Ⓐ

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



5

Accelerate vehicle keeping accelerator pedal depressed halfway.

Does vehicle start from D₁?
Read gear position.


No → Perform Diagnostic Procedure 8. Refer to AT-62.

Yes

6

Does A/T shift from D₁ to D₂ at the specified speed?
Read gear position, throttle position and vehicle speed.
 Specified speed when shifting from D₁ to D₂:
 Refer to Shift schedule on AT-27.

No → Perform Diagnostic Procedure 9. Refer to AT-63.




Yes

7

Does A/T shift from D₂ to D₃ at the specified speed?
Read gear position, throttle position and vehicle speed.
 Specified speed when shifting from D₂ to D₃:
 Refer to Shift schedule on AT-27.

No → Perform Diagnostic Procedure 10. Refer to AT-65.



Yes

8

Does A/T shift from D₃ to D₄ at the specified speed?
Read gear position, throttle position and vehicle speed.
 Specified speed when shifting from D₃ to D₄:
 Refer to Shift schedule on AT-27.

No → Perform Diagnostic Procedure 11. Refer to AT-66.

Yes

9

Does A/T perform lock-up at the specified speed?
Read vehicle speed, throttle position when lock-up duty becomes 94%.
 Specified speed when lock-up occurs:
 Refer to Shift schedule on AT-27.

No → Perform Diagnostic Procedure 12. Refer to AT-67.

Yes → (B)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST




BF

HA

EL

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)



TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

Cruise test — Part 2



Confirm overdrive switch is in "ON" position.

Confirm selector lever is in "D" position.




1 Accelerate vehicle by half throttle again.

Does vehicle start from D₁?
Read gear position.

No
Perform Diagnostic Procedure 16. Refer to AT-71.


2 Accelerate vehicle to A km/h as shown in illustration.



3 Release accelerator pedal and then quickly depress it fully.


4 Does A/T shift from D₄ to D₂ as soon as accelerator pedal is depressed fully?
Read gear position and throttle position

No
Perform Diagnostic Procedure 9. Refer to AT-63.



5 Does A/T shift from D₂ to D₃ at the specified speed?
Read gear position, throttle position and vehicle speed.
Specified speed when shifting from D₂ to D₃:
Refer to Shift schedule on AT-27.

No
Perform Diagnostic Procedure 10. Refer to AT-65.



6 Release accelerator pedal after shifting from D₂ to D₃.

A

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES





Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

Cruise test — Part 3



Confirm overdrive switch is in "ON" position.

Confirm selector lever is in "D" position.

1 Accelerate vehicle using half-throttle to D₄.

2 Release accelerator pedal.

3 Set overdrive switch to "OFF" position while driving in D₄.

4 Does A/T shift from D₄ to D₃?
 Read gear position and vehicle speed.

No Perform Diagnostic Procedure 17. Refer to AT-71.

5 Does vehicle decelerate by engine brake?

No Perform Diagnostic Procedure 15. Refer to AT-70.

6 Move selector lever from "D" to "2" position while driving in D₃.

7 Does A/T shift from D₃ to 2₂?
 Read gear position.

No Perform Diagnostic Procedure 18. Refer to AT-72.

8 Does vehicle decelerate by engine brake?



No Perform Diagnostic Procedure 15. Refer to AT-70.

A

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



Vehicle speed when shifting gears

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
	Auto power	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
Half throttle	Comfort	42 - 50 (26 - 31)	78 - 86 (48 - 53)	124 - 132 (77 - 82)	74 - 82 (46 - 51)	40 - 48 (25 - 30)	5 - 13 (3 - 8)	62 - 70 (39 - 43)
	Auto power	45 - 53 (28 - 33)	84 - 92 (52 - 57)	132 - 140 (82 - 87)	86 - 94 (53 - 58)	52 - 60 (32 - 37)	5 - 13 (3 - 8)	62 - 70 (39 - 43)


Vehicle speed when performing lock-up

Throttle position	Shift pattern	OD switch (shift range)	Vehicle speed km/h (MPH)	
			Lock-up "ON"	Lock-up "OFF"
2/8	Comfort	ON [D ₄]	105 - 113 (65 - 70)	53 - 61 (33 - 38)
		OFF [D ₃]	86 - 94 (53 - 58)	83 - 91 (52 - 57)
	Auto power	ON [D ₄]	108 - 116 (67 - 72)	53 - 61 (33 - 38)
		OFF [D ₃]	88 - 94 (55 - 58)	83 - 91 (52 - 57)

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

Shift schedule (Comfort pattern)



AAT185

Shift schedule (Auto power pattern)



AAT186

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Diagnosis by CONSULT

NOTICE

1. The CONSULT displays shift timing and lock-up timing (that is, operation timing of each solenoid). When a noticeable time difference occurs between shift timing (indicated by shift shock) and the CONSULT display, then mechanical parts (except solenoid valves, sensors, etc.) are considered to be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
2. Shift schedule (which implies gear position) displayed on CONSULT and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
 - Actual shift schedule has more or less tolerance or allowance than design specification.
 - Shift schedule indicated in Service Manual refers to the point where shifts starts, and gear position displayed on CONSULT indicates the point where shifts are completed.
3. Shift solenoid valve "A" or "B" is displayed on CONSULT at the start of shifting, while gear position is displayed upon completion of shifting [which is computed by TCM (A/T control module)].
4. Additional CONSULT information can be found in Operation Manual supplied with CONSULT unit.

TROUBLE DIAGNOSES

Diagnosis by CONSULT (Cont'd)

A/T COMPONENT PARTS APPLICATION

DIAGNOSTIC ITEM		MODE		
		SELF-DIAGNOSTIC RESULTS	DATA MONITOR	
INPUT	Vehicle speed sensor 1 (A/T)	X	X	GI
	Vehicle speed sensor 2 (meter)	X	X	MA
	Throttle position sensor	X	X	EM
	Fluid temperature sensor	X	X	LC
	Battery positive voltage	X	X	LC
	Engine speed (rpm)	X	X	EF & EC
	Selector lever switch (overdrive switch)	—	X	EF & EC
	ASCD — cruise signal	—	X	FE
	ASCD — OD cut signal	—	X	FE
	Kickdown switch	—	—	CL
	Power shift switch	—	—	CL
	Closed throttle position switch	—	X	MT
	Wide open throttle position switch	—	X	MT
	Shift solenoid valve A (feedback)	—	X	AT
	Shift solenoid valve B (feedback)	—	X	AT
	Overrun clutch solenoid valve (feedback)	—	X	AT
	Hold mode switch	—	—	FA
	"1" position switch	—	X	FA
	"2" position switch	—	X	RA
	"D" position switch	—	X	RA
Park/Neutral position switch	—	X	BR	
"R" position switch	—	X	BR	
DATA	Gear position	—	X	ST
	Range position	—	X	ST
	Vehicle speed	—	X	BF
	Throttle position	—	X	BF
OUTPUT	Shift solenoid valve A	X	X	HA
	Shift solenoid valve B	X	X	HA
	Overrun clutch solenoid valve	X	X	EL
	Line-pressure solenoid valve	X	X	EL
	Torque converter clutch solenoid valve	X	X	EL

X: Applicable —: Not applicable
 DATA = internal TCM calculation

TROUBLE DIAGNOSES


Diagnosis by CONSULT (Cont'd) DATA ANALYSIS

Item	Display	Condition
Torque converter clutch solenoid valve valve duty	Approximately 4%	Lock-up "OFF"
	↓ Approximately 94%	↓ Lock-up "ON"
Line pressure solenoid valve duty	Approximately 29%	Low line-pressure (Small throttle opening)
	↓ Approximately 94%	↓ High line-pressure (Large throttle opening)
Throttle position sensor	Approximately 0.5V	Fully-closed throttle
	Approximately 4V	Fully-open throttle
Fluid temperature sensor	Approximately 1.5V	Cold [20°C (68°F)]
	↓ Approximately 0.5V	↓ Hot [80°C (176°F)]

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

TROUBLE DIAGNOSES


A/T Electrical Parts Location



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Circuit Diagram for Quick Pinpoint Check



TROUBLE DIAGNOSES

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


TROUBLE DIAGNOSES

Wiring Diagram




TROUBLE DIAGNOSES

Wiring Diagram (Cont'd)



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL


TROUBLE DIAGNOSES



Self-diagnosis

SELF-DIAGNOSTIC PROCEDURE (CONSULT) With CONSULT




1. Turn on CONSULT.
2. Touch "A/T".
3. Touch "SELF-DIAG RESULTS".
CONSULT performs self-diagnosis.



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)





SELF-DIAGNOSTIC PROCEDURE (⌚ Without CONSULT)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)




TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

JUDGEMENT OF SELF-DIAGNOSIS CODE


Flickers of OD OFF indicator lamp: Damaged circuit

All judgement flickers are same.




All circuits that can be confirmed by self-diagnosis are O.K. AAT131

4th judgement flicker is longer than others.




Shift solenoid valve A circuit is short-circuited or disconnected. Go to **SHIFT SOLENOID VALVE A CIRCUIT CHECK (AT-44)**. SAT443F

1st judgement flicker is longer than others.




Revolution sensor circuit is short-circuited or disconnected. Go to **REVOLUTION SENSOR CIRCUIT CHECK (AT-41)**. SAT437F

5th judgement flicker is longer than others.




Shift solenoid valve B circuit is short-circuited or disconnected. Go to **SHIFT SOLENOID VALVE B CIRCUIT CHECK (AT-45)**. SAT445F

2nd judgement flicker is longer than others.




Vehicle speed sensor circuit is short-circuited or disconnected. Go to **VEHICLE SPEED SENSOR CIRCUIT CHECK (AT-42)**. SAT439F

6th judgement flicker is longer than others.




Overrun clutch solenoid valve circuit is short-circuited or disconnected. Go to **OVERRUN CLUTCH SOLENOID VALVE CIRCUIT CHECK (AT-46)**. SAT447F

3rd judgement flicker is longer than others.



Throttle position sensor circuit is short-circuited or disconnected. Go to **THROTTLE POSITION SENSOR CIRCUIT CHECK (AT-43)**. SAT441F

7th judgement flicker is longer than others.



Torque converter clutch solenoid valve circuit is short-circuited or disconnected. Go to **TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT CHECK (AT-47)**. SAT449F

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


Flickers of OD OFF indicator lamp: Damaged circuit

8th judgement flicker is longer than others.




SAT451F
Fluid temperature sensor is disconnected or TCM (A/T control module) power source circuit is damaged.
Go to **FLUID TEMPERATURE SENSOR AND TCM (A/T CONTROL MODULE) POWER SOURCE CIRCUIT CHECKS (AT-48)**.

Does not come on.




SAT458F
Inhibitor switch, overdrive switch or throttle position switch circuit is disconnected or TCM (A/T control module) is damaged.
Go to **INHIBITOR SWITCH, OVERDRIVE SWITCH AND THROTTLE POSITION SWITCH CIRCUIT CHECKS (AT-52)**.

9th judgement flicker is longer than others.




SAT453F
Engine speed signal circuit is short-circuited or disconnected.
Go to **ENGINE SPEED SIGNAL CIRCUIT CHECK (AT-50)**.

10th judgement flicker is longer than others.



SAT455F
Line pressure solenoid valve circuit is short-circuited or disconnected.
Go to **LINE PRESSURE SOLENOID VALVE CIRCUIT CHECK (AT-51)**.

Flickers as shown below.




SAT457F
Battery power is low.
Battery has been disconnected for a long time.
Battery is conversely connected.
(When reconnecting TCM (A/T control module) connectors. — This is not a problem.)

$t_4 = 1.0$ second

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

REVOLUTION SENSOR CIRCUIT CHECK



A

☆ MONITOR	☆ NO FAIL	▼
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	

RECORD

SAT916F

CHECK REVOLUTION SENSOR. — Refer to AT-79.

N.G. → Repair or replace revolution sensor.

O.K. →

A

CHECK INPUT SIGNAL.

1.

2.

- Select "ECU INPUT SIGNALS".
- Read out the value of "REVOLUTION SENSOR" while driving.
- Check the value changes according to driving speed.

OR

Check voltage between TCM (A/T control module) terminal (25) and ground while driving. (Measure with A.C. range.)

Voltage:

At 0 km/h (0 MPH):
0V


At 30 km/h (19 MPH):
1V or more

(Voltage rises gradually in response to vehicle speed.)

N.G. → Check the following items.

- Harness continuity between TCM (A/T control module) and revolution sensor (Main harness)
- Harness continuity between revolution sensor and ECM (ECCS control module) (Main harness)
- Ground circuit for ECM — Refer to EF & EC section ("Diagnostic Procedure 22", "TROUBLE DIAGNOSES").

O.K. →



Perform self-diagnosis again after driving for a while.

N.G. →

O.K. →

INSPECTION END

N.G. →

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

VEHICLE SPEED SENSOR CIRCUIT CHECK

A




☆ MONITOR	☆ NO FAIL	
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	


RECORD

SAT917F

A


CHECK INPUT SIGNAL.

1. 

2. 

- Select "ECU INPUT SIGNALS".
- Read out the value of "VEHICLE SPEED SENSOR" while driving.
- Check the value changes according to driving speed.

OR


 Check voltage between TCM (A/T control module) terminal (27) and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.

Voltage:
Varies from 0V to 5V



N.G. → Check the following items.

- Speed sensor and ground circuit for speed sensor — Refer to EL section ("Speed Sensor Signal Check", "METER AND GAUGES").
- Harness continuity between TCM and speed sensor (Main harness)

A



At 2 - 3 km/h (1 - 2 MPH)

AAT009

O.K. → Perform self-diagnosis again after driving for a while.


N.G. → 1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM pin terminals for damage or connection of TCM harness connector.

O.K. → **INSPECTION END**

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

THROTTLE POSITION SENSOR CIRCUIT CHECK





A

Depress slowly.

☆ MONITOR	☆ NO FAIL	
VHCL/S SE-A/T		0km/h
VHCL/S SE-MTR		5km/h
THRTL POS SEN		0.4V
FLUID TEMP SE		1.2V
BATTERY VOLT		13.4V
ENGINE SPEED		1024rpm
SLCT LEVER SW		ON
R POSITION SW		OFF
P/N POSI SW		ON

RECORD

SAT951F






GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

SHIFT SOLENOID VALVE A CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. 
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑥ and ground.

Resistance: 20 - 30Ω


N.G.

1. Remove control valve assembly. — Refer to AT-88.
2. Check the following items.
 - Shift solenoid A — Refer to AT-79.
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

1. 
2. Disconnect TCM (A/T control module) harness connector.
3. Check resistance between terminal ⑥ and TCM terminal ⑥.

Resistance:

Approximately 0Ω

4. Reinstall any part removed.

N.G.

1. Repair or replace harness between TCM (A/T control module) and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

SHIFT SOLENOID VALVE B CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑦ and ground.

Resistance: 20 - 30Ω

N.G.

1. Remove control valve assembly. — Refer to AT-88.
2. Check the following items.
 - Shift solenoid valve B — Refer to AT-79.
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Disconnect TCM (A/T control module) harness connector.
3. Check resistance between terminal ⑦ and TCM terminal ⑦.

Resistance: Approximately 0Ω

4. Reinstall any part removed.

N.G.

1. Repair or replace harness between TCM (A/T control module) and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

OVERRUN CLUTCH SOLENOID VALVE CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑧ and ground.

Resistance: 20 - 30Ω

N.G.

1. Remove control valve assembly. — Refer to AT-88.
2. Check the following items.
 - Overrun clutch solenoid valve. — Refer to AT-79.
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Disconnect TCM (A/T control module) harness connector.
3. Check resistance between terminal ⑧ and TCM terminal ⑧.

Resistance: Approximately 0Ω

N.G.

1. Repair or replace harness between TCM (A/T control module) and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. Disconnect terminal cord assembly connector in engine compartment.
2. Check resistance between terminal ⑤ and ground.

Resistance: 2.5 - 5Ω

N.G.

1. Remove oil pan. — Refer to AT-88.
2. Check the following items.
 - Torque converter clutch solenoid valve — Refer to AT-79.
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

1. Disconnect TCM (A/T control module) harness connector.
2. Check resistance between terminal ⑤ and TCM terminal ⑤.

Resistance: Approximately 0Ω

4. Reinstall any part removed.

N.G.

- Repair or replace harness between TCM (A/T control module) and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

FLUID TEMPERATURE SENSOR CIRCUIT AND TCM (A/T CONTROL MODULE) POWER SOURCE CIRCUIT CHECKS



A

CHECK TCM (A/T CONTROL MODULE) POWER SOURCE.

1.



2. Check voltage between TCM (A/T control module) terminals ④, ⑨ and ground.

Battery positive voltage should exist.

N.G.

Check the following items.


- Harness continuity between ignition switch and TCM (A/T control module) (Main harness)
- Ignition switch and fuse — Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

O.K.

B

CHECK FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY.

1.



2. Disconnect terminal cord assembly connector in engine compartment.

3. Check resistance between terminals ③③ and ③⑤ when A/T is cold.

Resistance:

Cold [20°C (68°F)]

Approximately 2.5 kΩ

4. Reinstall any part removed.

N.G.

1. Remove oil pan.
2. Check the following items.

- Fluid temperature sensor — Refer to AT-80.
- Harness continuity of terminal cord assembly


O.K.

Ⓐ

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

C





☆ MONITOR	☆ NO FAIL	▼
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	


RECORD

SAT952F

C

AAT084A




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

ENGINE SPEED SIGNAL CIRCUIT CHECK



Perform diagnostic test mode II (self-diagnostic results) for engine control. Check ignition signal circuit.

N.G.

Check ignition signal circuit for engine control. — Refer to EF & EC section (“Diagnostic Procedure for Trouble Code 21”, “TROUBLE DIAGNOSES”).

O.K.

A

Depress slowly.

☆MONITOR	☆NO FAIL	
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	

RECORD

SAT951F

A CHECK INPUT SIGNAL.

- - Select “ECU INPUT SIGNALS”.
 - Read out the value of “ENGINE SPEED”.
 - Check engine speed changes according to throttle opening.
- OR
- Check voltage between TCM (A/T control module) terminal ②4 and ground.
 - Voltage: 0.9 - 4.5V**

N.G.

Check the following items.

- Harness continuity between TCM (A/T control module) and ignition coil.
- Resistor
- Ignition coil — Refer to EF & EC section (“Electrical Components Inspection”, “TROUBLE DIAGNOSES”).

O.K.


Perform self-diagnosis again after driving for a while.

N.G.

- Perform TCM (A/T control module) input/output signal inspection.
- If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.




INSPECTION END



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

LINE PRESSURE SOLENOID VALVE CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ① and ground.

Resistance: 2.5 - 5Ω

N.G.

1. Remove control valve assembly. — Refer to AT-88.
2. Check the following items.
 - Line pressure solenoid valve — Refer to AT-79.
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Disconnect TCM (A/T control module) harness connector.
3. Check resistance between terminal ① and TCM terminal ②.

Resistance: 11.2 - 12.8Ω

N.G.

- Check the following items.
- Dropping resistor — Refer to AT-80.
 - Harness continuity between TCM (A/T control module) ② and terminal cord assembly (Main harness)

O.K.

C

CHECK POWER SOURCE CIRCUIT.

- 1.
 2. Check resistance between terminal ① and TCM (A/T control module) terminal ①
- Resistance: Approximately 0Ω**
3. Reinstall any part removed.

N.G.

- Repair or replace harness between TCM (A/T control module) ① and terminal cord assembly.

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

INHIBITOR SWITCH, OVERDRIVE SWITCH AND CLOSED THROTTLE POSITION SWITCH CHECKS




A

☆ MONITOR ☆ NO FAIL

VHCL/S SE•A/T	0km/h
VHCL/S SE•MTR	5km/h
THRTL POS SEN	0.4V
FLUID TEMP SE	1.2V
BATTERY VOLT	13.4V
ENGINE SPEED	1024rpm
SLCT LEVER SW	ON
R POSITION SW	OFF
P/N POSI SW	ON

RECORD

SAT953F



A

CHECK INHIBITOR SWITCH CIRCUIT.

1.



2.



- Select "ECU INPUT SIGNALS".
- Read out "R", "N", "D", "1" and "2" POSITION SWITCH moving selector lever to each position.
- Check the selector lever position is indicated properly.

OR



Check voltage between TCM (A/T control module) terminals 16, 17, 18, 19, 20 and ground while moving selector lever through each position.

Voltage:

B: Battery positive voltage
0: 0V

Lever position	Terminal No.				
	19	20	18	17	16
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

O.K.

A

N.G.


Check the following items.

- Inhibitor switch — Refer to AT-78.
- Harness continuity between ignition switch and inhibitor switch (Main harness)
- Harness continuity between inhibitor switch and TCM (A/T control module) (Main harness)

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

B



OVER DRIVE
ON OFF


ON
OFF

☆ MONITOR	☆ NO FAIL	<input type="checkbox"/>
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
SLCT LEVER SW	ON	
R POSITION SW	OFF	
P/N POSI SW	ON	

RECORD

SAT954F

B



OVER DRIVE
ON OFF

ON
OFF

CONNECT H.S. TCM CONNECTOR

39 B/R


V


AAT088

A


B

CHECK OVERDRIVE SWITCH CIRCUIT.

1. 

2.  • Select "ECU INPUT SIGNALS".
• Read out "SELECTOR LEVER SWITCH (Overdrive switch)".
• Check the position is indicated properly. (Selector lever switch "ON" displayed on CONSULT means overdrive "OFF".)

OR

 • Check voltage between TCM (A/T control module) terminal 39 and ground when overdrive switch is in "ON" position and in "OFF" position.

Switch position	Voltage
ON	Battery positive voltage
OFF	1V or less

N.G.

Check the following items.

- Overdrive switch — Refer to AT-78.
- Harness continuity between TCM (A/T control module) and overdrive switch (Main harness)
- Harness continuity of ground circuit for overdrive switch (Main harness)

O.K.

B

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

C D





☆ MONITOR	☆ NO FAIL	
D POSITION SW	OFF	
1 POSITION SW	OFF	
2 POSITION SW	OFF	
ASCD•CRUISE	OFF	
ASCD•OD OUT	OFF	
KICKDOWN SW	OFF	
POWERSHIFT SW	OFF	
CLOSED THL/SW	ON	
W/O THRL/P-SW	OFF	

RECORD

SAT955F

C D







AAT089


B

C

CHECK WIDE OPEN THROTTLE POSITION SWITCH CIRCUIT.

- 

- 
 - Select "ECU INPUT SIGNALS".
 - Read out "WIDE OPEN THROTTLE POSITION SWITCH" depressing accelerator pedal fully.
 - Check wide open throttle position switch position is indicated properly.

OR

- 
 - Check voltage between TCM (A/T control module) terminal ②1 and ground while depressing accelerator pedal slowly. (after warming up engine)

Voltage:

When releasing accelerator pedal:
1V or less

When depressing accelerator pedal fully:
8 - 15V

N.G. → Check harness continuity between TCM (A/T control module) and wide open throttle position switch.

O.K. →

N.G. → **D**

D

Check wide open throttle position switch — Refer to EF & EC section ("Electrical Components Inspection", "TROUBLE DIAGNOSES").


D

Repair harness or connector between TCM and wide open throttle position switch.

O.K. → **C**

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)







GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Diagnostic Procedure 1

SYMPTOM:

OD OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".



1

CHECK TCM (A/T CONTROL MODULE) POWER SOURCE.

-
- Check voltage between TCM (A/T control module) terminals (4), (9) and ground.
Battery positive voltage should exist.

N.G.

Check the following items.

- Harness continuity between ignition switch and TCM (A/T control module) (Main harness)
- Ignition switch and fuse — Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

O.K.

2

CHECK TCM (A/T CONTROL MODULE) GROUND CIRCUIT.

-
- Disconnect TCM (A/T control module) harness connector.
- Check resistance between TCM terminals (15), (48) and ground.
Resistance: Approximately 0Ω

N.G.

Check harness continuity between TCM (A/T control module) and ground.

O.K.

3

CHECK LAMP CIRCUIT.

-
- Check resistance between TCM (A/T control module) terminals (3) and (4).
Resistance: 50 - 100Ω
- Reinstall any part removed.

N.G.

Check the following items.

- OD OFF indicator lamp — Refer to EL section ("Combination Meter", "METER AND GAUGES").
- Harness continuity between ignition switch and OD OFF indicator lamp (Main harness)
- Harness continuity between OD OFF indicator lamp and TCM (A/T control module).

O.K.

Check again.



N.G.

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.

INSPECTION END



TROUBLE DIAGNOSES



Diagnostic Procedure 2

SYMPTOM:


Engine cannot be started with selector lever in "P" or "N" position or engine can be started with selector lever in "D", "2", "1" or "R" position.



Diagnostic Procedure 3





SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in "P" position.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES



Diagnostic Procedure 4

SYMPTOM:






Vehicle moves forward or backward when selecting "N" position.



Diagnostic Procedure 5

SYMPTOM:

There is large shock when changing from "N" to "R" position.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR





ST

BF

HA

EL


TROUBLE DIAGNOSES







Diagnostic Procedure 6

SYMPTOM:

Vehicle does not creep backward when selecting "R" range.




TROUBLE DIAGNOSES



Diagnostic Procedure 7





SYMPTOM:

Vehicle does not creep forward when selecting "D", "2" or "1" position.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES







Diagnostic Procedure 8

SYMPTOM:

Vehicle cannot be started from D₁ on Cruise test — Part 1.






Diagnostic Procedure 9

SYMPTOM:

A/T does not shift from D₁ to D₂ at the specified speed.
A/T does not shift from D₄ to D₂ when depressing accelerator pedal fully at the specified speed.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA





EL

TROUBLE DIAGNOSES

Diagnostic Procedure 9 (Cont'd)




TROUBLE DIAGNOSES



Diagnostic Procedure 10

SYMPTOM:

A/T does not shift from D₂ to D₃ at the specified speed.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL





TROUBLE DIAGNOSES

Diagnostic Procedure 11

SYMPTOM:

A/T does not shift from D₃ to D₄ at the specified speed.

- A/T must be warm before D₃ to D₄ shift will occur.



Are Diagnostic Procedures 7 and 8 O.K.?

No → Perform Diagnostic Procedure 7 or 8. Refer to AT-61 or AT-62.

Yes

1
Does self-diagnosis show damage to inhibitor switch, overdrive switch, shift solenoid valve A, B, vehicle speed pulse generator, speed sensor or fluid temperature sensor circuit after cruise test?

Yes → Check damaged circuit. — Refer to AT-42, AT-44, AT-45, AT-48.

No

2
Check throttle position sensor. — Refer to EF & EC section ("Diagnostic Procedure for Trouble Code 43", "TROUBLE DIAGNOSES").

N.G. → Repair or replace throttle position sensor.

O.K.

3
1. Remove oil pan.
2. Check A/T fluid condition.

N.G. →

1. Remove control valve assembly. — Refer to AT-88.
2. Check the following items.
 - Shift valve B
 - Overrun clutch control valve
 - Shift solenoid valve B
 - Pilot valve
 - Pilot filter

O.K.

O.K.

O.K.

3. Disassemble A/T.
4. Check the following items.
 - Servo piston assembly
 - Brake band
 - Torque converter
 - Oil pump assembly

4
Check again.




N.G. →

1. Perform TCM (A/T control module) input/output signal inspection.
2. If N.G., recheck TCM (A/T control module) pin terminals for damage or connection of TCM harness connector.

O.K.

INSPECTION END


TROUBLE DIAGNOSES



Diagnostic Procedure 12

SYMPTOM:

A/T does not perform lock-up at the specified speed.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

TROUBLE DIAGNOSES



Diagnostic Procedure 13

SYMPTOM:

A/T does not hold lock-up condition for more than 30 seconds.




TROUBLE DIAGNOSES



Diagnostic Procedure 14

SYMPTOM:

Lock-up is not released when accelerator pedal is released.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES






Diagnostic Procedure 15

SYMPTOM:


Engine speed does not return to idle smoothly when A/T is shifted from D₄ to D₃ with accelerator pedal released.

Vehicle does not decelerate by engine brake when changing overdrive switch to "OFF" position with accelerator pedal released.

Vehicle does not decelerate by engine brake when changing selector lever from "D" to "2" position with accelerator pedal released.




TROUBLE DIAGNOSES



Diagnostic Procedure 16

SYMPTOM:

Vehicle does not start from D₁ on Cruise test — Part 2.



GI

MA


EM

LC

EF & EC

FE


CL



Diagnostic Procedure 17

SYMPTOM:

A/T does not shift from D₄ to D₃ when changing overdrive switch to "OFF" position.



MT

AT

FA

RA

BR


ST

BF

HA

EL



TROUBLE DIAGNOSES



Diagnostic Procedure 18

SYMPTOM:



A/T does not shift from D₃ to 2₂ when changing selector lever from "D" to "2" position.



Diagnostic Procedure 19

SYMPTOM:

A/T does not shift from 2₂ to 1₁ when changing selector lever from "2" to "1" position.




TROUBLE DIAGNOSES

Diagnostic Procedure 20

SYMPTOM:

Vehicle does not decelerate by engine brake when shifting from 2₂ (1₂) to 1₁.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


TROUBLE DIAGNOSES



Electrical Components Inspection

INSPECTION OF TCM (A/T CONTROL MODULE)

- Measure voltage between each terminal and terminal ⑮ or ④⑧ by following "TCM (A/T CONTROL MODULE) INSPECTION TABLE".
- Pin connector terminal layout.



SAT678E




TCM (A/T CONTROL MODULE) INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	Line pressure solenoid valve	When releasing accelerator pedal after warming up engine.	1.5 - 2.5V
		When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	Line pressure solenoid valve (with dropping resistor)	When releasing accelerator pedal after warming up engine.	5 - 14V
		When depressing accelerator pedal fully after warming up engine.	0.5V or less
3	OD OFF indicator lamp	When setting overdrive switch in "OFF" position.	1V or less
		When setting overdrive switch in "ON" position.	Battery positive voltage
4	Power source	When turning ignition switch to "ON".	Battery positive voltage
		When turning ignition switch to "OFF".	1V or less

TROUBLE DIAGNOSES










Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
5	Torque converter clutch solenoid valve	When A/T performs lock-up.	8 - 15V	GI
		When A/T does not perform lock-up.	1V or less	
6	Shift solenoid valve A	When shift solenoid valve A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery positive voltage	MA
		When shift solenoid valve A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less	EM
7	Shift solenoid valve B 	When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery positive voltage	LC
		When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less	EF & EC
8	Overrun clutch solenoid valve	When overrun clutch solenoid valve operates.	Battery positive voltage	FE
		When overrun clutch solenoid valve does not operate.	1V or less	CL
9	Power source	Same as No. 4		
10*	—	—	—	MT
11*	—	—	—	
12*	—	—	—	
13*	—	—	—	AT
14	Closed throttle position switch	When releasing accelerator pedal after warming up engine.	8 - 15V	FA
		When depressing accelerator pedal after warming up engine.	1V or less	RA
15	Ground 	—	—	
16	"1" position switch 	When setting selector lever to "1" position.	Battery positive voltage	BR
		When setting selector lever to other positions.	1V or less	ST
17	"2" position switch	When setting selector lever to "2" position.	Battery positive voltage	BF
		When setting selector lever to other position.	1V or less	
18	"D" position switch	When setting selector lever to "D" position.	Battery positive voltage	HA
		When setting selector lever to other positions.	1V or less	EL

*: These terminals are connected to the ECM (ECCS control module).

TROUBLE DIAGNOSES








Electrical Components Inspection (Cont'd)

Terminal No.	Item		Condition	Judgement standard
19	Inhibitor switch (Park/Neutral position signal)		When setting selector lever to "N" and "P" position.	Battery positive voltage
			When setting selector lever to other position.	1V or less
20	"R" position switch		When setting selector lever to "R" position.	Battery positive voltage
			When setting selector lever to other positions.	1V or less
21	Wide open throttle position switch		When depressing accelerator pedal more than half-way after warming up engine.	8 - 15V
			When releasing accelerator pedal after warming up engine.	1V or less
22	—		—	—
23	Power source (Back-up)	 or 	When turning ignition switch to "OFF".	Battery positive voltage
			When turning ignition switch to "ON".	Battery positive voltage
24	Engine speed signal	 	When engine runs at idle speed.	0.9V
			When engine runs at 3,000 rpm.	Approximately 3.7V
25	Revolution sensor (Measure in AC range)		When vehicle cruises at 30 km/h (19 MPH).	1V or more Voltage rises gradually in response to vehicle speed.
			When vehicle parks.	0V
26	—		—	—
27	Vehicle speed sensor		When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Vary from 0 to 5V
28**	—		—	—
29**	—		—	—
30**	—		—	—
31	Throttle position sensor (Power source)	 	—	4.5 - 5.5V
			—	—
32	—		—	—

** : These terminals are connected to the data link connector for CONSULT.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition		Judgement standard	
33	Fluid temperature sensor		When ATF temperature is 20°C (68°F).	1.56V	GI
			When ATF temperature is 80°C (176°F).	0.45V	MA
34	Throttle position sensor	 	When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: 0.2 - 0.6V Fully-open throttle: 2.9 - 3.9V	EM
35	Throttle position sensor (Ground)		—	—	LC
36	—		—	—	EF & EC
37	ASCD cruise signal		When ASCD cruise is being performed. ("CRUISE" light comes on.)	Battery positive voltage	FE
			When ASCD cruise is not being performed. ("CRUISE" light does not come on.)	1V or less	CL
38	—		—	—	MT
39	Overdrive switch	 	When setting overdrive switch in "ON" position.	Battery positive voltage	AT
			When setting overdrive switch in "OFF" position.	1V or less	
40	ASCD OD cut signal		When "ACCEL" set switch on ASCD cruise is released.	5 - 8V	FA
			When "ACCEL" set switch on ASCD cruise is applied.	1V or less	RA
41	—		—	—	
42	—		—	—	BR
43	—		—	—	
44	—		—	—	
45	—		—	—	ST
46	—		—	—	
47	—		—	—	BF
48	Ground		—	—	HA


TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

OVERDRIVE SWITCH

- Check continuity between two terminals.

Overdrive switch	Continuity
ON	No
OFF	Yes




SAT679E

INHIBITOR SWITCH


1. Check continuity between terminals ① and ② and between terminals ③ and ④, ⑤, ⑥, ⑦, ⑧, ⑨ while moving selector lever through each position.

Lever position	Terminal No.								
	①	②	③	④	⑤	⑥	⑦	⑧	⑨
P	○—○		○—○						
R			○—○		○—○				
N	○—○		○—○			○—○			
D			○—○				○—○		
2			○—○					○—○	
1			○—○						○—○




SAT529F

2. If N.G., check again with control cable disconnected from manual shaft of A/T assembly. — Refer to step 1.
3. If O.K. on step 2, adjust control cable. — Refer to AT-90.



SAT530F

4. If N.G. on step 2, remove inhibitor switch from A/T and check continuity of inhibitor switch terminal. — Refer to step 1.
5. If O.K. on step 4, adjust inhibitor switch. — Refer to AT-90.
6. If N.G. on step 4, replace inhibitor switch.




SAT296F

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

REVOLUTION SENSOR

- For removal and installation, refer to AT-90.
- Check resistance between terminals ①, ② and ③.



SAT844B


Terminal No.		Resistance
①	②	500 - 650Ω
②	③	No continuity
①	③	No continuity

SOLENOID VALVES AND FLUID TEMPERATURE SENSOR

- For removal and installation, refer to AT-88.
- Check resistance between two terminals.

Solenoids

Solenoid	Terminal No.	Resistance (Approx.)
Shift solenoid valve A	⑥	25Ω
Shift solenoid valve B	⑦	
Overrun clutch solenoid valve	⑧	
Line pressure solenoid valve	①	3.2Ω
Torque converter clutch solenoid valve	⑤	13.4Ω



AAT188

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Fluid temperature sensor

Check resistance between terminals ③③ and ③⑤ while changing temperature as shown at left.




Temperature °C (°F)	Resistance (Approx.)
20 (68)	2.5 kΩ
80 (176)	0.3 kΩ

DROPPING RESISTOR

- Check resistance between two terminals.

Resistance: 11.2 - 12.8Ω



Final Check


STALL TESTING

Stall test procedure


- Check A/T and engine fluid levels. If necessary, add.
- Warm up engine until engine oil and ATF reach operating temperature after vehicle has been driven approx. 10 minutes.

ATF operating temperature:


50 - 80°C (122 - 176°F)



- Set parking brake and block wheels.
 - Install a tachometer where it can be seen by driver during test.
- It is good practice to put a mark on point of specified engine rpm on indicator.**





- Start engine, apply foot brake, and place selector lever in "D" position.



TROUBLE DIAGNOSES

Final Check (Cont'd)



6. Accelerate to wide-open throttle gradually while applying foot brake.
7. Quickly note the engine stall speed and immediately release throttle.

- **During test, never hold throttle wide-open for more than 5 seconds.**

Stall speed:

2,100 - 2,400 rpm

8. Shift selector lever to "N" position.
9. Cool off ATF

- **Run engine at idle for at least one minute.**

10. Perform stall tests in the same manner as in steps 5 through 9 with selector lever in "2", "1" and "R" positions, respectively.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES


Final Check (Cont'd)

Judgement of stall test

Selector lever position	Judgement		
	H	O	L
D	H	O	L
2	H	O	L
1	O	O	L
R	H	H	L

O : Stall speed is normal.
 H : Stall speed is higher than specified.
 L : Stall speed is lower than specified.

Damaged components



D	H	H	H	O
2	H	H	H	O
1	O	H	H	O
R	O	O	H	O
Selector lever position	Judgement			

Clutch and brakes except high clutch and brake band are O.K. (Condition of high clutch and brake band cannot be confirmed by stall test.)

TROUBLE DIAGNOSES

Final Check (Cont'd)

PRESSURE TESTING

- Location of line pressure test port
- **Always replace pressure plugs as they are self-sealing bolts.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA



BR

ST

BF

HA


EL




Line pressure test procedure

1. Check A/T and engine fluid levels. If necessary, add fluid.
2. Warm up engine until engine oil and ATF reach operating temperature after vehicle has been driven approx. 10 minutes.

**ATF operating temperature:
50 - 80°C (122 - 176°F)**




3. Install pressure gauge to corresponding line pressure port.



4. Set parking brake and block wheels.
- **Continue to depress brake pedal fully while line pressure test is being performed at stall speed.**

TROUBLE DIAGNOSES

Final Check (Cont'd)



5. Start engine and measure line pressure at idle and stall speed.
 - When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure:

Engine speed rpm	Line pressure (Approx.) kPa (kg/cm ² , psi)	
	"D", "2" and "1" positions	"R" position
Idle	755 (7.7, 109)	1,177 (12.0, 171)
Stall	1,226 (12.5, 178)	1,961 (20.0, 284)

Judgement of line pressure test

Judgement		Suspected parts
At idle	Line pressure is low in all positions.	<ul style="list-style-type: none"> ● Oil pump wear ● Control piston damage ● Pressure regulator valve or plug sticking ● Spring for pressure regulator valve damaged ● Fluid pressure leakage between oil strainer and pressure regulator valve
	Line pressure is low in particular position.	<ul style="list-style-type: none"> ● Fluid pressure leakage between manual valve and particular clutch ● For example; If line pressure is low in "R" and "1" positions but is normal in "D" and "2" positions, fluid leakage exists at or around low & reverse brake circuit.
	Line pressure is high.	<ul style="list-style-type: none"> ● Mal-adjustment of throttle position sensor ● Fluid temperature sensor damaged ● Line pressure solenoid valve sticking ● Short circuit of line pressure solenoid valve circuit ● Pressure modifier valve sticking ● Pressure regulator valve or plug sticking
At stall speed	Line pressure is low.	<ul style="list-style-type: none"> ● Mal-adjustment of throttle position sensor ● Line pressure solenoid valve sticking ● Short circuit of line pressure solenoid valve circuit ● Pressure regulator valve or plug sticking ● Pressure modifier valve sticking ● Pilot valve sticking

TROUBLE DIAGNOSES

Symptom Chart

Reference page (AT-)	ON vehicle										OFF vehicle					
	13, 90	78	79	83	130, 79	79	79	79, 88	88	107, 126,	146, 150	155, 164	155, 107	161, 173	107	
Reference page (AT-)	Fluid level Control linkage	Inhibitor switch Throttle position sensor (Adjustment)	Revolution sensor and vehicle speed sensor Engine speed signal	Engine idling rpm Line pressure	Control valve assembly Shift solenoid valve A	Shift solenoid valve B Line pressure solenoid valve	Torque converter clutch solenoid valve Overrun clutch solenoid valve	Fluid temperature sensor Accumulator N-D	Accumulator 3-R Ignition switch and starter	Torque converter Oil pump	Reverse clutch High clutch	Forward clutch Forward one-way clutch	Overrun clutch Low one-way clutch	Low & reverse brake solenoid Brake band	Parking components	
57 Engine does not start in "N", "P" positions.	. 2	3 1	
57 Engine starts in range other than "N" and "P".	. 1	2	
— Transaxle noise in "P" and "N" positions.	1	. 3	4 5	. 2	⑦ ⑥	
57 Vehicle moves when changing into "P" position or parking gear does not disengage when shifted out of "P" position.	. 1	②	
58 Vehicle runs in "N" position.	. 1	③	②	④	
60 Vehicle will not run in "R" position (but runs in "D", "2" and "1" positions). Clutch slips. Very poor acceleration.	. 1 2	4 3	⑤ ⑥	⑦	⑧	⑨	. . .	
— Vehicle braked when shifting into "R" position.	1 2 3	5 4	⑥	⑧	⑨	. . .	⑦	
— Sharp shock in shifting from "N" to "D" position. 2	. 5	1 3	7 6 4 8	⑨	
— Vehicle will not run in "D" and "2" positions (but runs in "1" and "R" positions).	. 1	②	
61 Vehicle will not run in "D", "1", "2" positions (but runs in "R" position). Clutch slips. Very poor acceleration.	1 2	4 3	⑥ ⑦	⑧ ⑨	. ⑩	
— Clutches or brakes slip somewhat in starting.	1 2	. 3 4	6 5	⑫ ⑪	⑨	⑧	. . .	⑩	. . .	
— Excessive creep. 1	
60, 61 No creep at all.	1 2	3	⑥ ⑤	. . .	④	
— Failure to change gear from "D ₁ " to "D ₂ ".	. 2	1	. 5	. . .	4 3	⑥	
— Failure to change gear from "D ₂ " to "D ₃ ".	. 2	1	. 5	. . .	4	. 3	⑥	⑦	
— Failure to change gear from "D ₃ " to "D ₄ ".	. 2	1	. 4 3 5	⑥	
63, 65, 66 Too high gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from "D ₃ " to "D ₄ ". 1	2 3	4	
— Gear change directly from "D ₁ " to "D ₃ " occurs.	1	2	③	
— Engine stops when shifting lever into "R", "D", "2" and "1". 1	. 3 2	④	
— Too sharp a shock in change from "D ₁ " to "D ₂ ". 1 2	4 5	. 3	⑥	
— Too sharp a shock in change from "D ₂ " to "D ₃ ". 1 2	3	④	⑤	

GI
 MA
 EM
 LC
 FF & EC
 FE
 CL
 MT
AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)


Reference page (AT-)	← ON vehicle →								← OFF vehicle →																				
	13, 90	78	79	83	130, 79	79	79	79, 88	88	107, 126,	146, 150	155, 164	155, 107	161, 173	107														
Numbers are arranged in order of probability. Perform inspections starting with number one and working up. Circled numbers indicate that the transaxle must be removed from the vehicle.	Fluid level	Control linkage	Inhibitor switch	Throttle position sensor (Adjustment)	Revolution sensor and vehicle speed sensor	Engine speed signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid valve A	Shift solenoid valve B	Line pressure solenoid valve	Torque converter clutch solenoid valve	Overrun clutch solenoid valve	Fluid temperature sensor	Accumulator N-D	Accumulator 3-R	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components
— Too sharp a shock in change from "D ₃ " to "D ₄ ".	.	.	1	.	.	2	3	5	.	.	4	.	.
— Almost no shock or clutches slipping in change from "D ₁ " to "D ₃ ".	1	.	2	.	.	3	5	4	6	.
— Almost no shock or slipping in change from "D ₂ " to "D ₃ ".	1	.	2	.	.	3	4	6	.
— Almost no shock or slipping in change from "D ₃ " to "D ₄ ".	1	.	2	.	.	3	4	6	.
— Vehicle braked by gear change from "D ₁ " to "D ₂ ".	1	2	4	.	.	.	5	3	.	.
— Vehicle braked by gear change from "D ₂ " to "D ₃ ".	1	2	.
— Vehicle braked by gear change from "D ₃ " to "D ₄ ".	1	4	.	3	2
— Maximum speed not attained. Acceleration poor.	1	.	2	.	.	.	5	3	4	11	10	6	7	.	.	.	9	8	.	
— Failure to change gear from "D ₄ " to "D ₃ ".	1	.	2	.	.	.	6	4	5	3	8	7	.	.	
— Failure to change gear from "D ₃ " to "D ₂ " or from "D ₄ " to "D ₃ ".	1	.	2	.	.	.	5	3	4	6	7	.	.
— Failure to change gear from "D ₂ " to "D ₁ " or from "D ₃ " to "D ₁ ".	1	.	2	.	.	.	5	3	4	7	.	.	6	.	8	.	.
— Gear change shock felt during deceleration by releasing accelerator pedal.	.	.	1	.	.	2	4	3
— Too high a change point from "D ₄ " to "D ₃ ", from "D ₃ " to "D ₂ ", from "D ₂ " to "D ₁ ".	.	.	1	2
— Kickdown does not operate when depressing pedal in "D ₄ " within kickdown vehicle speed.	.	.	1	2	.	.	3	4
— Kickdown operates or engine overruns when depressing pedal in "D ₄ " beyond kickdown vehicle speed limit.	.	.	2	1	.	.	3	4
— Races extremely fast or slips in changing from "D ₄ " to "D ₃ " when depressing pedal.	1	.	2	.	.	3	5	.	4	6	7
— Races extremely fast or slips in changing from "D ₄ " to "D ₂ " when depressing pedal.	1	.	2	.	.	3	6	5	4	8	.	.	.	7	.	.
— Races extremely fast or slips in changing from "D ₃ " to "D ₂ " when depressing pedal.	1	.	2	.	.	3	5	.	4	.	.	.	8	9	7	.	.	.	6	.	.
— Races extremely fast or slips in changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.	1	.	2	.	.	3	5	.	4	6	7	8
— Vehicle will not run in any position.	1	2	.	.	.	3	.	.	4	9	5	6	8	7	10	.
— Transaxle noise in "D", "2", "1" and "R" positions.	1	2

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)


Reference page (AT-)	ON vehicle										OFF vehicle																				
	13, 90	78	79	83	130, 79	79	79	79, 88	88	107, 126,	146, 150	155, 164	155, 107	161, 173	107																
Reference page (AT-)	Fluid level	Control linkage	Inhibitor switch	Throttle position sensor (Adjustment)	Revolution sensor and vehicle speed sensor	Engine speed signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid valve A	Shift solenoid valve B	Line pressure solenoid valve	Torque converter clutch solenoid valve	Overrun clutch solenoid valve	Fluid temperature sensor	Accumulator N-D	Accumulator 3-R	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components		
72	Failure to change from "D ₃ " to "2" when changing lever into "2" position.	. 7	1 2	6 5	4 .	. .	3	9	. .	8	
-	Gear change from "2" to "3" in "2" position.	. .	1	
73	Engine brake does not operate in "1" position.	. 2	1 3	4	6 5	8	. .	9	
-	Gear change from "1 ₁ " to "1 ₂ " in "1" position.	. 2	1	
-	Does not change from "1 ₂ " to "1 ₁ " in "1" position.	. .	1 .	2	4 3	6	. .	7	
-	Large shock changing from "1 ₂ " to "1 ₁ " in "1" position.	1	2	
-	Transaxle overheats.	1 .	. 3	. .	2 4	6 .	. 5	14 7	8 9	11	. .	12	. .	13 10	
-	ATF shoots out during operation.	1	2 3	5	. .	6	. .	7 4	
-	White smoke emitted from exhaust pipe during operation.	1	
-	Offensive smell at fluid charging pipe.	1	2 3	4 5	7	. .	8	. .	9 6	
-	Torque converter is not locked up.	. .	3 1	2 4	. 6	8	7 .	5	9
-	Lock-up piston slip	1 .	. 2	. .	. 3	6 .	. 5	4	7
67	Lock-up point is extremely high or low.	. .	. 1	2 4	. .	. 3
-	A/T does not shift to "D ₄ " when driving with overdrive switch "ON".	. .	2 1	3 .	. 8	6 4	. .	. 5	7	10	. .	9
-	Engine is stopped at "R", "D", "2" and "1" positions.	1 5	4 3	. 2

GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL




Control Valve Assembly and Accumulator REMOVAL

1. Drain ATF from transaxle.
2. Remove oil pan and gasket.




3. Disconnect A/T solenoid harness connector.



4. Remove stopper ring from A/T solenoid harness terminal body.
5. Remove A/T solenoid harness from transmission case by pushing on terminal body.

ON-VEHICLE SERVICE

Control Valve Assembly and Accumulator (Cont'd)




GI
MA
EM
LC
EF &
EC
FE
CL
MT

6. Remove control valve assembly by removing fixing bolts ⊕, ⊗ and ●.

Bolt length, number and location are shown in the illustration.

- Be careful not to drop manual valve and 3-R accumulator return spring.
7. Disassemble and inspect control valve assembly if necessary — Refer to AT-130.

AT



8. Remove 3-R and N-D accumulators by applying compressed air if necessary.

- **Hold each piston with a rag.**

FA

RA


BR

ST

BF


HA

EL



INSTALLATION


- Set manual shaft in Neutral, then align manual plate with groove in manual valve.
- After installing control valve on to transmission case, make sure that selector lever can be moved to all positions.



Revolution Sensor Replacement


1. Remove under cover.
2. Remove revolution sensor from A/T.
3. Reinstall any part removed.

Always use new sealing parts.




Inhibitor Switch Adjustment

1. Remove control cable from manual shaft.
2. Set manual shaft in "N" position.
3. Loosen inhibitor switch fixing bolts.




4. Insert pin into adjustment holes in both inhibitor switch and manual shaft as near vertical as possible.
5. Reinstall any part removed.
6. Check continuity of inhibitor switch. — Refer to AT-78.



Control Cable Adjustment

Move selector lever from "P" to "1" position. You should be able to feel the detents in each position. If the detents cannot be felt or the pointer indicating the position is improperly aligned, the linkage needs adjustment.

1. Place selector lever in "P" position.
2. Loosen lock nuts.
3. Tighten lock nut, pulling selector lever toward "R" position side.
4. Move selector lever from "P" to "1" position again. Make sure selector lever moves smoothly.




Differential Side Oil Seal Replacement

1. Remove drive shaft assembly. — Refer to FA section ("Removal", "FRONT AXLE — Drive Shaft").
2. Remove oil seal.

ON-VEHICLE SERVICE

Differential Side Oil Seal Replacement (Cont'd)

3. Install oil seal.
Apply ATF before installing.
4. Reinstall any part removed.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA


EL

Shift Lock Electrical Parts Location



TROUBLE DIAGNOSES — AT Shift Lock System

Circuit Diagram for Quick Pinpoint Check



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL




MAT051A

TROUBLE DIAGNOSES — AT Shift Lock System

Wiring Diagram



TROUBLE DIAGNOSES — A/T Shift Lock System



Diagnostic Procedure

SYMPTOM 1:

With key in "ON" position, selector lever cannot be moved from "P" position when applying brake pedal or can be moved when releasing brake pedal.

Selector lever can be moved from "P" position when key is removed from key cylinder.

SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to "P" position or can be removed when selector lever is set to any position except "P".

Check key interlock cable for damage.
 N.G. → Repair key interlock cable. Refer to AT-99.
 O.K. ↓

1 **CHECK POWER SOURCE.**
 N.G. → Check the following items:
 1. Harness continuity between battery and control module terminal ②
 2. Fuse
 O.K. ↓

1.
 2. Check voltage between control module terminal ② and ground.
Battery positive voltage should exist.

2 **CHECK IGNITION SIGNAL.**
 N.G. → Check the following items:
 1. Harness continuity between battery and control module terminal ①
 2. Fuse
 3. Ignition switch
 O.K. ↓

1.
 2. Check voltage between control module terminal ① and ground.
0V
 3.
 4. Check voltage between control module terminal ① and ground.
Battery positive voltage should exist.

3 **CHECK GROUND CIRCUIT FOR CONTROL MODULE.**
 N.G. → Repair harness or connector.
 O.K. ↓




1.
 2. Disconnect control module harness connector.
 3. Check continuity between control module terminal ⑧ and ground.
Continuity should exist.

O.K. ↓
A

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES — A/T Shift Lock System

Diagnostic Procedure (Cont'd)



CHECK INPUT SIGNAL (DETENTION SWITCH).

1. Reconnect control module harness connector.



3. Set selector lever in "P" position and release selector lever button. **When selector lever cannot be moved from "P" position with brake pedal depressed, set ignition key to "ACC" position and move lever. Then set ignition key to "ON" position.**

4. Disconnect control module harness connector.
5. Check continuity between control module terminal ⑥ and ground. **Continuity should not exist.**

N.G. Check detention switch—shift. (Refer to AT-101.)

O.K.

CHECK INPUT SIGNAL (DETENTION SWITCH).

- 1.
2. Check continuity between control module terminal ⑥ and ground with brake pedal depressed and selector lever button pushed. **Continuity should exist.**
3. Check continuity between control module terminal ⑥ and ground with selector lever set in any position except "P". **Battery positive voltage should exist.**






N.G. Check the following items:
 1. Harness continuity between control module terminal ⑥ and detention switch terminal ⑤
 2. Harness continuity between detention switch terminal ⑥ and ground
 3. Detention switch (Refer to AT-101.)

O.K.

B

TROUBLE DIAGNOSES — AT Shift Lock System

Diagnostic Procedure (Cont'd)



8

CHECK INPUT SIGNAL (STOP LAMP SWITCH).

- Check voltage between control module terminal ⑤ and ground.

Brake pedal	Voltage
Depressed	Battery positive voltage
Released	0V

N.G.

Check the following items:

- Harness continuity between control module terminal ⑤ and stop lamp switch terminal ②
- Harness continuity between stop lamp switch terminal ① and fuse
- Stop lamp switch (Refer to AT-101.)

O.K.

9

Set selector lever in "P" position.

CHECK OUTPUT SIGNAL (SHIFT LOCK SOLENOID).

-
- Check voltage between shift lock harness connector terminal ⑧ and body ground.

Brake pedal	Voltage
Depressed	Battery positive voltage
Released	0V

-
- Check voltage between shift lock harness connector terminal ⑧ and ground with brake pedal depressed. 0V

N.G.

Check harness continuity between control module terminal ④ and shift lock harness connector terminal ⑧.

12

CHECK GROUND CIRCUIT FOR SHIFT LOCK SOLENOID.

- Disconnect shift lock harness connector.
- Check continuity between shift lock harness connector terminal ⑨ and ground. Continuity should exist.

N.G.

Repair harness or connector.


O.K.

C


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES – A/T Shift Lock System


Diagnostic Procedure (Cont'd)



Key Interlock Cable



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL




REMOVAL

1. Remove snap pin temporarily and remove key interlock cable from vehicle.
2. Unlock slider from adjuster holder and remove rod from cable.
3. Install rod to control device with snap pin.

INSTALLATION

1. Set key interlock cable to steering lock assembly and install lock plate.
2. Clamp cable to steering column and fix to control cable with band.
3. Set control lever to "P".
4. Insert rod into adjuster holder.
5. Install casing cap to bracket.
6. Move slider in order to fix adjuster holder to rod.

TROUBLE DIAGNOSES — A/T Shift Lock System






Shift Lock Control Module Inspection

- Measure voltage between each terminal and terminal ⑧ by following “Shift Lock Control Module Inspection Table”.
- Pin connector terminal layout.

Shift Lock Control Module Inspection Table

(Data are reference values.)

Terminal No.		Item	Condition	Judgment standard
⊕	⊖			
1	8	Ignition signal		Battery positive voltage
			Except above	0V
2		Power source	Any condition	Battery positive voltage
4		Shift lock signal		Battery positive voltage
			When selector lever is set in “P” position and brake pedal is depressed.	
		Except above	0V	
5	Stop lamp switch	When brake pedal is depressed.	Battery positive voltage	
		When brake pedal is released.	0V	
6	Detention switch	<ul style="list-style-type: none"> ● When key is inserted into key cylinder and selector lever is set in “P” position with selector lever button pushed. ● When selector lever is set in any position except “P”. 	Battery positive voltage	
		Except above	0V	



Component Check

SHIFT LOCK SOLENOID

- Check operation by applying battery positive voltage to shift lock harness connector.

GI

MA

EM


LC

EF &
EC

FE

CL

MT



DETENTION SWITCH


- Check continuity between terminals ⑤ and ⑥ of shift lock harness connector.

AT

Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	No
Except above	Yes

FA

RA



STOP LAMP SWITCH

- Check continuity between terminals ① and ② of stop lamp switch harness connector.

BR

ST

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No






BF

HA

Check stop lamp switch after adjusting brake pedal — refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").

EL

REMOVAL AND INSTALLATION



Removal

- Remove battery and bracket.
- Remove air cleaner and resonator.
- Disconnect A/T solenoid harness connector and inhibitor switch harness connectors.
- Disconnect harness connectors of revolution sensor and vehicle speed sensor.
- Remove LH mounting bracket from transaxle and body.
- Disconnect control cable at transaxle side.
- Drain ATF.
- Remove drive shafts — Refer to FA section (“Removal”, “FRONT AXLE — Drive Shaft”).
- Disconnect oil cooler piping.
- Remove starter motor from transaxle.
- Support engine by placing a jack under oil pan.

Do not place jack under oil pan drain plug.

- Remove center member.
- Remove rear plate cover and bolts securing torque converter to drive plate.

Rotate crankshaft for access to securing bolts.


- Support transaxle with a jack.
- Remove bolts fixing A/T to engine.
- Lower transaxle while supporting it with a jack.

Installation


- Drive plate runout
Maximum allowable runout:
Refer to EM section (“Inspection”, “CYLINDER BLOCK”).
If this runout is out of allowance, replace drive plate and ring gear.

REMOVAL AND INSTALLATION


Installation (Cont'd)



- When connecting torque converter to transaxle, measure distance "A" to be certain that they are correctly assembled.
Distance "A":
19 mm (0.75 in) or more




- Install bolts fixing converter to drive plate.
- After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transaxle rotates freely without binding.**



- Tighten bolt securing transaxle.

Bolt No.	Tightening torque N•m (kg-m, ft-lb)	ℓ mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	45 (1.77)
2	30 - 36 (3.1 - 3.7, 22 - 27)	30 (1.18)
3	30 - 36 (3.1 - 3.7, 22 - 27)	40 (1.57)
4	74 - 83 (7.5 - 8.5, 54 - 61)	45 (1.77)
5	30 - 36 (3.1 - 3.7, 22 - 27)	80 (3.15)
6	30 - 36 (3.1 - 3.7, 22 - 27)	65 (2.56)


- Reinstall any part removed.



- Check fluid level in transaxle.
- Move selector lever through all positions to be sure that transaxle operates correctly.
 With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R". A slight shock should be felt by hand gripping selector each time transaxle is shifted.
- Perform road test — Refer to AT-13.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

MAJOR OVERHAUL




: N·m (kg·m, ft·lb)

: Apply ATF


: Apply petroleum jelly.

: Select proper thickness.


DISASSEMBLY



1. Drain ATF through drain plug.




2. Remove torque converter.



3. Check torque converter one-way clutch using check tool as shown at left.

- Insert check tool into the groove of bearing support built into one-way clutch outer race.
- When fixing bearing support with check tool, rotate one-way clutch spline using screwdriver.
- Check that inner race rotates clockwise only. If not, replace torque converter assembly.



4. Remove oil charging pipe and oil cooler tube.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY



5. Set manual lever to park position.
6. Remove inhibitor switch.



7. Remove oil pan and oil pan gasket.
 - **Do not reuse oil pan bolts.**




8. Analyze foreign materials in oil pan to trace possible causes of malfunction. If the fluid is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up which can cause valves, servo, and clutches to stick and may inhibit pump pressure.

DISASSEMBLY


Unit: mm (in)

- ① 5 bolts $l = 40$ (1.57)
- ⊗ 6 bolts $l = 33$ (1.30)
- 2 bolts $l = 43.5$ (1.713)




SAT647E

9. Remove control valve assembly according to the following procedures.
 - a. Remove control valve assembly mounting bolts ①, ⊗ and ●.



- b. Remove stopper ring from terminal body.



- c. Push terminal body into transmission case and draw out solenoid harness.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY



10. Remove manual valve from control valve assembly.




11. Remove return spring from 3-R accumulator piston.




12. Remove 3-R accumulator piston with compressed air.

13. Remove O-rings from 3-R accumulator piston.



14. Remove N-D accumulator piston and return spring with compressed air.

15. Remove O-rings from N-D accumulator piston.




16. Check accumulator pistons and contact surface of transmission case for damage.

17. Check accumulator return springs for damage and free length.


Unit: mm (in)

Spring	Free length	Outer diameter
3-R accumulator spring	52.5 (2.067)	20.4 (0.803)
N-D accumulator spring	43.5 (1.713)	27.0 (1.063)


DISASSEMBLY



18. Remove lip seals.




19. Remove tube and sleeve.




20. Remove converter housing according to the following procedures.

a. Remove converter housing mounting bolts.



b. Remove converter housing by tapping it lightly.



c. Remove O-ring from differential oil port.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY




21. Remove final drive assembly from transmission case.




22. Remove differential side bearing outer race from transmission case.



23. Remove differential side bearing adjusting shim from transmission case.




24. Remove differential side bearing outer race from converter housing.




25. Remove oil seal with screwdriver from converter housing.
● Be careful not to damage case.


DISASSEMBLY




26. Remove oil tube from converter housing.




27. Remove oil pump according to the following procedures.
a. Remove O-ring from input shaft.



b. Remove oil pump assembly, baffle plate and gasket from transmission case.



c. Remove thrust washer and bearing race from oil pump assembly.



28. Remove brake band according to the following procedures.
a. Loosen lock nut, then back off band servo anchor end pin.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY




b. Remove brake band and strut from transmission case.



● To prevent brake linings from cracking or peeling, do not stretch the flexible band unnecessarily. When removing the brake band, always secure it with a clip as shown in the figure at left. Leave the clip in position after removing the brake band.




c. Check brake band facing for damage, cracks, wear or burns.




29. Remove input shaft assembly (high clutch), reverse clutch and front sun gear according to the following procedures.

a. Remove input shaft assembly (high clutch) with reverse clutch.




b. Remove input shaft assembly (high clutch) from reverse clutch.


DISASSEMBLY




- c. Remove needle bearings from high clutch drum and check for damage or wear.




- d. Remove high clutch hub and front sun gear from transmission case.



- e. Remove front sun gear and needle bearing from high clutch hub and check for damage or wear.
- f. Remove bearing race from front sun gear and check for damage or wear.



30. Remove needle bearing from transmission case and check for damage or wear.



31. Apply compressed air and check to see that low and reverse brake operates.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY




32. Remove low one-way clutch and front planetary carrier assembly according to the following procedures.
- Remove snap ring with flat-bladed screwdriver.



- Remove low one way clutch with a hook made of wire.




- Remove snap ring with flat-bladed screwdriver.




- Remove front planetary carrier with low and reverse brake piston and retainer.


DISASSEMBLY




- e. Remove low and reverse brake spring retainer.
- **Do not remove return springs from spring retainer.**



- f. Check that low one-way clutch rotates in the direction of the arrow and locks in the opposite direction.



- g. Remove needle bearing, low and reverse brake piston and retainer from front planetary carrier.



- h. Check front planetary carrier, low one-way clutch and needle bearing for damage or wear.
- i. Check clearance between planetary gears and planetary carrier with feeler gauge.


Standard clearance:

0.20 - 0.70 mm (0.0079 - 0.0276 in)

Allowable limit:

0.80 mm (0.0315 in)

Replace front planetary carrier if the clearance exceeds allowable limit.



- 33. Remove rear planetary carrier assembly and rear sun gear according to the following procedures.
- a. Remove rear planetary carrier assembly from transmission case.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL


DISASSEMBLY



b. Remove rear sun gear from rear planetary carrier.



c. Remove needle bearings from rear planetary carrier assembly.



d. Check rear planetary carrier, rear sun gear and needle bearings for damage or wear.
e. Check clearance between pinion washer and rear planetary carrier with feeler gauge.


Standard clearance:

0.20 - 0.70 mm (0.0079 - 0.0276 in)


Allowable limit:

0.80 mm (0.0315 in)

Replace rear planetary carrier if the clearance exceeds allowable limit.




34. Remove rear internal gear and forward clutch hub from transmission case.



35. Remove overrun clutch hub from transmission case.

DISASSEMBLY



36. Remove needle bearing from overrun clutch hub and check for damage or wear.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA


EL



37. Remove forward clutch assembly from transmission case.




38. Remove needle bearing from transmission case.



39. Remove output shaft assembly according to the following procedures.

a. Remove side cover bolts.


- Do not mix bolts (A) and (B).
- Always replace bolts (A) as they are self-sealing bolts.




b. Remove side cover by lightly tapping it with a soft hammer.

- Be careful not to drop output shaft assembly as output shaft assembly may be removed together with side cover.


DISASSEMBLY




c. Remove adjusting shim.




d. Remove output shaft assembly.



- If output shaft assembly was removed together with side cover, remove side cover by tapping it lightly with a soft hammer.




e. Remove needle bearing.



40. Disassemble reduction gear according to the following procedures.

- a. Set manual lever to position "P" to fix idler gear.
- b. Unlock idler gear lock nut using a pin punch.

DISASSEMBLY



- c. Remove idler gear lock nut.
- **Do not reuse idler gear lock nut.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA


EL




- d. Remove idler gear with puller.



- e. Remove reduction gear.
- f. Remove adjusting shim from reduction gear.




- 41. Remove return spring from parking shaft with screwdriver.
- 42. Draw out parking shaft and remove parking pawl from transmission case.
- 43. Check parking pawl and shaft for damage or wear.




- 44. Remove parking actuator support from transmission case.
- 45. Check parking actuator support for damage or wear.

DISASSEMBLY



46. Remove side oil seal with screwdriver from transmission case.


Manual Shaft




GI
MA
EM
LC
EF & EC
FE
CL
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

REMOVAL


1. Remove detent spring from transmission case.



2. Drive out manual plate retaining pin.




3. Drive and pull out parking rod plate retaining pin.
4. Remove parking rod plate from manual shaft.
5. Draw out parking rod from transmission case.




REPAIR FOR COMPONENT PARTS

Manual Shaft (Cont'd)




6. Pull out manual shaft retaining pin.
7. Remove manual shaft and manual plate from transmission case.



8. Remove manual shaft oil seal.


INSPECTION

- Check component parts for wear or damage. Replace if necessary.



INSTALLATION


1. Install manual shaft oil seal.
- Apply ATF to outer surface of oil seal.




2. Install manual shaft and manual plate.

REPAIR FOR COMPONENT PARTS

Manual Shaft (Cont'd)




3. Align groove of manual shaft and hole of transmission case.
4. Install manual shaft retaining pin up to bottom of hole.




5. Install parking rod to parking rod plate.
6. Set parking rod assembly onto manual shaft and drive retaining pin.

Both ends of pin should protrude.



7. Drive manual plate retaining pin.

Both ends of pin should protrude.



8. Install detent spring.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL


REPAIR FOR COMPONENT PARTS

Oil Pump




DISASSEMBLY

1. Remove seal rings by undoing hooks.




2. Loosen bolts in a crisscross pattern and remove oil pump cover.




3. Remove inner and outer gear from oil pump housing.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



4. Remove O-ring from oil pump housing.




5. Remove oil pump housing oil seal.

INSPECTION

Oil pump housing, oil pump cover, inner gear and outer gear

- Check for wear or damage.



Side clearance

- Measure side clearance between end of oil pump housing and inner and outer gears in at least four places along their circumferences. Maximum measured values should be within specified ranges.

Standard clearance:

0.030 - 0.050 mm (0.0012 - 0.0020 in)

- If clearance is less than standard, select inner and outer gear as a set so that clearance is within specifications.

Inner and outer gear:

Refer to AT-213.

- If clearance is more than standard, replace whole oil pump assembly except oil pump cover.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



- Measure clearance between outer gear and oil pump housing.


Standard clearance:

0.111 - 0.181 mm (0.0044 - 0.0071 in)

Allowable limit:

0.181 mm (0.0071 in)

- If not within allowable limit, replace whole oil pump assembly except oil pump cover.



Seal ring clearance

- Measure clearance between seal ring and ring groove.


Standard clearance:

0.036 - 0.176 mm (0.0014 - 0.0069 in)

Allowable limit:


0.176 mm (0.0069 in)

- If not within allowable limit, replace oil pump cover assembly.




ASSEMBLY

1. Install oil seal on oil pump housing.



2. Install O-ring on oil pump housing.

- **Apply ATF to O-ring.**




3. Install inner and outer gears on oil pump housing.


- **Be careful of direction of inner gear.**

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



4. Install oil pump cover on oil pump housing.
 - a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly on oil pump housing assembly, then remove masking tape.
 - b. Tighten bolts in a crisscross pattern.



5. Install new seal rings carefully after packing ring groove with petroleum jelly and attach hooks.
 - **Do not spread gap of seal ring excessively while installing. The ring may be deformed.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

REPAIR FOR COMPONENT PARTS

Control Valve Assembly



- | | | |
|----------------------------------|---------------------------------|---------------------------------|
| ① Oil strainer | ⑧ Check ball | ⑮ Pilot filter |
| ② O-ring | ⑨ Lower separating gasket | ⑯ Upper inter separating gasket |
| ③ Clamp | ⑩ Separating plate | ⑰ Separating plate |
| ④ Terminal body | ⑪ Lower inter separating gasket | ⑱ Upper separating gasket |
| ⑤ O-rings | ⑫ Support plate | ⑲ Steel ball |
| ⑥ Control valve lower body | ⑬ Steel ball | ⑳ Control valve upper body |
| ⑦ Oil cooler relief valve spring | ⑭ Control valve inter body | |

DISASSEMBLY

Disassemble upper, inter and lower bodies.


Bolt length, number and location:

Bolt symbol	a	b	c	d	e	f
Bolt length "ℓ" mm (in)	13.5 (0.531)	58.0 (2.283)	40.0 (1.575)	66.0 (2.598)	33.0 (1.299)	78.0 (3.071)
Number of bolts	6	3	6	11	2	2


f: Reamer bolt and nut.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL



a. Remove bolts (a), (a) and nut (f) and remove oil strainer from control valve assembly.

MT

AT



b. Remove solenoid valve assembly and line pressure solenoid valve from control valve assembly.

FA


RA

BR

ST

BF

HA




c. Remove O-rings from solenoid valves and terminal body.


EL

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)




- d. Place upper body facedown, and remove bolts (b), (c) and nut (f).




- e. Remove inter body from lower body.



- f. Turn over lower body, and remove accumulator support plate.




- g. Remove bolts (e), separating plate and separating gasket from lower body.
h. Remove steel balls and relief valve springs from lower body.
● **Be careful not to lose steel balls and relief valve springs.**



- i. Remove inter body from upper body.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)



j. Check to see that steel balls are properly positioned in inter body and then remove them from inter body.

- **Be careful not to lose steel balls.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL



k. Check to see that steel balls are properly positioned in upper body and then remove them from upper body.


- **Be careful not to lose steel balls.**



INSPECTION


Lower and upper bodies

• Check to see that retainer plates are properly positioned in lower body.



• Check to see that retainer plates are properly positioned in upper body.

- **Be careful not to lose these parts.**




Oil strainer

• Check wire netting of oil strainer for damage.


REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)



Shift solenoid valve A and B, line pressure solenoid valve, torque converter clutch solenoid valve and overrun clutch solenoid valve.

- Measure resistance — Refer to AT-79.




Oil cooler relief valve spring.

- Check springs for damage or deformation.
- Measure free length and outer diameter

Inspection standard:


Unit: mm (in)

Part No.	l	D
31872-31X00	17.02 (0.6701)	8.0 (0.315)




ASSEMBLY

1. Install upper, inter and lower body.
 - a. Place oil circuit of upper body face up. Install steel balls in their proper positions.




- b. Install upper separating gasket, upper inter separating gasket and upper separating plate in order shown in illustration.




- c. Install reamer bolts (f) from bottom of upper body and install separating gaskets and separating plate as a set on upper body using reamer bolts as guides.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



d. Install pilot filter.




e. Place lower body as shown in illustration (side of inter body face up). Install steel balls in their proper positions.




f. Install inter body on upper body using reamer bolts (f) as guides.

• **Be careful not to dislocate or drop steel balls.**



g. Install steel balls and relief valve springs in their proper positions in lower body.



h. Install lower separating gasket, inter separating gasket and lower separating plate in order shown in illustration.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST




BF

HA

EL

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)



- i. Install bolts (e) from bottom of lower body and install separating gaskets and separating plate as a set on lower body using bolts (e) as guides.
- j. Temporarily install support plates on lower body.

- k. Install lower body on inter body using reamer bolts (f) as guides and tighten reamer bolts (f) slightly.

2. Install O-rings to solenoid valves and terminal body.
 - Apply ATF to O-rings.



3. Install and tighten bolts.

Bolt length, number and location:


Bolt symbol	a	b	c	d	e	f
Bolt length "l" mm (in)	13.5 (0.531)	58.0 (2.283)	40.0 (1.575)	66.0 (2.598)	33.0 (1.299)	78.0 (3.071)
Number of bolts	6	3	6	11	2	2

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



a. Install and tighten bolts (b) to specified torque.



b. Install solenoid valve assembly and line pressure solenoid valve to lower body.




c. Set oil strainer, then tighten bolts (a), (c), (d) and nuts (f) to specified torque.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)

d. Tighten bolts ⑤ (2 pieces) to specified torque.



Control Valve Upper Body



- | | | |
|-------------------------|----------------------------------|-----------------------|
| ① Upper body | ⑬ Return spring | ②⑤ Plug |
| ② Retainer plate | ⑭ Torque converter relief valve | ②⑥ Retainer plate |
| ③ Sequence valve | ⑮ Retainer plate | ②⑦ Return spring |
| ④ Retainer plate | ⑯ Plug | ②⑧ 1st reducing valve |
| ⑤ Plug | ⑰ Overrun clutch reducing valve | ②⑨ Plug |
| ⑥ Return spring | ⑱ Return spring | ③① Retainer plate |
| ⑦ 1-2 accumulator valve | ⑲ Pilot valve | ③② Return spring |
| ⑧ Retainer plate | ⑳ Return spring | ③③ Retainer plate |
| ⑨ Plug | ㉑ Retainer plate | |
| ⑩ Return spring | ㉒ 1-2 accumulator retainer plate | |
| ⑪ Lock-up control valve | ㉓ Return spring | |
| ⑫ Retainer plate | ㉔ 1-2 accumulator piston | |

SAT538F

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)


DISASSEMBLY




1. Remove valves at retainer plates.
- Do not use a magnetic "hand".



- a. Use a screwdriver to pry out retainer plates.



- b. Remove retainer plates while holding spring, plugs or sleeves.
- Remove plugs slowly to prevent internal parts from jumping out.



- c. Place mating surface of valve body face down, and remove internal parts.
- If a valve is hard to remove, place valve body face down and lightly tap it with a soft hammer.
 - Be careful not to drop or damage valves and sleeves.


REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

INSPECTION

Valve spring

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.
- Numbers of each valve spring listed in table below are the same as those in the figure on page AT-139.



Inspection standard

Unit: mm (in)

Parts	Item		
	Part No.	l	D
⑳ Pilot valve spring	31742 80x14	36.0 (1.417)	8.1 (0.319)
⑥ 1-2 accumulator valve spring	31742 80x10	20.5 (0.807)	7.0 (0.276)
㉓ 1-2 accumulator piston spring	31742 80x12	52.0 (2.047)	19.6 (0.772)
㉗ 1st reducing valve spring	31742 80x05	27.0 (1.063)	7.0 (0.276)
㉓② 2-3 timing valve	31742 80x18	30.5 (1.201)	6.6 (0.260)
⑱ Overrun clutch reducing valve spring	31742 80x15	37.5 (1.476)	6.9 (0.272)
⑬ Torque converter relief valve spring	31742 80x07	31.0 (1.220)	9.0 (0.354)
⑩ Lock-up control valve	31742 80x17	39.5 (1.555)	11.0 (0.433)



- Replace valve springs if deformed or fatigued.

Control valves

- Check sliding surfaces of valves, sleeves and plugs.

ASSEMBLY


- Lay control valve body down when installing valves. Do not stand the control valve body upright.




1. Lubricate the control valve body and all valves with ATF. Install control valves by sliding them carefully into their bores.
- Be careful not to scratch or damage valve body.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)




- Wrap a small screwdriver with vinyl tape and use it to insert the valves into their proper positions.




1-2 accumulator valve

- Install 1-2 accumulator valve and then align 1-2 accumulator retainer plate with 1-2 accumulator valve from opposite side of control valve body.
- Install return spring, 1-2 accumulator piston and plug.



2. Install retainer plates
- Install retainer plate while pushing plug or return spring.



Retainer plate


Unit: mm (in)

Location of retainer plate	Length A	Length B
Pilot valve	6.0 (0.236)	21.5 (0.846)
1-2 accumulator valve		38.5 (1.516)
1-2 accumulator piston		21.5 (0.846)
1st reducing valve		24.0 (0.945)
2-3 timing valve		21.5 (0.846)
Overrun clutch reducing valve		21.5 (0.846)
Torque converter relief valve		28.0 (1.102)
Lock-up control valve		
Sequence valve		

- Install proper retainer plates.

REPAIR FOR COMPONENT PARTS

Control Valve Lower Body



- | | | |
|---------------------------|----------------------------|--------------------------------|
| ① Lower body | ⑭ Accumulator shift valve | ⑳ Overran clutch control valve |
| ② Retainer plate | ⑮ Plug | ㉑ Plug |
| ③ Return spring | ⑯ Retainer plate | ㉒ Retainer plate |
| ④ Piston | ⑰ Retainer plate | ⑳ Return spring |
| ⑤ Parallel pin | ⑱ Plug | ㉓ Accumulator control valve |
| ⑥ Sleeve | ⑲ Manual valve | ㉔ Plug |
| ⑦ Return spring | ⑳ Pressure regulator valve | ㉕ Retainer plate |
| ⑧ Pressure modifier valve | ㉑ Return spring | ㉖ Shift valve A |
| ⑨ Retainer plate | ㉒ Spring seat | ㉗ Return spring |
| ⑩ Plug | ㉓ Plug | ㉘ Retainer plate |
| ⑪ Shift valve B | ㉔ Sleeve | ㉙ Shuttle shift valve |
| ⑫ Return spring | ㉕ Retainer plate | ㉚ Plug |
| ⑬ Return spring | ㉖ Return spring | ㉛ Retainer plate |

SAT059F

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



REPAIR FOR COMPONENT PARTS

Control Valve Lower Body (Cont'd)

DISASSEMBLY

Remove valves at retainer plate.

For removal procedures, refer to AT-140.



INSPECTION

Valve springs

- Check each valve spring for damage or deformation. Also measure free length and outer diameter.
- Numbers for each valve spring listed in the table below are the same as those in the figure on page AT-143.

Inspection standard


Unit: mm (in)

Parts	Item		
	Part No.	l	D
⑬ Accumulator shift valve spring	31736 01X00	23.0 (0.906)	6.65 (0.2618)
⑳ Pressure regulator valve spring	31742 80X13	45.0 (1.772)	15.0 (0.591)
⑳ Overrun clutch control valve spring	31762 80X00	21.7 (0.854)	7.0 (0.276)
⑳ Accumulator control valve spring	31742 80X02	22.0 (0.866)	6.5 (0.256)
㉑ Shift valve A spring	31762 80X00	21.7 (0.854)	7.0 (0.276)
⑫ Shift valve B	31762 80X00	21.7 (0.854)	7.0 (0.276)
③ Pressure modifier valve spring	31742 41X15	30.5 (1.201)	9.8 (0.386)
	⑦ 31742 80X16	32.0 (1.260)	6.9 (0.272)

- Replace valve springs if deformed or fatigued.

Control valves

- Check sliding surfaces of control valves, sleeves and plugs for damage.




ASSEMBLY

- Install control valves.
For installation procedures, refer to AT-141.

REPAIR FOR COMPONENT PARTS

Control Valve Lower Body (Cont'd)

Retainer plate





Unit: mm (in)

Location of retainer plate	Length A	Length B	Type
Accumulator shift valve	6.0 (0.236)	19.5 (0.768)	I
Pressure regulator valve			
Pressure clutch control			
Accumulator control valve			
Shift valve A			
Shuttle shift valve		28.0 (1.102)	
Overrun clutch control valve			
Pressure modifier valve			
Shift valve B		—	

- Install proper retainer plates


GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Reverse Clutch




DISASSEMBLY

1. Check operation of reverse clutch
 - a. Install seal ring onto drum support of oil pump cover and install reverse clutch assembly. Apply compressed air to oil hole.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not move to snap ring, D-ring or oil seal may be damaged or fluid may be leaking at piston check ball.




2. Remove snap ring.
3. Remove drive plates, driven plates, retaining plate, and dish plates.



4. Set Tool on spring retainer and remove snap ring from reverse clutch drum while compressing return springs.
 - **Set Tool directly over springs.**
 - **Do not expand snap ring excessively.**
5. Remove spring retainer and return springs.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)




6. Remove piston from reverse clutch drum by turning it.
7. Remove D-ring and oil seal from piston.

INSPECTION

Reverse clutch snap ring, spring retainer and return springs

- Check for deformation, fatigue or damage. If necessary, replace.



Reverse clutch drive plates


- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Standard value: 2.0 mm (0.079 in)

Wear limit: 1.8 mm (0.071 in)

- If not within wear limit, replace.



Reverse clutch dish plates

- Check for deformation or damage.
 - Measure thickness of dish plate.
- Thickness of dish plate: 3.08 mm (0.1213 in)**
- If deformed or fatigued, replace.

Reverse clutch piston

- Make sure that check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring to make sure that there is no air leakage.
- Apply compressed air to oil hole on return spring side to make sure that air leaks past ball.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)


ASSEMBLY




1. Install D-ring and oil seal on piston.
 - Take care with the direction of oil seal.
 - Apply ATF to both parts.




2. Install piston assembly by turning it slowly.
 - Apply ATF to inner surface of drum.



3. Install return springs and spring retainer on piston.
4. Set Tool on spring retainer and install snap ring while compressing return springs.
 - Set Tool directly over return springs.



5. Install drive plates, driven plates, retaining plate and dish plates.
 - Take care with order of plates.
6. Install snap ring.



7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard 0.5 - 0.8 mm (0.020 - 0.031 in)


Allowable limit 1.2 mm (0.047 in)

Retaining plate: Refer to AT-211.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

8. Check operation of reverse clutch.
Refer to AT-146.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL


REPAIR FOR COMPONENT PARTS

High Clutch




DISASSEMBLY

1. Check operation of high clutch.
 - a. Apply compressed air to oil hole of input shaft with nylon cloth.
 - **Stop up hole on opposite side of input shaft with nylon cloth.**
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not move to snap ring, D-ring or oil seal may be damaged or fluid may be leaking at piston check ball.






2. Remove seal rings from input shaft.
 - **Always replace when removed.**



3. Remove snap ring.
4. Remove drive plates, driven plates and retaining plate.

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)



5. Set Tool on spring retainer and remove snap ring from high clutch drum while compressing return springs.
 - **Set Tool directly over springs.**
 - **Do not expand snap ring excessively.**
6. Remove spring retainer and return springs.
7. Remove piston from high clutch drum by turning it.
8. Remove D-rings from piston.


INSPECTION

High clutch snap ring, spring retainer and return springs.

- Check for deformation, fatigue or damage. If necessary, replace.
- **When replacing spring retainer and return springs, replace them as a set.**

High clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.
 - Thickness of drive plate:**
 - Standard value 1.6 mm (0.063 in)**
 - Wear limit 1.4 mm (0.055 in)**
- If not within wear limit, replace.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

REPAIR FOR COMPONENT PARTS


High Clutch (Cont'd)

High clutch piston




- Make sure that check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring to make sure that there is no air leakage.
- Apply compressed air to oil hole on return spring side to make sure that air leaks past ball.

Seal ring clearance




- Measure clearance between seal ring and ring groove.
Standard clearance: 0.08 - 0.23 mm (0.0031 - 0.0091 in)
Allowable limit: 0.23 mm (0.0091 in)
- If not within allowable limit, replace input shaft assembly.


ASSEMBLY



1. Install D-rings on piston.
- Take care with the direction of oil seal.
 - Apply ATF to both parts.








2. Install piston assembly by turning it slowly.
- Apply ATF to inner surface of drum.



3. Install return springs and spring retainer on piston.

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)



4. Set Tool on spring retainer and install snap ring while compressing return springs.

- Set Tool directly over return springs.

- Do not align snap ring gap with spring retainer stopper.

5. Install drive plates, driven plates and retaining plate.

- Take care with direction of retaining plate and order of plates.

6. Install snap ring.

7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard 1.8 - 2.2 mm (0.071 - 0.087 in)

Allowable limit 2.8 mm (0.110 in)

Retaining plate: Refer to AT-211.

8. Check operation of high clutch.
Refer to AT-150.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)






9. Install seal rings to input shaft.
- **Apply petroleum jelly to seal rings.**
 - **Always replace when removed.**



- **Roll paper around seal rings to prevent seal rings from spreading.**

Forward Clutch and Overrun Clutch




DISASSEMBLY


1. Check operation of forward clutch and overrun clutch.
 - a. Install bearing retainer on forward clutch drum.
 - b. Apply compressed air to oil hole of forward clutch drum.
 - c. Check to see that retaining plate moves to snap ring.
 - d. If retaining plate does not move to snap ring, D-ring or oil seal may be damaged or fluid may be leaking at piston check ball.
2. Remove snap ring for forward clutch.
3. Remove drive plates, driven plates, retaining plate and dish plate for forward clutch.

REPAIR FOR COMPONENT PARTS


Forward Clutch and Overrun Clutch (Cont'd)




4. Remove snap ring for overrun clutch.
5. Remove drive plates, driven plates, retaining plate and dish plate for overrun clutch.




6. Set Tool on spring retainer and remove snap ring from forward clutch drum while compressing return springs.
 - Set Tool directly over return springs.
 - Do not expand snap ring excessively.
7. Remove spring retainer and return springs.
 - Do not remove return springs from spring retainer.



8. Remove forward clutch piston with overrun clutch piston from forward clutch drum by turning it.



9. Remove overrun clutch piston from forward clutch piston by turning it.



10. Remove D-rings and oil seals from forward clutch piston and overrun clutch piston.

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd) INSPECTION

Snap rings, spring retainer and return springs

- Check for deformation, fatigue or damage.
- Replace if necessary.
- When replacing spring retainer and return springs, replace them as a set.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



SAT162D

Forward clutch and overrun clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Forward clutch

Standard value: 1.6 mm (0.063 in)


Wear limit: 1.4 mm (0.055 in)

Overrun clutch

Standard value: 1.6 mm (0.063 in)

Wear limit: 1.4 mm (0.055 in)

- If not within wear limit, replace.



SAT163D

Forward clutch and overrun clutch dish plates


- Check for deformation or damage.
- Measure thickness of dish plate.

Thickness of dish plate:

Forward clutch 2.7 mm (0.106 in)


Overrun clutch 2.7 mm (0.106 in)

- If deformed or fatigued, replace.



Forward clutch drum

- Make sure that check balls are not fixed.
- Apply compressed air to check ball oil hole from outside of forward clutch drum to make sure that air leaks past ball.
- Apply compressed air to oil hole from inside of forward clutch drum to make sure that there is no air leakage.



Overrun clutch piston


- Make sure that check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring to make sure that there is no air leakage.
- Apply compressed air to oil hole on return spring side to make sure that air leaks past ball.

REPAIR FOR COMPONENT PARTS


Forward Clutch and Overrun Clutch (Cont'd)

ASSEMBLY


1. Install D-rings and oil seals on forward clutch piston and overrun clutch piston.
 - Take care with direction of oil seal.
 - Apply ATF to both parts.




2. Install overrun clutch piston assembly on forward clutch piston by turning it slowly.
 - Apply ATF to inner surface of forward clutch piston.




3. Install forward clutch piston assembly on forward clutch drum by turning it slowly.
 - Apply ATF to inner surface of drum.



4. Install return spring on overrun clutch piston.








- Align the mark on spring retainer with check ball in overrun clutch piston.



REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



5. Set Tool on spring retainer and install snap ring while compressing return springs.

- Set Tool directly over return springs.

- Do not align snap ring gap with spring retainer stopper.

6. Install drive plates, driven plates, retaining plate and dish plate for overrun clutch.

- Take care with order of plates.

7. Install snap ring for overrun clutch.

8. Measure clearance between overrun clutch retaining plate and snap ring.

If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard 0.7 - 1.1 mm (0.028 - 0.043 in)

Allowable limit 1.7 mm (0.067 in)

Overrun clutch retaining plate: Refer to AT-211.

9. Install drive plates, driven plates, retaining plate and dish plate for forward clutch.

- Take care with order of plates.

10. Install snap ring for forward clutch.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



11. Measure clearance between forward clutch retaining plate and snap ring.


If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard 0.45 - 0.85 mm (0.0177 - 0.0335 in)

Allowable limit 1.65 mm (0.0650 in)



Forward clutch retaining plate: Refer to AT-211.



12. Check operation of forward clutch.
Refer to AT-155.


13. Check operation of overrun clutch.
Refer to AT-155.

Low & Reverse Brake



DISASSEMBLY

1. Stand transmission case.
2. Remove snap ring.
3. Remove dish plate, retaining plate, drive plates and driven plates from transmission case.



4. In order to remove piston, apply compressed air to oil hole of retainer while holding piston.
 - Apply air gradually and allow piston to come out evenly.


GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT

AT

FA
 RA
 BR
 ST
 BF
 HA
 EL

REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)




5. Remove D-rings from piston.

INSPECTION


Low & reverse clutch snap ring, spring retainer and return springs

- Check for deformation, fatigue or damage. If necessary, replace.
- **When replacing spring retainer and return springs, replace them as a set.**




Low & reverse brake drive plate

- Check facing for burns, cracks or damage.
- Measure thickness of facing.
Thickness of drive plate:
Standard value 1.8 mm (0.071 in)
Wear limit 1.6 mm (0.063 in)
- If not within wear limit, replace.






ASSEMBLY

1. Install D-rings on piston.
 - **Take care with the direction of oil seal.**
 - **Apply ATF to both parts.**
2. Set and align piston with retainer.
 - **This operation is required in order to engage the protrusions of piston to return springs correctly. Further procedures are given in "ASSEMBLY" (Refer to AT-188).**



REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)



3. Install driven plates, drive plates, retaining plate and dish plate on transmission case.
- Refer to the illustration on the previous page for order of plates and direction of dish plate.

4. Install snap ring.

5. Measure clearance between driven plate and transmission case. If not within allowable limit, select proper retaining plate. (front side)

Specified clearance:

Standard 1.7 - 2.1 mm (0.067 - 0.083 in)

Allowable limit 3.1 mm (0.122 in)

Retaining plate: Refer to AT-211.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR




ST

BF

HA

EL

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub




DISASSEMBLY


1. Remove overrun clutch hub and thrust washer from forward clutch hub.
2. Remove forward clutch hub from rear internal gear.

REPAIR FOR COMPONENT PARTS


Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)




3. Remove end bearing from rear internal gear.




4. Remove thrust washer from rear internal gear.



5. Remove end bearing from forward one-way clutch.



6. Remove forward one-way clutch from forward clutch hub.



INSPECTION

Rear internal gear, forward clutch hub and overrun clutch hub

- Check rubbing surfaces for wear or damage.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

REPAIR FOR COMPONENT PARTS

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)


End bearings and forward one-way clutch

- Check end bearings for deformation and damage.
- Check forward one-way clutch for wear and damage.




ASSEMBLY


1. Install forward one-way clutch on forward clutch.
 - Take care with the direction of forward one-way clutch.



2. Install end bearing on forward one-way clutch.
 - Apply petroleum jelly to end bearing.




3. Install thrust washer on rear internal gear.
 - Apply petroleum jelly to thrust washer.
 - Align hooks of thrust washer with holes of rear internal gear.




4. Install end bearing on rear internal gear.
 - Apply petroleum jelly to end bearing.

REPAIR FOR COMPONENT PARTS

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)



5. Install forward clutch hub on rear internal gear.
 - Check operation of forward one-way clutch.



6. Install thrust washer and overrun clutch hub.
 - Apply petroleum jelly to thrust washer.
 - Align hooks of thrust washer with holes of overrun clutch hub.
 - Align projections of rear internal gear with holes of overrun clutch hub.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA


EL

Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer



DISASSEMBLY

1. Remove seal rings from output shaft and bearing retainer.




2. Remove output shaft bearing with screwdrivers.

- **Always replace bearing with a new one when removed.**
- **Do not damage output shaft.**


REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer (Cont'd)


3. Remove snap ring from bearing retainer.




4. Remove needle bearing from bearing retainer.




5. Remove idler gear bearing inner race from idler gear.



6. Remove idler gear bearing outer race from transmission case.



7. Press out reduction gear bearing inner race from reduction gear.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer (Cont'd)




8. Remove reduction gear bearing outer race from transmission case.

INSPECTION


Output shaft, idler gear and reduction gear

- Check shafts for cracks, wear or bending.
- Check gears for wear, chips and cracks.



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing taper roller bearing, replace outer and inner race as a set.**



Seal ring clearance

- Install new seal rings to output shaft.
- Measure clearance between seal ring and ring groove of output shaft.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Allowable limit:

0.25 mm (0.0098 in)

- If not within allowable limit, replace output shaft.
- Install new seal rings to bearing retainer.
- Measure clearance between seal ring and ring groove of bearing retainer.

Standard clearance:

0.10 - 0.30 mm (0.0039 - 0.0118 in)

Allowable limit:


0.30 mm (0.0118 in)

- If not within allowable limit, replace bearing retainer.


REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer (Cont'd)


ASSEMBLY




1. Press reduction gear bearing inner race on reduction gear.




2. Install reduction gear bearing outer race on transmission case.



3. Press idler gear bearing inner race on idler gear.



4. Install idler gear bearing outer race on transmission case.



5. Press output shaft bearing on output shaft.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REPAIR FOR COMPONENT PARTS


Output Shaft, Idler Gear, Reduction Gear and Bearing Retainer (Cont'd)




6. Press needle bearing on bearing retainer.



7. Install snap ring on to bearing retainer.





8. Install new seal rings to output shaft and bearing retainer carefully after packing ring grooves with petroleum jelly.




- Roll paper around seal rings to prevent seal rings from spreading.

Band Servo Piston Assembly




DISASSEMBLY

1. Remove OD servo piston retainer.



2. Apply compressed air to oil hole in transmission case to remove OD servo piston retainer and band servo piston assembly.

- Hold band servo piston assembly with a rag.



3. Apply compressed air to oil hole in OD servo piston retainer to remove OD band servo piston from retainer.


- Hold OD band servo piston while applying compressed air.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly (Cont'd)


4. Remove D-ring from OD band servo piston.




5. Remove O-rings from OD servo piston retainer.




6. Remove band servo piston assembly from servo piston retainer by pushing it forward.



7. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.





8. Remove OD servo return spring, band servo thrust washer and band servo piston stem from band servo piston.



REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)



INSPECTION

Pistons, retainers and piston stem

- Check frictional surfaces for abnormal wear or damage.




Return springs

- Check for deformation or damage.
- Measure free length and outer diameter.

Inspection standard

Parts	Unit: mm (in)	
	Free length	Outer diameter
2nd servo return spring	32.5 (1.280)	25.9 (1.020)
OD servo return spring	31.0 (1.220)	21.7 (0.854)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly (Cont'd)


ASSEMBLY




1. Install D-rings to servo piston retainer.
 - Apply ATF to D-rings.
 - Pay attention to position of each O-ring.




2. Install band servo piston stem, band servo thrust washer, OD servo return spring and spring retainer to band servo piston.



3. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.




4. Install O-rings onto servo piston retainer.
 - Apply ATF to O-rings.
 - Pay attention to position of each O-ring.



5. Install band servo piston assembly to servo piston retainer by pushing it inward.


REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly (Cont'd)




6. Install D-ring to OD band servo piston.

- Apply ATF to D-ring.




7. Install O-rings to OD servo piston retainer.

- Apply ATF to O-rings.
- Pay attention to position of each O-ring.




8. Install OD band servo piston to OD servo piston retainer.



9. Install band servo piston assembly and 2nd servo return spring to transmission case.

- Apply ATF to O-ring of band servo piston and transmission case.



10. Install OD band servo piston assembly to transmission case.

- Apply ATF to O-ring of band servo piston and transmission case.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL



REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly (Cont'd)

11. Install band servo piston snap ring to transmission case.




Final Drive — RE4F04A



DISASSEMBLY

1. Remove final gear.




2. Press out differential side bearings.


● Be careful not to mix up the right and left bearings.

REPAIR FOR COMPONENT PARTS


Final Drive — RE4F04A (Cont'd)




3. Remove differential side bearing outer race, and side bearing adjusting shim from transmission case.




4. Remove speedometer drive gear.



5. Drive out pinion mate shaft lock pin.



6. Draw out pinion mate shaft lock pin.
7. Remove pinion mate gears and side gears.



INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, side gears and pinion mate gears.
- Check washers for wear.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04A (Cont'd)




Bearings

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing taper roller bearing, replace outer and inner race as a set.**




ASSEMBLY

1. Attach side gear thrust washers to side gears, then install pinion mate washers and pinion mate gears in place.




2. Insert pinion mate shaft.

- **When inserting, be careful not to damage pinion mate thrust washers.**



3. Measure clearance between side gear and differential case with washers following the procedure below:

- a. Set Tool and dial indicator on side gear.



- b. Move side gear up and down to measure dial indicator deflection. Always measure indicator deflection on both side gears.

Clearance between side gear and differential case with washers:

0.1 - 0.2 mm (0.004 - 0.008 in)

REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04A (Cont'd)

- c. If not within specification, adjust clearance by changing thickness of side gear thrust washers.

Side gear thrust washer:

Refer to AT-212.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA


EL




4. Install lock pin.
● **Make sure that lock pin is flush with case.**



5. Install speedometer drive gear on differential case.
● **Align the projection of speedometer drive gear with the groove of differential case.**




6. Press on differential side bearings.



7. Install final gear and tighten fixing bolts in a crisscross pattern.


REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V




DISASSEMBLY


1. Remove final gear.



2. Press out differential side bearings.




3. Remove differential side bearing outer race, and side bearing adjusting shim from transmission case.




REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V (Cont'd)

4. Remove speedometer drive gear.




5. Remove viscous coupling.



6. Separate differential cases. Make paint marks to identify their original position.


7. Remove pinion mate shaft with gears.



INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, side gears, pinion mate gears and viscous coupling.
- Check washers for wear.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V (Cont'd)


Viscous coupling

- Check case for cracks.
- Check silicone oil for leakage



Bearings

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing taper roller bearing, replace outer and inner race as a set.**




ASSEMBLY

1. Measure clearance between side gear and differential case & viscous coupling with washers using the following procedure:

Differential case side


- a. Set tool on the differential case and lock gauging cylinder in place with set screw.



- b. Install gauging plunger into cylinder.

REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V (Cont'd)




- c. Install pinion mate gears and side gear with thrust washer on differential case.
- d. Set tool and allow gauging plunger to rest on side gear thrust washer.
- e. Measure gap between plunger and cylinder. This measurement should give exact clearance between side gear and differential case with washers.

Standard clearance:

0.1 - 0.2 mm (0.004 - 0.008 in)


- f. If not within specification adjust clearance by changing thickness of side gear thrust washer.

**Side gear thrust washers for differential case side:
Refer to AT-212.**



Viscous coupling side

- a. Set tool on viscous coupling and lock gauging cylinder in place with set screw.




- b. Install gauging plunger into cylinder.

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V (Cont'd)



- c. Install pinion mate gears and side gears with original washers on differential cases.

Align paint marks.


- d. Tighten differential case bolts.
- e. Set tool and allow plunger to rest on side gear thrust washer.
- f. Measure gap between plunger and cylinder. This measurement should give exact clearance between side gear and differential case with washers.

Standard clearance:


0.1 - 0.2 mm (0.004 - 0.008 in)

- g. If not within specification, adjust clearance by changing thickness of side gear thrust washer.


**Side gear thrust washers for viscous coupling side:
Refer to AT-212.**



2. Install viscous coupling





3. Install speedometer drive gear on differential case.
 - **Align the projection of speedometer drive gear with the groove of differential case.**



4. Press differential side bearings on differential case.

REPAIR FOR COMPONENT PARTS

Final Drive — RE4F04V (Cont'd)



5. Install final gear and tighten fixing bolts in a crisscross pattern.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR






ST

BF

HA

EL

ASSEMBLY



Assembly

1. Install differential side oil seals on transmission case and converter housing.

2. Install parking actuator support to transmission case.
 - Pay attention to direction of parking actuator support.

3. Install parking pawl on transmission case and fix it with parking shaft.
4. Install return spring.


Adjustment

DIFFERENTIAL SIDE BEARING PRELOAD

1. Install differential side bearing outer race without adjusting shim on transmission case.
2. Install differential side bearing outer race on converter housing.

ASSEMBLY

Adjustment (Cont'd)



3. Place final drive assembly on transmission case.
4. Install transmission case on converter housing and tighten transmission case fixing bolts to the specified torque.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL



— RE4F04A —

5. Attach dial indicator on differential case at converter housing side.
6. Insert Tool into differential side gear from transmission case side.
7. Move Tool up and down and measure dial indicator deflection.



— RE4F04V —

5. Set Tool on differential case at converter housing side and attach dial indicator on Tool.
6. Insert the other Tool viscous coupling from transmission case side.
7. Move Tool up and down and measure dial indicator deflection.

— RE4F04A and RE4F04V —

8. Select proper thickness of differential side bearing adjusting shim(s).

Suitable shim thickness = Dial indicator deflection
+ Specified bearing preload

Differential side bearing adjusting shim:



Refer to AT-212.

Bearing preload:

0.05 - 0.09 mm (0.0020 - 0.0035 in)

ASSEMBLY

Adjustment (Cont'd)




9. Remove converter housing from transmission case.
10. Remove final drive assembly from transmission case.
11. Remove differential side bearing outer race from transmission case.
12. Reinstall differential side bearing outer race and shim(s) selected from SDS table on transmission case.
13. Reinstall converter housing on transmission case and tighten transmission case fixing bolts to the specified torque.

14. Insert Tool into viscous coupling and measure turning torque of final drive assembly.

- **When measuring turning torque, turn final drive assembly in both directions several times to seat bearing rollers correctly.**


Turning torque of final drive assembly (New bearing):
0.78 - 1.37 N·m (8.0 - 14.0 kg-cm, 6.9 - 12.2 in-lb)

- **When old bearing is used again, turning torque will be slightly less than the above.**
- **Make sure torque is close to the specified range.**



REDUCTION GEAR BEARING PRELOAD


1. Remove transmission case and final drive assembly from converter housing.
2. Select proper thickness of reduction gear bearing adjusting shim using the following procedures.
 - a. Place reduction gear on transmission case as shown.



- b. Place idler gear bearing on transmission case.
- c. Measure dimensions "B" "C" and "D" and calculate dimension "A".

$$A = D - (B + C)$$


"A": Distance between the surface of idler gear bearing inner race and the adjusting shim mating surface of reduction gear.



- Measure dimension "B" between the end of reduction gear and the surface of transmission case.
- **Measure dimension "B" in at least two places.**

ASSEMBLY

Adjustment (Cont'd)




- Measure dimension "C" between the surface of idler gear bearing inner race and the surface of transmission case.
- **Measure dimension "C" in at least two places.**

GI

MA

EM

LC




- Measure dimension "D" between the end of reduction gear and the adjusting shim mating surface of reduction gear.
- **Measure dimension "D" in at least two places.**
- Calculate dimension "A"
 $A = D - (B + C)$

EF &
EC

FE

CL



- Measure dimension "E" between the end of idler gear and the idler gear bearing inner race mating surface of idler gear.
- **Measure dimension "E" in at least two places.**

MT

AT

FA

RA

BR

- Select proper thickness of reduction gear bearing adjusting shim.

Proper shim thickness = A - E - 0.5 mm (0.0020 in)*


(* ... Bearing preload)

Reduction gear bearing adjusting shim: Refer to AT-213.

ST

BF

HA




- Install reduction gear and reduction gear bearing adjusting shim selected in step 2-e on transmission case.
- Press idler gear bearing inner race on idler gear.
- Press idler gear on reduction gear.
- **Press idler gear so that idler gear can be locked by parking pawl.**


EL

ASSEMBLY


Adjustment (Cont'd)




6. Tighten idler gear lock nut to the specified torque.
- **Lock idler gear with parking pawl when tightening lock nut.**



7. Measure turning torque of reduction gear.
- **When measuring turning torque, turn reduction gear in both directions several times to seat bearing rollers correctly.**
Turning torque of reduction gear:
0.05 - 0.39 N·m (0.5 - 4.0 kg-cm, 0.43 - 3.47 in-lb)
- **If turning torque is out of specification, decrease or increase thickness of reduction gear bearing adjusting shim.**




8. After properly adjusting turning torque, clinch idler gear lock nut as shown.



OUTPUT SHAFT END PLAY


- Measure clearance between side cover and the end of the output shaft bearing.
- Select proper thickness of adjusting shim so that clearance is within specifications.




1. Install bearing retainer for output shaft.

ASSEMBLY


Adjustment (Cont'd)



2. Install output shaft thrust needle bearing on bearing retainer.




3. Install output shaft on transmission case.



4. Measure dimensions " l_1 " and " l_2 " at side cover and then calculate dimension "A".

- Measure dimension " l_1 " and " l_2 " in at least two places.
- "A": Distance between transmission case fitting surface and adjusting shim mating surface.

$$A = l_1 - l_2 \quad l_2: \text{Height of gauge}$$




5. Measure dimensions " l_2 " and " l_3 " and then calculate dimension "B".

- Measure " l_2 " and " l_3 " in at least two places.

- "B": Distance between the end of output shaft bearing outer race and the side cover fitting surface of transmission case.

$$B = l_2 - l_3 \quad l_2: \text{Height of gauge}$$



6. Select proper thickness of adjusting shim so that output shaft end play (clearance between side cover and output shaft bearing) is within specifications.

Output shaft end play (A - B):

0 - 0.15 mm (0 - 0.0059 in)

Output shaft end play adjusting shim:

Refer to AT-214.

7. Install adjusting shim on output shaft bearing.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA


EL

ASSEMBLY




Assembly


1. Apply locking sealant to transmission case as shown in illustration.
 - Wash mating surfaces with a brake cleaner type solvent, allow to dry.
 - The mating surfaces must be smooth and free of oil.
 - Use an anaerobic liquid gasket Loctite P/N 51813 or equivalent to mating surface of side cover.



2. Set side cover on transmission case.




3. Tighten side cover fixing bolts to specified torque.
 - Do not mix bolts (A) and (B).
 - Always replace bolts (A) as they are self-sealing bolts.




4. Remove paper rolled around bearing retainer.
5. Install thrust washer on bearing retainer.
 - Apply petroleum jelly to thrust washer.

ASSEMBLY


Assembly (Cont'd)




6. Install forward clutch assembly.
 - **Align teeth of low & reverse brake drive plates before installing.**
 - **Make sure that bearing retainer seal rings are not spread.**
 - **If forward clutch assembly is correctly seated, points ① and ② are at almost same level.**



7. Install thrust needle bearing on bearing retainer.
 - **Apply petroleum jelly to thrust needle bearing.**
 - **Pay attention to direction of thrust needle bearing.**



8. Install overrun clutch hub.
 - **Apply petroleum jelly to thrust washers.**
 - **Align teeth of overrun clutch drive plates before installing.**



9. Hold forward clutch hub and turn rear internal gear. Check overrun clutch hub for correct directions of lock and unlock.
 - **If not shown as illustration, check installed direction of forward one-way clutch.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


ASSEMBLY

Assembly (Cont'd)



10. Install forward clutch hub and rear internal gear assembly.


- **Align teeth of forward clutch drive plates before installing.**
- **Check three hooks of thrust washer are correctly aligned after installing.**



11. Install rear planetary carrier assembly and rear sun gear according to the following procedures.


a. Install needle bearings on rear planetary carrier.

- **Apply petroleum jelly to needle bearings.**
- **Pay attention to direction of needle bearings.**



b. Install rear sun gear on rear planetary carrier.


- **Pay attention to direction of rear sun gear.**



c. Install rear planetary carrier on transmission case.


ASSEMBLY

Assembly (Cont'd)




12. Install thrust needle bearing on front planetary carrier, then install them together on transmission case.

- Apply petroleum jelly to thrust needle bearing.
- Pay attention to direction of thrust needle bearing.




13. Install low and reverse brake piston according to the following procedures.

a. Set and align return springs to transmission case gutters as shown in illustration.



b. Set and align piston with retainer.



c. Install piston and retainer assembly on the transmission case.

- Align bracket to specified gutter as indicated in illustration.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

ASSEMBLY


Assembly (Cont'd)




- d. Check that each protrusions of piston is correctly set to corresponding return spring as follows.

Push piston and retainer assembly evenly and confirm they move smoothly.


If they can not move smoothly, remove piston and retainer assembly and align return spring correctly as instructed in step "a".




- e. Push down piston and retainer assembly and install snap ring.



14. Install low one-way clutch to front planetary carrier by turning carrier in the direction of the arrow shown.



15. Install snap ring with screwdriver.




16. Install needle bearing on transmission case.

- **Apply petroleum jelly to needle bearing.**
- **Pay attention to direction of needle bearing.**

ASSEMBLY

Assembly (Cont'd)



17. Install bearing race, needle bearing and high clutch hub on front sun gear.


- Apply petroleum jelly to needle bearing.
- Pay attention to direction of needle bearing.

GI

MA

EM

LC




18. Install high clutch hub and front sun gear on transmission case.

EF &

EC

FE

CL



19. Install needle bearings on high clutch drum.


- Apply petroleum jelly to needle bearings.
- Pay attention to direction of needle bearings.

MT

AT

FA

RA




20. Remove paper rolled around input shaft.

21. Install input shaft assembly in reverse clutch.

- Align teeth of reverse clutch drive plates before installing.

ST

BF



22. Install reverse clutch assembly on transmission case.

- Align teeth of high clutch drive plates before installing.

HA


EL

ASSEMBLY

Adjustment


When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.

Part name	Item	
	Total end play	Reverse clutch end play
Transmission case	•	•
Overrun clutch hub	•	•
Rear internal gear	•	•
Rear planetary carrier	•	•
Rear sun gear	•	•
Front planetary carrier	•	•
Front sun gear	•	•
High clutch hub	•	•
High clutch drum	•	•
Oil pump cover	•	•
Reverse clutch drum	•	•




TOTAL END PLAY

1. Adjust total end play "T₁".




- a. With original bearing race installed, place Tool onto oil pump. The long ends of legs should be placed firmly on machined surface of oil pump assembly and gauging cylinder should rest on top of bearing race. Lock gauging cylinder in place with set screw.



- b. Install gauging plunger into cylinder.

ASSEMBLY

Adjustment (Cont'd)



- c. With needle bearing installed on high clutch drum, place Tool legs on machined surface of transmission case (with gasket) and allow plunger to rest on needle bearing.
- d. Measure gap between cylinder and plunger. This measurement should give exact total end play.

Total end play "T₁":



0.25 - 0.55 mm (0.0098 - 0.0217 in)

- If end play is out of specification, decrease or increase thickness of bearing race as necessary.


Available bearing race:

Refer to AT-215.


- 2. Adjust reverse clutch drum end play "T₂".



- a. Place Tool on machined surface of transmission case (with gasket) and allow gauging cylinder to rest on reverse clutch drum. Lock cylinder in place with set screw.



- b. Install gauging plunger into cylinder.



- c. With original thrust washer installed on oil pump, place Tool legs onto machined surface of oil pump assembly and allow plunger to rest on thrust washer.
- d. Measure gap between cylinder and plunger with feeler gauge. This measurement should give exact reverse clutch drum end play.

Reverse clutch drum end play "T₂":

0.55 - 0.90 mm (0.0217 - 0.0354 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

ASSEMBLY

Adjustment (Cont'd)





- If end play is out of specification, decrease or increase thickness of thrust washer as necessary.

Available thrust washer:

Refer to AT-214.

Assembly


1. Install anchor end pin, washer and lock nut on transmission case.
2. Place brake band and strut on periphery of reverse clutch drum. Then, tighten anchor end pin just enough so that brake band is fitted on periphery of reverse clutch drum uniformly.
3. Place bearing race selected in total end play adjustment step on oil pump cover.
 - **Apply petroleum jelly to bearing race.**
4. Place thrust washer selected in reverse clutch end play step on reverse clutch drum.
 - **Apply petroleum jelly to thrust washer.**
5. Install oil pump assembly, baffle plate and gasket on transmission case.
6. Tighten oil pump fixing bolts to the specified torque.




7. Install O-ring to input shaft.
 - **Apply ATF to O-ring.**

ASSEMBLY


Assembly (Cont'd)




8. Adjust brake band.
 - a. Tighten anchor end pin to the specified torque.
Anchor end pin:
 \square : 4 - 6 N·m (0.4 - 0.6 kg-m, 2.9 - 4.3 ft-lb)
 - b. Back off anchor end pin two and a half turns.
 - c. While holding anchor end pin, tighten lock nut.




9. Apply compressed air to oil holes of transmission case and check operation of brake band.



10. Install final drive assembly on transmission case.



11. Install oil tube on converter housing.



12. Install O-ring on differential oil port of transmission case.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA



EL

ASSEMBLY


Assembly (Cont'd)



13. Install converter housing on transmission case.
 - Apply locking sealant to mating surface of converter housing.
 - Wash mating surfaces with a brake cleaner type solvent, allow to dry.
 - The mating surfaces must be smooth and free of oil.
 - Use an anaerobic liquid gasket Loctite P/N 51813 or equivalent to mating surface of converter housing.



14. Install accumulator piston.
 - a. Check contact surface of accumulator piston for damage.




- b. Install O-rings on accumulator piston.
 - Apply ATF to O-rings.

Accumulator piston O-rings:

Unit: mm (in)

Accumulator	Inner diameter (Small)	Inner diameter (Large)
3-R accumulator	26.9 (1.059)	44.2 (1.740)
N-D accumulator	34.6 (1.362)	39.4 (1.551)



- c. Install accumulator pistons and return springs on transmission case.
 - Apply ATF to inner surface of transmission case.


Return springs:

Unit: mm (in)

Spring	Free length	Outer diameter
3-R accumulator spring	52.5 (2.067)	20.4 (0.803)
N-D accumulator spring	43.5 (1.713)	27.0 (1.063)


ASSEMBLY

Assembly (Cont'd)




15. Install lip seals for band servo oil holes on transmission case.

- Apply petroleum jelly to lip seals.




16. Install tube and sleeve.



17. Install control valve assembly.


a. Insert manual valve into control valve assembly.

- Apply ATF to manual valve.



b. Set manual shaft in Park/neutral position.

c. Install control valve assembly on transmission case while aligning manual valve with manual plate.



d. Pass solenoid harness through transmission case and install terminal body on transmission case by pushing it.

e. Install stopper ring to terminal body.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

ASSEMBLY

Assembly (Cont'd)

Unit: mm (in)


- ⓪ 5 bolts $l = 40$ (1.57)
- ⊗ 6 bolts $l = 33$ (1.30)
- 2 bolts $l = 43.5$ (1.713)



SAT647E


f. Tighten bolts ①, ⊗ and ●.

Bolt length, number and location are shown in the illustration.



SAT003F

18. Install oil pan.
 - a. Attach a magnet to oil pan.




Oil pan fixing bolts
(21 pieces)

SAT002F


- b. Install new oil pan gasket on transmission case.
- c. Install oil pan on transmission case.
 - **Always replace oil pan bolts as they are self-sealing bolts.**
 - **Tighten bolts in a criss-cross pattern to prevent dislocation of gasket.**
- d. Tighten drain plug to the specified torque.

ASSEMBLY


Assembly (Cont'd)




19. Install inhibitor switch.
 - a. Set manual lever in "P" position.
 - b. Temporarily install inhibitor switch on manual shaft.
 - c. Move selector lever to "N" position.




- d. Insert 4.0 mm (0.157 in) dia. pin into adjustment hole in both inhibitor switch and manual shaft as near vertically as possible.
 - e. Tighten inhibitor switch fixing bolts.
 - f. Remove pin from adjustment hole after adjusting inhibitor switch.



20. Install oil charging pipe and oil cooler tube to transmission case.



21. Install torque converter.
 - a. Pour ATF into torque converter.
 - **Approximately 1 liters (1-1/8 US qt, 7/8 Imp qt) of fluid is required for a new torque converter.**
 - **When reusing old torque converter, add the same amount of fluid as was drained.**



- b. Install torque converter while aligning notches of torque converter with notches of oil pump.


GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

ASSEMBLY

Assembly (Cont'd)

- c. Measure distance "A" to check that torque converter is in proper position.

Distance "A": 19 mm (0.75 in) or more



SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Engine	KA24DE	
Automatic transaxle model	RE4F04A	RE4F04V
Automatic transaxle assembly		
Model code number	80X05	80X06
Transaxle gear ratio		
1st	2.785	
2nd	1.545	
3rd	1.000	
4th	0.694	
Reverse	2.272	
Final drive	3.619	
Recommended oil	Genuine Nissan Automatic Transmission Fluid (ATF) or equivalent DEXRON II E™ type fluid	
Oil capacity ℓ (US qt, Imp qt)	8.3 (8-3/4, 7-1/4)	8.5 (9, 7-1/2)

Specifications and Adjustments

VEHICLE SPEED WHEN SHIFTING GEARS

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
	Auto power	62 - 70 (39 - 43)	114 - 122 (71 - 76)	179 - 187 (111 - 116)	175 - 183 (109 - 114)	105 - 113 (65 - 70)	41 - 49 (25 - 30)	62 - 70 (39 - 43)
Half throttle	Comfort	42 - 50 (26 - 31)	78 - 86 (48 - 53)	124 - 132 (77 - 82)	74 - 82 (46 - 51)	40 - 48 (25 - 30)	5 - 13 (3 - 8)	62 - 70 (39 - 43)
	Auto power	45 - 53 (28 - 33)	84 - 92 (52 - 57)	132 - 140 (82 - 87)	86 - 94 (53 - 58)	52 - 60 (32 - 37)	5 - 13 (3 - 8)	62 - 70 (39 - 43)

VEHICLE SPEED WHEN PERFORMING LOCK-UP

Throttle position	Shift pattern	OD switch (shift range)	Vehicle speed km/h (MPH)	
			Lock-up "ON"	Lock-up "OFF"
2/8	Comfort	ON [D ₄]	105 - 113 (65 - 70)	53 - 61 (33 - 38)
		OFF [D ₃]	86 - 94 (53 - 58)	83 - 91 (52 - 57)
	Auto power	ON [D ₄]	108 - 116 (67 - 72)	53 - 61 (33 - 38)
		OFF [D ₃]	88 - 94 (55 - 58)	83 - 91 (52 - 57)

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

STALL REVOLUTION

Stall revolution	rpm	2,100 - 2,400
------------------	-----	---------------

LINE PRESSURE

Engine speed rpm	Line pressure kPa (kg/cm ² , psi)	
	D, 2 and 1 ranges	R range
Idle	755 (7.7, 109)	1,177 (12.0, 171)
Stall	1,226 (12.5, 178)	1,961 (20.0, 284)

CONTROL VALVES

Control valve return springs

Unit: mm (in)

Parts		Item		
		Part No.	Free length	Outer diameter
Lower body	Accumulator shift valve spring	31736-01X00	23.0 (0.906)	6.65 (0.2618)
	Pressure regulator valve spring	31742-80X13	45.0 (1.772)	15.0 (0.591)
	Overrun clutch control valve spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	Accumulator control valve spring	31742-80X02	22.0 (0.866)	6.5 (0.256)
	Shift valve A spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	Shift valve B spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	Pressure modifier valve spring	31742-41X15	30.5 (1.201)	9.8 (0.386)
31742-80X16		32.0 (1.260)	6.9 (0.272)	
Upper body	Pilot valve spring	31742-80X14	36.0 (1.417)	8.1 (0.319)
	1-2 accumulator valve spring	31742-80X10	20.5 (0.807)	7.0 (0.276)
	1-2 accumulator piston spring	31742-80X12	52.0 (2.047)	19.6 (0.772)
	1st reducing valve spring	31742-80X05	27.0 (1.063)	7.0 (0.276)
	2-3 timing valve	31742-80X18	30.5 (1.201)	6.6 (0.260)
	Overrun clutch reducing valve spring	31742-80X15	37.5 (1.476)	6.9 (0.272)
	Torque converter relief valve spring	31742-80X07	31.0 (1.220)	9.0 (0.354)
Lock-up control valve spring	31742-80X17	39.5 (1.555)	11.0 (0.433)	

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

CLUTCHES AND BRAKES

Reverse clutch		
Number of drive plates	2	
Number of driven plates	2	
Drive plate thickness mm (in)		
Standard	2.0 (0.079)	
Allowable limit	1.8 (0.071)	
Clearance mm (in)		
Standard	0.5 - 0.8 (0.020 - 0.031)	
Allowable limit	1.2 (0.047)	
Thickness of retaining plates	Thickness mm (in)	Part number
	6.6 (0.260)	31537-80X05
	6.8 (0.268)	31537-80X06
	7.0 (0.276)	31537-80X07
	7.2 (0.283)	31537-80X08
	7.4 (0.291)	31537-80X09
	7.6 (0.299)	31537-80X20
	7.8 (0.307)	31537-80X21
High clutch		
Number of drive plates	3	
Number of driven plates	8	
Drive plate thickness mm (in)		
Standard	1.6 (0.063)	
Allowable limit	1.4 (0.055)	
Clearance mm (in)		
Standard	1.8 - 2.2 (0.071 - 0.087)	
Allowable limit	2.8 (0.110)	
Thickness of retaining plates	Thickness mm (in)	Part number
	3.0 (0.118)	31537-80X15
	3.2 (0.126)	31537-80X16
	3.4 (0.134)	31537-80X17
	3.6 (0.142)	31537-80X18
	3.8 (0.150)	31537-80X19
	4.0 (0.157)	31537-80X22
	Forward clutch	
Number of drive plates	4	
Number of driven plates	4	
Drive plate thickness mm (in)		
Standard	1.6 (0.063)	
Allowable limit	1.4 (0.055)	
Clearance mm (in)		
Standard	0.45 - 0.85 (0.0177 - 0.0335)	
Allowable limit	1.65 (0.0650)	
Thickness of retaining plates	Thickness mm (in)	Part number
	3.6 (0.142)	31537-80X70
	3.8 (0.150)	31537-80X71
	4.0 (0.157)	31537-80X72
	4.2 (0.165)	31537-80X73
	4.4 (0.173)	31537-80X74
	3.4 (0.134)	31537-80X75

Overrun clutch		
Number of drive plates	3	
Number of driven plates	5	
Drive plate thickness mm (in)		
Standard	1.6 (0.063)	
Allowable limit	1.4 (0.055)	
Clearance mm (in)		
Standard	0.7 - 1.1 (0.028 - 0.043)	
Allowable limit	1.7 (0.067)	
Thickness of retaining plates	Thickness mm (in)	Part number
	3.0 (0.118)	31537-80X60
	3.2 (0.126)	31537-80X61
	3.4 (0.134)	31537-80X62
	3.6 (0.142)	31537-80X63
	3.8 (0.150)	31537-80X64
	Low & reverse brake	
Number of drive plates	5	
Number of driven plates	5	
Drive plate thickness mm (in)		
Standard	1.8 (0.071)	
Allowable limit	1.6 (0.063)	
Clearance mm (in)		
Standard	1.7 - 2.1 (0.067 - 0.083)	
Allowable limit	3.1 (0.122)	
Thickness of retaining plates	Thickness mm (in)	Part number
	2.0 (0.079)	31667-80X00
	2.2 (0.087)	31667-80X01
	2.4 (0.094)	31667-80X02
	2.6 (0.102)	31667-80X03
	2.8 (0.110)	31667-80X04
	3.0 (0.118)	31667-80X05
	3.2 (0.126)	31667-80X06
3.4 (0.134)	31667-80X07	
Brake band		
Anchor end bolt tightening torque	4 - 6 (0.4 - 0.6, 2.9 - 4.3)	
N•m (kg-m, ft-lb)		
Number of returning revolutions for anchor end bolt	2.5	
Lock nut tightening torque	31 - 42 (3.2 - 4.3, 23 - 31)	
N•m (kg-m, ft-lb)		

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

FINAL DRIVE

Differential side gear clearance

Clearance between side gear and differential case with washer	mm (in)	0.1 - 0.2 (0.004 - 0.008)
---	---------	---------------------------

Differential side gear thrust washers (RE4F04A)

Thickness mm (in)	Part number
0.75 (0.0295)	38424-81X00
0.80 (0.0315)	38424-81X01
0.85 (0.0335)	38424-81X02
0.90 (0.0354)	38424-81X03
0.95 (0.0374)	38424-81X04

(RE4F04V)

	Thickness mm (in)	Part number
Viscous coupling side	0.44 (0.0173)	38424-51E10
	0.53 (0.0209)	38424-51E11
	0.62 (0.0244)	38424-51E12
	0.71 (0.0280)	38424-51E13
	0.80 (0.0315)	38424-51E14
Differential case side	0.75 (0.0295)	38424-E3000
	0.80 (0.0315)	38424-E3001
	0.85 (0.0335)	38424-E3002
	0.90 (0.0354)	38424-E3003

Differential side bearing preload adjusting shims (RE4F04A)

Thickness mm (in)	Part number
0.48 (0.0189)	31438-80X00
0.52 (0.0205)	31438-80X01
0.56 (0.0220)	31438-80X02
0.60 (0.0236)	31438-80X03
0.64 (0.0252)	31438-80X04
0.68 (0.0268)	31438-80X05
0.72 (0.0283)	31438-80X06
0.76 (0.0299)	31438-80X07
0.80 (0.0315)	31438-80X08
0.84 (0.0331)	31438-80X09
0.88 (0.0346)	31438-80X10
0.92 (0.0362)	31438-80X11

(RE4F04V)

Thickness mm (in)	Part number
0.36 (0.0142)	38753-56E00
0.40 (0.0157)	38753-56E01
0.44 (0.0173)	38753-56E02
0.48 (0.0189)	38753-56E03
0.52 (0.0205)	38753-56E04
0.56 (0.0220)	38753-56E05
0.60 (0.0236)	38753-56E06
0.64 (0.0252)	38753-56E07
0.68 (0.0268)	38753-56E08
0.72 (0.0283)	38753-56E09
0.76 (0.0299)	38753-56E10
0.80 (0.0315)	38753-56E11
0.84 (0.0331)	38753-56E12
0.88 (0.0346)	38753-56E13
0.92 (0.0362)	38753-56E14
0.12 (0.0047)	38753-56E15
0.16 (0.0063)	38753-56E16
0.20 (0.0079)	38753-56E17
0.24 (0.0094)	38753-56E18
0.28 (0.0110)	38753-56E19
0.32 (0.0126)	38753-56E20

Bearing preload

Differential side bearing preload	mm (in)	0.05 - 0.09 (0.0020 - 0.0035)
-----------------------------------	---------	-------------------------------

Turning torque

Turning torque of final drive assembly	N•m (kg-cm, in-lb)	0.78 - 1.37 (8.0 - 14.0, 6.9 - 12.2)
--	--------------------	--------------------------------------

Clutch and brake return springs

Unit: mm (in)

Parts	Free length	Outer diameter
Forward clutch (Overrun clutch) (22 pcs)	21.4 (0.843)	10.3 (0.406)
High clutch (12 pcs)	22.5 (0.886)	10.8 (0.425)

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

PLANETARY CARRIER AND OIL PUMP

Planetary carrier		
Clearance between planetary carrier and pinion washer mm (in)		
Standard	0.20 - 0.70 (0.0079 - 0.0276)	
Allowable limit	0.80 (0.0315)	
Oil pump		
Oil pump side clearance mm (in)	0.030 - 0.050 (0.0012 - 0.0020)	
Thickness of inner gears and outer gears	Inner gear	
	Thickness mm (in)	Part number
	11.99 - 12.0 (0.4720 - 0.4724)	31346-80X00
	11.98 - 11.99 (0.4717 - 0.4720)	31346-80X01
	11.97 - 11.98 (0.4713 - 0.4717)	31346-80X02
	Outer gear	
	Thickness mm (in)	Part number
	11.99 - 12.0 (0.4720 - 0.4724)	31347-80X00
	11.98 - 11.99 (0.4717 - 0.4720)	31347-80X01
	11.97 - 11.98 (0.4713 - 0.4717)	31347-80X02
Clearance between oil pump housing and outer gear mm (in)		
Standard	0.111 - 0.181 (0.0044 - 0.0071)	
Allowable limit	0.181 (0.0071)	
Oil pump cover seal ring clearance mm (in)		
Standard	0.036 - 0.176 (0.0014 - 0.0069)	
Allowable limit	0.176 (0.0069)	

INPUT SHAFT

Input shaft seal ring clearance mm (in)		
Standard	0.08 - 0.23 (0.0031 - 0.0091)	
Allowable limit	0.23 (0.0091)	

REDUCTION GEAR

Turning torque

Turning torque of reduction gear N•m (kg-cm, in-lb)	0.05 - 0.39 (0.5 - 4.0, 0.43 - 3.47)	
---	---	--

Reduction gear bearing adjusting shims

Thickness mm (in)	Part number	
5.00 (0.1969)	31439-81X00	GI
5.02 (0.1976)	31439-81X01	
5.04 (0.1984)	31439-81X02	
5.06 (0.1992)	31439-81X03	MA
5.08 (0.2000)	31439-81X04	
5.10 (0.2008)	31439-81X05	
5.12 (0.2016)	31439-81X06	EM
5.14 (0.2024)	31439-81X07	
5.16 (0.2031)	31439-81X08	
5.18 (0.2039)	31439-81X09	
5.20 (0.2047)	31439-81X10	LC
5.22 (0.2055)	31439-81X11	
5.24 (0.2063)	31439-81X12	EF & EC
5.26 (0.2071)	31439-81X13	
5.28 (0.2079)	31439-81X14	
5.30 (0.2087)	31439-81X15	
5.32 (0.2094)	31439-81X16	FE
5.34 (0.2102)	31439-81X17	
5.36 (0.2110)	31439-81X18	
5.38 (0.2118)	31439-81X19	CL
5.40 (0.2126)	31439-81X20	
5.42 (0.2134)	31439-81X21	
5.44 (0.2142)	31439-81X22	MT
5.46 (0.2150)	31439-81X23	
5.48 (0.2157)	31439-81X24	
5.50 (0.2165)	31439-81X46	AT
5.52 (0.2173)	31439-81X47	
5.54 (0.2181)	31439-81X48	
5.56 (0.2189)	31439-81X49	
5.58 (0.2197)	31439-81X60	FA
5.60 (0.2205)	31439-81X61	
5.62 (0.2213)	31439-81X62	
5.64 (0.2220)	31439-81X63	RA
5.66 (0.2228)	31439-81X64	
5.68 (0.2236)	31439-81X65	
5.70 (0.2244)	31439-81X66	BR
5.72 (0.2252)	31439-81X67	
5.74 (0.2260)	31439-81X68	
5.76 (0.2268)	31439-81X69	ST
5.78 (0.2276)	31439-81X70	
5.80 (0.2283)	31439-81X71	
5.82 (0.2291)	31439-81X72	BF
5.84 (0.2299)	31439-81X73	
5.86 (0.2307)	31439-81X74	
5.88 (0.2315)	31439-81X75	HA
5.90 (0.2323)	31439-81X76	
5.92 (0.2331)	31439-81X77	
5.94 (0.2339)	31439-81X78	
5.96 (0.2346)	31439-81X79	EL
5.98 (0.2354)	31439-81X80	
6.00 (0.2362)	31439-81X81	
6.02 (0.2370)	31439-81X82	
6.04 (0.2378)	31439-81X83	
6.06 (0.2386)	31439-81X84	
6.08 (0.2394)	31439-82X00	
6.10 (0.2402)	31439-82X01	
6.12 (0.2409)	31439-82X02	
6.14 (0.2417)	31439-82X03	
6.16 (0.2425)	31439-82X04	
6.18 (0.2433)	31439-82X05	

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

6.20 (0.2441)	31439-82X06
6.22 (0.2449)	31439-82X07
6.24 (0.2457)	31439-82X08
6.26 (0.2465)	31439-82X09
6.28 (0.2472)	31439-82X10
6.30 (0.2480)	31439-82X11
6.32 (0.2488)	31439-82X12
6.34 (0.2496)	31439-82X13
6.36 (0.2504)	31439-82X14
6.38 (0.2512)	31439-82X15
6.40 (0.2520)	31439-82X16
6.42 (0.2528)	31439-82X17
6.44 (0.2535)	31439-82X18
6.46 (0.2543)	31439-82X19
6.48 (0.2551)	31439-82X20
6.50 (0.2559)	31439-82X21
6.52 (0.2567)	31439-82X22
6.54 (0.2575)	31439-82X23
6.56 (0.2583)	31439-82X24
6.58 (0.2591)	31439-82X60
6.60 (0.2598)	31439-82X61
6.62 (0.2606)	31439-82X62
6.64 (0.2614)	31439-82X63
6.66 (0.2622)	31439-82X64
6.68 (0.2630)	31439-82X65
6.70 (0.2638)	31439-82X66
6.72 (0.2646)	31439-82X67

REVERSE CLUTCH END PLAY

Reverse clutch end play mm (in)	0.55 - 0.90 (0.0217 - 0.0354)
------------------------------------	-------------------------------

Thrust washers for adjusting reverse clutch drum end play

Thickness mm (in)	Part number
0.80 (0.0315)	31508-80X00
1.40 (0.0551)	31508-80X03
0.95 (0.0374)	31508-80X07
1.10 (0.0433)	31508-80X08
1.25 (0.0492)	31508-80X09
1.55 (0.0610)	31508-80X10
1.70 (0.0669)	31508-80X11
1.85 (0.0728)	31508-80X12

ACCUMULATOR

O-ring

Unit: mm (in)

Accumulator	Inner diameter (Small)	Inner diameter (Large)
3-R accumulator	26.9 (1.059)	44.2 (1.740)
N-D accumulator	34.6 (1.362)	39.4 (1.551)

Return spring

Unit: mm (in)

Accumulator	Free length	Outer diameter
3-R accumulator	52.5 (2.067)	20.4 (0.803)
N-D accumulator	43.5 (1.713)	27.0 (1.063)

BAND SERVO

Return spring

Unit: mm (in)

Return spring	Free length	Outer diameter
2nd servo return spring	32.5 (1.280)	25.9 (1.020)
OD servo return spring	31.0 (1.220)	21.7 (0.854)

REMOVAL AND INSTALLATION

Unit: mm (in)

Distance between end of converter housing and torque converter	19 (0.75)
--	-----------

OUTPUT SHAFT

Seal ring clearance

Output shaft seal ring clearance mm (in)	
Standard	0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit	0.25 (0.0098)

End play

Output shaft end play mm (in)	0 - 0.15 (0 - 0.0059)
----------------------------------	-----------------------

Output shaft adjusting shims

Thickness mm (in)	Part number
0.80 (0.0315)	31438-80X60
0.84 (0.0331)	31438-80X61
0.88 (0.0346)	31438-80X62
0.92 (0.0362)	31438-80X63
0.96 (0.0378)	31438-80X64
1.00 (0.0394)	31438-80X65
1.04 (0.0409)	31438-80X66
1.08 (0.0425)	31438-80X67
1.12 (0.0441)	31438-80X68
1.16 (0.0457)	31438-80X69
1.20 (0.0472)	31438-80X70

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustments (Cont'd)

BEARING RETAINER

Seal ring clearance

Bearing retainer seal ring clearance	mm (in)	
Standard		0.10 - 0.30 (0.0039 - 0.0118)
Allowable limit		0.30 (0.0118)

TOTAL END PLAY

Total end play	mm (in)	0.25 - 0.55 (0.0098 - 0.0217)
----------------	---------	-------------------------------

Bearing race for adjusting total end play

Thickness mm (in)	Part number	
0.8 (0.031)	31435-80X00	GI
1.0 (0.039)	31435-80X01	
1.2 (0.047)	31435-80X02	MA
1.4 (0.055)	31435-80X03	
1.6 (0.063)	31435-80X04	EM
1.8 (0.071)	31435-80X05	
2.0 (0.079)	31435-80X06	
0.9 (0.035)	31435-80X09	LC
1.1 (0.043)	31435-80X10	
1.3 (0.051)	31435-80X11	EF & EC
1.5 (0.059)	31435-80X12	
1.7 (0.067)	31435-80X13	FE
1.9 (0.075)	31435-80X14	

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


FRONT AXLE AND FRONT SUSPENSION

SECTION FA

CONTENTS

PRECAUTIONS AND PREPARATION	2	Joint Assembly (Transaxle side).....	19
Precautions.....	2	Joint Assembly (Wheel side).....	19
Preparation.....	2	Support Bearing.....	19
Special Service Tools.....	2	Support Bearing Bracket.....	19
Commercial Service Tools.....	3	Assembly.....	19
FRONT AXLE AND FRONT SUSPENSION	4	Wheel Side.....	20
ON-VEHICLE SERVICE	5	Transaxle Side.....	21
Front Axle and Front Suspension Parts.....	5	Support Bearing.....	22
Front Wheel Bearing.....	6	FRONT SUSPENSION	23
Front Wheel Alignment.....	6	FRONT SUSPENSION – Coil Spring and Strut	
Preliminary Inspection.....	7	Assembly	24
Camber, Caster And Kingpin Inclination.....	7	Removal and Installation.....	24
Toe-In.....	7	Disassembly.....	24
Front Wheel Turning Angle.....	8	Inspection.....	24
Drive Shaft.....	8	Strut Assembly.....	24
FRONT AXLE	9	Strut Mounting Insulator.....	25
FRONT AXLE – Wheel Hub and Knuckle	10	Thrust Bearing.....	25
Removal.....	10	Coil Spring And Insulator.....	25
Installation.....	11	Assembly.....	25
Disassembly.....	11	FRONT SUSPENSION – Stabilizer Bar	26
Wheel Hub.....	11	Removal and Installation.....	26
Wheel Bearing.....	11	Inspection.....	26
Inspection.....	12	FRONT SUSPENSION – Transverse Link and	
Wheel Hub And Knuckle.....	12	Lower Ball Joint	27
Snap Ring.....	12	Removal and Installation.....	27
Assembly.....	12	Inspection.....	27
FRONT AXLE – Drive Shaft	15	SERVICE DATA AND SPECIFICATIONS (SDS)	28
Removal.....	15	General Specifications.....	28
Installation.....	16	Coil Spring.....	28
Transaxle Side.....	16	Strut.....	28
Wheel Side.....	16	Front Stabilizer Bar.....	28
Components.....	17	Wheelarch Height.....	28
Disassembly.....	17	Drive Shaft.....	28
Transaxle Side.....	17	Inspection and Adjustment.....	29
Wheel Side.....	18	Wheel Alignment.....	29
Support Bearing.....	18	Wheel Bearing.....	29
Inspection.....	19	Lower Ball Joint.....	29
Drive Shaft.....	19	Wheel Runout.....	29
Boot.....	19		

PRECAUTIONS AND PREPARATION








Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- When removing each suspension part, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.




Preparation

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
HT72520000 (J25730-A) Ball joint remover	 <p>Removing tie-rod outer end and lower ball joint</p>
HT71780000 (-) Spring compressor	 <p>Removing and installing coil spring</p>
ST35652000 (-) Strut attachment	 <p>Fixing strut assembly</p>
GG94310000 (-) Flare nut wrench	 <p>Removing and installing brake piping</p>
KV38106700 (J34296) KV38106800 (J34297) Differential side oil seal protector	 <p>Installing drive shaft</p> <p>LH: KV38106700 RH: KV38106800</p>

PRECAUTIONS AND PREPARATION

Preparation (Cont'd) COMMERCIAL SERVICE TOOLS

Tool name	Description
Attachment Wheel alignment	
Flare nut crows foot	
Torque wrench	

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

FRONT AXLE AND FRONT SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.








: N·m (kg-m, ft-lb)

AFA015

- ① Suspension member
- ② Stabilizer bar
- ③ Drive shaft

- ④ Rebound stopper
- ⑤ Transverse link
- ⑥ Knuckle

- ⑦ Strut assembly
- ⑧ Coil spring
- ⑨ Strut mounting insulator assembly



Front Axle and Front Suspension Parts

Check front axle and front suspension parts for looseness, cracks, wear or other damage.

- Shake each front wheel to check for excessive play.

- Make sure that cotter pin is inserted.
- Retighten all nuts and bolts to the specified torque.

Tightening torque:
Refer to FA-23.

- Check strut (shock absorber) for oil leakage or other damage.

- Check spring height from top of wheelarch to ground.
 - (1) Vehicle must be unladen*, parked on a level surface, and tires checked for proper inflation and wear (tread wear indicator must not be showing).

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

- (2) Bounce vehicle up and down several times before measuring.
Standard height: Refer to FA-28.
- (3) Spring height is not adjustable. If out of specification, check for worn springs or suspension parts.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL

ON-VEHICLE SERVICE

Front Axle and Front Suspension Parts (Cont'd)




- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage. If ball joint dust cover is cracked or damaged, replace transverse link.

- Check suspension ball joint end play.
 - (1) Jack up front of vehicle and set the stands.
 - (2) Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.
 - (3) Make sure front wheels are straight and brake pedal is depressed.
 - (4) Place a pry bar between transverse link and inner rim of road wheel.
 - (5) While raising and releasing pry bar, observe maximum dial indicator value.

Vertical end play:
0 mm (0 in)


- (6) If ball joint movement is beyond specifications, remove and recheck it.



Front Wheel Bearing

- Check that wheel bearings operate smoothly.
- Check axial end play.

Axial end play:
0.05 mm (0.0020 in) or less
- If axial end play is not within specification or wheel bearing does not turn smoothly, replace wheel bearing assembly. Refer to FA-10.



Front Wheel Alignment

Before checking front wheel alignment, be sure to make a preliminary inspection (Unladen*).

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

ON-VEHICLE SERVICE

Front Wheel Alignment (Cont'd)

PRELIMINARY INSPECTION

1. Check tires for wear and improper inflation.
2. Check wheel runout.

Wheel runout:

Refer to SDS, FA-29.

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly by using the standard bounce test.
7. Check vehicle posture (Unladen).

CAMBER, CASTER AND KINGPIN INCLINATION





Camber, caster and kingpin inclination are preset at factory and cannot be adjusted.

1. Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge.

Camber, Caster and Kingpin inclination:

Refer to SDS, FA-29.

2. If camber, caster and kingpin inclination are not within specification, inspect and replace any damaged or worn front suspension parts.



TOE-IN

1. Draw a base line across the tread.
 - After lowering front of vehicle, move it up and down to eliminate friction, and set steering wheel in straight-ahead position.

2. Measure toe-in.

- Measure distance "A" and "B" at the same height as hub center.

Toe-in:

Refer to SDS, FA-29.

3. Adjust toe-in by varying the length of steering tie-rods.
 - (1) Loosen lock nuts.
 - (2) Adjust toe-in by screwing tie-rods in or out.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

ON-VEHICLE SERVICE

Front Wheel Alignment (Cont'd)




Standard length "L":

Refer to ST section ("General Specifications", "SERVICE DATA AND SPECIFICATIONS").

- (3) Tighten lock nuts to specified torque.


Lock nut tightening torque:

Refer to ST section ("Description", "STEERING GEAR AND LINKAGE").



FRONT WHEEL TURNING ANGLE

1. Set wheels in straight-ahead position and then move vehicle forward until front wheels rest on turning radius gauge properly.




2. Rotate steering wheel all the way right and left; measure turning angle.

Wheel turning angle (Full turn):

Inside wheel: $31^{\circ}30'$ - $35^{\circ}30'$

Outside wheel: $25^{\circ}36'$ - $29^{\circ}36'$




3. If stopper bolt head does not contact stopper bracket at specified outside wheel angle, adjust stopper bolt to contact stopper bracket at correct angle.

Adjust protrusion of stopper bolt before placing stopper bolt cap.

Apply grease to face of stopper bracket that bolt touches.

Stopper bolt lock nut tightening torque:

54 - 72 N·m (5.5 - 7.3 kg·m, 40 - 53 ft·lb)



Drive Shaft

Check for grease leakage or other damage.

FRONT AXLE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA


EL



: N·m (kg-m, ft-lb)


AFA016

FRONT AXLE — Wheel Hub and Knuckle




Removal


- Remove wheel bearing lock nut.




- Remove brake caliper assembly.
Brake hose need not be disconnected from brake caliper. Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.



- Separate tie-rod from knuckle with Tool.
Install stud nut conversely on stud bolt to prevent damage to stud bolt.



- Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.
When removing drive shaft, cover boots with shop towel to prevent damage to them.





- Loosen lower ball joint tightening nut.
- Separate knuckle from lower ball joint stud with Tool.
- Remove knuckle from transverse link.

FRONT AXLE — Wheel Hub and Knuckle

Removal (Cont'd)

- Remove strut lower mounting bolts.



Installation

- Install knuckle with wheel hub.
When installing knuckle to strut, be sure to hold bolts and tighten nuts.

: 118 - 147 N·m
(12 - 15 kg-m, 87 - 108 ft-lb)



Before tightening wheel bearing lock nut, apply oil to threaded portion of drive shaft and to both sides of plain washer.

- Tighten wheel bearing lock nut.

: 235 - 314 N·m
(24 - 32 kg-m, 174 - 231 ft-lb)

- Check wheel bearing axial end play.

Axial end play:
0.05 mm (0.0020 in) or less.




Disassembly

CAUTION:

When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race, inner races and grease seals) with a new one.

WHEEL HUB

Drive out hub with inner race (outside) from knuckle with a suitable tool.



WHEEL BEARING

When replacing wheel bearing, replace wheel bearing assembly (inner races and outer race).

- Remove bearing inner race (outside), then remove outer grease seal.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

FRONT AXLE — Wheel Hub and Knuckle


Disassembly (Cont'd)



- Remove inner grease seal from knuckle.



- Remove inner and outer snap rings.



- Press out bearing outer race.

Inspection

WHEEL HUB AND KNUCKLE

Check wheel hub and knuckle for cracks by using a magnetic exploration or dyeing test.

SNAP RING

Check snap ring for wear or cracks. Replace if necessary.

Assembly


1. Install inner snap ring into groove of knuckle.
2. Press new wheel bearing assembly into knuckle.

Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)


CAUTION:

- Do not press inner race of wheel bearing assembly.
 - Do not apply oil or grease to mating surfaces of wheel bearing outer race and knuckle.
3. Install outer snap ring into groove of knuckle.




FRONT AXLE — Wheel Hub and Knuckle


Assembly (Cont'd)




4. Pack grease seal lip with multi-purpose grease.



5. Install outer grease seal.




6. Install inner grease seal.



7. Press wheel hub into knuckle.

Maximum load P:
29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)
Be careful not to damage grease seal.



8. Check bearing operation.

(1) Add load P with press.


Load P:
34.3 - 49.0 kN
(3.5 - 5.0 ton, 3.9 - 5.5 US ton, 3.44 - 4.92 Imp ton)

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


FRONT AXLE — Wheel Hub and Knuckle

Assembly (Cont'd)

- (2) Spin knuckle several turns in both directions.
- (3) Make sure that wheel bearings operate smoothly.



FRONT AXLE — Drive Shaft




Removal

- Remove wheel bearing lock nut.

Brake caliper need not be disconnected.


Do not twist or stretch brake hose when moving components.

- Remove cotter pin and nut securing lower ball joint to knuckle.
- Strike knuckle with a hammer and pull down transverse link to separate lower ball joint from knuckle.




- Remove tie-rod ball joint.
- Separate drive shaft from knuckle by slightly tapping it. If it is hard to remove, use a puller.

When removing drive shaft, cover boots with shop towel to prevent damage to them.



1. Remove right drive shaft from transaxle.



2. Remove left drive shaft with a suitable tool.

— **FOR M/T MODELS** —

- Pry drive shaft from transaxle as shown at left.

— **FOR A/T MODELS** —

Be careful not to damage pinion mate shaft and side gear.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA

EL

FRONT AXLE — Drive Shaft



Installation

TRANSAXLE SIDE

1. Drive a new oil seal to transaxle. Refer to MT or AT section ("Differential Side Oil Seal Replacement", "ON-VEHICLE SERVICE").
2. Set Tool along the inner circumference of oil seal (transaxle side).
3. Insert drive shaft into transaxle. Be sure to properly align the serrations and then withdraw Tool.
4. Push drive shaft, then press-fit circular clip on the drive shaft into circular clip groove of side gear.
5. After its insertion, try to pull the flange out of the slide joint by hand. If it pulls out, the circular clip is not properly meshed with the side gear.

WHEEL SIDE

- Install drive shaft into knuckle.
- Tighten wheel bearing lock nut. Refer to FA-11.


FRONT AXLE — Drive Shaft

Components

Circular clip:


Make sure circular clip is properly meshed with side gear (transaxle side) and joint assembly (wheel side), and will not come out.

Be careful not to damage boots. Use suitable protector or cloth during removal and installation.



SFA320B


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA



Disassembly

TRANSAXLE SIDE

1. Remove boot bands.
2. Put matching marks on slide joint housing and inner race, before separating joint assembly.
3. Pry off snap ring "A" with a screwdriver, and pull out slide joint housing.



4. Put matching marks on inner race and drive shaft.
5. Pry off snap ring "C", then remove ball cage, inner race and balls as a unit.
6. Pry off snap ring "B".
7. Draw out boot.

Cover drive shaft serrations with tape so as not to damage the boot.

RA
BR
ST
BF
HA
EL

FRONT AXLE — Drive Shaft

Disassembly (Cont'd)

WHEEL SIDE






CAUTION:

The joint on the wheel side cannot be disassembled.

- Before separating joint assembly, put matching marks on drive shaft and joint assembly.
- Separate joint assembly with a suitable tool.

Be careful not to damage threads on drive shaft.

- Remove boot bands.



SUPPORT BEARING

- Remove dust shield.


- Pry off snap ring.

- Press support bearing assembly out of drive shaft.

FRONT AXLE — Drive Shaft

Disassembly (Cont'd)

- Press support bearing out of retainer.



Inspection

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

DRIVE SHAFT

Replace drive shaft if it is twisted or cracked.

BOOT

Check boot for fatigue, cracks, or wear. Replace boot with new boot bands.

JOINT ASSEMBLY (Transaxle side)

- Replace joint assembly if it is deformed or damaged.

JOINT ASSEMBLY (Wheel side)

Replace joint assembly if it is deformed or damaged.

SUPPORT BEARING

Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.

SUPPORT BEARING BRACKET

Check support bearing bracket for cracks with a magnetic exploration or dyeing test.

Assembly

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use NISSAN GENUINE GREASE or equivalent after every overhaul.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


FRONT AXLE — Drive Shaft

Assembly (Cont'd)


WHEEL SIDE




1. Install boot and new small boot band on drive shaft.
Cover drive shaft serration with tape so as not to damage boot during installation.



2. Set joint assembly onto drive shaft by lightly tapping it; Install joint assembly securely, ensuring marks which were made during disassembly are properly aligned.




3. Pack drive shaft with specified amount of grease.
**Specified amount of grease:
100 - 120 g (3.53 - 4.23 oz)**



4. Make sure that boot is properly installed on the drive shaft groove.
Set boot so that it does not swell and deform when its length is "L₁".



**Length "L₁":
84.5 - 86.5 mm (3.327 - 3.406 in)**



5. Lock new larger and smaller boot bands securely with a suitable tool.

FRONT AXLE — Drive Shaft

Assembly (Cont'd)




Dynamic damper

1. Use new damper band when reinstalling.
2. Install dynamic damper from stationary-joint side while holding it securely.


Length:

	Unit: mm (in)	
	LH	RH
"A"	203.1 (8.00)	185.6 (7.31)
"B"	70 (2.76)	50 (1.97)




TRANSAXLE SIDE

1. Install boot and new small boot band on drive shaft.
Cover drive shaft serration with tape so as not to damage boot during installation.



2. Install new snap ring "B", then securely install ball cage, inner race and balls as a unit, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring "C".



4. Pack drive shaft with specified amount of grease.
Specified amount of grease:
145 - 165 g (5.11 - 5.82 oz)
5. Install slide joint housing, then install new snap ring "A".
6. Make sure that boot is properly installed on the drive shaft groove.
Set boot so that it does not swell and deform when its length is "L₂".
Length "L₂":
97 - 99 mm (3.82 - 3.90 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

FRONT AXLE — Drive Shaft


Assembly (Cont'd)

7. Lock new larger and smaller boot bands securely with a suitable tool.




SUPPORT BEARING


- Press bearing into retainer.



- Press drive shaft into bearing.




- Install snap ring.
- Install new dust shield.



FRONT SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.


* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.



- | | | |
|----------------------------|---------------------------|---------------------------|
| ① Bound bumper assembly | ⑪ Stabilizer | ⑳ Cotter pin |
| ② Upper spring seat | ⑫ Compression rod bushing | ㉑ Wheel bearing cap |
| ③ Strut mounting insulator | ⑬ Transverse link | ㉒ Washer |
| ④ Plain washer | ⑭ Cotter pin | ㉓ Baffle plate |
| ⑤ Cap | ⑮ Drive shaft | ㉔ Knuckle |
| ⑥ Spacer | ⑯ Cap | ㉕ Strut assembly |
| ⑦ (Polyuretane tube) | ⑰ Stopper bolt | ㉖ Dynamic damper assembly |
| ⑧ Coil spring | ⑱ Insulator (Rubber) | |
| ⑨ Front suspension member | | |
| ⑩ Stabilizer clamp | | |


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

FRONT SUSPENSION — Coil Spring and Strut Assembly



Removal and Installation


- Remove strut assembly fixing bolts and nuts (to hoodledge).
Do not remove piston rod lock nut on vehicle.




Disassembly

1. Set strut assembly on vise with Tool, then loosen piston rod lock nut.
Do not remove piston rod lock nut.

Do not remove piston rod lock nut.



2. Compress spring with Tool so that the strut mounting insulator can be turned by hand.



3. Remove piston rod lock nut.

Inspection

STRUT ASSEMBLY

- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage occurring on welded or gland packing portion.
- Check piston rod for cracks, deformation or other damage.
- Replace if necessary.

FRONT SUSPENSION — Coil Spring and Strut Assembly

Inspection (Cont'd)

STRUT MOUNTING INSULATOR

- Check cemented rubber-to-metal portion for separation or cracks.
- Check rubber parts for deterioration.

GI

THRUST BEARING

- Check thrust bearing parts for abnormal noise or excessive rattle in axial direction.
- Replace if necessary.

MA

EM

COIL SPRING AND INSULATOR

Check for cracks, deformation or other damage. Replace if necessary.


LC

EF &
EC

FE

CL

MT



Assembly


- When installing coil spring on strut, it must be positioned as shown in the figure at left.

AT

FA

RA

BR



- Install upper spring seat with its cutout facing the outer side of vehicle, in line with the strut-to-knuckle attachment points. **When installing strut to knuckle, be sure to hold bolts and tighten nuts.**

ST


BF

\square : 118 - 147 N·m
(12 - 15 kg-m, 87 - 108 ft-lb)

HA


EL

FRONT SUSPENSION — Stabilizer Bar




Removal and Installation


- Remove stabilizer bar.



- When installing stabilizer, make sure that paint mark and clamp face in their correct directions.



- Make sure that slit in bushing is in the position shown in the figure.



Inspection

- Check stabilizer for deformation or cracks. Replace if necessary.
- Check rubber bushings for deterioration or cracks. Replace if necessary.
- Check ball joint can rotate in all directions. If movement is not smooth and free, replace stabilizer bar link.

Removal and Installation

1. Remove stabilizer connecting rod from transverse link.
2. Remove cotter pin and lock nut securing lower ball joint to knuckle.
3. Strike knuckle with a hammer to separate lower ball joint from knuckle.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL




AFA017

4. Remove bolts and nuts as shown at left.
5. Remove transverse link and lower ball joint.
6. Install fixing bolts and nuts.
Tightening torque:
Refer to FA-23.
7. During installation, final tightening must be carried out at curb weight with tires on the ground.
8. After installation, check wheel alignment. Refer to FA-6.

Inspection

- Check transverse link for damage, cracks or deformation. Replace if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace transverse link if necessary.



SFA858A

- Check ball joint for play. If ball stud is worn, play in axial direction is excessive or joint is hard to swing, replace if necessary. Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.

Swinging force "A":

(measuring point: cotter pin hole of ball stud):

7.8 - 54.9 N (0.8 - 5.6 kg, 1.8 - 12.3 lb)

Turning torque "B":

0.5 - 3.4 N·m (5 - 35 kg-cm, 4.3 - 30.4 in-lb)

Vertical end play "C":

0 mm (0 in)

- Check dust cover for damage. Replace it and cover clamp if necessary.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COIL SPRING

Applied model	XE		SE	
	M/T	A/T	M/T	A/T
Wire diameter mm (in)	13.4 (0.528)	13.6 (0.535)	13.6 (0.535)	13.8 (0.543)
Coil diameter mm (in)	173.8 (6.84)	174.2 (6.86)		174.6 (6.87)
Free length mm (in)	365 (14.37)	375 (14.76)	354 (13.94)	364 (14.33)
Spring constant N/mm (kg/mm, lb/in)	21.6 (2.2, 123)		23.5 (2.4, 134)	
Identification color	White x 2	White x 1, Pink x 1	White x 1, Pink x 1	White x 1, Light green x 1


STRUT

Applied model	XE	SE
Piston rod diameter mm (in)	22 (0.87)	
Damping force [at 0.3 m (1.0 ft)/sec.] N (kg, lb)		
Expansion	1,196 (122, 269)	1,314 (134, 295)
Compression	333 (34, 75)	471 (48, 106)

FRONT STABILIZER BAR

Applied model	M/T	A/T
Stabilizer diameter mm (in)	21.0 (0.827)	
Identification color	Green	Pink

WHEELARCH HEIGHT (Unladen*)



SFA818A


Applied model	XE	SE
Front (Hf) mm (in)	691 (27.20)	690 (27.17)
Rear (Hr) mm (in)	680 (26.77)	678 (26.69)

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mate in designated positions.


DRIVE SHAFT

Applied model	All
Joint type	
Transaxle side	DS90
Wheel side	BF90
Boot length mm (in)	
Transaxle side (L ₂)	97 - 99 (3.82 - 3.90)
Wheel side (L ₁)	84.5 - 86.5 (3.327 - 3.406)
Grease	Nissan genuine grease or equivalent
Capacity g (oz)	
Transaxle side	145 - 165 (5.11 - 5.82)
Wheel side	100 - 120 (3.53 - 4.23)

Transaxle side



Wheel side



SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*1)

Applied model	All	
Camber	degree	-0°50' to 0°40'
Caster	degree	1°55' - 3°25'
Kingpin inclination	degree	13°20' - 14°50'
Toe-in		
A - B	mm (in)	0 - 2 (0 - 0.08)
Total angle 2θ	degree	0' - 12'
Front wheel turning angle		
Full turn*2	Inside	31°30' - 35°30'
	Outside	25°36' - 29°36'

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

WHEEL BEARING

Wheel bearing axial end play limit	mm (in)	0.05 (0.0020) or less
Wheel bearing lock nut tightening torque	N•m (kg-m, ft-lb)	235 - 314 (24 - 32, 174 - 231)

LOWER BALL JOINT

Swinging force (Measured at cotter pin hole)	N (kg, lb)	7.8 - 54.9 (0.8 - 5.6, 1.8 - 12.3)
Turning torque	N•m (kg-cm, in-lb)	0.5 - 3.4 (5 - 35, 4.3 - 30.4)
Vertical end play limit	mm (in)	0 (0)

WHEEL RUNOUT

Wheel type	Aluminum wheel	Steel wheel
Maximum radial runout limit	0.3 (0.012) or less	0.5 (0.020) or less
Maximum lateral runout limit	0.3 (0.012) or less	0.8 (0.031) or less

Unit: mm (in)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



REAR AXLE AND REAR SUSPENSION


SECTION RA

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS

PRECAUTIONS AND PREPARATION	2	Inspection	12
Precautions.....	2	Strut Assembly.....	12
Preparation	2	Upper Rubber Seat And Bushing	13
Special Service Tools.....	2	Strut Mounting Insulator	13
REAR AXLE AND REAR SUSPENSION	4	Coil Spring	13
ON-VEHICLE SERVICE	5	Assembly	13
Rear Axle and Rear Suspension Parts.....	5	REAR SUSPENSION — Parallel Link, Radius	
Rear Wheel Bearing	5	Link and Stabilizer Bar	14
Rear Wheel Alignment.....	6	Removal and Installation	14
Preliminary Inspection	6	Parallel Link And Radius Link	14
Camber	6	Stabilizer Bar	14
Toe-In.....	6	SERVICE DATA AND SPECIFICATIONS (SDS)	15
REAR AXLE — Wheel Hub	8	General Specifications	15
Removal	8	Coil Spring	15
Installation	9	Stabilizer Bar	15
REAR SUSPENSION	10	Strut.....	15
Removal and Installation	11	Inspection and Adjustment	15
REAR SUSPENSION — Coil Spring and Strut		Wheel Alignment	15
Assembly	12	Wheel Bearing	15
Disassembly	12		

PRECAUTIONS AND PREPARATION








Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- When removing each suspension part, check wheel alignment and adjust if necessary.
- Do not jack up at the parallel links.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.



Preparation

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST35490000 (J26083) Gland packing wrench	 <p>Removing and installing gland packing</p>
KV401021S0 (-) Bearing race drift	 <p>Installing wheel bearing outer race</p>
HT71780000 (-) Spring compressor	 <p>Removing and installing coil spring</p>
ST35652000 (-) Strut attachment	 <p>Fixing strut assembly</p>
GG94310000 (-) Flare nut wrench	 <p>Removing and installing brake piping</p>

PRECAUTIONS AND PREPARATION


Preparation (Cont'd) COMMERCIAL SERVICE TOOLS

Tool name	Description	
Flare nut crows foot		GI MA
Torque wrench		EM LC
		EF &
		EC
		FE
		CL
		MT
		AT
		FA
		RA
		BR
		ST
		BF
		HA
		EL


REAR AXLE AND REAR SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.





ARA008




Rear Axle and Rear Suspension Parts

Check axle and suspension parts for looseness, wear or damage.

- Shake each rear wheel to see excessive play.
- Retighten all nuts and bolts to the specified torque.
Tightening torque: Refer to RA-4.



- Check strut (shock absorber) for oil leakage or other damage.
- Check wheelarch height. Refer to FA section ("Front Axle and Front Suspension Parts", "ON-VEHICLE SERVICE").



Rear Wheel Bearing

- Check axial end play.
Axial end play:
0.05 mm (0.0020 in) or less
- Check that wheel bearings operate smoothly.
- Check tightening torque of wheel bearing lock nut.
Ⓜ: 186 - 255 N·m
(19 - 26 kg-m, 137 - 188 ft-lb)
- If there is any axial end play or wheel bearing does not turn smoothly, replace wheel bearing assembly. Refer to RA-8.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



Rear Wheel Alignment

PRELIMINARY INSPECTION


Make following checks. Adjust, repair or replace if necessary.

- Check tires for wear and for improper inflation.
- Check rear wheel bearings for looseness.
- Check wheel runout.

Wheel runout: Refer to FA section ("Inspection and Adjustment", "SDS").

- Check that rear strut (shock absorber) works properly.
- Check rear axle and rear suspension parts for looseness.
- Check vehicle posture (Unladen*).

*: Fuel, radiator and engine oil full. Spare tire, jack, hand tools and mats in designated positions.




CAMBER

Camber is preset at factory and cannot be adjusted.

Camber:


Refer to SDS, RA-15.

- If the camber is not within specification, inspect and replace any damaged or worn rear suspension parts.



TOE-IN


1. Draw a base line across the tread.
- After lowering rear of vehicle, move it up and down to eliminate friction.



2. Measure toe-in.
- Measure distance "A" and "B" at the same height as hub center.

Toe-in:


Refer to SDS, RA-15.



3. Adjust toe-in by varying the lengths of rear parallel links.

ON-VEHICLE SERVICE

Rear Wheel Alignment (Cont'd)



- Adjust left and right rear parallel links to the same length "A".
- Tighten lock nut while holding rear parallel link with wrench to prevent bushing from twisting.

Standard length "A":

50 - 55 mm (1.97 - 2.17 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

REAR AXLE — Wheel Hub




Removal

CAUTION:

Wheel hub bearing usually does not require maintenance. If any of the following symptoms are noted, replace wheel hub bearing assembly.

- Growling noise is emitted from wheel hub bearing during operation.
- Wheel hub bearing drags or turns roughly when hub is turned with your hand after bearing lock nut is tightened to specified torque.
- After wheel hub bearing is removed from knuckle spindle.




- 1) Remove brake caliper assembly.
- 2) Remove wheel bearing lock nut.

Brake hose does not need to be disconnected from brake caliper.


Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.

REAR AXLE — Wheel Hub



Installation

- Install wheel hub bearing.
- Tighten wheel bearing lock nut.
□: 186 - 255 N·m
(19 - 26 kg-m, 137 - 188 ft-lb)
- Check that wheel bearings operate smoothly.



- Check wheel bearing axial end play.
Axial end play:
0.05 mm (0.0020 in) or less

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

REAR SUSPENSION





- ① Lower spring rubber seat
- ② Coil spring
- ③ Bound bumper
- ④ Dust cover
- ⑤ Upper spring rubber seat
- ⑥ Upper spring seat

- ⑦ Strut mounting insulator
- ⑧ Spacer
- ⑨ Strut mounting collar
- ⑩ Strut damper
- ⑪ Strut assembly
- ⑫ Suspension member

- ⑬ Radius link
- ⑭ Front parallel link
- ⑮ Rear parallel link
- ⑯ Connecting rod
- ⑰ Bushing
- ⑱ Clamp
- ⑲ Stabilizer bar

REAR SUSPENSION



Removal and Installation

CAUTION:

Do not jack up at the parallel links or radius links.


- Disconnect brake hydraulic line and parking brake cable at equalizer. (Models with rear drum brake.)

- Remove suspension assembly.

- 1) Disconnect parking brake cable from caliper. (Models with rear disc brake.)
- 2) Remove brake caliper assembly. (Models with rear disc brake.)

Brake hose need not be disconnected from brake caliper. Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.

- 3) Remove parking brake cable fixing bolts. (Models with rear drum brake.)
- 4) Remove stabilizer fixing bolts and suspension member fixing bolts.
- 5) Remove rear seat. Refer to BF section ("Rear Seat", "SEAT").
- 6) Remove rear parcel shelf. Refer to BF section ("Interior", "INTERIOR AND EXTERIOR").



- 7) Remove strut securing nuts (Upper side). Then pull out strut assembly.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


REAR SUSPENSION — Coil Spring and Strut Assembly




Disassembly

1. Set strut assembly on vise with attachment, then loosen piston rod lock nut.


Do not remove piston rod lock nut.



2. Compress spring with Tool so that the strut mounting insulator can be turned by hand.



3. Remove piston rod lock nut.



4. Remove gland packing with Tool.

Avoid getting dirt and dust into gland packing portion.

5. Retract piston rod by pushing it down until it bottoms. Then, slowly withdraw piston rod from cylinder together with piston guide.

Inspection

STRUT ASSEMBLY

- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage occurring on welded or gland packing portions.
- Check piston rod for cracks, deformation or other damage. Replace if necessary.

REAR SUSPENSION — Coil Spring and Strut Assembly

Inspection (Cont'd)

UPPER RUBBER SEAT AND BUSHING

Check rubber parts for deterioration or cracks.
Replace if necessary.

GI

STRUT MOUNTING INSULATOR

- Check cemented rubber-to-metal portion for melting or cracks.
- Check rubber parts for deterioration.

MA

EM

COIL SPRING

Check for cracks, deformation or other damage.
Replace if necessary.

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF


HA

EL




Assembly

1. Locate upper spring seat as shown.



2. After placing coil spring in position on lower spring seat, release spring compressor gradually.



REAR SUSPENSION — Parallel Link, Radius Link and Stabilizer Bar



Removal and Installation


PARALLEL LINK AND RADIUS LINK

- Remove parallel link and radius link.
- **Models without ABS** —
- When installing front parallel link, make sure that paint mark faces in the correct direction.
- During installation, final tightening must be carried out at curb weight with tires on the ground.
- After installation, check wheel alignment. Refer to RA-6.
- **Check parallel link for cracks, deformation or other damage. Replace if necessary.**
- **Check radius link for cracks, deformation or other damage. Replace if necessary.**




STABILIZER BAR

- Remove stabilizer bar.
- When installing stabilizer, refer to paint marks to mount it even.



- Install stabilizer bar with ball joint socket properly placed.



SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COIL SPRING

Applied model		XE	SE
Wire diameter	mm (in)	11.9 (0.469)	12.2 (0.480)
Coil diameter	mm (in)	141.8 (5.58)	142.4 (5.61)
Free length	mm (in)	315 (12.40)	303.5 (11.95)
Spring constant	N/mm (kg/mm, lb/in)	19.6 (2.0, 112)	21.6 (2.2, 123)
Identification color		Yellow x 2	Yellow x 1, Pink x 1

STABILIZER BAR

Applied model		XE	SE
Diameter	mm (in)	15 (0.59)	16 (0.63)

STRUT

Applied model		SE	XE
Piston rod diameter	mm (in)	22 (0.87)	
Damping force [at 0.3 m (1.0 ft)/sec.]	N (kg, lb)		
Expansion		765 - 1,040 (78 - 106, 172 - 234)	608 - 824 (62 - 84, 137 - 185)
Compression		363 - 539 (37 - 55, 82 - 121)	265 - 402 (27 - 41, 60 - 90)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*)

Applied model		All
Camber	degree	- 2°00' to - 0°30'
Toe-in		
A - B	mm (in)	1 - 3 (0.04 - 0.12)
Total angle 2θ	degree	6' - 18'

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

WHEEL BEARING

Applied model		All
Wheel bearing axial end play	mm (in)	0.05 (0.0020) or less
Wheel bearing lock nut tightening torque	N•m (kg-m, ft-lb)	186 - 255 (19 - 26, 137 - 188)

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

BRAKE SYSTEM

SECTION BR

CONTENTS

PRECAUTIONS AND PREPARATION	2	Output Rod Length Check	15
Precautions.....	2	Installation	15
Supplemental Restraint System “Air Bag”.....	2	VACUUM HOSE	16
Brake System	2	Removal and Installation	16
Preparation	2	Inspection	16
Special Service Tools.....	2	Hoses And Connectors	16
CHECK AND ADJUSTMENT	4	Check Valve.....	16
Checking Brake Fluid Level.....	4	FRONT DISC BRAKE	17
Checking Brake Line.....	4	Pad Replacement	17
Changing Brake Fluid	4	Removal	18
AIR BLEEDING	5	Disassembly	19
Bleeding Procedure	5	Inspection — Caliper	19
BRAKE HYDRAULIC LINE	6	Cylinder Body	19
Removal	6	Piston	19
Inspection	6	Slide Pin, Pin Bolt And Pin Boot.....	19
Installation	6	Inspection — Rotor	19
CONTROL VALVE	7	Runout.....	19
Proportioning Valve.....	7	Thickness.....	20
Inspection.....	7	Assembly	20
Removal (Separated type)	7	Installation	20
Installation (Separated type)	8	REAR DRUM BRAKE	21
Removal And Installation (Built-in type).....	8	Removal	21
BRAKE PEDAL AND BRACKET	9	Inspection — Wheel Cylinder	23
Removal and Installation	9	Wheel Cylinder Overhaul.....	23
Inspection	9	Inspection — Drum	23
Adjustment.....	9	Inspection — Lining	24
MASTER CYLINDER	11	Installation	24
Removal	11	REAR DISC BRAKE	26
Disassembly	11	Pad Replacement	26
Inspection	12	Removal	28
Assembly	12	Disassembly	28
Installation	13	Inspection — Caliper	29
BRAKE BOOSTER	14	Cylinder Body	29
On-vehicle Service	14	Piston	29
Operating Check.....	14	Slide Pin, Pin Bolt And Pin Boot.....	29
Airtight Check	14	Inspection — Rotor	30
Removal	14	Runout.....	30
Inspection	15	Thickness.....	30

CONTENTS (Cont'd.)

Assembly	30	Ground Circuit Check	46	GI
Installation	32	Control Module Ground	46	
PARKING BRAKE CONTROL	33	Relay Box Ground	46	MA
Removal and Installation	33	Circuit Diagram for Quick Pinpoint Check	47	
Inspection	33	Diagnostic Procedure 1 (Not self-diagnostic item)	48	EM
Adjustment	34	Diagnostic Procedure 2 (Not Self-diagnostic Item)	49	
ANTI-LOCK BRAKE SYSTEM	35	Diagnostic Procedure 3	50	LC
Purpose	35	Actuator Solenoid (Malfunction code No. 45, 41 or 55)	50	EF & EC
Operation	35	Diagnostic Procedure 4	51	
System Description	36	Wheel Sensor Or Rotor	51	FE
Sensor	36	Diagnostic Procedure 5	53	
Control Module	36	Motor Relay Or Motor	53	CL
Removal and Installation	37	Diagnostic Procedure 6	55	
Front Wheel Sensor	37	Solenoid Valve Relay	55	MT
Rear Wheel Sensor	37	Diagnostic Procedure 7	56	
Control Module	38	Power Supply (Low voltage)	56	AT
Actuator	38	Diagnostic Procedure 8	56	
Actuator Relays	38	Stop Lamp Switch Circuit	56	FA
Wiring Diagram	39	Diagnostic Procedure 9	56	
TROUBLE DIAGNOSES	40	Control Module	56	RA
How to Perform Trouble Diagnoses for Quick and Accurate Repair	40	Electrical Components Inspection	57	
Introduction	40	Wheel Sensor	57	BR
Self-diagnosis	41	Motor Relay	57	
Function	41	Solenoid Valve Relay	57	ST
Self-Diagnosis Procedure	41	SERVICE DATA AND SPECIFICATIONS (SDS)	58	
How To Read Self-Diagnostic Results (Malfunction codes)	42	General Specifications	58	BF
How To Erase Self-Diagnostic Results (Malfunction codes)	43	Inspection and Adjustment	58	HA
Malfunction Code Chart	43	Disc Brake	58	
Component Parts and Harness Connector Location	44	Drum Brake	58	EL
Preliminary Check	45	Brake Pedal	58	
		Parking Brake	58	

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

PRECAUTIONS AND PREPARATION

Precautions

SUPPLEMENTAL RESTRAINT SYSTEM "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".

BRAKE SYSTEM



- Use brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean or wash all parts of master cylinder, disc brake caliper and wheel cylinder, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of hydraulic system.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.

WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder draffs caused by friction.



Preparation

SPECIAL SERVICE TOOLS


Tool number (Kent-Moore No.) Tool name	Description
GG94310000 (-) Flare nut wrench	 Removing and installing each brake piping
KV991V0010 (-) Brake fluid pressure gauge	 Measuring brake fluid pressure

PRECAUTIONS AND PREPARATION

Preparation (Cont'd) COMMERCIAL SERVICE TOOLS

Tool name	Description	GI
Flare nut crows foot		MA
Torque wrench		EM
		LC
		EF &
		EC
		FE
		CL
		MT
		AT
		FA
		RA
		BR
		ST
		BF
		HA
		EL

CHECK AND ADJUSTMENT



Checking Brake Fluid Level


- Check fluid level in reservoir tank. It should be between Max. and Min. lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.
- When brake warning lamp comes on even when parking brake lever is released, check brake system for leaks.

Checking Brake Line

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

1. Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.



Changing Brake Fluid



CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Connect a vinyl tube to each air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Refill until new brake fluid comes out of each air bleeder valve.

Use same procedure as in bleeding hydraulic system to refill brake fluid. Refer to BR-5.

AIR BLEEDING



Bleeding Procedure

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Fill reservoir with new brake fluid "DOT 3". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.

1. Connect a transparent vinyl tube to air bleeder valve.
2. Fully depress brake pedal several times.
3. With brake pedal depressed, open air bleeder valve to release air.
4. Close air bleeder valve.
5. Release brake pedal slowly.
6. Repeat steps 2. through 5. until clear brake fluid comes out of air bleeder valve.

- Bleed air in the following order.

Right rear brake
↓
Left front brake
↓
Left rear brake
↓
Right front brake

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA

EL

BRAKE HYDRAULIC LINE



Removal

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- All hoses must be free from excessive bending, twisting and pulling.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Remove flare nut securing brake tube to hose, then withdraw lock spring.
4. Cover openings to prevent entrance of dirt whenever disconnecting hydraulic line.

Inspection

Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.

Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.

1. Tighten all flare nuts and connecting bolts.


Flare nut:

○ : 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)



Connecting bolt:

○ : 17 - 20 N·m (1.7 - 2.0 kg-m, 12 - 14 ft-lb)

2. Refill until new brake fluid comes out of each air bleeder valve.
3. Bleed air. Refer to BR-5.



CONTROL VALVE



Proportioning Valve

INSPECTION

CAUTION:

- Carefully monitor brake fluid level at master cylinder.
- Use new brake fluid "DOT 3".
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on paint areas, wash it away with water immediately.
- Depress pedal slowly when raising front brake pressure.
- Check rear brake pressure 2 seconds after front brake pressure reaches specified value.
- For models with ABS, disconnect harness connectors from ABS actuator relay before checking.



1. Connect Tool to air bleeders of front and rear brakes on either LH and RH side.
2. Bleed air from the Tool.
3. Check rear brake pressure by depressing brake pedal (increasing front brake pressure).

Unit: kPa (kg/cm², psi)

	Without ABS	With ABS
Applied pressure (Front brake) D ₁	5,394 (55, 782)	5,884 (60, 853)
Output pressure (Rear brake) D ₂	2,452 - 2,844 (25 - 29, 356 - 412)	3,334 - 3,727 (34 - 38, 483 - 540)

If output pressure is out of specifications, replace dual proportioning valve (separated type) or master cylinder assembly (built-in type).

4. Bleed air after disconnecting the Tool. Refer to BR-5.



REMOVAL (Separated type)

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Loosen flare nut.
4. Remove proportioning valve mounting bolt, then remove flare nut.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTROL VALVE


Proportioning Valve (Cont'd)

INSTALLATION (Separated type)

CAUTION:

- **Refill with new brake fluid "DOT 3".**
 - **Never reuse drained brake fluid.**
1. Temporarily fit flare nut to proportioning valve.
 2. Tighten proportioning valve mounting bolt, then tighten flare nut.

Flare nut:

: **15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)**

3. Refill until new brake fluid comes out of each air bleeder valve.
4. Bleed air. Refer to BR-5.


REMOVAL AND INSTALLATION (Built-in type)

Always replace together with master cylinder as an assembly.


- Refer to BR-11.

BRAKE PEDAL AND BRACKET

Removal and Installation



GI
MA
EM
LC
EF &
EC
FE
CL
MT




Inspection

Check brake pedal for following items:

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion
- Crack or deformation of clevis pin stopper

AT
FA
RA



Adjustment

Check brake pedal free height from dash reinforcement panel.

- H: Free height**
Refer to SDS, BR-58.
- D: Depressed height**
Refer to SDS, BR-58.
Under force of 490 N (50 kg, 110 lb) with engine running
- C₁, C₂: Clearance between pedal stopper and threaded end of stop lamp switch and ASCD switch**
0.3 - 1.0 mm (0.012 - 0.039 in)
- A: Pedal free play**
1.0 - 3.0 mm (0.039 - 0.118 in)

BR
ST
BF
HA
EL


BRAKE PEDAL AND BRACKET

Adjustment (Cont'd)

If necessary, adjust brake pedal free height.

1. Loosen lock nut and adjust pedal free height by turning brake booster input rod. Tighten lock nut.

Make sure that tip of input rod stays inside of clevis.



2. Loosen lock nut and adjust clearance "C₁" and "C₂" with stop lamp switch and ASCD switch respectively. Then tighten lock nuts.


3. Check pedal free play.

Make sure that stop lamps go off when pedal is released.

4. Check brake pedal's depressed height while engine is running.

If depressed height is below specified value, check brake system for leaks, accumulation of air or any damage to components (master cylinder, etc.); then make necessary repairs.

MASTER CYLINDER



Removal



CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve, depressing brake pedal to empty fluid from master cylinder.
3. Remove brake pipe flare nuts.
4. Remove master cylinder mounting nuts.

Disassembly

1. Bend claws of stopper cap outward.



2. Remove valve stopper while piston is pushed into cylinder. (Models with ABS only)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


MASTER CYLINDER

Disassembly (Cont'd)

3. Remove piston assemblies.

If it is difficult to remove secondary piston assembly, tap flange with mallet or equivalent and pull out secondary piston.

4. Draw out reservoir tank.



Inspection




Check master cylinder inner wall for pin holes or scratches. Replace if damaged.

Assembly

1. Insert secondary piston assembly. Then insert primary piston assembly.

● Pay attention to direction of piston cups in figure at left. Also, insert pistons squarely to avoid scratches on cylinder bore.

● Pay attention to alignment of secondary piston slit with valve stopper mounting hole of cylinder body (For models with ABS only).



2. Install stopper cap.


Before installing stopper cap, ensure that claws are bent inward.

3. Push reservoir tank seals.

4. Push reservoir tank into master cylinder.

MASTER CYLINDER

Assembly (Cont'd)



5. Install valve stopper while piston is pushed into cylinder. (Models with ABS only)

Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Place master cylinder onto brake booster and secure mounting nuts lightly.
 2. Fit flare nuts to master cylinder.
 3. Tighten mounting nuts.
⚙️: 8 - 11 N•m (0.8 - 1.1 kg-m, 5.8 - 8.0 ft-lb)
 4. Tighten flare nuts.
⚙️: 15 - 18 N•m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)
 5. Bleed air. Refer to BR-5.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


BRAKE BOOSTER



On-vehicle Service

OPERATING CHECK


- Depress brake pedal several times with engine off, and check that there is no change in pedal stroke.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.



AIRTIGHT CHECK

- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. If pedal goes further down the first time and gradually rises after second or third time, booster is airtight.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. If there is no change in pedal stroke after holding pedal down **30 seconds**, brake booster is airtight.


Removal



CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- Be careful not to deform or bend brake pipes, during removal of booster.
- It is necessary to remove ABS actuator and actuator bracket first because space around booster is limited.

BRAKE BOOSTER




Inspection

OUTPUT ROD LENGTH CHECK

1. Apply vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg) to brake booster with a handy vacuum pump.
2. Check output rod length.

Specified length:

10.275 - 10.525 mm (0.4045 - 0.4144 in)



Installation

CAUTION:

- Be careful not to deform or bend brake pipes, during installation of booster.
- Replace clevis pin if damaged.
- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Take care not to damage brake booster mounting bolt thread when installing. Due to the acute angle of installation, the threads can be damaged on the metal surrounding the dash panel holes.

1. Before fitting booster, temporarily adjust clevis to dimension shown.
2. Fit booster, then secure mounting nuts (brake pedal bracket to brake booster) lightly.
3. Connect brake pedal and booster input rod with clevis pin.
4. Secure mounting nuts.
Torque: 13 - 16 N·m (1.3 - 1.6 kg·m, 9 - 12 ft·lb)
5. Install master cylinder. Refer to BR-13.
6. Bleed air. Refer to BR-5.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA

EL

VACUUM HOSE



Removal and Installation

CAUTION:


When installing vacuum hoses, pay attention to the following points.

- Do not apply any oil or lubricants to vacuum hose and check valve.
- Insert vacuum tube into vacuum hose as shown.
- Install check valve, paying attention to its direction.

Inspection

HOSES AND CONNECTORS

Check vacuum lines, connections and check valve for airtightness, improper attachment, chafing and deterioration.



CHECK VALVE

Check vacuum with a vacuum pump.

Connect to booster side	Vacuum should exist.
Connect to engine side	Vacuum should not exist.

FRONT DISC BRAKE

Pad Replacement

WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.

CAUTION:

- When cylinder body is open, do not depress brake pedal or piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST


BF

HA

EL



1. Remove master cylinder reservoir cap.
2. Remove lower pin bolt.



3. Open cylinder body upward. Then remove pad retainers and inner and outer shims.

Standard pad thickness:


11.0 mm (0.433 in)

Pad wear limit:

2.0 mm (0.079 in)

- Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.

FRONT DISC BRAKE




- | | | |
|-----------------------------|-------------------|-----------------|
| ① Main pin | ⑦ Inner pad | ⑬ Main pin bolt |
| ② Pin boot | ⑧ Pad retainer | ⑭ Bleed valve |
| ③ Torque member fixing bolt | ⑨ Outer pad | ⑮ Cylinder body |
| ④ Torque member | ⑩ Outer shim | ⑯ Piston seal |
| ⑤ Shim cover | ⑪ Connecting bolt | ⑰ Piston |
| ⑥ Inner shim | ⑫ Copper washer | ⑱ Piston boot |

Removal


WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.



Remove torque member fixing bolts and connecting bolt. It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

FRONT DISC BRAKE



Disassembly

WARNING:

Do not place your fingers in front of piston.

CAUTION:

Do not scratch or score cylinder wall.

1. Push out piston with dust seal with compressed air.
2. Remove piston seal with a suitable tool.

GI

MA

EM

LC

Inspection — Caliper

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign objects. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign objects may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

EF &

EC

FE

CL

CAUTION:

Use brake fluid to clean. Never use mineral oil.

PISTON

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign objects are stuck to sliding surface.

AT

Check piston for score, rust, wear, damage or presence of foreign objects. Replace if any of the above conditions are observed.


FA

SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks, rust or other damage. Replace if any of the above conditions are observed.

RA

BR



Inspection — Rotor

RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 × 1.25).
2. Check runout using a dial indicator.

ST

BF

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to section FA ("Front Wheel Bearing", "ON-VEHICLE SERVICE").

HA

Maximum runout:

0.07 mm (0.0028 in)

3. If the runout is out of specification, find minimum runout position as follows:
 - a. Remove nuts and rotor from wheel hub.
 - b. Shift the rotor one hole and secure rotor to wheel hub with nuts.
 - c. Measure runout.
 - d. Repeat steps a. to c. so that minimum runout position can be found.
4. If the runout is still out of specification, turn rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).

EL

FRONT DISC BRAKE

Inspection — Rotor (Cont'd)

THICKNESS


Thickness variation (At least 8 positions):

Maximum 0.01 mm (0.0004 in)


If thickness variation exceeds the specification, turn rotor with on-car brake lathe.

Rotor repair limit:

20.0 mm (0.787 in).



SBR831B



SBR574


Assembly

1. Insert piston seal into groove on cylinder body.
2. With piston boot fitted to piston, insert piston boot into groove on cylinder body and install piston.
3. Properly secure piston boot.

Installation


CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install caliper assembly.
 2. Install brake hose to caliper securely.
 3. Install all parts and secure all bolts.
 4. Bleed air. Refer to BR-5.



SBR980B

REAR DRUM BRAKE



ABR073

- | | | |
|---------------------------|-------------------|-------------------------|
| ① Wheel cylinder assembly | ⑦ Return spring | ⑬ Shoe hold-down spring |
| ② Boot | ⑧ Adjuster | ⑭ Operating lever |
| ③ Piston | ⑨ Shoe | ⑮ Washer |
| ④ Piston cup | ⑩ Adjuster lever | ⑯ Retainer ring |
| ⑤ Cylinder body | ⑪ Adjuster spring | ⑰ Shoe hold-down pin |
| ⑥ Spring | ⑫ Retainer | ⑱ Plug |


Removal

WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.

CAUTION:

Make sure parking brake lever is released completely.



ABR074

1. Release parking brake lever fully, then remove drum.

If drum is hard to remove, the following procedures should be carried out.



- a. Remove plug. Then push down stopper to back plate to make clearance between brake shoe and drum as shown.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


REAR DRUM BRAKE

Removal (Cont'd)


b. Tighten the two bolts gradually.



2. Push in shoe hold-down pins from behind the back plate. While pushing in the retainer, turn it and remove the shoe hold-down pins.
3. Pull out brake shoes in the direction of the arrows as illustrated.




4. Using pliers, remove the lower return spring from shoe.



5. Separate shoes, one at a time, from wheel cylinder, and remove them from back plate with the adjuster assembly still on as shown.

Be careful not to scratch or damage wheel cylinder boot.








6. Disconnect parking brake cable from toggle lever. **Be careful not to damage parking brake cable when separating it.**
7. Remove adjuster return spring and shoe return spring.

REAR DRUM BRAKE

Removal (Cont'd)

8. Remove retainer ring with a suitable tool. Then separate toggle lever and brake shoe.



Inspection – Wheel Cylinder

- Check wheel cylinder for leakage.
- Check for wear, damage and loose conditions. Replace if any such condition exists.

Wheel Cylinder Overhaul

Check all internal parts for wear, rust and damage. Replace if necessary. Pay attention so as not to scratch cylinder when installing pistons.

Inspection – Drum

Maximum inner diameter:

230 mm (9.06 in)

Out-of-roundness:

0.03 mm (0.0012 in) or less

- Contact surface should be fine finished with No. 120 to 150 emery paper.
- Using a drum lathe, lathe brake drum if it shows scoring, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

REAR DRUM BRAKE



Inspection — Lining


Check lining thickness.

Standard lining thickness:

4.1 mm (0.161 in)

Lining wear limit (A):


1.5 mm (0.059 in)




Installation

Always perform shoe clearance adjustment. Refer to BR-34.

1. Fit toggle lever to brake shoe with retainer ring.



2. Apply brake grease to the contact areas shown at left.




3. Shorten adjuster by rotating it.

● **Pay attention to direction of adjuster.**

Wheel	Screw	Depression
Left	Left-hand thread	Yes
Right	Right-hand thread	No


4. Apply brake grease to adjuster as shown.




5. Install adjuster and adjuster lever; then install upper return spring and adjuster spring as shown.

REAR DRUM BRAKE


Installation (Cont'd)



6. Connect parking brake cable to toggle lever.
Be careful not to damage brake cable.



7. Install shoes on wheel cylinder one at a time.
Do not allow the piston to spring away when assembling.
8. Install lower return spring.



9. Secure shoe installation with shoe hold-down pins and retainer.
10. Check to make sure all parts are installed properly.
Pay attention to direction of adjuster assembly.
11. Install brake drum.
12. When installing new wheel cylinder, bleed air. Refer to BR-5.
13. Adjust parking brake. Refer to BR-34.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

REAR DISC BRAKE


Pad Replacement

WARNING:


Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.

CAUTION:

- When cylinder body is open, do not depress brake pedal, or piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.
- Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.



1. Remove master cylinder reservoir cap.
2. Remove brake cable lock spring.
3. Disconnect cable.
4. Remove lower pin bolt.



5. Open cylinder body upward. Then remove pad retainers, and inner and outer shims.

Standard pad thickness:


10 mm (0.39 in)

Pad wear limit:

1.5 mm (0.059 in)


REAR DISC BRAKE

Pad Replacement (Cont'd)



6. When installing new pads, push piston into cylinder body by turning piston clockwise.

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.



- | | | |
|-----------------|-----------------|----------------|
| ① Spring | ⑫ Inner shim | ⑳ Spring |
| ② Toggle lever | ⑬ Pin bolt | ㉑ Spring cover |
| ③ Cam | ⑭ Copper washer | ㉒ Piston seal |
| ④ Cam boot | ⑮ Cable guide | ㉓ Spacer |
| ⑤ Torque member | ⑯ Cylinder | ㉔ Wave washer |
| ⑥ Pin boot | ⑰ Strut | ㉕ Bearing |
| ⑦ Side pin | ⑱ O-ring | ㉖ Adjuster nut |
| ⑧ Outer shim | ㉒ Push rod | ㉗ Piston cup |
| ⑨ Outer pad | ㉓ Key plate | ㉘ Piston |
| ⑩ Pad retainer | ㉔ Snap ring | ㉙ Piston boot |
| ⑪ Inner pad | ㉕ Spring seat | |


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

REAR DISC BRAKE

Removal


WARNING:

Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.




1. Remove brake cable mounting bracket bolt and lock spring.
2. Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.




Disassembly

1. Remove piston by turning it counterclockwise with suitable long nose pliers.



2. Pry off snap ring from piston with suitable pliers and remove adjusting nut.





3. Disassemble cylinder body.
 - a. Pry off snap ring with suitable pliers, then remove spring cover, spring and seat.
 - b. Pry off snap ring, then remove key plate, push rod and strut.

REAR DISC BRAKE

Disassembly (Cont'd)

c. Remove piston seal.

Be careful not to damage cylinder body.



4. Remove return spring and toggle lever.

Inspection — Caliper

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign objects. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign objects may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

CAUTION:

Use brake fluid to clean cylinder. Never use mineral oil.

PISTON

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign objects are stuck to sliding surface.

Check piston for score, rust, wear, damage or presence of foreign objects. Replace if any of the above conditions are observed.

SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks, rust or other damage. Replace if any of the above conditions are observed.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

REAR DISC BRAKE



Inspection — Rotor

RUNOUT


1. Secure rotor to wheel hub with two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to section RA (“Rear Wheel Bearing”, “ON-VEHICLE SERVICE”).

3. Change relative positions of rotor and wheel hub so that runout is minimized.

Maximum runout :

0.07 mm (0.0028 in)




THICKNESS

Rotor repair limit:

**Minimum thickness
8.0 mm (0.315 in)**


**Thickness variation (At least 8 portions)
Maximum 0.02 mm (0.0008 in)**

Replace rotor if any of the above do not meet the specifications.



Assembly


1. Insert cam with depression facing toward open end of cylinder.




2. Generously apply rubber grease to strut and push rod to make insertion easy.

REAR DISC BRAKE


Assembly (Cont'd)




3. Mate protrusion on key plate with depression in cylinder bottom.




4. Install snap ring with a suitable tool.



5. Install seat, spring, spring cover and snap ring with a suitable tool.



6. Install cup in the specified direction.



7. Install cup, adjuster, bearing, spacers, washers and snap ring with a suitable tool.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

REAR DISC BRAKE


Assembly (Cont'd)



8. Insert piston seal into groove on cylinder body.
9. With piston boot fitted to piston, insert piston boot into groove on cylinder body and fit piston by turning it clockwise with suitable long nose pliers.



10. Fit toggle lever and return spring.






Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install caliper assembly.
 2. Install brake hose to caliper securely.
 3. Install all parts and secure all bolts.
 4. Bleed air. Refer to BR-5.

PARKING BRAKE CONTROL



Removal and Installation


1. To remove parking brake cable, first remove center console.
2. Disconnect warning lamp connector.
3. Remove bolts, slacken off and remove adjusting nut.
4. Remove lock plate and disconnect cable (disc brake only).
For drum brake models, refer to BR-21.

Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Check warning lamp and switch. Replace if necessary.
4. Check parts at each connecting portion and, if deformed or damaged, replace.

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

PARKING BRAKE CONTROL




Adjustment


Before or after adjustment, pay attention to the following points.

- a. For rear disc brake be sure that toggle lever returns to stopper when parking brake lever is released.
- b. There is no drag when parking brake lever is released.

1. Adjust clearance between shoe and drum/pad and rotor as follows:
 - a. Release parking brake lever and loosen adjusting nut.
 - b. Depress brake pedal fully at least 10 times with engine running.



2. Pull control lever 4 - 5 notches. Then adjust control lever by turning adjusting nut.



3. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.

Number of notches:

Drum brake 7 - 8

Disc brake 7 - 8

4. Bend parking brake warning lamp switchplate so that brake warning lamp comes on when parking brake lever is pulled "A" notches.

Number of "A" notches: 1 or less

ANTI-LOCK BRAKE SYSTEM

Purpose

- Excessive braking in any condition (dry or wet) will adversely affect the normal turning of the vehicle's wheels and they may lock up.
- When the front wheels are locked, a vehicle cannot be controlled by the steering system.
- When the rear wheels are locked, the vehicle will enter a flat spin.

GI

MA

The ABS, by the use of electronic and hydraulic components, allows for control of braking force so that locking of the wheels can be avoided in the circumstances described above.

The ABS:

EM

- 1) Ensures proper tracking performance through steering wheel operation.
- 2) Enables obstacles to be avoided through steering wheel operation.
- 3) Ensures vehicle stability by preventing flat spins.

LC

Operation

- When the vehicle speed is less than 10 km/h (6 MPH) this system does not work.
- The Anti-Lock Brake System (ABS) has self-test capabilities. The system turns on the anti-lock warning light each time the engine is started. After the engine is started and the anti-lock warning light turns off, the system performs another test the first time the vehicle reaches 6 km/h (4 MPH). A mechanical noise may be heard as the ABS performs a self-test. This is a normal part of the self-test feature. If a malfunction is found during this check, the anti-lock warning light will come on.
- During ABS operation, a mechanical noise may be heard. This is a normal condition.

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

ANTI-LOCK BRAKE SYSTEM

System Components



ABR077



ABR078


System Description

SENSOR

The sensor unit consists of a gear-shaped rotor and a sensor element which contains a bar magnet around which a coil is wound. The sensor is installed on the back side of the brake rotor. Sine-wave current is generated by the sensor as the wheel rotates. The frequency and voltage increase(s) as the rotating speed increases.

CONTROL MODULE

The control module computes the rotating speed of the wheel by the signal current sent from the sensor, and supplies a DC current of about 5 amperes, about 2 amperes, or 0 amperes to the actuator solenoid valve provided for each wheel by changing its internal resistance. It also controls ON-OFF operation of the valve relay and pump relay. If any electrically detectable malfunction should occur in the system, the control module causes the warning lamp to light up. In this condition, the ABS will be deactivated by the control module, and the vehicle's braking system reverts to normal operation.



SBR146C


ANTI-LOCK BRAKE SYSTEM

Removal and Installation


CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth.

FRONT WHEEL SENSOR



REAR WHEEL SENSOR



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

ANTI-LOCK BRAKE SYSTEM


Removal and Installation (Cont'd)

CONTROL MODULE

Location: Driver side dash side lower.



ACTUATOR




CAUTION:

After installation, pay attention to the following points.

- Refill brake fluid and bleed air. Refer to BR-4 and BR-5, respectively.

1. Remove actuator relay assembly.
2. Drain brake fluid. Remove master cylinder.
3. Remove actuator.



ACTUATOR RELAYS

Large: MOTOR RELAY


Small: SOLENOID VALVE RELAY

1. Disconnect battery cable.
2. Remove actuator relay cover.



It is not necessary to remove the two screws for relay box.

ANTI-LOCK BRAKE SYSTEM

Wiring Diagram



MBR044A



How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION


The ABS system has an electronic control module to control major functions. The control module accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as air leaks in the booster or lines, lack of brake fluid, or other problems with brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a ABS complaint. The customer is a very good source of information on such problems; especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.




Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS controlled vehicle.




Self-diagnosis

FUNCTION

- When a problem occurs in the ABS, the warning lamp on the instrument panel comes on. The warning lamp is also lit by grounding the self-diagnostic (check) terminal located on the "Data Link Connector for Consult" to actuate the self-diagnostic results mode. The location of the malfunction is indicated by the warning lamp flashing on the instrument panel.



SELF-DIAGNOSIS PROCEDURE



NOTE 1: The indication terminates after five minutes. However, when the ignition switch is turned from "OFF" to "ON", the indication starts flashing again.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

Ⓐ


Check warning lamp for deactivation after driving vehicle over 30 km/h (20 MPH) for at least one minute.

After making certain that warning lamp does not come on, test the ABS in a safe area to verify that it functions properly.

HOW TO READ SELF-DIAGNOSTIC RESULTS (Malfunction codes)

- Determine the code No. by counting the number of times the warning lamp flashes on and off.
- When several malfunctions occur at one time, up to three code Nos. can be stored; the latest malfunction will be indicated first.
- The indication begins with the start code 12, after which a maximum of three code Nos. appear in the order of the latest one first. The indication then returns to the start code to repeat (the indication will stay on for five minutes at the most).
- The malfunction code chart is given on the next page.

Example: Code No. 32 REAR RIGHT SENSOR SHORT-CIRCUIT



TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

HOW TO ERASE SELF-DIAGNOSTIC RESULTS (Malfunction codes)

- Under the self-diagnostic results mode, the malfunction memory erase mode starts when the check terminal is disconnected from the ground.
- The self-diagnostic results (malfunction codes) can be erased by grounding the check terminal more than three times in succession within 12.5 seconds after the erase mode starts. (Each grounding must be longer than one second.)
The ABS warning lamp stays on while the self-diagnosis is in the erase mode, and goes out after the erase operation has been completed.

The self-diagnosis is also completed at the same time.

After the erase operation is completed, it is necessary to rerun the self-diagnostic mode to verify that malfunction codes no longer appear. Only the start code should be indicated when erase operation is completed and system is functioning normally.









MALFUNCTION CODE CHART




Code No.	Malfunctioning part	Diagnostic procedure
45	Front left actuator solenoid	3
41	Front right actuator solenoid	3
55	Rear actuator solenoid	3
25	Front left sensor (open-circuit)	4
26	Front left sensor (short-circuit)	4
21	Front right sensor (open-circuit)	4
22	Front right sensor (short-circuit)	4
35	Rear left sensor (open-circuit)	4
36	Rear left sensor (short-circuit)	4
31	Rear right sensor (open-circuit)	4
32	Rear right sensor (short-circuit)	4
18	Sensor rotor	4
61	Actuator motor or motor relay	5
63	Solenoid valve relay	6
57	Power supply (Low voltage)	7
16	Stop lamp switch circuit	8
71	Control module	9
Warning lamp stays on, does not blink.	Solenoid valve relay stuck or control module power supply circuit	2
Warning lamp does not come on.	Warning lamp bulb	1

TROUBLE DIAGNOSES


Component Parts and Harness Connector Location



TROUBLE DIAGNOSES



Preliminary Check



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


TROUBLE DIAGNOSES



Ground Circuit Check

CONTROL MODULE GROUND

- Check resistance between the terminals and ground.
Resistance: 0 Ω




RELAY BOX GROUND

- Check resistance between relay box harness connector terminal ⑤ and ground.
Resistance: 0 Ω

TROUBLE DIAGNOSES

Circuit Diagram for Quick Pinpoint Check

- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown on BR-44.
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES

Diagnostic Procedure 1 (Not self-diagnostic item)

Warning lamp does not work before engine starts.



TROUBLE DIAGNOSES



Diagnostic Procedure 2 (Not Self-diagnostic Item)

Warning lamp does not blink but stays on continuously.

A

CONTROL MODULE POWER SUPPLY CIRCUIT

- Disconnect connector from control module.
- Check voltage between control module connector terminal ① and ground after turning ignition switch "ON".
Battery positive voltage should exist.

N.G. → Repair harness and connector.

O.K.

GROUND-SHORT CHECK FOR WARNING LAMP CIRCUIT

- Turn ignition switch "OFF". Disconnect actuator connector.
- Check whether warning lamp goes on after turning ignition switch "ON".
Warning lamp should not go on.
- Turn ignition switch "OFF".

N.G. → Repair harness and connector.

O.K.

ACTUATOR SOLENOID VALVE RELAY CHECK

Refer to BR-57.

N.G. → Replace solenoid valve relay.

O.K.

- Erase self-diagnostic results.
- Carry out self-diagnosis. Refer to BR-41.
- Inspect the system according to the code No.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR




ST

BF

HA

EL

TROUBLE DIAGNOSES



Diagnostic Procedure 3

ACTUATOR SOLENOID (Malfunction code No. 45, 41 or 55)

A

ACTUATOR SOLENOID VALVE CHECK.

O.K. Replace control module.

- Disconnect control module connector.
- Check resistance between control module connector terminals.

Code No. 45

Terminals ③② and ②

Code No. 41

Terminals ③② and ③⑤

Code No. 55

Terminals ③② and ①⑧

Resistance: 1.07 - 1.17Ω

N.G.

B

- Disconnect relay box connectors.
- Check resistance between relay box connector terminals.

O.K. Repair harness between relay box connector and control module connector.

Code No. 45

Terminals ①② and ①

Code No. 41

Terminals ①② and ②

Code No. 55

Terminals ①② and ③

Resistance: 1.07 - 1.17Ω

N.G.

C

- Disconnect actuator connector.
- Check resistance between actuator connector terminals.

O.K. Replace relay box assembly.

Code No. 45

Terminals ①⑦ and ①④

Code No. 41

Terminals ①⑤ and ①⑥


Code No. 55

Terminals ①③ and ①⑧

Resistance: 1.07 - 1.17Ω

N.G.

Replace actuator.



Diagnostic Procedure 4 WHEEL SENSOR OR ROTOR (Malfunction code No. 21, 22, 25, 26, 31, 32, 35, 36 or 18)

A

O.K. → **A**

WHEEL SENSOR ELECTRICAL CHECK

- Disconnect control module connector.
- Check resistance between control module connector terminals.

Code No. 21 or 22 (Front RH wheel)
Terminals ②① and ②③

Code No. 25 or 26 (Front LH wheel)
Terminals ④ and ⑤

Code No. 31 or 32 (Rear RH wheel)
Terminals ②⑥ and ②④

Code No. 35 or 36 (Rear LH wheel)
Terminals ⑧ and ⑨

Resistance: 1.0 - 1.25kΩ

N.G.

Note

CHECK WHEEL SENSOR
Refer to BR-57.

Note

N.G. → **Replace wheel sensor.**

O.K.

Note




Repair harness and connectors between control module connector and wheel sensor connector.





Note: Wheel position should be distinguished by code No.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


TROUBLE DIAGNOSES

Diagnostic Procedure 4 (Cont'd)





Diagnostic Procedure 5 MOTOR RELAY OR MOTOR (Malfunction code No. 61)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)



A

E

RELAY BOX CHECK

Check continuity between relay terminals and relay box connector terminals.

Relay terminals	Connector terminals
①	⑩
②	⑨
③	⑦
④	⑰
④	⑧





Continuity should exist.

O.K.

N.G. → Replace relay box.

→ Replace control module.

TROUBLE DIAGNOSES



Diagnostic Procedure 6 SOLENOID VALVE RELAY (Malfunction code No. 63)

A SOLENOID VALVE POWER SUPPLY CHECK

N.G. → Repair harness and connector.

- Disconnect connectors from actuator and relay box.
- Check voltage between terminal ⑥ and ground.

Battery positive voltage should exist.

O.K. ↓

SOLENOID VALVE RELAY CHECK

Refer to BR-57.

N.G. → Replace solenoid valve relay.

O.K. ↓

B RELAY BOX CHECK

Check continuity between relay terminals and relay box connector terminals.

Relay terminals	Connector terminals
③①	⑫
⑧⑤	⑪
⑧⑥	⑩
⑧⑦	⑥
⑧⑦a	⑤

Continuity should exist.

N.G. → Replace relay box.

O.K. ↓

C CIRCUIT CHECK

N.G. → Repair harness and connectors.

- Disconnect control module connector.
- Check continuity between control module connector terminals and relay box connector terminals.

Control module	Relay box
⑮	⑩
⑳	⑪
㉓	⑫

Continuity should exist.

O.K. ↓

D Check continuity between relay box connector terminals ⑩, ⑪, ⑫ and ground.

N.G. → Repair harness and connectors.

Continuity should not exist.

O.K. ↓

Replace control module.

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES


Diagnostic Procedure 7

POWER SUPPLY (Low voltage) (Malfunction code No. 57)

BATTERY CHECK
Check battery.


Diagnostic Procedure 8

STOP LAMP SWITCH CIRCUIT (Malfunction code No. 16)




Diagnostic Procedure 9

CONTROL MODULE (Malfunction code No. 71)




TROUBLE DIAGNOSES



Electrical Components Inspection


WHEEL SENSOR

Check resistance between terminals (a) and (b).
Resistance: 1.0 - 1.25kΩ



MOTOR RELAY

Condition	Continuity existence between terminals (3) and (4)
Battery positive voltage not applied between terminals (1) and (2).	No
Battery positive voltage applied between terminals (1) and (2).	Yes



SOLENOID VALVE RELAY

Condition	Continuity existence between terminals (30) and (87a)	Continuity existence between terminals (30) and (87)
Battery positive voltage not applied between terminals (85) and (86).	Yes	No
Battery positive voltage applied between terminals (85) and (86).	No	Yes

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Model	Without ABS	With ABS
Front brake		
Brake model	CL25VB	
Cylinder bore diameter mm (in)	57.2 (2.252)	
Pad mm (in)		
Length x width x thickness	125.6 x 45.3 x 11.0 (4.94 x 1.783 x 0.433)	
Rotor outer diameter x thickness mm (in)	280 x 22 (11.02 x 0.87)	
Rear brake		
Brake model	LT23E	CL9HA
Cylinder bore diameter mm (in)	19.05 (3/4)	33.96 (1.3370)
Lining or pad mm (in)		
Length x width x thickness	219.4 x 35 x 4.1 (8.64 x 1.38 x 0.161)	89.1 x 39.5 x 10 (3.508 x 1.555 x 0.39)
Drum inner diameter or rotor outer diameter x thickness mm (in)	228.6 (9)	258 x 9 (10.16 x 0.35)

Model	Without ABS	With ABS
Master cylinder		
Cylinder bore diameter mm (in)	23.81 (15/16)	25.40 (1)
Control valve		
Valve model	Dual proportioning valve (built-in type)	Dual proportioning valve (separated type)
Split point kPa (kg/cm ² , psi) x reducing ratio	1,961 (20, 284) x 0.2	2,942 (30, 427) x 0.2
Brake booster		
Booster model	M195T	M215T
Diaphragm diameter mm (in)	Primary: 205 (8.07) Secondary: 180 (7.09)	Primary: 230 (9.06) Secondary: 205 (8.07)
Recommended brake fluid	DOT 3	

Inspection and Adjustment

DISC BRAKE

Brake model	CL25VB	CL9HA
Pad wear limit mm (in)		
Minimum thickness	2.0 (0.079)	1.5 (0.059)
Rotor repair limit mm (in)		
Minimum thickness	20.0 (0.787)	8.0 (0.315)

DRUM BRAKE

Brake model	LT23E
Lining wear limit mm (in)	
Minimum thickness	1.5 (0.059)
Drum repair limit mm (in)	
Maximum inner diameter	230 (9.06)
Out-of-roundness	0.03 (0.0012)

BRAKE PEDAL

Free height "H" mm (in)	
M/T	169 - 179 (6.65 - 7.05)
A/T	177 - 187 (6.97 - 7.36)
Depressed height "D" mm (in)	
[under force of 490 N (50 kg, 110 lb) with engine running]	90 (3.54)
Clearance between switches and pedal stopper bracket "C" mm (in)	0.3 - 1.0 (0.012 - 0.039)
Pedal free play "A" mm (in)	1.0 - 3.0 (0.039 - 0.118)

PARKING BRAKE

	Disc brake	Drum brake
Number of notches [under force of 196 N (20 kg, 44 lb)]	7 - 8	7 - 8
Number of notches when warning lamp switch comes on	1	

STEERING SYSTEM

SECTION **ST**

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS

PRECAUTIONS AND PREPARATION	2	Steering Column.....	10
Precautions.....	2	Disassembly and Assembly.....	11
Supplemental Restraint System "Air Bag".....	2	Tilt mechanism.....	12
Steering System.....	2	Inspection.....	12
Preparation.....	3	POWER STEERING GEAR AND LINKAGE	13
Special Service Tools.....	3	Removal and Installation.....	13
Commercial Service Tools.....	4	Disassembly.....	16
ON-VEHICLE SERVICE	5	Inspection.....	17
Checking Steering Wheel Play.....	5	Boot.....	17
Checking Neutral Position on Steering Wheel.....	5	Rack.....	17
Pre-checking.....	5	Pinion Assembly.....	17
Checking.....	5	Gear Housing Cylinder.....	17
Front Wheel Turning Angle.....	5	Tie-Rod Outer And Inner Socket.....	18
Checking Gear Housing Movement.....	5	Assembly.....	18
Checking and Adjusting Drive Belts.....	6	Adjustment.....	22
Checking Fluid Level.....	6	POWER STEERING OIL PUMP	24
Checking Fluid Leakage.....	6	Disassembly and Assembly.....	24
Bleeding Hydraulic System.....	6	Pre-disassembly Inspection.....	24
Checking Steering Wheel Turning Force.....	7	Disassembly.....	25
Checking Hydraulic System.....	8	Inspection.....	25
STEERING WHEEL AND STEERING COLUMN	9	Pulley And Pulley Shaft.....	25
Removal (With air bag).....	9	Assembly.....	26
Steering Wheel.....	9	SERVICE DATA AND SPECIFICATIONS (SDS)	27
Steering Column.....	9	General Specifications.....	27
Removal (Without air bag).....	10	Inspection and Adjustment.....	27
Steering Wheel.....	10	General.....	27
— Three spoke type —.....	10	Steering Column.....	27
Installation.....	10	Steering Gear And Linkage.....	27
Steering Wheel.....	10	Power Steering.....	28



Precautions

SUPPLEMENTAL RESTRAINT SYSTEM "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".








STEERING SYSTEM

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- When disassembling parts, be sure to place them in order on a part rack so they can be reinstalled in their proper positions.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended ATF* to hydraulic parts. Vaseline may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

*: Automatic transmission fluid

PRECAUTIONS AND PREPARATION




Preparation SPECIAL SERVICE TOOLS


Tool number (Kent-Moore No.) Tool name	Description	GI
KV48100700 (J26364) Torque adapter		MA EM
KV48102500 (-) Pressure gauge adapter		LC EF & EC
ST27180001 (J25726-A) Steering wheel puller		FE CL
HT72520000 (J25730-A) Ball joint remover		MT AT
ST27091000 (J26357) Pressure gauge		FA RA
KV48104400 (-) Rack seal ring reformer		BR ST BF HA
ST3127S000 (See J25765-A) ①GG91030000 (J25765-A) Torque wrench ②HT62940000 (-) Socket adapter ③HT62900000 (-) Socket adapter		EL

PRECAUTIONS AND PREPARATION

Preparation (Cont'd)

COMMERCIAL SERVICE TOOLS

Tool name	Description
Rear oil seal drift	 <p>28 mm (1.10 in) dia.</p> <p>Installing rear oil seal</p>
Pinion oil seal drift	 <p>40 mm (1.57 in) dia.</p> <p>Installing pinion oil seal</p>
Oil pump attachment	 <p>Unit: mm (in)</p> <p>Disassembling and assembling oil pump</p>



Checking Steering Wheel Play

1. With wheels in a straight-ahead position, check steering wheel play.

Steering wheel play:
35 mm (1.38 in) or less


2. If it is not within specification, check steering gear assembly when front suspension and axle, steering gear assembly and steering column are mounted correctly.

GI

MA

EM

LC



Checking Neutral Position on Steering Wheel

Pre-checking

- Make sure that wheel alignment is correct.

Wheel alignment:

Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").

- Verify that the steering gear is centered before removing the steering wheel.

EF &
EC

FE

CL

Checking


1. Check that the steering wheel is in the neutral position when driving straight ahead.
2. If it is not in the neutral position, remove the steering wheel and reinstall it correctly.
3. If the neutral position is between two serrated teeth, loosen tie-rod lock nut and move tie-rod in the opposite direction by the same amount on both left and right sides to compensate for error in the neutral position.

MT

AT

FA

RA



Front Wheel Turning Angle

1. Rotate steering wheel all the way right and left; measure turning angle.

Turning angle of full turns:

Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").

2. If it is not within specification, check rack stroke.

Rack stroke "L":

Refer to ST-28.


BR

ST

BF

HA

EL



Checking Gear Housing Movement

1. Check the movement of steering gear housing during stationary steering on a dry paved surface.

- Apply a force of 49 N (5 kg, 11 lb) to steering wheel to check the gear housing movement.

Turn off ignition key while checking.


Movement of gear housing:

± 2 mm (± 0.08 in) or less

2. If movement exceeds the limit, replace mount insulator after confirming proper installation of gear housing clamps.

Checking and Adjusting Drive Belts

Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").




Checking Fluid Level

Check fluid level.

Fluid level should be checked using "HOT" range on dipstick at fluid temperatures of 50 to 80°C (122 to 176°F) or using "COLD" range on dipstick at fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Automatic Transmission Fluid type "DEXRON II™" or equivalent.



Checking Fluid Leakage

Check the lines for improper attachment and for leaks, cracks, damage, loose connections, chafing or deterioration.

1. Run engine between idle speed and 1,000 rpm.

Make sure temperature of fluid in oil tank rises to 60 to 80°C (140 to 176°F).

2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each "lock" position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

4. If fluid leakage at connectors is noticed, loosen flare nut and then retighten.

Do not overtighten connector as this can damage O-ring, washer and connector.

Bleeding Hydraulic System



1. Raise front end of vehicle until wheels are clear of the ground.
2. Add fluid into oil tank to specified level. Meanwhile quickly turn steering wheel fully to right and left and lightly touch steering stoppers.
Repeat steering wheel operation until fluid level no longer decreases.
3. Start engine.
Repeat step 2 above.

ON-VEHICLE SERVICE

Bleeding Hydraulic System (Cont'd)

- Incomplete air bleeding will cause the following to occur. When this happens, bleed air again.
 - a. Generation of air bubbles in reservoir tank
 - b. Generation of clicking noise in oil pump
 - c. Excessive buzzing in oil pump

While the vehicle is stationary or while moving the steering wheel slowly, fluid noise may occur in the valve or oil pump. This noise is inherent in this steering system, and it will not affect performance or durability of the system.



Checking Steering Wheel Turning Force

1. Park vehicle on a level, dry surface and set parking brake.
2. Start engine.
3. Bring power steering fluid up to adequate operating temperature. [Make sure temperature of fluid is approximately 60 to 80°C (140 to 176°F).]

Tires need to be inflated to normal pressure.

4. Check steering wheel turning force when steering wheel has been turned 360° from neutral position.

Steering wheel turning force:

39 N (4 kg, 9 lb) or less

5. If steering wheel turning force is out of specifications, check rack sliding force to detect condition of steering gear assembly.
 - a. Disconnect steering column lower joint and knuckle arms from the gear.
 - b. Start and run engine at idle to make sure steering fluid has reached normal operating temperature.
 - c. While pulling tie-rod slowly from the neutral position, make sure rack sliding force is within specification.

Rack sliding force:

118 - 235 N (12 - 24 kg, 26 - 53 lb)

6. If rack sliding force is not within specification, replace steering gear assembly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL



Checking Hydraulic System

Before starting, check belt tension, driving pulley and tire pressure.

1. Set Tool. Open shut-off valve. Then bleed air. Refer to ST-6.
2. Run engine.

Make sure temperature of fluid in tank rises to 60 to 80°C (140 to 176°F).

WARNING:

Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, oil pressure in oil pump will increase to relief pressure, resulting in an abnormal rise in oil temperature.

3. Check pressure with steering wheel fully turned to left and right positions with engine idling at 1,000 rpm.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

Oil pump maximum standard pressure:

7,649 - 8,238 kPa (78 - 84 kg/cm², 1,109 - 1,194 psi)


4. If oil pressure is below the standard pressure, slowly close shut-off valve and check pressure.
 - When pressure reaches standard pressure, gear is damaged.
 - When pressure remains below standard pressure, pump is damaged.

CAUTION:


Do not close shut-off valve for more than 15 seconds.

5. If oil pressure is higher than standard pressure, check oil pump flow control valve.
6. After checking hydraulic system, remove Tool and add fluid as necessary, then completely bleed air out of system. Refer to ST-6.

STEERING WHEEL AND STEERING COLUMN




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Removal (With air bag)

STEERING WHEEL

Remove air bag module and spiral cable. Refer to BF section ("Removal — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM").




STEERING COLUMN

CAUTION:

The rotation of the spiral cable (SRS "Airbag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.

STEERING WHEEL AND STEERING COLUMN





Removal (Without air bag)

STEERING WHEEL

- Three spoke type —
- Four spoke type —


1. Insert a crosshead screwdriver into hole on lower side of spoke and remove clamps. Lift horn pad off by hand.
2. Remove steering wheel with Tool.



Installation

STEERING WHEEL

When installing steering wheel, apply multi-purpose grease to entire surface of turn signal cancel pin (both portions) and also to horn contact slip ring.



STEERING COLUMN


- When installing steering column, fingertighten all lower bracket and clamp retaining bolts; then tighten them securely. Do not apply undue stress to steering column.
- When attaching coupling joint, be sure tightening bolt faces cutout portion.

CAUTION:


After installing steering column, turn steering wheel to make sure it moves smoothly and that the number of turns from the straight forward position to left and right locks are equal. Be sure that the steering wheel is in a neutral position when driving straight ahead.

STEERING WHEEL AND STEERING COLUMN

Disassembly and Assembly



- When disassembling and assembling, unlock steering lock with key.
- Ensure that rounded surface of snap ring faces toward bearing when snap ring is installed.




- Install snap ring on upper shaft with a suitable tool.


GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

STEERING WHEEL AND STEERING COLUMN


Disassembly and Assembly (Cont'd)



- Steering lock
- a. Break self-shear type screws with a drill or other appropriate tool.




- b. Install self-shear type screws and then cut off self-shear type screw heads.



Tilt mechanism

- After installing steering column, check tilt mechanism operation.



Inspection


- When steering wheel can not be rotated smoothly, check the steering column for the following matters and replace damaged parts.
 - a. Check column bearings for damage or unevenness. Lubricate with recommended multi-purpose grease or replace steering column as an assembly, if necessary.
 - b. Check jacket tube for deformation or breakage. Replace if necessary.
- When the vehicle is involved in a light collision, check column length "L". If it is not within specifications, replace steering column as an assembly.

Column length "L":


525.6 - 528.4 mm (20.69 - 20.80 in)

POWER STEERING GEAR AND LINKAGE

Removal and Installation




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



- Detach tie-rod outer sockets from knuckle arms with Tool.

POWER STEERING GEAR AND LINKAGE

Removal and Installation (Cont'd)



- Install pipe connector.
- Observe specified tightening torque when tightening high-pressure and low-pressure pipe connectors. Excessive tightening can damage threads or connector O-ring.
- The O-ring in low-pressure pipe connector is larger than that in high-pressure connector. Take care to install the proper O-ring.


Connector tightening torque:

Low-pressure side "1"

27 - 39 N·m (2.8 - 4.0 kg-m, 20 - 29 ft-lb)

High-pressure side "2"


15 - 25 N·m (1.5 - 2.5 kg-m, 11 - 18 ft-lb)




- Initially, tighten nut on tie-rod outer socket and knuckle arm to 29 to 39 N·m (3 to 4 kg-m, 22 to 29 ft-lb). Then tighten further to align nut groove with first pin hole so that cotter pin can be installed.

CAUTION:

Tightening torque must not exceed 49 N·m (5 kg-m, 36 ft-lb).




- Before removing lower joint from gear, set gear in neutral (wheels in straight-ahead position). After removing lower joint, put matching mark on pinion shaft and pinion housing to record neutral position of gear.
- To install, set left and right dust boots to equal deflection, and attach lower joint by aligning matching marks of pinion shaft and pinion housing.




- Tighten gear housing mounting bracket bolts in the order shown.

POWER STEERING GEAR AND LINKAGE




GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
ST
 BF
 HA
 EL

POWER STEERING GEAR AND LINKAGE




Disassembly


1. Prior to disassembling, measure pinion rotating torque. Record the pinion rotating torque as a reference.
 - Before measuring, disconnect gear housing tube and drain fluid.
 - Use soft jaws when holding steering gear housing. Handle gear housing carefully, as it is made of aluminum. Do not grip cylinder in a vise.
2. Remove pinion gear.
Be careful not to damage pinion gear when removing pinion seal ring.



3. Remove tie-rod outer sockets and boots.
4. Loosen tie-rod inner socket by prying up staked portion, and remove socket.
5. Remove retainer.
6. Remove pinion assembly.




7. Drill staked portion of gear housing end with drill of 2 to 2.5 mm (0.079 to 0.098 in) diameter, until the staking is eliminated.




8. Remove end cover assembly with Tool.
9. Draw out rack assembly.

POWER STEERING GEAR AND LINKAGE

Disassembly (Cont'd)



10. Remove rack seal ring.
 - Using a heat gun, heat rack seal to approximately 40°C (104°F).
 - Remove rack seal ring.**Be careful not to damage rack.**



11. Remove center bushing and rack oil seal using tape wrapped socket and extension bar.
Do not scratch inner surfaces of pinion housing.

Inspection

Thoroughly clean all parts in cleaning solvent or automatic transmission fluid type "DEXRON II™", and blow dry with compressed air, if available.

BOOT

Check condition of boot. If cracked excessively, replace it.

RACK

Thoroughly examine rack gear. If damaged, cracked or worn, replace it.

PINION ASSEMBLY

- Thoroughly examine pinion gear. If pinion gear is damaged, cracked or worn, replace it.
- Inspect bearings to see that they roll freely and are free from cracked, pitted, or worn balls, rollers and races. Replace if necessary.

GEAR HOUSING CYLINDER

Check gear housing cylinder bore for scratches or other damage. Replace if necessary.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

POWER STEERING GEAR AND LINKAGE

Inspection (Cont'd)

TIE-ROD OUTER AND INNER SOCKET

- Check ball joint for swinging force.

Tie-rod outer ball joint:


6.9 - 64.7 N

(0.7 - 6.6 kg, 1.5 - 14.6 lb)

Tie-rod inner ball joint:

15.7 - 140.2 N

(1.6 - 14.3 kg, 3.5 - 31.5 lb)




- Check ball joint for rotating torque.

Tie-rod outer ball joint:

0.3 - 2.9 N·m

(3 - 30 kg-cm, 2.6 - 26.0 in-lb)



- Check ball joint for axial end play.


Tie-rod outer ball joint:

0.1 mm (0.004 in) or less

Tie-rod inner ball joint:


0.3 mm (0.012 in) or less

- Check condition of dust cover. If cracked excessively, replace it.




Assembly

1. Using a heat gun, heat new rack seal ring (made of Teflon) to approximately 40°C (104°F) and install it onto rack with your hand.




2. Using Tool, compress periphery of rack seal ring to position and secure it on rack.

Always insert Tool from the rack gear side.




POWER STEERING GEAR AND LINKAGE


Assembly (Cont'd)




3. Insert new rack oil seal.
 - Place plastic film into rack oil seal to prevent damage by rack teeth.
 - Do not forget to remove plastic film after rack oil seal is positioned properly.
 - Make sure lips of rack oil seal face each other.




4. Install center bushing and rack oil seal with rack assembly.



5. Tighten end cover assembly with a suitable tool.



6. Fasten end cover assembly to gear housing by staking.



7. Set rack gear in neutral position.
Rack stroke "L":
Refer to SDS, ST-28.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




8. Coat seal lip of new pinion oil seal with multi-purpose grease and install it to pinion housing of gear housing with a suitable tool.


Make sure lip of oil seal faces up when installed.




9. Install pinion bearing adjusting shim(s).
- Whenever pinion assembly, gear housing and rear housing are disassembled, replace shim(s) with new ones. Always use the same number of shim(s) when replacing.



10. Install new pinion seal ring (made of Teflon) on pinion gear assembly.
- Using a heat gun, heat pinion seal ring to approximately 40°C (104°F) before installing it onto pinion gear assembly.
 - Make sure pinion seal ring is properly settled in valve groove.




11. Apply a coat of multi-purpose grease to needle bearing roller and oil seal lip before installing pinion assembly in gear housing.




12. Install pinion assembly to pinion housing.
Be careful not to damage pinion oil seal.

POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)




13. Apply a coat of multi-purpose grease to new rear oil seal lip before installing rear housing.



14. Install rear cover cap so that protrusion of rear housing cover is positioned as shown in figure at left.

Be careful not to damage worm ring and oil seal.


15. Install retainer spring and adjusting screw temporarily.



16. Install new lock plate.
- Attach lock plate ② to side rod inner socket ①.
 - Apply locking sealant to inner socket threads ③.
 - Screw inner socket into rack ④ and tighten to specified torque.
 - Clinch two places of lock plate at rack's groove.

CAUTION:


To prevent scratching the boot, remove burrs from lock plate.



17. Tighten outer socket lock nut.

Tie-rod length "L":

Refer to SDS, ST-27.



18. Measure rack stroke.

Rack stroke "L":

Refer to SDS, ST-28.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

POWER STEERING GEAR AND LINKAGE

Assembly (Cont'd)


19. Before installing boot, coat the contact surfaces between boot and tie-rod with grease.




Adjustment

Adjust pinion rotating torque as follows:


1. Set rack to the neutral position without fluid in the gear.
2. Coat the adjusting screw with locking sealant and screw it in.
3. Lightly tighten lock nut.
4. Tighten adjusting screw to a torque of 14.7 N·m (150 kg-cm, 130 in-lb).



5. Move rack over its entire stroke several times.
6. Loosen adjusting screw by 30°.



7. Prevent adjusting screw from turning, and tighten lock nut to specified torque.



8. Measure pinion rotating torque.

Lock to lock:

Average rotating torque

0.8 - 1.3 N·m (8 - 13 kg-cm, 6.9 - 11.3 in-lb)

Within ±100° from the neutral position:


Maximum torque variation

0.4 N·m (4 kg-cm, 3.5 in-lb)

Outside the above range:

Maximum force variation

0.6 N·m (6 kg-cm, 5.2 in-lb)



POWER STEERING GEAR AND LINKAGE

Adjustment (Cont'd)


- If pinion rotating torque is not within specifications, readjust it starting from procedure 4. If pinion rotating torque is still out of specifications after readjustment, replace steering gear assembly.

GI

MA

EM

LC



SST090B

9. Check rack sliding force on vehicle as follows:
 - a. Install steering gear onto vehicle, but do not connect tie-rod to knuckle arm.
 - b. Connect all piping and fill with steering fluid.
 - c. Start engine and bleed air completely.
 - d. Disconnect steering column lower joint from the gear.
 - e. Keep engine at idle and make sure steering fluid has reached normal operating temperature.
 - f. While pulling tie-rod slowly from the neutral position, make sure rack sliding force is within specification.

EF &

EC

FE

CL

Rack sliding force:

118 - 235 N (12 - 24 kg, 26 - 53 lb)

- If rack sliding force is not within specification, readjust by repeating adjustment procedure from the beginning.
- If rack sliding force is still out of specification after readjustment, gear assembly needs to be replaced.

MT

AT

FA

RA

BR

ST



BF

HA

EL

POWER STEERING OIL PUMP

Disassembly and Assembly



Pre-disassembly Inspection

Disassemble the power steering oil pump only if the following items are found.


- Oil leak from any point shown in the figure.
- Deformed or damaged pulley.
- Poor performance.

POWER STEERING OIL PUMP


Disassembly

CAUTION:


- Parts which can be disassembled are strictly limited. Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- Follow the procedures and cautions in the Service Manual.
- When disassembling and reassembling, do not let foreign matter enter or contact the parts.



- Remove snap ring, then draw drive shaft out.
Be careful not to drop drive shaft.



- Remove oil seal.
Be careful not to damage front housing.



- Remove connector.
Be careful not to drop control valve.

Inspection

PULLEY AND PULLEY SHAFT

- If pulley is cracked or deformed, replace it.
- If an oil leak is found around pulley shaft oil seal, replace the seal.
- If serration of pulley or pulley shaft is deformed or worn, replace it.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


POWER STEERING OIL PUMP




Assembly

Assemble oil pump, noting the following instructions.


- Before installation, coat the O-rings and oil seal with ATF*
 - Make sure O-rings and oil seal are properly installed. When assembling vanes to rotor, rounded surfaces of vanes must face cam ring side.
 - Always install new O-rings and oil seal.
 - Be careful of oil seal direction.
- *: Automatic Transmission Fluid



- Pay attention to the direction of rotor.



- Install vanes properly.



- Insert pin ② into pin groove ① of front housing and front side plate. Then install cam ring ③ as shown at left.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Applied model	All
Steering model	Power steering
Steering gear type	PR26K
Steering overall gear ratio	17.2
Turns of steering wheel (Lock to lock)	2.83
Steering column type	Collapsible, tilt

GI
MA
EM
LC


Inspection and Adjustment

GENERAL

Steering wheel axial play mm (in)	0 (0)
Steering wheel play mm (in)	35 (1.38) or less
Movement of gear housing mm (in)	± 2 (± 0.08) or less

STEERING COLUMN

Steering column length "L" mm (in)	525.6 - 528.4 (20.69 - 20.80)
---------------------------------------	-------------------------------




SST125B

STEERING GEAR AND LINKAGE

Steering gear type		PR26SC
Tie-rod outer ball joint	Swinging force at cotter pin hole	6.9 - 64.7 (0.7 - 6.6, 1.5 - 14.6)
	Rotating torque N·m (kg-cm, in-lb)	0.3 - 2.9 (3 - 30, 2.6 - 26.0)
Axial end play	mm (in)	0.1 (0.004) or less
Tie-rod inner ball joint	Swinging force*	15.7 - 140.2 (1.6 - 14.3, 3.5 - 31.5)
	Axial end play	mm (in)
Tie-rod standard length "L"	mm (in)	158.2 (6.23)

*: Measuring point



SST371B


EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

STEERING GEAR AND LINKAGE (Cont'd)

Steering gear type	PR26K
Rack stroke "L"	66 (2.60)
mm (in)	



SST086B

Pinion gear preload without gear fluid N•m (kg-cm, in-lb)	
Lock to lock	
Average rotating torque	0.78 - 1.27 (8.0 - 13.0, 6.9 - 11.3)
Within $\pm 100^\circ$ from the neutral position	
Maximum torque variation	0.4 (4, 3.5)
Outside the above range	
Maximum torque variation	0.6 (6, 5.2)

POWER STEERING

Rack sliding force	N (kg, lb)	
Under normal operating oil pressure		118 - 235 (12 - 24, 26 - 53)
Retainer adjustment		
Adjusting screw		
Initial tightening torque	N•m (kg-cm, in-lb)	14.7 (150, 130)
Returning angle	degree	30°
Steering wheel turning force (Measured at one full turn from the neutral position)	N (kg, lb)	39 (4, 9) or less
Fluid capacity (Approximate)	ℓ (US qt, Imp qt)	0.9 (1, 3/4)
Oil pump maximum pressure	kPa (kg/cm ² , psi)	7,649 - 8,238 (78 - 84, 1,109 - 1,194)

SECTION BF

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS

GENERAL SERVICING	2	INSTRUMENT PANEL	23
Precautions.....	2	Removal — Instrument panel assembly	23
Supplemental Restraint System “AIR BAG”.....	2	Head-Up Display (Hud)	24
Circuit Breaker Inspection.....	2	INTERIOR AND EXTERIOR	26
Clip and Fastener.....	3	Interior.....	26
BODY END	5	Side And Floor Trim	26
Body Front End.....	5	Removal — Body side trim	26
Removal — Front bumper assembly.....	5	Door Trim Removal — Door trim.....	27
Body Rear End and Opener.....	7	Room Trim.....	28
Removal — Rear bumper assembly	7	Removal — Headlining	28
DOOR	9	Luggage Room Trim	29
Front Door	9	Exterior	30
Rear Door.....	10	① Front hood insulator	31
Power Window and Power Door Lock.....	11	② Cowl top grille and cowl top front	
Door Lock Timer.....	11	sealing rubber	31
Wiring Diagram.....	12	③ Front windshield molding	31
DOOR — Trouble Diagnoses for Power Window	14	Windshield upper and side molding	32
Symptom Chart	14	④ Sunroof lid weatherstrip	32
Main Power Supply and Ground Circuit Check.....	15	⑤ Body side drip weatherstrip	32
Procedure 1	15	⑥ Door weatherstrip	33
Main power supply.....	15	⑦ Body side welt	33
Ground circuit.....	15	⑧ Door waist outside molding.....	33
Procedure 2	15	⑨ Front door corner cover	34
Power supply for power window amp.		⑩ Rear windshield molding	34
(front and rear passengers).....	15	⑪ Trunk lid weatherstrip.....	34
Ground circuit for power window amp.		⑫ Rear combination lamp	35
(front and rear passengers).....	15	⑬ Side guard molding	35
Procedure 3	15	⑭ Center mudguard	36
Power supply for ignition signal.....	15	⑮ Front door parting seal.....	36
Component Layout.....	16	SEAT	37
Circuit Diagram for Quick Pinpoint Check	17	Front Seat.....	37
Diagnostic Procedure 1	18	Rear Seat	38
Diagnostic Procedure 2	19	2-POINT MOTORIZED AUTOMATIC SEAT BELT	
Diagnostic Procedure 3	20	SYSTEM	40
Diagnostic Procedure 4	21	Unit Location	40
Electrical Components Inspection	22	Wiring Diagram	42
Power Window Motor	22	Description.....	44
Power Window Switch.....	22	Function	44

CONTENTS (Cont'd.)

Timer (Ignition switch either "On" or "Off").....	44	WINDSHIELD AND WINDOWS	73
Quick Warning (Ignition switch "On").....	44	Windshield.....	73
Rear Lock (Fail safe operation).....	44	Removal.....	73
Shoulder Belt Locking Cancellor—elr		Installation.....	73
Solenoid (Ignition switch "On" or "Off").....	44	Repairing Water Leaks For Windshield.....	73
Warning Codes (Shoulder belt system).....	45	MIRROR — Door mirror	74
Warning Code (Seat adjustment).....	46	Door Mirror.....	74
2-POINT MOTORIZED AUTOMATIC SEAT BELT		Removal.....	74
SYSTEM — Trouble Diagnoses	47	Door Mirror/Wiring Diagram.....	75
Symptom Chart.....	47	REAR AIR SPOILER	76
Preliminary Check.....	48	Rear Air Spoiler.....	76
Procedure 1.....	48	BODY ALIGNMENT	77
Procedure 2.....	50	Engine Compartment.....	77
Main Power Supply and Ground Circuit Check.....	52	Measurement.....	77
Procedure 1.....	52	Measurement Points.....	78
Main power supply.....	52	Underbody.....	79
Ground circuit.....	52	Measurement.....	79
Procedure 2.....	52	Measurement Points.....	80
Power supply for motor drive.....	52	SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	81
Ground circuit for motor drive.....	52	Precautions for SRS "Air Bag" Service.....	81
Circuit Diagram for Quick Pinpoint Check.....	53	Preparation.....	81
Diagnostic Procedure 1.....	54	Special Service Tool.....	81
Diagnostic Procedure 2.....	56	Commercial Service Tools.....	81
Diagnostic Procedure 3.....	57	Description.....	82
Diagnostic Procedure 4.....	58	Self-diagnosis.....	82
Diagnostic Procedure 5.....	60	SRS Component Parts Location and Caution	
Diagnostic Procedure 6.....	61	Labels.....	83
Diagnostic Procedure 7.....	63	Caution Labels.....	84
Diagnostic Procedure 8.....	64	Maintenance Items.....	86
Diagnostic Procedure 9.....	65	Removal and Installation — Control Module	
Diagnostic Procedure 10.....	66	and Sensors.....	87
Electrical Components Inspection.....	67	Removal — Air Bag Module and Spiral Cable.....	88
Front Limit Switch.....	67	Installation — Air Bag Module and Spiral Cable....	89
Rear Limit Switch.....	67	Scrapping the Air Bag.....	91
Shoulder Belt Buckle Switch.....	67	Connecting To Battery.....	91
Door Latch Switch		Deployment Tool Check.....	91
(Built-into door lock assembly).....	67	Connecting To Air Bag.....	91
Drive Motor Assembly.....	67	Deployment.....	91
Lap Belt Buckle Switch		TROUBLE DIAGNOSES — Supplemental	
(Built-into lap belt buckle for LH side).....	68	Restraint System (SRS)	92
Seat Slide Switch		Schematic.....	92
(Seat slide inside rail).....	68	Wiring Diagram.....	93
SUNROOF	69	Self-diagnosis.....	94
Removal — Sunroof lid assembly.....	70	Using CONSULT.....	94
Removal — Shade assembly.....	70	Self-diagnosis results.....	95
Removal — Sunroof assembly.....	70	Using The Warning Lamp.....	96
Removal — Link & wire assembly.....	70	How to alternate self-diagnosis.....	96
Adjustment.....	71	Warning lamp flashing times and repair.....	98
Wiring Diagram.....	72	Diagnostic Procedure 1.....	99

CONTENTS (Cont'd.)

Diagnostic Procedure 2	99	Collision Diagnosis	101
Diagnostic Procedure 3	100		

GI

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

MA

EM

LC

- ★ For conventional seat belt, refer to MA section ("Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters", "CHASSIS AND BODY MAINTENANCE").

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

Precautions


- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installation. Be careful not to soil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.













Circuit breakers are used in the following systems.

- Power window & power door lock
- Automatic seat belt
- Power sun roof

GENERAL SERVICING

Clip and Fastener
























- Clips and fasteners in BF section correspond to the following numbers and symbols.
- Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
<p>C101</p> 	 <p style="text-align: right;">SBF256G</p>	<p>Removal: Remove by bending up with flat-bladed screwdrivers.</p>  <p style="text-align: right;">SBF367B</p>
<p>C102</p> 	 <p style="text-align: center;">SBF114B</p> <p style="text-align: center;">SBF137B</p> <p style="text-align: right;">SBF137B</p>	 <p>Removal: Pull up by rotating.</p> <p style="text-align: right;">SBF115B</p>
<p>C103</p> 	 <p style="text-align: right;">SBF257G</p>	<p>Removal: Remove with a flat-bladed screwdriver or pliers.</p>  <p style="text-align: right;">SBF292C</p>
<p>C203</p> 	 <p style="text-align: right;">SBF258G</p>	<p>Push center pin to catching position. (Do not remove center pin by hitting it.)</p>  <p>Installation:</p> <p style="text-align: right;">SBF708E</p>

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
BF
 HA
 EL

GENERAL SERVICING

Clip and Fastener (Cont'd)

Symbol No.	Shapes	Removal & Installation				
<p>CE103</p> 	 <p style="text-align: right;">SBF104B</p>	<p>Removal:</p>  <p style="text-align: right;">SBF147B</p>				
<p>CF118</p> 	 <p style="text-align: right;">SBF151D</p>	<p>Removal:</p>  <p style="text-align: right;">SBF259G</p>				
<p>CG101</p> 	 <p style="text-align: right;">SBF145B</p>	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>Removal</p>  <p>Rotate 45° to remove.</p> </td> <td style="width: 50%; vertical-align: top;"> <p>Installation</p>  </td> </tr> <tr> <td style="text-align: center;">  <p>Removal</p> </td> <td style="text-align: right;"> <p>SBF085B</p> </td> </tr> </table>	<p>Removal</p>  <p>Rotate 45° to remove.</p>	<p>Installation</p> 	 <p>Removal</p>	<p>SBF085B</p>
<p>Removal</p>  <p>Rotate 45° to remove.</p>	<p>Installation</p> 					
 <p>Removal</p>	<p>SBF085B</p>					
<p>CR103</p> 	 <p style="text-align: right;">SBF768B</p>	<p>Removal: Holder portion of clip must be spread out to remove rod.</p>  <p style="text-align: right;">SBF770B</p>				
<p>CS101</p> 	 <p style="text-align: right;">SBF260G</p>	<p>Removal: Screw out with a Phillips screwdriver.</p> <p>Remove female portion with flat-bladed screwdriver.</p>  <p style="text-align: right;">ASBF140B</p>				

BODY END

Body Front End

- Bumper fascia: It is made of plastic, so do not use excessive force and take care to keep oil away from it.
- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood locks engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so increases effort required to unlock hood.

REMOVAL — Front bumper assembly

- ① Remove screws and clips (C203) securing left and right fender protectors to bumper fascia.
- ② Remove screws securing left and right engine undercovers to bumper fascia.
- ③ Remove nuts securing left and right front fenders to bumper fascia.
- ④ Remove screws and clips (C203) securing bumper fascia to bumper reinforcement.
- ⑤ Extract bumper fascia.
- ⑥ Remove two bolts securing bumper reinforcement.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

BODY END


Body Front End (Cont'd)

Hood lock adjustment

- Adjust hood so that hood primary lock meshes at a position 1 to 1.5 mm (0.039 to 0.059 in) lower than fender.
- After hood lock adjustment, adjust bumper rubber.
- When securing hood lock, ensure it does not tilt. Striker must be positioned at the center of hood primary lock.
- After adjustment, ensure that hood primary and secondary lock operate properly.




Hood lock secondary latch hooking length

More than 5.0 mm (0.197 in)



Bumper rubber adjustment

- Adjust so that hood is aligned with fender. At that time deflection is approx. 2 mm (0.08 in).
[Bumper rubber free height is approx. 13 mm (0.51 in)]




Body Rear End and Opener

- Trunk lid adjustment: Adjust at hinge-trunk lid portion for proper trunk lid fit.
- Trunk lid lock system adjustment: Adjust striker so that it is in the center of the lock. After adjustment, check trunk lid lock operation.
- Opener cable: Do not attempt to bend cable using excessive force.
- After installing/adjusting opener, make sure that trunk lid and fuel filler lid open.







REMOVAL — Rear bumper assembly

- ① Remove luggage room trim. Refer to BF-29.
- ② Remove the two bolts from inside of trunk room.
- ③ Working inside trunk, remove nuts securing left and right rear fenders to bumper fascia.
- ④ Working inside trunk, remove left and right plugs from floor, then remove the four bolts.
- ⑤ Extract bumper assembly.



BODY END

Body Rear End and Opener (Cont'd)




Trunk lid and fuel filler lid opener installation

Installation (Refer to figure below)

- ① Temporarily route cable and secure fuel lock to vehicle body.
- ② Lightly pull stopper A (at cable end) in direction (A) to eliminate clearance b between stopper B and casing end.
- ③ Secure bracket A to vehicle body so that clearance a between stopper A and trunk striker is 0 mm (0 in). (At this point, do not pull striker lever.)
- ④ Attach stopper C to handle. While lightly pushing cable in direction (B) shown by arrow (do not allow any clearance c at fuel lock casing end to occur), secure handle to vehicle body.



Ensure that clearances a and b are eliminated after installation.



DOOR

Front Door


- When removing door, be sure not to scratch vehicle body.
- After adjusting door or door lock, check door lock operation.




Bell crank adjustment

Lock door after setting door lock assembly and inside handle in position.


Move bell crank in direction of arrow (shown in figure at left) to take up knob free play, and secure with bolts.




Hinge-body adjustment



Striker adjustment



Door adjustment




: N·m (kg·m, ft·lb)


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

DOOR


Rear Door



Hinge-body adjustment



Striker adjustment




: N·m (kg·m, ft·lb)

DOOR

Power Window and Power Door Lock

DOOR LOCK TIMER

- Carry out the inspections below.
 - Power source and ground: Battery voltage should exist between terminals ① and ⑤.
 - Input signals: Continuity should exist between terminals ④, ⑩, and ground in "ON" condition, and should not exist in "OFF" condition.
 - Output signals: Voltage shown in the chart should exist.



ABF167


- Carry out the complete inspection in the chart from left to right.

Connections		Operations			
		Main switch/door lock switch RH			
		N	Unlock	Lock	
1	Power source	12V	12V	12V	
5	Ground	Ground	Ground	Ground	
4	Input signal	Main switch/door lock switch RH (Input signal for lock)	OFF	OFF	ON
10		Main switch/door lock switch RH (Input signal for unlock)	OFF	ON	OFF
2	Output signal	Door lock actuator (Lock power source) VOLTMETER 1	0V	0V	12V (Approx. 1.0 sec.) → 0V
3		Door lock actuator (Unlock power source) VOLTMETER 2	0V	12V (Approx. 1.0 sec.) → 0V	0V

DOOR


Power Window and Power Door Lock (Cont'd)

WIRING DIAGRAM



DOOR

Power Window and Power Door Lock (Cont'd)



MBF627A

GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
BF
 HA
 EL

DOOR — Trouble Diagnoses for Power Window


Since left and right component parts are basically the same, harness layout and methods for electrical components inspection are shown for one side only.

Although methods for checking component parts on both sides are described in the flow chart, making it easier to troubleshoot, apply checking procedures to either side that have malfunction during trouble diagnoses.

Symptom Chart

Procedure	Main Power Supply and Ground Circuit Check			Diagnostic Procedure				Electrical Components Inspection		Remarks
	BF-15	BF-15	BF-15	BF-18	BF-19	BF-20	BF-21	BF-22	BF-22	
Reference Page	BF-15	BF-15	BF-15	BF-18	BF-19	BF-20	BF-21	BF-22	BF-22	—
	Procedure 1	Procedure 2	Procedure 3	Procedure 1	Procedure 2	Procedure 3	Procedure 4	Power window motor(s)	Power window switch(es)	—
SYMPTOM										
None of the power windows can be operated.	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Driver side power window cannot be operated but other windows can be operated.				<input type="radio"/>				<input type="radio"/>		
Passenger power windows cannot be operated.		<input type="radio"/>			<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	
Passenger power windows cannot be operated by main switch but can be operated by passenger's switches.	<input type="radio"/>						<input type="radio"/>			

DOOR – Trouble Diagnoses for Power Window




Main Power Supply and Ground Circuit Check

PROCEDURE 1


Main power supply

Terminals	Battery positive voltage existence
④ - Ground	Yes



Ground circuit


Terminals	Continuity
③ - Ground	Yes



PROCEDURE 2


Power supply for power window amp. (front and rear passengers)

Terminals	Battery positive voltage existence
④① - Ground	Yes



Ground circuit for power window amp. (front and rear passengers)

Terminals	Continuity
④② - Ground	Yes



PROCEDURE 3

Power supply for ignition signal

Terminals	Ignition switch	Battery positive voltage existence
①⑧ - Ground	ON	Yes

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


DOOR — Trouble Diagnoses for Power Window

Component Layout






ABF173

Circuit Diagram for Quick Pinpoint Check



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


DOOR – Trouble Diagnoses for Power Window






Diagnostic Procedure 1

SYMPTOM:

Driver side power window cannot be operated but other power windows can be operated.




DOOR – Trouble Diagnoses for Power Window



Diagnostic Procedure 2

SYMPTOM:

Passenger power windows cannot be operated by main switch and passenger switch.



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA





EL

DOOR – Trouble Diagnoses for Power Window

Diagnostic Procedure 3

SYMPTOM:

Passenger power windows cannot be operated but driver side power window can be operated.



START

A

CHECK POWER WINDOW LOCK SIGNAL CIRCUIT.


- 1) Disconnect connector from power window amp.
- 2) Check battery positive voltage between terminal (44) for each connector and ground while ignition switch is "ON".

Terminals	Power window lock switch	Battery positive voltage exists
(44) - Ground	ON	No
	OFF	Yes




D

Check continuity.

Terminals	Passenger switches	Continuity
(47) - (49)	Up	Yes
	Down	No
(48) - (49)	Up	No
	Down	Yes




DOOR – Trouble Diagnoses for Power Window



Diagnostic Procedure 4

SYMPTOM:

Passenger power windows cannot be operated by main switch but can be operated by passenger's switches.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

DOOR – Trouble Diagnoses for Power Window


Electrical Components Inspection

POWER WINDOW MOTOR



Terminals		Operation
⊕	⊖	
41	42	Downward
42	41	Upward

POWER WINDOW SWITCH



Terminals	Condition	Continuity
① - ②	UP	Yes
	Down	No
② - ③	UP	No
	Down	Yes

INSTRUMENT PANEL

CAUTION:

- a. Disconnect ground terminal from battery in advance.
- b. Disconnect air bag system line in advance.
- c. Be careful not to scratch pad and other parts.

REMOVAL — Instrument panel assembly

- ① Remove steering wheel.
- ② Remove steering column cover.
- ③ Remove A/T finisher or shift lever boot.
- ④ Remove lower instrument cover on driver's side.
- ⑤ Remove cluster lid C.
- ⑥ Remove radio and deck pocket.
- ⑦ Remove glove box.
- ⑧ Remove cluster lid A.
- ⑨ Remove instrument finisher A.
- ⑩ Remove combination meter assembly.
- ⑪ Remove instrument finisher B.
- ⑫ Remove console box.
- ⑬ Remove instrument cover.
- ⑭ Remove instrument panel center.
- ⑮ Remove instrument panel assembly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

INSTRUMENT PANEL






HEAD-UP DISPLAY (HUD)

- When removing HUD finisher, be extremely careful not to scratch HUD's reflective surface. To avoid scratching, cover HUD's reflective surface or finisher with a cloth or vinyl sheet.



MBF598A

INSTRUMENT PANEL



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

MBF598A-1

HA

EL

Interior




SIDE AND FLOOR TRIM

CAUTION:

Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.

REMOVAL — Body side trim

- ① Remove front and rear kick plates.
- ② Remove dash side finisher.
- ③ Remove center pillar lower garnish.
- ④ Remove front and rear body side welts.
- ⑤ Remove front pillar garnish.
- ⑥ Remove rear pillar garnish.
- ⑦ Remove rear parcel shelf.





INTERIOR AND EXTERIOR

Interior (Cont'd)

DOOR TRIM REMOVAL — Door trim

- ① Remove inside handle escutcheon.
(Refer to BF-9.)
- ② Remove pull handle.
- ③ Remove power window switch finisher.
- ④ Remove screws.
- ⑤ Remove clips securing door finisher.
- ⑥ Lift out door finisher. Disconnect main and door harnesses.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL




INTERIOR AND EXTERIOR

Interior (Cont'd)

ROOM TRIM

REMOVAL — Headlining


- ① Remove rear seat.
- ② Remove front and rear seat belts.
- ③ Remove body side trim. Refer to BF-26.
- ④ Remove assist grips.
- ⑤ Remove interior lamp.
- ⑥ Remove sunroof switch. (Models equipped with sunroof)
- ⑦ Remove sunvisors.
- ⑧ Remove rearview mirror.
- ⑨ Remove front and rear pillar garnishes.
- ⑩ Remove headlining.



INTERIOR AND EXTERIOR

Interior (Cont'd)

LUGGAGE ROOM TRIM



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

INTERIOR AND EXTERIOR


Exterior




INTERIOR AND EXTERIOR

Exterior (Cont'd)


① Front hood insulator



② Cowl top grille and cowl top front sealing rubber



③ Front windshield molding



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


INTERIOR AND EXTERIOR

Exterior (Cont'd)

Windshield upper and side molding

Method 1

Cut off top portion of molding and clean glass and panel surfaces.



Apply sealant to top portion of molding.



Cut off lower portion of new molding.




Finish well to give it a good appearance.

SBF266G

Method 2


1. Cut off sealant at glass end.
2. Clean the side on which panel was mounted.
3. Set molding fastener and apply sealant to body panel, and apply primer to molding and body.



4. Install molding by aligning the molding mark located on center with vehicle center. Be sure to install tightly so that there is no gap around the corner.



SBF267G

④ Sunroof lid weatherstrip




MBF109A


⑤ Body side drip weatherstrip



A - A



B - B




C - C

MBF568A


INTERIOR AND EXTERIOR

Exterior (Cont'd)


⑥ Door weatherstrip



⑦ Body side welt



⑧ Door waist outside molding



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


INTERIOR AND EXTERIOR

Exterior (Cont'd)


⑨ Front door corner cover



⑪ Trunk lid weatherstrip



⑩ Rear windshield molding




INTERIOR AND EXTERIOR

Exterior (Cont'd)

12 Rear combination lamp


- Rear combination lamps are installed with nuts and butyl seal.

Removal



- Warm up lamp assembly area to a temperature slightly below 60°C (140°F)


Installation




- Apply butyl seal evenly as it tends to become thin at the corners.
- Warm up lamp assembly area to a temperature slightly below 60°C (140°F).

MBF120A

13 Side guard molding



■ : Double-faced adhesive tape



SBF460E

- Original side guard molding is affixed to body panel with double-faced adhesive tape.
- The repair parts are also affixed with double-faced adhesive tape.

Removal:

1. Heat molding portion to 30 to 40°C (86 to 104°F) with a heat gun.
2. Raise end of molding and, while cutting off bonding agent, detach molding.

Installation:

1. Remove all traces of bonding agent from body panel. Then clean contact face of body.

CAUTION:

Never apply tack-paper adhesive remover to body panel surface finished with lacquer-based paint.

2. Heat body panel and molding to 30 to 40°C (86 to 104°F) with a heat gun. Then install molding.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


INTERIOR AND EXTERIOR

Exterior (Cont'd)

14 Center mudguard







15 Front door parting seal



SEAT

- When removing or installing the seat trim, handle carefully to keep dirt out and avoid damage.

Front Seat



: N·m (kg·m, ft·lb)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

BF-37

SEAT

Rear Seat



SEAT

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM

Unit Location





Control module



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM


Unit Location (Cont'd)

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM


Wiring Diagram



MBF629A-1

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM

Wiring Diagram (Cont'd)



(WA) : With active speaker
 (WO) : Without active speaker

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
BF
 HA
 EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM

Description

FUNCTION

Shoulder belt buckle is mainly operated while ignition switch is "ON".

Condition (A): Ignition switch is "ON".

When door is opened, shoulder belt buckle is moved forward and when door is closed, buckle is moved rearward.

Condition (B): Ignition switch is "OFF".

When door is opened, shoulder belt buckle is moved forward. When the door is closed, buckle will remain in this position.

(Voltage of output signal is approximate value.)

Input signal	Ignition switch	OFF	OFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
	Door latch switch	OFF	ON	OFF	OFF	OFF	ON	ON	ON	OFF	OFF	OFF	OFF	ON	ON	ON	OFF
	Front limit switch	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	ON	ON	ON	ON	ON	OFF	OFF
	Rear limit switch	ON	ON	ON	ON	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	ON	ON	ON
Output signal	Drive motor power source for frontward operation	0V	0V	0V	0V	0V	12V	12V	0V	0V	0V	0V	0V	12V	12V	0V	0V
	Drive motor power source for rearward operation	0V	0V	12V	12V	0V	0V	0V	0V	12V	12V	0V	0V	0V	0V	0V	0V
Shoulder belt buckle	Function	Stop	Stop	Start to move	Moving	Stop	Start to move	Moving	Stop	Start to move	Moving	Stop	Stop	Start to move	Moving	Stop	Stop
	Position	Front	Front	Front	Between Front & Rear	Rear	Rear	Between Front & Rear	Front	Front	Between Front & Rear	Rear	Rear	Rear	Between Front & Rear	Front	Front

TIMER (Ignition switch either "ON" or "OFF")

If limit switch does not operate (when accomplishing frontward operation, front limit switch can not be turned "OFF" or when accomplishing rearward operation, rear limit switch can not be turned "OFF"), control module will continue to supply power to drive motor for 15 seconds.

QUICK WARNING (Ignition switch "ON")

If front limit switch is not turned "OFF" after accomplishing frontward operation, control module will stop supplying power 15 seconds later and warning lamp will flash and chime will operate rapidly for approximately 6 seconds.

REAR LOCK (Fail safe operation)

If quick warning functions twice successively while ignition switch is "ON", shoulder belt buckle will move to rear position and will remain in the rear position. This function is canceled when the ignition switch is "OFF".

SHOULDER BELT LOCKING CANCELLER—ELR SOLENOID (Ignition switch "ON" or "OFF")

The shoulder belt retractor does not lock belt length when moving the seat position front-rear adjusting lever (Seat slide switch is turned on). While ignition switch is "ON", the system warning lamp also glows. This system can be operated independently of "Automatic Seat Belt System".

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM

Description (Cont'd)









WARNING CODES (Shoulder belt system)

Priority	Warning item	Ignition switch	Indication of warning (Indicating time is approximately value.)		
1	Shoulder anchors are not at rear lock position.	ON	Lamp		GI
		OFF → ON	Lamp		MA
			Anchor		EM
2	Shoulder belts are not fastened.	ON	Lamp		LC
			Chime		EF & EC
			Belts		FE
3	Driver's side lap belt is not fastened.	OFF → ON	Lamp		CL
			Chime		MT
			Belts		AT
4	Normal (All belts are fastened and shoulder anchors are in rear lock position.)	OFF → ON	Lamp		FA
			Chime		RA
			Belts		BR

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM

Description (Cont'd)

WARNING CODE (Seat adjustment)

Priority	Warning item	Ignition switch	Indication of warning (Indicating time is approximately value.)	
1	Move seat front-rear adjusting lever. (Seat slide switch is turned on.)	ON	Lamp	<div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">ON</div>  </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">OFF</div>  </div>
			Chime	<div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">ON</div>  </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">OFF</div>  </div>
			Seat slide switch	<div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">ON</div>  </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">OFF</div>  </div>
			ELR solenoid	<div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">ON</div>  </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 5px;">OFF</div>  </div>

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Since left and right component parts are basically the same, harness layout and methods for electrical components inspection are shown for one side only.
 For those methods enclosed by double rectangles, component parts on both sides must be checked.

Symptom Chart


Procedure	Reference page	SYMPTOM								
Electrical Components Inspection	BF-68	Seat slide switch						○	○	
	BF-67	Drive motor assembly	○	○						
	BF-67	Shoulder belt buckle switch	○					○		
	BF-67	Door latch switch	○		○	○				
	BF-67	Rear limit switch	○	○	○			○		
	BF-67	Front limit switch	○	○		○		○		
	BF-68	Seat slide switch						○	○	
	BF-68	Lap belt buckle switch	○					○		
	BF-67	Drive motor assembly	○	○						
	BF-67	Shoulder belt buckle switch	○					○		
	BF-67	Door latch switch	○		○	○				
	BF-67	Rear limit switch	○	○	○			○		
	BF-67	Front limit switch	○	○		○		○		
	—	Warning chime	○					○		
	—	Warning lamp	○					○		
	Diagnostic Procedure	BF-66	Procedure 10	○						
		BF-65	Procedure 9						○	○
		BF-64	Procedure 8						○	
BF-63		Procedure 7						○		
BF-61		Procedure 6						○		
BF-60		Procedure 5						○		
BF-58		Procedure 4	○	○	○			○		
BF-57		Procedure 3	○	○		○		○		
BF-56		Procedure 2			○	○				
BF-54		Procedure 1	○	○						
Main Power Supply and Ground Circuit Check	BF-52	Procedure 2		○						
	BF-52	Procedure 1	○							
Preliminary Check	BF-50	Procedure 2						○		
	BF-48	Procedure 1		○	○		○			
		No operation has made. (No warning indicated and no buckles movement performed) Shoulder belt buckle in LH or RH side does not move. Shoulder belt buckle moves forward only. (not rearward) Shoulder belt buckle moves rearward only. (not forward) Warnings indicate incorrectly or do not function. Quick warning operates. Shoulder belt locks when adjusting front-rear seat position.								

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
BF
 HA
 EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses


Preliminary Check

PROCEDURE 1



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses

Preliminary Check (Cont'd)




GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
BF
 HA
 EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses


Preliminary Check (Cont'd)

PROCEDURE 2



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Preliminary Check (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses



Main Power Supply and Ground Circuit Check PROCEDURE 1


Main power supply

Terminals	Battery positive voltage existence condition	
	Ignition switch "ON"	Other than ignition switch "ON"
②1 - Ground	Yes	No
②2 - Ground	Yes	Yes
③9 - Ground	Yes	Yes
④4 - Ground	Yes	Yes



Ground circuit

Terminals	Continuity
②9 - Ground	Yes
③7 - Ground	Yes
④6 - Ground	Yes



PROCEDURE 2


Power supply for motor drive

	Terminals	Battery positive voltage existence
LH side	③9 - Ground	Yes
RH side	④4 - Ground	Yes

Ground circuit for motor drive

	Terminals	Continuity
LH side	③7 - Ground	Yes
RH side	④6 - Ground	Yes





Circuit Diagram for Quick Pinpoint Check



- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF**
- HA
- EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Diagnostic Procedure 1



START

A

CHECK MOTOR CIRCUIT.

- 1) Disconnect 10-pin connector from control module.
- 2) Check continuity.

	Terminals
LH side	38 - 40
RH side	41 - 45

Continuity should exist.

N.G. (Go to A on next page.)

O.K.

B

Does continuity exist?

	Terminals
LH side	38 - Ground
RH side	41 - Ground

Yes (Go to B below.)

No

C

CHECK MOTOR OPERATION.

Check shoulder belt buckle movement.

O.K. (Go to C on next page.)

N.G.

Go to DRIVE MOTOR ASSEMBLY in Electrical Components Inspection. (Refer to BF-67.)

N.G. Replace drive motor assembly.

O.K.

Replace guide rail assembly.

D

- 1) Disconnect connector from drive motor assembly.
- 2) Does continuity exist in at least one point?

	Terminals
LH side	51 - Ground 52 - Ground
RH side	51 - Ground 52 - Ground

Yes Repair harness. There will be incorrect grounding.

No

Check drive motor harness for incorrect grounding.







N.G. Repair drive motor harness.

O.K.

Replace drive motor assembly.

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses





Diagnostic Procedure 1 (Cont'd)






GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses


Diagnostic Procedure 2




2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses



Diagnostic Procedure 3




O.K. (Go to **B** below.)



N.G. Repair harness.




O.K.
(Go to **A** on next page.)





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Diagnostic Procedure 3 (Cont'd)





Diagnostic Procedure 4









	Terminals	Shoulder belt buckle position	Continuity
LH side	(36) - Ground	At rear	No
		Not at rear	Yes
RH side	(35) - Ground	At rear	No
		Not at rear	Yes

B Check drive motor for operation.




2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Diagnostic Procedure 4 (Cont'd)



Replace rear switch assembly.







Reinstall any part removed.

Go to PROCEDURE 1 (STEP 3) or PROCEDURE 2 (STEP 3) in Preliminary Check. (Refer to BF-48 or BF-50.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses

Diagnostic Procedure 5



START

A

CHECK SHOULDER BELT BUCKLE SWITCH CIRCUIT.

- 1) Disconnect 16-pin connector from control module.
- 2) Check continuity when shoulder belt buckle is at rear lock position.

O.K. → (Go to **B**) on next page.)

	Terminals	Shoulder belt	Continuity
LH side	③① - Ground	Fas-tened	Yes
		Unfas-tened	No
RH side	③② - Ground	Fas-tened	Yes
		Unfas-tened	No

B If shoulder belt buckle is not at rear lock position, set it to rear lock position.

N.G.

C

- 1) Disconnect connector from rear switch assembly.
- 2) Check continuity.

N.G. → Repair harness.

	Terminals
LH side	③① - ⑤⑤
	⑤④ - Ground (①④⑥ , ①④④)
RH side	③② - ⑤⑤
	⑤④ - Ground (①④⑥ , ①④④)

Continuity should exist.

O.K.

D

Does continuity exist?

	Connector	Terminals
LH side	①④④	⑤⑤ - Ground
RH side	①④④	⑤⑤ - Ground

Yes → Repair harness.
There will be incorrect grounding between terminals ③① and ⑤⑤ or ③② and ⑤⑤.

No

Go to SHOULDER BELT BUCKLE SWITCH in Electrical Components Inspection. (Refer to BF-67.)


O.K. → (Go to **B**) on next page.)

N.G.


(Go to **A**) on next page.)

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses


Diagnostic Procedure 5 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
HA
EL












Diagnostic Procedure 6







2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses


Diagnostic Procedure 6 (Cont'd)



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses






Diagnostic Procedure 7




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL




2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses




Diagnostic Procedure 8



2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses







Diagnostic Procedure 9




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses



Diagnostic Procedure 10




2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM – Trouble Diagnoses



Electrical Components Inspection


FRONT LIMIT SWITCH

Condition	Continuity
Pushed	No
Released	Yes




REAR LIMIT SWITCH

Condition	Continuity
Pushed	No
Released	Yes




SHOULDER BELT BUCKLE SWITCH

Condition	Continuity
Move magnet toward buckle switch.	Yes
Move magnet away buckle switch.	No



DOOR LATCH SWITCH (Built-into door lock assembly)

Door condition	Continuity
Open	Yes
Closed	No



DRIVE MOTOR ASSEMBLY


Terminals		Drive belt operation
⊕	⊖	
52	51	Lengthen
51	52	Shorten

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

2-POINT MOTORIZED AUTOMATIC SEAT BELT SYSTEM — Trouble Diagnoses


Electrical Components Inspection (Cont'd)

LAP BELT BUCKLE SWITCH (Built-into lap belt buckle for LH side)




Condition	Continuity
Fastened	No
Unfastened	Yes

SEAT SLIDE SWITCH (Seat slide inside rail)



Condition	Continuity
Move seat front-rear adjusting lever	Yes
Release seat front-rear adjusting lever	No

SUNROOF



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

SUNROOF

- After any adjustment, check sunroof operation and lid alignment.
- Handle finisher plate and glass lid with care so not to cause damage.
- It is desirable for easy installation to mark each point before removal.

CAUTION:

- a. Always work with a helper.
- b. Remove sunroof frame from rear door opening.

REMOVAL — Sunroof lid assembly

- ① Open sunroof shade.
- ② Close sunroof lid.
- ③ Remove side trim clips.
- ④ Remove the six nuts securing sunroof lid assembly to link assembly.

REMOVAL — Shade assembly


- ⑤ After removing sunroof lid assembly, remove screws securing rear drains to roof.
- ⑥ Remove rear drain.
- ⑦ Remove shade assembly.

REMOVAL — Sunroof assembly

- ⑧ Remove headlining. Refer to BF-28.
- ⑨ Disconnect interior lamp harness.
- ⑩ Disconnect front and rear drain hoses.
- ⑪ Remove nuts and bolts securing sunroof rail and motor to roof.
- ⑫ Remove sunroof assembly.

REMOVAL — Link & wire assembly

- ⑬ After removing shade assembly and sunroof assembly, remove the two screws securing holders to sunroof rail.
- ⑭ Remove the two screws securing window deflector to sunroof rail.
- ⑮ Remove window deflector.
- ⑯ Remove the two screws securing guide stoppers to sunroof rail.




SUNROOF

ADJUSTMENT

Install motor & limit SW assembly and sunroof rail assembly in the following sequence:

1. Arrange equal lengths of link and wire assemblies on both sides of sunroof opening.
2. Connect sunroof connector to sunroof switch and positive (+) power supply.
3. Set lid assembly to fully closed position **A** by operating CLOSE switch and TILT switch.
4. Fit outer side of lid assembly to the surface of roof on body outer panel.
5. Remove motor, and keep CLOSE switch pressed until motor pinion gear reaches the end of its rotating range.
6. Install motor.
7. Check that motor drive gear fits properly in wires.
8. Press TILT-UP switch to check lid assembly for normal tilting.
9. Check sunroof lid assembly for normal operations (tilt-up, tilt-down, open, and close).



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

SUNROOF

Wiring Diagram




Windshield

REMOVAL

After removing moldings, remove glass.

CAUTION:

Be careful not to scratch glass when removing.



INSTALLATION

- Use genuine Nissan Sealant kit or equivalent. Follow instructions furnished with it.
- After installation, the vehicle should remain stationary for about 24 hours.

WARNING:



Keep heat and open flames away as primers are flammable.

CAUTION:



Advise the user of the fact that vehicle should not be driven on rough roads or surfaces until sealant has properly vulcanized.

- Do not use sealant which is past its usable term.
- Do not leave cartridge unattended with its cap open.
- Keep primers and sealant in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Windshield glass should be installed within 15 minutes of applying sealant: sealant starts to harden 15 minutes after it is applied.
- Molding must be installed securely so that it is in position and leaves no gap.

Body side



Glass side



REPAIRING WATER LEAKS FOR WINDSHIELD

Leaks can be repaired without removing and reinstalling glass.

If water is leaking between caulking material and body or between glass and caulking material, determine the extent of the leak by applying water while pushing glass outward.


To stop the leak, apply primer (if necessary) and then sealant to the leak point.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


Door Mirror

REMOVAL

- Wrap flat-bladed screwdriver with a cloth to prevent scratching rear of door mirror. Do not insert screwdriver too far.



Door Mirror/Wiring Diagram




MBF632A

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

REAR AIR SPOILER


- When installing, make sure that there are no gaps or waves at ends of air spoiler.
- Before installing spoiler, clean and remove oil from surface where spoiler will be mounted.

REAR AIR SPOILER



BODY ALIGNMENT


- All dimensions indicated in figures are actual ones.
- When a tram tracking gauge is used, adjust both pointers to equal length and check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check for elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



ABF159

Engine Compartment

MEASUREMENT



ABF156

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA







EL

BODY ALIGNMENT

Engine Compartment (Cont'd)

MEASUREMENT POINTS


Unit: mm



BODY ALIGNMENT

Underbody

MEASUREMENT



- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF**
- HA
- EL

BODY ALIGNMENT

Underbody (Cont'd)

MEASUREMENT POINTS

Unit: mm

Coordinates:

(A), (a) X: 330
Y: -655
Z: 208

(B), (b) X: 513
Y: -540
Z: 265

(C), (c) X: 475
Y: -52
Z: 376

(E), (e) X: 450
Y: 68
Z: 188.5

(F), (f) X: 441
Y: 354
Z: 111.5

(G), (g) X: 600
Y: 430
Z: 154.9

(H), (h) X: 412
Y: 700
Z: 109

(J), (j) X: 408
Y: 1,071
Z: 109

(K), (k) X: 412.5
Y: 1,625
Z: 105.4




(L), (l) X: 575
Y: 2,070
Z: 216.1

(M), (m) X: 508
Y: 2,190
Z: 133

(P), (p) X: 332
Y: 2,735
Z: 266

(R), (r) X: 529
Y: 3,280
Z: 326.5

(T), (t) X: 575
Y: 3,280
Z: 326.5



Coordinates:

(N), (n) X: 557.2
Y: 2,623.9
Z: 813.1

(D), (d) X: 529
Y: 27
Z: 756

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Precautions for SRS "Air Bag" Service

- Do not use a circuit tester to check SRS circuits.
- Before servicing the SRS, turn ignition switch "OFF", disconnect battery ground cable and wait for at least 10 minutes.
For approximately ten minutes after the cables are removed, it is still possible for the air bag to inflate. Therefore, do not work on any air bag system connectors or wires until at least ten minutes have passed.
- SRS sensors must always be installed with their arrow marks "↗" facing the front of the vehicle for proper operation. Also check sensors for cracks, deformities or rust before installation and replace as required.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place it with the pad side facing upward.
- After removing any SRS parts, discard old bolts and replace with new ones. Conduct self-diagnosis to check entire SRS for proper function.
- If front of vehicle is damaged in a collision, always check the crash zone sensor and the wiring harness.

GI
MA
EM
LC
EF &
EC



Preparation

SPECIAL SERVICE TOOL

Tool number (Kent-Moore No.) Tool name	Description	
(J38381) Deployment tool		Disposing of air bag module

FE
CL
MT
AT

COMMERCIAL SERVICE TOOLS

Tool name	Description	
Special torx bit		Use for special bolts (tamper resistant screw)
Spiral cable stopper		Avoiding unexpected spiral cable rotation

FA
RA
BR
ST

BF


HA
EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Description

The air bag deploys when any of the two sensors (front crash zone sensor or tunnel sensor) and the safing sensor simultaneously activate while the ignition switch is "ON".

Ignition	Crash zone sensor	Tunnel sensor	Safing sensor	Air bag signal
	Front			
ON	ON		ON	ON
ON		ON	ON	ON




Self-diagnosis


The control module (diagnostic module) diagnoses the SRS circuit. When the ignition key is in the "ON" or "START" position, the "AIR BAG" warning lamp will illuminate for about 7 seconds and then turn off. This means that the system is operational.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

SRS Component Parts Location and Caution Labels



Shoulder belt disconnected for clarity. For normal use, the shoulder belt should always be connected to the buckle.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Caution Labels

A

SRS-AIRBAG

B

INFORMATION SRS AIRBAG

- THIS CAR IS EQUIPPED WITH A DRIVER AIR BAG AS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS) TO HELP PROTECT THE DRIVER IN A FRONTAL COLLISION.
- ALWAYS WEAR YOUR SEAT BELT.
- THE SYSTEM MUST BE INSPECTED 10 YEARS AFTER DATE OF MANUFACTURE, AS NOTED ON THE CERTIFICATION LABEL LOCATED ON THE LEFT FRONT DOOR.
- IF ANY OF THE FOLLOWING CONDITIONS OCCUR, THE SYSTEM MUST BE SERVICED: THE "AIR BAG" LAMP DOES NOT GO ON, FLASHES INTERMITTENTLY OR REMAINS ON.
- SEE YOUR OWNER'S MANUAL FOR DETAILS ABOUT THE FUNCTIONING, SERVICE, AND DISPOSAL PROCEDURES FOR THE SYSTEM.

IMPORTANT SAFETY INFORMATION AUTOMATIC SHOULDER BELT AND MANUAL LAP BELT RESTRAINT SYSTEM

- ALWAYS USE MANUAL LAP BELT: Failure to do so may decrease the protection offered by the restraint system.
- DO NOT DISCONNECT THE EMERGENCY RELEASE FOR NORMAL DRIVING:
This feature is for emergency use only.
- REFER TO OWNER'S MANUAL FOR OTHER IMPORTANT SAFETY INFORMATION ON:
 1. Proper seating position and use of restraint system
 2. Release of shoulder belt in an emergency
 3. Use of hand crank for shoulder belt
 4. Use by children

C

NOTICE SRS AIRBAG

- THIS CAR IS EQUIPPED WITH A DRIVER AIR BAG AS A SUPPLEMENTAL RESTRAINT SYSTEM (S.R.S.).
- IT IS DESIGNED TO SUPPLEMENT THE SEAT BELT.
- ALWAYS WEAR YOUR SEAT BELT.

D

WARNING

SRS AIRBAG

- THIS CAR IS EQUIPPED WITH A DRIVER AIR BAG AS A SUPPLEMENTAL RESTRAINT SYSTEM (S.R.S.).
- ALL SRS ELECTRICAL WIRING AND CONNECTORS ARE COLORED YELLOW.
- DO NOT USE ELECTRICAL TEST EQUIPMENT ON THESE CIRCUITS.
- TAMPERING WITH OR DISCONNECTING THE S.R.S. WIRING AND CONNECTORS COULD RESULT IN ACCIDENTAL DEPLOYMENT OF THE AIR BAG OR MAKE THE SYSTEM INOPERATIVE, WHICH MAY RESULT IN SERIOUS INJURY.

E

CAUTION

SRS AIRBAG

- BEFORE ASSEMBLY;
 - LINE UP THE FRONT WHEELS STRAIGHT AHEAD.
 - ALIGN THE ARROW WITH THE YELLOW MARK ON THE SIDE GEAR.
 - READ SERVICE MANUAL.
- NO SERVICEABLE PARTS INSIDE.
- DO NOT DISASSEMBLE OR TAMPER.

F

WARNING

SRS AIRBAG

- BEFORE MOUNTING STEERING WHEEL;
- MAKE SURE THAT THE FRONT WHEELS ARE IN STRAIGHT-AHEAD POSITION.
 - ALIGN THE ARROW WITH THE YELLOW MARK ON THE SIDE GEAR. (SPIRAL CABLE)
 - READ SERVICE MANUAL.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Caution Labels (Cont'd)

G

WARNING

SRS AIRBAG

- THIS AIR BAG MODULE CANNOT BE REPAIRED.
- USE DIAGNOSTIC INSTRUCTIONS TO DETERMINE IF THE UNIT IS OPERATIONAL.
- IF NOT OPERATIONAL, REPLACE AND DISPOSE OF THE ENTIRE UNIT AS DIRECTED IN THE INSTRUCTIONS.
- UNDER NO CIRCUMSTANCES SHOULD A DIAGNOSIS BE PERFORMED USING ELECTRICALLY POWERED TEST EQUIPMENT OR PROBING DEVICES.
- TAMPERING OR MISHANDLING CAN RESULT IN PERSONAL INJURY.
- STORE THE REMOVED AIR BAG MODULE WITH THE PAD SURFACE UP.
- FOR SPECIAL HANDLING OR STORAGE REFER TO SERVICE MANUAL.

H

DANGER POISON

- KEEP OUT OF THE REACH OF CHILDREN.
- CONTAINS SODIUM AZIDE AND POTASSIUM NITRATE.
- CONTENTS ARE POISONOUS AND EXTREMELY FLAMMABLE.
- CONTACT WITH ACID, WATER OR HEAVY METALS MAY PRODUCE HARMFUL AND IRRITATING GASES OR EXPLOSIVE COMPOUNDS.
- DO NOT DISMANTLE, INCINERATE, OR BRING INTO CONTACT WITH ELECTRICITY OR STORE AT TEMPERATURES EXCEEDING 200°F.
- FIRST AID: IF CONTENTS ARE SWALLOWED, INDUCE VOMITING;
 - FOR EYE CONTACT, FLUSH EYES WITH WATER FOR 15 MINUTES
 - IF GASES FROM ACID OR WATER CONTACT ARE INHALED, SEEK FRESH AIR
 - IN EVERY CASE, GET PROMPT MEDICAL ATTENTION
- FOR ADDITIONAL INFORMATION, SEE MATERIAL SAFETY DATA SHEET (MSDS) FOR THIS PRODUCT.

I

CAUTION SRS AIRBAG

- NO SERVICEABLE PARTS INSIDE.
- DO NOT DISASSEMBLE OR TAMPER.
- DO NOT DROP; KEEP DRY.
- WHILE REMOVED, STORE IN A CLEAN AND DRY AREA.
- IF WET CONDITION OCCURS, THIS UNIT MUST BE SERVICED.

J

WARNING

SRS AIRBAG

- DO NOT DISASSEMBLE OR TAMPER.
- DISMANTLING AND INSTALLATION SHOULD ONLY BE PERFORMED BY TRAINED PERSONNEL.

K

CAUTION

SRS AIRBAG

TO AVOID DAMAGING THE SRS SPIRAL CABLE, REMOVE THE STEERING WHEEL BEFORE REMOVING THE STEERING JOINT.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



Maintenance Items

1. Check "AIR BAG" warning lamp
When the ignition key is in the "ON" or "START" position, the "AIR BAG" warning lamp will illuminate for about 7 seconds and then turn off. This means that the system is operational.

2. Visually check SRS components

(1) Sensors

- Check sensors to ensure the arrow marks face the front of the vehicle.
- Check body and sensor brackets for deformities or rust.
- Check sensor case for dents, cracks, deformities or rust.
- Check sensor harness for binds, connector for damage, and terminals for deformities.

(2) Control module — Airbag

- Check case and bracket for dents, cracks or deformities.
- Check connectors for damage, and terminals for deformities.

(3) Main harness and instrument harness

- Check connectors for poor connections.
- Check harnesses for binds, connectors for damage, and terminals deformities.

(4) Spiral cable

- Visually check lock (engagement) pins and combination switch for damage.
- Check connectors, flat cable and protective tape for damage.
- Check steering wheel for noise, binds or difficult operation.

(5) Steering wheel

- Check harness (built into steering wheel) and connectors for damage, and terminals for deformities.
- Install air bag module to check fit or alignment with steering wheel.
- Check steering wheel for excessive free play.

(6) Air bag module

- Remove air bag module from steering wheel.
Check harness cover and connectors for damage, terminals for deformities, and harness for binds.
- Install air bag module to steering wheel to check fit or alignment with the wheel.

CAUTION:


Replace previously used screws with new ones.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Removal and Installation — Control Module and Sensors

CAUTION:

- Before servicing SRS, turn the ignition switch off, disconnect battery ground cable and wait for at least 10 minutes.
- The special bolts are coated with bonding agent. Discard old ones after removal; replace with new ones.
- Check all sensors for proper installation.
- Check all sensors to ensure they are free of deformities, dents, cracks or rust. If they show any visible signs of damage, replace them with new ones.
- Check sensor brackets to ensure they are free of deformities or rust.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Removal — Air Bag Module and Spiral Cable




CAUTION:

Before servicing SRS, turn the ignition switch off, disconnect battery ground cable and wait for at least 10 minutes.

1. Remove lower lid from steering wheel, and disconnect air bag module connector.



2. Remove side lid. Using the T50H torx bit, remove left and right special bolts. Air bag module can then be removed.



CAUTION:


- Always place air bag module with pad side facing upward.
- Do not attempt to disassemble air bag module.
- The special bolts are coated with bonding agent. Discard old ones after removal; replace with new ones.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Removal — Air Bag Module and Spiral Cable (Cont'd)



- Do not drop or impact air bag module. If any portion is deformed or cracked, replace the module.
- Do not expose the air bag module to temperatures exceeding 100°C (212°F).
- Do not allow oil, grease or water to come in contact with the air bag module.




3. Set steering wheel in the neutral position.
4. Disconnect horn connector and remove nuts.
5. Using steering wheel puller, remove steering wheel. Be careful not to over-tighten puller bolt on steering wheel.



6. Attach spiral cable to stopper.
7. Remove steering column cover.
8. Disconnect connector and remove the four screws. The spiral cable can then be removed.

Installation — Air Bag Module and Spiral Cable

1. Connect spiral cable connector and tighten with screws. Install steering column cover.



2. Remove stopper by pulling two pin guides.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA


EL

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Installation — Air Bag Module and Spiral Cable (Cont'd)



- Alignment of spiral cable with neutral position
If stopper is not used, align spiral cable with neutral position as follows:
Turn spiral cable clockwise until it catches stopper. Then, back spiral cable off approximately two turns until yellow alignment mark appears on left gear. Align arrow mark “↙” of spiral cable with this yellow mark.




3. Install steering wheel setting spiral cable pin guides, and pull spiral cable through.
4. Connect horn connector and engage spiral cable with pawls in steering wheel.
5. Tighten nuts.



6. Position air bag module and tighten with new special bolts.
7. Connect air bag module connector.
8. Install all lids.

9. Conduct self-diagnosis to ensure entire SRS operates properly. (Use CONSULT or warning lamp check.)

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)




Scrapping the Air Bag

Before scrapping an air bag module or a vehicle equipped with an SRS air bag, be sure to deploy air bag.


CONNECTING TO BATTERY

Prepare a 12-volt battery. Locate it approximately 5 m (16 ft) away from vehicle and connect deployment tool's battery cable. Ensure red light illuminates. If it does not, replace the battery with a new one.




DEPLOYMENT TOOL CHECK

Connect check connector.




Push deployment tool switch to "ON" to ensure green light illuminates. If it does not, replace the deployment tool.



CONNECTING TO AIR BAG

1. Disconnect the prepared battery cable.
2. Also disconnect the vehicle battery ground cable and wait 10 minutes.
3. Remove lower lid from steering wheel and disconnect air bag module connector.
4. Connect deployment tool connector.
5. Reconnect the battery cable to the prepared battery. Ensure red light illuminates.



DEPLOYMENT

Press deployment tool switch. Green light will illuminate and air bag will deploy.

CAUTION:

- When deploying air bag, ensure vehicle is empty.
- No poisonous gas is produced upon air bag deployment. However, be careful not to inhale gas since it irritates throat and can cause choking.
- Due to heat, leave air bag module unattended for more than 30 minutes after air bag deployment.
- Do not attempt to disassemble air bag module.
- Air bag module can not be re-used.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


Wiring Diagram

CAUTION:

- Do not use a circuit tester to check SRS "Air Bag" harness connectors. The wiring harness and connectors have yellow outer insulation for easy identification.
- Do not attempt to repair, splice or modify the SRS "Air Bag" wiring harness. If the harness is damaged, replace it with a new one.
- Keep ground portion clean.




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Self-diagnosis USING CONSULT

The self-diagnosis results can be read by CONSULT, as follows:

1. Connect "CONSULT" to vehicle harness connector.
↓
2. Turn ignition switch to "ON". (When CONSULT is connected, the "AIR BAG" warning lamp will be turned to present diagnosis mode.)
↓
3. Touch "START" to operate "CONSULT".
↓
4. Touch "AIR BAG" to choose air bag system.
↓
5. Touch "SELF DIAG RESULTS" to read self-diagnosis results.
↓
6. Problem codes are displayed on "SELF DIAG RESULT 1" (first page — present mode). The problem code last indicated is displayed on "SELF DIAG RESULT 2" (second page — initial mode).
↓
7. When "PRINT" is pressed, information displayed on "SELF DIAG RESULTS 1 and 2" is printed out.
↓
8. After repairing malfunctioning parts, press "ERASE" to clear self-diagnosis results.
 - **After repairing malfunctioning parts, attempt to clear self-diagnosis results from memory.**
 - **If malfunctioning parts are not completely repaired, self-diagnosis results remain stored in memory.**
↓
9. Push Back Key of CONSULT until SELECT SYSTEM mode appears to make "SELF-DIAGNOSIS" user mode.
↓
10. Push the power off switch.
↓
11. Turn off ignition switch.



TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Self-diagnosis (Cont'd)

Self-diagnosis results

Failure parts group [Present] and [Initial]	Explanation	Repair order * Recheck SRS at each replacement.	
NO SELF DIAGNOSTIC FAILURE INDICATED.	Normal. The SRS "Air Bag" is in good order.	—	GI
SAFING SENSOR [OPEN/LWR-GND-SHORT]	The circuit for the safing sensor is open or the wire from the safing sensor to the control module (terminal No. 3) is shorted.	1. Visually check the wiring harness connections. 2. Replace the safing sensor. (safing sensor and tunnel sensor) 3. Replace the control module. 4. Replace the main harness.	MA
SAFING SENSOR [SHORT/LWR-VB-SHORT]	Both the wires for the safing sensor are shorted or the wire from the safing sensor to the control module (terminal No. 3) is shorted to some power supply circuit.		EM
AIRBAG MODULE [OPEN]	The circuit for the air bag module is open. (including the spiral cable)	1. Visually check the wiring harness connections. 2. Replace the spiral cable. 3. Replace the air bag module. (Before disposing of it, it must be deployed.) 4. Replace the control module. 5. Replace the main harness.	LC
AIRBAG MODULE [VB-SHORT]	The circuit for driver's air bag module is shorted to some power supply circuit. (including the spiral cable)		EF & EC
AIRBAG MODULE [GND-SHORT]	The circuit for the air bag module is shorted to ground. (including the spiral cable)		FE
AIRBAG MODULE [SHORT]	The circuit for driver's air bag module are shorted to each other.		CL
TUNNEL SENSOR [OPEN/UPR-VB-SHORT]	The circuit for the tunnel sensor is open or the wire from the control module (terminal No. 6) to the tunnel sensor is shorted to some power supply circuit.		MT
TUNNEL SENSOR [SHORT]	The circuits for the tunnel sensor are shorted to each other.	1. Visually check the wiring harness connections. 2. Replace the tunnel sensor. (safing sensor and tunnel sensor) 3. Replace the control module. 4. Replace the main harness.	AT
CRASH ZONE SEN-CTR [OPEN/UPR-VB-SHORT]	The circuit for the center crash zone sensor is open or the wire from the control module (terminal No. 9) to the center crash zone sensor is shorted to some power supply circuit.	1. Visually check the wiring harness connections. 2. Replace the center crash zone sensor. 3. Replace the control module. 4. Replace the main harness.	FA
CRASH ZONE SEN-CTR [SHORT]	The circuits for the center crash zone sensor are shorted to each other.		RA
CONTROL MODULE	The control module (diagnostic module) is out of order.	1. Visually check the wiring harness connections. 2. Replace the control module. 3. Replace the main harness.	BR
INDEFINITE FAILURES	A problem which cannot be specified occurs because more than two parts are out of order.	1. See the SELF-DIAGNOSIS RESULT 2 failure parts group [initial], then repair as necessary. 2. Visually check the wiring harness connections. 3. Replace the control module. 4. Replace all sensors, the spiral cable and air bag module. 5. Replace the main harness.	ST

BF


TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Self-diagnosis (Cont'd)


USING THE WARNING LAMP

Self-diagnosis results can be also read by using the "AIR BAG" warning lamp.

The "AIR BAG" warning lamp operates as shown below:




How to alternate self-diagnosis



Problem codes are displayed in present diagnosis mode (self-diagnosis result 1). The problem code last indicated is displayed in initial diagnosis mode (self-diagnosis result 2).

After the malfunctioning parts have been repaired and the system is returned to the user mode, the present diagnosis mode information, displayed as self-diagnosis results, is automatically cleared from memory.

- After repairing malfunctioning part, attempt to clear self-diagnosis results from memory.
- If a malfunctioning part is not completely repaired, information stored in memory will not be cleared.




TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)


Self-diagnosis (Cont'd)

Present diagnosis mode (self-diagnosis result 1)

(b) Start signal; Start signal identifies display modes.




- No failure (or intermittent failure/repair completion)



ABF182


Initial diagnosis mode (self-diagnosis result 2)

(b) Start signal; Start signal identifies display modes.



- No failure

Unit: sec.



ABF183

Self-diagnosis results in present- and initial-diagnosis modes can be identified by number of flashes (d). Refer to Table on next page for failed parts.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Self-diagnosis (Cont'd)

Warning lamp flashing times and repair



Flash code (d) (# of flashes)	Explanation	Repair order * Recheck SRS at each replacement.
0	Normal. The SRS "Air Bag" is in good order.	—
1	The circuit for the safing sensor is out of order.	<ol style="list-style-type: none">1. Visually check the wiring harness connections.2. Replace the safing sensor. (safing sensor and tunnel sensor)3. Replace the control module.4. Replace the main harness.
2	The circuit for the air bag module is out of order.	<ol style="list-style-type: none">1. Visually check the wiring harness connections.2. Replace the spiral cable.3. Replace the air bag module. (Before disposing of it, it must be deployed.)4. Replace the control module.5. Replace the main harness.
3	The circuit for the tunnel sensor is out of order.	<ol style="list-style-type: none">1. Visually check the wiring harness connections.2. Replace the tunnel sensor. (safing sensor and tunnel sensor)3. Replace the control module.4. Replace the main harness.
6	The circuit for the center crash zone sensor is out of order.	<ol style="list-style-type: none">1. Visually check the wiring harness connections.2. Replace the center crash zone sensor.3. Replace the control module.4. Replace the main harness.
7	The control module (diagnostic module) is out of order.	<ol style="list-style-type: none">1. Visually check the wiring harness connections.2. Replace the control module.3. Replace the main harness.
8	More than two parts groups are out of order.	<ol style="list-style-type: none">1. See the SELF-DIAGNOSIS RESULT 2 failure parts group [Initial], then repair it.2. Visually check the wiring harness connections.3. Replace the control module.4. Replace all sensors, spiral cable and air bag module.5. Replace the main harness.

TROUBLE DIAGNOSES – Supplemental Restraint System (SRS)





Diagnostic Procedure 1

SYMPTOM: Warning lamp flashes.



Diagnostic Procedure 2

SYMPTOM: Warning lamp does not come on.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA



BR

ST

BF


HA

EL



Diagnostic Procedure 3

SYMPTOM: Warning lamp does not go off.



* Recheck SRS after each replacement.

Collision Diagnosis

To repair the SRS “AIR BAG”, perform the following steps.

- ① Check the control module (diagnostic module).
 - Connect CONSULT and then erase the memory. (However, the memory may not be cleared.)

OR


- Check “AIR BAG” warning lamp and perform the following twice: turn driver’s door switch ON and OFF 5 times within 7 seconds after ignition switch turned “ON”.

If “AIR BAG” warning lamp comes on continuously.

Replace the control module.

- ② Remove the deployed air bag module.
- ③ Check the SRS components using the table shown below:
 - If the SRS components are showing any visible damage such as dents, cracks, or deformation, replace them with new ones.
- ④ Conduct self-diagnosis using CONSULT or “AIR BAG” warning lamp to ensure entire SRS operates properly except open circuit of air bag module.
- ⑤ Install new air bag module.

	Inspection (when air bag deploys in collision)	Inspection (when air bag does not deploy in low-speed collision)
Steering wheel	(1) Check harness (built into steering wheel) and connectors for damage, and terminals for deformities. (2) Install air bag module to check fit or alignment with steering wheel. (3) Check steering wheel for excessive free play.	
In-compartment sensor	(1) Check body and sensor brackets for deformities or rust. (2) Check sensor case for dents, cracks, deformities or rust. (3) Check sensor harness for binds, connector for damage, and terminals for deformities.	
All sensors (except those affected by collision)		
Air bag module	Replace air bag module.	(1) Remove air bag module from steering wheel. Check harness cover and connectors for damage, terminals for deformities, and harness for binds. (2) Install air bag module to steering wheel to check fit or alignment with the wheel. (3) Replace screws with new ones.
Harness connector (Main and Instrument harness)	(1) Check connectors for poor connections. (2) Check harness for binding, connectors for damage, and terminals for deformities.	
Spiral cable	(1) Visually check lock (engagement) pins and combination switch for damage. (2) Check connectors, flat cable and protective tape for damage. (3) Check steering wheel for noise, binds or heavy operation.	
Control module	Replace control module (diagnostic module).	(1) Check case and bracket for dents, cracks or deformities. (2) Check connectors for damage, and terminals for deformities.



HEATER AND AIR CONDITIONING

SECTION HA

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

CONTENTS

<p>PRECAUTIONS 2</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System "AIR BAG"..... 2</p> <p>DESCRIPTION — Overall System..... 6</p> <p style="padding-left: 20px;">Control Operation — Manual Air Conditioning 6</p> <p style="padding-left: 20px;">Introduction — Auto Air Conditioning..... 7</p> <p style="padding-left: 20px;">Features 7</p> <p style="padding-left: 20px;">Control Operation — Auto Air Conditioning..... 7</p> <p style="padding-left: 20px;">Component Layout..... 9</p> <p style="padding-left: 20px;">Air Flow — Auto Air Conditioning..... 10</p> <p>DESCRIPTION — Refrigeration System..... 11</p> <p>PREPARATION 12</p> <p style="padding-left: 20px;">Special Service Tools..... 12</p> <p style="padding-left: 20px;">HFC-134a (R-134a) Service Tools and Equipment 13</p> <p style="padding-left: 20px;">Precautions for Service Equipment..... 15</p> <p>SERVICE PROCEDURES..... 17</p> <p style="padding-left: 20px;">HFC-134a (R-134a) Service Procedure..... 17</p> <p style="padding-left: 20px;">Refrigerant Lines..... 19</p> <p style="padding-left: 20px;">Compressor Mounting..... 20</p> <p style="padding-left: 20px;">Belt Tension 20</p> <p style="padding-left: 20px;">Fast Idle Control Device (FICD)..... 20</p> <p>LUBRICATION OIL — Checking and Adjusting 21</p> <p style="padding-left: 20px;">Lubrication Oil 21</p> <p style="padding-left: 20px;">Maintenance of Oil Quantity in Compressor..... 21</p> <p style="padding-left: 20px;">Checking and Adjusting..... 21</p> <p>COMPRESSOR — Model DKV-14C (ZEXEL make) 23</p> <p style="padding-left: 20px;">Compressor Clutch 23</p> <p style="padding-left: 40px;">Removal..... 23</p> <p style="padding-left: 40px;">Inspection..... 24</p> <p style="padding-left: 40px;">Installation 25</p> <p style="padding-left: 40px;">Break-In Operation 26</p> <p style="padding-left: 20px;">Thermal Protector 26</p> <p>DIAGNOSES — Overall System..... 27</p> <p style="padding-left: 20px;">How to Perform Trouble Diagnoses for Quick and Accurate Repair — Manual Air Conditioning..... 27</p>	<p style="padding-left: 20px;">Work Flow..... 27</p> <p style="padding-left: 20px;">How to Perform Trouble Diagnoses for Quick and Accurate Repair — Auto Air Conditioning 28</p> <p style="padding-left: 40px;">Work Flow..... 28</p> <p>Operational Check 29</p> <p style="padding-left: 20px;">Conditions:..... 29</p> <p style="padding-left: 20px;">Procedure: 29</p> <ol style="list-style-type: none"> 1. Check blower 29 2. Check discharge air..... 29 3. Check recirc 30 4. Check temperature decrease 30 5. Check temperature increase 30 6. Check air conditioning switch (Manual Air Conditioning type only)..... 30 7. Check ECON mode (Auto Air Conditioning type only) 30 8. Check AUTO mode (Auto Air Conditioning type only) 31 9. Check memory function (Auto Air Conditioning type only) 31 10. Check fresh vent switch 31 <p>Performance Chart..... 32</p> <p style="padding-left: 20px;">Test Condition..... 32</p> <p style="padding-left: 20px;">Test Reading 32</p> <p>Performance Test Diagnoses 33</p> <p style="padding-left: 20px;">Insufficient Cooling 33</p> <p style="padding-left: 20px;">Trouble Diagnoses For Abnormal Pressure..... 34</p> <p>TROUBLE DIAGNOSES — Manual Air Conditioning 38</p> <p style="padding-left: 20px;">Symptom Chart 38</p> <p style="padding-left: 40px;">Diagnostic Table..... 38</p> <p>Preliminary Check..... 40</p> <p style="padding-left: 20px;">Preliminary Check 1 40</p> <p style="padding-left: 20px;">Preliminary Check 2 41</p> <p style="padding-left: 20px;">Preliminary Check 3 42</p> <p style="padding-left: 20px;">Preliminary Check 4 43</p> <p style="padding-left: 20px;">Preliminary Check 5 44</p> <p style="padding-left: 20px;">Preliminary Check 6 45</p>
--	---

CONTENTS (Cont'd.)

Harness Layout for A/C System.....	46	Preliminary Check 5	86
Wiring Diagram — Manual Air Conditioning.....	48	Preliminary Check 6	87
Circuit Diagram for Quick Pinpoint Check	50	Preliminary Check 7	88
Main Power Supply and Ground Circuit Check.....	51	Preliminary Check 8	88
Power Supply Circuit Check For A/C System.....	51	Harness Layout for A/C System.....	89
Push Control Module Check	51	Circuit Diagram for Quick Pinpoint Check	91
Diagnostic Procedure 1	52	Wiring Diagram	92
Diagnostic Procedure 2	54	Main Power Supply and Ground Circuit Check.....	94
Diagnostic Procedure 3	56	Power Supply Circuit Check For Auto A/C	
Diagnostic Procedure 4	57	System	94
Diagnostic Procedure 5	59	Auto Amp. Check	94
Diagnostic Procedure 5-1.....	59	Diagnostic Procedure 1	95
Diagnostic Procedure 5-2.....	60	Diagnostic Procedure 2	96
Diagnostic Procedure 6	61	Diagnostic Procedure 3	97
Electrical Components Inspection	65	Diagnostic Procedure 4	98
Fan Switch	65	Diagnostic Procedure 5	99
Blower Motor.....	65	Diagnostic Procedure 6	101
Blower Resistor.....	65	Diagnostic Procedure 7	102
A/C Switch	65	Diagnostic Procedure 8	103
Thermo Control Amp.....	66	Diagnostic Procedure 9	105
Thermal Protector.....	66	Diagnostic Procedure 10	108
Triple-Pressure Switch	66	Control Linkage Adjustment	111
A/C Relay And Blower Hi Relay	66	Mode Door	111
Fresh Vent Switch	67	Air Mix Door (Water cock).....	111
Control Linkage Adjustment	67	Intake Door	112
Mode Door	67	Fresh Vent Door	112
Air Mix Door (Water cock).....	67	SYSTEM DESCRIPTION — Auto Air	
Intake Door	68	Conditioning	113
Fresh Vent Door	68	Overview of Control System.....	113
TROUBLE DIAGNOSES — Auto Air		Control System Input Components	114
Conditioning	69	Potentio Temperature Control (Ptc).....	114
Self-diagnosis	69	In-Vehicle Sensor	114
Checking Procedure.....	70	Aspirator.....	114
Step 1: Checks Leds and segments	72	Ambient Sensor	115
Step 2: Checks each sensor circuit for open		Sunload Sensor	115
or short circuit.....	72	Control System Automatic Amplifier (Auto amp.) ..	116
Sensors and abnormalities	73	Ambient Temperature Input Process.....	116
Step 3: Checks mode door position	73	Sunload Input Process	116
Step 4: Checks operation of each actuator.....	74	Control System Output Components	116
Step 5: Checks temperature detected by		Air Mix Door Control (Automatic temperature	
sensors.....	74	control)	116
Auxiliary Mechanism: Temperature setting		Air Mix Door Motor	118
trimmer	76	PBR.....	118
Symptom Chart	78	Outlet Door Control	119
Diagnostic Table	78	Mode Door Motor	120
Preliminary Check	82	Intake Door Control	120
Preliminary Check 1	82	Intake Door Motor.....	121
Preliminary Check 2	83	Fan Speed Control	122
Preliminary Check 3	84	Component parts	122
Preliminary Check 4	85	System operation	122

CONTENTS (Cont'd.)

Automatic Mode.....	122	Blower Hi-Relay.....	124
Starting Fan Speed Control	122	Magnet Clutch Control	124
Blower Speed Compensation	123	SERVICE DATA AND SPECIFICATIONS (SDS)	125
Fan Control Amplifier.....	123		

When you read wiring diagrams:

- Read G1 section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read G1 section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

PRECAUTIONS

Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.

Precautions for Working with HFC-134a (R-134a)

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant must never be mixed, even in the smallest amounts, as they are incompatible with each other. If the refrigerants are mixed, compressor failure is likely to occur.
- Use only specified lubrication oil for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubrication oil other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) lubrication oil absorbs moisture from the atmosphere at a rapid rate, therefore the following handling precautions must be observed:
 - a: When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b: When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Also, complete the connection of all refrigerant loop components as quickly as possible to minimize the entry of moisture into the system.
 - c: Use the specified lubrication oil from a sealed container only. Containers must be re-sealed immediately after dispensing the lubrication oil. Lubrication oil in containers which are not properly sealed will become moisture saturated, and such lubrication oil is no longer suitable for use and should be properly disposed of.
 - d: Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. To remove HFC-134a (R-134a) from the A/C system, use service equipment certified to meet the requirements of SAE J2210 [HFC-134a (R-134a) recycling equipment] or J2209 [HFC-134a (R-134a) recovery equipment]. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e: Do not allow lubrication oil (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

PRECAUTIONS

General Refrigerant Precautions

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not introduce compressed air to any refrigerant container or refrigerant component.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

PRECAUTIONS

Precautions for Refrigerant Connection

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:


When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes, as compressor oil will enter low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, plug all openings immediately to prevent entrance of dirt and moisture.
- When installing an air conditioning in the vehicle, the pipes must be connected as the final stage of the operation. The seal caps of the pipes and other components must not be removed until their removal is required for connection.
- To prevent the condensation of moisture inside A/C components, components stored in cool areas should be allowed to warm to the working area temperature before removing the seal caps.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubrication oil to portions shown in illustration. Be careful not to apply oil to threaded portion.

Name: Nissan A/C System Oil Type R

Part No.: KLH00-PAGR0

- O-ring must be closely attached to inflated portion of tube.
- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



PRECAUTIONS

Precautions for Servicing Compressor

- Attach a blind plug to the suction port (low pressure) and discharge port (high pressure) of the compressor to prevent oil from leaking out and dust from getting inside. GI
- Do not keep the compressor in the upside down position or laid on its side for more than 10 minutes. MA
- When replacing or repairing compressor, be sure to remove oil from the compressor and check the oil quantity extracted. EM
- When replacing with a new compressor, be sure to remove oil from the new compressor so that the quantity of oil remaining in the new compressor is equal to the quantity collected from the removed compressor. See the section "LUBRICATION OIL". LC
- Pay attention so as not to allow dirt and oil to attach on the friction surfaces between clutch and pulley. If the surface is contaminated with oil, wipe it off by using a clean waste cloth moistened with thinner. EF & EC
- After completing the compressor service operation, be sure to rotate the compressor shaft more than five turns in both directions by hand to equalize oil distribution inside the compressor, then run the compressor for about one hour by idling the engine. FE
- When the compressor magnet clutch has been replaced, be sure to check the magnet clutch for normal operation by applying voltage to the clutch.

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

DESCRIPTION — Overall System

Control Operation — Manual Air Conditioning



AHA139

FAN CONTROL SWITCH

This switch turns the fan ON and OFF, and controls fan speed.

MODE SWITCHES

These switches allow you to select the outlet air flow.

When the MODE switch is moved to "DEF" or "F/D", the push control amplifier sets the intake door to "FRE". The compressor turns on when the MODE switch is moved to "DEF".

TEMPERATURE CONTROL LEVER

This lever allows you to adjust the temperature of the outlet air.

RECIRC SWITCH

OFF position:

Outside air is drawn into the passenger compartment when this switch is OFF.

ON position:

Interior air is recirculated inside the vehicle.

RECIRC is canceled when DEF or F/D are selected. RECIRC resumes when another mode is chosen.

AIR CONDITIONING SWITCH

Start the engine, set the fan control switch to the desired (1 to 4) position and push the air conditioning switch to turn ON the air conditioning. The indicator lamp will come on when the air conditioning is ON. To stop the air conditioning, push the switch again to return it to the original position.

The air conditioning cooling function operates only when the engine is running.

FRESH VENT SWITCH

When the fresh vent switch is in the "ON" position, a small amount of air flows directly from the evaporator outlet to the vent (face) duct, bypassing the heater unit. This provides a small amount of cool air in the occupant head/face area even though warm air may be discharging through the foot or defroster outlets.

DESCRIPTION – Overall System

Introduction – Auto Air Conditioning

The Automatic Temperature Control (ATC) system provides automatic regulation of the vehicles interior temperature based on the operator selected “set temperature”, regardless of the outside temperature changes. This is done by utilizing a microcomputer, also referred to as the automatic amplifier, which receives input signals from several sensors. The automatic amplifier uses these input signals (including the set temperature) to automatically control the ATC system’s outlet air volume, air temperature, and air distribution.

Features

Air mix door control (Automatic temperature control)

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a predetermined value by: The temperature setting, ambient temperature, in-vehicle temperature, amount of sunload.

Fan speed control

Blower speed is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, amount of sunload and air mix door position.

With FAN switch set to “AUTO”, the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower fan stops to prevent cool air from flowing to the floor area.

Intake door control

The intake door is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, amount of sunload and ON-OFF operation of the A/C switch.


Outlet door control

The outlet door is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, and amount of sunload.

Self-diagnostic system

The self-diagnostic system is built into the auto amplifier to quickly locate the cause of problems.

Control Operation – Auto Air Conditioning



AHA140

DESCRIPTION — Overall System

Control Operation — Auto Air Conditioning (Cont'd)

AUTO SWITCH

The compressor, air inlet door, air mix door, outlet doors, and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.

ECON SWITCH

Fully automatic control with the compressor off. With the compressor off, the system will not remove heat (cool) or de-humidify. The system will maintain the in-vehicle temperature at the set temperature when the set temperature is above the ambient (outside) temperature.

PTC (Potentio Temperature Control)





Increases or decreases the set temperature.

OFF SWITCH

The compressor and blower are off, the air inlet door is set to the outside air position, and the air outlet doors are set to the foot (78% foot and 28% defrost) position. In the off position the ATC system uses the vehicle's "flow through" ventilation to try to maintain the interior temperature based on the temperature set when the system was last operating.




FAN SWITCH

Manual control of the blower speed. Four speeds are available for manual control (as shown on the display screen):

low  , medium low  , medium high  , high 

MODE SWITCH

Manual control of the air discharge outlets. Three selections are available (as shown on the display screen):

face  , bi-level  , foot 

REC SWITCH

ON position: Interior air is recirculated inside the vehicle.

OFF position: Automatic control resumes.

DEF SWITCH


Positions the air discharge doors to the defrost position. Also positions the air inlet door to the outside air position. The compressor operates at ambient temperature approx. 2°C (35°F) or above.

FRESH VENT SWITCH

In order to prevent unpleasant hot air in the heater mode, or especially in the FOOT, FOOT/DEF or DEF modes, this system can provide cold air flow to the ventilator ducts directly (by-passing the heater core) by means of a fresh vent switch beside the center vent duct.

DESCRIPTION — Overall System


Component Layout




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

DESCRIPTION — Overall System

Air Flow — Auto Air Conditioning




Floor




*: When fresh door is opened.

Ventilation




Floor and defroster




*: When fresh vent door is opened.

Bi-level



Defroster



*: When fresh vent door is opened.

- ← : Air passed through heater core
- ← + ← : Mixed air (← + ←)
- ← : Air not passed through heater core

* : When fresh vent door is opened.

Refrigeration Cycle

REFRIGERANT FLOW

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the liquid tank, through the evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.


REFRIGERANT SYSTEM PROTECTION

Triple-pressure switch

The refrigerant system is protected against excessively high or low pressures by the triple-pressure switch, located on the liquid tank. If the system pressure rises above, or falls below the specifications, the triple-pressure switch opens to interrupt the compressor operation and to operate the radiator fan motor.

Pressure relief valve

The refrigerant system is also protected by a pressure relief valve, located on the end of high flexible hose near compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST





BF

HA

EL

PREPARATION

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description	Note
KV99231260 (J-38874) Clutch disc wrench	 A technical drawing of a clutch disc wrench. It consists of a long, thin handle and a circular head with four small protrusions around its perimeter, designed to fit into the slots of a clutch disc nut.	Removing shaft nut and clutch disc
KV99232340 (J-38874) Clutch disc puller	 A technical drawing of a clutch disc puller. It features a central shaft with a threaded section and a circular head with a textured, knurled surface. The head is designed to grip the outer edge of a clutch disc.	Removing clutch disc
KV99234330 (J-39024) Pulley installer	 A technical drawing of a pulley installer. It is a circular, dome-shaped tool with a textured, knurled top surface and a smooth bottom surface. The bottom surface is designed to fit over a pulley for installation.	Installing pulley
KV99233130 (J-39023) Pulley puller	 A technical drawing of a pulley puller. It is a cylindrical tool with a central hole and a textured, knurled top surface. The top surface is designed to grip the top of a pulley for removal.	Removing pulley

PREPARATION





HFC-134a (R-134a) Service Tools and Equipment

It is important to understand that HFC-134a (R-134a) refrigerant, and the specified lubrication oil which must be used with HFC-134a (R-134a), must never be mixed with CFC-12 (R-12) refrigerant and/or the CFC-12 (R-12) lubrication oil.

This means that separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubrication oil.

To prevent the mixing of refrigerants/lubrication oils, refrigerant container fittings, service hose fittings, and service equipment fittings (equipment which handles refrigerant and/or lubrication oil) are different between CFC-12 (R-12) and HFC-134a (R-134a).






Adapters to convert from one size fitting to the other must never be used: refrigerant/lubrication oil contamination will occur and compressor failure will result.

Tool number (Kent-Moore No.) Tool name	Description	Note
HFC-134a (R-134a) refrigerant	 <div style="text-align: right;">RHA259D</div>	Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size • large container 1/2"-16 ACME
KLH00-PAGRO (-) Nissan A/C System Oil Type R	 <div style="text-align: right;">RHA260D</div>	Type: Poly alkylene glycol oil (PAG), type R Application: HFC-134a (R-134a) vane rotary compressors (Nissan only) Lubricity: 40 ml (1.4 US fl oz, 1.4 Imp fl oz)
(J-39500-NI) Recovery/Recycling equipment (ACR4)	 <div style="text-align: right;">RHA261D</div>	Function: Refrigerant Recovery and Recycling and Recharging
(J-39400) Electronic leak detector	 <div style="text-align: right;">RHA267D</div>	Power supply: • DC 12 V (Cigarette lighter)

GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

PREPARATION

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Note
(J-39183) Manifold gauge set (with hoses and couplers)	 <p style="text-align: right;">RHA262D</p>	Identification: <ul style="list-style-type: none"> ● The gauge face indicates R-134a. Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME
Service hoses <ul style="list-style-type: none"> ● High side hose (J-39501-72) ● Low side hose (J-39502-72) ● Utility hose (J-39476-72) 	 <p style="text-align: right;">RHA263D</p>	Hose color: <ul style="list-style-type: none"> ● Low hose: Blue with black stripe ● High hose: Red with black stripe ● Utility hose: Yellow with black stripe or green with black stripe Hose fitting to gauge: <ul style="list-style-type: none"> ● 1/2"-16 ACME
Service couplers <ul style="list-style-type: none"> ● High side coupler (J-39500-20) ● Low side coupler (J-39500-24) 	 <p style="text-align: right;">RHA264D</p>	Hose fitting to service hose: <ul style="list-style-type: none"> ● M14 x 1.5 fitting (optional) or permanently attached
(J-39650) Refrigerant weight scale	 <p style="text-align: right;">RHA265D</p>	For measuring of refrigerant Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME
(J-39649) Vacuum pump (Including the isolator valve)	 <p style="text-align: right;">RHA266D</p>	Capacity: <ul style="list-style-type: none"> ● Air displacement: 4 CFM ● Micron rating: 20 microns ● Oil capacity: 482 g (17 oz) Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME

PREPARATION

Precautions for Service Equipment

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturers instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

Be certain to follow the manufactures instructions for tester operation and tester maintenance.



VACUUM PUMP

The lubrication oil contained inside the vacuum pump is not compatible with the specified lubrication oil for HFC-134a (R-134a) A/C systems. Since the vent side of the vacuum pump is exposed to atmospheric pressure, it is possible for the vacuum pump lubrication oil to migrate out of the pump into the service hose if the pump is switched off after evacuation (vacuuming) and the service hose is not isolated from the vacuum pump.

To prevent the migration of vacuum pump lubrication oil into service hoses, it is necessary to use a valve (which can be manually opened or closed) near the connection of the service hose to the pump.

- On a vacuum pump which is equipped with an isolator valve (usually part of the vacuum pump), closing this valve will isolate the service hose from the pump.
- For pumps without an isolator valve, be certain that the service hose is equipped with a manual shut off valve near the pump end of the hose.
- Hoses which contain an automatic shut off valve at the end of the service hose must be disconnected from the vacuum pump to prevent the migration of lubrication oil: as long as the hose is connected, the valve is open and lubrication oil may migrate.

One-way valves which open when vacuum is applied and close under a no vacuum condition are not recommended, because this valve may restrict the pump's ability to pull a deep vacuum.



MANIFOLD GAUGE SET


Be certain that the gauge face indicates R-134a or 134a. Be certain that the manifold gauge set has the 1/2"-16 ACME threaded connections for service hoses, and that no refrigerants other than HFC-134a (R-134a) (along with only specified lubrication oils) have been used with the manifold gauge set.

PREPARATION


Precautions for Service Equipment (Cont'd)

SERVICE HOSES


Be certain that the service hoses display the markings described (colored hose with black stripe). Be certain that all hoses include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.



RHA272D



RHA273D



RHA274D

SERVICE COUPLERS

Never attempt to connect HFC-134a (R-134a) service couplers to an CFC-12 (R-12) A/C system. Although the HFC-134a (R-134a) couplers will not secure on to the CFC-12 (R-12) system, CFC-12 (R-12) refrigerant and lubrication oil will be discharged into the HFC-134a (R-134a) coupler, causing contamination.

Shut off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

REFRIGERANT WEIGHT SCALE

If the scale allows electronic control of the flow of refrigerant through the scale, be certain that the hose fitting size is 1/2"-16 ACME, and that no refrigerant other than HFC-134a (R-134a) (along with only specified lubrication oil) have been used with the scale.

CHARGING CYLINDER

The charging cylinder is not recommended because refrigerant may be vented into the air from the top valve of the cylinder when filling the cylinder with refrigerant. Additionally, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

SERVICE PROCEDURES


HFC-134a (R-134a) Service Procedure

SETTING OF SERVICE TOOLS AND EQUIPMENT


DISCHARGING REFRIGERANT

WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. To remove HFC-134a (R-134a) from the A/C system, use service equipment certified to meet the requirements of SAE J2210 [HFC-134a (R-134a) recycling equipment] or J2209 [HFC-134a (R-134a) recovery equipment]. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.




EVACUATING SYSTEM AND CHARGING REFRIGERANT



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE PROCEDURES

HFC-134a (R-134a) Service Procedure (Cont'd)




Note: *1 Before charging refrigerant, ensure engine is off.

*2 Before checking for leaks, start engine to activate air conditioning system then turn it off.

SERVICE PROCEDURES

Refrigerant Lines


- Refer to HA-4.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SERVICE PROCEDURES

Compressor Mounting



Belt Tension

- Refer to MA section (“Checking Drive Belts”, “ENGINE MAINTENANCE”).

Fast Idle Control Device (FICD)

- Refer to EF & EC section (“IAC VALVE-FICD SOLENOID VALVE”, “Electrical Components Inspection”, “TROUBLE DIAGNOSES”).

Lubrication Oil

Name: Nissan A/C System Oil Type R

Part No.: KLH00-PAGR0

Maintenance of Oil Quantity in Compressor


The oil used to lubricate the compressor circulates through the system with the refrigerant. Whenever any component of the system is replaced or a large amount of gas leakage occurs, add oil to the compressor to maintain the specified amount.

If oil quantity is not maintained properly, the following malfunctions may result:

- Lack of oil: May lead to a seized compressor
- Excessive oil: Inadequate cooling (thermal exchange impeded)

Checking and Adjusting

Adjust the oil quantity according to the flowchart shown below.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


LUBRICATION OIL – Checking and Adjusting

Checking and Adjusting (Cont'd)


A

1. Discharge refrigerant into refrigerant recovery/recycling equipment. Measure oil discharged into the recovery/recycling equipment.
2. Remove the drain plug (for V-5 or V-6, and DKS-16H compressor) and drain the oil from the “old” (removed) compressor into a graduated container, and record the amount of oil drained.
3. Remove the drain plug and drain the oil from the “new” compressor into a separate, clean container.
4. Measure an amount of the new oil equivalent to that drained from the “old” compressor, and add this oil to the “new” compressor through the drain plug or suction port opening.
5. Measure an amount of the “new” oil equivalent to that recovered during discharging, and add this oil to the “new” compressor through the drain plug or suction port opening.
6. Torque the drain plug.
V-5 or V-6 compressor: 18 - 19 N·m (1.8 - 1.9 kg-m, 13 - 14 ft-lb)
DKS-16H compressor: 14 - 16 N·m (1.4 - 1.6 kg-m, 10 - 12 ft-lb)
7. If the liquid tank also needs to be replaced, add an additional 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of oil at this time.
Do not add this 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of oil if only replacing the compressor.

Oil adjusting procedure for compressor replacement



COMPRESSOR — Model DKV-14C (ZEXEL make)




GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
HA
 EL


Compressor Clutch

REMOVAL

- When removing center bolt, hold clutch disc with clutch disc wrench.




- Remove the drive plate using the clutch disc puller. Insert the holder's three pins into the holes in the drive plate, and rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the drive plate. When tightening the center bolt, insert a round bar (screwdriver, etc.) between two of the pins (as shown in the left-hand figure) to prevent drive plate rotation. After removing the drive plate, remove the shims from either the drive shaft or the drive plate.




COMPRESSOR — Model DKV-14C (ZEXEL make)

Compressor Clutch (Cont'd)



- Remove the snap ring using external snap ring pliers.



- Pulley removal
Position the center pulley puller on the end of the drive shaft, and remove the pulley assembly using any commercially available pulley puller.



For pressed pulleys

To prevent deformation of the pulley groove, the puller claws should be hooked into (not under) the pulley groove.

For machine latched pulleys

Align the pulley puller groove with the pulley groove, and then remove the pulley assembly.

- Remove the field coil harness clip using a screwdriver.
- Remove the three field coil fixing screws and remove the field coil.



INSPECTION

Clutch disc

If the contact surface shows signs of damage due to excessive heat, the clutch disc and pulley should be replaced.

Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and clutch disc should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

Check coil for loose connection or cracked insulation.

COMPRESSOR — Model DKV-14C (ZEXEL make)





Compressor Clutch (Cont'd)

INSTALLATION

- Install the field coil.

Be sure to align the coil's pin with the hole in the compressor's front head.

- Install the field coil harness clip using a screwdriver.



- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.

- Install the drive plate on the drive shaft, together with the original shim(s). Press the drive plate down by hand.

- Using the clutch disc wrench to prevent drive plate rotation, tighten the bolt to 12 to 15 N·m (1.2 to 1.5 kg-m, 9 to 11 ft-lb) torque.

After tightening the bolt, check that the pulley rotates smoothly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

COMPRESSOR — Model DKV-14C (ZEXEL make)

Compressor Clutch (Cont'd)



- Check clearance around the entire periphery of clutch disc.


Disc-to-pulley clearance:

0.3 - 0.6 mm (0.012 - 0.024 in)

If the specified clearance is not obtained, replace adjusting spacer and readjust.

BREAK-IN OPERATION

When replacing compressor clutch assembly, do not forget break-in operation, accomplished by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.



Thermal Protector


INSPECTION

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.

DIAGNOSES — Overall System

How to Perform Trouble Diagnoses for Quick and Accurate Repair — Manual Air Conditioning

WORK FLOW




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

DIAGNOSES — Overall System

How to Perform Trouble Diagnoses for Quick and Accurate Repair — Auto Air Conditioning

WORK FLOW



Operational Check


The purpose of the operational check is to confirm that the system is as it should be. The systems which will be checked are the blower, mode (discharge air), intake air, temperature decrease, temperature increase, A/C switch and the memory function (Auto air conditioning type only).




CONDITIONS:

- Engine running and at normal operating temperature.
- Fresh VENT "OFF"

PROCEDURE:

1. Check blower

- 1) Turn fan switch to 1-speed or Press fan switch (up side) at one time.
Blower should operate on low speed.
The fan symbol should have one blade lit . (Auto Air Conditioning type only)
- 2) Then turn fan switch to 2-speed or Press fan switch (up side) one more time.
- 3) Continue checking blower speed until all speeds are checked.
Continue checking fan symbol until all speeds are checked (Auto Air Conditioning type only)
- 4) Leave blower on speed 4.



2. Check discharge air.

- 1) Press each mode switch (Manual Air Conditioning type).
Press mode switch four times and DEF button (Auto Air Conditioning type).
- 2) Confirm that discharge air comes out according to the air distribution ratios table at left.

NOTE:


Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF button is pressed.

Confirm that the intake door position is at FRESH when the F/D button is pressed (Manual Air Conditioning type only).

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


DIAGNOSES — Overall System

Operational Check (Cont'd)




3. Check recirc

- 1) Press REC switch
Recirc indicator should illuminate.
- 2) Listen for intake door position change (you should hear blower sound change slightly).




4. Check temperature decrease

- 1) Slide temperature control lever to full cold. (Manual Air Conditioning type)
Press the temperature decrease button until 18°C (65°F) is displayed (Auto Air Conditioning type).
- 2) Check for cold air at discharge air outlets.




5. Check temperature increase

- 1) Slide temperature control lever to full hot. (Manual Air Conditioning type)
Press the temperature increase button until 32°C (85°F) is displayed (Auto Air Conditioning type).
- 2) Check for hot air at discharge air outlets.



6. Check air conditioning switch (Manual Air Conditioning type only)

Move the fan control switch to the desired (1 to 4 speed) position and push the A/C switch to turn ON the air conditioning.
The indicator lamp should come on when air conditioning is ON.




7. Check ECON mode (Auto Air Conditioning type only)

- 1) Press ECON switch.
- 2) Display should indicate ECON (no AUTO, no MANUAL).
Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air will depend on ambient, in-vehicle, and set temperatures).

DIAGNOSES – Overall System

Operational Check (Cont'd)



8. Check AUTO mode (Auto Air Conditioning type only)


- 1) Press AUTO switch.
- 2) Display should indicate AUTO (no ECON, no MANUAL). Confirm that the compressor clutch engages (audio or visual inspection). (Discharge air will depend on ambient, in-vehicle, and set temperatures).

GI

MA

EM

LC




9. Check memory function (Auto Air Conditioning type only)

- 1) Press OFF switch.
- 2) Turn the ignition off.
- 3) Turn the ignition on.
- 4) Press the AUTO switch.
- 5) Confirm that the set temperature remains at previous temperature.


EF &
EC

FE

CL



10. Check fresh vent switch

- 1) Set temperature control to full hot.
- 2) Set mode position at DEF.
- 3) Turn the fresh vent switch on ( position)
- 4) Confirm that discharge air comes out of defroster vents, and that cool air comes from face vents.

MT

AT

FA

RA

BR

ST

BF

HA

EL

DIAGNOSES — Overall System

Performance Chart

TEST CONDITION

For Auto Air Conditioning, before conducting performance test, disconnect ambient sensor harness connector and make short circuit using jumper cable.

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)

Doors: Closed

Door window: Open

Hood: Open

TEMP.: Max. COLD

Discharge Air: Face Vent

REC switch: (Recirculation) set

FAN speed: 4-speed

Engine speed: 1,500 rpm

Time required before starting testing after air conditioning starts operating: More than 10 minutes

TEST READING


Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	20 (68)	4.0 - 5.4 (39 - 42)
	25 (77)	4.2 - 5.6 (40 - 42)
	30 (86)	8.5 - 11.1 (47 - 52)
	35 (95)	13.5 - 16.7 (56 - 62)
	40 (104)	18.5 - 22.3 (65 - 72)
60 - 70	20 (68)	5.4 - 6.8 (42 - 44)
	25 (77)	5.6 - 8.0 (42 - 46)
	30 (86)	11.1 - 14.1 (52 - 57)
	35 (95)	16.7 - 20.3 (62 - 69)
	40 (104)	22.3 - 26.5 (72 - 80)

Ambient air temperature-to-compressor pressure table

Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	834 - 1,098 (8.5 - 11.2, 121 - 159)	122.6 - 161.8 (1.25 - 1.65, 17.8 - 23.5)
	25 (77)	1,049 - 1,363 (10.7 - 13.9, 152 - 198)	137.3 - 181.4 (1.4 - 1.85, 19.9 - 26.3)
	30 (86)	1,226 - 1,618 (12.5 - 16.5, 178 - 235)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
	35 (95)	1,255 - 1,716 (12.8 - 17.5, 182 - 249)	166.7 - 230.5 (1.7 - 2.35, 24.2 - 33.4)
	40 (104)	1,540 - 2,030 (15.7 - 20.7, 223 - 294)	201.0 - 289.3 (2.05 - 2.95, 29.2 - 41.9)

Performance Test Diagnoses INSUFFICIENT COOLING



Note: A, F in "Check discharge pressure 2" correspond to those in TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE.

GI
MA
EM
LC
FF &
FC
FF
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE




Whenever abnormal pressure of high and/or low sides of the system is noted, diagnosis must be conducted by using a manifold gauge. The large-line zone on the gauge scale (see illustrations.) shown in the following table refers to the standard (normal) pressure range for the corresponding pressure side (high or low). Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-32 ("Ambient air temperature-to-compressor pressure table").

Pressure measurements are effective only when ambient temperature is in the range indicated under the heading "INSPECTION DATA (1) Measurement of system pressure".

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too high.</p> <p>A</p>  <p style="text-align: right; margin-right: 50px;">AC359A</p>	<ul style="list-style-type: none"> ● Pressure is reduced soon after water is splashed on condenser. 	<p>Excessive refrigerant charge in refrigeration cycle</p>	<p>Reduce refrigerant until specified pressure is obtained.</p>
	<p>Air suction by radiator or radiator fan is insufficient.</p>	<p>Insufficient condenser cooling performance</p> <p style="text-align: center;">↓</p> <p>① Condenser fins are clogged.</p> <p>② Improper rotation of radiator fan or radiator fan</p>	<ul style="list-style-type: none"> ● Clean condenser. ● Check and repair radiator or radiator fan as necessary.
	<ul style="list-style-type: none"> ● Low-pressure pipe is not cold. ● When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	<p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p style="text-align: center;">↓</p> <p>Air in refrigeration cycle</p>	<p>Evacuate repeatedly and recharge system.</p>
	<p>Engine tends to overheat.</p>	<p>Engine cooling systems malfunction.</p>	<p>Check and repair each engine cooling system.</p>
	<ul style="list-style-type: none"> ● Areas near low-pressure pipe connection and service valves are considerably cold compared with areas near expansion valve outlet or evaporator. ● Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> ● Excessive liquid refrigerant on low-pressure side ● Excessive refrigerant discharge flow ● Expansion valve is open a little compared with the specification. <p style="text-align: center;">↓</p> <p>① Improper thermal valve installation</p> <p>② Improper expansion valve adjustment</p>	<p>Replace expansion valve.</p>



DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action	
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p style="text-align: center;">AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> ● Check and repair or replace malfunctioning parts. ● Check compressor oil for contamination. 	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EF & EC</p> <p>FE</p>
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p style="text-align: center;">AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>	<p>CL</p> <p>MT</p> <p>AT</p>
	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)</p>	<p>Replace compressor.</p>	<p>FA</p> <p>RA</p> <p>BR</p>
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p style="text-align: center;">AC353A</p>	<ul style="list-style-type: none"> ● There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. ● Liquid tank inlet and expansion valve are frosted. 	<p>Liquid tank inside is clogged a little.</p>	<ul style="list-style-type: none"> ● Replace liquid tank. ● Check compressor oil for contamination. 	<p>ST</p> <p>BF</p>
	<ul style="list-style-type: none"> ● Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. ● Expansion valve inlet may be frosted. ● Temperature difference occurs somewhere in high-pressure side 	<p>High-pressure pipe located between receiver drier and expansion valve is clogged.</p>	<ul style="list-style-type: none"> ● Check and repair malfunctioning parts. ● Check compressor oil for contamination. 	<p>HA</p> <p>EL</p>


DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p style="text-align: center;">AC353A</p>	<p>There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.</p>	<p>Expansion valve closes a little compared with the specification.</p> <p style="text-align: center;">↓</p> <p>① Improper expansion valve adjustment ② Malfunctioning thermal valve ③ Outlet and inlet may be clogged.</p>	<ul style="list-style-type: none"> ● Remove foreign particles by using compressed air. ● Check compressor oil for contamination.
<p>Areas near low-pressure pipe connection and service valve are extremely cold as compared with areas near expansion valve outlet and evaporator.</p>	<p>Low-pressure pipe is clogged or crushed.</p>	<p>Low-pressure pipe is clogged or crushed.</p>	<ul style="list-style-type: none"> ● Check and repair malfunctioning parts. ● Check compressor oil for contamination.
<p>Air flow volume is not enough or is too low.</p>	<p>Evaporator is frozen.</p> <p style="text-align: center;">↓</p> <p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)</p>	<p>Evaporator is frozen.</p> <p style="text-align: center;">↓</p> <p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)</p>	<p>Replace compressor.</p>
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p style="text-align: center;">AC354A</p>	<ul style="list-style-type: none"> ● Air conditioning system does not function and does not cyclically cool the compartment air. ● The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> ● Drain water from refrigerant or replace refrigerant. ● Replace liquid tank.

DIAGNOSES — Overall System

Performance Test Diagnoses (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p>AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>After the system is left at rest, start it again in order to confirm whether or not problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> ● If the problem is due to water, drain water from refrigerant or replace refrigerant. ● If it is due to foreign particles, remove expansion valve and remove them with dry and compressed air. ● If either of the above methods cannot correct the problem, replace expansion valve. ● Replace liquid tank. ● Check compressor oil for contamination.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES — Manual Air Conditioning

Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE	Preliminary Check						Diagnostic Procedure						Main Power Supply and Ground Circuit Check			
	HA-40	HA-41	HA-42	HA-43	HA-44	HA-45	HA-52	HA-54	HA-56	HA-57	HA-59	HA-61	HA-51	HA-51	HA-51	HA-51
REFERENCE PAGE	HA-40	HA-41	HA-42	HA-43	HA-44	HA-45	HA-52	HA-54	HA-56	HA-57	HA-59	HA-61	HA-51	HA-51	HA-51	HA-51
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Preliminary check 4	Preliminary check 5	Preliminary check 6	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	20A Fuses (#4, #5)	10A Fuse (#10)	10A Fuse (#20)	Push control module
A/C does not blow cold air.		①					○			○			○	○		
Insufficient heating.						①	○					○				
Blower motor does not rotate.		①					②						○			
Air outlet does not change.				①				②						○		○
Intake door does not change in VENT, B/L or FOOT mode.									①					○		○
Intake door is not set at "FRESH" in DEF or F/D mode.	①								○					○		○
Air mix door does not change.		①								②						
Fresh vent door does not change.											①					
Magnet clutch does not engage when A/C switch and fan switch are ON.		①										②		○	○	
Magnet clutch does not engage in DEF mode.		①	②									○		○	○	
Noise					①											


①, ② : The number means checking order.

○ : As for checking order, refer to each flow chart. (It depends on malfunctioning portion.)

Preliminary Check

PRELIMINARY CHECK 1

Intake door is not set at "FRESH" in DEF or F/D mode.




TROUBLE DIAGNOSES – Manual Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 2

A/C does not blow cold air.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Preliminary Check (Cont'd)

PRELIMINARY CHECK 3

Magnet clutch does not engage in DEF mode.

- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.



TROUBLE DIAGNOSES — Manual Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 4

Air outlet does not change.


DOES AIR COME OUT FROM EACH DUCT NORMALLY WHEN EACH MODE SWITCH IS PUSHED WITH IGNITION SWITCH AT ON?

No

Perform **Diagnostic Procedure 2**. Refer to HA-54.

Switch		Indicator illuminates					Air outlet
Mode		○					VENT
			○				FOOT & VENT
				○			FOOT & DEF
					○		FOOT & DEF
						○	DEF

Air distribution ratios



SHA527D

Yes

INSPECTION END

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES — Manual Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 5

Noise




TROUBLE DIAGNOSES — Manual Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 6

Insufficient heating



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

Harness Layout for A/C System







Engine compartment



TROUBLE DIAGNOSES — Manual Air Conditioning

Harness Layout for A/C System (Cont'd)


Passenger compartment



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES – Manual Air Conditioning


Wiring Diagram – Manual Air Conditioning




TROUBLE DIAGNOSES — Manual Air Conditioning

Wiring Diagram — Manual Air Conditioning (Cont'd)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Circuit Diagram for Quick Pinpoint Check



- All connectors shown in this illustration are unit side connectors.
- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown in the "Harness Layout for A/C System". (Refer to HA-46, HA-47.).
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".
- *: These switches are built into push control module and mechanically linked to corresponding switches.


Main Power Supply and Ground Circuit Check

POWER SUPPLY CIRCUIT CHECK FOR A/C SYSTEM

Check power supply circuit for air conditioning system.

Refer to EL section (“Wiring Diagram”, “POWER SUPPLY ROUTING”).

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL




PUSH CONTROL MODULE CHECK

Check power supply circuit for push control module with ignition switch at ACC.

1. Disconnect push control module harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑭ and body ground.

Voltmeter terminal		Voltage
⊕	⊖	
⑭	Body ground	Approx. 12V



Check body ground circuit for push control module with ignition switch ON.

1. Disconnect push control module harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.

Ohmmeter terminal		Continuity
⊕	⊖	
⑰	Body ground	Yes

TROUBLE DIAGNOSES — Manual Air Conditioning

	INCIDENT	Flow chart No.
1	Fan fails to rotate.	1
2	Fan does not rotate at 1-speed.	2
3	Fan does not rotate at 2-speed.	3
4	Fan does not rotate at 3-speed.	4
5	Fan does not rotate at 4-speed.	5

Diagnostic Procedure 1


SYMPTOM: Blower motor does not rotate.

- Perform **PRELIMINARY CHECK 2** before referring to the following flow chart.

Check if blower motor rotates properly at each fan speed.
Conduct check as per flow chart at left.

2 3 4 5
(Go to next page.)

➔ B




A
CHECK POWER SUPPLY FOR BLOWER MOTOR.
Disconnect blower motor harness connector.
Do approx. 12 volts exist between blower motor harness terminal No. (45) and body ground?

N.G.

Check 20A fuses at fuse block.
Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

O.K.



B
Check circuit continuity between blower motor harness terminal No. (46) and body ground.

N.G.


Reconnect blower motor harness connector.

O.K.

CHECK BLOWER MOTOR.
(Refer to HA-65.)

N.G.

Replace blower motor.




C
CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR.
Do approx. 12 volts exist between resistor harness terminal No. (28) and body ground?

N.G.

Disconnect blower motor and resistor harness connectors.

O.K.

D Note
Check circuit continuity between blower motor harness terminal No. (46) and resistor harness terminal No. (28).







➔ A
(Go to next page.)

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.




TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 1 (Cont'd)



Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Diagnostic Procedure 2

SYMPTOM: Air outlet does not change.

- Perform **PRELIMINARY CHECK 4** and **Main Power Supply and Ground Circuit Check** before referring to the following flow chart.

A

CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Turn VENT switch ON with ignition switch at ON position.
2. Turn ignition switch OFF. Disconnect push control module connector.
3. Turn ignition switch ON. Check if continuity exists between terminal No. ① or ② of push control module harness connector and body ground.
4. Using above procedures, check for continuity in any other mode, as indicated in chart.

Mode switch	Terminal No.		Continuity
	⊕	⊖	
VENT	① or ②	Body ground	Yes
B/L	② or ③		
FOOT	③ or ④		
F/D	④ or ⑤		
DEF	⑤ or ⑥		

O.K.

CHECK SIDE LINK.
Refer to HA-67.

N.G.

Disconnect mode door motor harness connector.

B Note

CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.
Does continuity exist between mode door motor harness terminal No. ⑩① and body ground?

O.K.

C Note

Check circuit continuity between each terminal on push control module and on mode door motor.

Terminal No.		Continuity
⊕	⊖	
Push control module	Mode door motor	Yes
①	①	
②	②	
③	③	
④	④	
⑤	⑤	
⑥	⑥	
⑦	⑦	
⑧	⑧	

O.K.


A
(Go to next page.)

Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 2 (Cont'd)



A

↓

Reconnect push control module and mode door motor harness connectors.

D

CHECK FOR OUTPUT OF PUSH CONTROL MODULE.

Do approx. 12 volts exist between push control module harness terminal No. ⑦ and ⑧ when mode is switched from "VENT" to "DEF" or when mode is switched from "DEF" to "VENT"?

Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
⊖	⊖	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counterclockwise

N.G. → Replace push control module.

O.K.

↓





Replace mode door motor.

- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL

Diagnostic Procedure 3


SYMPTOM: Intake door does not change in VENT, B/L or FOOT mode.

- Perform **PRELIMINARY CHECK 1** and **Main Power Supply and Ground Circuit Check** before referring to the following flow chart.







- A**
- CHECK INTAKE DOOR MOTOR POSITION SWITCH.**
1. Turn REC switch ON with ignition switch at ON position.
 2. Turn ignition switch OFF. Disconnect push control module connector.
 3. Turn ignition switch ON. Check if continuity exists between terminal No. (21) of push control module harness connector and body ground.
 4. Using above procedures, check for REC switch OFF position as indicated in chart.

REC switch	Terminal No.		Continuity
	⊕	⊖	
ON	(21)	Body ground	Yes
OFF	(24)		




Note: If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 4

SYMPTOM: Air mix door does not change.

Perform Main Power Supply and Ground Circuit Check before referring to the following chart.



Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 4 (Cont'd)



A

E

CHECK FOR PUSH CONTROL MODULE OUTPUT.
 Do approx. 12 volts exist between push control module harness terminal No. ②② and ②③ when temperature lever is slid from "HOT" to "COLD" or when temperature lever is slid from "COLD" to "HOT"?

Terminal No.		Air mix door motor	
②②	②③	Air mix door operation	Direction of linkage rotation
⊖	⊕	HOT → COLD	Clockwise
⊕	⊖	COLD → HOT	Counterclockwise
⊖	⊖	STOP	STOP




N.G. → Replace push control module.

O.K.

CHECK AIR MIX DOOR.
 (Refer to HA-67.)

O.K.

Replace air mix door motor.



Diagnostic Procedure 5

SYMPTOM: Fresh vent door does not operate.

- Perform Main Power Supply and Ground Circuit Check before referring to the following chart.

DIAGNOSTIC PROCEDURE 5-1

A Note

CHECK BODY GROUND CIRCUIT FOR FRESH VENT SWITCH.
Disconnect fresh vent switch connector.
Does continuity exist between fresh vent switch connector harness terminal No. (100) and body ground?

O.K.

B

CHECK POWER SUPPLY FOR FRESH VENT SWITCH.
Do approx. 12 volts exist between fresh vent switch harness terminal No. (9) and body ground when FRESH VENT SWITCH is ON?
Do approx. 12 volts exist between fresh vent switch connector harness terminal No. (10) and body ground when FRESH VENT SWITCH is OFF?

O.K.

CHECK FRESH VENT SWITCH.
(Refer to HA-67.)

N.G.

Replace fresh vent switch.

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

N.G. Disconnect push control module connector.

C Note

Check circuit continuity between fresh vent switch harness terminal No. (9) (10) and push control module harness terminal No. (9) (10).

O.K.


Perform DIAGNOSTIC PROCEDURE 5-2. Refer to HA-60.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 5 (Cont'd)

DIAGNOSTIC PROCEDURE 5-2



A

CHECK POWER SUPPLY FOR FRESH VENT DOOR MOTOR.
Disconnect fresh vent door motor harness connector.
Do approx. 12 volts exist between fresh vent switch harness terminal No. (19) and body ground when FRESH VENT SWITCH is ON?
Do approx. 12 volts exist between fresh vent door motor harness terminal No. (18) and body ground when FRESH VENT SWITCH is OFF?

N.G. Disconnect push control module connector.

B Note


Check circuit continuity between fresh vent door motor harness terminal No. (18) (19) and push control module harness terminal No. (18) (19).

O.K.

Replace push control module.





O.K.

Replace fresh vent door motor.



Note:


If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 6

SYMPTOM: Magnet clutch does not engage when A/C switch and fan switch are ON.

- Perform PRELIMINARY CHECK 2 before referring to the following chart.









Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL






TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 6 (Cont'd)



TROUBLE DIAGNOSES — Manual Air Conditioning

Diagnostic Procedure 6 (Cont'd)



J Note
Check circuit continuity between triple-pressure switch harness terminal No. 103 and body ground?

O.K.
CHECK TRIPLE-PRESSURE SWITCH. (Refer to HA-66.)

O.K.
Disconnect thermo control amp. harness connector.

K Note
Check circuit continuity between triple-pressure switch harness terminal No. 41 and thermo control amp. harness terminal No. 41.

O.K.
CHECK POWER SUPPLY FOR THERMO CONTROL AMP. Disconnect thermo control amp. harness connector. Do approx. 12 volts exist between thermo control amp. harness terminal No. 40 and body ground?

O.K.
CHECK BODY GROUND CIRCUIT FOR THERMO CONTROL AMP. Does continuity exist between thermo control amp. harness terminal No. 37 and body ground?

O.K.
Replace thermo control amp.

D
Disconnect ECM (ECCS control module) harness connector.

L Note
Check circuit continuity between ECM (ECCS control module) harness terminal No. 41 (45) and triple-pressure switch harness terminal No. 42 (43).

O.K.
Check ECM (ECCS control module). Refer to EF & EC section "ECM (ECCS Control Module) (Diagnostic trouble code No. 31)", "TROUBLE DIAGNOSES".

N.G.
Replace triple-pressure switch.

N.G.
Check 10A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

N.G.
Disconnect A/C switch harness connector.


E
(Go to next page.)

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES — Manual Air Conditioning


Diagnostic Procedure 6 (Cont'd)



O Note
 Check circuit continuity between thermo control amp. harness terminal No. (37) and A/C switch harness terminal No. (13).

O.K.
CHECK A/C SWITCH.
 (Refer to HA-65.)


N.G. → Replace A/C switch.



O.K.
 Disconnect fan switch harness connector.

O.K.
P Note
 Check circuit continuity between A/C switch harness terminal No. (12) and fan switch harness terminal No. (32).

O.K.
Q Note




CHECK BODY GROUND CIRCUIT FOR FAN SWITCH.
 Does continuity exist between fan switch harness terminal No. (104) and body ground?

O.K.
CHECK FAN SWITCH.
 (Refer to HA-65.)

N.G. → Replace fan switch.

Note:
 If the result is N.G. after checking circuit continuity, repair harness or connector.



Electrical Components Inspection

FAN SWITCH

Check continuity between terminals at each position.

TERMINAL	POSITION				
	OFF	1	2	3	4
28					○
29				○	○
30			○	○	○
31		○	○	○	○
32		○	○	○	○
104		○	○	○	○

GI

MA

EM


LC

EF &
EC

FE

CL

MT



BLOWER MOTOR

Check blower motor for smooth rotation.


- Ensure that there are no foreign particles inside the intake unit.

AT

FA

RA

BR




BLOWER RESISTOR

Check continuity between terminals.

ST

BF

HA



A/C SWITCH

Check continuity between terminals.


EL

TROUBLE DIAGNOSES – Manual Air Conditioning

Electrical Components Inspection (Cont'd)


THERMO CONTROL AMP.

1. Run engine, and operate A/C system.
2. Connect the voltmeter from harness side.
3. Check thermo control amp. operation shown in the table.




Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 2.5 - 3.5 (37 - 38)	Turn OFF	Approx. 12V
Increasing to 4.0 - 5.0 (39 - 41)	Turn ON	Approx. 0V

THERMAL PROTECTOR



Temperature of compressor °C (°F)	Operation
Increasing to approx. 145 - 155 (293 - 311)	Turn OFF
Decreasing to approx. 130 - 140 (266 - 284)	Turn ON

TRIPLE-PRESSURE SWITCH




	ON kPa (kg/cm ² , psi)	OFF kPa (kg/cm ² , psi)
Low-pressure side	157 - 226 (1.6 - 2.3, 23 - 33)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
Medium-pressure side*	1,422 - 1,618 (14.5 - 16.5, 206 - 235)	1,128 - 1,422 (11.5 - 14.5, 164 - 206)
High-pressure side	1,667 - 2,059 (17 - 21, 242 - 299)	2,452 - 2,844 (25 - 29, 356 - 412)

* For radiator fan motor operation.

A/C RELAY AND BLOWER HI RELAY

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of the relay.




TROUBLE DIAGNOSES – Manual Air Conditioning


Electrical Components Inspection (Cont'd)

FRESH VENT SWITCH

Check continuity between terminals.




Switch position	Terminal		
	9	10	100
Open	○	—	○
Closed	—	○	○



Control Linkage Adjustment


MODE DOOR

1. Move side link by hand and hold mode door in DEF mode.
2. Install mode door motor on heater unit and connect it to main harness.
3. Turn ignition switch to ON.
4. Turn VENT switch ON.
5. Attach mode door motor rod to side link rod holder.
6. Turn DEF switch ON. Check that side link operates at the fully-open position. Also turn DEF switch ON to check that side link operates at the fully-open position.



AIR MIX DOOR (Water cock)

1. Move air mix link by hand and hold air mix door in full cold position.
2. Install air mix door motor on heater unit and connect sub-harness.
3. Turn ignition switch to ON.
4. Slide temperature control lever to full cold.
5. Attach air mix door motor rod to air mix door link rod holder.
6. Check that air mix door and water cock operate properly when temperature control lever is slid to full hot and full cold.



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

TROUBLE DIAGNOSES – Manual Air Conditioning


Control Linkage Adjustment (Cont'd)

INTAKE DOOR



1. Connect intake door motor harness connector before installing intake door motor.
2. Turn ignition switch to ON.
3. Turn REC switch ON.
4. Install intake door motor on intake unit.
5. Install intake door lever.
6. Set intake door rod in REC position and fasten door rod to holder on intake door lever.
7. Check that intake door operates properly when REC switch is turned ON and OFF.




FRESH VENT DOOR





1. Connect fresh vent door motor harness connector before installing fresh vent door motor.
2. Turn ignition switch to ON.
3. Turn fresh vent switch OFF.
4. Install fresh vent door motor on heater unit.
5. Attach fresh vent door rod to fresh vent door link rod holder.
6. Check that fresh vent door operates properly when fresh vent switch is turned ON and OFF.

Self-diagnosis

During self-diagnosis, be certain that the fresh vent lever is in the "OFF" position.

The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from normal control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from "OFF" to "ON") and pressing "OFF" switch for at least 5 seconds. The "OFF" switch must be pressed within 10 seconds after starting the engine (ignition switch is turned "ON"). This system will be canceled by either pressing  switch or turning the ignition switch "OFF". Shifting from one step to another is accomplished by means of pushing  (HOT) or  (COLD) switch, as required.

Additionally shifting from STEP 5 to AUXILIARY MECHANISM is accomplished by means of pushing  (fan) switch.





Note:
Without engine running, STEP 4 and 5 are not useful for some case because compressor does not operate.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES – Auto Air Conditioning

Self-diagnosis (Cont'd)

CHECKING PROCEDURE













***1: Conduct self-diagnosis STEP 2 under sunshine.**
When conducting indoors, direct light (more than 60W) at sunload sensor or Code No. 25 will indicate despite that sunload sensor is functioning properly.

Code No.	Malfunctioning sensor (including circuits)
21	Ambient sensor
22	In-vehicle sensor
25	Sunload sensor*1
26	PBR

Note:
Without engine running, STEP 4 and 5 are not useful for some case because compressor does not operate.

TROUBLE DIAGNOSES – Auto Air Conditioning

Self-diagnosis (Cont'd)



Code No.	Malfunctioning mode and intake door motor position switch (including circuits)
31	VENT
32	B/L
34	FOOT
35	FOOT/DEF
36	DEF
37	REC
38	20% FRE
39	FRE

Code No.	Actuators test pattern					
	Mode door	Intake door	Air mix door	Fresh vent door	Blower motor	Compressor
41	VENT	REC	Full Cold	Open	4 - 5V	ON
42	B/L	REC	Full Cold	Open	9 - 11V	ON
43	B/L	20% FRE	Full Hot	Close	7 - 9V	ON
44	FOOT	FRE	Full Hot	Close	7 - 9V	OFF
45	F/D	FRE	Full Hot	Close	7 - 9V	OFF
46	DEF	FRE	Full Hot	Close	10 - 12V	ON




TROUBLE DIAGNOSES – Auto Air Conditioning


Self-diagnosis (Cont'd)

STEP 1: Checks LEDs and segments

When switch's LED and segments are in good order in STEP 1 mode, the corresponding LED and fluorescent display tube will illuminate.




RHA165D



RHA166D

If LEDs or segments malfunction, LED does not come on or display shows incomplete segment.



RHA167D


STEP 2: Checks each sensor circuit for open or short circuit

Display shows "2" in STEP 2 mode.

When all sensors are in good order, display shows "20".

It takes approximately 4 seconds to check all sensors.

If a circuit is shorted, display shows ECON mark blinks on display.



RHA501A

If two or more sensors malfunction, corresponding code Nos. respectively blink two times.

TROUBLE DIAGNOSES — Auto Air Conditioning

Self-diagnosis (Cont'd)

Sensors and abnormalities

If a circuit is opened or shorted, display shows its code No. when input corresponds with any of following conditions.

Code No.	Sensor	Open circuit	Short circuit
21	Ambient sensor	Less than -50°C (-58°F)	Greater than 75°C (167°F)
22	In-vehicle sensor	Less than -50°C (-58°F)	Greater than 75°C (167°F)
25	Sunload sensor*2	Less than 48.84 W/m ² (42 kcal)	Greater than 1,640 W/m ² (1,410 kcal)
26	PBR*1	Greater than 50%	Less than 30%

*1: "50%" and "30%" refer to percentage with respect to full stroke of air mix door. (Full cold: 0%, Full hot: 100%)

*2: **Conduct self-diagnosis STEP 2 under sunshine.**

When conducting indoors, direct light (more than 60W) at sunload sensor.

Display (when all doors are in good order) Illuminates 16 seconds after "3" is shown on display.

RHA496A

STEP 3: Checks mode door position

Display shows "3" in STEP 3 mode.

When all doors are in good order, display will then show "30".

It takes approximately 16 seconds to check all mode and intake doors.

Display (when a door is out of order) Code No. (blinks)

RHA168D

When abnormalities are detected, display shows a code No. corresponding with malfunctioning part.

Code No.	31	32	34	35	36
Malfunctioning part	VENT	B/L	FOOT	F/D	DEF

Each code No. blinks two times.

RHA498A

If two or more mode and intake doors are out of order, corresponding code numbers respectively blink two times.

If any mode and intake door motor position switch is malfunctioning, mode and intake door motor will also malfunction.


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES – Auto Air Conditioning

Self-diagnosis (Cont'd)


STEP 4: Checks operation of each actuator

Display shows "41" in STEP 4 mode.

When  (DEF) switch is pressed one time, display shows "42". Thereafter, each time the switch is pressed, display advances one number at a time, up to "45", then returns to "41".


During inspection in STEP 4 mode, be certain that the fresh vent lever is in the "OFF" position. The auto amplifier will forcefully transmit an output to the affected actuators in response to code No. shown on display, as indicated in table below.

Checks must be made visually, by listening to any noise, or by touching air outlets with your hand, etc. for improper operation.






Actuator	Code No.					
	41	42	43	44	45	46
Mode door	VENT	B/L	B/L	F/D 1	F/D 2	DEF
Intake door	REC	REC	20% FRE	FRE	FRE	FRE
Air mix door	Full Cold	Full Cold	Full Hot	Full Hot	Full Hot	Full Hot
Fresh vent door	OPEN	OPEN	CLOSE	CLOSE	CLOSE	CLOSE
Blower motor V	4 - 5	9 - 11	7 - 9	7 - 9	7 - 9	10 - 12
Compressor	ON	ON	ON	OFF	OFF	ON


Operating condition of each actuator cannot be checked by indicators.



STEP 5: Checks temperature detected by sensors


Display shows "5" in STEP 5 mode.

- When  (DEF) switch is pressed one time, display shows temperature detected by ambient sensor.
- When  (DEF) switch is pressed second time, display shows temperature detected by in-vehicle sensor.
- When  (DEF) switch is pressed third time, display returns to original presentation "5".



TROUBLE DIAGNOSES – Auto Air Conditioning

Self-diagnosis (Cont'd)



If temperature shown on display greatly differs from actual temperature, check sensor circuit at first then inspect sensor itself according to the procedures described in **Control System Input Components**. Refer to HA-114.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL


TROUBLE DIAGNOSES — Auto Air Conditioning

Self-diagnosis (Cont'd)

AUXILIARY MECHANISM: Temperature setting trimmer

This trimmer compensates for differences between temperature setting (displayed digitally) and temperature felt by driver in a range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$).

Operating procedures for this trimmer are as follows: Starting with STEP 5 under "Self-diagnostic mode", press  (fan) switch to set air conditioning system in auxiliary mode. Then, press either  (HOT) or  (COLD) switch as desired. Temperature will change at a rate of 0.5°C (1°F) each time a switch is pressed.



When battery cable is disconnected, trimmer operation is canceled and temperature set becomes that of initial condition, i.e. 0°C (0°F).

TROUBLE DIAGNOSES — Auto Air Conditioning

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE		Self-diagnosis					Preliminary Check								Diagnostic Procedure				
REFERENCE PAGE		HA-70, 72	HA-70, 72	HA-70, 73	HA-70, 74	HA-70, 74	HA-70, 76	HA-82	HA-83	HA-84	HA-85	HA-86	HA-87	HA-88	HA-95	HA-96	HA-97	HA-98	
SYMPTOM		STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	AUXILIARY MECHANISM	Preliminary Check 1	Preliminary Check 2	Preliminary Check 3	Preliminary Check 4	Preliminary Check 5	Preliminary Check 6	Preliminary Check 7	Preliminary Check 8	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4
Air outlet does not change.		①	②	○	○	○		③								○	○	○	○
Intake door does not change.		①	②		○	○			③							○	○	○	○
Insufficient cooling		○	○	○	○	○	○	○		①		○	○	○		○	○	○	○
Insufficient heating		○	○	○	○	○	○	○	○		①	○		○		○	○	○	○
Blower motor operation is malfunctioning.		①	②		○	○						③				○	○	○	○
Magnet clutch does not engage.		①	②		○	○							③			○	○	○	○
Discharged air temperature does not change.		①	②		○	○								③		○	○	○	○
Noise															①				
Result Self-diagnosis STEP 2	21	Ambient sensor circuit is open.		①	②											④			
	22	In-vehicle sensor circuit is open.		①	②												④		
	25	Sunload sensor circuit is open.		①	②														③
	26	PBR circuit is open.		①	②														

①, ②, ...: The number means checking order.

○: As for checking order, refer to each flow chart. (It depends on malfunctioning portion.)

TROUBLE DIAGNOSES – Auto Air Conditioning

Symptom Chart (Cont'd)

PROCEDURE		Self-diagnosis					Preliminary Check								Diagnostic Procedure				
REFERENCE PAGE		HA-70, 72	HA-70, 72	HA-70, 73	HA-70, 74	HA-70, 74	HA-70, 76	HA-82	HA-83	HA-84	HA-85	HA-86	HA-87	HA-88	HA-88	HA-95	HA-96	HA-97	HA-98
SYMPTOM		STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	AUXILIARY MECHANISM	Preliminary Check 1	Preliminary Check 2	Preliminary Check 3	Preliminary Check 4	Preliminary Check 5	Preliminary Check 6	Preliminary Check 7	Preliminary Check 8	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4
Result of Self-diagnosis STEP 2	ECON 21 Ambient sensor circuit is shorted.	①	②			③										④			
	ECON 22 In-vehicle sensor circuit is shorted.	①	②			③											④		
	ECON 25 Sunload sensor circuit is shorted.	①	②															③	
	ECON 26 PBR circuit is shorted.	①	②																③
Mode door motor does not operate normally.		①	②	③	④	○										○	○	○	○
Intake door motor does not operate normally.		①	②		③	○										○	○	○	○
Air mix door motor does not operate normally.		①	②		③	○										○	○	○	○
Fresh vent door does not operate normally.		①	②		③														
Blower motor operation is malfunctioning under out of Starting Fan Speed Control.		①	②		○	○						③				○	○	○	○
Magnet clutch does not operate after performing Preliminary Check 6.		①	②		○	○							③						
Self-diagnosis cannot be performed.																			

①, ②, ...: The number means checking order.


○: As for checking order, refer to each flow chart. (It depends on malfunctioning portion.)

Preliminary Check

PRELIMINARY CHECK 1

Air outlet does not change.

- Perform Self-diagnosis STEP 1 before referring to the flow chart.



TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 2

Intake door does not change.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.

CHECK SENSOR CIRCUIT.
Set up Self-diagnosis STEP 2.
Is each sensor circuit normal?
Code No. 20 should be indicated on the display after approx. 4 seconds later.

N.G.

CHECK SENSOR CIRCUIT IN DETAIL ACCORDING TO THE DIAGNOSTIC PROCEDURE BELOW CORRESPONDED TO EACH CODE NO.

Code No.	How to repair
21	Perform Diagnostic Procedure 1. Refer to HA-95.
22	Perform Diagnostic Procedure 2. Refer to HA-96.
25	Perform Diagnostic Procedure 3. Refer to HA-97.
26	Perform Diagnostic Procedure 4. Refer to HA-98.
ECON 21	Perform Diagnostic Procedure 1. Refer to HA-95.
ECON 22	Perform Diagnostic Procedure 2. Refer to HA-96.
ECON 25	Perform Diagnostic Procedure 3. Refer to HA-97.
ECON 26	Perform Diagnostic Procedure 4. Refer to HA-98.

When malfunctioning sensor circuits for ambient sensor and in-vehicle sensor are suspected, it is useful check temperature detected by each sensor with Self-diagnosis STEP 5 to confirm the temperature is within normal range before performing Diagnostic Procedures.

O.K.

CHECK INTAKE DOOR MOTOR OPERATION.
Set up Self-diagnosis STEP 4.
Does intake air change according to each code No.?

41	42	43	44	45	46
REC	REC	20% FRESH	FRESH	FRESH	FRESH

N.G.

CHECK INTAKE DOOR ROD or LEVER MECHANISM. Refer to HA-112.

N.G.

Repair or adjust.

O.K.

Perform **Diagnostic Procedure 6.**
Refer to HA-101.

O.K.

Intake door control system is normal. Refer to HA-120.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 3

Insufficient cooling




TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 4

Insufficient heating



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


TROUBLE DIAGNOSES – Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 5

Blower motor operation is malfunctioning.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.



N.G. CHECK SENSOR CIRCUIT IN DETAIL ACCORDING TO THE DIAGNOSTIC PROCEDURE BELOW CORRESPONDING TO EACH CODE NO.

Code No.	How to repair
21	Perform Diagnostic Procedure 1. Refer to HA-95.
22	Perform Diagnostic Procedure 2. Refer to HA-96.
25	Perform Diagnostic Procedure 3. Refer to HA-97.
26	Perform Diagnostic Procedure 4. Refer to HA-98.
ECON 21	Perform Diagnostic Procedure 1. Refer to HA-95.
ECON 22	Perform Diagnostic Procedure 2. Refer to HA-96.
ECON 25	Perform Diagnostic Procedure 3. Refer to HA-97.
ECON 26	Perform Diagnostic Procedure 4. Refer to HA-98.

When malfunctioning sensor circuits for ambient sensor and in-vehicle sensor are suspected, it is useful check temperature detected by each sensor with Self-diagnosis STEP 5 to confirm the temperature is within normal range before performing Diagnostic Procedures.

Perform **Diagnostic Procedure 9.**
Refer to HA-105.

TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 6

Magnet clutch does not engage.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.

CHECK SENSOR CIRCUIT.
Set up Self-diagnosis STEP 2.
Is each sensor circuit normal?
Code No. 20 should be indicated on the display after approx. 4 seconds.

N.G.

CHECK SENSOR CIRCUIT IN DETAIL ACCORDING TO THE DIAGNOSTIC PROCEDURE BELOW CORRESPONDING TO EACH CODE NO.

Code No.	How to repair
21	Perform Diagnostic Procedure 1. Refer to HA-95.
22	Perform Diagnostic Procedure 2. Refer to HA-96.
25	Perform Diagnostic Procedure 3. Refer to HA-97.
26	Perform Diagnostic Procedure 4. Refer to HA-98.
ECON 21	Perform Diagnostic Procedure 1. Refer to HA-95.
ECON 22	Perform Diagnostic Procedure 2. Refer to HA-96.
ECON 25	Perform Diagnostic Procedure 3. Refer to HA-97.
ECON 26	Perform Diagnostic Procedure 4. Refer to HA-98.

When malfunctioning sensor circuits for ambient sensor and in-vehicle sensor are suspected, it is useful check temperature detected by each sensor with Self-diagnosis STEP 5 to confirm the temperature is within normal range before performing Diagnostic Procedures.

O.K.

CHECK MAGNET CLUTCH OPERATION.
Set up Self-diagnosis STEP 4.
Does magnet clutch operate according to each code No.?

Actuator	Code No.					
	41	42	43	44	45	46
Compressor	ON	ON	ON	OFF	OFF	ON

N.G.

CHECK REFRIGERANT.
Connect manifold gauge, then check system pressure.

N.G.

Check refrigerant leaks.

O.K.

Perform **Diagnostic Procedure 10**.
Refer to HA-108.

O.K.

Magnet clutch control system is normal.
Refer to HA-124.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Preliminary Check (Cont'd)

PRELIMINARY CHECK 7

Discharged air temperature does not change.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.

CHECK SENSOR CIRCUIT.
Set up Self-diagnosis STEP 2.
Is each sensor circuit normal?
Code No. 20 should be indicated on the display after approx. 4 seconds later.

N.G.

CHECK SENSOR CIRCUIT IN DETAIL ACCORDING TO THE DIAGNOSTIC PROCEDURE BELOW CORRESPONDING TO EACH CODE NO.

Code No.	How to repair
21	Perform Diagnostic Procedure 1. Refer to HA-95.
22	Perform Diagnostic Procedure 2. Refer to HA-96.
25	Perform Diagnostic Procedure 3. Refer to HA-97.
26	Perform Diagnostic Procedure 4. Refer to HA-98.
ECON 21	Perform Diagnostic Procedure 1. Refer to HA-95.
ECON 22	Perform Diagnostic Procedure 2. Refer to HA-96.
ECON 25	Perform Diagnostic Procedure 3. Refer to HA-97.
ECON 26	Perform Diagnostic Procedure 4. Refer to HA-98.

When malfunctioning sensor circuits for ambient sensor and in-vehicle sensor are suspected, it is useful check temperature detected by each sensor with Self-diagnosis STEP 5 to confirm the temperature is within normal range before performing Diagnostic Procedures.

O.K.

CHECK AIR MIX DOOR OPERATION.
Set up Self-diagnosis STEP 4.
Does discharged air temperature change according to each code No.?

41	42	43	44	45	46
Full cold		Full hot			

O.K.

Air mix door control system is normal.
Refer to HA-116.

N.G.

CHECK AIR MIX DOOR MECHANISM.
Refer to HA-111.

N.G.

Repair or adjust.

O.K.

Perform **Diagnostic Procedure 7**. Refer to HA-102.


PRELIMINARY CHECK 8

Noise

Refer to HA-44.

Harness Layout for A/C System

Engine compartment




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

HA


TROUBLE DIAGNOSES — Auto Air Conditioning

Harness Layout for A/C System (Cont'd)

Passenger compartment



Circuit Diagram for Quick Pinpoint Check



- All connectors shown in this illustration are unit side connectors.
- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown in the "Harness Layout for A/C System". (Refer to HA-89, HA-90.)
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".


(N) : For Canada
 (OH) : Models without head-up display system
 (WH) : Models equipped with head-up display system

11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

GI
 MA
 EM
 LC
 FF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
HA
 EL


TROUBLE DIAGNOSES — Auto Air Conditioning

Wiring Diagram



TROUBLE DIAGNOSES – Auto Air Conditioning

Wiring Diagram (Cont'd)




GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
HA
 EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Main Power Supply and Ground Circuit Check POWER SUPPLY CIRCUIT CHECK FOR AUTO A/C SYSTEM

Check power supply circuit for auto air conditioning system.

Refer to EL section (“Wiring Diagram”, “POWER SUPPLY ROUTING”) and HA-92.




AUTO AMP. CHECK

Check power supply circuit for auto amp. with ignition switch ON.

1. Disconnect auto amp. harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑪, ⑫, ⑯ and body ground.


Voltmeter terminal		Voltage
⊕	⊖	
⑪	Body ground	Approx. 12V
⑫		
⑯		






Check body ground circuit for auto amp. with ignition switch OFF.

1. Disconnect auto amp. harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑳ and body ground.


Ohmmeter terminal		Continuity
⊕	⊖	
⑳	Body ground	Yes
⑳(Canada only)	Body ground	Yes








Diagnostic Procedure 1

SYMPTOM: Ambient sensor circuit is open or shorted. (\mathcal{Z} or $\text{ECON}_{\mathcal{Z}}$ is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL






Diagnostic Procedure 2

SYMPTOM: In-vehicle sensor circuit is open or shorted. (22 or ECON 22 is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)




Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 3






SYMPTOM: Sunload sensor circuit is open or shorted. (25 or ECON₂₅ is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)



Note:


If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL






Diagnostic Procedure 4

SYMPTOM: PBR circuit is open or shorted. (25 or ^{ECON}25 is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)



Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 5

SYMPTOM: Mode door motor does not operate normally.

- Perform Self-diagnosis STEPS 1 to 4 before referring to the following flow chart.

A

CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Set up code No. 41 in Self-diagnosis STEP 4.
2. Disconnect auto amp. harness connector after turning ignition switch OFF.
3. Check if continuity exists between terminal No. (22) or (31) of auto amp. harness connector and body ground.
4. Using above procedure, check for continuity in any other mode, as indicated in chart.

Code No.	Condition	Terminal No.		Continuity
		+	-	
41	VENT	(22) or (31)		Body ground Yes
42 or 43	B/L	(21) or (31)		
44	FOOT	(21) or (22)		
45	F/D	(30) or (22)		
46	DEF	(21) or (30)		

O.K. → INSPECTION END

N.G. → Disconnect mode door motor harness connector.

B Note
CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.
Does continuity exist between mode door motor harness terminal No. (101) and body ground?

O.K. → Reconnect auto amp. harness connector.

C CHECK POWER SUPPLY FOR MODE DOOR MOTOR CONTROL CIRCUIT.
Do approx. 5 volts exist between mode door motor harness terminals and body ground?

Terminal No.		Voltage
+	-	
(21)	Body ground	Approx. 5V
(30)		
(22)		
(36)		
(31)		
(14)		

O.K. → Reconnect mode door motor harness connector.

N.G. →




(A) (B)
(Go to next page.)

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 5 (Cont'd)



A

D

CHECK MODE DOOR MOTOR POSITION SWITCH.
Set up Self-diagnosis STEP 4.
Measure voltage across auto amp. harness terminals and body ground.

Code No.	Con- dition	Terminal No.				Body ground
		(22)	(31)	(21)	(30)	
41	VENT	0V	0V	5V	5V	Yes
42 or 43	B/L	5V	0V	0V	5V	
44	FOOT	0V	5V	0V	5V	
45	D/F	0V	5V	5V	0V	
46	DEF	5V	5V	0V	0V	

0V: Approx. 0V
5V: Approx. 5V

B

E

Note

Check circuit continuity between each terminal on auto amp. and on mode door motor.

Terminal No.		Continuity
+	-	
Auto amp. (22)	Mode door motor (30)	Yes
Auto amp. (30)	Mode door motor (30)	
Auto amp. (22)	Mode door motor (14 or 22)	
Auto amp. (21)	Mode door motor (21 or 36)	
Auto amp. (31)	Mode door motor (31)	

O.K. →

N.G. →

Replace mode door motor.

O.K. →

Replace auto amp.

F

CHECK FOR AUTO AMP. OUTPUT.
Do approx. 10.5 volts exist between auto amp. harness terminals No. (5) and (6) when code No. is switched from "41" to "42" or when code No. is switched from "46" to "41"?

Code No.	Mode door motor operation	Terminal No.		Voltage V
		(6)	(5)	
41	VENT	+	-	Approx. 10.5
→42	→ B/L	+	-	
46	DEF	-	+	0
→41	→ VENT	-	+	
-	Stop	-	-	




N.G. →

Replace auto amp.

O.K. →

Replace mode door motor.

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 6

SYMPTOM: Intake door motor does not operate normally.

- Perform Self-diagnosis STEPS 1, 2 and 4 before referring to the flow chart.

A Note

CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR.
Disconnect intake door motor harness connector.
Does continuity exist between intake door motor harness terminal No. (102) and body ground?

B Note

CHECK FOR AUTO AMP. OUTPUT.
Set up Self-diagnosis STEP 4.
Measure voltage across auto amp. harness terminals and body ground.

Code No.	Terminal No.		Condition	Voltage V
	+	-		
41	(23)	Body ground	REC	0
	(24)			12
42	(32)	Body ground	REC	12
	(23)			0
43	(24)	Body ground	20% REC	0
	(32)			0
44	(23)	Body ground	FRE	0
45	(24)			12
46	(32)			12

0V: Approx. 0V
12V: Approx. 12V

O.K.

Replace intake door motor.

C Note

Check circuit continuity between each terminal on auto amp. and on intake door motor.



Terminal No.		Continuity
+	-	
Auto amp. (23)	Intake door motor (23 or 37)	Yes
(24)	(24)	
(32)	(32)	

O.K.

Replace auto amp.

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL



Diagnostic Procedure 7





SYMPTOM: Air mix door motor does not operate normally.

- Perform Self-diagnosis STEPS 1, 2 and 4 before referring to the following flow chart.



Note:


If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 8

SYMPTOM: Fresh vent door motor does not operate normally.

- Perform Self-diagnosis STEP 4 before referring to the following flow chart.





Note: If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL






TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 8 (Cont'd)



Note:


If the result is N.G. after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 9

SYMPTOM: Blower motor operation is malfunctioning under out of Starting Fan Speed Control.

- Perform Preliminary Check 5 before referring to the following flow chart.




Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 9 (Cont'd)




A

Disconnect auto amp. and fan control amp. harness connector.

F Note

Does continuity exist between auto amp. harness terminal No. (10) and fan control amp. harness terminal No. (10)?

O.K.



G


CHECK POWER SUPPLY FOR BLOWER HI-RELAY.

Do approx. 12 volts exist between blower Hi-relay harness terminals No. (44), (46) and body ground?

N.G.

Check 10A or 20A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING") and HA-92.

O.K.



H Note

CHECK BODY GROUND CIRCUIT FOR BLOWER HI-RELAY.

Does continuity exist between blower Hi-relay harness terminal No. (103) and body ground?

O.K.

CHECK BLOWER HI-RELAY AFTER DISCONNECTING IT. (Refer to HA-66.)

N.G.

Replace blower Hi-relay.

O.K.

Reconnect blower Hi-relay.




B

(Go to next page.)

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 9 (Cont'd)








Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 10 (Cont'd)








GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

Note:
If the result is N.G. after checking circuit continuity, repair harness or connector.

TROUBLE DIAGNOSES — Auto Air Conditioning

Diagnostic Procedure 10 (Cont'd)




Note:

If the result is N.G. after checking circuit continuity, repair harness or connector.

Control Linkage Adjustment

MODE DOOR


1. Install mode door motor on heater unit and connect it to main harness.
2. Set up code No. 45 in Self-diagnosis STEP 4.
3. Move side link by hand and hold mode door in DEF mode.
4. Attach mode door motor rod to side link rod holder.
5. Make sure mode door operates properly when changing from code No. 41 to 45 by pushing DEF switch.




41	42	43	44	45	46
VENT	B/L	B/L	FOOT	F/D	DEF

AIR MIX DOOR (Water cock)

1. Install air mix door motor on heater unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4.
3. Move air mix door lever by hand and hold it in full cold position.
4. Attach air mix door lever to rod holder.
5. Make sure air mix door and water cock operate properly when changing from code No. 41 to 45 by pushing DEF switch.



41	42	43	44	45	46
Full cold			Full hot		




GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL

TROUBLE DIAGNOSES — Auto Air Conditioning


Control Linkage Adjustment (Cont'd)

INTAKE DOOR



1. Install intake door motor on intake unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4.
3. Move intake door link by hand and hold it in REC position.
4. Attach intake door lever to rod holder.
5. Make sure intake door operates properly when changing from code No. 41 to 45 by pushing DEF switch.

41	42	43	44	45	46
REC		20% FRE	FRE		




FRESH VENT DOOR

1. Install fresh vent door motor on heater unit and connect it to main harness.
2. Set up code No. 45 in self-diagnosis STEP 4.
3. Move fresh vent door link by hand and hold it in CLOSE position.
4. Attach fresh vent door lever to rod holder.
5. Make sure fresh vent door operates properly when changing from code No. 41 to 45 by pushing DEF switch.

41	42	43	44	45	46
OPEN			CLOSE		


Overview of Control System

The control system consists of a) input sensors and switches, b) the automatic amplifier (microcomputer), and c) outputs. The relationship of these components is shown in the diagram below:



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SYSTEM DESCRIPTION — Auto Air Conditioning



Control System Input Components

POTENTIO TEMPERATURE CONTROL (PTC)


The PTC is built into the auto amplifier. It can be set at an interval of 1°C (2°F) through both ▲ (HOT) and ▼ (COLD) control switches. Setting temperature is digitally displayed.

IN-VEHICLE SENSOR

The in-vehicle sensor is attached to cluster lid-C. It converts variations in temperature of compartment air drawn from an aspirator into a resistance value which is then input into the auto amplifier.


After disconnecting in-vehicle sensor harness connector, measure resistance between terminals ②⑤ and ④⑨ at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07



ASPIRATOR


The aspirator is located on heater unit. It produces vacuum pressure due to air discharged from the heater unit, continuously taking compartment air in the aspirator.



SYSTEM DESCRIPTION – Auto Air Conditioning

Control System Input Components (Cont'd)


AMBIENT SENSOR



The ambient sensor is attached to hood lock stay. It detects ambient temperature and converts it into a resistance value which is then input to the auto amplifier.

After disconnecting ambient sensor harness connector, measure resistance between terminals ③④ and ③⑨ at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
- 15 (5)	12.73
- 10 (14)	9.92
- 5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07



SUNLOAD SENSOR

The sunload sensor is located on the right defroster grille. It detects sunload entering through windshield by means of a photo diode and converts it into a current value which is then input to the auto amplifier.

Measure voltage between terminals ②⑥ and ③⑧ at vehicle harness side, using the table below.

Input current mA	Output voltage V
0	5.0
0.1	4.1
0.2	3.1
0.3	2.2
0.4	1.3
0.5	0.4

- When checking sunload sensor, select a place where sun shines directly on it.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

SYSTEM DESCRIPTION — Auto Air Conditioning



Control System Automatic Amplifier (Auto amp.)

The auto amplifier has a built-in microcomputer which processes information sent from various sensors needed for air conditioning operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled.

The auto amplifier is unitized with control mechanisms. Signals from various switches and Potentio Temperature Control (PTC) are directly entered into auto amplifier.

Self-diagnostic functions are also built into auto amplifier to provide quick check of malfunctions in the auto air conditioning system.

AMBIENT TEMPERATURE INPUT PROCESS

The automatic amplifier includes a “processing circuit” for the ambient sensor input. When the temperature detected by the ambient sensor increases quickly, the processing circuit allows the auto amp. to recognize an ambient temperature increase of only 0.2°C (0.4°F) per 100 seconds.

As an example, consider stopping for a cup of coffee after high speed driving. Even though the actual ambient temperature has not changed, the temperature detected by the ambient sensor will increase because heat radiated from the engine compartment can radiate to the front grille area (where the ambient sensor is located).

SUNLOAD INPUT PROCESS

The auto amp. also includes a processing circuit which “average” the variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.

Control System Output Components

AIR MIX DOOR CONTROL (Automatic temperature control)

Component parts

Air mix door control system components are:


- 1) Auto amplifier
- 2) Air mix door motor (PBR)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor

System operation


Temperature set by Potentio Temperature Control (PTC) is compensated through setting temperature correction circuit to determine target temperature. Auto amplifier will operate air mix door motor to set air conditioning system in HOT or COLD position, depending upon relationship between conditions (target temperature, sunload, in-vehicle temperature and ambient temperature) and conditions (air mix door position and compressor operation).

SYSTEM DESCRIPTION – Auto Air Conditioning

Control System Output Components (Cont'd)



Air mix door control specification





SYSTEM DESCRIPTION — Auto Air Conditioning

Control System Output Components (Cont'd)

AIR MIX DOOR MOTOR

The air mix door motor is attached to the heater unit. It rotates so that the air mix door is opened to a position set by the auto amplifier. Motor rotation is then conveyed through a shaft and air mix door position is then fed back to the auto amplifier by PBR built-in air mix door motor.




Air mix door operation

7	8	Air mix door operation	Direction of lever movement
⊕	⊖	COLD → HOT	Clockwise (Toward passenger compartment)
⊖	⊖	STOP	STOP
⊖	⊕	HOT → COLD	Counterclockwise (Toward engine compartment)

PBR

Measure voltage between terminals ②⑦ and ③③ at vehicle harness side.



PBR characteristics

SYSTEM DESCRIPTION — Auto Air Conditioning

Control System Output Components (Cont'd)

OUTLET DOOR CONTROL


Component parts

Outlet door control system components are:

- 1) Auto amplifier
- 2) Mode door motor
- 3) PBR
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor


System operation

The auto amplifier computes the air outlet conditions according to the ambient temperature and the in-vehicle temperature. The computed outlet conditions are then corrected for sunload to determine the air outlets through which air is discharged into the passenger compartment.



AHA133

Outlet door control specification




AHA134

SYSTEM DESCRIPTION — Auto Air Conditioning


Control System Output Components (Cont'd)

MODE DOOR MOTOR

The mode door motor is attached to the heater unit. It rotates so that air is discharged from outlet set by the auto amplifier. Motor rotation is conveyed to a link which activates the mode door.



6	5	Mode door operation	Direction of side link rotation
⊕	⊖	VENT → DEF	Clockwise
⊖	⊖	STOP	STOP
⊖	⊕	DEF → VENT	Counterclockwise



INTAKE DOOR CONTROL


Components parts

Intake door control system components are:

- 1) Auto amplifier
- 2) Intake door motor
- 3) PBR
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor

System operation



The intake door control determines intake door position based on the ambient temperature and the in-vehicle temperature. When the ECON, DEF, or OFF buttons are pushed, the auto amplifier sets the intake door at the "Fresh" position.



SYSTEM DESCRIPTION — Auto Air Conditioning

Control System Output Components (Cont'd)

Intake door control specification




INTAKE DOOR MOTOR

The intake door motor is attached to the heater unit. It rotates so that air is drawn from inlets set by the auto amplifier. Motor rotation is conveyed to a lever which activates the intake door.

Intake door motor operation

3	4	Intake door operation	Movement of link rotation
⊕	⊖	REC → FRE	Clockwise
⊖	⊖	STOP	STOP
⊖	⊕	FRE → REC	Counterclockwise



SYSTEM DESCRIPTION – Auto Air Conditioning

Control System Output Components (Cont'd)

FAN SPEED CONTROL

Component parts

Fan speed control system components are:


- 1) Auto amplifier
- 2) Fan control amplifier
- 3) PBR
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor
- 7) Blower Hi-relay
- 8) ECM (ECCS control module) (Engine coolant temperature sensor)

System operation

AUTOMATIC MODE

In the automatic mode, the blower motor speed is calculated by the automatic amplifier based on inputs from the PBR, in-vehicle sensor, sunload sensor, and ambient sensor. The blower motor applied voltage ranges from approximately 4.5 volts (lowest speed) to 12 volts (highest speed).

To control blower speed (in the range of 4.5V to 10.5V), the automatic amplifier supplies a signal to the thermo control amplifier. Based on this signal, the thermo control amplifier controls the current flow from the blower motor to ground. If the computed blower voltage (from the automatic amplifier) is above 10.5 volts, the high blower relay is activated. The high blower relay provides a direct path to ground (bypassing the blower amplifier), and the blower motor operates at high speed.



STARTING FAN SPEED CONTROL

Start up from "COLD SOAK" condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 50°C (122°F), the blower will not operate for a short period of time (up to 180 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient) the blower starting delay will be 180 seconds. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 50°C (122°F), at which time the blower speed will increase to the objective speed.

Start up from normal or "HOT SOAK" condition (Automatic mode)

The blower will begin operation momentarily after the AUTO button is pushed. The blower speed will gradually rise to the objective speed over a time period of 5 seconds or less (actual time depends on the objective blower speed).

SYSTEM DESCRIPTION — Auto Air Conditioning



Control System Output Components (Cont'd)

BLOWER SPEED COMPENSATION

Sunload

When the in-vehicle temperature and the set temperature are very close, the blower will be operating at low speed. The low speed will vary depending on the sunload. During conditions of high sunload, the blower low speed is "normal" low speed (approx. 5.5V). During low or no sunload conditions, the low speed will drop to "low" low speed (approx. 4.5V).

Fan speed control specification





FAN CONTROL AMPLIFIER

The fan control amplifier is located on the cooling unit. It amplifies a 12-step base current flowing from the auto amplifier to change the blower speed within the range of 5V to 10.5V. Above 10.5 volts, the high relay applies a direct ground to the blower motor.

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

SYSTEM DESCRIPTION — Auto Air Conditioning

Control System Output Components (Cont'd)




BLOWER HI-RELAY

The blower Hi-relay is located on the intake unit. It receives a signal from the auto amplifier to operate the blower motor at high speed.

MAGNET CLUTCH CONTROL

The ECM (ECCS control module) controls compressor operation using inputs from the throttle position sensor and auto amplifier.



Low temperature protection control

The auto amplifier will signal the ECM (ECCS control module) to turn the compressor "ON" or "OFF" based on the signal supplied to the auto amplifier by the ambient temperature sensor.

Acceleration cut control

The ECM (ECCS control module) will turn the compressor "ON" or "OFF" based on the signal from the throttle position sensor.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COMPRESSOR

Model	DKV-14C
Type	Vane rotary
Displacement cm ³ (cu in)/Rev	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	Poly V type

LUBRICATION OIL

Model	ZEXEL make DKV-14C
Name	Nissan A/C System Oil Type R
Part No.	KLH00-RAGR0
Capacity ml (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Compressor (Service part) charging amount	200 (6.8, 7.0)

REFRIGERANT

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.70 - 0.80 (1.54 - 1.76)

Inspection and Adjustment

ENGINE IDLING SPEED

When A/C is ON

- Refer to EF & EC section ("Inspection and Adjustments", "SERVICE DATA AND SPECIFICATIONS").

BELT TENSION

- Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

COMPRESSOR

Model	DKV-14C
Clutch disc-pulley clearance mm (in)	0.3 - 0.6 (0.012 - 0.024)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

ELECTRICAL SYSTEM

SECTION **EL**

CONTENTS

PRECAUTIONS	2	HEADLAMP	26
Precautions for Supplemental Restraint System		Wiring Diagram (For USA)	26
“AIR BAG”	2	Schematic (For Canada)	27
HARNESS CONNECTOR	3	Wiring Diagram (For Canada)	28
Description	3	Bulb Replacement	29
STANDARDIZED RELAY	4	Aiming Adjustment	29
Description	4	Low Beam	29
POWER SUPPLY ROUTING	6	Adjustment After Headlamp Assembly	
Wiring Diagram	6	Replacement	30
Fuse	8	EXTERIOR LAMP	31
Fusible Link	8	Clearance, License, Tail and Stop	
BATTERY	9	Lamps/Wiring Diagram	31
How to Handle Battery	9	Back-up Lamp/Wiring Diagram	32
Methods Of Preventing Discharge	9	Front Fog Lamp/Wiring Diagram	33
Checking Electrolyte Level	10	Turn Signal and Hazard Warning Lamps/Wiring	
Specific Gravity Check	10	Diagram	34
Hydrometer temperature correction	11	Cornering Lamp/Wiring Diagram	35
Charging The Battery	11	Flasher Module Check	36
Voltage chart	13	Bulb Specifications	36
Service Data and Specifications (SDS)	13	INTERIOR LAMP	37
STARTING SYSTEM	14	Illumination/Wiring Diagram	37
Wiring Diagram	14	Interior, Personal and Trunk Room	
M/T models for USA	14	Lamps/Wiring Diagram	38
A/T models and CANADA M/T models	15	METER AND GAUGES – Without Head-up	
STARTING SYSTEM – Starter –	16	Display –	39
Pinion/Clutch Check	17	Combination Meter	39
Service Data and Specifications (SDS)	17	METER AND GAUGES – With Head-up	
CHARGING SYSTEM	18	Display –	40
Wiring Diagram	18	Combination Meter	40
Trouble-shooting	19	METER AND GAUGES – Without Head-up	
CHARGING SYSTEM – Generator –	20	Display –	42
Construction	20	Speedometer, Tachometer, Temp. and Fuel	
Diode Check	21	Gauges/Wiring Diagram	42
Assembly	22	METER AND GAUGES – With Head-up	
Service Data and Specifications (SDS)	23	Display –	43
COMBINATION SWITCH	24	Speedometer, Tachometer, Temp. and Fuel	
Combination Switch/Check	24	Gauges/Wiring Diagram	43
Combination Switch/Replacement	25	METER AND GAUGES	44

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

CONTENTS (Cont'd.)

Inspection/Fuel Gauge and Water Temperature Gauge	44	Active Speaker System	73
Inspection/Tachometer	45	Except Active Speaker System	74
Inspection/Speedometer and Vehicle Speed Sensor	46	Power Antenna/Wiring Diagram	75
Inspection/Speedometer and Fuse	47	Location of Antenna	76
Fuel Tank Gauge Unit Check	48	Antenna Rod Replacement	77
Fuel Warning Lamp Sensor Check	48	Window Antenna Repair	78
Thermal Transmitter Check	48	AUTOMATIC SPEED CONTROL DEVICE (ASC) ...	79
Oil Pressure Switch Check	49	Component Parts and Harness Connector	
Vehicle Speed Sensor Signal Check	49	Location	79
WARNING LAMPS AND CHIME	50	Wiring Diagram	80
Warning Lamps/Schematic	50	Schematic	81
Warning Lamps/Wiring Diagram	51	Trouble Diagnoses	82
Warning Chime/Wiring Diagram	52	Symptom Chart	82
Diode Check	53	Diagnostic Procedure 1	83
Warning Chime Check	53	Diagnostic Procedure 2	85
TIME CONTROL SYSTEM	54	Diagnostic Procedure 3	85
Description	54	Diagnostic Procedure 4	85
Function	54	Diagnostic Procedure 5	86
Wiring Diagram	55	Diagnostic Procedure 6	87
Trouble Diagnoses	56	Diagnostic Procedure 7	88
Symptom Chart	56	Diagnostic Procedure 8	89
Circuit Diagram For Quick Pinpoint Check	57	ASC Wire Adjustment	90
Preliminary Check	58	Electrical Components Inspection	91
Preliminary check 1	58	ASC actuator/ASC pump	91
Preliminary check 2	58	ASC main switch	92
Preliminary check 3	58	ASC steering switch	92
Main Power Supply And Ground Circuit		ASC cancel switch and stop lamp switch ...	92
Check	59	ASC clutch pedal position switch (For	
Diagnostic Procedure 1	60	M/T models)	92
Diagnostic Procedure 2	61	Inhibitor switch (For A/T models)	93
Diagnostic Procedure 3	61	Vehicle speed sensor	93
Diagnostic Procedure 4	62	THEFT WARNING SYSTEM	94
Diagnostic Procedure 5	63	Component Parts and Harness Connector	
Diagnostic Procedure 6	64	Location	94
Diagnostic Procedure 7	65	Wiring Diagram	96
Diagnostic Procedure 8	65	Trouble Diagnoses	98
WIPER AND WASHER	66	System Operation Check	98
Front Wiper and Washer/Wiring Diagram	66	Circuit Diagram For Quick Pinpoint Check	100
Installation	67	Power Supply And Ground Circuit Check	102
Washer Nozzle Adjustment	68	Main power supply circuit check	102
HORN, CIGARETTE LIGHTER, CLOCK	69	Power supply circuit check for system	
Wiring Diagram	69	cancel	102
REAR WINDOW DEFOGGER	70	Ground circuit check	102
Wiring Diagram	70	Diagnostic Procedure 1	103
Filament Check	71	Diagnostic procedure 1-(1)	103
Filament Repair	72	Diagnostic procedure 1-(2)	104
AUDIO AND POWER ANTENNA	73	Diagnostic procedure 1-(3)	105
Audio/Wiring Diagram	73	Diagnostic procedure 1-(4)	106
		Diagnostic Procedure 2	107
		Diagnostic Procedure 3	108

CONTENTS (Cont'd.)

Diagnostic Procedure 4..... 109	Engine Compartment 120	
Diagnostic Procedure 5..... 110	Passenger Compartment 122	GI
Diagnostic Procedure 6..... 111	Main Harness 124	
Diagnostic Procedure 7..... 112	Body Harness..... 126	MA
Diagnostic Procedure 8..... 113	MFI Harness..... 128	
Electrical Components Inspection..... 114	Engine Harness No. 2 130	EM
Door switches..... 114	Room Lamp Harness..... 131	
Hood switch..... 114	Air Bag Harness..... 132	LC
Trunk room lamp switch 114	Tail Harness 133	
Key cylinder switch 115	Door Harness (LH side)..... 134	EF & EC
Indicator lamp (security lamp) 115	Front..... 134	
Door unlock sensor..... 115	Rear 134	FE
LOCATION OF ELECTRICAL UNITS 117	Door Harness (RH side) 135	
Engine Compartment..... 117	Front..... 135	CL
Passenger Compartment..... 118	Rear 135	
HARNESS LAYOUT 119	SUPER MULTIPLE JUNCTION (SMJ) 137	
Outline 119	Terminal Arrangement 138	MT
Engine Room Harness 120	JOINT CONNECTOR (J/C) 139	AT

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system)	EF & EC SECTION	FA
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM.....	AT SECTION	
ABS	BR SECTION	RA
POWER WINDOW AND POWER DOOR LOCK, AUTOMATIC		
SEAT BELT SYSTEM, SUN ROOF, DOOR MIRROR.....	BF SECTION	BR
HEATER AND AIR CONDITIONING.....	HA SECTION	ST

PRECAUTIONS



Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control module, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS
















1M 1 Make 2M 2 Make
 1T 1 Transfer 1M·1B 1Make 1 Break



SEL882H

STANDARDIZED RELAY


Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				<p style="text-align: center;">BLACK</p>
1M				<p style="text-align: center;">BLUE, GREEN or YELLOW</p>
2M				<p style="text-align: center;">BROWN</p>
1M-1B				<p style="text-align: center;">GRAY</p>
1M				<p style="text-align: center;">BLUE</p>


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

POWER SUPPLY ROUTING

Wiring Diagram



POWER SUPPLY ROUTING Wiring Diagram (Cont'd)




* : 10A-Models without active speaker
15A-Models with active speaker

(WH) : Models with head-up display system


GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL

POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.



Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness, or vinyl or rubber parts.

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

EL




How to Handle Battery

METHODS OF PREVENTING DISCHARGE


The following precautions must be taken to prevent battery discharge.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- During every routine maintenance, check the electrolyte level.**

This also applies to batteries designated as “low maintenance” and “maintenance-free”.



- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the condition of the battery by checking the specific gravity of the electrolyte.

BATTERY

How to Handle Battery (Cont'd)


CHECKING ELECTROLYTE LEVEL

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.


- Remove the vent cap using a suitable tool.
- Add distilled water up to the MAX level.



SULPHATION


When a battery has been left unattended for a long period of time and has a specific gravity of less than 1.100, it will be completely discharged, resulting in sulphation on the cell plates.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.



- When electrolyte level is too low, tilt battery case to raise it for easy measurement.

BATTERY

How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

BATTERY

How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to **initial** charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.
- After the battery is charged, always perform a "capacity test" as follows, to assure that the battery is serviceable.



BATTERY

How to Handle Battery (Cont'd)

- Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT
(Load tester)

Type	Current (A)
35	225
24R	260



Voltage chart

Estimated electrolyte temperature °C (°F)	Minimum voltage under 15 second load
21 (70)	9.6
16 (60)	9.5
10 (50)	9.4
4 (40)	9.3
-1 (30)	9.1
-7 (20)	8.9
-12 (10)	8.7
-18 (0)	8.5

Service Data and Specifications (SDS)


Applied model	USA	USA option and Canada
Type	35	24R
Capacity	V-AH 12-48	12-55

GI
MA
EM
LC
EF & EC
FE
SEL008Z
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

STARTING SYSTEM

Wiring Diagram


M/T models for USA



STARTING SYSTEM

Wiring Diagram (Cont'd)

A/T models and CANADA M/T models




GI
MA
EM
LC
FF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

STARTING SYSTEM — Starter —

M1T73881ZC


Plate thickness:
0.25 (0.0098)
0.50 (0.0197)



SEL197R

- | | | |
|-------------------|----------------------------|------------------|
| ① Sleeve bearing | ⑧ Adjusting plate | ⑮ Armature |
| ② Gear case | ⑨ Magnetic switch assembly | ⑯ Sleeve bearing |
| ③ Pinion stopper | ⑩ Internal gear | ⑰ Brush (+) |
| ④ Pinion assembly | ⑪ Shaft | ⑱ Brush spring |
| ⑤ Shift lever | ⑫ Planetary gear | ⑲ Brush (-) |
| ⑥ Plate | ⑬ Packing | ⑳ Brush holder |
| ⑦ Packing | ⑭ Yoke | ㉑ Rear cover |

S114-754



SEL198R

- | | | |
|----------------------|----------------------------|----------------------|
| ① Pinion stopper | ⑧ Planetary gear | ⑮ Center bracket (A) |
| ② Pinion gear | ⑨ Internal gear | ⑯ Yoke assembly |
| ③ Gear case | ⑩ Shift lever | ⑰ Armature assembly |
| ④ Clutch assembly | ⑪ Dust cover | ⑱ Brush holder |
| ⑤ Thrust washer | ⑫ Return spring | ⑲ Rear cover |
| ⑥ Center bracket (P) | ⑬ Adjusting plate | |
| ⑦ Pinion shaft | ⑭ Magnetic switch assembly | |

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident. ... Replace.

GI
MA
EM
LC

Service Data and Specifications (SDS)

STARTER

EF &
EC

Type	M1T73881ZC		S114-754	
	MELMAC		HAP	
	Reduction gear type			
Applied model	A/T		M/T	
System voltage	V	12		
No-load				
Terminal voltage	V	11.0		
Current	A	Less than 88	Less than 85	
Revolution	rpm	More than 3,000	More than 2,950	
Minimum diameter of commutator	mm (in)	28.8 (1.134)	28.0 (1.102)	
Minimum length of brush	mm (in)	12.0 (0.472)	10.5 (0.413)	
Brush spring tension	N (kg, lb)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	14.7 - 17.7 (1.5 - 1.8, 3.3 - 4.0)	
Clearance of bearing metal and armature shaft	mm (in)	—	0.03 - 0.3 (0.0012 - 0.0118)	
Clearance "ℓ" between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	0.05 - 1.5 (0.0020 - 0.0591)	
Installed current	A	140	120	

FE
CL
MT
AT
FA
RA
BR
ST
BF
HA




Trouble-shooting

Before conducting an generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The generator can be checked easily by referring to the Inspection Table.

Before starting trouble-shooting, inspect the fusible link.


WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light
G.C.G. : Generator parts except IC regulator
IC-RG : IC regulator
O.K. : IC-generator is in good condition.
- 3) When reaching "Damaged G.C.G.", remove generator from vehicle and disassemble, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Gasoline engine model

Contact tip of wire with brush and attach wire to generator body.




SEL030Z

- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of generator.

CHARGING SYSTEM — Generator —

Construction

LR180-736B



SEL287R

- ① Pulley assembly
- ② Front cover
- ③ Front bearing
- ④ Retainer

- ⑤ Rotor
- ⑥ Slip ring
- ⑦ Stator
- ⑧ Condenser

- ⑨ IC regulator assembly
- ⑩ Brush holder
- ⑪ Diode assembly
- ⑫ Rear cover


Diode Check

MAIN DIODES


- In order to check diodes, they must be unsoldered from the stator.
- Use an ohmmeter to check condition of diodes as indicated in chart below.
- If any of the test results is not satisfactory, replace diode assembly.

	Ohmmeter probes		Judgement
	Positive ⊕	Negative ⊖	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Positive diode plate	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Negative diode plate	


Type 1




Type 4




Type 2




Type 5



Type 3



Type 6



SEL039Z

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

Assembly

Carefully observe the following instructions.

- When soldering each stator coil lead wire to diode assembly terminal, carry out the operation as fast as possible.




RING FITTING IN REAR BEARING

- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.

CAUTION:


Do not reuse rear bearing after removal.



REAR COVER INSTALLATION

- (1) Fit brush assembly, diode assembly, regulator assembly and stator.
- (2) Push brushes up with fingers and install them to rotor.

Take care not to damage slip ring sliding surface.



Service Data and Specifications (SDS)

GENERATOR

Type		LR180-736B	GI
		HAP	
Nominal rating	V-A	12-80	MA
Ground polarity		Negative	
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000	EM
Hot output current (When 13.5 volts is applied)	A/rpm	More than 23/1,300 More than 63/2,500 More than 77/5,000	LC
Regulated output voltage	V	14.1 - 14.7	EF & EC
Minimum length of brush	mm (in)	6.0 (0.236)	
Brush spring pressure	N (g, oz)	1.000 - 2.452 (102 - 250, 3.60 - 8.82)	
Slip ring minimum diameter	mm (in)	26.0 (1.024)	FE
Rotor (Field coil) resistance	Ω	2.67	

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST



BF

HA

EL

COMBINATION SWITCH

Combination Switch/Check



LIGHTING SWITCH


	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5			○				○	○	○
6			○				○	○	○
7									○
8			○				○	○	○
9			○				○	○	○
10									○
11				○	○	○	○	○	○
12				○	○	○	○	○	○

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○	○		
15	○				
16		○		○	
17	○	○	○	○	
18					○

ASCD SWITCH

	RESUME ACCEL	SET COAST	CANCEL
1	○	○	○
2	○	○	○
3	○	○	○



TURN SIGNAL SWITCH


	R	N	L
1	○	○	○
2	○	○	○
3			○

CORNERING LAMP SWITCH


	R	N	L
61	○	○	○
62	○	○	○
63			○

FRONT FOG LAMP SWITCH

	OFF	ON
2	○	○
1		○




COMBINATION SWITCH



Combination Switch/Replacement

- Each switch can be replaced without removing combination switch base.



- To remove combination switch base, remove base attaching screws.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


HEADLAMP

Wiring Diagram (For USA)



HEADLAMP


Schematic (For Canada)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

HEADLAMP

Wiring Diagram (For Canada)





SEL995K

Bulb Replacement


The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Disconnect the harness connector from the back side of the bulb.
3. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
4. Pull off the rubber cap.
5. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
6. Install in the reverse order of removal.

CAUTION:

Do not leave the bulb out of the headlamp reflector for a long period of time as dust, moisture, smoke, etc. may enter the headlamp body and affect the performance of the headlamp. Thus, the headlamp bulb should not be removed from the headlamp reflector until just before a replacement bulb is to be installed.




AEL116

Aiming Adjustment

Before performing aiming adjustment, make sure of the following.


- a. Keep all tires inflated to correct pressure.
- b. Place vehicle on level ground.
- c. See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.



AEL242

LOW BEAM

1. Open the hood.
2. Adjust the vertical indicator by turning the adjusting screw. The bubble in the gauge should be centered on the "o" mark as shown in the illustration.



AEL243

3. Adjust the horizontal indicator by turning the adjusting screw with a Philips screwdriver. The inner red line with the "o" mark should align with the indicator line. Never turn screw (A).

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

HEADLAMP


Aiming Adjustment (Cont'd)

ADJUSTMENT AFTER HEADLAMP ASSEMBLY REPLACEMENT

If the vehicle has had front body repair and the headlamp assembly has been replaced, the aiming should be checked using the aiming chart as shown in the illustration.


- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in the illustration.**
- Dotted lines in illustration show center of headlamp.**
 - "H": Horizontal center line of headlamps
 - "W_L": Distance between each headlamp center
 - "L": 7,620 mm (300.00 in)
 - "C": 106 mm (4.17 in)

Even if the horizontal indicator does not align with the indicator line or the water level bubble is not centered in the gauge after aiming by the chart, it is acceptable if they are within the O.K. ranges.



EXTERIOR LAMP


Cornering Lamp/Wiring Diagram



(U) : For U. S. A.
 (N) : For Canada
 J/C : Joint connector
 (Refer to last page.)

GI
 MA
 EM
 LC
 FF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL

EXTERIOR LAMP



Flasher Module Check


- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the flasher module, as shown. Flasher module is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (12 volt)	Bulb No.
Headlamp (Semi-sealed beam)		
High/Low	60/55	HB2
Front turn signal lamp	27	1156NA
Cornering lamp/Front clearance lamp	27/5	1157
Front side marker lamp	3.8	194
Front fog lamp	55	
Rear combination lamp		
Turn signal	27	1156
Stop/Tail	27/8	1157
Back-up	27	1156
Rear side marker lamp	3.8	194
License plate lamp	5	168
High-mounted stop lamp	13	912
Interior lamp	10	
Front personal lamp	10	
Trunk room lamp	3.4	158

INTERIOR LAMP

Illumination/Wiring Diagram




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



EL

INTERIOR LAMP

Interior, Personal and Trunk Room Lamps/Wiring Diagram



Combination Meter




1	2	3	4	5	6
7	8	9	10	11	12

19
20
21
22
23



25	26	27	28	29
30	31	32	34	

35	36	37	38	39
40	41	42	43	44




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

METER AND GAUGES — With Head-up Display — Combination Meter (Cont'd)




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram







Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


Inspection/Fuel Gauge and Water Temperature Gauge



METER AND GAUGES



Inspection/Tachometer








GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

Inspection/Speedometer and Vehicle Speed Sensor




SYMPTOM: Speedometer stays at 0 km/h (0 MPH).



METER AND GAUGES


Inspection/Speedometer and Vehicle Speed Sensor (Cont'd)

SYMPTOM: Speedometer indication flutters.



Inspection/Speedometer and Fuse

SYMPTOM: Speedometer does not go back to 0 km/h (0 MPH).




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

METER AND GAUGES

Fuel Tank Gauge Unit Check

- For removal, refer to FE section ("Fuel Pump and Gauge", "FUEL SYSTEM").


Check the resistance between terminals (G) and (E).



Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm	(in)	
G	E	*3	Full	80.5 (3.169)
		*2	1/2	29.4 (1.157)
		*1	Empty	19.0 (0.748)


Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.




Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.



Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω


METER AND GAUGES



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transaxle.
2. Turn speedometer pinion quickly and measure voltage across ① and ②.

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


WARNING LAMPS AND CHIME

Warning Lamps/Schematic




WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram




WARNING LAMPS AND CHIME

Warning Chime/Wiring Diagram



WARNING LAMPS AND CHIME



Diode Check


- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

GI

MA

EM

LC



- Diodes for warning lamps are built into the combination meter printed circuit.

Refer to EL-39 and EL-40.


EF &
EC

FE

CL

MT

Warning Chime Check



AT

FA

RA

BR

ST

BF

HA

EL

TIME CONTROL SYSTEM

Description

FUNCTION


- Time control module has the following functions.

Item		Details of control
1, 2	Intermittent wiper control	Regulates intermittent time from approximately 1 to 20 seconds depending on the intermittent wiper volume setting.
3	Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
4	Light warning chime timer	When driver's door is opened with lighting switch ON and ignition switch OFF, warning chime sounds.
5	Ignition key warning chime timer	When driver's door is opened with ignition switch OFF, warning chime sounds.
6*	Seat belt warning chime timer	Sounds warning chime for about 7 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).
7*	Seat belt warning lamp timer	Seat belt warning lamp blinks for about 7 seconds when ignition switch is turned to "ON".
8	Rear defogger timer	Rear defogger operates for about 15 minutes when defogger switch is ON.

*: Vehicles without automatic seat belt system.

TIME CONTROL SYSTEM

Wiring Diagram



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

TIME CONTROL SYSTEM

Trouble Diagnoses

SYMPTOM CHART


PROCEDURE		Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure							
		EL-58	EL-58	EL-58		EL-59	EL-60	EL-61	EL-61	EL-62	EL-63	EL-64	EL-65
REFERENCE PAGE		EL-58	EL-58	EL-58	EL-59	EL-60	EL-61	EL-61	EL-62	EL-63	EL-64	EL-65	EL-65
SYMPTOM		Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8
Wiper & washer	Intermittent wiper does not operate.				○	○							
	Intermittent time of wiper cannot be adjusted.						○						
	Wiper and washer activate individually but not in combination.							○					
Warning	Light warning chime does not activate.	○			○				○				
	Ignition key warning chime does not activate.		○		○					○			
	Seat belt warning chime does not activate.*			○	○						○		
	Seat belt warning lamp does not come on, or does not go off after coming on.*				○							○	
Rear defogger	Rear defogger does not activate, or go off after activating.				○								○

*: Vehicles without automatic seat belt system.

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL


TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3

- Seat belt warning chime does not activate.





TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply



Terminals	Battery positive voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑨ - ⑮	Yes	Yes	Yes
⑤ - ⑮	No	No	Yes
② - ⑮	No	Yes	Yes

Ground circuit

Terminals	Continuity
⑮ - Ground	Yes

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



EL

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.




A

WIPER RELAY OUTPUT SIGNAL CHECK

- 1) Turn ignition switch to "ACC".
- 2) Turn wiper switch to "INT" or "OFF".
- 3) Measure voltage between control module harness terminals ① and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	Pointer swings from 0 to 12 every 3 to 23 seconds





B

INTERMITTENT SWITCH INPUT SIGNAL CHECK

Measure voltage between control module harness terminals ⑫ and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	0




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.



A


INTERMITTENT WIPER VOLUME INPUT SIGNAL CHECK
Measure resistance between control module harness terminals (14) and (15) while turning intermittent wiper volume.

Position of wiper knob	Resistance [Ω]
S	0
L	Approx. 1 k

O.K. → **TRY A KNOWN GOOD CONTROL MODULE.***

N.G. ↓

Check intermittent wiper volume.
Check harness continuity between control module and wiper switch.



DIAGNOSTIC PROCEDURE 3


SYMPTOM: Wiper and washer activate individually but not in combination.

A

WASHER SWITCH INPUT SIGNAL CHECK
1) Turn ignition switch to "ACC".
2) Measure voltage between control module harness terminals (13) and (15).

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0

N.G. → Check harness continuity between control module and washer switch.



O.K. ↓

B

TIME CONTROL MODULE SIGNAL CHECK
Measure voltage between control module harness terminals (1) and (15) after operating washer switch.
0V for approx. 3 seconds after washer has operated.

N.G. → **TRY A KNOWN GOOD CONTROL MODULE.***

O.K. ↓

Check wiper relay and circuit.

N.G. → Repair wiper circuit or replace wiper relay.

*: Time control module may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL





TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Light warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 1" before referring to the following flow chart.



*: Time control module may be the cause of a problem, but this is rarely the case.




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Ignition key warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 2" before referring to the following flow chart.



A Step 3

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control module harness terminals (18) and (15).

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	0

N.G. Check door switch. Check harness continuity between control module and door switch.

B Step 2

CHIME OUTPUT SIGNAL CHECK
Measure voltage between control module harness terminals (19) and (15).

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	Pointer deflects intermittently

O.K. Check chime. Check harness continuity between control module and chime.

C Step 1

IGNITION KEY SWITCH INPUT SIGNAL CHECK
Measure voltage between control module harness terminals (10) and (15).

Condition	Voltage [V]
Key is inserted	Approx. 12
Key is pulled	0

N.G. Check ignition key switch. Check harness continuity between control module and ignition key switch.

O.K. **TRY A KNOWN GOOD CONTROL MODULE.***

*: Time control module may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Seat belt warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 3" before referring to the following flow chart.



A Step 2

SEAT BELT SWITCH INPUT SIGNAL CHECK

Check continuity between control module harness terminals (16) and (19).

Condition	Continuity
Unfastened	Yes
Fastened	No

N.G. Check seat belt switch. Check harness continuity between control module and seat belt switch.

O.K.

B Step 1

CHIME OUTPUT SIGNAL CHECK

- 1) Connect control module harness connector.
- 2) Turn ignition switch "ON".
- 3) Measure voltage between control module harness terminals (19) and (15).

Condition of seat belt	Voltage [V]
Unfastened	Pointer deflects intermittently
Fastened	Approx. 12

O.K. Check chime. Check harness continuity between control module and chime.

N.G.

TRY A KNOWN GOOD CONTROL MODULE.*


*: Time control module may be the cause of a problem, but this is rarely the case.

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Seat belt warning lamp does not come on, or does not go off after coming on.



A


WARNING LAMP OUTPUT SIGNAL CHECK

- 1) Connect control module harness connector.
- 2) Turn ignition switch "ON", after connecting control module harness terminals (16) and (15).
- 3) Does voltmeter needle keep swinging for about 7 seconds after ignition switch has been turned "ON"?

Yes → Check warning lamp.
Check harness continuity between control module and warning lamp.

No ↓

TRY A KNOWN GOOD CONTROL MODULE.*



DIAGNOSTIC PROCEDURE 8

SYMPTOM: Rear defogger does not activate, or does not go off after activating.


A

REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK
Measure voltage between control module harness terminals (4) and (15).

Condition of defogger switch	Voltage [V]
Defogger switch is "OFF"	Approx. 12
Defogger switch is "ON"	0

O.K. → Check rear window defogger relay.
Check rear window defogger circuit.

N.G. ↓



B

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK

- 1) Disconnect control module harness connector.
- 2) Check continuity between control module harness terminals (3) and (15).

Condition of defogger switch	Continuity
Defogger switch is "OFF"	No
Defogger switch is "ON"	Yes

N.G. → Check rear window defogger switch.
Check harness continuity between control module and rear window defogger switch.

O.K. ↓

TRY A KNOWN GOOD CONTROL MODULE.*

*: Time control module may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram



WIPER AND WASHER

Installation



1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L".

Clearance "L": 27 - 41 mm (1.06 - 1.61 in)

- Tighten windshield wiper arm nuts to specified torque.


Windshield wiper:

21 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)




- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER AND WASHER




Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.
Adjustable range: $\pm 10^\circ$



HORN, CIGARETTE LIGHTER, CLOCK

Wiring Diagram




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA





EL

REAR WINDOW DEFOGGER

Wiring Diagram



REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.
2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL




- When measuring voltage, wind a piece of tin foil around the top of the negative probe and press the foil against the wire with your finger.

REAR WINDOW DEFOGGER

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth



REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.


3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Audio/Wiring Diagram

ACTIVE SPEAKER SYSTEM




GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL

AUDIO AND POWER ANTENNA


Audio/Wiring Diagram (Cont'd)

EXCEPT ACTIVE SPEAKER SYSTEM



AUDIO AND POWER ANTENNA

Power Antenna/Wiring Diagram



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

AUDIO AND POWER ANTENNA

Location of Antenna





MEL358B

AUDIO AND POWER ANTENNA

Antenna Rod Replacement


REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


Window Antenna Repair

ELEMENT CHECK


1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.



2. If an element is broken, no continuity will exist.



3. To locate broken point, move probe to left and right along element to determine point where tester needle swings abruptly.





ELEMENT REPAIR

Refer to EL-72.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Component Parts and Harness Connector Location



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic



GI
MA
EM
LC
FF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

SYMPTOM CHART




PROCEDURE	Diagnostic Procedure								—	Electrical Components Inspection						
REFERENCE PAGE	EL-83	EL-85	EL-85	EL-85	EL-86	EL-87	EL-88	EL-89	EL-90	EL-91	EL-92	EL-92	EL-92	EL-92	EL-92	EL-93
SYMPTOM	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD Wire Adjustment	ASCD actuator/ASCD pump	ASCD switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	Clutch pedal position switch (M/T models)	Inhibitor switch (A/T models)	Vehicle speed sensor
ASCD control module cannot be set properly.	<input type="radio"/>									<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Engine hunts.		<input type="radio"/>							<input type="radio"/>	<input type="radio"/>						
Large difference between set speed and actual vehicle speed.			<input type="radio"/>						<input type="radio"/>	<input type="radio"/>						
Deceleration is greatest immediately after ASCD has been set.				<input type="radio"/>					<input type="radio"/>	<input type="radio"/>						
ACCEL switch will not operate.	<input type="radio"/>				<input type="radio"/>							<input type="radio"/>				
RESUME switch will not operate.	<input type="radio"/>					<input type="radio"/>						<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Set speed cannot be cancelled.							<input type="radio"/>		<input type="radio"/>	<input type="radio"/>			<input type="radio"/>	<input type="radio"/>		
"CRUISE" indicator lamp blinks.								<input type="radio"/>		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>			

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: ASCD control cannot be set.



Turn ASCD switch "OFF" and "ON" to make sure indicator illuminates.

A CHECK POWER SUPPLY FOR ASCD SWITCH.

1. Disconnect switch harness connector.
2. Do approx. 12 volts exist between switch harness terminal ① and body ground?

No

Check fuse and harness.

Yes

CHECK ASCD SWITCH. Refer to EL-92. CHECK ASCD HOLD RELAY.

O.K.

B CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL MODULE.

1. Turn ASCD switch "ON".
2. Check voltage between control module harness terminals ④ and ③.

Battery positive voltage should exist.

N.G.

Check continuity between control module harness terminal ④ and ASCD hold relay.

O.K.

C CHECK CUT-OFF CIRCUIT FOR ASCD CONTROL MODULE.

Check voltage between control module harness terminals ⑤ and ③.

Battery positive voltage should exist.

N.G.

CHECK ASCD CANCEL SWITCH, ASCD CLUTCH PEDAL POSITION SWITCH (M/T models) AND INHIBITOR SWITCH (A/T models). Refer to EL-92. CHECK INHIBITOR RELAY (A/T models).

O.K.

Ⓐ (Next page)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST





BF

HA

EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

SYMPTOM: Engine hunts.




DIAGNOSTIC PROCEDURE 3

SYMPTOM: Large difference between set vehicle speed and actual speed.



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Deceleration is greatest immediately after ASCD has been set.






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: ACCEL switch will not operate.



Check constant-speed function for operating using SET/COAST switch.

N.G. → Perform "DIAGNOSTIC PROCEDURE 1". Refer to EL-83.

O.K. ↓

A

Check voltage between control module harness terminals ① and ③ after turning on and holding RESUME/ACCEL switch.

Battery positive voltage should exist.

O.K. ↓

N.G. → CHECK ASCD STEERING SWITCH. Refer to EL-92.

B

Check voltage between control module harness terminals ① and ③ after releasing RESUME/ACCEL switch.

Voltage is 0V.

O.K. ↓

N.G. → CHECK ASCD STEERING SWITCH. Refer to EL-92.

C

Does vehicle accelerate when RESUME/ACCEL switch is turned on?

No → Replace control module.

Yes ↓

Does vehicle maintain the new (faster) speed when RESUME/ACCEL switch is released?

No → Replace control module.

Yes ↓






System is O.K.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: RESUME switch will not operate.



Check constant-speed function for operation using SET/COAST switch.

N.G. Perform "DIAGNOSTIC PROCEDURE 1". Refer to EL-83.

O.K.

A Check voltage between control module harness terminals ① and ③ after turning on and holding RESUME/ACCEL switch.

Battery positive voltage should exist.

N.G.

O.K.

B Check voltage between control module harness terminals ① and ③ after releasing RESUME/ACCEL switch.

Voltage is 0V.

N.G.

O.K.

CHECK ASCD STEERING SWITCH.
Refer to EL-92.

C Set vehicle speed at 80 km/h (50 MPH) by turning on SET/COAST switch.

O.K.

D While cruising at set speed, depress and release brake pedal.

O.K.

Does speed control disengage and "CRUISE" lamp turn off?

No **CHECK STOP LAMP SWITCH, ASCD CANCEL SWITCH AND ASCD CLUTCH PEDAL POSITION SWITCH (M/T models).**
Refer to EL-92.

Yes

E Above 48 km/h (30 MPH), press and release "RESUME/ACCEL switch."

O.K.

Does vehicle return to previously set speed [80 km/h (50 MPH)]?

No **Replace control module.**

Yes

System is O.K.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA


EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Set speed cannot be cancelled.



A

CHECK ASCD CANCEL, CLUTCH PEDAL POSITION, INHIBITOR SWITCH CIRCUIT.


1. Turn ASCD switch on.
2. Check voltage between control module harness terminals ⑤ and ③.

N.G.

CHECK ASCD CANCEL, CLUTCH PEDAL POSITION, and INHIBITOR SWITCH. Refer to EL-92.

Conditions		Voltage [V]
M/T	ASCD cancel switch	Depressed: 0 Released: Approx. 12
	ASCD clutch pedal position switch	Depressed: 0 Released: Approx. 12
A/T	A/T shift lever position is at any position except N or P.	Approx. 12
	A/T shift lever position is at N or P.	0

O.K.



B

CHECK STOP LAMP SWITCH CIRCUIT. Check voltage between control module harness terminals ⑪ and ③.

N.G.

CHECK STOP LAMP SWITCH. Refer to EL-92.

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

O.K.

Check ASCD wire moves smoothly.

N.G.

Replace ASCD wire.

O.K.

CHECK ASCD ACTUATOR/ASC PUMP. Refer to EL-91.

N.G.

Replace ASCD actuator assembly.

O.K.



Replace ASCD control module.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: "CRUISE" indicator lamp blinks.



AEL161

Terminals	Resistance [Ω]	
⑧	⑨	Approx. 8 - 45
	⑩	Approx. 65
	⑭	Approx. 65


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD WIRE ADJUSTMENT



AEL162

CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Confirm that accelerator wire is properly adjusted and adjust tension of ASCD wire in the following manner.

- (1) After adjusting the length of ASCD wire, turn adjusting nut counterclockwise 1/2 to 1 turn from closed throttle position. (Must be carried out to prevent response delay of operation of the ASCD.)
 - (2) Securely tighten lock nut to hold adjusting nut in place.
- For ASCD cancel switch and clutch pedal position switch adjustment, refer to BR and CL sections ("Adjustment", "BRAKE PEDAL AND BRACKET" and "Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT", respectively).






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


ASCD main switch

Check continuity between terminals by pushing switch to each position.



AEL167

Switch position	Terminal					
	1	2	3	4	5	6
ON	○	○	○	○		
N		○	○	○		ILL. ○
OFF						




AEL168

ASCD steering switch

Check continuity between terminals by pushing each button.

Button	Terminal		
	1	2	3
SET/COAST	○	○	
RESUME/ACCEL	○		○
CANCEL	○	▶	○
	○	▶	○




AEL169

ASCD cancel switch and stop lamp switch

Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").



AEL235

ASCD clutch pedal position switch (For M/T models)


Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Check switch after adjusting clutch pedal — refer to CL section ("Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT").


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Inhibitor switch (For A/T models)



Shift lever position	Terminal		
	3	4	6
"P"	○	○	
"N"	○		○
Except "N" or "P"			



Vehicle speed sensor

- 1 Remove vehicle speed sensor from transaxle.
- 2 Turn speedometer pinion quickly and measure voltage across ② and ①.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST









BF

HA

EL

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location



THEFT WARNING SYSTEM

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

THEFT WARNING SYSTEM

Wiring Diagram




THEFT WARNING SYSTEM

Trouble Diagnoses


SYSTEM OPERATION CHECK

If ignition switch is set in the "ACC" position in the step of START to ARMED or in the ARMED state shown in this flow chart, the system operation is canceled.



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK


Main power supply circuit check

Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑩	Battery positive voltage	Battery positive voltage	Battery positive voltage




Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
③ - ⑩	0V	Battery positive voltage	Battery positive voltage



Ground circuit check

Terminals	Continuity
⑩ - Ground	Yes






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: ● Indicator lamp does not blink.
● Indicator lamp remains blinking.

Diagnostic procedure 1-(1)





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(2)



A

HOOD SWITCH INPUT SIGNAL CHECK
Check continuity between control module harness terminals (15) and (16).

Condition	Continuity
Hood is open	Yes
Hood is closed	No

O.K. → Perform Diagnostic Procedure 2. Refer to EL-107.

N.G.

Check hood switch and hood fitting condition.

N.G. → Adjust installation of hood switch or hood.

O.K.

HOOD SWITCH CHECK
Refer to EL-114.

N.G. → Replace hood switch.

O.K.

B

HOOD SWITCH CIRCUIT CHECK

- Check harness continuity between control module harness terminal (15) and hood switch harness terminal.
- Check harness continuity between hood switch terminal and body ground.

Continuity should exist.

N.G. → Repair harness or connectors.




O.K.

CHECK THE CONNECTIONS AT EACH CONNECTOR.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)



GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)









THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Indicator lamp does not blink.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA


EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Indicator lamp does not come on.



A

DOOR UNLOCK SENSOR INPUT SIGNAL CHECK
Check continuity between control module harness terminals ⑨ and ⑯.

Condition	Continuity
Driver's door	
Locked	No
Unlocked	Yes
Except driver's door	
All locked	No
At least one is unlocked	Yes

O.K. → Perform Diagnostic Procedure 4. Refer to EL-109.

O.K. ↓

Replace control module.

N.G. ↓

DOOR UNLOCK SENSOR CHECK
Refer to EL-115.

N.G. → Replace door lock actuator.

O.K. ↓

B


DOOR UNLOCK SENSOR CIRCUIT CHECK

- Check harness continuity between control module harness terminal ⑨ and door lock actuator terminal.
 - Check harness continuity between door lock actuator terminal and body ground.
- Continuity should exist.**

N.G. → Repair harness or connectors.

O.K. ↓

CHECK THE CONNECTIONS AT EACH CONNECTOR.






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.













GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Alarm does not operate.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: STARTER MOTOR can be operated. (Starter killed phase)



STARTER MOTOR KILL OUTPUT SIGNAL CHECK
 Check voltage between control module harness terminals ④ and ⑯ when ignition switch is turned to ON or "START".

Approx. 12V

Replace control module.

Approx. 0 volt

Check theft warning relay-1 and circuit.

N.G.

Replace theft warning relay-1.

O.K.

Repair harness between control module and clutch interlock relay (M/T models) or inhibitor switch (A/T models).

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA



EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.



A

KEY CYLINDER SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)
Check continuity between control module harness terminals ⑪ and ⑫.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

O.K. → Replace control module.

N.G.

KEY CYLINDER SWITCH CHECK
Refer to EL-115.

N.G. → Replace key cylinder switch.

O.K.

B

KEY CYLINDER SWITCH CIRCUIT CHECK

- Check harness continuity between control module harness terminal ⑪ and key cylinder switch terminal.
- Check harness continuity between key cylinder switch terminal and body ground.

Continuity should exist.

N.G. → Repair harness or connectors.

O.K.



CHECK THE CONNECTIONS AT EACH CONNECTOR.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Alarm does not stop even if stop signal is given.



A

TRUNK KEY CYLINDER SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)

Check continuity between control module harness terminals (10) and (16).

O.K. → Replace control module.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

N.G. → TRUNK KEY CYLINDER SWITCH CHECK
Refer to EL-115.

N.G. → Replace trunk key cylinder switch.

O.K. →

B

TRUNK KEY CYLINDER SWITCH CIRCUIT CHECK

- Check harness continuity between control module harness terminal (10) and trunk key cylinder switch terminal.
- Check harness continuity between trunk key cylinder switch terminal and body ground.

N.G. → Repair harness or connectors.

O.K. → CHECK THE CONNECTIONS AT EACH CONNECTOR.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)


ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminal (a) and switch body.




Terminal	Pushed	Released
a		○
switch body		○



Hood switch

Check continuity between terminals when hood switch is pushed and released.

Terminal	Pushed	Released
a		○
b		○



Trunk room lamp switch

Terminal	Trunk lid	
	Closed	Open
a		○
b		○

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



Key cylinder switch

Door

	TAMPER SWITCH		DOOR LOCK SWITCH		DOOR UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral	Between full stroke and neutral	Full stroke
1				○			
2						○	
3		○					
4		○		○			○


Trunk

	TAMPER SWITCH		Trunk lid unlock switch		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral
1				○	
2		○			
3		○		○	



Indicator lamp (security lamp)

Check if it lights when 12V is supplied.



Door unlock sensor

	LOCK	UNLOCK
1		○
2		○





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

THEFT WARNING SYSTEM

NOTE

LOCATION OF ELECTRICAL UNITS

Engine Compartment



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL


LOCATION OF ELECTRICAL UNITS

Passenger Compartment



HARNES LAYOUT

Outline




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

HARNESS LAYOUT

Engine Room Harness

ENGINE COMPARTMENT



HARNES LAYOUT

Engine Room Harness (Cont'd)

Engine room harness

- E1 : ASCD actuator
- E2 : Brake fluid level switch
- E3 : Joint connectors 3-6
- E4 : Actuator (For ABS)
- E5 : Actuator (For ABS)
- E6 : Actuator (For ABS)
- E7 : Body ground (For ABS)
- E8 : Front sensor LH (For ABS)
- E9 : Dropping resistor (A/T models)
- E10 : Hood switch (For theft warning system)
- E11 : Battery
- E12 : Body ground
- E13 : Fusible link and fuse box
- E14 : Relay box-2
- E15 : To E213
- E16 : To E214
- E17 : To E215
- E18 : Air conditioning triple-pressure switch
- E19 : Radiator fan motor-1
- E20 : Radiator fan motor-2
- E21 : Front side marker lamp LH
- E22 : Front fog lamp LH (For standard fog lamp models)
- E23 : Front turn signal lamp LH
- E24 : Headlamp LH
- E25 : Clearance and cornering lamp LH (XE-L models)
- E26 : Clearance lamp LH
- E27 : Horn
- E28 : Ambient sensor
- E29 : Clearance lamp RH
- E30 : Clearance and cornering lamp RH (XE-L models)
- E31 : Headlamp RH
- E32 : Front turn signal lamp RH
- E33 : Front fog lamp RH (For standard fog lamp models)
- E34 : Front side marker RH
- E35 : Compressor
- E36 : Front fog lamp sub-harness (For optional fog lamp models)
- E37 : Body ground
- E38 : Washer level switch
- E39 : Washer motor
- E40 : Relay box-1
- E41 : Body ground
- E42 : Generator
- E43 : Generator
- E44 : Generator

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

HARNESS LAYOUT

Engine Room Harness (Cont'd)

PASSENGER COMPARTMENT



EL-122

HARNES LAYOUT

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

HARNES LAYOUT

Main Harness (Cont'd)


Main harness

- (M1) : Theft warning control module (For theft warning system)
- (M2) : Circuit breaker-1
- (M3) : Circuit breaker-2
- (M4) : To (E106)
- (M5) : To (E107)
- (M6) : To (B1) (SMJ)
- (M7) : To (E108) (SMJ)
- (M8) : To (D1)
- (M8) : To (D2)
- (M10) : To (D3)
- (M11) : Fuse block
- (M12) : Rear window defogger relay
- (M13) : Clutch pedal position switch (M/T models for USA)
- (M14) : ASCD clutch pedal position switch (M/T models)
- (M15) : Data link connector for CONSULT
- (M16) : To (R1)
- (M17) : ASCD switch
- (M18) : Mirror switch
- (M19) : Illumination control switch
- (M20) : ASCD control module
- (M21) : Shift lock control module (A/T models)
- (M22) : Door lock timer
- (M23) : ASCD cancel switch
- (M24) : Stop lamp switch
- (M25) : Hazard switch
- (M26) : Auto air conditioning unit
- (M27) : Auto air conditioning unit
- (M28) : Push control module
- (M29) : Push control module
- (M30) : Air conditioner switch
- (M31) : Potentio temperature control
- (M32) : Fan switch
- (M33) : Clock
- (M34) : Flasher module
- (M35) : Air mix door motor
- (M36) : Mode door motor
- (M37) : Time control module
- (M38) : Rear window defogger switch
- (M39) : Fresh vent switch
- (M40) : In-vehicle sensor
- (M41) : Combination meter
- (M42) : Combination meter
- (M43) : Combination meter
- (M44) : Combination meter
- (M45) : Head-up display control module
- (M46) : CD player
- (M47) : Radio
- (M48) : Radio
- (M49) : To (F23)
- (M50) : To (F24)
- (M51) : Body Ground
- (M52) : Cigarette lighter illumination
- (M53) : Cigarette lighter
- (M54) : Ashtray illumination
- (M55) : Blower HI - relay
- (M56) : Thermo control amp.
- (M57) : Glove box lamp
- (M59) : Fresh vent door motor
- (M59) : To (F21)
- (M60) : To (F22)
- (M61) : Automatic seat belt control module (For USA)
- (M62) : Automatic seat belt control module (For USA)
- (M63) : Joint connector-7 (With audio amp. for USA)
- (M64) : Joint connector-8 (With audio amp. for Canada)
- (M65) : Joint connector-9 (With audio amp. for Canada)
- (M66) : To (A2)
- (M67) : Fan control amp.
- (M68) : Glove box lamp switch
- (M69) : Intake door motor
- (M70) : Sunload sensor
- (M71) : To pillar sub-harness (Without audio amp. for USA)
- (M72) : To pillar sub-harness (With audio amp. for USA)
- (M73) : To pillar sub-harness (With audio amp. for Canada)
- (M74) : To (D51)
- (M75) : To (D52)
- (M76) : Body ground
- (M77) : Body ground
- (M78) : Fan resistor
- (M79) : Blower motor
- (M80) : Daytime light control module (For Canada)
- (M81) : TCM (A/T control module)
- (M82) : To (B31)

Engine Compartment

- (M101) : Power steering pressure switch
- (M102) : Front sensor RH (For ABS)
- (M103) : Body ground (For ABS)
- (M104) : Wiper motor
- (M105) : Horn (For theft warning system)


Diode (In joint connector-8 (M64)
In joint connector-9 (M65))



GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL

HARNESS LAYOUT

Body Harness



HARNES LAYOUT

Body Harness (Cont'd)


- (B1) : To (M6) (SMJ)
- (B3) : Front door switch LH (Driver's side)
- (B4) : Rear limit switch and shoulder belt buckle switch LH (For USA)
- (B5) : Drive motor LH (For USA)
- (B6) : Body ground
- (B7) : To (D107)
- (B8) : Lap belt buckle switch and shoulder belt locking canceler LH (For USA)
- (B9) : Seat belt switch (For Canada)
- (B10) : Shift lock solenoid, detention switch and A/T illumination (A/T models)
- (B11) : Parking brake switch
- (B12) : Shoulder belt locking canceler RH (For USA)
- (B13) : Front door switch RH (Passenger side)
- (B14) : Body ground
- (B15) : To (D151)
- (B16) : Rear limit switch and shoulder belt buckle switch RH (For USA)
- (B17) : Drive motor RH (For USA)
- (B18) : To (B107)
- (B19) : Fuel pump
- (B20) : Fuel tank gauge unit
- (B21) : Rear window defogger condenser
- (B22) : Rear door switch LH
- (B23) : To (T1)
- (B24) : Trunk room lamp
- (B25) : Rear speaker LH
- (B26) : Front speaker amp.
- (B27) : Rear speaker amp.
- (B28) : High-mounted stop lamp (Without rear air spoiler)
- (B29) : Rear speaker RH
- (B30) : Rear door switch RH
- (B31) : To (M82)
- (B32) : Diode (For Canada)
- (B101) : To (B19)
- (B102) : Rear sensor LH (For ABS)
- (B103) : Rear sensor RH (For ABS)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

HARNESS LAYOUT

MFI Harness



Engine ground

HARNES LAYOUT

MFI Harness (Cont'd)

MFI harness

- (F1) : Oxygen sensor
- (F2) : Crankshaft position sensor
- (F3) : Mass air flow sensor
- (F4) : Power transistor
- (F5) : Revolution sensor (A/T models)
- (F6) : To terminal cord assembly (A/T models)
- (F7) : Ignition coil
- (F8) : Resistor & condenser
- (F9) : Throttle position switch
- (F10) : Throttle position sensor
- (F11) : EGR temperature sensor
- (F12) : EGR control-solenoid valve


- (F13) : Injector No. 1
- (F14) : Injector No. 2
- (F15) : Injector No. 3
- (F16) : Injector No. 4
- (F17) : Engine ground
- (F18) : To (E205)
- (F19) : ECM (ECCS control module)
- (F20) : ECM relay
- (F21) : To (M59)
- (F22) : To (M60)
- (F23) : To (M49)
- (F24) : To (M50)

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

HARNES LAYOUT

Engine Harness No. 2




Engine harness No. 2

- E200** : Thermal transmitter
- E201** : Engine coolant temperature sensor
- E202** : IAC valve-FICD solenoid valve & IAC valve-AAC valve
- E203** : Oil pressure switch
- E204** : To (F18)
- E205** : Knock sensor
- E206** : Starter motor
- E207** : Starter motor
- E208** : Starter motor
- E209** : Vehicle speed sensor
- E210** : Position switch (M/T models)
- E211** : Inhibitor switch (A/T models)
- E212** : Inhibitor switch (A/T models)
- E213** : To (E15)
- E214** : To (E16)
- E215** : To (E17)
- E216** : Battery

HARNES LAYOUT

Room Lamp Harness




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


HARNESS LAYOUT

Air Bag Harness



HARNESS LAYOUT

Tail Harness



- (T1) : To E28
- (T2) : Automatic seat belt G sensor
- (T3) : Rear side marker lamp LH
- (T4) : Rear combination lamp LH
- (T5) : License lamp LH
- (T6) : License lamp RH
- (T7) : Body ground


- (T8) : Trunk key cylinder switch
- (T9) : Trunk room lamp switch
- (T10) : Rear combination lamp RH
- (T11) : Rear side marker lamp RH
- (T12) : Power antenna
- (T13) : High-mounted stop lamp (With rear air spoiler)

- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**


HARNESS LAYOUT

Door Harness (LH side)

FRONT




REAR




HARNESS LAYOUT

FRONT

Door Harness (RH side)



REAR




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL

HARNES LAYOUT


NOTE

SUPER MULTIPLE JUNCTION (SMJ)




INSTALLATION

To install SMJ, tighten bolts until orange “fulltight” mark appears and then retighten to specified torque as required.

: 3 - 5 N·m
(0.3 - 0.5 kg-m, 2.2 - 3.6 ft-lb)

CAUTION:





Do not overtighten bolts, otherwise, they may be damaged.



SUPER MULTIPLE JUNCTION (SMJ)

Terminal Arrangement


MAIN HARNESS



ENGINE ROOM HARNESS


BODY HARNESS

ECM (ECCS control module)



View from harness side


TCM (A/T control module)




View from harness side

JOINT CONNECTOR (J/C)


Location



Terminal Arrangement



1993 NISSAN STANZA ALTIMA
CIRCUIT DIAGRAM



INCH TO METRIC CONVERSION TABLE

(Rounded-off for automotive use)

inches	mm	inches	mm
.100	2.54	.610	15.49
.110	2.79	.620	15.75
.120	3.05	.630	16.00
.130	3.30	.640	16.26
.140	3.56	.650	16.51
.150	3.81	.660	16.76
.160	4.06	.670	17.02
.170	4.32	.680	17.27
.180	4.57	.690	17.53
.190	4.83	.700	17.78
.200	5.08	.710	18.03
.210	5.33	.720	18.29
.220	5.59	.730	18.54
.230	5.84	.740	18.80
.240	6.10	.750	19.05
.250	6.35	.760	19.30
.260	6.60	.770	19.56
.270	6.86	.780	19.81
.280	7.11	.790	20.07
.290	7.37	.800	20.32
.300	7.62	.810	20.57
.310	7.87	.820	20.83
.320	8.13	.830	21.08
.330	8.38	.840	21.34
.340	8.64	.850	21.59
.350	8.89	.860	21.84
.360	9.14	.870	22.10
.370	9.40	.880	22.35
.380	9.65	.890	22.61
.390	9.91	.900	22.86
.400	10.16	.910	23.11
.410	10.41	.920	23.37
.420	10.67	.930	23.62
.430	10.92	.940	23.88
.440	11.18	.950	24.11
.450	11.43	.960	24.38
.460	11.68	.970	24.64
.470	11.94	.980	24.89
.480	12.19	.990	25.15
.490	12.45	1.000	25.40
.500	12.70	2.000	50.80
.510	12.95	3.000	76.20
.520	13.21	4.000	101.60
.530	13.46	5.000	127.00
.540	13.72	6.000	152.40
.550	13.97	7.000	177.80
.560	14.22	8.000	203.20
.570	14.48	9.000	228.60
.580	14.73	10.000	254.00
.590	14.99	20.000	508.00
.600	15.24		

METRIC TO INCH CONVERSION TABLE

(Rounded-off for automotive use)

mm	inches	mm	inches
1	.0394	51	2.008
2	.079	52	2.047
3	.118	53	2.087
4	.157	54	2.126
5	.197	55	2.165
6	.236	56	2.205
7	.276	57	2.244
8	.315	58	2.283
9	.354	59	2.323
10	.394	60	2.362
11	.433	61	2.402
12	.472	62	2.441
13	.512	63	2.480
14	.551	64	2.520
15	.591	65	2.559
16	.630	66	2.598
17	.669	67	2.638
18	.709	68	2.677
19	.748	69	2.717
20	.787	70	2.756
21	.827	71	2.795
22	.866	72	2.835
23	.906	73	2.874
24	.945	74	2.913
25	.984	75	2.953
26	1.024	76	2.992
27	1.063	77	3.031
28	1.102	78	3.071
29	1.142	79	3.110
30	1.181	80	3.150
31	1.220	81	3.189
32	1.260	82	3.228
33	1.299	83	3.268
34	1.339	84	3.307
35	1.378	85	3.346
36	1.417	86	3.386
37	1.457	87	3.425
38	1.496	88	3.465
39	1.535	89	3.504
40	1.575	90	3.543
41	1.614	91	3.583
42	1.654	92	3.622
43	1.693	93	3.661
44	1.732	94	3.701
45	1.772	95	3.740
46	1.811	96	3.780
47	1.850	97	3.819
48	1.890	98	3.858
49	1.929	99	3.898
50	1.969	100	3.937

QUICK REFERENCE CHART: STANZA ALTIMA 1993

ENGINE TUNE-UP DATA

Engine model	KA24DE		
Firing order	1-3-4-2		
Idle speed	rpm		
M/T		700 ± 50	
A/T (in "N" position)		700 ± 50	
Ignition timing (degree B.T.D.C. at idle speed)	20° ± 2°		
Idle "CO" (% at idle speed)	idle mixture screw is preset and sealed at factory.		
Valve clearance (Hot)	mm (in)		
Intake		0.31 - 0.39 (0.012 - 0.015)	
Exhaust		0.33 - 0.41 (0.013 - 0.016)	
Spark plug			
Standard	BKR5E-11		
Type	Cold	BKR6E-11	
Type	Cold	BKR7E-11	
Gap	mm (in)	1.0 - 1.1 (0.039 - 0.043)	
Drive belt deflection (Cold)	mm (in)	Used belt deflection	
		Limit	Deflection after adjustment
Generator & Power steering oil pump		8 (0.31)	6 - 7 (0.24 - 0.28)
Air conditioner compressor		10 (0.39)	7 - 8 (0.28 - 0.31)
Applied pressed force	N (kg, lb)	98 (10, 22)	
Tightening torque		N•m	kg-m
Spark plug		20 - 29	2.0 - 3.0
Oil pan drain plug		29 - 39	3.0 - 4.0
			ft-lb
			14 - 22
			22 - 29

CLUTCH PEDAL

Unit: mm (in)

Pedal height	165 - 175 (6.50 - 6.89)
Pedal free play	1 - 3 (0.04 - 0.12)

FRONT WHEEL ALIGNMENT (Unladen*)

Camber	degree	-0°50' to 0°40'
Caster	degree	1°55' - 3°25'
Kingpin inclination	degree	13°20' - 14°50'
Toe-in		
A - B	mm (in)	0 - 2 (0 - 0.08)
Total angle 2θ	degree	0' - 12'
Turning angle		
Inside		31°30' - 35°30'
Outside		25°36' - 29°36'

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

REAR WHEEL ALIGNMENT (Unladen*)

Camber	degree	-2°00' to -0°30'
Toe-in		
A - B	mm (in)	1 - 3 (0.04 - 0.12)
Total angle 2θ	degree	6' - 18'

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

BRAKE

Unit: mm (in)

Disc brake		
Pad minimum thickness	2.0 (0.079)	
Rotor repair limit	20.0 (0.787)*1, 8.0 (0.315)*2	
Minimum thickness		
Drum brake		
Lining minimum thickness	1.5 (0.059)	
Drum repair limit	230.0 (9.06)	
Maximum inner diameter		

*1 Front disc brake
*2 Rear disc brake

REFILL CAPACITIES

Unit	Liter	US measure
Fuel tank	60	15-7/8 gal
Coolant	With reservoir tank	7.8
	With oil filter	3.9
Engine	Without oil filter	3.5
	M/T	4.7
Transaxle	A/T	9.4
Power steering system (approximate)	0.9	1 qt
Air conditioning system	Compressor oil	0.2
	Refrigerant*	0.7 - 0.8 kg
		1.5 - 1.8 lb

* R-134a



NISSAN NORTH AMERICA, INC.
Technical Information Department
Torrance, California

Edition: June 1992
Printing: June 1992 (01)
Publication No. SM3E-0U13U0
Printed in U.S.A.

The inside pages of this manual contain a minimum of 50% recycled fibers, including 10% post-consumer fibers.

