

ENGINE LUBRICATION & COOLING SYSTEM

SECTION LC

GI

MA

EM

LC

CONTENTS

PRECAUTIONS	2	Checking Cooling System For Leaks	9	EC
Precautions for Supplemental Restraint System "AIR BAG"	2	Checking Radiator Cap	9	
Liquid Gasket Application Procedure	2	Water Pump	9	FE
PREPARATION	3	Removal	10	
Special Service Tools	3	Inspection	10	CL
ENGINE LUBRICATION SYSTEM	4	Installation	10	
Lubrication Circuit	4	Thermostat	11	
Oil Pressure Check	5	Inspection	11	MT
Oil Pump	5	Installation	11	
Removal	5	Radiator	12	
Installation	6	Overheating Cause Analysis	13	AT
Regulator Valve Inspection	6	SERVICE DATA AND SPECIFICATIONS (SDS)	14	
Oil Pressure Relief Valve Inspection	7	Engine Lubrication System	14	FA
Oil Pump Inspection	7	Oil pressure check	14	
ENGINE COOLING SYSTEM	8	Oil pump	14	
Cooling Circuit	8	Engine Cooling System	14	RA
System Check	8	Thermostat	14	
Checking Cooling System Hoses	8	Radiator	14	BR

ST

RS


BT

HA

EL

IDX

PRECAUTIONS




Precautions for Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".







Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
- Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.





PREPARATION

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge		GI MA EM
ST25052000 (J25695-2) Hose		Adapting oil pressure gauge to cylinder block LC EC
EG17650301 (J33984-A) Radiator cap tester adapter		Adapting radiator cap tester to radiator filler neck FE CL MT
WS39930000 (—) Tube presser		Pressing the tube of liquid gasket AT FA RA BR ST RS BT HA EL IDX

ENGINE LUBRICATION SYSTEM

Lubrication Circuit





SLC749A

- | | | |
|--------------------------|--------------------------|--------------------------------|
| ① Connecting rod | ⑥ Oil strainer | ⑩ Idler sprocket |
| ② Connecting rod bearing | ⑦ Oil pump | ⑪ Upper timing chain tensioner |
| ③ Main bearing | ⑧ Piston oil jet | ⑫ Exhaust camshaft |
| ④ Oil filter | ⑨ Timing chain tensioner | ⑬ Intake camshaft |
| ⑤ Oil pan | | |

Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may hot.
- Oil pressure check should be done with selector lever in "Neutral" position for M/T. Put selector lever in "Park" position for A/T.




1. Check oil level.
2. Remove oil pressure switch.

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.




Oil Pump

REMOVAL

1. Remove front cover.
- Refer to EM section ("Removal", "TIMING CHAIN").**
2. Remove oil pump cover.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)




- ① Front cover
- ② Outer gear
- ③ Inner gear
- ④ Oil pump cover
- ⑤ Oil strainer
- ⑥ Cap
- ⑦ Washer
- ⑧ Spring
- ⑨ Regulator valve
- ⑩ Regulator valve assembly

INSTALLATION

Install in the reverse order of removal.

- Always replace oil seals and gaskets with new ones. Refer to EM section ("OIL SEAL REPLACEMENT").
- When installing oil pump, apply engine oil to inner and outer gears.



REGULATOR VALVE INSPECTION


1. Visually inspect components for wear and damage.
 2. Check oil pressure regulator valve sliding surface and valve spring.
 3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
- If damaged, replace regulator valve set or oil pump assembly.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)

OIL PRESSURE RELIEF VALVE INSPECTION

Inspect oil pressure relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove valve by prying it out with a suitable tool. Install a new valve in place by tapping it.



OIL PUMP INSPECTION


Using a feeler gauge, check the following clearances.

Standard clearance:

Unit: mm (in)


Body to outer gear clearance ①	0.114 - 0.20 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance ②	0.04 - 0.18 (0.0016 - 0.0071)
Cover to inner gear clearance ③	0.05 - 0.09 (0.0020 - 0.0035)
Cover to outer gear clearance ④	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion clearance ⑤	..	0.045 - 0.091 (0.0018 - 0.0036)

- If the tip clearance (②) exceeds the limit, replace gear set.
- If body to gear clearances (①, ③, ④, ⑤) exceed the limit, replace front cover assembly.



ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the radiator cap when the engine is hot; serious burns could be caused by high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap and slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

ENGINE COOLING SYSTEM

System Check (Cont'd)

CHECKING COOLING SYSTEM FOR LEAKS



To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:

157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.



CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.

Radiator cap relief pressure:


Standard

78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)

Water Pump



CAUTION:




- When removing water pump assembly, be careful not to get coolant on drive belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.

ENGINE COOLING SYSTEM

Water Pump (Cont'd)

REMOVAL

1. Drain coolant from drain plug on water pipe and radiator. Refer to MA section ("Changing Engine Coolant").
2. Remove generator and air compressor.
3. Remove water pump.




INSPECTION


1. Check for badly rusted or corroded vanes and body assembly.
2. Check for rough operation due to excessive end play.

INSTALLATION

1. Use a scraper to remove old liquid gasket from water outlet.
 - Also remove traces of liquid gasket from mating surface of cylinder block.






2. Apply a continuous bead of liquid gasket to mating surface of water pump.
 - Use genuine liquid gasket or equivalent.



When filling radiator with coolant, refer to MA section ("Changing Engine Coolant"). When installing drive belts, refer to MA section ("Checking Drive Belts").

ENGINE COOLING SYSTEM

Thermostat



Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

INSPECTION

1. Check valve seating condition at normal room temperatures. It should seat tightly.
2. Check valve opening temperature and maximum valve lift.

		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Maximum valve lift	mm/°C (in/°F)	10/90 (0.39/194)

3. Then check if valve is closed at 5°C (9°F) below valve opening temperature.

INSTALLATION


Install thermostat with jiggle valve or air bleeder at upper side.

- Apply a continuous bead of liquid gasket to mating surface of water inlet.
- After installation, run engine for a few minutes, and check for leaks.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ENGINE COOLING SYSTEM

Radiator



CAUTION:
When filling radiator with coolant, refer to MA section ("Changing Engine Coolant").

ENGINE COOLING SYSTEM

Overheating Cause Analysis

	Symptom		Check items			
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	GI	
		Thermostat stuck closed	—		MA	
		Damaged fins	Dust contamination or paper clogging.		—	EM
			Mechanical damage			LC
	Reduced air flow	Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)	—	EC	
		Cooling fan does not operate.	—		—	FE
		High resistance to fan rotation				CL
		Damaged fan blades			MT	
		Damaged radiator shroud	—	—	—	AT
		Improper coolant mixture ratio	—	—	—	FA
		Poor coolant quality	—	—	—	RA
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	—	BR
				Cracked hose		ST
			Water pump	Poor sealing	—	RS
						BT
Radiator cap			Loose	—	HA	
			Poor sealing		EL	
Radiator		O-ring for damage, deterioration or improper fitting	—	IDX		
		Cracked radiator tank				
	Cracked radiator core					
	Reservoir tank	Cracked reservoir tank				
Except cooling system parts malfunction	Overload on engine	Overflowing reservoir tank	Exhaust gas leaks into cooling system	—	GI	
			Cylinder head deterioration		MA	
			Cylinder head gasket deterioration		EM	
		Abusive driving	High engine rpm under no load	—	LC	
			Driving in low gear for extended time		EC	
			Driving at extremely high speed		FE	
		Powertrain system malfunction			CL	
	Installed improper size wheels and tires			MT		
	Dragging brakes			AT		
	Improper ignition timing.			FA		
Blocked or restricted air flow	Blocked bumper	—	—	RA		
	Blocked radiator grille	Installed car brassiere		BR		
		Mud contamination or paper clogging		ST		
	Blocked radiator	—		RS		
	Blocked condenser	—		BT		
	Installed large fog lamp	—	HA			

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure check

Engine speed	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

Oil pump

		Unit: mm (in)
Body to outer gear clearance	0.114 - 0.20 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance	0.04 - 0.18 (0.0016 - 0.0071)
Cover to inner gear clearance	0.05 - 0.09 (0.0020 - 0.0035)
Cover to outer gear clearance	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion clearance	0.045 - 0.091 (0.0018 - 0.0036)

Engine Cooling System

Thermostat

Valve opening temperature	°C (°F)	76.5 (170)
Max. valve lift	mm/°C (in/°F)	10/90 (0.39/194)

Radiator

		Unit: kPa (kg/cm ² , psi)
Cap relief pressure		
Standard		78 - 98 (0.8 - 1.0, 11 - 14)
Limit		59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure		157 (1.6, 23)