

SECTION **DI**

DRIVER INFORMATION SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M

CONTENTS

<p>PRECAUTION 3</p> <p> Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 3</p> <p> Wiring Diagrams and Trouble Diagnosis 3</p> <p>COMBINATION METERS 4</p> <p> Component Parts and Harness Connector Location... 4</p> <p> System Description 4</p> <p> UNIFIED CONTROL METER 4</p> <p> HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER 4</p> <p> POWER SUPPLY AND GROUND CIRCUIT 5</p> <p> WATER TEMPERATURE GAUGE 5</p> <p> TACHOMETER 5</p> <p> FUEL GAUGE 5</p> <p> SPEEDOMETER (WITH TCS OR 5-SPEED A/T)... 6</p> <p> SPEEDOMETER (WITHOUT TCS OR 5-SPEED A/T) 6</p> <p> CAN Communication System Description 6</p> <p> Combination Meter 7</p> <p> CHECK 7</p> <p> Schematic 8</p> <p> Wiring Diagram — METER — 9</p> <p> Terminals and Reference Value for Combination Meter 11</p> <p> Meter/Gauges Operation and Odo/Trip Meter 11</p> <p> SELF-DIAGNOSIS FUNCTION 11</p> <p> HOW TO ALTERNATE DIAGNOSIS MODE 11</p> <p> How to Proceed With Trouble Diagnosis 12</p> <p> Diagnosis Flow 12</p> <p> Power Supply and Ground Circuit Check 13</p> <p> Trouble Diagnosis Chart by Symptom 14</p> <p> DIAGNOSIS RESULTS 14</p> <p> Fuel System 14</p> <p> FUEL GAUGE 15</p> <p> LOW-FUEL WARNING LAMP 15</p> <p> Tachometer System 16</p> <p> Engine Coolant Temperature System 16</p> <p> Vehicle Speed System 17</p> <p> WITH TCS OR 5-SPEED A/T 17</p>	<p> WITHOUT TCS OR 5-SPEED A/T 17</p> <p> The Fuel Gauge Pointer Fluctuates, Indicates Wrong Value or Varies 18</p> <p> The Fuel Gauge Does Not Move to FULL Position.. 18</p> <p> Electrical Components Inspection 18</p> <p> FUEL LEVEL SENSOR UNIT CHECK 18</p> <p> Removal and Installation of Combination Meter 18</p> <p>TRIPLE METERS 19</p> <p> System Description 19</p> <p> TRIPLE METER 19</p> <p> POWER SUPPLY AND GROUND CIRCUIT 19</p> <p> FUEL CONSUMPTION GAUGE 19</p> <p> OIL PRESSURE GAUGE 19</p> <p> VOLTMETER 19</p> <p> Wiring Diagram — 3METER — 21</p> <p> Terminals and Reference Value for Triple Meter ... 23</p> <p> Terminals and Reference Value for Combination Meter 23</p> <p> Meter/Gauges Operation 24</p> <p> SELF-DIAGNOSIS FUNCTION 24</p> <p> HOW TO ALTERNATE DIAGNOSIS MODE 24</p> <p> How to Proceed With Trouble Diagnosis 25</p> <p> Diagnosis Flow 25</p> <p> Power Supply and Ground Circuit Check 26</p> <p> Symptom Chart 26</p> <p> Fuel Consumption Gauge Inspection 27</p> <p> Oil Pressure Sensor Inspection 27</p> <p> Removal and Installation of Triple Meters 29</p> <p> REMOVAL 29</p> <p> INSTALLATION 29</p> <p> Disassembly and Assembly for Triple Meters 29</p> <p> DISASSEMBLY 29</p> <p> ASSEMBLY 29</p> <p>WARNING LAMPS 30</p> <p> System Description 30</p> <p> OUTLINE 30</p> <p> MALFUNCTION INDICATOR LAMP 30</p> <p> LOW WASHER FLUID LEVEL WARNING LAMP.. 30</p> <p> AIR BAG WARNING LAMP 30</p> <p> SEAT BELT WARNING LAMP 30</p>
--	---

DI

LOW FUEL LEVEL WARNING LAMP	30	SEAT BELT WARNING CHIME	46
LOW OIL PRESSURE WARNING LAMP	30	CAN Communication System Description	46
CHARGE WARNING LAMP	31	Major Component Parts and Function	46
BRAKE WARNING LAMP	31	Wiring Diagram — CHIME —	47
TRUNK WARNING LAMP	31	Terminals and Reference Value for BCM	49
DOOR WARNING LAMP	31	How to Proceed With Trouble Diagnosis	50
ASCD SET INDICATOR LAMP	31	Preliminary Check	50
CRUISE INDICATOR LAMP	31	INSPECTION FOR POWER SUPPLY AND	
ABS WARNING LAMP	31	GROUND CIRCUIT	50
TCS OFF WARNING LAMP	31	CONSULT-II Function (BCM)	51
SLIP WARNING LAMP	32	CONSULT-II BASIC OPERATION PROCEDURE	
AT CHECK WARNING LAMP (5-SPEED A/T		51
MODELS)	32	DATA MONITOR	52
A/T CHECK (POSITION) INDICATOR LAMP (4-		ACTIVE TEST	52
SPEED A/T MODELS)	32	SELF-DIAGNOSTIC RESULTS	53
CAN Communication System Description	32	All Warnings Are Not Operated	53
Schematic	33	Key Warning Chime and Light Warning Chime Does	
Wiring Diagram — WARN —	34	Not Operate (Seat Belt Warning Chime Does Oper-	
Terminals And Reference Value For BCM	38	ate)	54
Work Flow	38	Key Warning Chime Does Not Operate	55
Preliminary Check	38	Light Warning Chime Does Not Operate	57
INSPECTION FOR POWER SUPPLY AND		Seat Warning Chime Does Not Operate	58
GROUND CIRCUIT	38	BOARD COMPUTER	60
Trouble Diagnosis For Door Warning Lamp	39	System Description	60
Oil Pressure Warning Lamp Stays Off (Ignition		FUNCTION	60
Switch ON)	39	OUTSIDE AIR TEMPERATURE INDICATION	60
Oil Pressure Warning Lamp Does Not Turn Off (Oil		DTE (DISTANCE TO EMPTY) INDICATION	60
Pressure Is Normal)	40	TRIP DISTANCE	60
Component Inspection	41	TRIP TIME	60
OIL PRESSURE SWITCH	41	AVERAGE FUEL CONSUMPTION	60
A/T INDICATOR	42	AVERAGE VEHICLE SPEED	60
Wiring Diagram — AT/IND —	42	HOW TO CHANGE/RESET INDICATION	60
4-SPEED A/T	42	CAN Communication System Description	61
5-SPEED A/T	43	Schematic	62
A/T Indicator Does Not Illuminate	44	Wiring Diagram — B/COMP —	63
WARNING CHIME	45	Trouble Diagnoses	66
Component Parts and Harness Connector Location..	45	SEGMENT CHECK	66
System Description	45	PRELIMINARY CHECK	66
FUNCTION	45	DIAGNOSIS PROCEDURE	66
IGNITION KEY WARNING CHIME	46	Electrical Components Inspection	67
LIGHT WARNING CHIME	46	AMBIENT SENSOR	67

PRECAUTION

PRECAUTION

PFP:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS0080V

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS0080W

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) .
- Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) .
- Refer to [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

DI


COMBINATION METERS

COMBINATION METERS

PF2:24814

Component Parts and Harness Connector Location

EKS0080X



WKIA3380E

System Description

UNIFIED CONTROL METER

EKS0080Y


- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled by the unified meter control unit, which is built into the combination meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segments can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The vehicle speed signal and the memory signals from the meter memory circuit are processed by the combination meter and the mileage is displayed.

COMBINATION METERS

- Depressing the odometer/trip switch toggles the mode in the following order.



- The odo/trip meter display mode toggling and trip display resetting can be identified by the amount of time that elapses from pressing the odo/trip meter switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (Trip B operates the same way).

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 22.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to combination meter terminal 37.

Ground is supplied

- to combination meter terminals 23, 25, and 28
- through body grounds M57, M61, and F14.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature.

ECM provides an engine coolant temperature signal to combination meter for water temperature gauge with CAN communication line.

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 35
- from terminal 2 of the fuel level sensor unit
- through terminal 5 of the fuel level sensor unit and
- through body grounds M57, M61, and F14.

COMBINATION METERS

SPEEDOMETER (WITH TCS OR 5-SPEED A/T)

The ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter for speedometer with CAN communication line.

SPEEDOMETER (WITHOUT TCS OR 5-SPEED A/T)

The vehicle speed sensor provides a vehicle speed signal to the combination meter for speedometer indication.

CAN Communication System Description

EKS0080Z



Refer to [LAN-21, "CAN COMMUNICATION"](#) .

COMBINATION METERS

Combination Meter CHECK

EKS008P0

A
B
C
D
E
F
G
H
I
J
DI
L
M



- (EP) : Early production
- (LP) : Late production
- (U) : For USA
- (N) : For Canada
- Bulb wattage : 1.4W
- () : Bulb socket color

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M24)


WKIA3175E

COMBINATION METERS

EKS008P1

Schematic

- (A4) : WITH 4-SPEED A/T
- (AB) : WITH ABS
- (AS) : WITH ASCD
- (A) : WITH A/T
- (BD) : WITH BOARD COMPUTER
- (TS) : WITH TCS
- (W5) : WITHOUT TCS OR 5-SPEED A/T




WKWA3002E

COMBINATION METERS


Wiring Diagram — METER —

EKS008P2

DI-METER-01



A
B
C
D
E
F
G
H
I
J
DI
L
M



WKWA1252E



COMBINATION METERS

DI-METER-02

— : DATA LINE

◻T5◻ : WITH TCS OR 5-SPEED A/T

◻W5◻ : WITHOUT TCS OR 5-SPEED A/T



REFER TO THE FOLLOWING.

◻F54◻ - ELECTRICAL UNITS

WKWA3003E

COMBINATION METERS

Terminals and Reference Value for Combination Meter

EKS008P3

Terminal	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Operation or condition	
21	Y/R	Battery power supply	—	—	Battery voltage
22	GY	Ignition switch ON or START	ON	—	Battery voltage
23	B	Ground	—	—	0
25	B	Ground	—	—	0
26	L	CAN-H	—	—	—
27	P	CAN-L	—	—	—
28	B	Ground	—	—	0
35	G/B	Fuel level sensor signal	ON	—	Refer to DI-18. "FUEL LEVEL SENSOR UNIT CHECK" .
36	L/Y	Vehicle speed signal (without TCS or 5-speed A/T)	ON	Speedometer operated [When vehicle speed is approx. 20 km/h (12 MPH)]	240 Hz
37	PU	Ignition switch ACC or ON	ON	—	Battery voltage

Meter/Gauges Operation and Odo/Trip Meter SELF-DIAGNOSIS FUNCTION

EKS008P4

- Odo/trip meter (board computer) segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn the ignition switch ON and switch the odometer/trip meter to "trip A" or "trip B".

NOTE:

If the diagnosis function is activated with the trip meter A displayed, the mileage on the trip meter A will indicate 000.0 miles, but the actual trip mileage will be retained. (Trip B operates the same way.)

2. Turn the ignition switch OFF.
3. While pushing the odo/trip meter switch, turn the ignition switch ON again.
4. Check that the trip meter displays "000.0".
5. Push the odo/trip meter switch at least 7 times within 7 seconds after the ignition switch is turned ON.


COMBINATION METERS

6. All the segments on the odo/trip meter illuminate, and simultaneously the low-fuel warning lamp indicator illuminates. At this time, the unified meter control unit is turned to diagnosis mode.


NOTE:

If any of the segments is not displayed, replace the combination meter.

With NAVI




Without NAVI



WKIA1867E

7. Push the odo/trip meter switch. Each meter/gauge should indicate as shown in the figure while pushing odo/trip meter switch. (At this time, the low-fuel warning lamp goes off).



LKIA0480E

How to Proceed With Trouble Diagnosis

EKS008P5

1. Confirm the trouble symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-12, "Diagnosis Flow"](#).
3. According to the trouble diagnosis chart, repair or replace the cause of the trouble symptom. Refer to [DI-14, "Trouble Diagnosis Chart by Symptom"](#).
4. Does the meter operate normally? Yes: Go to 5. No: Go to 2.
5. Inspection End.

Diagnosis Flow

EKS008P6

1. WARNING LAMP ILLUMINATION INSPECTION

1. Turn ignition switch ON.
2. Check that warning lamps (such as MIL and oil pressure warning lamp) illuminate.

Do warning lamps illuminate?

YES >> GO TO 2.

NO >> Check ignition power supply system of combination meter. Refer to [DI-13, "Power Supply and Ground Circuit Check"](#).

COMBINATION METERS

2. SELF-DIAGNOSIS OPERATION CHECK

Perform combination meter self-diagnosis. Refer to [DI-11, "SELF-DIAGNOSIS FUNCTION"](#) .

Does self-diagnosis function operate?

YES >> GO TO 3.

NO >> Check battery power supply of combination meter and ground system. Refer to [DI-13, "Power Supply and Ground Circuit Check"](#) .

3. ODO/TRIP METER OPERATION CHECK

Check segment display status of odo/trip meter. Refer to [DI-11, "SELF-DIAGNOSIS FUNCTION"](#) .

Is the display normal?

YES >> GO TO 4.

NO >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#) .

4. FUEL WARNING LAMP ILLUMINATION CONFIRMATION

During fuel warning lamp check, confirm illumination of fuel warning lamp. Refer to [DI-11, "SELF-DIAGNOSIS FUNCTION"](#) .

Does fuel warning lamp illuminate?

YES >> GO TO 5.

NO >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#) .

5. METER CIRCUIT CHECK

During meter circuit check, confirm meter illumination. Refer to [DI-11, "SELF-DIAGNOSIS FUNCTION"](#) .

Is the display normal?

YES >> Go to diagnosis results. Refer to [DI-14, "DIAGNOSIS RESULTS"](#) .

NO >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#) .

Power Supply and Ground Circuit Check

EKS008P7

1. CHECK FUSES

Check for blown combination meter fuses.

Unit	Power source	Fuse No.
Combination meter	Battery	19
	Ignition switch ON or START	14
	Ignition switch ACC or ON	6

OK or NG

OK >> GO TO 2.


NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

COMBINATION METERS

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector M24 terminals 21 (Y/R), 22 (GY), 37 (PU) and ground.

Terminals		Ignition switch position				
(+)		(-)	OFF	ACC	ON	START
Connector	Terminal (Wire color)					
M24	21 (Y/R)	Ground	Battery voltage	Battery voltage	Battery voltage	Battery voltage
	22 (GY)		0V	0V	Battery voltage	Battery voltage
	37 (PU)		0V	Battery voltage	Battery voltage	Battery voltage



OK or NG


OK >> GO TO 3.

NG >> Check harness for open between combination meter and fuse.

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector terminals 23 (B), 25 (B), 28 (B) and ground.

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M24	23 (B)	Ground	Yes
	25 (B)		
	28 (B)		



OK or NG

OK >> Inspection End.

NG >> Check ground harness.

Trouble Diagnosis Chart by Symptom DIAGNOSIS RESULTS

EKS008P8

Trouble phenomenon	Possible cause
Tachometer indication is irregular.	Refer to DI-16, "Tachometer System" .
Fuel warning lamp indication is irregular.	Refer to DI-18, "FUEL LEVEL SENSOR UNIT CHECK" .
Fuel gauge indication is irregular.	
Water temperature gauge indication is irregular.	Refer to DI-16, "Engine Coolant Temperature System" .
Indication is irregular for the speedometer and odo/trip meter.	Refer to DI-17, "Vehicle Speed System" .
Indications are irregular for more than one gauge.	Replace combination meter. Refer to IP-13, "Combination Meter" .
A/T position indication is irregular.	Refer to DI-42, "A/T INDICATOR" .

Fuel System

EKS008P9

The following symptoms do not indicate a malfunction.

COMBINATION METERS

FUEL GAUGE

- Depending on vehicle position or driving circumstance, the fuel in the tank flows and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle position or driving circumstance, the fuel in the tank flows and the warning lamp ON timing may change.

1. CONNECTOR INSPECTION

- Turn ignition switch OFF.
- Check meter, fuel level sensor unit and terminals (meter-side, unit-side, harness-side) for looseness or damaged terminals.


OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CONTINUITY INSPECTION BETWEEN COMBINATION METER AND FUEL LEVEL SENSOR UNIT

- Disconnect combination meter connector and fuel level sensor unit connector.
- Check continuity between combination meter harness connector M24 terminal 35 (G/B) and fuel level sensor unit harness connector B16 terminal 2 (G/B).
- Check continuity between combination meter harness connector M24 terminal 35 (G/B) and ground.

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M24	35 (G/B)	B16	2 (G/B)	Yes
M24	35 (G/B)	—	Ground	No




OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

3. GROUND CIRCUIT INSPECTION OF FUEL LEVEL SENSOR

Check continuity between fuel level sensor unit harness connector B16 terminal 5 (B) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
B16	5 (B)	Ground	Yes



OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.

COMBINATION METERS

4. FUEL LEVEL SENSOR INSPECTION

Check components. Refer to [DI-18, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace fuel level sensor unit. Refer to [FL-5, "Removal and Installation For All Models Except PZEV"](#) or [FL-8, "Removal and Installation For PZEV Models Only"](#) .

5. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

OK or NG

OK >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#) .

NG >> Install the fuel level sensor unit properly.

Tachometer System

EKS008PA

1. VISUAL INSPECTION

Check if tachometer fluctuates when the engine starts.

Is the fluctuation acceptable?

YES >> GO TO 2.

NO >> GO TO 3.


2. ENGINE SPEED INSPECTION

1. Select "ENGINE" on CONSULT-II.
2. Using "ENG SPEED" on "DATA MONITOR", compare the value of "DATA MONITOR" with tachometer pointer of combination meter.

OK or NG

OK >> GO TO 3.

NG >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#) .



DATA MONITOR	
MONITOR	
ENG SPEED	XXX rpm

SKIA4367E

3. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-128, "CONSULT-II Function \(ENGINE\)"](#) (QR25DE) or [EC-750, "CONSULT-II Function \(ENGINE\)"](#) (VQ35DE).

OK or NG

OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#) .

NG >> Go to ECM trouble diagnosis. Refer to [EC-99, "TROUBLE DIAGNOSIS"](#) (QR25DE) or [EC-716, "TROUBLE DIAGNOSIS"](#) (VQ35DE).

Engine Coolant Temperature System

EKS008PB

1. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-128, "CONSULT-II Function \(ENGINE\)"](#) (QR25DE) or [EC-750, "CONSULT-II Function \(ENGINE\)"](#) (VQ35DE).

OK or NG

OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#) .

NG >> Go to ECM trouble diagnosis. Refer to [EC-99, "TROUBLE DIAGNOSIS"](#) (QR25DE) or [EC-716, "TROUBLE DIAGNOSIS"](#) (VQ35DE).

COMBINATION METERS

EKS008PC

Vehicle Speed System WITH TCS OR 5-SPEED A/T

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-59, "SELF-DIAGNOSIS PROCEDURE"](#).

OK or NG

- OK >> Replace the combination meter. Refer to [IP-13, "Combination Meter"](#).
- NG >> Perform "Diagnostic Procedure" for the displayed DTC.

WITHOUT TCS OR 5-SPEED A/T


1. CHECK VEHICLE SPEED SENSOR CIRCUITS

1. Remove vehicle speed sensor.
2. Turn ignition switch ON.
3. Rotate vehicle speed sensor while checking voltage between combination meter harness connector M24 terminal 36 (L/Y) and ECM harness connector F54 terminal 67 (B).

Terminals				Voltage (Approx.)
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M24	36 (L/Y)	F54	67 (B)	0.5V

OK or NG

- OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#).
- NG >> GO TO 2.




2. CHECK VEHICLE SPEED SENSOR

1. Turn ignition switch OFF.
2. Disconnect vehicle speed sensor connector.
3. Check resistance between vehicle speed sensor terminals + and -.

Terminals				Resistance value (Approx.)
(+)		(-)		
Component	Terminal	Component	Terminal	
Vehicle speed sensor	+	Vehicle speed sensor	-	250Ω

OK or NG

- OK >> Check harness or connector between combination meter, vehicle speed sensor and ECM.
- NG >> Replace vehicle speed sensor.



COMBINATION METERS

The Fuel Gauge Pointer Fluctuates, Indicates Wrong Value or Varies

EKS008PD

1. CHECK FUEL GAUGE FLUCTUATION

Test drive vehicle to see if gauge fluctuates only during driving or before or after stopping.

Does the indication value vary only during driving or before or after stopping?

- Yes >> The pointer fluctuation may be caused by fuel level change in the fuel tank. Condition is normal.
- No >> Ask the customer about the situation when the symptom occurs in detail, and perform the trouble diagnosis.

The Fuel Gauge Does Not Move to FULL Position

EKS008PE

1. OBSERVE FUEL GAUGE

Does it take a long time for the pointer to move to FULL position?

YES or NO

- YES >> GO TO 2.
- NO >> GO TO 3.

2. IDENTIFY FUELING CONDITION

Was the vehicle fueled with the ignition switch ON?

YES or NO

- YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise, it will take a long time to move to FULL position because of the characteristic of the fuel gauge.
- NO >> GO TO 3.

3. OBSERVE VEHICLE POSITION

Is the vehicle parked on an incline?

YES or NO

- YES >> Check the fuel level indication with vehicle on a level surface.
- NO >> GO TO 4.

4. OBSERVE FUEL GAUGE POINTER

During driving, does the fuel gauge pointer move gradually toward EMPTY position?

YES or NO

- YES >> Check the components. Refer to [DI-18, "FUEL LEVEL SENSOR UNIT CHECK"](#).
- NO >> The float arm may interfere or bind with any of the components in the fuel tank.


Electrical Components Inspection

EKS008PF

FUEL LEVEL SENSOR UNIT CHECK

- For removal, refer to [FL-5, "Removal and Installation For All Models Except PZEV"](#) or [FL-8, "Removal and Installation For PZEV Models Only"](#).
- Check the resistance between terminals 2 and 5.

Terminal	Float position mm (in)	Resistance value (Approx.)
2	Full (1)	82.7 (3.3)
	1/2 (2)	200.3 (7.9)
	Empty (3)	325.0 (12.8)



Removal and Installation of Combination Meter

EKS008PG


For removal and installation procedure, refer to [IP-13, "Combination Meter"](#).

TRIPLE METERS

System Description

TRIPLE METER

- Fuel consumption gauge, oil pressure gauge and voltmeter are controlled by the triple meter.
- Meters/gauges can be checked in self-diagnosis mode of combination meter.



POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to triple meter terminal 1 and
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to triple meter terminal 2 and
- to combination meter terminal 22.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to triple meter terminal 6 and
- to combination meter terminal 37.

Ground is supplied

- to triple meter terminals 3 and 4 and
- to combination meter terminals 23, 25 and 28
- through body grounds M57, M61 and F14.

FUEL CONSUMPTION GAUGE

The fuel consumption gauge displays the average fuel consumption according to signal from the combination meter. Average fuel consumption is calculated by signals from the ABS actuator and electric unit (control unit) (with TCS or 5-speed A/T) or vehicle speed sensor (without TCS or 5-speed A/T) and the ECM.

OIL PRESSURE GAUGE

The oil pressure gauge indicates engine oil pressure.

With the ignition switch in the ON or START position, power is supplied

- through triple meter terminal 9
- to oil pressure sensor terminal 1.

Ground is supplied

- through triple meter terminal 11
- to oil pressure sensor terminal 3.

Triple meter receives oil pressure signal from oil pressure sensor

- through oil pressure sensor terminal 2
- to triple meter terminal 10.

VOLTMETER

When the ignition switch is turned to the ON position, the voltmeter indicates the battery voltage. While the engine is running, it indicates the generator voltage of about 13 to 15 volts.

With the ignition switch in the ON or START position, power is supplied

TRIPLE METERS

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to triple meter terminal 2.

Ground is supplied

- to triple meter terminals 3 and 4
- through body grounds M57, M61 and F14.


TRIPLE METERS

Wiring Diagram — 3METER —


EKS00A7N

DI-3METER-01

— : DATA LINE



NEXT PAGE










WKWA1837E

TRIPLE METERS

DI-3METER-02

— : DATA LINE



WKWA1838E

TRIPLE METERS

Terminals and Reference Value for Triple Meter

EKS00A70

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Operation or condition	
1	Y/R	Battery power supply	OFF	—	Battery voltage
2	GY	Ignition switch ON or START	ON	—	Battery voltage
3	B	Ground	ON	—	0
4					
6	PU	ACC power supply	ACC	—	Battery voltage
7	Y	Meter serial communication	ON	—	—
9	W	Oil pressure sensor power supply	ON	—	5.5
10	G	Oil pressure sensor signal	ON	When ignition switch is in the ON position. (Engine stopped)	0.5
				Engine running. [When the oil pressure is 60 psi (4.22 kg/cm ²)]	2.5
11	SB	Oil pressure sensor ground	ON	—	0
12	P/L	Oil pressure warn out	ON	Engine oil pressure is below 4.52 psi (0.318 kg/cm ²)	0.5
				Engine oil pressure is above 6.5 psi (0.457 kg/cm ²)	Battery voltage

Terminals and Reference Value for Combination Meter

EKS00A7P

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Operation or condition	
4	Y	Meter serial communication	ON	—	—
21	Y/R	Battery power supply	OFF	—	Battery voltage
22	GY	Ignition switch ON or START	ON	—	Battery voltage
23	B	Ground	ON	—	0
25					
28					
37	PU	Ignition switch ACC or ON	ON	—	Battery voltage

TRIPLE METERS

EKS00A7R

Meter/Gauges Operation SELF-DIAGNOSIS FUNCTION

Meters/gauges can be checked in self-diagnosis mode of combination meter.


HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn the ignition switch ON and switch the odometer/trip meter to "trip A" or "trip B".

NOTE:

If the diagnosis function is activated with the trip meter A displayed, the mileage on the trip meter A will indicate 000.0 miles, but the actual trip mileage will be retained. (Trip B operates the same way.)

2. Turn the ignition switch OFF.
3. While pushing the odo/trip meter switch, turn the ignition switch ON again.
4. Check that the trip meter displays "000.0".
5. Push the odo/trip meter switch at least 7 times within 7 seconds after the ignition switch is turned ON.
6. All the segments on the odo/trip meter illuminate, and simultaneously the low-fuel warning lamp indicator illuminates. At this time, the unified meter control unit is turned to diagnosis mode.
7. Push the odo/trip meter switch. Each meter/gauge should indicate as shown in the figure while pushing odo/trip meter switch.



TRIPLE METERS

How to Proceed With Trouble Diagnosis

EKS00A7T

1. Confirm the symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-25, "Diagnosis Flow"](#) .
3. According to the symptom chart, repair or replace the cause of the symptom.
4. Does the triple meter operate normally? If so, go to 5. If not, go to 2.
5. Inspection End.

Diagnosis Flow

EKS00A7U

1. CHECK VOLTMETER OPERATION

Turn ignition switch ON.

Does voltmeter display battery voltage?

YES >> GO TO 2.

NO >> Check ignition power supply system of triple meter. Refer to [DI-26, "Power Supply and Ground Circuit Check"](#) .


2. CHECK METER CIRCUIT

Check indication of each meter/gauge in self-diagnosis mode. Refer to [DI-24, "SELF-DIAGNOSIS FUNCTION"](#) .

OK or NG

OK >> Go to [DI-26, "Symptom Chart"](#) .

NG >> Replace triple meter. Refer to [DI-29, "Removal and Installation of Triple Meters"](#) .



A
B
C
D
E
F
G
H
I
J
DI
L
M

TRIPLE METERS

EKS00A7V

Power Supply and Ground Circuit Check

1. CHECK FUSES

Check for blown triple meter fuses.

Unit	Power source	Fuse No.
Triple meter	Battery	19
	Ignition switch ACC or ON	6
	Ignition switch ON or START	14

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect the triple meter connector.
2. Check voltage between triple meter harness connector terminals and ground.

Terminals		Ignition switch position				
(+)		(-)	OFF	ACC	ON	START
Connector	Terminal (Wire color)					
M99	1 (Y/R)	Ground	Battery voltage	Battery voltage	Battery voltage	Battery voltage
	2 (GY)		0V	0V	Battery voltage	Battery voltage
	6 (PU)		0V	Battery voltage	0V	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness for open between triple meter and fuse.

3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between triple meter harness connector M99 terminals 3 (B), 4 (B) and ground.

Continuity should exist.

OK or NG

OK >> Inspection End.

NG >> Check harness or connector.



Symptom Chart

EKS00A7W

Trouble phenomenon	Possible cause
Fuel consumption gauge is irregular.	Refer to DI-27, "Fuel Consumption Gauge Inspection" .
Oil pressure gauge is irregular.	Refer to DI-27, "Oil Pressure Sensor Inspection" .
Voltmeter is irregular.	<ul style="list-style-type: none"> ● Refer to SC-21, "CHARGING SYSTEM". ● Replace triple meter. Refer to DI-29, "Removal and Installation of Triple Meters".

TRIPLE METERS

EKS00A7Z

Fuel Consumption Gauge Inspection

1. CHECK ECM SELF-DIAGNOSIS

Perform the ECM self-diagnosis. Refer to [EC-754, "SELF-DIAG RESULTS MODE"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Check the applicable parts.

2. CHECK METER SERIAL COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter and triple meter connectors.
3. Check continuity between combination meter connector M24 terminal 4 (Y) and triple meter connector M99 terminal 7 (Y).


Continuity should exist.

4. Check continuity between combination meter connector M24 terminal 4 (Y) and ground.

Continuity should not exist.

OK or NG

- OK >> Replace triple meter. Refer to [DI-29, "Removal and Installation of Triple Meters"](#) .
- NG >> Repair harness or connector between combination meter and triple meter.



Oil Pressure Sensor Inspection

EKS00A80

1. CHECK OIL PRESSURE SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage between triple meter harness connector M99 terminal 10 (G) and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Connector	Terminal (Wire color)		
M99	10 (G)	When ignition switch is in ON position. (Engine stopped.)	0.5V
		Engine running. [When the oil pressure is 60 psi (4.22 kg/cm ²)]	2.5V

OK or NG

- OK >> Replace triple meter. Refer to [DI-29, "Removal and Installation of Triple Meters"](#) .
- NG >> GO TO 2.



2. CHECK OIL PRESSURE SENSOR POWER SUPPLY

Check voltage between triple meter harness connector M99 terminal 9 (W) and ground.

Approx. 5.5V

OK or NG

- OK >> GO TO 3.
- NG >> Replace triple meter. Refer to [DI-29, "Removal and Installation of Triple Meters"](#) .



TRIPLE METERS

3. CHECK OIL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect triple meter and oil pressure sensor connectors.
3. Check continuity between triple meter harness connector M99 terminal 9 (W) and oil pressure sensor harness connector F106 terminal 1 (W).

Continuity should exist.


4. Check continuity between triple meter harness connector M99 terminal 9 (W) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector between triple meter and oil pressure sensor.



4. CHECK OIL PRESSURE SENSOR SIGNAL CIRCUIT

1. Check continuity between triple meter harness connector M99 terminal 10 (G) and oil pressure sensor harness connector F106 terminal 2 (R/L).

Continuity should exist.


2. Check continuity between triple meter harness connector M99 terminal 10 (G) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector between triple meter and oil pressure sensor.



5. CHECK OIL PRESSURE SENSOR GROUND CIRCUIT


Check continuity between triple meter harness connector M99 terminal 11 (SB) and oil pressure sensor harness connector F106 terminal 3 (B).

Continuity should exist.

OK or NG

OK >> Replace oil pressure sensor.

NG >> Repair harness or connector between triple meter and oil pressure sensor.



TRIPLE METERS

Removal and Installation of Triple Meters

EKS00A83

REMOVAL

To remove triple meters, remove cluster lid D. Refer to [IP-12, "Cluster Lid D"](#) .

INSTALLATION


Installation is in the reverse order of removal.

Disassembly and Assembly for Triple Meters

EKS00A84

DISASSEMBLY

1. Remove the triple meter screws as shown, then separate from bezel of cluster lid D.



ASSEMBLY

Assembly is in the reverse order of disassembly.

A
B
C
D
E
F
G
H
I
J
DI
L
M

DI

WARNING LAMPS

System Description OUTLINE

With ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 22.

Ground is supplied

- to seat belt buckle switch LH terminal 2 and
- to trunk lamp switch and trunk release solenoid terminal 4
- through body grounds B7 and B19,
- to brake fluid level switch terminal 2 and
- to washer fluid level sensor terminal –
- through body grounds E15 and E24,
- to fuel level sensor unit and fuel pump terminal 5
- through body grounds M57, M61 and F14.

MALFUNCTION INDICATOR LAMP

The malfunction indicator lamp is controlled by the ECM. During prove out or when an engine control malfunction occurs, the ECM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the malfunction indicator lamp.

When power and ground are supplied, the malfunction indicator lamp illuminates.

LOW WASHER FLUID LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied

- to combination meter terminal 15
- from washer fluid level sensor terminal +.

When power and ground are supplied, the low washer level warning lamp illuminates.

AIR BAG WARNING LAMP

During prove out or when an air bag malfunction occurs, the ground path is interrupted

- from the air bag diagnosis sensor unit terminal 15
- to combination meter terminal 20.

SEAT BELT WARNING LAMP

When the driver seat belt is unfastened, ground is supplied

- to combination meter terminal 11
- from seat belt buckle switch LH terminal 1.

When power and ground are supplied, the seat belt warning lamp illuminates.

LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. A signal is sent

- to combination meter terminal 35
- from fuel level sensor unit terminal 2.

The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

When power and ground are supplied, the low fuel level warning lamp illuminates.

LOW OIL PRESSURE WARNING LAMP

Low oil pressure warning lamp is controlled by the IPDM E/R (intelligent power distribution module engine room).

Low oil pressure causes oil pressure switch terminal + to provide ground to IPDM E/R terminal 57. The IPDM E/R then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the low oil pressure warning lamp.

When power and ground are supplied, the low oil pressure warning lamp illuminates.

WARNING LAMPS

CHARGE WARNING LAMP

During prove out or when a generator malfunction occurs, ground is supplied

- to combination meter terminal 14
- from generator terminal L.

When power and ground are supplied, the charge warning lamp and brake lamp illuminate.

BRAKE WARNING LAMP

When the parking brake is applied or if the brake fluid level is low, ground is supplied

- to combination meter terminal 17
- from parking brake switch terminal 1 or
- to combination meter terminal 19
- from brake fluid level switch terminal 1.

When power and ground are supplied, the brake warning lamp illuminates.

TRUNK WARNING LAMP

Trunk warning lamp is controlled by the BCM.

When the trunk is opened, ground is supplied

- to BCM terminal 53
- through trunk lamp switch and trunk release solenoid terminal 3
- through trunk lamp switch and trunk release solenoid terminal 4
- to body grounds B7 and B19.

The BCM then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the trunk warning lamp.

When power and ground are supplied, the trunk warning lamp illuminates.

DOOR WARNING LAMP

Door warning lamp is controlled by the BCM.

When one of the doors is opened, ground is supplied to BCM terminals 12, 13, 47 or 48. The BCM then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the door warning lamp.

When power and ground are supplied, the door warning lamp illuminates.

ASCD SET INDICATOR LAMP

The ASCD set indicator lamp is controlled by the ECM.

When the ASCD system is turned on and the speed is set, the ECM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the SET indicator lamp.

When power and ground are supplied, the set indicator lamp illuminates.

CRUISE INDICATOR LAMP

The cruise indicator lamp is controlled by the ECM.

When the ASCD system is turned on, the ECM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the cruise indicator lamp.

When power and ground are supplied, the CRUISE indicator lamp illuminates.

ABS WARNING LAMP

When an ABS malfunction occurs, ground is supplied

- to combination meter terminal 16
- from ABS actuator and electric unit (control unit) terminal 21.

When power and ground are supplied, the ABS warning lamp illuminates.

TCS OFF WARNING LAMP

When TCS OFF switch is in OFF position or a TCS malfunction occurs, ground is supplied

- to combination meter terminal 12
- from ABS actuator and electric unit (control unit) terminal 5.

When power and ground are supplied, the TCS OFF warning lamp illuminates.

A

B

C

D

E

F

G

H

I

J

DI

L

M

WARNING LAMPS

SLIP WARNING LAMP

When TCS is in operation or a TCS malfunction occurs, ground is supplied

- to combination meter terminal 13
- from ABS actuator and electric unit (control unit) terminal 2.

When power and ground are supplied, the SLIP warning lamp illuminates.

AT CHECK WARNING LAMP (5-SPEED A/T MODELS)

The AT CHECK warning lamp is controlled by the TCM (transmission control module). When an A/T system malfunction occurs, the TCM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the AT CHECK warning lamp.

When power and ground are supplied, the AT CHECK warning lamp illuminates.

A/T CHECK (POSITION) INDICATOR LAMP (4-SPEED A/T MODELS)

The A/T check (position) indicator lamp is controlled by the TCM (transmission control module). When an A/T system malfunction occurs, the TCM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the A/T check (position) indicator lamp.

When power and ground are supplied, the A/T check (position) indicator lamp illuminates.

CAN Communication System Description


EKS008PI

Refer to [LAN-21, "CAN COMMUNICATION"](#) .

WARNING LAMPS

Schematic

EKS008PJ









A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING LAMPS

Wiring Diagram — WARN —

EKS008PK

DI-WARN-01





REFER TO THE FOLLOWING.
 (F54), (F56) - ELECTRICAL UNITS

WKWA3005E

WARNING LAMPS

DI-WARN-02





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

WKWA1841E

WARNING LAMPS



DI-WARN-03



WKWA1256E

WARNING LAMPS

DI-WARN-04



REFER TO THE FOLLOWING.
E125 - ELECTRICAL UNITS

WKWA1257E

WARNING LAMPS

Terminals And Reference Value For BCM

EKS008PL

Terminal	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Operation	
12	P/L	Front door switch RH	OFF	Front door switch RH	ON (open) 0
					OFF (closed) Battery voltage
13	R/W	Rear door switch RH	OFF	Rear door switch RH	ON (open) 0
					OFF (closed) Battery voltage
39	L	CAN-H	—	—	—
40	P	CAN-L	—	—	—
47	SB	Front door switch LH	OFF	Front door switch LH	ON (open) 0
					OFF (closed) Battery voltage
48	R/B	Rear door switch LH	OFF	Rear door switch LH	ON (open) 0
					OFF (closed) Battery voltage
53	P	Trunk lamp switch and trunk release solenoid	OFF	Trunk lamp switch	ON (open) 0
					OFF (closed) Battery voltage

Work Flow

EKS008PM

1. Check the trouble symptom and customer's requests.
2. Understand the outline of system. Refer to [DI-30, "System Description"](#).
3. Perform the preliminary check. Refer to [DI-38, "Preliminary Check"](#).
4. Referring to Trouble diagnosis chart, repair or replace the cause of the incident. Refer to [DI-39, "Trouble Diagnosis For Door Warning Lamp"](#).
5. Does warning lamp system operate normally? If it operates normally, go to step 6. If not, go to step 4.
6. Inspection End.

Preliminary Check

EKS008PN

INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSIBLE LINK

Check for blown BCM fusible link.

Unit	Power source	Fusible link
BCM	Battery	f

Refer to [DI-47, "Wiring Diagram — CHIME —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fusible link is blown, be sure to eliminate cause of problem before installing new fusible link.
Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

WARNING LAMPS

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect BCM connector.
2. Check voltage between BCM connector M20 terminal 70 (W/B) and ground. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).




Terminals		Ignition switch position	
(+)		(-)	OFF
Connector	Terminal (Wire color)		
M20	70 (W/B)	Ground	Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> Check harness for open between BCM and fuse.

3. GROUND CIRCUIT CHECK

Check continuity between BCM harness connector M20 terminal 67 (B) and body ground. Refer to [PG-28, "GROUND CIRCUIT"](#).



Terminals		Continuity	
(+)		(-)	
Connector	Terminal (Wire color)		
M20	67 (B)	Ground	Yes

OK or NG

- OK >> Inspection End.
- NG >> Check harness ground circuit.

Trouble Diagnosis For Door Warning Lamp

EKS008PP

Symptom	Diagnostic procedure and repair order
Door warning lamp does not illuminate with any of doors open.	<ul style="list-style-type: none"> ● Check front door switches. Refer to BL-30, "Door Switch Check". ● Check rear door switches. Refer to BL-30, "Door Switch Check".
Door warning lamp illuminates constantly.	If the above systems work properly, replace the BCM. Refer to BCS-20, "Removal and Installation of BCM" .

Oil Pressure Warning Lamp Stays Off (Ignition Switch ON)

EKS008PQ

1. CHECK IPDM E/R OUTPUT SIGNAL

Activate IPDM E/R auto active test. Refer to [PG-21, "Auto Active Test"](#).

Is oil pressure warning lamp blinking?

- YES >> GO TO 4.
- NO >> GO TO 2.

2. CHECK SELF-DIAGNOSTIC RESULTS OF IPDM E/R

Select "IPDM E/R" on CONSULT-II, and perform self-diagnosis of IPDM E/R. Refer to [PG-17, "CONSULT-II Function \(IPDM E/R\)"](#).

Self-diagnostic results content

- No malfunction detected>>GO TO 3.
- Malfunction detected>>Go to [PG-18, "SELF-DIAGNOSTIC RESULTS"](#) in "IPDM E/R".

WARNING LAMPS

3. CHECK IPDM E/R INPUT SIGNAL

Select "IPDM E/R" on CONSULT-II. Operate ignition switch with "OIL P SW" of "DATA MONITOR" and check operation status.


When ignition switch is in ON : OIL P SW CLOSE position (Engine stopped)

When engine running : OIL P SW OPEN

OK or NG

OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#).

NG >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).



4. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check the following.

QR25DE models

Continuity between IPDM E/R harness connector E121 terminal 57 (P/L) and oil pressure switch harness connector F19 terminal + (P/L).

Continuity should exist.

VQ35DE models without triple meter

Continuity between IPDM E/R harness connector E121 terminal 57 (P/L) and oil pressure switch harness connector F106 terminal + (R/L).

Continuity should exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.

5. CHECK OIL PRESSURE SWITCH

Check oil pressure switch. Refer to [DI-41, "OIL PRESSURE SWITCH"](#).

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).


NG >> Replace oil pressure switch.

Oil Pressure Warning Lamp Does Not Turn Off (Oil Pressure Is Normal)

EKS008PR

NOTE:

For oil pressure inspection, refer to [LU-8, "OIL PRESSURE CHECK"](#) (QR25DE) or [LU-21, "OIL PRESSURE CHECK"](#) (VQ35DE).



WARNING LAMPS

1. CHECK OIL PRESSURE SWITCH CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector E121 terminal 57 (P/L) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



2. CHECK OIL PRESSURE SWITCH

Check oil pressure switch. Refer to [DI-41, "OIL PRESSURE SWITCH"](#).

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).


NG >> Replace oil pressure switch.

Component Inspection OIL PRESSURE SWITCH

EKS008PS

Check continuity between the oil pressure switch and body ground.

Condition	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine stopped	Less than 29 (0.3, 4)	Yes
Engine running	More than 29 (0.3, 4)	No



A/T INDICATOR

PF2:24814





EKS008PT

A/T INDICATOR

Wiring Diagram — AT/IND — 4-SPEED A/T

DI-AT/IND-01

— : DATA LINE





WKWA1258E

A/T INDICATOR

5-SPEED A/T

DI-AT/IND-02

— : DATA LINE



WKWA3006E

A/T INDICATOR

A/T Indicator Does Not Illuminate

EKS008PU

1. TCM CONTROL UNIT SYSTEM INSPECTION

Perform TCM self-diagnosis. Refer to [AT-44, "SELF-DIAGNOSTIC PROCEDURE \(WITH CONSULT-II\)"](#) (4-speed A/T) or [AT-456, "SELF-DIAG RESULT MODE"](#) (5-speed A/T).

OK or NG

- OK >> GO TO 2.
- NG >> Go to TCM trouble diagnosis.

2. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-11, "Meter/Gauges Operation and Odo/Trip Meter"](#) .

OK or NG

- OK >> A/T indicator is OK.
- NG >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#) .


WARNING CHIME

PF2:24814

WARNING CHIME

Component Parts and Harness Connector Location

EKS008PV



WKIA3382E

System Description

FUNCTION

EKS008PW

Item	Description
Ignition key warning chime	Sounds warning chime when driver's door is opened with key in ignition key cylinder and ignition switch "OFF" or "ACC" position.
Light warning chime	Sounds warning chime when driver's door is opened with lighting switch in the 1st or 2nd position and the key removed from the ignition switch.
Seat belt warning chime	Sounds warning chime for approximately 6 seconds after ignition switch is turned "ON" when driver seat belt is unfastened.

NOTE:

When ignition key warning chime, light warning chime, and seat belt warning chime should be performed at the same time, the priorities for each chime are the following.

1. Seat belt warning chime
2. Ignition key warning chime
3. Light warning chime

Power is supplied at all times

- through 50A fusible link (letter f, located in the fuse and fusible link box)
- to BCM terminal 70, and
- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch and key lock solenoid terminal 3.

Ground is supplied

- to BCM terminal 67
- through body grounds M57, M61, and F14.

WARNING CHIME

When the proper signal, or combination of signals, is received by the combination meter, the warning chime will sound.

IGNITION KEY WARNING CHIME

Power is supplied

- through key switch and key lock solenoid terminal 4
- to BCM terminal 37.

Ground is supplied

- to BCM terminal 47
- through front door switch LH terminal 2
- through front door switch LH case ground.

With the key inserted in the ignition switch, and the driver door open, the ignition key warning chime will sound.

LIGHT WARNING CHIME

With the key removed from the ignition switch, the driver door open, and the lighting switch in 1ST or 2ND position, the warning chime will sound. [Except when headlamp battery saver control operates (for 5 minutes after ignition switch is turned to OFF or ACC position) and headlamps do not illuminate.]

Signal is supplied

- from combination switch (lighting switch) terminals 5, 6, 7, 10, 11, 12, 13, 14, 15 and 16
- to BCM terminals 2, 3, 4, 5, 6, 32, 33, 34, 35 and 36.

Ground is supplied

- to BCM terminal 47
- through front door switch LH terminal 2
- through front door switch LH case ground.

With these conditions, when power and ground are supplied, the light warning chime sounds.

SEAT BELT WARNING CHIME

With the driver seat belt unfastened (seat belt buckle switch LH ON), warning chime will sound for approximately 6 seconds after the ignition switch is turned ON.

Ground is supplied

- to combination meter terminal 11
- through seat belt buckle switch LH terminal 1
- through seat belt buckle switch LH terminal 2
- through body grounds B7 and B19.

With these conditions, when power and ground are supplied, the seat belt warning chime sounds.

CAN Communication System Description

EKS008PX

Refer to [LAN-21, "CAN COMMUNICATION"](#).

Major Component Parts and Function

EKS008PY



Components	Functions
BCM	Intermittently operates the warning chime by signals from the ignition switch, key switch and key lock solenoid, lighting switch, front door switch LH and seat belt buckle switch LH.
Warning chime	Generates intermittent sounds by signals from the BCM.

WARNING CHIME

Wiring Diagram — CHIME —

EKS008PZ

DI-CHIME-01





WKWA1259E

WARNING CHIME

DI-CHIME-02

■ ■ ■ : DATA LINE








WKWA1260E

WARNING CHIME

Terminals and Reference Value for BCM

EKS00800

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)	
			Ignition switch	Measurement method		
2	L	Combination switch input 5	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
3	R/Y	Combination switch input 4	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
4	R/G	Combination switch input 3	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
5	R/B	Combination switch input 2	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
6	R/W	Combination switch input 1	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
32	L/W	Combination switch output 5	ON	Lighting switch and wiper switch are OFF.	5V or more	
33	G/Y	Combination switch output 4	ON	Lighting switch and wiper switch are OFF.	5V or more	
34	G/R	Combination switch output 3	ON	—	5V or more	
35	G/B	Combination switch output 2	ON	—	5V or more	
36	G/W	Combination switch output 1	ON	—	5V or more	
37	B/R	Key switch signal	OFF	Key is removed.	0	
				Key is inserted.	Battery voltage	
39	L	CAN-H	—	—	—	
40	P	CAN-L	—	—	—	
47	SB	Front door switch LH signal	OFF	Driver door	ON (open)	0
					OFF (closed)	5V

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING CHIME

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Measurement method	
67	B	Ground	OFF	—	0
70	W/B	Battery power supply	OFF	—	Battery voltage

How to Proceed With Trouble Diagnosis

EKS008Q1

1. Confirm the trouble symptom or customer complaint.
2. Understand operation description and function description. Refer to [DI-45, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [DI-50, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Does the warning chime operate normally? Yes: Go to 6. No: Go to 4.
6. Inspection End.

Preliminary Check INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

EKS008Q2

1. CHECK FUSIBLE LINK

Check for blown BCM fusible link.

Unit	Power source	Fusible link
BCM	Battery	f

Refer to [DI-47, "Wiring Diagram — CHIME —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fusible link is blown, be sure to eliminate cause of problem before installing new fusible link.
Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect BCM connector.
2. Check voltage between BCM connector M20 terminal 70 (W/B) and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
M20	70 (W/B)	Ground	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fusible link.



WKIA1874E

WARNING CHIME


3. GROUND CIRCUIT CHECK

Check continuity between BCM harness connector M20 terminal 67 (B) and ground.

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M20	67 (B)	Ground	Yes

OK or NG

- OK >> Inspection End.
- NG >> Check harness ground circuit.



CONSULT-II Function (BCM)

EKS008Q3

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
BUZZER	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

CONSULT-II BASIC OPERATION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, and turn the ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".




WARNING CHIME

3. Touch "BCM".



4. Touch "BUZZER" or "BCM".

5. Select "DATA MONITOR" "ACTIVE TEST" or "SELF-DIAG RESULTS".



DATA MONITOR

Operation Procedure

1. Touch "BUZZER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all selected test item related signals.
SELECTION FROM MENU	Selects and monitors the specified item.

4. If "SELECTION FROM MENU" is selected, touch the item desired to monitor. If "ALL SIGNALS" is selected, all selected test item related signals are monitored.
5. Touch "START".
6. During monitoring, touching "COPY" will print the monitored item status.

Data Monitor Item

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
LIGHT SW 1ST	Indicates [ON/OFF] condition of combination switch (lighting switch).
BUCKLE SW	Indicates [ON/OFF] condition of seat belt buckle switch LH.

ACTIVE TEST

Operation Procedure

1. Touch "BUZZER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

WARNING CHIME

Active Test Item (IGN KEY WARN ALM)

Test item	Malfunction detecting condition
CHIME	This test is able to check key warning chime operation. Key warning chime sounds after touching "ON" on CONSULT-II screen.

Active Test Item (LIGHT WARN ALM)

Test item	Malfunction detecting condition
CHIME	This test is able to check light warning chime operation. Light warning chime sounds after touching "ON" on CONSULT-II screen.

Active Test Item (SEAT BELT WARN TEST)

Test item	Malfunction detecting condition
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds after touching "ON" on CONSULT-II screen.

SELF-DIAGNOSTIC RESULTS

Operation Procedure

1. Touch "BCM" on "DIAGNOSIS ITEM SELECTION" screen.
2. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
3. Self-diagnostic results are displayed.

Display Item List

Items to be displayed	CONSULT-II display	Description
CAN communication	CAN communication [U1000]	Malfunction is detected in CAN communication.
CAN communication system	CAN communication system 1 to 6 [U1000]	Malfunction is detected in CAN system.
Combination switch	Diagnosis 1 - 5 systems open circuit	Malfunction is detected in combination switch system.

All Warnings Are Not Operated


EKS008Q4

1. CHIME OPERATION INSPECTION

Select "BUZZER" on CONSULT-II, and perform "LIGHT WARN ALM", "IGN KEY WARN ALM", or "SEAT BELT WARN TEST" active test.

Does chime sound?

- YES >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NO >> GO TO 2.



2. BCM SELF-DIAGNOSIS

Select "BCM" on CONSULT-II, and perform BCM self-diagnosis.

Self-diagnostic results content

- No malfunction detected>> Replace combination meter. Refer to [IP-13, "Combination Meter"](#).
- CAN communication or CAN communication system>> Check BCM CAN communication system. Go to [LAN-21, "CAN COMMUNICATION"](#).
- Diagnosis 1 - 5 systems open circuit>> Malfunction in combination switch system. Go to [LT-90, "Combination Switch Reading Function"](#) according to self-diagnostic results.

WARNING CHIME

Key Warning Chime and Light Warning Chime Does Not Operate (Seat Belt Warning Chime Does Operate)

EKS008Q5


1. CHECK BCM INPUT SIGNAL

Ⓜ With CONSULT-II

With "DATA MONITOR" of "BUZZER", confirm "DOOR SW-DR" when the front door switch LH is operated.

When front door LH is opened : DOOR SW-DR ON

When front door LH is closed : DOOR SW-DR OFF




⊗ Without CONSULT-II

Check voltage between BCM harness connector M19 terminal 47 (SB) and ground.

When front door LH is opened : Approx. 0V

When front door LH is closed : Approx. 5V




OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> GO TO 2.

2. CONTINUITY INSPECTION OF DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M19 and front door switch LH connector B8.
3. Check continuity between BCM harness connector M19 terminal 47 (SB) and front door switch LH harness connector B8 terminal 2 (SB).



Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M19	47 (SB)	B8	2 (SB)	Yes

4. Check continuity between BCM harness connector M19 terminal 47 (SB) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M19	47 (SB)	Ground	No

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

WARNING CHIME

3. CHECK DOOR SWITCH

Check front door switch LH.


When front door switch LH is released : Continuity should exist

When front door switch LH is pushed : Continuity should not exist

OK or NG

OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).

NG >> Replace front door switch LH.



EKS008Q6

Key Warning Chime Does Not Operate

1. CHECK FUSE

Check if the key switch and key lock solenoid (key detection) switch fuse is blown. Refer to [DI-47, "Wiring Diagram — CHIME —"](#).

Is the fuse blown?

YES >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

NO >> GO TO 2.

2. CHECK WARNING CHIME OPERATION

With key removed from the ignition and the front door LH open, turn the lighting switch to 1st or 2nd position.

Does warning chime sound?

YES >> GO TO 3.

NO >> Go to [DI-53, "All Warnings Are Not Operated"](#) or [DI-54, "Key Warning Chime and Light Warning Chime Does Not Operate \(Seat Belt Warning Chime Does Operate\)"](#).


WARNING CHIME

3. KEY SWITCH INSPECTION

With CONSULT-II

With "BUZZER" on the data monitor, insert the key into the ignition cylinder to check ON/OFF operation.


Switch operation	CONSULT-II display	Operation status
Ignition switch (key in switch)	KEY ON SW	ON
Ignition switch (key out of switch)		OFF



Without CONSULT-II

Check voltage between BCM harness connector M18 terminal 37 (B/R) and ground.

Terminals		Condition	Voltage (V) (Approx.)
(+)			
Connector	Terminal (Wire color)	(-)	
M18	37 (B/R)	Ground	Battery voltage
			0V



OK or NG

- OK >> Replace BCM. Refer to [BCS-20. "Removal and Installation of BCM"](#).
- NG >> GO TO 4.


4. CHECK KEY SWITCH (INSERT)

1. Disconnect key switch and key lock solenoid connector.
2. Check continuity between key switch and key lock solenoid terminals 3 and 4.

Terminals		Condition	Continuity
3	4	Key is inserted	Yes
		Key is removed	No

OK or NG

- OK >> GO TO 5.
- NG >> Replace key switch and key lock solenoid.



WARNING CHIME

5. BCM AND KEY SWITCH CONTINUITY INSPECTION

1. Disconnect BCM connector M18.
2. Check continuity between BCM harness connector M18 terminal 37 (B/R) and key switch and key lock solenoid harness connector M26 terminal 4 (B/R).

Continuity should exist.


3. Check continuity between BCM harness connector M18 terminal 37 (B/R) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



6. KEY SWITCH INPUT SIGNAL INSPECTION


Check voltage between key switch and key lock solenoid harness connector M26 terminal 3 (W) and ground.

Battery voltage should exist.

OK or NG

OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).

NG >> Check harness for open between key switch and key lock solenoid and fuse.



Light Warning Chime Does Not Operate

1. CHECK WARNING CHIME OPERATION

Check key warning chime and seat belt warning chime functions.

Do key warning chime and seat belt warning chime sound?

YES >> GO TO 2.

NO >> Go to [DI-53, "All Warnings Are Not Operated"](#) or [DI-54, "Key Warning Chime and Light Warning Chime Does Not Operate \(Seat Belt Warning Chime Does Operate\)"](#).

2. DATA MONITOR INSPECTION


With "BUZZER" on the data monitor, confirm "LIGHT SW 1ST" turns ON/OFF when lighting switch and front fog switch are operated.

Switch operation	CONSULT-II display	Operation status
Headlamp switch (1st position)	LIGHT SW 1ST	ON
Headlamp switch (OFF)		OFF

OK or NG

OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).

NG >> GO TO 3.



WARNING CHIME

3. INSPECTION BETWEEN COMBINATION SWITCH AND BCM

Select "BCM" on CONSULT-II, and perform BCM self-diagnosis.

Self-diagnostic results content

- No malfunction detected>> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
- CAN communication or CAN communication system>> Check BCM CAN communication system. Go to [LAN-21, "CAN COMMUNICATION"](#) .
- Diagnosis 1 - 5 systems open circuit>> Malfunction in combination switch system. Go to [LT-90, "Combination Switch Reading Function"](#) according to self-diagnostic results.

Seat Warning Chime Does Not Operate

EKS00808

1. CHECK WARNING CHIME OPERATION

1. With key removed from the ignition switch and the front door LH open, turn the lighting switch to 1st or 2nd position.
2. Return lighting switch to OFF position, and insert key into ignition switch.


Does warning chime sound for both steps?

- YES >> GO TO 2.
- NO >> Go to [DI-53, "All Warnings Are Not Operated"](#) .

2. DATA MONITOR INSPECTION

With "BUZZER" on the data monitor, confirm "BUCKLE SW " when the seat belt buckle switch LH is operated.

Switch operation	CONSULT-II display	Operation status
Seat belt buckle switch LH (unfastened)	BUCKLE SW	ON
Seat belt buckle switch LH (fastened)		OFF




OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
- NG >> GO TO 3.

3. COMBINATION METER INPUT SIGNAL INSPECTION

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector M24 terminal 11 (OR) and ground.

Terminals		Condition	Voltage (V) (Approx.)
(+)	(-)		
Connector	Terminal		
M24	11 (OR)	Seat belt is fastened	Battery voltage
		Seat belt is unfastened	0V



OK or NG

- OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#)
- NG >> GO TO 4.

WARNING CHIME

4. SEAT BELT BUCKLE SWITCH INSPECTION


1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch LH connector.
3. Check continuity between seat belt buckle switch LH terminals 1 and 2.

Terminals		Condition	Continuity
1	2	Seat belt is fastened	No
		Seat belt is unfastened	Yes

OK or NG

OK >> GO TO 5.

NG >> Replace seat belt buckle switch LH.



5. SEAT BELT BUCKLE SWITCH CIRCUIT INSPECTION

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector M24 terminal 11 (OR) and seat belt buckle switch LH harness connector P2 terminal 1 (OR).

Continuity should exist.


3. Check continuity between combination meter harness connector M24 terminal 11 (OR) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



6. SEAT BELT BUCKLE SWITCH GROUND CIRCUIT INSPECTION


1. Disconnect seat belt buckle switch LH connector.
2. Check continuity between seat belt buckle switch LH harness connector P2 terminal 2 (B) and ground.

Continuity should exist.

OK or NG

OK >> Replace combination meter. Refer to [IP-13, "Combination Meter"](#).

NG >> Repair harness or connector.



BOARD COMPUTER

System Description FUNCTION

The board computer can indicate the following items.

- Outside air temperature
- DTE (distance to empty) (without NAVI)
- Trip distance
- Trip time (without NAVI)
- Average fuel consumption (without NAVI)
- Average vehicle speed (without NAVI)

OUTSIDE AIR TEMPERATURE INDICATION

The outside air temperature indication is displayed while the ignition switch is in the ON position.

Signal is supplied

- through ambient sensor terminal 1
- to combination meter (board computer) terminal 33.

Indication range is between -30 and 55°C (-22 and 131°F). When outside temperature is less than 3°C (37°F), display shows ICY. In this case, the display will change to the outside air temperature mode even though the display is showing a different mode. When outside temperature is more than 55°C (131°F), indication will be blank. The indicated temperature is not affected by engine heat. It changes only when one of the following conditions exists.

- When vehicle speed is more than 20 km/h (12 MPH).
- The ignition switch has been turned OFF for more than 3.5 hours.
- When outside air temperature is less than the indicated temperature.

DTE (DISTANCE TO EMPTY) INDICATION

The range indication provides the driver with an estimation of the distance that can be driven before refueling. The range is calculated by signals from the fuel level sensor unit (fuel remaining), ECM (fuel consumption) and vehicle speed sensor (without TCS or 5-speed A/T) or the ABS actuator and electric unit (with TCS or 5-speed A/T). The indication will be refreshed every 30 seconds. When fuel remaining is less than approximately 10 ℓ (2 5/8 US gal, 2 1/4 Imp gal), the indication will blink as a warning. If the fuel remaining is less than approximately 8 ℓ (2 1/8 US gal, 1 3/4 Imp gal), the indication will show "---". In this case, the display will change to the DTE mode even though the display is showing a different mode. When the battery is disconnected and reconnected, DTE mode will display "---" until the vehicle is driven 500 miles (804.5 km).

TRIP DISTANCE

Trip distance is calculated by signal from the vehicle speed sensor (without TCS or 5-speed A/T) or the ABS actuator and electric unit (with TCS or 5-speed A/T). If trip distance is reset, trip time will be reset at the same time.

TRIP TIME

Trip time displays cumulative ignition switch ON time. If trip time is reset, trip distance will be reset at the same time.

AVERAGE FUEL CONSUMPTION

Average fuel consumption indication is calculated by signals from the vehicle speed sensor (without TCS or 5-speed A/T) or the ABS actuator and electric unit (with TCS or 5-speed A/T) and the ECM (fuel consumption). The indication will be refreshed every 30 seconds.

AVERAGE VEHICLE SPEED

Average vehicle speed indication is calculated by running distance and running time. The indication will be refreshed every 30 seconds. If average vehicle speed is reset, average fuel consumption will be reset at the same time. After resetting, the display will show "---" for 30 seconds.

HOW TO CHANGE/RESET INDICATION

Indication can be changed in the following order by momentarily depressing the board computer switch or the board computer steering switch.

BOARD COMPUTER

Outside air temperature → dte (without NAVI) → Average fuel consumption (without NAVI) → Average vehicle speed (without NAVI) → Trip time (without NAVI) → Trip distance.
Holding the switch for more than 0.8 second will reset the indication of the currently displayed mode (trip distance, trip time, average vehicle speed or average fuel consumption).

NOTE:

After the display changes automatically, the indication can be changed to the last mode by pushing the board computer switch or the board computer steering switch.

CAN Communication System Description

EKS008QA

Refer to [LAN-21, "CAN COMMUNICATION"](#) .


A
B
C
D
E
F
G
H
I
J
DI
L
M



BOARD COMPUTER

Schematic

EKS008QB




WKWA3007E

BOARD COMPUTER


Wiring Diagram — B/COMP —

EKS008QC

DI-B/COMP-01



A
B
C
D
E
F
G
H
I
J
DI
L
M



WKWA1350E



BOARD COMPUTER

DI-B/COMP-02

— : DATA LINE

◊T5◊ : WITH TCS OR 5-SPEED A/T

◊W5◊ : WITHOUT TCS OR 5-SPEED A/T




REFER TO THE FOLLOWING.

(F54) - ELECTRICAL UNITS

WKWA3008E


BOARD COMPUTER

DI-B/COMP-03



- ⬡ AA : WITH AUTO A/C
- ⬡ EN : WITHOUT NAVI
- ⬡ MA : WITH MANUAL A/C
- ⬡ NV : WITH NAVI

A
B
C
D
E
F
G
H
I
J
DI
L
M



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

WKWA1262E


BOARD COMPUTER

EKS008QD

Trouble Diagnoses SEGMENT CHECK

The board computer segment display can be checked by entering combination meter self-diagnostic mode. Refer to [DI-11, "SELF-DIAGNOSIS FUNCTION"](#).

PRELIMINARY CHECK



LKIA0061E

*1 [DI-66, "DIAGNOSIS PROCEDURE"](#) *2 [DI-7, "CHECK"](#)

DIAGNOSIS PROCEDURE

Symptom	Possible cause	Repair order
Outside air temperature display is not displayed properly. (It may take a short time to steady the indication after ignition switch is turned ON.) NOTE: If the meter is powered up with the ambient sensor disconnected, outside air temperature display will show "---" even if the sensor is reconnected. In this case, with the sensor connected, disconnect and reconnect the battery, then the correct temperature will be displayed.	1. Ambient sensor 2. Ambient sensor circuit 3. Vehicle speed sensor signal (without TCS or 5-speed A/T) 4. ABS actuator and electric unit (with TCS or 5-speed A/T)	1. Check ambient sensor. 2. Check harness for open or short between ambient sensor and board computer. 3. Check harness for open or short between combination meter terminal 36 and vehicle speed sensor. 4. Perform ABS actuator and electric unit self diagnosis.
DTE (distance to empty) is not displayed properly.)	1. Average fuel consumption display 2. Fuel tank gauge signal circuit.	1. Make sure fuel consumption is displayed properly. If NG, check fuel consumption display. 2. Make sure fuel gauge operates properly. If NG, check fuel gauge. Refer to DI-14, "Fuel System" .

BOARD COMPUTER

Symptom	Possible cause	Repair order
Trip distance is not indicated properly.	<ol style="list-style-type: none"> 1. Vehicle speed sensor signal circuit (without TCS or 5-speed A/T) 2. ABS actuator and electric unit (with TCS or 5-speed A/T) 	<ol style="list-style-type: none"> 1. Check harness for open or short between combination meter terminal 36 and vehicle speed sensor. 2. Perform ABS actuator and electric unit self diagnosis.
Trip time is not indicated properly.	<ol style="list-style-type: none"> 1. Fuse 	<ol style="list-style-type: none"> 1. 10A fuse [No. 19 located in fuse block (J/B)]. Verify battery voltage is present at combination meter terminal 21.
Average fuel consumption is not displayed properly.	<ol style="list-style-type: none"> 1. Trip distance display 2. Fuel consumption signal 	<ol style="list-style-type: none"> 1. Check harness for open or short between combination meter terminal 36 and vehicle speed sensor (without TCS or 5-speed A/T) or perform ABS actuator and electric unit self diagnosis (with TCS or 5-speed A/T). 2. Check CAN lines for open or short between ECM and combination meter.
Average vehicle speed is not indicated properly.	<ol style="list-style-type: none"> 1. Trip distance display 2. Trip time display 	<ol style="list-style-type: none"> 1. Check harness for open or short between combination meter terminal 36 and vehicle speed sensor (without TCS or 5-speed A/T) or perform ABS actuator and electric unit self diagnosis (with TCS or 5-speed A/T). 2. Make sure trip time is displayed properly. If NG, check trip time display.


Electrical Components Inspection AMBIENT SENSOR

EKS008QE

After disconnecting ambient sensor harness connector, measure resistance between terminals 2 and 1 at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace ambient sensor.



WJIA0079E

BOARD COMPUTER
