

SECTION **BCS**

BODY CONTROL SYSTEM

A
B
C

CONTENTS

D
E

| | | |
|---|----|---|
| BCM | | |
| BASIC INSPECTION | 3 | |
| INSPECTION AND ADJUSTMENT | 3 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) | 3 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description | 3 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure | 3 | |
| CONFIGURATION (BCM) | 4 | |
| CONFIGURATION (BCM) : Description | 4 | |
| CONFIGURATION (BCM) : Work Procedure | 4 | |
| CONFIGURATION (BCM) : Configuration List | 5 | |
| SYSTEM DESCRIPTION | 6 | |
| BODY CONTROL SYSTEM | 6 | |
| System Description | 6 | |
| Component Parts Location | 7 | |
| COMBINATION SWITCH READING SYSTEM | 8 | |
| System Diagram | 8 | |
| System Description | 8 | |
| SIGNAL BUFFER SYSTEM | 12 | |
| System Diagram | 12 | |
| System Description | 12 | |
| POWER CONSUMPTION CONTROL SYSTEM | 13 | |
| System Diagram | 13 | |
| System Description | 13 | |
| Component Parts Location | 15 | |
| DIAGNOSIS SYSTEM (BCM) | 16 | |
| COMMON ITEM | 16 | |
| COMMON ITEM : Diagnosis Description | 16 | |
| COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) | 16 | F |
| DOOR LOCK | 17 | G |
| DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) | 17 | |
| REAR WINDOW DEFOGGER | 17 | H |
| REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER) | 17 | |
| BUZZER | 18 | I |
| BUZZER : CONSULT Function (BCM - BUZZER) | 18 | |
| INT LAMP | 18 | J |
| INT LAMP : CONSULT Function (BCM - INT LAMP) | 18 | |
| MULTI REMOTE ENT | 19 | K |
| MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT) | 19 | |
| HEADLAMP | 20 | L |
| HEADLAMP : CONSULT Function (BCM - HEAD LAMP) | 20 | |
| WIPER | 21 | |
| WIPER : CONSULT Function (BCM - WIPER) | 21 | |
| FLASHER | 22 | N |
| FLASHER : CONSULT Function (BCM - FLASHER) | 22 | |
| AIR CONDITIONER | 23 | O |
| AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER) | 23 | |
| INTELLIGENT KEY | 23 | P |
| INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) | 23 | |
| COMB SW | 26 | |
| COMB SW : CONSULT Function (BCM - COMB SW) | 26 | |

F
G
H
I
J
K
L



BCS

N
O
P

| | | | |
|---|-----------|---|-----------|
| BCM | 26 | Special Repair Requirement | 36 |
| BCM : CONSULT Function (BCM - BCM) | 26 | | |
| IMMU | 27 | COMBINATION SWITCH INPUT CIRCUIT | 37 |
| IMMU : CONSULT Function (BCM - IMMU) | 27 | Diagnosis Procedure | 37 |
| | | Special Repair Requirement | 38 |
| BATTERY SAVER | 27 | COMBINATION SWITCH OUTPUT CIRCUIT ... | 39 |
| BATTERY SAVER : CONSULT Function (BCM - | | Diagnosis Procedure | 39 |
| BATTERY SAVER) | 27 | Special Repair Requirement | 40 |
| TRUNK | 28 | ECU DIAGNOSIS INFORMATION | 41 |
| TRUNK : CONSULT Function (BCM - TRUNK) | 28 | | |
| THEFT ALM | 29 | BCM (BODY CONTROL MODULE) | 41 |
| THEFT ALM : CONSULT Function (BCM - THEFT | | Reference Value | 41 |
| ALM) | 29 | Terminal Layout | 45 |
| | | Physical Values | 45 |
| RETAINED PWR | 30 | Fail Safe | 63 |
| RETAINED PWR : CONSULT Function (BCM - | | DTC Inspection Priority Chart | 65 |
| RETAINED PWR) | 30 | DTC Index | 67 |
| SIGNAL BUFFER | 30 | WIRING DIAGRAM | 70 |
| SIGNAL BUFFER : CONSULT Function (BCM - | | | |
| SIGNAL BUFFER) | 30 | BCM (BODY CONTROL MODULE) | 70 |
| AIR PRESSURE MONITOR | 30 | Wiring Diagram - Coupe | 70 |
| AIR PRESSURE MONITOR : CONSULT Function | | Wiring Diagram - Sedan | 79 |
| (BCM - AIR PRESSURE MONITOR) | 30 | | |
| DTC/CIRCUIT DIAGNOSIS | 32 | SYMPTOM DIAGNOSIS | 88 |
| U1000 CAN COMM CIRCUIT | 32 | | |
| Description | 32 | COMBINATION SWITCH SYSTEM SYMP- | 88 |
| DTC Logic | 32 | TOMS | 88 |
| Diagnosis Procedure | 32 | Symptom Table | 88 |
| U1010 CONTROL UNIT (CAN) | 33 | PRECAUTION | 89 |
| DTC Logic | 33 | | |
| Diagnosis Procedure | 33 | PRECAUTIONS | 89 |
| U0415 VEHICLE SPEED SIG | 34 | Precaution for Supplemental Restraint System | |
| Description | 34 | (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | |
| DTC Logic | 34 | SIONER" | 89 |
| Diagnosis Procedure | 34 | Precaution Necessary for Steering Wheel Rota- | |
| B2562 LOW VOLTAGE | 35 | tion After Battery Disconnect | 89 |
| DTC Logic | 35 | | |
| Diagnosis Procedure | 35 | PREPARATION | 91 |
| Special Repair Requirement | 35 | | |
| POWER SUPPLY AND GROUND CIRCUIT | 36 | PREPARATION | 91 |
| Diagnosis Procedure | 36 | Commercial Service Tools | 91 |
| | | REMOVAL AND INSTALLATION | 92 |
| | | BCM (BODY CONTROL MODULE) | 92 |
| | | Removal and Installation | 92 |

BASIC INSPECTION

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description

INFOID:000000007421597

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure

INFOID:000000007421598

1. SAVING VEHICLE SPECIFICATION

CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. REPLACE BCM

Replace BCM. Refer to [BCS-92. "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-4. "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-4. "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

4. INITIALIZE BCM (NATS)

Perform BCM initialization (NATS). Refer to CONSULT Immobilizer mode and follow the on-screen instructions.

>> Work End.

CONFIGURATION (BCM)

CONFIGURATION (BCM) : Description

INFOID:000000009325914

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM.
Configuration has three functions as follows:

| Function | Description |
|--------------------------|--|
| "Before Replace ECU" | <ul style="list-style-type: none"> • Reads the vehicle configuration of current BCM. • Saves the read vehicle configuration. |
| "After Replace ECU" | Writes the vehicle configuration with manual selection. |
| "Select Saved Data List" | Writes the vehicle configuration with saved data. |

CAUTION:

- When replacing BCM, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new BCM.

CONFIGURATION (BCM) : Work Procedure

INFOID:000000007421600

1. WRITING MODE SELECTION

ⓅCONSULT

Select "Reprogramming, Configuration" of BCM.

When writing saved data>>GO TO 2.
When writing manually>>GO TO 3.

2. PERFORM "SAVED DATA LIST"

ⓅCONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

ⓅCONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [BCS-5. "CONFIGURATION \(BCM\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by BCM operates normally.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[BCM]

>> Work End.

CONFIGURATION (BCM) : Configuration List

INFOID:000000007421601

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

| MANUAL SETTING ITEM | | NOTE |
|---------------------|------------------------------|--|
| Items | Setting value | |
| AUTO LIGHT | WITH⇔WITHOUT | — |
| DTRL | WITH⇔WITHOUT | — |
| TRANSMISSION | •AT with ABS •MT with ABS | • AT with ABS: CVT • MT with ABS: MT |
| TIRE PRESSURE | •220 kPa •230 kPa | • 220 kPa: 215/55R18 Tire • 230 kPa: 215/55R17 Tire |
| TPMS | WITH⇔WITHOUT | — |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

SYSTEM DESCRIPTION

BODY CONTROL SYSTEM

System Description

INFOID:000000007421602

OUTLINE

- BCM (body control module) controls the various electrical components. It inputs the information required to the control from CAN communication and the signal received from each switch and sensor.
- BCM has combination switch reading function for reading the operation status of combination switches (light, turn signal, wiper and washer) in addition to a function for controlling the operation of various electrical components. It also has the signal transmission function as the passed point of signal and the power saving control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with the diagnosis function that performs the diagnosis with CONSULT and various settings.

CAN communication control

In CAN communication, control units are connected with 2 communication lines (CAN-L, CAN-H) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives the data but selectively reads required information only.

CAN communication signal

Refer to the [LAN-24, "CAN System Specification Chart"](#).

BCM control function list

| System | Refer to |
|--|--|
| Combination switch reading system | BCS-8, "System Description" |
| Signal buffer system | BCS-12, "System Description" |
| Power consumption control system | BCS-13, "System Description" |
| Auto light system | EXL-11, "System Description" |
| Turn signal and hazard warning lamp system | EXL-15, "System Description" |
| Headlamp system (xenon type) | EXL-7, "System Description" |
| Headlamp system (halogen type) | EXL-9, "System Description" |
| Front fog lamp system | EXL-13, "System Description" |
| Exterior lamp battery saver system | EXL-7, "System Description" (xenon type) EXL-9, "System Description" (halogen type) |
| Interior room lamp control system | INL-7, "System Description" |
| Step lamp system | |
| Interior room lamp battery saver system | INL-7, "System Description" |
| Front wiper and washer system | WW-6, "System Description" |
| Warning chime system | WCS-4, "WARNING CHIME SYSTEM : System Description" |
| Door lock system | DLK-237, "DOOR LOCK AND UNLOCK SWITCH : System Description" |
| Trunk open system | DLK-250, "TRUNK LID OPENER SWITCH : System Description" |
| Nissan vehicle immobilizer system | SEC-234, "System Description" |
| Vehicle security system | SEC-238, "System Description" |
| Panic alarm | |
| Rear window defogger system | DEF-6, "System Description" |
| Remote keyless entry system | DLK-237, "DOOR LOCK AND UNLOCK SWITCH : System Description" |

BODY CONTROL SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

| System | Refer to |
|--|--|
| Intelligent Key system/engine start system | Door lock function <ul style="list-style-type: none"> • DLK-239, "DOOR REQUEST SWITCH : System Description" (door request switch) • DLK-244, "INTELLIGENT KEY : System Description" (Intelligent Key) |
| | Trunk open function <ul style="list-style-type: none"> • DLK-252, "TRUNK REQUEST SWITCH : System Description" (trunk request switch) • DLK-257, "INTELLIGENT KEY : System Description" (Intelligent Key) |
| | Warning function <ul style="list-style-type: none"> • DLK-262, "System Description" |
| | Key reminder function <ul style="list-style-type: none"> • DLK-270, "System Description" |
| | Engine start function <ul style="list-style-type: none"> • SEC-228, "System Description" |
| Power window system | <ul style="list-style-type: none"> • PWC-199, "System Description" (front LH and RH power window anti-pinch) • PWC-13, "System Description" (front LH only window anti-pinch) |
| RAP (retained accessory power) system | BCS-30, "RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)" |
| TPMS (tire pressure monitor system) | BCS-30, "AIR PRESSURE MONITOR : CONSULT Function (BCM - AIR PRESSURE MONITOR)" |

Component Parts Location

INFOID:000000007421603



1. BCM M16, M17, M18, M19, M20, M21 (view with instrument panel removed)

NOTE:

Sedan shown, Coupe similar.

BCS

COMBINATION SWITCH READING SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

COMBINATION SWITCH READING SYSTEM

System Diagram

INFOID:000000007421604



System Description


INFOID:000000007421605

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5) and reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



Combination switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|-----------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | INT VOLUME 1 | — | — | HEADLAMP 2 | HI BEAM |

COMBINATION SWITCH READING SYSTEM

[BCM]


< SYSTEM DESCRIPTION >

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|--------------|------------|---------|-----------|
| OUTPUT 4 | — | INT VOLUME 3 | AUTO LIGHT | — | TAIL LAMP |
| OUTPUT 5 | INT VOLUME 2 | — | — | FR FOG | — |

COMBINATION SWITCH READING FUNCTION

Description


- BCM reads the status of the combination switch at 10ms intervals normally.



NOTE:

BCM reads the status of the combination switch at 60ms intervals when BCM is controlled at low power consumption mode.

- BCM operates as follows and judges the status of the combination switch.
- It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5 and outputs voltage waveform.
- The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination switch.



Operation Example

Revision: February 2013

BCS-9

2012 Altima GCC

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH READING SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TURN RH switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION SETTING (FRONT WIPER INTERMITTENT OPERATION)

BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2, and 3 switches.

COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >

[BCM]

| Wiper intermittent dial position | Intermittent operation delay interval | INT VOLUME switch ON/OFF status | | |
|----------------------------------|---------------------------------------|---------------------------------|---------------------|---------------------|
| | | INT VOLUME 1 switch | INT VOLUME 2 switch | INT VOLUME 3 switch |
| 1 | Short ↑ | ON | ON | ON |
| 2 | | ON | ON | OFF |
| 3 | | ON | OFF | OFF |
| 4 | | OFF | OFF | OFF |
| 5 | ↓ Long | OFF | OFF | ON |
| 6 | | OFF | ON | ON |
| 7 | | OFF | ON | OFF |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

SIGNAL BUFFER SYSTEM


< SYSTEM DESCRIPTION >

[BCM]

SIGNAL BUFFER SYSTEM

System Diagram

INFOID:000000007421606



JPMIA0070GB

System Description

INFOID:000000007421607

OUTLINE


BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.

Signal transmission function list

| Signal name | Input | Output | Description |
|---|-----------------------------|---|---|
| <ul style="list-style-type: none"> Ignition switch ON signal Ignition switch signal | Engine switch (push switch) | IPDM E/R (CAN) | Inputs the push-button ignition switch (push switch) signal and transmits the ignition switch status judged with BCM via CAN communication. |
| Door switch signal | Any door switch | <ul style="list-style-type: none"> Combination meter (CAN) IPDM E/R (CAN) | Inputs the door switch signal and transmits it via CAN communication. |
| Trunk switch signal | Trunk lamp switch | Combination meter (CAN) | Inputs the trunk room lamp switch signal and transmits the trunk switch signal via CAN communication. |
| Oil pressure switch signal | IPDM E/R (CAN) | Combination meter (CAN) | Transmits the received oil pressure switch signal via CAN communication. |

POWER CONSUMPTION CONTROL SYSTEM

System Diagram



System Description

INFOID:000000007421609

OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R and combination meter) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of the each switches changes from 10 ms interval to 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R and combination meter via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wakeup signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and perform the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

POWER CONSUMPTION CONTROL SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

Sleep condition

| CAN sleep condition | BCM sleep condition |
|--|--|
| <ul style="list-style-type: none"> Receiving the sleep-ready signal (ready) from all units Ignition switch: OFF Vehicle security system alarm and panic alarm : No operation Warning lamp: Not operation Intelligent Key system buzzer: No operation Trunk lamp switch status: No change Brake switch: OFF Key slot status: No change Turn signal indicator lamp: No operation Exterior lamp: OFF Door lock status: No change CONSULT communication status: No communication Meter display signal : Non-transmission Electronic steering column lock operation: No operation Door switch status: No change Rear window defogger: OFF | <ul style="list-style-type: none"> Interior room lamp battery saver: Time out RAP system: OFF Power window switch communication: No transmission Push-button ignition switch (push switch) illumination: OFF NATS: No operation Remote keyless entry receiver communication status: No communication Tire pressure monitor system: Stop |

Wake-up operation

- BCM changes from the low power consumption mode to the CAN communication sleep mode when the any of the BCM wake-up conditions is fulfilled. Only the control with BCM is activated.
- BCM transmits the sleep wake up signal (wake up) to each unit when any of the CAN wake-up conditions is fulfilled. It changes from the low power consumption mode or the CAN communication sleep mode to the normal mode.
- Each unit starts the transmission of CAN communication with the sleep wake up signal. In addition, the combination meter transmits the wake up signal to BCM via CAN communication to report the CAN communication start.

Wake-up condition

| BCM wake-up condition | CAN wake-up condition |
|--|--|
| <ul style="list-style-type: none"> Front door unlock sensor: OFF→ON, ON→OFF Front door lock assembly LH (key cylinder switch): Lock or unlock Door lock switch: OFF→ON Door unlock switch: OFF→ON Trunk lid opener switch: OFF→ON Power window serial link communication: Receiving Remote keyless entry receiver: Receiving valid keyfob | <ul style="list-style-type: none"> Receiving the sleep-ready signal (Not-ready) from any units Key slot: OFF→ON, ON→OFF Push-button ignition switch: OFF→ON Hazard switch: OFF→ON PASSING switch: OFF→ON TAIL LAMP switch: OFF→ON Front door switch LH: OFF→ON, ON→OFF Front door switch RH: OFF→ON, ON→OFF Rear door switch LH: OFF→ON, ON→OFF Rear door switch RH: OFF→ON, OFF→ON Trunk lamp switch: OFF→ON, ON→OFF Front door LH request switch: OFF→ON Front door RH request switch: OFF→ON Trunk request switch: OFF→ON Stop lamp switch 2 signal: ON Remote keyless entry receiver: Receiving valid keyfob |


POWER CONSUMPTION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[BCM]

Component Parts Location

INFOID:000000007421610



1. BCM M16, M17, M18, M19, M20, M21 (view with instrument panel removed)
2. Combination meter M24
3. IPDM E/R E16, E17, E18, E200, E201, F10

NOTE:

Sedan shown, Coupe similar.

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) COMMON ITEM

COMMON ITEM : Diagnosis Description

INFOID:000000007421611

BCM CONSULT FUNCTION

CONSULT performs the following functions via CAN communication with BCM.

| Diagnosis mode | Function Description |
|-----------------------|--|
| WORK SUPPORT | Changes the setting for each system function. |
| SELF-DIAG RESULTS | Displays the diagnosis results judged by BCM. |
| CAN DIAG SUPPORT MNTR | Monitors the reception status of CAN communication viewed from BCM. |
| DATA MONITOR | The BCM input/output signals are displayed. |
| ACTIVE TEST | The signals used to activate each device are forcibly supplied from BCM. |
| ECU IDENTIFICATION | The BCM part number is displayed. |
| CONFIGURATION | This function is not used even though it is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

| System | Sub system selection item | Diagnosis mode | | |
|--------------------------------------|---------------------------|----------------|--------------|-------------|
| | | WORK SUPPORT | DATA MONITOR | ACTIVE TEST |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp timer | INT LAMP | | × | × |
| Remote keyless entry system | MULTI REMOTE ENT | | × | |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | × | × | × |
| Turn signal and hazard warning lamps | FLASHER | × | × | × |
| Air conditioner | AIR CONDITONER | | × | |
| Intelligent Key system | INTELLIGENT KEY | × | × | × |
| Combination switch | COMB SW | | × | |
| BCM | BCM | × | | |
| Immobilizer | IMMU | | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | |
| Trunk open | TRUNK | | × | × |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | | × | |
| Signal buffer system | SIGNAL BUFFER | | × | × |
| TPMS | AIR PRESSURE MONITOR | × | × | × |

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000007421612

ECU IDENTIFICATION

Displays the BCM part No.

SELF-DIAG RESULT

Refer to [BCS-67. "DTC Index"](#).

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000007421613

WORK SUPPORT

| Work Item | Description |
|------------------------------|---|
| DOOR LOCK-UNLOCK SET | <ul style="list-style-type: none">• ON• OFF |
| AUTOMATIC DOOR LOCK SELECT | <ul style="list-style-type: none">• P RANGE• VH SPD |
| AUTOMATIC DOOR UNLOCK SELECT | <ul style="list-style-type: none">• MODE1• MODE2• MODE3• MODE4 |
| AUTOMATIC LOCK/UNLOCK SELECT | <ul style="list-style-type: none">• LOCK/UNLOCK• LOCK ONLY• UNLOCK ONLY• OFF |

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW-DR [ON/OFF] | Indicates condition of door request switch LH |
| REQ SW-AS [ON/OFF] | Indicates condition of door request switch RH |
| REQ SW-BD/TR [ON/OFF] | Indicates condition of trunk request switch |
| CDL LOCK SW [ON/OFF] | Indicates condition of door lock and unlock switch |
| CDL UNLOCK SW [ON/OFF] | Indicates condition of door lock and unlock switch |
| DOOR SW-DR [ON/OFF] | Indicates condition of front door switch LH |
| DOOR SW-AS [ON/OFF] | Indicates condition of front door switch RH |
| DOOR SW-RR [ON/OFF] | Indicates condition of rear door switch RH |
| DOOR SW-RL [ON/OFF] | Indicates condition of rear door switch LH |
| DOOR SW-BK [ON/OFF] | Indicates condition of trunk switch |
| KEY CYL LK-SW [ON/OFF] | Indicates condition of lock signal from door key cylinder switch |
| KEY CYL UN-SW [ON/OFF] | Indicates condition of unlock signal from door key cylinder switch |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| DOOR LOCK | This test is able to check door lock operation [OTR ULK / AS UNLK / DR UNLK / ALL UNLK / ALL LCK]. |

REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000007421614

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| PUSH SW [ON/OFF] | Indicates condition of push switch |
| REAR DEF SW [ON/OFF] | Displays "Press (ON)/other (OFF)" status determined with the rear window defogger switch |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

ACTIVE TEST

| Test Item | Description |
|---------------|---|
| REAR DEFOGGER | This test is able to check rear window defogger operation. Rear window defogger operates when "ON" on CONSULT screen is touched |

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000007421615

DATA MONITOR

| Display item [Unit] | Description |
|--------------------------|--|
| VEH SPEED 1 [Km/h] | Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line. |
| PUSH SW [ON/OFF] | Status of push button ignition switch judged by BCM. |
| UNLK SEN -DR [ON/OFF] | Status of front door lock assembly LH (door unlock sensor) judged by BCM. |
| KEY SW-SLOT [ON/OFF] | Status of key slot judged by BCM. |
| TAIL LAMP SW [ON/OFF] | Status of each switch judged by BCM using the combination SW readout function. |
| FR FOG SW [ON/OFF] | Status of front fog lamp switch judged by BCM. |
| DOOR SW -DR [ON/OFF] | Status of driver side door switch judged by BCM. |

ACTIVE TEST

| Display item [Unit] | Description |
|------------------------|---|
| IGN KEY WARN ALM | The key warning chime operation can be checked by operating the relevant function (ON/OFF). |
| SEAT BELT WARN TEST | The seat belt warning chime operation can be checked by operating the relevant function (ON/OFF). |
| ID REGIST WARNING | The ID regist warning chime operation can be checked by operating the relevant function (ON/OFF). |
| LIGHT WARN ALM | The light warning chime operation can be checked by operating the relevant function (ON/OFF). |

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000007421616

DATA MONITOR

| Monitor item [Unit] | Description |
|-------------------------|--|
| REQ SW-DR [ON/OFF] | The switch status input from request switch (driver side) |
| REQ SW-AS [ON/OFF] | The switch status input from front request switch (passenger side) |
| PUSH SW [ON/OFF] | The switch status input from push-button ignition switch |
| ACC RLY-F/B [ON/OFF] | Indicates [ON/OFF] condition of accessory relay-1. |
| UNLK SEN-DR [ON/OFF] | Indicates [ON/OFF] condition of driver door UNLOCK status. |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Monitor item [Unit] | Description |
|---------------------------|--|
| KEY SW-SLOT [ON/OFF] | Key switch status input from key slot |
| DOOR SW-DR [ON/OFF] | The switch status input from front door switch LH |
| DOOR SW-AS [ON/OFF] | The switch status input from front door switch RH |
| DOOR SW-RR [ON/OFF] | The switch status input from rear door switch RH |
| DOOR SW- RL [ON/OFF] | The switch status input from rear door switch LH |
| CDL LOCK SW [ON/OFF] | Lock switch status received from central door lock switch by power window switch serial link |
| CDL UNLOCK SW [ON/OFF] | Unlock switch status received from central door lock switch by power window switch serial link |
| KEY CYL LK-SW [ON/OFF] | Lock switch status received from key cylinder switch by power window switch serial link |
| KEY CYL UN-SW [ON/OFF] | Unlock switch status received from key cylinder switch by power window switch serial link |
| TRNK/HAT MNTR [ON/OFF] | The switch status input from trunk room lamp switch |
| RKE-LOCK [ON/OFF] | Lock signal status received from remote keyless entry receiver |
| RKE-UNLOCK [ON/OFF] | Unlock signal status received from remote keyless entry receiver |

ACTIVE TEST

| Test item | Operation | Description |
|-------------------|-----------|--|
| INT LAMP | ON | Outputs the interior room lamp control signal to turn map lamp and personal lamp ON (Map lamp switch is in DOOR position). |
| | OFF | Stops the interior room lamp control signal to turn map lamp and personal lamp OFF. |
| STEP LAMP TEST | ON | Outputs the step lamp control signal to turn step lamp ON. |
| | OFF | Stops the step lamp control signal to turn step lamp OFF. |
| LUGGAGE LAMP TEST | ON | Outputs the luggage room lamp control signal to turn step lamp ON. |
| | OFF | Stops the luggage room lamp control signal to turn step lamp ON. |

MULTI REMOTE ENT

MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT)

INFOID:000000007421617

DATA MONITOR

| Monitor Item | Condition |
|--------------|---|
| REQ SW -DR | Indicates [ON/OFF] condition of door request switch (driver side). |
| REQ SW -AS | Indicates [ON/OFF] condition of door request switch (passenger side). |
| DOOR SW-DR | Indicates [ON/OFF] condition of front door switch (driver side). |
| DOOR SW-AS | Indicates [ON/OFF] condition of front door switch (passenger side). |
| DOOR SW-RR | Indicates [ON/OFF] condition of rear door switch RH. |
| DOOR SW-RL | Indicates [ON/OFF] condition of rear door switch LH. |
| CDL LOCK SW | Indicates [ON/OFF] condition of door lock and unlock switch. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Monitor Item | Condition |
|---------------|---|
| CDL UNLOCK SW | Indicates [ON/OFF] condition of door lock and unlock switch. |
| KEY CYL LK-SW | Indicated [ON/OFF] condition of lock signal from door key cylinder. |
| KEY CYL UN-SW | Indicated [ON/OFF] condition of unlock signal from door key cylinder. |

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000007421618

WORK SUPPORT

| Service item | Setting item | Setting |
|-------------------|--------------|--|
| BATTERY SAVER SET | ON* | With the exterior lamp battery saver function |
| | OFF | Without the exterior lamp battery saver function |

* : Initial setting

DATA MONITOR

| Monitor item [Unit] | Description |
|--|---|
| PUSH SW [ON/OFF] | The switch status input from push-button ignition switch |
| ENGINE STATE [STOP/STALL/CRANK/RUN] | The engine status received from ECM with CAN communication |
| VEH SPEED 1 [km/h] | The value of the vehicle speed received from combination meter with CAN communication |
| KEY SW-SLOT [ON/OFF] | Key switch status input from key slot |
| TURN SIGNAL R [ON/OFF] | Each switch status that BCM judges from the combination switch reading function |
| TURN SIGNAL L [ON/OFF] | |
| TAIL LAMP SW [ON/OFF] | |
| HI BEAM SW [ON/OFF] | |
| HEAD LAMP SW 1 [ON/OFF] | |
| HEAD LAMP SW 2 [ON/OFF] | |
| PASSING SW [ON/OFF] | |
| AUTO LIGHT SW* [ON/OFF] | |
| FR FOG SW [ON/OFF] | |
| DOOR SW-DR [ON/OFF] | |
| DOOR SW-AS [ON/OFF] | The switch status input from front door switch (passenger side) |
| DOOR SW-RR [ON/OFF] | The switch status input from rear door switch RH |
| DOOR SW- RL [ON/OFF] | The switch status input from rear door switch LH |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

*: With auto light system

ACTIVE TEST

| Test item | Operation | Description |
|----------------|-----------|--|
| TAIL LAMP | ON | Transmits the Position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON. |
| | OFF | Stops the tail lamp request signal transmission. |
| HEAD LAMP | HI | Transmits the high beam request signal with CAN communication to turn the headlamp (HI) |
| | LOW | Transmits the low beam request signal with CAN communication to turn the headlamp (LOW). |
| | OFF | Stops the high & low beam request signal transmission. |
| FR FOG LAMP | ON | Transmits the front fog lights request signal to IPDM E/R with CAN communication to turn the front fog lamp ON. |
| | OFF | Stops the front fog lights request signal transmission. |
| ILL DIM SIGNAL | ON | Transmits the delay timer function timer operation time signal to IPDM E/R with CAN communication to turn the headlamps ON (All doors closed). |
| | OFF | Stops the delay timer function timer signal transmission. |

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000007421619

WORK SUPPORT

| Service item | Setting item | Description |
|---------------------|--------------|---|
| WIPER SPEED SETTING | ON | With vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper dial position) |
| | OFF* | Without vehicle speed (Front wiper intermittent time linked with the wiper dial position) |

*: Initial setting

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------------|--|
| PUSH SW [OFF/ON] | Displays the status of the engine switch (push switch) judged by BCM. |
| VEH SPEED 1 [km/h] | Displays the value of the vehicle speed signal received from combination meter with CAN communication. |
| FR WIPER HI [OFF/ON] | Status of each switch judged by BCM using the combination switch reading function |
| FR WIPER LOW [OFF/ON] | |
| FR WASHER SW [OFF/ON] | |
| FR WIPER INT [OFF/ON] | |
| FR WIPER STOP [OFF/ON] | Displays the status of the front wiper auto stop signal received from IPDM E/R with CAN communication. |
| INT VOLUME [1 - 6] | Status of each switch judged by BCM using the combination switch reading function |

ACTIVE TEST

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Test item | Operation | Description |
|-----------|-----------|---|
| FR WIPER | HI | Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation. |
| | LO | Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation. |
| | INT | Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation. |
| | OFF | Stops transmitting the front wiper request signal to stop the front wiper operation. |

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000007421620

WORK SUPPORT

| Service item | Setting item | Setting |
|--------------------|--------------|--|
| HAZARD ANSWER BACK | LOCK ONLY | Activated when locking. |
| | UNLOCK ONLY* | Activated when unlocking. |
| | LOCK/UNLOCK | Activated when locking/unlocking |
| | OFF | Not activated |
| | | Sets the hazard warning lamp answer back activation when the door is lock/unlock with the request switch or the key fob. |

* : Initial setting

DATA MONITOR

| Monitor item [Unit] | Description |
|---------------------------|--|
| REQ SW-DR [ON/OFF] | The switch status input from request switch (driver side) |
| REQ SW-AS [ON/OFF] | The switch status input from front request switch (passenger side) |
| PUSH SW [ON/OFF] | The switch status input from push-button ignition switch |
| TURN SIGNAL R [ON/OFF] | Each switch condition that BCM judges from the combination switch reading function |
| TURN SIGNAL L [ON/OFF] | |
| HAZARD SW [ON/OFF] | The switch status input from the hazard warning switch |
| RKE-LOCK [ON/OFF] | The lock signal status received from the keyless receiver |
| RKE-UNLOCK [ON/OFF] | The unlock signal status received from the keyless receiver |
| RKE-PANIC [ON/OFF] | The panic alarm signal status received from the keyless receiver |

ACTIVE TEST

| Test item | Operation | Description |
|-----------|-----------|---|
| FLASHER | RH | Blinks right turn signal lamp. |
| | LH | Blinks left turn signal lamp. |
| | OFF | Turns turn signal lamps (right and left) OFF. |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

AIR CONDITIONER

AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER)

INFOID:000000007421621

DATA MONITOR

| Monitor Item [Unit] | Contents |
|------------------------|--|
| FAN ON SIG [ON/OFF] | Display [FAN (On)/FAN (Off)] status as judged from blower fan motor switch signal |
| AIR COND SW [ON/OFF] | Display [COMP (On)/COMP (Off)] status as judged from air conditioner switch signal |

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000007421622

WORK SUPPORT

| Monitor item | Description |
|--------------------------|--|
| CONFIRM KEY FOB ID | It can be checked whether Intelligent Key ID code is registered or not in this mode. |
| AUTO LOCK SET | Auto door lock time can be changed in this mode. <ul style="list-style-type: none">• MODE1: 1 minute• MODE2: 5 minutes• MODE3: 30 seconds• MODE4: 2 minutes |
| LOCK/UNLOCK BY I-KEY | Door lock/unlock function by door request switch mode can be changed to operate (ON) or not operate (OFF) in this mode. |
| ENGINE START BY I-KEY | Engine start function mode can be changed to operate (ON) or not operate (OFF) with this mode. |
| TRUNK/GLASS HATCH OPEN | Buzzer reminder function mode by trunk request switch can be changed to operate (ON) or not operate (OFF) with this mode. |
| PANIC ALARM SET | Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode. <ul style="list-style-type: none">• MODE1: 0.5 sec.• MODE2: Non-operation• MODE3: 1.5 sec. |
| PW DOWN SET | Unlock button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none">• MODE1: 3 sec.• MODE2: Non-operation• MODE3: 5 sec. |
| TRUNK OPEN DELAY | Trunk button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none">• MODE1: 0.5 sec.• MODE2: 1.5 sec.• MODE3: OFF: No delay |
| LO- BATT OF KEY FOB WARN | Intelligent Key low battery warning mode can be changed to operate (ON) or not operate (OFF) with this mode. |
| ANTI KEY LOCK IN FUNCTI | Key reminder function mode can be changed to operate (ON) or not operate (OFF) with this mode. |
| HAZARD ANSWER BACK | Hazard reminder function mode can be selected from the following with this mode. <ul style="list-style-type: none">• LOCK ONLY: Door lock operation only• UNLOCK ONLY: Door unlock operation only• LOCK/UNLOCK: Lock/unlock operation• OFF: Non-operation |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Monitor item | Description |
|------------------------|--|
| ANS BACK I-KEY LOCK | Buzzer reminder function (lock operation) mode by door request switch (driver side and passenger side) can be selected from the following with this mode. <ul style="list-style-type: none"> • Horn chirp: Sound horn • Buzzer: Sound Intelligent Key warning buzzer • OFF: Non-operation |
| ANS BACK I-KEY UNLOCK | Buzzer reminder function (unlock operation) mode by door request switch can be changed to operate (ON) or not operate (OFF) with this mode. |
| SHORT CRANKING OUTPUT | Starter motor can be forcibly activated. |
| INSIDE ANT DIAGNOSIS | This function allows inside key antenna self-diagnosis. |
| HORN WITH KEYLESS LOCK | Horn reminder function mode by Intelligent Key button can be changed to operate (ON) or not operate (OFF) with this mode. |

SELF-DIAG RESULT

Refer to [BCS-67, "DTC Index"](#).

DATA MONITOR

| Monitor Item | Condition |
|-----------------|---|
| REQ SW-DR | Indicates [ON/OFF] condition of door request switch (driver side). |
| REQ SW-AS | Indicates [ON/OFF] condition of door request switch (passenger side). |
| REQ SW-BD/TR | Indicates [ON/OFF] condition of trunk opener request switch. |
| PUSH SW | Indicates [ON/OFF] condition of push button ignition switch. |
| CLUTCH SW | Indicates [ON/OFF] condition of clutch switch. |
| IGN RLY2 -F/B | Indicates [ON/OFF] condition of ignition relay 2. |
| ACC RLY-F/B | Indicates [ON/OFF] condition of accessory relay-1. |
| BRAKE SW 1 | Indicates [ON/OFF] condition of brake switch. |
| BRAKE SW 2 | Indicates [ON/OFF] condition of brake switch. |
| DETE/CANCL SW | Indicates [ON/OFF] condition of P position. |
| SFT PN/N SW | Indicates [ON/OFF] condition of P or N position. |
| S/L -LOCK | Indicates [ON/OFF] condition of steering lock (LOCK). |
| S/L -UNLOCK | Indicates [ON/OFF] condition of steering lock (UNLOCK). |
| S/L RELAY-F/B | Indicates [ON/OFF] condition of ignition switch. |
| UNLK SEN-DR | Indicates [ON/OFF] condition of driver door UNLOCK status. |
| PUSH SW -IPDM | Indicates [ON/OFF] condition of push button ignition switch. |
| IGN RLY1 -F/B | Indicates [ON/OFF] condition of ignition relay 1. |
| DETE SW -IPDM | Indicates [ON/OFF] condition of P position. |
| SFT PN -IPDM | Indicates [ON/OFF] condition of P or N position. |
| SFT P -MET | Indicates [ON/OFF] condition of P position. |
| SFT N -MET | Indicates [ON/OFF] condition of N position. |
| ENGINE STATE | Indicates [STOP/STALL/CRANK/RUN] condition of engine states. |
| S/L LOCK-IPDM | Indicates [ON/OFF] condition of steering lock (LOCK) request. |
| S/L UNLOCK-IPDM | Indicates [ON/OFF] condition of steering lock (UNLOCK) request. |
| S/L RELAY-REQ | Indicates [ON/OFF] condition of steering lock relay. |
| VEH SPEED 1 | Display the vehicle speed signal received from combination meter by numerical value [Km/h]. |
| VEH SPEED 2 | Display the vehicle speed signal received from ABS or VDC or CVT by numerical value [Km/h]. |
| DOOR STAT-DR | Indicates [LOCK/READY/UNLK] condition of driver side door status. |
| DOOR STAT-AS | Indicates [LOCK/READY/UNLK] condition of passenger side door status. |
| ID OK FLAG | Indicates [SET/RESET] condition of key ID. |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Monitor Item | Condition |
|---------------|--|
| PRMT ENG STRT | Indicates [SET/RESET] condition of engine start possibility. |
| KEY SW -SLOT | Indicates [ON/OFF] condition of key slot. |
| RKE OPE COUN1 | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| TRNK/HAT MNTR | Indicates [ON/OFF] condition of trunk lid. |
| RKE-LOCK | Indicates [ON/OFF] condition of LOCK signal from Intelligent Key. |
| RKE-UNLOCK | Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key. |
| RKE-TR/BD | Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key. |
| RKE-PANIC | Indicates [ON/OFF] condition of PANIC button of Intelligent Key. |
| RKE-P/W OPEN | Indicates [ON/OFF] condition of P/W DOWN signal from Intelligent Key. |
| RKE-MODE CHG | Indicates [ON/OFF] condition of MODE CHANGE signal from Intelligent Key. |
| PRMT RKE STRT | Indicates [ON/OFF] condition of ENGINE START signal from Intelligent Key. |
| RKE OPE COUN2 | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| REVERSE SW | Indicates [ON/OFF] condition of R position. |

ACTIVE TEST

| Test item | Description |
|--------------------|---|
| BATTERY SAVER | This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT screen is touched. |
| PW REMOTO DOWN SET | This test is able to check power window down operation. The power window down is activated after "ON" on CONSULT screen is touched. |
| OUTSIDE BUZZER | This test is able to check Intelligent Key warning buzzer operation. The Intelligent Key warning buzzer is activated after "ON" on CONSULT screen is touched. |
| INSIDE BUZZER | This test is able to check warning chime in combination meter operation. <ul style="list-style-type: none"> • Take away warning chime sounds when "TAKE OUT" on CONSULT screen is touched. • Key warning chime sounds when "KEY" on CONSULT screen is touched. • OFF position warning chime sounds when "KNOB" on CONSULT screen is touched. |
| INDICATOR | This test is able to check warning lamp operation. <ul style="list-style-type: none"> • "KEY" Warning lamp illuminates when "KEY ON" on CONSULT screen is touched. • "KEY" Warning lamp blinks when "KEY IND" on CONSULT screen is touched. |
| INT LAMP | This test is able to check interior room lamp operation. The interior room lamp is activated after "ON" on CONSULT screen is touched. |
| LCD | This test is able to check meter display information <ul style="list-style-type: none"> • Engine start information displays when "BP N" on CONSULT screen is touched. • Engine start information displays when "BP I" on CONSULT screen is touched. • Key ID warning displays when "ID NG" on CONSULT screen is touched. • P position warning displays when "SFT P" on CONSULT screen is touched. • Intelligent Key insert information displays when "INSRT" on CONSULT screen is touched. • Intelligent Key low battery warning displays when "BATT" on CONSULT screen is touched. • Take away through window warning displays when "NO KY" on CONSULT screen is touched. • Take away warning display when "OUTKEY" on CONSULT screen is touched. • OFF position warning display when "LK WN" on CONSULT screen is touched. |
| FLASHER | This test is able to check hazard warning lamp operation. The hazard warning lamps are activated after "LH/RH/OFF" on CONSULT screen is touched. |
| HORN | This test is able to check horn operation. The horn is activated after "ON" on CONSULT screen is touched. |
| P RANGE | This test is able to check CVT shift selector power supply CVT shift selector power is supplied when "ON" on CONSULT screen is touched. |
| ENGINE SW ILLUMI | This test is able to check push-ignition switch illumination operation. Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Test item | Description |
|-----------------|--|
| LOCK INDICATOR | This test is able to check LOCK indicator in push-ignition switch operation. LOCK indicator in push-ignition switch illuminates when "ON" on CONSULT screen is touched. |
| ACC INDICATOR | This test is able to check ACC indicator in push-ignition switch operation. ACC indicator in push-ignition switch illuminates when "ON" on CONSULT screen is touched. |
| IGNITION ON IND | This test is able to check ON indicator in push-ignition switch operation. ON indicator in push-ignition switch illuminates when "ON" on CONSULT screen is touched. |
| KEY SLOT ILLUMI | This test is able to check key slot illumination operation. Key slot illumination blinks when "ON" on CONSULT screen is touched. |
| TRUNK/BACK DOOR | This test is able to check trunk opener actuator open operation. This actuator opens when "OPEN" on CONSULT screen is touched. |

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000007421623

DATA MONITOR

| Monitor item [UNIT] | Description |
|-------------------------|--|
| FR WIPER HI [OFF/ON] | Displays the status of the FR WIPER HI switch in combination switch judged by BCM with the combination switch reading function. |
| FR WIPER LOW [OFF/ON] | Displays the status of the FR WIPER LOW switch in combination switch judged by BCM with the combination switch reading function. |
| FR WASHER SW [OFF/ON] | Displays the status of the FR WASHER switch in combination switch judged by BCM with the combination switch reading function. |
| FR WIPER INT [OFF/ON] | Displays the status of the FR WIPER INT switch in combination switch judged by BCM with the combination switch reading function. |
| FR WIPER STOP [OFF/ON] | Displays the status of the front wiper stop position signal received from IPDM E/R via CAN communication. |
| INT VOLUME [1 - 7] | Displays the status of wiper intermittent dial position judged by BCM with the combination switch reading function. |
| TURN SIGNAL R [OFF/ON] | Displays the status of the TURN RH switch in combination switch judged by BCM with the combination switch reading function. |
| TURN SIGNAL L [OFF/ON] | Displays the status of the TURN LH switch in combination switch judged by BCM with the combination switch reading function. |
| TAIL LAMP SW [OFF/ON] | Displays the status of the TAIL LAMP switch in combination switch judged by BCM with the combination switch reading function. |
| HI BEAM SW [OFF/ON] | Displays the status of the HI BEAM switch in combination switch judged by BCM with the combination switch reading function. |
| HEAD LAMP SW 1 [OFF/ON] | Displays the status of the HEADLAMP 1 switch in combination switch judged by BCM with the combination switch reading function. |
| HEAD LAMP SW 2 [OFF/ON] | Displays the status of the HEADLAMP 2 switch in combination switch judged by BCM with the combination switch reading function. |
| PASSING SW [OFF/ON] | Displays the status of the PASSING switch in combination switch judged by BCM with the combination switch reading function. |
| AUTO LIGHT SW* [OFF/ON] | Displays the status of the AUTO LIGHT switch in combination switch judged by BCM with the combination switch reading function. |
| FR FOG SW [OFF/ON] | Displays the status of the FR FOG switch in combination switch judged by BCM with the combination switch reading function. |

*: With auto light system

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000007421624

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Item | Description |
|---------------------|--|
| RESET SETTING VALUE | Return a value set with WORK SUPPORT of each system to a default value in initial setting. |

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000007421625

DATA MONITOR

| Monitor item | Content |
|----------------|---|
| CONFIRM ID ALL | Indicates [YET] at all time. Switch to [DONE] when a registered Intelligent Key is inserted into the key slot. |
| CONFIRM ID4 | |
| CONFIRM ID3 | |
| CONFIRM ID2 | |
| CONFIRM ID1 | |
| TP 4 | Indicates the number of ID which has been registered. |
| TP 3 | |
| TP 2 | |
| TP 1 | |
| PUSH SW | Indicates [ON/OFF] condition of push-button ignition switch. |
| KEY SW -SLOT | Indicates [ON/OFF] condition of key slot. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| THEFT IND | This test is able to check security indicator operation [ON/OFF]. |

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000007421626

WORK SUPPORT

| Service item | Setting item | Setting |
|-----------------------|--------------|---|
| BATTERY SAVER SET | ON* | With the exterior lamp battery saver function |
| | OFF | Without the exterior lamp battery saver function |
| ROOM LAMP BAT SAV SET | ON* | With the interior room lamp battery saver function |
| | OFF | Without the interior room lamp battery saver function |
| ROOM LAMP TIMER SET | MODE 1* | Sets the interior room lamp battery saver timer operating time. |
| | MODE 2 | |

*: Initial setting

DATA MONITOR

| Monitor item [Unit] | Description |
|------------------------|--|
| REQ SW-DR [ON/OFF] | The switch status input from request switch (driver side) |
| REQ SW-AS [ON/OFF] | The switch status input from front request switch (passenger side) |
| PUSH SW [ON/OFF] | The switch status input from push-button ignition switch |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Monitor item [Unit] | Description |
|---------------------------|--|
| ACC RLY-F/B [ON/OFF] | Indicates [ON/OFF] condition of accessory relay-1. |
| UNLK SEN-DR [ON/OFF] | Status of front door lock assembly LH (door unlock sensor) judged by BCM |
| KEY SW-SLOT [ON/OFF] | Key switch status input from key slot |
| DOOR SW-DR [ON/OFF] | The switch status input from front door switch (driver side) |
| DOOR SW-AS [ON/OFF] | The switch status input from front door switch (passenger side) |
| DOOR SW-RR [ON/OFF] | The switch status input from rear door switch RH |
| DOOR SW- RL [ON/OFF] | The switch status input from rear door switch LH |
| CDL LOCK SW [ON/OFF] | Lock switch status received from central door lock switch by power window switch serial link |
| CDL UNLOCK SW [ON/OFF] | Unlock switch status received from central door lock switch by power window switch serial link |
| KEY CYL LK-SW [ON/OFF] | Lock switch status received from key cylinder switch by power window switch serial link |
| KEY CYL UN-SW [ON/OFF] | Unlock switch status received from key cylinder switch by power window switch serial link |
| TRNK/HAT MNTR [ON/OFF] | The switch status input from trunk room lamp switch |
| RKE-LOCK [ON/OFF] | Lock signal status received from remote keyless entry receiver |
| RKE-UNLOCK [ON/OFF] | Unlock signal status received from remote keyless entry receiver |

ACTIVE TEST

| Test item | Operation | Description |
|---------------|-----------|---|
| BATTERY SAVER | OFF | Cuts the interior room lamp power supply to turn interior room lamp OFF. |
| | ON | Outputs the interior room lamp power supply to turn interior room lamp ON.* |

*: Each lamp switch is in ON position.

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:000000007421627

DATA MONITOR

| Monitor Item | Contents |
|---------------|--|
| PUSH SW | Indicates [ON/OFF] condition of push button ignition switch. |
| UNLK SEN -DR | Indicates [ON/OFF] condition of driver door UNLOCK status. |
| VEH SPEED 1 | Indicates [Km/h] condition of vehicle speed signal from combination meter. |
| TR CANCEL SW | Indicates [ON/OFF] condition of trunk cancel switch. |
| TR/BD OPEN SW | Indicates [ON/OFF] condition of trunk opener switch. |
| TRNK/HAT MNTR | Indicates [ON/OFF] condition of trunk lid. |
| RKE-TR/BD | Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Test Item | Description |
|-------------------|---|
| TRUNK/GLASS HATCH | This test is able to check trunk open operation. Trunk opens when "OPEN" on CONSULT screen is touched. |

THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:000000007421628

WORK SUPPORT

| Test Item | Description |
|--------------------|---|
| SECURITY ALARM SET | This mode is able to confirm and change security alarm ON-OFF setting. |
| THEFT ALM TRG | The switch which triggered vehicle security alarm is recorded. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching "CLEAR" on CONSULT screen. |

DATA MONITOR

| Monitored Item | Description |
|----------------|---|
| REQ SW -DR | Indicates [ON/OFF] condition of front door request switch (driver side). |
| REQ SW -AS | Indicates [ON/OFF] condition of front door request switch (passenger side). |
| REQ SW -BD/TR | Indicates [ON/OFF] condition of trunk request switch. |
| PUSH SW | Indicates [ON/OFF] condition of push-button ignition switch |
| UNLK SEN -DR | Indicates [ON/OFF] condition of driver door UNLOCK status. |
| KEY SW -SLOT | Indicates [ON/OFF] condition of key slot. |
| DOOR SW-DR | Indicates [ON/OFF] condition of front door switch LH. |
| DOOR SW-AS | Indicates [ON/OFF] condition of front door switch RH. |
| DOOR SW-RR | Indicates [ON/OFF] condition of rear door switch RH. |
| DOOR SW-RL | Indicates [ON/OFF] condition of rear door switch LH. |
| CDL LOCK SW | Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH. |
| CDL UNLOCK SW | Indicates [ON/OFF] condition of unlock signal from door lock/unlock switch LH and RH. |
| KEY CYL LK-SW | Indicates [ON/OFF] condition of lock signal from front door key cylinder switch. |
| KEY CYL UN-SW | Indicates [ON/OFF] condition of unlock signal from front door key cylinder switch. |
| TR/BD OPEN SW | Indicates [ON/OFF] condition of trunk opener switch. |
| TRNK/HAT MNTR | Indicates [ON/OFF] condition of trunk lid. |
| RKE-LOCK | Indicates [ON/OFF] condition of LOCK signal from Intelligent Key. |
| RKE-UNLOCK | Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key. |
| RKE-TR/BD | Indicates [ON/OFF] condition of TRUNK OPEN signal from Intelligent Key. |

ACTIVE TEST

| Test item | Operation | Description |
|-----------------------|-----------|--|
| THEFT IND | | This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT screen is touched. |
| VEHICLE SECURITY HORN | | This test is able to check vehicle security horn operation. The horns will be activated for 0.5 seconds after "ON" on CONSULT screen is touched. |
| HEAD LAMP(HI) | | This test is able to check vehicle security lamp operation. The headlamps will be activated for 0.5 seconds after "ON" on CONSULT screen is touched. |
| FLASHER | RH | Outputs the voltage to blink the right side turn signal lamps. |
| | LH | Outputs the voltage to blink the left side turn signal lamps. |
| | Off | Stops the voltage to turn the turn signal lamps OFF. |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000007421629

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| DOOR SW-DR [ON/OFF] | Indicates condition of front door switch LH. |
| DOOR SW-AS [ON/OFF] | Indicates condition of front door switch RH. |

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000007421630

DATA MONITOR

| Monitor item [UNIT] | Description |
|---------------------|---|
| PUSH SW [OFF/ON] | Displays the status of the push-button ignition switch (push switch) judged by BCM. |

ACTIVE TEST

| Test item | Operation | Description |
|-----------------|-----------|---|
| OIL PRESSURE SW | OFF | OFF |
| | ON | BCM transmits the oil pressure switch signal to the combination meter via CAN communication, which illuminates the oil pressure warning lamp. |

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR : CONSULT Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000007421631

WORK SUPPORT

ID Read

The registered ID number is displayed.

ID Regist

Refer to [WT-6. "ID Registration Procedure"](#).

SELF-DIAG RESULTS

Refer to [BCS-67. "DTC Index"](#).

DATA MONITOR

Screen of data monitor mode is displayed.

NOTE:

When malfunction is detected, CONSULT perform REAL-TIME DIAGNOSIS.
Also, any malfunction detected while in this mode will be displayed at real time.

Display item list

| Monitor | Condition | Specification |
|--|--|--|
| AIR PRESS FL AIR PRESS FR AIR PRESS RR AIR PRESS RL | <ul style="list-style-type: none">Drive vehicle for a few minutes. orIgnition switch ON and activation tool is transmitting activation signals. | Tire pressure (kPa, kg/cm ² or Psi) |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

| Monitor | Condition | Specification |
|--|--------------------|--|
| ID REGST FL1 ID REGST FR1 ID REGST RR1 ID REGST RL1 | Ignition switch ON | Registration ID: Green No registration: Red |
| WARNING LAMP | | Low tire pressure warning lamp on: ON Low tire pressure warning lamp off: OFF |
| BUZZER | | Buzzer in combination meter on: ON Buzzer in combination meter off: OFF |

A
B
C

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction location may be different from that displayed on CONSULT.

D

ACTIVE TEST

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or else the actual malfunction may be different from that displayed on CONSULT.

E

TEST ITEM LIST

F

| Test item | Content |
|-------------------|---|
| WARNING LAMP | This test is able to check warning lamp operation. The lamp will be turned on when "ON" on CONSULT screen is touched. |
| ID REGIST WARNING | This test is able to check to make sure that the buzzer sounds or the warning lamp turns on. |
| FLASHER | This test is able to check to make sure that each turn signal lamp turns on. |
| HORN | This test is able to check to make sure that the horn sounds. |

G
H
I

J
K
L

BCS

N
O
P

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007421632

Refer to [BCS-6, "System Description"](#).

DTC Logic

INFOID:000000007421633

DTC DETECTION LOGIC

| CONSULT display description | DTC Detection Condition | Possible cause |
|-----------------------------|---|--|
| CAN COMM CIRCUIT [U1000] | When any listed module cannot communicate CAN communication signal continuously for 2 seconds or more with ignition switch ON | In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none"> • Transmission • Receiving (ECM) • Receiving (VDC/TCS/ABS) • Receiving (METER/M&A) • Receiving (TCM) • Receiving (IPDM E/R) |

Diagnosis Procedure

INFOID:000000007421634

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF- DIAG RESULTS".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-7, "CAN Communication Control Circuit"](#).
- NO >> Refer to [GI-42, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000007421635

DTC DETECTION LOGIC

| CONSULT display description | DTC Detection Condition | Possible cause |
|-----------------------------|--|----------------|
| CAN COMM CIRCUIT [U1010] | BCM detected internal CAN communication circuit malfunction. | BCM |

Diagnosis Procedure

INFOID:000000007421636

1. REPLACE BCM

When DTC U1010 is detected, replace BCM.

>> Replace BCM. Refer to [BCS-92, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

U0415 VEHICLE SPEED SIG

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

U0415 VEHICLE SPEED SIG

Description

INFOID:000000007421637

U0415 is displayed if any unusual condition is present in the reception status of the vehicle speed signal from the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007421638

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|---|---|
| U0415 | VEHICLE SPEED SIG [U0415] | When the vehicle speed signal received from the ABS actuator and electric unit (control unit) remains abnormal for 2 seconds or more. | <ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• BCM |

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase the DTC.
2. Turn ignition switch OFF.
3. Perform the "SELF-DIAG RESULTS" of CONSULT, when passed 2 seconds or more after the ignition switch is turned ON

Is any DTC detected?

- YES >> Refer to [BCS-34, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000007421639

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAG RESULTS

Perform "SELF-DIAG RESULTS" of ABS actuator and electric unit (control unit) with CONSULT. Refer to [BRC-15, "CONSULT Function \(ABS\)"](#).

Is any DTC detected?

- YES >> Repair or replace the malfunctioning part.
NO >> Replace BCM. Refer to [BCS-92, "Removal and Installation"](#).

B2562 LOW VOLTAGE

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

B2562 LOW VOLTAGE

DTC Logic

INFOID:000000007421640

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Possible cause |
|-------|-----------------------------|--|---|
| B2562 | LOW VOLTAGE | When the power supply voltage to BCM remains less than 8.8 V for 1.5 seconds or more | Harness or connector (power supply circuit) |

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "SELF-DIAG RESULTS" of CONSULT, when passed 1.5 seconds or more after ignition switch is turned ON.

Is any DTC detected?

YES >> Refer to [BCS-35, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:000000007421641

1. CHECK BATTERY VOLTAGE

Check battery voltage.

Is battery voltage less than 8.8V?

Yes >> Charge battery and retest. Refer to [PG-142, "Battery"](#).

No >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

Check BCM power supply circuit. Refer to [BCS-36, "Diagnosis Procedure"](#).

Is the circuit OK?

Yes >> Replace BCM. Refer to [BCS-92, "Removal and Installation"](#).

No >> Repair or replace the malfunctioning part.

Special Repair Requirement

INFOID:000000007421642

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-3, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\): Work Procedure"](#).

BCS

>> Work End.

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000007421643

Regarding Wiring Diagram information, refer to [BCS-70. "Wiring Diagram - Coupe"](#) or [BCS-79. "Wiring Diagram - Sedan"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check if the following BCM fuse or fusible link are blown.

| Terminal No. | Signal name | Fuse and fusible link No. |
|--------------|----------------------|---------------------------|
| 1 | Battery power supply | H |
| 11 | | 10 |


Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
 NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM harness connector and ground.

| Terminals | | Voltage (Approx.) |
|-----------|----------|-------------------|
| (+) | (-) | |
| BCM | | Ground |
| Connector | Terminal | |
| M16 | 1 | |
| M17 | 11 | Battery voltage |



Is the measurement normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M17 | 13 | | Yes |

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



Special Repair Requirement

INFOID:000000007421644

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-3. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\): Work Procedure"](#).

>> Work End.

COMBINATION SWITCH INPUT CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000007421645

Regarding Wiring Diagram information, refer to [BCS-70. "Wiring Diagram - Coupe"](#) or [BCS-79. "Wiring Diagram - Sedan"](#).

1. CHECK COMBINATION SWITCH

CONSULT DATA MONITOR and ACTIVE TEST

Check combination switch function. Refer to [BCS-26. "COMB SW : CONSULT Function \(BCM - COMB SW\)"](#).


Does combination switch function?

- YES >> Combination switch operation is normal.
- NO >> GO TO 2

2. CHECK INPUT 1 - 5 SYSTEM CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect the BCM and combination switch.
3. Check continuity between BCM harness connector and combination switch harness connector.

| System | BCM | | Combination switch | | Continuity |
|---------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| INPUT 1 | M19 | 95 | M28 | 11 | Yes |
| INPUT 2 | | 97 | | 9 | |
| INPUT 3 | | 76 | | 7 | |
| INPUT 4 | | 96 | | 10 | |
| INPUT 5 | | 75 | | 13 | |




Does continuity exist?

- YES >> GO TO 3
- NO >> Repair or replace harness.

3. CHECK INPUT 1 - 5 SYSTEM CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

| System | BCM | | Continuity |
|---------|-----------|----------|------------|
| | Connector | Terminal | |
| INPUT 1 | M19 | 95 | No |
| INPUT 2 | | 97 | |
| INPUT 3 | | 76 | |
| INPUT 4 | | 96 | |
| INPUT 5 | | 75 | |



Does continuity exist?

- YES >> Repair or replace harness.
- NO >> GO TO 4

4. CHECK BCM OUTPUT VOLTAGE

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS


COMBINATION SWITCH INPUT CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect the BCM.
2. Check voltage between BCM harness connector and ground.

| System | Terminals | | Voltage (Approx.) | |
|---------|-----------|----------|-------------------|--|
| | (+) | (-) | | |
| | BCM | | | |
| | Connector | Terminal | Ground | Refer to BCS-45 , "Physical Values". |
| INPUT 1 | M19 | 95 | | |
| INPUT 2 | | 97 | | |
| INPUT 3 | | 76 | | |
| INPUT 4 | | 96 | | |
| INPUT 5 | | 75 | | |




Is the measurement normal?

- YES >> GO TO 5
 NO >> Replace BCM. Refer to [BCS-92](#), "Removal and Installation".

5. CHECK BCM INPUT SIGNAL

1. Connect the combination switch.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM harness connector and ground.

| System | Terminals | | Voltage (Approx.) | |
|---------|-----------|----------|-------------------|--|
| | (+) | (-) | | |
| | BCM | | | |
| | Connector | Terminal | Ground | Refer to BCS-45 , "Physical Values". |
| INPUT 1 | M19 | 95 | | |
| INPUT 2 | | 97 | | |
| INPUT 3 | | 76 | | |
| INPUT 4 | | 96 | | |
| INPUT 5 | | 75 | | |



Is the measurement normal when any of the switches is turned ON?

- YES >> Replace BCM. Refer to [BCS-92](#), "Removal and Installation".
 NO >> Replace the combination switch. Refer to [EXL-219](#), "Removal and Installation".

Special Repair Requirement

INFOID:000000007421646

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-3](#), "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM): Work Procedure".

>> Work End.

COMBINATION SWITCH OUTPUT CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:000000007421647

Regarding Wiring Diagram information, refer to [BCS-70. "Wiring Diagram - Coupe"](#) or [BCS-79. "Wiring Diagram - Sedan"](#).

1. CHECK COMBINATION SWITCH

Ⓜ CONSULT DATA MONITOR and ACTIVE TEST

Check combination switch function. Refer to [BCS-26. "COMB SW : CONSULT Function \(BCM - COMB SW\)"](#).


Does combination switch function?

- YES >> Combination switch operation is normal.
- NO >> GO TO 2

2. CHECK OUTPUT 1 - 5 SYSTEM CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect the BCM and combination switch.
3. Check continuity between BCM harness connector and combination switch harness connector.

| System | BCM | | Combination switch | | Continuity |
|----------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| OUTPUT 1 | M18 | 51 | M28 | 12 | Yes |
| OUTPUT 2 | | 52 | | 14 | |
| OUTPUT 3 | | 53 | | 5 | |
| OUTPUT 4 | | 54 | | 2 | |
| OUTPUT 5 | | 50 | | 8 | |




Does continuity exist?

- YES >> GO TO 3
- NO >> Repair or replace harness.

3. CHECK OUTPUT 1 - 5 SYSTEM CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

| System | BCM | | Continuity |
|----------|-----------|----------|------------|
| | Connector | Terminal | |
| OUTPUT 1 | M18 | 51 | No |
| OUTPUT 2 | | 52 | |
| OUTPUT 3 | | 53 | |
| OUTPUT 4 | | 54 | |
| OUTPUT 5 | | 50 | |



Does continuity exist?

- YES >> Repair or replace harness.
- NO >> GO TO 4

4. CHECK COMBINATION SWITCH OUTPUT VOLTAGE

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


BCS

COMBINATION SWITCH OUTPUT CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect the BCM and combination switch.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between combination switch harness connector and ground.



| System | Terminals | | Value (Approx.) | |
|----------|-----------|----------|-----------------|-----|
| | (+) | | | (-) |
| | Connector | Terminal | | |
| OUTPUT 1 | M28 | 12 | Ground | |
| OUTPUT 2 | | 14 | | |
| OUTPUT 3 | | 5 | | |
| OUTPUT 4 | | 2 | | |
| OUTPUT 5 | | 8 | | |

1.4 V

Is the measurement normal when any of the switches is turned ON?

- YES >> Replace BCM. Refer to [BCS-92. "Removal and Installation"](#).
 NO >> Replace the combination switch. Refer to [EXL-219. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000007421648

1. REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to [BCS-3. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).

>> Work End.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000007421649

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------------|
| FR WIPER HI | Other than front wiper switch HI | OFF |
| | Front wiper switch HI | ON |
| FR WIPER LOW | Other than front wiper switch LO | OFF |
| | Front wiper switch LO | ON |
| FR WASHER SW | Front washer switch OFF | OFF |
| | Front washer switch ON | ON |
| FR WIPER INT | Other than front wiper switch INT | OFF |
| | Front wiper switch INT | ON |
| FR WIPER STOP | Front wiper is not in STOP position | OFF |
| | Front wiper is in STOP position | ON |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 6 | Wiper intermittent dial position |
| TURN SIGNAL R | Other than turn signal switch RH | OFF |
| | Turn signal switch RH | ON |
| TURN SIGNAL L | Other than turn signal switch LH | OFF |
| | Turn signal switch LH | ON |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | OFF |
| | Lighting switch 1ST or 2ND | ON |
| HI BEAM SW | Other than lighting switch HI | OFF |
| | Lighting switch HI | ON |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | OFF |
| | Lighting switch 2ND | ON |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | OFF |
| | Lighting switch 2ND | ON |
| PASSING SW | Other than lighting switch PASS | OFF |
| | Lighting switch PASS | ON |
| AUTO LIGHT SW | Other than lighting switch AUTO | OFF |
| | Lighting switch AUTO | ON |
| FR FOG SW | Front fog lamp switch OFF | OFF |
| | Front fog lamp switch ON | ON |
| DOOR SW-DR | Driver door closed | OFF |
| | Driver door opened | ON |
| DOOR SW-AS | Passenger door closed | OFF |
| | Passenger door opened | ON |
| DOOR SW-RR | Rear RH door closed | OFF |
| | Rear RH door opened | ON |
| DOOR SW-RL | Rear LH door closed | OFF |
| | Rear LH door opened | ON |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Monitor Item | Condition | Value/Status |
|----------------|---|--------------|
| CDL LOCK SW | Other than power door lock switch LOCK | OFF |
| | Power door lock switch LOCK | ON |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | OFF |
| | Power door lock switch UNLOCK | ON |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | OFF |
| | Driver door key cylinder LOCK position | ON |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | OFF |
| | Driver door key cylinder UNLOCK position | ON |
| HAZARD SW | When hazard switch is not pressed | OFF |
| | When hazard switch is pressed | ON |
| REAR DEF SW | When rear window defogger switch is pressed | ON |
| FAN ON SIG | When AUTO switch or fan switch is pressed | ON |
| AIR COND SW | When A/C switch is pressed | ON |
| TR CANCEL SW | Trunk lid opener cancel switch OFF | OFF |
| | Trunk lid opener cancel switch ON | ON |
| TR/BD OPEN SW | Trunk lid opener switch OFF | OFF |
| | While the trunk lid opener switch is turned ON | ON |
| TRNK/HAT MNTR | Trunk lid closed | OFF |
| | Trunk lid opened | ON |
| RKE-LOCK | When LOCK button of Intelligent Key is not pressed | OFF |
| | When LOCK button of Intelligent Key is pressed | ON |
| RKE-UNLOCK | When UNLOCK button of Intelligent Key is not pressed | OFF |
| | When UNLOCK button of Intelligent Key is pressed | ON |
| RKE-TR/BD | When TRUNK OPEN button of Intelligent Key is not pressed | OFF |
| | When TRUNK OPEN button of Intelligent Key is pressed | ON |
| RKE-PANIC | When PANIC button of Intelligent Key is not pressed | OFF |
| | When PANIC button of Intelligent Key is pressed | ON |
| RKE-P/W OPEN | When UNLOCK button of Intelligent Key is not pressed and held | OFF |
| | When UNLOCK button of Intelligent Key is pressed and held | ON |
| RKE-MODE CHG | When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously | OFF |
| | When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously | ON |
| OPTICAL SENSOR | When outside of the vehicle is bright | Close to 5 V |
| | When outside of the vehicle is dark | Close to 0 V |
| REQ SW-DR | When driver door request switch is not pressed | OFF |
| | When driver door request switch is pressed | ON |
| REQ SW-AS | When passenger door request switch is not pressed | OFF |
| | When passenger door request switch is pressed | ON |
| REQ SW-BD/TR | When trunk request switch is not pressed | OFF |
| | When trunk request switch is pressed | ON |
| PUSH SW | When engine switch (push switch) is not pressed | OFF |
| | When engine switch (push switch) is pressed | ON |
| IGN RLY -F/B | Ignition switch OFF or ACC | OFF |
| | Ignition switch ON | ON |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Monitor Item | Condition | Value/Status |
|----------------|--|-----------------------------------|
| ACC RLY -F/B | Ignition switch OFF | OFF |
| | Ignition switch ACC or ON | ON |
| CLUTCH SW | When the clutch pedal is not depressed | OFF |
| | When the clutch pedal is depressed | ON |
| BRAKE SW 1 | When the brake pedal is not depressed | ON |
| | When the brake pedal is depressed | OFF |
| DETE/CANCL SW | When selector lever is in P position | OFF |
| | When selector lever is in any position other than P | ON |
| SFT PN/N SW | When selector lever is in any position other than P or N | OFF |
| | When selector lever is in P or N position | ON |
| S/L -LOCK | Electronic steering column lock LOCK status | OFF |
| | Electronic steering column lock UNLOCK status | ON |
| S/L -UNLOCK | Electronic steering column lock UNLOCK status | OFF |
| | Electronic steering column lock LOCK status | ON |
| S/L RELAY-F/B | Ignition switch OFF or ACC | OFF |
| | Ignition switch ON | ON |
| UNLK SEN-DR | Driver door UNLOCK status | OFF |
| | Driver door LOCK status | ON |
| PUSH SW -IPDM | When engine switch (push switch) is not pressed | OFF |
| | When engine switch (push switch) is pressed | ON |
| IGN RLY1 F/B | Ignition switch OFF or ACC | OFF |
| | Ignition switch ON | ON |
| DETE SW -IPDM | When selector lever is in P position | OFF |
| | When selector lever is in any position other than P | ON |
| SFT PN -IPDM | When selector lever is in any position other than P or N | OFF |
| | When selector lever is in P or N position | ON |
| SFT P -MET | When selector lever is in any position other than P | OFF |
| | When selector lever is in P position | ON |
| SFT N -MET | When selector lever is in any position other than N | OFF |
| | When selector lever is in N position | ON |
| ENGINE STATE | Engine stopped | STOP |
| | While the engine stalls | STALL |
| | At engine cranking | CRANK |
| | Engine running | RUN |
| S/L LOCK-IPDM | Electronic steering column lock LOCK status | OFF |
| | Electronic steering column lock UNLOCK status | ON |
| S/L UNLCK-IPDM | Electronic steering column lock UNLOCK status | OFF |
| | Electronic steering column lock LOCK status | ON |
| S/L RELAY-REQ | Ignition switch OFF or ACC | OFF |
| | Ignition switch ON | ON |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Monitor Item | Condition | Value/Status |
|---------------|--|--|
| DR DOOR STATE | Driver door LOCK status | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Driver door UNLOCK status | UNLK |
| AS DOOR STATE | Passenger door LOCK status | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Passenger door UNLOCK status | UNLK |
| ID OK FLAG | Ignition switch ACC or ON | RESET |
| | Ignition switch OFF | SET |
| PRMT ENG STAT | When the engine start is prohibited | RESET |
| | When the engine start is permitted | SET |
| KEY SW -SLOT | When Intelligent Key is not inserted into key slot | OFF |
| | When Intelligent Key is inserted into key slot | ON |
| RKE OPE COUN1 | During the operation of Intelligent Key | Operation frequency of Intelligent Key |
| AIR PRESS FL | Ignition switch ON (only when the signal from the transmitter is received) | Air pressure of front LH tire |
| AIR PRESS FR | Ignition switch ON (only when the signal from the transmitter is received) | Air pressure of front RH tire |
| AIR PRESS RR | Ignition switch ON (only when the signal from the transmitter is received) | Air pressure of rear RH tire |
| AIR PRESS RL | Ignition switch ON (only when the signal from the transmitter is received) | Air pressure of rear LH tire |
| ID REGST FL1 | When ID of front LH tire transmitter is registered | DONE |
| | When ID of front LH tire transmitter is not registered | YET |
| ID REGST FR1 | When ID of front RH tire transmitter is registered | DONE |
| | When ID of front RH tire transmitter is not registered | YET |
| ID REGST RR1 | When ID of rear RH tire transmitter is registered | DONE |
| | When ID of rear RH tire transmitter is not registered | YET |
| ID REGST RL1 | When ID of rear LH tire transmitter is registered | DONE |
| | When ID of rear LH tire transmitter is not registered | YET |
| WARNING LAMP | Tire pressure indicator OFF | OFF |
| | Tire pressure indicator ON | ON |


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

Terminal Layout

INFOID:000000007421650



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS


Physical Values

INFOID:000000007421651

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]




| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|--|---|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 1 (W/B) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (R/Y) | Ground | Battery power supply output | Output | Ignition switch OFF | | Battery voltage |
| 3 (L/W) | Ground | Ignition power supply output | Output | Ignition switch ON | | Battery voltage |
| 4 (P/W) | Ground | Interior room lamp power supply | Output | After passing the interior room lamp battery saver operation time | | 0V |
| | | | | Any other time after passing the interior room lamp battery saver operation time | | Battery voltage |
| 5 (G/Y) | Ground | Front door RH UNLOCK | Output | Front door RH | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 7 (R/W) | Ground | Step lamp | Output | Step lamp | ON | 0V |
| | | | | | OFF | Battery voltage |
| 8 (V) | Ground | All doors LOCK | Output | All doors | LOCK (actuator is activated) | Battery voltage |
| | | | | | Other than LOCK (actuator is not activated) | 0V |
| 9 (G) | Ground | Front door LH UNLOCK | Output | Front door LH | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 10 ¹ (G/Y) | Ground | Rear door RH and rear door LH UNLOCK | Output | Rear door RH and rear door LH | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 11 (Y/R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0V |
| 14 ¹ (O/W) | Ground | Engine switch (push switch) illumination ground | Input | Tail lamp | OFF | 0V |
| | | | | | ON | NOTE: When the illumination brightening/dimming level is in the neutral position  |

JSN1A0010GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|-------------------------|---------------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 14 ⁸ (R/Y) | Ground | Engine switch (push switch) illumination ground | Input | Tail lamp | OFF | 0V |
| | | | | | ON | NOTE: When the illumination brightening/dimming level is in the neutral position  |
| 15 (Y/L) | Ground | ACC indicator lamp | Output | Ignition switch | OFF | Battery voltage |
| | | | | | ACC | 0V |
| 17 (G/B) | Ground | Turn signal (RH) | Output | Ignition switch ON | Turn signal switch OFF | 0V |
| | | | | | Turn signal switch RH |  |
| 18 (G/Y) | Ground | Turn signal (LH) | Output | Ignition switch ON | Turn signal switch OFF | 0V |
| | | | | | Turn signal switch LH |  |
| 19 (Y) | Ground | Room lamp timer control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | | ON | 0V |
| 21 (P/B) | Ground | Optical sensor signal | Input | Ignition switch ON | When outside of the vehicle is bright | Close to 5V |
| | | | | | When outside of the vehicle is dark | Close to 0V |
| 22 ² (R/Y) | Ground | Clutch interlock switch | Input | Clutch interlock switch | OFF (clutch pedal is not depressed) | 0V |
| | | | | | ON (clutch pedal is depressed) | Battery voltage |
| 24 (R/W) | Ground | Stop lamp switch 1 | Input | — | Battery voltage | |
| 26 (O/L) | Ground | Stop lamp switch 2 | Input | Stop lamp switch | OFF (brake pedal is not depressed) | 0V |
| | | | | | ON (brake pedal is depressed) | Battery voltage |

A
B
C
D
E
F
G
H
I
J
K
L




BCS

N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[BCM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|-------------------------------|--------|--|------------------|---|------------------------------------|--|
| (+) | (-) | Signal name | Input/ Output | | | |
| 27 (G/W) | Ground | Front door lock as- sembly LH (unlock sensor) | Input | Front door LH | LOCK status |  <small>JPM1A0011GB</small> 11.8V |
| | | | | | UNLOCK status | 0V |
| 29 (Y) | Ground | Key slot switch | Input | When Intelligent Key is inserted into key slot | | Battery voltage |
| | | | | When Intelligent Key is not inserted into key slot | | 0V |
| 30 (V/Y) | Ground | ACC feedback signal | Input | Ignition switch | OFF | 0 |
| | | | | | ACC or ON | Battery voltage |
| 31 (G) | Ground | Rear window defog- ger feedback signal | Input | Rear window de- fogger switch | OFF | 0V |
| | | | | | ON | Battery voltage |
| 32 (R/B) | Ground | Front door RH switch | Input | Front door RH switch | OFF (when front door RH closes) |  <small>JPM1A0011GB</small> 11.8 V |
| | | | | | ON (when front door RH opens) | 0V |
| 33 (SB) | Ground | Compressor ON sig- nal | Input | A/C switch | OFF | 9V - 12V |
| | | | | | ON | 0V |
| 34 ³ (L/R) | Ground | Front door lock as- sembly LH (key cylin- der switch) (unlock) | Input | Front door lock assembly LH (key cylinder switch) | OFF (neutral) | Battery voltage |
| | | | | | ON (unlock) | 0V |
| 36 ³ (GR) | Ground | Lock switch signal | Input | Door lock/unlock switch | Lock | Battery voltage |
| | | | | | Unlock | 0V |
| 37 (O) | Ground | Trunk lid opener can- cel switch | Input | Trunk lid opener cancel switch | CANCEL |  <small>JPM1A0012GB</small> 1.1V |
| | | | | | ON | 0V |
| 38 (GR/ W) | Ground | Rear window defog- ger ON signal | Input | Rear window de- fogger switch | OFF | Battery voltage |
| | | | | | ON | 0V |
| 39 ³ (GR/ R) | Ground | Unlock switch signal | Input | Door lock/unlock switch | Unlock | Battery voltage |
| | | | | | Lock | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) | |
|------------------------------|--------|--|------------------|--|---|---|-----------------|
| (+) | (-) | Signal name | Input/ Output | | | | |
| 40 ⁴ (Y/G) | Ground | Power window serial link | Input/ Output | Ignition switch ON |  | | |
| | | | | Ignition switch OFF or ACC | 0V | | |
| 41 (W) | Ground | Engine switch (push switch) illumination | Output | Engine switch (push switch) illumination | ON | 5.5V | |
| | | | | OFF | 0V | | |
| 42 (R) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | ON | 0V | |
| | | | | OFF | Battery voltage | | |
| 45 (P) | Ground | Receiver & sensor ground | Input | Ignition switch ON | | 0V | |
| 46 (V/W) | Ground | Receiver & sensor power supply output | Output | Ignition switch | OFF | 0V | |
| | | | | ACC or ON | | 5.0V | |
| 47 (G/O) | Ground | Tire pressure receiver signal | Input/ Output | Ignition switch ON | Standby state |  | |
| | | | | | When receiving the signal from the transmitter |  | |
| 48 (R/G) | Ground | Selector lever P/N position signal | Input | Selector lever | P or N position | 12.0V | |
| | | | | | Except P and N positions | | 0V |
| 49 (L/O) | Ground | Security indicator signal | Output | Security indicator | ON | 0V | |
| | | | | | Blinking |  | |
| | | | | | OFF | | Battery voltage |






A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--------------------------------|------------------|---|---|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 50 (LG/ B) | Ground | Combination switch OUTPUT 5 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0V |
| | | | | | Lighting switch 1ST |  |
| | | | | | Lighting switch high-beam | |
| | | | | | Lighting switch 2ND | |
| | | | | | Turn signal switch RH | |
| 51 (L/W) | Ground | Combination switch OUTPUT 1 | Input | Combination switch | All switch OFF (Wiper intermittent dial 4) | 0V |
| | | | | | Front wiper switch HI (Wiper intermittent dial 4) |  |
| | | | | | Any of the conditions below with all switch OFF | |
| | | | | | • Wiper intermittent dial 1 | |
| | | | | | • Wiper intermittent dial 2 | |
| • Wiper intermittent dial 3 | | | | | | |
| • Wiper intermittent dial 6 | | | | | | |
| • Wiper intermittent dial 7 | | | | | | |
| 52 (G/B) | Ground | Combination switch OUTPUT 2 | Input | Combination switch | All switch OFF (Wiper intermittent dial 4) | 0V |
| | | | | | Front washer switch ON (Wiper intermittent dial 4) |  |
| | | | | | Any of the conditions below with all switch OFF | |
| • Wiper intermittent dial 1 | | | | | | |
| • Wiper intermittent dial 5 | | | | | | |
| • Wiper intermittent dial 6 | | | | | | |
| 53 (LG/ R) | Ground | Combination switch OUTPUT 3 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0V |
| | | | | | Front wiper switch INT |  |
| | | | | | Front wiper switch LO | |
| | | | | | Lighting switch AUTO | |
| 54 (G/Y) | Ground | Combination switch OUTPUT 4 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0V |
| | | | | | Front fog lamp switch ON |  |
| | | | | | Lighting switch 2ND | |
| | | | | | Lighting switch flash-to- pass | |
| | | | | | Turn signal switch LH | |
| 55 (BR/ W) | Ground | Front blower monitor | Input | Front blower mo- tor switch | ON | Battery voltage |
| | | | | | OFF | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|--|
| | | Signal name | Input/ Output | | | |
| (+) | (-) | | | | | |
| 56 ³ (L/B) | Ground | Front door lock assembly LH (key cylinder switch) (lock) | Input | Front door lock assembly LH (key cylinder switch) | OFF (neutral) | Battery voltage |
| | | | | | ON (lock) | 0V |
| 57 (W) | Ground | Tire pressure warning check switch | Input | — | — | Battery voltage |
| 58 (SB) | Ground | Front door LH switch | Input | Front door LH switch | OFF (front door LH CLOSE) |  <p style="text-align: center;">11.8V</p> |
| | | | | | ON (front door LH OPEN) | 0V |
| 59 (G/R) | Ground | Rear window defogger relay | Output | Rear window defogger | Active | Battery voltage |
| | | | | | Not activated | 0V |
| 60 (B/R) | Ground | Front console antenna 2 (-) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compartment |  |
| | | | | | When Intelligent Key is not in the passenger compartment |  |
| 61 (W/R) | Ground | Center console antenna 2 (+) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compartment |  |
| | | | | | When Intelligent Key is not in the passenger compartment |  |

A
B
C
D
E
F
G
H
I
J
K
L






BCS

N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 62 (B/Y) | Ground | Front outside handle RH antenna (-) | Output | | |
| | | | | When the front door RH request switch is operat- ed with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 63 (LG) | Ground | Front outside handle RH antenna (+) | Output | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the front door RH request switch is operat- ed with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 64 (V) | Ground | Front outside handle LH antenna (-) | Output | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the front door LH request switch is operat- ed with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|---|------------------|--|--|
| (+) | (-) | Signal name | Input/ Output | | |
| 65 (P) | Ground | Front outside handle LH antenna (+) | Output | When the front door LH request switch is operat- ed with ignition switch OFF | When Intelligent Key is in the antenna detection area  |
| | | | | When Intelligent Key is not in the antenna detection area  | |
| 68 (G/O) | Ground | NATS antenna amp (built in key slot) | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelli- gent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move. |
| 69 (O) | Ground | NATS antenna amp (built in key slot) | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelli- gent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move. |
| 70 (R/B) | Ground | Ignition relay-2 con- trol | Output | Ignition switch | OFF or ACC ON |
| | | | | | 0V Battery voltage |
| 71 (L/O) | Ground | Remote keyless entry receiver signal | Input/ Output | During waiting |  |
| | | | | When operating either button on Intelligent Key |  |



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|---|--|
| (+) | (-) | Signal name | Input/ Output | | |
| 75 (R/Y) | Ground | Combination switch INPUT 5 | Output | | |
| | | | | Front fog lamp switch ON (Wiper intermittent dial 4) |  1.3V |
| | | | | Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 |  1.3V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--------------------------------|------------------|--------------------------------|---|---|
| | | Signal name | Input/ Output | | | |
| (+) | (-) | | | | | |
| 76 (R/G) | Ground | Combination switch INPUT 3 | Output | Combination switch | All switch OFF (Wiper intermittent dial 4) |  <small>JPMIA0041GB</small> 1.4V |
| | | | | | Lighting switch high-beam (Wiper intermittent dial 4) |  <small>JPMIA0036GB</small> 1.3V |
| | | | | | Lighting switch 2ND (Wiper intermittent dial 4) |  <small>JPMIA0037GB</small> 1.3V |
| | | | | | Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 |  <small>JPMIA0040GB</small> 1.3V |
| 77 (BR) | Ground | Engine switch (push switch) | Input | Engine switch (push switch) | Pressed | 0V |
| | | | | | Not pressed | Battery voltage |
| 78 (P) | Ground | CAN-L | Input/ Output | — | — | |
| 79 (L) | Ground | CAN-H | Input/ Output | — | — | |
| 80 (R/L) | Ground | Key slot illumination | Output | Key slot illumina- tion | OFF | 0V |
| | | | | | Blinking |  <small>JPMIA0015GB</small> 6.5V |
| | | | | | ON | Battery voltage |



A
B
C
D
E
F
G
H
I
J
K
L

B C S

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[BCM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---------------------------------|---------------------------|--|
| | | Signal name | Input/ Output | | | |
| (+) | (-) | | | | | |
| 81 (LG) | Ground | ON indicator lamp | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0V |
| 83 (L) | Ground | ACC relay-1 control | Output | Ignition switch | OFF | 0V |
| | | | | | ACC or ON | Battery voltage |
| 84 ⁵ (Y/R) | Ground | CVT shift selector | Output | — | | Battery voltage |
| 85 (L/O) | Ground | Electronic steering column lock condition No. 1 | Input | Electronic steering column lock | Lock status | 0V |
| | | | | | Unlock status | Battery voltage |
| 86 (G/R) | Ground | Electronic steering column lock condition No. 2 | Input | Electronic steering column lock | Lock status | Battery voltage |
| | | | | | Unlock status | 0V |
| 87 ⁵ (G/B) | Ground | Selector lever P position switch | Input | Selector lever | P position | 0V |
| | | | | | Any position other than P | Battery voltage |
| 88 (P/L) | Ground | Front door RH request switch | Input | Front door RH request switch | ON (pressed) | 0V |
| | | | | | OFF (not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB 1.0V</p> |
| 89 (B/W) | Ground | Front door LH request switch | Input | Front door LH request switch | ON (pressed) | 0V |
| | | | | | OFF (not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB 1.0V</p> |
| 90 (Y) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0V |
| | | | | | ON | Battery voltage |
| 91 (L/R) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | | Battery voltage |
| 94 (G/Y) | Ground | Electronic steering column lock power supply | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 95 (R/W) | Ground | Combination switch INPUT 1 | Output | All switch OFF |  1.4V |
| | | | | Turn signal switch LH |  1.3V |
| | | | | Turn signal switch RH |  1.3V |
| | | | | Front wiper switch LO |  1.3V |
| | | | | Front washer switch ON |  1.3V |





A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 96 (P/B) | Ground | Combination switch INPUT 4 | Output | Combination switch | All switch OFF (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0041GB</p> <p style="margin: 0;">1.4V</p> </div> |
| | | | | Combination switch | Lighting switch AUTO (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0038GB</p> <p style="margin: 0;">1.3V</p> </div> |
| | | | | Combination switch | Lighting switch 1ST (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0036GB</p> <p style="margin: 0;">1.3V</p> </div> |
| | | | | Combination switch | Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0039GB</p> <p style="margin: 0;">1.3V</p> </div> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|--|-------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 97 (R/B) | Ground | Combination switch INPUT 2 | Output | Combination switch (Wiper intermittent dial 4) | All switch OFF |  1.4V |
| | | | | | Lighting switch flash-to-pass |  1.3V |
| | | | | | Lighting switch 2ND |  1.3V |
| | | | | | Front wiper switch INT |  1.3V |
| | | | | | Front wiper switch HI |  1.3V |
| | | | | | Pressed | 0 V |
| 98 (G/O) | Ground | Hazard switch | Input | Hazard switch | Not pressed |  1.1V |




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|--------------------------------------|--|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 99 (L/Y) | Ground | Electronic steering column lock unit com- munication | Input/ Output | Electronic steer- ing column lock | LOCK status | Battery voltage |
| | | | | | LOCK or UNLOCK |  <p style="text-align: right; font-size: small;">JMKIA0066GB</p> |
| | | | | | For 15 seconds after UN- LOCK | Battery voltage |
| | | | | | 15 seconds or later after UNLOCK | 0V |
| 103 (V) | Ground | Trunk lid opening | Output | Trunk lid | Open (trunk lid opener ac- tuator is activated) | Battery voltage |
| | | | | | Close (trunk lid opener ac- tuator is not activated) | 0V |
| 110 (V/W) | Ground | Trunk room lamp | Output | Trunk room lamp | ON | 0V |
| | | | | | OFF | Battery voltage |
| 114 (B) | Ground | Trunk room antenna 1 (-) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|------------------------------|------------------|--|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 115 (W) | Ground | Trunk room antenna 1 (+) | Output | | |
| | | | | When Intelligent Key is not in the passenger compart- ment  | |
| 118 (L/O) | Ground | Rear bumper anten- na (-) | Output | When the trunk lid request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area  |
| | | | | When Intelligent Key is not in the antenna detection area  | |
| 119 (BR/ W) | Ground | Rear bumper anten- na (+) | Output | When the trunk lid request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area  |
| | | | | When Intelligent Key is not in the antenna detection area  | |




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--------------------------------------|------------------|--|--|---|
| | | Signal name | Input/ Output | | | |
| (+) | (-) | | | | | |
| 127 (BR/ W) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0V |
| 130 (Y/G) | Ground | Trunk room lamp switch | Input | Trunk room lamp switch | OFF (trunk is closed) |  <p style="text-align: right; margin-right: 50px;">11.8V</p> |
| | | | | | ON (trunk is open) | 0V |
| 132 (R) | Ground | Starter motor relay control | Output | Ignition switch OFF (M/T vehi- cle) | When the clutch pedal is depressed | Battery voltage |
| | | | | | When the clutch pedal is not depressed | 0V |
| | | | | Ignition switch ON (other than M/ T vehicle) | When selector lever is in P or N position and the brake is depressed | Battery voltage |
| | | | | | When selector lever is in P or N position and the brake is not depressed | 0V |
| 141 (G/R) | Ground | Trunk request switch | Input | Trunk request switch | ON (pressed) | 0V |
| | | | | | OFF (not pressed) |  <p style="text-align: right; margin-right: 50px;">1.0V</p> |
| 144 (GR) | Ground | Request switch buzz- er | Output | Request switch buzzer | Sounding | 0V |
| | | | | | Not sounding | Battery voltage |
| 147 (L/R) | Ground | Trunk lid opener switch | Input | Trunk lid opener switch | Pressed | 0V |
| | | | | | Not pressed | Battery voltage |
| 148 ¹ (R/W) | Ground | Rear door RH switch | Input | Rear door RH switch | OFF (when rear door RH closes) |  <p style="text-align: right; margin-right: 50px;">11.8V</p> |
| | | | | | ON (when rear door RH opens) | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|---------------------|------------------|---------------------|--|
| (+) | (-) | Signal name | Input/ Output | | |
| 149 ¹ (R/B) | Ground | Rear door LH switch | Input | Rear door LH switch | <div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="margin-bottom: 5px;">OFF (when rear door LH closes)</div>  <div style="margin-top: 5px;">11.8V</div> </div> <div style="margin-top: 5px;">ON (when rear door LH opens)</div> </div> |
| | | | | | 0V |

- 1: Sedan only
- 2: M/T only
- 3: With LH front window anti-pinch
- 4: With LH and RH front window anti-pinch.
- 5: CVT only
- 6: With auto lights
- 7: With low tire pressure warning system
- 8: Coupe only

Fail Safe

INFOID:000000007421652

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|---|
| B2013: ID DISCORD BCM-S/L | Inhibit engine cranking | Erase DTC |
| B2014: CHAIN OF S/L-BCM | Inhibit engine cranking | Erase DTC |
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI-SCANNING | Inhibit engine cranking | Erase DTC |
| B2557: VEHICLE SPEED | Inhibit electronic steering column lock | When normal vehicle speed signals have been received from ABS actuator and electric unit (control unit) for 500 ms |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal |
| B2562: LO VOLTAGE | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit electronic steering column lock | 100 ms after the power supply voltage increases to more than 8.8 V |
| B2601: SHIFT POSITION | Inhibit electronic steering column lock | 500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN) |
| B2602: SHIFT POSITION | Inhibit electronic steering column lock | 5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 /h or more |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|---|
| B2603: SHIFT POSI STATUS | Inhibit electronic steering column lock | 500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V) |
| B2604: PNP SW | Inhibit electronic steering column lock | 500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF |
| B2605: PNP SW | Inhibit electronic steering column lock | 500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position <ul style="list-style-type: none"> - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/transmission switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - transmission switch signal (CAN): ON |
| B2606: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Electronic steering column lock relay signal (Request signal) • Electronic steering column lock relay signal (Condition signal) |
| B2607: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Electronic steering column lock relay signal (Request signal) • Electronic steering column lock relay signal (Condition signal) |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B2609: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit electronic steering column lock | When the following electronic steering column lock conditions agree <ul style="list-style-type: none"> • BCM electronic steering column lock control status • Electronic steering column lock condition No. 1 signal status • Electronic steering column lock condition No. 2 signal status |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B2612: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit electronic steering column lock | When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Electronic steering column lock unit status signal (CAN) is received normally • The BCM electronic steering column lock control status matches the electronic steering column lock status recognized by the electronic steering column lock unit status signal (CAN from IPDM E/R) |
| B2617: STARTER RELAY CIRC | Inhibit engine cranking | 1 second after the starter motor relay control inside BCM becomes normal |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|--|
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B2619: BCM | Inhibit engine cranking | 1 second after the electronic steering column lock unit power supply output control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |
| B26E1: ENG STATE NO RECIV | Inhibit engine cranking | When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B26E8: CLUTCH SW | Inhibit engine cranking | When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): ON - Clutch interlock switch signal: OFF (0 V) • Status 2 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): OFF - Clutch interlock switch signal: OFF (Battery voltage) |
| B26E9: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit electronic steering column lock | When BCM transmits the LOCK request signal to the steering lock unit and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No 1 signal: LOCK (0V) • Steering condition No 2 signal: LOCK (Battery voltage) |

DTC Inspection Priority Chart

INFOID:000000007421653

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> • B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) |
| 3 | <ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING |

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| Priority | DTC |
|----------|---|
| 4 | <ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2611: ACC RELAY • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • B26E8: CLUTCH SW • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG |
| 5 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT |
| 6 | <ul style="list-style-type: none"> • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

DTC Index

INFOID:000000007421654

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|--|-----------|---------------------------------|---------------------------------------|--|
| No DTC is detected. further testing may be required. | — | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | — | BCS-32 |
| U1010: CONTROL UNIT (CAN) | — | — | — | BCS-33 |
| U0415: VEHICLE SPEED SIG | — | — | — | BCS-34 |
| B2013: ID DISCORD BCM-S/L | × | — | — | SEC-36 (Coupe), SEC-250 (Sedan) |
| B2014: CHAIN OF S/L-BCM | × | — | — | SEC-37 (Coupe), SEC-251 (Sedan) |
| B2190: NATS ANTENNA AMP | × | — | — | SEC-65 (Coupe), SEC-281 (Sedan) |
| B2191: DIFFERENCE OF KEY | × | — | — | SEC-69 (Coupe), SEC-285 (Sedan) |
| B2192: ID DISCORD BCM-ECM | × | — | — | SEC-70 (Coupe), SEC-286 (Sedan) |
| B2193: CHAIN OF BCM-ECM | × | — | — | SEC-71 (Coupe), SEC-287 (Sedan) |
| B2195: ANTI-SCANNING | — | — | — | SEC-72 |
| B2553: IGNITION RELAY | — | — | — | PCS-59 |
| B2555: STOP LAMP | — | — | — | SEC-73 (Coupe), SEC-289 (Sedan) |
| B2556: PUSH-BTN IGN SW | — | × | — | SEC-78 (Coupe), SEC-294 (Sedan) |
| B2557: VEHICLE SPEED | × | × | — | SEC-80 (Coupe), SEC-296 (Sedan) |
| B2560: STARTER CONT RELAY | × | × | — | SEC-81 (Coupe), SEC-297 (Sedan) |
| B2562: LOW VOLTAGE | — | — | — | BCS-35 |
| B2601: SHIFT POSITION | × | × | — | SEC-82 (Coupe), SEC-298 (Sedan) |
| B2602: SHIFT POSITION | × | × | — | SEC-86 (Coupe), SEC-302 (Sedan) |
| B2603: SHIFT POSI STATUS | × | × | — | SEC-89 (Coupe), SEC-305 (Sedan) |
| B2604: PNP SW | × | × | — | SEC-92 (Coupe), SEC-308 (Sedan) |
| B2605: PNP SW | × | × | — | SEC-94 (Coupe), SEC-310 (Sedan) |
| B2606: S/L RELAY | × | × | — | SEC-96 (Coupe), SEC-312 (Sedan) |

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|---------------------------|-----------|---------------------------------|---------------------------------------|---|
| B2607: S/L RELAY | × | × | — | SEC-97 (Coupe), SEC-313 (Sedan) |
| B2608: STARTER RELAY | × | × | — | SEC-99 (Coupe), SEC-315 (Sedan) |
| B2609: S/L STATUS | × | × | — | SEC-101 (Coupe), SEC-317 (Sedan) |
| B260A: IGNITION RELAY | × | × | — | PCS-61 |
| B260B: STEERING LOCK UNIT | — | × | — | SEC-106 (Coupe), SEC-322 (Sedan) |
| B260C: STEERING LOCK UNIT | — | × | — | SEC-107 (Coupe), SEC-323 (Sedan) |
| B260D: STEERING LOCK UNIT | — | × | — | SEC-108 (Coupe), SEC-324 (Sedan) |
| B260F: ENG STATE SIG LOST | × | × | — | SEC-109 (Coupe), SEC-325 (Sedan) |
| B2611: ACC RELAY | — | — | — | PCS-62 |
| B2612: S/L STATUS | × | × | — | SEC-110 (Coupe), SEC-331 (Sedan) |
| B2614: ACC RELAY CIRC | — | × | — | PCS-64 |
| B2615: BLOWER RELAY CIRC | — | × | — | PCS-67 |
| B2616: IGN RELAY CIRC | — | × | — | PCS-70 |
| B2617: STARTER RELAY CIRC | × | × | — | SEC-115 (Coupe), SEC-336 (Sedan) |
| B2618: BCM | × | × | — | PCS-73 |
| B2619: BCM | × | × | — | SEC-117 (Coupe), SEC-338 (Sedan) |
| B261A: PUSH-BTN IGN SW | — | × | — | SEC-118 (Coupe), SEC-339 (Sedan) |
| B261E: VEHICLE TYPE | × | × (Turn ON for 15 seconds) | — | SEC-121 |
| B2622: INSIDE ANTENNA | — | — | — | DLK-282 |
| B2623: INSIDE ANTENNA | — | — | — | DLK-285 |
| B26E1: ENG STATE NO RES | × | × | — | SEC-326 |
| B26E8: CLUTCH SW | × | × | — | SEC-123 |
| B26E9: S/L STATUS | × | × (Turn ON for 15 seconds) | — | SEC-125 |
| B26EA: KEY REGISTRATION | × | × (Turn ON for 15 seconds) | — | SEC-126 |
| C1704: LOW PRESSURE FL | — | — | × | WT-8 |
| C1705: LOW PRESSURE FR | — | — | × | WT-8 |
| C1706: LOW PRESSURE RR | — | — | × | WT-8 |
| C1707: LOW PRESSURE RL | — | — | × | WT-8 |
| C1708: [NO DATA] FL | — | — | × | WT-13 |
| C1709: [NO DATA] FR | — | — | × | WT-13 |
| C1710: [NO DATA] RR | — | — | × | WT-13 |
| C1711: [NO DATA] RL | — | — | × | WT-13 |
| C1712: [CHECKSUM ERR] FL | — | — | × | WT-15 |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page | |
|---------------------------|-----------|------------------------------------|---|-----------------------|---|
| C1713: [CHECKSUM ERR] FR | — | — | × | WT-15 | A |
| C1714: [CHECKSUM ERR] RR | — | — | × | WT-15 | B |
| C1715: [CHECKSUM ERR] RL | — | — | × | WT-15 | |
| C1716: [PRESSDATA ERR] FL | — | — | × | WT-17 | C |
| C1717: [PRESSDATA ERR] FR | — | — | × | WT-17 | |
| C1718: [PRESSDATA ERR] RR | — | — | × | WT-17 | |
| C1719: [PRESSDATA ERR] RL | — | — | × | WT-17 | D |
| C1720: [CODE ERR] FL | — | — | × | WT-15 | |
| C1721: [CODE ERR] FR | — | — | × | WT-15 | E |
| C1722: [CODE ERR] RR | — | — | × | WT-15 | |
| C1723: [CODE ERR] RL | — | — | × | WT-15 | |
| C1724: [BATT VOLT LOW] FL | — | — | × | WT-15 | F |
| C1725: [BATT VOLT LOW] FR | — | — | × | WT-15 | |
| C1726: [BATT VOLT LOW] RR | — | — | × | WT-15 | |
| C1727: [BATT VOLT LOW] RL | — | — | × | WT-15 | G |
| C1729: VHCL SPEED SIG ERR | — | — | × | WT-18 | |
| C1734: CONTROL UNIT | — | — | × | WT-19 | H |


BCS

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >

AL : WITH AUTO LIGHT SYSTEM



AAMWA0315GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]




AAMWA0316GB

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


BCS

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >

PS : WITH POWER SEATS
 SU : WITH SUNROOF




*:THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

AAMWA0318GB

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]



ABMWA0715GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]

BCM (BODY CONTROL MODULE) CONNECTORS

| | |
|-----------------|---------------------------|
| Connector No. | M16 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------|
| 1 | W/B | BAT_POWER_F/L |
| 2 | R/Y | P/W_POWER_SUPPLY_PERM |
| 3 | L/W | POWER_WINDOW_POWER_SUPPLY (RAP) |

| | |
|-----------------|---------------------------|
| Connector No. | M17 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 4 | P/W | ROOM_LAMP_BAT_SAVER |
| 5 | G/Y | CDL_AS |
| 6 | - | - |
| 7 | R/W | STEP_LAMP_OUTPUT |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------|
| 8 | V | CDL_COMMON |
| 9 | G | CDL_DR/FL |
| 10 | - | - |
| 11 | Y/R | BAT_BCM_FUSE |
| 12 | - | - |
| 13 | B | GND1 |
| 14 | R/Y | LOW_SIDE_PUSH_LED_OUTPUT |
| 15 | Y/L | ACC_LED |
| 16 | - | - |
| 17 | G/B | FR_FLASHER |
| 18 | G/Y | FL_FLASHER |
| 19 | Y | ROOM_LAMP_OUTPUT |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------|
| 20 | - | - |
| 21 | P/B | AUTO_LIGHT_SENSOR_INPUT1 |
| 22 | R/Y | CLUTCH_SW |
| 23 | - | - |
| 24 | R/W | STOP_LAMP_LOW_SW |
| 25 | - | - |
| 26 | O/L | STOP_LAMP_HIGH_SW |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------|
| 27 | G/W | DOOR_LOCK_STATUS |
| 28 | - | - |
| 29 | Y | FOB_IN_SW_1 |
| 30 | V/Y | ACC_F/B |
| 31 | G | IGN_F/B |
| 32 | R/B | AS_DOOR_SW |
| 33 | SB | AIRCON_SW |
| 34 | - | - |
| 35 | - | - |
| 36 | - | - |
| 37 | O | TRUNK_CANCEL_SW |
| 38 | GR/W | REAR_DEFOGGER_SW |
| 39 | - | - |
| 40 | Y/G | PW_K-LINE |
| 41 | W | PUSH_LED |
| 42 | R | S/L_LOCK_LED |
| 43 | - | - |
| 44 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 45 | P | GND_RF2_A/L |
| 46 | V/W | A/L_SENS_KEYLESS_TUNER_POWER_SUPPLY |
| 47 | G/O | KEYLESS_TUNER_SI |
| 48 | R/G | SHIFT_N/P |
| 49 | L/O | IMMO_LED |
| 50 | LG/B | INPUT_5 |
| 51 | L/W | INPUT_1 |
| 52 | G/B | INPUT_2 |
| 53 | LG/R | INPUT_3 |
| 54 | G/Y | INPUT_4 |
| 55 | BR/W | BLOWER_FAN_SW |
| 56 | - | - |
| 57 | W | TPMS_MODE_TRIGGER_SW |
| 58 | SB | DR_DOOR_SW |
| 59 | G/R | REAR_DEFOGGER_RLY |

AAMIA01596B

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 79 | 78 | 77 | 76 | 75 | 74 | 73 | 72 | 71 | 70 | 69 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 | 60 |
| 99 | 98 | 97 | 96 | 95 | 94 | 93 | 92 | 91 | 90 | 89 | 88 | 87 | 86 | 85 | 84 | 83 | 82 | 81 | 80 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 60 | B/R | ROOM_ANT_2_B |
| 61 | W/R | ROOM_ANT_2_A |
| 62 | B/Y | AS_DOOR_ANT_B |
| 63 | LG | AS_DOOR_ANT_A |
| 64 | V | DR_DOOR_ANT_B |
| 65 | P | DR_DOOR_ANT_A |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------|
| 66 | - | - |
| 67 | - | - |
| 68 | G/O | FOB_READER_CLOCK |
| 69 | O | FOB_READER_DATA |
| 70 | R/B | IGN_ELEC_CONT |
| 71 | L/O | RF1_TUNER_SIGNAL |
| 72 | - | - |
| 73 | - | - |
| 74 | - | - |
| 75 | R/Y | OUTPUT_5 |
| 76 | R/G | OUTPUT_3 |
| 77 | BR | ENG_START_SW |
| 78 | P | CAN-L |
| 79 | L | CAN-H |
| 80 | R/L | FOB_SLOT_ILLUMINATION |
| 81 | LG | IGN_ON_LED |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 82 | - | - |
| 83 | L | ACC_CONT |
| 84 | Y/R | AT_DEVICE_OUT |
| 85 | L/O | S/L_CONDITION_1 |
| 86 | G/R | S/L_CONDITION_2 |
| 87 | G/B | SHIFT_P |
| 88 | P/L | AS_REQUEST_SWITCH |
| 89 | B/W | DR_REQUEST_SWITCH |
| 90 | Y | IGN2_CONT |
| 91 | L/R | RF1_POWER_SUPPLY |
| 92 | - | - |
| 93 | - | - |
| 94 | G/Y | S/L_POWER_SUPPLY_12V |
| 95 | R/W | OUTPUT_1 |
| 96 | P/B | OUTPUT_4 |
| 97 | R/B | OUTPUT_2 |
| 98 | G/O | HAZARD_SW |
| 99 | L/Y | S/L_K-LINE |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|
| 100 | 101 | 102 | 103 | 104 | | |
| 105 | 106 | 107 | 108 | 109 | 110 | 111 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 100 | - | - |
| 101 | - | - |
| 102 | - | - |
| 103 | V | CDL_BACK_TRUNK |
| 104 | - | - |
| 105 | - | - |
| 106 | - | - |
| 107 | - | - |
| 108 | - | - |
| 109 | - | - |
| 110 | V/W | TRUNK_LAMP_OUTPUT |
| 111 | - | - |

ABMIA1890GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P




BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >


| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | WASH MTR |
| 2 | G/Y | OUTPUT_4 |
| 5 | LG/R | OUTPUT_3 |
| 6 | B | GND |
| 7 | R/G | INPUT_3 |
| 8 | LG/B | OUTPUT_5 |
| 9 | R/B | INPUT_2 |
| 10 | P/B | INPUT_4 |
| 11 | R/W | INPUT_1 |
| 12 | L/W | OUTPUT_1 |
| 13 | R/Y | INPUT_5 |
| 14 | G/B | OUTPUT_2 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 119 | BR/W | BACK_DOOR_ANT_A |
| 120 | - | - |
| 121 | - | - |
| 122 | - | - |
| 123 | - | - |
| 124 | - | - |
| 125 | - | - |
| 126 | - | - |
| 127 | BR/W | IGN_USM_CONT1 |
| 128 | - | - |
| 129 | - | - |
| 130 | Y/G | TRUNK_SW |
| 131 | - | - |
| 132 | R | ST_CONT_USM |
| 133 | - | - |
| 134 | - | - |
| 135 | - | - |
| 136 | - | - |
| 137 | - | - |
| 138 | - | - |
| 139 | - | - |
| 140 | - | - |
| 141 | G/R | TRUNK_REQUEST_SW |
| 142 | - | - |
| 143 | - | - |
| 144 | GR | BUZZER |
| 145 | - | - |
| 146 | - | - |
| 147 | L/R | BACK_TRUNK_OPENER |
| 148 | - | - |
| 149 | - | - |
| 150 | - | - |
| 151 | - | - |

| | |
|-----------------|---------------------------|
| Connector No. | M21 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 112 | - | - |
| 113 | - | - |
| 114 | B | TRUNK_ANT_1_B |
| 115 | W | TRUNK_ANT_1_A |
| 116 | - | - |
| 117 | - | - |
| 118 | L/O | BACK_DOOR_ANT_B |


ABM1A1891GB

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >

◁AL▷ : WITH AUTO LIGHT SYSTEM
 ◁WL▷ : WITH LOW TIRE PRESSURE WARNING SYSTEM




AAMWA0320GB

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]



AAMWA0321GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >




ABMWA1321GB

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >

- <A1> : WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM
- <A2> : WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM
- <PS> : WITH POWER SEATS
- <SU> : WITH SUNROOF



* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

AAMWA0323GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >



ABMWA0721GB


BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >


BCM (BODY CONTROL MODULE) CONNECTORS

| | |
|-----------------|---------------------------|
| Connector No. | M16 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------|
| 1 | W/B | BAT_POWER_F/L |
| 2 | R/Y | P/W POWER SUPPLY_PERM |
| 3 | L/W | POWER_WINDOW_POWER_SUPPLY (RAP) |


| | |
|-----------------|---------------------------|
| Connector No. | M17 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 4 | P/W | ROOM_LAMP_BAT_SAVER |
| 5 | G/Y | CDL_AS |
| 6 | - | - |
| 7 | R/W | STEP_LAMP_OUTPUT |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------|
| 8 | V | CDL_COMMON |
| 9 | G | CDL_DR/FL |
| 10 | G/Y | CDL_RR_RL_BACK |
| 11 | Y/R | BAT_BCM_FUSE |
| 12 | - | - |
| 13 | B | GND1 |
| 14 | O/W | LOW_SIDE_PUSH_LED_OUTPUT |
| 15 | Y/L | ACC_LED |
| 16 | - | - |
| 17 | G/B | FR_FLASHER |
| 18 | G/Y | FL_FLASHER |
| 19 | Y | ROOM_LAMP_OUTPUT |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------|
| 20 | - | - |
| 21 | P/B | AUTO LIGHT SENSOR_INPUT1 |
| 22 | R/Y | CLUTCH_SW |
| 23 | - | - |
| 24 | R/W | STOP_LAMP_LOW_SW |
| 25 | - | - |
| 26 | O/L | STOP_LAMP_HIGH_SW |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 27 | G/W | DOOR_LOCK_STATUS |
| 28 | - | - |
| 29 | Y | FOB_IN_SW_1 |
| 30 | V/Y | ACC_F/B |
| 31 | G | IGN_F/B |
| 32 | R/B | AS_DOOR_SW |
| 33 | SB | AIRCON_SW |
| 34 | L/R | DOOR_KEY/C_UNLOCK_SW |
| 35 | - | - |
| 36 | GR | CENTRAL_LOCK_SW |
| 37 | O | TRUNK_CANCEL_SW |
| 38 | GR/W | REAR_DEFOGGER_SW |
| 39 | GR/R | CENTRAL_UNLOCK_SW |
| 40 | Y/G | PW_K-LINE |
| 41 | W | PUSH_LED |
| 42 | R | S/L_LOCK_LED |
| 43 | - | - |
| 44 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 45 | P | GND_RF2_A/L |
| 46 | V/W | A/L_SENS_KEYLESS_TUNER_POWER_SUPPLY |
| 47 | G/O | KEYLESS_TUNER_SI |
| 48 | R/G | SHIFT_N/P |
| 49 | L/O | IMMO_LED |
| 50 | LG/B | INPUT_5 |
| 51 | L/W | INPUT_1 |
| 52 | G/B | INPUT_2 |
| 53 | LG/R | INPUT_3 |
| 54 | G/Y | INPUT_4 |
| 55 | BR/W | BLOWER_FAN_SW |
| 56 | L/B | DOOR_KEY/C_LOCK_SW |
| 57 | W | TPMS_MODE_TRIGGER_SW |
| 58 | SB | DR_DOOR_SW |
| 59 | G/R | REAR_DEFOGGER_RLY |

AAMIA0606GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 79 | 78 | 77 | 76 | 75 | 74 | 73 | 72 | 71 | 70 | 69 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 | 60 |
| 99 | 98 | 97 | 96 | 95 | 94 | 93 | 92 | 91 | 90 | 89 | 88 | 87 | 86 | 85 | 84 | 83 | 82 | 81 | 80 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 60 | B/R | ROOM_ANT_2_B |
| 61 | W/R | ROOM_ANT_2_A |
| 62 | B/Y | AS_DOOR_ANT_B |
| 63 | LG | AS_DOOR_ANT_A |
| 64 | V | DR_DOOR_ANT_B |
| 65 | P | DR_DOOR_ANT_A |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------|
| 66 | - | - |
| 67 | - | - |
| 68 | G/O | FOB_READER_CLOCK |
| 69 | O | FOB_READER_DATA |
| 70 | R/B | IGN_ELEC_CONT |
| 71 | L/O | RF1_TUNER_SIGNAL |
| 72 | - | - |
| 73 | - | - |
| 74 | - | - |
| 75 | R/Y | OUTPUT_5 |
| 76 | R/G | OUTPUT_3 |
| 77 | BR | ENG_START_SW |
| 78 | P | CAN-L |
| 79 | L | CAN-H |
| 80 | R/L | FOB_SLOT_ILLUMINATION |
| 81 | LG | IGN_ON_LED |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 82 | - | - |
| 83 | L | ACC_CONT |
| 84 | Y/R | AT_DEVICE_OUT |
| 85 | L/O | S/L_CONDITION_1 |
| 86 | G/R | S/L_CONDITION_2 |
| 87 | G/B | SHIFT_P |
| 88 | P/L | AS_REQUEST_SWITCH |
| 89 | B/W | DR_REQUEST_SWITCH |
| 90 | Y | IGN2_CONT |
| 91 | L/R | RF1_POWER_SUPPLY |
| 92 | - | - |
| 93 | - | - |
| 94 | G/Y | S/L_POWER_SUPPLY_12V |
| 95 | R/W | OUTPUT_1 |
| 96 | P/B | OUTPUT_4 |
| 97 | R/B | OUTPUT_2 |
| 98 | G/O | HAZARD_SW |
| 99 | L/Y | S/L_K-LINE |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|
| 100 | 101 | 102 | 103 | 104 | | |
| 105 | 106 | 107 | 108 | 109 | 110 | 111 |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 100 | - | - |
| 101 | - | - |
| 102 | - | - |
| 103 | V | CDL_BACK_TRUNK |
| 104 | - | - |
| 105 | - | - |
| 106 | - | - |
| 107 | - | - |
| 108 | - | - |
| 109 | - | - |
| 110 | V/W | TRUNK_LAMP_OUTPUT |
| 111 | - | - |

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >


| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | WASH MTR |
| 2 | G/Y | OUTPUT_4 |
| 5 | LG/R | OUTPUT_3 |
| 6 | B | GND |
| 7 | R/G | INPUT_3 |
| 8 | LG/B | OUTPUT_5 |
| 9 | R/B | INPUT_2 |
| 10 | P/B | INPUT_4 |
| 11 | R/W | INPUT_1 |
| 12 | L/W | OUTPUT_1 |
| 13 | R/Y | INPUT_5 |
| 14 | G/B | OUTPUT_2 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 119 | BR/W | BACK_DOOR_ANT_A |
| 120 | - | - |
| 121 | - | - |
| 122 | - | - |
| 123 | - | - |
| 124 | - | - |
| 125 | - | - |
| 126 | - | - |
| 127 | BR/W | IGN_USM_CONT1 |
| 128 | - | - |
| 129 | - | - |
| 130 | Y/G | TRUNK_SW |
| 131 | - | - |
| 132 | R | ST_CONT_USM |
| 133 | - | - |
| 134 | - | - |
| 135 | - | - |
| 136 | - | - |
| 137 | - | - |
| 138 | - | - |
| 139 | - | - |
| 140 | - | - |
| 141 | G/R | TRUNK_REQUEST_SW |
| 142 | - | - |
| 143 | - | - |
| 144 | GR | BUZZER |
| 145 | - | - |
| 146 | - | - |
| 147 | L/R | BACK_TRUNK_OPENER |
| 148 | R/W | RR_DOOR_SW |
| 149 | R/B | RL_DOOR_SW |
| 150 | - | - |
| 151 | - | - |

| | |
|-----------------|---------------------------|
| Connector No. | M21 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 112 | - | - |
| 113 | - | - |
| 114 | B | TRUNK_ANT_1_B |
| 115 | W | TRUNK_ANT_1_A |
| 116 | - | - |
| 117 | - | - |
| 118 | L/O | BACK_DOOR_ANT_B |

ABMIA1894GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BCM]

SYMPTOM DIAGNOSIS

COMBINATION SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:000000007421657

1. Perform the data monitor of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunction item: ×

| Malfunction combination | Data monitor item | | | | | | | | | | | | | |
|-------------------------|---|--------------|--------------|--------------|------------|---------------|---------------|--------------|------------|----------------|----------------|------------|---------------|-----------|
| | FR WIPER HI | FR WIPER LOW | FR WASHER SW | FR WIPER INT | INT VOLUME | TURN SIGNAL R | TURN SIGNAL L | TAIL LAMP SW | HI BEAM SW | HEAD LAMP SW 1 | HEAD LAMP SW 2 | PASSING SW | AUTO LIGHT SW | FR FOG SW |
| A | | × | × | | | × | × | | | | | | | |
| B | × | | | × | | | | | | × | | × | | |
| C | | | | | × | | | | × | | × | | | |
| D | | | | | × | | | × | | | | | × | |
| E | | | | | × | | | | | | | | | × |
| F | × | | | | × | | | | | | | | | |
| G | | | × | | × | | | | | | | | | |
| H | | × | | × | | | | | | | | | × | |
| I | | | | | | | × | | | | × | × | | × |
| J | | | | | | × | | × | × | × | | | | |
| K | All Items | | | | | | | | | | | | | |
| L | If only one item is detected or the item is not applicable to the combinations A to K | | | | | | | | | | | | | |

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

| Malfunction combination | Malfunctioning part | Repair or replace |
|-------------------------|-------------------------------------|--|
| A | Combination switch INPUT 1 circuit | Inspect the combination switch input circuit applicable to the malfunctioning part. BCS-37. "Diagnosis Procedure" |
| B | Combination switch INPUT 2 circuit | |
| C | Combination switch INPUT 3 circuit | |
| D | Combination switch INPUT 4 circuit | |
| E | Combination switch INPUT 5 circuit | |
| F | Combination switch OUTPUT 1 circuit | Inspect the combination switch output circuit applicable to the malfunctioning part. BCS-39. "Diagnosis Procedure" |
| G | Combination switch OUTPUT 2 circuit | |
| H | Combination switch OUTPUT 3 circuit | |
| I | Combination switch OUTPUT 4 circuit | |
| J | Combination switch OUTPUT 5 circuit | |
| K | BCM | Replace BCM. Refer to BCS-92. "Removal and Installation" . |
| L | Combination switch | Replace the combination switch. Refer to EXL-219. "Removal and Installation" . |

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007421658

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000007421659

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Carry the Intelligent Key or insert it to the key slot and turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

PRECAUTIONS

< PRECAUTION >

[BCM]

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT.

PREPARATION

< PREPARATION >



[BCM]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007421660

| Tool name | Description |
|--|---|
| <p data-bbox="159 411 280 438">Power tools</p>  <p data-bbox="776 632 849 646">PIIB1407E</p> | <p data-bbox="1008 411 1344 438">Loosening nuts, screws and bolts</p> |
| <p data-bbox="159 661 415 716">One-way Screw Removal Tool</p>  <p data-bbox="776 884 865 898">ALMIA0486ZZ</p> | <p data-bbox="1008 661 1279 688">Removing one-way screws</p> |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation


INFOID:000000007421661

REMOVAL

CAUTION:

Before replacing BCM, perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-3, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Description"](#).

1. Disconnect the negative battery terminal. Refer to [PG-68, "Removal and Installation \(Battery\)"](#) (coupe) and [PG-140, "Removal and Installation \(Battery\)"](#) (sedan).
2. Remove the combination meter. Refer to [MWI-139, "Removal and Installation"](#).
3. Remove the BCM screws (A) using a suitable tool, and pull out the BCM (1).
4. Disconnect the BCM connector and remove the BCM (1).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When replacing BCM, perform "WRITE CONFIGURATION". Refer to [BCS-3, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Description"](#).
- When replacing BCM, perform the system initialization (NATS). Refer to the CONSULT immobilizer mode and follow the on-screen instructions.
- When replacing BCM, if new BCM does not come with keyfobs attached, all existing keyfobs must be re-registered. Refer to the CONSULT immobilizer mode and follow the on-screen instructions for the initialization procedure.