

SECTION **CCS**
CRUISE CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

CONTENTS

PRECAUTION	2	AUTOMATIC SPEED CONTROL DEVICE	
PRECAUTIONS	2	(ASCD)	3
Precaution for Supplemental Restraint System		Information	3
(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	REMOVAL AND INSTALLATION	4
SYSTEM DESCRIPTION	3	SWITCH	4
		Removal and Installation	4



PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008721896

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Information

INFOID:000000008688970

The Automatic Speed Control Device (ASCD) system is controlled by the ECM.

For information regarding the ASCD system, refer to [EC-63. "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\) : System Description"](#) (QR25DE) or [EC-573. "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\) : System Description"](#) (VQ35DE).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



SWITCH

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

SWITCH

Removal and Installation

INFOID:000000008688906

For removal and installation of the steering switch, refer to [AV-49, "Removal and Installation"](#).