

A  
B  
C

# SECTION **WW**

## WIPER & WASHER

### CONTENTS

|   |  |
|---|--|
| <p><b>PRECAUTION</b> ..... 3</p> <p><b>PRECAUTIONS</b> ..... 3</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....3</p> <p style="padding-left: 20px;">Precaution for Procedure without Cowl Top Cover.....3</p> <p><b>SYSTEM DESCRIPTION</b> ..... 4</p> <p><b>FRONT WIPER AND WASHER SYSTEM</b> ..... 4</p> <p style="padding-left: 20px;">Component Parts Location .....4</p> <p style="padding-left: 20px;">Component Description .....5</p> <p><b>SYSTEM</b> ..... 6</p> <p style="padding-left: 20px;">System Diagram .....6</p> <p style="padding-left: 20px;">System Description .....6</p> <p style="padding-left: 20px;">Fail-Safe .....9</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> .....10</p> <p><b>COMMON ITEM</b> ..... 10</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) ..... 10</p> <p><b>WIPER</b> .....10</p> <p style="padding-left: 20px;">WIPER : CONSULT Function (BCM - WIPER) ..... 11</p> <p><b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....12</p> <p style="padding-left: 20px;">Diagnosis Description ..... 12</p> <p style="padding-left: 20px;">CONSULT Function (IPDM E/R) ..... 13</p> <p><b>ECU DIAGNOSIS INFORMATION</b> .....16</p> <p><b>BCM, IPDM E/R</b> .....16</p> <p style="padding-left: 20px;">List of ECU Reference ..... 16</p> <p><b>WIRING DIAGRAM</b> .....17</p> <p><b>FRONT WIPER AND WASHER SYSTEM</b> .....17</p> <p style="padding-left: 20px;">Wiring Diagram - Without Rear View Camera</p> <p style="padding-left: 20px;">Washer Control System ..... 17</p> | <p style="padding-left: 20px;">Wiring Diagram - With Rear View Camera Washer Control System .....23</p> <p><b>BASIC INSPECTION</b> .....31</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....31</p> <p style="padding-left: 20px;">Work Flow .....31</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> .....33</p> <p><b>WIPER AND WASHER FUSE</b> .....33</p> <p style="padding-left: 20px;">Description .....33</p> <p style="padding-left: 20px;">Diagnosis Procedure .....33</p> <p><b>FRONT WIPER MOTOR LO CIRCUIT</b> .....34</p> <p style="padding-left: 20px;">Component Function Check .....34</p> <p style="padding-left: 20px;">Diagnosis Procedure .....34</p> <p><b>FRONT WIPER MOTOR HI CIRCUIT</b> .....36</p> <p style="padding-left: 20px;">Component Function Check .....36</p> <p style="padding-left: 20px;">Diagnosis Procedure .....36</p> <p><b>FRONT WIPER AUTO STOP SIGNAL CIRCUIT</b> .....38</p> <p style="padding-left: 20px;">Component Function Check .....38</p> <p style="padding-left: 20px;">Diagnosis Procedure .....38</p> <p><b>FRONT WIPER MOTOR GROUND CIRCUIT</b> ...39</p> <p style="padding-left: 20px;">Diagnosis Procedure .....39</p> <p><b>WASHER MOTOR CIRCUIT</b> .....40</p> <p style="padding-left: 20px;">Diagnosis Procedure .....40</p> <p><b>WASHER SWITCH</b> .....44</p> <p style="padding-left: 20px;">Description .....44</p> <p style="padding-left: 20px;">Component Inspection .....44</p> <p><b>SYMPTOM DIAGNOSIS</b> .....45</p> <p><b>WIPER AND WASHER SYSTEM SYMPTOMS</b> .....45</p> <p style="padding-left: 20px;">Symptom Table .....45</p> |
|---|--|

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

|  |           |   |           |
|--|-----------|---|-----------|
| <b>FRONT WIPER DOES NOT OPERATE</b> .....      | <b>48</b> | WASHER TUBE : Removal and Installation .....  | 56        |
| Description .....                              | 48        | <b>FRONT WIPER ARM</b> .....                  | <b>58</b> |
| Diagnosis Procedure .....                      | 48        | Removal and Installation .....                | 58        |
| <b>NORMAL OPERATING CONDITION</b> .....        | <b>50</b> | <b>WIPER BLADE</b> .....                      | <b>59</b> |
| Description .....                              | 50        | <b>WIPER BLADE</b> .....                      | <b>59</b> |
| <b>REMOVAL AND INSTALLATION</b> .....          | <b>51</b> | WIPER BLADE : Removal and Installation .....  | 59        |
| <b>WASHER TANK</b> .....                       | <b>51</b> | WIPER BLADE : Adjustment .....                | 60        |
| Exploded View .....                            | 51        | <b>WIPER BLADE REFILL</b> .....               | <b>60</b> |
| Removal and Installation .....                 | 51        | WIPER BLADE REFILL : Removal and Installation | ... 60    |
| <b>WASHER PUMP</b> .....                       | <b>52</b> | <b>FRONT WIPER DRIVE ASSEMBLY</b> .....       | <b>64</b> |
| Exploded View .....                            | 52        | Exploded View .....                           | 64        |
| Removal and Installation .....                 | 52        | Removal and Installation .....                | 64        |
| <b>WASHER LEVEL SWITCH</b> .....               | <b>53</b> | <b>WIPER AND WASHER SWITCH</b> .....          | <b>65</b> |
| Exploded View .....                            | 53        | Removal and Installation .....                | 65        |
| Removal and Installation .....                 | 53        | <b>SERVICE DATA AND SPECIFICATIONS</b>        |           |
| <b>WASHER NOZZLE &amp; TUBE</b> .....          | <b>54</b> | <b>(SDS)</b> .....                            | <b>66</b> |
| Exploded View .....                            | 54        | <b>SERVICE DATA AND SPECIFICATIONS</b>        |           |
| <b>WASHER NOZZLE</b> .....                     | <b>54</b> | <b>(SDS)</b> .....                            | <b>66</b> |
| WASHER NOZZLE : Removal and Installation ..... | 54        | Specifications .....                          | 66        |
| WASHER NOZZLE : Adjustment .....               | 55        |   |           |
| <b>WASHER TUBE</b> .....                       | <b>56</b> |   |           |

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008721367

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000007987003

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### FRONT WIPER AND WASHER SYSTEM

#### Component Parts Location

INFOID:000000007986969

#### FRONT WIPER AND WASHER SYSTEM



AWLIA19852Z

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

- |   |  |   |
|---|--|---|
| 1. Combination meter  | 2. BCM (view with combination meter removed)       | 3. IPDM E/R                                       |
| 4. Combination switch (wiper and washer switch)                             | 5. Front wiper motor (with the wiper cowl removed) | 6. Front washer motor (with front bumper removed) |
| 7. Rear view camera washer control unit* (with rear trunk finisher removed) |  |   |

\*: For models with rear camera washer system

## Component Description

INFOID:000000007986970

| Part   | Description  |
|--|--|
| Combination meter  | Transmits the vehicle speed signal to BCM with CAN communication.  |
| BCM  | <ul style="list-style-type: none"> <li>Judges the switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>                                       |
| IPDM E/R   | <ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> <li>Supplies power to the rear view camera washer control unit.</li> </ul> |
| Combination switch (Wiper and washer switch)                             | <ul style="list-style-type: none"> <li>Provides input for wiper and washer control to the BCM.</li> <li>Refer to <a href="#">WW-6, "System Description"</a>.</li> <li>Supplies signal to the rear view camera washer control unit.</li> </ul>                                |
| Front washer motor   | Washer fluid is sprayed according to combination switch signal.  |
| Front wiper motor  | <ul style="list-style-type: none"> <li>IPDM E/R controls front wiper operation.</li> <li>Front wiper stop position is transmitted to IPDM E/R.</li> </ul>  |
| Rear view camera washer control unit (with rear view camera wash system) | <ul style="list-style-type: none"> <li>Judges the signal status from the combination switch for washer operation.</li> <li>Supplies signal to the front washer motor.</li> </ul>   |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM


### System Diagram

INFOID:000000007986967

#### SYSTEM WITH REAR VIEW CAMERA WASH



#### SYSTEM WITHOUT REAR VIEW CAMERA WASH



### System Description

INFOID:000000007986968

#### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

##### Control by BCM

- Combination switch reading function
- Front wiper control function

##### Control by IPDM E/R

- Front wiper control function
- Relay control function

#### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

#### FRONT WIPER LO OPERATION

# SYSTEM

## < SYSTEM DESCRIPTION >

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition


- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

### FRONT WIPER INT OPERATION

- BCM transmits the front wiper request signal (INT) to IPDM E/R with CAN communication depending on the front wiper INT operating condition and intermittent operation delay interval according to the wiper intermittent dial position.

Front wiper INT operating condition

- Ignition switch ON
- Front wiper switch INT
- IPDM E/R turns ON the integrated front wiper relay so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper auto stop signal received from IPDM E/R with CAN communication.
- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval.



#### NOTE:

Front wiper intermittent operation can be set to the operation with vehicle speed by CONSULT. Refer to [BCS-20. "WIPER : CONSULT Function \(BCM - WIPER\)"](#).

- Front wiper intermittent operation with vehicle speed
- BCM calculates the intermittent operation delay interval from the following
  - Vehicle speed signal (received from the combination meter with CAN communication)
  - Wiper intermittent dial position

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# SYSTEM


## < SYSTEM DESCRIPTION >

| Wiper intermittent dial position | Intermittent operation interval | Intermittent operation delay Interval (s)     |  |  |                           |
|----------------------------------|---------------------------------|---|--|--|---------------------------|
|                                  |                                 | Vehicle speed                                 |  |  |                           |
|                                  |                                 | Vehicle stopped or less than 5 km/h (3.1 MPH) | 5 km/h (3.1MPH) or more or less than 35km/h (21.7 MPH) | 35 km/h (21.7 MPH) or more or less than 65km/h (40.4 MPH)* | 65 km/h (40.4MPH) or more |
| 1                                | Short<br>↑                      | 0.8   | 0.6  | 0.4  | 0.24                      |
| 2                                |                                 | 4   | 3  | 2  | 1.2                       |
| 3                                |                                 | 10  | 7.5  | 5  | 3                         |
| 4                                |                                 | 16  | 12   | 8  | 4.8                       |
| 5                                |                                 | 24  | 18   | 12   | 7.2                       |
| 6                                | Long<br>↓                       | 32  | 24   | 16   | 9.6                       |
| 7                                |                                 | 42  | 31.5   | 21   | 12.6                      |

\*: When without vehicle speed setting

### FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper auto stop signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).
- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch OFF.

### FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The front washer motor is grounded through the combination switch when the front washer switch is ON.

### REAR VIEW CAMERA WASHER CONTROL UNIT (if equipped)

- Rear view camera washer control unit detects the combination switch condition by the combination switch reading function.
- Rear view camera washer control unit supplies power and ground to operate the front washer motor.



# SYSTEM

## < SYSTEM DESCRIPTION >

---

Washer linked operating condition of rear view camera washer control unit

- Ignition switch ON
- Front washer switch ON (0.4 second or more).
- IPDM E/R turns ON the integrated front wiper relay.
- The washer motor is grounded through the rear view camera washer control unit.
- The rear view camera washer control unit decides to spray the windshield or the rear camera.

### Fail-Safe

INFOID:000000008527540

### FAIL-SAFE OPERATION

IPDM E/R performs the fail-safe function when the front wiper auto stop circuit is malfunctioning. Refer to [PCS-19. "Fail Safe"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

### DIAGNOSIS SYSTEM (BCM)

#### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000008682971

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description  |
|------------------------|--|
| Ecu Identification     | The BCM part number is displayed.  |
| Self Diagnostic Result | The BCM self diagnostic results are displayed.   |
| Data Monitor           | The BCM input/output data is displayed in real time.   |
| Active Test            | The BCM activates outputs to test components.  |
| Work support           | The settings for BCM functions can be changed.   |
| Configuration          | <ul style="list-style-type: none"> <li>• The vehicle specification can be read and saved.</li> <li>• The vehicle specification can be written when replacing BCM.</li> </ul> |
| CAN Diag Support Mntr  | The result of transmit/receive diagnosis of CAN communication is displayed.  |

#### SYSTEM APPLICATION

BCM can perform the following functions.

| System                               | Sub System           | Direct Diagnostic Mode |                        |              |             |              |               |                       |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
|                                      |                      | Ecu Identification     | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock                            | DOOR LOCK            |                        | ×                      | ×            | ×           | ×            |               |                       |
| Rear window defogger                 | REAR DEFOGGER        |                        |                        | ×            | ×           | ×            |               |                       |
| Warning chime                        | BUZZER               |                        |                        | ×            | ×           |              |               |                       |
| Interior room lamp timer             | INT LAMP             |                        |                        | ×            | ×           | ×            |               |                       |
| Remote keyless entry system          | MULTI REMOTE ENT     |                        |                        | ×            | ×           | ×            |               |                       |
| Exterior lamp                        | HEADLAMP             |                        |                        | ×            | ×           | ×            |               |                       |
| Wiper and washer                     | WIPER                |                        |                        | ×            | ×           | ×            |               |                       |
| Turn signal and hazard warning lamps | FLASHER              |                        |                        | ×            | ×           |              |               |                       |
| Air conditioner                      | AIR CONDITIONER      |                        |                        | ×            |             |              |               |                       |
| Intelligent Key system               | INTELLIGENT KEY      |                        | ×                      | ×            | ×           | ×            |               |                       |
| Combination switch                   | COMB SW              |                        |                        | ×            |             |              |               |                       |
| BCM                                  | BCM                  | ×                      | ×                      |              |             | ×            | ×             | ×                     |
| Immobilizer                          | IMMU                 |                        | ×                      | ×            | ×           |              |               |                       |
| Interior room lamp battery saver     | BATTERY SAVER        |                        |                        | ×            | ×           |              |               |                       |
| Trunk open                           | TRUNK                |                        |                        | ×            |             |              |               |                       |
| Vehicle security system              | THEFT ALM            |                        |                        | ×            | ×           | ×            |               |                       |
| RAP system                           | RETAINED PWR         |                        |                        | ×            |             |              |               |                       |
| Signal buffer system                 | SIGNAL BUFFER        |                        |                        | ×            |             |              |               |                       |
| TPMS                                 | AIR PRESSURE MONITOR |                        | ×                      | ×            | ×           | ×            |               |                       |

#### WIPER

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000008682972

### DATA MONITOR

| Monitor Item [Unit]    | Description  |
|------------------------|--|
| PUSH SW [On/Off]       | Indicates condition of push-button ignition switch.                                      |
| VEH SPEED 1 [km/h]     | Indicates vehicle speed signal received from ABS on CAN communication line.              |
| FR WIPER HI [On/Off]   | Indicates condition of wiper operation of combination switch.                            |
| FR WIPER LOW [On/Off]  |  |
| FR WASHER SW [On/Off]  |  |
| FR WIPER INT [On/Off]  |  |
| FR WIPER STOP [On/Off] | Indicates front wiper auto stop signal received from IPDM E/R on CAN communication line. |
| INT VOLUME [1 - 7]     | Indicates condition of intermittent wiper operation of combination switch.               |

### ACTIVE TEST

| Test Item | Description   |
|-----------|---|
| FR WIPER  | This test is able to check front wiper operation [Hi/Lo/INT/Off]. |

### WORK SUPPORT

| Support Item        | Setting | Description  |
|---------------------|---------|--|
| WIPER SPEED SETTING | On      | Front wiper intermittent time linked with vehicle speed and wiper dial position. |
|                     | Off*    | Front wiper intermittent time linked with wiper dial position.                   |

\* : Initial setting

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000008682961

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Front fog lamps
- Parking lamps
- Side marker lamps
- Tail lamps
- License plate lamps
- Daytime running lamps
- Headlamps (LO, HI)
- A/C compressor
- Cooling fans (LO, HI)

##### Operation Procedure

##### **CAUTION:**

**Do not start the engine.**

##### **NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield before hand.

##### **NOTE:**

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-99, "Component Function Check"](#).
  - When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.
1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)
  2. Turn ignition switch OFF.
  3. Turn the ignition switch ON, and within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
  4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once, and the auto active test starts.
  5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.


| Operation sequence | Inspection Location  | Operation                           |
|--------------------|--|-------------------------------------|
| 1                  | Front wiper  | LO for 3 seconds → HI for 3 seconds |
| 2                  | <ul style="list-style-type: none"><li>• Front fog lamps</li><li>• Parking lamps</li><li>• Side marker lamps</li><li>• Tail lamps</li><li>• License plate lamps</li></ul> | 10 seconds                          |
| 3                  | Daytime running lamps  | 10 seconds                          |
| 4                  | Headlamps  | LO ⇔ HI 5 times                     |
| 5                  | A/C compressor   | ON ⇔ OFF 5 times                    |
| 6*                 | Cooling fans   | LO for 5 seconds → HI for 5 seconds |

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

| Symptom  | Inspection contents  | Possible cause   |
|--|--|--|
| Any of the following components do not operate <ul style="list-style-type: none"> <li>• Front fog lamps</li> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Daytime running lamps</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper</li> </ul> | Perform auto active test.<br>Does the applicable system operate? | YES<br>BCM signal input circuit  |
|  |  | NO<br><ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>   |
| Cooling fans do not operate  | Perform auto active test.<br>Do the cooling fans operate?        | YES<br><ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>   |
|  |  | NO<br><ul style="list-style-type: none"> <li>• Cooling fans</li> <li>• Harness or connectors between cooling fans and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connectors between cooling fan relay and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connectors between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul> |

## CONSULT Function (IPDM E/R)

INFOID:000000008682962

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

| Direct Diagnostic Mode | Description   |
|------------------------|---|
| Ecu Identification     | The IPDM E/R part number is displayed.                                      |
| Self Diagnostic Result | The IPDM E/R self diagnostic results are displayed.                         |
| Data Monitor           | The IPDM E/R input/output data is displayed in real time.                   |
| Active Test            | The IPDM E/R activates outputs to test components.                          |
| CAN Diag Support Mntr  | The result of transmit/receive diagnosis of CAN communication is displayed. |

### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

### DATA MONITOR

| Monitor Item [Unit]           | Main Signals | Description   |
|-------------------------------|--------------|---|
| MOTOR FAN REQ [%]             | ×            | Indicates cooling fan speed signal received from ECM on CAN communication line          |
| AC COMP REQ [On/Off]          | ×            | Indicates A/C compressor request signal received from ECM on CAN communication line     |
| TAIL&CLR REQ [On/Off]         | ×            | Indicates position light request signal received from BCM on CAN communication line     |
| HL LO REQ [On/Off]            | ×            | Indicates low beam request signal received from BCM on CAN communication line           |
| HL HI REQ [On/Off]            | ×            | Indicates high beam request signal received from BCM on CAN communication line          |
| FR FOG REQ [On/Off]           | ×            | Indicates front fog light request signal received from BCM on CAN communication line    |
| FR WIP REQ [Stop/1LOW/Low/Hi] | ×            | Indicates front wiper request signal received from BCM on CAN communication line        |
| WIP AUTO STOP [STOP P/ACT P]  | ×            | Indicates condition of front wiper auto stop signal                                     |
| WIP PROT [Off/BLOCK]          | ×            | Indicates condition of front wiper fail-safe operation                                  |
| IGN RLY1 -REQ [On/Off]        |              | Indicates ignition switch ON signal received from BCM on CAN communication line         |
| IGN RLY [On/Off]              | ×            | Indicates condition of ignition relay   |
| PUSH SW [On/Off]              |              | Indicates condition of push-button ignition switch                                      |
| INTER/NP SW [On/Off]          |              | Indicates condition of CVT shift position   |
| ST RLY CONT [On/Off]          |              | Indicates starter relay status signal received from BCM on CAN communication line       |
| IHBT RLY -REQ [On/Off]        |              | Indicates starter control relay signal received from BCM on CAN communication line      |
| ST/INH RLY [Off/ ST /INH]     |              | Indicates condition of starter relay and starter control relay                          |
| DETENT SW [On/Off]            |              | Indicates condition of CVT shift selector (park position switch)                        |
| DTRL REQ [Off]                |              | Indicates daytime light request signal received from BCM on CAN communication line      |
| HOOD SW [On/Off]              |              | Indicates condition of hood switch  |
| THFT HRN REQ [On/Off]         |              | Indicates theft warning horn request signal received from BCM on CAN communication line |
| HORN CHIRP [On/Off]           |              | Indicates horn reminder signal received from BCM on CAN communication line              |
| HOOD SW 2 [On/Off]            |              | Indicates condition of hood switch 2  |

### ACTIVE TEST

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

| Test item      | Description  |
|----------------|--|
| HORN           | This test is able to check horn operation [On].                          |
| FRONT WIPER    | This test is able to check wiper motor operation [Hi/Lo/Off].            |
| MOTOR FAN      | This test is able to check cooling fan operation [4/3/2/1].              |
| EXTERNAL LAMPS | This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off]. |

### CAN DIAG SUPPORT MNTR

Refer to [LAN-15, "CAN Diagnostic Support Monitor"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# BCM, IPDM E/R

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000008525008

| ECU      | Reference   |
|----------|---|
| BCM      | <a href="#">BCS-28. "Reference Value"</a>               |
|          | <a href="#">BCS-47. "Fail Safe"</a>                     |
|          | <a href="#">BCS-47. "DTC Inspection Priority Chart"</a> |
|          | <a href="#">BCS-49. "DTC Index"</a>                     |
| IPDM E/R | <a href="#">PCS-12. "Reference Value"</a>               |
|          | <a href="#">PCS-19. "Fail Safe"</a>                     |
|          | <a href="#">PCS-20. "DTC Index"</a>                     |



# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >


## WIRING DIAGRAM

### FRONT WIPER AND WASHER SYSTEM

Wiring Diagram - Without Rear View Camera Washer Control System

INFOID:000000007986996

FRONT WIPER AND WASHER SYSTEM - WITHOUT REAR VIEW CAMERA WASHER CONTROL SYSTEM



ABLWA1773GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# FRONT WIPER AND WASHER SYSTEM


< WIRING DIAGRAM >

## FRONT WIPER AND WASHER SYSTEM CONNECTORS - WITHOUT REAR VIEW CAMERA WASHER CONTROL SYSTEM

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |                  |
|-----------------|------------------|
| Connector No.   | M3               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6N           | W             | -           |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M17                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN                     |



| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 10           | W             | COMBI SW IN 5 |
| 11           | BG            | COMBI SW IN 4 |
| 12           | W             | COMBI SW IN 3 |
| 13           | G             | COMBI SW IN 2 |
| 14           | P             | COMBI SW IN 1 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1G           | LG            | -           |
| 5G           | W             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 36G          | G             | -           |
| 95G          | BG            | -           |
| 100G         | LG            | -           |

ABLIA3705GB

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M18                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 |
| 80 | 79 | 78 | 77 | 76 | 75 | 74 | 73 | 72 | 71 | 70 | 69 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 |

|     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 137 | 136 | 135 | 134 | 133 | 132 | 131 | 130 | 129 |
| 143 | 142 | 141 | 140 | 139 | 138 |     |     |     |

| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 59           | P             | CAN-L          |
| 60           | L             | CAN-H          |
| 70           | G             | IGN USM OUT 1  |
| 75           | BG            | COMBI SW OUT 5 |
| 76           | W             | COMBI SW OUT 4 |
| 77           | R             | COMBI SW OUT 3 |
| 78           | P             | COMBI SW OUT 2 |
| 79           | G             | COMBI SW OUT 1 |

| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 131          | W             | BAT BCM FUSE  |
| 134          | B             | GND2          |
| 139          | W             | BAT POWER F/L |
| 143          | B             | GND1          |

|                 |                    |
|-----------------|--------------------|
| Connector No.   | M28                |
| Connector Name  | COMBINATION SWITCH |
| Connector Color | WHITE              |

|   |   |   |    |    |    |    |    |
|---|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4  | 5  | 6  |    |    |
| 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |

| Terminal No. | Color of Wire | Signal Name                         |
|--------------|---------------|-------------------------------------|
| 1            | BG            | WASH MTR (WITH REAR VIEW CAMERA)    |
| 1            | LG            | WASH MTR (WITHOUT REAR VIEW CAMERA) |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | BG            | OUTPUT 4    |
| 5            | W             | OUTPUT 3    |
| 6            | B             | GND         |
| 7            | R             | INPUT 3     |
| 8            | W             | OUTPUT 5    |
| 9            | P             | INPUT 2     |
| 10           | W             | INPUT 4     |
| 11           | G             | INPUT 1     |
| 12           | P             | OUTPUT 1    |
| 13           | BG            | INPUT 5     |
| 14           | G             | OUTPUT 2    |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M89                 |
| Connector Name  | JOINT CONNECTOR-M05 |
| Connector Color | WHITE               |

|   |   |   |   |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

ABLIA3706GB

A B C D E F G H I J K L M N O P

WW

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M157                |
| Connector Name  | JOINT CONNECTOR-M08 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M156                |
| Connector Name  | JOINT CONNECTOR-M07 |
| Connector Color | WHITE               |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M155                |
| Connector Name  | JOINT CONNECTOR-M06 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | E18  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7            | B             | GND (POWER) |
| 11           | Y             | FR WIPER LO |
| 18           | L             | FR WIPER HI |

|                 |              |
|-----------------|--------------|
| Connector No.   | E12          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | BG            | -           |
| 4            | BG            | -           |

ABLIA3707GB

# FRONT WIPER AND WASHER SYSTEM


< WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E21                 |
| Connector Name  | JOINT CONNECTOR-E03 |
| Connector Color | GRAY                |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 5            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-E04 |
| Connector Color | GRAY                |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 5            | P             | -           |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | E25               |
| Connector Name  | FRONT WIPER MOTOR |
| Connector Color | GRAY              |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | GR            | -           |
| 3            | Y             | -           |
| 4            | SB            | -           |
| 5            | L             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E30          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1G           | BG            | -           |
| 5G           | P             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 36G          | LG            | -           |
| 95G          | BG            | -           |
| 100G         | B             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E56                 |
| Connector Name  | JOINT CONNECTOR-E08 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 32           | GR            | -           |
| 33           | GR            | -           |

ABLIA3708GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# FRONT WIPER AND WASHER SYSTEM


< WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | E202         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | BG            | -           |
| 4            | BG            | -           |

|                 |  |
|-----------------|--|
| Connector No.   | E200   |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 74           | V             | WASH MTR    |

|                 |  |
|-----------------|--|
| Connector No.   | E63  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 28           | P             | CAN-L          |
| 29           | L             | CAN-H          |
| 34           | SB            | WIPER AUTOSTOP |
| 41           | B             | GND (SIGNAL)   |
| 43           | LG            | IGN SIGNAL     |

|                 |              |
|-----------------|--------------|
| Connector No.   | E226         |
| Connector Name  | WASHER MOTOR |
| Connector Color | BLACK        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | -           |
| 2            | BG            | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E203         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | B             | -           |

ABLIA37096B


# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

## Wiring Diagram - With Rear View Camera Washer Control System

INFOID:00000007986997

### FRONT WIPER AND WASHER SYSTEM - WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM




ABLWA1771GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >



ABLWA1789GB




# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

## FRONT WIPER AND WASHER SYSTEM CONNECTORS - WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM


|                 |                  |
|-----------------|------------------|
| Connector No.   | M3               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 6N           | W             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1G           | LG            | -           |
| 5G           | W             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 36G          | G             | -           |
| 95G          | BG            | -           |
| 100G         | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW



ABLIA3699GB

# FRONT WIPER AND WASHER SYSTEM


< WIRING DIAGRAM >



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5J           | B             | -           |
| 10J          | LG            | -           |
| 88J          | LG            | -           |
| 91J          | BG            | -           |
| 96J          | B             | -           |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 75           | BG            | COMBI SW OUT 5 |
| 76           | W             | COMBI SW OUT 4 |
| 77           | R             | COMBI SW OUT 3 |
| 78           | P             | COMBI SW OUT 2 |
| 79           | G             | COMBI SW OUT 1 |



ABLIA3700GB

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >


|                 |                     |
|-----------------|---------------------|
| Connector No.   | M89                 |
| Connector Name  | JOINT CONNECTOR-M05 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | B             | GND         |
| 7            | R             | INPUT 3     |
| 8            | W             | OUTPUT 5    |
| 9            | P             | INPUT 2     |
| 10           | W             | INPUT 4     |
| 11           | G             | INPUT 1     |
| 12           | P             | OUTPUT 1    |
| 13           | BG            | INPUT 5     |
| 14           | G             | OUTPUT 2    |

|                 |                    |
|-----------------|--------------------|
| Connector No.   | M28                |
| Connector Name  | COMBINATION SWITCH |
| Connector Color | WHITE              |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | LG            | WASH MTR    |
| 2            | BG            | OUTPUT 4    |
| 5            | W             | OUTPUT 3    |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M157                |
| Connector Name  | JOINT CONNECTOR-M08 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M156                |
| Connector Name  | JOINT CONNECTOR-M07 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M155                |
| Connector Name  | JOINT CONNECTOR-M06 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

ABLIA3701GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

|                 |  |
|-----------------|--|
| Connector No.   | E18  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7            | B             | GND (POWER) |
| 11           | Y             | FR WIPER LO |
| 18           | L             | FR WIPER HI |

|                 |              |
|-----------------|--------------|
| Connector No.   | E12          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | BG            | -           |
| 4            | BG            | -           |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | E25               |
| Connector Name  | FRONT WIPER MOTOR |
| Connector Color | GRAY              |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | GR            | -           |
| 3            | Y             | -           |
| 4            | SB            | -           |
| 5            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-E04 |
| Connector Color | GRAY                |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 5            | P             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E21                 |
| Connector Name  | JOINT CONNECTOR-E03 |
| Connector Color | GRAY                |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 5            | L             | -           |

ABLIA3702GB

# FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >


|                 |                     |
|-----------------|---------------------|
| Connector No.   | E56                 |
| Connector Name  | JOINT CONNECTOR-E08 |
| Connector Color | WHITE               |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 32           | GR            | -           |
| 33           | GR            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1G           | BG            | -           |
| 5G           | P             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 36G          | LG            | -           |
| 95G          | BG            | -           |
| 100G         | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E30          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |              |
|-----------------|--------------|
| Connector No.   | E202         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | O             | -           |
| 4            | Y             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | E200   |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 74           | V             | WASH-MTR    |

|                 |  |
|-----------------|--|
| Connector No.   | E63  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 28           | P             | CAN-L          |
| 29           | L             | CAN-H          |
| 34           | SB            | WIPER AUTOSTOP |
| 41           | B             | GND (SIGNAL)   |
| 43           | LG            | IGN SIGNAL     |

ABLIA3703GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# FRONT WIPER AND WASHER SYSTEM


< WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | E203         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 6            | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E226         |
| Connector Name  | WASHER MOTOR |
| Connector Color | BLACK        |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 1            | B             | -           |
| 2            | O             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 5J           | B             | -           |
| 10J          | W             | -           |
| 88J          | LG            | -           |
| 91J          | L             | -           |
| 96J          | B             | -           |

|                 |   |
|-----------------|---|
| Connector No.   | B16                                     |
| Connector Name  | REAR VIEW CAMERA<br>WASHER CONTROL UNIT |
| Connector Color | WHITE                                   |



|              |               |                            |
|--------------|---------------|----------------------------|
| Terminal No. | Color of Wire | Signal Name                |
| 1            | V             | PUMP MOTOR+                |
| 2            | BR            | PUMP MOTOR-                |
| 3            | L             | WASHER MOTOR -             |
| 4            | B             | WASHER MOTOR +             |
| 5            | B             | GND                        |
| 6            | P             | SERIAL GND                 |
| 7            | G             | FROM PUMP TO<br>CAMERA C/W |
| 8            | W             | FROM CAMERA C/U<br>TO PUMP |
| 10           | LG            | FR WASHER SW               |
| 12           | W             | IGN                        |

ABLIA3704GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000008525584

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. CONFIRM THE SYMPTOM

---

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

## 3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

---

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms. Refer to [WW-45. "Symptom Table"](#).

>> GO TO 4.

## 4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

---

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

## 5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

---

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

## 6. FINAL CHECK

---

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.



# WIPER AND WASHER FUSE

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### WIPER AND WASHER FUSE

#### Description

INFOID:000000007986975

#### Fuse list

| Unit               | Location | Fuse No. | Capacity |
|--------------------|----------|----------|----------|
| Front wiper motor  | IPDM E/R | 41       | 30 A     |
| Front washer motor | IPDM E/R | 50       | 10 A     |

#### Diagnosis Procedure

INFOID:000000007986976

#### 1. CHECK FUSES

Check that the following fuses are not blown.

| Unit               | Location | Fuse No. | Capacity |
|--------------------|----------|----------|----------|
| Front wiper motor  | IPDM E/R | 41       | 30 A     |
| Front washer motor | IPDM E/R | 50       | 10 A     |

#### Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.
- NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR LO CIRCUIT

### Component Function Check

INFOID:000000007986977

#### 1. CHECK FRONT WIPER LO OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO operation.

##### Ⓟ CONSULT ACTIVE TEST

1. Select FRONT WIPER of IPDM E/R active test item.
2. While operating the test item, check that front wiper LO operation and OFF.

**Lo** : Front wiper LO operation

**Off** : Stop the front wiper.

Is the inspection result normal?

- YES >> Front wiper motor LO circuit is normal.  
NO >> Refer to [WW-34, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000007986978

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

#### 1. CHECK FRONT WIPER MOTOR (LO) INPUT VOLTAGE

##### Ⓟ CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor.
3. Turn the ignition switch ON.
4. Select FRONT WIPER of IPDM E/R active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector E18 and ground.

| Terminals |          | Test item   | Voltage (Approx.) |
|-----------|----------|-------------|-------------------|
| (+)       | (-)      |             |                   |
| IPDM E/R  |          | FRONT WIPER | Battery voltage   |
| Connector | Terminal |             |                   |
| E18       | 11       | Lo          | Battery voltage   |
|           |          | Off         | 0V                |

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

#### 2. CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R.
3. Check continuity between IPDM E/R harness connector E18 and front wiper motor harness connector E25.

| IPDM E/R  |          | Front wiper motor |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| E18       | 11       | E25               | 3        | Yes        |

Is the inspection result normal?

- YES >> GO TO 3.

# FRONT WIPER MOTOR LO CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace the harness or connectors.

### 3. CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E18 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E18       | 11       |        | No         |

Is the inspection result normal?

YES >> Repair or replace the harness or connectors.

NO >> Replace front wiper motor. Refer to [WW-64. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR HI CIRCUIT

### Component Function Check

INFOID:000000007986979

#### 1. CHECK FRONT WIPER HI OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front wiper operates at the HI operation.

##### Ⓟ CONSULT ACTIVE TEST

1. Select FRONT WIPER of IPDM E/R active test item.
2. While operating the test item, check that front wiper HI operation and OFF.

**Hi** : Front wiper HI operation

**Off** : Stop the front wiper.

Is the inspection result normal?

YES >> The front wiper motor HI circuit is normal.

NO >> Refer to [WW-36, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000007986980

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

#### 1. CHECK FRONT WIPER MOTOR (HI) INPUT VOLTAGE

##### Ⓟ CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor.
3. Turn the ignition switch ON.
4. Select FRONT WIPER of IPDM E/R active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector E18 and ground.

| Terminals |          | Test item   | Voltage (Approx.) |
|-----------|----------|-------------|-------------------|
| (+)       | (-)      |             |                   |
| IPDM E/R  |          | FRONT WIPER | Battery voltage   |
| Connector | Terminal |             |                   |
| E18       | 18       |             |                   |
|           |          | Ground      |                   |
|           |          | Hi          | Battery voltage   |
|           |          | Off         | 0V                |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

#### 2. CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R.
3. Check continuity between IPDM E/R harness connector E18 and front wiper motor harness connector E25.

| IPDM E/R  |          | Front wiper motor |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| E18       | 18       | E25               | 5        | Yes        |

Is the inspection result normal?

YES >> GO TO 3.

# FRONT WIPER MOTOR HI CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace the harness or connectors.

### 3. CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E18 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E18       | 18       |        | No         |

Is the inspection result normal?

YES >> Repair or replace the harness or connectors.

NO >> Replace front wiper motor. Refer to [WW-64. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000007986981

#### 1. CHECK FRONT WIPER (AUTO STOP) OPERATION

##### ⓐ CONSULT DATA MONITOR

1. Select "WIP AUTO STOP" of IPDM E/R DATA MONITOR item.
2. Operate the front wiper.
3. With the front wiper operation, check the monitor status.

| Monitor item  | Condition         |               | Monitor status |
|---------------|-------------------|---------------|----------------|
| WIP AUTO STOP | Front wiper motor | Stop position | STOP P         |
|               |                   | Except        | ACT P          |

Is the inspection result normal?

- YES >> Auto stop signal circuit is normal.  
NO >> Refer to [WW-38, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000007986982

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

#### 1. CHECK IPDM E/R OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor.
3. Turn the ignition switch ON.
4. Check voltage between front wiper motor connector E25 and ground.

| Front wiper motor |          | Ground | Voltage (Approx.) |
|-------------------|----------|--------|-------------------|
| Connector         | Terminal |        | Battery voltage   |
| E25               | 4        |        |                   |

Is the inspection result normal?

- YES >> Replace front wiper motor. Refer to [WW-64, "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR (AUTO STOP) CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E63 and front wiper motor harness connector E25.

| IPDM E/R  |          | Front wiper motor |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| E63       | 34       | E25               | 4        | Yes        |

4. Check continuity between IPDM E/R harness connector E18 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        | No         |
| E63       | 34       |        |            |

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> Repair or replace the harness or connectors.

# FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000007986983

Regarding Wiring Diagram information, refer to [WW-23. "Wiring Diagram - With Rear View Camera Washer Control System"](#).

### 1. CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor.
3. Check continuity between front wiper motor harness connector E25 and ground.

| Front wiper motor |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| E25               | 2        |        | Yes        |

Is the inspection result normal?

- YES >> Front wiper motor ground circuit is normal.  
NO >> Repair or replace the harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# WASHER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## WASHER MOTOR CIRCUIT

### Diagnosis Procedure

INFOID:000000007986986

#### WITHOUT REAR VIEW CAMERA WASHER CONTROL SYSTEM

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

### 1. CHECK FRONT WASHER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not blown.

| Unit               | Location | Fuse No. | Capacity |
|--------------------|----------|----------|----------|
| Front washer motor | IPDM E/R | 50       | 10A      |

#### Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

### 2. CHECK FRONT WASHER MOTOR POWER SUPPLY

1. Disconnect front washer motor.
2. Turn ignition switch ON.
3. Check voltage between front washer motor harness connector E226 and ground.

| Front washer motor |          | Ground | Voltage (Approx.) |
|--------------------|----------|--------|-------------------|
| Connector          | Terminal |        | Battery voltage   |
| E226               | 1        |        |                   |

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the harness or connectors.

### 3. CHECK FRONT WASHER MOTOR CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect combination switch (wiper and washer switch).
3. Check continuity between combination switch (wiper and washer switch) harness connector M28 and front washer motor E226.

| Combination switch (wiper and washer switch) |          | Front washer motor |          | Continuity |
|--|----------|--------------------|----------|------------|
| Connector                                    | Terminal | Connector          | Terminal |            |
| M28  | 1        | E226               | 2        | Yes        |

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the harness or connectors.

### 4. CHECK WIPER AND WASHER SWITCH GROUND CIRCUIT

Check continuity between combination switch (wiper and washer switch) harness connector M28 and ground.

| Combination switch (wiper and washer switch) |          | Ground | Continuity |
|--|----------|--------|------------|
| Connector                                    | Terminal |        | Yes        |
| M28  | 6        |        |            |

#### Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the harness or connectors.



# WASHER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 5. CHECK WIPER AND WASHER SWITCH

Check wiper and washer switch. Refer to [WW-44, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace front washer motor. Refer to [WW-52, "Removal and Installation"](#).  
NO >> Replace wiper and washer switch. Refer to [WW-65, "Removal and Installation"](#).

## WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

## 1. CHECK WASHER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not blown.

| Unit               | Location | Fuse No. | Capacity |
|--------------------|----------|----------|----------|
| Front washer motor | IPDM E/R | 50       | 10A      |

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

## 2. CHECK WASHER SWITCH OPERATION

With CONSULT

1. Select FRONT WASHER SW of BCM active test item.
2. While operating the test, check front wiper operation.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Refer to [WW-44, "Component Inspection"](#).

## 3. CHECK COMBINATION SWITCH CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect the combination switch and rear view camera washer control unit.
3. Check continuity between rear view camera washer control unit harness connector B16 and combination switch harness connector M28.

| Rear view camera washer control unit |          | Combination switch |          | Continuity |
|--------------------------------------|----------|--------------------|----------|------------|
| Connector                            | Terminal | Connector          | Terminal |            |
| B16                                  | 10       | M28                | 1        | Yes        |

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the harness or connectors.

## 4. CHECK WASHER MOTOR POWER SUPPLY

1. Disconnect the washer motor.
2. Turn ignition switch ON.
3. Check voltage between washer motor harness connector E226 and ground.

| Front washer motor |          | Ground | Voltage (Approx.) |
|--------------------|----------|--------|-------------------|
| Connector          | Terminal |        | Battery voltage   |
| E226               | 1        |        |                   |

Is the inspection result normal?

- YES >> GO TO 9.

# WASHER MOTOR CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 5.

### 5. CHECK WASHER MOTOR POWER SUPPLY CONTINUITY

1. Turn ignition OFF.
2. Disconnect the washer motor connector harness.
3. Check continuity between the washer motor harness connector E226 and the rear view camera washer control unit harness connector B16.

| Rear view camera washer control unit |          | Washer motor |          | Continuity |
|--------------------------------------|----------|--------------|----------|------------|
| Connector                            | Terminal | Connector    | Terminal |            |
| B16                                  | 4        | E226         | 1        | Yes        |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the harness or connectors.

### 6. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY

1. Disconnect the rear view camera washer control unit.
2. Turn ignition switch ON.
3. Check voltage between the rear view camera washer control unit harness connector B16 and ground.

| Rear view camera washer control unit |          | Ground | Voltage (Approx.) |
|--------------------------------------|----------|--------|-------------------|
| Connector                            | Terminal |        |                   |
| B16                                  | 12       |        | Battery voltage   |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace the harness or connectors.

### 7. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CONTINUITY

1. Turn ignition OFF.
2. Check continuity between rear view camera washer control unit harness connector B16 and IPDM E/R harness connector E200.

| Rear view camera washer control unit |          | IPDM E/R  |          | Continuity |
|--------------------------------------|----------|-----------|----------|------------|
| Connector                            | Terminal | Connector | Terminal |            |
| B16                                  | 12       | E200      | 74       | Yes        |

Is the inspection result normal?

Yes >> Refer to [PCS-31. "Diagnosis Procedure"](#).

NO >> GO TO 8.

### 8. CHECK WASHER MOTOR GROUND CIRCUIT

Check continuity between combination switch harness connector E226 and ground.

| Washer motor |          | Ground | Continuity |
|--------------|----------|--------|------------|
| Connector    | Terminal |        |            |
| E226         | 2        |        | Yes        |

Is the inspection result normal?

YES >> Replace the washer pump. Refer to [WW-52. "Removal and Installation"](#).

NO >> GO TO 9.

### 9. CHECK WASHER MOTOR GROUND CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Check continuity between rear view camera washer control unit harness connector B16 and front washer motor E226.

# WASHER MOTOR CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

| Rear view camera washer control unit |          | Washer motor |          | Continuity |
|--------------------------------------|----------|--------------|----------|------------|
| Connector                            | Terminal | Connector    | Terminal |            |
| B16                                  | 3        | E226         | 2        | Yes        |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace the harness or connectors.

### **10.** CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT.

Check continuity between rear view camera washer control unit connector B16 and ground.

| Rear view camera washer control unit |          | Ground | Continuity |
|--------------------------------------|----------|--------|------------|
| Connector                            | Terminal |        |            |
| B16                                  | 5        |        | Yes        |

Is the inspection result normal?

YES >> Replace rear view camera washer control unit.

NO >> Repair or replace the harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# WASHER SWITCH


< DTC/CIRCUIT DIAGNOSIS >

## WASHER SWITCH

### Description

INFOID:000000007986984

- Washer switch is integrated with combination switch (wiper and washer switch).
- Combination switch (wiper and washer switch) supplies ground and fuse # 38 from the IPDM E/R supplies power for the front washer motor to operate.



### Component Inspection

INFOID:000000007986985

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

## 1. CHECK WASHER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch (wiper and washer switch) connector M28.
3. Check continuity between the combination switch (wiper and washer switch) terminals.

A: Terminal 1  
B: Terminal 6

|   | OFF | ON |
|---|-----|----|
| A |     | ○  |
| B |     | ○  |

ALLIA0546GB

| Combination switch (wiper and washer switch) |   | Condition        | Continuity |
|--|---|------------------|------------|
| Terminal                                     |   |                  |            |
| 1  | 6 | Washer switch ON | Yes        |

### Does continuity exist?

YES >> Washer switch is normal.

NO >> Replace combination switch (wiper and washer switch). Refer to [WW-65, "Removal and Installation"](#).

# WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### WIPER AND WASHER SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000007986998

**CAUTION:**

Perform the self-diagnosis with CONSULT before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

| Symptom                      | Probable malfunction location | Inspection item   |  |
|------------------------------|-------------------------------|---|--|
| Front wiper does not operate | HI only                       | <ul style="list-style-type: none"> <li>Combination switch (wiper and washer switch)</li> <li>Harness between combination switch (wiper and washer switch) and BCM</li> <li>BCM</li> </ul> | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description"</a> . |
|                              |                               | <ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>   | Front wiper motor (HI) circuit<br>Refer to <a href="#">WW-36, "Component Function Check"</a> .   |
|                              |                               | Front wiper request signal<br>• BCM<br>• IPDM E/R   | IPDM E/R<br>Data monitor "FR WIP REQ"  |
|                              | LO and INT                    | <ul style="list-style-type: none"> <li>Combination switch (wiper and washer switch)</li> <li>Harness between combination switch (wiper and washer switch) and BCM</li> <li>BCM</li> </ul> | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description"</a> . |
|                              |                               | <ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>   | Front wiper motor (LO) circuit<br>Refer to <a href="#">WW-34, "Component Function Check"</a> .   |
|                              |                               | Front wiper request signal<br>• BCM<br>• IPDM E/R   | IPDM E/R<br>Data monitor "FR WIP REQ"  |
|                              | INT only                      | <ul style="list-style-type: none"> <li>Combination switch (wiper and washer switch)</li> <li>Harness between combination switch (wiper and washer switch) and BCM</li> <li>BCM</li> </ul> | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description"</a> . |
|                              |                               | Front wiper request signal<br>• BCM<br>• IPDM E/R   | IPDM E/R<br>Data monitor "FR WIP REQ"  |
|                              | HI, LO, and INT               | SYMPTOM DIAGNOSIS<br>Refer to <a href="#">WW-48, "Diagnosis Procedure"</a> .  |  |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

| Symptom   | Probable malfunction location   | Inspection item   |   |
|---|---|---|---|
| Front wiper does not stop   | HI only   | <ul style="list-style-type: none"> <li>• Combination switch (wiper and washer switch)</li> <li>• BCM</li> </ul>   | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8. "COMBINATION SWITCH READING SYSTEM : System Description"</a> .  |
|   |   | Front wiper request signal<br><ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>   | IPDM E/R<br>Data monitor "FR WIP REQ"   |
|   |   | IPDM E/R  | —   |
|   | LO only   | <ul style="list-style-type: none"> <li>• Combination switch (wiper and washer switch)</li> <li>• BCM</li> </ul>   | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8. "COMBINATION SWITCH READING SYSTEM : System Description"</a> .  |
|   |   | Front wiper request signal<br><ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>   | IPDM E/R<br>Data monitor "FR WIP REQ"   |
|   |   | IPDM E/R  | —   |
|   | INT only  | <ul style="list-style-type: none"> <li>• Combination switch (wiper and washer switch)</li> <li>• BCM</li> </ul>   | Combination switch (wiper and washer switch)<br>refer to <a href="#">BCS-8. "COMBINATION SWITCH READING SYSTEM : System Description"</a> .  |
|   |   | Front wiper request signal<br><ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>   | IPDM E/R<br>Data monitor "FR WIP REQ"   |
|   | Front wiper does not operate normally   | Intermittent adjustment cannot be performed   | <ul style="list-style-type: none"> <li>• Combination switch (wiper and washer switch)</li> <li>• Harness between combination switch (wiper and washer switch) and BCM</li> <li>• BCM</li> </ul> |
| BCM   |   |   | —   |
| Intermittent control linked with vehicle speed cannot be performed  |   | Check the vehicle speed detection wiper setting.<br>Refer to <a href="#">BCS-20. "WIPER : CONSULT Function (BCM - WIPER)"</a> .   |   |
| Wiper is not linked to the washer operation   |   | <ul style="list-style-type: none"> <li>• Combination switch (wiper and washer switch)</li> <li>• Harness between combination switch (wiper and washer switch) and BCM</li> <li>• BCM</li> </ul> | Combination switch (wiper and washer switch)<br>Refer to <a href="#">BCS-8. "COMBINATION SWITCH READING SYSTEM : System Diagram"</a> .  |
|   |   | BCM   | —   |
| Does not return to stop position (Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. | <ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• Harness between IPDM E/R and front wiper motor</li> <li>• Front wiper motor</li> </ul> | Front wiper auto stop signal circuit<br>Refer to <a href="#">WW-38. "Component Function Check"</a> .  |   |

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

| Symptom   |  | Probable malfunction location  | Inspection item   |
|---|--|--|---|
| Washer motor does not operate (with rear view camera wash system) | Washer motor does not operate when washing the windshield. | <ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>  | Combination switch. Refer to <a href="#">BCS-76, "Symptom Table"</a> .        |
|   |  | <ul style="list-style-type: none"> <li>• Harness between IPDM E/R and rear view camera washer control unit</li> <li>• IPDM E/R</li> <li>• Harness between Combination switch and rear view camera washer control unit</li> <li>• Rear view camera washer control unit</li> </ul> | Washer motor circuit. Refer to <a href="#">WW-40, "Diagnosis Procedure"</a> . |
|   |  | BCM  | —   |

A  
B  
C  
D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT WIPER DOES NOT OPERATE

### Description

INFOID:000000007986999

The front wiper does not operate under any operation conditions

### Diagnosis Procedure

INFOID:000000007987000

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram - With Rear View Camera Washer Control System"](#).

## 1. CHECK WIPER RELAY OPERATION

### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/HI operation.

### Ⓟ CONSULT ACTIVE TEST

1. Select FRONT WIPER of IPDM E/R active test item.
2. While operating the test item, check that front wiper LO/HI operation and OFF.

**Lo** : Front wiper LO operation

**Hi** : Front wiper HI operation

**Off** : Stop the front wiper.

is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 2.

## 2. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the front wiper motor fuse 30A (No. 41, located in the IPDM E/R) is not blown.

Is the fuse blown?

YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 3.

## 3. CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

1. Disconnect front wiper motor.
2. Check continuity between front wiper motor harness connector E25 and ground.

| Front wiper motor |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| E25               | 2        |        | Yes        |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

## 4. CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

### Ⓟ CONSULT ACTIVE TEST

1. Turn the ignition switch ON.
2. Select FRONT WIPER of IPDM E/R active test item.
3. With operating the test item, check voltage between IPDM E/R harness connector E18 and ground.



# FRONT WIPER DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

| Terminals |          | Test item   | Voltage<br>(Approx.) |     |                 |
|-----------|----------|-------------|----------------------|-----|-----------------|
| (+)       | (-)      |             |                      |     |                 |
| IPDM E/R  |          | FRONT WIPER |                      |     |                 |
| Connector | Terminal |             |                      |     |                 |
| E18       | 11       |             |                      | Lo  | Battery voltage |
|           | 18       |             |                      | Off | 0 V             |
|           |          | Hi          | Battery voltage      |     |                 |
|           |          | Off         | 0 V                  |     |                 |

**Is the inspection result normal?**

YES LO circuit>>Refer to [WW-34, "Diagnosis Procedure"](#).

YES HI circuit>>Refer to [WW-36, "Diagnosis Procedure"](#).

NO >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

### 5. CHECK FRONT WIPER REQUEST SIGNAL INPUT

#### CONSULT DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R DATA MONITOR item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the monitor status.

| Monitor item | With operating the front wiper switch condition |     | Monitor status |
|--------------|---|-----|----------------|
| FR WIP REQ   | Front wiper switch HI                           | ON  | Hi             |
|              |   | OFF | Stop           |
|              | Front wiper switch LO                           | ON  | Low            |
|              |   | OFF | Stop           |

**Is the status of item normal?**

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> GO TO 6.

### 6. CHECK COMBINATION SWITCH (WIPER AND WASHER SWITCH)

1. Perform the inspection of the combination switch (wiper and washer switch). Refer to [BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description"](#).

**Is the inspection result normal?**

YES >> Replace BCM. Refer to [BCS-77, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

---

### NORMAL OPERATING CONDITION

#### Description

INFOID:000000007987001

#### FRONT WIPER MOTOR PROTECTION FUNCTION

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

# WASHER TANK


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### WASHER TANK

#### Exploded View

INFOID:000000008707365



- |                |                        |                     |
|----------------|------------------------|---------------------|
| 1. Washer tank | 2. Washer level switch | 3. Washer tank seal |
| 4. Washer pump | 5. Washer tank inlet   |                     |

### Removal and Installation

INFOID:000000007987012

#### REMOVAL

1. Drain the washer fluid.
2. Remove the front under cover. Refer to [EXT-28, "Removal and Installation"](#).
3. Remove the fender protector (RH). Refer to [EXT-26, "FENDER PROTECTOR : Removal and Installation"](#).
4. Disconnect the harness connectors from the washer pump and washer level switch.
5. Disconnect the washer tube from the washer pump.
6. Remove the washer tank bolts, then remove the washer tank.
7. Remove the washer pump, washer level switch, and washer tank seals from the washer tank (if necessary).

#### INSTALLATION

Installation is in the reverse order of removal.

#### NOTE:

- After installation, add water to the top of the washer tank inlet to check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-66, "Specifications"](#).


# WASHER PUMP

< REMOVAL AND INSTALLATION >

## WASHER PUMP

### Exploded View

INFOID:000000008707366



- |                |                        |                     |
|----------------|------------------------|---------------------|
| 1. Washer tank | 2. Washer level switch | 3. Washer tank seal |
| 4. Washer pump | 5. Washer tank inlet   |                     |

### Removal and Installation

INFOID:000000007987013

#### REMOVAL

1. Drain the washer fluid.
2. Remove the front under cover. Refer to [EXT-28. "Removal and Installation"](#).
3. Remove the fender protector (RH). Refer to [EXT-26. "FENDER PROTECTOR : Removal and Installation"](#).
4. Disconnect the harness connector from the washer pump.
5. Disconnect the washer tube from the washer pump.
6. Remove the washer pump.
7. Remove the washer tank seal (if necessary).

#### INSTALLATION

Installation is in the reverse order of removal.

#### NOTE:

- After installation, add water to the top of the washer tank inlet to check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-66. "Specifications"](#).


# WASHER LEVEL SWITCH

< REMOVAL AND INSTALLATION >

## WASHER LEVEL SWITCH

Exploded View

INFOID:000000008707367



- |                |                        |                     |
|----------------|------------------------|---------------------|
| 1. Washer tank | 2. Washer level switch | 3. Washer tank seal |
| 4. Washer pump | 5. Washer tank inlet   |                     |

## Removal and Installation

INFOID:000000007987015

### REMOVAL

1. Drain the washer fluid.
2. Remove the front under cover. Refer to [EXT-28, "Removal and Installation"](#).
3. Remove the fender protector (RH). Refer to [EXT-26, "FENDER PROTECTOR : Removal and Installation"](#).
4. Disconnect the harness connector from the washer level switch.
5. Remove the washer level switch.
6. Remove the washer tank seal (if necessary).

### INSTALLATION

Installation is in the reverse order of removal.

#### NOTE:

- After installation, add water to the top of the washer tank inlet to check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-66, "Specifications"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# WASHER NOZZLE & TUBE

< REMOVAL AND INSTALLATION >

## WASHER NOZZLE & TUBE

Exploded View

INFOID:000000008707369



1. Washer tube

2. Washer tank

3. Washer pump

4. Washer nozzle

⇐ Front

## WASHER NOZZLE


### WASHER NOZZLE : Removal and Installation

INFOID:000000007987010

#### REMOVAL

1. Disconnect the washer tube from the washer nozzle.
2. Disconnect the washer nozzle from the hood by pushing on the pawl in the direction shown (A).

(○): Pawl



3. Remove the washer nozzle.

#### INSTALLATION

# WASHER NOZZLE & TUBE

## < REMOVAL AND INSTALLATION >


Installation is in the reverse order of removal.

### CAUTION:

Adjust the nozzle spray pattern. Refer to [WW-55, "WASHER NOZZLE : Adjustment"](#).

## WASHER NOZZLE : Adjustment

INFOID:000000007987011



- A. 553.3 mm (21.8 in)
- D. 272.6 mm (10.7 in)
- G. 71.1 mm (2.8 in)
- K. 505.5 mm (19.9 in)

- B. 77.8 mm (3.1 in)
- E. 393 mm (15.5 in)
- H. 141 mm (5.6 in)

- C. 163.2 mm (6.4 in)
- F. 54.2 mm (2.1 in)
- J. 500.2 mm (19.7 in)

### NOTE:


Spray positions for LH shown; RH is symmetrical.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## WASHER NOZZLE & TUBE

### < REMOVAL AND INSTALLATION >




1. Washer Nozzle LH  
B. 6°

2. Washer Nozzle RH  
C. 1.5° ± 1.0°

- A. 60° ± 7.5°  
D. 4°

Insert a suitable tool (A) into the nozzle hole (B) and move up/down and left/right to adjust the spray position of each nozzle (1).




## WASHER TUBE

### WASHER TUBE : Removal and Installation

INFOID:000000008707368

#### REMOVAL

1. Drain the washer fluid.
2. Remove the hood ledge finisher clips and the hood ledge finisher (1) (RH).  
△: Clip



3. Remove the hood insulator. Refer to [DLK-169, "HOOD ASSEMBLY : Exploded View"](#).
4. Disconnect the washer tube from the washer nozzles (LH/RH).
5. Remove the front under cover. Refer to [EXT-28, "Removal and Installation"](#).
6. Remove the fender protector (RH). Refer to [EXT-26, "FENDER PROTECTOR : Removal and Installation"](#).
7. Disconnect the washer tube from the washer pump.



## WASHER NOZZLE & TUBE

### < REMOVAL AND INSTALLATION >

---

8. Remove the washer tube.

#### INSTALLATION

Installation is in the reverse order of removal.

**NOTE:**

Fill washer tank with specified amount of fluid. Refer to [WW-66. "Specifications"](#).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

## FRONT WIPER ARM

### Removal and Installation

INFOID:000000007987007

#### REMOVAL


1. Remove the wiper arm cap.
2. Remove the wiper arm nut.
3. Raise the wiper arm, then remove the wiper arm.

#### INSTALLATION

1. Clean the wiper arm mount as shown.

**NOTE:**

This will reduce the possibility of wiper arm looseness.



2. Install the wiper arm.
3. Install the wiper arm nut.
4. Install the wiper arm cap.
5. Check that the wiper blades stop at the specified position. Refer to [WW-60, "WIPER BLADE : Adjustment"](#).

# WIPER BLADE

< REMOVAL AND INSTALLATION >

## WIPER BLADE


## WIPER BLADE

### WIPER BLADE : Removal and Installation

INFOID:000000007987006

#### REMOVAL

1. Lift the wiper arm and wiper blade away from the windshield glass.
2. Rotate the wiper blade and push the release tab (A), then move the wiper blade down (B) the wiper arm.
3. Remove the wiper blade.



#### INSTALLATION

##### **CAUTION:**

- Return the wiper arm to the original position on the windshield to prevent damage when the hood is opened.
- Check that the wiper blade contacts the windshield properly; otherwise the wiper arm may be damaged from wind pressure while driving.

1. Insert the wiper blade onto the wiper arm and slide it up until it clicks into place.
2. Rotate the wiper blade so the dimple is in the groove.
3. Lay the wiper arm and wiper blade back down on the windshield.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


WW

# WIPER BLADE

< REMOVAL AND INSTALLATION >

## WIPER BLADE : Adjustment

INFOID:000000008707734



A. 25 mm (1.0 in)

B. 90 mm (3.5 in)

C. 40mm (1.6 in)

D. 50 mm (2.0 in)

E. 25 mm (1.0 in)

Adjust the wiper blades to the specification shown above.

## WIPER BLADE REFILL

### WIPER BLADE REFILL : Removal and Installation

INFOID:000000007987005


#### REMOVAL

1. Remove the wiper blade. Refer to [WW-59. "WIPER BLADE : Removal and Installation"](#).


# WIPER BLADE

## < REMOVAL AND INSTALLATION >

2. Hold the wiper blade refill lip at the end (A) of the wiper blade (1) with a suitable tool (B) as shown, and pull it firmly in the direction (C).  
(D): U clip (part of wiper blade)




- If the wiper blade refill lip is torn due to wear, insert a suitable tool (A) into the space between the end of the wiper blade refill (1) and the wiper blade (2) and pull the wiper blade refill (1) out as shown.



## INSTALLATION

1. If the rib (A) has become detached from the wiper blade refill (1), check that the curve of the rib (A) is in the same direction as the curve of the wiper blade refill (1) and insert the rib (A) into the slit (B) in the wiper blade refill (1) as shown.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW


# WIPER BLADE

## < REMOVAL AND INSTALLATION >


- If the rib (A) has a notch (B), insert the rib (A) into the wiper blade refill (1) so the notch (B) fits over the protrusion (C) in the wiper blade refill (1) as shown.



2. Insert the wiper blade refill (1) tip into the end of the wiper blade (2) in the direction (C). Push the wiper blade refill (1) in while pressing it into the end of the wiper blade (2) as shown. After the wiper blade refill is fully inserted, remove the holder (B). (A): Tab (part of wiper blade) (2)




- Make sure to slide the refill into the wiper blade so that the wiper blade refill is held by the tabs (A) on the wiper blade as shown.




# WIPER BLADE

## < REMOVAL AND INSTALLATION >

3. Push the wiper blade refill (1) until the tabs on the wiper blade (2) fit into the stoppers (A) in the end of the wiper blade refill (1). Make sure the LOCK mark (B) on the wiper blade refill (1) is aligned with the lock point symbol (C) on the wiper blade (2) as shown.



4. Before installing the wiper blade, make sure that the wiper blade refill (1) end is fully covered by the wiper blade (2) in area (A) as shown.



5. Install the wiper blade. Refer to [WW-59. "WIPER BLADE : Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# FRONT WIPER DRIVE ASSEMBLY

< REMOVAL AND INSTALLATION >

## FRONT WIPER DRIVE ASSEMBLY

Exploded View

INFOID:000000007987004



- |                         |                   |                 |
|-------------------------|-------------------|-----------------|
| 1. Wiper blade LH       | 2. Wiper blade RH | 3. Wiper arm RH |
| 4. Wiper drive assembly | 5. Wiper arm LH   |                 |

## Removal and Installation

INFOID:000000007987008

### REMOVAL

1. Remove the cowl top. Refer to [EXT-24, "Removal and Installation"](#).
2. Remove the strut tower bar. Refer to [FSU-19, "Exploded View"](#).
3. Disconnect the harness connector from the wiper drive assembly.
4. Remove the wiper drive assembly bolts.
5. Remove the wiper drive assembly.

### INSTALLATION

1. Install the wiper drive assembly.
2. Install the wiper drive assembly bolts.
3. Connect the harness connector to the wiper drive assembly.
4. Install the strut tower bar. Refer to [FSU-19, "Exploded View"](#).
5. Install the cowl top. Refer to [EXT-24, "Removal and Installation"](#).
6. Check that the wiper blades stop at the specified position. Refer to [WW-60, "WIPER BLADE : Adjustment"](#).



# WIPER AND WASHER SWITCH

< REMOVAL AND INSTALLATION >

## WIPER AND WASHER SWITCH

### Removal and Installation

INFOID:000000007987014

The wiper and washer switch is serviced as an assembly with the combination switch. Refer to [BCS-78](#), "[Removal and Installation](#)".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### Specifications

INFOID:000000007987016

### WINDSHIELD WASHER FLUID

|                                       |  |
|---------------------------------------|--|
| Windshield washer fluid capacity      | 4.5 ℓ (4 3/4 US qt, 4 Imp qt)  |
| Windshield washer fluid specification | Refer to <a href="#">MA-20, "FOR USA AND CANADA : Fluids and Lubricants"</a> (United States and Canada), <a href="#">MA-21, "FOR MEXICO : Fluids and Lubricants"</a> (Mexico). |