

SECTION **EXT**
EXTERIOR

A
B
C
D
E
F
G
H
I
J
EXT
L
M
N
O
P

CONTENTS

PRECAUTION	3	FENDER PROTECTOR	26
PRECAUTIONS	3	FENDER PROTECTOR	26
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	FENDER PROTECTOR : Exploded View	26
Precaution for Procedure without Cowl Top Cover.....	3	FENDER PROTECTOR : Removal and Installation	26
Precaution for Work	3	REAR WHEEL HOUSE PROTECTOR	26
PREPARATION	5	REAR WHEEL HOUSE PROTECTOR : Exploded View	27
PREPARATION	5	REAR WHEEL HOUSE PROTECTOR : Removal and Installation	27
Special Service Tools	5	FRONT UNDER COVER	28
Commercial Service Tool	5	Exploded View	28
CLIP LIST	6	Removal and Installation	28
Descriptions for Clips	6	REAR UNDER COVER	29
PERIODIC MAINTENANCE	10	Removal and Installation	29
SQUEAK AND RATTLE TROUBLE DIAGNOSES	10	MUDGUARD	30
Work Flow	10	Exploded View	30
Generic Squeak and Rattle Troubleshooting	11	Removal and Installation	30
Diagnostic Worksheet	14	DOOR SASH MOLDING	31
REMOVAL AND INSTALLATION	16	Exploded View	31
FRONT BUMPER	16	Removal and Installation	31
Exploded View	16	SIDE GUARD MOLDING	34
Removal and Installation	17	Exploded View	34
REAR BUMPER	20	Removal and Installation	34
Exploded View	20	DOOR OUTSIDE MOLDING	35
Removal and Installation	21	Exploded View	35
FRONT GRILLE	23	Removal and Installation	35
Exploded View	23	ROOF SIDE MOLDING	36
Removal and Installation	23	Exploded View	36
COWL TOP	24	Removal and Installation	36
Exploded View	24	LICENSE LAMP FINISHER	37
Removal and Installation	24	Removal and Installation	37

REAR SPOILER	38	Removal and Installation	38
Exploded View	38		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009951571

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000009460986

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Work

INFOID:000000009460987

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:

A
B
C
D
E
F
G
H
I
J
EXT
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >




PREPARATION

PREPARATION

Special Service Tools

INFOID:000000009895306



The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear  SIIA0993E	Locating the noise
— (J-46534) Trim Tool Set  AWJIA0483ZZ	Removing trim components
— (J-50397) NISSAN Squeak and Rattle Kit  ALJIA1232ZZ	Repairing the cause of noise

Commercial Service Tool

INFOID:000000009460989

EXT

(TechMate No.) Tool name	Description
(J-39565) Engine Ear  SIIA0995E	Locating the noise
Power tool  PIIB1407E	Loosening nuts, screws and bolts

CLIP LIST

















< PREPARATION >

CLIP LIST

Descriptions for Clips

INFOID:000000009460990
















Replace any clips which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
<p>C101</p> 		<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
<p>C103</p> 		 <p>Removal: Remove with a clip remover.</p>
<p>C203</p> 		<p>Removal: Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p>Push</p>  <p>Installation:</p> 
<p>C205</p> 		<p>Removal:</p> 
<p>C206</p> 		<p>Removal:</p> 

SIIA0315E

CLIP LIST

< PREPARATION >














Symbol No.	Shapes	Removal & Installation
<p>CE103</p> 		<p>Removal:</p> 
<p>CF110</p> 		<p>Removal:</p> 
<p>CF118</p> 		<p>Removal:</p> 
<p>CR103</p> 		<p>Removal: Holder portion of clip must be spread out to remove rod.</p> 
<p>CS101</p> 		<p>Removal:</p> <ol style="list-style-type: none"> 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

A
B
C
D
E
F
G
H
I
J
EXT
L
M
N
O
P

CLIP LIST










< PREPARATION >

Symbol No.	Shapes	Removal & Installation	
CG101 		Removal:  Rotate 45° to remove	Installation: 
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			

SIIA0317E

CLIP LIST

< PREPARATION >

Symbol No.	Shapes	Removal & Installation
<p>CG104</p> 		<p>Removal: Remove by bending up with flat-bladed screwdrivers.</p> 
<p>CE114</p> 		
<p>CF118</p> 		<p>Removal: Flat-bladed screwdrivers Finisher</p> 

ALJIA0564GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000009895307



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [EXT-14, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< PERIODIC MAINTENANCE >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [EXT-11. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
 - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
 - SILICONE SPRAY: Use when grease cannot be applied.
 - DUCT TAPE: Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000009895308

Refer to Table of Contents for specific component removal and installation information.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< PERIODIC MAINTENANCE >

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< PERIODIC MAINTENANCE >

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

A

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

B

Cause of seat noise include:

C

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

D

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

E

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

F

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

G

H

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

I

J

EXT

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< PERIODIC MAINTENANCE >

Diagnostic Worksheet

INFOID:000000009460993

Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< PERIODIC MAINTENANCE >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI/A0071E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT

FRONT BUMPER


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

FRONT BUMPER

Exploded View

INFOID:000000009460994



FRONT BUMPER

< REMOVAL AND INSTALLATION >


- | | | | |
|--|---|---|---|
| 1. Core support cover | 2. Front bumper fascia hood seal | 3. Front bumper fascia upper retainer bracket | A |
| 4. Front bumper fascia upper retainer bracket (RH) | 5. Front bumper reinforcement bracket | 6. Front bumper fascia upper retainer bracket (LH) | B |
| 7. Front bumper fascia upper retainer upper center bracket | 8. Front bumper fascia side bracket (RH) | 9. Front bumper reinforcement support (RH) | B |
| 10. Front bumper reinforcement | 11. Front energy absorber | 12. Front bumper fascia upper side bracket (RH) | C |
| 13. Front bumper fascia side stiffener (RH) | 14. Front fog lamp (RH) (if equipped) | 15. Front fog lamp finisher (RH) (if equipped) | C |
| 16. Turn signal and hazard warning lamp (RH) | 17. Front bumper fascia finisher (RH) (if equipped) | 18. Tow cover | D |
| 19. Front license plate bracket (if equipped) | 20. Turn signal and hazard warning lamp (LH) | 21. Front bumper fascia finisher (LH) (if equipped) | E |
| 22. Front fog lamp finisher (LH) (if equipped) | 23. Front bumper fascia | 24. Front fog lamp (LH) (if equipped) | E |
| 25. Front bumper fascia side stiffener (LH) | 26. Front bumper fascia upper side bracket (LH) | 27. Front bumper reinforcement support (LH) | F |
| 28. Front bumper fascia side bracket (LH) | A. Clip | | F |

Removal and Installation


INFOID:000000009460995

REMOVAL

1. Remove the core support cover clips (A), then remove the core support cover (1).




2. Partially remove the front fender protectors (LH/RH). Refer to [EXT-26. "FENDER PROTECTOR : Removal and Installation"](#).
3. Remove the front under cover. Refer to [EXT-28. "Removal and Installation"](#).
4. Remove the hood ledge finisher.
5. Remove the front bumper fascia to upper fender screws (A) (LH/RH), then rotate clockwise each front bumper fascia upper side bracket (1) to remove.



FRONT BUMPER

< REMOVAL AND INSTALLATION >


6. Remove the front bumper fascia to fender screw (A) (LH/RH).




7. Disconnect the harness connectors from front fog lamps (LH/RH) (if equipped).
8. Disconnect the harness connectors from turn signal and hazard warning lamps (LH/RH).
9. Release the front bumper fascia from the front bumper fascia side brackets (LH/RH).
10. Remove the front bumper fascia by releasing in the order shown.

CAUTION:

When removing front bumper fascia, two people are required to avoid damaging.



11. Remove the front energy absorber.
12. Remove the front bumper reinforcement bracket bolts (A) and the front bumper reinforcement bracket (1).



13. Remove the front bumper reinforcement nuts, then the front bumper reinforcement.
14. Remove the front bumper support bolts, then the front bumper reinforcement supports (LH/RH).
15. Remove the following parts after removing front bumper fascia.
- Front grille
 - Front bumper fascia (LH/RH) finisher (if equipped)
 - Tow cover
 - Turn signal and hazard warning lamps (LH/RH). Refer to [EXL-130, "Removal and Installation"](#).
 - Front fog lamp finishers (LH/RH) (if equipped)
 - Front fog lamp assemblies (LH/RH) (if equipped)
 - Front bumper fascia side brackets (LH/RH)
 - Front license plate bracket (if equipped)


INSTALLATION

Installation is in the reverse order of removal.

- Adjust fog lamp aiming (if equipped). Refer to [EXL-124, "Aiming Adjustment"](#).

FRONT BUMPER

< REMOVAL AND INSTALLATION >



mm (in)

Section	Measurement	Minimum	Target Value	Maximum
A-A	Clearance	2.0 (0.08)	4.1 (0.16)	6.2 (0.24)
A-A	Surface height	-0.6 (-0.02)	0.8 (0.03)	2.0 (0.08)
B-B	Clearance	0.2 (0.01)	1.5 (0.06)	2.8 (0.11)
B-B	Surface height	0.8 (0.03)	2.1 (0.08)	3.4 (0.13)
C-C	Clearance	0.2 (0.01)	1.5 (0.06)	2.8 (0.11)
C-C	Surface height	3.2 (0.13)	4.5 (0.18)	5.8 (0.23)
D-D	Clearance	0.2 (0.01)	1.5 (0.06)	2.8 (0.11)
D-D	Surface height	2.2 (0.09)	3.5 (0.14)	4.8 (0.19)
E-E	Clearance	-0.7 (-0.03)	0.0 (0.00)	0.7 (0.03)
E-E	Surface height	-1.0 (-0.04)	0.0 (0.00)	1.0 (0.04)
F-F	Clearance	-0.8 (-0.03)	0.0 (0.00)	0.8 (0.03)
F-F	Surface height	-0.3 (-0.01)	0.7 (0.03)	1.7 (0.07)
G-G	Clearance	0.2 (0.01)	1.5 (0.06)	3.2 (0.13)
H-H	Clearance	0.2 (0.01)	1.5 (0.06)	3.2 (0.13)
J-J	Surface height	0.2 (0.01)	1.5 (0.06)	3.2 (0.13)
K-K	Surface height	0.5 (0.02)	1.5 (0.06)	2.5 (0.10)
L-L	Surface height	0.5 (0.02)	1.5 (0.06)	2.5 (0.10)
M-M	Surface height	0.5 (0.02)	1.5 (0.06)	2.5 (0.10)
N-N	Surface height	0.1 (0.00)	1.5 (0.06)	2.9 (0.11)
O-O	Surface height	0.1 (0.00)	1.5 (0.06)	2.9 (0.11)
P-P	Surface height	0.1 (0.00)	1.5 (0.06)	2.9 (0.11)
Q-Q	Clearance	0.0 (0.00)	0.5 (0.02)	1.0 (0.04)
Q-Q	Surface height	-0.2 (-0.01)	0.3 (0.01)	0.8 (0.03)


REAR BUMPER

< REMOVAL AND INSTALLATION >

REAR BUMPER

Exploded View

INFOID:000000009460996



- | | | |
|----------------------------------|---|---|
| 1. Rear bumper side bracket (LH) | 2. Rear bumper reinforcement support (LH) | 3. Rear bumper reinforcement (LH) |
| 4. Rear bumper energy absorber | 5. Rear bumper fascia | 6. Rear bumper reinforcement support (RH) |
| 7. Rear bumper side bracket (RH) | A. Clip | |

REAR BUMPER


< REMOVAL AND INSTALLATION >

Removal and Installation


INFOID:000000009460997

REMOVAL


1. Remove the rear combination lamps (LH/RH). Refer to [EXL-137, "Removal and Installation"](#).
2. Remove the rear bumper fascia clips (A) and screws (B) (LH/RH).




3. Remove the rear bumper fascia upper side screws (A) (LH/RH).



4. Remove rear bumper fascia lower side clips (A) (LH/RH).



5. Remove the rear bumper fascia lower rear clips (A).




A
B
C
D
E
F
G
H
I
J
EXT
L
M
N
O
P

REAR BUMPER

< REMOVAL AND INSTALLATION >

- Pull rear bumper fascia outward in the order as shown by the arrows to release from rear bumper side brackets (LH/RH).

⊖: Pawl



- Remove the rear bumper fascia.


CAUTION:

When removing rear bumper fascia, two people are required to avoid damaging.

- Remove the rear bumper side brackets (LH/RH) from the rear bumper fascia.
- Remove rear bumper energy absorber.
- Remove the nuts and the rear bumper reinforcement.
- Remove the nuts and the rear bumper supports (LH/RH).

INSTALLATION

Installation is in the reverse order of removal.



mm (in)

Section	Measurement	Minimum	Target Value	Maximum
A-A	Clearance	0.0 (0.00)	0.0 (0.00)	0.8 (0.03)
A-A	Surface height	-1.8 (-0.07)	-0.8 (-0.03)	0.2 (0.01)
B-B	Clearance	0.0 (0.00)	0.0 (0.00)	0.8 (0.03)
B-B	Surface height	-1.8 (-0.07)	-0.8 (-0.03)	0.2 (0.01)
C-C	Clearance	0.0 (0.00)	0.0 (0.00)	0.8 (0.03)
C-C	Surface height	-1.8 (-0.07)	-0.8 (-0.03)	0.2 (0.01)
D-D	Clearance	0.5 (0.02)	2.0 (0.08)	3.5 (0.14)
D-D	Surface height	-1.5 (-0.06)	0.0 (0.00)	1.5 (0.06)
E-E	Clearance	2.0 (0.08)	4.0 (0.16)	6.0 (0.24)
F-F	Clearance	4.0 (0.16)	6.0 (0.24)	8.0 (0.31)


FRONT GRILLE

< REMOVAL AND INSTALLATION >

FRONT GRILLE

Exploded View

INFOID:000000009460998



1. Front grille

2. Emblem

A. Screw

 Pawl

Removal and Installation

INFOID:000000009460999

EXT

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove the front grille screws from the front grille.
3. Release the front grille pawls from the front bumper fascia and remove.
4. Remove the front grille emblem (if necessary).

INSTALLATION

Installation is in the reverse order of removal.


COWL TOP

< REMOVAL AND INSTALLATION >

COWL TOP

Exploded View

INFOID:000000009461000




- | | | |
|----------------------------------|------------------|----------------------------------|
| 1. Cowl top side trim cover (RH) | 2. Cowl top seal | 3. Cowl top side trim cover (LH) |
| 4. Cowl top cover | A. Clip | ○: Pawl |

Removal and Installation

INFOID:000000009461001

REMOVAL

1. Remove front wiper arms (LH/RH). Refer to [WW-58, "Removal and Installation"](#).
2. Release the cowl top seal clips, then remove the cowl top seal.
3. Release the pawls, then remove cowl top side trim covers (1) (LH/RH).
○: Pawl




4. Remove cowl top cover clips.

COWL TOP

< REMOVAL AND INSTALLATION >

5. Pull forward to release cowl top cover (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT

FENDER PROTECTOR


< REMOVAL AND INSTALLATION >

FENDER PROTECTOR

FENDER PROTECTOR

FENDER PROTECTOR : Exploded View

INFOID:000000009461002



1. Front fender protector

2. J-nut

3. Front fender protector side cover

A. Clip

FENDER PROTECTOR : Removal and Installation

INFOID:000000009461003

REMOVAL

Release the front fender protector clips, then remove the front fender protector screws and the front fender protector.

INSTALLATION

Installation is in the reverse order of removal.


REAR WHEEL HOUSE PROTECTOR

FENDER PROTECTOR

< REMOVAL AND INSTALLATION >

REAR WHEEL HOUSE PROTECTOR : Exploded View

INFOID:000000009461004



1. Rear wheel house protector A. Plastic nut B. Clip

REAR WHEEL HOUSE PROTECTOR : Removal and Installation

INFOID:000000009461005

REMOVAL

1. Remove the rear tires. Refer to [WT-55. "Adjustment"](#).
2. Remove the rear wheel house protector clips.
3. Remove rear wheel house protector plastic nuts and the rear wheel house protector.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT


FRONT UNDER COVER

< REMOVAL AND INSTALLATION >

FRONT UNDER COVER

Exploded View

INFOID:000000009461006



1. Front under cover

A. Clip

B. Screws

Removal and Installation

INFOID:000000009461007

REMOVAL

Remove the front under cover screws and clips, then remove front under cover.

INSTALLATION

Installation is in the reverse order of removal.

REAR UNDER COVER

< REMOVAL AND INSTALLATION >


REAR UNDER COVER

Removal and Installation

INFOID:000000009461008

REMOVAL

Remove the rear under cover clips (A) and nuts (B), then remove rear under cover (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT


MUDGUARD

< REMOVAL AND INSTALLATION >

MUDGUARD


Exploded View

INFOID:000000009461009



1. Center mudguard

2. Rear wheel wind deflector

 Clips

 Front

NOTE:

LH side shown; RH side similar.

Removal and Installation

INFOID:000000009461010

REMOVAL

1. Remove the center mudguard clips located on the under body.
2. Remove the center mudguard screws and the center mudguard.

INSTALLATION

Installation is in the reverse order of removal.


DOOR SASH MOLDING

< REMOVAL AND INSTALLATION >

DOOR SASH MOLDING

Exploded View

INFOID:000000009461011



- 1. Front door
- 2. Front door weatherstrip
- 3. Front door sash molding
- 4. Sash molding inner finisher
- A. Clip

NOTE:

RH side shown; LH side similar.

Removal and Installation

INFOID:000000009461012


FRONT DOOR

Removal

1. Remove the door mirror assembly. Refer to [MIR-20. "Removal and Installation"](#).
2. Remove the clip (A) using a suitable tool (B).

CAUTION:

Do not reuse the clip (A).




A
B
C
D
E
F
G
H
I
J
EXT
L
M
N
O
P

DOOR SASH MOLDING

< REMOVAL AND INSTALLATION >


3. Reposition the front door weatherstrip (2).
4. Reposition the front door rubber run (3).
5. Remove the front door sash molding (1) using a suitable tool (A), starting at the lower rear edge and rotating towards the top of the door as shown and remove.



Installation

Installation is in the reverse order of removal.

REAR DOOR



1. Rear door
 2. Rear door weatherstrip
 3. Rear door sash molding
- A. Rear door clip (front/rear)

Removal

NOTE:

RH side shown; LH side similar

1. Remove the rear door finisher. Refer to [INT-18. "Removal and Installation"](#).


DOOR SASH MOLDING

< REMOVAL AND INSTALLATION >

2. Remove the rear door front clip (A) using a suitable tool (B) and remove.

CAUTION:


Do not reuse the clip (A).




3. Remove the rear door rear clip (A) using a suitable tool (B) and remove.

CAUTION:

Do not reuse the clip (A).



4. Reposition the rear door weatherstrip (2).
5. Reposition the rear door rubber run (3).
6. Remove the rear door sash molding (1) using a suitable tool (A), starting at the lower rear edge and rotating towards the top of the door as shown and remove.



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J

EXT

L
M
N
O
P


DOOR OUTSIDE MOLDING

< REMOVAL AND INSTALLATION >

DOOR OUTSIDE MOLDING


Exploded View

INFOID:000000009461015



1. Front door outside molding

2. Rear door outside molding

 Clips

Removal and Installation

INFOID:000000009461016

FRONT DOOR OUTSIDE MOLDING

Removal

1. Remove the door mirror assembly. Refer to [MIR-20, "Removal and Installation"](#).
2. Lift and twist from rear side, disconnect clips from flange and pull the front door outside molding toward rear of the vehicle.

Installation

Installation is in the reverse order of removal.

REAR DOOR OUTSIDE MOLDING

Removal

Lift and twist from rear side, then disconnect clips from flange and pull the rear door outside molding out.

Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT


ROOF SIDE MOLDING

< REMOVAL AND INSTALLATION >

ROOF SIDE MOLDING

Exploded View

INFOID:000000009461017



1. Roof side molding

2. Roof panel

3. Body side outer panel

⇐ Front

Removal and Installation

INFOID:000000009461018

REMOVAL

1. Lift and pull the roof side molding up from the rear edge.
2. Release the roof side molding from the channel and remove from the roof.

INSTALLATION

Installation is in the reverse order of removal.

- Engage the roof molding into the clips starting at the rear.


LICENSE LAMP FINISHER

< REMOVAL AND INSTALLATION >

LICENSE LAMP FINISHER

Removal and Installation

INFOID:000000009461019



1. License lamp finisher

REMOVAL

1. Remove the trunk lid finisher (if equipped). Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Remove the license lamp finisher nuts and bolts.
3. Remove license lamp finisher by pulling toward the rear, then disconnect the harness connector from the trunk opener request switch and remove.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

EXT


REAR SPOILER

< REMOVAL AND INSTALLATION >

REAR SPOILER

Exploded View

INFOID:000000009461020



1. Rear spoiler
A. Nut
2. High mounted stop lamp harness
3. Gasket

Removal and Installation

INFOID:000000009461021

Removal

1. Remove trunk lid finisher (if equipped). Refer to [INT-33. "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect harness connector from the high mounted stop lamp.
3. Remove foam tape free from trunk lid surface, using a suitable tool.
CAUTION:
Use care not to damage painted surfaces during removal of or releasing adhesive backed foam tape.
4. Release the high mounted stop lamp harness grommet from trunk lid, then remove rear spoiler.

Installation

Installation is in the reverse order of removal.

NOTE:

- Before installing rear spoiler, clean the surface where it will be mounted with isopropyl alcohol or equivalent to degrease the surface.
- Before installing, be sure there are no gaps or waves in the foam tape where the surfaces meet.
- During installation, be sure grommet of high mounted stop lamp harness is fully seated into trunk lid opening prior to final rear spoiler assembly placement.