

# SECTION **INL**

## INTERIOR LIGHTING SYSTEM

### CONTENTS

<b>PRECAUTION</b> .....	3	INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) .....	13
<b>PRECAUTIONS</b> .....	3	<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	17
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	Diagnosis Description .....	17
Precaution for Work .....	3	CONSULT Function (IPDM E/R) .....	18
<b>PREPARATION</b> .....	4	<b>ECU DIAGNOSIS INFORMATION</b> .....	21
<b>PREPARATION</b> .....	4	<b>BCM, IPDM E/R</b> .....	21
Special Service Tool .....	4	List of ECU Reference .....	21
<b>SYSTEM DESCRIPTION</b> .....	5	<b>WIRING DIAGRAM</b> .....	22
<b>COMPONENT PARTS</b> .....	5	<b>INTERIOR ROOM LAMP</b> .....	22
Component Parts Location .....	5	Wiring Diagram .....	22
Component Description .....	5	<b>ILLUMINATION</b> .....	33
<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....	7	Wiring Diagram .....	33
System Diagram .....	7	<b>BASIC INSPECTION</b> .....	47
System Description .....	7	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	47
<b>ILLUMINATION CONTROL SYSTEM</b> .....	9	Work Flow .....	47
System Diagram .....	9	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	50
System Description .....	9	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	50
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	11	<b>BCM</b> .....	50
<b>COMMON ITEM</b> .....	11	BCM : Diagnosis Procedure .....	50
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	11	<b>IPDM E/R</b> .....	50
<b>INT LAMP</b> .....	12	IPDM E/R : Diagnosis Procedure .....	50
INT LAMP : CONSULT Function (BCM - INT LAMP) .....	12	<b>BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT</b> .....	52
<b>BATTERY SAVER</b> .....	13	Description .....	52
BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) .....	13	Component Function Check .....	52
<b>INTELLIGENT KEY</b> .....	13	Diagnosis Procedure .....	52
		<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b> .....	54
		Description .....	54

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

Component Function Check .....	54	<b>VANITY MIRROR LAMP</b> .....	64
Diagnosis Procedure .....	54	Removal and Installation .....	64
<b>STEP LAMP CIRCUIT</b> .....	<b>56</b>	Bulb or Lens Replacement .....	64
Description .....	56	<b>GLOVE BOX LAMP</b> .....	65
Component Function Check .....	56	Removal and Installation .....	65
Diagnosis Procedure .....	56	Bulb Replacement .....	65
<b>TRUNK ROOM LAMP CIRCUIT</b> .....	<b>58</b>	<b>STEP LAMP</b> .....	66
Description .....	58	Bulb or Lens Replacement .....	66
Component Function Check .....	58	<b>PERSONAL LAMP</b> .....	67
Diagnosis Procedure .....	58	Removal and Installation .....	67
<b>PUSH-BUTTON IGNITION SWITCH ILLUMI-</b>		Bulb or Lens Replacement .....	67
<b>NATION CIRCUIT</b> .....	<b>60</b>	<b>TRUNK ROOM LAMP</b> .....	68
Description .....	60	Removal and Installation .....	68
Component Function Check .....	60	Bulb Replacement .....	68
Diagnosis Procedure .....	60	<b>ILLUMINATION CONTROL SWITCH</b> .....	69
<b>SYMPTOM DIAGNOSIS</b> .....	<b>62</b>	Removal and Installation .....	69
<b>INTERIOR LIGHTING SYSTEM SYMPTOMS</b> ... <b>62</b>		<b>SERVICE DATA AND SPECIFICATIONS</b>	
Symptom Table .....	62	<b>(SDS)</b> .....	<b>70</b>
<b>REMOVAL AND INSTALLATION</b> .....	<b>63</b>	<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>FRONT ROOM/MAP LAMP</b> .....	<b>63</b>	<b>(SDS)</b> .....	<b>70</b>
Removal and Installation .....	63	Bulb Specifications .....	70
Bulb Replacement .....	63		

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000009951586

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

### Precaution for Work

INFOID:0000000009463859

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

## PREPARATION

< PREPARATION >

# PREPARATION


## PREPARATION

### Special Service Tool

INFOID:000000009463860

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— (J-46534) Trim Tool Set	Removing trim components



# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009463861



1. BCM (view with combination meter removed)
2. Front door switch LH (RH similar)
3. Rear door switch LH (RH similar)
4. Main power window and door lock/unlock switch
5. Power window and door lock/unlock switch RH
6. Trunk lamp switch and trunk release solenoid (Trunk lamp switch)
7. Front door lock assembly LH (key cylinder switch)
8. Combination switch (lighting and turn signal switch)
9. Push-button ignition switch
10. IPDM E/R (tail lamp relay)
11. Meter control switch (illumination control switch)

#### Component Description

INFOID:000000009463862

Part name	Description
BCM	The BCM monitors the combination switch (lighting and turn signal switch) position. The BCM requests via CAN communication that the IPDM E/R activate the tail lamp relay.

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >


IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication.
Push button ignition switch	Provides ignition switch status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM.
Combination switch (lighting and turn signal switch)	The combination switch (lighting and turn signal switch) provides input to the BCM. The BCM then sends a tail lamp relay request signal to the IPDM E/R via CAN communication to operate the illumination system.
Trunk lamp switch and release solenoid (trunk lamp switch)	Provides trunk lamp switch OPEN/CLOSED status to the BCM.
Power window and door lock/unlock switch RH	Provides door lock/unlock position switch RH status to the BCM.
Main power window and door lock/unlock switch	Provides door lock/unlock position switch LH status to the BCM.
Meter control switch (illumination control switch)	<ul style="list-style-type: none"><li>• Adjusts the illumination system and combination meter illumination brightness (with multiple illumination control).</li><li>• Only adjusts the combination meter illumination brightness (with meter illumination control only).</li></ul>
Front door lock assembly LH (key cylinder switch)	Provides front door lock assembly LH (key cylinder switch) door lock/unlock switch position status to the BCM.

# INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

## INTERIOR ROOM LAMP CONTROL SYSTEM

### System Diagram



### System Description

INFOID:0000000009463864

#### OUTLINE

- Front room/map lamps and personal lamps rear are controlled by the room lamp timer control function of the BCM when lamp switch is in the DOOR position.
- Front step lamps are controlled by step lamp control function of BCM.
- Trunk room lamp is controlled by trunk lamp control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.
- Interior room lamps are illuminated by the welcome light function of Intelligent Key system. Refer to [DLK-32, "WELCOME LIGHT FUNCTION : System Description"](#).

INL

#### ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position and when all conditions below are met, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with Intelligent Key, main power window and door lock/unlock switch or front door lock assembly LH (key cylinder switch)].
- When a door opens → closes.

Timer control is cancelled under the following conditions:

- When the front door LH is locked [with Intelligent Key, main power window and door lock/unlock switch or front door lock assembly LH (key cylinder switch)].
- A door is opened (door switch turns ON).
- Ignition switch is turned ON.

M

N

O

P

#### INTERIOR LAMP BATTERY SAVER CONTROL

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 15 minutes after the ignition switch is turned OFF.

## **INTERIOR ROOM LAMP CONTROL SYSTEM**

### **< SYSTEM DESCRIPTION >**

The BCM controls the following interior lamps:

- Front step lamp LH/RH
- Front room/map lamp LH/RH
- Personal lamp rear LH/RH
- Vanity mirror lamp LH/RH (if equipped)
- Trunk room lamp

After the battery saver system turns the lamps OFF, the lamps will illuminate again when:

- A signal is received from an Intelligent Key or main power window and door lock/unlock switch or when the front door lock assembly LH (key cylinder switch) is locked or unlocked.
- A door is opened or closed.

# ILLUMINATION CONTROL SYSTEM


< SYSTEM DESCRIPTION >

## ILLUMINATION CONTROL SYSTEM

### System Diagram


INFOID:0000000009463865

#### WITH MULTIPLE ILLUMINATION CONTROL



AWLIA1963GB

#### WITH METER ILLUMINATION CONTROL ONLY



AWLIA2226GB

### System Description

INFOID:0000000009463866

#### WITH MULTIPLE ILLUMINATION CONTROL

The illumination system is activated by the combination switch (lighting and turn signal switch) when the switch is placed in the 1st or 2nd position (or if the auto light system is activated).

The illumination system and combination meter illumination brightness is adjustable using the meter control switch (illumination control switch).

- The BCM (body control module) receives the parking lamp request signal from the combination switch (lighting and turn signal switch) to turn the lights on.
- The BCM sends the parking lamp request signal to the IPDM E/R (intelligent power distribution module engine room) via CAN communication.
- IPDM E/R receives the parking lamp request signal from the BCM to activate the tail lamp relay and provide power to the illumination system.

#### WITH METER ILLUMINATION CONTROL ONLY

The illumination system is activated by the combination switch (lighting and turn signal switch) when the switch is placed in the 1st or 2nd position (or if the auto light system is activated).

Only the combination meter illumination brightness is adjustable using the meter control switch (illumination control switch).

## ILLUMINATION CONTROL SYSTEM

### < SYSTEM DESCRIPTION >

- The BCM (body control module) receives the parking lamp request signal from the combination switch (lighting and turn signal switch) to turn the lights on.
- The BCM sends the parking lamp request signal to the IPDM E/R (intelligent power distribution module engine room) via CAN communication.
- IPDM E/R receives the parking lamp request signal from the BCM to activate the tail lamp relay and provide power to the illumination system.

### BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the 1st or 2nd position and the ignition switch is set from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination system remains on for 15 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination system is turned off after a 30 second delay. When the combination switch (lighting and turn signal switch) is turned from OFF to 1st or 2nd position (or if auto light system is activated) after illumination system has been turned off by the battery saver control, the illumination lights illuminate again.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000009956797

##### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"><li>• The vehicle specification can be read and saved.</li><li>• The vehicle specification can be written when replacing BCM.</li></ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Remote keyless entry system	MULTI REMOTE ENT			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Air conditioner	AIR CONDITIONER			x				
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Trunk open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

System	Sub System	Direct Diagnostic Mode					
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration
RAP system	RETAINED PWR			×			
Signal buffer system	SIGNAL BUFFER			×			
TPMS	AIR PRESSURE MONITOR		×	×	×	×	

## INT LAMP

### INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000009956798

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH -SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
TRNK/HAT MNTR [On/Off]	Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior room lamp operation [On/Off].
STEP LAMP TEST	This test is able to check step lamp operation [On/Off].

## WORK SUPPORT

#### NOTE:

The items listed below are the only applicable Work Support items for this vehicle. If other items are displayed on CONSULT, do not use or change the setting for these other items.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Support Item	Setting	Description
SCENARIO LIGHTING SETTING	On	<b>NOTE:</b> Do not use this function since interior room lamp control is changed.
	Off*	
SET I/L D-UNLCK INTCON	On	Interior room lamp timer function ON.
	Off*	Interior room lamp timer function OFF.
FOG LAMP OVERRIDE	On*	Fog lamp override function ON.
	Off	Fog lamp override function OFF.

\* : Initial setting

A

## BATTERY SAVER

### BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000009956799

B

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

C

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
TRNK/HAT MNTR [On/Off]	Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

D

## ACTIVE TEST

E

Test item	Description
BATTERY SAVER	This test is able to check battery saver operation [On/Off].

F

## INTELLIGENT KEY

G

### INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009956802

H

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

I

J

K

INL

L

M

N

O

P

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

## DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of trunk opener request switch.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
SHFTLCK SLNID PER SPLY [On/Off]	×	Indicates condition of power supply to shiftlock solenoid.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [STOP/START/CRANK/RUN]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT -RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT -RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENT CANCEL TIMER [STOP]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [STOP]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of engine crank prohibit time.
AUTO CRNK TME [sec]		Indicates condition of automatic engine crank time from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main	Description
DETE SW PWR [On/Off]		Indicates condition of detent switch voltage.
ACC RLY -REQ [On/Off]		Indicates condition of accessory relay control request.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
TRNK/HAT MNTR [On/Off]		Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]		Indicates condition of trunk open signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key identification number [Off/ID No1/ID N02/ID No3/ID No4/ID No5].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
HORN	This test is able to check horn operation [On].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
TRUNK/BACK DOOR	This test is able to check trunk actuator operation [Open].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].
PUSH SWITCH INDICATOR	This test is able to check push-button ignition switch indicator operation [On/Off].
ACC CONT	This test is able to check accessory relay control operation [On/Off].
IGN CONT1	This test is able to check ignition relay-1 control operation [On/Off].
ST CONT LOW	This test is able to check starter control relay operation [On/Off].
IGNITION RELAY	This test is able to ignition relay operation [On/Off].
REVERSE LAMP TEST	This test is able to check reverse lamp illumination operation [On/Off].
TRUNK/LUGGAGE LAMP TEST	This test is able to check cargo lamp illumination operation [On/Off].
KEYFOB PW TEST	This test is able to check power window operation using the Intelligent Key [Off/DOWN/UP].
SHIFTLOCK SOLENOID TEST	This test is able to check shift lock solenoid operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description
IGN/ACC BATTERY SAVER	On*	Battery saver function ON.
	Off	Battery saver function OFF.
REMOTE ENGINE STARTER	On*	Remote engine start function ON.
	Off	Remote engine start function OFF.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Support Item	Setting	Description	
ANSWERBACK I-KEY LOCK UNLOCK	BUZZER	Buzzer reminder function by door lock/unlock request switch ON.	
	HORN	Horn chirp reminder function by door lock request switch ON.	
	Off*	No reminder function by door lock/unlock request switch.	
	INVALID	This mode is not used.	
ANSWERBACK KEYLESS LOCK UNLOCK	On	Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.	
	Off*	No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.	
ANSWER BACK	On*	Horn chirp reminder when doors are locked with Intelligent Key.	
	Off	No horn chirp reminder when doors are locked with Intelligent Key.	
RETRACTABLE MIRROR SET	On	Retractable mirror set ON.	
	Off*	Retractable mirror set OFF.	
CONFIRM KEY FOB ID	—	Intelligent Key ID code can check.	
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock function from Intelligent Key ON.	
	Off	Door lock/unlock function from Intelligent Key OFF.	
ENGINE START BY I-KEY	On*	Engine start function from Intelligent Key ON.	
	Off	Engine start function from Intelligent Key OFF.	
TRUNK/GLASS HATCH OPEN	On*	Buzzer reminder function by trunk opener request switch ON.	
	Off	Buzzer reminder function by trunk opener request switch OFF.	
INTELLIGENT KEY LINK SET	On	Intelligent Key link set ON.	
	Off*	Intelligent Key link set OFF.	
SHORT CRANKING OUTPUT	Start	70 msec	Starter motor operation duration times.
		100 msec	
		200 msec	
	End	—	
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.	
AUTO LOCK SET	MODE7	5 min	Auto door lock time can be set in this mode.
	MODE6	4 min	
	MODE5	3 min	
	MODE4	2 min	
	MODE3*	1 min	
	MODE2	30 sec	
	MODE1	Off	

\*: Initial Setting

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:0000000009956803

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Front fog lamps
- Parking lamps
- Side marker lamps
- Tail lamps
- License plate lamps
- Daytime running lamps
- Headlamps (LO, HI)
- A/C compressor
- Cooling fans (LO, HI)

##### Operation Procedure

###### **CAUTION:**

**Do not start the engine.**

###### **NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield before hand.

###### **NOTE:**

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-100, "Component Function Check".](#)
  - When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.
1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)
  2. Turn ignition switch OFF.
  3. Turn the ignition switch ON, and within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
  4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once, and the auto active test starts.
  5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

INL


Operation sequence	Inspection Location	Operation
1	Front wiper	LO for 3 seconds → HI for 3 seconds
2	<ul style="list-style-type: none"><li>• Front fog lamps</li><li>• Parking lamps</li><li>• Side marker lamps</li><li>• Tail lamps</li><li>• License plate lamps</li></ul>	10 seconds
3	Daytime running lamps	10 seconds
4	Headlamps	LO ⇄ HI 5 times
5	A/C compressor	ON ⇄ OFF 5 times
6*	Cooling fans	LO for 5 seconds → HI for 5 seconds

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Front fog lamps • Parking lamps • Side marker lamps • License plate lamps • Tail lamps • Daytime running lamps • Headlamp (HI, LO) • Front wiper	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
Cooling fans do not operate	Perform auto active test. Do the cooling fans operate?	YES • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO • Cooling fans • Harness or connectors between cooling fans and cooling fan control module • Cooling fan control module • Harness or connectors between cooling fan relay and cooling fan control module • Cooling fan relay • Harness or connectors between IPDM E/R and cooling fan relay • IPDM E/R

## CONSULT Function (IPDM E/R)

INFOID:0000000009956804

### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

### DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main Signals	Description
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2

### ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

### CAN DIAG SUPPORT MNTR

Refer to [LAN-15, "CAN Diagnostic Support Monitor".](#)

&lt; ECU DIAGNOSIS INFORMATION &gt;

**ECU DIAGNOSIS INFORMATION****BCM, IPDM E/R****List of ECU Reference**

INFOID:000000009463873

ECU	Reference
BCM	<a href="#">BCS-31, "Reference Value"</a>
	<a href="#">BCS-50, "Fail_Safe"</a>
	<a href="#">BCS-50, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-52, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-12, "Reference Value"</a>
	<a href="#">PCS-19, "Fail_Safe"</a>
	<a href="#">PCS-20, "DTC Index"</a>

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR ROOM LAMP


< WIRING DIAGRAM >

## WIRING DIAGRAM INTERIOR ROOM LAMP

### Wiring Diagram

INFOID:0000000009463874


INTERIOR ROOM LAMP



ABLWA1764GB

# INTERIOR ROOM LAMP


< WIRING DIAGRAM >



ABLWA2249GB

# INTERIOR ROOM LAMP

< WIRING DIAGRAM >



AALWA0826GB

# INTERIOR ROOM LAMP


**< WIRING DIAGRAM >**

## INTERIOR ROOM LAMP CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
6N	W	-





Terminal No.	Color of Wire	Signal Name
74J	G	-
75J	BG	-
76J	SB	-
77J	BR	-
78J	Y	-

A      B      C      D      E      F      G      H      I      J      K      L      M      N      O      P      INL

# INTERIOR ROOM LAMP

< WIRING DIAGRAM >


Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
9	P	-
11	GR	-

Terminal No.	Color of Wire	Signal Name
13	V	-
14	SB	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3	R	-
4	G	-
8	B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
54	P	PW LIN
59	P	CANL
60	L	CANH
74	P	DOOR KEY/C LOCK SW


# INTERIOR ROOM LAMP

< WIRING DIAGRAM >

Connector No.	M19
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	GRAY



Connector No.	M21
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82	Y	RL DOOR SW
85	BG	TRUNK LAMP CONT
93	V	RR DOOR SW
94	SB	AS DOOR SW
96	BR	DR DOOR SW
97	SB	TRUNK SW


Terminal No.	Color of Wire	Signal Name
129	G	BATTERY SAVER OUT
131	W	BAT BCM FUSE
134	B	GND2
136	P	ROOM LAMP CONT
139	W	BAT POWER F/L
143	B	GND1

Terminal No.	Color of Wire	Signal Name
11	W	-
12	G	-
19	P	-
20	BG	-
21	G	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	2	5
2	3	6
3	4	7
4	5	8
5	6	9
6	7	10
7	8	11
8	9	12
9	10	-
10	11	-
11	12	-



Terminal No.	Color of Wire	Signal Name
3	G	-
4	P	-

ABLIA5196GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P


Q

R

S

# INTERIOR ROOM LAMP

**< WIRING DIAGRAM >**




ABLIA3684GB

# INTERIOR ROOM LAMP

< WIRING DIAGRAM >

Connector No.	B104
Connector Name	WIRES TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
13	V	-
14	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	BG	-

Connector No.	B36
Connector Name	TRUNK ROOM LAMP
Connector Color	WHITE



Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	L	-



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B/W	-

Connector No.	R3
Connector Name	VANITY MIRROR LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B/W	-
9	R	-
11	B	-

Terminal No.	Color of Wire	Signal Name
3	V	-

A

B

C

D

E

F

G

K

INL

M

Z

O


P

AALIA2333GB


# INTERIOR ROOM LAMP

**< WIRING DIAGRAM >**

Connector No.	R9
Connector Name	VANITY MIRROR LAMP RH
Connector Color	WHITE



Connector No.	R50
Connector Name	PERSONAL LAMP REAR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/L	-
3	L	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/L	-
3	L	-


Connector No.	R9
Connector Name	VANITY MIRROR LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
4	G	-

Terminal No.	Color of Wire	Signal Name
3	R	-
4	G	-


Connector No.	R51
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	B	-
6	R	-
7	W/L	-
8	B/W	-



Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GND	-
3	P	-
11	P	COM
15	G	UNLOCK

AALIA2334GB

# INTERIOR ROOM LAMP


< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
INL

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Connector No.	D12
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Connector No.	D11
Connector Name	FRONT STEP LAMP LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
3	G	LOCK SW
15	R	UNLOCK SW

Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

Terminal No.	Color of Wire	Signal Name
4	B	-
5	G	-
6	P	-



Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-


Terminal No.	Color of Wire	Signal Name
3	P	COM
7	B	GND

ABLIA5208GB

# INTERIOR ROOM LAMP


< WIRING DIAGRAM >

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK UNLOCK SWITCH RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Color of Wire	Signal Name
11	G	LOCK	G	-
12	W	UNLOCK	W	-
19	P	GND	P	-
20	BG		BG	-
21	G		G	-

Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA5197GB

# ILLUMINATION

< WIRING DIAGRAM >



## ILLUMINATION


### Wiring Diagram



# ILLUMINATION

< WIRING DIAGRAM >


  
  
  




ABLWA2246GB

# ILLUMINATION

## < WIRING DIAGRAM >




AALWA0825GB

# ILLUMINATION

**< WIRING DIAGRAM >**

## ILLUMINATION CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5G	W	-
22G	L	-
23G	P	-
36G	G	-




Connector No.	M2
Connector Name	JOINT CONNECTOR-M02
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	GR	-
3	B	-
4	B	-




Terminal No.	Color of Wire	Signal Name
8P	BR	-
13P	G	-




Terminal No.	Color of Wire	Signal Name
1R	R	-



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	G	-
3	W	-
4	GR	-
5	Y	-
6	BL	-
7	RD	-
8	BL	-
9	RD	-
10	Y	-
11	BL	-
12	RD	-
13	Y	-
14	BL	-
15	RD	-
16	Y	-
17	BL	-
18	RD	-
19	Y	-
20	BL	-
21	RD	-
22	Y	-
23	BL	-
24	RD	-
25	Y	-
26	BL	-
27	RD	-
28	Y	-
29	BL	-
30	RD	-




Terminal No.	Color of Wire	Signal Name
1R	R	-



# ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	B	-
10	R	-


Terminal No.	Color of Wire	Signal Name
3	GR	-
5	R	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
10	W	COMBI SW IN 5
11	BG	COMBI SW IN 4
12	W	COMBI SW IN 3
13	G	COMBI SW IN 2
14	P	COMBI SW IN 1


Terminal No.	Color of Wire	Signal Name
10	W	COMBI SW IN 5
11	BG	COMBI SW IN 4
12	W	COMBI SW IN 3
13	G	COMBI SW IN 2
14	P	COMBI SW IN 1



Terminal No.	Color of Wire	Signal Name
107	W	LOW SIDE START SW LED

Terminal No.	Color of Wire	Signal Name
48	BR	HIGH SIDE START SW LED
59	P	CAN-L
60	L	CAN-H
70	G	IGN USM OUT 1
75	BG	COMBI SW OUT 5
76	W	COMBI SW OUT 4
77	R	COMBI SW OUT 3
78	P	COMBI SW OUT 2
79	G	COMBI SW OUT 1

Terminal No.	Color of Wire	Signal Name
48	BR	HIGH SIDE START SW LED
59	P	CAN-L
60	L	CAN-H
70	G	IGN USM OUT 1
75	BG	COMBI SW OUT 5
76	W	COMBI SW OUT 4
77	R	COMBI SW OUT 3
78	P	COMBI SW OUT 2
79	G	COMBI SW OUT 1



ABLIA5179GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
INL  
INL

# ILLUMINATION

**< WIRING DIAGRAM >**

---

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND1	42	SB	ILLUMI DOWN SW
2	B	GND2	47	Y	ILLUMI UP SW
21	BR	IGN	48	G	SW GND
22	G	BAT			
23	GR	ILLUMI CONT OUT			
38	P	CAN-L			
39	L	CAN-H			


Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1

Terminal No.	Color of Wire	Signal Name
42	SB	ILLUMI DOWN SW
47	Y	ILLUMI UP SW
48	G	SW GND



Terminal No.	Color of Wire	Signal Name
9	P	-
10	W	-
11	G	-
12	P	-
13	EG	-
14	G	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	R	-
26	B	-


ABLIA5180GB

# ILLUMINATION


< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
INL


Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE



Connector No.	M43
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO SYSTEM WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE




Connector No.	M37
Connector Name	FRONT AIR CONTROL (WITHOUT AUTO A/C)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	BR	ILL+
6	W	ILL-

Connector No.	M54
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	GR	ILL (-)
9	R	ILL (+), LIGHT SW

Connector No.	M51
Connector Name	HEATED STEERING WHEEL SWITCH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
3	R	ILL (-)
4	GR	ILL (+), LIGHT SW

Connector No.	M45
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO SYSTEM AND BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	GR	ILL (-)
9	R	ILL (+), LIGHT SW


# ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	GRAY




Connector No.	M64
Connector Name	JOINT CONNECTOR-M01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	R	-
3	R	-
4	R	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	R	-
3	R	-
4	R	-


Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	GREEN



Connector No.	M73
Connector Name	USB INTERFACE LAMP
Connector Color	WHITE



Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	GREEN




Connector No.	M73
Connector Name	USB INTERFACE LAMP
Connector Color	WHITE




Connector No.	M72
Connector Name	VDC OFF SWITCH
Connector Color	BLACK



Connector No.	M72
Connector Name	VDC OFF SWITCH
Connector Color	BLACK




Connector No.	M75
Connector Name	TRUNK LID OPENER SWITCH
Connector Color	GREEN



# ILLUMINATION

< WIRING DIAGRAM >


Connector No.	M79
Connector Name	A/C SWITCH ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	—
6	GR	—


Terminal No.	Color of Wire	Signal Name
1	W	—
2	GR	—

Connector No.	M80
Connector Name	DIODE-3
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	GR	ILLUMINATION GND
9	R	ILL+, LIGHT SW


Terminal No.	Color of Wire	Signal Name
8	GR	ILLUMINATION GND
9	R	ILL+, LIGHT SW



Terminal No.	Color of Wire	Signal Name
9	R	ILL (+), LIGHT SW
—	—	—

Terminal No.	Color of Wire	Signal Name
9	R	ILL (+), LIGHT SW
—	—	—

Terminal No.	Color of Wire	Signal Name
8	GR	ILLUMINATION GND
9	R	ILL+, LIGHT SW



Terminal No.	Color of Wire	Signal Name
9	R	ILL (+), LIGHT SW
—	—	—

Terminal No.	Color of Wire	Signal Name
3	L	—
4	L	—

Terminal No.	Color of Wire	Signal Name
19	Y	—
20	R	—

ABLIA5183GB

A

B

D

E

G

I

J

K

L

M

N

O

Z

P

R


S

T


# ILLUMINATION

**< WIRING DIAGRAM >**


---

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE
Connector	

Terminal No.	Color of Wire	Signal Name
19	GR	ILL (-)
20	R	-

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE
Connector	

Terminal No.	Color of Wire	Signal Name
33	GR	ILL (-)
		-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE
Connector	

Terminal No.	Color of Wire	Signal Name
33	GR	ILL (-)
		-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

ABLIA5184GB

# ILLUMINATION


< WIRING DIAGRAM >

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M201
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	G	-(FOR MEXICO)
2	B	-(EXCEPT MEXICO)
4	G	-
6	Y	-
7	SB	-


Terminal No.	Color of Wire	Signal Name
5	R	-
6	B	-




Connector No.	M204
Connector Name	CVT SHIFT SELECTOR
Connector Color	BROWN



Connector No.	M202
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3	B	-
5	R	-



Connector No.	INL-43
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE

ABLIA5185GB

A

B

C

D

E

F

G

H

K

M

Z

O


P

INL


# ILLUMINATION

**< WIRING DIAGRAM >**

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY




Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
10	V	TAIL LH

Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-




Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6M	V	-

Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
10	V	TAIL LH


Terminal No.	Color of Wire	Signal Name
1	P	-
5	P	-



# ILLUMINATION

**< WIRING DIAGRAM >**

Connector No.	E63
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE
	




Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	CAN-L
10	L	CAN-H
41	B	GND (SIGNAL)
43	LG	IGN SIGNAL

Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/L	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/L	-



Terminal No.	Color of Wire	Signal Name
11	R	-
12	G	-

Terminal No.	Color of Wire	Signal Name
1	SB	-
2	W/R	-

AALIA2332GB

A

B

C

D

E

F

G

H

K

M

Z

O

P


INL

# ILLUMINATION


< WIRING DIAGRAM >

---

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D52
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	R	-
12	G	-

Terminal No.	Color of Wire	Signal Name
13	G	-
14	R	-

ABLIA5188GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009463876

#### OVERALL SEQUENCE



AWLIA1837GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

## DETAILED FLOW

### 1. INTERVIEW FOR MALFUNCTION

---

Find out what the customer's concerns are.

>> GO TO 2.

### 2. SYMPTOM CHECK

---

Verify the symptom from the customer's information.

>> GO TO 3.

### 3. BASIC INSPECTION

---

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

### 4. SELF-DIAGNOSIS WITH CONSULT

---

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

### 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

### 6. FAIL-SAFE ACTIVATION CHECK

---

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

### 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

### 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis, refer to [INL-62, "Symptom Table"](#). Specify the malfunctioning part.

>> GO TO 9.

### 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

### 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

---

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES    >> GO TO 5.  
NO    >> GO TO 11.

A

### 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

B

Does it operate normally?

YES    >> Inspection End  
NO    >> GO TO 3.

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:0000000009956807

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

#### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.

2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

#### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

IPDM E/R

IPDM E/R : Diagnosis Procedure

INFOID:0000000009956808

Regarding Wiring Diagram information, refer to [PCS-21, "Wiring Diagram"](#).

#### 1. CHECK FUSIBLE LINKS

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Check that the following fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Fusible link main	E (80A)
2	Fusible link IPDM E/R	A (250A), C (80A)
3	Fusible link ignition switch	A (250A), B (100A), M (40A)

### Is the fusible link blown?

- YES >> Replace the blown fusible link after repairing the affected circuit.  
NO >> GO TO 2

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E16 and E17.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E16	1	—	Battery voltage
	2		
E17	3	—	—

### Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E18 and E63.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E18	7	—	Yes
E63	41	—	—

### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

### Description

INFOID:0000000009463879

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

### Component Function Check

INFOID:0000000009463880

#### 1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

##### ④ CONSULT

1. Turn ignition switch ON.
2. Turn each interior room lamp ON.
  - Front room/map lamps
  - Personal lamps rear
  - Front step lamps
  - Vanity mirror lamps (if equipped)
  - Trunk room lamp
3. Open the driver door to turn ON the front step lamps.
4. Select BATTERY SAVER of BCM (BATTERY SAVER) active test item.
5. While operating the test item, check that each interior room lamp turn ON/OFF.

**OFF** : Interior room lamp OFF

**ON** : Interior room lamp ON

##### Is the inspection result normal?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-52, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000009463881

Regarding Wiring Diagram information, refer to [INL-22, "Wiring Diagram"](#).

#### 1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

##### ④ CONSULT

1. Turn ignition switch ON.
2. Select BATTERY SAVER of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M21 terminal 129 and ground.

Connector	Terminal	( - )	Test item	Voltage (Approx.)
			BATTERY SAVER	
M21	129	Ground	OFF	0V
			ON	Battery voltage

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM after making sure battery saver output/power supply circuit is not shorted to voltage. Refer to [BCS-80, "Removal and Installation"](#).

#### 2. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
  - BCM M21
  - Front step lamp LH D11
  - Front step lamp RH D109
  - Front room/map lamp assembly R51

## BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

- Vanity mirror lamp LH (if equipped) R3
  - Vanity mirror lamp RH (if equipped) R9
  - Trunk room lamp B36
  - Personal lamp rear R50
3. Check continuity between BCM connector M21 terminal 129 and each interior room lamp connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M21	129	Front step lamp LH	D11	1
		Front step lamp RH	D109	1
		Front room/map lamp assembly	R51	1
		Vanity mirror lamp LH	R3	2
		Vanity mirror lamp RH	R9	2
		Trunk room lamp	B36	1
		Personal lamp rear	R50	3

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM connector M21 terminal 129 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	129		No

Is the inspection result normal?

YES >> Check that each interior room lamp has no internal short circuit.

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:0000000009463882

Controls the room lamp control circuit (ground side) to turn the room lamps ON and OFF.

### Component Function Check

INFOID:0000000009463883

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Front room/map lamp assembly bulbs
- Personal lamp bulbs

#### 1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

##### ④CONSULT

1. Switch the front room/map lamp assembly switch to DOOR.
2. Turn ignition switch ON.
3. Select INT LAMP of BCM (INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turn ON/OFF.

ON : Interior room lamp ON

OFF : Interior room lamp OFF

Is the inspection result normal?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-54. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000009463884

Regarding Wiring Diagram information, refer to [INL-22. "Wiring Diagram"](#).

#### 1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

##### ④CONSULT

1. Turn ignition switch ON.
2. Select INT LAMP of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M21 terminal 136 and ground.

BCM		Ground	Test item	Voltage
Connector	Terminal		INT LAMP	
M21	136		ON	0V
			OFF	Battery voltage

Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>>GO TO 3.

Fixed OFF>>GO TO 2.

#### 2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M21, front room/map lamp harness connector R51.
3. Check continuity between BCM harness connector M21 terminal 136 and front room/map lamp assembly harness connector R51 terminal 6.

## INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Front room/map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M21	136	R51	6	Yes

4. Reconnect the front room/map lamp assembly harness connector.
5. Check continuity between BCM harness connector M21 terminal 136 and personal lamp rear harness connector R50 terminal 2.

BCM		Personal lamp rear		Continuity
Connector	Terminal	Connector	Terminal	
M21	136	R50	2	Yes

Is the inspection result normal?

YES    >> Check interior room lamps for an open. If NG, replace lamp in question. Refer to [INL-63, "Removal and Installation"](#) (front room/map lamp assembly) or refer to [INL-67, "Removal and Installation"](#) (personal lamp rear). If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO    >> Repair or replace harness or connectors.

### 3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M21 and front room/map lamp harness connector R51 lamp harness.
3. Check continuity between BCM harness connector M21 terminal 136 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	136		No

Is the inspection result normal?

YES    >> Check the interior room lamps for a short circuit. If NG, replace the interior room lamp. Refer to [INL-63, "Removal and Installation"](#) (front room/map lamp assembly) or refer to [INL-67, "Removal and Installation"](#) (personal lamp rear). If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO    >> Repair or replace the harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## STEP LAMP CIRCUIT

### Description

INFOID:0000000009463885

Controls the step lamp control circuit (ground side) to turn the step lamp ON and OFF.

### Component Function Check

INFOID:0000000009463886

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Step lamp bulbs

#### 1. CHECK STEP LAMP OPERATION

##### CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP of BCM (INT LAMP) active test item.
3. While operating the test item, check that step lamps turn ON/OFF.

**ON** : Step lamp ON

**OFF** : Step lamp OFF

##### Is the inspection result normal?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-56, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000009463887

Regarding Wiring Diagram information, refer to [INL-22, "Wiring Diagram"](#).

#### 1. CHECK STEP LAMP OUTPUT

##### CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP TEST of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M17 terminal 21 and ground.

BCM		Ground	Test item	Voltage	
Connector	Terminal		STEP LAMP TEST		
M17	21		ON		
			OFF		

##### Is the inspection result normal?

YES >> Step lamp circuit is operating normally.

Fixed ON>> GO TO 3.

Fixed OFF>> GO TO 2.

#### 2. CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M17 and step lamp LH and RH connectors.
3. Check continuity between BCM connector M17 terminal 21 and step lamp connector terminal 2.

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M17	21	LH	D11	2	
		RH	D109	Yes	

## STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Check the step lamps for an open. If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#). If NG, replace the step lamp. Refer to [INL-66, "Bulb or Lens Replacement"](#).

NO      >> Repair or replace harness or connectors.

### 3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M17 and step lamp LH and RH connectors.
3. Check continuity between BCM connector M17 terminal 21 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	21		No

Is the inspection result normal?

YES    >> Check the step lamps for a short circuit. If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#). If NG, replace the interior room lamp. Refer to [INL-66, "Bulb or Lens Replacement"](#).

NO      >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK ROOM LAMP CIRCUIT

### Description

INFOID:0000000009463888

Controls the trunk room lamp (ground side) to turn the trunk room lamp ON and OFF.

### Component Function Check

INFOID:0000000009463889

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Trunk room lamp bulb

#### 1. CHECK TRUNK ROOM LAMP OPERATION

##### CONSULT

1. Turn ignition switch ON.
2. Select TRUNK/LUGGAGE LAMP TEST of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check that the trunk room lamp turns ON/OFF.

**ON : Trunk room lamp ON**

**OFF : Trunk room lamp OFF**

##### Is the inspection result normal?

YES >> Trunk room lamp circuit is normal.

NO >> Refer to [INL-58, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000009463890

Regarding Wiring Diagram information, refer to [INL-22, "Wiring Diagram"](#).

#### 1. CHECK TRUNK ROOM LAMP OUTPUT

##### CONSULT

1. Turn ignition switch ON.
2. Select TRUNK/LUGGAGE LAMP TEST of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check voltage between BCM connector M19 terminal 85 and ground.

BCM		Ground	Test item	Voltage	
Connector	Terminal		TRUNK/LUGGAGE LAMP TEST		
M19	85		ON	0V	
			OFF	Battery voltage	

##### Is the inspection result normal?

YES >> Trunk room lamp circuit is operating normally.

Fixed ON>> GO TO 3.

Fixed OFF>> GO TO 2.

#### 2. CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M19 and trunk room lamp connector.
3. Check continuity between BCM connector M19 terminal 85 and trunk room lamp connector B36 terminal 2.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M19	85	B36	2	Yes

## TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Check the trunk room lamp for an open. If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#). If NG, replace the trunk room lamp. Refer to [INL-68, "Removal and Installation"](#).

NO      >> Repair or replace harness or connectors.

### 3.CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M19 and trunk room lamp connector.
3. Check continuity between BCM connector M19 terminal 85 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	85		No

Is the inspection result normal?

YES    >> Check the trunk room lamp for a short circuit. If OK, replace BCM. Refer to [BCS-80, "Removal and Installation"](#). If NG, replace the trunk room lamp. Refer to [INL-68, "Removal and Installation"](#).

NO      >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:0000000009463891

Provides the power supply and the ground to control the push-button ignition switch illumination.

### Component Function Check

INFOID:0000000009463892

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

##### CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check that the push-button ignition switch illumination turns ON/OFF

**ON** : Push-button ignition switch illumination ON

**OFF** : Push-button ignition switch illumination OFF

##### Is the inspection result normal?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-60, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000009463893

Regarding Wiring Diagram information, refer to [INL-33, "Wiring Diagram"](#).

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

##### CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check voltage between push-button ignition switch connector M38 terminal 5 and ground.

Terminals		Test item	Voltage
(+)	(-)		
Push-button ignition switch		ENGINE SW ILLUMI	
Connector	Terminal		
M38	5	ON	5 V
		OFF	0 V

##### Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

#### 2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector M18 and push-button ignition switch connector.
3. Check continuity between BCM connector M18 terminal 48 and push-button ignition switch connector M38 terminal 5.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	48	M38	5	Yes

##### Is the inspection result normal?

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3

NO >> Repair or replace the harness or connectors.

## 3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM connector M18 terminal 48 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	48		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

## 4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF

2. Disconnect push-button ignition switch connector.

3. Check continuity between push-button ignition switch connector M38 terminal 6 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M38	6		Yes

Is the inspection result normal?

YES >> Replace push-button ignition switch.

NO >> GO TO 5

## 5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND OPEN CIRCUIT

1. Disconnect BCM connector M20.

2. Check continuity between BCM connector M20 terminal 107 and push-button ignition switch connector M38 terminal 6.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M20	107	M38	6	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000009463894

##### CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none"><li>• Front room/map lamp LH/RH</li><li>• Personal lamp rear LH/ RH</li><li>• Trunk room lamp</li><li>• Front step lamp LH/RH</li><li>• Vanity mirror lamp LH/RH (if equipped)</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and each interior room lamp</li><li>• BCM</li></ul>	Battery saver output/power supply circuit Refer to <a href="#">INL-52</a> .
<ul style="list-style-type: none"><li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li><li>• Interior room lamp does not turn OFF even though the door is closed.</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and each door switch</li><li>• Harness between BCM and each interior room lamp</li><li>• BCM</li></ul>	Door switch circuit Refer to <a href="#">DLK-100</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Interior room lamp control circuit Refer to <a href="#">INL-54</a> .
Front step lamps do not turn ON. (The front room/map lamps and the personal lamps turn ON.)	<ul style="list-style-type: none"><li>• Harness between BCM and each step lamp</li><li>• BCM</li></ul>	Step lamp circuit Refer to <a href="#">INL-56</a> .
Front step lamps do not turn OFF. (The front room/map lamps and the personal lamps turn OFF.)	<ul style="list-style-type: none"><li>• Harness between BCM and trunk room lamp switch</li><li>• Harness between BCM and trunk room lamp</li><li>• BCM</li></ul>	Trunk room lamp switch circuit Refer to <a href="#">DLK-126</a> .
<ul style="list-style-type: none"><li>• Trunk room lamp does not turn ON. (The bulb is normal.)</li><li>• Trunk room lamp does not turn OFF.</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and trunk room lamp switch</li><li>• Harness between BCM and trunk room lamp</li><li>• BCM</li></ul>	Trunk room lamp circuit Refer to <a href="#">INL-58</a> .
<ul style="list-style-type: none"><li>• Push-button ignition switch illumination does not turn ON.</li><li>• Push-button ignition switch illumination does not turn OFF.</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and combination switch (lighting and turn signal switch) input circuit</li><li>• Harness between BCM and push-button ignition switch</li><li>• BCM</li></ul>	Combination switch (lighting and turn signal switch) input circuit Refer to <a href="#">BCS-79</a> .
Interior room lamp battery saver does not activate.	—	Push-button ignition switch illumination circuit Refer to <a href="#">INL-60</a> .
	—	Check the interior room lamp battery saver setting. Refer to <a href="#">BCS-26</a> .

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### FRONT ROOM/MAP LAMP

#### Removal and Installation


INFOID:000000009463895

#### REMOVAL

1. Lower front edge of front room/map lamp assembly (1) down from the headlining by releasing the metal clips, then slide forward to clear pawls at rear.

Metal clip

Pawl



2. Disconnect the harness connectors from the front room/map lamp assembly and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

#### Bulb Replacement

INFOID:000000009463896

The front room/map lamp LED bulbs are serviced as an assembly. Refer to [INL-63, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

J

K

INL

M

N

O

P

# VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

## VANITY MIRROR LAMP

### Removal and Installation

INFOID:0000000009463897

#### CAUTION:

Do not attempt to separate the vanity mirror lamp from the sun visor or damage to the components may occur.

The vanity mirror lamp is replaced as part of the sun visor. Refer to [INT-30, "Removal and Installation"](#).

### Bulb or Lens Replacement

INFOID:0000000009463898

#### WARNING:

Do not touch bulb while it is lit or right after being turned OFF. Burning may result.


#### CAUTION:

- Do not attempt to separate the vanity mirror lamp from the sun visor or damage to the components may occur.
- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

1. Release the pawls on the vanity mirror lamp lens (1) using a suitable tool.

(○): Pawl

2. Remove the bulb (A) using a suitable tool.



3. Install bulb to vanity mirror lamp.

4. Install the vanity mirror lamp lens.

# GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

## GLOVE BOX LAMP

### Removal and Installation

INFOID:0000000009463899

#### **WARNING:**


Do not touch bulb while it is lit or right after being turned OFF. Burning may result.

#### **CAUTION:**

Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

#### REMOVAL

1. Remove the glove box assembly (1). Refer to [IP-22, "Removal and Installation"](#).
2. Rotate the glove box lamp socket assembly (2) counterclockwise and remove.



#### INSTALLATION

1. Insert bulb socket into glove box assembly and rotate clockwise to lock in position.
2. Install glove box assembly. Refer to [IP-22, "Removal and Installation"](#).

#### Bulb Replacement

INFOID:0000000009463900

The glove box lamp bulb is serviced as part of the glove box lamp socket. Refer to [INL-65, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

K

INL

M

N

O

P

## STEP LAMP

< REMOVAL AND INSTALLATION >

### STEP LAMP

#### Bulb or Lens Replacement

INFOID:000000009463901


##### **WARNING:**

Do not touch bulb while it is lit or right after being turned OFF. Burning may result.

##### **CAUTION:**

Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

1. Release the front step lamp pawls using a suitable tool and remove.
2. Disconnect the harness connector (A) from the front step lamp (1).
3. Remove front step lamp bulb (B).



4. Install the front step lamp bulb.
5. Connect the harness connector to the front step lamp.
6. Install the front step lamp.

# PERSONAL LAMP

< REMOVAL AND INSTALLATION >

## PERSONAL LAMP

### Removal and Installation

INFOID:0000000009463902

#### CAUTION:

Do not attempt to separate the personal lamp rear from the headlining or damage to the components may occur.

The personal lamp rear is replaced as part of the headlining. Refer to [INT-30, "Removal and Installation"](#).

### Bulb or Lens Replacement

INFOID:0000000009463903


#### WARNING:

Do not touch bulb while it is lit or right after being turned OFF. Burning may result.

#### CAUTION:

Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

1. Using a suitable tool, release the pawls and remove lens (2) from the personal lamp rear (1).
2. Remove personal lamp rear bulb (A).



3. Install personal lamp bulb to personal lamp rear.
4. Install the personal lamp rear lens.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# TRUNK ROOM LAMP

< REMOVAL AND INSTALLATION >

## TRUNK ROOM LAMP

### Removal and Installation

INFOID:0000000009463904


#### **WARNING:**

Do not touch bulb while it is lit or right after being turned OFF. Burning may result.

#### **CAUTION:**

Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

1. Release the tab (B) to open the lens.  
↳ Front
2. Remove the trunk room bulb (2).
3. Release tab (C), then pull trunk room lamp (1) down to remove.
4. Disconnect the harness connector (A) from the trunk room lamp and remove.



### INSTALLATION

Installation is in the reverse order of removal.

### Bulb Replacement

INFOID:0000000009463905

#### **WARNING:**

Do not touch bulb while it is lit or right after being turned OFF. Burning may result.

#### **CAUTION:**

Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.

1. Release the tab to open the lens.
2. Remove bulb from trunk room lamp.
3. Install bulb to trunk room lamp.
4. Close lens.

# ILLUMINATION CONTROL SWITCH

< REMOVAL AND INSTALLATION >


## ILLUMINATION CONTROL SWITCH

### Removal and Installation

INFOID:0000000009463906

#### REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-21, "Removal and Installation"](#).
2. Remove screws (➡) and remove illumination control (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

# **SERVICE DATA AND SPECIFICATIONS (SDS)**

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

### Bulb Specifications

INFOID:000000009463907

Item	Wattage (W)*
Front room/map lamp	LED
Vanity mirror lamp	-
Glove box lamp	-
Front step lamp	3.8
Personal lamp rear	8
Trunk room lamp	3.4

\* Always check with the Parts Department for the latest parts information.