

# PCS

## SECTION

### POWER CONTROL SYSTEM

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

## CONTENTS

<p style="text-align: center;"><b>IPDM E/R</b></p> <p><b>PRECAUTION</b> ..... 3</p> <p><b>PRECAUTIONS</b> ..... 3</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....3</p> <p style="padding-left: 20px;">Precaution for Procedure without Cowl Top Cover.....3</p> <p><b>SYSTEM DESCRIPTION</b> ..... 4</p> <p><b>COMPONENT PARTS</b> ..... 4</p> <p style="padding-left: 20px;">Component Parts Location .....4</p> <p><b>SYSTEM</b> ..... 5</p> <p><b>RELAY CONTROL SYSTEM</b> .....5</p> <p style="padding-left: 20px;">RELAY CONTROL SYSTEM : System Diagram .....5</p> <p style="padding-left: 20px;">RELAY CONTROL SYSTEM : System Description .....6</p> <p><b>POWER CONSUMPTION CONTROL SYSTEM</b> .....6</p> <p style="padding-left: 20px;">POWER CONSUMPTION CONTROL SYSTEM : System Diagram .....7</p> <p style="padding-left: 20px;">POWER CONSUMPTION CONTROL SYSTEM : System Description .....7</p> <p><b>DIAGNOSIS SYSTEM (IPDM E/R)</b> ..... 8</p> <p style="padding-left: 20px;">Diagnosis Description .....8</p> <p style="padding-left: 20px;">CONSULT Function (IPDM E/R) .....9</p> <p><b>ECU DIAGNOSIS INFORMATION</b> .....12</p> <p><b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....12</p> <p style="padding-left: 20px;">Reference Value ..... 12</p> <p style="padding-left: 20px;">Fail Safe ..... 19</p> <p style="padding-left: 20px;">DTC Index .....20</p> <p><b>WIRING DIAGRAM</b> .....21</p>	<p><b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....21</p> <p style="padding-left: 20px;">Wiring Diagram .....21</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> .....27</p> <p><b>U1000 CAN COMM CIRCUIT</b> .....27</p> <p style="padding-left: 20px;">Description .....27</p> <p style="padding-left: 20px;">DTC Logic .....27</p> <p style="padding-left: 20px;">Diagnosis Procedure .....27</p> <p><b>U1010 CONTROL UNIT (CAN)</b> .....28</p> <p style="padding-left: 20px;">DTC Logic .....28</p> <p style="padding-left: 20px;">Diagnosis Procedure .....28</p> <p><b>B2098 IGNITION RELAY ON STUCK</b> .....29</p> <p style="padding-left: 20px;">DTC Logic .....29</p> <p style="padding-left: 20px;">Diagnosis Procedure .....29</p> <p><b>B2099 IGNITION RELAY OFF STUCK</b> .....30</p> <p style="padding-left: 20px;">DTC Logic .....30</p> <p style="padding-left: 20px;">Diagnosis Procedure .....30</p> <p><b>POWER SUPPLY AND GROUND CIRCUIT</b> ....31</p> <p style="padding-left: 20px;">Diagnosis Procedure .....31</p> <p><b>REMOVAL AND INSTALLATION</b> .....32</p> <p><b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....32</p> <p style="padding-left: 20px;">Removal and Installation .....32</p> <p style="text-align: center;"><b>POWER DISTRIBUTION SYSTEM</b></p> <p><b>PRECAUTION</b> .....33</p> <p><b>PRECAUTIONS</b> .....33</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....33</p> <p style="padding-left: 20px;">Precaution for Work .....33</p> <p><b>PREPARATION</b> .....34</p>
---	--

<b>PREPARATION</b> .....	<b>34</b>	<b>B2615 BLOWER RELAY CIRCUIT</b> .....	<b>62</b>
Special Service Tool .....	34	DTC Logic .....	62
<b>SYSTEM DESCRIPTION</b> .....	<b>35</b>	Diagnosis Procedure .....	62
<b>COMPONENT PARTS</b> .....	<b>35</b>	Component Inspection (Relay) .....	63
Component Parts Location .....	35	<b>B2616 IGNITION RELAY CIRCUIT</b> .....	<b>64</b>
<b>SYSTEM</b> .....	<b>36</b>	DTC Logic .....	64
<b>POWER DISTRIBUTION SYSTEM</b> .....	<b>36</b>	Diagnosis Procedure .....	64
POWER DISTRIBUTION SYSTEM : System Dia-		Component Inspection (Relay) .....	65
gram .....	36	<b>B2618 BCM</b> .....	<b>66</b>
POWER DISTRIBUTION SYSTEM : System De-		DTC Logic .....	66
scription .....	36	Diagnosis Procedure .....	66
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	<b>38</b>	<b>B261A PUSH-BUTTON IGNITION SWITCH</b> ....	<b>68</b>
<b>COMMON ITEM</b> .....	<b>38</b>	DTC Logic .....	68
COMMON ITEM : CONSULT Function (BCM -		Diagnosis Procedure .....	68
COMMON ITEM) .....	38	<b>B26F1 IGNITION RELAY</b> .....	<b>70</b>
<b>INTELLIGENT KEY</b> .....	<b>39</b>	DTC Logic .....	70
INTELLIGENT KEY : CONSULT Function (BCM -		Diagnosis Procedure .....	70
INTELLIGENT KEY) .....	39	<b>B26F2 IGNITION RELAY</b> .....	<b>72</b>
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>43</b>	DTC Logic .....	72
<b>BCM, IPDM E/R</b> .....	<b>43</b>	Diagnosis Procedure .....	72
List of ECU Reference .....	43	<b>B26F6 BCM</b> .....	<b>74</b>
<b>WIRING DIAGRAM</b> .....	<b>44</b>	DTC Logic .....	74
<b>POWER DISTRIBUTION SYSTEM</b> .....	<b>44</b>	Diagnosis Procedure .....	74
Wiring Diagram .....	44	<b>PUSH-BUTTON IGNITION SWITCH</b> .....	<b>76</b>
<b>BASIC INSPECTION</b> .....	<b>53</b>	Component Function Check .....	76
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>53</b>	Diagnosis Procedure .....	76
Work Flow .....	53	Component Inspection .....	77
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>56</b>	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	<b>79</b>
<b>U1000 CAN COMM CIRCUIT</b> .....	<b>56</b>	<b>BCM</b> .....	<b>79</b>
Description .....	56	BCM : Diagnosis Procedure .....	79
DTC Logic .....	56	<b>IPDM E/R (INTELLIGENT POWER DISTRIBU-</b>	
Diagnosis Procedure .....	56	<b>TION MODULE ENGINE ROOM)</b> .....	<b>79</b>
<b>U1010 CONTROL UNIT (CAN)</b> .....	<b>57</b>	IPDM E/R (INTELLIGENT POWER DISTRIBU-	
DTC Logic .....	57	TION MODULE ENGINE ROOM) : Diagnosis Pro-	
Diagnosis Procedure .....	57	cedure .....	79
<b>B260A IGNITION RELAY</b> .....	<b>58</b>	<b>SYMPTOM DIAGNOSIS</b> .....	<b>81</b>
DTC Logic .....	58	<b>PUSH-BUTTON IGNITION SWITCH DOES</b>	
Diagnosis Procedure .....	58	<b>NOT OPERATE</b> .....	<b>81</b>
<b>B2614 ACC RELAY CIRCUIT</b> .....	<b>60</b>	Description .....	81
DTC Logic .....	60	Diagnosis Procedure .....	81
Diagnosis Procedure .....	60	<b>REMOVAL AND INSTALLATION</b> .....	<b>82</b>
Component Inspection (Relay) .....	61	<b>BCM (BODY CONTROL MODULE)</b> .....	<b>82</b>
		Removal and Installation .....	82
		<b>PUSH BUTTON IGNITION SWITCH</b> .....	<b>83</b>
		Exploded View .....	83
		Removal and Installation .....	83

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009951596

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000009461595

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P


< SYSTEM DESCRIPTION >

# SYSTEM DESCRIPTION

## COMPONENT PARTS

### Component Parts Location

INFOID:000000009461596



1. IPDM E/R

# SYSTEM

< SYSTEM DESCRIPTION >


[IPDM E/R]

## SYSTEM

### RELAY CONTROL SYSTEM

### RELAY CONTROL SYSTEM : System Diagram

INFOID:000000009461597



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# SYSTEM

< SYSTEM DESCRIPTION >

[IPDM E/R]

## RELAY CONTROL SYSTEM : System Description

INFOID:000000009461598

IPDM E/R activates the internal control circuit to perform the relay ON-OFF control according to the input signals from various sensors and the request signals received from control units via CAN communication.

**CAUTION:**

**IPDM E/R integrated relays cannot be removed.**

Control relay	Input/output	Transmit unit	Control part	Reference page
Front fog lamp relay	Front fog lamp request signal	BCM (CAN)	Front fog lamp	<a href="#">EXL-101</a>
Headlamp high relay	High beam request signal	BCM (CAN)	Headlamp high	<a href="#">EXL-91</a>
Headlamp low relay	Low beam request signal	BCM (CAN)	Headlamp low	<a href="#">EXL-93</a> (halogen) <a href="#">EXL-94</a> (xenon)
Tail lamp relay	Position light request signal	BCM (CAN)	<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• Side marker lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> </ul>	<a href="#">EXL-103</a>
<ul style="list-style-type: none"> <li>• Front wiper relay</li> <li>• Front wiper high relay</li> </ul>	Front wiper request signal Front wiper auto stop signal	BCM (CAN) Front wiper motor	Front wiper	<a href="#">WW-48</a>
Cooling fan relay-1	Cooling fan request signal	ECM	Cooling fan	<a href="#">EC-499</a> (QR25DE) <a href="#">EC-953</a> (VQ35DE)
A/C relay	A/C compressor request signal	ECM (CAN)	A/C compressor	<a href="#">HAC-87</a> (automatic air conditioner) <a href="#">HAC-151</a> (manual air conditioner)
Ignition relay-1	Ignition switch ON signal	BCM (CAN)	Ignition relay-1	<a href="#">PCS-58</a>
	Vehicle speed signal	Combination meter (CAN)		
	Push-button ignition switch	Push-button ignition switch		
Fuel pump relay	Fuel pump request signal	ECM	Fuel pump	<a href="#">EC-508</a> (QR25DE) <a href="#">EC-965</a> (VQ35DE)
ECM relay	ECM relay control signal	ECM	ECM relay	<a href="#">EC-203</a> (QR25DE) <a href="#">EC-709</a> (VQ35DE)
Throttle control motor relay	Throttle control motor relay signal	ECM	Throttle control motor relay	<a href="#">EC-475</a> (QR25DE) <a href="#">EC-933</a> (VQ35DE)
Starter relay	Starter relay control signal	BCM	Starter motor	<a href="#">PCS-12</a>
Starter control relay				

## POWER CONSUMPTION CONTROL SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

[IPDM E/R]

## POWER CONSUMPTION CONTROL SYSTEM : System Diagram

INFOID:000000009461599



## POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000009461600

### OUTLINE

- IPDM E/R incorporates a power consumption control function that reduces the power consumption according to the vehicle status.
- IPDM E/R changes its status (control mode) with the sleep wake up signal received from BCM via CAN communication.

#### Normal mode (wake-up)

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.

#### Low power consumption mode (sleep)

- Low power consumption control is active.
- CAN transmission is stopped.

### SLEEP MODE ACTIVATION

- IPDM E/R judges that the sleep-ready conditions are fulfilled when the ignition switch is OFF and none of the conditions below are present. Then it transmits a sleep-ready signal (ready) to BCM via CAN communication.
  - Front wiper fail-safe operation
  - Outputting signals to actuators
  - Switches or relays operating
  - Auto active test is starting
  - Emergency OFF
  - Output requests are being received from control units via CAN communication.
- IPDM E/R stops CAN communication and enters the low power consumption mode when it receives a sleep wake up signal (sleep) from BCM and the sleep-ready conditions are fulfilled.

### WAKE-UP OPERATION

- IPDM E/R changes from the low power consumption mode to the normal mode when it receives a sleep wake-up signal (wake up) from BCM or any of the following conditions is fulfilled. In addition, it transmits a sleep-ready signal (not-ready) to BCM via CAN communication to report the CAN communication start.
  - Ignition switch ON
  - An output request is received from a control unit via CAN communication.

### IGNITION BATTERY SAVER LOGIC

If the ignition is ON for 30 minutes with the engine OFF, the IPDM E/R and BCM turn OFF to save the battery.

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000009461601

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Front fog lamps
- Parking lamps
- Side marker lamps
- Tail lamps
- License plate lamps
- Daytime running lamps
- Headlamps (LO, HI)
- A/C compressor
- Cooling fans (LO, HI)

##### Operation Procedure

##### **CAUTION:**

**Do not start the engine.**

##### **NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield before hand.

##### **NOTE:**

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-100, "Component Function Check"](#).
  - When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.
1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)
  2. Turn ignition switch OFF.
  3. Turn the ignition switch ON, and within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
  4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once, and the auto active test starts.
  5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection Location	Operation
1	Front wiper	LO for 3 seconds → HI for 3 seconds
2	<ul style="list-style-type: none"> <li>• Front fog lamps</li> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• Tail lamps</li> <li>• License plate lamps</li> </ul>	10 seconds
3	Daytime running lamps	10 seconds
4	Headlamps	LO ⇔ HI 5 times
5	A/C compressor	ON ⇔ OFF 5 times
6*	Cooling fans	LO for 5 seconds → HI for 5 seconds

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.




# DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

## < SYSTEM DESCRIPTION >

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Front fog lamps</li> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Daytime running lamps</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
Cooling fans do not operate	Perform auto active test. Do the cooling fans operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Cooling fans</li> <li>• Harness or connectors between cooling fans and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connectors between cooling fan relay and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connectors between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT Function (IPDM E/R)

INFOID:000000009461602

### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

# DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

## APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

## ECU IDENTIFICATION

The IPDM E/R part number is displayed.

## SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

## DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Monitor Item [Unit]	Main Signals	Description
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-15. "CAN Diagnostic Support Monitor"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

## ECU DIAGNOSIS INFORMATION

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### Reference Value

INFOID:000000009461603

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1, 2, 3, 4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		<ul style="list-style-type: none"> <li>• Front fog lamp switch ON</li> <li>• Daytime running light activated (Only for Canada models)</li> </ul>	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	STOP
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	CVT selector lever in any position other than P or N	Off
		CVT selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Monitor Item	Condition	Value/Status
ST/INHI RLY	Ignition switch ON	Off
	At engine cranking	ST →INHI
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN
DETENT SW	Ignition switch ON <ul style="list-style-type: none"> <li>• Press the selector button with CVT selector lever in P position</li> <li>• CVT selector lever in any position other than P</li> </ul>	Off
	Release the CVT selector button with CVT selector lever in P position	On
DTRL REQ	DTRL OFF	Off
	DTRL ON	On
HOOD SW	Hood closed	Off
	Hood open	On
THFT HRN REQ	Not operated	Off
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On
HORN CHIRP	Not operated	Off
	Door locking with Intelligent Key (horn chirp mode)	On
HOOD SW 2	Hood closed	Off
	Hood open	On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P


PCS

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (R)	Ground	Fusible link main	Input	Ignition switch OFF	Battery voltage
2 (L)	Ground	Fusible link IPDM E/R	Input	Ignition switch OFF	Battery voltage
3 (G)	Ground	Fusible link ignition switch	Input	Ignition switch ON	Battery voltage
4 (P)	Ground	Motor fan 1	Output	Ignition switch OFF	0V
				Ignition switch ON	Battery voltage
6 (R)	Ground	Fusible link motor fan	Input	Ignition switch OFF	0V
				Ignition switch ON	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
7 (B)	Ground	Ground (Power)	—	Ignition switch ON		0V
9 (SB)	Ground	Tail RH	Output	Ignition switch ON	Lighting switch OFF	0V
					Lighting switch 1ST	Battery voltage
10 (V)	Ground	Tail LH	Output	Ignition switch ON	Lighting switch OFF	0V
					Lighting switch 1ST	Battery voltage
11 (Y)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0V
					Front wiper switch LO	Battery voltage
13 (LG)	Ground	ECM battery	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage
14 (Y)	Ground	Daytime running lamps	Output	Ignition switch OFF		Battery voltage
15 (R)	Ground	Fuel pump	Output	Approximately 1 second or more after turning the ignition switch ON		0V
				<ul style="list-style-type: none"> <li>• Approximately 1 second after turning the ignition switch ON</li> <li>• Engine running</li> </ul>		Battery voltage
18 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0V
					Front wiper switch HI	Battery voltage
19 (BR)	Ground	Power steering control unit	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage
21 (L)	Ground	ECM ignition switch	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage
22 (W)	Ground	Horn relay	Input	The horn is deactivated		Battery voltage
				The horn is activated		0V
23 (V)	Ground	Horn switch	Input	The horn is deactivated		Battery voltage
				The horn is activated		0V
27 (BG)	Ground	Fan motor relay mid	Input	Ignition switch OFF		0V
				Ignition switch ON		0.7V
28 (P)	—	CAN-L	Input/ Output	—		—
29 (L)	—	CAN-H	Input/ Output	—		—
31 (Y)	Ground	Detent switch	Input	Ignition switch ON	Press the CVT selector button (CVT selector lever P)	Battery voltage
					<ul style="list-style-type: none"> <li>• CVT selector lever in any position other than P</li> <li>• Release the CVT selector button (CVT selector lever P)</li> </ul>	
33 (R)	Ground	Starter control	Input	Ignition switch ON	CVT selector lever in any position other than P or N	0V
					CVT selector lever P or N	Battery voltage
34 (SB)	Ground	Wiper autostop	Input	Ignition switch ON	Front wiper stop position	0V
					Any position other than front wiper stop position	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
35 (BR)	Ground	ABS actuator and electric unit (control unit)	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage
36 (W)	Ground	Cooling fan relay-2, 3	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage
37 (W)	Ground	Transmission range switch signal	Input	Ignition switch ON	CVT selector lever in P (park) or N (neutral) position	Battery voltage
					CVT selector lever in any position other than P (park) or N (neutral) position	0V
38 (G)	Ground	Push start switch	Input	Press the push-button ignition switch		0V
				Release the push-button ignition switch		Battery voltage
39 (G)	Ground	Motor fan relay HI	Input	Ignition switch OFF		0V
				Ignition switch ON		0.7V
41 (B)	Ground	Ground (signal)	—	Ignition switch ON		0V
43 (LG)	Ground	Ignition signal <sup>1</sup>	Input	Ignition switch OFF or ACC		0V
				Ignition switch ON		Battery voltage
45 <sup>2</sup> (V)	Ground	Power distribution sensor signal-E/R	—	<ul style="list-style-type: none"> <li>• Ignition switch ON (READY)</li> <li>• Both A/C switch and blower motor switch ON (A/C compressor operates)</li> </ul>		1.0 - 4.0V
45 <sup>3</sup> (P)						
47 <sup>2</sup> (O)	Ground	Power distribution sensor power-E/R	—	Ignition switch ON		5V
47 <sup>3</sup> (BG)						
48 (SB)	Ground	Power distribution sensor ground-E/R	—	Ignition switch ON		0V
49 (P)	Ground	Ambient sensor signal-E/R	—	Ignition switch ON		5V
50 (BG)	Ground	Ambient sensor ground-E/R	—	Ignition switch ON		0V
51 (R)	Ground	Starter motor	Output	At engine cranking		Battery voltage
52 <sup>2</sup> (G)	Ground	O2 sensor #2	Output	Ignition switch OFF		0V
52 <sup>3</sup> (P)				Ignition switch ON		Battery voltage
53 <sup>2</sup> (W)	Ground	O2 sensor #1	Output	Ignition switch OFF		0V
53 <sup>3</sup> (G)				Ignition switch ON		Battery voltage
54 (LG)	Ground	Injector #1	Output	Ignition switch OFF		0V
				Ignition switch ON		Battery voltage



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >




[IPDM E/R]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
55 <sup>2</sup> (W)	Ground	Ignition coil	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)	0V	A
55 <sup>3</sup> (G)				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage	B
56 (SB)	Ground	A/C compressor	Output	Engine running	A/C compressor OFF	0V
				A/C compressor ON (A/C compressor is operating)	Battery voltage	D
57 (R)	Ground	Electronic throttle control	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)	0V	E
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage	F
58 (SB)	Ground	ECM battery	Output	Ignition switch OFF	Battery voltage	G
59 (L)	Ground	Engine solenoid	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)	0V	H
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage	I
60 (Y)	Ground	Injector #2	Output	Ignition switch OFF	0V	J
				Ignition switch ON	Battery voltage	
61 (Y)	Ground	Transmission control module	Output	Ignition switch OFF	0V	K
				Ignition switch ON	Battery voltage	
65 <sup>2</sup> (BR)	Ground	Throttle control motor relay	Output	Ignition switch ON → OFF	0 - 1.0V ↓ Battery voltage ↓ 0V	L
65 <sup>3</sup> (L)				Ignition switch ON	0 - 1.0V	PCS
66 (LG)	Ground	N/P switch	Input	CVT selector lever in P or N position	Battery voltage	N
				Ignition switch ON	CVT selector lever in any position other than P or N position	0V
69 (V)	Ground	Fuel pump relay	Output	• Approximately 1 second after turning the ignition switch ON • Engine running	0 - 1.0V	P
				Approximately 1 second or more after turning the ignition switch ON	Battery voltage	

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
71 (SB)	Ground	Alternator C	Output	Ignition switch ON	 6.3V	
				40% is set on "Active test", "ALTERNATOR DUTY" of "ENGINE"	 3.8V	
				80% is set on "Active test", "ALTERNATOR DUTY" of "ENGINE"	 1.4V	
72 <sup>2</sup> (V)	Ground	ECM relay (Self shut-off)	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage	
72 <sup>3</sup> (Y)				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (More than a few seconds after turning ignition switch OFF)</li> </ul>	0 - 1.5V	
74 <sup>4</sup> (BG)	Ground	Washer motor	Output	Ignition switch ON	Battery voltage	
74 <sup>5</sup> (V)						
75 (R)	Ground	Headlamp LO RH	Output	Ignition switch ON	Lighting switch OFF	0V
					Lighting switch 2ND	Battery voltage
76 (P)	Ground	Headlamp LO LH	Output	Ignition switch ON	Lighting switch OFF	0V
					Lighting switch 2ND	Battery voltage
78 (W)	Ground	Front fog lamp RH	Output	Ignition switch ON	Fog lamp switch OFF	0V
					Fog lamp switch ON	Battery voltage
79 (G)	Ground	Front fog lamp LH	Output	Ignition switch ON	Fog lamp switch OFF	0V
					Fog lamp switch ON	Battery voltage
80 (L)	Ground	Headlamp HI RH	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>• Lighting switch HI</li> <li>• Lighting switch PASS</li> </ul>	Battery voltage
					Lighting switch OFF	0V
81 (Y)	Ground	Headlamp HI LH	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>• Lighting switch HI</li> <li>• Lighting switch PASS</li> </ul>	Battery voltage
					Lighting switch OFF	0V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
82 (W)	Ground	Power distribution sensor signal-fem	—	<ul style="list-style-type: none"> <li>Ignition switch ON (READY)</li> <li>Both A/C switch and blower motor switch ON (electric compressor operates)</li> </ul>		1.0 - 4.0V
83 (G)	Ground	Power distribution sensor power-fem	—	Ignition switch ON		5V
85 (V)	Ground	Daytime running lamps re- lay	Output	Ignition switch ON	Daytime light system ac- tive	Battery voltage
				Ignition switch ON	Daytime light system inac- tive	0V
86 (R)	Ground	Power distribution sensor ground-fem	—	Ignition switch ON		0V
87 (P)	Ground	Ambient sensor signal-fem	—	Ignition switch ON		5V
90 (LG)	Ground	Clearance lamps	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
					Lighting switch OFF	0V
94 (SB)	Ground	Hood switch 2	Input	Ignition switch ON	Hood closed	0V
					Hood open	Battery voltage
95 (BG)	Ground	Ambient sensor ground- fem	—	Ignition switch ON		0V
96 (Y)	Ground	Hood switch	Input	Ignition switch ON	Hood closed	0V
					Hood open	Battery voltage

1: Ignition battery saver logic turns OFF the IPDM E/R and BCM if the ignition is ON for 30 minutes with the engine OFF.

2: With QR25DE.

3: With VQ35DE.

4: With rear view camera.

5: Without rear view camera.

## Fail Safe

INFOID:000000009461604

## CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>Side marker lamps</li> <li>License plate lamps</li> <li>Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

DTC	Ignition switch	Ignition relay	Tail lamp relay
—	ON	ON	—
—	OFF	OFF	—
B2098: IGN RELAY ON	OFF	ON	ON (10 minutes)
B2099: IGN RELAY OFF	ON	OFF	—

### NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

## FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

## STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

## DTC Index

INFOID:000000009461605

CONSULT display	Fail-safe	TIME <sup>NOTE</sup>		Refer to
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39	<a href="#">PCS-27</a>
U1010: CONTROL UNIT (CAN)	×	CRNT	1 – 39	<a href="#">PCS-28</a>
B2098: IGN RELAY ON	×	CRNT	1 – 39	<a href="#">PCS-29</a>
B2099: IGN RELAY OFF	—	CRNT	1 – 39	<a href="#">PCS-30</a>
B210B: INHIBIT relay ON stuck failure	—	CRNT	1 – 39	<a href="#">SEC-73</a>
B210C: INHIBIT relay OFF stuck failure	—	CRNT	1 – 39	<a href="#">SEC-74</a>
B210D: STARTER relay ON stuck failure	—	CRNT	1 – 39	<a href="#">SEC-76</a>
B210E: STARTER relay OFF stuck failure	—	CRNT	1 – 39	<a href="#">SEC-78</a>
B210F: Interlock/NP switch ON stuck failure	—	CRNT	1 – 39	<a href="#">SEC-80</a>
B2110: Interlock/NP switch OFF stuck failure	—	CRNT	1 – 39	<a href="#">SEC-82</a>

### NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >


[IPDM E/R]

## WIRING DIAGRAM

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### Wiring Diagram

INFOID:000000009461606



ABMWA2159GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


PCS

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

QR : WITH QR25DE  
VQ : WITH VQ35DE




ABMWA2160GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

- AA : WITH AUTO A/C
- DC : WITH DRIVER ASSISTANCE SYSTEM
- DZ : WITHOUT DRIVER ASSISTANCE SYSTEM
- MA : WITHOUT AUTO A/C
- QR : WITH QR25DE
- VO : WITH VC35DE



ABMWA2161GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS

Connector No.	E4
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	E5
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	R	-

Connector No.	E16
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	F/L MAIN
2	L	F/L USM

Connector No.	E17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	F/L IGNSW
4	P	MOTOR FAN 1
5	-	-
6	R	F/L MOTOR FAN

Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
8	-	-
9	SB	TAIL RH
10	V	TAIL LH

Terminal No.	Color of Wire	Signal Name
11	Y	FR WIPER LO
12	-	-
13	LG	ECM VB
14	Y	DTRL
15	R	FUEL PUMP
16	-	-
17	-	-
18	L	FR WIPER HI



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< WIRING DIAGRAM >

[IPDM E/R]

Terminal No.	Color of Wire	Signal Name
41	B	GND (SIGNAL)
42	-	-
43	LG	IGN SIGNAL
44	-	-
45	V	PD SENS SIG-E/R (WITH QR25DE)
45	P	PD SENS SIG-E/R (WITH VQ35DE)
46	-	-
47	O	PD SENS PWR-E/R (WITH QR25DE)
47	BG	PD SENS PWR-E/R (WITH VQ35DE)
48	SB	PD SENS GND-E/R
49	P	AMB SENS SIG-E/R
50	BG	AMB SENS GND-E/R

Terminal No.	Color of Wire	Signal Name
26	-	-
27	BG	MOTOR FAN RLY MID
28	P	CAN-L
29	L	CAN-H
30	-	-
31	Y	DETENT SW
32	-	-
33	R	START CONT
34	SB	WIPER AUTOSTOP
35	BR	ABS ECU
36	W	START IG-E/R
37	W	TRANS RANGE SW
38	G	PUSH START SW
39	G	MOTOR FAN RLY HI
40	-	-


Connector No.	E63
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	BR	SUB ECU
20	-	-
21	L	BCM IGNSW
22	W	HORN RLY
23	V	HORN SW
24	-	-
25	-	-


Terminal No.	Color of Wire	Signal Name
86	R	PD SENS GND-FEM
87	BG	AMB SENS SIG-FEM
88	-	-
89	-	-
90	LG	CLEARANCE
91	-	-
92	-	-
93	-	-
94	SB	HOODSW 2
95	R	AMB SENS GND-FEM
96	Y	HOODSW
97	-	-

Connector No.	E201
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82	W	PD SENS SIG-FEM
83	G	PD SENS PWR-FEM
84	-	-
85	V	DTFL RLY

Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
74	BG	WASH MTR (WITH REAR VIEW CAMERA)
74	V	WASH MTR (WITHOUT REAR VIEW CAMERA)
75	R	HEADLAMP LO RH
76	P	HEADLAMP LO LH
77	-	-
78	W	FR FOG LAMP RH
79	G	FR FOG LAMP LH
80	L	HEADLAMP HI RH
81	Y	HEADLAMP HI LH

ABMIA5101GB

A B C D E F G H I J K L N O P

PCS


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

Terminal No.	Color of Wire	Signal Name
53	G	O2SENS #1 (WITH VQ35DE)
54	LG	INJECTOR #1
55	W	IGN COIL (WITH QR25DE)
55	G	IGN COIL (WITH VQ35DE)
56	SB	A/C COMP
57	R	ETC
58	SB	ECM BAT
59	L	ENG SOL
60	V	INJECTOR #2
61	Y	AT ECU

Connector No.	F83
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
52	G	O2SENS #2 (WITH QR25DE)
52	P	O2SENS #2 (WITH VQ35DE)
53	W	O2SENS #1 (WITH QR25DE)


Connector No.	F10
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
51	R	STARTER MOTOR

Terminal No.	Color of Wire	Signal Name
66	LG	NP SW
67	-	-
68	-	-
69	V	FPR
70	-	-
71	SB	ALTC
72	V	SSOFF (WITH QR25DE)
72	Y	SSOFF (WITH VQ35DE)
73	-	-

Connector No.	F84
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
62	-	-
63	-	-
64	-	-
65	BR	MOTRLY (WITH QR25DE)
65	L	MOTRLY (WITH VQ35DE)

ABMIA5102GB

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000009461607

Refer to [LAN-9, "CAN COMMUNICATION SYSTEM : System Description"](#).

#### DTC Logic

INFOID:000000009461608

#### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	When IPDM E/R cannot communicate with CAN communication signal continuously for 2 seconds or more	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none"><li>• Transmission</li><li>• Receiving (ECM)</li><li>• Receiving (BCM)</li><li>• Receiving (Combination meter)</li></ul>

#### Diagnosis Procedure

INFOID:000000009461609

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF-DIAG RESULTS" of IPDM E/R.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-18, "Trouble Diagnosis Flow Chart"](#).  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## U1010 CONTROL UNIT (CAN)

### DTC Logic

INFOID:000000009461610

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1010]	IPDM E/R detected internal CAN communication circuit malfunction.	IPDM E/R

### Diagnosis Procedure

INFOID:000000009461611

#### 1. REPLACE IPDM E/R

When DTC U1010 is detected, replace IPDM E/R.

>> Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).

# B2098 IGNITION RELAY ON STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## B2098 IGNITION RELAY ON STUCK

### DTC Logic

INFOID:000000009941319

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGN RELAY ON [B2098]	The ignition relay ON is detected for 1 second at ignition switch OFF (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	IPDM E/R

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn the power supply position to start under the following conditions and wait for at least 1 second.
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal
- Check "Self-diagnostic result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [PCS-29, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009941320

#### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of IPDM E/R using CONSULT.

#### Is display history of DTC B2098 CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# B2099 IGNITION RELAY OFF STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## B2099 IGNITION RELAY OFF STUCK

### DTC Logic

INFOID:000000009461616

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGN RELAY OFF [B2099]	The ignition relay OFF is detected for 1 second at ignition switch ON (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	IPDM E/R

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to start under the following conditions and wait for at least 1 second.
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal
2. Check "Self-diagnostic result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [PCS-30, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461617

#### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of IPDM E/R using CONSULT.

#### Is display history of DTC B2099 CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000009461618

Regarding Wiring Diagram information, refer to [PCS-21, "Wiring Diagram"](#).

### 1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Fusible link main	E (80A)
2	Fusible link IPDM E/R	A (250A), C (80A)
3	Fusible link ignition switch	A (250A), B (100A), M (40A)

Is the fusible link blown?

- YES >> Replace the blown fusible link after repairing the affected circuit.  
NO >> GO TO 2

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E16 and E17.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E16	1	—	Battery voltage
	2		
E17	3		

Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E18 and E63.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E18	7	—	Yes
E63	41		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

## REMOVAL AND INSTALLATION

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### Removal and Installation

INFOID:000000009461619


**CAUTION:**

IPDM E/R integrated relays are not serviceable parts and must not be removed from unit.


#### REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-73. "Removal and Installation \(Battery\)"](#).
2. Release the pawls and separate the IPDM E/R (1) from the case.

○: Pawl



3. Disconnect all harness connectors (A) from the IPDM E/R (1) and remove.



#### INSTALLATION

Installation is in the reverse order of removal.



PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009951597

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000009461621

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009461622

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[POWER DISTRIBUTION SYSTEM]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009461623



AWMIA1309ZZ

- |  |   |                                |
|--|---|--------------------------------|
| 1. BCM (view with combination meter removed) | 2. IPDM E/R (contains Ignition relay-1) | 3. Fuse block (J/B)            |
| 4. Fuse block (J/B) (back side shown)        | 5. Ignition relay-2                     | 6. Front blower motor relay    |
| 7. Rear window defogger relay                | 8. Accessory relay-1                    | 9. Push-button ignition switch |

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O


P

## SYSTEM

### POWER DISTRIBUTION SYSTEM

#### POWER DISTRIBUTION SYSTEM : System Diagram

INFOID:000000009461624



#### POWER DISTRIBUTION SYSTEM : System Description

INFOID:000000009461625

##### SYSTEM DESCRIPTION

- PDS (POWER DISTRIBUTION SYSTEM) is the system that BCM controls with the operation of the push-button ignition switch and performs the power distribution to each power circuit. This system is used instead of the mechanical power supply changing mechanism with the operation of the conventional key cylinder.
- The push-button ignition switch can be operated when Intelligent Key is in the following condition.
  - Intelligent Key is in the detection area of the inside key antenna.
  - Intelligent Key backside is contacted to push-button ignition switch.
- The push-button ignition switch operation is input to BCM as a signal. BCM changes the power supply position according to the status and operates the following relays to supply power to each power circuit.
  - Ignition relay-1
  - Ignition relay-2
  - Accessory relay-1
  - Accessory relay-2
  - Front blower motor relay

**NOTE:**

- The engine switch operation changes due to the conditions of brake pedal, selector lever and vehicle speed.
- The power supply position can be confirmed with the lighting of the indicators in the push-button ignition switch.

##### BATTERY SAVER SYSTEM

When all the following conditions are met for 30 minutes, the battery saver system will cut off the power supply to prevent battery discharge.

- The ignition switch is in the ACC or ON position
- All doors are closed
- Selector lever is in the P (park) position

##### Reset Condition of Battery Saver System

In order to prevent the battery from discharging, the battery saver system will cut off the power supply when all doors are closed, the selector lever is in P (park) position and the ignition switch is left in the ACC or ON position for 30 minutes. If any of the following conditions are met the battery saver system is released and the steering will change automatically to lock position from OFF position.

- Opening any door
- Operating door request switch on door handle
- Operating Intelligent Key

# SYSTEM

## [POWER DISTRIBUTION SYSTEM]

< SYSTEM DESCRIPTION >

### POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

**NOTE:**

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
OFF → ACC	—	Not depressed	1
OFF → ACC → ON	—	Not depressed	2
OFF → ACC → ON → OFF	—	Not depressed	3
OFF → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009941330

#### CAUTION:

**After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.**

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>• The vehicle specification can be read and saved.</li> <li>• The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

## INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009941331

### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

## SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

## DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of trunk opener request switch.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
SHFTLCK SLNID PER SPLY [On/Off]	×	Indicates condition of power supply to shiftlock solenoid.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [STOP/START/CRANK/RUN]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item [Unit]	Main	Description
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT -RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT -RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENT CANCEL TIMER [STOP]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [STOP]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of engine crank prohibit time.
AUTO CRNK TME [sec]		Indicates condition of automatic engine crank time from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.
DETE SW PWR [On/Off]		Indicates condition of detent switch voltage.
ACC RLY -REQ [On/Off]		Indicates condition of accessory relay control request.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
TRNK/HAT MNTR [On/Off]		Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]		Indicates condition of trunk open signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key identification number [Off/ID No1/ID N02/ID No3/ID No4/ID No5].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
HORN	This test is able to check horn operation [On].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
TRUNK/BACK DOOR	This test is able to check trunk actuator operation [Open].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].



# DIAGNOSIS SYSTEM (BCM)

## [POWER DISTRIBUTION SYSTEM]

### < SYSTEM DESCRIPTION >

Test Item	Description
PUSH SWITCH INDICATOR	This test is able to check push-button ignition switch indicator operation [On/Off].
ACC CONT	This test is able to check accessory relay control operation [On/Off].
IGN CONT1	This test is able to check ignition relay-1 control operation [On/Off].
ST CONT LOW	This test is able to check starter control relay operation [On/Off].
IGNITION RELAY	This test is able to ignition relay operation [On/Off].
REVERSE LAMP TEST	This test is able to check reverse lamp illumination operation [On/Off].
TRUNK/LUGGAGE LAMP TEST	This test is able to check cargo lamp illumination operation [On/Off].
KEYFOB PW TEST	This test is able to check power window operation using the Intelligent Key [Off/DOWN/UP].
SHIFTLOCK SOLENOID TEST	This test is able to check shift lock solenoid operation [On/Off].

### WORK SUPPORT

Support Item	Setting	Description
IGN/ACC BATTERY SAVER	On*	Battery saver function ON.
	Off	Battery saver function OFF.
REMOTE ENGINE STARTER	On*	Remote engine start function ON.
	Off	Remote engine start function OFF.
ANSWERBACK I-KEY LOCK UNLOCK	BUZZER	Buzzer reminder function by door lock/unlock request switch ON.
	HORN	Horn chirp reminder function by door lock request switch ON.
	Off*	No reminder function by door lock/unlock request switch.
	INVALID	This mode is not used.
ANSWERBACK KEYLESS LOCK UNLOCK	On	Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
	Off*	No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
ANSWER BACK	On*	Horn chirp reminder when doors are locked with Intelligent Key.
	Off	No horn chirp reminder when doors are locked with Intelligent Key.
RETRACTABLE MIRROR SET	On	Retractable mirror set ON.
	Off*	Retractable mirror set OFF.
CONFIRM KEY FOB ID	—	Intelligent Key ID code can check.
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock function from Intelligent Key ON.
	Off	Door lock/unlock function from Intelligent Key OFF.
ENGINE START BY I-KEY	On*	Engine start function from Intelligent Key ON.
	Off	Engine start function from Intelligent Key OFF.
TRUNK/GLASS HATCH OPEN	On*	Buzzer reminder function by trunk opener request switch ON.
	Off	Buzzer reminder function by trunk opener request switch OFF.
INTELLIGENT KEY LINK SET	On	Intelligent Key link set ON.
	Off*	Intelligent Key link set OFF.
SHORT CRANKING OUTPUT	Start	70 msec
		100 msec
		200 msec
	End	—
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.

# DIAGNOSIS SYSTEM (BCM)

## [POWER DISTRIBUTION SYSTEM]

< SYSTEM DESCRIPTION >

Support Item	Setting		Description
AUTO LOCK SET	MODE7	5 min	Auto door lock time can be set in this mode.
	MODE6	4 min	
	MODE5	3 min	
	MODE4	2 min	
	MODE3*	1 min	
	MODE2	30 sec	
	MODE1	Off	

\*: Initial Setting

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000009461628

ECU	Reference
BCM	<a href="#">BCS-31, "Reference Value"</a>
	<a href="#">BCS-50, "Fail Safe"</a>
	<a href="#">BCS-50, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-52, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-12, "Reference Value"</a>
	<a href="#">PCS-19, "Fail Safe"</a>
	<a href="#">PCS-20, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >


[POWER DISTRIBUTION SYSTEM]

## WIRING DIAGRAM

### POWER DISTRIBUTION SYSTEM

Wiring Diagram

INFOID:000000009461629




ABMWA2162GB

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]



ABMWA1569GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P


# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]


## POWER DISTRIBUTION SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5G	W	-
15G	L	-
22G	L	-
23G	P	-
31G	BR	-
36G	G	-
37G	R	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1N	V	-
2N	LG	-
3N	W	-
6N	W	-
7N	P	-
8N	W	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN





Terminal No.	Color of Wire	Signal Name
6R	LG	-
9R	G	-
10R	BG	-
12R	W	-
13R	B	-
16R	LG	-

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61



Terminal No.	Color of Wire	Signal Name
48	BR	HIGH SIDE START SW LED
59	P	CAN-L
60	L	CAN-H
62	BR	STARTER RELAY OUT
66	R	BLOWER FAN RELAY OUT
67	W	IGN ELEC RELAY OUT 2
70	G	IGN USM OUT 1

Connector No.	M25
Connector Name	ACCESSORY RELAY-2
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	LG	-
5	P	-



Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	R	ENG START SW NO ESCL
25	BG	BRAKE SW FUSE
26	Y	SHORTING INPUT
27	G	BRAKE SW LAMP
39	L	SHIFT N/P

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3P	W	-
7P	G	-
9P	Y	-
16P	R	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
107	W	LOW SIDE START SW LED
111	Y	ACC LED
113	P	ACC RELAY OUT

ABMIA5103GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PCS

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-
5	BR	-
6	W	-
7	Y	-
8	R	-

Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1M	BG	-
5M	G	-
8M	W	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

ABMIA3767GB




# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	E18
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	7	Color of Wire	B	Signal Name	GND (POWER)
--------------	---	---------------	---	-------------	-------------

Connector No.	E17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	3	Color of Wire	G	Signal Name	F/L IGNSW
--------------	---	---------------	---	-------------	-----------

Connector No.	E16
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK




Terminal No.	1	Color of Wire	R	Signal Name	F/L MAIN
--------------	---	---------------	---	-------------	----------

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY



Terminal No.	1	Color of Wire	P	Signal Name	-
Terminal No.	5	Color of Wire	P	Signal Name	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	1	Color of Wire	L	Signal Name	-
Terminal No.	5	Color of Wire	L	Signal Name	-

ABMIA3768GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]


Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-

Terminal No.	Color of Wire	Signal Name
5G	P	-
15G	W	-
22G	L	-
23G	P	-
31G	R	-
36G	LG	-
37G	G	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E57
Connector Name	STOP LAMP RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	W	-
5	G	-

Connector No.	E56
Connector Name	JOINT CONNECTOR-E08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	W	-
25	W	-

ABMIA5104GB

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	E64
Connector Name	JOINT CONNECTOR-E10
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
3	G	-
4	G	-

Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
33	R	START CONT
37	W	TRANS RANGE SW
38	G	PUSH START SW
41	B	GND (SIGNAL)
43	LG	IGN SIGNAL

Connector No.	E63
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	J-1
Connector Name	FUSE BLOCK (J/B) (IGNITION RELAY-2)
Connector Color	-



Connector No.	F10
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
51	R	STARTER MOTOR

ABMIA5105GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P


PCS

# POWER DISTRIBUTION SYSTEM


< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	J-4
Connector Name	FUSE BLOCK (J/B) (FRONT BLOWER MOTOR RELAY)
Connector Color	-



Connector No.	J-3
Connector Name	FUSE BLOCK (J/B) (ACCESSORY RELAY-1)
Connector Color	-



ABMIA3771GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009461630

OVERALL SEQUENCE



DETAILED FLOW

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

---

## 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the component or system that is malfunctioning.

>> GO TO 2.

---

## 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT).
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

### Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

---

## 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

---

## 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

### **NOTE:**

Freeze frame data is useful if the DTC is not detected.

>> GO TO 6.

---

## 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-50, "DTC Inspection Priority Chart"](#), and determine trouble diagnosis order.

### Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

---

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

### Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

---

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

---

Inspect according to Diagnosis Procedure of the system.

### Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

## 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

## 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000009461631

Refer to [LAN-9, "CAN COMMUNICATION SYSTEM : System Description"](#).

#### DTC Logic

INFOID:000000009461632

#### DTC DETECTION LOGIC

##### NOTE:

U1000 can be set if a module harness was disconnected and reconnected, perhaps during a repair. Confirm that there are actual CAN diagnostic symptoms and a present DTC by performing the Self Diagnostic Result procedure.

CONSULT Display	DTC Detection Condition	Possible cause
CAN COMM CIRCUIT [U1000]	When any listed module cannot communicate with CAN communication signal continuously for 2 seconds or more with ignition switch ON	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none"><li>• Transmission</li><li>• Receiving (ECM)</li><li>• Receiving (VDC/TCS/ABS)</li><li>• Receiving (METER/M&amp;A)</li><li>• Receiving (TCM)</li><li>• Receiving (IPDM E/R)</li></ul>

#### Diagnosis Procedure

INFOID:000000009461633

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF- DIAG RESULTS".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform CAN Diagnosis as described in DIAGNOSIS section of CONSULT Operation Manual.  
NO >> Refer to [GI-43, "Intermittent Incident"](#).



# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## U1010 CONTROL UNIT (CAN)

### DTC Logic

INFOID:000000009461634

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1010]	BCM detected internal CAN communication circuit malfunction.	BCM

### Diagnosis Procedure

INFOID:000000009461635

#### 1. REPLACE BCM

When DTC U1010 is detected, replace BCM.

>> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# B260A IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B260A IGNITION RELAY

### DTC Logic

INFOID:000000009461636

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B260A is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-56, "DTC Logic"](#).
- If DTC B260A is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-57, "DTC Logic"](#).
- If DTC B260A is displayed with DTC B261A, first perform the trouble diagnosis for DTC B261A. Refer to [PCS-68, "DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
IGNITION RELAY [B260A]	BCM detects a difference of signal for 2 seconds or more between the following information: <ul style="list-style-type: none"> <li>• Ignition relay-1 operation request.</li> <li>• Ignition relay-1 feedback from IPDM E/R (CAN).</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connectors</li> <li>• IPDM E/R</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for at least 2 seconds.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release the brake pedal.
2. Perform self diagnostic result.

#### Is DTC B260A detected?

- YES >> Refer to [PCS-58, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461637

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R

Perform self diagnostic result for IPDM E/R.

#### Are any DTCs detected?

- YES >> Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2

#### 2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)

Check voltage between IPDM E/R connector E63 terminal 43 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E63	43	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> GO TO 3.

#### 3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)

Check voltage between BCM connector M18 terminal 70 and ground.

# B260A IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M18	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B2614 ACC RELAY CIRCUIT

### DTC Logic

INFOID:000000009461638

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible cause
ACC RELAY CIRCUIT [B2614]	An immediate operation of accessory relay-1 and accessory relay-2 is requested by BCM, but there is no response for more than 1 second.	<ul style="list-style-type: none"> <li>• Harness or connectors</li> <li>• Accessory relay-1</li> <li>• Accessory relay-2</li> <li>• Fuse block J/B</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn the power supply position to ACC under the following conditions, and wait for at least 1 second.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release the brake pedal.
2. Perform self diagnostic result.

#### Is DTC B2614 detected?

- YES >> Refer to [PCS-60. "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461639

Regarding Wiring Diagram information, refer to [PCS-44. "Wiring Diagram"](#).

#### 1. CHECK ACCESSORY RELAY-1 AND ACCESSORY RELAY-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect accessory relay-1 and accessory relay-2.
3. Disconnect BCM connector M20.
4. Check continuity between accessory relay-1 connector J-3 terminal 2 and BCM connector M20 terminal 113.

Accessory relay-1		BCM		Continuity
Connector	Terminal	Connector	Terminal	
J-3	2	M20	113	Yes

5. Check continuity between accessory relay-2 connector M25 terminal 1 and BCM connector M20 terminal 113.

Accessory relay-2		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M25	1	M20	113	Yes

6. Check continuity between BCM connector M20 terminal 113 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	113	—	No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness or connectors.

# B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## 2. CHECK ACCESSORY RELAY-1 AND ACCESSORY RELAY-2 GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between accessory relay-1 connector J-3 terminal 1 and ground.

Accessory relay-1		Ground	Continuity
Connector	Terminal		
J-3	1	—	Yes

3. Check continuity between accessory relay-2 connector M25 terminal 2 and ground.

Accessory relay-2		Ground	Continuity
Connector	Terminal		
M25	2	—	Yes

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness or connectors.

## 3. CHECK ACCESSORY RELAYS

Perform the relay component inspection. Refer to [PCS-61, "Component Inspection \(Relay\)"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Replace relay.

## 4. CHECK ACCESSORY RELAY-1 AND ACCESSORY RELAY-2 POWER SUPPLY (BCM)

Check voltage between BCM connector M20 terminal 113 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M20	113	—	Ignition: OFF	0V
			Ignition: ACC	Battery voltage

Is the inspection result normal?

- YES >> Refer to [GI-43, "Intermittent Incident"](#).  
 NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

## Component Inspection (Relay)

INFOID:000000009461640

### 1. CHECK RELAY

1. Remove relay.
2. Check the continuity between relay terminals under the following conditions.

Relay terminals	Condition	Continuity
3 and 5	Battery voltage applied to terminal 1 and ground to terminal 2.	Yes
	Voltage and ground removed.	No

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Replace relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# B2615 BLOWER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B2615 BLOWER RELAY CIRCUIT

### DTC Logic

INFOID:000000009461641

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
BLOWER RELAY CIRCUIT [B2615]	An immediate operation of front blower motor relay is requested by BCM, but there is no response for more than 1 second.	<ul style="list-style-type: none"><li>• Harness or connectors.</li><li>• Front blower motor relay.</li><li>• Fuse block J/B.</li><li>• BCM.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for at least 1 second.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release brake pedal.
2. Perform self diagnostic result.

#### Is DTC B2615 detected?

- YES >> Refer to [PCS-62, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461642

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK FRONT BLOWER MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front blower motor relay.
3. Disconnect BCM connector M19.
4. Check continuity between front blower motor relay connector J-4 terminal 2 and BCM connector M18 terminal 66.

Front blower motor relay		BCM		Continuity
Connector	Terminal	Connector	Terminal	
J-4	2	M18	66	Yes

5. Check continuity between front blower motor relay connector J-4 terminal 2 and ground.

Front blower motor relay		Ground	Continuity
Connector	Terminal		
J-4	2	—	No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness or connectors.

#### 2. CHECK FRONT BLOWER MOTOR RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front blower motor relay connector J-4 terminal 1 and ground.

# B2615 BLOWER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Front blower motor relay		Ground	Continuity
Connector	Terminal		
J-4	1	—	Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness or connectors.

## 3. CHECK FRONT BLOWER MOTOR RELAY

Perform the relay component inspection. Refer to [PCS-63, "Component Inspection \(Relay\)"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace front blower motor relay.

## 4. CHECK FRONT BLOWER MOTOR RELAY POWER SUPPLY (BCM)

Check voltage between BCM connector M19 terminal 66 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M19	66	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

- YES >> Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

## Component Inspection (Relay)

INFOID:000000009461643

### 1. CHECK RELAY

1. Remove relay.
2. Check the continuity between relay terminals under the following conditions.

Relay terminals	Condition	Continuity
3 and 5	Battery voltage applied to terminal 1 and ground to terminal 2.	Yes
	Voltage and ground removed.	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace relay.

PCS

# B2616 IGNITION RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B2616 IGNITION RELAY CIRCUIT

### DTC Logic

INFOID:000000009461644

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGNITION RELAY CIRCUIT [B2616]	An immediate operation of ignition relay-2 is requested by BCM, but there is no response for more than 1 second.	<ul style="list-style-type: none"> <li>• Harness or connectors.</li> <li>• Ignition relay-2.</li> <li>• Fuse block J/B.</li> <li>• BCM.</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for at least 1 second.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release brake pedal
2. Perform self diagnostic result.

#### Is DTC B2616 detected?

- YES >> Refer to [PCS-64, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461645

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK IGNITION RELAY-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M19.
3. Check continuity between ignition relay-2 connector J-1 terminal 1 and BCM connector M18 terminal 67.

Ignition relay-2		BCM		Continuity
Connector	Terminal	Connector	Terminal	
J-1	1	M18	67	Yes

4. Check continuity between ignition relay-2 connector J-1 terminal 1 and ground.

Ignition relay-2		Ground	Continuity
Connector	Terminal		
J-1	1	—	No

#### Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace harness or connectors.

#### 2. CHECK IGNITION RELAY-2 GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ignition relay-2 connector J-1 terminal 2 and ground.

Ignition relay-2		Ground	Continuity
Connector	Terminal		
J-1	2	—	Yes

#### Is the inspection result normal?



# B2616 IGNITION RELAY CIRCUIT

[POWER DISTRIBUTION SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
- NO >> Repair or replace harness or connectors.

## 3. CHECK IGNITION RELAY-2

Perform the relay component inspection. Refer to [PCS-65. "Component Inspection \(Relay\)".](#)

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace ignition relay-2.

## 4. CHECK IGNITION RELAY-2 POWER SUPPLY (BCM)

Check voltage between BCM connector M18 terminal 67 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M18	67	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

- YES >> Refer to [GI-43. "Intermittent Incident".](#)
- NO >> Replace BCM. Refer to [BCS-80. "Removal and Installation".](#)

## Component Inspection (Relay)

INFOID:000000009461646

### 1. CHECK RELAY

1. Remove relay.
2. Check the continuity between relay terminals under the following conditions.

Relay terminals	Condition	Continuity
3 and 5	Battery voltage applied to terminal 1 and ground to terminal 2.	Yes
	Voltage and ground removed.	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

**B2618 BCM**

**DTC Logic**

INFOID:000000009461647

**DTC DETECTION LOGIC**

**NOTE:**

- If DTC B2618 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-56, "DTC Logic"](#).
- If DTC B2618 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-57, "DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
BCM [B2618]	An immediate operation of ignition relay-1 is requested by BCM, but there is no response for more than 1 second	• BCM

**DTC CONFIRMATION PROCEDURE**

**1. PERFORM SELF DIAGNOSTIC RESULT**

1. Turn ignition switch ON under the following conditions, and wait for at least 1 second.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release brake pedal
2. Perform self diagnostic result.

**Is DTC B2618 detected?**

- YES >> Refer to [PCS-66, "Diagnosis Procedure"](#).
- NO >> Inspection End.

**Diagnosis Procedure**

INFOID:000000009461648

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

**1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R**

Perform self diagnostic result for IPDM E/R.

**Are any DTCs detected?**

- YES >> Refer to [PCS-20, "DTC Index"](#).
- NO >> GO TO 2

**2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)**

Check voltage between IPDM E/R connector E63 terminal 43 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E63	43	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

**Is the inspection result normal?**

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
- NO >> GO TO 3.

**3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)**

Check voltage between BCM connector M18 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			

# B2618 BCM

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

M18	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B261A PUSH-BUTTON IGNITION SWITCH

### DTC Logic

INFOID:000000009461649

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
PUSH-BUTTONIGNITION SWITCH [B261A]	BCM detects a difference of signal for 1 second or more between the following information: <ul style="list-style-type: none"><li>• Power supply position by push-button ignition switch.</li><li>• Power supply position from IPDM E/R (CAN).</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors</li><li>• Push-button ignition switch</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Press the push-button ignition switch under the following conditions, and wait for at least 1 second.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Release the brake pedal.
2. Perform self diagnostic result.

#### Is DTC B261A detected?

- YES >> Refer to [PCS-68. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461650

Regarding Wiring Diagram information, refer to [PCS-44. "Wiring Diagram"](#).

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Disconnect push-button ignition switch connector.
2. Check voltage between push-button ignition switch connector M38 terminal 8 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M38	8	—	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 4.

#### 2. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E63 terminal 38 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E63	38	—	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).

#### 3. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E63 and BCM connector M17.

## B261A PUSH-BUTTON IGNITION SWITCH

[POWER DISTRIBUTION SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between IPDM E/R connector E63 terminal 38 and push-button ignition switch connector M38 terminal 8.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E63	38	M38	8	Yes

4. Check continuity between IPDM E/R connector E63 terminal 38 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E63	38	—	No

Is the inspection result normal?

YES >> Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

### 4. CHECK IGNITION SWITCH OUTPUT SIGNAL (BCM)

Check voltage between BCM connector M17 terminal 1 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M17	1	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

### 5. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Turn ignition switch OFF.
2. Disconnect BCM connector M17 and IPDM E/R connector E63.
3. Check continuity between BCM connector M17 terminal 1 and push-button ignition switch connector M38 terminal 8.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	1	M38	8	Yes

4. Check continuity between BCM connector M17 terminal 1 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	1	—	No

Is the inspection result normal?

YES >> Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

# B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B26F1 IGNITION RELAY

### DTC Logic

INFOID:000000009461651

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible cause
IGN RELAY OFF [B26F1]	BCM transmits the ignition relay control signal, but does not receive ignition switch ON signal (CAN) from IPDM E/R.	<ul style="list-style-type: none"><li>• Harness or connectors</li><li>• BCM</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Do not depress brake pedal.
2. Perform self diagnostic result.

#### Is DTC B26F1 detected?

- YES >> Go to [PCS-70, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461652

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R

1. Perform self diagnostic result for IPDM E/R.
2. Erase DTCs.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Perform self diagnostic result for IPDM E/R.

#### Are any DTCs detected?

- YES >> Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

Check voltage between BCM connector M18 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M18	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

#### 3. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E63 and BCM connector M18.
3. Check continuity between IPDM E/R connector E63 terminal 43 and BCM connector M18 terminal 70.

# B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E63	43	M18	70	Yes

4. Check continuity between IPDM E/R connector E63 terminal 43 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E63	43	—	No

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B26F2 IGNITION RELAY

### DTC Logic

INFOID:000000009461653

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible cause
IGN RELAY ON [B26F2]	BCM transmits the ignition relay control signal, but does not receive ignition switch ON signal (CAN) from IPDM E/R.	<ul style="list-style-type: none"><li>• Harness or connectors</li><li>• BCM</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Do not depress brake pedal.
2. Perform self diagnostic result.

#### Is DTC B26F2 detected?

- YES >> Go to [PCS-72, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000009461654

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R

1. Perform self diagnostic result for IPDM E/R.
2. Erase DTCs.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Perform self diagnostic result for IPDM E/R.

#### Are any DTCs detected?

- YES >> Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E63.
3. Check voltage between IPDM E/R connector E63 terminal 43 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E63	43	—	Ignition: OFF	0V

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> GO TO 3.

#### 3. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT

1. Disconnect BCM connector M18.
2. Check voltage between IPDM E/R connector E63 terminal 43 and ground.



# B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E63	43	—	Ignition: OFF	0V

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

B26F6 BCM

DTC Logic

INFOID:000000009461655

DTC DETECTION LOGIC

**NOTE:**

- If DTC B26F6 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-56, "DTC Logic"](#).
- If DTC B26F6 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-57, "DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
BCM [B26F6]	Ignition relay ON signal is not transmitted from IPDM E/R (CAN) when BCM turns ignition relay ON.	BCM

DTC CONFIRMATION PROCEDURE

**1. PERFORM SELF DIAGNOSTIC RESULT**

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more.
  - CVT selector lever is in the P (park) or N (neutral) position.
  - Do not depress brake pedal.
2. Perform self diagnostic result.

Is DTC B26F6 detected?

- YES >> Go to [PCS-74, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009461656

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

**1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R**

Perform self diagnostic result for IPDM E/R.

Are any DTCs detected?

- YES >> Refer to [PCS-20, "DTC Index"](#).
- NO >> GO TO 2

**2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)**

Check voltage between IPDM E/R connector E63 terminal 43 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E63	43	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
- NO >> GO TO 3.

**3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)**

Check voltage between BCM connector M18 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			

# B26F6 BCM

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

M18	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## PUSH-BUTTON IGNITION SWITCH

### Component Function Check

INFOID:000000009461657

#### 1. CHECK FUNCTION

1. Select "PUSH SW" in "Data Monitor" of BCM with CONSULT.
2. Check the push-button ignition switch signal under the following conditions.

Test item	Condition	Status
PUSH SW	Push-button ignition switch is pressed	On
	Push-button ignition switch is not pressed	Off

#### Is the indication normal?

- YES >> Inspection End.  
NO >> Go to [PCS-76, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000009461658

Regarding Wiring Diagram information, refer to [PCS-44, "Wiring Diagram"](#).

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector and IPDM E/R connector E63.
3. Check voltage between push-button ignition switch connector M38 terminal 8 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M38	8	—	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Disconnect BCM connector M17.
2. Check continuity between BCM connector M17 terminal 1 and push-button ignition switch connector M38 terminal 8.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	1	M38	8	Yes

3. Check continuity between BCM connector M17 terminal 1 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	1	—	No

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

#### 3. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E63 terminal 38 and ground.

# PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E63	38	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 4.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Disconnect BCM connector M17.
2. Check continuity between IPDM E/R connector E63 terminal 38 and push-button ignition switch connector M38 terminal 8.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E63	38	M38	8	Yes

3. Check continuity between IPDM E/R connector E63 terminal 38 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E63	38	—	No

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

## 5. CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch connector M38 terminal 4 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M38	4	—	Yes

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace harness or connectors.

## 6. CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [PCS-77, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace push-button ignition switch.

## Component Inspection

INFOID:000000009461659

### 1. CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch terminals	Condition	Continuity
4 – 8	Pressed	Yes
	Not pressed	No

Is the inspection result normal?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

## PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

---

- YES >> Inspection End.
- NO >> Replace push-button ignition switch.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000009941339

Regarding Wiring Diagram information, refer to [BCS-55. "Wiring Diagram"](#).

### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.  
NO >> GO TO 2

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000009953403

Regarding Wiring Diagram information, refer to [PCS-21. "Wiring Diagram"](#).

### 1. CHECK FUSIBLE LINKS

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Check that the following fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Fusible link main	E (80A)
2	Fusible link IPDM E/R	A (250A), C (80A)
3	Fusible link ignition switch	A (250A), B (100A), M (40A)

Is the fusible link blown?

YES >> Replace the blown fusible link after repairing the affected circuit.

NO >> GO TO 2

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E16 and E17.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E16	1	—	Battery voltage
	2		
E17	3		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E18 and E63.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E18	7	—	Yes
E63	41		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.



# PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## SYMPTOM DIAGNOSIS

### PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

#### Description

INFOID:000000009461662

Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

#### NOTE:

The engine start function, door lock function, power distribution system, and NATS-IVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

#### Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” in “WORK SUPPORT” is ON when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

#### Diagnosis Procedure

INFOID:000000009461663

#### 1.PERFORM WORK SUPPORT

Perform “INSIDE ANT DIAGNOSIS” on Work Support of “INTELLIGENT KEY”.

Refer to [PCS-39, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

>> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSTIC RESULT

Perform self diagnostic result.

Are any DTCs detected?

YES >> Refer to [BCS-52, "DTC Index"](#).

NO >> GO TO 3.

#### 3.CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-76, "Component Function Check"](#).

Is the operation normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

#### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

## BCM (BODY CONTROL MODULE)

< REMOVAL AND INSTALLATION >

[POWER DISTRIBUTION SYSTEM]

---

# REMOVAL AND INSTALLATION

## BCM (BODY CONTROL MODULE)

### Removal and Installation

INFOID:000000009461664

For removal and installation of the BCM (Body Control Module), refer to [BCS-80, "Removal and Installation"](#).

# PUSH BUTTON IGNITION SWITCH


< REMOVAL AND INSTALLATION >

[POWER DISTRIBUTION SYSTEM]

## PUSH BUTTON IGNITION SWITCH

Exploded View

INFOID:000000009461665



1. NATS antenna amp.
2. Push-button ignition switch


## Removal and Installation

INFOID:000000009461666

### REMOVAL

1. Remove instrument pad (LH). Refer to [IP-14. "Exploded View"](#).
2. Release the pawl on each side of NATS antenna amp. (1) using a suitable tool and remove from the instrument pad (LH).

⊖: Pawl



3. Release the pawl on each side using a suitable tool and remove the push-button ignition switch from the NATS antenna amp.

### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS