

SECTION **PWC**

POWER WINDOW CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

CONTENTS

<p>LH FRONT ONLY ANTI-PINCH</p> <p>PRECAUTION 6</p> <p>PRECAUTIONS 6</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"6</p> <p style="padding-left: 20px;">Precaution for Work6</p> <p>PREPARATION 7</p> <p>PREPARATION 7</p> <p style="padding-left: 20px;">Special Service Tool7</p> <p>SYSTEM DESCRIPTION 8</p> <p>COMPONENT PARTS 8</p> <p style="padding-left: 20px;">Component Parts Location8</p> <p style="padding-left: 20px;">Component Description8</p> <p>SYSTEM10</p> <p style="padding-left: 20px;">System Diagram 10</p> <p style="padding-left: 20px;">System Description 10</p> <p style="padding-left: 20px;">Fail-safe 11</p> <p>DIAGNOSIS SYSTEM (BCM)13</p> <p>COMMON ITEM13</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) 13</p> <p>RETAINED PWR14</p> <p style="padding-left: 20px;">RETAINED PWR : CONSULT Function (BCM - RETAINED PWR) 14</p> <p>ECU DIAGNOSIS INFORMATION15</p> <p>BCM (BODY CONTROL MODULE)15</p> <p style="padding-left: 20px;">List of ECU Reference 15</p> <p>POWER WINDOW MAIN SWITCH16</p> <p style="padding-left: 20px;">Reference Value 16</p>	<p>WIRING DIAGRAM18</p> <p>POWER WINDOW SYSTEM18</p> <p style="padding-left: 20px;">Wiring Diagram - With Left Front Only Power Window Anti- Pinch18</p> <p>BASIC INSPECTION25</p> <p>DIAGNOSIS AND REPAIR WORKFLOW25</p> <p style="padding-left: 20px;">Work Flow25</p> <p>INSPECTION AND ADJUSTMENT27</p> <p>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL27</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description27</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement27</p> <p>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT27</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description27</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement27</p> <p>DTC/CIRCUIT DIAGNOSIS29</p> <p>POWER SUPPLY AND GROUND CIRCUIT29</p> <p>BCM29</p> <p style="padding-left: 20px;">BCM : Diagnosis Procedure29</p> <p>POWER WINDOW MAIN SWITCH29</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Description29</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Component Function Check30</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Diagnosis Procedure30</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Component Inspection33</p>
---	--



POWER WINDOW MAIN SWITCH : Special Repair Requirement	34	Component Inspection	51
FRONT POWER WINDOW SWITCH	34	POWER WINDOW LOCK SWITCH	52
FRONT POWER WINDOW SWITCH : Description	34	Description	52
FRONT POWER WINDOW SWITCH : Component Function Check	34	Component Function Check	52
FRONT POWER WINDOW SWITCH : Diagnosis Procedure	35	Special Repair Requirement	52
FRONT POWER WINDOW SWITCH : Component Inspection	36	SYMPTOM DIAGNOSIS	53
REAR POWER WINDOW SWITCH	36	POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES	53
REAR POWER WINDOW SWITCH : Description	36	Diagnosis Procedure	53
REAR POWER WINDOW SWITCH : Component Function Check	37	DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	54
REAR POWER WINDOW SWITCH : Diagnosis Procedure	37	Diagnosis Procedure	54
REAR POWER WINDOW SWITCH : Component Inspection	38	FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE	55
POWER WINDOW MOTOR	40	Diagnosis Procedure	55
DRIVER SIDE	40	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	56
DRIVER SIDE : Description	40	Diagnosis Procedure	56
DRIVER SIDE : Component Function Check	40	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	57
DRIVER SIDE : Diagnosis Procedure	40	Diagnosis Procedure	57
DRIVER SIDE : Component Inspection	41	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	58
DRIVER SIDE : Special Repair Requirement	41	Diagnosis Procedure	58
PASSENGER SIDE	41	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	59
PASSENGER SIDE : Description	42	Diagnosis Procedure	59
PASSENGER SIDE : Component Function Check	42	POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	60
PASSENGER SIDE : Diagnosis Procedure	42	Diagnosis Procedure	60
PASSENGER SIDE : Component Inspection	43	POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	61
REAR LH	43	Diagnosis Procedure	61
REAR LH : Description	43	DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	62
REAR LH : Component Function Check	43	Diagnosis Procedure	62
REAR LH : Diagnosis Procedure	43	KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	63
REAR LH : Component Inspection	44	Diagnosis Procedure	63
REAR RH	45	PERIODIC MAINTENANCE	64
REAR RH : Description	45	PRE-INSPECTION FOR DIAGNOSTIC	64
REAR RH : Component Function Check	45	Basic Inspection	64
REAR RH : Diagnosis Procedure	45	REMOVAL AND INSTALLATION	65
REAR RH : Component Inspection	46		
ENCODER	47		
DRIVER SIDE	47		
DRIVER SIDE : Description	47		
DRIVER SIDE : Component Function Check	47		
DRIVER SIDE : Diagnosis Procedure	47		
DRIVER SIDE : Special Repair Requirement	49		
DOOR SWITCH	50		
Description	50		
Component Function Check	50		
Diagnosis Procedure	50		

MAIN POWER WINDOW AND DOOR LOCK/ UNLOCK SWITCH	65	Wiring Diagram - With Left And Right Front Power Window Anti-Pinch	83	A
Removal and Installation	65	BASIC INSPECTION	91	
POWER WINDOW AND DOOR LOCK/UN- LOCK SWITCH RH	66	DIAGNOSIS AND REPAIR WORKFLOW	91	B
Removal and Installation	66	Work Flow	91	
REAR POWER WINDOW SWITCH	67	INSPECTION AND ADJUSTMENT	93	C
Removal and Installation	67	ADDITIONAL SERVICE WHEN REMOVING BAT- TERY NEGATIVE TERMINAL	93	D
LH & RH FRONT ANTI-PINCH		ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description	93	
PRECAUTION	68	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Re- pair Requirement	93	E
PRECAUTIONS	68	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	93	F
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	68	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	93	
Precaution for Work	68	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	93	G
PREPARATION	69	DTC/CIRCUIT DIAGNOSIS	95	H
PREPARATION	69	POWER SUPPLY AND GROUND CIRCUIT	95	
Special Service Tool	69	BCM	95	I
SYSTEM DESCRIPTION	70	BCM : Diagnosis Procedure	95	
COMPONENT PARTS	70	POWER WINDOW MAIN SWITCH	95	J
Component Parts Location	70	POWER WINDOW MAIN SWITCH : Description	95	
Component Description	70	POWER WINDOW MAIN SWITCH : Component Function Check	96	
SYSTEM	72	POWER WINDOW MAIN SWITCH : Diagnosis Procedure	96	
System Diagram	72	POWER WINDOW MAIN SWITCH : Component Inspection	98	
System Description	72	POWER WINDOW MAIN SWITCH : Special Re- pair Requirement	99	
Fail-safe	74	FRONT POWER WINDOW SWITCH	99	M
DIAGNOSIS SYSTEM (BCM)	75	FRONT POWER WINDOW SWITCH : Descrip- tion	99	
COMMON ITEM	75	FRONT POWER WINDOW SWITCH : Compon- ent Function Check	100	N
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	75	FRONT POWER WINDOW SWITCH : Diagnosis Procedure	100	
RETAINED PWR	76	FRONT POWER WINDOW SWITCH : Special Repair Requirement	101	O
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	76	REAR POWER WINDOW SWITCH	101	P
ECU DIAGNOSIS INFORMATION	77	REAR POWER WINDOW SWITCH : Description	101	
BCM (BODY CONTROL MODULE)	77	REAR POWER WINDOW SWITCH : Component Function Check	101	
List of ECU Reference	77	REAR POWER WINDOW SWITCH : Diagnosis Procedure	101	
POWER WINDOW MAIN SWITCH	78	REAR POWER WINDOW SWITCH : Component Inspection	103	
Reference Value	78			
Fail Safe	79			
FRONT POWER WINDOW SWITCH	81			
Reference Value	81			
Fail Safe	82			
WIRING DIAGRAM	83			
POWER WINDOW SYSTEM	83			

PWC

POWER WINDOW MOTOR	105	POWER WINDOW MAIN SWITCH : Diagnosis Procedure	123
DRIVER SIDE	105	FRONT POWER WINDOW SWITCH	124
DRIVER SIDE : Description	105	FRONT POWER WINDOW SWITCH : Descrip- tion	124
DRIVER SIDE : Component Function Check	105	FRONT POWER WINDOW SWITCH : Compo- nent Function Check	124
DRIVER SIDE : Diagnosis Procedure	105	FRONT POWER WINDOW SWITCH : Diagnosis Procedure	125
DRIVER SIDE : Component Inspection	106	POWER WINDOW LOCK SWITCH	127
DRIVER SIDE : Special Repair Requirement	106	Description	127
PASSENGER SIDE	106	Component Function Check	127
PASSENGER SIDE : Description	107	Special Repair Requirement	127
PASSENGER SIDE : Component Function Check	107	SYMPTOM DIAGNOSIS	128
PASSENGER SIDE : Diagnosis Procedure	107	POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES	128
PASSENGER SIDE : Component Inspection	108	Diagnosis Procedure	128
PASSENGER SIDE : Special Repair Requirement	108	DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	129
REAR LH	108	Diagnosis Procedure	129
REAR LH : Description	109	FRONT PASSENGER SIDE POWER WIN- DOW ALONE DOES NOT OPERATE	130
REAR LH : Component Function Check	109	Diagnosis Procedure	130
REAR LH : Diagnosis Procedure	109	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	131
REAR LH : Component Inspection	110	Diagnosis Procedure	131
REAR RH	110	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	132
REAR RH : Description	110	Diagnosis Procedure	132
REAR RH : Component Function Check	110	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	133
REAR RH : Diagnosis Procedure	110	Diagnosis Procedure	133
REAR RH : Component Inspection	111	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)	134
ENCODER	113	Diagnosis Procedure	134
DRIVER SIDE	113	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	135
DRIVER SIDE : Description	113	Diagnosis Procedure	135
DRIVER SIDE : Component Function Check	113	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)	136
DRIVER SIDE : Diagnosis Procedure	113	Diagnosis Procedure	136
PASSENGER SIDE	115	POWER WINDOW RETAINED POWER OP- ERATION DOES NOT OPERATE PROPERLY	137
PASSENGER SIDE : Description	115	Diagnosis Procedure	137
PASSENGER SIDE : Component Function Check	115		
PASSENGER SIDE : Diagnosis Procedure	115		
DOOR SWITCH	118		
Description	118		
Component Function Check	118		
Diagnosis Procedure	118		
Component Inspection	119		
DOOR KEY CYLINDER SWITCH	120		
Description	120		
Component Function Check	120		
Diagnosis Procedure	120		
Component Inspection	121		
Special Repair Requirement	122		
POWER WINDOW SERIAL LINK	123		
POWER WINDOW MAIN SWITCH	123		
POWER WINDOW MAIN SWITCH : Description ..	123		
POWER WINDOW MAIN SWITCH : Component Function Check	123		

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	138	Basic Inspection	141	A
Diagnosis Procedure	138	REMOVAL AND INSTALLATION	142	
DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	139	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	142	B
Diagnosis Procedure	139	Removal and Installation	142	
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	140	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	143	C
Diagnosis Procedure	140	Removal and Installation	143	
PERIODIC MAINTENANCE	141	REAR POWER WINDOW SWITCH	144	D
PRE-INSPECTION FOR DIAGNOSTIC	141	Removal and Installation	144	

E
F
G
H
I
J
L
M
N
O
P

PWC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009951561

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000009460817

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[LH FRONT ONLY ANTI-PINCH]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009460818

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH FRONT ONLY ANTI-PINCH]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009460819



AWKIA2028ZZ

- | | | |
|--|--|---|
| 1. BCM (view with combination meter removed) | 2. Front power window motor LH (RH similar) | 3. Rear power window motor LH (RH similar) |
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

Component Description

INFOID:000000009460820

FRONT POWER WINDOW LH ANTI-PINCH SYSTEM

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

Component	Function
BCM	<ul style="list-style-type: none"> • Supplies power to power window switches. • Controls retained power.
Front power window motor LH	<ul style="list-style-type: none"> • Integrates the ENCODER POWER and WINDOW MOTOR. • Starts operating with signals from main power window and door lock/unlock switch. • Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Front power window motor RH	Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH.
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> • Directly controls all power window motor of all doors. • Controls anti-pinch operation of front power window LH.
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> • Controls front power window motor RH.
Rear power window switch	<ul style="list-style-type: none"> • Controls rear power window motors LH and RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch & rear power window switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

SYSTEM

System Diagram

INFOID:000000009460821

FRONT POWER WINDOW LH ANTI-PINCH SYSTEM



System Description

INFOID:000000009460822

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
INPUT/OUTPUT SIGNAL CHART

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Encoder	Encoder pulse signal	Power window control	Front power window motor
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

POWER WINDOW OPERATION

- Power window system is activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch is turned OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Front & rear power window switches can open/close the corresponding windows.
- Power window lock switch can lock all power windows other than driver seat.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation (Front LH), power window will move in the reverse direction (Anti-Pinch Function).

POWER WINDOW AUTO-OPERATION (FRONT LH)

SYSTEM

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch turns to AUTO. A
- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating. B
- Main power window and door lock/unlock switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position. C
- Power window motor is operable in case encoder is malfunctioning. D

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF E

Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON). F
- When ignition switch is ON. G
- When timer time passes. (45 seconds) H
- AUTO function does not operate if encoder is malfunctioning. I

POWER WINDOW LOCK FUNCTION

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch. J

ANTI-PINCH OPERATION (FRONT LH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150mm. (5.9 in.) or 2 seconds when detected. K
- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating. L
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass. M
- Power window switch controls to lower the window glass for 150 mm. (5.9 in.) or 2 seconds after it detects encoder pulse signal frequency change. N

OPERATION CONDITION

- When door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed) O

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower. P

PWC

KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed. Q

The power window opening stops when the following operations are performed:

- When the unlock button is pressed for more than 15 seconds. R
- When the ignition switch is turned ON while the power window opening is operated. S
- When the unlock button is released. T

While retained power operation activate, keyless power window down function cannot be operated. U

Fail-safe

INFOID:000000009460823

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in the encoder signal that detects UP/DOWN speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass. V

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.

SYSTEM

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

Malfunction	Malfunction condition
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009955247

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000009955264

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY ANTI-PINCH]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000009460826

ECU	Reference
BCM	BCS-31, "Reference Value"
	BCS-50, "Fail Safe"
	BCS-50, "DTC Inspection Priority Chart"
	BCS-52, "DTC Index"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MAIN SWITCH

Reference Value



INFOID:000000009460827

TERMINAL LAYOUT



PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
1 (B)	Ground	Ground	—	—	0
2 (L)	16	Front power window motor RH DOWN signal	Output	When front RH switch in power window main switch is operated DOWN.	Battery voltage
4 (BG)	12	Encoder pulse signal 2	Input	When power window mo- tor operates.	 JMKIA0070GB
5 (R)	12	Encoder pulse signal 1	Input	When power window mo- tor operates.	 JMKIA0070GB
6 (SB)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (L)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY ANTI-PINCH]

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
9 (Y)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When driver side or passenger side door is opened during retained power operation.	0
12 (B)	Ground	Encoder ground	—	—	0
14 (P)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
16 (BR)	2	Front power window motor RH UP signal	Output	When front RH switch in power window main switch is operated UP.	Battery voltage
17 (W)	19	Front power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
18 (LG)	Ground	Battery power supply	Input	—	Battery voltage
19 (R)	17	Front power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O
P

POWER WINDOW SYSTEM

[LH FRONT ONLY ANTI-PINCH]

< WIRING DIAGRAM >


WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - With Left Front Only Power Window Anti- Pinch

INFOID:000000009460828

POWER WINDOW SYSTEM - WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM



ABKWA2192GB


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY ANTI-PINCH]


POWER WINDOW SYSTEM CONNECTORS - WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	W	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5N	BR	-
6N	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	BR	-
92J	LG	-
93J	Y	-
94J	SB	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	GR	-
6	Y	-
7	V	-
8	LG	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	V	-
7	V	-
8	B	-
12	SB	-
13	Y	-
14	BR	-
15	V	-
16	LG	-


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
8	LG	-
9	V	-
10	BR	-
14	SB	-


Terminal No.	Color of Wire	Signal Name
140	LG	PW POWER SUPPLY IGN
141	V	PW POWER SUPPLY BAT
142	BR	BAT FRONT DOOR
143	B	GND1

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
94	SB	AS DOOR SW
96	BR	DR DOOR SW

ABKIA3690GB


POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Terminal No.	Color of Wire	Signal Name
77J	L	-
92J	L	-
93J	SB	-
94J	LG	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	P	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
8	L	-
9	V	-
10	SB	-
14	L	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-
6	B	-
7	LG	-
8	L	-

ABKIA3691GB

A B C D E F G H I J L M N O P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	B111
Connector Name	JOINT CONNECTOR-B02
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	SB	-
8	L	-

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	W	UP
2	P	VCC (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
3	R	DN
4	B	GND (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
5	R	PLS A
6	BG	PLS B

Connector No.	D8
Connector Name	MAIN POWER WINDOW DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	W	DR UP
18	LG	BAT
19	R	DR DN

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	BR	-
7	LG	-
8	B	-
12	L	-
13	Y	-
14	SB	-
15	V	-
16	BR	-


ABKIA4834GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY ANTI-PINCH]


Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
6	L	-
7	LG	-
8	SB	-

Terminal No.	Color of Wire	Signal Name
4	BG	ENCODER 2
5	R	ENCODER 1
6	SB	RR DN
7	V	RR UP
8	L	RL DN
9	Y	RL UP
10	BR	ING
11	-	-
12	B	GND
13	-	-
14	P	ENCODER +
15	-	-
16	BR	AS UP

Connector No.	D12
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	L	AS DN
3	-	-


Connector No.	D111
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	Y	-
3	V	-

Terminal No.	Color of Wire	Signal Name
6	V	-
7	Y	-
8	SB	-
11	L	-
12	LG	-

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-

ABKIA4835GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

ABKIA4836GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009460829

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000009460830

Initial setting is necessary when battery terminal is disconnected.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000009460831

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the power window main switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-11, "Fail-safe"](#).
- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function
3. Retained power operation when ignition switch is OFF.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000009460832

Initial setting is necessary when replacing power window main switch.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000009460833

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the power window main switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
 - Check that AUTO-UP operates before inspection when system initialization is performed.
 - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-11, "Fail-safe"](#).
 - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
 - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation
 2. Anti-pinch function
 3. Retained power operation when ignition switch is OFF.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000009955265

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000009460835

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000009460836

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
NO >> Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000009460837

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors D8, D12 and ground.

Terminal (+)		Terminal (-)	Voltage (Approx.)
Main power window and door lock/unlock switch	Terminal		
D12	10	Ground	Battery voltage
D8	18		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M21	140	D12	10	Yes
	141	D8	18	

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		Ground
	141		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

3. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch RH) GO TO 8.
- NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM connector	Terminal	Ground	
M21	140		Ground
	141		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

PWC

Terminal		(-)	Window switch position (rear LH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal	Ground	UP	
D12	8			DOWN
	9		0	
			9	UP
	DOWN	Battery voltage		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D12	6	Ground	UP	Battery voltage
			DOWN	0
	7		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D8 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D8	17	Ground	UP	Battery voltage
			DOWN	0
	19		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

8. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

Terminal		(-)	Window switch position (front RH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D12	2	Ground	UP	Battery voltage
			DOWN	0
	16		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

POWER SUPPLY AND GROUND CIRCUIT

[LH FRONT ONLY ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000009460838

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D12.

Terminal		Main power window and door lock/unlock switch condition		Continuity
10	8	Rear LH	UP	Yes
10	6	Rear RH		
10	2	Front RH		
8	9	Rear LH	NEUTRAL	
6	7	Rear RH		
2	16	Front RH		
10	9	Rear LH	DOWN	
10	7	Rear RH		
10	16	Front RH		
1	12	-		

2. Check continuity between main power window and door lock/unlock switch D12 (power window lock switch) (Lock operation).

Terminal		Main power window and door lock/unlock switch condition		Continuity
9	1	Rear LH	UP	No
7		Rear RH		
16		Front RH		
8		Rear LH	NEUTRAL	
9		Rear RH		
7		Front RH		
6		Rear LH	DOWN	
2		Rear RH		
16		Front RH		

3. Check continuity between main power window and door lock/unlock switch D12 (power window lock switch) (Unlock operation).

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
7	Rear RH	
16	Front RH	
8	Rear LH	NEUTRAL
9	Rear LH	
7	Rear RH	
6	Rear RH	
2	Front RH	DOWN
16	Front RH	
8	Rear LH	
6	Rear RH	
2	Front RH	

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000009460839

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000009460840

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000009460841

Power Window And Door Lock/unlock Switch RH

1. CHECK POWER WINDOW MOTOR FUNCTION

Check front power window motor operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.

NO >> Refer to [PWC-35, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:00000009460842

Regarding Wiring Diagram information, refer to [PWC-18. "Wiring Diagram - With Left Front Only Power Window Anti- Pinch"](#).

Power Window And Door Lock/Unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch ON.
2. Check voltage between power window and door lock/unlock switch RH connector D110 and ground.

Terminal			Voltage (Approx.)
(+)		(-)	
Power window and door lock/unlock switch RH connector	Terminal		
D110	8	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector M21 and power window and door lock/unlock switch RH connector D110.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M21	140	D110	8	Yes

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D12 and power window and door lock/unlock switch RH connector D110.

Main power window and door lock/unlock switch connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
D12	2	D110	11	Yes
	16		12	

4. Check continuity between main power window and door lock/unlock switch connector D12 and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity	
D12	2			No
	16			

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM connector	Terminal		
M21	140	Ground	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).
 NO >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

5. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.
 Refer to [PWC-36. "FRONT POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).
 NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-65. "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Component Inspection

INFOID:000000009460843

COMPONENT INSPECTION

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH D110.

Terminal		Power window switch condition	Continuity
8	7	UP	Yes
12	6		
12	6	NEUTRAL	
7	11		
8	6	DOWN	
7	11		

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH is OK.
 NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-66. "Removal and Installation"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:000000009460844

- BCM supplies power.

POWER SUPPLY AND GROUND CIRCUIT

[LH FRONT ONLY ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000009460845

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.
- NO >> Refer to [PWC-37, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000009460846

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Rear Power Window Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear power window switch connector and ground.

Terminal		Terminal	Condition	Voltage (Approx.)	
(+)					(-)
Rear power window switch connector					
LH	D203	4	Ground	Ignition switch ON	Battery voltage
RH	D303				

Is the inspection result normal?

- YES >> GO TO 2 (Rear power window switch LH).
- YES >> GO TO 3 (Rear power window switch RH).
- NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch LH connector.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D12	8	D203	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	8	Ground	No
	9		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch RH connector.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D12	6	D303	7	Yes
	7		8	

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	6		No
	7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the harness or connectors.

4. CHECK HARNESS CONTINUITY

1. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
2. Check continuity between BCM connector and rear power window switch connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M21	140	LH	D203	4	Yes
		RH	D303		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-38. "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-67. "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000009460847

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
8	6		
8	6	NEUTRAL	
5	7		
4	6	DOWN	
5	7		

Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-67, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000009460848

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch.

DRIVER SIDE : Component Function Check

INFOID:000000009460849

1. CHECK FRONT POWER WINDOW MOTOR LH CIRCUIT

Check front power window motor LH operation with the main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-40, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009460850

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor LH connector D9 and ground.

Terminal		Main power window and door lock/unlock switch condition	Voltage (Approx.)
(+)	(-)		
Front power window motor LH connector	Terminal		
	D9	1	UP DOWN
	3	UP DOWN	0 Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D8 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D8	17	D9	1	Yes
	19		3	

4. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	17		No
	19		

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-41, "DRIVER SIDE : Special Repair Requirement"](#).
- NO >> Repair or replace harness.

3. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-41, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-41, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Component Inspection

INFOID:000000009460851

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-41, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Special Repair Requirement

INFOID:000000009460852

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
- NO >> Refer to [PWC-40, "DRIVER SIDE : Component Function Check"](#).

PASSENGER SIDE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

PASSENGER SIDE : Description

INFOID:000000009460853

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

PASSENGER SIDE : Component Function Check

INFOID:000000009460854

1. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH operation with main power window and door lock/unlock switch or power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-42, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009460855

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Front Power Window Motor RH Circuit Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D111 and ground.

Terminal		(-)	Front power window motor RH condition	Voltage (V) (Approx.)
(+) Front power window motor RH connector				
Terminal		Ground	UP	Battery voltage
D111	1		DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D110 and front power window motor RH connector D111.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D110	7	D111	1	Yes
	6		3	

4. Check continuity between power window and door lock/unlock switch connector D110 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D110	7		No
	6		

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-65, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-43, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#).

PASSENGER SIDE : Component Inspection

INFOID:000000009460856

COMPONENT INSPECTION

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D111.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#).

REAR LH

REAR LH : Description

INFOID:000000009460857

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000009460858

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-43, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:000000009460859

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Rear Power Window Motor LH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH LH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

Terminal		Window condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor LH connector	Terminal		
D204	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D203 and rear power window motor LH connector D204.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203	5	D204	1	Yes
	6		3	

4. Check continuity between rear power window switch LH connector D203 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203	5	Ground	No
	6		

Is the inspection result normal?

YES >> Check rear power window switch LH. Refer to [PWC-44, "REAR LH : Component Inspection"](#).

NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-44, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000009460860

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000009460861

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000009460862

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor RH operation with operating power window main switch or rear power window switch RH.

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Refer to [PWC-45, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000009460863

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector	Terminal		
D304	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector D303 and rear power window motor RH connector D304.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303	5	D304	1	Yes
	6		3	

4. Check continuity between rear power window switch RH connector D303 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303	5	Ground	No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch RH. Refer to [PWC-46, "REAR RH : Component Inspection"](#).
- NO >> Repair or replace harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-46, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:000000009460864

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Power window motor is OK.
- NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

ENCODER
DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000009460865

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000009460866

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO open/close operation normally with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Encoder operation is OK.
- NO >> Refer to [PWC-47, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009460867


Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Connect front power window motor LH.
2. Turn ignition switch ON.
3. Check signal between main power window and door lock/unlock switch connector D12 and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Refer to following signal
D12	4 5	
		Ground



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal			Voltage (Approx.)
(+)		(-)	
Front power window motor LH connector	Terminal		
D9	2	Ground	10

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D12 and front power window motor connector D9.

Main power window and door lock/ unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	14	D9	2	Yes

4. Check continuity between main power window and door lock/unlock switch connector D12 and ground.

Main power window and door lock/unlock switch con- nector	Terminal	Ground	Continuity
D12	14		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-65, "Removal and Installation"](#). After that, refer to [PWC-49, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	4		Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D12 and front power window motor LH connector D9.

Main power window and door lock/un- lock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	12	D9	4	Yes

Is the inspection result normal?

YES >> Check main power window and door lock/unlock switch. Refer to [PWC-33, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

2. Check continuity between main power window D12 and door lock/unlock switch connector and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	4	D9	6	Yes
	5		5	

3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	4		No
	5		

Is the inspection result normal?

- YES >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-49, "DRIVER SIDE : Special Repair Requirement"](#).
NO >> Repair or replace harness or connectors.

DRIVER SIDE : Special Repair Requirement

INFOID:000000009460868

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DOOR SWITCH

Description

INFOID:000000009460869

Detects door open/close condition.

Component Function Check

INFOID:000000009460870

1. CHECK FUNCTION

With CONSULT

Check door switches DOOR SW-DR, DOOR SW-AS in Data Monitor mode with CONSULT.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	

Is the inspection result normal?

- YES >> Door switch is OK.
- NO >> Refer to [PWC-50, "Diagnosis Procedure"](#).



Diagnosis Procedure

INFOID:000000009460871

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).

1. CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.

Terminals		(-)	Door condition	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector M19	96	Ground	OPEN	0
			CLOSE	 JPMIA0011GB
	OPEN		0	
	CLOSE		 JPMIA0011GB	

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
M19	96	Front door switch LH	Ground part of door switch	Yes
	94	Front door switch RH		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M19	96	Ground	No
	94		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness between BCM and door switch.

3.CHECK DOOR SWITCH

Refer to [PWC-51, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace malfunctioning door switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000009460872

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
3	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning door switch.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW LOCK SWITCH

Description

INFOID:000000009460873

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:000000009460874

1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-65. "Removal and Installation"](#). After that, refer to [PWC-52. "Special Repair Requirement"](#).
NO >> Check condition of harness and connector.

Special Repair Requirement

INFOID:000000009460875

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
NO >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

Diagnosis Procedure

INFOID:000000009460876

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-74, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-33, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check main power window and door lock/unlock switch power supply and ground circuit.

Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460877

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-40, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460878

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-34, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-42, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460879

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-37, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-43, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460880

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-37, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-42, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000009460881

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-47, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:00000009460882

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-47, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000009460883

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-100, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000009460884

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-65, "Removal and Installation"](#). After that, [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000009460885

1. PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2. CHECK FRONT DOOR LOCK ASSEMBLY LH (DOOR KEY CYLINDER SWITCH)

Check front door lock assembly LH (door key cylinder switch).

Refer to [PWC-52, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460886

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [DLK-144, "Component Function Check"](#).

2.CHECK POWER WINDOW OPERATION

Check power window operation.

In the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [PWC-40, "DRIVER SIDE : Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRE-INSPECTION FOR DIAGNOSTIC

< PERIODIC MAINTENANCE >

[LH FRONT ONLY ANTI-PINCH]

PERIODIC MAINTENANCE

PRE-INSPECTION FOR DIAGNOSTIC

Basic Inspection

INFOID:000000009460887

BASIC INSPECTION

1.INSPECTION START

1. Check the service history.
2. Check the following parts.
 - Fuse/circuit breaker blown.
 - Poor connection, open or short circuit of harness connector.
 - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace the malfunctioning parts.

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

REMOVAL AND INSTALLATION

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:000000009460888


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the main power window and door lock/unlock switch and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the main power window and door lock/unlock switch.
4. Release the four pawls (two on each side) using a suitable tool, then separate the main power window and door lock/unlock switch (1) from the main power window and door lock switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is disconnected from the harness connector it is necessary to perform the initialization procedure. Refer to [PWC-27. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000009460889


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the power window switch and door lock/unlock switch RH finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the power window and door lock/unlock switch RH.
4. Release the four pawls (two on each side) using a suitable tool, then separate the power window and door lock/unlock switch RH (1) from the power window and door lock/unlock switch RH finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:000000009460890


REMOVAL

1. Release the pawls using a suitable tool and lift the rear power window switch and finisher as an assembly by starting at the rear, then pull upward and remove
2. Disconnect the harness connector from the rear power window switch.
3. Release the pawl (one on each side) using a suitable tool, then separate the rear power window switch (1) from the rear power switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009951562

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000009460892

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[LH & RH FRONT ANTI-PINCH]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009460893

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH & RH FRONT ANTI-PINCH]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009460894



AWKIA2029ZZ

- | | | |
|--|--|---|
| 1. BCM (view with combination meter removed) | 2. Front power window motor LH (RH similar) | 3. Rear power window motor LH (RH similar) |
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

Component Description

INFOID:000000009460895

FRONT WINDOW ANTI-PINCH SYSTEM

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

Component	Function
BCM	<ul style="list-style-type: none"> Supplies power to power window switches. Controls retained power.
Front power window motor LH	<ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Front power window motor RH	<ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> Directly controls all power window motor of all doors. Controls anti-pinch operation of front power window LH.
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> Controls front power window motor RH. Controls anti-pinch operation of front power window RH.
Rear power window switch	<ul style="list-style-type: none"> Controls rear power window motors LH and RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch & rear power window switch.
Front door lock assembly LH (key cylinder switch)	Transmits operation condition of key cylinder switch to power window main switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

SYSTEM

System Diagram

INFOID:000000009460896

FRONT WINDOW ANTI-PINCH SYSTEM



System Description

INFOID:000000009460897

POWER WINDOW MAIN SWITCH
INPUT/OUTPUT SIGNAL CHART

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Key cylinder switch	LOCK/UNLOCK signal (more than 1 seconds over)	Power window control	Front power window motor
Encoder	Encoder pulse signal		
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
INPUT/OUTPUT SIGNAL CHART

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

Item	Input signal to front power window switch	Front power window switch function	Actuator
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal	Power window control	Front power window motor RH
Encoder	Encoder pulse signal		
BCM	RAP signal		

POWER WINDOW OPERATION

- Power window system activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch turns OFF.
- Power window main switch (driver side) can open/close all windows.
- Front & rear power window switch can open/close the corresponding windows.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation (Front LH & RH), power window will move in the reverse direction (Anti-Pinch Function).

POWER WINDOW AUTO-OPERATION (FRONT LH & RH)

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch & power window and door lock/unlock switch RH turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.
- AUTO function does not operate if encoder is malfunctioning.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF

Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes. (45 seconds)

POWER WINDOW LOCK FUNCTION

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window switch.

ANTI-PINCH OPERATION (FRONT LH & RH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.9 in.) or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm (5.9 in.) or 2 seconds after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for more than 1 second to OPEN or CLOSE front power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL when operating.

OPERATION CONDITION

- Ignition switch OFF

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

- Hold door key cylinder to LOCK position for more than 1 second to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for more than 1 second to perform OPEN operation of the door glass.

KEYLESS POWER WINDOW DOWN OPERATION (FRONT LH & RH)

Front power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3^(NOTE) seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Fail-safe

INFOID:000000009460898

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects UP/DOWN speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more that the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more that the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009955266

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000009955267

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000009460901

ECU	Reference
BCM	BCS-31, "Reference Value"
	BCS-50, "Fail Safe"
	BCS-50, "DTC Inspection Priority Chart"
	BCS-52, "DTC Index"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT ANTI-PINCH]

POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000009460902

TERMINAL LAYOUT



PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
1 (B)	Ground	Ground	—	—	0
3 (P)	Ground	Door key cylinder switch LH LOCK signal	Input	Key position (Neutral/Unlocked → Locked)	5 → 0
4 (BG)	12	Encoder pulse signal 2	Input	When power window motor operates.	 <small>JMKIA0070GB</small>
5 (R)	12	Encoder pulse signal 1	Input	When power window motor operates.	 <small>JMKIA0070GB</small>
6 (SB)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (L)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage
9 (Y)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When front LH or RH door is opened during retained power operation.	0
11 (P)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	
12 (P)	Ground	Encoder ground	—	—	0
14 (LG)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
15 (G)	Ground	Door key cylinder switch LH UNLOCK signal	Input	Key position (Neutral/Locked → Unlocked)	5 → 0
17 (W)	19	Front door power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
18 (LG)		Battery power supply	Input	—	Battery voltage
19 (R)	17	Front door power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage

A
B
C
D
E
F
G
H
I
J
PWC

Fail Safe

INFOID:000000009460903

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

L
M
N
O
P

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT ANTI-PINCH]

FRONT POWER WINDOW SWITCH

Reference Value

INFOID:000000009460904

TERMINAL LAYOUT



PHYSICAL VALUES

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
3 (P)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	<p>JPMIA0013GB</p>
4 (BG)	Ground	Encoder ground	—	—	0
5 (W)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	10
7 (B)	Ground	Ground	—	—	0
8 (LG)	Ground	Battery power supply	Input	—	Battery voltage
9 (LG)	4	Encoder pulse signal 1	Input	When power window motor operates.	<p>JMKIA0070GB</p>
10 (G)	4	Encoder pulse signal 2	Input	When power window motor operates.	<p>JMKIA0070GB</p>

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
11 (R)	12	Power window motor UP signal	Output	When power window motor is UP at operated.	Battery voltage
12 (P)	11	Power window motor DOWN signal	Output	When power window motor is DOWN at operated.	Battery voltage

Fail Safe

INFOID:000000009460905

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT ANTI-PINCH]


WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - With Left And Right Front Power Window Anti-Pinch

INFOID:000000009460906

POWER WINDOW SYSTEM - WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM




ABKWA2190GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




POWER WINDOW SYSTEM CONNECTORS - WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	W	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5N	BR	-
6N	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	BR	-
92J	LG	-
93J	Y	-
94J	SB	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN





Terminal No.	Color of Wire	Signal Name
8	LG	-
9	V	-
10	BR	-
14	SB	-

POWER WINDOW SYSTEM

< WIRING DIAGRAM >



[LH & RH FRONT ANTI-PINCH]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
54	P	PW LIN

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	GR	-
5	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	V	-
8	B	-
12	SB	-
13	Y	-
14	BR	-
15	V	-
16	LG	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	P	-

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
140	LG	P/W POWER SUPPLY IGN
141	V	P/W POWER SUPPLY BAT
142	BR	BAT FRONT DOOR
143	B	GND1

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
94	SB	AS DOOR SW
96	BR	DR DOOR SW

ABKIA4846GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	P	-
18	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	P	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	L	-
92J	L	-
93J	SB	-
94J	LG	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-
6	B	-
7	LG	-
8	L	-

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	SB	-
8	L	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
8	L	-
9	V	-
10	SB	-
14	L	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	LG	-
8	B	-
12	L	-
13	Y	-
14	SB	-
15	V	-
16	BR	-

Connector No.	B111
Connector Name	JOINT CONNECTOR-B02
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

ABKIA3685GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT ANTI-PINCH]


Terminal No.	Color of Wire	Signal Name
6	SB	UNLOCK
7	V	RR UP
8	L	AS UP
9	Y	ENCODER SIG2
10	BR	IGN
11	P	COM
12	P	ENCODER GND
13	-	-
14	LG	ENCODER +
15	G	UNLOCK
16	-	-

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	-	-
3	P	LOCK
4	BG	ENCODER SIG2
5	R	ENCODER SIG1

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	P	-
18	B	-

Terminal No.	Color of Wire	Signal Name
1	W	UP
2	LG	VCC (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
3	R	DN
4	P	GND (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
5	R	PSL A
6	BG	PSL B

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	GREEN



Connector No.	D8
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	W	DR UP
18	LG	BAT
19	R	DR DN

ABKIA4826GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	R	UP SW
2	W	VCC
3	P	DOWN SW
4	BG	GND
5	LG	PULSE A
6	G	PULSE B

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-
5	LG	-

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	G	-
6	P	-


Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	P	-

Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	P	COM
4	BG	ENCODER GND
5	W	ENCODER +
6	-	-
7	B	GND
8	LG	BAT
9	LG	ENCODER SGN1
10	G	ENCODER SGN2
11	R	UP
12	P	DOWN

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



ABKIA4827GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

ABKIA4828GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009460907

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000009460908

Initial setting is necessary when battery terminal is disconnected.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000009460909

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm (5.91 in.) or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the power window main switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-79, "Fail Safe"](#).
- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function
3. Retained power operation when ignition switch is OFF.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000009460910

Initial setting is necessary when replacing power window main switch.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000009460911

INITIALIZATION PROCEDURE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm (5.91 in.) or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the power window main switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
 - Check that AUTO-UP operates before inspection when system initialization is performed.
 - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-79, "Fail Safe"](#).
 - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
 - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation
 2. Anti-pinch function
 3. Retained power operation when ignition switch is OFF.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000009955268

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000009460913

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000009460914

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
- NO >> Refer to [PWC-96, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000009460915

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors and ground.

Terminal		Terminal	Voltage (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector			
D7	10	Ground	Battery voltage
D8	18		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M21	140	D7	10	Yes
	141	D8	18	

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		
	141		

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
 YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
 YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
 NO >> Repair or replace the harness and connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	Battery voltage
M21	140	
	141	

Is the measurement value within the specification?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

PWC

Terminal		Window switch position (rear LH)	Voltage (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	8	UP	Battery voltage
		DOWN	0
	9	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)
(+)	Terminal			
Main power window and door lock/unlock switch connector				
D7	7	Ground	UP	Battery voltage
			DOWN	0
	6		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)
(+)	Terminal			
Main power window and door lock/unlock switch connector				
D7	17	Ground	UP	Battery voltage
			DOWN	0
	19		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#).

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000009460916

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D7.

Terminal		Main power window and door lock/unlock switch condition	Continuity
10	8	Rear LH	Yes
10	7	Rear RH	
8	9	Rear LH	
6	7	Rear RH	
10	9	Rear LH	
10	6	Rear RH	
1	12	-	

2. Check continuity between main power window and door lock/unlock switch D7 (power window lock switch). (Lock operation).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
6	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
7	Rear LH	DOWN
6	Rear RH	
8	Rear LH	DOWN
7	Rear RH	

3. Check continuity between main power window and door lock/unlock switch D7 (power window lock switch). (Unlock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
6	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
6	Rear LH	DOWN
7	Rear RH	
8	Rear LH	DOWN
7	Rear RH	

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000009460917

PWC

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Refer to [PWC-105, "DRIVER SIDE : Component Function Check"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000009460918

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000009460919

Power Window And Door Lock/unlock Switch RH

1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Check front power window motor RH operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
NO >> Refer to [PWC-100, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000009460920

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window And Door Lock/unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between power window and door lock/unlock switch RH connector D105 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	
D105	8	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and power window and door lock/unlock switch RH.
- Check continuity between BCM connector M21 and power window and door lock/unlock switch RH connector D105.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M21	141	D105	8	Yes

- Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	141		No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH	Terminal	Ground	Continuity
D105	7		Yes

Is the inspection result normal?

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

- YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).
NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	141	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).
NO >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Special Repair Requirement

INFOID:000000009460921

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-93. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
NO >> Refer to [PWC-100. "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:000000009460922

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000009460923

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.
NO >> Refer to [PWC-101. "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000009460924

Regarding Wiring Diagram information, refer to [PWC-83. "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Rear Power Window Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between rear power window switch connector and ground.

Terminal		Terminal	Condition	Voltage (Approx.)
(+)				
Rear power window switch connector		4	Ignition switch ON	Battery voltage
LH	D203			
RH	D303			

Is the inspection result normal?

- YES >> GO TO 2 (Rear power window switch LH).
- YES >> GO TO 3 (Rear power window switch RH).
- NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and rear power window switch LH connector D203.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7	8	D203	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	8		Ground
	9		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and rear power window switch RH connector D303.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7	6	D303	7	Yes
	7		8	

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	6		Ground
	7		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

4. CHECK HARNESS CONTINUITY

1. Disconnect BCM and rear power window switch.
2. Check continuity between BCM connector and rear power window switch connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M21	140	LH	D203	4	Yes
		RH	D303		

3. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-144, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000009460925

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH D203.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
8	6		
8	6	NEUTRAL	
5	7		
6	4	DOWN	
5	7		

Is the inspection result normal?

YES >> Rear power window switch LH is OK.

NO >> Replace rear power window switch. Refer to [PWC-144, "Removal and Installation"](#).

2. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH D303.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
7	6		
7	6	NEUTRAL	
5	8		
6	4	DOWN	
5	8		

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

YES >> Rear power window switch RH is OK.

NO >> Replace rear power window switch. Refer to [PWC-144, "Removal and Installation"](#).

POWER WINDOW MOTOR

[LH & RH FRONT ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000009460926

Door glass moves UP/DOWN by receiving the signal from power window main switch.

DRIVER SIDE : Component Function Check

INFOID:000000009460927

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor LH operation with operating main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Refer to [PWC-105, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009460928

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector D9 and ground.

Terminal (+)		Terminal (-)	Main power window and door lock/unlock switch condition	Voltage (Approx.)
Power window motor LH connector	Terminal			
D9	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D8 and front power window motor connector LH D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D8	17	D9	1	Yes
	19		3	

4. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	17		No
	19		

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-106, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

3. CHECK POWER WINDOW MOTOR

Check front power window motor LH.

Refer to [PWC-106, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-106, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Component Inspection

INFOID:000000009460929

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-106, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Special Repair Requirement

INFOID:000000009460930

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-113, "DRIVER SIDE : Component Function Check"](#).

PASSENGER SIDE

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

PASSENGER SIDE : Description

INFOID:00000009460931

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

PASSENGER SIDE : Component Function Check

INFOID:00000009460932

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check power window motor operation with operating main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-107, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:00000009460933

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Front Power Window Motor RH Circuit Check

1. CHECK FRONT POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D104 and ground.

Terminal		Terminal	Front power window motor RH condition	Voltage (Approx.)
(+)				
Front power window motor RH connector	Terminal			
D104	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	11	D104	1	Yes
	12		3	

4. Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	11		Ground
	12		

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-143, "Removal and Installation"](#). After that, refer to [PWC-108, "PASSENGER SIDE : Special Repair Requirement"](#).
- NO >> Repair or replace harness or connectors.

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-108, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-108, "PASSENGER SIDE : Special Repair Requirement"](#).

PASSENGER SIDE : Component Inspection

INFOID:000000009460934

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D104.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-108, "PASSENGER SIDE : Special Repair Requirement"](#).

PASSENGER SIDE : Special Repair Requirement

INFOID:000000009460935

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [PWC-115, "PASSENGER SIDE : Component Function Check"](#).

REAR LH

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

REAR LH : Description

INFOID:000000009460936

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000009460937

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
- NO >> Refer to [PWC-109, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:000000009460938

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Motor Circuit Check

1. CHECK REAR POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

Terminal		Window condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor LH connector	Terminal		
	D204	Ground	
	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D203 and rear power window motor LH connector D204.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203	5	D204	1	Yes
	6		3	

4. Check continuity between rear power window switch LH connector D203 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203	5		
	6		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Is the inspection result normal?

- YES >> Check rear power window switch LH. Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).
NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-110, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000009460939

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000009460940

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000009460941

1. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

Check rear power window motor RH operation with operating main power window and door lock/unlock switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
NO >> Refer to [PWC-110, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000009460942

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector	Terminal		
D304	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector D303 and rear power window motor RH connector D304.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303	5	D304	1	Yes
	6		3	

4. Check continuity between rear power window switch RH connector D303 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303	5	Ground	No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch RH. Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).
- NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.
Refer to [PWC-111, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:000000009460943

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

NO >> Replace rear power window motor RH. Refer to [GW-25. "Removal and Installation"](#).

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ENCODER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000009460944

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000009460945

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-113, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009460946


Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector D7 and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Refer to following signal
D7	4	
	5	



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor LH connector	Terminal	
D9	2	10

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	14	D9	2	Yes

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	14		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	4		Yes

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	12	D9	4	Yes

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	5	D9	5	Yes
	4		6	

3. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	5	Ground	No
	4		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000009460947

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

PASSENGER SIDE : Component Function Check

INFOID:000000009460948

1. CHECK ENCODER OPERATION

Check front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-115, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009460949

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

1. CHECK ENCODER SIGNAL

1. Connect front power window motor RH.
2. Turn ignition switch ON.
3. Check signal between power window and door lock/unlock switch RH connector D105 and ground with oscilloscope.


Terminals		Signal (Reference value)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	Refer to following signal
D105	9	
	10	

PWC

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

- Turn ignition switch ON.
- Check voltage between front power window motor RH connector D105 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor RH connector	Terminal	
D105	5	Ground
		10

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH and front power window motor RH.
- Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	5	D104	2	Yes

- Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	5		No

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-143, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
 NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect front power window motor RH.
- Check continuity between front power window motor RH connector D104 and ground.

Front power window motor RH connector	Terminal	Ground	Continuity
D104	4		Yes

Is the inspection result normal?

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

- YES >> GO TO 6.
- NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	4	D104	4	Yes

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-143, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	9	D104	5	Yes
	10		6	

3. Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	9	Ground	No
	10		

Is the inspection result normal?

- YES >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DOOR SWITCH

Description

INFOID:000000009460950

Detects door open/close condition.

Component Function Check

INFOID:000000009460951

1. CHECK FUNCTION

With CONSULT

Check door switches DOOR SW-DR, DOOR SW-AS in Data Monitor mode with CONSULT.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	

Is the inspection result normal?

- YES >> Door switch is OK.
- NO >> Refer to [PWC-118, "Diagnosis Procedure"](#).



Diagnosis Procedure

INFOID:000000009460952

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).

1. CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.

Terminals		(-)	Door condition	Voltage (V) (Approx.)
(+)	Terminal			
BCM connector M19	96	Ground	OPEN	0
			CLOSE	 JPMIA0011GB
	OPEN		0	
	CLOSE		 JPMIA0011GB	

Is the inspection result normal?

- YES >> GO TO 4
- NO >> GO TO 2

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
M19	96	Front door switch LH	Ground part of door switch	Yes
	94	Front door switch RH		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M19	96		No
	94		

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness between BCM and door switch.

3. CHECK DOOR SWITCH

Refer to [PWC-119, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Replace malfunctioning door switch.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000009460953

1. CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
3	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace malfunctioning door switch.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DOOR KEY CYLINDER SWITCH

Description

INFOID:000000009460954

Power window main switch detects condition of the door key cylinder and transmits to BCM as the LOCK or UNLOCK signals.

Component Function Check

INFOID:000000009460955

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check ("KEY CYL LK-SW", "KEY CYL UN-SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

- YES >> Key cylinder switch is OK.
NO >> Refer to [PWC-120, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009460956

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

Terminals		Key position	Voltage (Approx.)	
(+)	(-)			
Main power window and door lock/unlock switch connector	Terminal	Ground	Lock	0
			Neutral/Unlock	5
D7	3		Unlock	0
			Neutral/Lock	5
	15			

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. After that, refer to [PWC-122, "Special Repair Requirement"](#).
NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front door lock assembly LH (key cylinder switch).
3. Check continuity between main power window and door lock/unlock switch connector D7 and front door lock assembly LH (key cylinder switch) connector D14.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Front door lock assembly LH (key cylinder switch) connector	Terminal	Continuity
D7	3	D14	6	Yes
	15		5	

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	3	Ground	No
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH (key cylinder switch) connector D14 and ground.

Front door lock assembly LH (key cylinder switch) connector	Terminal	Ground	Continuity
D14	4	Ground	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [PWC-121, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace front door lock assembly LH (door key cylinder switch). After that, refer to [PWC-122, "Special Repair Requirement"](#).

Component Inspection

INFOID:000000009460957

PWC

COMPONENT INSPECTION

1. CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly LH (key cylinder switch) D14.

Terminal		Key position	Continuity
Front door lock assembly LH (key cylinder switch) connector			
5	4	Unlock	Yes
		Neutral/Lock	No
6		Lock	Yes
		Neutral/Unlock	No

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace front door lock assembly LH (key cylinder switch). After that, refer to [PWC-122, "Special Repair Requirement"](#).

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Special Repair Requirement

INFOID:000000009460958

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [DLK-84, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000009460959

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000009460960

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-123, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000009460961

PWC

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Serial Link Check

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL


1. Remove Intelligent Key, and close front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M18	54	Ground



PIIA1297E

Is the inspection result normal?

- YES >> Power window serial link is OK.
- NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector M18 and main power window and door lock/unlock switch connector D7.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M18	54	D7	11	Yes

4. Check continuity between BCM connector M18 and ground.

BCM connector	Terminal	Ground	Continuity
M18	54		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace harness or connectors.

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000009460962

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000009460963

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-125, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000009460964

Regarding Wiring Diagram information, refer to [PWC-83, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Serial Link Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

1. Remove Intelligent Key, and close the front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M18	54	

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check continuity between BCM connector M18 and power window and door lock/unlock switch RH connector D105.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M18	54	D105	3	Yes

4. Check continuity between BCM connector M18 and ground.

BCM connector	Terminal	Ground	Continuity
M18	54		No

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace the harness or connectors.

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW LOCK SWITCH

Description

INFOID:000000009460965

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:000000009460966

1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-142, "Removal and Installation"](#). After that, refer to [PWC-127, "Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

Special Repair Requirement

INFOID:000000009460967

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
- NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

Diagnosis Procedure

INFOID:000000009460968

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-74, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-98, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.

Refer to [PWC-96, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.

Refer to [PWC-123, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460969

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-105, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460970

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-100, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-124, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-107, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460971

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-101, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-109, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460972

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-101, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-110, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000009460973

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-113, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000009460974

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-115, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000009460975

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-113, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000009460976

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-115, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000009460977

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-100, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000009460978

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-142, "Removal and Installation"](#). After that, [PWC-99, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

>> INSPECTION END

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000009460979

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-93, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2.CHECK FRONT DOOR LOCK ASSEMBLY LH (DOOR KEY CYLINDER SWITCH)

Check front door lock assembly LH (door key cylinder switch).

Refer to [PWC-120, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009460980

1. CHECK INTELLIGENT KEY FUNCTION

Check Intelligent Key function.

Refer to [DLK-146, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

PRE-INSPECTION FOR DIAGNOSTIC

< PERIODIC MAINTENANCE >

[LH & RH FRONT ANTI-PINCH]

PERIODIC MAINTENANCE

PRE-INSPECTION FOR DIAGNOSTIC

Basic Inspection

INFOID:000000009460981

BASIC INSPECTION

1. INSPECTION START

1. Check the service history.
2. Check the following parts.
 - Fuse/circuit breaker blown.
 - Poor connection, open or short circuit of harness connector.
 - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

REMOVAL AND INSTALLATION

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:000000009460982


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the main power window and door lock/unlock switch and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the main power window and door lock/unlock switch.
4. Release the four pawls (two on each side) using a suitable tool, then separate the main power window and door lock/unlock switch (1) from the main power window and door lock switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is disconnected from the harness connector it is necessary to perform the initialization procedure. Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000009460983


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the power window and door lock/unlock switch RH and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the power window and door lock/unlock switch RH.
4. Release the four pawls (two on each side) using a suitable tool, then separate the power window and door lock/unlock switch RH (1) from the power window and door lock switch RH finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O
P

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:000000009460984


REMOVAL

1. Release the pawls using a suitable tool and lift the rear power window switch and finisher as an assembly by starting at the rear, then pull upward and remove
2. Disconnect the harness connector from the rear power window switch.
3. Release the pawl (one on each side) using a suitable tool, then separate the rear power window switch (1) from the rear power switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



ALKIA2631ZZ

INSTALLATION

Installation is in the reverse order of removal.