

# SECTION **WCS**

## WARNING CHIME SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<b>PRECAUTION</b> .....	<b>COMMON ITEM</b> .....	
<b>PRECAUTIONS</b> .....	COMMON ITEM : CONSULT Function (BCM -	
Precaution for Supplemental Restraint System	COMMON ITEM) .....	
(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	<b>BUZZER</b> .....	
.....	BUZZER : CONSULT Function (BCM - BUZZER)...	
<b>SYSTEM DESCRIPTION</b> .....	<b>ECU DIAGNOSIS INFORMATION</b> .....	
<b>COMPONENT PARTS</b> .....	<b>BCM, COMBINATION METER</b> .....	
Component Parts Location .....	List of ECU Reference .....	
Component Description .....	<b>WIRING DIAGRAM</b> .....	
<b>SYSTEM</b> .....	<b>WARNING CHIME SYSTEM</b> .....	
<b>WARNING CHIME SYSTEM</b> .....	Wiring Diagram .....	
WARNING CHIME SYSTEM : System Diagram .....	<b>BASIC INSPECTION</b> .....	
WARNING CHIME SYSTEM : System Description .....	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	
.....	Work Flow .....	
<b>LIGHT REMINDER WARNING CHIME</b> .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	
LIGHT REMINDER WARNING CHIME : System	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	
Diagram .....	<b>COMBINATION METER</b> .....	
LIGHT REMINDER WARNING CHIME : System	COMBINATION METER : Diagnosis Procedure ....	
Description .....	<b>BCM (BODY CONTROL MODULE)</b> .....	
<b>SEAT BELT WARNING CHIME</b> .....	BCM (BODY CONTROL MODULE) : Diagnosis	
SEAT BELT WARNING CHIME : System Diagram	Procedure .....	
.....	<b>METER BUZZER CIRCUIT</b> .....	
SEAT BELT WARNING CHIME : System Description	Description .....	
.....	Component Function Check .....	
<b>PARKING BRAKE RELEASE WARNING CHIME</b> .....	Diagnosis Procedure .....	
PARKING BRAKE RELEASE WARNING CHIME	<b>SEAT BELT BUCKLE SWITCH SIGNAL CIR-</b>	
: System Diagram .....	<b>CUIT</b> .....	
PARKING BRAKE RELEASE WARNING CHIME	Description .....	
: System Description .....	Component Function Check .....	
<b>DIAGNOSIS SYSTEM (METER)</b> .....	Diagnosis Procedure .....	
Description .....		
CONSULT Function (METER/M&A) .....		
<b>DIAGNOSIS SYSTEM (BCM)</b> .....		

WCS

Component Inspection .....	29	Diagnosis Procedure .....	31
<b>SYMPTOM DIAGNOSIS .....</b>	<b>30</b>	<b>THE LIGHT REMINDER WARNING DOES NOT SOUND .....</b>	<b>32</b>
<b>WARNING CHIME SYSTEM SYMPTOMS .....</b>	<b>30</b>	Description .....	32
Symptom Table .....	30	Diagnosis Procedure .....	32
<b>THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND .....</b>	<b>31</b>	<b>THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND .....</b>	<b>33</b>
Description .....	31	Description .....	33
		Diagnosis Procedure .....	33

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009955588

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009462877



AWNIA2649ZZ

- |   |  |   |
|---|--|---|
| 1. Combination switch (lighting and turn signal switch) | 2. Combination meter                         | 3. Seat belt buckle switch LH   |
| 4. Front door switch LH                                 | 5. BCM (view with combination meter removed) | 6. Parking brake switch (view with lower instrument panel LH removed) |
| 7. ABS actuator and electric unit (control unit)        |  |   |

#### Component Description

INFOID:000000009462878

Unit	Description
Combination switch (lighting and turn signal switch)	Transmits the lighting switch signal to the BCM.
Combination meter	<ul style="list-style-type: none"> <li>Receives a buzzer output signal from the BCM with CAN communication and sounds the buzzer.</li> <li>Receives the seat belt buckle switch signal from the seat belt buckle switch LH (driver seat) and transmits it to the BCM via CAN communication.</li> <li>Judges whether the parking brake is released using the vehicle speed signal and the parking brake switch signal, and sounds the buzzer if necessary.</li> </ul>
BCM	Based on the signals received from various units and switches, transmits the buzzer output signal to the combination meter via CAN communication.
Front door switch LH	Transmits the front door switch LH signal to the BCM.
Seat belt buckle switch LH (driver seat)	Transmits the seat belt buckle switch LH (driver seat) signal to the combination meter.

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

Unit	Description
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### WARNING CHIME SYSTEM

#### WARNING CHIME SYSTEM : System Diagram

INFOID:000000009462879



#### WARNING CHIME SYSTEM : System Description

INFOID:000000009462880


##### DESCRIPTION

- The buzzer for the warning chime system is installed in the combination meter.
- The buzzer sounds when the combination meter receives a buzzer output signal from the BCM.
- The BCM receives signals from various units and transmits a buzzer output signal to the combination meter with CAN communication line if it judges that the warning buzzer should be activated.

### LIGHT REMINDER WARNING CHIME

#### LIGHT REMINDER WARNING CHIME : System Diagram

INFOID:000000009462881



#### LIGHT REMINDER WARNING CHIME : System Description

INFOID:000000009462882

##### DESCRIPTION

With ignition switch in OFF or ACC position, driver door open, and lighting switch in 1st or 2nd position, the light warning chime will sound.

- BCM detects ignition switch in OFF or ACC position, front door switch LH ON, and lighting switch in 1st or 2nd position. And then transmits buzzer output signal (light reminder warning chime) to combination meter with CAN communication line.
- When combination meter receives buzzer output signal (light reminder warning chime), it sounds the buzzer.

##### WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Lighting switch is at 1st or 2nd position
- Ignition switch is at OFF or ACC
- Front door switch LH is ON

# SYSTEM

## < SYSTEM DESCRIPTION >

### WARNING CANCEL CONDITIONS


Warning is canceled if any of the following conditions is fulfilled.

- Lighting switch OFF
- Ignition switch ON
- Front door switch LH is OFF

### SEAT BELT WARNING CHIME

#### SEAT BELT WARNING CHIME : System Diagram

INFOID:000000009462883



#### SEAT BELT WARNING CHIME : System Description

INFOID:000000009462884

##### DESCRIPTION

With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime will sound for approximately 6 seconds.

- BCM receives seat belt buckle switch LH (driver seat) signal from combination meter via CAN communication.
- BCM detects ignition switch turned ON and seat belt buckle switch LH (driver seat) is ON, and then transmits buzzer output signal (seat belt warning chime) to combination meter via CAN communication.
- When combination meter receives buzzer output signal (seat belt warning chime), it sounds the buzzer.

##### WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Ignition switch OFF→ON
- Seat buckle switch LH (driver seat) is ON (driver seat belt not fastened)

##### WARNING CANCEL CONDITIONS


Cancels the warning if any of the following conditions is fulfilled.

- Ignition switch OFF
- Seat buckle switch LH (driver seat) is OFF (driver seat belt fastened)
- 90 seconds have passed since the start of the warning

### PARKING BRAKE RELEASE WARNING CHIME

#### PARKING BRAKE RELEASE WARNING CHIME : System Diagram

INFOID:000000009462885



WCS

#### PARKING BRAKE RELEASE WARNING CHIME : System Description

INFOID:000000009462886

##### DESCRIPTION

## SYSTEM

### < SYSTEM DESCRIPTION >

---

- The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line.
- The combination meter judges whether the parking brake is released using the parking brake switch signal from the parking brake switch, and sounds the warning buzzer if necessary.

### WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Vehicle speed is approximately 4.3 MPH (7 km/h) or higher
- Parking brake switch ON

### WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.

- Vehicle speed is approximately 1.9 MPH (3 km/h) or less
- Parking brake switch OFF

# DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (METER)

### Description

INFOID:000000009941189

#### COMBINATION METER SELF-DIAGNOSIS MODE

The following meter functions can be checked during Combination Meter Self-Diagnosis Mode:

- Pointer sweep of speedometer, tachometer and gauges.
- Illumination of all LCD segments and color patterns for meter displays.
- Illumination of all lamps/LEDs that are controlled by the combination meter (regardless of switch status).


#### STARTING COMBINATION METER SELF-DIAGNOSIS MODE

##### NOTE:

- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [MWI-58, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-82, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

#### How to Initiate Self-Diagnosis Mode

1. Press and hold the trip reset switch while turning the ignition switch ON. After 2 seconds release trip reset switch, then press the trip reset switch 3 times within 7 seconds after the ignition switch is turned ON.
2. When the diagnosis function is activated, the meter illuminates all of the following:
  - Warning lights/indicators.
  - Meter assembly.
  - Information display color bars red, green, blue and white (1).
  - Odometer, trip A/B odometers and CVT indicator LCD display segments (2).
3. Pressing and holding the trip reset switch performs the pointer sweep test.



### CONSULT Function (METER/M&A)

INFOID:000000009941190

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

WCS

#### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

METER/M&A Diagnosis mode	Description
SELF DIAGNOSTIC RESULT	Displays combination meter self-diagnosis results.
DATA MONITOR	Displays combination meter input/output data in real time.
WARNING HISTORY	Lighting history of the warning lamp and indicator lamp can be checked.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

#### SELF DIAG RESULT

## DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Refer to [MWI-27, "DTC Index"](#).

### DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [mph or km/h]	X	Displays the value of vehicle speed signal.
SPEED OUTPUT [mph or km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication.
ODO OUTPUT [mph or km/h]		Odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM via CAN communication.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°F] or [°C]	X	Displays the value of engine coolant temperature signal, which is input from ECM.
ABS W/L [On/Off]		Displays [ON/OFF] condition of ABS warning indicator.
VDC/TCS IND [ON/OFF]		Displays [ON/OFF] condition of VDC OFF indicator lamp.
SLIP IND [ON/OFF]		Displays [ON/OFF] condition of SLIP indicator lamp.
BRAKE W/L [ON/OFF]		Displays [ON/OFF] condition of brake warning indicator.
DOOR W/L [ON/OFF]		Displays [ON/OFF] condition of door warning message.
TRUNK/GLAS-H [On/Off]		Displays [ON/OFF] condition of trunk warning message.
HI-BEAM IND [ON/OFF]		Displays [ON/OFF] condition of high beam indicator.
TURN IND [On/Off]		Displays [ON/OFF] condition of turn indicator.
FR FOG IND [On/Off]		Displays [ON/OFF] condition of front fog lamp indicator.
LIGHT IND [On/Off]		Displays [ON/OFF] condition of light indicator.
OIL W/L [ON/OFF]		Displays [ON/OFF] condition of low oil pressure warning message.
MIL [ON/OFF]		Displays [ON/OFF] condition of malfunction indicator.
CRUISE IND [Off]		Displays [ON/OFF] condition of CRUISE indicator in the information display.
CRUISE W/L [ON/OFF]		Displays [ON/OFF] condition of tire CRUISE warning message.
CVT IND [Off]		Displays [ON/OFF] condition of CVT indicator in the information display.
SET IND [On/Off]		Displays [ON/OFF] condition of SET indicator in the information display.
O/D OFF IND [ON/OFF]		Displays [ON/OFF] condition of O/D OFF indicator.

## DIAGNOSIS SYSTEM (METER)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description	A
FUEL W/L [On/Off]		Displays [ON/OFF] condition of low-fuel warning message.	A
WASHER W/L [On/Off]		Displays [ON/OFF] condition of low washer fluid warning message.	B
AIR PRES W/L [ON/OFF]		Displays [ON/OFF] condition of tire pressure warning lamp.	C
KEY G/Y W/L [On/Off]		Displays [ON/OFF] condition of key green warning lamp.	D
EPS W/L [On/Off]		Displays [ON/OFF] condition of EPS warning indicator.	D
LCD		Displays the value of Intelligent Key system message indication.	E
ACC SET SPEED [Off, km/h or mph]		Displays OFF or SET vehicle speed status in the information display.	E
ACC UNIT [On/Off]		Displays [ON/OFF] condition of display unit in the information display.	F
SHIFT IND [P, R, N, D, DS]		Displays [P, R, N, D, DS] shift selector position.	F
FUEL CAP W/L [On/Off]		Displays [ON/OFF] condition of loose fuel cap warning message.	G
O/D OFF SW [ON/OFF]		Displays [ON/OFF] condition of O/D OFF switch.	H
M RANGE SW [On/Off]		Displays [ON/OFF] condition of manual mode switch.	H
NM RANGE SW [On/Off]		Displays [ON/OFF] condition of non-manual mode switch.	I
AT SFT UP SW [On/Off]		Displays [ON/OFF] condition of manual mode shift up switch.	J
AT SFT DWN SW [On/Off]		Displays [ON/OFF] condition of manual mode shift down switch.	J
ST SFT UP SW [On/Off]		Displays [ON/OFF] condition of paddle shift up switch.	K
ST SFT DWN SW [On/Off]		Displays [ON/OFF] condition of paddle shift down switch.	K
PKB SW [On/Off]		Displays [ON/OFF] condition of parking brake switch.	L
BUCKLE SW [ON/OFF]		Status of seat belt buckle switch (LH).	M
BRAKE OIL SW [On/Off]		Displays [ON/OFF] condition of brake fluid level switch.	M
PASS BUCKLE SW [ON/OFF]		Status of passenger seat belt buckle switch (RH).	M
DISTANCE [Mi] or [km]		Displays distance to empty.	O
OUTSIDE TEMP [°F or °C]		Displays the ambient air temperature which is input from the ambient sensor.	P
FUEL LOW SIG [On/Off]		Displays [ON/OFF] condition of low-fuel warning signal.	P
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.	P
BSW IND [ON/OFF]		Displays [ON/OFF] condition of BSW warning indicator message in the information display.	P

## DIAGNOSIS SYSTEM (METER)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
LDW IND [ON/OFF]		Displays [ON/OFF] condition of LDW warning indicator message in the information display.
TPMS MALF [ON/OFF]		Displays [ON/OFF] condition of TPMS warning indicator.

### SPECIAL FUNCTION

#### Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

#### W/L ON HISTORY

- “W/L ON HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is:
  - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
  - 1 - 39: The number of times the engine was restarted after the 0 condition.
  - NO W/L ON HISTORY: No warning/indicator lamp history is stored.

#### NOTE:

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009941192

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

## BUZZER

### BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000009941193

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

## DATA MONITOR

Monitor Item [Unit]	Description
PUSH -SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TAIL LAMP SW [On/Off]	Indicates condition of combination switch.
FR FOG SW [On/Off]	Indicates condition of front fog lamp switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.

## ACTIVE TEST

Test Item	Description
SEAT BELT WARN TEST	This test is able to check seat belt warning chime operation [On/Off].
LIGHT WARN ALM	This test is able to check light warning chime operation [On/Off].
REVERSE WARNING	This test is able to check reverse warning chime operation [On/Off].
ID REGIST WARNING	This test is able to check TPMS transmitter ID regist warning chime operation [On/Off].

# BCM, COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### BCM, COMBINATION METER

#### List of ECU Reference

INFOID:000000009462891

ECU	Reference
BCM	<a href="#">BCS-31, "Reference Value"</a>
	<a href="#">BCS-50, "Fail Safe"</a>
	<a href="#">BCS-50, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-52, "DTC Index"</a>
COMBINATION METER	<a href="#">MWI-22, "Reference Value"</a>
	<a href="#">MWI-27, "Fail-Safe"</a>
	<a href="#">MWI-27, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS

# WARNING CHIME SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### WARNING CHIME SYSTEM

#### Wiring Diagram

INFOID:000000009462892




ABNWA1895GB

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >


## WARNING CHIME SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5G	W	-
12G	G	-
22G	L	-
23G	P	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	6N	Color of Wire	W	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	BR	-
13P	G	-

ABNIA3633GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WCS

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
10	W	COMBI SW IN 5
11	BG	COMBI SW IN 4
12	W	COMBI SW IN 3
13	G	COMBI SW IN 2
14	P	COMBI SW IN 1

Terminal No.	Color of Wire	Signal Name
77J	BR	-
82J	V	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



92	91	90	89	88	87	86	85	84	83	82	81
104	103	102	101	100	99	98	97	96	95	94	93

Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
75	BG	COMBI SW OUT 5
76	W	COMBI SW OUT 4
77	R	COMBI SW OUT 3
78	P	COMBI SW OUT 2
79	G	COMBI SW OUT 1

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




80	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
96	BR	DR DOOR SW

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
1	B	GND1
2	B	GND2
9	V	DR BUCKLE SW
12	G	PKB
21	BR	IGN
22	G	BAT
38	P	CAN-L
39	L	CAN-H

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1


Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Terminal No.	Color of Wire	Signal Name
9	P	-
10	W	-
11	G	-
12	P	-
13	BG	-
14	G	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
2	BG	-
5	W	-
7	R	-
8	W	-

ABNIA4967GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WCS

# WARNING CHIME SYSTEM


< WIRING DIAGRAM >

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5G	P	-
12G	LG	-
22G	L	-
23G	P	-

# WARNING CHIME SYSTEM


< WIRING DIAGRAM >

Connector No.	E35
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	LG	-

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	L	-
82J	LG	-

Connector No.	B3
Connector Name	JOINT CONNECTOR-B05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	-
3	LG	-

ABNIA3637GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WCS

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-
6	O	-(WITH MULTIPLE ILLUMINATION CONTROL)
6	LG	-(WITH METER ILLUMINATION CONTROL ONLY)

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-
6	LG	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B202
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-(WITH METER ILLUMINATION CONTROL ONLY)
1	O	-(WITH MULTIPLE ILLUMINATION CONTROL)
2	B	-

ABNIA4968GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009462893

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

##### 2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

##### 3. CHECK CONSULT SELF-DIAGNOSIS RESULTS

Connect CONSULT and perform Self-Diagnosis. Refer to [MWI-27, "DTC Index"](#).

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

Are self-diagnosis results normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

---

Perform symptom diagnosis and repair or replace the identified malfunctioning parts.

>> GO TO 5.

### 5.REPAIR OR REPLACE MALFUNCTIONING PARTS

---

Repair or replace malfunctioning parts.

**NOTE:**

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

>> GO TO 6.

### 6.FINAL CHECK

---

Check that the warning buzzer in the combination meter operates normally.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 1.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

#### COMBINATION METER : Diagnosis Procedure

INFOID:000000009941198

Regarding Wiring Diagram information, refer to [MWI-32, "Wiring Diagram"](#).

#### 1. CHECK FUSES

Check that the following fuses are not blown.

Unit	Power source	Fuse No.
Combination meter	Battery	13
		25
	Ignition switch ON or START	31

##### Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

#### 2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector M24 terminals 5, 21, 22 and ground.

Terminals		Ignition switch position				
(+)		(-)	OFF	ACC	ON	START
Connector	Terminal					
M24	22	Ground	Battery voltage	Battery voltage	Battery voltage	Battery voltage
	21		0V	0V	Battery voltage	Battery voltage
	5		0V	Battery voltage	Battery voltage	0V

##### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

#### 3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M24 terminals 1, 2 and ground.

Terminals		Continuity	
(+)			(-)
Connector	Terminal		
M24	1	Ground	Yes
	2		

##### Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

#### BCM (BODY CONTROL MODULE)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000009941194

Regarding Wiring Diagram information, refer to [BCS-55. "Wiring Diagram"](#).

### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

# METER BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## METER BUZZER CIRCUIT

### Description

INFOID:000000009462896

- The buzzer for warning chime system is installed in the combination meter.
- The combination meter sounds the alarm buzzer based on the signals transmitted from various units.

### Component Function Check

INFOID:000000009462897

#### 1. CHECK OPERATION OF METER BUZZER

1. Select BUZZER of BCM on CONSULT.
2. Perform LIGHT WARN ALM or SEAT BELT WARN TEST of active test.

#### Does meter buzzer activate?

- YES >> Inspection End.  
NO >> Refer to [WCS-27, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000009462898

#### 1. CHECK COMBINATION METER INPUT SIGNAL

Select the Data Monitor for the METER/M&A and check the BUZZER monitor value.

BUZZER

Under the condition of buzzer input : On

Except above : Off

#### Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000009462899

Transmits a seat belt buckle switch LH (driver seat) signal to the combination meter.

### Component Function Check

INFOID:000000009462900

#### 1. CHECK COMBINATION METER INPUT SIGNAL

Select DATA MONITOR for METER/M&A and check the BUCKLE SW monitor value.

##### BUCKLE SW

When seat belt LH (driver seat) is fastened : OFF

When seat belt LH (driver seat) is unfastened : ON

YES >> Inspection End.

NO >> Refer to [WCS-28, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000009462901

Regarding Wiring Diagram information, refer to [WCS-16, "Wiring Diagram"](#).

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector M24 terminal 9 and ground.

Connector	Combination meter		Condition	Voltage (Approx.)
	Terminals			
	(+)	(-)		
M24	9	Ground	When driver seat belt is fastened	12 V
			When driver seat belt is unfastened	0 V

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2. CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M24 and seat belt buckle switch LH (driver seat) harness connector B202.
3. Check continuity between combination meter harness connector M24 terminal 9 and seat belt buckle switch LH (driver seat) harness connector B202 terminal 1.

Combination meter		Seat belt buckle switch LH (driver seat)		Continuity
Connector	Terminal	Connector	Terminal	
M24	9	B202	1	Yes

4. Check continuity between combination meter harness connector M24 terminal 9 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	9		No

Is the inspection result normal?

YES >> GO TO 3.

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness or connectors.

### 3. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch LH (driver seat) harness connector B202 terminal 2 and ground.

Seat belt buckle switch LH (driver seat)		Ground	Continuity
Connector	Terminal		
B202	2		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

## Component Inspection

INFOID:000000009462902

### 1. CHECK SEAT BELT BUCKLE SWITCH

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch LH (driver seat).
3. Check continuity between the seat belt buckle switch LH (driver seat) terminals 1 and 2.

Terminal		Condition	Continuity
1	2	When seat belt is fastened	No
		When seat belt is unfastened	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the seat belt buckle switch LH (driver seat). Refer to [SR-30, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS

## WARNING CHIME SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

### SYMPTOM DIAGNOSIS

#### WARNING CHIME SYSTEM SYMPTOMS

##### Symptom Table

INFOID:000000009462903

**CAUTION:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
The light reminder warning does not sound.	<ul style="list-style-type: none"><li>• Harness between BCM and front door switch LH</li><li>• Front door switch LH</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-32</a> .
The parking brake release warning continues sounding or does not sound.	<ul style="list-style-type: none"><li>• Harness between combination meter and parking brake switch</li><li>• Parking brake switch</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-31</a> .
The seat belt warning continues sounding or does not sound.	<ul style="list-style-type: none"><li>• Harness between combination meter and seat belt buckle switch LH (driver seat)</li><li>• Seat belt buckle switch LH (driver seat)</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-33</a> .
Warning chime does not sound at all.	<ul style="list-style-type: none"><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-27</a> .

# THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

## THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

### Description

INFOID:000000009462904

- The parking brake warning buzzer sounds continuously during vehicle travel though the parking brake is released
- The parking brake warning buzzer does not sound at all even though driving the vehicle with the parking brake applied.

### Diagnosis Procedure

INFOID:000000009462905

#### 1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

**Parking brake ON** : ON  
**Parking brake OFF** : OFF

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-82. "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Perform inspection of the parking brake switch signal circuit. Refer to [MWI-63. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit inspection for the parking brake switch. Refer to [MWI-63. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-82. "Removal and Installation"](#).  
NO >> Replace the parking brake switch. Refer to [PB-7. "Exploded View"](#).

WCS

# THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

---

## THE LIGHT REMINDER WARNING DOES NOT SOUND

### Description

INFOID:000000009462906

Light reminder warning does not sound even though headlamp is illuminated.

### Diagnosis Procedure

INFOID:000000009462907

#### 1. CHECK METER BUZZER OPERATION

---

Perform meter buzzer function check. Refer to [WCS-27, "Component Function Check"](#).

Is the meter buzzer function normal?

YES >> GO TO 2

NO >> Refer to [WCS-27, "Diagnosis Procedure"](#).

#### 2. CHECK COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) OPERATION

---

Check that the headlamps operate normally by operating the combination switch (lighting and turn signal switch).

Do they operate normally?

YES >> GO TO 3

NO >> Refer to [EXL-86, "Work Flow"](#).

#### 3. CHECK FRONT DOOR SWITCH LH SIGNAL CIRCUIT

---

Perform inspection of the front door switch LH signal circuit. Refer to [DLK-100, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

#### 4. CHECK FRONT DOOR SWITCH LH

---

Perform a unit inspection for the front door switch LH. Refer to [DLK-102, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Replace the front door switch LH. Refer to [DLK-219, "Removal and Installation"](#).

# THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

## THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

### Description

INFOID:000000009462908

- Seat belt warning does not sound even though driver seat belt is not fastened.
- Seat belt warning sounds even though driver seat belt is fastened.

### Diagnosis Procedure

INFOID:000000009462909

#### 1. CHECK WARNING CHIME OPERATION

1. Select BUZZER of BCM on CONSULT.
2. Perform SEAT BELT WARN TEST of ACTIVE TEST.

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace combination meter. Refer to [MWI-82. "Removal and Installation"](#).

#### 2. CHECK SEAT BELT WARNING LAMP

1. Turn ignition switch ON.
2. Check the operation of the seat belt warning lamp in the combination meter.

**Seat belt fastened** : OFF

**Seat belt not fastened** : ON

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

NO >> GO TO 3

#### 3. CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

Perform inspection of the seat belt buckle switch LH (driver seat) circuit. Refer to [WCS-28. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

#### 4. CHECK SEAT BELT BUCKLE SWITCH UNIT

Perform a unit inspection for the seat belt buckle switch. Refer to [WCS-29. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-82. "Removal and Installation"](#).

NO >> Replace the seat belt buckle switch LH (driver seat). Refer to [SR-30. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

WCS