

SECTION **DAS**

DRIVER ASSISTANCE SYSTEM

A
B
C

CONTENTS

D

E

ITS CONTROL UNIT	Inspection Procedure36	F
PRECAUTION 8	ACTION TEST37	
PRECAUTIONS 8	Description37	G
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"8	Inspection Procedure37	
Precautions For Harness Repair8	ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA39	H
SYSTEM DESCRIPTION 9	Description39	
COMPONENT PARTS 9	Work Procedure39	
Component Parts Location9	REAR VIEW CAMERA CALIBRATION40	I
Component Description 10	Description40	
SYSTEM11	Work Procedure (Preparation)40	J
System Description 11	Work Procedure (Target Setting)41	
Fail-safe (ITS Control Unit) 12	Work Procedure (Rear View Camera Calibration)...42	
DIAGNOSIS SYSTEM (ITS CONTROL UNIT) ...13	DTC/CIRCUIT DIAGNOSIS44	K
CONSULT Function (AVM) 13	C1A03 VEHICLE SPEED SENSOR44	
ECU DIAGNOSIS INFORMATION 16	DTC Logic44	L
ITS CONTROL UNIT16	Diagnosis Procedure44	
Reference Value 16	C1A04 ABS/TCS/VDC SYSTEM45	M
Fail-safe 18	DTC Logic45	
DTC Inspection Priority Chart 18	Diagnosis Procedure45	
DTC Index 19	C1A39 STEERING ANGLE SENSOR46	N
WIRING DIAGRAM21	DTC Logic46	
DRIVER ASSISTANCE SYSTEMS21	Diagnosis Procedure46	
Wiring Diagram21	U0122 VDC P-RUN DIAG47	DAS
BASIC INSPECTION33	DTC Logic47	
DIAGNOSIS AND REPAIR WORK FLOW33	Diagnosis Procedure47	
Work Flow33	U0416 VDC CHECKSUM DIAG48	P
Diagnostic Work Sheet34	DTC Logic48	
PRE-INSPECTION FOR DIAGNOSIS36	Diagnosis Procedure48	
	U0428 STEERING ANGLE SENSOR49	
	DTC Logic49	
	Diagnosis Procedure49	

U1000 CAN COMM CIRCUIT	50	REAR VIEW CAMERA WASHER CONTROL UNIT	71
Description	50	Exploded View	71
DTC Logic	50	Removal and Installation	71
Diagnosis Procedure	50		
U1010 CONTROL UNIT (CAN)	51	REAR VIEW CAMERA AIR PUMP MOTOR	72
Description	51	Exploded View	72
DTC Logic	51	Removal and Installation	72
Diagnosis Procedure	51		
		LDW	
U111A REAR CAMERA IMAGE SIGNAL CIRCUIT	52	PRECAUTION	73
DTC Logic	52	PRECAUTIONS	73
Diagnosis Procedure	52	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	73
U1232 STEERING ANGLE SENSOR	54	Precaution for Work	73
DTC Logic	54	Precautions For Harness Repair	73
Diagnosis Procedure	54	Precaution for LDW System Service	74
U1305 CAMERA IMAGE CALIB	55	PREPARATION	75
DTC Logic	55	PREPARATION	75
Diagnosis Procedure	55	Special Service Tool	75
U1308 CAMERA CONFIG	56	SYSTEM DESCRIPTION	76
DTC Logic	56	COMPONENT PARTS	76
Diagnosis Procedure	56	Component Parts Location	76
U1309 PUMP UNIT CURRENT	57	Component Description	77
DTC Logic	57	SYSTEM	78
Diagnosis Procedure	57	System Description	78
U130B REAR CAMERA COMM ERROR	60	Fail-safe (ITS Control Unit)	80
DTC Logic	60	Fail-safe (Rear View Camera)	80
Diagnosis Procedure	60	OPERATION	81
U1310 PUMP UNIT CIRCUIT	61	Switch Name and Function	81
DTC Logic	61	Menu Displayed by Pressing Each Switch	81
Diagnosis Procedure	61	HANDLING PRECAUTION	83
POWER SUPPLY AND GROUND CIRCUIT	64	Precautions for Lane Departure Warning	83
Diagnosis Procedure	64	DIAGNOSIS SYSTEM (ITS CONTROL UNIT)..	84
WARNING SYSTEMS SWITCH CIRCUIT	65	CONSULT Function (AVM)	84
Component Function Check	65	ECU DIAGNOSIS INFORMATION	87
Diagnosis Procedure	65	ITS CONTROL UNIT	87
Component Inspection	66	Reference Value	87
WARNING SYSTEMS ON INDICATOR CIRCUIT	67	Fail-safe	89
Diagnosis Procedure	67	DTC Inspection Priority Chart	89
Component Inspection	68	DTC Index	90
REMOVAL AND INSTALLATION	69	WIRING DIAGRAM	92
ITS CONTROL UNIT	69	DRIVER ASSISTANCE SYSTEMS	92
Removal and Installation	69	Wiring Diagram	92
REAR VIEW CAMERA	70	BASIC INSPECTION	104
Exploded View	70	DIAGNOSIS AND REPAIR WORK FLOW	104
Removal and Installation	70		

Work Flow	104	U1232 STEERING ANGLE SENSOR	125	
Diagnostic Work Sheet	105	DTC Logic	125	A
PRE-INSPECTION FOR DIAGNOSIS	107	Diagnosis Procedure	125	
Inspection Procedure	107	U1305 CAMERA IMAGE CALIB	126	B
ACTION TEST	108	DTC Logic	126	
Description	108	Diagnosis Procedure	126	
Inspection Procedure	108	U1308 CAMERA CONFIG	127	C
ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA	110	DTC Logic	127	
Description	110	Diagnosis Procedure	127	
Work Procedure	110	U1309 PUMP UNIT CURRENT	128	D
REAR VIEW CAMERA CALIBRATION	111	DTC Logic	128	
Description	111	Diagnosis Procedure	128	
Work Procedure (Preparation)	111	U130B REAR CAMERA COMM ERROR	131	E
Work Procedure (Target Setting)	112	DTC Logic	131	
Work Procedure (Rear View Camera Calibration)	113	Diagnosis Procedure	131	F
DTC/CIRCUIT DIAGNOSIS	115	U1310 PUMP UNIT CIRCUIT	132	
C1A03 VEHICLE SPEED SENSOR	115	DTC Logic	132	G
DTC Logic	115	Diagnosis Procedure	132	
Diagnosis Procedure	115	POWER SUPPLY AND GROUND CIRCUIT ..	135	H
C1A04 ABS/TCS/VDC SYSTEM	116	Diagnosis Procedure	135	
DTC Logic	116	WARNING SYSTEMS SWITCH CIRCUIT	136	I
Diagnosis Procedure	116	Component Function Check	136	
C1A39 STEERING ANGLE SENSOR	117	Diagnosis Procedure	136	
DTC Logic	117	Component Inspection	137	J
Diagnosis Procedure	117	WARNING SYSTEMS ON INDICATOR CIR- CUIT	138	
U0122 VDC P-RUN DIAG	118	Diagnosis Procedure	138	K
DTC Logic	118	Component Inspection	139	
Diagnosis Procedure	118	SYMPTOM DIAGNOSIS	140	L
U0416 VDC CHECKSUM DIAG	119	LDW SYSTEM SYMPTOMS	140	
DTC Logic	119	Symptom Table	140	
Diagnosis Procedure	119	THE SYSTEM OPERATES EVEN WHEN US- ING TURN SIGNAL	141	M
U0428 STEERING ANGLE SENSOR	120	Description	141	
DTC Logic	120	Diagnosis Procedure	141	
Diagnosis Procedure	120	LDW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMA- TION DISPLAY	142	N
U1000 CAN COMM CIRCUIT	121	Description	142	
Description	121	Diagnosis Procedure	142	DAS
DTC Logic	121	NORMAL OPERATING CONDITION	143	
Diagnosis Procedure	121	Description	143	P
U1010 CONTROL UNIT (CAN)	122	REMOVAL AND INSTALLATION	144	
Description	122	WARNING SYSTEMS SWITCH	144	
DTC Logic	122	Removal and Installation	144	
Diagnosis Procedure	122	REAR VIEW CAMERA		
U111A REAR CAMERA IMAGE SIGNAL CIR- CUIT	123			
DTC Logic	123			
Diagnosis Procedure	123			

Exploded View	145	DIAGNOSIS AND REPAIR WORK FLOW	180
Removal and Installation	145	Work Flow	180
REAR VIEW CAMERA WASHER CONTROL UNIT	146	Diagnostic Work Sheet	181
Exploded View	146	PRE-INSPECTION FOR DIAGNOSIS	183
Removal and Installation	146	Inspection Procedure	183
REAR VIEW CAMERA AIR PUMP MOTOR ..	147	ACTION TEST	184
Exploded View	147	Description	184
Removal and Installation	147	Inspection Procedure	184
BSW			
PRECAUTION	148	ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA	186
PRECAUTIONS	148	Description	186
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	148	Work Procedure	186
Precaution for Work	148	REAR VIEW CAMERA CALIBRATION	187
Precautions For Harness Repair	148	Description	187
Precaution for BSW System Service	149	Work Procedure (Preparation)	187
PREPARATION	150	Work Procedure (Target Setting)	188
PREPARATION	150	Work Procedure (Rear View Camera Calibration)	189
Special Service Tool	150	DTC/CIRCUIT DIAGNOSIS	191
SYSTEM DESCRIPTION	151	C1A03 VEHICLE SPEED SENSOR	191
COMPONENT PARTS	151	DTC Logic	191
Component Parts Location	151	Diagnosis Procedure	191
Component Description	152	C1A04 ABS/TCS/VDC SYSTEM	192
SYSTEM	153	DTC Logic	192
System Description	153	Diagnosis Procedure	192
Fail-safe (ITS Control Unit)	156	C1A39 STEERING ANGLE SENSOR	193
OPERATION	157	DTC Logic	193
Switch Name and Function	157	Diagnosis Procedure	193
System Display and Warning	157	U0122 VDC P-RUN DIAG	194
HANDLING PRECAUTION	159	DTC Logic	194
Precautions for Blind Spot Warning	159	Diagnosis Procedure	194
DIAGNOSIS SYSTEM (ITS CONTROL UNIT).	160	U0416 VDC CHECKSUM DIAG	195
CONSULT Function (AVM)	160	DTC Logic	195
ECU DIAGNOSIS INFORMATION	163	Diagnosis Procedure	195
ITS CONTROL UNIT	163	U0428 STEERING ANGLE SENSOR	196
Reference Value	163	DTC Logic	196
Fail-safe	165	Diagnosis Procedure	196
DTC Inspection Priority Chart	165	U1000 CAN COMM CIRCUIT	197
DTC Index	166	Description	197
WIRING DIAGRAM	168	DTC Logic	197
DRIVER ASSISTANCE SYSTEMS	168	Diagnosis Procedure	197
Wiring Diagram	168	U1010 CONTROL UNIT (CAN)	198
BASIC INSPECTION	180	Description	198
		DTC Logic	198
		Diagnosis Procedure	198
		U111A REAR CAMERA IMAGE SIGNAL CIRCUIT	199
		DTC Logic	199
		Diagnosis Procedure	199

U1232 STEERING ANGLE SENSOR	201	WARNING SYSTEMS SWITCH	222	
DTC Logic	201	Removal and Installation	222	A
Diagnosis Procedure	201			
U1305 CAMERA IMAGE CALIB	202	BSW INDICATOR	223	
DTC Logic	202	Exploded View	223	B
Diagnosis Procedure	202	Removal and Installation	223	
U1308 CAMERA CONFIG	203	REAR VIEW CAMERA	224	
DTC Logic	203	Exploded View	224	C
Diagnosis Procedure	203	Removal and Installation	224	
U1309 PUMP UNIT CURRENT	204	REAR VIEW CAMERA WASHER CONTROL UNIT	225	
DTC Logic	204	Exploded View	225	D
Diagnosis Procedure	204	Removal and Installation	225	E
U130B REAR CAMERA COMM ERROR	207	REAR VIEW CAMERA AIR PUMP MOTOR ...	226	
DTC Logic	207	Exploded View	226	F
Diagnosis Procedure	207	Removal and Installation	226	
U1310 PUMP UNIT CIRCUIT	208			
DTC Logic	208			
Diagnosis Procedure	208			
POWER SUPPLY AND GROUND CIRCUIT ...	211	MOD		
Diagnosis Procedure	211	PRECAUTION	227	G
WARNING SYSTEMS SWITCH CIRCUIT	212	PRECAUTIONS	227	
Component Function Check	212	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	227	H
Diagnosis Procedure	212	Precaution for Work	227	
Component Inspection	213	Precautions For Harness Repair	227	I
WARNING SYSTEMS ON INDICATOR CIRCUIT	214	PREPARATION	229	
Diagnosis Procedure	214	PREPARATION	229	J
Component Inspection	215	Special Service Tool	229	
BLIND SPOT WARNING INDICATOR CIRCUIT	216	SYSTEM DESCRIPTION	230	K
Component Function Check	216	COMPONENT PARTS	230	
Diagnosis Procedure	216	Component Parts Location	230	L
		Component Description	231	
SYMPTOM DIAGNOSIS	218	SYSTEM	232	
BSW SYSTEM SYMPTOMS	218	System Description	232	M
Symptom Table	218	OPERATION	235	
SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF	219	System Display and Warning	235	N
Description	219	HANDLING PRECAUTION	236	
Diagnosis Procedure	219	Precautions for Moving Objects Detection	236	
BSW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY	220	DIAGNOSIS SYSTEM (ITS CONTROL UNIT)	237	
Description	220	CONSULT Function (AVM)	237	DAS
Diagnosis Procedure	220	ECU DIAGNOSIS INFORMATION	240	
NORMAL OPERATING CONDITION	221	ITS CONTROL UNIT	240	P
Description	221	Reference Value	240	
REMOVAL AND INSTALLATION	222	Fail-safe	242	
		DTC Inspection Priority Chart	242	
		DTC Index	243	
		WIRING DIAGRAM	245	

DRIVER ASSISTANCE SYSTEMS	245	U111A REAR CAMERA IMAGE SIGNAL CIRCUIT	275
Wiring Diagram	245	DTC Logic	275
BASIC INSPECTION	257	Diagnosis Procedure	275
DIAGNOSIS AND REPAIR WORK FLOW	257	U1232 STEERING ANGLE SENSOR	277
Work Flow	257	DTC Logic	277
Diagnostic Work Sheet	258	Diagnosis Procedure	277
PRE-INSPECTION FOR DIAGNOSIS	260	U1305 CAMERA IMAGE CALIB	278
Inspection Procedure	260	DTC Logic	278
ACTION TEST	261	Diagnosis Procedure	278
Description	261	U1308 CAMERA CONFIG	279
Inspection Procedure	261	DTC Logic	279
ADDITIONAL SERVICE WHEN REPLACING		Diagnosis Procedure	279
REAR VIEW CAMERA	262	U1309 PUMP UNIT CURRENT	280
Description	262	DTC Logic	280
Work Procedure	262	Diagnosis Procedure	280
REAR VIEW CAMERA CALIBRATION	263	U130B REAR CAMERA COMM ERROR	283
Description	263	DTC Logic	283
Work Procedure (Preparation)	263	Diagnosis Procedure	283
Work Procedure (Target Setting)	264	U1310 PUMP UNIT CIRCUIT	284
Work Procedure (Rear View Camera Calibration)	265	DTC Logic	284
DTC/CIRCUIT DIAGNOSIS	267	Diagnosis Procedure	284
C1A03 VEHICLE SPEED SENSOR	267	POWER SUPPLY AND GROUND CIRCUIT ...	287
DTC Logic	267	Diagnosis Procedure	287
Diagnosis Procedure	267	WARNING SYSTEMS SWITCH CIRCUIT	288
C1A04 ABS/TCS/VDC SYSTEM	268	Component Function Check	288
DTC Logic	268	Diagnosis Procedure	288
Diagnosis Procedure	268	Component Inspection	289
C1A39 STEERING ANGLE SENSOR	269	WARNING SYSTEMS ON INDICATOR CIRCUIT	290
DTC Logic	269	Diagnosis Procedure	290
Diagnosis Procedure	269	Component Inspection	291
U0122 VDC P-RUN DIAG	270	SYMPTOM DIAGNOSIS	292
DTC Logic	270	MOD SYSTEM SYMPTOMS	292
Diagnosis Procedure	270	Symptom Table	292
U0416 VDC CHECKSUM DIAG	271	MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY	293
DTC Logic	271	Description	293
Diagnosis Procedure	271	Diagnosis Procedure	293
U0428 STEERING ANGLE SENSOR	272	NORMAL OPERATING CONDITION	294
DTC Logic	272	Description	294
Diagnosis Procedure	272	REMOVAL AND INSTALLATION	295
U1000 CAN COMM CIRCUIT	273	REAR VIEW CAMERA WASHER CONTROL UNIT	295
Description	273	Exploded View	295
DTC Logic	273	Removal and Installation	295
Diagnosis Procedure	273		
U1010 CONTROL UNIT (CAN)	274		
Description	274		
DTC Logic	274		
Diagnosis Procedure	274		

REAR VIEW CAMERA AIR PUMP MOTOR ... 296	Removal and Installation296	
Exploded View 296		A

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011039330

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precautions For Harness Repair


INFOID:000000011039332

ITS communication uses a twisted pair line. Be careful when repairing it.

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[ITS CONTROL UNIT]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000011039333



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ALOIA0235ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

- | | | |
|--|---|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit | 14. ITS control unit
(view with center console assembly removed) | 15. Steering angle sensor
(view with steering wheel removed) |
| 16. Washer fluid level switch
(view with front bumper fascia removed) | 17. Washer motor | 18. ABS actuator and electric unit (control unit) |

Component Description

INFOID:000000011039334

Component	Description
ITS control unit	<ul style="list-style-type: none"> • Controls each system, based on signals received from the rear view camera and CAN communication signals received from each control unit. • Transmits signals necessary for control between CAN communication.
Blind Spot Warning indicator LH/RH	Receives Blind Spot Warning indicator operation signal from the ITS control unit and turns ON, turns OFF or blinks.
Warning systems switch	Inputs the switch signal to ITS control unit.
Warning systems ON indicator (On the warning systems switch)	Indicates BSW/LDW system status.
Rear view camera	<ul style="list-style-type: none"> • With the mirror processing function, a mirror image is sent as if it is viewed by a rear view mirror. • Transmits the detected image signal to the ITS control unit.
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication. • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication.
Buzzer (combination meter)	Receives buzzer signal from ITS control unit and sounds buzzer.
Combination meter	<ul style="list-style-type: none"> • Turns the Lane Departure Warning/Blind Spot Warning indicator ON/OFF in the combination meter information display according to the signals from the ITS control unit via CAN communication. • Receives Lane Departure Warning/Blind Spot Warning ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication.
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication. • Transmits dimmer signal to ITS control unit via CAN communication.
ECM	Transmits engine speed signal to ITS control unit via CAN communication.
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication.
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the A/V control unit display.
Rear view camera washer control unit	Controls the rear view camera air pump motor and washer motor according to the signals received from the ITS control unit.
Rear view camera air pump motor	Pumps air to the rear camera lens according to the signals received from the pump control unit.
Washer fluid level switch	Transmits the washer fluid level switch signal to the ITS control unit.
Washer motor	Washer fluid is sprayed when the rear view camera washer control unit activates the washer motor.

SYSTEM

< SYSTEM DESCRIPTION >


[ITS CONTROL UNIT]

SYSTEM

System Description

INFOID:000000011039335

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name	Description
ECM	CAN communication Engine speed signal	Receives engine speed.
TCM	CAN communication Input speed signal	Receives the number of revolutions of input shaft.
	CAN communication Current gear position signal	Receives a current gear position.
	CAN communication Shift position signal	Receives a shift selector position.
	CAN communication Output shaft revolution signal	Receives the number of revolutions of output shaft.
ABS actuator and electric unit (control unit)	CAN communication Vehicle speed signal (ABS)	Receives wheel speeds of four wheels.
	CAN communication Yaw rate signal	Receives yaw rate acting on the vehicle.
Combination meter	CAN communication Parking brake switch signal	Receives an operational state of the parking brake.
BCM	CAN communication Front wiper request signal	Receives an operational state of front wiper(s).
	CAN communication Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp.
	CAN communication Dimmer signal	Receives ON/OFF state of dimmer signal.

SYSTEM

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Transmit unit	Signal name		Description
Steering angle sensor	CAN communication	Steering angle sensor malfunction signal	Receives a malfunction state of steering angle sensor.
		Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel.
		Steering angle speed signal	Receives the turning angle speed of the steering wheel.
Warning systems switch	Warning systems switch signal		Receives an ON/OFF state of the warning systems switch.

Output Signal Item

Reception unit	Signal name		Description
Combination meter	CAN communication	Meter display signal Own vehicle indicator signal	Transmits a signal to display a state of the system on the information display.
		Blind Spot Warning indicator	Transmits a Blind Spot Warning signal to turn ON the Blind Spot Warning indicator.
		Lane Departure Warning lamp signal	Transmits a Lane Departure Warning signal to turn ON the Lane Departure Warning indicator.
		Buzzer output signal	Transmits a buzzer output signal to turn ON the buzzer of the following systems: <ul style="list-style-type: none"> • Moving Object Detection (MOD) • Blind Spot Warning (BSW) • Lane Departure Warning (LDW)
Warning buzzer	Warning buzzer signal		Activates the warning buzzer of the following systems: <ul style="list-style-type: none"> • Moving Object Detection (MOD) • Blind Spot Warning (BSW) • Lane Departure Warning (LDW)
Warning systems ON indicator	Warning systems ON indicator signal		Turns ON the warning systems ON indicator.
A/V control unit	CAN communication	Visual signal request	Transmits a visual signal request from the ITS control unit to display rear view while the shift selector is in R (reverse).

DESCRIPTION

- ITS* control unit controls the following systems, based on ITS communication signals from the rear view camera and a CAN communication signal from each control unit.

NOTE:

- *: Intelligent Technology Suite
- Moving Object Detection (MOD)
- Blind Spot Warning (BSW)
- Lane Departure Warning (LDW)

System	Reference
Moving Object Detection (MOD)	DAS-232. "System Description"
Blind Spot Warning (BSW)	DAS-153. "System Description"
Lane Departure Warning (LDW)	DAS-78. "System Description"

Fail-safe (ITS Control Unit)

INFOID:0000000011039336

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning lamp/Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on AV control unit display)	Cancel

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:0000000011039337

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit.
Data Monitor	Displays ITS control unit input/output data in real time.
Work support	Displays causes of automatic system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load.
ECU identification	Displays ITS control unit part number.
Configuration	The vehicle specification can be written when replacing the ITS control unit.

SELF DIAGNOSTIC RESULT

Refer to [DAS-19. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication).
REVERSE SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication).
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication].
CAMERA SWITCH SIGNAL [On/Off]	Indicates [ON/OFF] status of camera switch signal as judged from ITS control unit.
CAMERA OFF SIGNAL [On/Off]	Indicates [ON/OFF] status of camera OFF signal as judged from ITS control unit.
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling").
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2).
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD).
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines.
WASH SW [On/Off]	Indicates the state of the wash switch indicator output.
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines.
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines.
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit.

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

Monitored item [Unit]	Description
ILL [On/Off]	Indicates [ON/OFF] status of the illumination signal.
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit.
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output.
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output.
ITS SW 2 [On/Off/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit.
ITS SW 2 IND [On/Off/No setting]	Indicates the state of the warning system secondary switch indicator output.

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not.
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera.
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor.
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process.
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view.
REAR CAMERA ITS	Displays and sets camera image calibration values.
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation.
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation.

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - **Lane Departure Warning indicator**
 - **Blind Spot Warning indicator**
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description	
WASH ACTIVE	ON	Activates the washer to clean the lens of rear camera.
	OFF	
LED LH INDICATOR	ON	Flashes the left side LED light for ITS system.
	OFF	
LED RH INDICATOR	ON	Flashes the right side LED light for ITS system.
	OFF	
AIR ACTIVE	ON	Activates the air pump to clean the lens of rear camera.
	OFF	
AIR & WASH ACTIVE	ON	Activates the air pump and washer to clean the lens of rear camera.
	OFF	

ECU IDENTIFICATION

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[ITS CONTROL UNIT]

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:0000000011039338

VALUES ON THE DIAGNOSIS TOOL


Monitor item	Condition		Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch ON	Steering angle signal is received.	On
		Steering angle signal is not received.	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse).	On
		Shift selector is not in R (reverse).	Off
VEHICLE SPEED SIGNAL	While driving	Vehicle speed signal is received.	On
		Vehicle speed signal is not received.	Off
CAMERA SWITCH SIGNAL	Ignition switch ON	Camera switch is pressed.	On
		Camera switch is not pressed.	Off
CAMERA OFF SIGNAL	Ignition switch ON	Purpose switch is pressed.	On
		Purpose switch is not pressed.	Off
ST ANGLE SENSOR TYPE	Ignition switch ON	Steering angle sensor type is displayed.	Absolute
		Steering angle sensor type is not received.	Not
STEERING GEAR RATIO TYPE	Ignition switch ON	Pattern 1 type of steering gear ratio displayed.	Pattern 1
		Pattern 2 type of steering gear ratio displayed.	Pattern 2
STEERING POSITION	Ignition switch ON	It recognizes steering position is left.	LHD
		It recognizes steering position is right.	RHD
R-CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK.	OK
		Rear camera serial status is not OK.	NG
R-CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received.	OK
		Rear camera serial communication signal is not received.	NG
ILL	Ignition switch ON	Illumination is ON.	On
		Illumination is OFF.	Off
ITS SW 1	Ignition switch ON	ITS switch is pressed.	On
		ITS switch is not pressed.	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting.	On
		Indicator of ITS switch 1 is not lighting.	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received.	Left
		Turn signal neutral is received.	N
		Turn signal right is received.	Right
REAR CAMERA IMAGE SIGNAL	Ignition switch ON	Camera image signal is received.	On
		Camera image signal is not received.	Off
ITS SW 2	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
WASH SW	Ignition switch ON	Wash switch signal is pressed.	On
		Wash switch signal is not pressed.	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received.	On
		Pump communication signal is not received.	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer fluid level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (G)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (W)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN low	—	—		—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (P)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN high	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (reverse)	12 V
					Shift selector not in R (reverse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—		0 V
50	Ground	Shield	—	—		0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON		0 V



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
53	Ground	Shield	—	— —	0 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	Camera image signal	Input	When camera image is displayed	

Fail-safe

INFOID:000000011039339

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on AV control unit display)	Cancel

DTC Inspection Priority Chart

INFOID:000000011039340

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

Priority	Detected items (DTC)
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

DTC Index

INFOID:0000000011039341

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
 - 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
 - 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
 - Other than CAN communication system (Other than U1000, U1010)
 - 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-44
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-45
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-46
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-47
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-48
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-49
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-50
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-51

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[ITS CONTROL UNIT]

Systems for fail-safe

- A: Lane Departure Warning (LDW)
- B: Blind Spot Warning (BSW)
- C: Moving Object Detection (MOD)

DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-52
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-54
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-55
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-56
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-57
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-60
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-61

NOTE:


With the detection of “U1000” some systems do not perform the fail-safe operation.
 A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000011039342



AAOWA0043GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]

(QB) : QR25DE FOR CALIFORNIA
 (QC) : QR25DE EXCEPT FOR CALIFORNIA *1
 (VD) : WITH VQ35DE
 (QB) : 99
 (QC) : 99 *2
 (VD) : 123
 (QB) : 100
 (QC) : 100 *1
 (VD) : 124




AAOWA0044GB

DRIVER ASSISTANCE SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1G	LG	-
2G	BR	-
22G	L	-
23G	P	-
95G	R	-(WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM)
100G	B	-(WITH REAR VIEW CAMER WASHER CONTROL SYSTEM)

Terminal No.	Color of Wire	Signal Name
10J	LG	-
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	R	-
96J	B	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[ITS CONTROL UNIT]

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	109	Color of Wire	G	Signal Name	REVERSE SIGNAL
--------------	-----	---------------	---	-------------	----------------

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	59	Color of Wire	P	Signal Name	CAN-L
Terminal No.	60	Color of Wire	L	Signal Name	CAN-H

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	4	Color of Wire	GR	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	M53
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE



Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	5	Color of Wire	L	Signal Name	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	38	Color of Wire	P	Signal Name	CAN-L
Terminal No.	39	Color of Wire	L	Signal Name	CAN-H

AAOIA0177GB

DRIVER ASSISTANCE SYSTEMS


< WIRING DIAGRAM >

[ITS CONTROL UNIT]

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

AAOIA0178GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[ITS CONTROL UNIT]

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	G	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	BG	-
5	G	-
6	P	-
8	B	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA+
42	SHIELD	CAMERA-SHIELD

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN+H
17	P	CAN-L

AAOIA0179GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[ITS CONTROL UNIT]

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA - (SHIELD)

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	-(WITH REAR VIEW CAMERA)
8	R	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-
4	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-
4	L	-

AAOIA0180GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]

Connector No.	E12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	9	Color of Wire	P	Signal Name	-
10	L	-	-	-	-

Connector No.	E10
Connector Name	ECM
Connector Color	GRAY




Terminal No.	99	Color of Wire	P	Signal Name	CAN-L
100	L	-	-	-	CAN-H

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY



Terminal No.	1	Color of Wire	P	Signal Name	-
2	P	-	-	-	-
4	P	-	-	-	-
6	P	-	-	-	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	1	Color of Wire	L	Signal Name	-
2	L	-	-	-	-
4	L	-	-	-	-
6	L	-	-	-	-


AAOIA0181GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]


Connector No.	E31
Connector Name	ECM
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Terminal No.	Color of Wire	Signal Name
1G	BG	-(WITH REAR VIEW CAMERA)
2G	R	-
22G	L	-
23G	P	-
95G	BG	-
100G	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
74	BG	WASH MTR (WITH REAR VIEW CAMERA)

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E32
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
123	L	CAN-H
124	P	CAN-L

AAOIA0182GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P




DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]

Connector No.	E208
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	E203
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	- (WITH REAR VIEW CAMERA)
8	R	-

Connector No.	F16
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	E226
Connector Name	WASHER MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	O	-


AAOIA0183GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[ITS CONTROL UNIT]


Connector No.	B16
Connector Name	REAR VIEW CAMERA WASHER CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	PUMP MOTOR +
2	BR	PUMP MOTOR -
3	L	WASHER MOTOR -
4	B	WASHER MOTOR +
5	B	GND
6	P	SERIAL GND
7	G	FROM PUMP TO CAMERA C/U
8	W	FROM CAMERA C/U TO PUMP
12	W	IGN

Terminal No.	Color of Wire	Signal Name
10J	W	-
51J	W	-
52J	B	-
53J	R	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	L	-
96J	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
18	B	-

Connector No.	B35
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
4	G	-
5	R	-
7	B	-
8	W	-

Connector No.	B17
Connector Name	REAR VIEW CAMERA AIR PUMP MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	BR	-

AAOIA0184GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[ITS CONTROL UNIT]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-

Connector No.	D3
Connector Name	BLIND SPOT WARNING INDICATOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-

AAOIA0185GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000011039343

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-34, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[ITS CONTROL UNIT]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading".
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-36, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform LDW system action test to check the operation status. Refer to [DAS-37, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-19, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-140, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform "self-diagnosis". Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform LDW system action test. Also check the system operation.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000011039344

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using LDW				
	<input type="checkbox"/> All functions do not operate. <input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator) <input type="checkbox"/> Yawing function does not operate. (Warning function is operated.) <input type="checkbox"/> Functions when changing the course in the turn signal direction. <input type="checkbox"/> Functions are untimely. <input type="checkbox"/> Does not function when driving on lane markers. <input type="checkbox"/> Functions when driving in a lane. <input type="checkbox"/> Functions in a different position from the actual position. <input type="checkbox"/> Others ()				
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

ALOIA0189GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000011039345

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

- YES >> Clean camera lens.
- NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

- YES >> GO TO 3.
- NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-40](#), "[Description](#)".

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26](#), "[Wheelarch Height \(Unladen*1\)](#)".

Is vehicle height appropriate?

- YES >> Inspection End.
- NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[ITS CONTROL UNIT]

ACTION TEST

Description

INFOID:000000011039346

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-83, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000011039347

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-236, "Precautions for Moving Objects Detection"](#).


1. CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR LDW



1. Enable the setting of the LDW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the LDW operation according to the following table.

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	 White <small>ALOIA0191GB</small>	—

ACTION TEST

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer	
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> • Buzzer sounds • Warning lamp blinks 	ON	 <p style="text-align: center; font-size: small;">ALOIA0190GB</p>	Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action	ON	 <p style="text-align: center; font-size: small;">ALOIA0191GB</p>	—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-11. "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[ITS CONTROL UNIT]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:0000000011039348

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:0000000011039349

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment using CONSULT. Refer to [DAS-40, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the "self-diagnosis" of "ITS control unit" using CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-19, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-37, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform "WASH ACTIVE" in "Active Test" using CONSULT.

2. Perform air and washer tube connection check by "AIR & WASH ACTIVE" in Active Test:

(1) Washer fluid output count on the rear view camera is 3 to 5 times → OK.

(2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking.

(3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking.

(4) No washer fluid output → Check tube with blue marking or check valve.

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000011039350

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the **CONSULT** when performing the calibration. (Rear view camera calibration cannot be operated without **CONSULT**).

Work Procedure (Preparation)

INFOID:000000011039351

1.PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of the "ITS control unit".

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19, "DTC Index"](#).
"U1308" or no DTC>>GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the "ITS control unit" using CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-36, "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

>> Refer to [DAS-41, "Work Procedure \(Target Setting\)"](#).


Work Procedure (Target Setting)

INFOID:000000011039352

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".

9. Position the center of the target mark to point of "Ct".




PKIB7667E

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-42. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000011039353


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-40. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" using CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
 - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
4. Input the rear view camera height "H", and then touch "APPLY".
 5. Confirm that the same value is displayed on the center display.
 6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
 7. Select "Start" to perform calibration.
 8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[ITS CONTROL UNIT]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-41, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> Temporary malfunction in internal processing of the rear view camera. Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> A target is not-yet-placed. (The rear view camera cannot detect a target.) The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-40, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> Inappropriate work environment. Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of "ITS control unit" using CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19, "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-37, "Description"](#).

>> Work End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000011039354

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-44, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011039355

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000011039356

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-45, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011039357

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
- NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011039358

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-46, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011039359

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000011039360

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-47, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011039361

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000011039362

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit).

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-48, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011039363

1.CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011039364

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000011039365

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When "U1232" is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011039366

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-30, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:0000000011039367

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more.	<ul style="list-style-type: none"> • CAN communication system • ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:0000000011039368

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" using CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-50, "Description"](#).
 NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1010 CONTROL UNIT (CAN)

Description

INFOID:0000000011039369

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:0000000011039370

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis.	ITS control unit

Diagnosis Procedure

INFOID:0000000011039371

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
- NO >> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000011039372

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted.	Check rear camera image signal circuit between rear camera and ITS control unit.

Diagnosis Procedure

INFOID:000000011039373

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK CONTINUITY OF REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector and rear view camera connector.
3. Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear view Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

4. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK VOLTAGE OF REAR VIEW CAMERA POWER SUPPLY

1. Connect the ITS control unit connector and rear view camera connector.
2. Turn the ignition switch ON.
3. Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		"CAMERA" switch is ON or shift selector is in R (Reverse)	6.2 V
Connector	Terminal		
M59	52	Ground	

Is inspection result normal?

- YES >> GO TO 3.
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

3. CHECK CONTINUITY OF REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

1. Turn ignition switch OFF.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

2. Disconnect the ITS control unit connector and rear view camera connector.
3. Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.


ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4. CHECK OF REAR VIEW CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear view camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
 NO >> Replace rear view camera. Refer to [DAS-70. "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011039374

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:000000011039375

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-13. "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" using CONSULT. Refer to [DAS-13. "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000011039376

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete.	Perform ITS configuration with CONSULT.

Diagnosis Procedure

INFOID:000000011039377

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-13, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000011039378

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB	ITS control unit calibration is incomplete.	Perform ITS calibration with CONSULT.

Diagnosis Procedure

INFOID:000000011039379

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-13, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:0000000011039380

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect.	<ul style="list-style-type: none"> Rear view camera washer control unit Harness ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform "All DTC Reading" using CONSULT.
- Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-57, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000011039381

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

- Disconnect the rear view camera washer control unit connector.
- Turn the ignition switch ON.
- Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the harness or connector.

3.CHECK CONTINUITY OF ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

- Disconnect the ITS control unit connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY OF REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor.

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit				
Connector	Terminals			
B16	7, 8	Ground	Activating pump	5 V

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000011039382

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-60, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011039383

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:0000000011039384

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-61, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000011039385

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

YES >> GO TO 6.

NO >> Replace the rear view camera air pump motor. Refer to [DAS-72, "Removal and Installation"](#).

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit				
Connector	Terminals			
B16	7, 8	Ground	Activating pump	5 V

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000011039386

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition switch	
Connector	Terminal		
M58	20	OFF	Battery voltage
		ON	Battery voltage
	39	OFF	0 V
		ON	Battery voltage
Ground			

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:0000000011039387

1.CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the Data Monitor item "ITS SW 1" of "AVM" using CONSULT.
3. While operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	Off

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-65. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011039388

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	0 V
Connector	Terminal		
M58	32	Released	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-66. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-144. "Removal and Installation"](#).

3.CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011039389

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8		
		When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Diagnosis Procedure

INFOID:0000000011039391

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M62	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-68, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Replace warning systems switch. [DAS-144, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ITS CONTROL UNIT]

Component Inspection

INFOID:000000011039392

1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.


NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

REMOVAL AND INSTALLATION**ITS CONTROL UNIT****Removal and Installation**

INFOID:000000011039395

REMOVAL

1. Disconnect the battery negative terminal. Refer to [PG-78. "Exploded View"](#).
2. Remove the center console assembly. Refer to [IP-18. "Removal and Installation"](#).
3. Disconnect the harness connectors (B,C) from the ITS control unit (1).
↔: Front
4. Remove bolts (←) and plastic screw (A) that retain the ITS control unit (1) and remove.

**INSTALLATION**

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA


< REMOVAL AND INSTALLATION >

[ITS CONTROL UNIT]

REAR VIEW CAMERA

Exploded View

INFOID:000000011039396



1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039397

REMOVAL

1. Remove license lamp finisher. Refer to [EXT-36, "Removal and Installation"](#).
2. Disconnect the harness connector from rear view camera.
3. Disconnect rear washer tubes from rear view camera.
4. Remove rear view camera.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Perform rear view camera calibration. Refer to [DAS-40, "Description"](#).

REAR VIEW CAMERA WASHER CONTROL UNIT


< REMOVAL AND INSTALLATION >

[ITS CONTROL UNIT]

REAR VIEW CAMERA WASHER CONTROL UNIT

Exploded View

INFOID:000000011039398




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039399

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA AIR PUMP MOTOR


< REMOVAL AND INSTALLATION >

[ITS CONTROL UNIT]

REAR VIEW CAMERA AIR PUMP MOTOR

Exploded View

INFOID:000000011039400




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039401

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tubes from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor (1).



INSTALLATION

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011039404

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000011039406

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000011039407

ITS communication uses a twisted pair line. Be careful when repairing it.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



PRECAUTIONS


[LDW]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



Precaution for LDW System Service

INFOID:000000011039408

WARNING:

Be cautious of traffic conditions and other vehicles when performing a road test.

CAUTION:

- Do not use the LDW system when driving with free rollers or a chassis dynamometer.
- Do not disassemble or alter the rear view camera.
- Do not use the rear view camera when removed from the vehicle.
- Do not disable the LDW system without the consent of the customer.

PREPARATION

< PREPARATION >

[LDW]


PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000011039409

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
<p>— (J-46534) Trim Tool Set</p>  <p>AWJIA0483ZZ</p>	Removing trim components

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LDW]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011059273



ALOIA0235ZZ

COMPONENT PARTS

[LDW]

< SYSTEM DESCRIPTION >

- | | | | |
|--|---|---|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) | A |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM | |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator | B |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera | |
| 13. AV control unit | 14. ITS control unit
(view with center console assembly removed) | 15. Steering angle sensor
(view with steering wheel removed) | C |
| 16. Washer fluid level switch
(view with front bumper fascia removed) | 17. Washer motor | 18. ABS actuator and electric unit (control unit) | D |

Component Description

INFOID:000000011059274

Component	Description	
ITS control unit	<ul style="list-style-type: none"> Judges the lane departure depending on the lane detection result and each signal. Controls the warning buzzer and the warning systems ON indicator. Transmits lane departure warning lamp signal to combination meter via CAN communication. 	F
Warning systems switch	Inputs the warning system switch signal to ITS control unit.	
Warning systems ON indicator (On the warning systems switch)	Indicates LDW system status.	G
Rear view camera	<ul style="list-style-type: none"> Detects the lane marker in travel lane. Transmits the detected lane condition signal to ITS control unit via ITS communication. 	H
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> Transmits vehicle speed signal to ITS control unit via CAN communication. Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication. 	
Buzzer (combination meter)	Receives buzzer signal from ITS control unit and sounds buzzer.	I
Combination meter	<ul style="list-style-type: none"> Turns the Lane Departure Warning lamp ON/OFF in the combination meter information display according to the signals from the ITS control unit via CAN communication. Receives Lane Departure Warning ON indicator signal via CAN communication. 	J
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication.	
BCM	<ul style="list-style-type: none"> Transmits turn signal indicator to ITS control unit via CAN communication. Transmits dimmer signal to ITS control unit via CAN communication. 	K
ECM	Transmits engine speed signal to ITS control unit via CAN communication.	
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication.	L
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the A/V control unit display.	
Rear view camera washer control unit	Controls the rear view camera air pump motor and washer motor according to the signals received from the ITS control unit.	M
Rear view camera air pump motor	Pumps air to the rear view camera lens according to the signals received from the rear view camera washer control unit.	N
Washer fluid level switch	Transmits the washer fluid level switch signal to the ITS control unit.	
Washer motor	Washer fluid is sprayed when the rear view camera washer control unit activates the washer motor.	P


DAS

SYSTEM

System Description

INFOID:000000011039412

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name		Description
BCM	CAN communication	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp.
Rear view camera	ITS communication	Detected lane condition signal	Receives detection results of lane marker.
Warning systems switch	Warning systems switch signal		Receives an ON/OFF state of the warning systems switch.

Output Signal Item

Reception unit	Signal name		Description
Combination meter	CAN communication	Lane departure warning lamp signal	Transmits a lane departure warning lamp signal to turn ON the lane departure warning lamp.
Rear view camera	ITS communication	Vehicle speed signal	Transmits a vehicle speed calculated by the ITS control unit.
		Turn indicator signal	Transmits a turn indicator signal received from BCM.
Warning buzzer	Warning buzzer signal		Activates the warning buzzer.
Warning systems ON indicator	Warning systems ON indicator signal		Turns ON the warning systems ON indicator.

SYSTEM


[LDW]

< SYSTEM DESCRIPTION >

FUNCTION DESCRIPTION

- Lane Departure Warning (LDW) system provides a lane departure warning function when the vehicle is driven at speeds of approximately 70 km/h (45 MPH) or more.
- When the vehicle approaches either the left or the right side of the traveling lane, a warning will sound and the lane departure warning lamp (orange) on the combination meter will blink to alert the driver.
- The warning does not occur during turn signal operation (Lane change side).
- The warning function will stop when the vehicle returns inside of the lane markers.

EXAMPLE



When the vehicle approaches the right lane marker, the driver is alerted by the buzzer and the blinking of lane departure warning lamp (orange).

OPERATION DESCRIPTION

- When the system is turned ON by operating the warning systems switch, ITS control unit turns ON the warning systems ON indicator.
- Rear view camera monitors lane markers of the traveling lane. It transmits the detected lane condition signal to ITS control unit via ITS communication.
- When judging from a lane marker detection signal that the vehicle is approaching the lane marker, the ITS control unit controls the following item to alert the driver.
 - Activates warning buzzer.
 - ITS control unit transmits a lane departure warning lamp signal to combination meter via CAN communication and turns ON/OFF the lane departure warning lamp (orange).

OPERATING CONDITION

- Warning systems ON indicator: ON
- Vehicle speed: Approximately 70 km/h (45 MPH) or more.
- Turn indicator signal: After 2 seconds or more from turned OFF.

NOTE:

- When the LDW system setting on the vehicle information display is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH).
- The LDW system may not function properly, depending on the situation. Refer to [DAS-83. "Precautions for Lane Departure Warning"](#).



Bulb Check Action and Fail-safe Indication.

DAS

SYSTEM

< SYSTEM DESCRIPTION >

[LDW]

Vehicle condition/ Driver's operation	Warning systems ON indicator	Indication on the combination meter
Ignition switch OFF ⇒ ON (Bulb check)	Approx. 5 sec. ON	ON (white)  <small>ALOIA0183ZZ</small> ON: Operational Blinking: LDW detected
When DTC is detected (Except "U1308")	ON	LDW OFF (orange)
Camera aiming is not completed ("U1308" is detected) NOTE: This is detected while driving the vehicle and the indication remains ON until the ignition switch is turned OFF.	ON	 <small>ALOIA0159GB</small>
When rear camera needs cleaning.	OFF	Unavailable: Clean Rear Camera
Temporary disabled status.	OFF	LDW light (white) will blink
When the warning systems switch is pressed (When the settings of LDW system and BSW system on the vehicle information display is "OFF").	Blink	—

Fail-safe (ITS Control Unit)

INFOID:000000011039413

If a malfunction occurs in each system, ITS control unit cancels each control, and turns ON the warning lamp or indicator lamp.

System	Warning lamp/Indicator lamp	Description
Blind Spot Warning (BSW)	Blind Spot Warning lamp	Cancel
Lane Departure Warning (LDW)	Lane Departure Warning indicator	Cancel

Fail-safe (Rear View Camera)

INFOID:000000011039414

FAIL-SAFE CONTROL BY DTC

If a malfunction occurs in the rear view camera, ITS control unit cancels control, and turns ON the lane departure warning lamp in the combination meter.

BSW/LDW TEMPORARY DISABLED STATUS

Under the following condition, the BSW and/or LDW system is turned off temporarily, the BSW light (white) and /or LDW light (white) will blink, and either of the following messages will appear in the vehicle information display:

- "trunk is open"
- "washer fluid is low"

When the above condition no longer exists, the BSW and /or LDW system will resume automatically.

OPERATION


< SYSTEM DESCRIPTION >

[LDW]

OPERATION

Switch Name and Function

INFOID:0000000011039415




No.	Switch name	Description
1	Warning systems switch	Turns the LDW system ON/OFF. (When the setting of LDW system on the combination meter information display is ON).

Menu Displayed by Pressing Each Switch

INFOID:0000000011039416

INDICATOR LAMP AND WARNING LAMP



No.	Display item	Description
1	Warning systems ON indicator	Indicates that the LDW system is ON.
2	Lane departure warning lamp	<ul style="list-style-type: none"> Blinks orange when LDW system is activated. Turns ON in the combination meter information display when LDW system is ON. Blinks when DTC is detected or system is temporarily disabled. Blinks when rear view camera blockage is detected.

DISPLAY AND WARNING

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	ON	White	—


A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

OPERATION

< SYSTEM DESCRIPTION >

[LDW]

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> • Buzzer sounds • Warning lamp blinks (orange) 	ON	OFF (orange) Blink  <small>ALOIA0185ZZ</small>	Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action	ON	White	—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-78. "System Description"](#).

HANDLING PRECAUTION

Precautions for Lane Departure Warning


INFOID:000000011039417

REAR VIEW CAMERA HANDLING

The rear camera unit "1" for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



LANE DEPARTURE WARNING (LDW)

- LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- The camera unit may not detect properly under the following conditions:
 - When towing a trailer.
 - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
 - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect properly under the following conditions:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt or snow, etc.
 - On roads where the discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
 - On roads where the traveling lane merges or separates.
 - When the vehicle's traveling direction does not align with the lane marker.
 - When the road surface is very dark due to scarce ambient light or impaired tail lamp.
- When driving on a curved road, warning will be late on the outside of the curve due to the nature of the system.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LDW]

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000011059275

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit.
Data Monitor	Displays ITS control unit input/output data in real time.
Work support	Displays causes of automatic system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load.
ECU identification	Displays ITS control unit part number.
Configuration	The vehicle specification can be written when replacing the ITS control unit.

SELF DIAGNOSTIC RESULT

Refer to [DAS-19, "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication).
REVERSE SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication).
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication].
CAMERA SWITCH SIGNAL [On/Off]	Indicates [ON/OFF] status of camera switch signal as judged from ITS control unit.
CAMERA OFF SIGNAL [On/Off]	Indicates [ON/OFF] status of camera OFF signal as judged from ITS control unit.
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling").
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2).
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD).
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines.
WASH SW [On/Off]	Indicates the state of the wash switch indicator output.
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines.
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines.
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit.

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LDW]

Monitored item [Unit]	Description
ILL [On/Off]	Indicates [ON/OFF] status of the illumination signal.
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit.
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output.
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output.
ITS SW 2 [On/Off/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit.
ITS SW 2 IND [On/Off/No setting]	Indicates the state of the warning system secondary switch indicator output.

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not.
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera.
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor.
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process.
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view.
REAR CAMERA ITS	Displays and sets camera image calibration values.
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation.
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation.

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description	
WASH ACTIVE	ON	Activates the washer to clean the lens of rear camera.
	OFF	
LED LH INDICATOR	ON	Flashes the left side LED light for ITS system.
	OFF	
LED RH INDICATOR	ON	Flashes the right side LED light for ITS system.
	OFF	
AIR ACTIVE	ON	Activates the air pump to clean the lens of rear camera.
	OFF	
AIR & WASH ACTIVE	ON	Activates the air pump and washer to clean the lens of rear camera.
	OFF	

ECU IDENTIFICATION

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LDW]

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:0000000011059280

VALUES ON THE DIAGNOSIS TOOL

Monitor item	Condition		Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch ON	Steering angle signal is received.	On
		Steering angle signal is not received.	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse).	On
		Shift selector is not in R (reverse).	Off
VEHICLE SPEED SIGNAL	While driving	Vehicle speed signal is received.	On
		Vehicle speed signal is not received.	Off
CAMERA SWITCH SIGNAL	Ignition switch ON	Camera switch is pressed.	On
		Camera switch is not pressed.	Off
CAMERA OFF SIGNAL	Ignition switch ON	Purpose switch is pressed.	On
		Purpose switch is not pressed.	Off
ST ANGLE SENSOR TYPE	Ignition switch ON	Steering angle sensor type is displayed.	Absolute
		Steering angle sensor type is not received.	Not
STEERING GEAR RATIO TYPE	Ignition switch ON	Pattern 1 type of steering gear ratio displayed.	Pattern 1
		Pattern 2 type of steering gear ratio displayed.	Pattern 2
STEERING POSITION	Ignition switch ON	It recognizes steering position is left.	LHD
		It recognizes steering position is right.	RHD
R-CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK.	OK
		Rear camera serial status is not OK.	NG
R-CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received.	OK
		Rear camera serial communication signal is not received.	NG
ILL	Ignition switch ON	Illumination is ON.	On
		Illumination is OFF.	Off
ITS SW 1	Ignition switch ON	ITS switch is pressed.	On
		ITS switch is not pressed.	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting.	On
		Indicator of ITS switch 1 is not lighting.	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received.	Left
		Turn signal neutral is received.	N
		Turn signal right is received.	Right
REAR CAMERA IMAGE SIGNAL	Ignition switch ON	Camera image signal is received.	On
		Camera image signal is not received.	Off
ITS SW 2	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
WASH SW	Ignition switch ON	Wash switch signal is pressed.	On
		Wash switch signal is not pressed.	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received.	On
		Pump communication signal is not received.	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer fluid level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (G)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (W)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN low	—	—		—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (P)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN high	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (reverse)	12 V
					Shift selector not in R (reverse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—		0 V
50	Ground	Shield	—	—		0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON		0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
53	Ground	Shield	—	—	0 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	Camera image signal	Input	When camera image is displayed	

Fail-safe

INFOID:000000011059281

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on AV control unit display)	Cancel

DTC Inspection Priority Chart

INFOID:000000011039421

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

Priority	Detected items (DTC)
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

DTC Index

INFOID:000000011039422

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now.
 - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now.
CAN communication system (U1000, U1010).
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010).
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-115
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-116
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-117
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-118
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-119
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-120
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-121
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-122

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LDW]

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-123
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-125
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-126
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-127
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-128
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-131
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-132

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.
 A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000011059261




AAOWA0043GB

DRIVER ASSISTANCE SYSTEMS

[LDW]

< WIRING DIAGRAM >

(QB) : QR25DE FOR CALIFORNIA
 (QC) : QR25DE EXCEPT FOR CALIFORNIA *1
 (VD) : WITH VQ35DE
 (OE) : 99
 (OC) : 99 *2
 (VC) : 123
 (OE) : 100
 (OC) : 100 *2
 (VC) : 124



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

AAOWA0044GB

DRIVER ASSISTANCE SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




2R	6R	8R	4R	3R	2R	1R
16R	15R	14R	13R	12R	11R	10R

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



1J	2J	3J	4J	5J
6J	7J	8J	9J	10J



Terminal No.	Color of Wire	Signal Name
1G	LG	-
2G	BR	-
22G	L	-
23G	P	-
95G	R	-(WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM)
100G	B	-(WITH REAR VIEW CAMER WASHER CONTROL SYSTEM)

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-


Terminal No.	Color of Wire	Signal Name
10J	LG	-
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	R	-
96J	B	-

DRIVER ASSISTANCE SYSTEMS

[LDW]


< WIRING DIAGRAM >

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	109	Color of Wire	G	Signal Name	REVERSE SIGNAL
--------------	-----	---------------	---	-------------	----------------

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	59	Color of Wire	P	Signal Name	CAN-L
Terminal No.	60	Color of Wire	L	Signal Name	CAN-H

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	4	Color of Wire	GR	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	M53
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE



Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	5	Color of Wire	L	Signal Name	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	38	Color of Wire	P	Signal Name	CAN-L
Terminal No.	39	Color of Wire	L	Signal Name	CAN-H

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

AAOIA0177GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

AAOIA0178GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[LDW]

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	G	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	BG	-
5	G	-
6	P	-
8	B	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA+
42	SHIELD	CAMERA-SHIELD

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

AAOIA0179GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[LDW]

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA - (SHIELD)

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	-(WITH REAR VIEW CAMERA)
8	R	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-
4	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-
4	L	-

AAOIA0180GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]

Connector No.	E12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	9	Color of Wire	P	Signal Name	-
Terminal No.	10	Color of Wire	L	Signal Name	-

Connector No.	E10
Connector Name	ECM
Connector Color	GRAY




Terminal No.	99	Color of Wire	P	Signal Name	CAN-L
Terminal No.	100	Color of Wire	L	Signal Name	CAN-H

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY



Terminal No.	1	Color of Wire	P	Signal Name	-
Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	4	Color of Wire	P	Signal Name	-
Terminal No.	6	Color of Wire	P	Signal Name	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	1	Color of Wire	L	Signal Name	-
Terminal No.	2	Color of Wire	L	Signal Name	-
Terminal No.	4	Color of Wire	L	Signal Name	-
Terminal No.	6	Color of Wire	L	Signal Name	-

AAOIA0181GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]


Connector No.	E31
Connector Name	ECM
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Terminal No.	Color of Wire	Signal Name
1G	BG	-(WITH REAR VIEW CAMERA)
2G	R	-
22G	L	-
23G	P	-
95G	BG	-
100G	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
74	BG	WASH MTR (WITH REAR VIEW CAMERA)

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E32
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
123	L	CAN-H
124	P	CAN-L


AAOIA0182GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]

Connector No.	E208
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	E203
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	- (WITH REAR VIEW CAMERA)
8	R	-

Connector No.	F16
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	E226
Connector Name	WASHER MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	O	-

AAOIA0183GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[LDW]


Connector No.	B16
Connector Name	REAR VIEW CAMERA WASHER CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	PUMP MOTOR +
2	BR	PUMP MOTOR -
3	L	WASHER MOTOR -
4	B	WASHER MOTOR +
5	B	GND
6	P	SERIAL GND
7	G	FROM PUMP TO CAMERA C/U
8	W	FROM CAMERA C/U TO PUMP
12	W	IGN

Terminal No.	Color of Wire	Signal Name
10J	W	-
51J	W	-
52J	B	-
53J	R	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	L	-
96J	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
18	B	-

Connector No.	B35
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
4	G	-
5	R	-
7	B	-
8	W	-

Connector No.	B17
Connector Name	REAR VIEW CAMERA AIR PUMP MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	BR	-


AAOIA0184GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[LDW]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-

Connector No.	D3
Connector Name	BLIND SPOT WARNING INDICATOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-

AAOIA0185GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

[LDW]

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000011059282

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-105, "Diagnostic Work Sheet"](#).)

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[LDW]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading".
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-107, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform LDW system action test to check the operation status. Refer to [DAS-108, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-90, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-140, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform "self-diagnosis". Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform LDW system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:0000000011059283

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DIAGNOSIS AND REPAIR WORK FLOW

[LDW]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using LDW				
	<input type="checkbox"/> All functions do not operate.				
	<input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator)				
	<input type="checkbox"/> Yawing function does not operate. (Warning function is operated.)				
	<input type="checkbox"/> Functions when changing the course in the turn signal direction.				
<input type="checkbox"/> Functions are untimely.					
<input type="checkbox"/> Does not function when driving on lane markers.					
<input type="checkbox"/> Functions when driving in a lane.					
<input type="checkbox"/> Functions in a different position from the actual position.					
<input type="checkbox"/> Others ()					
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> At night		<input type="checkbox"/> Sunrise/sunset (Strong light)	
	<input type="checkbox"/> In the daytime	<input type="checkbox"/> Backlight		<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Direct light				
Driving conditions	<input type="checkbox"/> Not affected	MPH (km/h)		<input type="checkbox"/> Vehicle is stopped	
	<input type="checkbox"/> Vehicle speed				
Weather conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Raining		<input type="checkbox"/> Snowing	
	<input type="checkbox"/> Fine	<input type="checkbox"/> Clouding		<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Clouding				
Road conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> In town		<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Highway	<input type="checkbox"/> Winding roads		<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Uneven roads				
Lane maker conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Unclear		<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Clear				
Other conditions					

ALOIA0189GB

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[LDW]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:0000000011039426

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-111. "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26. "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ACTION TEST

< BASIC INSPECTION >

[LDW]

ACTION TEST

Description

INFOID:000000011039427

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-83, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000011039428

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-236, "Precautions for Moving Objects Detection"](#).


1. CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR LDW



1. Enable the setting of the LDW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the LDW operation according to the following table.

Vehicle condition/ Driver's operation		Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	ON	 White _{ALOIA0191GB}	—

ACTION TEST

< BASIC INSPECTION >

[LDW]

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning • Buzzer sounds • Warning lamp blinks		Short continuous beeps
	<ul style="list-style-type: none"> • Close to lane marker • Turn signal ON (Deviate side) 	No action		—

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-78. "System Description"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[LDW]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000011059284

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000011059285

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment using CONSULT. Refer to [DAS-111, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the "self-diagnosis" of "ITS control unit" using CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-19, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-37, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform "WASH ACTIVE" in "Active Test" using CONSULT.

2. Perform air and washer tube connection check by "AIR & WASH ACTIVE" in Active Test:

- (1) Washer fluid output count on the rear view camera is 3 to 5 times → OK.
- (2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking.
- (3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking.
- (4) No washer fluid output → Check tube with blue marking or check valve.

>> Inspection End.

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:0000000011059286

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the **CONSULT** when performing the calibration. (Rear view camera calibration cannot be operated without **CONSULT**).

Work Procedure (Preparation)

INFOID:0000000011059287

1.PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of the "ITS control unit".

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19. "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the "ITS control unit" using **CONSULT**.

1. Perform pre-inspection for diagnosis. Refer to [DAS-36. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

[LDW]

< BASIC INSPECTION >

>> Refer to [DAS-112, "Work Procedure \(Target Setting\)"](#).


Work Procedure (Target Setting)

INFOID:000000011059288

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".


9. Position the center of the target mark to point of "Ct".



REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-113. "Work Procedure \(Rear View Camera Calibration\)".](#)

Work Procedure (Rear View Camera Calibration)

INFOID:000000011059289


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-111. "Work Procedure \(Preparation\)".](#)

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" using CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
- Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.

4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[LDW]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-112. "Work Procedure (Target Setting)".
	10H Writing error	<ul style="list-style-type: none">Temporary malfunction in internal processing of the rear view camera.Rear view camera malfunction.	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none">A target is not-yet-placed. (The rear view camera cannot detect a target.)The position of the rear view camera is not correct.	Position the target appropriately again. Perform the aiming again. Refer to DAS-111. "Work Procedure (Preparation)".
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none">Inappropriate work environment.Inappropriate vehicle condition.	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of "ITS control unit" using CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19. "DTC Index".](#)

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-37. "Description".](#)

>> Work End.

C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000011059290

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-115, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059291

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000011059292

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-116, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059293

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011059294

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-117, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059295

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000011059296

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-118, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059297

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:000000011059298

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit).

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-119, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059299

1.CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011059300

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000011059301

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When "U1232" is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011059302

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-30, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:0000000011059303

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more.	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:0000000011059304

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" using CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-121, "Description"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000011059305

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000011059306

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis.	ITS control unit

Diagnosis Procedure

INFOID:000000011059307

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
- NO >> Inspection End.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:0000000011059308

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted.	Check rear camera image signal circuit between rear camera and ITS control unit.

Diagnosis Procedure

INFOID:0000000011059309

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK CONTINUITY OF REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear view camera connector.
- Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear view Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE OF REAR VIEW CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear view camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		"CAMERA" switch is ON or shift selector is in R (Reverse)	6.2 V
Connector	Terminal		
M59	52		

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

3. CHECK CONTINUITY OF REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

- Turn ignition switch OFF.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect the ITS control unit connector and rear view camera connector.
3. Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.


ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4. CHECK OF REAR VIEW CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear view camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
 NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:0000000011059310

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:0000000011059311

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-84, "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" using CONSULT. Refer to [DAS-84, "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000011059312

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete.	Perform ITS configuration with CONSULT.

Diagnosis Procedure

INFOID:000000011059313

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-84, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1308 CAMERA CONFIG

DTC Logic

INFOID:000000011059314

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB	ITS control unit calibration is incomplete.	Perform ITS calibration with CONSULT.

Diagnosis Procedure

INFOID:000000011059315

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-84, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000011059316

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-128, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059317

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY OF ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1309 PUMP UNIT CURRENT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
NO >> Repair the harness or connector.

4.CHECK CONTINUITY OF REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
NO >> Replace the rear view camera air pump motor.

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		
	Ground		

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

U130B REAR CAMERA COMM ERROR

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000011059318

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-131, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059319

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000011059320

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-132, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059321

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3.CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair the harness or connector.

4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
 NO >> Repair the harness or connector.

5. CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
 NO >> Replace the rear view camera air pump motor. Refer to [DAS-72. "Removal and Installation"](#).

6. CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.



U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011059322

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	OFF		Battery voltage
	39	ON		Battery voltage
Ground		OFF	0 V	
		ON	Battery voltage	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000011059323

1. CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the Data Monitor item "ITS SW 1" of "AVM" using CONSULT.
3. While operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	Off

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-136. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011059324

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	0 V
Connector	Terminal		
M58	32		
		Pressed	0 V
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-137. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-144. "Removal and Installation"](#).

3. CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[LDW]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011059325

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

DAS

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Diagnosis Procedure

INFOID:000000011059326

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M62	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-139. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

NO >> Replace warning systems switch. [DAS-144. "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

Component Inspection

INFOID:0000000011059327

1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

SYMPTOM DIAGNOSIS

LDW SYSTEM SYMPTOMS

Symptom Table

INFOID:000000011039476

NOTE:

For the operational conditions of Lane Departure Warning (LDW), refer to the following description.

- LDW: [DAS-78. "System Description"](#)

Symptom	Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	Lane departure warning lamp does not illuminate.	<ul style="list-style-type: none"> • Combination meter • ITS control unit Combination meter. Refer to MWI-18. "CONSULT Function (METER/M&A)" .
	Warning systems ON indicator does not illuminate.	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch. • Warning systems switch • ITS control unit Warning systems ON indicator circuit. Refer to DAS-138. "Diagnosis Procedure" .
	All of indicator/warning lamps does not illuminate; <ul style="list-style-type: none"> • Lane departure warning lamp • Warning systems ON indicator 	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit. • ITS control unit Power supply and ground circuit of ITS control unit. Refer to DAS-135. "Diagnosis Procedure" .
LDW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON).	Warning systems ON indicator is not turned ON ⇔ OFF when operating warning systems switch.	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch. • Harness between warning systems switch and ground. • Warning systems switch • ITS control unit <ul style="list-style-type: none"> • Warning systems switch circuit. Refer to DAS-136. "Component Function Check". • LDW system setting cannot be turned ON/OFF on the combination meter information display. Refer to DAS-142. "Diagnosis Procedure".
	Warning buzzer is not sounding. (Lane departure warning lamp is activated).	<ul style="list-style-type: none"> • Warning buzzer • ITS control unit Meter buzzer circuit. Refer to WCS-27. "Component Function Check" .
Warning functions are not timely (Example) <ul style="list-style-type: none"> • Does not function when driving on lane markers. • Functions when driving in a lane. • Functions in a different position from the actual position. 	<ul style="list-style-type: none"> • Rear view camera • ITS control unit 	Camera calibration Refer to DAS-111. "Description" .
Functions when changing the course in direction of the turn signal.	Turn indicator signal (CAN) <ul style="list-style-type: none"> • BCM • ITS control unit 	System operates even when using turn signal. Refer to DAS-141. "Description" .

THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL

< SYMPTOM DIAGNOSIS >

[LDW]

THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL

Description

INFOID:0000000011039479

The warning of Lane Departure Warning (LDW) is activated during the use of a turn signal.

NOTE:

For the operational conditions of Lane Departure Warning (LDW), refer to [DAS-78. "System Description"](#).

Diagnosis Procedure

INFOID:0000000011039480

1. CHECK TURN SIGNAL OPERATION

Check that both right and left turn signals are operational.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts. Refer to [DAS-140. "Symptom Table"](#).

2. CHECK SELF-DIAGNOSIS RESULTS

1. Perform "All DTC Reading" with CONSULT.

2. Check if the DTC is detected in self-diagnosis results of "AVM" Refer to [DAS-90. "DTC Index"](#).

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.

NO >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

LDW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[LDW]

LDW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:000000011039481

LDW system setting is not selectable on the combination meter information display.

Diagnosis Procedure

INFOID:000000011039482

1. CHECK LDW SYSTEM SETTING

1. Ignition On.
2. Check that the LDW system setting can be turned ON/OFF in the combination meter information display using the steering switch.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> GO TO 2.

2. CHECK STEERING SWITCH CIRCUIT

Check the steering switch circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness or connector.

3. CHECK STEERING SWITCH RESISTANCE

Check the steering switch resistance. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-81, "Removal and Installation"](#).
- NO >> Replace steering switch. Refer to [AV-52, "Removal and Installation"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[LDW]

NORMAL OPERATING CONDITION

Description

INFOID:0000000011039483

PRECAUTIONS FOR LANE DEPARTURE WARNING (LDW)

- LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- LDW system will not operate at speeds below approximately 70 km/h (45 MPH) or if it cannot detect lane markers.
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.
- LDW system may not function properly under the following conditions:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt or snow, etc.
 - On roads where the discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
 - On roads where the traveling lane merges or separates.
 - When the vehicle's traveling direction does not align with the lane marker.
 - When rain, snow or dirt adheres to the rear view camera.
 - When a sudden change in brightness occurs. (For example, when the vehicle enters or exits a tunnel or under a bridge.)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[LDW]

REMOVAL AND INSTALLATION


WARNING SYSTEMS SWITCH

Removal and Installation

INFOID:000000011039484


REMOVAL

1. Remove the instrument lower panel LH. Refer to [JP-21. "Removal and Installation"](#).
2. Remove screws (A) that retain the switch carrier (2) to the instrument lower panel LH (1).



3. Release the pawls then remove the warning system switch from the switch carrier (1).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

REAR VIEW CAMERA


< REMOVAL AND INSTALLATION >

[LDW]

REAR VIEW CAMERA

Exploded View

INFOID:000000011039485



1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039486

REMOVAL

1. Remove license lamp finisher. Refer to [EXT-36, "Removal and Installation"](#).
2. Disconnect the harness connector from rear view camera.
3. Disconnect rear washer tubes from rear view camera.
4. Remove rear view camera.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Perform rear view camera calibration. Refer to [DAS-111, "Description"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA WASHER CONTROL UNIT


< REMOVAL AND INSTALLATION >

[LDW]

REAR VIEW CAMERA WASHER CONTROL UNIT

Exploded View

INFOID:000000011039487




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039488

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR VIEW CAMERA AIR PUMP MOTOR


< REMOVAL AND INSTALLATION >

[LDW]

REAR VIEW CAMERA AIR PUMP MOTOR

Exploded View

INFOID:000000011039489




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039490

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tubes from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011039493

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000011039495

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000011039496

ITS communication uses a twisted pair line. Be careful when repairing it.

PRECAUTIONS


[BSW]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



Precaution for BSW System Service

INFOID:000000011039497

WARNING:

Be cautious of traffic conditions and other vehicles when performing a road test.

CAUTION:

- Do not use the BSW system when driving with free rollers or on a chassis dynamometer.
- Do not perform BSW ACTIVE TESTS while driving.
- Do not disassemble or alter the rear view camera.
- Do not use the rear view camera when removed from the vehicle.
- Do not disable the BSW system without the consent of the customer.

OBSERVE THE FOLLOWING ITEMS IN ORDER TO KEEP THE BSW SYSTEM OPERATING PROPERLY:

Rear view Camera Maintenance

The rear view camera for the BSW system is located in the truck lid. To keep the BSW system operating properly and prevent a malfunction, be sure to observe the following:

- Always keep the camera lens area clean.
- Do not attach bumper stickers (including transparent materials) or install an accessory near the rear view-camera.
- Do not strike or damage the areas around the rear view camera.
- Do not touch the camera lens (except for cleaning) or remove the rear view camera.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

PREPARATION

< PREPARATION >

[BSW]


PREPARATION

PREPARATION

Special Service Tool

INFOID:000000011039498

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
<p>— (J-46534) Trim Tool Set</p>  <p>AWJIA0483ZZ</p>	Removing trim components

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[BSW]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011060210



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ALOIA0235ZZ

COMPONENT PARTS

[BSW]

< SYSTEM DESCRIPTION >

- | | | |
|--|---|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera |
| 13. AV control unit | 14. ITS control unit
(view with center console assembly removed) | 15. Steering angle sensor
(view with steering wheel removed) |
| 16. Washer fluid level switch
(view with front bumper fascia removed) | 17. Washer motor | 18. ABS actuator and electric unit (control unit) |

Component Description

INFOID:000000011039500

Component	Description
ITS control unit	<ul style="list-style-type: none"> • ITS control unit receives a camera image signal from the rear view camera and recognizes a vehicle traveling in the adjacent lane. • When a vehicle traveling in the adjacent lane approaches, ITS control unit sounds the buzzer and blinks the BSW indicator to warn the driver. • Receives steering angle sensor signal from steering angle sensor via CAN communication. • Transmits a warning buzzer signal and a Blind Spot Warning to the combination meter via CAN communication.
Blind Spot Warning indicator LH/RH	Receives Blind Spot Warning indicator operation signal from ITS control unit and turns ON, turns OFF or blinks.
Warning system switch	Inputs the switch signal to ITS control unit.
Warning systems ON indicator (On the warning systems switch)	Indicates BSW system status.
Rear view camera	Transmits the image of rear view of vehicle to the ITS control unit.
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> • Transmits vehicle speed signal to ITS control unit via CAN communication. • Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication.
Buzzer (combination meter)	Receives buzzer signal from ITS control unit and sounds buzzer.
Combination meter	<ul style="list-style-type: none"> • Turns the Blind Spot Warning indicator ON/OFF in the combination meter information display according to the signals from the ITS control unit via CAN communication. • Receives Blind Spot Warning ON indicator signal via CAN communication.
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication.
BCM	<ul style="list-style-type: none"> • Transmits turn signal indicator to ITS control unit via CAN communication • Transmits dimmer signal to ITS control unit via CAN communication.
ECM	Transmits engine speed signal to ITS control unit via CAN communication.
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication.
AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the A/V control unit display.
Rear view camera washer control unit	Controls the rear view camera air pump motor and washer motor according to the signals received from the ITS control unit.
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the rear view camera washer control unit.
Washer fluid level switch	Transmits the washer fluid level switch signal to ITS control unit.
Washer motor	Washer fluid is sprayed when the rear view camera washer control unit activates the washer motor.

SYSTEM

[BSW]


< SYSTEM DESCRIPTION >

SYSTEM

System Description

INFOID:000000011039501

SYSTEM DIAGRAM



CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Control unit receives signals via CAN communication. It also detects vehicle conditions that are necessary for BSW control.

Input Signal Item

BCM	CAN communication	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp.
		Back door switch signal	Receives a state of the back door switch.
Combination meter	CAN communication	System selection signal	Receives a selection state of each item in "Driver assistance" selected with the combination meter.
Steering angle sensor	CAN communication	Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel.
ECM	CAN communication	Engine status signal	Receives the engine status.
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal	Receives wheel speed.
Rear view camera	Communication line	Camera image signal	Receives the camera image signal.
Warning system switch	Warning system switch signal		Receives an ON/OFF state of the warning system switch.

Output Signal Item

SYSTEM


< SYSTEM DESCRIPTION >

[BSW]

Reception unit	Signal name		Description
Combination meter	CAN communication	BSW warning signal	Transmits a meter display signal to turn ON the BSW warning.
		BSW ON indicator signal	Transmits a meter display signal to turn ON the BSW ON indicator.
	Buzzer output signal		Transmits a buzzer output signal to activate the warning buzzer.
Rear view camera washer control unit	CAN Communication	Rear view camera washer signal	Transmits a rear view camera washer motor signal to activate the rear view camera washer motor.
		Rear view camera air blow signal	Transmits a rear view camera air blow signal to activate the air pump
Warning system ON indicator	Warning systems ON indicator signal		Turns ON the warning system ON indicator.
Warning buzzer	Warning buzzer operation signal		Activates the warning buzzer.
BSW indicator LH, RH	Indicator operation signal		Turns ON the BSW indicator LH, RH.

FUNCTION DESCRIPTION

- The BSW system can help alert the driver of other vehicles in adjacent lanes when changing lanes.
- The BSW system uses rear view camera near the rear bumper to detect vehicles in an adjacent lane.
- The rear view camera can detect vehicles on either side of vehicle within the detection zone shown as illustrated.
- This detection zone starts from the back of the vehicle and extends approximately 3.0 m (10 ft) behind the rear bumper, and approximately 3.0 m (10 ft) sideways.
- The BSW system operates above approximately 32 km/h (20 MPH).
- If the rear view camera detects vehicles in the detection zone, the Blind Spot Warning indicator illuminates.



- If the driver then activates the turn signal, a buzzer will sound twice and the Blind Spot Warning indicator will blink.


NOTE:

SYSTEM

[BSW]

< SYSTEM DESCRIPTION >

A buzzer sounds if the rear view camera has already detected vehicles when the driver activates the turn signal. If a vehicle comes into the detection zone after the driver activates the turn signal, then only the Blind Spot Warning indicator blinks and no buzzer sounds.



OPERATION DESCRIPTION

- ITS control unit enables BSW system.
- The ITS control unit turns on the BSW system when the warning systems switch is turned ON.
- Rear view camera detects a vehicle in the adjacent lane, and transmits the vehicle detection signal to control unit.
- ITS control unit starts the control as follows, based on a vehicle detection signal, turn signal and dimmer signal transmitted from BCM via CAN communication:
 - Blind Spot Warning indicator signal and Blind Spot Warning indicator dimmer signal transmission to rear view camera.
 - Buzzer signal transmission to warning buzzer.
- Rear view camera transmits an indicator operation signal to the Blind Spot Warning indicator according to Blind Spot Warning indicator signal and Blind Spot Warning indicator dimmer signal.

Operation Condition of BSW System


ITS control unit performs the control when the following conditions are satisfied:

- When the warning systems switch is turned ON*.
- When the vehicle drives at 32 km/h (20 MPH) or more in the forward direction.

NOTE:

- *: When the BSW system setting on the vehicle information display screen is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed is reduced below approximately 29 km/h (18 MPH)
- The BSW system may not function properly, depending on the situation.

BULB CHECK ACTION AND FAIL-SAFE INDICATION

Vehicle condition/Driver's operation	Blind Spot Warning/ Blind Spot Intervention indicator	Warning systems ON indicator	Indication on the combination meter information display
When DTC is detected	OFF	ON	OFF → Orange 
Temporary disabled status	OFF	ON	BSW light (white) will blink

ALOIA0172GB


SYSTEM

[BSW]

< SYSTEM DESCRIPTION >

Vehicle condition/Driver's operation	Blind Spot Warning/ Blind Spot Intervention indicator	Warning systems ON indicator	Indication on the combination meter information display
When rear view camera needs cleaning	OFF	ON	Unavailable: Clean Rear Camera
When the warning systems switch is pressed (When the settings of LDW system and BSW system on the vehicle information screen are "OFF")	OFF	Blink	—

*: Blinking cycle when there is a rear view camera blockage condition.



NOTE:

Time shown in the figure is approximate.

Fail-safe (ITS Control Unit)

INFOID:000000011039502

If a malfunction occurs in each system, ITS control unit cancels each control, and turns ON the warning lamp or indicator lamp.

System	Warning lamp/Indicator lamp	Description
Blind Spot Warning (BSW)	Blind Spot Warning lamp	Cancel
Lane Departure Warning (LDW)	Lane Departure Warning indicator	Cancel

OPERATION


< SYSTEM DESCRIPTION >

[BSW]

OPERATION

Switch Name and Function

INFOID:000000011039503




ALOIA0109ZZ

No.	Name	Function
1	Warning systems switch	Turns the BSW system ON/OFF. (When the setting of BSW system on the vehicle information display setting screen is ON).

System Display and Warning

INFOID:000000011039504

INDICATOR AND WARNING LAMP



AWOIA0087ZZ

No.	Name	Description
1	Warning systems ON indicator	Indicates that the BSW system is ON.
2	Blind Spot Warning lamp (orange)	<ul style="list-style-type: none"> • Turns ON when Blind Spot Warning system is malfunctioning • Blinks during the following conditions: <ul style="list-style-type: none"> - DTC is detected or system is temporarily disabled. - When rear view camera blockage is detected.

DISPLAY AND WARNING OPERATION

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
OFF	—	—	—	OFF	OFF




A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

OPERATION

[BSW]

< SYSTEM DESCRIPTION >

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
ON	Less than approx. 29km/h (18MPH)	—	—	OFF	OFF
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF
		OFF	Vehicle is detected	ON	OFF
		ON (vehicle detected direction)	Before turn signal operates Vehicle is detected	Blink  Indicator ON Indicator OFF 200 ms 200 ms JSOIA0251GB	Short continuous beep  Buzzer ON Buzzer OFF 80 ms 550 ms JSOIA0252GB
	ON (vehicle detected direction)	Vehicle is detected after turn signal operates	Blink  Indicator ON Indicator OFF 200 ms 200 ms JSOIA0251GB	OFF	

NOTE:

- If vehicle speed exceeds approximately 32 km/h (20 MPH), BSW function operates until the vehicle speed becomes lower than approximately 29 km/h (18 MPH).
- Time shown in the figure is approximate.
- Whenever Blind Spot Warning system is turned off, the warning systems ON indicator remains OFF.

HANDLING PRECAUTION

Precautions for Blind Spot Warning


INFOID:000000011039505

REAR VIEW CAMERA HANDLING

The rear camera unit "1" for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



BLIND SPOT WARNING (BSW)

- BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- The camera unit may not detect properly under the following conditions:
 - When towing a trailer.
 - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
 - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - Several types of vehicles such as motorcycles.
 - Oncoming vehicles.
 - A vehicle approaching rapidly from behind
 - A vehicle which your vehicle overtakes rapidly.
- The camera unit may not be able to detect properly when your vehicle travels beside the middle section of a vehicle with a long wheelbase (e.g., trailer truck, semi-trailer, tractor).
- The camera unit is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- The camera unit may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

[BSW]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:000000011059332

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit.
Data Monitor	Displays ITS control unit input/output data in real time.
Work support	Displays causes of automatic system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load.
ECU identification	Displays ITS control unit part number.
Configuration	The vehicle specification can be written when replacing the ITS control unit.

SELF DIAGNOSTIC RESULT

Refer to [DAS-19, "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication).
REVERSE SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication).
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication].
CAMERA SWITCH SIGNAL [On/Off]	Indicates [ON/OFF] status of camera switch signal as judged from ITS control unit.
CAMERA OFF SIGNAL [On/Off]	Indicates [ON/OFF] status of camera OFF signal as judged from ITS control unit.
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling").
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2).
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD).
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines.
WASH SW [On/Off]	Indicates the state of the wash switch indicator output.
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines.
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines.
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit.

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BSW]

Monitored item [Unit]	Description
ILL [On/Off]	Indicates [ON/OFF] status of the illumination signal.
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit.
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output.
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output.
ITS SW 2 [On/Off/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit.
ITS SW 2 IND [On/Off/No setting]	Indicates the state of the warning system secondary switch indicator output.

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not.
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera.
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor.
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process.
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view.
REAR CAMERA ITS	Displays and sets camera image calibration values.
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation.
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation.

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description	
WASH ACTIVE	ON	Activates the washer to clean the lens of rear camera.
	OFF	
LED LH INDICATOR	ON	Flashes the left side LED light for ITS system.
	OFF	
LED RH INDICATOR	ON	Flashes the right side LED light for ITS system.
	OFF	
AIR ACTIVE	ON	Activates the air pump to clean the lens of rear camera.
	OFF	
AIR & WASH ACTIVE	ON	Activates the air pump and washer to clean the lens of rear camera.
	OFF	

ECU IDENTIFICATION

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BSW]

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:0000000011059333

VALUES ON THE DIAGNOSIS TOOL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


Monitor item	Condition		Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch ON	Steering angle signal is received.	On
		Steering angle signal is not received.	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse).	On
		Shift selector is not in R (reverse).	Off
VEHICLE SPEED SIGNAL	While driving	Vehicle speed signal is received.	On
		Vehicle speed signal is not received.	Off
CAMERA SWITCH SIGNAL	Ignition switch ON	Camera switch is pressed.	On
		Camera switch is not pressed.	Off
CAMERA OFF SIGNAL	Ignition switch ON	Purpose switch is pressed.	On
		Purpose switch is not pressed.	Off
ST ANGLE SENSOR TYPE	Ignition switch ON	Steering angle sensor type is displayed.	Absolute
		Steering angle sensor type is not received.	Not
STEERING GEAR RATIO TYPE	Ignition switch ON	Pattern 1 type of steering gear ratio displayed.	Pattern 1
		Pattern 2 type of steering gear ratio displayed.	Pattern 2
STEERING POSITION	Ignition switch ON	It recognizes steering position is left.	LHD
		It recognizes steering position is right.	RHD
R-CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK.	OK
		Rear camera serial status is not OK.	NG
R-CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received.	OK
		Rear camera serial communication signal is not received.	NG
ILL	Ignition switch ON	Illumination is ON.	On
		Illumination is OFF.	Off
ITS SW 1	Ignition switch ON	ITS switch is pressed.	On
		ITS switch is not pressed.	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting.	On
		Indicator of ITS switch 1 is not lighting.	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received.	Left
		Turn signal neutral is received.	N
		Turn signal right is received.	Right
REAR CAMERA IMAGE SIGNAL	Ignition switch ON	Camera image signal is received.	On
		Camera image signal is not received.	Off
ITS SW 2	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
WASH SW	Ignition switch ON	Wash switch signal is pressed.	On
		Wash switch signal is not pressed.	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received.	On
		Pump communication signal is not received.	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer fluid level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (G)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (W)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN low	—	—		—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (P)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN high	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (reverse)	12 V
					Shift selector not in R (reverse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—		0 V
50	Ground	Shield	—	—		0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON		0 V

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
53	Ground	Shield	—	—	0 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	Camera image signal	Input	When camera image is displayed	

Fail-safe

INFOID:0000000011059334

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on AV control unit display)	Cancel

DTC Inspection Priority Chart

INFOID:0000000011059335

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

Priority	Detected items (DTC)
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

DTC Index

INFOID:000000011039510

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
 - 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
 - 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
 - Other than CAN communication system (Other than U1000, U1010)
 - 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-191
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-192
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-193
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-194
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-195
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-196
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-197
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-198

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BSW]

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-199
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-201
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-202
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-203
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-204
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-207
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-208

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.
 A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000011059262




AAOWA0043GB

DRIVER ASSISTANCE SYSTEMS

[BSW]

< WIRING DIAGRAM >

(QB) : QR25DE FOR CALIFORNIA
 (QC) : QR25DE EXCEPT FOR CALIFORNIA *1
 (VD) : WITH VQ35DE
 (OE) : 99
 (OC) : 99 *2
 (VC) : 123
 (OE) : 100
 (OC) : 100 *2
 (VC) : 124



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

AAOWA0044GB

DRIVER ASSISTANCE SYSTEM CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1G	LG	-
2G	BR	-
22G	L	-
23G	P	-
95G	R	-(WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM)
100G	B	-(WITH REAR VIEW CAMER WASHER CONTROL SYSTEM)

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-




Terminal No.	Color of Wire	Signal Name
10J	LG	-
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	R	-
96J	B	-

DRIVER ASSISTANCE SYSTEMS

[BSW]


< WIRING DIAGRAM >

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	109	Color of Wire	G	Signal Name	REVERSE SIGNAL
--------------	-----	---------------	---	-------------	----------------

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	59	Color of Wire	P	Signal Name	CAN-L
Terminal No.	60	Color of Wire	L	Signal Name	CAN-H

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	4	Color of Wire	GR	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	M53
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE



Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	5	Color of Wire	L	Signal Name	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	38	Color of Wire	P	Signal Name	CAN-L
Terminal No.	39	Color of Wire	L	Signal Name	CAN-H

AAOIA0177GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[BSW]

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

AAOIA0178GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[BSW]

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	G	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	BG	-
5	G	-
6	P	-
8	B	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA+
42	SHIELD	CAMERA-SHIELD

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

AAOIA0179GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[BSW]

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA - (SHIELD)

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	-(WITH REAR VIEW CAMERA)
8	R	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-
4	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-
4	L	-

AAOIA0180GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[BSW]

Connector No.	E12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	9	Color of Wire	P	Signal Name	-
Terminal No.	10	Color of Wire	L	Signal Name	-

Connector No.	E10
Connector Name	ECM
Connector Color	GRAY




Terminal No.	99	Color of Wire	P	Signal Name	CAN-L
Terminal No.	100	Color of Wire	L	Signal Name	CAN-H

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY



Terminal No.	1	Color of Wire	P	Signal Name	-
Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	4	Color of Wire	P	Signal Name	-
Terminal No.	6	Color of Wire	P	Signal Name	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	1	Color of Wire	L	Signal Name	-
Terminal No.	2	Color of Wire	L	Signal Name	-
Terminal No.	4	Color of Wire	L	Signal Name	-
Terminal No.	6	Color of Wire	L	Signal Name	-

AAOIA0181GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

[BSW]

< WIRING DIAGRAM >


Connector No.	E31
Connector Name	ECM
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Terminal No.	Color of Wire	Signal Name
1G	BG	-(WITH REAR VIEW CAMERA)
2G	R	-
22G	L	-
23G	P	-
95G	BG	-
100G	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
74	BG	WASH MTR (WITH REAR VIEW CAMERA)

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E32
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
123	L	CAN-H
124	P	CAN-L


AAOIA0182GB

DRIVER ASSISTANCE SYSTEMS

[BSW]

< WIRING DIAGRAM >

Connector No.	E208
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	E203
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	- (WITH REAR VIEW CAMERA)
8	R	-

Connector No.	F16
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	E226
Connector Name	WASHER MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	O	-

AAOIA0183GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

[BSW]

< WIRING DIAGRAM >


Connector No.	B16
Connector Name	REAR VIEW CAMERA WASHER CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	PUMP MOTOR +
2	BR	PUMP MOTOR -
3	L	WASHER MOTOR -
4	B	WASHER MOTOR +
5	B	GND
6	P	SERIAL GND
7	G	FROM PUMP TO CAMERA C/U
8	W	FROM CAMERA C/U TO PUMP
12	W	IGN

Terminal No.	Color of Wire	Signal Name
10J	W	-
51J	W	-
52J	B	-
53J	R	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	L	-
96J	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
18	B	-

Connector No.	B35
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
4	G	-
5	R	-
7	B	-
8	W	-

Connector No.	B17
Connector Name	REAR VIEW CAMERA AIR PUMP MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	BR	-


AAOIA0184GB

DRIVER ASSISTANCE SYSTEMS

[BSW]


< WIRING DIAGRAM >

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-

Connector No.	D3
Connector Name	BLIND SPOT WARNING INDICATOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-

AAOIA0185GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000011039512

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-181, "Diagnostic Work Sheet"](#).)

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[BSW]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading".
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-183, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform BSW system action test to check the operation status. Refer to [DAS-184, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-166, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-218, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform "self-diagnosis". Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform BSW system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:0000000011039513

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

[BSW]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using BSW				
	<input type="checkbox"/> All functions do not operate.				
	<input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator)				
	<input type="checkbox"/> Yawing function does not operate. (Warning function is operated.)				
	<input type="checkbox"/> Functions when changing the course in the turn signal direction.				
<input type="checkbox"/> Functions are untimely.					
<input type="checkbox"/> Does not function when driving on lane markers.					
<input type="checkbox"/> Functions when driving in a lane.					
<input type="checkbox"/> Functions in a different position from the actual position.					
<input type="checkbox"/> Others ()					
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> In the daytime	<input type="checkbox"/> At night	<input type="checkbox"/> Sunrise/sunset (Strong light)	
	<input type="checkbox"/> Direct light	<input type="checkbox"/> Backlight	<input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped	
Weather conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Fine	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing	
	<input type="checkbox"/> Clouding	<input type="checkbox"/> Others ()			
Road conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Highway	<input type="checkbox"/> In town	<input type="checkbox"/> Others ()	
	<input type="checkbox"/> Uneven roads	<input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected	<input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()	
Other conditions					

ALOIA0193GB

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[BSW]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:0000000011039514

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

YES >> Clean camera lens.

NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

YES >> GO TO 3.

NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-189, "Work Procedure \(Rear View Camera Calibration\)"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26, "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

YES >> Inspection End.

NO >> Repair vehicle to appropriate height.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ACTION TEST

Description

INFOID:000000011059336

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-83, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000011059337

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-236, "Precautions for Moving Objects Detection"](#).

1.CHECK BSW SYSTEM SETTING

1. Start the engine.
2. Check that the BSW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2.ACTION TEST FOR BSW

1. Enable the setting of the BSW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the BSW operation according to the following table.

ACTION TEST

[BSW]

< BASIC INSPECTION >

Vehicle condition/Driver's operation					
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the combination meter	Buzzer
ON	Less than Approx. 29 km/h (18 MPH)	—	—	OFF	OFF
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF
		OFF	Vehicle is detected	ON	ON
		ON (vehicle detected direction)	Before turn signal operates vehicle is detected	Blink	Short continuous beeps
				<p style="text-align: center;">Indicator ON Indicator OFF</p> <p style="text-align: center;">200 ms</p> <p style="text-align: center;">200 ms</p> <p style="text-align: center;">JSOIA0251GB</p> <p style="text-align: center;">Buzzer ON Buzzer OFF</p> <p style="text-align: center;">80 ms</p> <p style="text-align: center;">550 ms</p> <p style="text-align: center;">JSOIA0252GB</p>	
Vehicle is detected after turn signal operates	Blink	OFF			
<p style="text-align: center;">Indicator ON Indicator OFF</p> <p style="text-align: center;">200 ms</p> <p style="text-align: center;">200 ms</p> <p style="text-align: center;">JSOIA0251GB</p>					

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-153. "System Description"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[BSW]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000011059338

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000011059339

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment using CONSULT. Refer to [DAS-187, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the "self-diagnosis" of "ITS control unit" using CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-166, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-184, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform "WASH ACTIVE" in "Active Test" using CONSULT.

2. Perform air and washer tube connection check by "AIR & WASH ACTIVE" in Active Test:

- (1) Washer fluid output count on the rear view camera is 3 to 5 times → OK.
- (2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking.
- (3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking.
- (4) No washer fluid output → Check tube with blue marking or check valve.

>> Inspection End.

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[BSW]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:000000011059340

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the CONSULT when performing the calibration. (Rear view camera calibration cannot be operated without CONSULT).

Work Procedure (Preparation)

INFOID:000000011059341

1.PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of the "ITS control unit".

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-166. "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

2.PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the "ITS control unit" using CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-183. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3.PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

[BSW]

< BASIC INSPECTION >

>> Refer to [DAS-188. "Work Procedure \(Target Setting\)".](#)


Work Procedure (Target Setting)

INFOID:000000011059342

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".


9. Position the center of the target mark to point of "Ct".



REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[BSW]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-189, "Work Procedure \(Rear View Camera Calibration\)"](#).

Work Procedure (Rear View Camera Calibration)

INFOID:000000011059343


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-187, "Work Procedure \(Preparation\)"](#).

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" using CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
- Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.

4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[BSW]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-188, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> • Temporary malfunction in internal processing of the rear view camera. • Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> • A target is not-yet-placed. (The rear view camera cannot detect a target.) • The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-187, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> • Inappropriate work environment. • Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of "ITS control unit" using CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-166, "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-184, "Description"](#).

>> Work End.

C1A03 VEHICLE SPEED SENSOR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000011059344

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-191, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059345

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

DAS

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000011059346

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-192, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059347

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011059348

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-193, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059349

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000011059350

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-194, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059351

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:0000000011059352

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit).

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-195, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:0000000011059353

1. CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011059354

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000011059355

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When "U1232" is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

U1000 CAN COMM CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011059356

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-30, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:0000000011059357

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more.	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:0000000011059358

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" using CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-197, "Description"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000011059359

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000011059360

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis.	ITS control unit

Diagnosis Procedure

INFOID:000000011059361

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
- NO >> Inspection End.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:0000000011059362

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted.	Check rear camera image signal circuit between rear camera and ITS control unit.

Diagnosis Procedure

INFOID:0000000011059363

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK CONTINUITY OF REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear view camera connector.
- Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear view Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE OF REAR VIEW CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear view camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		"CAMERA" switch is ON or shift selector is in R (Reverse)	6.2 V
Connector	Terminal		
M59	52		

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

3. CHECK CONTINUITY OF REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

- Turn ignition switch OFF.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect the ITS control unit connector and rear view camera connector.
3. Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.


ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4. CHECK OF REAR VIEW CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear view camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
 NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:0000000011059364

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:0000000011059365

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-160, "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" using CONSULT. Refer to [DAS-160, "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000011059366

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete.	Perform ITS configuration with CONSULT.

Diagnosis Procedure

INFOID:000000011059367

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-160, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1308 CAMERA CONFIG

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U1308 CAMERA CONFIG

DTC Logic

INFOID:0000000011059368

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB	ITS control unit calibration is incomplete.	Perform ITS calibration with CONSULT.

Diagnosis Procedure

INFOID:0000000011059369

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-160, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000011059370

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-204, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059371

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY OF ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1309 PUMP UNIT CURRENT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
NO >> Repair the harness or connector.

4.CHECK CONTINUITY OF REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
NO >> Replace the rear view camera air pump motor.

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		
	Ground		

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

U130B REAR CAMERA COMM ERROR

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000011059372

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-207, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059373

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000011059374

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-208, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059375

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair the harness or connector.

4.CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
 NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
 NO >> Replace the rear view camera air pump motor. Refer to [DAS-72. "Removal and Installation"](#).

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011059376

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	OFF		Battery voltage
	39	ON		Battery voltage
Ground		OFF	0 V	
		ON	Battery voltage	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

WARNING SYSTEMS SWITCH CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000011059377

1. CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the Data Monitor item "ITS SW 1" of "AVM" using CONSULT.
3. While operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	Off

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-212. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011059378

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	0 V
Connector	Terminal		
M58	32		
		Pressed	0 V
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-213. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-144. "Removal and Installation"](#).

3. CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011059379

1.CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

DAS

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Diagnosis Procedure

INFOID:000000011059380

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M62	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-215. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

NO >> Replace warning systems switch. [DAS-144. "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

Component Inspection

INFOID:0000000011059381

1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

BLIND SPOT WARNING INDICATOR CIRCUIT

[BSW]

< DTC/CIRCUIT DIAGNOSIS >

BLIND SPOT WARNING INDICATOR CIRCUIT

Component Function Check

INFOID:000000011059331

1. CHECK BLIND SPOT WARNING INDICATOR LH/RH

1. Turn the ignition switch ON.
2. Select "LED LH INDICATOR/LED RH INDICATOR" in Active Test of "AVM" using CONSULT.
3. While operating the test items, check that the BSW indicator LH/RH turns ON/OFF.

On : LED LH INDICATOR/LED RH INDICATOR ON.

Off : LED LH INDICATOR/LED RH INDICATOR OFF.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-216, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011059330

1. CHECK BSW INDICATOR VOLTAGE CIRCUIT

1. Disconnect the BSW indicator harness connector in question.
2. Turn the ignition switch ON.
3. Select "LED LH INDICATOR/LED RH INDICATOR" in "Active Test" of "AVM" using CONSULT.
4. With LED LH INDICATOR /LED RH INDICATOR ON, check the voltage between the BSW indicator harness connector and ground.

(+)		(-)	Voltage (Approx.)
BSW indicator		Ground	
Connector	Terminal		
D3 (LH)	1		12 V
D103 (RH)			

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK BSW INDICATOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ITS control unit harness connector.
3. Check continuity between ITS control unit harness connector and BSW indicator harness connector.

ITS control unit		BSW indicator		Continuity
Connector	Terminal	Connector	Terminal	
M58	37	D3 (LH)	1	Yes
	17	D103 (RH)		

4. Check continuity between ITS control unit harness connector and ground.

ITS control unit		(-)	Continuity
Connector	Terminal	Ground	
M58	37		No
	17		

Is the inspection result normal?

YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Repair or replace the harness or connector.

BLIND SPOT WARNING INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

3. CHECK BSW INDICATOR GROUND CIRCUIT FOR OPEN

Check continuity between BSW indicator harness connector and ground.

BSW indicator		Ground	Continuity
Connector	Terminal		
D3 (LH)	1		Yes
D103 (RH)			

Is the inspection result normal?

YES >> Replace BSW indicator. Refer to [DAS-223, "Removal and Installation"](#).

NO >> Repair or replace the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

SYMPTOM DIAGNOSIS

BSW SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000011039564

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

NOTE:

Refer to the following for operating conditions of the Blind Spot Warning system.

- Blind Spot Warning system: [DAS-153, "System Description"](#).

Symptom	Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	Blind Spot Warning lamp does not illuminate.	<ul style="list-style-type: none"> • Combination meter • ITS control unit Combination meter. Refer to MWI-18, "Description" .
	All of indicator/warning lamps do not illuminate; <ul style="list-style-type: none"> • Blind Spot Warning lamp • Warning systems ON indicator 	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit. • ITS control unit • Combination meter Power supply and ground circuit of ITS control unit. Refer to DAS-211, "Diagnosis Procedure" .
	Warning systems ON indicator (on the warning systems switch) does not illuminate.	<ul style="list-style-type: none"> • Harness between ITS control unit and warning systems switch • Warning systems switch • ITS control unit Warning systems ON indicator circuit. Refer to DAS-214, "Diagnosis Procedure" .
	Blind Spot Warning indicator does not turn ON.	<ul style="list-style-type: none"> • Harness between ITS control unit and Blind Spot Warning indicator. • Blind Spot Warning indicator BSW indicator circuit. Refer to DAS-216, "Component Function Check" .
BSW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON.)	Warning systems ON indicator is not turned ON ⇔ OFF when operating warning systems switch.	<ul style="list-style-type: none"> • Warning systems switch circuit. Refer to DAS-212, "Diagnosis Procedure". • BSW system setting cannot be turned ON/OFF on the combination meter information display. Refer to MWI-69, "Diagnosis Procedure".
	Buzzer is not sounding.	<ul style="list-style-type: none"> • Warning buzzer • ITS control unit Meter buzzer circuit. Refer to WCS-27, "Component Function Check" .
Blind Spot Warning functions are not timely (Example) <ul style="list-style-type: none"> • Does not function when approaching a lane marker with a vehicle in the blind spot. • Functions when driving in the middle of lane. 	<ul style="list-style-type: none"> • Camera aiming • Rear view camera 	Camera aiming. Refer to DAS-187, "Description" .

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[BSW]

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

Description

INFOID:000000011039565

The switch does not turn ON

- The warning system switch does not turn ON when the warning system switch is pressed.

The switch does not turn OFF

- The warning system switch does not turn OFF when the warning system switch is pressed.

Diagnosis Procedure

INFOID:000000011039566

1. CHECK WARNING SYSTEM SWITCH CIRCUIT

Check the warning system switch circuit. Refer to [DAS-212. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2. CHECK WARNING SYSTEM SWITCH

Check the warning system switch. Refer to [DAS-213. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

NO >> Replace the warning system switch. Refer to [DAS-222. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

BSW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[BSW]

BSW SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:000000011039567

BSW system setting is not selectable on the combination meter information display.

Diagnosis Procedure

INFOID:000000011039568

1. CHECK BSW SYSTEM SETTING

1. Ignition On.
2. Check that the BSW system setting can be turned ON/OFF in the combination meter information display using the steering switch.

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 2.

2. CHECK STEERING SWITCH CIRCUIT

Check steering switch circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector.

3. CHECK STEERING SWITCH RESISTANCE

Check steering switch resistance. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-81, "Removal and Installation"](#).
NO >> Replace steering switches. Refer to [AV-52, "Removal and Installation"](#).

NORMAL OPERATING CONDITION

[BSW]

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000011039569

PRECAUTIONS FOR BLIND SPOT WARNING (BSW)

- The Blind Spot Warning system is not a replacement for proper driving procedure and are not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction driver will move to ensure it is safe to change lanes. Never rely solely on the Blind Spot Warning system.
- The Blind Spot Warning system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Blind Spot Warning system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect and activate Blind Spot Warning when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - Several types of vehicles such as motorcycles.
 - Oncoming vehicles.
 - Vehicles remaining in the detection zone when driver accelerates from a stop.
 - A vehicle merging into an adjacent lane at a speed approximately the same as vehicle.
 - A vehicle approaching rapidly from behind.
 - Another vehicle which overtakes this vehicle rapidly.
- Severe weather or road spray conditions may reduce the ability of the rear view camera to detect other vehicles.
- The rear view camera detection zone is designed based on a standard lane width. When driving in a wider lane, the rear view camera may not detect vehicles in an adjacent lane. When driving in a narrow lane, the rear view camera may detect vehicles driving two lanes away.
- The rear view camera is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.

PRECAUTIONS FOR BLIND SPOT WARNING

- Do not use the Blind Spot Warning system under the following conditions because the system may not function properly:
 - During bad weather (e.g., rain, fog, snow, wind, etc.)
 - When driving on slippery roads, such as on ice or snow, etc.
 - When driving on winding or uneven roads.
 - When there is a lane closure due to road repairs.
 - When driving in a makeshift lane.
 - When driving on roads where the lane width is too narrow.
 - When driving with a tire that is not within normal tire conditions (e.g., tire wear, low tire pressure, installation of spare tire, tire chains, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.
- The rear view camera may not detect lane markers in the following situations and the Blind Spot Warning system may not operate properly:
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; nonstandard lane markers; lane markers covered with water, dirt, snow, etc.
 - On roads where discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs.
 - On roads where the traveling lane merges or separates.
 - When the vehicle traveling direction does not align with the lane markers.
 - When rain, snow or dirt adheres to the lens of a the rear view camera unit.
 - When a sudden change in brightness occurs. (e.g., when the vehicle enters or exits a tunnel or under a bridge.)
 - When steering quickly.
 - When the hazard warning flashers are operated.
 - When driving on a curve at a high speed.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[BSW]

REMOVAL AND INSTALLATION


WARNING SYSTEMS SWITCH

Removal and Installation

INFOID:000000011039570


REMOVAL

1. Remove the instrument lower panel LH. Refer to [JP-21. "Removal and Installation"](#).
2. Remove screws (A) that retain the switch carrier (2) to the instrument lower panel LH (1).



3. Release the pawls then remove the warning system switch from the switch carrier (1).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

BSW INDICATOR


< REMOVAL AND INSTALLATION >

[BSW]

BSW INDICATOR

Exploded View

INFOID:000000011039571



1. Blind spot warning indicator 2. Front door 3. Door mirror corner finisher
A. Blind spot warning indicator harness connector ⇐ Front

NOTE:

LH side shown; RH side similar.

Removal and Installation


INFOID:000000011039572

REMOVAL AND INSTALLATION

Removal

1. Remove the front door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Disconnect the harness connector (A) for the BSW indicator.
3. Release the clips and pawl using a suitable tool and remove the door mirror corner finisher (1).
 - Push suitable tool underneath finisher, then pry outward as shown. Move tool further up near upper fastened area, then pry outward again.

- △: Clip
○: Pawl



4. Remove the blind spot warning indicator screws.
5. Remove the blind spot warning indicator.

Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA


[BSW]

< REMOVAL AND INSTALLATION >

REAR VIEW CAMERA

Exploded View

INFOID:000000011039573



1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039574

REMOVAL

1. Remove license lamp finisher. Refer to [EXT-36, "Removal and Installation"](#).
2. Disconnect the harness connector from rear view camera.
3. Disconnect rear washer tubes from rear view camera.
4. Remove rear view camera.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Perform rear view camera calibration. Refer to [DAS-187, "Description"](#).

REAR VIEW CAMERA WASHER CONTROL UNIT


< REMOVAL AND INSTALLATION >

[BSW]

REAR VIEW CAMERA WASHER CONTROL UNIT

Exploded View

INFOID:000000011039575




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039576

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA AIR PUMP MOTOR


< REMOVAL AND INSTALLATION >

[BSW]

REAR VIEW CAMERA AIR PUMP MOTOR

Exploded View

INFOID:000000011039577




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039578

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tubes from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor (1).



INSTALLATION

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011039582

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000011039584

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precautions For Harness Repair

INFOID:000000011039585

ITS communication uses a twisted pair line. Be careful when repairing it.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



PRECAUTIONS


[MOD]

< PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



PREPARATION

< PREPARATION >

[MOD]


PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000011039586

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
<p>— (J-46534) Trim Tool Set</p>  <p>AWJIA0483ZZ</p>	Removing trim components

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[MOD]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011060158



ALOIA0235ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[MOD]

- | | | | |
|--|---|---|---|
| 1. Combination meter | 2. Vehicle information display | 3. BCM (view with combination meter removed) | A |
| 4. Blind spot warning indicator RH | 5. Blind spot warning indicator LH | 6. TCM | |
| 7. ECM | 8. Warning systems switch | 9. Warning systems ON indicator | B |
| 10. Rear view camera washer control unit | 11. Rear view camera air pump motor | 12. Rear view camera | |
| 13. AV control unit | 14. ITS control unit
(view with center console assembly removed) | 15. Steering angle sensor
(view with steering wheel removed) | C |
| 16. Washer fluid level switch
(view with front bumper fascia removed) | 17. Washer motor | 18. ABS actuator and electric unit (control unit) | D |

Component Description

INFOID:000000011039588

Component	Description	
ITS control unit	<ul style="list-style-type: none"> Receives rear view camera image signal to detect moving objects. Receives steering angle sensor signal from steering angle sensor via CAN communication. Transmits a warning buzzer signal to the combination meter. Transmits rear view camera image signal to the AV control unit display. 	F
Blind Spot Warning indicator LH/RH	Receives blind spot warning indicator operation signal from ITS control unit and turns OFF, turns ON or blinks.	G
Warning system switch	Inputs the switch signal to ITS control unit.	
Warning system switch indicator (on the warning systems switch)	Indicates LDW/BSW system status.	H
Rear view camera	Detects moving objects rear of the vehicle	
ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"> Transmits vehicle speed signal to ITS control unit via CAN communication. Transmits yaw rate signal/side G sensor signal to ITS control unit via CAN communication. 	I
Buzzer (combination meter)	Receives buzzer signal from ITS control unit via CAN and sounds buzzer.	
Combination meter (vehicle information display)	Turns the Moving Object Detection (MOD) system ON/OFF according to the settings in information display.	J
Steering angle sensor	Transmits steering angle sensor signal to ITS control unit via CAN communication.	
BCM	Transmits the reverse signal to the ITS control unit via CAN communication.	K
ECM	Transmits engine speed signal to ITS control unit via CAN communication.	
TCM	Transmits the output shaft speed signal, input speed signal, current gear position signal and shift position signal to ITS control unit via CAN communication.	L
AV control unit	<ul style="list-style-type: none"> Receives the various systems and camera signals via CAN communication and routes them to the A/V control unit display. Turns the MOD indicator ON at the upper right corner of the AV control unit display. 	M
Rear view camera washer control unit	Controls the rear view camera air pump motor and washer motor according to the signals received from the ITS control unit.	
Rear view camera air pump motor	Drives air to the rear camera lens according to the signals received from the rear view camera washer control unit.	N
Washer fluid level switch	Transmits the washer fluid level switch signal to the ITS control unit.	
Washer motor	Washer fluid sprayed when the rear view camera washer control unit activates the washer motor.	DAS

SYSTEM

< SYSTEM DESCRIPTION >


[MOD]

SYSTEM

System Description

INFOID:000000011039589

SYSTEM DIAGRAM



ITS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

Transmit unit	Signal name	Description
ECM	CAN communication	Engine speed signal Receives engine status.
BCM	CAN communication	Door open status signal Receives door open status.
		Light status signal Receives light status.
		Reverse signal Receives reverse signal status.
Washer fluid level switch	Hard wire	Washer fluid level status.
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal Receives wheel speed.
TCM	CAN communication	Shift selector position signal Receives shift selector position.
Combination meter	CAN communication	Moving Object Detection ON/OFF signal Receives the ON/OFF status for Moving Object Detection function.
Rear view camera	NTSC	Video signal Receives the Rear View Camera image from camera for Moving Object Detection function in ITS controller.

Output Signal Item

SYSTEM


< SYSTEM DESCRIPTION >

[MOD]


Reception unit	Signal name		Description
Combination meter	CAN communication	Buzzer Request	Transmits a buzzer request signal when a moving object is detected.
Display	CAN communication	Visual signal request	Transmits a visual signal request from the ITS controller to display Rear View while the shift selector is in R (reverse).

FUNCTION DESCRIPTION


- The Moving Object Detection (MOD) system can help alert the driver of approaching vehicles or rear objects when the driver is backing out of a parking space.
- The MOD system comprises of the rear view camera as the main detection system, which is located on the trunk as illustrated.
- The MOD system operates at speeds below 8 km/h (5 MPH) whenever the vehicle is in R (reverse).



- The MOD system uses the rear view camera to detect approaching moving objects from either side.



- The MOD system can detect moving objects on either side as close as rear obstacles of up to approximately 3 m (10 feet).



OPERATION DESCRIPTION

- ITS control unit enables Moving Object Detection system.
- MOD system is turned ON/OFF according to the settings in the combination meter information display.
- MOD indicator is displayed on the AV control unit display.
- ITS control unit starts the control as follows, based on a vehicle detection signal.

Operation Condition of Moving Object Detection System

ITS control unit performs the control when the following conditions are satisfied:

- Moving Object Detection indicator: ON
- When the vehicle is moving in R (reverse) at 8 km/h (5 MPH) or less.

NOTE:

- When the Moving Object Detection system setting on the Vehicle Information Display is ON.

A
B
C
D
E
F
G
H
I
J
K
L
M
N

DAS

P

SYSTEM

< SYSTEM DESCRIPTION >

[MOD]

- Moving Object Detection braking will not operate or will stop operating and only a warning chime will sound under the following conditions:
 - When driving with a tire that is not within normal tire conditions (pressure, wear, chain, spare, etc.)
 - When the vehicle is equipped with non-original brake parts or suspension parts.
- Do not use the MOD system when towing a trailer.
- Excessive noise such as the audio system will interfere with the chime sound, and it may not be heard.

OPERATION

< SYSTEM DESCRIPTION >

[MOD]

OPERATION

System Display and Warning

INFOID:0000000011039590

INDICATOR AND WARNING LAMP

The MOD system can be turned ON or OFF for the current ignition cycle using the warning system switch. When toggled between ON and OFF, the indicator will appear on the right side of the rear view camera screen.

No.	Name	Description
1	MOD indicator (blue)	<ul style="list-style-type: none"> • Turns ON while MOD system is ON. • Under the following conditions, the MOD indicator (blue) will blink. <ul style="list-style-type: none"> - When the VDC system (except TCS function) or ABS operates. - When the VDC system is turned off.
	MOD warning lamp (orange)	<ul style="list-style-type: none"> • Turns ON when MOD system is malfunctioning. • Blinks under the following conditions: <ul style="list-style-type: none"> - When the component temperature reaches high level. - When rear view camera blockage is detected.

DISPLAY AND WARNING OPERATION

Vehicle condition/Driver's operation				
Moving Object Detection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area	Indication on the Moving Object Detection indicator	Buzzer
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
		Vehicle is absent	ON	OFF
	Approx. 8 km/h (5 MPH) or more	Vehicle is detected	ON	OFF
		Vehicle is not detected	ON	OFF

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

HANDLING PRECAUTION

Precautions for Moving Objects Detection

INFOID:000000011039591

REAR VIEW CAMERA HANDLING

- The rear view camera which is located on the back of the trunk performs the Moving Object Detection system.
- Always keep the rear view camera lens clean.
- Do not attach a sticker (including transparent material), install an accessory or paint work over the camera lens.
- Do not strike or scratch the lens causing physical damage to the camera or the surrounding area.

MOVING OBJECT DETECTION

- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather conditions could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect and activate Moving Object Detection when certain objects are present such as:
 - Pedestrians, bicycles, animals.
 - A vehicle passing at a speed greater than approximately 15 MPH (24km/h).
 - Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- Do not use the MOD system under the following conditions because the system may not function properly:
 - When driving with a tire that is not within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MOD]

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

CONSULT Function (AVM)

INFOID:0000000011060131

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ITS control unit.

Diagnosis mode	Description
Self Diagnostic Result	Displays the name of a malfunctioning system stored in the ITS control unit.
Data Monitor	Displays ITS control unit input/output data in real time.
Work support	Displays causes of automatic system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the ITS control unit to the load.
ECU identification	Displays ITS control unit part number.
Configuration	The vehicle specification can be written when replacing the ITS control unit.

SELF DIAGNOSTIC RESULT

Refer to [DAS-19. "DTC Index"](#).

DATA MONITOR

Monitored item [Unit]	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (Angle sensor transmits angle signal through CAN communication).
REVERSE SIGNAL [On/Off]	Indicates [ON/OFF] status as judged from ITS control unit (TCM transmits reverse signal through CAN communication).
VEHICLE SPEED SIGNAL [On/Off]	Indicates vehicle speed calculated from ITS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication].
CAMERA SWITCH SIGNAL [On/Off]	Indicates [ON/OFF] status of camera switch signal as judged from ITS control unit.
CAMERA OFF SIGNAL [On/Off]	Indicates [ON/OFF] status of camera OFF signal as judged from ITS control unit.
ST ANGLE SENSOR TYPE [Absolute/Not]	Indicates whether steering angle sensor type is absolute or not (ON means "controlling").
STEERING GEAR RATIO TYPE [Type 0/1]	Indicates the type of the steering gear ratio (type 1 or 2).
STEERING POSITION [LHD/RHD]	Indicates the steering position (LHD or RHD).
REAR CAMERA IMAGE SIGNAL [OK/Not]	Indicates the status of the rear camera image as read from ITS control unit through dedicated ITS communication lines.
WASH SW [On/Off]	Indicates the state of the wash switch indicator output.
R-CAMERA COMM STATUS [OK/Not]	Indicates the status of the rear camera communication status as read from ITS control unit through dedicated ITS communication lines.
R-CAMERA COMM LINE [OK/Not]	Indicates the condition of the rear camera communication line whether transmitting properly through dedicated ITS communication lines.
PUMP COMM STATUS [OK/NG]	Indicates the state of the communication signal from pump control unit.

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MOD]

Monitored item [Unit]	Description
ILL [On/Off]	Indicates [ON/OFF] status of the illumination signal.
ITS SW 1 [On/Off]	Indicates the state of the warning system switch as seen by the ITS control unit.
ITS SW 1 IND [On/Off]	Indicates the state of the warning system switch indicator output.
TURN SIGNAL [Left/N/Right]	Indicates [Left/N/Right] status of the turn signal output.
ITS SW 2 [On/Off/No setting]	Indicates the state of the warning system secondary switch as seen by the ITS control unit.
ITS SW 2 IND [On/Off/No setting]	Indicates the state of the warning system secondary switch indicator output.

WORK SUPPORT

Work support items	Description
PREDICTIVE COURSE LINE DISPLAY	Setting whether predictive guide line displays or not.
INITIALIZE CAMERA IMAGE CALIBRATION	Start the initialization process of the rear camera.
STEERING ANGLE SENSOR ADJUSTMENT	Execute register neutral point of steering angle sensor.
CALIBRATING CAMERA IMAGE (REAR CAMERA)	Displays the various values of the rear camera during the calibration process.
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	Adjustment the position of fixed guide line on rear wide view.
REAR CAMERA ITS	Displays and sets camera image calibration values.
CAUSE OF LDW CANCEL	Displays the information about reason of LDW cancellation.
CAUSE OF BSW CANCEL	Displays the information about reason of BSW cancellation.

ACTIVE TEST

CAUTION:

- **Never perform “Active Test” while driving the vehicle.**
- **The “Active Test” cannot be performed when the following systems warning indicators are illuminated:**
 - Lane Departure Warning indicator
 - Blind Spot Warning indicator
- **Place the shift selector to P (park) position, and then perform the test.**

Test item	Description	
WASH ACTIVE	ON	Activates the washer to clean the lens of rear camera.
	OFF	
LED LH INDICATOR	ON	Flashes the left side LED light for ITS system.
	OFF	
LED RH INDICATOR	ON	Flashes the right side LED light for ITS system.
	OFF	
AIR ACTIVE	ON	Activates the air pump to clean the lens of rear camera.
	OFF	
AIR & WASH ACTIVE	ON	Activates the air pump and washer to clean the lens of rear camera.
	OFF	

ECU IDENTIFICATION

DIAGNOSIS SYSTEM (ITS CONTROL UNIT)

[MOD]

< SYSTEM DESCRIPTION >

ITS control unit part number is displayed.

CONFIGURATION

The specifications of the vehicle can be written and read in the ITS control unit when replaced.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

ECU DIAGNOSIS INFORMATION

ITS CONTROL UNIT

Reference Value

INFOID:0000000011060128

VALUES ON THE DIAGNOSIS TOOL


Monitor item	Condition		Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch ON	Steering angle signal is received.	On
		Steering angle signal is not received.	Off
REVERSE SIGNAL	Ignition switch ON	Shift selector in R (reverse).	On
		Shift selector is not in R (reverse).	Off
VEHICLE SPEED SIGNAL	While driving	Vehicle speed signal is received.	On
		Vehicle speed signal is not received.	Off
CAMERA SWITCH SIGNAL	Ignition switch ON	Camera switch is pressed.	On
		Camera switch is not pressed.	Off
CAMERA OFF SIGNAL	Ignition switch ON	Purpose switch is pressed.	On
		Purpose switch is not pressed.	Off
ST ANGLE SENSOR TYPE	Ignition switch ON	Steering angle sensor type is displayed.	Absolute
		Steering angle sensor type is not received.	Not
STEERING GEAR RATIO TYPE	Ignition switch ON	Pattern 1 type of steering gear ratio displayed.	Pattern 1
		Pattern 2 type of steering gear ratio displayed.	Pattern 2
STEERING POSITION	Ignition switch ON	It recognizes steering position is left.	LHD
		It recognizes steering position is right.	RHD
R-CAMERA COMM STATUS	Ignition switch ON	Rear camera serial status is OK.	OK
		Rear camera serial status is not OK.	NG
R-CAMERA COMM LINE	Ignition switch ON	Rear camera serial communication signal is received.	OK
		Rear camera serial communication signal is not received.	NG
ILL	Ignition switch ON	Illumination is ON.	On
		Illumination is OFF.	Off
ITS SW 1	Ignition switch ON	ITS switch is pressed.	On
		ITS switch is not pressed.	Off
ITS SW 1 IND	Ignition switch ON	Indicator of ITS switch 1 is lighting.	On
		Indicator of ITS switch 1 is not lighting.	Off
TURN SIGNAL	Ignition switch ON	Turn signal left is received.	Left
		Turn signal neutral is received.	N
		Turn signal right is received.	Right
REAR CAMERA IMAGE SIGNAL	Ignition switch ON	Camera image signal is received.	On
		Camera image signal is not received.	Off
ITS SW 2	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
ITS SW 2 IND	Ignition switch ON	For this vehicle, the displaying is fixed.	No setting
WASH SW	Ignition switch ON	Wash switch signal is pressed.	On
		Wash switch signal is not pressed.	Off
PUMP COMM STATUS	Ignition switch ON	Pump communication signal is received.	On
		Pump communication signal is not received.	Off

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Washer fluid level switch	Input	Ignition switch ON	When washer fluid is low (switch closed)	0 V
					When washer fluid is not low (switch open)	12 V
2 (G)	Ground	Washer signal pump to camera	Input	Ignition switch ON		5 V
3 (W)	Ground	Washer signal camera to pump	Output	Ignition switch ON		5 V
7 (P)	Ground	CAN low	—	—		—
17 (G)	Ground	SOW LED signal R	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
20 (G)	Ground	Battery supply	Input	—	—	12 V
22 (P)	Ground	Serial ground	Output	—	—	0 V
27 (L)	Ground	CAN high	—	—	—	—
28 (R)	Ground	Reverse	Input	Ignition switch ON	Shift selector in R (reverse)	12 V
					Shift selector not in R (reverse)	0 V
32 (P)	Ground	Cancel SW output	Input	Ignition switch ON	Cancel switch pressed	0 V
					Cancel switch not pressed	12 V
33 (BG)	Ground	LED input	Output	Ignition switch ON	Warning system is ON	12 V
					Warning system is OFF	0 V
37 (W)	Ground	SOW LED signal L	Output	While driving	LDW/BSW detected	12 V
					LDW/BSW is not detected	0 V
39 (BG)	Ground	Ignition power supply	Input	Ignition switch ON		Battery Voltage
40 (B)	Ground	Ground	—	—		0 V
50	Ground	Shield	—	—		0 V
51 (R)	Ground	RR CAM GND	Output	Ignition switch ON		0 V



A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
52 (W)	Ground	RR CAM ON	Output	Ignition switch ON	6 V
53	Ground	Shield	—	—	0 V
66 (B)	Ground	RR CAM COMP +	Input	Ignition switch ON	
68 (G)	Ground	RR CAM CONT	Input	Ignition switch ON	5 V
69 (B)	Ground	Camera image signal	Input	When camera image is displayed	

Fail-safe

INFOID:000000011060129

If a malfunction occurs in each system, ITS control unit cancels each control, sounds a beep, and turns ON the warning lamp or indicator lamp.

System	Buzzer	Warning Indicator lamp	Description
Lane Departure Warning (LDW)	Low-pitched tone	Lane Departure Warning lamp	Cancel
Blind Spot Warning (BSW)	High-pitched tone	Blind Spot Warning lamp	Cancel
Moving Object Detection (MOD)	Low-pitched tone	Warning lamp MOD icon (on AV control unit display)	Cancel

DTC Inspection Priority Chart

INFOID:000000011060130

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • U1305: CAMERA IMAGE CALIB • U1308: CAMERA CONFIG

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

Priority	Detected items (DTC)
3	<ul style="list-style-type: none"> • C1A39: STRG SEN CIR • U0428: STRG SEN CAN CIR 2 • U111A: REAR CAMERA IMAGE SIGNAL • U1232: ST ANGLE SEN CALIB • U1309: PUMP UNIT CURRENT • U130B: REAR CAMERA COMM ERROR • U1310: PUMP UNIT CIRCUIT
4	<ul style="list-style-type: none"> • C1A03: VHCL SPEED SE CIRC • C1A04: VDC FAIL • U0122: VDC P-RUN DIAG • U0416: VDC CHECKSUM DIAG

DTC Index

INFOID:000000011039596

NOTE:

- The details of time display are as follows:
 - CRNT: A malfunction is detected now
 - PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
 - 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
 - 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
 - Other than CAN communication system (Other than U1000, U1010)
 - 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

Systems for fail-safe						
<ul style="list-style-type: none"> • A: Lane Departure Warning (LDW) • B: Blind Spot Warning (BSW) • C: Moving Object Detection (MOD) 						
DTC	CONSULT display	Warning lamp			Fail-safe	Reference
		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
C1A03	VHCL SPEED SE CIRC	ON	ON	ON	A, B, C	DAS-267
C1A04	VDC FAIL	ON	ON	ON	A, B, C	DAS-268
C1A39	STRG SEN CIR	ON	ON	ON	A, B, C	DAS-269
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	—	—	—	—	—
U0122	VDC P-RUN DIAG	ON	ON	ON	A, B, C	DAS-270
U0416	VDC CHECKSUM DIAG	ON	ON	ON	A, B, C	DAS-271
U0428	STRG SEN CAN CIR 2	ON	ON	ON	A, B, C	DAS-272
U1000 ^{NOTE}	CAN COMM CIRCUIT	ON	ON	ON	A, B, C	DAS-273
U1010	CONTROL UNIT (CAN)	ON	ON	ON	A, B, C	DAS-274

ITS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MOD]

Systems for fail-safe

- A: Lane Departure Warning (LDW)
- B: Blind Spot Warning (BSW)
- C: Moving Object Detection (MOD)

DTC	CONSULT display	Warning lamp			Fail-safe	Reference
CONSULT		Lane Departure Warning	Blind Spot Warning	Moving Object Detection	System	
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	ON	A, B, C	DAS-275
U1232	ST ANGLE SEN CALIB	ON	ON	ON	A, B, C	DAS-277
U1305	CAMERA IMAGE CALIB	ON	ON	ON	A, B, C	DAS-278
U1308	CAMERA CONFIG	ON	ON	ON	A, B, C	DAS-279
U1309	PUMP UNIT CURRENT	ON	ON	ON	A, B, C	DAS-280
U130B	REAR CAMERA COMM ERROR	ON	ON	ON	A, B, C	DAS-283
U1310	PUMP UNIT CIRCUIT	ON	ON	ON	A, B, C	DAS-284

NOTE:

With the detection of "U1000" some systems do not perform the fail-safe operation.
 A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ITS control unit becomes inoperable.


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:000000011059264



DRIVER ASSISTANCE SYSTEM

AAOWA0043GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]

(QB) : QR25DE FOR CALIFORNIA
 (QC) : QR25DE EXCEPT FOR CALIFORNIA *1
 (VD) : WITH VQ35DE
 (QB) : 99
 (QC) : 99 *2
 (VD) : 123
 (QB) : 100
 (QC) : 100
 (VD) : 124



AAOWA0044GB

DRIVER ASSISTANCE SYSTEM CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
2R	BG	-
5R	G	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1G	LG	-
2G	BR	-
22G	L	-
23G	P	-
95G	R	-(WITH REAR VIEW CAMERA WASHER CONTROL SYSTEM)
100G	B	-(WITH REAR VIEW CAMER WASHER CONTROL SYSTEM)

Terminal No.	Color of Wire	Signal Name
10J	LG	-
51J	W	-
52J	R	-
53J	B	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	R	-
96J	B	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS


AAOIA0176GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	109	Color of Wire	G	Signal Name	REVERSE SIGNAL
--------------	-----	---------------	---	-------------	----------------

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	59	Color of Wire	P	Signal Name	CAN-L
Terminal No.	60	Color of Wire	L	Signal Name	CAN-H

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	4	Color of Wire	GR	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	M53
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE



Terminal No.	2	Color of Wire	P	Signal Name	-
Terminal No.	5	Color of Wire	L	Signal Name	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	38	Color of Wire	P	Signal Name	CAN-L
Terminal No.	39	Color of Wire	L	Signal Name	CAN-H

AAOIA0177GB

DRIVER ASSISTANCE SYSTEMS


< WIRING DIAGRAM >

[MOD]

Terminal No.	Color of Wire	Signal Name
24	-	-
25	-	-
26	-	-
27	L	CAN-H
28	R	REV
29	-	-
30	-	-
31	-	-
32	P	CANCEL SW OUTPUT
33	BG	LED INPUT
34	-	-
35	-	-
36	-	-
37	W	SOW LED SIGNAL L
38	-	-
39	BG	IGN
40	B	GND

Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	G	SOW LED SIGNAL R
18	-	-
19	-	-
20	G	B+
21	-	-
22	P	SERIAL GND
23	-	-

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	WASH LVL SW
2	G	FROM PUMP TO CAMERA C/U
3	W	FROM CAMERA C/U TO PUMP
4	-	-
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
59	-	-
60	-	-
61	-	-
62	-	-
63	-	-
64	-	-
65	-	-
66	B	RR CAM COMP +
67	-	-
68	G	RR CAM CONT
69	B	COMP OUT +
70	-	-
71	-	-
72	-	-

Terminal No.	Color of Wire	Signal Name
46	-	-
47	-	-
48	-	-
49	-	-
50	SHIELD	-
51	R	RR CAM GND
52	W	RR CAM ON
53	SHIELD	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-

Connector No.	M59
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-

AAOIA0178GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	G	-

Connector No.	M62
Connector Name	WARNING SYSTEM SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	BG	-
5	G	-
6	P	-
8	B	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-
18	B	-

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA+
42	SHIELD	CAMERA-SHIELD

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITHOUT BOSE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN+H
17	P	CAN-L

AAOIA0179GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	P	-

Connector No.	M153
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
25	G	REVERSE
41	B	CAMERA +
42	SHIELD	CAMERA - (SHIELD)

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BG	-(WITH REAR VIEW CAMERA)
8	R	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-
4	P	-

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-
4	L	-

AAOIA0180GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]

Connector No.	E12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	9	Color of Wire	P	Signal Name	-
10	L	-	-	-	-

Connector No.	E10
Connector Name	ECM
Connector Color	GRAY




Terminal No.	99	Color of Wire	P	Signal Name	CAN-L
100	L	-	-	-	CAN-H

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY



Terminal No.	1	Color of Wire	P	Signal Name	-
2	P	-	-	-	-
4	P	-	-	-	-
6	P	-	-	-	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	1	Color of Wire	L	Signal Name	-
2	L	-	-	-	-
4	L	-	-	-	-
6	L	-	-	-	-


AAOIA0181GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]


Connector No.	E31
Connector Name	ECM
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Terminal No.	Color of Wire	Signal Name
1G	BG	-(WITH REAR VIEW CAMERA)
2G	R	-
22G	L	-
23G	P	-
95G	BG	-
100G	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E200
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
74	BG	WASH MTR (WITH REAR VIEW CAMERA)

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E32
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
123	L	CAN-H
124	P	CAN-L

AAOIA0182GB

A B C D E F G H I J K L M N P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]

Connector No.	E208
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	E203
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	BG	- (WITH REAR VIEW CAMERA)
8	R	-

Connector No.	F16
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	E226
Connector Name	WASHER MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	O	-


AAOIA0183GB

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[MOD]


Connector No.	B16
Connector Name	REAR VIEW CAMERA WASHER CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	PUMP MOTOR +
2	BR	PUMP MOTOR -
3	L	WASHER MOTOR -
4	B	WASHER MOTOR +
5	B	GND
6	P	SERIAL GND
7	G	FROM PUMP TO CAMERA C/U
8	W	FROM CAMERA C/U TO PUMP
12	W	IGN

Terminal No.	Color of Wire	Signal Name
10J	W	-
51J	W	-
52J	B	-
53J	R	-
54J	SHIELD	-
55J	G	-
65J	W	-
66J	G	-
67J	P	-
91J	L	-
96J	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
18	B	-

Connector No.	B35
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
4	G	-
5	R	-
7	B	-
8	W	-

Connector No.	B17
Connector Name	REAR VIEW CAMERA AIR PUMP MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	BR	-

AAOIA0184GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P


DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >


[MOD]

Connector No.	D103
Connector Name	BLIND SPOT WARNING INDICATOR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-

Connector No.	D3
Connector Name	BLIND SPOT WARNING INDICATOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-

AAOIA0185GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[MOD]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000011039598

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer to obtain information about symptoms using "Diagnostic Work Sheet". (Refer to [DAS-258, "Diagnostic Work Sheet"](#).)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[MOD]

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform "All DTC Reading".
2. Check if the DTC is detected on the self-diagnosis results of "AVM".

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to [DAS-260, "Inspection Procedure"](#).

>> GO TO 4.

4. ACTION TEST

Perform MOD system action test to check the operation status. Refer to [DAS-261, "Description"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to [DAS-243, "DTC Index"](#) (ITS CONTROL UNIT).

>> GO TO 7.

6. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to [DAS-292, "Symptom Table"](#).

>> GO TO 7.

7. MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform "self-diagnosis". Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

- YES >> GO TO 5.
NO >> GO TO 9.

9. REPAIR CHECK (ACTION TEST)

Perform MOD system action test. Also check the system operation.

Does it operate normally?

- YES >> Inspection End.
NO >> GO TO 4.

Diagnostic Work Sheet

INFOID:000000011039599

DESCRIPTION

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

There are many operating conditions that lead to the malfunction. A good grasp of such conditions can make troubleshooting faster and more accurate.

Some conditions may cause the lane departure warning lamp to stay ON.

DIAGNOSIS AND REPAIR WORK FLOW

[MOD]

< BASIC INSPECTION >

Utilize a work sheet sample to organize all of the information for troubleshooting.

KEY POINTS

- WHAT..... System and functions
- WHEN..... Date, Frequencies
- WHERE..... Road conditions
- HOW..... Operating conditions, Symptoms

WORK SHEET SAMPLE

Customer name MR/MS		Model and Year		VIN	
Engine #		Trans.		Mileage	
Incident Date		Manuf. Date		In Service Date	
Symptoms					
Indicator/Warning lamps	<input type="checkbox"/> Lane departure warning lamp	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Warning systems ON indicator	<input type="checkbox"/> Stays ON	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
	<input type="checkbox"/> Other lamps ()	<input type="checkbox"/> Stays ON <input type="checkbox"/> Turned ON occasionally	<input type="checkbox"/> Stays OFF <input type="checkbox"/> Others ()	<input type="checkbox"/> Blinks	
Functions	<input type="checkbox"/> When using MOD <input type="checkbox"/> All functions do not operate. <input type="checkbox"/> Warning function does not operate. (<input type="checkbox"/> No sound <input type="checkbox"/> No indicator) <input type="checkbox"/> Yawing function does not operate. (Warning function is operated.) <input type="checkbox"/> Functions when changing the course in the turn signal direction. <input type="checkbox"/> Functions are untimely. <input type="checkbox"/> Does not function when driving on lane markers. <input type="checkbox"/> Functions when driving in a lane. <input type="checkbox"/> Functions in a different position from the actual position. <input type="checkbox"/> Others ()				
Conditions					
Frequency	<input type="checkbox"/> Continuously		<input type="checkbox"/> Intermittently		
Light conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> In the daytime <input type="checkbox"/> Direct light	<input type="checkbox"/> At night <input type="checkbox"/> Backlight	<input type="checkbox"/> Sunrise/sunset (Strong light) <input type="checkbox"/> Others ()		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Vehicle speed	MPH (km/h)	<input type="checkbox"/> Vehicle is stopped		
Weather conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Fine <input type="checkbox"/> Clouding	<input type="checkbox"/> Raining	<input type="checkbox"/> Snowing <input type="checkbox"/> Others ()		
Road conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Highway <input type="checkbox"/> Uneven roads	<input type="checkbox"/> In town <input type="checkbox"/> Winding roads	<input type="checkbox"/> Others ()		
Lane maker conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> Clear	<input type="checkbox"/> Unclear	<input type="checkbox"/> Others ()		
Other conditions					

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

ALOIA0194GB

PRE-INSPECTION FOR DIAGNOSIS

< BASIC INSPECTION >

[MOD]

PRE-INSPECTION FOR DIAGNOSIS

Inspection Procedure

INFOID:000000011039600

1.CHECK CAMERA LENS

Is camera lens contaminated with foreign materials?

- YES >> Clean camera lens.
- NO >> GO TO 2.

2.CHECK REAR VIEW CAMERA UNIT INSTALLATION CONDITION

Check rear view camera unit installation condition (installation position, properly fitted).

Is it properly installed?

- YES >> GO TO 3.
- NO >> Install rear view camera unit properly, and perform rear view camera calibration. Refer to [DAS-263. "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-26. "Wheelarch Height \(Unladen*1\)"](#).

Is vehicle height appropriate?

- YES >> Inspection End.
- NO >> Repair vehicle to appropriate height.

ACTION TEST

< BASIC INSPECTION >

[MOD]

ACTION TEST

Description

INFOID:000000011039601

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-83, "Precautions for Lane Departure Warning"](#).

Inspection Procedure

INFOID:000000011039602

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

CAUTION:

- Fully understand the following items well before the road test;
 - Precautions: Refer to [DAS-74, "Precaution for LDW System Service"](#).
 - System description for LDW: Refer to [DAS-78, "System Description"](#).
 - System description for BSW: Refer to [DAS-153, "System Description"](#).
 - System description for MOD: Refer to [DAS-232, "System Description"](#).
 - Handling precaution: Refer to [DAS-236, "Precautions for Moving Objects Detection"](#).

1. CHECK MOD SYSTEM SETTING

1. Start the engine.
2. Check that the MOD system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

2. ACTION TEST FOR MOD

1. Enable the setting of the MOD system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the MOD operation according to the following table.

Vehicle condition/ Driver's operation			Vehicle response	
Moving Object De- tection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area	Indication on the Moving Object Detection indicator	Buzzer
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
		Vehicle is absent	ON	OFF
	Approx. 8 km/h (5 MPH) or more	Vehicle is detected	ON	OFF
Vehicle is not detected		ON	OFF	

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle reaches a higher speed. Refer to [DAS-232, "System Description"](#).

>> Inspection End.

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

< BASIC INSPECTION >

[MOD]

ADDITIONAL SERVICE WHEN REPLACING REAR VIEW CAMERA

Description

INFOID:000000011060126

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

The system does not operate normally unless the rear view camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:000000011060127

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment using CONSULT. Refer to [DAS-263, "Description"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the "self-diagnosis" of "ITS control unit" using CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-19, "DTC Index"](#).

NO >> GO TO 3.

3. LDW/BSW SYSTEM ACTION TEST

1. Perform the LDW/BSW system action test. Refer to [DAS-37, "Description"](#).

2. Check that the LDW/BSW system operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. LDW/BSW ACTIVE TEST

1. Perform "WASH ACTIVE" in "Active Test" using CONSULT.

2. Perform air and washer tube connection check by "AIR & WASH ACTIVE" in Active Test:

- (1) Washer fluid output count on the rear view camera is 3 to 5 times → OK.
- (2) Washer fluid output count on the rear view camera is 10 times → Check tube with yellow marking.
- (3) Washer fluid output count on the rear view camera is 1 time → Check tube with green marking.
- (4) No washer fluid output → Check tube with blue marking or check valve.

>> Inspection End.

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

REAR VIEW CAMERA CALIBRATION

Description

INFOID:0000000011060069

Always perform the calibration after removing and installing or replacing the rear view camera.

CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the **CONSULT** when performing the calibration. (Rear view camera calibration cannot be operated without **CONSULT**).

Work Procedure (Preparation)

INFOID:0000000011060070

1. PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of the "ITS control unit".

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19. "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

2. PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

NOTE:


Select the "AVM" to diagnose the "ITS control unit" using **CONSULT**.

1. Perform pre-inspection for diagnosis. Refer to [DAS-36. "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

3. PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

>> Refer to [DAS-264. "Work Procedure \(Target Setting\)"](#).


Work Procedure (Target Setting)

INFOID:000000011060071

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

1. TARGET SETTING



Side distance (S_d): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (L_d): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (R_d): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".

6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.


7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".


9. Position the center of the target mark to point of "Ct".



REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]



CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-265, "Work Procedure \(Rear View Camera Calibration\)"](#).

Work Procedure (Rear View Camera Calibration)

INFOID:000000011060072


CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-263, "Work Procedure \(Preparation\)"](#).

1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" using CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".

CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
- Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.

4. Input the rear view camera height "H", and then touch "APPLY".
5. Confirm that the same value is displayed on the center display.
6. Confirm the following items:
 - The target should be accurately placed.
 - The vehicle should be stopped.
 - The vehicle should be under the specified vehicle condition.
7. Select "Start" to perform calibration.
8. Confirm the displayed item.
 - "Completed": Select "Completion".
 - Otherwise, perform the following services:

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[MOD]

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to DAS-264, "Work Procedure (Target Setting)" .
	10H Writing error	<ul style="list-style-type: none"> • Temporary malfunction in internal processing of the rear view camera. • Rear view camera malfunction. 	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> • A target is not-yet-placed. (The rear view camera cannot detect a target.) • The position of the rear view camera is not correct. 	Position the target appropriately again. Perform the aiming again. Refer to DAS-263, "Work Procedure (Preparation)" .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> • Inappropriate work environment. • Inappropriate vehicle condition. 	

NOTE:

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform "self-diagnosis" of "ITS control unit" using CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-19, "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the system operation by action test. Refer to [DAS-37, "Description"](#).

>> Work End.

C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

DTC/CIRCUIT DIAGNOSIS

C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000011059955

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SEN CIRC	ITS control unit detects that the result of calculation about velocity has error.	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to [DAS-267, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059956

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).
NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

INFOID:000000011059957

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	VDC CIRCUIT	ITS control unit receives the message that means "VDC is failed" from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none">• ABS actuator and electric unit (control unit)• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to [DAS-268, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059958

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about VDC in "ALL DTC READING" using CONSULT.

Is any DTC detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).
- NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:0000000011059959

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	ITS control unit receives the message that means "Steering angle sensor is failed" from steering angle sensor.	<ul style="list-style-type: none">Steering angle sensorITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to [DAS-269, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:0000000011059960

1.CHECK STRG SENSOR SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-45, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK ALL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected except for ITS control unit about ABS in "ALL DTC READING" using CONSULT.

Is any DTC detected except for ITS?

- YES >> Replace steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).
NO >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0122 VDC P-RUN DIAG

DTC Logic

INFOID:000000011059961

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0122" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0122" detected as the current malfunction?

- YES >> Refer to [DAS-270, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000011059962

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2.CHECK ITS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0416 VDC CHECKSUM DIAG

DTC Logic

INFOID:0000000011059963

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DIAG	ITS control unit receives the incorrect signal about P-RUN from VDC via V-CAN communication.	ABS actuator and electric unit (control unit).

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U0416" is detected as the current malfunction in self-diagnosis results of "AVM".

Is "U0416" detected as the current malfunction?

- YES >> Refer to [DAS-271, "Diagnosis Procedure"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:0000000011059964

1. CHECK VDC UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts.
NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000011059965

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	Adjust neutral position of the steering angle sensor.

Diagnosis Procedure

INFOID:000000011059966

1. ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When "U1232" is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to [BRC-33, "CONSULT Function \(ABS\)"](#).

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011059967

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-30, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DTC Logic

INFOID:0000000011059968

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	If ITS control unit is not transmitting or receiving CAN communication signal or ITS communication signal for 2 seconds or more.	<ul style="list-style-type: none">• CAN communication system• ITS communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:0000000011059969

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ITS system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" using CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [DAS-273, "Description"](#).
NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000011059970

CAN controller controls the communication of CAN communication signal and ITS communication signal, and the error detection.

DTC Logic

INFOID:000000011059971

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	If ITS control unit detects malfunction by CAN controller initial diagnosis.	ITS control unit

Diagnosis Procedure

INFOID:000000011059972

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ITS system ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
- NO >> Inspection End.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000011059973

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Rear camera image signal circuit is open or shorted.	Check rear camera image signal circuit between rear camera and ITS control unit.

Diagnosis Procedure

INFOID:000000011059974

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK CONTINUITY OF REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the ITS control unit connector and rear view camera connector.
- Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear view Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	51	B35	7	Yes
	52		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M59	52		No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the harness or connector.

2. CHECK VOLTAGE OF REAR VIEW CAMERA POWER SUPPLY

- Connect the ITS control unit connector and rear view camera connector.
- Turn the ignition switch ON.
- Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)				(-)
ITS control unit				
Connector	Terminal			
M59	52	Ground	6.2 V	
		"CAMERA" switch is ON or shift selector is in R (Reverse)		

Is inspection result normal?

- YES >> GO TO 3.
 NO >> Replace ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

3. CHECK CONTINUITY OF REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

- Turn ignition switch OFF.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect the ITS control unit connector and rear view camera connector.
3. Check for continuity between ITS control unit harness connector and rear view camera harness connector.

ITS control unit		Rear View Camera		Continuity
Connector	Terminal	Connector	Terminal	
M59	50	B35	1	Yes
	66		5	

4. Check for continuity between ITS control unit harness connector and ground.


ITS control unit		Ground	Continuity
Connector	Terminal		
M59	50		No
	66		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4. CHECK OF REAR VIEW CAMERA IMAGE SIGNAL

1. Connect the ITS control unit connector and rear view camera connector.
2. Turn the ignition switch ON.
3. Using an oscilloscope, check voltage between ITS control unit harness connector terminals.

Terminal				Condition	Voltage (Approx.)
(+)		(-)			
ITS control unit					
Connector	Terminal	Connector	Terminal		
M59	66	M59	50	"CAMERA" switch is ON or shift selector is in R (Reverse)	

Is inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
 NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:0000000011059975

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor cannot finish.	<ul style="list-style-type: none">Steering angle sensorITS control unit

Diagnosis Procedure

INFOID:0000000011059976

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- Turn the ignition switch ON.
- Perform registration of the neutral position of the steering angle sensor. Refer to [DAS-237, "CONSULT Function \(AVM\)"](#).
- Check "Self Diagnostic Result" of "AVM" using CONSULT. Refer to [DAS-237, "CONSULT Function \(AVM\)"](#).

Is "ST ANGLE SEN CALIB" detected?

- YES >> GO TO 2.
NO >> Inspection End.

2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1305 CAMERA IMAGE CALIB

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1305 CAMERA IMAGE CALIB

DTC Logic

INFOID:000000011059977

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CAMERA CONFIG	ITS control unit configuration is incomplete.	Perform ITS configuration with CONSULT.

Diagnosis Procedure

INFOID:000000011059978

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1305" is current in "Self Diagnostic Result" of "AVM".

Is "U1305" detected?

- YES >> Perform ITS configuration using CONSULT. Refer to [DAS-237, "CONSULT Function \(AVM\)"](#). If problem persists, repair or replace the malfunctioning part.
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1308 CAMERA CONFIG

DTC Logic

INFOID:0000000011059979

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	ITS CALIB	ITS control unit calibration is incomplete.	Perform ITS calibration with CONSULT.

Diagnosis Procedure

INFOID:0000000011059980

1. CHECK SELF-DIAGNOSIS RESULTS

Check if "U1308" is current in "Self Diagnostic Result" of "AVM".

Is "U1308" detected?

- YES >> Perform ITS calibration of camera image using CONSULT. Refer to [DAS-237, "CONSULT Function \(AVM\)"](#).
- NO >> Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1309 PUMP UNIT CURRENT

DTC Logic

INFOID:000000011059981

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP UNIT CURRENT	ITS control unit detects the value of current from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

- YES >> Refer to [DAS-280, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059982

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit	Ground	Ignition ON	Battery voltage
Connector			
B16	12		

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY OF ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1309 PUMP UNIT CURRENT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

2. Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair the harness or connector.

4.CHECK CONTINUITY OF REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump connector.
2. Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
 NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
 NO >> Replace the rear view camera air pump motor.

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

1. Reconnect the ITS control unit connector.
2. Turn the ignition switch ON.
3. Using CONSULT, activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Activating pump	5 V
Connector	Terminals		
B16	7, 8		
	Ground		

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U130B REAR CAMERA COMM ERROR

DTC Logic

INFOID:000000011059983

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	ITS control unit receives the incorrect communication signal from rear view camera.	<ul style="list-style-type: none">• Rear view camera• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to [DAS-283, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059984

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the ITS control unit and rear view camera connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK REAR VIEW CAMERA VOLTAGE

1. Connect ITS control unit and rear view camera harness connectors.
2. Check voltage between ITS control unit connector M59 and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Ignition ON	5 V
Connector	Terminal		
M59	68	Ground	

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).
NO >> Replace rear view camera. Refer to [DAS-70, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

U1310 PUMP UNIT CIRCUIT

DTC Logic

INFOID:000000011059985

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP UNIT CIRCUIT	ITS control unit detects the value of voltage from pump control unit is incorrect.	<ul style="list-style-type: none">• Rear view camera washer control unit• Harness• ITS control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Perform "All DTC Reading" using CONSULT.
3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to [DAS-284, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000011059986

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT SUPPLY CIRCUIT

1. Disconnect the rear view camera washer control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between rear view camera washer control unit connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)	(-)		
Rear view camera washer control unit		Ignition ON	Battery voltage
Connector	Terminal		
B16	12	Ground	

Is inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harness or connector.

2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	5		Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK CONTINUITY ITS CONTROL UNIT TO REAR VIEW CAMERA WASHER CONTROL UNIT

1. Disconnect the ITS control unit connector.

U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

- Check for continuity between ITS control unit harness connector and rear view camera washer control unit connector.

ITS control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M58	2	B16	7	Yes
	3		8	

- Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	2		No
	3		

Is inspection result normal?

- YES >> GO TO 4.
 NO >> Repair the harness or connector.

4.CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

- Disconnect rear view camera air pump connector.
- Check for continuity between rear view camera washer control unit connector and pump connector.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	B17	1	Yes
	2		2	

- Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B16	1		No
	2		

Is inspection result normal?

- YES >> GO TO 5.
 NO >> Repair the harness or connector.

5.CHECK REAR VIEW CAMERA AIR PUMP MOTOR

Momentarily connect a jumper from a fused battery positive to terminal 1 and from ground to terminal 2 of the rear view camera air pump motor.

Does the pump operate?

- YES >> GO TO 6.
 NO >> Replace the rear view camera air pump motor. Refer to [DAS-72. "Removal and Installation"](#).

6.CHECK REAR VIEW CAMERA AIR PUMP MOTOR ITS CONTROL UNIT SUPPLY CIRCUIT

- Reconnect the ITS control unit connector.
- Turn the ignition switch ON.
- Activate the rear view camera air pump while checking voltage between rear view camera washer control unit connector and ground.



U1310 PUMP UNIT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Rear view camera washer control unit		Ground	Activating pump	5 V
Connector	Terminals			
B16	7, 8			

Can voltage be measured on either terminal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-71, "Removal and Installation"](#).
- NO >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011059987

Regarding Wiring Diagram information, refer to [DAS-21, "Wiring Diagram"](#).

1. CHECK ITS CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between ITS control unit harness connector and ground.

Terminal		Condition	Voltage (Approx.)	
(+)	(-)			
ITS control unit		Ignition switch		
Connector	Terminal			
M58	20	OFF		Battery voltage
	39	ON		Battery voltage
Ground		OFF	0 V	
		ON	Battery voltage	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the ITS control unit power supply circuit.

2. CHECK ITS CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the ITS control unit connector.
3. Check for continuity between ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	40		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the ITS control unit ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

INFOID:000000011059988

1. CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Select the Data Monitor item "ITS SW 1" of "AVM" using CONSULT.
3. While operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
ITS SW 1	Warning systems switch is pressed	On
	Warning systems switch is not pressed	Off

Is the inspection result normal?

- YES >> Warning systems switch circuit is normal.
NO >> Refer to [DAS-288. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011059989

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between ITS control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
ITS control unit		Warning systems switch	0 V
Connector	Terminal		
M58	32		
		Pressed	0 V
		Released	12 V

Is the inspection result normal?

- YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning systems switch.
3. Check warning systems switch. Refer to [DAS-289. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the warning systems switch. Refer to [DAS-144. "Removal and Installation"](#).

3. CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M62	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.

WARNING SYSTEMS SWITCH CIRCUIT

[MOD]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the ITS control unit connector.
2. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	32	M62	6	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	32		No

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011059990

1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
6	8	When warning systems switch is pressed	Yes
		When warning systems switch is released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

DAS

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

WARNING SYSTEMS ON INDICATOR CIRCUIT

Diagnosis Procedure

INFOID:000000011059991

Regarding Wiring Diagram information, refer to [DAS-21. "Wiring Diagram"](#).

1. CHECK WARNING SYSTEMS ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M62	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the ITS control unit harness connector.
3. Check continuity between the ITS control unit harness connector and warning system switch harness connector.

ITS control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M58	33	M62	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the ITS control unit harness connector and ground.

ITS control unit		Ground	Continuity
Connector	Terminal		
M58	33		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-291. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the ITS control unit. Refer to [DAS-69. "Removal and Installation"](#).

NO >> Replace warning systems switch. [DAS-144. "Removal and Installation"](#).

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MOD]

Component Inspection

INFOID:0000000011059992

1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning systems ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-144, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

SYMPTOM DIAGNOSIS

MOD SYSTEM SYMPTOMS

Symptom Table

INFOID:000000011039650

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

NOTE:

Refer to the following the operation condition of the Moving Object Detection system.

- Moving Object Detection system: [DAS-232, "System Description"](#).

Symptom	Possible cause	Inspection item/Reference page
MOD system is not activated.	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit. • ITS control unit • Combination meter • Steering switch 	<ul style="list-style-type: none"> • Power supply and ground circuit of ITS control unit. Refer to DAS-287, "Diagnosis Procedure". • MOD system setting cannot be turned ON/OFF in the combination meter information display. Refer to DAS-293, "Diagnosis Procedure".
Buzzer is not sounding.	<ul style="list-style-type: none"> • Buzzer (combination meter) 	Meter buzzer circuit. Refer to WCS-27, "Component Function Check" .

MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[MOD]

MOD SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

Description

INFOID:0000000011039651

Moving Object Detection system setting is not selectable on the combination meter information display.

Diagnosis Procedure

INFOID:0000000011039652

1. CHECK MOVING OBJECT DETECTION SYSTEM SETTING

1. Ignition On.
2. Check that the MOD system setting can be turned ON/OFF in the combination meter information display using the steering switch.

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 2.

2. CHECK STEERING SWITCH CIRCUIT

Check the steering switch circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector.

3. CHECK STEERING SWITCH RESISTANCE

Check the steering switch resistance. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-81, "Removal and Installation"](#).
NO >> Replace steering switches. Refer to [AV-52, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

NORMAL OPERATING CONDITION

Description

INFOID:000000011039653

MOVING OBJECT DETECTION

- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather condition could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
 - Pedestrians, bicycles, animals.
 - A vehicle passing at a speed greater than approximately 24km/h (15 MPH).
- A rear view camera may not detect approaching vehicles in certain situations:
 - When the vehicle parked aside obstruct the beam of the rear view camera.
 - When the vehicle is parked in an angled parking space.
 - When the vehicle is parked on an inclined ground.
 - When the vehicle turns around into your vehicle's aisle.
 - When the angle formed by your vehicle and approaching vehicle is small.
- Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- The rear view camera system may not detect:
 - Small or moving object.
 - Wedge-shaped objects.
 - Object closer to the bumper than 30 cm (10 inch).
 - Thin objects such as rope, wire, chain, etc.
- Do not use the MOD system under the following conditions because the system may not function properly:
 - When driving with a tire that is not the within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
 - When the vehicle is equipped with non-original brake parts or suspension parts.

REAR VIEW CAMERA WASHER CONTROL UNIT

< REMOVAL AND INSTALLATION >


[MOD]

REMOVAL AND INSTALLATION

REAR VIEW CAMERA WASHER CONTROL UNIT

Exploded View

INFOID:0000000011039654




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:0000000011039655

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER: Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts (A).
4. Remove the rear view camera washer control unit (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P

DAS

REAR VIEW CAMERA AIR PUMP MOTOR


< REMOVAL AND INSTALLATION >

[MOD]

REAR VIEW CAMERA AIR PUMP MOTOR

Exploded View

INFOID:000000011039656




1. Rear view camera washer control unit
2. Rear view camera air pump motor
3. Rear view camera
4. Trunk lid

Removal and Installation

INFOID:000000011039657

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-33, "TRUNK LID FINISHER : Removal and Installation"](#).
2. Disconnect the air tubes from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove the rear view camera air pump motor bracket nuts (A).
5. Remove the rear view camera air pump motor (1).



INSTALLATION

Installation is in the reverse order of removal.