

# SECTION LAN

## LAN SYSTEM

### CONTENTS

<b>CAN FUNDAMENTAL</b>	<b>HOW TO USE THIS SECTION</b> .....	<b>21</b>
<b>HOW TO USE THIS MANUAL</b> .....	Information .....	21
<b>HOW TO USE THIS SECTION</b> .....	Abbreviation List .....	21
Information .....	<b>PRECAUTION</b> .....	<b>22</b>
<b>PRECAUTION</b> .....	<b>PRECAUTIONS</b> .....	<b>22</b>
<b>PRECAUTIONS</b> .....	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	22
Precautions for Trouble Diagnosis .....	Precautions for Trouble Diagnosis .....	22
Precautions for Harness Repair .....	Precautions for Harness Repair .....	22
<b>SYSTEM DESCRIPTION</b> .....	<b>SYSTEM DESCRIPTION</b> .....	<b>24</b>
<b>SYSTEM</b> .....	<b>COMPONENT PARTS</b> .....	<b>24</b>
<b>CAN COMMUNICATION SYSTEM</b> .....	Component Parts Location .....	24
CAN COMMUNICATION SYSTEM : System Description .....	<b>SYSTEM</b> .....	<b>25</b>
<b>DIAG ON CAN</b> .....	<b>CAN COMMUNICATION SYSTEM</b> .....	<b>25</b>
DIAG ON CAN : System Description .....	CAN COMMUNICATION SYSTEM : System Description .....	25
<b>TROUBLE DIAGNOSIS</b> .....	CAN COMMUNICATION SYSTEM : CAN Communication Control Circuit .....	28
Component Description .....	CAN COMMUNICATION SYSTEM : CAN System Specification Chart .....	29
Condition of Error Detection .....	CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart .....	30
Symptom When Error Occurs in CAN Communication System .....	<b>WIRING DIAGRAM</b> .....	<b>33</b>
CAN Diagnosis with CONSULT .....	<b>CAN SYSTEM</b> .....	<b>33</b>
Self-Diagnosis .....	Wiring Diagram .....	33
CAN Diagnostic Support Monitor .....	<b>BASIC INSPECTION</b> .....	<b>39</b>
How to Use CAN Communication Signal Chart .....	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>39</b>
<b>BASIC INSPECTION</b> .....	Interview Sheet .....	39
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>40</b>
Trouble Diagnosis Flow Chart .....	<b>MALFUNCTION AREA CHART</b> .....	<b>40</b>
Trouble Diagnosis Procedure .....		
<b>CAN</b>		
<b>HOW TO USE THIS MANUAL</b> .....		

Main Line .....	40
Branch Line .....	40
Short Circuit .....	40
<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT .....</b>	<b>41</b>
Diagnosis Procedure .....	41
<b>MAIN LINE BETWEEN DLC AND M&amp;A CIR- CUIT .....</b>	<b>42</b>
Diagnosis Procedure .....	42
<b>MAIN LINE BETWEEN M&amp;A AND A-BAG CIRCUIT .....</b>	<b>43</b>
Diagnosis Procedure .....	43
<b>MAIN LINE BETWEEN M&amp;A AND AV CIR- CUIT .....</b>	<b>44</b>
Diagnosis Procedure .....	44
<b>MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT .....</b>	<b>45</b>
Diagnosis Procedure .....	45
<b>MAIN LINE BETWEEN AV AND HVAC CIR- CUIT .....</b>	<b>46</b>
Diagnosis Procedure .....	46
<b>ECM BRANCH LINE CIRCUIT .....</b>	<b>47</b>
Diagnosis Procedure .....	47
<b>ABS BRANCH LINE CIRCUIT .....</b>	<b>48</b>
Diagnosis Procedure .....	48
<b>EPS BRANCH LINE CIRCUIT .....</b>	<b>49</b>
Diagnosis Procedure .....	49
<b>IPDM-E BRANCH LINE CIRCUIT .....</b>	<b>50</b>
Diagnosis Procedure .....	50
<b>TCM BRANCH LINE CIRCUIT .....</b>	<b>51</b>
Diagnosis Procedure .....	51
<b>DLC BRANCH LINE CIRCUIT .....</b>	<b>52</b>
Diagnosis Procedure .....	52
<b>M&amp;A BRANCH LINE CIRCUIT .....</b>	<b>53</b>
Diagnosis Procedure .....	53
<b>STRG BRANCH LINE CIRCUIT .....</b>	<b>54</b>
Diagnosis Procedure .....	54
<b>A-BAG BRANCH LINE CIRCUIT .....</b>	<b>55</b>
Diagnosis Procedure .....	55
<b>AV BRANCH LINE CIRCUIT .....</b>	<b>56</b>
Diagnosis Procedure .....	56
<b>AVM BRANCH LINE CIRCUIT .....</b>	<b>57</b>
Diagnosis Procedure .....	57
<b>HVAC BRANCH LINE CIRCUIT .....</b>	<b>58</b>
Diagnosis Procedure .....	58

<b>BCM BRANCH LINE CIRCUIT .....</b>	<b>59</b>
Diagnosis Procedure .....	59
<b>CAN COMMUNICATION CIRCUIT .....</b>	<b>60</b>
Diagnosis Procedure .....	60
<b>CAN SYSTEM (TYPE 1)</b>	
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>62</b>
<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT .....</b>	<b>62</b>
Diagnosis Procedure .....	62
<b>MAIN LINE BETWEEN DLC AND M&amp;A CIR- CUIT .....</b>	<b>63</b>
Diagnosis Procedure .....	63
<b>MAIN LINE BETWEEN M&amp;A AND A-BAG CIRCUIT .....</b>	<b>64</b>
Diagnosis Procedure .....	64
<b>MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT .....</b>	<b>65</b>
Diagnosis Procedure .....	65
<b>ECM BRANCH LINE CIRCUIT .....</b>	<b>66</b>
Diagnosis Procedure .....	66
<b>ABS BRANCH LINE CIRCUIT .....</b>	<b>67</b>
Diagnosis Procedure .....	67
<b>EPS BRANCH LINE CIRCUIT .....</b>	<b>68</b>
Diagnosis Procedure .....	68
<b>IPDM-E BRANCH LINE CIRCUIT .....</b>	<b>69</b>
Diagnosis Procedure .....	69
<b>TCM BRANCH LINE CIRCUIT .....</b>	<b>70</b>
Diagnosis Procedure .....	70
<b>DLC BRANCH LINE CIRCUIT .....</b>	<b>71</b>
Diagnosis Procedure .....	71
<b>M&amp;A BRANCH LINE CIRCUIT .....</b>	<b>72</b>
Diagnosis Procedure .....	72
<b>STRG BRANCH LINE CIRCUIT .....</b>	<b>73</b>
Diagnosis Procedure .....	73
<b>A-BAG BRANCH LINE CIRCUIT .....</b>	<b>74</b>
Diagnosis Procedure .....	74
<b>HVAC BRANCH LINE CIRCUIT .....</b>	<b>75</b>
Diagnosis Procedure .....	75
<b>BCM BRANCH LINE CIRCUIT .....</b>	<b>76</b>
Diagnosis Procedure .....	76
<b>CAN COMMUNICATION CIRCUIT .....</b>	<b>77</b>
Diagnosis Procedure .....	77
<b>CAN SYSTEM (TYPE 2)</b>	
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>79</b>

<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT</b> .....	79	Diagnosis Procedure .....	98	
Diagnosis Procedure .....	79	<b>MAIN LINE BETWEEN DLC AND M&amp;A CIRCUIT</b> .....	99	A
<b>MAIN LINE BETWEEN DLC AND M&amp;A CIRCUIT</b> .....	80	Diagnosis Procedure .....	99	B
Diagnosis Procedure .....	80	<b>MAIN LINE BETWEEN M&amp;A AND A-BAG CIRCUIT</b> .....	100	C
<b>MAIN LINE BETWEEN M&amp;A AND AV CIRCUIT</b> .....	81	Diagnosis Procedure .....	100	
Diagnosis Procedure .....	81	<b>MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT</b> .....	101	D
<b>MAIN LINE BETWEEN AV AND HVAC CIRCUIT</b> .....	82	Diagnosis Procedure .....	101	
Diagnosis Procedure .....	82	<b>ECM BRANCH LINE CIRCUIT</b> .....	102	E
<b>ECM BRANCH LINE CIRCUIT</b> .....	83	Diagnosis Procedure .....	102	
Diagnosis Procedure .....	83	<b>ABS BRANCH LINE CIRCUIT</b> .....	103	F
<b>ABS BRANCH LINE CIRCUIT</b> .....	84	Diagnosis Procedure .....	103	
Diagnosis Procedure .....	84	<b>EPS BRANCH LINE CIRCUIT</b> .....	104	G
<b>EPS BRANCH LINE CIRCUIT</b> .....	85	Diagnosis Procedure .....	104	
Diagnosis Procedure .....	85	<b>IPDM-E BRANCH LINE CIRCUIT</b> .....	105	
<b>IPDM-E BRANCH LINE CIRCUIT</b> .....	86	Diagnosis Procedure .....	105	
Diagnosis Procedure .....	86	<b>TCM BRANCH LINE CIRCUIT</b> .....	106	H
<b>TCM BRANCH LINE CIRCUIT</b> .....	87	Diagnosis Procedure .....	106	
Diagnosis Procedure .....	87	<b>DLC BRANCH LINE CIRCUIT</b> .....	107	I
<b>DLC BRANCH LINE CIRCUIT</b> .....	88	Diagnosis Procedure .....	107	
Diagnosis Procedure .....	88	<b>M&amp;A BRANCH LINE CIRCUIT</b> .....	108	J
<b>M&amp;A BRANCH LINE CIRCUIT</b> .....	89	Diagnosis Procedure .....	108	
Diagnosis Procedure .....	89	<b>STRG BRANCH LINE CIRCUIT</b> .....	109	K
<b>STRG BRANCH LINE CIRCUIT</b> .....	90	Diagnosis Procedure .....	109	
Diagnosis Procedure .....	90	<b>A-BAG BRANCH LINE CIRCUIT</b> .....	110	L
<b>A-BAG BRANCH LINE CIRCUIT</b> .....	91	Diagnosis Procedure .....	110	
Diagnosis Procedure .....	91	<b>HVAC BRANCH LINE CIRCUIT</b> .....	111	
<b>AV BRANCH LINE CIRCUIT</b> .....	92	Diagnosis Procedure .....	111	
Diagnosis Procedure .....	92	<b>BCM BRANCH LINE CIRCUIT</b> .....	112	LAN
<b>AVM BRANCH LINE CIRCUIT</b> .....	93	Diagnosis Procedure .....	112	
Diagnosis Procedure .....	93	<b>CAN COMMUNICATION CIRCUIT</b> .....	113	N
<b>HVAC BRANCH LINE CIRCUIT</b> .....	94	Diagnosis Procedure .....	113	
Diagnosis Procedure .....	94	<b>CAN SYSTEM (TYPE 4)</b>		
<b>BCM BRANCH LINE CIRCUIT</b> .....	95	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	115	O
Diagnosis Procedure .....	95	<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT</b> .....	115	P
<b>CAN COMMUNICATION CIRCUIT</b> .....	96	Diagnosis Procedure .....	115	
Diagnosis Procedure .....	96	<b>MAIN LINE BETWEEN DLC AND M&amp;A CIRCUIT</b> .....	116	
<b>CAN SYSTEM (TYPE 3)</b>		Diagnosis Procedure .....	116	
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	98	<b>MAIN LINE BETWEEN M&amp;A AND AV CIRCUIT</b> .....	117	
<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT</b> .....	98			

Diagnosis Procedure .....	117
<b>MAIN LINE BETWEEN AV AND HVAC CIRCUIT .....</b>	<b>118</b>
Diagnosis Procedure .....	118
<b>ECM BRANCH LINE CIRCUIT .....</b>	<b>119</b>
Diagnosis Procedure .....	119
<b>ABS BRANCH LINE CIRCUIT .....</b>	<b>120</b>
Diagnosis Procedure .....	120
<b>EPS BRANCH LINE CIRCUIT .....</b>	<b>121</b>
Diagnosis Procedure .....	121
<b>IPDM-E BRANCH LINE CIRCUIT .....</b>	<b>122</b>
Diagnosis Procedure .....	122
<b>TCM BRANCH LINE CIRCUIT .....</b>	<b>123</b>
Diagnosis Procedure .....	123
<b>DLC BRANCH LINE CIRCUIT .....</b>	<b>124</b>
Diagnosis Procedure .....	124
<b>M&amp;A BRANCH LINE CIRCUIT .....</b>	<b>125</b>
Diagnosis Procedure .....	125
<b>STRG BRANCH LINE CIRCUIT .....</b>	<b>126</b>
Diagnosis Procedure .....	126
<b>A-BAG BRANCH LINE CIRCUIT .....</b>	<b>127</b>
Diagnosis Procedure .....	127
<b>AV BRANCH LINE CIRCUIT .....</b>	<b>128</b>
Diagnosis Procedure .....	128
<b>HVAC BRANCH LINE CIRCUIT .....</b>	<b>129</b>
Diagnosis Procedure .....	129
<b>BCM BRANCH LINE CIRCUIT .....</b>	<b>130</b>
Diagnosis Procedure .....	130
<b>CAN COMMUNICATION CIRCUIT .....</b>	<b>131</b>
Diagnosis Procedure .....	131
<b>CAN SYSTEM (TYPE 5)</b>	
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>133</b>
<b>MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT .....</b>	<b>133</b>
Diagnosis Procedure .....	133

<b>MAIN LINE BETWEEN DLC AND M&amp;A CIRCUIT .....</b>	<b>134</b>
Diagnosis Procedure .....	134
<b>MAIN LINE BETWEEN M&amp;A AND AV CIRCUIT .....</b>	<b>135</b>
Diagnosis Procedure .....	135
<b>MAIN LINE BETWEEN AV AND HVAC CIRCUIT .....</b>	<b>136</b>
Diagnosis Procedure .....	136
<b>ECM BRANCH LINE CIRCUIT .....</b>	<b>137</b>
Diagnosis Procedure .....	137
<b>ABS BRANCH LINE CIRCUIT .....</b>	<b>138</b>
Diagnosis Procedure .....	138
<b>EPS BRANCH LINE CIRCUIT .....</b>	<b>139</b>
Diagnosis Procedure .....	139
<b>IPDM-E BRANCH LINE CIRCUIT .....</b>	<b>140</b>
Diagnosis Procedure .....	140
<b>TCM BRANCH LINE CIRCUIT .....</b>	<b>141</b>
Diagnosis Procedure .....	141
<b>DLC BRANCH LINE CIRCUIT .....</b>	<b>142</b>
Diagnosis Procedure .....	142
<b>M&amp;A BRANCH LINE CIRCUIT .....</b>	<b>143</b>
Diagnosis Procedure .....	143
<b>STRG BRANCH LINE CIRCUIT .....</b>	<b>144</b>
Diagnosis Procedure .....	144
<b>A-BAG BRANCH LINE CIRCUIT .....</b>	<b>145</b>
Diagnosis Procedure .....	145
<b>AV BRANCH LINE CIRCUIT .....</b>	<b>146</b>
Diagnosis Procedure .....	146
<b>AVM BRANCH LINE CIRCUIT .....</b>	<b>147</b>
Diagnosis Procedure .....	147
<b>HVAC BRANCH LINE CIRCUIT .....</b>	<b>148</b>
Diagnosis Procedure .....	148
<b>BCM BRANCH LINE CIRCUIT .....</b>	<b>149</b>
Diagnosis Procedure .....	149
<b>CAN COMMUNICATION CIRCUIT .....</b>	<b>150</b>
Diagnosis Procedure .....	150

## HOW TO USE THIS MANUAL

### HOW TO USE THIS SECTION

#### Information

INFOID:0000000010480441

- “CAN FUNDAMENTAL” of LAN Section describes the basic knowledge of the CAN communication system and the method of trouble diagnosis.
- For information peculiar to a vehicle and inspection procedure, refer to “CAN”.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

## PRECAUTION

### PRECAUTIONS

#### Precautions for Trouble Diagnosis

INFOID:000000010480442

#### CAUTION:

Follow the instructions listed below. Failure to do this may cause damage to parts:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


#### Precautions for Harness Repair

INFOID:000000010480443

- Solder the repaired area and wrap tape around the soldered area.

#### NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

#### NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

## SYSTEM DESCRIPTION

### SYSTEM

### CAN COMMUNICATION SYSTEM

### CAN COMMUNICATION SYSTEM : System Description

INFOID:0000000010480444


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DIAG ON CAN

### DIAG ON CAN : System Description

INFOID:0000000010480445

### SYSTEM DIAGRAM



# SYSTEM

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Name	Harness	Description
DDL1	Tx Rx	For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling)
DDL2	K-LINE	For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling)
Diag on CAN	CAN-H CAN-L	For communications with the diagnostic tool. (CAN-H and CAN-L are also used for control and diagnoses.)

## DESCRIPTION


“Diag on CAN” is a diagnosis method which uses the CAN communication line for the communication between the control unit and the diagnostic tool.



## TROUBLE DIAGNOSIS

## Component Description

INFOID:000000010480446



Component	Description
Main line	CAN communication line between splices
Branch line	CAN communication line between splice and a control unit
Splice	A point connecting a branch line with a main line
Termination circuit	Circuit connected across the CAN communication system. (Resistor)

## Condition of Error Detection

INFOID:000000010480447

DTC (e.g. U1000 and U1001) of CAN communication is indicated on SELF-DIAG RESULTS on CONSULT if a CAN communication signal is not transmitted or received between units for 2 seconds or more.

## CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

## WHEN DTC OF CAN COMMUNICATION IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

**NOTE:**

CAN communication system is normal if DTC of CAN communication is indicated on SELF-DIAG RESULTS of CONSULT under the above conditions. Erase the memory of the self-diagnosis of each control unit.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

# TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

## Symptom When Error Occurs in CAN Communication System

INFOID:000000010480448


In CAN communication system, multiple control units mutually transmit and receive signals. Each control unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

### ERROR EXAMPLE

#### NOTE:

Each vehicle differs in symptom of each control unit under fail-safe mode and CAN communication line wiring.

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit




Unit name	Major symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	<ul style="list-style-type: none"> <li>Reverse warning buzzer does not sound.</li> <li>The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position.</li> </ul>
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> <li>The shift position indicator and OD OFF indicator turn OFF.</li> <li>The speedometer is inoperative.</li> <li>The odo/trip meter stops.</li> </ul>
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> <li>The headlamps (Lo) turn ON.</li> <li>The cooling fan continues to rotate.</li> </ul>

# TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Example: TCM Branch Line Open Circuit




Unit name	Major symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	Reverse warning buzzer does not sound.
EPS control unit	Normal operation.
Combination meter	<ul style="list-style-type: none"> <li>Shift position indicator and O/D OFF indicator turn OFF.</li> <li>Warning lamps turn ON.</li> </ul>
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	Normal operation.

## NOTE:

The model (all control units on CAN communication system are Diag on CAN) cannot perform CAN diagnosis with CONSULT if the following error occurs. The error is judged by the symptom.

Error	Difference of symptom
Data link connector branch line open circuit	Normal operation.
CAN-H, CAN-L harness short-circuit	Most of the control units which are connected to the CAN communication system enter fail-safe mode or are deactivated.

Example: Data Link Connector Branch Line Open Circuit



# TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >


[CAN FUNDAMENTAL]

Unit name	Major symptom
ECM	Normal operation.
BCM	
EPS control unit	
Combination meter	
ABS actuator and electric unit (control unit)	
TCM	
IPDM E/R	

## NOTE:

When data link connector branch line is open, transmission and reception of CAN communication signals are not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.

Example: CAN-H, CAN-L Harness Short Circuit



Unit name	Major symptom
ECM	<ul style="list-style-type: none"> <li>Engine torque limiting is affected, and shift harshness increases.</li> <li>Engine speed drops.</li> </ul>
BCM	<ul style="list-style-type: none"> <li>Reverse warning buzzer does not sound.</li> <li>The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position.</li> <li>The room lamp does not turn ON.</li> <li>The engine does not start (if an error or malfunction occurs while turning the ignition switch OFF.)</li> <li>The steering lock does not release (if an error or malfunction occurs while turning the ignition switch OFF.)</li> </ul>
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> <li>The tachometer and the speedometer do not move.</li> <li>Warning lamps turn ON.</li> <li>Indicator lamps do not turn ON.</li> </ul>
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> <li>The headlamps (Lo) turn ON.</li> <li>The cooling fan continues to rotate.</li> </ul>

## CAN Diagnosis with CONSULT

INFOID:0000000010480449

CAN diagnosis on CONSULT extracts the root cause by receiving the following information.

# TROUBLE DIAGNOSIS

## < SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

- Response to the system call
- Control unit diagnosis information
- Self-diagnosis
- CAN diagnostic support monitor

## Self-Diagnosis

INFOID:0000000010480450

If communication signals cannot be transmitted or received among control units communicating via CAN communication line, CAN communication-related DTC is displayed on the CONSULT "Self Diagnostic Result" screen.

### NOTE:

The following table shows examples of CAN communication-related DTC. For other DTC, refer to the applicable sections.

DTC	Self-diagnosis item (CONSULT indication)	DTC detection condition		Inspection/Action
U1000	CAN COMM CIRCUIT	ECM	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more.	Start the inspection. Refer to the applicable section of the indicated control unit.
		Except for ECM	When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more.	
U1001	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more.		
U1002	SYSTEM COMM	When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less.		
U1010	CONTROL UNIT(CAN)	When an error is detected during the initial diagnosis for CAN controller of each control unit.		Replace the control unit indicating "U1010".

## CAN Diagnostic Support Monitor

INFOID:0000000010480451

### MONITOR ITEM (CONSULT)

#### Example: CAN DIAG SUPPORT MNTR indication

Without PAST				With PAST			
BCM				ENGINE			
MONITOR ITEM	PRESENT	PAST		MONITOR ITEM	PRESENT	PAST	
INITIAL DIAG	OK	-		TRANSMIT DIAG	OK	OK	
TRANSMIT DIAG	OK	-		VDC/TCS/ABS	OK	5	
ECM	OK	-		METER/M&A	Not diagnosed	-	
METER/M&A	OK	-		BCM/SEC	OK	OK	
TCM	OK	-		ICC	Not diagnosed	-	
IPDM E/R	OK	-		HVAC	Not diagnosed	-	
I-KEY	OK	-		TCM	OK	OK	
				EPS	OK	OK	
				IPDM E/R	OK	5	
				e4WD	Not diagnosed	-	
				AWD/4WD	Not diagnosed	-	

JSMIA0964GB

### Without PAST

Item	PRESENT	Description
Initial diagnosis	OK	Normal at present
	NG	Control unit error (Except for some control units)

# TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Item	PRESENT	Description
Transmission diagnosis	OK	Normal at present
	UNKWN	Unable to transmit signals for 2 seconds or more.
		Diagnosis not performed
Control unit name (Reception diagnosis)	OK	Normal at present
	UNKWN	Unable to receive signals for 2 seconds or more.
		Diagnosis not performed
		No control unit for receiving signals. (No applicable optional parts)

With PAST

Item	PRESENT	PAST	Description
Transmission diagnosis	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to transmit signals for 2 seconds or more at present.
Control unit name (Reception diagnosis)	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to receive signals for 2 seconds or more at present.
	Not diagnosed	–	Diagnosis not performed.
			No control unit for receiving signals. (No applicable optional parts)

# TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

## How to Use CAN Communication Signal Chart

INFOID:000000010480452

The CAN communication signal chart lists the signals transmitted/received among control units. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.


Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	BCM	M&A	STRG	ABS	IPDM-E
A/C compressor feedback signal	T		R			
A/C compressor request signal	T					R
Accelerator pedal position signal	T				R	
Cooling fan motor operation signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R		R	
Fuel consumption monitor signal	T		R			
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				
Ignition switch signal		T				R
Sleep/wake up signal		T	R			R

No communication between ECM and M&A (Combination meter).

It indicates that an error occurs between ECM and Combination meter (Shaded area).




JSMIA0446GB

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Trouble Diagnosis Flow Chart

INFOID:0000000010480453



#### Trouble Diagnosis Procedure

INFOID:0000000010480454

##### INTERVIEW WITH CUSTOMER

Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

##### Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment
- Result: Symptom

##### Notes for checking error symptoms:

- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.
- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.




# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

[CAN FUNDAMENTAL]

- Indication of the combination meter is important to detect the root cause because it is the most obvious to the customer, and it performs CAN communication with many units.



### INSPECTION OF VEHICLE CONDITION

Check whether the symptom is reproduced or not.

#### NOTE:

Do not turn the ignition switch OFF or disconnect the battery cable while reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.

### CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment.

#### NOTE:

- This chart is used if CONSULT does not automatically recognize CAN system type.
- There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.

CAN System Type Specification Chart (Style A)

#### NOTE:

LAN

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:  
Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)

**CAN System Specification Chart**  
Determine CAN system type from the following specification chart.

Body type	Wagon					
Axle	2WD			AWD		
Engine	QR25DE			VQ35DE		
Transmission	A/T			CVT		
Brake control	ABS			VDC		
Intelligent Key system		×		×		×
CAN system type	1	2	3	4	5	6

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

The number indicates the CAN system type of the vehicle.

CAN communication control unit						
ECM	×	×	×	×	×	×
AWD control unit					×	×
Air bag diagnosis sensor unit	×	×	×	×	×	×
BCM	×	×	×	×	×	×
Intelligent Key unit		×		×		×
Steering angle sensor					×	×
EPS control unit	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×
TCM	×	×	×	×	×	×
IPDM E/R	×	×	×	×	×	×

× : Applicable

**VEHICLE EQUIPMENT IDENTIFICATION INFORMATION**  
**NOTE:**  
Check CAN system type from the vehicle shape and equipment.

**(A)**

1. VDC OFF switch  
A. With VDC

**(B)**

2. Ignition knob  
B. With Intelligent Key system

In the above example,

- Checking VDC OFF switch leads to judge whether or not VDC is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.

For the above case, CAN system type is "6".

JSMIA0529GB

CAN System Type Specification Chart (Style B)

**NOTE:**

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:

Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

## CAN System Specification Chart

Refer to the specification as shown in the chart.

Body type	Sedan		
Axle	2WD		AWD
Engine	HR15DE	MR20DE	HR15DE
Transmission	A/T	CVT	A/T
Brake control		ABS	
Specification chart	XX.XX. SPECIFICATION CHART A.	XX.XX. SPECIFICATION CHART B.	XX.XX. SPECIFICATION CHART C.

×: Applicable

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

Select the applicable vehicle equipment. Refer to the specification chart.

## SPECIFICATION CHART B

Determine CAN system type from the following specification chart.

Body type	Sedan										
Axle	2WD										
Engine	MR20DE										
Transmission	CVT										
Brake control	ABS										
Active AFS		×			×	×			×	×	×
Intelligent Key system			×		×		×	×	×	×	×
Navigation system				×		×		×		×	×
Automatic drive positioner								×		×	×
CAN system type	9	10	11	12	13	14	15	16	17	18	19
CAN communication control unit											
ECM	×	×	×	×	×	×	×	×	×	×	×
AFS control unit		×			×	×			×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×

×: Applicable


Check the vehicle equipment.

The number indicates the CAN system type of the vehicle.

## VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

### NOTE:

Check CAN system type from the vehicle shape and equipment.



- 1. Bending lamp
- 2. Xenon bulb
- 3. Ignition knob
- 4. Display
- 5. Multifunction switch
- 6. Seat memory switch
- A. With active AFS
- B. With Intelligent Key system
- C. With navigation system
- D. With automatic drive positioner

In the above example,

- Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
- Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
- Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

[ For the above case, CAN system type is "20". ]

JSMIA0530GB

## CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

Interview Sheet (Example)

CAN Communication System Diagnosis Interview Sheet	
Date received: 3, Feb. 2006	
Type: DBA-KG11	VIN No.: KG11-005040
Model: BDRARGZG11EDA-E-J-	
First registration: 10, Jan. 2001	Mileage: 62,140
CAN system type: Type 19	
Symptom (Results from interview with customer)	
<ul style="list-style-type: none"><li>• Headlamps suddenly turn ON while driving the vehicle.</li><li>• The engine does not restart after stopping the vehicle and turning the ignition switch OFF.</li><li>• The cooling fan continues rotating while turning the ignition switch ON.</li></ul>	
Condition at inspection	
Error Symptom: Present / Past	
<p>The engine does not start.</p> <p>While turning the ignition switch ON,</p> <ul style="list-style-type: none"><li>• The headlamps (Lo) turn ON, and the cooling fan continues rotating.</li><li>• The interior lamp does not turn ON.</li></ul>	

JSMIA0531GB

## DETECT THE ROOT CAUSE

CAN diagnosis function of CONSULT detects the root cause.

## HOW TO USE THIS MANUAL

### HOW TO USE THIS SECTION

#### Information

INFOID:0000000010480455

- “CAN” of LAN Section describes information peculiar to a vehicle and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-16. "Trouble Diagnosis Flow Chart"](#) of “CAN FUNDAMENTAL”.

#### Abbreviation List

INFOID:0000000010480456

Unit name abbreviations in CONSULT CAN diagnosis and in this section are as per the following list.

Abbreviation	Unit name
A-BAG	Air bag diagnosis sensor unit
ABS	ABS actuator and electric unit (control unit)
AV	AV control unit
AVM	ITS control unit
BCM	BCM
DLC	Data link connector
ECM	ECM
EPS	Power steering control module
HVAC	A/C auto amp. or front air control
IPDM-E	IPDM E/R
M&A	Combination meter
STRG	Steering angle sensor
TCM	TCM

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010480457

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precautions for Trouble Diagnosis

INFOID:0000000010480458

#### **CAUTION:**

Follow the instructions listed below. Failure to do this may cause damage to parts:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


#### Precautions for Harness Repair

INFOID:0000000010480459

- Solder the repaired area and wrap tape around the soldered area.

#### **NOTE:**

A fray of twisted lines must be within 110 mm (4.33 in).



## PRECAUTIONS


### < PRECAUTION >

[CAN]

- Bypass connection is never allowed at the repaired area.

**NOTE:**

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P


LAN

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000010480460



AWMIA1288ZZ

- |   |                                 |   |
|---|---------------------------------|---|
| ① Air bag diagnosis sensor unit                 | ② AV control unit               | ③ ITS control unit  |
| ④ ABS actuator and electric unit (control unit) | ⑤ Power steering control module | ⑥ TCM   |
| ⑦ ECM   | ⑧ IPDM E/R                      | ⑨ • A/C auto amp. (with auto A/C)<br>• Front air control (without auto A/C) |
| ⑩ Data link connector                           | ⑪ BCM                           | ⑫ Combination meter   |
| ⑬ Steering angle sensor                         |                                 |   |




## SYSTEM

## CAN COMMUNICATION SYSTEM

## CAN COMMUNICATION SYSTEM : System Description

INFOID:0000000010480461

## SYSTEM DIAGRAM

**NOTE:**


For manual A/C, A/C auto amp. is described as front air control.

## DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN COMMUNICATION SIGNAL GENERATION

- Termination circuits (resistors) are connected across the CAN communication system. When transmitting a CAN communication signal, each control unit passes a current to the CAN-H line and the current returns to the CAN-L line.



# SYSTEM


[CAN]

## < SYSTEM DESCRIPTION >


- The current flows separately into the termination circuits connected across the CAN communication system and the termination circuits drop voltage to generate a potential difference between the CAN-H line and the CAN-L line.

### NOTE:


A signal with no current passage is called "Recessive" and one with current passage is called "Dominant".



- The system produces digital signals for signal communications, by using the potential difference.



## THE CONSTRUCTION OF CAN COMMUNICATION SIGNAL (MESSAGE)



No.	Message name	Description
1	Start of frame (1 bit)	Start of message.
2	Arbitration of field (11 bit)	Priorities of message-sending are shown when there is a possibility that multiple messages are sent at the same time.
3	Control field (6 bit)	Signal quantity in data field is shown.
4	Data field (0-64 bit)	Actual signal is shown.
5	CRC field (16 bit)	<ul style="list-style-type: none"> <li>The transmitting control unit calculates sending data in advance and writes the calculated value in a message.</li> <li>The receiving control unit calculates received data and judges that the data reception is normal when the calculated value is the same as the value written in the sent data.</li> </ul>
6	ACK field (2 bit)	The completion of normal reception is sent to the transmitting unit.
7	End of frame (7 bit)	End of message.


## CAN Communication Line

# SYSTEM

## < SYSTEM DESCRIPTION >

[CAN]


The CAN communication line is a twisted pair wire consisting of strands of CAN-H ① and CAN-L ② and has noise immunity.



### NOTE:

The CAN communication system has the characteristics of noise-resistant because this system produces digital signals by using the potential difference between the CAN-H line and the CAN-L line and has the twisted pair wire structure.


Since the CAN-H line and the CAN-L line are always adjacent to each other, the same degree of noise occurs, respectively, when a noise ① occurs. Although the noise changes the voltage, the potential difference ② between the CAN-H line and the CAN-L line is insensitive to noise. Therefore, noise-resistant signals can be obtained.



## CAN Signal Communications


Each control unit of the CAN communication system transmits signals through the CAN communication control circuit included in the control unit and receives only necessary signals from each control unit to perform various kinds of control.

- Example: Transmitted signals



## < SYSTEM DESCRIPTION >

- Example: Received signals




### NOTE:

The above signal names and signal communications are provided for reference purposes. For CAN communications signals of this vehicle, refer to [LAN-30, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

## CAN COMMUNICATION SYSTEM : CAN Communication Control Circuit

INFOID:000000010480462

CAN communication control circuit is incorporated into the control unit and transmits/receives CAN communication signals.



Component	System description
CAN controller	It controls CAN communication signal transmission and reception, error detection, etc.
Transceiver IC	It converts digital signal into CAN communication signal, and CAN communication signal into digital signal.

# SYSTEM

## < SYSTEM DESCRIPTION >

[CAN]

Component	System description
Noise filter	It eliminates noise of CAN communication signal.
Termination circuit* (Resistance of approx. 120 Ω)	Generates a potential difference between CAN-H and CAN-L.

\*: These are the only control units wired with both ends of CAN communication system.

## CAN COMMUNICATION SYSTEM : CAN System Specification Chart

INFOID:0000000010480463

Determine CAN system type from the following specification chart.

### NOTE:

Refer to [LAN-16. "Trouble Diagnosis Procedure"](#) for how to use CAN system specification chart.


Body type	Sedan				
Axle	2WD				
Engine	QR25DE		VQ35DE		
Transmission	CVT				
Brake control	VDC				
Driver assistance system		×			×
Navigation system		×		×	×
CAN system type	1	2	3	4	5
CAN communication unit					
ECM	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×
Power steering control module	×	×	×	×	×
IPDM E/R	×	×	×	×	×
TCM	×	×	×	×	×
Data link connector	×	×	×	×	×
Combination meter	×	×	×	×	×
Steering angle sensor	×	×	×	×	×
Air bag diagnosis sensor unit	×	×	×	×	×
AV control unit		×		×	×
ITS control unit		×			×
A/C auto amp. or front air control	×	×	×	×	×
BCM	×	×	×	×	×

×: Applicable

## VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

### NOTE:

Check CAN system type from the vehicle shape and equipment.



- ① Warning systems switch  
 ② 7 inch color display  
 ③ NAVI switches  
 (A) With driver assistance system  
 (B) With Navigation system

## CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart

INFOID:0000000010480464

Refer to [LAN-15, "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

### NOTE:

Refer to [LAN-21, "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

Signal name	ECM	EPS	IPDM-E	TCM	M&A	STRG	A-BAG	AV	AVM	HVAC	ABS	BCM
A/C compressor request signal	T		R							R		
Accelerator pedal position signal	T			R				R			R	
ASCD operation signal	T			R								
ASCD status signal	T				R							
Closed throttle position signal	T			R								
Cooling fan speed request signal	T		R							R		
Engine coolant temperature signal	T		R	R	R				R	R		
Engine and CVT integrated control signal	T			R								
	R			T								
Engine speed signal	T			R	R			R	R	R	R	
Engine status signal	T	R	R					R				R
Fuel consumption monitor signal	T				R			R				
Fuel filler cap warning display signal	T				R							
Malfunctioning indicator lamp signal	T				R							
	R			T								
Oil pressure warning lamp signal	T				R							
Power generation command value signal	T		R									
Target throttle position signal	T										R	
Wide open throttle position signal	T			R								
EPS operation signal	R	T										

# SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	EPS	IPDM-E	TCM	M&A	STRG	A-BAG	AV	AVM	HVAC	ABS	BCM
Hydraulic pump electric power steering warning lamp signal		T			R							
Detention switch signal			T		R							R
Front wiper stop position signal			T									R
High beam status signal	R		T									
Hood switch signal			T									R
Interlock/PNP switch signal			R									T
			T		R							R
Low beam status signal	R		T									
Oil pressure switch signal					R							T
			T		R							R
Push-button ignition switch status signal			T									R
Rear window defogger control signal	R		T									
Sleep ready signal			T									R
Starter relay status signal			T									R
Current gear position signal				T				R			R	
CVT position indicator signal				T	R						R	
Input shaft revolution signal	R			T				R			R	
Manual mode indicator signal				T	R						R	
N range signal				T								R
Output shaft revolution signal	R			T				R			R	
O/D OFF indicator signal*1				T	R				R			
P range signal				T							R	R
Shift position signal				T	R			R				
Brake fluid level signal					T						R	
Distance to empty signal					T			R				
Fuel filler cap warning reset signal	R				T							
Fuel level low warning signal					T			R				
Fuel level sensor signal	R				T							
Paddle shift down signal*2				R	T							
Paddle shift up signal*2				R	T							
Manual mode signal*2				R	T							
Market information signal					T			R		R		
Non-manual mode signal*2				R	T							
Overdrive control switch signal*1				R	T							
Parking brake switch signal					T			R			R	R
Seat belt buckle switch signal					T							R
Vehicle speed signal	R	R	R	R	T			R		R		R
	R	R	R		R			R	R		T	R
Steering angle sensor signal		R				T			R		R	
Shock status signal							T					R

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

# SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	EPS	IPDM-E	TCM	M&A	STRG	A-BAG	AV	AVM	HVAC	ABS	BCM
Buzzer output signal					R				T			
					R							T
Meter display signal					R				T			
A/C switch signal	R									T <sup>*3</sup>		T <sup>*4</sup>
Ambient sensor signal <sup>*3</sup>					R					T		
Blower fan motor switch signal	R									T <sup>*3</sup>		T <sup>*4</sup>
ABS operation signal				R							T	
ABS warning lamp signal					R						T	
Brake warning lamp signal					R						T	
SLIP indicator lamp signal					R						T	
TCS operation signal	R			R							T	
VDC OFF indicator lamp signal					R						T	
VDC operation signal	R			R							T	
Yaw rate signal									R		T	
Day time running light request signal			R						R	R		T
Door switch signal			R		R			R	R			T
Front fog light request signal			R		R				R	R		T
Front wiper request signal			R						R			T
High beam request signal			R		R				R	R		T
Horn reminder signal			R									T
Ignition switch ON signal			R									T
Key warning signal					R							T
Low beam request signal			R		R				R	R		T
Meter TPMS display signal					R							T
Position light request signal			R		R				R	R		T
Rear window defogger switch signal			R							R		T
Sleep wake up signal			R		R							T
Starter control relay signal			R									T
Theft warning horn request signal			R									T
Tire pressure data signal					R			R				T
Trunk switch signal					R			R	R			T
Turn indicator signal					R			R	R			T

\*1: QR25DE models

\*2: VQ35DE models

\*3: With automatic air conditioning system

\*4: With manual air conditioning system

## NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.




&lt; WIRING DIAGRAM &gt;

## WIRING DIAGRAM

## CAN SYSTEM

## Wiring Diagram


INFOID:0000000010480465



ABMWA2640GB


## CAN SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
22G	L	—
23G	P	—

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H

Connector No.	M22
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	L	—
14	P	—

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38	P	CAN-L
39	L	CAN-H

Connector No.	M35
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
45	P	CAN-L
46	L	CAN-H

# CAN SYSTEM

< WIRING DIAGRAM >


[CAN]

Connector No.	M37
Connector Name	FRONT AIR CONTROL (WITHOUT AUTO A/C)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	CAN-L
4	L	CAN-H

Connector No.	M53
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	-
5	L	-

Connector No.	M58
Connector Name	ITS CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
27	L	CAN-H

Connector No.	M89
Connector Name	JOINT CONNECTOR-M05
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L	-
3	L	-
4	L	-

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

Connector No.	M151
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	P	CAN-L

ABMIA6218GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

# CAN SYSTEM

< WIRING DIAGRAM >

[CAN]

Connector No.	M156
Connector Name	JOINT CONNECTOR-M07
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
4	L	-

Connector No.	M155
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	-
3	P	-
4	P	-

Connector No.	M152
Connector Name	A/C AUTO AMP. (WITH AUTO A/C)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
21	P	CAN-L

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Connector No.	E10
Connector Name	ECM (QR25DE EXCEPT FOR CALIFORNIA)
Connector Color	GRAY



97	101	105	109	113	117	121	125
98	102	106	110	114	118	122	126
99	103	107	111	115	119	123	127
100	104	108	112	116	120	124	128

Terminal No.	Color of Wire	Signal Name
9	P	-
10	L	-

Connector No.	M157
Connector Name	JOINT CONNECTOR-M08
Connector Color	WHITE



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-
4	P	-


ABMIA6219GB

# CAN SYSTEM

< WIRING DIAGRAM >


[CAN]

Connector No.	E22
Connector Name	JOINT CONNECTOR-E04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-
4	P	-
5	P	-
6	P	-

Connector No.	E21
Connector Name	JOINT CONNECTOR-E03
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-


Connector No.	E31
Connector Name	ECM (QR25DE FOR CALIFORNIA)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Terminal No.	Color of Wire	Signal Name
22G	L	-
23G	P	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABMIA6220GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

# CAN SYSTEM

< WIRING DIAGRAM >


[CAN]

Connector No.	E59
Connector Name	POWER STEERING CONTROL MODULE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
8	L	CAN-H

Connector No.	E54
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E32
Connector Name	ECM (WITH VO35DE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
123	P	CAN-L
124	L	CAN-H

Connector No.	F16
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	F2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	P	-
10	L	-

Connector No.	E63
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H

ABMIA6221GB

**BASIC INSPECTION**

## DIAGNOSIS AND REPAIR WORKFLOW

## Interview Sheet

INFOID:0000000010480466

**NOTE:**Refer to [LAN-16. "Trouble Diagnosis Procedure"](#) for how to use interview sheet.

CAN Communication System Diagnosis Interview Sheet	
Date received: <input type="text"/>	
Type: <input type="text"/>	VIN No.: <input type="text"/>
Model: <input type="text"/>	
First registration: <input type="text"/>	Mileage: <input type="text"/>
CAN system type: <input type="text"/>	
Symptom (Results from interview with customer)	
<div></div>	
Condition at inspection	
Error symptom : Present / Past	
<div></div>	

SKIB8898E

# MALFUNCTION AREA CHART

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## DTC/CIRCUIT DIAGNOSIS

### MALFUNCTION AREA CHART

#### Main Line

INFOID:0000000010480467

Malfunction area	Reference
Main line between IPDM E/R and data link connector	<a href="#">LAN-41, "Diagnosis Procedure"</a>
Main line between data link connector and combination meter	<a href="#">LAN-42, "Diagnosis Procedure"</a>
Main line between combination meter and air bag diagnosis sensor unit	<a href="#">LAN-43, "Diagnosis Procedure"</a>
Main line between combination meter and air AV control unit	<a href="#">LAN-44, "Diagnosis Procedure"</a>
Main line between air bag diagnosis sensor unit and A/C auto amp. (with auto A/C)	<a href="#">LAN-45, "Diagnosis Procedure"</a>
Main line between air bag diagnosis sensor unit and front air control (without auto A/C)	
Main line between AV control unit and A/C auto amp. (with auto A/C)	<a href="#">LAN-46, "Diagnosis Procedure"</a>
Main line between AV control unit and front air control (without auto A/C)	

#### Branch Line

INFOID:0000000010480468

Malfunction area	Reference
ECM branch line circuit	<a href="#">LAN-47, "Diagnosis Procedure"</a>
ABS actuator and electric unit (control unit) branch line circuit	<a href="#">LAN-48, "Diagnosis Procedure"</a>
Power steering control module branch line circuit	<a href="#">LAN-49, "Diagnosis Procedure"</a>
IPDM E/R branch line circuit	<a href="#">LAN-50, "Diagnosis Procedure"</a>
TCM branch line circuit	<a href="#">LAN-51, "Diagnosis Procedure"</a>
Data link connector branch line circuit	<a href="#">LAN-52, "Diagnosis Procedure"</a>
Combination meter branch line circuit	<a href="#">LAN-53, "Diagnosis Procedure"</a>
Steering angle sensor branch line circuit	<a href="#">LAN-54, "Diagnosis Procedure"</a>
Air bag diagnosis sensor unit branch line circuit	<a href="#">LAN-55, "Diagnosis Procedure"</a>
AV control unit branch line circuit	<a href="#">LAN-56, "Diagnosis Procedure"</a>
ITS control unit branch line circuit	<a href="#">LAN-57, "Diagnosis Procedure"</a>
A/C auto amp. branch line circuit	<a href="#">LAN-58, "Diagnosis Procedure"</a>
BCM branch line circuit	<a href="#">LAN-59, "Diagnosis Procedure"</a>

#### Short Circuit

INFOID:0000000010480469

Malfunction area	Reference
CAN communication circuit	<a href="#">LAN-60, "Diagnosis Procedure"</a>



# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

### Diagnosis Procedure

INFOID:000000010480470

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

### MAIN LINE BETWEEN DLC AND M&A CIRCUIT

#### Diagnosis Procedure

INFOID:0000000010480471

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.

# MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

### Diagnosis Procedure

INFOID:000000010480472

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the air bag diagnosis sensor unit.

NO >> Repair the main line between the air bag diagnosis sensor unit and the air bag diagnosis sensor unit.

LAN

# MAIN LINE BETWEEN M&A AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## MAIN LINE BETWEEN M&A AND AV CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480473

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - AV control unit
  - ECM
4. Check the continuity between the combination meter harness connector and the AV control unit harness connector.
  - Navigation without BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M96	8	Existed
	38		7	Existed

- Navigation with BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M151	8	Existed
	38		7	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the AV control unit.

NO >> Repair the main line between the combination meter and the air AV control unit.

# MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480474

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

LAN

# MAIN LINE BETWEEN AV AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## MAIN LINE BETWEEN AV AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011005346

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - AV control unit
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the AV control unit harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C and BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M152	1	Existed
	17		21	Existed

- With auto A/C without BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M152	1	Existed
	17		21	Existed

- Without auto A/C and BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M37	4	Existed
	17		3	Existed

- Without auto A/C without BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

# ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## ECM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480475

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ECM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to the following.

- QR25DE: [EC-541, "Removal and Installation"](#).
- VQ35DE: [EC-1042, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480476

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.

NO >> Repair the power supply and the ground circuit.



# EPS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## EPS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480477

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the Power steering control module branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the power steering control module branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

## IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

### IPDM-E BRANCH LINE CIRCUIT

#### Diagnosis Procedure

INFOID:0000000010480478

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

# TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000010480479

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to the following.

- QR25DE: [TM-187, "Removal and Installation"](#)
- VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

LAN

# DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## DLC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480480

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

# M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## M&A BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480481

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the combination meter branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the combination meter branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480482

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle sensor branch line.

NO >> Repair the power supply and the ground circuit.

# A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## A-BAG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480483

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### **1**.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

#### **2**.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

## AV BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480484

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
  2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system without BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M96	8	17	Approx. 54 – 66

- With navigation system and BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M151	8	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the AV control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- With navigation system without BOSE audio system: [AV-267, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- With navigation system and BOSE audio system: [AV-376, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- With navigation system without BOSE audio system: [AV-298, "Removal and Installation"](#)
  - With navigation system and BOSE audio system: [AV-416, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.



# AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## AVM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000010480485

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ITS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ITS control unit.
2. Check the resistance between the ITS control unit harness connector terminals.

ITS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	27	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ITS control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ITS control unit. Refer to [DAS-64, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the ITS control unit branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000010480486

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

# BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480487

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the BCM branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000010480488

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
  2. Check the resistance between the ECM terminals.
- QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

## CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

### 5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

### 6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

LAN

# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## DTC/CIRCUIT DIAGNOSIS

### MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051332

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

# MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051333

#### 1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.

LAN

# MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

### Diagnosis Procedure

INFOID:000000011051334

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the air bag diagnosis sensor unit.

NO >> Repair the main line between the air bag diagnosis sensor unit and the air bag diagnosis sensor unit.



# MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051336

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

LAN

## ECM BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051338

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ECM branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to the following.

- QR25DE: [EC-541, "Removal and Installation"](#).
- VQ35DE: [EC-1042, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

# ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051339

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

## EPS BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051340

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the Power steering control module branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the power steering control module branch line.

NO >> Repair the power supply and the ground circuit.

# IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## IPDM-E BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051341

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the IPDM E/R branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000011051342

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to the following.

- QR25DE: [TM-187, "Removal and Installation"](#)
- VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

# DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## DLC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051343

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

LAN

## M&amp;A BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051344

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the combination meter branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the combination meter branch line.

NO >> Repair the power supply and the ground circuit.



# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051345

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the steering angle sensor branch line.  
NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## A-BAG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051346

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### **1**.CHECK CONNECTOR

---

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the main harness.

#### **2**.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

---

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.  
NO >> Replace parts whose air bag system has a malfunction.

# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051349

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

# BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051350

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the BCM branch line.

NO >> Repair the power supply and the ground circuit.

# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051351

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.
  - QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

## CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

### 5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

### 6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## DTC/CIRCUIT DIAGNOSIS

### MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051354

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

### MAIN LINE BETWEEN DLC AND M&A CIRCUIT

#### Diagnosis Procedure

INFOID:000000011051355

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.



# MAIN LINE BETWEEN M&A AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## MAIN LINE BETWEEN M&A AND AV CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051357

#### 1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - AV control unit
  - ECM
4. Check the continuity between the combination meter harness connector and the AV control unit harness connector.
  - Navigation without BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M96	8	Existed
	38		7	Existed

- Navigation with BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M151	8	Existed
	38		7	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the AV control unit.

NO >> Repair the main line between the combination meter and the air AV control unit.

LAN

# MAIN LINE BETWEEN AV AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## MAIN LINE BETWEEN AV AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051359

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - AV control unit
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the AV control unit harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C and BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M152	1	Existed
	17		21	Existed

- With auto A/C without BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M152	1	Existed
	17		21	Existed

- Without auto A/C and BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M37	4	Existed
	17		3	Existed

- Without auto A/C without BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

## ECM BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051360

## 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES &gt;&gt; GO TO 2.

NO &gt;&gt; Repair the terminal and connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

YES &gt;&gt; GO TO 3.

NO &gt;&gt; Repair the ECM branch line.

## 3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)&gt;&gt;Replace the ECM. Refer to the following.

• QR25DE: [EC-541, "Removal and Installation"](#).• VQ35DE: [EC-1042, "Removal and Installation"](#).

YES (Past error)&gt;&gt;Error was detected in the ECM branch line.

NO &gt;&gt; Repair the power supply and the ground circuit.

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051361

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).  
 YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.  
 NO >> Repair the power supply and the ground circuit.

# EPS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## EPS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051362

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the Power steering control module branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the power steering control module branch line.  
NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## IPDM-E BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051363

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

# TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051364

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the TCM. Refer to the following.
  - QR25DE: [TM-187, "Removal and Installation"](#)
  - VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## DLC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051365

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.



## M&amp;A BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051366

## 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

## 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the combination meter branch line.

## 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the combination meter branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051367

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle sensor branch line.

NO >> Repair the power supply and the ground circuit.

# A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## A-BAG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051368

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

#### 2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

## AV BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000011051369

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
  2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system without BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M96	8	17	Approx. 54 – 66

- With navigation system and BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M151	8	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the AV control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- With navigation system without BOSE audio system: [AV-267, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- With navigation system and BOSE audio system: [AV-376, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- With navigation system without BOSE audio system: [AV-298, "Removal and Installation"](#)
  - With navigation system and BOSE audio system: [AV-416, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.

# AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## AVM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051370

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ITS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ITS control unit.
2. Check the resistance between the ITS control unit harness connector terminals.

ITS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	27	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ITS control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ITS control unit. Refer to [DAS-64, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the ITS control unit branch line.  
NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051371

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

# BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051372

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the BCM branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051373

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.
  - QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132



# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

## 5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

## 6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## DTC/CIRCUIT DIAGNOSIS

### MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051378

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

# MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051379

#### 1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.

LAN

# MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## MAIN LINE BETWEEN M&A AND A-BAG CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051380

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the air bag diagnosis sensor unit.

NO >> Repair the main line between the air bag diagnosis sensor unit and the air bag diagnosis sensor unit.

# MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## MAIN LINE BETWEEN A-BAG AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051382

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the combination meter harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C

Combination meter harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M152	1	Existed
	38		21	Existed

- Without auto A/C

Combination meter harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M37	4	Existed
	38		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the air bag diagnosis sensor unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

LAN

## ECM BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051384

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the ECM branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to the following.
- QR25DE: [EC-541, "Removal and Installation"](#).
  - VQ35DE: [EC-1042, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the ECM branch line.  
 NO >> Repair the power supply and the ground circuit.

# ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051385

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

## EPS BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051386

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the Power steering control module branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the power steering control module branch line.

NO >> Repair the power supply and the ground circuit.



# IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## IPDM-E BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051387

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the IPDM E/R branch line.  
NO >> Repair the power supply and the ground circuit.

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000011051388

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to the following.

- QR25DE: [TM-187, "Removal and Installation"](#)
- VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

# DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## DLC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051389

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

LAN

## M&amp;A BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051390

**1.CHECK CONNECTOR**

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

**2.CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the combination meter branch line.

**3.CHECK POWER SUPPLY AND GROUND CIRCUIT**

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the combination meter branch line.

NO >> Repair the power supply and the ground circuit.

# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051391

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the steering angle sensor branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

## A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

### A-BAG BRANCH LINE CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051392

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### **1**.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

#### **2**.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051395

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051396

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).  
 YES (Past error)>>Error was detected in the BCM branch line.  
 NO >> Repair the power supply and the ground circuit.



# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051397

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.
  - QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

## CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

---

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

### 5.CHECK SYMPTOM

---

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

### 6.CHECK UNIT REPRODUCTION

---

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## DTC/CIRCUIT DIAGNOSIS

### MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051401

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

### MAIN LINE BETWEEN DLC AND M&A CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051402

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.

# MAIN LINE BETWEEN M&A AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## MAIN LINE BETWEEN M&A AND AV CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051404

#### 1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - AV control unit
  - ECM
4. Check the continuity between the combination meter harness connector and the AV control unit harness connector.
  - Navigation without BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M96	8	Existed
	38		7	Existed

- Navigation with BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M151	8	Existed
	38		7	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the AV control unit.

NO >> Repair the main line between the combination meter and the air AV control unit.

LAN

# MAIN LINE BETWEEN AV AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## MAIN LINE BETWEEN AV AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051406

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - AV control unit
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the AV control unit harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C and BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M152	1	Existed
	17		21	Existed

- With auto A/C without BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M152	1	Existed
	17		21	Existed

- Without auto A/C and BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M37	4	Existed
	17		3	Existed

- Without auto A/C without BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

## ECM BRANCH LINE CIRCUIT

## Diagnosis Procedure

INFOID:0000000011051407

## 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

## 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the ECM branch line.

## 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to the following.
- QR25DE: [EC-541, "Removal and Installation"](#).
  - VQ35DE: [EC-1042, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the ECM branch line.  
 NO >> Repair the power supply and the ground circuit.

# ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051408

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.

NO >> Repair the power supply and the ground circuit.



# EPS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## EPS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051409

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the Power steering control module branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the power steering control module branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## IPDM-E BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051410

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

# TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051411

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to the following.

- QR25DE: [TM-187, "Removal and Installation"](#)
- VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

LAN

## DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

### DLC BRANCH LINE CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051412

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

# M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## M&A BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051413

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the combination meter branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the combination meter branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051414

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle sensor branch line.

NO >> Repair the power supply and the ground circuit.

# A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## A-BAG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051415

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the main harness.

#### 2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.  
NO >> Replace parts whose air bag system has a malfunction.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

## AV BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000011051416

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
  2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system without BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M96	8	17	Approx. 54 – 66

- With navigation system and BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M151	8	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the AV control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- With navigation system without BOSE audio system: [AV-267, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- With navigation system and BOSE audio system: [AV-376, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- With navigation system without BOSE audio system: [AV-298, "Removal and Installation"](#)
  - With navigation system and BOSE audio system: [AV-416, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.



# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051418

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051419

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the BCM branch line.  
NO >> Repair the power supply and the ground circuit.

# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051420

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.
  - QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
LAN  
N  
O  
P

## CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

---

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

### 5.CHECK SYMPTOM

---

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

### 6.CHECK UNIT REPRODUCTION

---

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

# MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## DTC/CIRCUIT DIAGNOSIS

### MAIN LINE BETWEEN IPDM-E AND DLC CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051421

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E30
  - Harness connector M1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
  - IPDM E/R
  - Harness connectors E30 and M1
2. Check the continuity between the IPDM E/R harness connector and the harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E63	29	E30	22G	Existed
	28		23G	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the IPDM E/R and the harness connector E30.

#### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M1	22G	M22	6	Existed
	23G		14	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the data link connector.

NO >> Repair the main line between the harness connector M1 and the data link connector.

## MAIN LINE BETWEEN DLC AND M&A CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

### MAIN LINE BETWEEN DLC AND M&A CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051422

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - ECM
  - Combination meter
4. Check the continuity between the data link connector and the combination meter harness connector.

Data link connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M24	39	Existed
	14		38	Existed

#### Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the combination meter.

NO >> Repair the main line between the data link connector and the combination meter.

# MAIN LINE BETWEEN M&A AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## MAIN LINE BETWEEN M&A AND AV CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051424

#### 1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - Combination meter
  - AV control unit
  - ECM
4. Check the continuity between the combination meter harness connector and the AV control unit harness connector.
  - Navigation without BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M96	8	Existed
	38		7	Existed

- Navigation with BOSE system

Combination meter harness connector		AV control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	39	M151	8	Existed
	38		7	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the combination meter and the AV control unit.

NO >> Repair the main line between the combination meter and the air AV control unit.

LAN

# MAIN LINE BETWEEN AV AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## MAIN LINE BETWEEN AV AND HVAC CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051426

#### 1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
  - AV control unit
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)
  - ECM
4. Check the continuity between the AV control unit harness connector and the A/C auto amp. harness connector (with auto A/C) or front air control harness connector (without auto A/C).
  - With auto A/C and BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M152	1	Existed
	17		21	Existed

- With auto A/C without BOSE audio system

AV control unit harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M152	1	Existed
	17		21	Existed

- Without auto A/C and BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M151	8	M37	4	Existed
	17		3	Existed

- Without auto A/C without BOSE audio system

AV control unit harness connector		Front air control harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M96	8	M37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).

NO >> Repair the main line between the AV control unit and the A/C auto amp. (with auto A/C) or front air control (without auto A/C).



# ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## ECM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051427

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
  2. Check the resistance between the ECM harness connector terminals.
- QR25DE except for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E10	100	99	Approx. 108 – 132

- QR25DE for California

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E31	100	99	Approx. 108 – 132

- VQ35DE

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E32	124	123	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ECM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to the following.

- QR25DE: [EC-204, "Diagnosis Procedure"](#)
- VQ35DE: [EC-720, "Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to the following.
- QR25DE: [EC-541, "Removal and Installation"](#).
  - VQ35DE: [EC-1042, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the ECM branch line.  
NO >> Repair the power supply and the ground circuit.

# ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## ABS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051428

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E54	26	14	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ABS actuator and electric unit (control unit) branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-71, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-129, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.

NO >> Repair the power supply and the ground circuit.

## EPS BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051429

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

Power steering control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E59	8	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the Power steering control module branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [ST-38, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the power steering control module branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

## IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

### IPDM-E BRANCH LINE CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051430

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E63	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the IPDM E/R branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

# TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## TCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051431

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - TCM
  - Harness connector F2
  - Harness connector E11

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F16	33	23	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to the following.

- QR25DE: [TM-168, "Diagnosis Procedure"](#)
- VQ35DE: [TM-374, "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to the following.

- QR25DE: [TM-187, "Removal and Installation"](#)
- VQ35DE: [TM-392, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

LAN

## DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

### DLC BRANCH LINE CIRCUIT

#### Diagnosis Procedure

INFOID:0000000011051432

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

# M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## M&A BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051433

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	39	38	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the combination meter branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-57, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the combination meter branch line.  
NO >> Repair the power supply and the ground circuit.

LAN

# STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## STRG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051434

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	5	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the steering angle sensor branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-47, "Wiring Diagram"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-133, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle sensor branch line.

NO >> Repair the power supply and the ground circuit.



# A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## A-BAG BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051435

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the main harness.

#### 2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40. "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.  
NO >> Replace parts whose air bag system has a malfunction.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

## AV BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:000000011051436

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair the terminal and connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
  2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system without BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M96	8	17	Approx. 54 – 66

- With navigation system and BOSE audio system

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M151	8	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
 NO >> Repair the AV control unit branch line.

#### 3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- With navigation system without BOSE audio system: [AV-267, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- With navigation system and BOSE audio system: [AV-376, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- With navigation system without BOSE audio system: [AV-298, "Removal and Installation"](#)
  - With navigation system and BOSE audio system: [AV-416, "Removal and Installation"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.

# AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## AVM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051437

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ITS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ITS control unit.
2. Check the resistance between the ITS control unit harness connector terminals.

ITS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	27	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the ITS control unit branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ITS control unit. Refer to [DAS-64, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ITS control unit. Refer to [DAS-69, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the ITS control unit branch line.  
NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## HVAC BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051438

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
  - A/C auto amp. (with auto A/C)
  - Front air control (without auto A/C)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp. (with auto A/C) or front air control (without auto A/C).
2. Check the resistance between the A/C auto amp. harness connector terminals (with auto A/C) or front air control harness connector terminals (without auto A/C).
  - With auto A/C

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M152	1	21	Approx. 54 – 66

- Without auto A/C

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-78. "A/C AUTO AMP. : Diagnosis Procedure"](#)
- MANUAL AIR CONDITIONER: [HAC-153. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES (Present error)>>Replace the A/C auto amp. (with auto A/C) or front air control (without auto A/C). Refer to following.

- AUTOMATIC AIR CONDITIONER: [HAC-102. "Removal and Installation"](#)
- MANUAL AIR CONDITIONER: [HAC-162. "Removal and Installation"](#)

YES (Past error)>>Error was detected in the A/C auto amp. branch line (with auto A/C) or front air control branch line (without auto A/C).

NO >> Repair the power supply and the ground circuit.

# BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## BCM BRANCH LINE CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051439

#### 1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.  
NO >> Repair the BCM branch line.

#### 3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-81, "Removal and Installation"](#).  
YES (Past error)>>Error was detected in the BCM branch line.  
NO >> Repair the power supply and the ground circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

LAN

# CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

## CAN COMMUNICATION CIRCUIT

### Diagnosis Procedure

INFOID:0000000011051440

#### 1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair the terminal and connector.

#### 2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check the harness and repair the root cause.

#### 3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check the harness and repair the root cause.

#### 4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.
  - QR engine models

ECM		Resistance (Ω)
Terminal No.		
100	99	Approx. 108 – 132

- VQ engine models

ECM		Resistance (Ω)
Terminal No.		
124	123	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

## CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Is the measurement value within the specification?

YES >> GO TO 5.

NO >> Replace the ECM and/or the BCM.

### 5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

### 6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

**NOTE:**

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

**NOTE:**

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

LAN