

SECTION **PWC**

POWER WINDOW CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

CONTENTS

LH FRONT ONLY ANTI-PINCH	Reference Value16
PRECAUTION 6	WIRING DIAGRAM18
PRECAUTIONS 6	POWER WINDOW SYSTEM18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"6	Wiring Diagram - With Left Front Only Power Window Anti- Pinch18
Precaution for Work6	BASIC INSPECTION25
PREPARATION 7	DIAGNOSIS AND REPAIR WORKFLOW25
PREPARATION 7	Work Flow25
Special Service Tool7	INSPECTION AND ADJUSTMENT27
SYSTEM DESCRIPTION 8	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL27
COMPONENT PARTS 8	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description27
Component Parts Location8	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement27
Component Description9	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT27
SYSTEM10	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description27
System Diagram10	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement27
System Description10	DTC/CIRCUIT DIAGNOSIS29
Fail-safe11	POWER SUPPLY AND GROUND CIRCUIT29
DIAGNOSIS SYSTEM (BCM)13	BCM29
COMMON ITEM13	BCM : Diagnosis Procedure29
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)13	POWER WINDOW MAIN SWITCH29
RETAINED PWR14	POWER WINDOW MAIN SWITCH : Description29
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)14	POWER WINDOW MAIN SWITCH : Component Function Check30
ECU DIAGNOSIS INFORMATION15	POWER WINDOW MAIN SWITCH : Diagnosis Procedure30
BCM (BODY CONTROL MODULE)15	
List of ECU Reference15	
MAIN POWER WINDOW AND DOOR LOCK/ UNLOCK SWITCH16	

PWC

POWER WINDOW MAIN SWITCH : Component Inspection	33	Component Function Check	49
POWER WINDOW MAIN SWITCH : Special Repair Requirement	34	Diagnosis Procedure	49
FRONT POWER WINDOW SWITCH	34	Component Inspection	51
FRONT POWER WINDOW SWITCH : Description	34	KEY CYLINDER SWITCH	52
FRONT POWER WINDOW SWITCH : Component Function Check	34	Description	52
FRONT POWER WINDOW SWITCH : Diagnosis Procedure	35	Component Function Check	52
FRONT POWER WINDOW SWITCH : Component Inspection	36	Diagnosis Procedure (With LH and RH Anti-Pinch) ...	52
REAR POWER WINDOW SWITCH	36	Diagnosis Procedure (With LH Anti-Pinch Only)	53
REAR POWER WINDOW SWITCH : Description...	36	Component Inspection	54
REAR POWER WINDOW SWITCH : Component Function Check	36	POWER WINDOW LOCK SWITCH	56
REAR POWER WINDOW SWITCH : Diagnosis Procedure	37	Description	56
REAR POWER WINDOW SWITCH : Component Inspection	38	Component Function Check	56
POWER WINDOW MOTOR	39	Special Repair Requirement	56
DRIVER SIDE	39	SYMPTOM DIAGNOSIS	57
DRIVER SIDE : Description	39	POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES	57
DRIVER SIDE : Component Function Check	39	Diagnosis Procedure	57
DRIVER SIDE : Diagnosis Procedure	39	DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	58
DRIVER SIDE : Component Inspection	40	Diagnosis Procedure	58
DRIVER SIDE : Special Repair Requirement	40	FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE	59
PASSENGER SIDE	40	Diagnosis Procedure	59
PASSENGER SIDE : Description	40	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	60
PASSENGER SIDE : Component Function Check	41	Diagnosis Procedure	60
PASSENGER SIDE : Diagnosis Procedure	41	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	61
PASSENGER SIDE : Component Inspection	42	Diagnosis Procedure	61
REAR LH	42	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	62
REAR LH : Description	42	Diagnosis Procedure	62
REAR LH : Component Function Check	42	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	63
REAR LH : Diagnosis Procedure	42	Diagnosis Procedure	63
REAR LH : Component Inspection	43	POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	64
REAR RH	43	Diagnosis Procedure	64
REAR RH : Description	44	POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	65
REAR RH : Component Function Check	44	Diagnosis Procedure	65
REAR RH : Diagnosis Procedure	44	DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	66
REAR RH : Component Inspection	45	Diagnosis Procedure	66
ENCODER	46		
DRIVER SIDE	46		
DRIVER SIDE : Description	46		
DRIVER SIDE : Component Function Check	46		
DRIVER SIDE : Diagnosis Procedure	46		
DRIVER SIDE : Special Repair Requirement	48		
DOOR SWITCH	49		
Description	49		

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	67	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	82	A
Diagnosis Procedure	67	Reference Value	82	
PERIODIC MAINTENANCE	68	Fail Safe	83	B
PRE-INSPECTION FOR DIAGNOSTIC	68	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	85	
Basic Inspection	68	Reference Value	85	C
REMOVAL AND INSTALLATION	69	Fail Safe	86	
MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	69	WIRING DIAGRAM	87	D
Removal and Installation	69	POWER WINDOW SYSTEM	87	
POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	70	Wiring Diagram - With Left And Right Front Power Window Anti-Pinch	87	E
Removal and Installation	70	BASIC INSPECTION	95	
REAR POWER WINDOW SWITCH	71	DIAGNOSIS AND REPAIR WORKFLOW	95	F
Removal and Installation	71	Work Flow	95	
LH & RH FRONT ANTI-PINCH		INSPECTION AND ADJUSTMENT	97	G
PRECAUTION	72	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL	97	
PRECAUTIONS	72	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description	97	H
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	72	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement	97	I
Precaution for Work	72	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	97	J
PREPARATION	73	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	97	
PREPARATION	73	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	97	PWC
Special Service Tool	73	DTC/CIRCUIT DIAGNOSIS	99	
SYSTEM DESCRIPTION	74	POWER SUPPLY AND GROUND CIRCUIT	99	L
COMPONENT PARTS	74	BCM	99	
Component Parts Location	74	BCM : Diagnosis Procedure	99	M
Component Description	74	POWER WINDOW MAIN SWITCH	99	
SYSTEM	76	POWER WINDOW MAIN SWITCH : Description	99	N
System Diagram	76	POWER WINDOW MAIN SWITCH : Component Function Check	100	
System Description	76	POWER WINDOW MAIN SWITCH : Diagnosis Procedure	100	O
Fail-safe	78	POWER WINDOW MAIN SWITCH : Component Inspection	102	
DIAGNOSIS SYSTEM (BCM)	79	POWER WINDOW MAIN SWITCH : Special Repair Requirement	103	P
COMMON ITEM	79	FRONT POWER WINDOW SWITCH	103	
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	79	FRONT POWER WINDOW SWITCH : Description	103	
RETAINED PWR	80	FRONT POWER WINDOW SWITCH : Component Function Check	104	
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	80			
ECU DIAGNOSIS INFORMATION	81			
BCM (BODY CONTROL MODULE)	81			
List of ECU Reference	81			

FRONT POWER WINDOW SWITCH : Diagnosis Procedure	104	Component Inspection	122
FRONT POWER WINDOW SWITCH : Special Repair Requirement	105	KEY CYLINDER SWITCH	123
REAR POWER WINDOW SWITCH	105	Description	123
REAR POWER WINDOW SWITCH : Description ..	105	Component Function Check	123
REAR POWER WINDOW SWITCH : Component Function Check	105	Diagnosis Procedure (With LH and RH Anti-Pinch) ..	123
REAR POWER WINDOW SWITCH : Diagnosis Procedure	105	Component Inspection	124
REAR POWER WINDOW SWITCH : Component Inspection	107	POWER WINDOW SERIAL LINK	126
POWER WINDOW MOTOR	108	POWER WINDOW MAIN SWITCH	126
DRIVER SIDE	108	POWER WINDOW MAIN SWITCH : Description ..	126
DRIVER SIDE : Description	108	POWER WINDOW MAIN SWITCH : Component Function Check	126
DRIVER SIDE : Component Function Check	108	POWER WINDOW MAIN SWITCH : Diagnosis Procedure	126
DRIVER SIDE : Diagnosis Procedure	108	FRONT POWER WINDOW SWITCH	127
DRIVER SIDE : Component Inspection	109	FRONT POWER WINDOW SWITCH : Description ..	127
DRIVER SIDE : Special Repair Requirement	109	FRONT POWER WINDOW SWITCH : Component Function Check	127
PASSENGER SIDE	109	FRONT POWER WINDOW SWITCH : Diagnosis Procedure	128
PASSENGER SIDE : Description	110	POWER WINDOW LOCK SWITCH	130
PASSENGER SIDE : Component Function Check ..	110	Description	130
PASSENGER SIDE : Diagnosis Procedure	110	Component Function Check	130
PASSENGER SIDE : Component Inspection	111	Special Repair Requirement	130
PASSENGER SIDE : Special Repair Requirement ..	111	SYMPTOM DIAGNOSIS	131
REAR LH	111	POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES	131
REAR LH : Description	111	Diagnosis Procedure	131
REAR LH : Component Function Check	111	DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	132
REAR LH : Diagnosis Procedure	112	Diagnosis Procedure	132
REAR LH : Component Inspection	113	FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE	133
REAR RH	113	Diagnosis Procedure	133
REAR RH : Description	113	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	134
REAR RH : Component Function Check	113	Diagnosis Procedure	134
REAR RH : Diagnosis Procedure	113	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	135
REAR RH : Component Inspection	114	Diagnosis Procedure	135
ENCODER	115	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	136
DRIVER SIDE	115	Diagnosis Procedure	136
DRIVER SIDE : Description	115	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)	137
DRIVER SIDE : Component Function Check	115	Diagnosis Procedure	137
DRIVER SIDE : Diagnosis Procedure	115		
PASSENGER SIDE	117		
PASSENGER SIDE : Description	117		
PASSENGER SIDE : Component Function Check ..	117		
PASSENGER SIDE : Diagnosis Procedure	117		
DOOR SWITCH	120		
Description	120		
Component Function Check	120		
Diagnosis Procedure	120		

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	138		
Diagnosis Procedure	138		
AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)	139		
Diagnosis Procedure	139		
POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	140		
Diagnosis Procedure	140		
POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	141		
Diagnosis Procedure	141		
DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	142		
Diagnosis Procedure	142		
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	143	A	
Diagnosis Procedure	143		
PERIODIC MAINTENANCE	144	B	
PRE-INSPECTION FOR DIAGNOSTIC	144		
Basic Inspection	144		C
REMOVAL AND INSTALLATION	145		
MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	145	D	
Removal and Installation	145		
POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	146	E	
Removal and Installation	146		
REAR POWER WINDOW SWITCH	147	F	
Removal and Installation	147		
		G	
		H	
		I	
		J	
		L	
		M	
		N	
		O	
		P	

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010481306

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.**

Precaution for Work

INFOID:000000010481307

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[LH FRONT ONLY ANTI-PINCH]

PREPARATION


PREPARATION

Special Service Tool

INFOID:0000000010481308

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH FRONT ONLY ANTI-PINCH]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010481309



AWKIA2028ZZ

- | | | |
|--|--|---|
| 1. BCM (view with combination meter removed) | 2. Front power window motor LH (RH similar) | 3. Rear power window motor LH (RH similar) |
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

Component Description

INFOID:000000010481310

Component	Function
BCM	<ul style="list-style-type: none"> Supplies power to power window switches. Controls retained power.
Front power window motor LH	<ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Front power window motor RH	Starts operating with signals from main power window and door lock/unlock switch and power window and door lock/unlock switch RH.
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> Directly controls all power window motor of all doors. Controls anti-pinch operation of front power window LH.
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> Controls front power window motor RH.
Rear power window switch	<ul style="list-style-type: none"> Controls rear power window motors LH and RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch and rear power window switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

System Diagram

INFOID:000000010481311



System Description

INFOID:000000010481312

INPUT/OUTPUT SIGNAL CHART

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Encoder	Encoder pulse signal	Power window control	Front power window motor
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

POWER WINDOW OPERATION

- Power window system is activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch is turned OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Front & rear power window switches can open/close the corresponding windows.
- Power window lock switch can lock all power windows other than driver seat.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation (Front LH), power window will move in the reverse direction (Anti-Pinch Function).

POWER WINDOW AUTO-OPERATION (FRONT LH)

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch turns to AUTO.

SYSTEM

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating.
- Main power window and door lock/unlock switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF.

Retained power function cancel conditions:

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes. (45 seconds)
- AUTO function does not operate if encoder is malfunctioning.

POWER WINDOW LOCK FUNCTION

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch.

ANTI-PINCH OPERATION (FRONT LH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150mm. (5.9 in.) or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm. (5.9 in.) or 2 seconds after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are performed:

- When the unlock button is pressed for more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Fail-safe

INFOID:000000010481313

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in the encoder signal that detects UP/DOWN speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

Malfunction	Malfunction condition
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011009026

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY ANTI-PINCH]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000011009027

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY ANTI-PINCH]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:0000000010481316

ECU	Reference
BCM	BCS-32. "Reference Value"
	BCS-51. "Fail Safe"
	BCS-52. "DTC Inspection Priority Chart"
	BCS-53. "DTC Index"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH FRONT ONLY ANTI-PINCH]

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Reference Value

INFOID:000000010481317

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
1 (B)	Ground	Ground	—	—	0
2 (L)	16 (BR)	Front power window motor RH DOWN signal	Output	When the front RH switch on the main power window and door lock/ unlock switch is operated in the DOWN position.	Battery voltage
4 (BG)	12 (B)	Encoder pulse signal 2	Input	When power window motor operates.	<p style="text-align: right;">JMKIA0070GB</p>
5 (R)	12 (B)	Encoder pulse signal 1	Input	When power window motor operates.	<p style="text-align: right;">JMKIA0070GB</p>
6 (SB)	Ground	Rear power window motor RH DOWN signal	Output	When the rear RH switch on the main power window and door lock/ unlock switch is operated in the DOWN position.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When the rear RH switch on the main power window and door lock/ unlock switch is operated in the UP position.	Battery voltage
8 (L)	Ground	Rear power window motor LH DOWN signal	Output	When the rear LH switch on the main power window and door lock/ unlock switch is operated in the DOWN position.	Battery voltage

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY ANTI-PINCH]

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
9 (Y)	Ground	Rear power window motor LH UP signal	Output	When the rear LH switch on the main power window and door lock/ unlock switch is operated in the UP position.	Battery voltage
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When driver side or passenger side door is opened during retained power operation.	0
12 (B)	Ground	Encoder ground	—	—	0
14 (P)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
16 (BR)	2 (L)	Front power window motor RH UP signal	Output	When the front RH switch on the main power window and door lock/ unlock switch is operated in the UP position.	Battery voltage
17 (W)	19 (R)	Front power window motor LH UP signal	Output	When the front LH switch on the main power window and door lock/ unlock switch is operated in the UP position.	Battery voltage
18 (LG)	Ground	Battery power supply	Input	—	Battery voltage
19 (R)	17 (W)	Front power window motor LH DOWN signal	Output	When the front LH switch on the main power window and door lock/ unlock switch is operated in the DOWN position.	Battery voltage

A
B
C
D
E
F
G
H
I
J

L
M
N
O
P

PWC

POWER WINDOW SYSTEM

[LH FRONT ONLY ANTI-PINCH]

< WIRING DIAGRAM >


WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - With Left Front Only Power Window Anti- Pinch

INFOID:000000010481318

POWER WINDOW SYSTEM - WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM



ABKWA2192GB


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY ANTI-PINCH]


POWER WINDOW SYSTEM CONNECTORS - WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	W	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5N	BR	-
6N	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	BR	-
92J	LG	-
93J	Y	-
94J	SB	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	GR	-
6	Y	-
7	V	-
8	LG	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	V	-
7	V	-
8	B	-
12	SB	-
13	Y	-
14	BR	-
15	V	-
16	LG	-


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
8	LG	-
9	V	-
10	BR	-
14	SB	-


Terminal No.	Color of Wire	Signal Name
140	LG	PW POWER SUPPLY IGN
141	V	PW POWER SUPPLY BAT
142	BR	BAT FRONT DOOR
143	B	GND1

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
94	SB	AS DOOR SW
96	BR	DR DOOR SW

ABKIA3690GB


POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Terminal No.	Color of Wire	Signal Name
77J	L	-
92J	L	-
93J	SB	-
94J	LG	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	P	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
8	L	-
9	V	-
10	SB	-
14	L	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-
6	B	-
7	LG	-
8	L	-

ABKIA3691GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	B111
Connector Name	JOINT CONNECTOR-B02
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	SB	-
8	L	-

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	W	M2
2	P	VCC (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
3	R	M1
4	B	GND (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
5	R	PLS A
6	BG	PLS B

Connector No.	D8
Connector Name	MAIN POWER WINDOW DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	W	DR UP
18	LG	BAT
19	R	DR DN

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	BR	-
7	LG	-
8	B	-
12	L	-
13	Y	-
14	SB	-
15	V	-
16	BR	-


AAKIA2235GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY ANTI-PINCH]


Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
6	L	-
7	LG	-
8	SB	-

Terminal No.	Color of Wire	Signal Name
4	BG	ENCODER SIG 2
5	R	ENCODER SIG 1
6	SB	RR DN
7	V	RR UP
8	L	RL DN
9	Y	RL UP
10	BR	IGN
11	-	-
12	B	ENCODER GND
13	-	-
14	P	ENCODER +
15	-	-
16	BR	AS UP

Connector No.	D12
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	L	AS DN
3	-	-

Connector No.	D111
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	Y	-
3	V	-

Terminal No.	Color of Wire	Signal Name
6	V	-
7	Y	-
8	SB	-
11	L	-
12	LG	-

Connector No.	D110
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-

AAKIA2236GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY ANTI-PINCH]

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

ABKIA4836GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010481319

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000010481320

Initial setting is necessary when battery terminal is disconnected.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000010481321

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or main power window and door lock/unlock switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the main power window and door lock/unlock switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-11, "Fail-safe"](#).
- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function
3. Retained power operation when ignition switch is OFF.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000010481322

Initial setting is necessary when replacing main power window and door lock/unlock switch.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000010481323

INITIALIZATION PROCEDURE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH FRONT ONLY ANTI-PINCH]

1. Disconnect battery minus terminal or main power window and door lock/unlock switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the main power window and door lock/unlock switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
 - Check that AUTO-UP operates before inspection when system initialization is performed.
 - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-11, "Fail-safe"](#).
 - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
 - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation
 2. Anti-pinch function
 3. Retained power operation when ignition switch is OFF.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000011009037

Regarding Wiring Diagram information, refer to [BCS-56, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000010481325

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000010481326

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
NO >> Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000010481327

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors D8, D12 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Main power window and door lock/unlock switch	Terminal	Ground
D12	10	
D8	18	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M21	140	D12	10	Yes
	141	D8	18	

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		Ground
	141		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch RH) GO TO 8.
- NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	Battery voltage
M21	140	
	141	

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

Terminal		Window switch position (rear LH)	Voltage (Approx.)	
(+)	(-)			
Main power window and door lock/unlock switch connector	Terminal	Ground	Battery voltage	
D12	8			
	9		DOWN	0
			UP	0
	DOWN	Battery voltage		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT: Special Repair Requirement"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D12	6	Ground	UP	Battery voltage
			DOWN	0
	7		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D8 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D8	17	Ground	UP	Battery voltage
			DOWN	0
	19		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

8. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D12 and ground.

Terminal		(-)	Window switch position (front RH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D12	2	Ground	UP	Battery voltage
			DOWN	0
	16		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000010481328

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D12.

Terminal		Main power window and door lock/unlock switch condition		Continuity
10	8	Rear LH	UP	Yes
10	6	Rear RH		
10	2	Front RH		
8	9	Rear LH	NEUTRAL	
6	7	Rear RH		
2	16	Front RH		
10	9	Rear LH	DOWN	
10	7	Rear RH		
10	16	Front RH		
1	12	-		

2. Check continuity between main power window and door lock/unlock switch D12 (power window lock switch) (Lock operation).

Terminal		Main power window and door lock/unlock switch condition		Continuity
9	1	Rear LH	UP	No
7		Rear RH		
16		Front RH		
8		Rear LH	NEUTRAL	
9		Rear RH		
7		Front RH		
6		Rear LH	DOWN	
2		Rear RH		
16		Front RH		

3. Check continuity between main power window and door lock/unlock switch D12 (power window lock switch) (Unlock operation).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
7	Rear RH	
16	Front RH	
8	Rear LH	NEUTRAL
9	Rear LH	
7	Rear RH	
6	Rear RH	
2	Front RH	DOWN
16	Front RH	
8	Rear LH	
6	Rear RH	
2	Front RH	

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000010481329

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000010481330

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000010481331

Power Window And Door Lock/unlock Switch RH

1. CHECK POWER WINDOW MOTOR FUNCTION

Check front power window motor operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.

NO >> Refer to [PWC-35, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000010481332

Regarding Wiring Diagram information, refer to [PWC-18. "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Power Window And Door Lock/Unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch ON.
2. Check voltage between power window and door lock/unlock switch RH connector D110 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	Battery voltage
D110	8	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector M21 and power window and door lock/unlock switch RH connector D110.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M21	140	D110	8	Yes

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D12 and power window and door lock/unlock switch RH connector D110.

Main power window and door lock/unlock switch connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
D12	2	D110	11	Yes
	16		12	

4. Check continuity between main power window and door lock/unlock switch connector D12 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	2		No
	16		

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

- YES >> GO TO 5.
NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	140	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

5. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.
Refer to [PWC-36, "FRONT POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-69, "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Component Inspection

INFOID:0000000010481333

COMPONENT INSPECTION

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH D110.

Terminal		Power window switch condition	Continuity
8	7	UP	Yes
12	6		
12	6	NEUTRAL	
7	11		
8	6	DOWN	
7	11		

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH is OK.
NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-70, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:0000000010481334

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:0000000010481335

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

POWER SUPPLY AND GROUND CIRCUIT

[LH FRONT ONLY ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.
- NO >> Refer to [PWC-37. "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:0000000010481336

Regarding Wiring Diagram information, refer to [PWC-18. "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Rear Power Window Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear power window switch connector and ground.

Terminal		Condition	Voltage (Approx.)
(+)			
Rear power window switch connector	Terminal		
LH	D203	Ignition switch ON	Battery voltage
RH	D303		
	4	Ground	

Is the inspection result normal?

- YES >> GO TO 2 (Rear power window switch LH).
- YES >> GO TO 3 (Rear power window switch RH).
- NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch LH connector.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D12	8	D203	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	8	Ground	No
	9		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch RH connector.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D12	6	D303	7	Yes
	7		8	

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	6		
	7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the harness or connectors.

4. CHECK HARNESS CONTINUITY

1. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
2. Check continuity between BCM connector and rear power window switch connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M21	140	LH	D203	4	Yes
		RH	D303		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-38, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-71, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:0000000010481337

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
8	6		
8	6	NEUTRAL	
5	7		
4	6	DOWN	
5	7		

Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-71, "Removal and Installation"](#).

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000010481338

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch.

DRIVER SIDE : Component Function Check

INFOID:0000000010481339

1. CHECK FRONT POWER WINDOW MOTOR LH CIRCUIT

Check front power window motor LH operation with the main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-39, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010481340

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti- Pinch"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor LH connector D9 and ground.

Terminal (+)		Terminal (-)	Main power window and door lock/unlock switch condition	Voltage (Approx.)
Front power window motor LH connector	Terminal			
D9	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D8 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D8	17	D9	1	Yes
	19		3	

4. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal		Ground	Continuity
	D8	17		
19				

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-40, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness.

3. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-40, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-40, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Component Inspection

INFOID:0000000010481341

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-40, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Special Repair Requirement

INFOID:0000000010481342

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Refer to [PWC-39, "DRIVER SIDE : Component Function Check"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000010481343

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

PASSENGER SIDE : Component Function Check

INFOID:000000010481344

1. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH operation with main power window and door lock/unlock switch or power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Refer to [PWC-41, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010481345

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti- Pinch"](#).

Front Power Window Motor RH Circuit Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D111 and ground.

Terminal		(-)	Front power window motor RH condition	Voltage (V) (Approx.)
(+)				
Front power window motor RH connector	Terminal	Ground		
D111	1		UP	Battery voltage
	3		DOWN	0
			UP	0
		DOWN	Battery voltage	

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D110 and front power window motor RH connector D111.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D110	7	D111	1	Yes
	6		3	

4. Check continuity between power window and door lock/unlock switch connector D110 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D110	7		
	6		

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-69, "Removal and Installation"](#).
- NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-42, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#).

PASSENGER SIDE : Component Inspection

INFOID:0000000010481346

COMPONENT INSPECTION

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D111.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#).

REAR LH

REAR LH : Description

INFOID:0000000010481347

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:0000000010481348

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-42, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:0000000010481349

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Rear Power Window Motor LH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH LH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		Window condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor LH connector	Terminal		
D204	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D203 and rear power window motor LH connector D204.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203	5	D204	1	Yes
	6		3	

4. Check continuity between rear power window switch LH connector D203 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203	5	Ground	No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch LH. Refer to [PWC-43, "REAR LH : Component Inspection"](#).
- NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.
Refer to [PWC-43, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000010481350

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
- NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

REAR RH : Description

INFOID:000000010481351

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000010481352

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor RH operation with operating main power window and door lock/unlock switch or rear power window switch RH.

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Refer to [PWC-44, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000010481353

Regarding Wiring Diagram information, refer to [PWC-18, "Wiring Diagram - With Left Front Only Power Window Anti-Pinch"](#).

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector D304	Terminal		
	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector D303 and rear power window motor RH connector D304.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303	5	D304	1	Yes
	6		3	

4. Check continuity between rear power window switch RH connector D303 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303	5		No
	6		

Is the inspection result normal?

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

- YES >> Check rear power window switch RH. Refer to [PWC-45, "REAR RH : Component Inspection"](#).
- NO >> Repair or replace harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-45, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:000000010481354

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Power window motor is OK.
- NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

ENCODER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000010481355

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000010481356

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO open/close operation normally with main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-46. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000010481357


Regarding Wiring Diagram information, refer to [PWC-18. "Wiring Diagram - With Left Front Only Power Window Anti- Pinch"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Connect front power window motor LH.
2. Turn ignition switch ON.
3. Check signal between main power window and door lock/unlock switch connector D12 and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Refer to following signal
D12	4	
	5	Ground



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal			Voltage (Approx.)
(+)		(-)	
Front power window motor LH connector	Terminal		
D9	2	Ground	10

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D12 and front power window motor connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	14	D9	2	Yes

4. Check continuity between main power window and door lock/unlock switch connector D12 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D12	14	Ground	No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-48, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	4	Ground	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D12 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	12	D9	4	Yes

Is the inspection result normal?

YES >> Check main power window and door lock/unlock switch. Refer to [PWC-33, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window D12 and door lock/unlock switch connector and front power window motor LH connector D9.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D12	4	D9	6	Yes
	5		5	

3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
D12	4	Ground	No
	5		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-48, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness or connectors.

DRIVER SIDE : Special Repair Requirement

INFOID:0000000010481358

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DOOR SWITCH

Description

INFOID:0000000011009028

Detects door open/close condition.

Component Function Check

INFOID:0000000011009029

1.CHECK FUNCTION

With CONSULT

Check door switches "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR" in "Data Monitor".

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	
DOOR SW-RL	
DOOR SW-RR	

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [PWC-49. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011009030

Regarding Wiring Diagram information, refer to [DLK-51. "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL





1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminals		(-)	Door condition	Voltage (V) (Approx.)
(+)				
BCM connector	Terminal			
M19	96	Ground	OPEN	0
			CLOSE	
	94		OPEN	0
			CLOSE	
	93		OPEN	0
			CLOSE	
	82		OPEN	0
			CLOSE	

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 2.

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
M19	96	Front door switch LH	Ground part of door switch	Yes
	94	Front door switch RH		
	93	Rear door switch RH		
	82	Rear door switch LH		

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

3. Check continuity between BCM connector and ground.

BCM connector	Terminal		Continuity
M19	96	Ground	No
	94		
	93		
	82		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness between BCM and door switch.

3.CHECK DOOR SWITCH

Refer to [PWC-51, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch. Refer to [DLK-219, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:0000000011009031

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
3	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning door switch. Refer to [DLK-219, "Removal and Installation"](#).

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

KEY CYLINDER SWITCH

Description

INFOID:000000011009032

For vehicles equipped with LH and RH anti-pinch system, the main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

For vehicles equipped with LH anti-pinch system only, the front door lock assembly LH (key cylinder switch) transmits the LOCK or UNLOCK signal directly to the BCM.

Component Function Check

INFOID:000000011009033

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check "KEY CYL UN-SW", "KEY CYL UN-SW" in "Data Monitor" for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [DLK-81, "Work Flow"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> With LH and RH anti-pinch, refer to [PWC-52, "Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [PWC-53, "Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:000000011009034

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/ unlock switch connector	Terminal		
	D7	Ground	
	3	Lock	0
		Neutral / Unlock	5
	15	Unlock	0
		Neutral / Lock	5

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

1. Turn ignition switch OFF.

KEY CYLINDER SWITCH

[LH FRONT ONLY ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect main power window and door lock/unlock switch connector and front door lock assembly LH connector.
3. Check continuity between main power window and door lock/unlock switch connector and front door lock assembly LH connector.

Main power window and door lock/unlock switch connector	Terminal	Front door lock assembly LH connector	Terminal	Continuity
D7	3	D14	6	Yes
	15		5	

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	3	Ground	No
	15		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	4	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.
 Refer to [PWC-54, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace front door lock assembly LH. Refer to [DLK-203, "FRONT DOOR LOCK : Removal and Installation"](#).

Diagnosis Procedure (With LH Anti-Pinch Only)

INFOID:000000011009035

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).

1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	74	Lock	0
		Neutral / Unlock	5
M17	24	Unlock	0
		Neutral / Lock	5

Is the inspection result normal?

- YES >> Replace front door lock assembly LH. Refer to [PWC-69, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect front door lock assembly LH connector.
- Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	4		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Disconnect BCM connector M18 and M17.
- Check continuity between front door lock assembly LH connector and BCM connector M18 or M17.

Front door lock assembly LH connector	Terminal	BCM connector	Terminal	Continuity
D14	5	M17	24	Yes
	6	M18	74	

- Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	5		
	6		

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.
 Refer to [PWC-54, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace front door lock assembly LH. Refer to [DLK-203, "FRONT DOOR LOCK : Removal and Installation"](#).

Component Inspection

INFOID:000000011009036

COMPONENT INSPECTION

1. CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly LH.

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

Terminal		Key position	Continuity
Front door lock assembly LH (key cylinder switch) connector			
5	4	Unlock	Yes
		Neutral / Lock	No
6		Lock	Yes
		Neutral / Unlock	No

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace front door lock assembly LH. Refer to [DLK-203, "FRONT DOOR LOCK : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW LOCK SWITCH

Description

INFOID:000000010481363

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:000000010481364

1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-69, "Removal and Installation"](#). After that, refer to [PWC-56, "Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

Special Repair Requirement

INFOID:000000010481365

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
- NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

Diagnosis Procedure

INFOID:0000000010481366

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-33, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check main power window and door lock/unlock switch power supply and ground circuit.

Refer to [PWC-30, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481367

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-39, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481368

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-34, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-41, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481369

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-36. "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-42. "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481370

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-36, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-41, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000010481371

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-46. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000010481372

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-46, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000010481373

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-100, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000010481374

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-69. "Removal and Installation"](#). After that, [PWC-27. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000010481375

1. PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-27. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2. CHECK FRONT DOOR LOCK ASSEMBLY LH (DOOR KEY CYLINDER SWITCH)

Check front door lock assembly LH (door key cylinder switch).

Refer to [PWC-56. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> GO TO 1.

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY ANTI-PINCH]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481376

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [DLK-144, "Component Function Check"](#).

2.CHECK POWER WINDOW OPERATION

Check power window operation.

In the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [PWC-39, "DRIVER SIDE : Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRE-INSPECTION FOR DIAGNOSTIC

< PERIODIC MAINTENANCE >

[LH FRONT ONLY ANTI-PINCH]

PERIODIC MAINTENANCE

PRE-INSPECTION FOR DIAGNOSTIC

Basic Inspection

INFOID:000000010481377

BASIC INSPECTION

1.INSPECTION START

1. Check the service history.
2. Check the following parts.
 - Fuse/circuit breaker blown.
 - Poor connection, open or short circuit of harness connector.
 - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace the malfunctioning parts.

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

REMOVAL AND INSTALLATION

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:0000000010481378


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the main power window and door lock/unlock switch and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the main power window and door lock/unlock switch.
4. Release the four pawls (two on each side) using a suitable tool, then separate the main power window and door lock/unlock switch (1) from the main power window and door lock switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is disconnected from the harness connector it is necessary to perform the initialization procedure. Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000010481379


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the power window switch and door lock/unlock switch RH finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the power window and door lock/unlock switch RH.
4. Release the four pawls (two on each side) using a suitable tool, then separate the power window and door lock/unlock switch RH (1) from the power window and door lock/unlock switch RH finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY ANTI-PINCH]

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:000000010481380


REMOVAL

1. Release the pawls using a suitable tool and lift the rear power window switch and finisher as an assembly by starting at the rear, then pull upward and remove
2. Disconnect the harness connector from the rear power window switch.
3. Release the pawl (one on each side) using a suitable tool, then separate the rear power window switch (1) from the rear power switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010481381

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000010481382

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[LH & RH FRONT ANTI-PINCH]

PREPARATION


PREPARATION

Special Service Tool

INFOID:0000000010481383

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH & RH FRONT ANTI-PINCH]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010481384



AWKIA2029ZZ

- | | | |
|--|--|---|
| 1. BCM (view with combination meter removed) | 2. Front power window motor LH (RH similar) | 3. Rear power window motor LH (RH similar) |
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

Component Description

INFOID:000000010481385

FRONT WINDOW ANTI-PINCH SYSTEM

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

Component	Function
BCM	<ul style="list-style-type: none"> Supplies power to power window switches. Controls retained power.
Front power window motor LH	<ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Front power window motor RH	<ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> Directly controls all power window motor of all doors. Controls anti-pinch operation of front power window LH.
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> Controls front power window motor RH. Controls anti-pinch operation of front power window RH.
Rear power window switch	<ul style="list-style-type: none"> Controls rear power window motors LH and RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch & rear power window switch.
Front door lock assembly LH (key cylinder switch)	Transmits operation condition of key cylinder switch to main power window and door lock/unlock switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

< SYSTEM DESCRIPTION >


[LH & RH FRONT ANTI-PINCH]

SYSTEM

System Diagram

INFOID:000000010481386

FRONT WINDOW ANTI-PINCH SYSTEM



System Description

INFOID:000000010481387

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT/OUTPUT SIGNAL CHART

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Key cylinder switch	LOCK/UNLOCK signal (more than 1 seconds over)	Power window control	Front power window motor
Encoder	Encoder pulse signal		
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH INPUT/OUTPUT SIGNAL CHART

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

Item	Input signal to front power window switch	Front power window switch RH function	Actuator
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal	Power window control	Front power window motor RH
Encoder	Encoder pulse signal		
BCM	RAP signal		

POWER WINDOW OPERATION

- Power window system activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch turns OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Front & rear power window switch can open/close the corresponding windows.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation (Front LH & RH), power window will move in the reverse direction (Anti-Pinch Function).

POWER WINDOW AUTO-OPERATION (FRONT LH & RH)

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch & power window and door lock/unlock switch RH turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.
- AUTO function does not operate if encoder is malfunctioning.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF

Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes. (45 seconds)

POWER WINDOW LOCK FUNCTION

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window switch.

ANTI-PINCH OPERATION (FRONT LH & RH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.9 in.) or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm (5.9 in.) or 2 seconds after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for more than 1 second to OPEN or CLOSE front power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL when operating.

OPERATION CONDITION

- Ignition switch OFF

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

- Hold door key cylinder to LOCK position for more than 1 second to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for more than 1 second to perform OPEN operation of the door glass.

KEYLESS POWER WINDOW DOWN OPERATION (FRONT LH & RH)

Front power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3^(NOTE) seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Fail-safe

INFOID:000000010481388

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects UP/DOWN speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more that the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more that the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011009038

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT ANTI-PINCH]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000011009039

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:0000000010481391

ECU	Reference
BCM	BCS-32. "Reference Value"
	BCS-51. "Fail Safe"
	BCS-52. "DTC Inspection Priority Chart"
	BCS-53. "DTC Index"

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT ANTI-PINCH]

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH



Reference Value

INFOID:000000010481392

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
1 (B)	Ground	Ground	—	—	0
3 (P)	Ground	Door key cylinder switch LH LOCK signal	Input	Key position (Neutral/Unlocked → Locked)	5 → 0
4 (BG)	12 (P)	Encoder pulse signal 2	Input	When power window motor operates.	 <p style="text-align: right; font-size: small;">JMkia0070GB</p>
5 (R)	12 (P)	Encoder pulse signal 1	Input	When power window motor operates.	 <p style="text-align: right; font-size: small;">JMkia0070GB</p>
6 (SB)	Ground	Rear power window motor RH DOWN signal	Output	When the rear RH switch on the main power window and door lock/unlock switch is operated in the DOWN position.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When the rear RH switch on the main power window and door lock/unlock switch is operated in the UP position.	Battery voltage
8 (L)	Ground	Rear power window motor LH DOWN signal	Output	When the rear LH switch on the main power window and door lock/unlock switch is operated in the DOWN position.	Battery voltage
9 (Y)	Ground	Rear power window motor LH UP signal	Output	When the rear LH switch on the main power window and door lock/unlock switch is operated in the UP position.	Battery voltage

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When front LH or RH door is opened during retained power operation.	0
11 (P)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p>
12 (P)	Ground	Encoder ground	—	—	0
14 (LG)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
15 (G)	Ground	Door key cylinder switch LH UNLOCK signal	Input	Key position (Neutral/Locked → Unlocked)	5 → 0
17 (W)	19 (R)	Front door power window motor LH UP signal	Output	When the front LH switch on the main power window and door lock/unlock switch is operated in the UP position.	Battery voltage
18 (LG)	Ground	Battery power supply	Input	—	Battery voltage
19 (R)	17 (W)	Front door power window motor LH DOWN signal	Output	When the front LH switch on the main power window and door lock/unlock switch is operated in the DOWN position.	Battery voltage

A
B
C
D
E
F
G
H
I
J

PWC

Fail Safe

INFOID:000000010481393

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

L
M
N
O
P

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT ANTI-PINCH]

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Reference Value

INFOID:000000010481394

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
3 (P)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	<p>JPMIA0013GB</p>
4 (BG)	Ground	Encoder ground	—	—	0
5 (W)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	10
7 (B)	Ground	Ground	—	—	0
8 (LG)	Ground	Battery power supply	Input	—	Battery voltage
9 (LG)	4 (BG)	Encoder pulse signal 1	Input	When power window motor operates.	<p>JMKIA0070GB</p>
10 (G)	4 (BG)	Encoder pulse signal 2	Input	When power window motor operates.	<p>JMKIA0070GB</p>
11 (R)	12 (P)	Power window motor UP signal	Output	When power window motor is UP at operated.	Battery voltage
12 (P)	11 (R)	Power window motor DOWN signal	Output	When power window motor is DOWN at operated.	Battery voltage

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT ANTI-PINCH]

Fail Safe

INFOID:000000010481395

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT ANTI-PINCH]


WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - With Left And Right Front Power Window Anti-Pinch

INFOID:000000010481396

POWER WINDOW SYSTEM - WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM



AAKWA0930GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT ANTI-PINCH]


POWER WINDOW SYSTEM CONNECTORS - WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	W	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5N	BR	-
6N	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	BR	-
92J	LG	-
93J	Y	-
94J	SB	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
8	LG	-
9	V	-
10	BR	-
14	SB	-



ABKIA3682GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >



[LH & RH FRONT ANTI-PINCH]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
54	P	PW LIN

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	GR	-
5	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	V	-
8	B	-
12	SB	-
13	Y	-
14	BR	-
15	V	-
16	LG	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	P	-

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
140	LG	P/W POWER SUPPLY IGN
141	V	P/W POWER SUPPLY BAT
142	BR	BAT FRONT DOOR
143	B	GND1

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
94	SB	AS DOOR SW
96	BR	DR DOOR SW

ABKIA4846GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	P	-
18	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5G	P	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
77J	L	-
92J	L	-
93J	SB	-
94J	LG	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-
6	B	-
7	LG	-
8	L	-


ABKIA3684GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	SB	-
8	L	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
8	L	-
9	V	-
10	SB	-
14	L	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	LG	-
8	B	-
12	L	-
13	Y	-
14	SB	-
15	V	-
16	BR	-

Connector No.	B111
Connector Name	JOINT CONNECTOR-B02
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

ABKIA3685GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT ANTI-PINCH]


Terminal No.	Color of Wire	Signal Name
6	SB	RR DN
7	V	RR UP
8	L	RL DN
9	Y	RL UP
10	BR	IGN
11	P	COM
12	P	ENCODER GND
13	-	-
14	LG	ENCODER +
15	G	KEYCYLINDER UNLOCK
16	-	-

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	-	-
3	P	KEYCYLINDER LOCK
4	BG	ENCODER SIG2
5	R	ENCODER SIG1


Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	P	-
18	B	-

Terminal No.	Color of Wire	Signal Name
1	W	M2
2	LG	VCC (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
3	R	M1
4	P	GND (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
5	R	PLS A
6	BG	PLS B

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	GREEN



Connector No.	D8
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	W	DR UP
18	LG	BAT
19	R	DR DN


AAKIA2233GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	R	M2
2	W	VCC
3	P	M1
4	BG	GND
5	LG	PLS A
6	G	PLS B

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-
5	LG	-

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	G	-
6	P	-


Connector No.	D114
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	P	-

Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	P	COM
4	BG	ENCODER GND
5	W	ENCODER +
6	-	-
7	B	GND
8	LG	BAT
9	LG	ENCODER SGN1
10	G	ENCODER SGN2
11	R	AS UP
12	P	AS DN

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Color	WHITE



AAKIA2234GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT ANTI-PINCH]

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	Y	-
5	L	-
6	LG	-
7	BR	-
8	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
6	B	-
7	BR	-
8	Y	-

ABKIA4828GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010481397

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000010481398

Initial setting is necessary when battery terminal is disconnected.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000010481399

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or main power window and door lock/unlock switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm (5.91 in.) or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the main power window and door lock/unlock switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
 - Check that AUTO-UP operates before inspection when system initialization is performed.
 - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-83, "Fail Safe"](#).
 - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
 - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation
 2. Anti-pinch function
 3. Retained power operation when ignition switch is OFF.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000010481400

Initial setting is necessary when replacing main power window and door lock/unlock switch.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000010481401

INITIALIZATION PROCEDURE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH & RH FRONT ANTI-PINCH]

1. Disconnect battery minus terminal or main power window and door lock/unlock switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
 - Check that glass lowers for approximately 150 mm (5.91 in.) or 2 seconds without pinching piece of wood and stops.
 - Check that glass does not rise when operating the main power window and door lock/unlock switch while lowering.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
 - Check that AUTO-UP operates before inspection when system initialization is performed.
 - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-83, "Fail Safe"](#).
 - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
 - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation
 2. Anti-pinch function
 3. Retained power operation when ignition switch is OFF.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000011009040

Regarding Wiring Diagram information, refer to [BCS-56, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	I (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M21	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M21	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000010481403

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000010481404

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
NO >> Refer to [PWC-100, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000010481405

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Battery voltage
D7	10	
D8	18	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M21	140	D7	10	Yes
	141	D8	18	

4. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity	
M21	140		Ground	No
	141			

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
- NO >> Repair or replace the harness and connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	Battery voltage
M21	140	
	141	
	Ground	

Is the measurement value within the specification?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

Terminal		Window switch position (rear LH)	Voltage (Approx.)	
(+)	(-)			
Main power window and door lock/unlock switch connector	Terminal	Ground	Battery voltage	
D7	8			UP
	9		DOWN	0
			UP	0
	DOWN	Battery voltage		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)	
(+) Main power window and door lock/unlock switch connector					
Terminal		Ground	UP	Battery voltage	
D7					7
			6	UP	0

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D7 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)	
(+) Main power window and door lock/unlock switch connector					
Terminal		Ground	UP	Battery voltage	
D7					17
			19	UP	0

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#).

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000010481406

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D7.

Terminal		Main power window and door lock/unlock switch condition		Continuity
10	8	Rear LH	UP	
10	7	Rear RH		
8	9	Rear LH	NEUTRAL	
6	7	Rear RH		
10	9	Rear LH	DOWN	
10	6	Rear RH		
1	12	-		

2. Check continuity between main power window and door lock/unlock switch D7 (power window lock switch). (Lock operation).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
6	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
7	Rear LH	DOWN
6	Rear RH	
8	Rear LH	DOWN
7	Rear RH	

3. Check continuity between main power window and door lock/unlock switch D7 (power window lock switch). (Unlock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
6	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
6	Rear LH	DOWN
7	Rear RH	
8	Rear LH	DOWN
7	Rear RH	

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000010481407

PWC

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Refer to [PWC-108, "DRIVER SIDE : Component Function Check"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000010481408

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000010481409

Power Window And Door Lock/unlock Switch RH

1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Check front power window motor RH operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
NO >> Refer to [PWC-104, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000010481410

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window And Door Lock/unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between power window and door lock/unlock switch RH connector D105 and ground.

Terminal (+)		Terminal (-)	Voltage (Approx.)
Power window and door lock/unlock switch RH connector	Terminal		
D105	8	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and power window and door lock/unlock switch RH.
- Check continuity between BCM connector M21 and power window and door lock/unlock switch RH connector D105.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M21	141	D105	8	Yes

- Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	141		No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH	Terminal	Ground	Continuity
D105	7		Yes

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M21 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	
M21	141	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Special Repair Requirement

INFOID:000000010481411

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Refer to [PWC-104, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

REAR POWER WINDOW SWITCH

PWC

REAR POWER WINDOW SWITCH : Description

INFOID:000000010481412

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000010481413

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

YES >> Rear power window switch power supply and ground circuit are OK.

NO >> Refer to [PWC-105, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000010481414

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Rear Power Window Switch Power Supply Circuit Check

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between rear power window switch connector and ground.

Terminal		Terminal	Condition	Voltage (Approx.)
(+)	(-)			
Rear power window switch connector		4	Ground	Ignition switch ON
LH	D203			
RH	D303			

Is the inspection result normal?

YES >> GO TO 2 (Rear power window switch LH).

YES >> GO TO 3 (Rear power window switch RH).

NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and rear power window switch LH connector D203.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7	8	D203	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	8		No
	9		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and rear power window switch RH connector D303.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7	6	D303	7	Yes
	7		8	

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	6		No
	7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the harness or connectors.

4. CHECK HARNESS CONTINUITY

1. Disconnect BCM and rear power window switch.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

2. Check continuity between BCM connector and rear power window switch connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M21	140	LH	D203	4	Yes
		RH	D303		

3. Check continuity between BCM connector M21 and ground.

BCM connector	Terminal	Ground	Continuity
M21	140		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-107, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-147, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000010481415

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH D203.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
8	6		
8	6	NEUTRAL	
5	7		
6	4	DOWN	
5	7		

Is the inspection result normal?

YES >> Rear power window switch LH is OK.

NO >> Replace rear power window switch. Refer to [PWC-147, "Removal and Installation"](#).

2. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH D303.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
7	6		
7	6	NEUTRAL	
5	8		
6	4	DOWN	
5	8		

Is the inspection result normal?

YES >> Rear power window switch RH is OK.

NO >> Replace rear power window switch. Refer to [PWC-147, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

[LH & RH FRONT ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000010481416

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch.

DRIVER SIDE : Component Function Check

INFOID:0000000010481417

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor LH operation with operating main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-108, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010481418

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector D9 and ground.

Terminal		Main power window and door lock/unlock switch condition	Voltage (Approx.)
(+)	(-)		
Power window motor LH connector D9	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D8 and front power window motor connector LH D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D8	17	D9	1	Yes
	19		3	

4. Check continuity between main power window and door lock/unlock switch connector D8 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	17		No
	19		

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-109, "DRIVER SIDE : Special Repair Requirement"](#).
- NO >> Repair or replace the harness or connectors.

3. CHECK POWER WINDOW MOTOR

Check front power window motor LH.

Refer to [PWC-109, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-109, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Component Inspection

INFOID:000000010481419

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-109, "DRIVER SIDE : Special Repair Requirement"](#).

DRIVER SIDE : Special Repair Requirement

INFOID:000000010481420

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [PWC-115, "DRIVER SIDE : Component Function Check"](#).

PASSENGER SIDE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

PASSENGER SIDE : Description

INFOID:000000010481421

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

PASSENGER SIDE : Component Function Check

INFOID:000000010481422

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check power window motor operation with operating main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-110, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010481423

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Front Power Window Motor RH Circuit Check

1. CHECK FRONT POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D104 and ground.

Terminal		(-)	Front power window motor RH condition	Voltage (Approx.)
(+) Front power window motor RH connector				
Terminal		Ground	UP	Battery voltage
D104	1		DOWN	0
			3	UP
	DOWN			Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	11	D104	1	Yes
	12		3	

4. Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	11		No
	12		

POWER WINDOW MOTOR

[LH & RH FRONT ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-146, "Removal and Installation"](#). After that, refer to [PWC-111, "PASSENGER SIDE : Special Repair Requirement"](#).
- NO >> Repair or replace harness or connectors.

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-111, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
- NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-111, "PASSENGER SIDE : Special Repair Requirement"](#).

PASSENGER SIDE : Component Inspection

INFOID:000000010481424

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D104.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-111, "PASSENGER SIDE : Special Repair Requirement"](#).

PASSENGER SIDE : Special Repair Requirement

INFOID:000000010481425

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [PWC-117, "PASSENGER SIDE : Component Function Check"](#).

REAR LH

REAR LH : Description

INFOID:000000010481426

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000010481427

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
- NO >> Refer to [PWC-112, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:000000010481428

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Motor Circuit Check

1. CHECK REAR POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

Terminal		Window condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor LH connector	Terminal		
D204	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D203 and rear power window motor LH connector D204.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203	5	D204	1	Yes
	6		3	

4. Check continuity between rear power window switch LH connector D203 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203	5		No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch LH. Refer to [PWC-107, "REAR POWER WINDOW SWITCH : Component Inspection"](#).
- NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.
Refer to [PWC-113, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000010481429

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000010481430

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000010481431

1. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

Check rear power window motor RH operation with operating main power window and door lock/unlock switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
NO >> Refer to [PWC-113, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000010481432

PWC

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector D304	Terminal		
	1	UP	Battery voltage
		DOWN	0
	3	UP	0
	Ground	DOWN	Battery voltage

Is the measurement value within the specification?

POWER WINDOW MOTOR

[LH & RH FRONT ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector D303 and rear power window motor RH connector D304.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303	5	D304	1	Yes
	6		3	

4. Check continuity between rear power window switch RH connector D303 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303	5	Ground	No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch RH. Refer to [PWC-107, "REAR POWER WINDOW SWITCH : Component Inspection"](#).
NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.
Refer to [PWC-114, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:0000000010481433

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ENCODER DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000010481434

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:0000000010481435

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Encoder operation is OK.
- NO >> Refer to [PWC-115. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010481436


Regarding Wiring Diagram information, refer to [PWC-87. "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector D7 and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Refer to following signal
D7	4	
	5	
	Ground	



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
- NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor LH connector	Terminal	
D9	2	Ground
		10

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	14	D9	2	Yes

4. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	14		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	4		Yes

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	12	D9	4	Yes

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7	5	D9	5	Yes
	4		6	

3. Check continuity between main power window and door lock/unlock switch connector D7 and ground.

Main power window and door lock/unlock switch connector	Terminal		Continuity
D7	5	Ground	No
	4		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000010481437

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

PASSENGER SIDE : Component Function Check

INFOID:000000010481438

1. CHECK ENCODER OPERATION

Check front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-117, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010481439

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

1. CHECK ENCODER SIGNAL


1. Connect front power window motor RH.
2. Turn ignition switch ON.
3. Check signal between power window and door lock/unlock switch RH connector D105 and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	Ground
	D105	
	9	Refer to following signal
	10	

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor RH connector D105 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor RH connector	Terminal	
D105	5	Ground
		10

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH and front power window motor RH.
3. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	5	D104	2	Yes

4. Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	5	Ground	No

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-146, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Check continuity between front power window motor RH connector D104 and ground.

Front power window motor RH connector	Terminal	Ground	Continuity
D104	4	Ground	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

5. CHECK HARNESS CONTINUITY 2

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	4	D104	4	Yes

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-146, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D105 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105	9	D104	5	Yes
	10		6	

3. Check continuity between power window and door lock/unlock switch RH connector D105 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105	9	Ground	No
	10		

Is the inspection result normal?

YES >> Replace front power window motor RH. Refer to [GW-16, "Removal and Installation - Front Regulator"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DOOR SWITCH

Description

INFOID:000000011009041

Detects door open/close condition.

Component Function Check

INFOID:000000011009042

1.CHECK FUNCTION

With CONSULT

Check door switches "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR" in "Data Monitor".

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	
DOOR SW-RL	
DOOR SW-RR	

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [PWC-120, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011009043

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).





1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check signal between BCM connector and ground with oscilloscope.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminals		(-)	Door condition		Voltage (V) (Approx.)
(+)					
BCM connector	Terminal				
M19	96	Ground	Front door switch LH	OPEN	0
				CLOSE	 JPMIA0011GB
	94		Front door switch RH	OPEN	0
				CLOSE	 JPMIA0011GB
	93		Rear door switch RH	OPEN	0
				CLOSE	 JPMIA0011GB
	82		Rear door switch LH	OPEN	0
				CLOSE	 JPMIA0011GB

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 2.

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and door switch connector.

BCM connector	Terminal	Door switch connector	Terminal	Continuity
M19	96	Front door switch LH	Ground part of door switch	Yes
	94	Front door switch RH		
	93	Rear door switch RH		
	82	Rear door switch LH		

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

3. Check continuity between BCM connector and ground.

BCM connector	Terminal		Continuity
M19	96	Ground	No
	94		
	93		
	82		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness between BCM and door switch.

3.CHECK DOOR SWITCH

Refer to [PWC-122, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch. Refer to [DLK-219, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000011009044

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch.

Terminal		Door switch condition	Continuity
Door switch			
3	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning door switch. Refer to [DLK-219, "Removal and Installation"](#).

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

KEY CYLINDER SWITCH

Description

INFOID:0000000011009045

For vehicles equipped with LH and RH anti-pinch system, the main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

For vehicles equipped with LH anti-pinch system only, the front door lock assembly LH (key cylinder switch) transmits the LOCK or UNLOCK signal directly to the BCM.

Component Function Check

INFOID:0000000011009046

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check "KEY CYL UN-SW", "KEY CYL UN-SW" in "Data Monitor" for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [DLK-81, "Work Flow"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> With LH and RH anti-pinch, refer to [PWC-123, "Diagnosis Procedure \(With LH and RH Anti-Pinch\)"](#).

NO >> With LH anti-pinch only, refer to [PWC-53, "Diagnosis Procedure \(With LH Anti-Pinch Only\)"](#).

Diagnosis Procedure (With LH and RH Anti-Pinch)

INFOID:0000000011009047

Regarding Wiring Diagram information, refer to [DLK-51, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/ unlock switch connector	Terminal		
	D7	Ground	
	3	Lock	0
		Neutral / Unlock	5
	15	Unlock	0
		Neutral / Lock	5

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

1. Turn ignition switch OFF.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

KEY CYLINDER SWITCH

[LH & RH FRONT ANTI-PINCH]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect main power window and door lock/unlock switch connector and front door lock assembly LH connector.
3. Check continuity between main power window and door lock/unlock switch connector and front door lock assembly LH connector.

Main power window and door lock/unlock switch connector	Terminal	Front door lock assembly LH connector	Terminal	Continuity
D7	3	D14	6	Yes
	15		5	

4. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7	3	Ground	No
	15		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH connector and ground.

Front door lock assembly LH connector	Terminal	Ground	Continuity
D14	4	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.
 Refer to [PWC-124, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace front door lock assembly LH. Refer to [DLK-203, "FRONT DOOR LOCK : Removal and Installation"](#).

Component Inspection

INFOID:000000011009049

COMPONENT INSPECTION

1. CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly LH.

Terminal	Front door lock assembly LH (key cylinder switch) connector	Key position	Continuity
5	4	Unlock	Yes
		Neutral / Lock	No
6		Lock	Yes
		Neutral / Unlock	No

Is the inspection result normal?

- YES >> Key cylinder switch is OK.

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

NO >> Replace front door lock assembly LH. Refer to [DLK-203. "FRONT DOOR LOCK : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000010481449

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000010481450

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "Data Monitor" for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-16, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-126, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000010481451

Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Serial Link Check


1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Remove Intelligent Key, and close front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M18	54	

Is the inspection result normal?

- YES >> Power window serial link is OK.
- NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector M18 and main power window and door lock/unlock switch connector D7.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M18	54	D7	11	Yes

4. Check continuity between BCM connector M18 and ground.

BCM connector	Terminal	Ground	Continuity
M18	54		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace harness or connectors.

PWC

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000010481452

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000010481453

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

Check ("CDL LOCK SW ", "CDL UNLOCK SW") in "Data Monitor" for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-16, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-128, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000010481454


Regarding Wiring Diagram information, refer to [PWC-87, "Wiring Diagram - With Left And Right Front Power Window Anti-Pinch"](#).

Power Window Serial Link Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

1. Remove Intelligent Key, and close the front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M18	54	Ground



PIIA1297E

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check continuity between BCM connector M18 and power window and door lock/unlock switch RH connector D105.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M18	54	D105	3	Yes

4. Check continuity between BCM connector M18 and ground.

BCM connector	Terminal	Ground	Continuity
M18	54	Ground	No

Is the inspection result normal?

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW LOCK SWITCH

Description

INFOID:000000010481455

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:000000010481456

1. CHECK POWER WINDOW LOCK SIGNAL

Main power window and door lock/unlock switch operation (window lock signal) is checked.

Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-145, "Removal and Installation"](#). After that, refer to [PWC-130, "Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

Special Repair Requirement

INFOID:000000010481457

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.
- NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH ANY POWER WINDOW SWITCHES

Diagnosis Procedure

INFOID:000000010481458

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.
Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.
Refer to [PWC-102, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.
Refer to [PWC-100, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.
Refer to [PWC-126, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481459

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-108, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481460

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-104, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-127, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-110, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481461

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-105, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-111, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481462

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-105, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-113, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000010481463

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-115. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000010481464

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-117, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000010481465

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-115, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000010481466

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-97, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-117, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000010481467

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-100, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000010481468

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-145, "Removal and Installation"](#). After that, [PWC-103, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000010481469

1. PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-97. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> GO TO 2.

2. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check front door lock assembly LH (key cylinder switch).

Refer to [PWC-123. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
- NO >> GO TO 1.

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT ANTI-PINCH]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010481470

1. CHECK INTELLIGENT KEY FUNCTION

Check Intelligent Key function.

Refer to [DLK-146. "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRE-INSPECTION FOR DIAGNOSTIC

< PERIODIC MAINTENANCE >

[LH & RH FRONT ANTI-PINCH]

PERIODIC MAINTENANCE

PRE-INSPECTION FOR DIAGNOSTIC

Basic Inspection

INFOID:000000010481471

BASIC INSPECTION

1.INSPECTION START

1. Check the service history.
2. Check the following parts.
 - Fuse/circuit breaker blown.
 - Poor connection, open or short circuit of harness connector.
 - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace the malfunctioning parts.

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

REMOVAL AND INSTALLATION

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:0000000010481472


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the main power window and door lock/unlock switch and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the main power window and door lock/unlock switch.
4. Release the four pawls (two on each side) using a suitable tool, then separate the main power window and door lock/unlock switch (1) from the main power window and door lock switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is disconnected from the harness connector it is necessary to perform the initialization procedure. Refer to [PWC-27. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O
P

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000010481473


REMOVAL

1. Remove the front door pull handle outer finisher using a suitable tool.
2. Release the pawls using a suitable tool and lift the power window and door lock/unlock switch RH and finisher as an assembly by starting at the rear, then pull upward and remove.
3. Disconnect the harness connector from the power window and door lock/unlock switch RH.
4. Release the four pawls (two on each side) using a suitable tool, then separate the power window and door lock/unlock switch RH (1) from the power window and door lock switch RH finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is disconnected from the harness connector it is necessary to perform the initialization procedure. Refer to [PWC-27, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT ANTI-PINCH]

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:000000010481474


REMOVAL

1. Release the pawls using a suitable tool and lift the rear power window switch and finisher as an assembly by starting at the rear, then pull upward and remove
2. Disconnect the harness connector from the rear power window switch.
3. Release the pawl (one on each side) using a suitable tool, then separate the rear power window switch (1) from the rear power switch finisher (2).

○: Pawl

CAUTION:

Do not bend back the pawls on the switch finisher too far or breakage may occur.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC