

## SECTION **SEC** SECURITY CONTROL SYSTEM

### CONTENTS

|  |    |   |    |
|--|----|---|----|
| <b>PRECAUTION</b> .....  | 4  | <b>INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION</b> .....               | 11 |
| <b>PRECAUTIONS</b> .....   | 4  | INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram .....     | 11 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 4  | INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description ..... | 11 |
| Precaution for Work .....  | 4  | <b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b> ...                       | 13 |
| <b>PREPARATION</b> .....   | 5  | NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram .....           | 14 |
| <b>PREPARATION</b> .....   | 5  | NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description .....       | 14 |
| Special Service Tool .....   | 5  | <b>VEHICLE SECURITY SYSTEM</b> .....                                    | 16 |
| <b>SYSTEM DESCRIPTION</b> .....  | 6  | VEHICLE SECURITY SYSTEM : System Diagram .....                          | 16 |
| <b>COMPONENT PARTS</b> .....   | 6  | VEHICLE SECURITY SYSTEM : System Description .....                      | 16 |
| Component Parts Location .....   | 6  | <b>DIAGNOSIS SYSTEM (BCM)</b> .....                                     | 20 |
| Component Description .....  | 8  | <b>COMMON ITEM</b> .....  | 20 |
| CVT Shift Selector (Park Position Switch) .....  | 8  | COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....                | 20 |
| BCM .....  | 8  | <b>INTELLIGENT KEY</b> .....  | 21 |
| ECM .....  | 8  | INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) .....        | 21 |
| IPDM E/R .....   | 9  | <b>THEFT ALM</b> .....  | 24 |
| NATS Antenna Amp. ....   | 9  | THEFT ALM : CONSULT Function (BCM - THEFT ALM) .....                    | 24 |
| TCM .....  | 9  | <b>IMMU</b> .....   | 25 |
| Combination Meter .....  | 9  | IMMU : CONSULT Function (BCM - IMMU) .....                              | 25 |
| Door Switch .....  | 9  | <b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....                                | 26 |
| Outside Key Antenna .....  | 9  | CONSULT Function (IPDM E/R) .....                                       | 26 |
| Hood Switch .....  | 9  | <b>ECU DIAGNOSIS INFORMATION</b> .....                                  | 28 |
| Inside Key Antenna .....   | 9  | <b>ECM, IPDM E/R, BCM</b> .....   | 28 |
| Remote Keyless Entry Receiver .....  | 9  | List of ECU Reference .....   | 28 |
| Intelligent Key .....  | 9  |   |    |
| Push-button Ignition Switch .....  | 10 |   |    |
| Security Indicator Lamp .....  | 10 |   |    |
| Starter Control Relay .....  | 10 |   |    |
| Starter Relay .....  | 10 |   |    |
| Stop Lamp Switch .....   | 10 |   |    |
| Transmission Range Switch .....  | 10 |   |    |
| Vehicle Information Display .....  | 10 |   |    |
| <b>SYSTEM</b> .....  | 11 |   |    |

|   |            |  |            |
|---|------------|--|------------|
| <b>WIRING DIAGRAM .....</b>                                     | <b>29</b>  | <b>B210D STARTER RELAY .....</b>             | <b>82</b>  |
| <b>ENGINE START FUNCTION .....</b>                              | <b>29</b>  | DTC Logic .....                              | 82         |
| Wiring Diagram .....  | 29         | Diagnosis Procedure .....                    | 82         |
| <b>NISSAN VEHICLE IMMOBILIZER SYSTEM-<br/>NATS .....</b>        | <b>42</b>  | <b>B210E STARTER RELAY .....</b>             | <b>84</b>  |
| Wiring Diagram .....  | 42         | DTC Logic .....                              | 84         |
| <b>VEHICLE SECURITY SYSTEM .....</b>                            | <b>52</b>  | Diagnosis Procedure .....                    | 84         |
| Wiring Diagram .....  | 52         | <b>B210F TRANSMISSION RANGE SWITCH .....</b> | <b>86</b>  |
| <b>BASIC INSPECTION .....</b>                                   | <b>65</b>  | Description .....                            | 86         |
| <b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>                     | <b>65</b>  | DTC Logic .....                              | 86         |
| Work Flow .....   | 65         | Diagnosis Procedure .....                    | 86         |
| <b>ADDITIONAL SERVICE WHEN REPLACING<br/>CONTROL UNIT .....</b> | <b>68</b>  | <b>B2110 TRANSMISSION RANGE SWITCH .....</b> | <b>88</b>  |
| <b>ECM .....</b>  | <b>68</b>  | Description .....                            | 88         |
| ECM : Description .....   | 68         | DTC Logic .....                              | 88         |
| ECM : Work Procedure .....                                      | 68         | Diagnosis Procedure .....                    | 88         |
| <b>BCM .....</b>  | <b>68</b>  | <b>B2190 NATS ANTENNA AMP. ....</b>          | <b>90</b>  |
| BCM : Description .....   | 68         | Description .....                            | 90         |
| BCM : Work Procedure .....                                      | 68         | DTC Logic .....                              | 90         |
| <b>DTC/CIRCUIT DIAGNOSIS .....</b>                              | <b>70</b>  | Diagnosis Procedure .....                    | 90         |
| <b>P1610 LOCK MODE .....</b>                                    | <b>70</b>  | <b>B2191 DIFFERENCE OF KEY .....</b>         | <b>92</b>  |
| Description .....   | 70         | Description .....                            | 92         |
| DTC Logic .....   | 70         | DTC Logic .....                              | 92         |
| Diagnosis Procedure .....                                       | 70         | Diagnosis Procedure .....                    | 92         |
| <b>P1611 ID DISCORD, IMMU-ECM .....</b>                         | <b>71</b>  | <b>B2192 ID DISCORD, IMMU-ECM .....</b>      | <b>93</b>  |
| DTC Logic .....   | 71         | DTC Logic .....                              | 93         |
| Diagnosis Procedure .....                                       | 71         | Diagnosis Procedure .....                    | 93         |
| <b>P1612 CHAIN OF ECM-IMMU .....</b>                            | <b>72</b>  | <b>B2193 CHAIN OF ECM-IMMU .....</b>         | <b>94</b>  |
| DTC Logic .....   | 72         | DTC Logic .....                              | 94         |
| Diagnosis Procedure .....                                       | 72         | Diagnosis Procedure .....                    | 94         |
| <b>P1614 CHAIN OF IMMU-KEY .....</b>                            | <b>73</b>  | <b>B2195 ANTI-SCANNING .....</b>             | <b>95</b>  |
| DTC Logic .....   | 73         | DTC Logic .....                              | 95         |
| Diagnosis Procedure .....                                       | 73         | Diagnosis Procedure .....                    | 95         |
| <b>B20A8 IPDM EXTERNAL MALF FOR ST1 .....</b>                   | <b>75</b>  | <b>B2196 DONGLE UNIT .....</b>               | <b>96</b>  |
| DTC Logic .....   | 75         | Description .....                            | 96         |
| Diagnosis Procedure .....                                       | 75         | DTC Logic .....                              | 96         |
| <b>B20A9 IPDM EXTERNAL MALF FOR ST2 .....</b>                   | <b>77</b>  | Diagnosis Procedure .....                    | 96         |
| DTC Logic .....   | 77         | <b>B2198 NATS ANTENNA AMP. ....</b>          | <b>98</b>  |
| Diagnosis Procedure .....                                       | 77         | DTC Logic .....                              | 98         |
| <b>B210B STARTER CONTROL RELAY .....</b>                        | <b>79</b>  | Diagnosis Procedure .....                    | 98         |
| DTC Logic .....   | 79         | <b>B2555 STOP LAMP .....</b>                 | <b>100</b> |
| Diagnosis Procedure .....                                       | 79         | DTC Logic .....                              | 100        |
| <b>B210C STARTER CONTROL RELAY .....</b>                        | <b>80</b>  | Diagnosis Procedure .....                    | 100        |
| DTC Logic .....   | 80         | Component Inspection .....                   | 102        |
| Diagnosis Procedure .....                                       | 80         | <b>B2556 PUSH-BUTTON IGNITION SWITCH ...</b> | <b>103</b> |
| <b>B210D STARTER RELAY .....</b>                                | <b>82</b>  | DTC Logic .....                              | 103        |
| DTC Logic .....   | 82         | Diagnosis Procedure .....                    | 103        |
| Diagnosis Procedure .....                                       | 82         | Component Inspection .....                   | 104        |
| <b>B210E STARTER RELAY .....</b>                                | <b>84</b>  | <b>B2557 VEHICLE SPEED .....</b>             | <b>105</b> |
| DTC Logic .....   | 84         | DTC Logic .....                              | 105        |
| Diagnosis Procedure .....                                       | 84         | Diagnosis Procedure .....                    | 105        |
| <b>B210F TRANSMISSION RANGE SWITCH .....</b>                    | <b>86</b>  |  |            |
| Description .....   | 86         |  |            |
| DTC Logic .....   | 86         |  |            |
| Diagnosis Procedure .....                                       | 86         |  |            |
| <b>B2110 TRANSMISSION RANGE SWITCH .....</b>                    | <b>88</b>  |  |            |
| Description .....   | 88         |  |            |
| DTC Logic .....   | 88         |  |            |
| Diagnosis Procedure .....                                       | 88         |  |            |
| <b>B2190 NATS ANTENNA AMP. ....</b>                             | <b>90</b>  |  |            |
| Description .....   | 90         |  |            |
| DTC Logic .....   | 90         |  |            |
| Diagnosis Procedure .....                                       | 90         |  |            |
| <b>B2191 DIFFERENCE OF KEY .....</b>                            | <b>92</b>  |  |            |
| Description .....   | 92         |  |            |
| DTC Logic .....   | 92         |  |            |
| Diagnosis Procedure .....                                       | 92         |  |            |
| <b>B2192 ID DISCORD, IMMU-ECM .....</b>                         | <b>93</b>  |  |            |
| DTC Logic .....   | 93         |  |            |
| Diagnosis Procedure .....                                       | 93         |  |            |
| <b>B2193 CHAIN OF ECM-IMMU .....</b>                            | <b>94</b>  |  |            |
| DTC Logic .....   | 94         |  |            |
| Diagnosis Procedure .....                                       | 94         |  |            |
| <b>B2195 ANTI-SCANNING .....</b>                                | <b>95</b>  |  |            |
| DTC Logic .....   | 95         |  |            |
| Diagnosis Procedure .....                                       | 95         |  |            |
| <b>B2196 DONGLE UNIT .....</b>                                  | <b>96</b>  |  |            |
| Description .....   | 96         |  |            |
| DTC Logic .....   | 96         |  |            |
| Diagnosis Procedure .....                                       | 96         |  |            |
| <b>B2198 NATS ANTENNA AMP. ....</b>                             | <b>98</b>  |  |            |
| DTC Logic .....   | 98         |  |            |
| Diagnosis Procedure .....                                       | 98         |  |            |
| <b>B2555 STOP LAMP .....</b>                                    | <b>100</b> |  |            |
| DTC Logic .....   | 100        |  |            |
| Diagnosis Procedure .....                                       | 100        |  |            |
| Component Inspection .....                                      | 102        |  |            |
| <b>B2556 PUSH-BUTTON IGNITION SWITCH ...</b>                    | <b>103</b> |  |            |
| DTC Logic .....   | 103        |  |            |
| Diagnosis Procedure .....                                       | 103        |  |            |
| Component Inspection .....                                      | 104        |  |            |
| <b>B2557 VEHICLE SPEED .....</b>                                | <b>105</b> |  |            |
| DTC Logic .....   | 105        |  |            |
| Diagnosis Procedure .....                                       | 105        |  |            |

|  |            |   |            |            |
|--|------------|---|------------|------------|
| <b>B2560 STARTER CONTROL RELAY</b> .....   | <b>106</b> | <b>HEADLAMP FUNCTION</b> .....              | <b>131</b> | <b>A</b>   |
| Description .....                          | 106        | Component Function Check .....              | 131        |            |
| DTC Logic .....                            | 106        | Diagnosis Procedure .....                   | 131        |            |
| Diagnosis Procedure .....                  | 106        |   |            |            |
| <b>B2601 SHIFT POSITION</b> .....          | <b>107</b> | <b>HOOD SWITCH</b> .....                    | <b>132</b> | <b>B</b>   |
| DTC Logic .....                            | 107        | Component Function Check .....              | 132        |            |
| Diagnosis Procedure .....                  | 107        | Diagnosis Procedure .....                   | 132        |            |
| Component Inspection .....                 | 108        | Component Inspection .....                  | 133        | <b>C</b>   |
| <b>B2602 SHIFT POSITION</b> .....          | <b>110</b> | <b>SECURITY INDICATOR LAMP</b> .....        | <b>134</b> |            |
| DTC Logic .....                            | 110        | Component Function Check .....              | 134        | <b>D</b>   |
| Diagnosis Procedure .....                  | 110        | Diagnosis Procedure .....                   | 134        |            |
| Component Inspection .....                 | 111        | <b>SYMPTOM DIAGNOSIS</b> .....              | <b>136</b> |            |
| <b>B2603 SHIFT POSITION</b> .....          | <b>112</b> | <b>INTELLIGENT KEY SYSTEM SYMPTOMS</b> ...  | <b>136</b> | <b>E</b>   |
| DTC Logic .....                            | 112        | Diagnosis Procedure .....                   | 136        |            |
| Diagnosis Procedure .....                  | 112        | <b>ENGINE CAN NOT START</b> .....           | <b>137</b> | <b>F</b>   |
| Component Inspection .....                 | 115        | Description .....                           | 137        |            |
| <b>B2604 SHIFT POSITION</b> .....          | <b>116</b> | Diagnosis Procedure .....                   | 137        |            |
| DTC Logic .....                            | 116        | <b>ENGINE DOES NOT START WHEN INTELLI-</b>  |            | <b>G</b>   |
| Diagnosis Procedure .....                  | 116        | <b>GEN T KEY IS INSIDE OF VEHICLE</b> ..... | <b>138</b> |            |
| <b>B2605 SHIFT POSITION</b> .....          | <b>119</b> | Description .....                           | 138        | <b>H</b>   |
| DTC Logic .....                            | 119        | Diagnosis Procedure .....                   | 138        |            |
| Diagnosis Procedure .....                  | 119        | <b>ENGINE DOES NOT START WHEN INTELLI-</b>  |            | <b>I</b>   |
| <b>B2608 STARTER RELAY</b> .....           | <b>122</b> | <b>GEN T KEY IS INSIDE OF VEHICLE (ONE</b>  |            |            |
| DTC Logic .....                            | 122        | <b>KEY)</b> .....                           | <b>140</b> |            |
| Diagnosis Procedure .....                  | 122        | Description .....                           | 140        | <b>J</b>   |
| <b>B2617 STARTER RELAY CIRCUIT</b> .....   | <b>124</b> | Diagnosis Procedure .....                   | 140        |            |
| Description .....                          | 124        | <b>DOOR DOES NOT LOCK/UNLOCK AND EN-</b>    |            |            |
| DTC Logic .....                            | 124        | <b>GINE DOES NOT START (REQ SW/PUSH</b>     |            |            |
| Diagnosis Procedure .....                  | 124        | <b>SW) (ONE KEY)</b> .....                  | <b>141</b> | <b>SEC</b> |
| <b>B261E VEHICLE TYPE</b> .....            | <b>126</b> | Description .....                           | 141        |            |
| DTC Logic .....                            | 126        | Diagnosis Procedure .....                   | 141        |            |
| Diagnosis Procedure .....                  | 126        | <b>REMOVAL AND INSTALLATION</b> .....       | <b>143</b> | <b>L</b>   |
| <b>B26F4 STARTER CONTROL RELAY</b> .....   | <b>128</b> | <b>NATS ANTENNA AMP.</b> .....              | <b>143</b> |            |
| DTC Logic .....                            | 128        | Exploded View .....                         | 143        | <b>M</b>   |
| Diagnosis Procedure .....                  | 128        | Removal and Installation .....              | 143        |            |
| <b>POWER SUPPLY AND GROUND CIRCUIT</b> ... | <b>129</b> | <b>PUSH BUTTON IGNITION SWITCH</b> .....    | <b>144</b> | <b>N</b>   |
| Diagnosis Procedure .....                  | 129        | Exploded View .....                         | 144        |            |
| <b>POWER SUPPLY AND GROUND CIRCUIT</b> ... | <b>130</b> | Removal and Installation .....              | 144        |            |
| Diagnosis Procedure .....                  | 130        | <b>IMMOBILIZER CONTROL MODULE</b> .....     | <b>145</b> | <b>O</b>   |
|  |            | Removal and Installation .....              | 145        | <b>P</b>   |

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012592365

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:0000000012592366

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:0000000012592367

The actual shape of the tools may differ from those illustrated here.

| Tool number<br>(TechMate No.)<br>Tool name | Description              |
|--|--------------------------|
| —<br>(J-46534)<br>Trim Tool Set            | Removing trim components |



AWJIA0483ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS


#### Component Parts Location

INFOID:0000000012592368



# COMPONENT PARTS

## < SYSTEM DESCRIPTION >



- |   |  |  |
|---|--|--|
| 1. BCM (view with combination meter removed)                                | 2. IPDM E/R  | 3. Combination meter   |
| 4. Security indicator lamp  | 5. Push-button ignition switch   | 6. NATS antenna amp.   |
| 7. Inside key antenna (front console)                                       | 8. Inside key antenna (rear parcel shelf) (view with rear parcel shelf trim removed) | 9. Stop lamp switch  |
| 10. CVT shift selector (park position switch)                               | 11. Outside key antenna (drivers side)   | 12. Outside key antenna (passenger side)                             |
| 13. Outside key antenna (rear bumper) (view with rear bumper cover removed) | 14. Hood switch  | 15. Remote keyless entry receiver (view with upper dash pad removed) |
| 16. Front door switch (LH)  | 17. Front door switch (RH)   | 18. Rear door switch (LH)  |
| 19. Rear door switch (RH)   | 20. Transmission range switch  |  |

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Component Description

INFOID:0000000012592369

| Component                                 | Reference              |
|---|------------------------|
| CVT shift selector (park position switch) | <a href="#">SEC-8</a>  |
| BCM                                       | <a href="#">SEC-8</a>  |
| ECM                                       | <a href="#">SEC-8</a>  |
| IPDM E/R                                  | <a href="#">SEC-9</a>  |
| NATS antenna amp.                         | <a href="#">SEC-9</a>  |
| TCM                                       | <a href="#">SEC-9</a>  |
| Combination meter                         | <a href="#">SEC-9</a>  |
| Door switch                               | <a href="#">SEC-9</a>  |
| Hood switch                               | <a href="#">SEC-9</a>  |
| Outside key antenna                       | <a href="#">SEC-9</a>  |
| Inside key antenna                        | <a href="#">SEC-9</a>  |
| Intelligent Key                           | <a href="#">SEC-9</a>  |
| Push-button ignition switch               | <a href="#">SEC-10</a> |
| Remote keyless entry receiver             | <a href="#">SEC-9</a>  |
| Security indicator lamp                   | <a href="#">SEC-10</a> |
| Starter control relay                     | <a href="#">SEC-10</a> |
| Starter relay                             | <a href="#">SEC-10</a> |
| Stop lamp switch                          | <a href="#">SEC-10</a> |
| Transmission range switch                 | <a href="#">SEC-10</a> |
| Vehicle information display               | <a href="#">SEC-10</a> |

#### CVT Shift Selector (Park Position Switch)

INFOID:0000000012592370

Park position switch detects that CVT shift selector is in the P (Park) position and then transmits the signal to BCM and IPDM E/R.

BCM confirms the CVT shift selector position with the following 5 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P (Park) position signal from IPDM E/R (CAN).
- P/N position signal from IPDM E/R (CAN).
- P/N position signal from TCM (CAN).

IPDM E/R confirms the CVT shift selector position with the following 3 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P/N position signal from BCM (CAN).

#### BCM

INFOID:0000000012592371

BCM controls INTELLIGENT KEY SYSTEM (ENGINE START FUNCTION), NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)], and VEHICLE SECURITY SYSTEM.

BCM performs the ID verification between BCM and Intelligent Key when the Intelligent Key is carried into the detection area of inside key antenna and push-button ignition switch is pressed. If the ID verification result is OK, push-button ignition switch operation is available.

Then, when the power supply position is turned ON, BCM performs ID verification between BCM and ECM. If the ID verification result is OK, ECM can start engine.

#### ECM

INFOID:0000000012592372

ECM controls the engine.

When power supply position is turned ON, BCM starts communication with ECM and performs the ID verification between BCM and ECM.



## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

If the verification result is OK, the engine can start. If the verification result is NG, the engine can not start.

#### IPDM E/R

INFOID:0000000012592373

IPDM E/R has the starter relay and starter control relay inside. Starter relay and starter control relay are used for the engine starting function. IPDM E/R controls these relays while communicating with BCM.

#### NATS Antenna Amp.

INFOID:0000000012592374

The ID verification is performed between BCM and transponder in Intelligent Key via NATS antenna amp. when Intelligent Key backside is contacted to push-button ignition switch in case that Intelligent Key battery is discharged. If the ID verification result is OK, the operation of starting engine is available.

#### TCM

INFOID:0000000012592375

TCM transmits the shift position signal (P/N position) to BCM and IPDM E/R. And further, TCM transmits the shift position signal (P/N position) to BCM via CAN communication.

BCM confirms the CVT shift selector position with the following 5 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P (Park) position signal from IPDM E/R (CAN).
- P/N position signal from IPDM E/R (CAN).
- P/N position signal from TCM (CAN).

IPDM E/R confirms the CVT shift selector position with the following 3 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P/N position signal from BCM (CAN).

#### Combination Meter

INFOID:0000000012592376

Combination meter transmits the vehicle speed signal to BCM via CAN communication.

BCM also receives the vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication. BCM compares both signals to detect the vehicle speed.

#### Door Switch

INFOID:0000000012592377

Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.

#### Outside Key Antenna

INFOID:0000000012592378

Outside key antenna detects whether Intelligent Key is outside the vehicle and transmits the signal to BCM. Three outside key antennas are installed in the front outside handle LH, front outside handle RH and rear bumper.

#### Hood Switch

INFOID:0000000012592379

Hood switch detects that hood is open/closed, and then transmits the signal to IPDM E/R. IPDM E/R transmits hood switch signal to BCM via CAN communication.

#### Inside Key Antenna

INFOID:0000000012592380

Inside key antenna detects whether Intelligent Key is inside the vehicle and transmits the signal to BCM.

Two inside key antennas are installed in the front console and rear parcel shelf.

#### Remote Keyless Entry Receiver

INFOID:0000000012592381

Remote keyless entry receiver receives each button operation signal and electronic key ID signal from Intelligent Key and then transmits the signal to BCM.

#### Intelligent Key

INFOID:0000000012592382

Each Intelligent Key has an individual electronic ID and transmits the ID signal by request from BCM.

Carrying the Intelligent Key whose ID is registered in BCM, the driver can perform, remote start, door lock/unlock operation, remote trunk, panic alarm and push-button ignition switch operation.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

---

#### Push-button Ignition Switch

INFOID:0000000012592383

Push-button ignition switch detects that push-button is pressed and then transmits the signal to BCM. BCM changes the power supply position with the operation of push-button ignition switch. BCM maintains the power supply position status while push-button is not operated.

#### Security Indicator Lamp

INFOID:0000000012592384

Security indicator lamp is located on combination meter.

Security indicator lamp blinks when power supply position is any position other than ON to warn that NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] is on board.

#### Starter Control Relay

INFOID:0000000012592385

Engine starting system functions by controlling both starter relay and starter control relay.

Both relays are integrated in IPDM E/R. Starter relay is controlled by BCM and starter control relay is controlled by IPDM E/R on request from BCM.

IPDM E/R transmits starter relay and starter control relay status signal to BCM via CAN communication.

#### Starter Relay

INFOID:0000000012592386

Engine starting system functions by controlling both starter relay and starter control relay.

Both relays are integrated in IPDM E/R. Starter relay is controlled by BCM, and starter control relay is controlled by IPDM E/R on request from BCM.

IPDM E/R transmits starter relay and starter control relay status signal to BCM via CAN communication.

#### Stop Lamp Switch

INFOID:0000000012592387

Stop lamp switch detects that brake pedal is depressed, and then transmits the signal to BCM.

#### Transmission Range Switch

INFOID:0000000012592388

Transmission range switch is integrated in CVT assembly, and detects the CVT shift selector position.

TCM receives the transmission range switch signal and then transmits the P/N position signal to BCM and IPDM E/R.

BCM confirms the CVT shift selector position with the following 5 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P (Park) position signal from IPDM E/R (CAN).
- P/N position signal from IPDM E/R (CAN).
- P/N position signal from TCM (CAN).

IPDM E/R confirms the CVT shift selector position with the following 3 signals:

- P (Park) position signal from CVT shift selector (park position switch).
- P/N position signal from TCM.
- P/N position signal from BCM (CAN).

#### Vehicle Information Display

INFOID:0000000012592389

Vehicle information display is integrated in combination meter.

Various information and warnings regarding the Intelligent Key System are displayed.

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram

INFOID:0000000012592390



### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description

INFOID:0000000012592391

#### SYSTEM DESCRIPTION

- The engine start function of Intelligent Key system makes it possible to start and stop the engine without using the key, based on the electronic ID verification. The electronic ID verification is performed between BCM and Intelligent Key when the push-button ignition switch is pressed while the Intelligent Key is within the detection area of inside key antenna.

#### NOTE:

The driver should carry the Intelligent Key at all times.

- Intelligent Key has 2 IDs [Intelligent Key ID and NVIS (NATS) ID]. It can perform the door lock/unlock operation and the push-button ignition switch operation when the registered Intelligent Key is carried.
- When Intelligent Key battery is discharged, engine can be started by operating push-button ignition switch after contacting Intelligent Key backside to push-button ignition switch. At that time, the NVIS (NATS) ID verification is performed.
- If the ID is successfully verified, when push-button ignition switch is pressed, the engine can be started.
- Up to 4 Intelligent Keys can be registered (Including the standard Intelligent Key) upon request from the customer.

# SYSTEM

## < SYSTEM DESCRIPTION >

- For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

### NOTE:

Refer to [SEC-14. "NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description"](#) for any functions other than engine start function of Intelligent Key system.

## PRECAUTIONS FOR INTELLIGENT KEY SYSTEM

**The transponder [the chip for NVIS (NATS) ID verification] is integrated into the Intelligent Key. In that case, the NVIS (NATS) ID verification can be performed when Intelligent Key backside is contacted to push-button ignition switch. If verification result is OK, engine can be started.**

## OPERATION WHEN INTELLIGENT KEY IS CARRIED

- When the push-button ignition switch is pressed, the BCM activates the inside key antenna and transmits the request signal to the Intelligent Key.
- The Intelligent Key receives the request signal and transmits the Intelligent Key ID signal to the BCM.
- BCM receives the Intelligent Key ID signal via remote keyless entry receiver and verifies it with the registered ID.
- BCM turns ACC relay ON and transmits the ignition power supply ON signal to IPDM E/R.
- IPDM E/R turns the ignition relay ON and starts the ignition power supply.
- BCM detects that the selector lever position and brake pedal operating condition.
- BCM transmits the starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
- IPDM E/R turns the starter control relay ON when receiving the starter request signal.
- Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.

### CAUTION:

**If a malfunction is detected in the Intelligent Key system, the "KEY" warning lamp in the combination meter illuminates. At that time, the engine cannot be started.**

- When BCM receives feedback signal from ECM indicating that the engine is started, the BCM transmits a stop signal to IPDM E/R and stops cranking by turning OFF the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

### CAUTION:

**When the Intelligent Key is carried outside of the vehicle (inside key antenna detection area) while the power supply is in the ACC or ON position, even if the engine start condition\* is satisfied, the engine cannot be started.**

\*: For the engine start condition, refer to the table below "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION":

## OPERATION RANGE

Engine can be started when Intelligent Key is inside the vehicle. However, sometimes engine may not start when Intelligent Key is on instrument panel or in glove box.

## ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

When Intelligent Key battery is discharged, the NVIS (NATS) ID verification between transponder in Intelligent Key and BCM is performed when Intelligent Key backside is contacted to push-button ignition switch. If the verification result is OK, engine can be started.

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below:
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

# SYSTEM

## < SYSTEM DESCRIPTION >

| Power supply position                     | Engine start/stop condition |                                 | Push-button ignition switch operation frequency |
|---|-----------------------------|---------------------------------|---|
|   | Selector lever              | Brake pedal operation condition |   |
| LOCK → ACC                                | —                           | Not depressed                   | 1   |
| LOCK → ACC → ON                           | —                           | Not depressed                   | 2   |
| LOCK → ACC → ON → OFF                     | —                           | Not depressed                   | 3   |
| LOCK → START<br>ACC → START<br>ON → START | P or N position             | Depressed                       | 1   |
| Engine is running → OFF                   | —                           | —                               | 1   |

Vehicle speed: 4 km/h (2.5 MPH) or more

| Power supply position                       | Engine start/stop condition |                                 | Push-button ignition switch operation frequency |
|---|-----------------------------|---------------------------------|---|
|   | Selector lever              | Brake pedal operation condition |   |
| Engine is running → ACC                     | —                           | —                               | Emergency stop operation                        |
| Engine stall return operation while driving | N position                  | Not depressed                   | 1   |

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


SEC

# SYSTEM

< SYSTEM DESCRIPTION >

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram

INFOID:000000012592392



## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description

INFOID:000000012592393

### SYSTEM DESCRIPTION

- The NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] prevents the engine from being started by Intelligent Key whose ID is not registered to the vehicle (BCM). It has higher protection against auto theft involving the duplication of mechanical keys.
- The ignition key integrated in the Intelligent Key cannot start the engine. When the Intelligent Key battery is discharged, the NVIS (NATS) ID verification is performed between the transponder integrated with Intelligent Key and BCM via NATS antenna amp. when the Intelligent Key backside is contacted to push-button ignition switch. If the verification results are OK, the engine start operation can be performed by the push-button ignition switch operation.
- Locate the security indicator lamp and apply the anti-theft system equipment sticker that warns that the NVIS (NATS) is on-board the model.
- Security indicator lamp always blinks when the power supply position is any position other than ON.
- Up to 4 Intelligent Keys can be registered (including the standard ignition key) upon request from the owner.
- Specified registration is required when replacing ECM, BCM or Intelligent Key.
- For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.
- Possible symptom of NVIS (NATS) malfunction is "Engine cannot start". The engine can not be started because of other than NVIS (NATS) malfunction, so start the trouble diagnosis according to [SEC-65. "Work Flow"](#).

# SYSTEM

## < SYSTEM DESCRIPTION >

- If ECM other than genuine part is installed, the engine cannot be started. For ECM replacement procedure, refer to [EC-577, "Removal and Installation"](#) (QR25DE) or [EC-1088, "Removal and Installation"](#) (VQ35DE).

## PRECAUTIONS FOR KEY REGISTRATION

- The ID registration is a procedure that erases the current NVIS (NATS) ID once, and then reregisters a new ID. Therefore before starting the registration operation, collect all registered Intelligent Keys from the customer.
- When registering the Intelligent Key, perform only one procedure to simultaneously register both ID [NVIS (NATS) ID and Intelligent Key ID].

## SECURITY INDICATOR LAMP

- Warns that the vehicle is equipped with NVIS (NATS).
- Security indicator lamp always blinks when the power supply position is any position other than ON.

### NOTE:

Because security indicator lamp is highly efficient, the battery is barely affected.

## ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

1. When brake pedal is depressed while selector lever is in the P (Park) position, BCM activates NATS antenna amp. that is located behind push-button ignition switch.
2. When Intelligent Key (transponder built-in) backside is contacted to push-button ignition switch, BCM starts NVIS (NATS) ID verification between BCM and Intelligent Key (transponder built-in) via NATS antenna amp.
3. When the NVIS (NATS) ID verification result is OK, buzzer in combination meter sounds and BCM transmits the result to ECM.
4. BCM turns ACC relay ON and transmits ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position is P (Park) or N (Neutral).
7. BCM transmits starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.
10. When BCM receives feedback signal from ECM indicating that the engine is started, BCM transmits a stop signal to IPDM E/R and stops cranking by turning off the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

\*: For the engine start condition, refer to the table "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION" below.

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations:

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below:
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

| Power supply position | Engine start/stop condition |                                 | Push-button ignition switch operation frequency |
|-----------------------|-----------------------------|---------------------------------|---|
|                       | Selector lever              | Brake pedal operation condition |   |
| LOCK → ACC            | —                           | Not depressed                   | 1   |
| LOCK → ACC → ON       | —                           | Not depressed                   | 2   |
| LOCK → ACC → ON → OFF | —                           | Not depressed                   | 3   |

# SYSTEM

## < SYSTEM DESCRIPTION >

| Power supply position                     | Engine start/stop condition      |                                 | Push-button ignition switch operation frequency |
|---|----------------------------------|---------------------------------|---|
|   | Selector lever                   | Brake pedal operation condition |   |
| LOCK → START<br>ACC → START<br>ON → START | P (Park) or N (Neutral) position | Depressed                       | 1   |
| Engine is running → OFF                   | —                                | —                               | 1   |

Vehicle speed: 4 km/h (2.5 MPH) or more

| Power supply position                       | Engine start/stop condition |                                 | Push-button ignition switch operation frequency |
|---|-----------------------------|---------------------------------|---|
|   | Selector lever              | Brake pedal operation condition |   |
| Engine is running → ACC                     | —                           | —                               | Emergency stop operation                        |
| Engine stall return operation while driving | N (Neutral) position        | Not depressed                   | 1   |


Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## VEHICLE SECURITY SYSTEM

### VEHICLE SECURITY SYSTEM : System Diagram

INFOID:0000000012592394



ALKIA3629GB

### VEHICLE SECURITY SYSTEM : System Description

INFOID:0000000012592395

- The vehicle security system has two alarm functions (theft warning alarm and panic alarm) and reduces the possibility of a theft or mischief by activating horns and headlamps intermittently.



# SYSTEM

## < SYSTEM DESCRIPTION >


- The panic alarm does not start when the theft warning alarm is activating and the panic alarm stops when the theft warning alarm is activated.
- The priority of the functions are as per the following:

| Priority | Function            |
|----------|---------------------|
| 1        | Theft warning alarm |
| 2        | Panic alarm         |

## THEFT WARNING ALARM

- The theft warning alarm function activates horns and headlamps intermittently when BCM detects that any door or hood is opened by unauthorized means while the system is in the ARMED state.
- Security indicator lamp on combination meter always blinks when power supply position is any position other than ON. Security indicator lamp blinking warns that the vehicle is equipped with a vehicle security system.

### Operation Flow



| No. | System state           | Switching condition  |  |   |
|-----|------------------------|--|--|---|
| 1   | DISARMED to PRE-ARMED  | When all conditions of A and one condition of B is satisfied.      | A  | B   |
|     |                        |  | <ul style="list-style-type: none"><li>Power supply position: OFF/LOCK</li><li>All doors: Closed</li><li>Hood: Closed</li></ul> | All doors are locked by: <ul style="list-style-type: none"><li>Door key cylinder LOCK switch</li><li>LOCK button of Intelligent Key</li><li>Door request switch (if equipped)</li></ul> |
| 2   | PRE-ARMED to ARMED     | When all of the following conditions are satisfied for 30 seconds. | <ul style="list-style-type: none"><li>Power supply position: OFF/LOCK</li><li>All doors: Locked</li><li>Hood: Closed</li></ul> |   |
| 3   | ARMED to ALARM         | When one condition of A and one condition of B are satisfied.      | A  | B   |
|     |                        |  | Intelligent Key: Not used  | <ul style="list-style-type: none"><li>Any door: Open</li><li>Hood: Open</li></ul>   |
| 4   | DISARMED to PRE-RESET  | When all conditions of A and one condition of B is satisfied.      | A  | B   |
|     |                        |  | <ul style="list-style-type: none"><li>Power supply position: OFF/LOCK</li><li>All doors: Closed</li><li>Hood: Open</li></ul>   | All doors are locked by: <ul style="list-style-type: none"><li>Door key cylinder LOCK switch</li><li>LOCK button of Intelligent Key</li><li>Door request switch (if equipped)</li></ul> |
| 5   | PRE-ARMED to PRE-RESET | When one of the following conditions is satisfied.                 | <ul style="list-style-type: none"><li>Hood: Open</li></ul>   |   |
| 6   | ARMED to PRE-RESET     | No conditions.   |  |   |
| 7   | ALARM to PRE-RESET     |  |  |   |

# SYSTEM

## < SYSTEM DESCRIPTION >

| No. | System state           | Switching condition  |  |
|-----|------------------------|--|--|
| 8   | PRE-RESET to DISARMED  | When one of the following conditions is satisfied.                                       | <ul style="list-style-type: none"> <li>Power supply position: ACC/ON/CRANKING/RUN</li> <li>Door key cylinder UNLOCK switch: ON</li> <li>UNLOCK button of Intelligent Key: ON</li> <li>Door request switch (if equipped): ON</li> <li>UNLOCK switch of door lock and unlock switch: ON</li> <li>Any door: Open</li> </ul> |
| 9   | PRE-RESET to PRE-ARMED | When all of the following conditions are satisfied.                                      | <ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Closed</li> </ul>   |
| 10  | PRE-ARMED to DISARMED  | When one of the following conditions is satisfied.                                       | <ul style="list-style-type: none"> <li>Power supply position: ACC/ON/CRANKING/RUN</li> <li>Door key cylinder UNLOCK switch: ON</li> <li>UNLOCK button of Intelligent Key: ON</li> <li>TRUNK button of Intelligent Key: ON</li> <li>Door request switch (if equipped): ON</li> <li>Any door: Open</li> </ul>              |
| 11  | ARMED to DISARMED      | When one of the following conditions is satisfied.                                       | <ul style="list-style-type: none"> <li>Power supply position: ACC/ON/CRANKING/RUN</li> <li>Door key cylinder UNLOCK switch: ON</li> <li>UNLOCK button of Intelligent Key: ON</li> <li>TRUNK button of Intelligent Key: ON</li> <li>Door request switch (if equipped): ON</li> </ul>                                      |
| 12  | ALARM to DISARMED      |  |  |
| 13  | RE-ALARM               | When one of the following conditions is satisfied after the ALARM operation is finished. | <ul style="list-style-type: none"> <li>Any door: Open</li> <li>Hood: Open</li> </ul>   |

### NOTE:

- BCM ignores the door key cylinder UNLOCK switch signal input for 1 second after the door key cylinder LOCK switch signal input.
- To lock/unlock all doors by operating remote controller button of Intelligent Key or door request switch (if equipped), Intelligent Key must be within the detection area of outside key antenna. For details, refer to [DLK-21, "System Description"](#).
- To open trunk by operating trunk opener switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [DLK-41, "System Description"](#).

### DISARMED Phase

The vehicle security system is not set in the DISARMED phase. The vehicle security system stays in this phase while any door is open because it is assumed that the owner is inside or nearby the vehicle. Security indicator lamp blinks every 2.4 seconds.

When the vehicle security system is reset, each phase switches to the DISARMED phase directly.

### PRE-ARMED Phase

The PRE-ARMED phase is the transient state between the DISARMED phase and the ARMED phase. This phase is maintained for 30 seconds so that the owner can reset the setting due to a mis-operation. This phase switches to the ARMED phase when vehicle conditions are not changed for 30 seconds. Security indicator lamp illuminates while being in this phase.

To reset the PRE-ARMED phase, refer to the switching condition of No. 10 in the table above.

### ARMED Phase

The vehicle security system is set and BCM monitors all necessary inputs. If any door or hood is opened without using Intelligent Key, vehicle security system switches to the ALARM phase. Security indicator lamp blinks every 2.4 seconds.

To reset the ARMED phase, refer to the switching condition of No. 11 in the table above.

### ALARM Phase

BCM transmits "Theft Warning Horn Request" signal and "High Beam Request" signal intermittently to IPDM E/R via CAN communication. In this phase, horns and headlamps are activated intermittently for approximately 50 seconds to warn that the vehicle is accessed by unauthorized means. ON/OFF timing of horns and headlamps are synchronized. After 50 seconds, the vehicle security system returns to the ARMED phase. At this time, if BCM still detects unauthorized access to the vehicle, the system is switched to the ALARM phase again. This RE-ALARM operation is carried out a maximum of 2 times.

To cancel the ALARM operation, refer to the switching condition of No. 12 in the table above.

### NOTE:

If a battery terminal is disconnected during the ALARM phase, theft warning alarm stops. But when the battery terminal is reconnected, theft warning alarm is activated again.

< SYSTEM DESCRIPTION >

PRE-RESET Phase

The PRE-RESET phase is the transient state between each phase and DISARMED phase. If only the condition of hood is not satisfied, the system switches to the PRE-RESET phase. Then, when any condition is changed, the system switches to the DISARMED phase or PRE-ARMED phase.

PANIC ALARM

- The panic alarm function activates horns and headlamps intermittently when the owner presses the PANIC ALARM button of Intelligent Key outside the vehicle while the power supply position is OFF or LOCK.
- When BCM receives panic alarm signal from Intelligent Key, BCM transmits “Theft Warning Horn Request” signal and “High Beam Request” signal intermittently to IPDM E/R via CAN communication. To prevent the activation due to mis-operation of Intelligent Key by owner, the panic alarm function is activated when BCM receives the signal for 0.4 - 0.6 seconds.
- Panic alarm operation is maintained for 25 seconds.
- Panic alarm operation is cancelled when BCM receives one of the following signals:
  - LOCK button of Intelligent Key: ON
  - UNLOCK button of Intelligent Key: ON
  - PANIC ALARM button of Intelligent Key: Long pressed
  - Any door request switch (if equipped): ON

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

## DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

### DIAGNOSIS SYSTEM (BCM)

#### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000012827062

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description  |
|------------------------|--|
| ECU Identification     | The BCM part number is displayed.  |
| Self Diagnostic Result | The BCM self diagnostic results are displayed.   |
| Data Monitor           | The BCM input/output data is displayed in real time.   |
| Active Test            | The BCM activates outputs to test components.  |
| Work support           | The settings for BCM functions can be changed.   |
| Configuration          | <ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul> |
| CAN Diag Support Mntr  | The result of transmit/receive diagnosis of CAN communication is displayed.  |

#### SYSTEM APPLICATION

BCM can perform the following functions.

| System                               | Sub System      | Direct Diagnostic Mode |                        |              |             |              |               |                       |
|--------------------------------------|-----------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
|                                      |                 | ECU Identification     | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock                            | DOOR LOCK       |                        | ×                      | ×            | ×           | ×            |               |                       |
| Rear window defogger                 | REAR DEFOGGER   |                        |                        | ×            | ×           | ×            |               |                       |
| Warning chime                        | BUZZER          |                        |                        | ×            | ×           |              |               |                       |
| Interior room lamp timer             | INT LAMP        |                        |                        | ×            | ×           | ×            |               |                       |
| Exterior lamp                        | HEADLAMP        |                        |                        | ×            | ×           | ×            |               |                       |
| Wiper and washer                     | WIPER           |                        |                        | ×            | ×           | ×            |               |                       |
| Turn signal and hazard warning lamps | FLASHER         |                        |                        | ×            | ×           | ×            |               |                       |
| Air conditioner                      | AIR CONDITIONER |                        |                        | ×            |             |              |               |                       |
| Intelligent Key system               | INTELLIGENT KEY |                        | ×                      | ×            | ×           | ×            |               |                       |
| Combination switch                   | COMB SW         |                        |                        | ×            |             |              |               |                       |
| BCM                                  | BCM             | ×                      | ×                      |              |             | ×            | ×             | ×                     |
| Immobilizer                          | IMMU            |                        | ×                      | ×            | ×           |              |               |                       |
| Interior room lamp battery saver     | BATTERY SAVER   |                        |                        | ×            | ×           |              |               |                       |
| Trunk open                           | TRUNK           |                        |                        | ×            |             |              |               |                       |
| Vehicle security system              | THEFT ALM       |                        |                        | ×            | ×           | ×            |               |                       |
| RAP system                           | RETAINED PWR    |                        |                        | ×            |             |              |               |                       |

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

| System               | Sub System           | Direct Diagnostic Mode |                        |              |             |              |               |                       |
|----------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
|                      |                      | ECU Identification     | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Signal buffer system | SIGNAL BUFFER        |                        |                        | ×            | ×           |              |               |                       |
| TPMS                 | AIR PRESSURE MONITOR |                        | ×                      | ×            | ×           |              |               |                       |

## INTELLIGENT KEY

### INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000012827063

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

## SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

## DATA MONITOR

| Monitor Item [Unit]                 | Main | Description  |
|-------------------------------------|------|--|
| REQ SW -DR [On/Off]                 | ×    | Indicates condition of door request switch LH.   |
| REQ SW -AS [On/Off]                 | ×    | Indicates condition of door request switch RH.   |
| REQ SW -BD/TR [On/Off]              | ×    | Indicates condition of trunk opener request switch.  |
| PUSH SW [On/Off]                    |      | Indicates condition of push-button ignition switch.  |
| SHFTLCK SLNID PER SPLY [On/Off]     | ×    | Indicates condition of power supply to shift lock solenoid.  |
| BRAKE SW 1 [On/Off]                 | ×    | Indicates condition of brake switch.   |
| BRAKE SW 2 [On/Off]                 |      | Indicates condition of brake switch.   |
| DETE/CANCL SW [On/Off]              | ×    | Indicates condition of P (park) position.  |
| SFT PN/N SW [On/Off]                | ×    | Indicates condition of P (park) or N (neutral) position.   |
| UNLK SEN -DR [On/Off]               | ×    | Indicates condition of door unlock sensor.   |
| PUSH SW -IPDM [On/Off]              |      | Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.   |
| IGN RLY1 -F/B [On/Off]              |      | Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.              |
| DETE SW -IPDM [On/Off]              |      | Indicates condition of detent switch received from TCM on CAN communication line.                      |
| SFT PN -IPDM [On/Off]               |      | Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.            |
| SFT P -MET [On/Off]                 |      | Indicates condition of P (park) position from TCM on CAN communication line.                           |
| SFT N -MET [On/Off]                 |      | Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.                   |
| ENGINE STATE [STOP/START/CRANK/RUN] | ×    | Indicates condition of engine state from ECM on CAN communication line.                                |
| VEH SPEED 1 [mph/km/h]              | ×    | Indicates condition of vehicle speed signal received from ABS on CAN communication line.               |
| VEH SPEED 2 [mph/km/h]              | ×    | Indicates condition of vehicle speed signal received from combination meter on CAN communication line. |

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

| Monitor Item [Unit]             | Main | Description  |
|---------------------------------|------|--|
| DOOR STAT -DR [LOCK/READY/UNLK] | ×    | Indicates condition of driver side door status.  |
| DOOR STAT -AS [LOCK/READY/UNLK] | ×    | Indicates condition of passenger side door status.   |
| DOOR STAT -RR [LOCK/READY/UNLK] | ×    | Indicates condition of rear right side door status.  |
| DOOR STAT -RL [LOCK/READY/UNLK] | ×    | Indicates condition of rear left side door status.   |
| ID OK FLAG [Set/Reset]          |      | Indicates condition of Intelligent Key ID.   |
| PRMT ENG STRT [Set/Reset]       |      | Indicates condition of engine start possibility.   |
| PRMT RKE STRT [Set/Reset]       |      | Indicates condition of engine start possibility from Intelligent Key.  |
| I-KEY OK FLAG [Key ON/Key OFF]  | ×    | Indicates condition of Intelligent Key OK flag.  |
| PRBT ENG STRT [Set/Reset]       |      | Indicates condition of engine start prohibit.  |
| ID AUTHENT CANCEL TIMER [STOP]  |      | Indicates condition of Intelligent Key ID authentication.  |
| ACC BATTERY SAVER [STOP]        |      | Indicates condition of battery saver.  |
| CRNK PRBT TMR [On/Off]          |      | Indicates condition of crank prohibit timer.   |
| AUT CRNK TMR [On/Off]           |      | Indicates condition of automatic engine crank timer from Intelligent Key.  |
| CRNK PRBT TME [sec]             |      | Indicates condition of engine crank prohibit time.   |
| AUT CRNK TME [sec]              |      | Indicates condition of automatic engine crank time from Intelligent Key.   |
| CRANKING TME [sec]              |      | Indicates condition of engine cranking time from Intelligent Key.  |
| ST RLY -REQ [On/Off]            |      | Indicates condition of starter relay.  |
| IGN RLY 1 -REQ [On/Off]         |      | Indicates condition of ignition 1 relay.   |
| IGN RLY 2 -REQ [On/Off]         |      | Indicates condition of ignition 2 relay.   |
| DETE SW PWR [On/Off]            |      | Indicates condition of detent switch voltage.  |
| ACC RLY -REQ [On/Off]           |      | Indicates condition of accessory relay control request.  |
| RKE OPE COUN1 [0-19]            | ×    | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| RKE OPE COUN2 [0-19]            | ×    | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| TRNK/HAT MNTR [On/Off]          |      | Indicates condition of trunk room lamp switch.   |
| RKE-LOCK [On/Off]               |      | Indicates condition of lock signal from Intelligent Key.   |
| RKE-UNLOCK [On/Off]             |      | Indicates condition of unlock signal from Intelligent Key.   |
| RKE-TR/BD [On/Off]              |      | Indicates condition of trunk open signal from Intelligent Key.   |
| RKE-PANIC [On/Off]              |      | Indicates condition of panic signal from Intelligent Key.  |
| RKE-MODE CHG [On/Off]           |      | Indicates condition of mode change signal from Intelligent Key.  |

## ACTIVE TEST

| Test Item                  | Description  |
|----------------------------|--|
| INTELLIGENT KEY LINK (CAN) | This test is able to check Intelligent Key identification number [Off/ID No1/ID No2/ID No3/ID No4/ID No5]. |
| INT LAMP                   | This test is able to check interior room lamp operation [On/Off].  |
| FLASHER                    | This test is able to check hazard lamp operation [LH/RH/Off].  |
| HORN                       | This test is able to check horn operation [On].  |
| BATTERY SAVER              | This test is able to check battery saver operation [On/Off].   |
| TRUNK/BACK DOOR            | This test is able to check trunk actuator operation [Open].  |
| OUTSIDE BUZZER             | This test is able to check Intelligent Key warning buzzer operation [On/Off].                              |
| INSIDE BUZZER              | This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].              |
| INDICATOR                  | This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].                  |
| IGN CONT2                  | This test is able to check ignition relay-2 control operation [On/Off].                                    |

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

| Test Item               | Description  |
|-------------------------|--|
| ENGINE SW ILLUMI        | This test is able to check push-button ignition switch START indicator operation [On/Off]. |
| PUSH SWITCH INDICATOR   | This test is able to check push-button ignition switch indicator operation [On/Off].       |
| ACC CONT                | This test is able to check accessory relay control operation [On/Off].                     |
| IGN CONT1               | This test is able to check ignition relay-1 control operation [On/Off].                    |
| ST CONT LOW             | This test is able to check starter control relay operation [On/Off].                       |
| IGNITION RELAY          | This test is able to ignition relay operation [On/Off].                                    |
| REVERSE LAMP TEST       | This test is able to check reverse lamp illumination operation [On/Off].                   |
| DR SEAT LAMP TEST       | This test is able to check driver seat lamp illumination operation [On/Off].               |
| AS SEAT LAMP TEST       | This test is able to check passenger seat lamp illumination operation [On/Off].            |
| SHIFT SPOT LAMP TEST    | This test is able to check shift spot lamp illumination operation [On/Off].                |
| TRUNK/LUGGAGE LAMP TEST | This test is able to check cargo lamp illumination operation [On/Off].                     |
| KEYFOB PW TEST          | This test is able to check power window operation using the Intelligent Key [Off/DOWN/UP]. |
| SHIFTLOCK SOLENOID TEST | This test is able to check shift lock solenoid operation [On/Off].                         |

## WORK SUPPORT

| Support Item                   | Setting | Description   |
|--------------------------------|---------|---|
| IGN/ACC BATTERY SAVER          | On*     | Battery saver function ON.  |
|                                | Off     | Battery saver function OFF.   |
| REMOTE ENGINE STARTER          | On*     | Remote engine start function ON.  |
|                                | Off     | Remote engine start function OFF.   |
| ANSWER BACK I-KEY LOCK UNLOCK  | BUZZER  | Buzzer reminder function by door lock/unlock request switch ON.                       |
|                                | HORN    | Horn chirp reminder function by door lock request switch ON.                          |
|                                | Off*    | No reminder function by door lock/unlock request switch.                              |
|                                | INVALID | This mode is not used.  |
| ANSWERBACK KEYLESS LOCK UNLOCK | On      | Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.    |
|                                | Off*    | No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key. |
| ANSWER BACK                    | On*     | Horn chirp reminder when doors are locked with Intelligent Key.                       |
|                                | Off     | No horn chirp reminder when doors are locked with Intelligent Key.                    |
| RETRACTABLE MIRROR SET         | On      | Retractable mirror set ON.  |
|                                | Off*    | Retractable mirror set OFF.   |
| CONFIRM KEY FOB ID             | —       | Intelligent Key ID code can check.  |
| LOCK/UNLOCK BY I-KEY           | On*     | Door lock/unlock function from Intelligent Key ON.                                    |
|                                | Off     | Door lock/unlock function from Intelligent Key OFF.                                   |
| ENGINE START BY I-KEY          | On*     | Engine start function from Intelligent Key ON.  |
|                                | Off     | Engine start function from Intelligent Key OFF.                                       |
| TRUNK/GLASS HATCH OPEN         | On*     | Buzzer reminder function by trunk opener request switch ON.                           |
|                                | Off     | Buzzer reminder function by trunk opener request switch OFF.                          |
| INTELLIGENT KEY LINK SET       | On      | Intelligent Key link set ON.  |
|                                | Off*    | Intelligent Key link set OFF.   |
| SHORT CRANKING OUTPUT          | Start   | 70 msec   |
|                                |         | 100 msec  |
|                                |         | 200 msec  |
|                                | End     | —   |

## DIAGNOSIS SYSTEM (BCM)

### < SYSTEM DESCRIPTION >

| Support Item                                 | Setting | Description   |
|--|---------|---|
| INSIDE ANT DIAGNOSIS                         | —       | This function allows inside key antenna self-diagnosis. |
| AUTO LOCK SET                                | MODE7   | 5 min   |
|  | MODE6   | 4 min   |
|  | MODE5   | 3 min   |
|  | MODE4   | 2 min   |
|  | MODE3*  | 1 min   |
|  | MODE2   | 30 sec  |
|  | MODE1   | Off   |
| Auto door lock time can be set in this mode. |         |   |

\*: Initial Setting

## THEFT ALM

### THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:0000000012827064

#### CAUTION:

**After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.**

## DATA MONITOR

| Monitored Item         | Description  |
|------------------------|--|
| REQ SW -DR [On/Off]    | Indicates condition of door request switch LH.                         |
| REQ SW -AS [On/Off]    | Indicates condition of door request switch RH.                         |
| REQ SW -BD/TR [ON/OFF] | Indicates condition of trunk opener request switch.                    |
| PUSH SW [On/Off]       | Indicates condition of push-button ignition switch.                    |
| UNLK SEN -DR [On/Off]  | Indicates condition of door unlock sensor.                             |
| DOOR SW-DR [On/Off]    | Indicates condition of front door switch LH.                           |
| DOOR SW-AS [On/Off]    | Indicates condition of front door switch RH.                           |
| DOOR SW-RR [On/Off]    | Indicates condition of rear door switch RH.                            |
| DOOR SW-RL [On/Off]    | Indicates condition of rear door switch LH.                            |
| DOOR SW-BK [On/Off]    | Indicates condition of trunk switch.                                   |
| CDL LOCK SW [On/Off]   | Indicates condition of lock signal from door lock and unlock switch.   |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch.      |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch.    |
| TR/BD OPEN SW [On/Off] | Indicates condition of trunk opener switch.                            |
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk room lamp switch.                         |
| RKE-LOCK [On/Off]      | Indicates condition of lock signal from Intelligent Key.               |
| RKE-UNLOCK [On/Off]    | Indicates condition of unlock signal from Intelligent Key.             |
| RKE-TR/BD [On/Off]     | Indicates condition of trunk open signal from Intelligent Key.         |

## ACTIVE TEST

| Test Item             | Description  |
|-----------------------|--|
| FLASHER               | This test is able to check turn signal lamp operation [LH/RH/Off].     |
| THEFT IND             | This test is able to check security indicator lamp operation [On/Off]. |
| VEHICLE SECURITY HORN | This test is able to check vehicle security horn operation [On].       |
| HEAD LAMP(HI)         | This test is able to check vehicle security lamp operation [On].       |



## DIAGNOSIS SYSTEM (BCM)

### < SYSTEM DESCRIPTION >

#### WORK SUPPORT

| Support Item       | Setting | Description         |
|--------------------|---------|---------------------|
| SECURITY ALARM SET | On      | Security alarm ON.  |
|                    | Off     | Security alarm OFF. |

#### IMMU

#### IMMU : CONSULT Function (BCM - IMMU)

INFOID:0000000012827065

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

#### SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

#### DATA MONITOR

| Monitor Item [Unit]       | Description  |
|---------------------------|--|
| CONFIRM ID ALL [Yet/DONE] | Switches to DONE when an Intelligent Key is registered.  |
| CONFIRM ID4 [Yet/DONE]    |  |
| CONFIRM ID3 [Yet/DONE]    |  |
| CONFIRM ID2 [Yet/DONE]    |  |
| CONFIRM ID1 [Yet/DONE]    |  |
| NOT REGISTERED            | Indicates [ID OK] when key ID that is registered is received or is not yet received. Indicates {ID-NG] when key ID that is not registered is received. |
| TP 4 [Yet/DONE]           | DONE indicates the number of Intelligent Key ID which has been registered.   |
| TP 3 [Yet/DONE]           |  |
| TP 2 [Yet/DONE]           |  |
| TP 1 [Yet/DONE]           |  |
| PUSH SW [On/Off]          | Indicates condition of push-button ignition switch.  |
| TCU ID [Yet/DONE]         | Indicates condition of telematics control unit.  |

#### ACTIVE TEST

| Test Item | Description   |
|-----------|---|
| THEFT IND | This test is able to check security indicator operation [On/Off]. |

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:0000000012827067

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

| Direct Diagnostic Mode | Description   |
|------------------------|---|
| ECU Identification     | The IPDM E/R part number is displayed.                                      |
| Self Diagnostic Result | The IPDM E/R self diagnostic results are displayed.                         |
| Data Monitor           | The IPDM E/R input/output data is displayed in real time.                   |
| Active Test            | The IPDM E/R activates outputs to test components.                          |
| CAN Diag Support Mntr  | The result of transmit/receive diagnosis of CAN communication is displayed. |

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-21, "DTC Index"](#).

#### DATA MONITOR

| Monitor Item [Unit]           | Main Signals | Description  |
|-------------------------------|--------------|--|
| MOTOR FAN REQ [1/2/3/4]       | ×            | Indicates cooling fan speed signal received from ECM on CAN communication line       |
| AC COMP REQ [On/Off]          | ×            | Indicates A/C compressor request signal received from ECM on CAN communication line  |
| TAIL&CLR REQ [On/Off]         | ×            | Indicates position light request signal received from BCM on CAN communication line  |
| HL LO REQ [On/Off]            | ×            | Indicates low beam request signal received from BCM on CAN communication line        |
| HL HI REQ [On/Off]            | ×            | Indicates high beam request signal received from BCM on CAN communication line       |
| FR FOG REQ [On/Off]           | ×            | Indicates front fog light request signal received from BCM on CAN communication line |
| FR WIP REQ [Stop/1LOW/Low/Hi] | ×            | Indicates front wiper request signal received from BCM on CAN communication line     |
| WIP AUTO STOP [STOP P/ACT P]  | ×            | Indicates condition of front wiper auto stop signal                                  |
| WIP PROT [Off/BLOCK]          | ×            | Indicates condition of front wiper fail-safe operation                               |
| IGN RLY1 -REQ [On/Off]        |              | Indicates ignition switch ON signal received from BCM on CAN communication line      |
| IGN RLY [On/Off]              | ×            | Indicates condition of ignition relay  |
| PUSH SW [On/Off]              |              | Indicates condition of push-button ignition switch                                   |
| INTER/NP SW [On/Off]          |              | Indicates condition of CVT shift position  |
| ST RLY CONT [On/Off]          |              | Indicates starter relay status signal received from BCM on CAN communication line    |
| IHBT RLY -REQ [On/Off]        |              | Indicates starter control relay signal received from BCM on CAN communication line   |

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

| Monitor Item [Unit]       | Main Signals | Description  |
|---------------------------|--------------|--|
| ST/INH RLY [Off/ ST /INH] |              | Indicates condition of starter relay and starter control relay                             |
| DETENT SW [On/Off]        |              | Indicates condition of CVT shift selector (park position switch)                           |
| DTRL REQ [Off]            |              | Indicates daytime running light request signal received from BCM on CAN communication line |
| HOOD SW [On/Off]          |              | Indicates condition of hood switch   |
| THFT HRN REQ [On/Off]     |              | Indicates theft warning horn request signal received from BCM on CAN communication line    |
| HORN CHIRP [On/Off]       |              | Indicates horn reminder signal received from BCM on CAN communication line                 |
| HOOD SW 2 [On/Off]        |              | Indicates condition of hood switch 2   |

### ACTIVE TEST

| Test item      | Description  |
|----------------|--|
| HORN           | This test is able to check horn operation [On].                          |
| FRONT WIPER    | This test is able to check wiper motor operation [Hi/Low/Off].           |
| MOTOR FAN      | This test is able to check cooling fan operation [4/3/2/1].              |
| EXTERNAL LAMPS | This test is able to check external lamp operation [Fog/Hi/Low/TAILOff]. |

### CAN DIAG SUPPORT MNTR

Refer to [LAN-16. "CAN Diagnostic Support Monitor"](#).

SEC

## ECM, IPDM E/R, BCM

< ECU DIAGNOSIS INFORMATION >

# ECU DIAGNOSIS INFORMATION

ECM, IPDM E/R, BCM

List of ECU Reference

INFOID:0000000012592401

| ECU               | Reference   |
|-------------------|---|
| ECM (with QR25DE) | <a href="#">EC-91, "Reference Value"</a>                |
|                   | <a href="#">EC-106, "Fail Safe"</a>                     |
|                   | <a href="#">EC-108, "DTC Inspection Priority Chart"</a> |
|                   | <a href="#">EC-110, "DTC Index"</a>                     |
| ECM (with VQ35DE) | <a href="#">EC-656, "Reference Value"</a>               |
|                   | <a href="#">EC-673, "Fail-safe"</a>                     |
|                   | <a href="#">EC-674, "DTC Inspection Priority Chart"</a> |
|                   | <a href="#">EC-676, "DTC Index"</a>                     |
| IPDM E/R          | <a href="#">PCS-13, "Reference Value"</a>               |
|                   | <a href="#">PCS-20, "Fail Safe"</a>                     |
|                   | <a href="#">PCS-21, "DTC Index"</a>                     |
| BCM               | <a href="#">BCS-31, "Reference Value"</a>               |
|                   | <a href="#">BCS-50, "Fail Safe"</a>                     |
|                   | <a href="#">BCS-51, "DTC Inspection Priority Chart"</a> |
|                   | <a href="#">BCS-52, "DTC Index"</a>                     |

# ENGINE START FUNCTION

< WIRING DIAGRAM >


## WIRING DIAGRAM

### ENGINE START FUNCTION

#### Wiring Diagram


INFOID:0000000012592402

#### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION



AAKWA0938GB

## < WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SE  
L  
M  
N  
O  
P

## SEC




# ENGINE START FUNCTION

< WIRING DIAGRAM >


## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5G           | W             | -           |
| 15G          | L             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 31G          | BR            | -           |
| 32G          | W             | -           |
| 36G          | G             | -           |
| 37G          | R             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M3               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4N           | V             | -           |
| 5N           | BR            | -           |
| 6N           | W             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M4               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | BROWN            |



|                 |                  |
|-----------------|------------------|
| Connector No.   | M5               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9R           | G             | -           |
| 10R          | BG            | -           |
| 12R          | W             | -           |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13P          | G             | -           |

ABKIA3637GB



# ENGINE START FUNCTION

< WIRING DIAGRAM >



ABKIA3638GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# ENGINE START FUNCTION

< WIRING DIAGRAM >

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M19                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GRAY                      |

|     |     |     |     |     |    |    |    |    |    |    |    |
|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|
| 92  | 91  | 90  | 89  | 88  | 87 | 86 | 85 | 84 | 83 | 82 | 81 |
| 104 | 103 | 102 | 101 | 100 | 99 | 98 | 97 | 96 | 95 | 94 | 93 |



| Terminal No. | Color of Wire | Signal Name  |
|--------------|---------------|--------------|
| 82           | Y             | RL DOOR SW   |
| 93           | V             | RR DOOR SW   |
| 94           | SB            | AS DOOR SW   |
| 96           | BR            | DR DOOR SW   |
| 99           | G             | ROOM ANT 3 B |
| 100          | R             | ROOM ANT 3 A |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M20                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |

|     |     |     |     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 116 | 115 | 114 | 113 | 112 | 111 | 110 | 109 | 108 | 107 | 106 | 105 |
| 128 | 127 | 126 | 125 | 124 | 123 | 122 | 121 | 120 | 119 | 118 | 117 |



| Terminal No. | Color of Wire | Signal Name  |
|--------------|---------------|--------------|
| 111          | Y             | ACC LED      |
| 116          | W             | ROOM ANT 2 A |
| 119          | G             | RF NIMOCO    |
| 128          | BG            | ROOM ANT 2 B |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M21                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE                     |

|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| 137 | 136 | 135 | 134 | 133 | 132 | 131 | 130 |
| 143 | 142 | 141 | 140 | 139 | 138 | 137 | 136 |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 131          | W             | BAT BCM FUSE   |
| 134          | B             | GND2           |
| 138          | V             | BAT REAR DOOR  |
| 139          | W             | BAT POWER F/L  |
| 142          | BR            | BAT FRONT DOOR |
| 143          | B             | GND1           |

|                 |                    |
|-----------------|--------------------|
| Connector No.   | M23                |
| Connector Name  | CVT SHIFT SELECTOR |
| Connector Color | WHITE              |

|   |   |   |    |    |    |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4  | 5  | 6  |
| 7 | 8 | 9 | 10 | 11 | 12 |



|                 |                   |
|-----------------|-------------------|
| Connector No.   | M24               |
| Connector Name  | COMBINATION METER |
| Connector Color | WHITE             |

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |



|                 |                               |
|-----------------|-------------------------------|
| Connector No.   | M27                           |
| Connector Name  | REMOTE KEYLESS ENTRY RECEIVER |
| Connector Color | BLACK                         |

|   |   |   |   |
|---|---|---|---|
| 1 | 2 | 3 | 4 |
|---|---|---|---|



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5            | L             | -           |
| 6            | W             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | GND1        |
| 2            | B             | GND2        |
| 6            | G             | SECURITY    |
| 22           | G             | BAT         |
| 38           | P             | CAN-L       |
| 39           | L             | CAN-H       |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | W             | -           |
| 2            | G             | -           |
| 3            | B             | -           |

ABK1A3639GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >

|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | M38                         |
| Connector Name  | PUSH-BUTTON IGNITION SWITCH |
| Connector Color | WHITE                       |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | W             | -           |
| 4            | B             | -           |
| 7            | Y             | -           |
| 8            | R             | -           |

|                 |                       |
|-----------------|-----------------------|
| Connector No.   | M81                   |
| Connector Name  | FRONT CONSOLE ANTENNA |
| Connector Color | GRAY                  |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | W             | -           |
| 2            | BG            | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M89                 |
| Connector Name  | JOINT CONNECTOR-M05 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M155                |
| Connector Name  | JOINT CONNECTOR-M06 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M156                |
| Connector Name  | JOINT CONNECTOR-M07 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M157                |
| Connector Name  | JOINT CONNECTOR-M08 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

ABKIA3640GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# ENGINE START FUNCTION

< WIRING DIAGRAM >

|                 |                  |
|-----------------|------------------|
| Connector No.   | E6               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |

|     |    |    |    |
|-----|----|----|----|
| 4M  | 3M | 2M | 1M |
| 10M | 9M | 8M | 7M |
| 6M  | 5M |    |    |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5M           | G             | –           |
| 8M           | W             | –           |

|                 |                                    |
|-----------------|------------------------------------|
| Connector No.   | E10                                |
| Connector Name  | ECM (QR25DE EXCEPT FOR CALIFORNIA) |
| Connector Color | GRAY                               |

|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| 97  | 101 | 105 | 108 | 113 | 117 | 121 | 125 |
| 98  | 102 | 106 | 110 | 114 | 118 | 122 | 126 |
| 99  | 103 | 107 | 111 | 115 | 119 | 123 | 127 |
| 100 | 104 | 108 | 112 | 116 | 120 | 124 | 128 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 99           | P             | CAN-L       |
| 100          | L             | CAN-H       |

|                 |              |
|-----------------|--------------|
| Connector No.   | E11          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |

|   |    |    |    |    |    |    |    |
|---|----|----|----|----|----|----|----|
| 1 | 2  | 3  | 4  | 5  | 6  | 7  | 8  |
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9            | P             | –           |
| 10           | L             | –           |

|                 |  |
|-----------------|--|
| Connector No.   | E18  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |

|    |    |    |    |    |
|----|----|----|----|----|
| 7  | 8  | 9  | 10 | 11 |
| 12 | 13 | 14 | 15 | 16 |
| 17 | 18 |    |    |    |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7            | B             | GND (POWER) |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E21                 |
| Connector Name  | JOINT CONNECTOR-E03 |
| Connector Color | GRAY                |

|   |   |   |   |   |   |
|---|---|---|---|---|---|
| 6 | 5 | 4 | 3 | 2 | 1 |
|---|---|---|---|---|---|



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | –           |
| 2            | L             | –           |
| 4            | L             | –           |
| 5            | L             | –           |
| 6            | L             | –           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-E04 |
| Connector Color | GRAY                |

|   |   |   |   |   |   |
|---|---|---|---|---|---|
| 6 | 5 | 4 | 3 | 2 | 1 |
|---|---|---|---|---|---|



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | –           |
| 2            | P             | –           |
| 4            | P             | –           |
| 5            | P             | –           |
| 6            | P             | –           |

ABK1A7193GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >

|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | E31                         |
| Connector Name  | ECM (QR25DE FOR CALIFORNIA) |
| Connector Color | GRAY                        |



|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| 97  | 101 | 105 | 109 | 113 | 117 | 121 | 125 |
| 98  | 102 | 106 | 110 | 114 | 118 | 122 | 126 |
| 99  | 103 | 107 | 111 | 115 | 119 | 123 | 127 |
| 100 | 104 | 108 | 112 | 116 | 120 | 124 | 128 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 99           | P             | CAN-L       |
| 100          | L             | CAN-H       |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5G           | P             | -           |
| 15G          | W             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 31G          | R             | -           |
| 32G          | Y             | -           |
| 36G          | LG            | -           |
| 37G          | G             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E30          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|     |     |     |     |     |
|-----|-----|-----|-----|-----|
| 5G  | 4G  | 3G  | 2G  | 1G  |
| 10G | 9G  | 8G  | 7G  | 6G  |
| 21G | 20G | 19G | 18G | 17G |
| 30G | 29G | 28G | 27G | 26G |
| 25G | 24G | 23G | 22G | 21G |
| 41G | 40G | 39G | 38G | 37G |
| 36G | 35G | 34G | 33G | 32G |
| 31G | 30G | 29G | 28G | 27G |
| 43G | 42G | 41G | 40G | 39G |
| 51G | 50G | 49G | 48G | 47G |
| 56G | 55G | 54G | 53G | 52G |
| 57G | 56G | 55G | 54G | 53G |
| 63G | 62G | 61G | 60G | 59G |
| 64G | 63G | 62G | 61G | 60G |
| 76G | 75G | 74G | 73G | 72G |
| 71G | 70G | 69G | 68G | 67G |
| 83G | 82G | 81G | 80G | 79G |
| 84G | 83G | 82G | 81G | 80G |
| 91G | 90G | 89G | 88G | 87G |
| 96G | 95G | 94G | 93G | 92G |
| 97G | 96G | 95G | 94G | 93G |

|                 |   |
|-----------------|---|
| Connector No.   | E54   |
| Connector Name  | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Color | BLACK   |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 |
| 13 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 |
| 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |    |    |    |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14           | P             | CAN-L       |
| 26           | L             | CAN-H       |

|                 |                  |
|-----------------|------------------|
| Connector No.   | E38              |
| Connector Name  | STOP LAMP SWITCH |
| Connector Color | WHITE            |



|   |   |
|---|---|
| 2 | 1 |
| 4 | 3 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | G             | -           |
| 4            | R             | -           |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | E32               |
| Connector Name  | ECM (WITH VQ35DE) |
| Connector Color | BLACK             |



|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| 121 | 125 | 129 | 133 | 137 | 141 | 145 | 149 |
| 122 | 126 | 130 | 134 | 138 | 142 | 146 | 150 |
| 123 | 127 | 131 | 135 | 139 | 143 | 147 | 151 |
| 124 | 128 | 132 | 136 | 140 | 144 | 148 | 152 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 123          | P             | CAN-L       |
| 124          | L             | CAN-H       |

ABKIA7177GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# ENGINE START FUNCTION

< WIRING DIAGRAM >

|                 |  |
|-----------------|--|
| Connector No.   | E63  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 |
| 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 |

| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 28           | P             | CAN-L          |
| 29           | L             | CAN-H          |
| 31           | Y             | DETENT SW      |
| 33           | R             | START CONT     |
| 37           | W             | TRANS RANGE SW |
| 38           | G             | PUSH START SW  |
| 41           | B             | GND (SIGNAL)   |
| 43           | LG            | IGN SIGNAL     |

|                 |                 |
|-----------------|-----------------|
| Connector No.   | E57             |
| Connector Name  | STOP LAMP RELAY |
| Connector Color | BLUE            |



|   |   |   |
|---|---|---|
| 3 | 5 | 1 |
| 2 | 4 | 1 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | -           |
| 2            | R             | -           |
| 3            | W             | -           |
| 5            | G             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E56                 |
| Connector Name  | JOINT CONNECTOR-E08 |
| Connector Color | WHITE               |



|    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|
| 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 |
| 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23           | W             | -           |
| 25           | W             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | F10  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK  |



|    |
|----|
| 51 |
|----|

| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 51           | R             | STARTER MOTOR |

|                 |              |
|-----------------|--------------|
| Connector No.   | F2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|    |    |    |    |    |    |    |   |
|----|----|----|----|----|----|----|---|
| 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1 |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9            | P             | -           |
| 10           | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E64                 |
| Connector Name  | JOINT CONNECTOR-E10 |
| Connector Color | BLUE                |



|    |    |    |   |   |   |   |   |   |   |   |   |
|----|----|----|---|---|---|---|---|---|---|---|---|
| 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
|----|----|----|---|---|---|---|---|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4            | W             | -           |
| 6            | W             | -           |
| 10           | G             | -           |
| 11           | G             | -           |
| 12           | G             | -           |

ABKIA7178GB

# ENGINE START FUNCTION

## < WIRING DIAGRAM >

|                 |  |
|-----------------|--|
| Connector No.   | F83  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |

|    |    |    |    |
|----|----|----|----|
| 52 | 53 | 54 | 55 |
| 56 | 57 | 58 | 59 |
| 60 | 61 |    |    |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 61           | Y             | AT ECU      |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | F48                 |
| Connector Name  | JOINT CONNECTOR-F02 |
| Connector Color | BLACK               |

|    |   |   |   |   |
|----|---|---|---|---|
| 5  | 4 | 3 | 2 | 1 |
| 10 | 9 | 8 | 7 | 6 |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 2            | Y             | -              |
| 3            | Y             | -              |
| 5            | Y             | -              |
| 6            | Y             | -(WITH QR25DE) |
| 6            | L             | -(WITH VQ35DE) |

|                 |                                   |
|-----------------|-----------------------------------|
| Connector No.   | F16                               |
| Connector Name  | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK                             |

|    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 47 | 48 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 45 | 46 |
| 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 43 | 44 |
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 41 | 42 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23           | P             | CAN-L       |
| 33           | L             | CAN-H       |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | F85                       |
| Connector Name  | TRANSMISSION RANGE SWITCH |
| Connector Color | BLACK                     |

|   |   |   |   |
|---|---|---|---|
| 8 | 4 | 3 | 7 |
| 2 | 6 | 5 | 1 |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 1            | Y             | -(WITH QR25DE) |
| 1            | L             | -(WITH VQ35DE) |
| 2            | LG            | -(WITH QR25DE) |
| 2            | G             | -(WITH VQ35DE) |

|                 |  |
|-----------------|--|
| Connector No.   | F84  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |

|    |    |    |    |    |    |
|----|----|----|----|----|----|
| 62 | 63 | 64 | 65 | 66 | 67 |
| 68 | 69 | 70 | 71 | 72 | 73 |




| Terminal No. | Color of Wire | Signal Name         |
|--------------|---------------|---------------------|
| 66           | LG            | NP SW (WITH QR25DE) |
| 66           | G             | NP SW (WITH VQ35DE) |

ABKIA7179GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >


|                 |                      |
|-----------------|----------------------|
| Connector No.   | B8                   |
| Connector Name  | FRONT DOOR SWITCH LH |
| Connector Color | WHITE                |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 77J          | L             | -           |
| 78J          | LG            | -           |
| 83J          | BG            | -           |
| 84J          | R             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | GRAY         |



|                 |                     |
|-----------------|---------------------|
| Connector No.   | B18                 |
| Connector Name  | REAR DOOR SWITCH LH |
| Connector Color | WHITE               |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | LG            | -           |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | B29                       |
| Connector Name  | REAR PARCEL SHELF ANTENNA |
| Connector Color | GRAY                      |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | BG            | -           |
| 2            | R             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B104         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | BROWN        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13           | V             | -           |
| 14           | L             | -           |



ENGINE START FUNCTION


< WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B116                |
| Connector Name  | REAR DOOR SWITCH RH |
| Connector Color | WHITE               |



|               |   |
|---------------|---|
| Terminal No.  | 3 |
| Color of Wire | V |
| Signal Name   | - |

|                 |                      |
|-----------------|----------------------|
| Connector No.   | B108                 |
| Connector Name  | FRONT DOOR SWITCH RH |
| Connector Color | WHITE                |



|               |   |
|---------------|---|
| Terminal No.  | 3 |
| Color of Wire | L |
| Signal Name   | - |

AAKIA2216GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC


# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

### Wiring Diagram


INFOID:0000000012592403



NVIS


ABKWA2195GB

## < WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

## < WIRING DIAGRAM >




# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >


## NVIS CONNECTORS

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5G           | W             | -           |
| 15G          | L             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 31G          | BR            | -           |
| 32G          | W             | -           |
| 36G          | G             | -           |
| 37G          | R             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M3               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6N           | W             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M4               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | BROWN            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9R           | G             | -           |
| 10R          | BG            | -           |
| 12R          | W             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M5               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13P          | G             | -           |

ABKIA3645GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## < WIRING DIAGRAM >

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M17                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN                     |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |

| Terminal No. | Color of Wire | Signal Name          |
|--------------|---------------|----------------------|
| 1            | R             | ENG START SW NO ESCL |
| 18           | G             | SECURITY INDICATOR   |
| 20           | W             | SHIFT P              |
| 25           | BG            | BRAKE SW FUSE        |
| 27           | G             | BRAKE SW LAMP        |
| 39           | L             | SHIFT N/P            |



|     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 137 | 136 | 135 | 134 | 133 | 132 | 131 | 130 | 129 |
| 143 | 142 | 141 | 140 | 139 | 138 |     |     |     |

| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 131          | W             | BAT BCM FUSE  |
| 134          | B             | GND2          |
| 139          | W             | BAT POWER F/L |
| 143          | B             | GND1          |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M18                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 |
| 80 | 79 | 78 | 77 | 76 | 75 | 74 | 73 | 72 | 71 | 70 | 69 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 |

| Terminal No. | Color of Wire | Signal Name       |
|--------------|---------------|-------------------|
| 52           | G             | AUDIO DONGLE      |
| 59           | P             | CAN-L             |
| 60           | L             | CAN-H             |
| 62           | BR            | STARTER RELAY OUT |
| 69           | L             | AT DEVICE OUT     |
| 70           | G             | IGN USM OUT 1     |



|   |   |   |    |    |    |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4  | 5  | 6  |
| 7 | 8 | 9 | 10 | 11 | 12 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5            | L             | -           |
| 6            | W             | -           |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M20                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |



|     |     |     |     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 116 | 115 | 114 | 113 | 112 | 111 | 110 | 109 | 108 | 107 | 106 | 105 |
| 128 | 127 | 126 | 125 | 124 | 123 | 122 | 121 | 120 | 119 | 118 | 117 |

| Terminal No. | Color of Wire | Signal Name             |
|--------------|---------------|-------------------------|
| 111          | Y             | ACC LED                 |
| 126          | BR            | IMMO START BUTTON ANT B |
| 127          | L             | IMMO START BUTTON ANT A |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | M24               |
| Connector Name  | COMBINATION METER |
| Connector Color | WHITE             |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | GND1        |
| 2            | B             | GND2        |
| 6            | G             | SECURITY    |
| 22           | G             | BAT         |
| 38           | P             | CAN-L       |
| 39           | L             | CAN-H       |

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## < WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M89                 |
| Connector Name  | JOINT CONNECTOR-M05 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | M40               |
| Connector Name  | NATS ANTENNA AMP. |
| Connector Color | WHITE             |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 3            | BR            | -           |

|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | M38                         |
| Connector Name  | PUSH-BUTTON IGNITION SWITCH |
| Connector Color | WHITE                       |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | W             | -           |
| 4            | B             | -           |
| 7            | Y             | -           |
| 8            | R             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M157                |
| Connector Name  | JOINT CONNECTOR-M08 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M156                |
| Connector Name  | JOINT CONNECTOR-M07 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |
| 4            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M155                |
| Connector Name  | JOINT CONNECTOR-M06 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | -           |
| 4            | P             | -           |

ABKIA4815GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


## < WIRING DIAGRAM >

|                 |                                    |
|-----------------|------------------------------------|
| Connector No.   | E10                                |
| Connector Name  | ECM (QR25DE EXCEPT FOR CALIFORNIA) |
| Connector Color | GRAY                               |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 99           | P             | CAN-L       |
| 100          | L             | CAN-H       |

|                 |                  |
|-----------------|------------------|
| Connector No.   | E6               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5M           | G             | -           |
| 8M           | W             | -           |

|                 |             |
|-----------------|-------------|
| Connector No.   | M159        |
| Connector Name  | DONGLE UNIT |
| Connector Color | WHITE       |




| Terminal No. | Color of Wire | Signal Name     |
|--------------|---------------|-----------------|
| 1            | G             | DATA&+5V SUPPLY |
| 2            | -             | -               |
| 3            | -             | -               |
| 4            | GR            | GND             |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E21                 |
| Connector Name  | JOINT CONNECTOR-E03 |
| Connector Color | GRAY                |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |
| 4            | L             | -           |
| 5            | L             | -           |
| 6            | L             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | E18  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7            | B             | GND (POWER) |

|                 |              |
|-----------------|--------------|
| Connector No.   | E11          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9            | P             | -           |
| 10           | L             | -           |

ABK1A7194GB




# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


## < WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5G           | P             | -           |
| 15G          | W             | -           |
| 22G          | L             | -           |
| 23G          | P             | -           |
| 31G          | R             | -           |
| 32G          | Y             | -           |
| 36G          | LG            | -           |
| 37G          | G             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E30          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-E04 |
| Connector Color | GRAY                |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 2            | P             | -           |
| 4            | P             | -           |
| 5            | P             | -           |
| 6            | P             | -           |


|                 |                  |
|-----------------|------------------|
| Connector No.   | E38              |
| Connector Name  | STOP LAMP SWITCH |
| Connector Color | WHITE            |



|                 |                   |
|-----------------|-------------------|
| Connector No.   | E32               |
| Connector Name  | ECM (WITH VQ35DE) |
| Connector Color | BLACK             |



|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | E31                         |
| Connector Name  | ECM (QR25DE FOR CALIFORNIA) |
| Connector Color | GRAY                        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | G             | -           |
| 4            | R             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 123          | P             | CAN-L       |
| 124          | L             | CAN-H       |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 99           | P             | CAN-L       |
| 100          | L             | CAN-H       |

ABK1A7180GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


## < WIRING DIAGRAM >

|                 |                 |
|-----------------|-----------------|
| Connector No.   | E57             |
| Connector Name  | STOP LAMP RELAY |
| Connector Color | BLUE            |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | -           |
| 2            | R             | -           |
| 3            | W             | -           |
| 5            | G             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E56                 |
| Connector Name  | JOINT CONNECTOR-E08 |
| Connector Color | WHITE               |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23           | W             | -           |
| 25           | W             | -           |

|                 |   |
|-----------------|---|
| Connector No.   | E54   |
| Connector Name  | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Color | BLACK   |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14           | P             | CAN-L       |
| 26           | L             | CAN-H       |

|                 |              |
|-----------------|--------------|
| Connector No.   | F2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9            | P             | -           |
| 10           | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E64                 |
| Connector Name  | JOINT CONNECTOR-E10 |
| Connector Color | BLUE                |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4            | W             | -           |
| 6            | W             | -           |
| 10           | G             | -           |
| 11           | G             | -           |
| 12           | G             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | E63  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 28           | P             | CAN-L          |
| 29           | L             | CAN-H          |
| 31           | Y             | DETENT SW      |
| 33           | R             | START CONT     |
| 37           | W             | TRANS RANGE SW |
| 38           | G             | PUSH START SW  |
| 41           | B             | GND (SIGNAL)   |
| 43           | LG            | IGN SIGNAL     |

ABK1A7181GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


## < WIRING DIAGRAM >

|                 |  |
|-----------------|--|
| Connector No.   | F10  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK  |




| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 51           | R             | STARTER MOTOR |

|                 |                                   |
|-----------------|-----------------------------------|
| Connector No.   | F16                               |
| Connector Name  | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK                             |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23           | P             | CAN-L       |
| 33           | L             | CAN-H       |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | F48                 |
| Connector Name  | JOINT CONNECTOR-F02 |
| Connector Color | BLACK               |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 2            | Y             | -              |
| 3            | Y             | -              |
| 5            | Y             | -              |
| 6            | Y             | -(WITH QR25DE) |
| 6            | L             | -(WITH VQ35DE) |

|                 |  |
|-----------------|--|
| Connector No.   | F83  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 61           | Y             | AT ECU      |

|                 |  |
|-----------------|--|
| Connector No.   | F84  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name         |
|--------------|---------------|---------------------|
| 66           | LG            | NP SW (WITH QR25DE) |
| 66           | G             | NP SW (WITH VQ35DE) |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | F85                       |
| Connector Name  | TRANSMISSION RANGE SWITCH |
| Connector Color | BLACK                     |



| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 1            | Y             | -(WITH QR25DE) |
| 1            | L             | -(WITH VQ35DE) |
| 2            | LG            | -(WITH QR25DE) |
| 2            | G             | -(WITH VQ35DE) |

ABK1A7182GB


# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM

### Wiring Diagram


INFOID:0000000012592404



ABKWA2187GB

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >




ABKWA3134GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC



## < WIRING DIAGRAM >



< WIRING DIAGRAM >

VEHICLE SECURITY SYSTEM CONNECTORS

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 4N           | V             | -           |
| 5N           | BR            | -           |
| 6N           | W             | -           |

|                 |                  |
|-----------------|------------------|
| Connector No.   | M5               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 13P          | G             | -           |







ABKIA3651GB

SEC

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >



ABKIA4845GB



# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M19                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GRAY                      |



|     |     |     |     |     |    |    |    |    |    |    |    |
|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|
| 92  | 91  | 90  | 89  | 88  | 87 | 86 | 85 | 84 | 83 | 82 | 81 |
| 104 | 103 | 102 | 101 | 100 | 99 | 98 | 97 | 96 | 95 | 94 | 93 |

| Terminal No. | Color of Wire | Signal Name       |
|--------------|---------------|-------------------|
| 82           | Y             | RL DOOR SW        |
| 93           | V             | RR DOOR SW        |
| 94           | SB            | AS DOOR SW        |
| 96           | BR            | DR DOOR SW        |
| 97           | SB            | TRUNK SW          |
| 99           | G             | ROOM ANT 3 B      |
| 100          | R             | ROOM ANT 3 A      |
| 101          | G             | REAR BUMPER ANT B |
| 102          | W             | REAR BUMPER ANT A |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M18                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 |
| 80 | 79 | 78 | 77 | 76 | 75 | 74 | 73 | 72 | 71 | 70 | 69 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 |

| Terminal No. | Color of Wire | Signal Name        |
|--------------|---------------|--------------------|
| 54           | P             | PW LIN             |
| 59           | P             | CAN-L              |
| 60           | L             | CAN-H              |
| 70           | G             | IGN USM OUT 1      |
| 74           | P             | DOOR KEY/C LOCK SW |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M17                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN                     |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |

| Terminal No. | Color of Wire | Signal Name            |
|--------------|---------------|------------------------|
| 18           | G             | SECURITY INDICATOR     |
| 19           | G             | CENTRAL DOOR LOCK SW   |
| 24           | G             | DOOR KEY/C UNLOCK SW   |
| 34           | BG            | CENTRAL DOOR UNLOCK SW |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | M24               |
| Connector Name  | COMBINATION METER |
| Connector Color | WHITE             |



|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | G             | SECURITY    |
| 22           | G             | BAT         |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M21                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE                     |



|     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 137 | 136 | 135 | 134 | 133 | 132 | 131 | 130 | 129 |
| 143 | 142 | 141 | 140 | 139 | 138 |     |     |     |

| Terminal No. | Color of Wire | Signal Name    |
|--------------|---------------|----------------|
| 131          | W             | BAT BCM FUSE   |
| 134          | B             | GND2           |
| 138          | V             | BAT REAR DOOR  |
| 139          | W             | BAT POWER F/L  |
| 142          | BR            | BAT FRONT DOOR |
| 143          | B             | GND1           |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M20                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |



|     |     |     |     |     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 116 | 115 | 114 | 113 | 112 | 111 | 110 | 109 | 108 | 107 | 106 | 105 |
| 128 | 127 | 126 | 125 | 124 | 123 | 122 | 121 | 120 | 119 | 118 | 117 |

| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 114          | P             | AS DOOR ANT A |
| 115          | R             | AS DOOR ANT B |
| 116          | W             | ROOM ANT 2 A  |
| 121          | R             | DR DOOR ANT B |
| 122          | P             | DR DOOR ANT A |
| 128          | BG            | ROOM ANT 2 B  |

ABKIA3653GB

# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | M112         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 |
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | G             | —           |
| 4            | P             | —           |
| 17           | P             | —           |
| 18           | B             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M89                 |
| Connector Name  | JOINT CONNECTOR-M05 |
| Connector Color | WHITE               |



|   |   |   |   |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | —           |
| 4            | L             | —           |

|                 |              |
|-----------------|--------------|
| Connector No.   | M84          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 |
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 19           | P             | —           |
| 20           | BG            | —           |
| 21           | G             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M157                |
| Connector Name  | JOINT CONNECTOR-M08 |
| Connector Color | WHITE               |



|   |   |   |   |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | —           |
| 4            | P             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M156                |
| Connector Name  | JOINT CONNECTOR-M07 |
| Connector Color | WHITE               |



|   |   |   |   |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | —           |
| 4            | L             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M155                |
| Connector Name  | JOINT CONNECTOR-M06 |
| Connector Color | WHITE               |



|   |   |   |   |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | —           |
| 4            | P             | —           |

ABKIA4837GB

VEHICLE SECURITY SYSTEM


< WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | E2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




|               |   |
|---------------|---|
| Terminal No.  | 2 |
| Color of Wire | R |
| Signal Name   | — |

|                 |  |
|-----------------|--|
| Connector No.   | E18  |
| Connector Name  | IPDM/E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |




|               |             |
|---------------|-------------|
| Terminal No.  | 7           |
| Color of Wire | B           |
| Signal Name   | GND (POWER) |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E21                 |
| Connector Name  | JOINT CONNECTOR-E03 |
| Connector Color | GRAY                |




|               |   |
|---------------|---|
| Terminal No.  | 1 |
| Color of Wire | L |
| Signal Name   | — |
| Terminal No.  | 5 |
| Color of Wire | L |
| Signal Name   | — |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-E04 |
| Connector Color | GRAY                |



|               |   |
|---------------|---|
| Terminal No.  | 1 |
| Color of Wire | P |
| Signal Name   | — |
| Terminal No.  | 5 |
| Color of Wire | P |
| Signal Name   | — |

|                 |              |
|-----------------|--------------|
| Connector No.   | E30          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|               |     |
|---------------|-----|
| Terminal No.  | 5G  |
| Color of Wire | P   |
| Signal Name   | —   |
| Terminal No.  | 22G |
| Color of Wire | L   |
| Signal Name   | —   |
| Terminal No.  | 23G |
| Color of Wire | P   |
| Signal Name   | —   |
| Terminal No.  | 36G |
| Color of Wire | LG  |
| Signal Name   | —   |

# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | E202         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |

|   |   |   |
|---|---|---|
| 3 | 2 | 1 |
| 8 | 7 | 6 |
| 5 | 4 |   |



|                 |  |
|-----------------|--|
| Connector No.   | E201   |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |

|    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|
| 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 |
| 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 |



|                 |  |
|-----------------|--|
| Connector No.   | E63  |
| Connector Name  | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE  |

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 |
| 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 2            | G             | –           |

|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 94           | SB            | HOODSW 2    |
| 96           | Y             | HOODSW      |

|              |               |              |
|--------------|---------------|--------------|
| Terminal No. | Color of Wire | Signal Name  |
| 22           | W             | HORN RLY     |
| 28           | P             | CAN-L        |
| 29           | L             | CAN-H        |
| 41           | B             | GND (SIGNAL) |
| 43           | LG            | IGN SIGNAL   |

|                 |            |
|-----------------|------------|
| Connector No.   | E238       |
| Connector Name  | HORN (LOW) |
| Connector Color | BLACK      |

|   |
|---|
| 2 |
|---|



|                 |             |
|-----------------|-------------|
| Connector No.   | E216        |
| Connector Name  | HORN (HIGH) |
| Connector Color | BROWN       |

|   |
|---|
| 1 |
|---|



|                 |            |
|-----------------|------------|
| Connector No.   | E215       |
| Connector Name  | HORN (LOW) |
| Connector Color | BROWN      |

|   |
|---|
| 1 |
|---|



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 2            | B             | –           |

|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 1            | G             | –           |

|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 1            | G             | –           |

ABK1A7185GB

VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

|                 |             |
|-----------------|-------------|
| Connector No.   | E239        |
| Connector Name  | HORN (HIGH) |
| Connector Color | BLACK       |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | B             | -           |

|                 |                            |
|-----------------|----------------------------|
| Connector No.   | E247                       |
| Connector Name  | PRE-WIRING FOR HOOD SWITCH |
| Connector Color | BLACK                      |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | SB            | -           |
| 2            | Y             | -           |
| 3            | B             | -           |

|                 |             |
|-----------------|-------------|
| Connector No.   | E248        |
| Connector Name  | HOOD SWITCH |
| Connector Color | BLACK       |





| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | SB            | -           |
| 2            | Y             | -           |
| 3            | B             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | GRAY         |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 76J          | W             | -           |
| 77J          | L             | -           |
| 78J          | LG            | -           |

|                 |                      |
|-----------------|----------------------|
| Connector No.   | B8                   |
| Connector Name  | FRONT DOOR SWITCH LH |
| Connector Color | WHITE                |



ABKIA7186GB


SEC

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B18                 |
| Connector Name  | REAR DOOR SWITCH LH |
| Connector Color | WHITE               |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 3            | LG            | —           |

|                 |  |
|-----------------|--|
| Connector No.   | B28  |
| Connector Name  | TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID |
| Connector Color | WHITE  |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 1            | W             | —           |
| 2            | GR            | —           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B104         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | BROWN        |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 13           | V             | —           |
| 14           | L             | —           |

|                 |                      |
|-----------------|----------------------|
| Connector No.   | B108                 |
| Connector Name  | FRONT DOOR SWITCH RH |
| Connector Color | WHITE                |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 3            | L             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B116                |
| Connector Name  | REAR DOOR SWITCH RH |
| Connector Color | WHITE               |



|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 3            | V             | —           |

|                 |              |
|-----------------|--------------|
| Connector No.   | D1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 3            | R             | —           |
| 4            | G             | —           |
| 8            | B             | —           |

ABKIA7187GB

# VEHICLE SECURITY SYSTEM


## < WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | D2           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | G             | -           |
| 4            | P             | -           |
| 17           | P             | -           |
| 18           | B             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | D7   |
| Connector Name  | MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM) |
| Connector Color | WHITE  |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | GND         |
| 3            | P             | LOCK        |
| 11           | P             | COM         |
| 15           | G             | UNLOCK      |

|                 |   |
|-----------------|---|
| Connector No.   | D12   |
| Connector Name  | MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM) |
| Connector Color | WHITE   |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | B             | GND         |
| 3            | G             | LOCK SW     |
| 15           | R             | UNLOCK SW   |

|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | D14                         |
| Connector Name  | FRONT DOOR LOCK ASSEMBLY LH |
| Connector Color | GRAY                        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4            | B             | -           |
| 5            | G             | -           |
| 6            | P             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | D101         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4            | B             | -           |

|                 |  |
|-----------------|--|
| Connector No.   | D105   |
| Connector Name  | POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT POWER WINDOW ANTI-PINCH SYSTEM) |
| Connector Color | WHITE  |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | P             | COM         |
| 7            | B             | GND         |

ABKIA7188GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

|                 |              |
|-----------------|--------------|
| Connector No.   | D114         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 12 | 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  | 3  | 2  | 1  |
| 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 19           | P             | -           |
| 20           | BG            | -           |
| 21           | G             | -           |

|                 |   |
|-----------------|---|
| Connector No.   | D110  |
| Connector Name  | POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM) |
| Connector Color | WHITE   |



|   |   |   |   |    |    |    |
|---|---|---|---|----|----|----|
| 1 | 2 |   |   | 3  | 4  | 5  |
| 6 | 7 | 8 | 9 | 10 | 11 | 12 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | G             | LOCK        |
| 2            | BG            | UNLOCK      |
| 3            | B             | GND         |

ABKIA7189GB



# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000012592405

OVERALL SEQUENCE



DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

---

### 1.GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

### 2.CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected:
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

#### Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

### 3.CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

### 4.CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

### 5.PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-51. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

#### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

#### Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

### 6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

#### Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

### 7.DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

---

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ECM

##### ECM : Description

INFOID:0000000012592406

Performing the following procedure can automatically activate recommunication of ECM and BCM, but only when the ECM is replaced with a new one\*.

\*: New one means an ECM that has never been energized on-board.

(In this step, initialization procedure by CONSULT is not necessary)

##### NOTE:

- If multiple keys are attached to the key holder, separate them before beginning work.
- Distinguish keys with unregistered key IDs from those with registered IDs.

##### ECM : Work Procedure

INFOID:0000000012592407

#### 1.PERFORM ECM RECOMMUNICATING FUNCTION

1. Install ECM.
2. Contact backside of registered Intelligent Key\* to push-button ignition switch, then turn ignition switch to ON.  
\*: To perform this step, use the key that is used before performing ECM replacement.
3. Maintain ignition switch in the ON position for at least 5 seconds.
4. Turn ignition switch to OFF.
5. Check that the engine starts.

>> GO TO 2.

#### 2.PERFORM ADDITIONAL SERVICE WHEN REPLACING ECM

Perform [EC-182. "Work Procedure"](#) (QR25DE) or [EC-728. "Work Procedure"](#) (VQ35DE).

>> Inspection End.

#### BCM

##### BCM : Description

INFOID:0000000012592408

##### BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

##### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

##### AFTER REPLACEMENT

##### CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

##### BCM : Work Procedure

INFOID:0000000012592409

#### 1.SAVING VEHICLE SPECIFICATION

##### ⓑCONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

##### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

### < BASIC INSPECTION >

---

>> GO TO 2.

#### 2. REPLACE BCM

---

Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

>> GO TO 3.

#### 3. WRITING VEHICLE SPECIFICATION

---

##### CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

#### 4. INITIALIZE BCM (NATS)

---

Perform BCM initialization. (NATS)

>> Work End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## P1610 LOCK MODE

< DTC/CIRCUIT DIAGNOSIS >

### DTC/CIRCUIT DIAGNOSIS

#### P1610 LOCK MODE

##### Description

INFOID:0000000012592410

ECM forcibly switches to the mode that inhibits engine start, when engine start operation is performed 5 times or more while communication between ECM and BCM is not normal.

##### DTC Logic

INFOID:0000000012592411

##### DTC DETECTION LOGIC

###### NOTE:

- If DTC P1610 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC P1610 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause |
|---------|------------------------|---|----------------|
| P1610   | LOCK MODE              | When ECM detects a communication malfunction between ECM and BCM 5 times or more. | —              |

##### DTC CONFIRMATION PROCEDURE

###### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

###### Is DTC detected?

- YES >> Go to [SEC-70, "Diagnosis Procedure"](#).  
NO >> Inspection End.

##### Diagnosis Procedure

INFOID:0000000012592412

###### 1.CHECK ENGINE START FUNCTION

1. Check that there are no DTC's except for DTC P1610 detected.  
If detected, erase the DTC after fixing.
2. Turn ignition switch OFF.
3. Contact the registered Intelligent Key backside to push-button ignition switch and wait 5 seconds.
4. Turn ignition switch ON.
5. Turn ignition switch OFF and wait 5 seconds.
6. Repeat steps 3 and 5 twice (a total of 3 times).
7. Check that engine can start.

>> Inspection End.

# P1611 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

## P1611 ID DISCORD, IMMU-ECM

### DTC Logic

INFOID:0000000012592413

### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition                                 | Possible cause   |
|---------|------------------------|---|--|
| P1611   | ID DISCORD, IMMU-ECM   | The ID verification results between BCM and ECM are NG. | <ul style="list-style-type: none"><li>• Harness or connectors<br/>(The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul> |

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-71, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012592414

#### 1.PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT.

#### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.CHECK SELF DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" of "ENGINE" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-71, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
  2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.
- Can the system be initialized and can the engine be started with registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4.REPLACE ECM

1. Replace ECM. Refer to [EC-577, "Removal and Installation"](#) (QR25DE) or [EC-1088, "Removal and Installation"](#) (VQ35DE).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-182, "Work Procedure"](#) (QR25DE) or [EC-728, "Work Procedure"](#) (VQ35DE).

>> Inspection End.

# P1612 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

## P1612 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:0000000012592415

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition                     | Possible cause   |
|---------|------------------------|---|--|
| P1612   | CHAIN OF BCM-ECM       | Inactive communication between BCM and ECM. | <ul style="list-style-type: none"><li>• Harness or connectors<br/>(The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-72, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012592416

##### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-74, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

##### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-211, "Diagnosis Procedure"](#) (QR25DE) or [EC-758, "Diagnosis Procedure"](#) (VQ35DE).

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the harness.

##### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-72, "DTC Logic"](#).

##### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Inspection End.



# P1614 CHAIN OF IMMU-KEY

< DTC/CIRCUIT DIAGNOSIS >

## P1614 CHAIN OF IMMU-KEY

### DTC Logic

INFOID:0000000012592417

### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition                                   | Possible cause  |
|---------|------------------------|---|---|
| P1614   | CHAIN OF IMMU-KEY      | Inactive communication between NATS antenna amp. and BCM. | <ul style="list-style-type: none"><li>• Harness or connectors (NATS antenna amp. circuit is open or shorted.)</li><li>• NATS antenna amp.</li><li>• BCM</li><li>• Intelligent Key fob</li></ul> |

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

YES >> GO TO [SEC-73. "Diagnosis Procedure"](#).  
NO >> GO TO 2.

#### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

YES >> GO TO [SEC-73. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012592418

Regarding Wiring Diagram information, refer to [SEC-42. "Wiring Diagram"](#).

SEC

#### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Repair or replace as necessary.

#### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

| BCM       |          | NATS antenna amp. |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| M20       | 126      | M40               | 3        | Yes        |
|           | 127      |                   | 1        |            |

2. Check continuity between BCM harness connector and ground.

# P1614 CHAIN OF IMMU-KEY

## < DTC/CIRCUIT DIAGNOSIS >

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M20       | 126      |        | No         |
|           | 127      |        |            |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK NATS ANTENNA AMP. INPUT SIGNAL

1. Connect BCM connector and NATS antenna amp. connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) BCM   |          | (-)    | Condition  | Signal<br>(Reference value)  |
|-----------|----------|--------|--|--|
| Connector | Terminal |        |  |  |
| M20       | 126, 127 | Ground | When Intelligent Key is in the antenna detection area.     | <br>JMKIA3839GB  |
|           |          |        | When Intelligent Key is not in the antenna detection area. | <br>JMKIA5951GB |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-143. "Removal and Installation"](#).

## B20A8 IPDM EXTERNAL MALF FOR ST1

< DTC/CIRCUIT DIAGNOSIS >

### B20A8 IPDM EXTERNAL MALF FOR ST1

#### DTC Logic

INFOID:0000000012592419

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B20A8 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-29, "DTC Logic"](#).
- If DTC B20A8 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-30, "DTC Logic"](#).

| CONSULT Display                          | DTC Detection Condition   | Possible Cause   |
|--|---|--|
| IPDM EXTERNAL<br>MALF FOR ST1<br>[B20A8] | When comparing the following items, IPDM E/R detects that starter relay is stuck in the ON or OFF position for 1 second or more: <ul style="list-style-type: none"><li>• Starter control circuit is greater than 7.2V.</li><li>• Starting mode BCM ON (CAN) from BCM.</li></ul> or <ul style="list-style-type: none"><li>• Starter control circuit is less than 1.0V.</li><li>• Starting mode BCM OFF (CAN) from BCM.</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors.</li><li>- Starter control circuit short to voltage.</li><li>- Starter control circuit open or short to ground.</li><li>• BCM.</li><li>• IPDM E/R.</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Turn ignition switch ON.
4. Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is DTC B20A8 displayed?

- YES >> Refer to [SEC-75, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592420

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B20A8 CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

##### 2.CHECK STARTER CONTROL CIRCUIT VOLTAGE

Check voltage between IPDM E/R connector and ground.

| IPDM E/R  |          | Ground | Condition       |                                | Voltage<br>(Approx.) |
|-----------|----------|--------|-----------------|--------------------------------|----------------------|
| Connector | Terminal |        | Ignition switch | CVT selector lever             |                      |
| E63       | 33       | —      | ON              | P or N                         | Battery voltage      |
|           |          |        |                 | Any position other than P or N | 0V                   |

##### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO-1 >> Voltage present with CVT selector lever in any position other than P or N, GO TO 3.  
NO-2 >> No voltage present with CVT selector lever in P or N, GO TO 4.

## B20A8 IPDM EXTERNAL MALF FOR ST1

< DTC/CIRCUIT DIAGNOSIS >

### 3. CHECK STARTER CONTROL CIRCUIT FOR SHORT TO VOLTAGE

1. Disconnect IPDM E/R connector E63 and BCM connector M18.
2. Check voltage between IPDM E/R connector and ground.

| IPDM E/R  |          | Ground | Condition       |                                | Voltage<br>(Approx.) |
|-----------|----------|--------|-----------------|--------------------------------|----------------------|
| Connector | Terminal |        | Ignition switch | CVT selector lever             |                      |
| E63       | 33       | —      | ON              | Any position other than P or N | 0V                   |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

### 4. CHECK STARTER CONTROL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Disconnect IPDM E/R connector E63 and BCM connector M18.
2. Check continuity between IPDM E/R connector E63 and BCM connector M18.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

3. Check continuity between IPDM E/R connector E63 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 33       | —      | No         |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

## B20A9 IPDM EXTERNAL MALF FOR ST2

< DTC/CIRCUIT DIAGNOSIS >

### B20A9 IPDM EXTERNAL MALF FOR ST2

#### DTC Logic

INFOID:0000000012592421

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B20A9 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-29, "DTC Logic"](#).
- If DTC B20A9 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-30, "DTC Logic"](#).

| CONSULT Display                          | DTC Detection Condition   | Possible Cause   |
|--|---|--|
| IPDM EXTERNAL<br>MALF FOR ST2<br>[B20A9] | When comparing the following items, IPDM E/R detects that starter control relay is stuck in the OFF position for 1 second or more: <ul style="list-style-type: none"><li>• AD INPUT (IPDM E/R internal terminal) detects intermittent voltage level.</li><li>• Inhibit request ON (CAN) from BCM.</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors.</li><li>- Fusible link is open.</li><li>- Fusible link ignition switch circuit open.</li><li>- Starter control circuit open.</li><li>• BCM.</li><li>• IPDM E/R.</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Turn ignition switch ON.
4. Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

Is DTC B20A9 displayed?

- YES >> Refer to [SEC-77, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592422

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

Is display history of DTC B20A9 CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

##### 2.CHECK FUSIBLE LINK IGNITION SWITCH CIRCUIT VOLTAGE

Check voltage between IPDM E/R connector and ground.

| IPDM E/R  |          | Ground | Voltage<br>(Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal |        |                      |
| E17       | 3        | —      | Battery voltage      |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check fusible link M (40A) and fusible link ignition switch circuit for open. Repair or replace harness or connectors.

##### 3.CHECK STARTER CONTROL CIRCUIT VOLTAGE

Check voltage between IPDM E/R connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B20A9 IPDM EXTERNAL MALF FOR ST2

### < DTC/CIRCUIT DIAGNOSIS >

| IPDM E/R  |          | Ground | Condition       |                                | Voltage<br>(Approx.) |
|-----------|----------|--------|-----------------|--------------------------------|----------------------|
| Connector | Terminal |        | Ignition switch | CVT selector lever             |                      |
| E63       | 33       | —      | ON              | P or N                         | Battery voltage      |
|           |          |        |                 | Any position other than P or N | 0V                   |

#### Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-47. "Removal and Installation"](#).

NO >> GO TO 4.

### 4. CHECK STARTER CONTROL CIRCUIT FOR OPEN

1. Disconnect IPDM E/R connector E63 and BCM connector M18.
2. Check continuity between IPDM E/R connector E63 and BCM connector M18.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

#### Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

## B210B STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B210B STARTER CONTROL RELAY

#### DTC Logic

INFOID:0000000012592423

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210B is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210B is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause   |
|---------|------------------------|--|--|
| B210B   | START CONT RLY ON      | When comparing the following items, IPDM E/R detects that starter control relay is stuck in the ON position for 1 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul> | <ul style="list-style-type: none"><li>• IPDM E/R</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-79, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592424

##### 1.INSPECTION START

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B210B CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

## B210C STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B210C STARTER CONTROL RELAY

#### DTC Logic

INFOID:0000000012592425

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210C is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210C is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the DTC B210C may be detected.

| DTC No. | Trouble diagnosis name     | DTC detecting condition   | Possible cause   |
|---------|----------------------------|---|--|
| B210C   | START CONT RLY<br>OFF CIRC | When comparing the following items, IPDM E/R detects that starter control relay is stuck in the OFF position for 1 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul> | <ul style="list-style-type: none"><li>• IPDM E/R</li><li>• BCM</li><li>• Battery</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-80, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592426

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B210C CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

##### 2.CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

| IPDM E/R  |          | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal |        |                   |
| E63       | 33       | —      | Battery voltage   |

##### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> GO TO 3.



## B210C STARTER CONTROL RELAY

### < DTC/CIRCUIT DIAGNOSIS >

#### 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connector E63 and BCM connector M18.
2. Check continuity between IPDM E/R connector E63 and BCM connector M18.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

3. Check continuity between IPDM E/R connector E63 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 33       | —      | No         |

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B210D STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B210D STARTER RELAY

#### DTC Logic

INFOID:0000000012592427

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210D is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210D is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- If DTC B210D is displayed with DTC B2617, first perform the trouble diagnosis for DTC B2617. Refer to [SEC-124, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B210D   | STARTER RELAY ON CIRC  | When comparing the following items, IPDM E/R detects that starter control relay is stuck in the ON position for 5 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors (starter motor relay control circuit open or short).</li><li>• IPDM E/R</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-82, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592428

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B210D CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

##### 2. CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

| IPDM E/R  |          | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal |        |                   |
| E63       | 33       | —      | Battery voltage   |

##### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> GO TO 3.

## B210D STARTER RELAY

### < DTC/CIRCUIT DIAGNOSIS >

#### 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connectors E63 and BCM connector M18.
2. Check continuity between IPDM E/R connector E63 and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 33       | —      | No         |

Is the inspection result normal?

- YES >> Refer to [SEC-122. "Diagnosis Procedure"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B210E STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B210E STARTER RELAY

#### DTC Logic

INFOID:0000000012592429

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the DTC B210F may be detected.

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause   |
|---------|------------------------|---|--|
| B210E   | STARTER RELAY OFF      | When comparing the following items, IPDM E/R detects that starter control relay is stuck in the OFF position for 5 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul> | <ul style="list-style-type: none"><li>• IPDM E/R</li><li>• BCM</li><li>• Battery</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-84, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592430

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B210E CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-44, "Intermittent Incident"](#).

##### 2. CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

| IPDM E/R  |          | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal |        |                   |
| E63       | 33       | —      | Battery voltage   |

##### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> GO TO 3.

## B210E STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

### 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connector E63 and BCM connector M18
2. Check continuity between IPDM E/R connector E63 and BCM connector M18.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

### B210F TRANSMISSION RANGE SWITCH

#### Description

INFOID:0000000012592431

IPDM E/R confirms the shift position with the following signals:

- Transmission range switch.
- Shift position signal from BCM (CAN).

#### DTC Logic

INFOID:0000000012592432

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210F is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210F is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name    | DTC detecting condition   | Possible cause  |
|---------|---------------------------|---|---|
| B210F   | TRANSMISSION RANGE SWITCH | IPDM E/R detects a mismatch between the signals below for 1 second or more: <ul style="list-style-type: none"><li>• Transmission range switch input signal</li><li>• Shift position signal from BCM (CAN)</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors</li><li>• Transmission range switch circuit is open or shorted.</li><li>• Transmission range switch</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-86, "Diagnosis Procedure"](#).
- NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592433

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#) or [SEC-42, "Wiring Diagram"](#).

##### 1.CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace malfunctioning parts.

##### 2.CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector E63 terminal 37 and ground under following condition.

| IPDM E/R  |          | Ground | Condition          |                         | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--------------------|-------------------------|--------------------------|
| Connector | Terminal |        |                    |                         |                          |
| E63       | 37       | Ground | CVT selector lever | P (Park) or N (Neutral) | Battery voltage          |
|           |          |        |                    | Other than above        | 0                        |

## B210F TRANSMISSION RANGE SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> GO TO 3.

### 3.CHECK TRANSMISSION RANGE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the transmission range switch harness connector.
3. Check continuity between IPDM E/R harness connector F84 terminal 66 and transmission range switch harness connector F85 terminal 2.

| TRANSMISSION RANGE SWITCH |          | IPDM E/R  |          | Continuity |
|---------------------------|----------|-----------|----------|------------|
| Connector                 | Terminal | Connector | Terminal |            |
| F85                       | 2        | F84       | 66       | Yes        |

4. Check continuity between transmission range switch harness connector F85 terminal 2 and ground.

| TRANSMISSION RANGE SWITCH |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| F85                       | 2        | Ground | No         |

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair harness or connector.

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

SEC

## B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

### B2110 TRANSMISSION RANGE SWITCH

#### Description

INFOID:0000000012592434

IPDM E/R confirms the shift position with the following signals:

- Transmission range switch.
- Shift position signal from BCM (CAN).

#### DTC Logic

INFOID:0000000012592435

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2110 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2110 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name    | DTC detecting condition   | Possible cause  |
|---------|---------------------------|---|---|
| B2110   | TRANSMISSION RANGE SWITCH | IPDM E/R detects mismatch between the signal below for 1 second or more: <ul style="list-style-type: none"><li>• Transmission range switch input signal</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors</li><li>Transmission range switch circuit is open or shorted.</li><li>• Transmission range switch</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-88, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592436

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#) or [SEC-42, "Wiring Diagram"](#).

##### 1.CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

##### 2.CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector E63 terminal 37 and ground under following condition:



## B2110 TRANSMISSION RANGE SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

| IPDM E/R  |          | Ground | Condition          |                         | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--------------------|-------------------------|--------------------------|
| Connector | Terminal |        |                    |                         |                          |
| E63       | 37       | Ground | CVT selector lever | P (Park) or N (Neutral) | Battery voltage          |
|           |          |        |                    | Other than above        | 0                        |

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).

NO >> GO TO 3.

### 3. CHECK TRANSMISSION RANGE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the transmission range switch harness connector.
3. Check continuity between IPDM E/R harness connector F84 terminal 66 and transmission range switch harness connector F85 terminal 2.

| TRANSMISSION RANGE SWITCH |          | IPDM E/R  |          | Continuity |
|---------------------------|----------|-----------|----------|------------|
| Connector                 | Terminal | Connector | Terminal |            |
| F85                       | 2        | F84       | 66       | Yes        |

4. Check continuity between transmission range switch harness connector F85 terminal 2 and ground.

| TRANSMISSION RANGE SWITCH |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| F85                       | 2        | Ground | No         |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

### B2190 NATS ANTENNA AMP.

#### Description

INFOID:0000000012592437

Performs ID verification through BCM and Intelligent Key when push-button ignition switch is pressed.  
Prohibits starting of the engine when an unregistered ID of Intelligent Key is used.

#### DTC Logic

INFOID:0000000012592438

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition                                   | Possible cause  |
|---------|------------------------|---|---|
| B2190   | NATS ANTENNA AMP       | Inactive communication between NATS antenna amp. and BCM. | <ul style="list-style-type: none"><li>• Harness or connectors (The NATS antenna amp. circuit is open or shorted.)</li><li>• NATS antenna amp.</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

YES >> GO TO [SEC-90, "Diagnosis Procedure"](#).  
NO >> GO TO 2.

##### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

YES >> GO TO [SEC-90, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592439

Regarding Wiring Diagram information, refer to [SEC-42, "Wiring Diagram"](#).

##### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

##### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Repair or replace as necessary.

##### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

| BCM       |          | NATS antenna amp. |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| M20       | 126      | M40               | 3        | Yes        |
|           | 127      |                   | 1        |            |

2. Check continuity between BCM harness connector and ground.

## B2190 NATS ANTENNA AMP.

### < DTC/CIRCUIT DIAGNOSIS >

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M20       | 126      |        | No         |
|           | 127      |        |            |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK NATS ANTENNA AMP. INPUT SIGNAL

1. Connect BCM connector and NATS antenna amp. connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) BCM   |          | (-)    | Condition  | Signal<br>(Reference value)  |
|-----------|----------|--------|--|--|
| Connector | Terminal |        |  |  |
| M20       | 126, 127 | Ground | When Intelligent Key is in the antenna detection area.     | <br>JMKIA3839GB   |
|           |          |        | When Intelligent Key is not in the antenna detection area. | <br>JMKIA5951GB |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-143, "Removal and Installation"](#).

## B2191 DIFFERENCE OF KEY

< DTC/CIRCUIT DIAGNOSIS >

### B2191 DIFFERENCE OF KEY

#### Description

INFOID:0000000012592440

Performs ID verification through BCM and Intelligent Key when push-button ignition switch is pressed.  
Prohibits starting of the engine when an unregistered ID of Intelligent Key is used.

#### DTC Logic

INFOID:0000000012592441

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B2191   | DIFFERENCE OF KEY      | The ID verification results between BCM and Intelligent Key are NG. The registration is necessary. | <ul style="list-style-type: none"><li>Intelligent Key</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

- Place the back side of the Intelligent Key up to the push-button ignition switch.
- Press the push-button ignition switch.
- Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-92, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592442

##### 1.PERFORM INITIALIZATION

Perform initialization with CONSULT. Re-register all Intelligent Keys.  
For initialization and registration of Intelligent Key, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

##### Can the system be initialized and can the engine be started with re-registered Intelligent Key?

- YES >> Intelligent Key was unregistered.  
NO >> Intelligent Key fob is malfunctioning:
  - Replace Intelligent Key fob.
  - Perform initialization again.

## B2192 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

### B2192 ID DISCORD, IMMU-ECM

#### DTC Logic

INFOID:0000000012592443

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition                                 | Possible cause   |
|---------|------------------------|---|--|
| B2192   | ID DISCORD BCM-ECM     | The ID verification results between BCM and ECM are NG. | <ul style="list-style-type: none"><li>• Harness or connectors<br/>(The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

YES >> GO TO [SEC-93, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592444

##### 1.PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT.

##### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

YES >> Inspection End.

NO >> GO TO 2.

##### 2.CHECK SELF-DIAGNOSIS RESULT

1. Select "Self Diagnostic Result" of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-93, "DTC Logic"](#).

##### Is DTC detected?

YES >> GO TO 3.

NO >> Inspection End.

##### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT.

##### Can the system be initialized and can the engine be started with registered Intelligent Key?

YES >> Inspection End.

NO >> GO TO 4.

##### 4.REPLACE ECM

1. Replace ECM. Refer to [EC-577, "Removal and Installation"](#) (QR25DE) or [EC-1088, "Removal and Installation"](#) (VQ35DE).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-182, "Work Procedure"](#) (QR25DE) or [EC-728, "Work Procedure"](#) (VQ35DE).

>> Inspection End.

## B2193 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

### B2193 CHAIN OF ECM-IMMU

#### DTC Logic

INFOID:0000000012592445

#### DTC DETECTION LOGIC

**NOTE:**

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition                     | Possible cause   |
|---------|------------------------|---|--|
| B2193   | CHAIN OF BCM-ECM       | Inactive communication between BCM and ECM. | <ul style="list-style-type: none"><li>• Harness or connectors<br/>(The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

Is DTC detected?

- YES >> GO TO [SEC-94, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592446

##### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-74, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

##### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-211, "Diagnosis Procedure"](#) (QR25DE) or [EC-758, "Diagnosis Procedure"](#) (VQ35DE).

Is the inspection result normal?

- YES >> Replace ECM. Refer to [EC-577, "Removal and Installation"](#) (QR25DE) or [EC-1088, "Removal and Installation"](#) (VQ35DE). GO TO 3.  
NO >> Repair or replace the harness.

##### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-94, "DTC Logic"](#).

Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Inspection End.

## B2195 ANTI-SCANNING

< DTC/CIRCUIT DIAGNOSIS >

### B2195 ANTI-SCANNING

#### DTC Logic

INFOID:0000000012592447

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause   |
|---------|------------------------|--|--|
| B2195   | ANTI-SCANNING          | ID verification between BCM and ECM that is out of the designated specification is detected. | ID verification request out of the designated specification. |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-95, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592448

##### 1.CHECK SELF DIAGNOSTIC RESULT 1

1. Select "Self Diagnostic Result" of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-95, "DTC Logic"](#).

##### Is DTC detected?

- YES >> GO TO 2.  
NO >> Inspection End.

##### 2.CHECK EQUIPMENT OF THE VEHICLE

Check that unspecified accessory part related to engine start is not installed.

##### Is unspecified accessory part related to engine start installed?

- YES >> GO TO 3.  
NO >> GO TO 4.

##### 3.CHECK SELF DIAGNOSTIC RESULT 2

1. Obtain the customers approval to remove unspecified accessory part related to engine start, and then remove it.
2. Select "Self Diagnostic Result" of "BCM" using CONSULT.
3. Erase DTC.
4. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-95, "DTC Logic"](#).

##### Is DTC detected?

- YES >> GO TO 4.  
NO >> Inspection End.

##### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## B2196 DONGLE UNIT

< DTC/CIRCUIT DIAGNOSIS >

### B2196 DONGLE UNIT

#### Description

INFOID:0000000012592449

BCM performs ID verification between BCM and dongle unit.  
When verification result is OK, BCM permits cranking.

#### DTC Logic

INFOID:0000000012592450

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2196 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2196 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B2196   | DONGLE NG              | The ID verification results between BCM and dongle unit is NG. | <ul style="list-style-type: none"><li>• Harness or connectors (Dongle unit circuit is open or shorted.)</li><li>• Dongle unit</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Check "Self Diagnosis Result" using CONSULT.

##### Is the DTC detected?

- YES >> Refer to [SEC-96, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592451

Regarding Wiring Diagram information, refer to [SEC-42, "Wiring Diagram"](#).

##### 1.PERFORM INITIALIZATION

1. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT.
2. Start the engine.

##### Dose the engine start?

- YES >> Inspection End.  
NO >> GO TO 2.

##### 2.CHECK DONGLE UNIT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and dongle unit connector.
3. Check continuity between BCM harness connector and dongle unit harness connector.

| BCM       |          | Dongle unit |          | Continuity |
|-----------|----------|-------------|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M18       | 52       | M159        | 1        | Yes        |

4. Check continuity between BCM harness connector and ground.



## B2196 DONGLE UNIT

### < DTC/CIRCUIT DIAGNOSIS >

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M18       | 52       |        | No         |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK DONGLE UNIT GROUND CIRCUIT

Check continuity between dongle unit harness connector and ground.

| Dongle unit |          | Ground | Continuity |
|-------------|----------|--------|------------|
| Connector   | Terminal |        |            |
| M159        | 4        |        | Yes        |

Is the inspection result normal?

YES >> Replace dongle unit.

NO >> Repair or replace harness.

SEC

## B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

### B2198 NATS ANTENNA AMP.

#### DTC Logic

INFOID:0000000012592452

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition                                   | Possible cause  |
|---------|------------------------|---|---|
| B2198   | NATS ANTENNA AMP       | Inactive communication between NATS antenna amp. and BCM. | <ul style="list-style-type: none"><li>• Harness or connectors (The NATS antenna amp. circuit is open or shorted.)</li><li>• NATS antenna amp.</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

YES >> GO TO [SEC-98. "Diagnosis Procedure"](#).  
NO >> GO TO 2.

##### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

YES >> GO TO [SEC-98. "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592453

Regarding Wiring Diagram information, refer to [SEC-42. "Wiring Diagram"](#).

##### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

##### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Repair or replace as necessary.

##### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

| BCM       |          | NATS antenna amp. |          | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector         | Terminal |            |
| M20       | 126      | M40               | 3        | Yes        |
|           | 127      |                   | 1        |            |

2. Check continuity between BCM harness connector and ground.

## B2198 NATS ANTENNA AMP.

### < DTC/CIRCUIT DIAGNOSIS >

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M20       | 126      |        | No         |
|           | 127      |        |            |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK NATS ANTENNA AMP. INPUT SIGNAL

1. Connect BCM connector and NATS antenna amp. connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) BCM   |          | (-)    | Condition  | Signal<br>(Reference value)  |
|-----------|----------|--------|--|--|
| Connector | Terminal |        |  |  |
| M20       | 126, 127 | Ground | When Intelligent Key is in the antenna detection area.     | <br>JMKIA3839GB   |
|           |          |        | When Intelligent Key is not in the antenna detection area. | <br>JMKIA5951GB |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-143, "Removal and Installation"](#).

## B2555 STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

### B2555 STOP LAMP

#### DTC Logic

INFOID:0000000012592454

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause   |
|---------|------------------------|---|--|
| B2555   | STOP LAMP              | BCM makes a comparison between the upper voltage and lower voltage of stop lamp switch. It judges from their values to detect the malfunctioning circuit. | <ul style="list-style-type: none"><li>• Harness or connectors (Stop lamp switch circuit is open or shorted.)</li><li>• Stop lamp switch</li><li>• Fuse</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Depress the brake pedal and wait 1 second or more.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-100. "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592455

Regarding Wiring Diagram information, refer to [SEC-29. "Wiring Diagram"](#).

##### 1. CHECK STOP LAMP SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect BCM connector M17.
3. Check voltage between BCM harness connector and ground.

| (+)       |          | (-)    | Condition   |               | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|-------------|---------------|--------------------------|
| BCM       |          |        |             |               |                          |
| Connector | Terminal | Ground | Brake pedal | Depressed     | Battery voltage          |
| M17       | 27       |        |             | Not depressed | 0                        |

##### Is the inspection result normal?

- YES >> GO TO 8.  
NO >> GO TO 2.

##### 2. CHECK POWER SOURCE (STOP LAMP SWITCH)

1. Disconnect stop lamp switch connector.
2. Check voltage between stop lamp switch connector E38 terminal 3 and ground.

| Stop lamp switch |          | Ground | Voltage (V)<br>(Approx.) |
|------------------|----------|--------|--------------------------|
| Connector        | Terminal |        | Battery voltage          |
| E38              | 3        |        |                          |

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check the following:
- Harness for short or open between fuse block (J/B) and stop lamp switch
  - 10A fuse (No. 10, located in fuse block [J/B])

##### 3.CHECK STOP LAMP SWITCH

## B2555 STOP LAMP

### < DTC/CIRCUIT DIAGNOSIS >

Check stop lamp switch. Refer to [SEC-102. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace stop lamp switch. Refer to [BR-21. "Exploded View"](#).

#### 4.CHECK HARNESS BETWEEN STOP LAMP RELAY AND BCM

1. Check continuity between stop lamp relay connector E57 terminal 3 and BCM connector M17 terminal 27.

| BCM       |          | Stop lamp relay |          | Continuity |
|-----------|----------|-----------------|----------|------------|
| Connector | Terminal | Connector       | Terminal |            |
| M17       | 27       | E57             | 3        | Yes        |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

#### 5.CHECK HARNESS BETWEEN STOP LAMP SWITCH AND STOP LAMP RELAY

1. Check continuity between stop lamp relay connector E57 terminal 2 and stop lamp switch connector E38 terminal 4.

| Stop lamp switch |          | Stop lamp relay |          | Continuity |
|------------------|----------|-----------------|----------|------------|
| Connector        | Terminal | Connector       | Terminal |            |
| E38              | 4        | E57             | 2        | Yes        |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

#### 6.CHECK GROUND CIRCUIT (STOP LAMP RELAY)

1. Remove the stop lamp relay.
2. Check continuity between stop lamp relay connector E57 terminal 1 and ground.

| Stop lamp relay |              | Ground | Continuity |
|-----------------|--------------|--------|------------|
| Connector       | Terminal (+) |        |            |
| E57             | 1            |        | Yes        |

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.

#### 7.CHECK POWER SOURCE (STOP LAMP RELAY)

1. Check voltage between stop lamp relay connector E57 terminal 5 and ground.

| Stop lamp relay |              | Ground | Voltage (V)<br>(Approx.) |
|-----------------|--------------|--------|--------------------------|
| Connector       | Terminal (+) |        |                          |
| E57             | 5            |        | Battery voltage          |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace damaged parts.

#### 8.CONNECTOR INSPECTION

Check BCM connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace as necessary.

## B2555 STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

### 9.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 10.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012592456

### 1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch terminals.

| Stop lamp switch |   | Condition   |               | Continuity |
|------------------|---|-------------|---------------|------------|
| Terminal         |   |             |               |            |
| 3                | 4 | Brake pedal | Not depressed | No         |
|                  |   |             | Depressed     | Yes        |

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace stop lamp switch. Refer to [BR-21, "Exploded View"](#).

## B2556 PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

### B2556 PUSH-BUTTON IGNITION SWITCH

#### DTC Logic

INFOID:0000000012592457

#### DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B2556   | PUSH-BTN IGN SW        | BCM detects the push-button ignition switch stuck at ON for 100 seconds or more. | <ul style="list-style-type: none"><li>• Harness or connectors (Push-button ignition switch circuit is shorted.)</li><li>• Push-button ignition switch</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following condition:
  - Brake pedal: Not depressed
2. Release push-button ignition switch and wait 100 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

Is DTC detected?

YES >> GO TO [SEC-103. "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592458

Regarding Wiring Diagram information, refer to [SEC-29. "Wiring Diagram"](#).

##### 1.CHECK PUSH-BUTTON IGNITION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

| (+)                         |          | (-)    | Voltage (V)<br>(Approx.) |
|-----------------------------|----------|--------|--------------------------|
| Push-button ignition switch |          |        |                          |
| Connector                   | Terminal |        |                          |
| M38                         | 8        | Ground | Battery voltage          |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2.

##### 2.CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between push-button ignition switch harness connector and BCM harness connector.

| Push-button ignition switch |          | BCM       |          | Continuity |
|-----------------------------|----------|-----------|----------|------------|
| Connector                   | Terminal | Connector | Terminal |            |
| M38                         | 8        | M17       | 1        | Yes        |

3. Check continuity between push-button ignition switch harness connector and ground.

| Push-button ignition switch |          | Ground | Continuity |
|-----------------------------|----------|--------|------------|
| Connector                   | Terminal |        |            |
| M38                         | 8        |        | No         |

## B2556 PUSH-BUTTON IGNITION SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 4.CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [SEC-104, "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace push-button ignition switch. Refer to [SEC-144, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012592459

### 1.CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

| Push-button ignition switch |   | Condition                   |             | Continuity |
|-----------------------------|---|-----------------------------|-------------|------------|
| Terminal                    |   |                             |             |            |
| 4                           | 8 | Push-button ignition switch | Pressed     | Yes        |
|                             |   |                             | Not pressed | No         |

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace push-button ignition switch. Refer to [SEC-144, "Removal and Installation"](#).



## B2557 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

### B2557 VEHICLE SPEED

#### DTC Logic

INFOID:0000000012592460

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2557 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2557 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible causes  |
|---------|------------------------|--|--|
| B2557   | VEHICLE SPEED          | BCM detects one of the following conditions for 10 seconds continuously: <ul style="list-style-type: none"><li>• Vehicle speed signal from combination meter is 10 km/h (6.2 MPH) or more, and vehicle speed signal from ABS actuator and electric unit (control unit) is 4 km/h (2.5 MPH) or less.</li><li>• Vehicle speed signal from combination meter is 4 km/h (2.5 MPH) or less, and vehicle speed signal from ABS actuator and electric unit (control unit) is 10 km/h (6.2 MPH) or more.</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Combination meter</li><li>• ABS actuator and electric unit (control unit)</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait 10 seconds or more.
2. Drive the vehicle at a vehicle speed of 10 km/h (6.2 MPH) or more for 10 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> GO TO [SEC-105, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592461

##### 1.CHECK DTC OF "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

SEC

Check DTC in "Self Diagnostic Result" of "ABS" using CONSULT.

##### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-224, "DTC Index"](#).  
NO >> GO TO 2.

##### 2.CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnostic Result" of "METER/M&A" using CONSULT.

##### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-29, "DTC Index"](#).  
NO >> GO TO 3.

##### 3.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## B2560 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B2560 STARTER CONTROL RELAY

#### Description

INFOID:0000000012592462

Starter control relay, integrated in IPDM E/R, permits the starter relay operation when in N (Neutral) or P (Park) position.

#### DTC Logic

INFOID:0000000012592463

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2560 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2560 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC   | Self-diagnosis name   | DTC detecting condition  | Possible causes  |
|-------|-----------------------|--|--|
| B2560 | STARTER CONTROL RELAY | BCM detects a mismatch between the OFF request of starter control relay to IPDM E/R and the feedback. (The feedback is ON instead of OFF.) | <ul style="list-style-type: none"><li>• IPDM E/R</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 2 seconds:
  - CVT selector lever is in the P (Park) position.
  - Depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-106, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592464

##### 1.CHECK DTC WITH IPDM E/R

Check "Self Diagnostic Result" using CONSULT. Refer to [PCS-21, "DTC Index"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

##### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## B2601 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2601 SHIFT POSITION

#### DTC Logic

INFOID:0000000012592465

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2601 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2601 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause   |
|---------|------------------------|---|--|
| B2601   | SHIFT POSITION         | When there is a difference between P (Park) range signal from CVT shift selector (park position switch) and P (Park) position signal from IPDM E/R (CAN). | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors [CVT shift selector (park position switch) circuit is open or shorted.]</li><li>• CVT shift selector (park position switch)</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 2 seconds or more.
3. Shift the selector lever to any position other than P (Park) and wait 2 seconds or more.
4. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-107, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592466

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "DETENT SW - IPDM" in "Data Monitor" using CONSULT.
3. Check "DETE/CANCEL SW" and "DETENT SW - IPDM" indication under the following conditions:

| Monitor item     | Condition          |                                     | Indication |
|------------------|--------------------|-------------------------------------|------------|
| DETE/CANCEL SW   | CVT Shift selector | In any position other than P (Park) | OFF        |
|                  |                    | P (Park)                            | ON         |
| DETENT SW - IPDM | CVT Shift selector | In any position other than P (Park) | OFF        |
|                  |                    | P (Park)                            | ON         |

##### Is the inspection result normal?

- YES >> Refer to [GI-44, "Intermittent Incident"](#).  
NO-1 >> If "DETE/CANCEL SW" function is incorrect. GO TO 2.  
NO-2 >> If "DETENT SW - IPDM" function is incorrect. GO TO 5.

##### 2.CHECK CVT SHIFT SELECTOR CIRCUIT (BCM)

1. Disconnect BCM connector and IPDM E/R connector.

## B2601 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

| CVT shift selector (park position switch) |          | BCM       |          | Continuity |
|---|----------|-----------|----------|------------|
| Connector                                 | Terminal | Connector | Terminal |            |
| M23                                       | 6        | M17       | 20       | Yes        |

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

| CVT shift selector (park position switch) |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                                 | Terminal |        |            |
| M23                                       | 6        |        | No         |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CONNECTOR INSPECTION

1. Disconnect BCM.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace as necessary.

### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 5.CHECK CVT SHIFT SELECTOR CIRCUIT (IPDM E/R)

Check continuity between CVT shift selector (park position switch) harness connector and IPDM E/R harness connector.

| CVT shift selector (park position switch) |          | IPDM E/R  |          | Continuity |
|---|----------|-----------|----------|------------|
| Connector                                 | Terminal | Connector | Terminal |            |
| M23                                       | 6        | E63       | 31       | Yes        |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

### 6.CONNECTOR INSPECTION

1. Disconnect IPDM E/R.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace as necessary.

### 7.REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012592467

### 1.CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.

## B2601 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

| CVT shift selector (park position switch) |   | Condition      |                   | Continuity |
|---|---|----------------|-------------------|------------|
| Terminal                                  |   |                |                   |            |
| 5   | 6 | Selector lever | P (Park) position | No         |
|   |   |                | Other than above  | Yes        |

#### Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace CVT shift selector. Refer to [TM-186. "Removal and Installation"](#) (RE0F10D) or [TM-389. "Removal and Installation"](#) (RE0F10H).

SEC

## B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2602 SHIFT POSITION

#### DTC Logic

INFOID:0000000012592468

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2602 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2602 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause   |
|---------|------------------------|--|--|
| B2602   | SHIFT POSITION         | BCM detects the following status for 10 seconds: <ul style="list-style-type: none"><li>• Selector lever is in the P (Park) position.</li><li>• Vehicle speed is 4 km/h (2.5 MPH) or more.</li><li>• Ignition switch is in the ON position.</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors [CVT shift selector (park position switch) circuit is open or shorted.]</li><li>• CVT shift selector (park position switch)</li><li>• Combination meter</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine.
2. Drive vehicle at a speed of 4 km/h (2.5 MPH) or more for 10 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-110, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592469

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "VEH SPEED 1" in "Data Monitor" using CONSULT.
3. Check "DETE/CANCEL SW" and "VEH SPEED 1" indication under the following conditions:

| Monitor item   | Condition          |                                     | Indication |
|----------------|--------------------|-------------------------------------|------------|
| DETE/CANCEL SW | CVT Shift selector | In any position other than P (Park) | OFF        |
|                |                    | P (Park)                            | ON         |
| VEH SPEED 1    | Vehicle not moving |                                     | 0          |
|                | Vehicle moving     |                                     | Varies     |

##### Is the inspection result normal?

- YES >> Refer to [GI-44, "Intermittent Incident"](#).  
NO-1 >> If "DETE/CANCEL SW" is incorrect. GO TO 4.  
NO-2 >> If "VEH SPEED 1" is incorrect. GO TO 2.

##### 2.CHECK DTC OF COMBINATION METER

Check DTC in "Self Diagnostic Result" of "METER/M&A" using CONSULT.

## B2602 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-224, "DTC Index"](#).  
NO >> GO TO 3.

### 3.CHECK DTC OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check DTC in "Self Diagnostic Result" of "ABS" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-224, "DTC Index"](#).  
NO >> GO TO 6.

### 4.CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

| CVT shift selector (park position switch) |          | BCM       |          | Continuity |
|---|----------|-----------|----------|------------|
| Connector                                 | Terminal | Connector | Terminal |            |
| M23                                       | 6        | M17       | 20       | Yes        |

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

| CVT shift selector (park position switch) |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                                 | Terminal |        |            |
| M23                                       | 6        |        | No         |

#### Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace harness.

### 5.CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-111, "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Replace CVT shift selector. Refer to [TM-186, "Removal and Installation"](#) (RE0F10D) or [TM-389, "Removal and Installation"](#) (RE0F10H).

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012592470

### 1.CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

| CVT shift selector (park position switch) |   | Condition      |                   | Continuity |
|---|---|----------------|-------------------|------------|
| Terminal                                  |   |                |                   |            |
| 5   | 6 | Selector lever | P (Park) position | No         |
|   |   |                | Other than above  | Yes        |

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace CVT shift selector. Refer to [TM-186, "Removal and Installation"](#) (RE0F10D) or [TM-389, "Removal and Installation"](#) (RE0F10H).

## B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2603 SHIFT POSITION

#### DTC Logic

INFOID:0000000012592471

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2603 is displayed with DTC B2601, first perform the trouble diagnosis for DTC B2601. Refer to [SEC-107, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible causes  |
|---------|------------------------|---|--|
| B2603   | SHIFT POSI STATUS      | BCM detects the following status when ignition switch is in the ON position: <ul style="list-style-type: none"><li>P (Park) position signal from transmission range switch: approx. 0 V</li><li>CVT shift selector (park position switch) signal: approx. 0 V</li></ul> | <ul style="list-style-type: none"><li>Harness or connector [CVT shift selector (park position switch) circuit is open or shorted.]</li><li>Harness or connectors (Transmission range switch circuit is open or shorted.)</li><li>CVT shift selector (park position switch)</li><li>Transmission range switch</li><li>BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

- Shift the selector lever to the P (Park) position.
- Turn ignition switch ON and wait 1 second or more.
- Check DTC in "Self Diagnostic Result" of BCM using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-112, "Diagnosis Procedure"](#).  
NO >> GO TO 2.

##### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

- Shift the selector lever to any position other than P (Park) and wait 1 second or more.
- Check DTC in "Self Diagnostic Result" of BCM using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-112, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592472

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

- Turn ignition switch ON.
- Select "DETE/CANCEL SW" and "SFT PN/N SW" in "Data Monitor" using CONSULT.
- Check "DETE/CANCEL SW" and "SFT PN/N SW" indication under the following conditions:

| Monitor item   | Condition          |                                     | Indication |
|----------------|--------------------|-------------------------------------|------------|
| DETE/CANCEL SW | CVT Shift selector | In any position other than P (Park) | OFF        |
|                |                    | P (Park)                            | ON         |
| SFT PN/N SW    | CVT Shift selector | In any position other than P (Park) | OFF        |
|                |                    | P (Park)                            | ON         |

##### Is the inspection result normal?

- YES >> Refer to [GI-44, "Intermittent Incident"](#).



## B2603 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

NO-1 >> If "DETE/CANCEL SW" is incorrect. GO TO 6.

NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 2.

### 2.CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

| (+)       |          | (-)    | Condition      |                  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|----------------|------------------|--------------------------|
| BCM       |          |        |                |                  |                          |
| Connector | Terminal |        |                |                  |                          |
| M17       | 39       | Ground | Selector lever | P or N position  | Battery voltage          |
|           |          |        |                | Other than above | 0                        |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

### 3.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect transmission range switch connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

| Transmission range switch |          | BCM       |          | Continuity |
|---------------------------|----------|-----------|----------|------------|
| Connector                 | Terminal | Connector | Terminal |            |
| F85                       | 2        | M17       | 39       | Yes        |

5. Check continuity between transmission range switch harness connector and ground.

| Transmission range switch |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| F85                       | 2        |        | No         |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 5.CHECK DTC OF TCM

Check DTC in "Self Diagnostic Result" of "TCM" using CONSULT.

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-60, "DTC Index"](#) (RE0F10D) or [TM-267, "DTC Index"](#) (RE0F10H).

NO >> Perform the trouble diagnosis related to the TCM power and ground circuits. Refer to [TM-171, "Diagnosis Procedure"](#) (RE0F10D) or [TM-377, "Diagnosis Procedure"](#) (RE0F10H).

### 6.CHECK CVT SHIFT SELECTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector (park position switch) connector.
3. Check voltage between CVT shift selector (park position switch) harness connector and ground.

## B2603 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

| (+)                                       |          | (-)    | Voltage (V)<br>(Approx.) |
|---|----------|--------|--------------------------|
| CVT shift selector (park position switch) |          |        |                          |
| Connector                                 | Terminal |        |                          |
| M23                                       | 5        | Ground | Battery voltage          |

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

### 7. CHECK CVT SHIFT SELECTOR POWER SUPPLY CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

| CVT shift selector (park position switch) |          | BCM       |          | Continuity |
|---|----------|-----------|----------|------------|
| Connector                                 | Terminal | Connector | Terminal |            |
| M23                                       | 5        | M18       | 69       | Yes        |

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

| CVT shift selector (park position switch) |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                                 | Terminal |        |            |
| M23                                       | 5        |        | No         |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).

NO >> Repair or replace harness.

### 8. CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

| CVT shift selector (park position switch) |          | BCM       |          | Continuity |
|---|----------|-----------|----------|------------|
| Connector                                 | Terminal | Connector | Terminal |            |
| M23                                       | 6        | M17       | 20       | Yes        |

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

| CVT shift selector (park position switch) |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                                 | Terminal |        |            |
| M23                                       | 6        |        | No         |

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

### 9. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-115. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace CVT shift selector. Refer to [TM-186. "Removal and Installation"](#) (RE0F10D) or [TM-389. "Removal and Installation"](#) (RE0F10H).

### 10. REPLACE BCM

1. Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

## B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

>> Inspection End.

### Component Inspection

INFOID:0000000012592473

#### 1. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

| CVT shift selector (park position switch) |   | Condition      |                   | Continuity |
|---|---|----------------|-------------------|------------|
| Terminal                                  |   |                |                   |            |
| 5   | 6 | Selector lever | P (Park) position | No         |
|   |   |                | Other than above  | Yes        |

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace CVT shift selector. Refer to [TM-186, "Removal and Installation"](#) (RE0F10D) or [TM-389, "Removal and Installation"](#) (RE0F10H).

SEC

## B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2604 SHIFT POSITION

#### DTC Logic

INFOID:0000000012592474

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2604 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2604 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause   |
|---------|------------------------|--|--|
| B2604   | PNP/CLUTCH SW          | The following states are detected for 5 seconds while ignition switch is ON: <ul style="list-style-type: none"><li>• P/N position signal is sent from IPDM E/R but shift position signal input from transmission range switch is other than P (Park) and N (Neutral).</li><li>• P/N position signal is not sent from IPDM E/R but shift position signal input from transmission range switch is P (Park) or N (Neutral).</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors (transmission range switch circuit is open or shorted.)</li><li>• Transmission range switch</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 5 seconds or more.
3. Shift the selector lever to the N (Neutral) position and wait 5 seconds or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 5 seconds or more.
5. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-116, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592475

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" in "Data Monitor" using CONSULT.
3. Check "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" indication under the following conditions:

| Monitor item | Condition          |  | Indication |
|--------------|--------------------|--|------------|
| SFT P -MET   | CVT Shift selector | Selector lever is in any position except the P (Park) position.    | OFF        |
|              |                    | Selector lever is in the P (Park) position.                        | ON         |
| SFT N -MET   | CVT Shift selector | Selector lever is in any position except the N (Neutral) position. | OFF        |
|              |                    | Selector lever is in the N (Neutral) position.                     | ON         |

## B2604 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

| Monitor item | Condition          |  | Indication |
|--------------|--------------------|--|------------|
| SFT PN/N SW  | CVT Shift selector | Selector lever is in and position except the P (Park) or N (Neutral) position. | OFF        |
|              |                    | Selector lever is in the P (Park) or N (Neutral) position.                     | ON         |

#### Is the inspection result normal?

YES >> Refer to [GI-44, "Intermittent Incident"](#).

NO-1 >> If "SFT N -MET" or "SFT P -MET" is incorrect. GO TO 7.

NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 2.

### 2.CHECK DTC OF TCM

Check DTC in "Self Diagnostic Result" of "TCM" using CONSULT.

#### Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-60, "DTC Index"](#) (RE0F10D) or [TM-267, "DTC Index"](#) (RE0F10H).

NO >> GO TO 3.

### 3.CHECK BCM INPUT SIGNAL

Check voltage between BCM harness connector and ground.

| (+)       |          | (-)    | Condition      |                                  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|----------------|----------------------------------|--------------------------|
| BCM       |          |        |                |                                  |                          |
| Connector | Terminal |        |                |                                  |                          |
| M17       | 39       | Ground | Selector lever | P (Park) or N (Neutral) position | Battery voltage          |
|           |          |        |                | Other than above                 | 0                        |

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 5.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect transmission range switch connector.

3. Disconnect BCM connector.

4. Check continuity between transmission range switch harness connector and BCM harness connector.

| Transmission Range Switch |          | BCM       |          | Continuity |
|---------------------------|----------|-----------|----------|------------|
| Connector                 | Terminal | Connector | Terminal |            |
| F85                       | 2        | M17       | 39       | Yes        |

5. Check continuity between transmission range switch harness connector and ground.

| Transmission Range Switch |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| F85                       | 2        |        | No         |

#### Is the inspection result normal?

YES >> GO TO 6.

## B2604 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

### 7.CHECK CVT SHIFT SELECTOR RANGE SWITCH FUNCTION (METER)

1. Select "SHIFT IND" in "Data Monitor" of "METER" using CONSULT.
2. Check "SHIFT IND" indication under the following conditions:

| Monitor item | Condition          |                      | Indication |
|--------------|--------------------|----------------------|------------|
| SHIFT IND    | CVT Shift selector | P (Park) position    | P          |
|              |                    | N (Neutral) position | N          |

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [TM-104, "Component Inspection"](#) (RE0F10D) or [TM-310, "Component Inspection"](#) (RE0F10H).

## B2605 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2605 SHIFT POSITION

#### DTC Logic

INFOID:0000000012592476

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2605 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2605 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B2605   | PNP/CLUTCH SW          | When ignition switch is ON, P/N position signal input from transmission range switch and P/N position signal (CAN) input from IPDM E/R do not match. | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors (Transmission range switch circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 1 second or more.
3. Shift the selector lever to the N (Neutral) position and wait 1 second or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 1 second or more.
5. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-119, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592477

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "SFT PN-IPDM" and "SFT PN/N SW" in "Data Monitor" using CONSULT.
3. Check "SFT PN-IPDM" and "SFT PN/N SW" indication under the following conditions:

| Monitor item | Condition          |   | Indication |
|--------------|--------------------|---|------------|
| SFT PN-IPDM  | CVT Shift selector | Any position other than P (Park) or N (Neutral) position. | OFF        |
|              |                    | P (Park) or N (Neutral) position                          | ON         |
| SFT PN/N SW  | CVT Shift selector | Any position other than P (Park) or N (Neutral) position. | OFF        |
|              |                    | P (Park) or N (Neutral) position                          | ON         |

##### Is the inspection result normal?

- YES >> Refer to [GI-44, "Intermittent Incident"](#).  
NO-1 >> If "SFT PN-IPDM" is incorrect. GO TO 2.  
NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 5.

## B2605 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

#### 2. CHECK IPDM E/R INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

| (+)       |          | (−)    | Condition      |                                  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|----------------|----------------------------------|--------------------------|
| IPDM E/R  |          |        |                |                                  |                          |
| Connector | Terminal |        |                |                                  |                          |
| F84       | 66       | Ground | Selector lever | P (Park) or N (Neutral) position | Battery voltage          |
|           |          |        |                | Other than above                 | 0                        |

#### Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).

NO >> GO TO 3.

#### 3. CHECK IPDM E/R INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between IPDM E/R harness connector and BCM harness connector.

| IPDM E/R  |          | Transmission Range Switch |          | Continuity |
|-----------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector                 | Terminal |            |
| E63       | 37       | F85                       | 2        | Yes        |

4. Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 37       |        | No         |

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

#### 4. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).

>> Inspection End.

#### 5. CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

| (+)       |          | (-)    | Condition      |                                  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|----------------|----------------------------------|--------------------------|
| BCM       |          |        |                |                                  |                          |
| Connector | Terminal |        |                |                                  |                          |
| M17       | 39       | Ground | Selector lever | P (Park) or N (Neutral) position | Battery voltage          |
|           |          |        |                | Other than above                 | 0                        |

#### Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 7.

#### 6. REPLACE BCM



## B2605 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 7. CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Disconnect BCM connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

| Transmission Range Switch |          | BCM       |          | Continuity |
|---------------------------|----------|-----------|----------|------------|
| Connector                 | Terminal | Connector | Terminal |            |
| F85                       | 2        | M17       | 39       | Yes        |

5. Check continuity between transmission range switch harness connector and ground.

| Transmission Range Switch |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| F85                       | 2        |        | No         |

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

### 8. CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

SEC

## B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B2608 STARTER RELAY

#### DTC Logic

INFOID:0000000012592478

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2608 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2608 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition  | Possible cause  |
|---------|------------------------|--|---|
| B2608   | STARTER RELAY          | BCM outputs starter motor relay OFF signal but BCM receives starter motor relay ON signal from IPDM E/R (CAN). | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine:
  - Shift selector lever: In the P (Park) position.
  - Brake pedal: Depressed
2. Wait 1 second after engine started.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-122, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592479

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK DTC OF IPDM E/R

Check DTC in "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [PCS-21, "DTC Index"](#).  
NO >> GO TO 2.

##### 2.CHECK BCM POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

| (+) BCM   |          | (-)    | Condition      |                                  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|----------------|----------------------------------|--------------------------|
| Connector | Terminal |        |                |                                  |                          |
| M18       | 62       | Ground | Selector lever | N (Neutral) or P (Park) position | Battery voltage          |
|           |          |        |                | Other than above                 | 0                        |

##### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 3.

## B2608 STARTER RELAY

### < DTC/CIRCUIT DIAGNOSIS >

#### 3.CHECK STARTER RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Disconnect BCM connector.
4. Check continuity between IPDM E/R harness connector and BCM harness connector.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

5. Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 33       |        | No         |

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

SEC

## B2617 STARTER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### B2617 STARTER RELAY CIRCUIT

#### Description

INFOID:0000000012592480

Located in IPDM E/R, it runs the starter motor. The starter relay is turned ON by the BCM when the ignition switch is in START position. IPDM E/R transmits the starter relay ON signal to BCM via CAN communication.

#### DTC Logic

INFOID:0000000012592481

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2617 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2617 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause   |
|---------|------------------------|---|--|
| B2617   | STARTER RELAY CIRCUIT  | <ul style="list-style-type: none"><li>• An immediate operation of starter relay is requested by BCM, but there is no response for more than 1 second.</li><li>• BCM is not commanding starter relay activation, but BCM detects starter relay output is active.</li></ul> | <ul style="list-style-type: none"><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• BCM</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-124, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592482

Regarding Wiring Diagram information, refer to [SEC-29, "Wiring Diagram"](#).

##### 1.CHECK STARTER RELAY

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground under the following condition.

| BCM       |          | Ground | Condition                            | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--------------------------------------|--------------------------|
| Connector | Terminal |        |                                      |                          |
| M18       | 62       | Ground | Ignition switch cranking             | 0                        |
|           |          |        | Ignition switch ON (Park or Neutral) | Battery voltage          |
|           |          |        | Other than above                     | 0                        |

##### Is the measurement value within the specification.

- YES >> GO TO 3.  
NO >> GO TO 2.

##### 2.CHECK STARTER RELAY CIRCUIT

## B2617 STARTER RELAY CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector and IPDM E/R harness connector.
3. Check continuity between IPDM E/R harness connector and BCM harness connector.

| IPDM E/R  |          | BCM       |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E63       | 33       | M18       | 62       | Yes        |

4. Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E63       | 33       | Ground | No         |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Repair harness or connector.

### 3.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

### B261E VEHICLE TYPE

#### DTC Logic

INFOID:0000000012592484

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B261E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B261E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition          | Possible cause  |
|---------|------------------------|----------------------------------|---|
| B261E   | VEHICLE TYPE           | Difference of BCM configuration. | <ul style="list-style-type: none"><li>• BCM mis-configuration</li><li>• Wrong ECM installed</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions:
  - Shift selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> GO TO [SEC-126, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592485

##### 1.INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure. Refer to [SEC-126, "DTC Logic"](#).

##### Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 2.  
NO >> Inspection End.

##### 2.PERFORM BCM CONFIGURATION.

Perform the BCM configuration. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 3.

##### 3.INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
Refer to [SEC-126, "DTC Logic"](#).

##### Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 4.  
NO >> Inspection End.

##### 4.CONFIRM ECM PART NUMBER.

Confirm the part number of the installed ECM is correct.

##### Is the ECM part number correct?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

NO     >> Replace ECM. Refer to [EC-577. "Removal and Installation"](#) (QR25DE) or [EC-1088. "Removal and Installation"](#) (VQ35DE).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B26F4 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B26F4 STARTER CONTROL RELAY

#### DTC Logic

INFOID:0000000012592486

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B26F4 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B26F4 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

| DTC No. | Trouble diagnosis name | DTC detecting condition   | Possible cause  |
|---------|------------------------|---|---|
| B26F4   | START CONT RELAY OFF   | BCM requests IPDM E/R to turn starter control relay ON, but BCM cannot receive starter control relay ON state signal from IPDM E/R. | <ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• IPDM E/R</li></ul> |

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Shift selector lever: In the P (Park) position
  - Brake pedal: Depressed
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> GO TO [SEC-128, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012592487

##### 1.CHECK DTC OF IPDM E/R

Check DTC in "Self-Diagnostic Result" mode of "IPDM E/R" using CONSULT.

##### Is DTC detected?

- YES >> Perform the diagnosis procedure related to the detected DTC. Refer to [PCS-21, "DTC Index"](#).  
NO >> GO TO 2.

##### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:0000000012829251

Regarding Wiring Diagram information, refer to [BCS-55. "Wiring Diagram"](#).

### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Terminal No. | Signal name                | Fuse and fusible link No. |
|--------------|----------------------------|---------------------------|
| 139          | Fusible link battery power | I (40A)                   |
| 131          | BCM battery fuse           | 1 (10A)                   |

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.  
NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M21.
2. Check voltage between BCM connector M21 terminals 131, 139 and ground.

| BCM       |          | Ground | Voltage<br>(Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal |        |                      |
| M21       | 131      | —      | Battery voltage      |
|           | 139      |        |                      |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M21 terminals 134, 143 and ground.

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M21       | 134      | —      | Yes        |
|           | 143      |        |            |

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:0000000012829252

Regarding Wiring Diagram information, refer to [PCS-23. "Wiring Diagram"](#).

### 1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

| Terminal No. | Signal name                  | Fusible link No.            |
|--------------|------------------------------|-----------------------------|
| 1            | Fusible link main            | E (80A)                     |
| 2            | Fusible link IPDM E/R        | A (250A), C (80A)           |
| 3            | Fusible link ignition switch | A (250A), B (100A), M (40A) |

Is the fusible link blown?

YES >> Replace the blown fusible link after repairing the affected circuit.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E16 and E17.
2. Check voltage between IPDM E/R connectors and ground.

| IPDM E/R  |          | Ground | Voltage<br>(Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal |        |                      |
| E16       | 1        | —      | Battery voltage      |
|           | 2        |        |                      |
| E17       | 3        |        |                      |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E18 and E63.
2. Check continuity between IPDM E/R connectors and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E18       | 7        | —      | Yes        |
| E63       | 41       |        |            |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

# HEADLAMP FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP FUNCTION

### Component Function Check

INFOID:0000000012592490

#### 1.CHECK FUNCTION

1. Perform "HEAD LAMP(HI)" in "Active Test" of "THEFT ALM" in "BCM" using CONSULT.
2. Check headlamps operation.

| Test item      |     | Description    |              |
|----------------|-----|----------------|--------------|
| HEAD LAMP (HI) | ON  | Headlamps (Hi) | Light        |
|                | OFF |                | Do not light |

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SEC-131, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012592491

#### 1.CHECK HEADLAMP FUNCTION

Refer to [SEC-131, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

SEC

# HOOD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## HOOD SWITCH

### Component Function Check

INFOID:0000000012592492

#### 1.CHECK FUNCTION

1. Select "HOOD SW" in "Data Monitor" of "IPDM E/R" using CONSULT.
2. Check "HOOD SW" indication under the following condition:

| Monitor item | Condition |       | Indication |
|--------------|-----------|-------|------------|
| HOOD SW      | Hood      | Open  | OFF        |
|              |           | Close | ON         |

Is the indication normal?

- YES >> Hood switch is OK.  
NO >> Go to [SEC-132, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012592493

Regarding Wiring Diagram information, refer to [SEC-52, "Wiring Diagram"](#).

#### 1.CHECK HOOD SWITCH SIGNAL CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect hood switch connector.
3. Check voltage between hood switch harness connector and ground.

| (+)         |          | (-)    | Voltage (V)<br>(Approx.) |
|-------------|----------|--------|--------------------------|
| Hood switch |          |        |                          |
| Connector   | Terminal |        |                          |
| E248        | 1        | Ground | Battery voltage          |
|             | 2        |        |                          |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK HOOD SWITCH SIGNAL CIRCUITS

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and hood switch harness connector.

| IPDM E/R  |          | Hood switch |          | Continuity |
|-----------|----------|-------------|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| E201      | 94       | E248        | 1        | Yes        |
|           | 96       |             | 2        |            |

3. Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R  |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E201      | 94       |        | No         |
|           | 96       |        |            |

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-47, "Removal and Installation"](#).  
NO >> Repair or replace harness.

# HOOD SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

### 3.CHECK HOOD SWITCH GROUND CIRCUIT

Check continuity between hood switch harness connector and ground.

| Hood switch |          | Ground | Continuity |
|-------------|----------|--------|------------|
| Connector   | Terminal |        |            |
| E248        | 3        |        | Yes        |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK HOOD SWITCH

Refer to [SEC-133, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace hood switch. Refer to [DLK-173, "HOOD LOCK CONTROL : Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012592494

### 1.CHECK HOOD SWITCH

1. Turn ignition switch OFF.
2. Disconnect hood switch connector.
3. Check continuity between hood switch terminals.

| Hood switch |   | Condition   |         | Continuity |
|-------------|---|-------------|---------|------------|
| Terminal    |   |             |         |            |
| 1           | 3 | Hood switch | Press   | Yes        |
|             |   |             | Release | No         |
| 2           |   |             | Press   | No         |
|             |   |             | Release | Yes        |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace hood switch. Refer to [DLK-173, "HOOD LOCK CONTROL : Removal and Installation"](#).

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

## SECURITY INDICATOR LAMP

### Component Function Check

INFOID:0000000012592495

#### 1.CHECK FUNCTION

1. Perform "THEFT IND" in "Active Test" of "IMMU" in "BCM" using CONSULT.
2. Check security indicator lamp operation.

| Test item |     | Description             |                     |
|-----------|-----|-------------------------|---------------------|
| THEFT IND | ON  | Security indicator lamp | Illuminates         |
|           | OFF |                         | Does not illuminate |

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Go to [SEC-134, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012592496

Regarding Wiring Diagram information, refer to [SEC-52, "Wiring Diagram"](#).

#### 1.CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check voltage between combination meter harness connector and ground.

| (+)<br>Combination meter |          | (-)    | Voltage (V)<br>(Approx.) |
|--------------------------|----------|--------|--------------------------|
| Connector                | Terminal |        |                          |
| M24                      | 22       | Ground | Battery voltage          |

Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Check 10 A fuse [No. 13, located in the fuse block (J/B)].  
NO-2 >> Check harness for open or short between combination meter and fuse.

#### 2.CHECK SECURITY INDICATOR LAMP SIGNAL

1. Connect combination meter connector.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

| (+)<br>BCM |          | (-)    | Voltage (V)<br>(Approx.) |
|------------|----------|--------|--------------------------|
| Connector  | Terminal |        |                          |
| M17        | 18       | Ground | Battery voltage          |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 4.

#### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

### 4. CHECK SECURITY INDICATOR LAMP CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector and BCM harness connector.

| Combination meter |          | BCM       |          | Continuity |
|-------------------|----------|-----------|----------|------------|
| Connector         | Terminal | Connector | Terminal |            |
| M24               | 6        | M17       | 18       | Yes        |

3. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M24               | 6        |        | No         |

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-83. "Removal and Installation"](#).  
NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# INTELLIGENT KEY SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTELLIGENT KEY SYSTEM SYMPTOMS

#### Diagnosis Procedure

INFOID:0000000013317007

#### NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

#### SYMPTOM TABLE 1 (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

| No. | Door lock operation<br>(remote keyless entry) | Door lock operation<br>(request switch) | Engine started with<br>push-button ignition<br>switch operation (registered Intelligent Key is within the detection area of inside key antenna) | Engine started with<br>push-button ignition<br>switch operation (registered Intelligent Key placed next to push-button ignition switch) | Symptom                 |
|-----|---|---|---|---|-------------------------|
| 1   | OK  | OK                                      | No start  | No start  | <a href="#">SEC-137</a> |
| 2   | OK  | NG                                      | OK  | OK  | <a href="#">DLK-150</a> |
| 3   | OK  | NG                                      | No crank, No start  | OK  | <a href="#">DLK-152</a> |
| 4   | NG  | NG                                      | No crank, No start  | OK  | <a href="#">DLK-154</a> |
| 5   | NG  | NG                                      | No start  | No start  | <a href="#">DLK-155</a> |
| 6   | OK  | OK                                      | No crank, No start  | OK  | <a href="#">SEC-138</a> |
| 7   | NG  | OK                                      | OK  | OK  | <a href="#">DLK-157</a> |
| 8   | NG  | NG                                      | OK  | OK  | <a href="#">DLK-158</a> |
| 9   | Poor range                                    | OK                                      | OK  | OK  | <a href="#">DLK-159</a> |

#### SYMPTOM TABLE 2 (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

| No. | Door lock operation<br>(remote keyless entry) | Door lock operation<br>(request switch) | Engine started with<br>push-button ignition<br>switch operation (Intelligent Key is within the detection area of inside key antenna) | Engine started with<br>push-button ignition<br>switch operation (registered Intelligent Key placed next to push-button ignition switch) | Symptom                 |
|-----|---|---|--|---|-------------------------|
| 1   | NG  | OK                                      | OK   | OK  | <a href="#">DLK-161</a> |
| 2   | NG  | NG                                      | No crank, No start   | OK  | <a href="#">DLK-162</a> |
| 3   | NG  | NG                                      | No crank, No start   | No crank, No start  | <a href="#">DLK-164</a> |
| 4   | OK  | OK                                      | No crank, No start   | No crank, No start  | <a href="#">SEC-140</a> |
| 5   | OK  | NG                                      | No crank, No start   | OK  | <a href="#">SEC-141</a> |
| 6   | Poor range                                    | OK                                      | OK   | OK  | <a href="#">DLK-166</a> |



# ENGINE CAN NOT START

< SYMPTOM DIAGNOSIS >

## ENGINE CAN NOT START

### Description

INFOID:0000000013317008

Engine does not start when push-button ignition switch is pressed.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

| Door lock operation (remote keyless entry) | Door lock operation (request switch) | Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna) | Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch) |
|--|--------------------------------------|---|---|
| OK   | OK                                   | No start  | No start  |

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

"ENGINE START BY I-KEY" setting in "Work support" mode of "INTELLIGENT KEY" of "BCM" is ON.

### DIAGNOSIS PROCEDURE

Refer to [SEC-137, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000013317009

#### 1.CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-149, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSIS RESULT

Select "Self Diagnostic Result" mode of all systems, and check if DTC is detected.

>> Follow troubleshooting for each DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

< SYMPTOM DIAGNOSIS >

## ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

### Description

INFOID:0000000013317010

Engine does not start when push-button ignition switch is pressed while carrying Intelligent Key.

#### NOTE:

- Before starting diagnosis check that vehicle condition is as shown in “Conditions of vehicle”, and check each symptom.
- The engine start function, door lock function, power distribution system, and NATS-IVIS/NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

| Door lock operation (remote keyless entry) | Door lock operation (request switch) | Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna) | Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch) |
|--|--------------------------------------|---|---|
| OK   | OK                                   | No crank, No start  | OK  |

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- “ENGINE START BY I-KEY” setting in “Work support” mode of “INTELLIGENT KEY” of “BCM” is ON.
- One or more Intelligent Keys with a registered Intelligent Key ID are in the vehicle.

### DIAGNOSIS PROCEDURE

Refer to [SEC-138, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000013317011

#### 1.CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-149, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSIS RESULT

Select “Self Diagnostic Result” mode of “BCM”, and check if DTC is detected.

Is DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC.

NO >> GO TO 3.

#### 3.CHECK “ENGINE START BY I-KEY” SETTING IN “WORK SUPPORT”

1. Select “INTELLIGENT KEY” of “BCM” using CONSULT.

2. Select “ENGINE START BY I-KEY” of “Work support” mode.

3. Check “ENGINE START BY I-KEY” in “Work support”.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set “On” in “ENGINE START BY I-KEY”.

#### 4.CHECK INSIDE KEY ANTENNA

Use SIGNAL TECH II to check each inside key antenna. For the inspection method and how to use SIGNAL TECH II, refer to “NISSAN/INFINITI SIGNAL TECH II USER GUIDE”.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

< SYMPTOM DIAGNOSIS >

## 5.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

## < SYMPTOM DIAGNOSIS >

### ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

#### Description

INFOID:0000000013317012

Engine does not start when push-button ignition switch is pressed. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

| Door lock operation (remote keyless entry) | Door lock operation (request switch) | Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna) | Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch) |
|--|--------------------------------------|--|---|
| OK   | OK                                   | No crank, No start   | No crank, No start  |

#### DIAGNOSIS PROCEDURE

Refer to [SEC-140, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:0000000013317013

#### 1.CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-149, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2.REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 3.

#### 3.REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

#### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

# DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/ PUSH SW) (ONE KEY)

< SYMPTOM DIAGNOSIS >

## DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/PUSH SW) (ONE KEY)

### Description

INFOID:0000000013317014

Door does not lock/unlock with door request switch, and engine does not start when push-button ignition switch is pressed while carrying Intelligent Key. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

| Door lock operation (remote keyless entry) | Door lock operation (request switch) | Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna) | Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch) |
|--|--------------------------------------|--|---|
| OK   | NG                                   | No crank, No start   | OK  |

### DIAGNOSIS PROCEDURE

Refer to [SEC-141, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000013317015

#### 1.CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-149, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2.CHECK INTELLIGENT KEY LOW BATTERY WARNING

Check that the Intelligent Key low battery warning operates.

Is the Intelligent Key low battery warning operated?

YES >> Replace Intelligent Key battery. Refer to [DLK-222, "Removal and Installation"](#).

NO >> GO TO 3.

#### 3.CHECK INTELLIGENT KEY BATTERY

Check the Intelligent Key battery.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace Intelligent Key battery. Refer to [DLK-222, "Removal and Installation"](#).

#### 4.REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 5.

#### 5.REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 6.

#### 6.REPLACE BCM

## DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/ PUSH SW) (ONE KEY)

### < SYMPTOM DIAGNOSIS >

---

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

#### Is the inspection result normal?

- YES    >> Inspection End.
- NO     >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

# NATS ANTENNA AMP.


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### NATS ANTENNA AMP.

#### Exploded View

INFOID:0000000012592511



1. NATS antenna amp.


2. Push-button ignition switch

#### Removal and Installation

INFOID:0000000012592512

##### REMOVAL

1. Remove the instrument pad (LH). Refer to [IP-14, "Exploded View"](#).
2. Release the pawl on each side of NATS antenna amp (1) using a suitable tool and remove from the instrument pad (LH) (2).



3. Release the pawl on each side using a suitable tool and remove the NATS antenna amp from the push-button ignition switch.

##### INSTALLATION

Installation is in the reverse order of removal.


# PUSH BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >

## PUSH BUTTON IGNITION SWITCH

### Exploded View

INFOID:0000000012592513



1. NATS antenna amp.

2. Push button ignition switch


### Removal and Installation

INFOID:0000000012592514

#### REMOVAL

1. Remove instrument pad (LH). Refer to [IP-14, "Exploded View"](#).
2. Release the pawl on each side of NATS antenna amp (1) using a suitable tool and remove from the instrument pad LH.

(○): Pawl



3. Release the pawl on each side using a suitable tool and remove the push button ignition switch from the NATS antenna amp.

#### INSTALLATION

Installation is in the reverse order of removal.



# IMMOBILIZER CONTROL MODULE

< REMOVAL AND INSTALLATION >

## IMMOBILIZER CONTROL MODULE

### Removal and Installation

INFOID:0000000012592515

#### Removal


The immobilizer control unit is integrated into the body control module (BCM). For removal and installation, Refer to [BCS-81, "Removal and Installation"](#).

#### Installation

Installation is in the reverse order of removal.

#### Removal (Canada only)

1. Remove instrument panel. Refer to [IP-15, "Removal and Installation"](#).
2. Disconnect the harness connector from the immobilizer control unit.
3. Remove the immobilizer control unit screw (A) and remove the immobilizer control unit (1) from behind the heating and cooling unit assembly (2).



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC