

SECTION **INL**

INTERIOR LIGHTING SYSTEM

A
B
C
D
E

F
G
H
I
J
K

INL

M

N

O

P

CONTENTS

BASIC INSPECTION	3	Description	17
DIAGNOSIS AND REPAIR WORKFLOW	3	Component Function Check	17
Work Flow	3	Diagnosis Procedure	17
FUNCTION DIAGNOSIS	6	INTERIOR ROOM LAMP CONTROL CIRCUIT	19
INTERIOR ROOM LAMP CONTROL SYSTEM	6	Description	19
System Diagram	6	Component Function Check	19
System Description	6	Diagnosis Procedure	19
Component Parts Location	7	STEP LAMP CIRCUIT	22
Component Description	8	Description	22
ILLUMINATION CONTROL SYSTEM	9	Component Function Check	22
System Diagram	9	Diagnosis Procedure	22
System Description	9	CARGO LAMP CONTROL CIRCUIT	24
Component Parts Location	9	Description	24
Component Description	10	Component Function Check	24
DIAGNOSIS SYSTEM (BCM)	11	Diagnosis Procedure	24
COMMON ITEM	11	IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT	26
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	11	Description	26
INT LAMP	11	Component Function Check	26
INT LAMP : CONSULT-III Function (BCM - INT LAMP)	12	Diagnosis Procedure	26
BATTERY SAVER	13	INTERIOR ROOM LAMP CONTROL SYSTEM	28
BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)	13	Wiring Diagram	28
COMPONENT DIAGNOSIS	15	ILLUMINATION	44
POWER SUPPLY AND GROUND CIRCUIT	15	Wiring Diagram	44
BCM	15	ECU DIAGNOSIS	58
BCM : Diagnosis Procedure	15	BCM (BODY CONTROL MODULE)	58
BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT	17	Reference Value	58
		Terminal Layout	61
		Physical Values	61
		Wiring Diagram	67
		Fail Safe	71
		DTC Inspection Priority Chart	72

DTC Index	72	General precautions for service operations	76
SYMPTOM DIAGNOSIS	74	ON-VEHICLE REPAIR	77
INTERIOR LIGHTING SYSTEM SYMPTOMS... 	74	INTERIOR ROOM LAMP	77
Symptom Table	74	Removal and Installation	77
PRECAUTION	75	ILLUMINATION	81
PRECAUTIONS	75	Removal and Installation	81
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	75	SERVICE DATA AND SPECIFICATIONS (SDS)	83
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	75	BULB SPECIFICATIONS	83
		Interior Lamp/Illumination	83

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004917226

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

AWLIA1661GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Verified that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL SYSTEM


< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram

INFOID:000000004917227



AWLIA1065GB

System Description

INFOID:000000004917228

OUTLINE

- Interior room lamps* are controlled by the interior room lamp timer control function of the BCM.
*Front room/map lamps, personal lamp 2nd row, personal lamp 3rd row (when lamp switch is in DOOR position) and puddle lamps (if equipped).
- Cargo lamp is controlled by the cargo lamp control function of the BCM.
- Step lamps* are controlled by the step lamp control function of the BCM.
*Front step lamps, rear step lamps and foot lamps (if equipped).

The timer control functions of the BCM activate based on inputs from the remote keyless entry receiver, the key cylinder lock/unlock switch, the door switches, the key switch and lock solenoid (without Intelligent Key) or the key switch and ignition knob switch (with Intelligent Key).

ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position and when all conditions below are met, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with Intelligent Key (with Intelligent Key), key fob (without Intelligent Key), main power window and door lock/unlock switch, or front door lock assembly LH (key cylinder switch)].
- When a door opens → closes and the key is not inserted in the ignition switch.

Timer control is cancelled under the following conditions.

- When the front door LH is locked [with Intelligent Key (with Intelligent Key), key fob (without Intelligent Key), main power window and door lock/unlock switch, or front door lock assembly LH (key cylinder switch)].
- A door is opened (door switch turns ON).
- Ignition switch is turned ON.

Interior lamp operational settings can be changed with the function setting of CONSULT-III.

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

INTERIOR LAMP BATTERY SAVER CONTROL

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 30 minutes after the ignition switch is turned OFF.

The BCM controls power and ground to all interior lamps.


After the battery saver system turns the lamps OFF, the lamps will illuminate again when

- a signal is received from an Intelligent Key (with Intelligent Key), key fob (without Intelligent Key), or main power window and door lock/unlock switch, or when the front door lock assembly LH (key cylinder switch) is locked or unlocked
- a door is opened or closed
- the key is removed from or inserted into the ignition switch.

The Interior lamp battery saver control time period can be changed with the function setting of CONSULT-III.

Component Parts Location

INFOID:000000004917229



AWLIA1066ZZ

1. BCM M18, M19, M20 (view with instrument lower panel LH removed)
2. Key switch and ignition knob switch M12 (with Intelligent Key)
Key switch and key lock solenoid M27 (without Intelligent Key)
3. Front door switch LH B8
Front door switch RH B108
4. Rear door switch LH B18
Rear door switch RH B116
5. Glass hatch ajar switch D707
6. Back door switch D502 (without power back door)
Back door latch (door ajar switch) D503 (with power back door)

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

- | | | |
|--|---|---|
| 7. Front room/map lamp assembly R102 | 8. Vanity lamp LH R3
Vanity lamp RH R8 | 9. Door mirror LH (puddle lamp) D4
Door mirror RH (puddle lamp) D107 |
| 10. Ignition keyhole illumination M150 | 11. Foot lamp LH M99 (if equipped)
Foot lamp RH M100 (if equipped) | 12. Front step lamp LH D11
Front step lamp RH D109 |
| 13. Rear step lamp LH D206
Rear step lamp RH D306 | 14. Cargo lamp B153 | 15. Personal lamp 3rd row R205 |
| 16. Personal lamp 2nd row R203 | | |

Component Description

INFOID:000000004917230

Part name	Description
BCM	Provides power and ground and controls timer functions for the interior room lamps, step lamps and cargo lamp.
Key switch and ignition knob switch (with Intelligent Key)	Provides key in ignition status to the BCM.
Key switch and key lock solenoid (without Intelligent Key)	
Door switches	Provides door OPEN/CLOSED status to the BCM.
Glass hatch switch	Provides glass hatch OPEN/CLOSED status to the BCM.
Back door latch (with power back door)	Provides back door OPEN/CLOSED status to the BCM.
Back door switch (without power back door)	
Power window and door lock/unlock switch RH	Provides door lock/unlock position switch RH status to the BCM.
Main power window and door lock/unlock switch [front door lock assembly LH (key cylinder switch)].	Provides door lock/unlock position switch LH status to the BCM.


ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

ILLUMINATION CONTROL SYSTEM

System Diagram

INFOID:0000000004917231



AWLIA1754GB

System Description

INFOID:0000000004917232

The illumination lamps operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate.


BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 30 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination lamps are turned off after a 30 second delay. When the combination switch (lighting and turn signal switch) is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

Component Parts Location

INFOID:0000000004917233

INL



AWLIA1590ZZ

ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

1. BCM M18, M20 (view with instrument lower panel LH removed)
2. IPDM E/R E122, E123, E124
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter (illumination control switch) M23, M24

Component Description

INFOID:0000000004917234

Part name	Description
BCM	The BCM monitors the lighting switch position with the combination switch reading function. The BCM requests, via CAN communication, that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication network.
Combination meter (illumination control switch)	The illumination control switch is a part of the combination meter. The combination meter controls illumination intensity by varying ground to the illumination lamps based on the illumination control switch position.
Combination switch (lighting and turn signal switch)	The combination switch provides input to the BCM about the lighting switch position.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005199686

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to BCS-55, "DTC Index" .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"> • Enables to read and save the vehicle specification. • Enables to write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	x		
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Remote keyless entry system	MULTI REMOTE ENT	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER		x	x
Air conditioner	AIR CONDITIONER		x	
Intelligent Key system*	INTELLIGENT KEY		x	
Combination switch	COMB SW		x	
Immobilizer	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open	TRUNK		x	x
RAP (retained accessory power)	RETAINED PWR	x	x	x
Signal buffer system	SIGNAL BUFFER		x	x
TPMS (tire pressure monitoring system)	AIR PRESSURE MONITOR	x	x	x
Vehicle security system	THEFT ALM	x	x	x
Panic alarm system	PANIC ALARM			x

*: With Intelligent Key

INT LAMP


DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

INT LAMP : CONSULT-III Function (BCM - INT LAMP)

INFOID:0000000005199687

WORK SUPPORT



Work Item	Setting item	Setting
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function
	OFF	Without the interior room lamp timer function
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.
	MODE 2*	1 sec.
	MODE 3	2 sec.
	MODE 4	3 sec.
	MODE 5	4 sec.
	MODE 6	5 sec.
	MODE 7	0 sec.
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.
	MODE 2	1 sec.
	MODE 3	2 sec.
	MODE 4*	3 sec.
	MODE 5	4 sec.
	MODE 6	5 sec.
	MODE 7	0 sec.

* : Initial setting

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judges from IGN signal (ignition power supply)
KEY ON SW [ON/OFF]	The switch status input from key switch
DOOR SW-DR [ON/OFF]	The switch status input from front door switch LH
DOOR SW-AS [ON/OFF]	The switch status input from front door switch RH
DOOR SW-RR [ON/OFF]	The switch status input from rear door switch RH
DOOR SW- RL [ON/OFF]	The switch status input from rear door switch LH
BACK DOOR SW [ON/OFF]	The switch status input from back door switch
KEY CYL LK-SW [ON/OFF]	Lock switch status input from door lock and unlock switch
KEY CYL UN-SW [ON/OFF]	Lock switch status input from door lock and unlock switch

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

Monitor Item [Unit]	Description
CDL LOCK SW [ON/OFF]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Unlock switch status input from door lock and unlock switch
KEYLESS LOCK [ON/OFF]	Lock signal status received from remote keyless entry receiver (integrated in the BCM)
KEYLESS UNLOCK [ON/OFF]	Unlock signal status received from remote keyless entry receiver (integrated in the BCM)
I-KEY LOCK* [ON/OFF]	Lock signal status received from Intelligent Key unit by CAN communication
I-KEY UNLOCK* [ON/OFF]	Unlock signal status received from Intelligent Key unit by CAN communication

*: With Intelligent Key

ACTIVE TEST

Test Item	Operation	Description
IGN ILLUM	ON	Outputs the ignition keyhole illumination control signal to turn the ignition keyhole illumination lamp ON.
	OFF	Stops the ignition keyhole illumination control signal to turn the ignition keyhole illumination lamp OFF.
INT LAMP	ON	Outputs the interior room lamp control signal to turn the interior room lamps ON.
	OFF	Stops the interior room lamp control signal to turn the interior room lamps OFF.
STEP LAMP TEST	ON	Outputs the step lamp control signal to turn the step lamps ON.
	OFF	Stops the step lamp control signal to turn the step lamps OFF.
LUGGAGE LAMP TEST	ON	Outputs the luggage lamp control signal to turn the luggage lamp ON.
	OFF	Stops the luggage lamp control signal to turn the luggage lamp OFF.

BATTERY SAVER

BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)

INFOID:0000000005199688

WORK SUPPORT

Work Item	Setting Item	Setting	
ROOM LAMP TIMER SET	MODE 1*	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	
	MODE 3	10 min.	

*: Initial setting

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judges from IGN signal (ignition power supply)
KEY ON SW [ON/OFF]	The switch status input from key switch
DOOR SW-DR [ON/OFF]	The switch status input from front door switch (driver side)
DOOR SW-AS [ON/OFF]	The switch status input from front door switch (passenger side)
DOOR SW-RR [ON/OFF]	The switch status input from rear door switch RH
DOOR SW- RL [ON/OFF]	The switch status input from rear door switch LH
BACK DOOR SW [ON/OFF]	The switch status input from back door switch
KEY CYL LK-SW [ON/OFF]	Lock switch status input from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Unlock switch status input from door key cylinder switch

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

Monitor Item [Unit]	Description
CDL LOCK SW [ON/OFF]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Unlock switch status input from door lock and unlock switch
I-KEY LOCK* [ON/OFF]	Lock signal status received from Intelligent Key unit by CAN communication
I-KEY UNLOCK* [ON/OFF]	Unlock signal status received from Intelligent Key unit by CAN communication
KEYLESS LOCK [ON/OFF]	Lock signal status received from remote keyless entry receiver (integrated in the BCM)
KEYLESS UNLOCK [ON/OFF]	Unlock signal status received from remote keyless entry receiver (integrated in the BCM)

*: With Intelligent Key

ACTIVE TEST

Test Item	Operation	Description
BATTERY SAVER	OFF	Cuts the interior room lamp power supply to turn interior room lamps OFF.
	ON	Outputs the interior room lamp power supply to turn interior room lamps ON.*

*: Each lamp switch is in ON position.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:0000000005266451

Regarding Wiring Diagram information, refer to [BCS-50. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	22 (15A)
70		F (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	59 (10A)

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Ap-prox.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >


Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair or replace harness.



LIA0915E

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

Description

INFOID:0000000004917239

Provides the battery saver output/power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

Component Function Check

INFOID:0000000004917240

1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

CONSULT-III

1. Turn ignition switch ON.
2. Turn each interior room lamp ON.
 - Front room/map lamp assembly
 - Vanity lamps
 - Personal lamp 2nd row
 - Personal lamp 3rd row
 - Cargo lamp
3. Open the driver door to turn ON the step lamps and puddle lamps.
 - Front step lamps
 - Rear step lamps
 - Foot lamps (if equipped)
 - Puddle lamps (if equipped)
4. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
5. While operating the test item, check that each interior room lamp turns ON/OFF.

OFF : Interior room lamp OFF

ON : Interior room lamp ON

Is the inspection result normal?

YES >> Battery saver output/power supply circuit is normal.

NO >> Refer to [INL-17, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004917241


Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

CONSULT-III

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 56 and ground.

Connector	(+) Terminal	(-) Terminal	Test item	Voltage
			BATTERY SAVER	
M20	56	Ground	OFF	0V
			ON	Battery voltage



Is the inspection result normal?

YES >> GO TO 2

NO >> Replace BCM. Refer to [BCS-60, "Removal and Installation"](#).

2. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

2. Disconnect the following connectors.
 - BCM M20
 - Ignition keyhole illumination
 - Front step lamp LH
 - Front step lamp RH
 - Door mirror LH (with puddle lamps)
 - Door mirror RH (with puddle lamps)
 - Rear step lamp LH
 - Rear step lamp RH
 - Foot lamp LH (if equipped)
 - Foot lamp RH (if equipped)
 - Front room/map lamp assembly
 - Vanity lamp LH
 - Vanity lamp RH
 - Cargo lamp
 - Personal lamp 2nd row
 - Personal lamp 3rd row
3. Check continuity between BCM connector M20 terminal 56 and each interior room lamp connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M20	56	Ignition keyhole illumination	M150	1
		Front step lamp LH	D11	1
		Front step lamp RH	D109	1
		Door mirror LH (with puddle lamps)	D4	12
		Door mirror RH (with puddle lamps)	D107	12
		Rear step lamp LH	D206	1
		Rear step lamp RH	D306	1
		Foot lamp LH (if equipped)	M99	1
		Foot lamp RH (if equipped)	M100	1
		Front room/map lamp assembly	R102	6
		Vanity lamp LH	R3	1
		Vanity lamp RH	R8	1
		Cargo lamp	B153	2
		Personal lamp 2nd row	R203	3
		Personal lamp 3rd row	R205	3

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair the harness or connectors.

3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT


Check continuity between BCM connector M20 terminal 56 and ground.

Connector	Terminal	—	Continuity
M20	56	Ground	No

Is the inspection result normal?

YES >> Check that each interior room lamp has no internal short circuit.

NO >> Repair the harness or connectors.



ALLIA0409GB

INTERIOR ROOM LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000004917242

Controls the following interior room lamps (ground side) by PWM signal

- Puddle lamps (if equipped)
- Front room/map lamp assembly
- Personal lamp 2nd row
- Personal lamp 3rd row

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:0000000004917243

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Front room/map lamp bulbs
- Personal lamp bulbs
- Puddle lamp bulbs (if equipped)

1 .CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

(P)CONSULT-III

1. Place the front room/map lamp assembly switch in the DOOR position.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

ON : Interior room lamp gradual brightening
OFF : Interior room lamp gradual dimming

Is the inspection result normal?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-19, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004917244

Regarding Wiring Diagram information, refer to [INL-28, "Wiring Diagram"](#).


INL

1 .CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

(P)CONSULT-III

1. Switch the front room/map lamp assembly switch to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. While operating the test item, check voltage between BCM connector M20 terminal 63 and ground.

Connector	(+)	(-)	INT LAMP	Voltage
M20	63	Ground	ON	0V
			OFF	Battery voltage



Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

INTERIOR ROOM LAMP CONTROL CIRCUIT


< COMPONENT DIAGNOSIS >

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, door mirror connectors (if equipped with puddle lamps) and front room/map lamp assembly connector.
3. Check continuity between BCM connector M20 (A) terminal 63 and the door mirror connectors (B) and front room/map lamp assembly connector (C).

BCM		Interior room lamp			Continuity
Connector	Terminal	Component	Connector	Terminal	
M20 (A)	63	Door mirror LH (if equipped with puddle lamps)	D4 (B)	13	Yes
		Door mirror RH (if equipped with puddle lamps)	D107 (B)	13	
		Front room/map lamp	R102 (C)	1	


4. Reconnect the front room/map lamp assembly connector.



AWLIA0968ZZ

5. Check continuity between BCM connector M20 (A) terminal 63 and the 2nd and 3rd row personal lamp connectors (B) terminal 1.

BCM		Interior room lamp			Continuity
Connector	Terminal	Component	Connector	Terminal	
M20 (A)	63	Personal lamp 2nd row	R203 (B)	1	Yes
		Personal lamp 3rd row	R205 (B)	1	



ALLIA0412GB

Is the inspection result normal?


YES >> Check interior room lamps for an open. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace interior room lamp. Refer to [INL-77, "Removal and Installation"](#) or [EXL-146, "Removal and Installation"](#).

NO >> Repair the harness or connectors.

3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, door mirror connectors (if equipped with puddle lamps) and 2nd and 3rd row personal lamp connectors.
3. Switch the front room/map lamp assembly switch to ON position.
4. Check continuity between BCM connector M20 terminal 63 and ground.

Connector	Terminal	—	Continuity
M20	63	Ground	No



ALLIA0413GB

Is the inspection result normal?

INTERIOR ROOM LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

YES >> Check interior room lamps for a short circuit. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace interior room lamp. Refer to [INL-77, "Removal and Installation"](#) or [EXL-146, "Removal and Installation"](#).

NO >> Repair the harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

STEP LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000004917245

Controls the front and rear step lamps and the foot lamps (if equipped) (ground side) to turn the lamps ON and OFF.

Component Function Check

INFOID:0000000004917246

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Front step lamp bulbs
- Rear step lamp bulbs
- Foot lamp bulbs (if equipped)

1.CHECK STEP LAMP OPERATION

(H)CONSULT-III

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test item, check that the front step lamps, rear step lamps and foot lamps (if equipped) turn ON/OFF.

ON : Step lamp ON

OFF : Step lamp OFF

Is the inspection result normal?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-22, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004917247

Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

1.CHECK STEP LAMP OUTPUT

(H)CONSULT-III

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 62 and ground.

Connector	Terminal	—	STEP LAMP TEST	Voltage
M20	62	Ground	ON	0V
			OFF	Battery voltage


Is the inspection result normal?

YES >> Step lamp control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

2.CHECK STEP LAMP OPEN CIRCUIT



STEP LAMP CIRCUIT

< COMPONENT DIAGNOSIS >


1. Turn ignition switch OFF.
2. Disconnect BCM connector M20 and front step lamp, rear step lamp and foot lamp connectors (if equipped).
3. Check continuity between BCM connector M20 (A) terminal 62 and step lamp connectors (B) and foot lamp connectors (C).

Connector	Terminal	Connector	Terminal	Continuity
M20 (A)	62	Front step lamp LH	D11 (B)	2
		Front step lamp RH	D109 (B)	2
		Rear step lamp LH	D206 (B)	2
		Rear step lamp RH	D306 (B)	2
		Foot lamp LH (if equipped)	M99 (C)	2
		Foot lamp RH (if equipped)	M100 (C)	2

Is the inspection result normal?

YES >> Check step lamp or foot lamp for an open. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace step lamp or foot lamp. Refer to [INL-77, "Removal and Installation"](#).

NO >> Repair harness or connectors.



3.CHECK STEP LAMP SHORT CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, front step lamp, rear step lamp and foot lamp connectors (if equipped).
3. Check continuity between BCM connector M20 terminal 62 and ground.

Connector	Terminal	—	Continuity
M20	62	Ground	No

Is the inspection result normal?

YES >> Check step lamp or foot lamp for a short circuit. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace step lamp or foot lamp. Refer to [INL-77, "Removal and Installation"](#).

NO >> Repair the harness or connectors.



A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

CARGO LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

CARGO LAMP CONTROL CIRCUIT

Description

INFOID:0000000004917248

Controls the cargo lamp (ground side) to turn the cargo lamp ON and OFF.

Component Function Check

INFOID:0000000004917249

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Cargo lamp bulb

1. CHECK CARGO LAMP OPERATION

(B) CONSULT-III

1. Turn ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test item, check that cargo lamp turns ON/OFF.

ON : Cargo lamp ON

OFF : Cargo lamp OFF

Is the inspection result normal?

YES >> Cargo lamp circuit is normal.

NO >> Refer to [INL-24, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004917250


Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

1. CHECK CARGO LAMP OUTPUT

(B) CONSULT-III

1. Turn ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M19 terminal 49 and ground.

Connector	Terminal	—	LUGGAGE LAMP TEST	Voltage
M19	49	Ground	ON	0V
			OFF	Battery voltage



Is the inspection result normal?

YES >> Cargo lamp control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

2. CHECK CARGO LAMP OPEN CIRCUIT

CARGO LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector M19 and cargo lamp connector.
3. Check continuity between BCM connector M19 (A) terminal 49 and cargo lamp connector B153 (B) terminal 1.

BCM		Cargo lamp		Continuity
Connector	Terminal	Connector	Terminal	
M19 (A)	49	B153 (B)	1	Yes

Is the inspection result normal?

YES >> Check cargo lamp for an open. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace cargo lamp. Refer to [INL-81, "Removal and Installation"](#).

NO >> Repair harness or connectors.

3.CHECK CARGO LAMP SHORT CIRCUIT



1. Turn ignition switch OFF.
2. Disconnect BCM connector M19 and cargo lamp connector.
3. Check continuity between BCM connector M19 terminal 49 and ground.

Connector	Terminal	—	Continuity
M19	49	Ground	No

Is the inspection result normal?

YES >> Check cargo lamp for a short circuit. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace cargo lamp. Refer to [INL-81, "Removal and Installation"](#).

NO >> Repair harness or connectors.



IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

Description

INFOID:0000000004917251

Controls the ignition keyhole illumination (ground side) to turn the ignition keyhole illumination ON and OFF.

Component Function Check

INFOID:0000000004917252

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply circuit
- Ignition keyhole illumination bulb

1. CHECK IGNITION KEYHOLE ILLUMINATION OPERATION

CONSULT-III

1. Turn the ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check that the ignition keyhole illumination turns ON/OFF

ON : Ignition keyhole illumination ON

OFF : Ignition keyhole illumination OFF

Is the inspection result normal?

YES >> Ignition keyhole illumination circuit is normal.

NO >> Refer to [INL-26, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004917253

Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

1. CHECK IGNITION KEYHOLE OUTPUT

CONSULT-III

1. Turn ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M18 terminal 1 and ground.

Connector	Terminal	—	IGN ILLUM	Voltage
M18	1	Ground	ON	0V
			OFF	Battery voltage


Is the inspection result normal?

YES >> Ignition keyhole illumination circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

2. CHECK IGNITION KEYHOLE ILLUMINATION OPEN CIRCUIT




IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 (A) terminal 1 and ignition keyhole illumination connector M150 (B) terminal 2.

BCM		Ignition keyhole illumination		Continuity
Connector	Terminal	Connector	Terminal	
M18 (A)	1	M150 (B)	2	Yes

Is the inspection result normal?



YES >> Check the ignition keyhole illumination for an open. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace ignition keyhole illumination.


NO >> Repair harness or connectors.

3.CHECK IGNITION KEYHOLE ILLUMINATION SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 terminal 1 and ground.

Connector	Terminal	—	Continuity
M18	1	Ground	No

Is the inspection result normal?



YES >> Check the ignition keyhole illumination for a short circuit. If OK, replace BCM. Refer to [BCS-60, "Removal and Installation"](#). If NG, replace ignition keyhole illumination.

NO >> Repair harness or connectors.


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram


INFOID:0000000004917254



ABLWA0431GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< COMPONENT DIAGNOSIS >



ABLWA0432GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >



ABLWA0433GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

INTERIOR ROOM LAMP CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE
	
Terminal No.	Color of Wire Signal Name
10	L -
12	R/G -
13	B -
14	R -

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Terminal No.	Color of Wire	Signal Name
13P	P	-

Terminal No.	Color of Wire	Signal Name
13P	P	-


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE
	
Terminal No.	Color of Wire Signal Name
8	W/V -
14	B -

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Terminal No.	Color of Wire	Signal Name
13P	P	-


Terminal No.	Color of Wire	Signal Name
1	2	-
2	3	-
3	4	-
4	5	-
5	6	-

Connector No.	M4	
Connector Name	FUSE BLOCK (J/B)	
Connector Color	WHITE	
		
Terminal No.	Color of Wire Signal Name	
7	8P	4P
8	6P	5P
9	14P	13P
10	12P	11P
11	10P	9P
12	8P	7P
13	6N	5N
14	4N	3N

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Terminal No.	Color of Wire	Signal Name
13P	P	-

Terminal No.	Color of Wire	Signal Name
13P	P	-

Connector No.	M8	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire Signal Name	
6	R/W	-
7	R/G	-
24	L	-

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Terminal No.	Color of Wire	Signal Name
1N	Y/R	-


Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P
 Q
 R
 S
 T
 U
 V
 W
 X
 Y
 Z
 INL


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Connector No.	M27
Connector Name	KEY SWITCH AND KEY LOCK SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
42	GR	GLASS HATCH SW
43	R/B	BACK DOOR SW
47	SB	DOOR SW (DR)
48	R/Y	DOOR SW (RL)
49	R	LUGGAGE LAMP OUTPUT
37	B/R	KEY SW
38	W/L	IGN SW
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
1	BR/W	KEY RING OUTPUT
12	R/L	DOOR SW (AS)
13	GR	DOOR SW (FR)
22	W/V	ANTI-PINCH SERIAL LINK (RX, TX)
37	B/R	KEY SW
38	W/L	IGN SW
39	L	CAN-H
40	P	CAN-L


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
56	R/G	BATTERY SAVER OUTPUT
57	Y/R	BAT (FUSE)
62	R/W	STEP LAMP OUTPUT
63	L	ROOM LAMP OUTPUT
67	B	GND (POWER)
70	W/B	BAT (F/L)

Terminal No.	Color of Wire	Signal Name
7G	W/L	-
10G	W/B	-
30G	Y	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	B/R	-

ABLIA1404GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >



Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L	-
5	W/W	-
6	R/W	-
7	R/G	-

Terminal No.

Color of Wire

Signal Name

Terminal No.

Color of Wire

Signal Name

Terminal No.	Color of Wire	Signal Name
49M	R/G	-
50M	R	-
55M	GR	-
56M	GR	-
61M	R/L	-
64M	R/W	-
65M	R/B	-

Terminal No.

Color of Wire

Signal Name


A B C D E F G H I J K L M N O P INL

ABLIA0162GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M99
Connector Name	FOOT LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
12	R	-

Terminal No.	Color of Wire	Signal Name
3	B	-

Connector No.	M150
Connector Name	IGNITION KEY HOLE ILLUMINATION
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	R/W	-

Connector No.	M150
Connector Name	IGNITION KEY HOLE ILLUMINATION
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	R/W	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


A B C D E F G H I J K L M N O P INL

Connector No.	E152	Color of Wire	Signal Name
Connector Name	WIRE TO WIRE		
Connector Color	WHITE		




Terminal No.	Color of Wire	Signal Name
7G	L/W	-
10G	W/B	-
30G	Y	-

Terminal No.	Color of Wire	Signal Name
7G	L/W	-
10G	W/B	-
30G	Y	-




Terminal No.	Color of Wire	Signal Name
9	R/W	-
10	R/G	-




Terminal No.	Color of Wire	Signal Name
10	R/W	-

Terminal No.	Color of Wire	Signal Name
10	R/W	-

Terminal No.	Color of Wire	Signal Name
9	R/W	-
10	R/G	-



Terminal No.	Color of Wire	Signal Name
2	R/Y	-
2	SB	-




INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
58J	R/G	—
59J	R/W	—
60J	SB	—
61J	R/Y	—

Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B	—
15	R/W	—



Terminal No.	Color of Wire	Signal Name
59J	R/W	—
60J	SB	—
61J	R/Y	—

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R/L	—
10	R/G	—


Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	B111
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-


Terminal No.	Color of Wire	Signal Name
10	R/W	-

Terminal No.	Color of Wire	Signal Name
13	GR	-


Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B146
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
5	R/G	-
6	R	-



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

ABLIA0166GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B153
Connector Name	CARGO LAMP
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	L	-
12	R/G	-
13	B	-
14	R	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	R/G	-

Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	B	-



Terminal No.	Color of Wire	Signal Name
1	R	-
3	R/G	-
5	L	-
10	B	-




Connector No.	R6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	6	-
8	5	-
9	4	-
10	15	-
11	14	-
12	13	-
13	12	-
14	11	-
15	10	-
16	9	-

Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	B	-



Terminal No.	Color of Wire	Signal Name
1	R	-
3	R/G	-
5	L	-
10	B	-

ABLIA0167GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	R201
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	R102
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L	DOOR BATT
2	R	GND_THRU_SW
5	B	GND
6	R/G	BAT


Terminal No.	Color of Wire	Signal Name
1	B	-
5	R/G	-
6	R	-
11	10	8
23	22	20
24	21	19
		18
		17
		16
		15
		14
		13
		12
		1




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	R/G	-



Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	R/G	-



Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	2	3
2	9	10
3	11	12
4	13	14
5	15	16
6	17	18
7	19	20
8	21	22
9	23	24


Terminal No.	Color of Wire	Signal Name
6	R/W	-
7	R/G	-
24	L	-

ABLIA0168GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	D4
Connector Name	DOOR MIRROR LH
Connector Color	WHITE



Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L	LOCK
6	R	UNLOCK
14	LGW	ANTI PINCH SERIAL LINK

Terminal No.	Color of Wire	Signal Name
12	R/G	—
13	L	—


Connector No.	D4
Connector Name	FRONT STEP LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	GND




Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	BLACK



Connector No.	D11
Connector Name	FRONT STEP LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	—



Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

K

INL


M

Z


O

P

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
11	B	GND
16	LG/W	ANTI PINCH SERIAL

Terminal No.	Color of Wire	Signal Name
4	L	-
5	LG/W	-
6	R/W	-
7	R/G	-


Terminal No.	Color of Wire	Signal Name
12	R/G	-
13	L	-

Connector No.	D206
Connector Name	REAR STEP LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	R/W	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/W	-
10	R/G	-


Connector No.	D109
Connector Name	FRONT STEP LAMP RH
Connector Color	WHITE



INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



 H.S.

Connector No.	D306
Connector Name	REAR STEP LAMP RH
Connector Color	WHITE



 H.S.

Terminal No.	Color of Wire	Signal Name
1	R/G	-
2	R/W	-

Terminal No.	Color of Wire	Signal Name
9	R/W	-
10	R/G	-

Terminal No.	Color of Wire	Signal Name
14	B	-
15	R/W	-

Terminal No.	Color of Wire	Signal Name
1	B	-
3	R/W	-



 H.S.

Connector No.	D401
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
10	R/G	-
9	R/W	-

Terminal No.	Color of Wire	Signal Name
8	R/W	-
7	R/G	-



 H.S.

Connector No.	D502
Connector Name	BACK DOOR SWITCH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-
3	R/W	-


Terminal No.	Color of Wire	Signal Name
14	B	-
15	R/W	-

ABLIA0171GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	D602
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D503
Connector Name	BACK DOOR LATCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R/W	DOOR AJAR SW
8	B	GND



Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

Terminal No.	Color of Wire	Signal Name
13	GR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

ABLIA0172GB


ILLUMINATION

< COMPONENT DIAGNOSIS >

ILLUMINATION

Wiring Diagram

INFOID:0000000004917255




ABLWA0434GB*

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ILLUMINATION

< COMPONENT DIAGNOSIS >


◀4W▶ : WITH 4-WHEEL DRIVE
 ◀AD▶ : WITH AUTOMATIC DRIVE POSITIONER
 ◀PB▶ : WITH POWER BACK DOOR
 ◀PV▶ : WITH REAR POWER VENT WINDOWS
 ◀SW▶ : WITH HEATED STEERING WHEEL
 ◀WD▶ : WITH DVD ENTERTAINMENT SYSTEM
 ◀XA▶ : WITHOUT AUTOMATIC DRIVE POSITIONER



ABLWA0435GB

ILLUMINATION

< COMPONENT DIAGNOSIS >




ABLWA0436GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

ILLUMINATION CONNECTORS


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	BR	—
11	R/L	—

Terminal No.	Color of Wire	Signal Name
5P	O/L	—
13P	P	—


Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
22	R/L	—

Terminal No.	Color of Wire	Signal Name
22	R/L	—

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	SB	INPUT 5
3	G/Y	INPUT 4

Terminal No.	Color of Wire	Signal Name
22	R/G	OUTPUT 5
33	R/Y	OUTPUT 4
34	L	OUTPUT 3
35	O/B	OUTPUT 2
36	R/W	OUTPUT 1
38	W/L	IGN SW
39	L	CAN-H
40	P	CAN-L


ABLIA1407GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

ILLUMINATION

< COMPONENT DIAGNOSIS >

Connector No.	M23
Connector Name	COMBINATION METER
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
50	BR	ILL LED CON OUTPUT
52	B	ILL GND

Terminal No.	Color of Wire	Signal Name
8	P	BATTERY
9	B	GND
11	L	CAN-H
12	P	CAN-L
24	O/L	RUN/START

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




12	13	10	—	9	8	7
14	11	1	2	3	4	5


Terminal No.	Color of Wire	Signal Name
1	R/W	INPUT 1
2	O/B	INPUT 2
3	L	INPUT 3
4	R/Y	INPUT 4
5	R/G	OUTPUT 5
6	V	OUTPUT 1
7	G/B	OUTPUT 2
8	SB	OUTPUT 5
9	G/Y	OUTPUT 4
10	Y	OUTPUT 3

Terminal No.	Color of Wire	Signal Name
7G	W/L	—
10G	W/B	—
31G	L	—
37G	R/L	—
42G	P	—

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



24	25	26	27
31	32	33	34


Terminal No.	Color of Wire	Signal Name
26	Y	—
27	BR	—



ILLUMINATION


< COMPONENT DIAGNOSIS >

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	R/L	ILL
20	B	GND

Connector No.	M42
Connector Name	AV CONTROL UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	R/L	ILL
20	B	GND

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
30M	R/L	-

Connector No.	M44
Connector Name	AV CONTROL UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54	B	GND

Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/L	-
4	BR	-

Connector No.	M49
Connector Name	A/C AUTO AMP.
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
9	R/L	ILL+
20	BR	ILL-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

ILLUMINATION

< COMPONENT DIAGNOSIS >


Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/L	—
2	B	—

Terminal No.	Color of Wire	Signal Name
1	R/L	—
2	B	—
3	—	—
4	—	—
5	—	—
6	—	—
7	—	—
8	—	—
9	—	—
10	—	—
11	—	—
12	—	—
13	—	—
14	—	—
15	—	—
16	—	—
17	—	—
18	—	—
19	—	—
20	—	—
21	—	—
22	—	—
23	—	—
24	—	—

Terminal No.	Color of Wire	Signal Name
7	R/L	—
8	BR	—
11	R/L	—
17	BR	—
18	R/L	—




Terminal No.	Color of Wire	Signal Name
7	R/L	—
8	BR	—
11	R/L	—
17	BR	—
18	R/L	—



Terminal No.	Color of Wire	Signal Name
1	Y	—
2	R/L	—

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GND	—
2	R/L	ILL (TAIL)



Connector No.	M64
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M59
Connector Name	GLOVE BOX LAMP
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	—
4	R/L	ILL (TAIL)

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

H

K

M

Z

O


P

INL

Connector No.	M83
Connector Name	PEDAL ADJUSTING SWITCH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
5	R/L	-
6	BR	-

Connector No.	M92
Connector Name	POWER LIFTGATE SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R/L	ILL
4	BR	ILL CONT GND

Terminal No.	Color of Wire	Signal Name
5	R/L	-
6	BR	-



Terminal No.	Color of Wire	Signal Name
18	O	-
21	L	-



Connector No.	M96
Connector Name	PEDAL ADJUSTING SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
5	R/L	-
6	BR	-

Connector No.	M98
Connector Name	AC AND AV SWITCH ASSEMBLY
Connector Color	WHITE




14	15	16
17	18	19
20	21	-

ABLA1A1410GB

ILLUMINATION


< COMPONENT DIAGNOSIS >

Connector No.	M116
Connector Name	SONAR SYSTEM OFF SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	R/L	-
4	BR	-

Connector No.	M141
Connector Name	4WD SHIFT SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	R/L	-
8	BR	-

Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	BR	-
5	BR	-

Terminal No.	Color of Wire	Signal Name
4	BR	-
5	BR	-

Connector No.	M165
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R/L	-
8	BR	-

Connector No.	M161
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	R/L	-
8	BR	-

Connector No.	M160
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM, WITHOUT NAVI)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	R/L	-
8	BR	-

Connector No.	M165
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	R/L	-
8	BR	-

Connector No.	M165
Connector Name	GND
Connector Color	GND

Terminal No.	Color of Wire	Signal Name
65	B	GND
67	B	GND

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

H


K

M


Z

P

Connector No.	M171
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM, WITHOUT NAVI)
Connector Color	WHITE



Connector No.	M166
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM, WITHOUT NAVI)
Connector Color	WHITE




Terminal No.	54
Color of Wire	B
Signal Name	GND


Terminal No.	54
Color of Wire	B
Signal Name	GND

Terminal No.	9
Color of Wire	R/L
Signal Name	-

Terminal No.	9
Color of Wire	R/L
Signal Name	-




Connector No.	M202
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	6
Color of Wire	BR
Signal Name	ILL+

Terminal No.	22
Color of Wire	R/L
Signal Name	LIGHTING SW



Terminal No.	7
Color of Wire	R/L
Signal Name	-

Terminal No.	8
Color of Wire	BR
Signal Name	-

Terminal No.	11
Color of Wire	R/L
Signal Name	-

Terminal No.	17
Color of Wire	BR
Signal Name	-


Terminal No.	18
Color of Wire	R/L
Signal Name	-

ABLIA1412GB

ILLUMINATION


< COMPONENT DIAGNOSIS >

Connector No.	M253
Connector Name	VDC OFF SWITCH
Connector Color	GRAY



H.S.

Connector No.	M252
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




H.S.

Terminal No.	Color of Wire	Signal Name
3	R/L	-
4	BR	-



H.S.

Terminal No.	Color of Wire	Signal Name
5	R/L	-
6	BR	-




H.S.

Terminal No.	Color of Wire	Signal Name
3	R/L	-
4	BR	-



H.S.

Connector No.	M256
Connector Name	A/T SHIFT SELECTOR
Connector Color	BLACK



H.S.

Terminal No.	Color of Wire	Signal Name
3	R/L	-
4	BR	-



H.S.

Terminal No.	Color of Wire	Signal Name
11	R/L	-
12	BR	-



H.S.


ABLIA1413GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
49	R/L	ILLUMINATION


Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
17	B	-


Terminal No.	Color of Wire	Signal Name
22	R/L	-




ILLUMINATION

< COMPONENT DIAGNOSIS >


Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	BR	—
11	R/L	—




Terminal No.	Color of Wire	Signal Name
30M	R/L	—




Connector No.	R201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	R102
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY
Connector Color	GRAY



Connector No.	R101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R201
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	R/L	ILL+
8	BR	ILL-

Terminal No.	Color of Wire	Signal Name
11	BR	—
13	R/L	—

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

L


M

N


O

P

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R204
Connector Name	REAR AUDIO REMOTE CONTROL UNIT
Connector Color	WHITE




Terminal No.	Signal Name
22	R/L
23	-

Terminal No.	Color of Wire	Signal Name
6	R/L	ILL+
15	B	GND

Terminal No.	Color of Wire	Signal Name
8	BR	-
9	R/L	-

Terminal No.	Color of Wire	Signal Name
4	BR	-

Connector No.	D13
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	BR	-
9	R/L	-

Terminal No.	Color of Wire	Signal Name
8	BR	-
9	R/L	-

ABIA1416GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000005199700

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
AIR COND SW	A/C switch OFF	OFF
	A/C switch ON	ON
AUT LIGHT SYS	Outside of the room is dark	OFF
	Outside of the room is bright	ON
AUTO LIGHT SW	Lighting switch OFF	OFF
	Lighting switch AUTO	ON
BACK DOOR SW	Back door closed	OFF
	Back door opened	ON
CARGO LAMP SW	Cargo lamp switch OFF	OFF
	Cargo lamp switch ON	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the LOCK side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the UNLOCK side	ON
DOOR SW-AS	Front door RH closed	OFF
	Front door RH opened	ON
DOOR SW-DR	Front door LH closed	OFF
	Front door LH opened	ON
DOOR SW-RL	Rear door LH closed	OFF
	Rear door LH opened	ON
DOOR SW-RR	Rear door RH closed	OFF
	Rear door RH opened	ON
ENGINE RUN	Engine stopped	OFF
	Engine running	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER LOW	Front wiper switch OFF	OFF
	Front wiper switch LO	ON
FR WIPER HI	Front wiper switch OFF	OFF
	Front wiper switch HI	ON
FR WIPER INT	Front wiper switch OFF	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Any position other than front wiper stop position	OFF
	Front wiper stop position	ON
HAZARD SW	When hazard switch is not pressed	OFF
	When hazard switch is pressed	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1st	ON
HEAD LAMP SW1	Headlamp switch OFF	OFF
	Headlamp switch 1st	ON
HEAD LAMP SW2	Headlamp switch OFF	OFF
	Headlamp switch 1st	ON
HI BEAM SW	High beam switch OFF	OFF
	High beam switch HI	ON
IGN ON SW	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
IGN SW CAN	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
I-KEY LOCK ¹	LOCK button of Intelligent Key is not pressed	OFF
	LOCK button of Intelligent Key is pressed	ON
I-KEY UNLOCK ¹	UNLOCK button of Intelligent Key is not pressed	OFF
	UNLOCK button of Intelligent Key is pressed	ON
KEY CYL LK-SW	Door key cylinder LOCK position	ON
	Door key cylinder other than LOCK position	OF
KEY CYL UN-SW	Door key cylinder UNLOCK position	ON
	Door key cylinder other than UNLOCK position	ON
KEY ON SW	Mechanical key is removed from key cylinder	OFF
	Mechanical key is inserted to key cylinder	ON
KEYLESS LOCK ²	LOCK button of key fob is not pressed	OFF
	LOCK button of key fob is pressed	ON
KEYLESS UNLOCK ²	UNLOCK button of key fob is not pressed	OFF
	UNLOCK button of key fob is pressed	ON
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	OFF
	Ignition switch ON	ON
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5V
	Dark outside of the vehicle	Close to 0V
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
PUSH SW ¹	Return to ignition switch to LOCK position	OFF
	Press ignition switch	ON
REAR DEF SW	Rear window defogger switch OFF	OFF
	Rear window defogger switch ON	ON
RKE LCK-UNLK	LOCK/UNLOCK buttons of key fob not pressed at same time	OFF
	LOCK/UNLOCK buttons of key fob pressed at same time	ON
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	OFF
	UNLOCK button of key fob is pressed	ON
RR WASHER SW	Rear washer switch OFF	OFF
	Rear washer switch ON	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
RR WIPER INT	Rear wiper switch OFF	OFF
	Rear wiper switch INT	ON
RR WIPER ON	Rear wiper switch OFF	OFF
	Rear wiper switch ON	ON
RR WIPER STOP	Rear wiper stop position	OFF
	Other than rear wiper stop position	ON
RR WIPER STP2	Rear wiper stop position	OFF
	Other than rear wiper stop position	ON
TRNK OPNR SW	When back door opener switch is not pressed	OFF
	When back door opener switch is pressed	ON
TURN SIGNAL L	Turn signal switch OFF	OFF
	Turn signal switch LH	ON
TURN SIGNAL R	Turn signal switch OFF	OFF
	Turn signal switch RH	ON
VEHICLE SPEED	While driving	Equivalent to speedometer reading

1: With Intelligent Key

2: With remote keyless entry system

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Terminal Layout

INFOID:000000005199701

A
B
C
D
E
F
G
H
I
J
K

INL

M
N
O
P







Physical Values

LIIA2443E

INFOID:000000005199702





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR/W	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	SB	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
3	G/Y	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
4	Y	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
5	G/B	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
6	V	Combination switch input 1				
9	GR/R	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
10	G	Hazard lamp flash	Input	OFF	ON (opening or closing)	0V
					OFF (other than above)	Battery voltage
11	O	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage
12	R/L	Front door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
13	GR	Rear door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	L/W	Tire pressure warning check connector	Input	OFF	—	5V
18	P	Remote keyless entry receiver and optical sensor (ground)	Output	OFF	—	0V

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
19	V/W	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LIIA1893E
20	G/W	Remote keyless entry receiver (signal)	Input	OFF	Stand-by (keyfob buttons released)	 LIIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LIIA1895E
21	G	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
22	W/V	BUS	—	—	Ignition switch ON or power window timer operates	 PIIA2344E
23	G/O	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
26	Y/L	Rear wiper auto stop switch 2	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	0V
					Forward sweep (counterclockwise direction)	Fluctuating
					B Position (full counterclockwise stop position)	Battery voltage
					Reverse sweep (clockwise direction)	Fluctuating
27	W/R	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 INL
 M
 N
 O
 P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)				
				Ignition switch	Operation or condition					
28	L/R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage				
					Front blower motor ON	0V				
29	W/B	Hazard switch	Input	OFF	ON	0V				
					OFF	5V				
32	R/G	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E				
33	R/Y	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E				
34	L	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E				
35	O/B	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E				
36	R/W	Combination switch output 1								
37 ¹	B/R	Key switch and ignition knob switch	Input	OFF	Intelligent Key inserted	Battery voltage				
					Intelligent Key inserted	0V				
37 ²	B/R	Key switch and key lock solenoid	Input	OFF	Key inserted	Battery voltage				
					Key inserted	0V				
38	W/L	Ignition switch (ON)	Input	ON	—	Battery voltage				
39	L	CAN-H	—	—	—	—				
40	P	CAN-L	—	—	—	—				
42	GR	Glass hatch ajar switch	Input	ON	Glass hatch open	0				
					Glass hatch closed	Battery				
43	R/B	Back door switch (without power back door) or back door latch (door ajar switch) (with power back door)	Input	OFF	ON (open)	0V				
					OFF (closed)	Battery voltage				

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
44	O	Rear wiper auto stop switch 1	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	Battery voltage
					Forward sweep (counterclockwise direction)	Fluctuating
					B Position (full counterclockwise stop position)	0V
					Reverse sweep (clockwise direction)	Fluctuating
47	SB	Front door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
48	R/Y	Rear door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
49	R	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
51	G/Y	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	G/B	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
54	Y	Rear wiper output circuit 2	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	0V
					Forward sweep (counterclockwise direction)	0V
					B Position (full counterclockwise stop position)	Battery voltage
					Reverse sweep (clockwise direction)	Battery voltage
55	SB	Rear wiper output circuit 1	Output	ON	OFF	0
					ON	Battery voltage
56	R/G	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V
					ON	—
57	Y/R	Battery power supply	Input	OFF	—	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

INL

M



N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
58	W/R	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	G	Front door lock assembly LH actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	G/B	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
61	G/Y	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
62	R/W	Step lamp LH and RH	Output	OFF	ON (any door open)	0V
					OFF (all doors closed)	Battery voltage
63	L	Interior room/map lamp	Output	OFF	Any door switch	0V
					ON (open)	Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V
					ON (lock)	Battery voltage
66	G/Y	Front door lock actuator RH, rear door lock actuators LH/RH and back door lock actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
67	B	Ground	Input	ON	—	0V
68	W/L	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	W/R	Power window power supply	Output	—	—	Battery voltage
70	W/B	Battery power supply	Input	OFF	—	Battery voltage

1: With Intelligent Key system


2: With remote keyless entry system

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Wiring Diagram


BCM (BODY CONTROL MODULE)



INFO ID: 0000000005199703

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




ABMWAA0370GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

(PV) : WITH REAR POWER VENT WINDOWS




AAMWA0182GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE) CONNECTORS


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
16	-	-	41	GR	GLASS HATCH SW
17	-	-	42	GR	GLASS HATCH SW
18	P	KEYLESS AND AUTO LIGHT SENSOR GND	43	R/B	BACK DOOR SW
19	V/W	KEYLESS TUNER POWER SUPPLY OUTPUT	44	O	REAR WIPER AUTO STOP SW1
20	G/W	KEYLESS TUNER SIGNAL	45	-	-
21	G	IMMOBILIZER ANTENNA SIGNAL (CLOCK)	46	-	-
22	W/V	ANTI-PINCH SERIAL LINK (RX,TX)	47	SB	DOOR SW (DR)
23	G/O	SECURITY INDICATOR OUTPUT	48	R/Y	DOOR SW (RL)
24	-	-	49	R	LUGGAGE LAMP OUTPUT
25	BR	IMMOBILIZER ANTENNA SIGNAL (RX,TX)	50	-	-
26	Y/L	REAR WIPER AUTO STOP SW2	51	G/Y	TRAILER FLASHER OUTPUT (RIGHT)
27	W/R	AIRCON SW	52	G/B	TRAILER FLASHER OUTPUT (LEFT)
28	L/R	BLOWER FAN SW	53	-	-
29	W/B	HAZARD SW	54	Y	REAR WIPER MOTOR OUTPUT2
30	-	-	55	SB	REAR WIPER MOTOR OUTPUT1
31	-	-			
32	R/G	OUTPUT 5			
33	R/Y	OUTPUT 4			
34	L	OUTPUT 3			
35	O/B	OUTPUT 2			
36	R/W	OUTPUT 1			
37	B/R	KEY SW			
38	W/L	IGN SW			
39	L	CAN-H			
40	P	CAN-L			



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	BR/W	KEY RING OUTPUT	23	G/O	SECURITY INDICATOR OUTPUT
2	SB	INPUT 5	24	-	-
3	G/Y	INPUT 4	25	BR	IMMOBILIZER ANTENNA SIGNAL (RX,TX)
4	Y	INPUT 3	26	Y/L	REAR WIPER AUTO STOP SW2
5	G/B	INPUT 2	27	W/R	AIRCON SW
6	V	INPUT 1	28	L/R	BLOWER FAN SW
7	-	-	29	W/B	HAZARD SW
8	-	-	30	-	-
9	GR/R	REAR DEFOGGER SW	31	-	-
10	G	IVCS INPUT	32	R/G	OUTPUT 5
11	O	ACC SW	33	R/Y	OUTPUT 4
12	R/L	DOOR SW (AS)	34	L	OUTPUT 3
13	GR	DOOR SW (RR)	35	O/B	OUTPUT 2
14	-	-	36	R/W	OUTPUT 1
15	L/W	TPMS MODE TRIGGER SW	37	B/R	KEY SW
			38	W/L	IGN SW
			39	L	CAN-H
			40	P	CAN-L



ABMIA1055GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

A

B

C

D

E

F

G

H

K

NL


M

Z


O

P

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	R/W	INPUT 1	1	R/W	INPUT 1
2	O/B	INPUT 2	2	O/B	INPUT 2
3	L	INPUT 3	3	L	INPUT 3
4	R/Y	INPUT 4	4	R/Y	INPUT 4
5	R/G	INPUT 5	5	R/G	INPUT 5
6	V	OUTPUT 1	6	V	OUTPUT 1
7	G/B	OUTPUT 2	7	G/B	OUTPUT 2
8	SB	OUTPUT 5	8	SB	OUTPUT 5
9	G/Y	OUTPUT 4	9	G/Y	OUTPUT 4
10	Y	OUTPUT 3	10	Y	OUTPUT 3
11	V/W	WASHER MOTOR	11	V/W	WASHER MOTOR
12	B	GND	12	B	GND
13	W/R	WASHER MOTOR	13	W/R	WASHER MOTOR
14	R/L	IGN	14	R/L	IGN

60	G/B	FLASHER OUTPUT (LEFT)	61	G/Y	FLASHER OUTPUT (RIGHT)
62	R/W	STEP LAMP OUTPUT	63	L	ROOM LAMP OUTPUT
64	-	-	65	V	DOOR LOCK OUTPUT (ALL)
66	G/Y	DOOR UNLOCK OUTPUT (OTHER)	67	B	GND (POWER)
68	W/L	POWER WINDOW POWER SUPPLY (LINKED TO RAP)	69	W/R	POWER WINDOW POWER SUPPLY (BAT)
70	W/B	BAT (F/L)			

ABMIA1056GB

INFOID:0000000005199704

Fail Safe

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

DTC Inspection Priority Chart

INFOID:000000005199705

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT
2	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2013: STRG COMM 1 • B2552: INTELLIGENT KEY • B2590: NATS MALFUNCTION
3	<ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL
4	<ul style="list-style-type: none"> • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL

DTC Index

INFOID:000000005199706

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-33
B2013: STRG COMM 1	—	—	—	SEC-28

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2190: NATS ANTENNA AMP	—	—	—	SEC-31 (with I-Key), SEC-134 (without I-Key)
B2191: DIFFERENCE OF KEY	—	—	—	SEC-34 (with I-Key), SEC-137 (without I-Key)
B2192: ID DISCORD BCM-ECM	—	—	—	SEC-35 (with I-Key), SEC-138 (without I-Key)
B2193: CHAIN OF BCM-ECM	—	—	—	SEC-37 (with I-Key), SEC-140 (without I-Key)
B2552: INTELLIGENT KEY	—	—	—	SEC-39
B2590: NATS MALFUNCTION	—	—	—	SEC-40
C1708: [NO DATA] FL	—	—	—	WT-14
C1709: [NO DATA] FR	—	—	—	WT-16
C1710: [NO DATA] RR	—	—	—	WT-16
C1711: [NO DATA] RL	—	—	—	WT-16
C1712: [CHECKSUM ERR] FL	—	—	—	WT-16
C1713: [CHECKSUM ERR] FR	—	—	—	WT-16
C1714: [CHECKSUM ERR] RR	—	—	—	WT-16
C1715: [CHECKSUM ERR] RL	—	—	—	WT-16
C1716: [PRESSDATA ERR] FL	—	—	—	WT-18
C1717: [PRESSDATA ERR] FR	—	—	—	WT-16
C1718: [PRESSDATA ERR] RR	—	—	—	WT-16
C1719: [PRESSDATA ERR] RL	—	—	—	WT-16
C1720: [CODE ERR] FL	—	—	—	WT-16
C1721: [CODE ERR] FR	—	—	—	WT-16
C1722: [CODE ERR] RR	—	—	—	WT-16
C1723: [CODE ERR] RL	—	—	—	WT-16
C1724: [BATT VOLT LOW] FL	—	—	—	WT-16
C1725: [BATT VOLT LOW] FR	—	—	—	WT-16
C1726: [BATT VOLT LOW] RR	—	—	—	WT-16
C1727: [BATT VOLT LOW] RL	—	—	—	WT-16
C1729: VHCL SPEED SIG ERR	—	—	—	WT-19
C1735: IGN_CIRCUIT_OPEN	—	—	—	—

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000004917263

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All of the following lamps do not turn ON <ul style="list-style-type: none">• Front room/map lamp assembly• Personal lamp 2nd and 3rd row• Cargo room lamp• Front and rear step lamps• Vanity mirror lamps• Ignition keyhole illumination• Puddle lamps (if equipped)• Foot lamps (if equipped)	<ul style="list-style-type: none">• Harness between BCM and each interior room lamp• BCM	Battery saver output/power supply circuit Refer to INL-17 .
Some or all of the following interior room lamps do not turn ON/OFF <ul style="list-style-type: none">• Puddle lamps (if equipped)• Front room/map lamp assembly• Personal lamp 2nd row• Personal lamp 3rd row	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and each interior room lamp• BCM	Door switch circuit Refer to DLK-73 (with Intelligent Key) or DLK-274 (without Intelligent Key).
		Interior room lamp control circuit Refer to INL-19 .
Some or all of the following lamps do not turn ON/OFF <ul style="list-style-type: none">• Front step lamps• Rear step lamps• Foot lamps (if equipped)	<ul style="list-style-type: none">• Harness between BCM and step lamps and foot lamps• BCM	Step lamp circuit Refer to INL-22 .
Cargo lamp does not turn ON/OFF	<ul style="list-style-type: none">• Harness between BCM and cargo lamp• BCM	Cargo lamp control circuit Refer to INL-24 .
Ignition keyhole illumination does not turn ON/OFF	<ul style="list-style-type: none">• Harness between BCM and ignition keyhole illumination• BCM	Ignition keyhole illumination control circuit Refer to INL-26
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-12, "INT LAMP : CONSULT-III Function (BCM - INT LAMP)" .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to INL-12, "INT LAMP : CONSULT-III Function (BCM - INT LAMP)" .

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005156646

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000005260671

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

INL

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

M

N

O

P

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

General precautions for service operations

INFOID:000000004917265

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts which may get in the way with cloth.
- When removing parts with a screw driver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If an non-reuseable part is removed, replace it with a new one.
- After re-assembly has been completed, make sure each part functions correctly.
- Never work with wet hands.
- Turn the combination switch (lighting and turn signal switch) OFF before disconnecting and connecting the connector.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps or remove sealant residue.


< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR**INTERIOR ROOM LAMP****Removal and Installation**

INFOID:000000004917266

MAP LAMP**Removal**

1. Remove overhead console (3). Refer to [INT-17, "Removal and Installation"](#).
2. Disconnect connectors (4) and remove the map lamp screws (1), then remove map lamp (2) from overhead console.

**Installation**


Installation is in the reverse order of removal.

Bulb Replacement

1. Using a suitable tool (A), remove map lamp lens (1).
2. Release one side of the bulb (2) from the tab, then pull straight downward to remove.

Map lamp bulb : 12V - 8W**CAUTION:**

Wrap a cloth around tool to protect the housing and lens.

**VANITY MIRROR LAMP****Removal**The vanity mirror lamp is replaced as part of the sunvisor assembly. Refer to [INT-17, "Removal and Installation"](#).**Installation**

Installation is in the reverse order of removal.

Bulb Replacement

INTERIOR ROOM LAMP


< ON-VEHICLE REPAIR >

1. Using a suitable tool (A), release the tabs and remove the vanity mirror lamp lens (1).
2. Release one side of the bulb (2) from the tab, then pull straight out to remove.

Vanity mirror lamp bulb : 12V - 1.8W

CAUTION:

Wrap a cloth around tool to protect the housing and lens.



ALLIA0320ZZ

GLOVE BOX LAMP

Removal

1. Remove instrument lower panel RH and glove box. Refer to [IP-17, "Removal and Installation"](#).
2. Rotate glove box lamp socket and rotate counterclockwise to release from steering member.


Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Remove instrument lower panel RH and glove box. Refer to [IP-17, "Removal and Installation"](#).
2. Pull bulb (2) straight out from glove box lamp socket (1) to remove.

Glove box lamp bulb : 12V - 3.4W




ALLIA0321ZZ

STEP LAMP

Removal

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >



- 1. Step lamp connector
- 2. Door finisher
- 3. Step lamp lens/socket
- 4. Step lamp bulb

← Vehicle front

1. Insert a suitable tool between door finisher and step lamp lens/socket to release the pawls.
2. Disconnect the step lamp connector, then remove step lamp.

Installation

Installation is in the reverse order of removal.

Bulb Replacement


1. Remove the step lamp lens/socket.
2. Pull the bulb straight out to remove.

Step lamp bulb : 12V - 3.8W

PERSONAL LAMP (if equipped)

Removal

1. Remove overhead console. Refer to [INT-17, "Removal and Installation"](#).
2. Remove personal lamp screws (3).
3. Disconnect personal lamp electrical connectors (1), then remove personal lamps (2) from overhead console.



Installation

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

Installation is in the reverse order of removal.


Bulb Replacement

1. Using a suitable tool (A), release the pawls and remove personal lamp lens (1).
2. Pull bulb (2) straight out to remove.

Personal lamp bulb : 12V - 6W

CAUTION:


Wrap a cloth around tool to protect the housing and lens.



FOOTWELL LAMP

Removal

Rotate footwell lamp socket (3) counterclockwise from bracket.




Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Release the pawls and remove bulb shield from bracket (1).
2. Pull bulb (2) straight out from footwell lamp socket (3) to remove.

Footwell lamp bulb : 12V - 3.4W



ILLUMINATION

< ON-VEHICLE REPAIR >

ILLUMINATION


Removal and Installation

INFOID:0000000004917267

ILLUMINATION CONTROL SWITCH

Removal

The illumination control switch (1) is replaced as a part of the combination meter assembly. Refer to [MWI-106, "Removal and Installation"](#).




Installation

Installation is in the reverse order of removal.

CARGO LAMP (if equipped)

Removal

1. Using a suitable tool (A), release the pawls and remove the cargo lamp lens (1).
2. Remove cargo lamp screws (2).
3. Disconnect the connector, then remove cargo lamp.



Installation

Installation is in the reverse order of removal.

Bulb Replacement


ILLUMINATION

< ON-VEHICLE REPAIR >

1. Using a suitable tool, release the pawls and remove the cargo lamp lens.
2. Release the cargo lamp bulb retainers (1), then pull bulb (2) straight out to remove.

Cargo lamp bulb

: 12V - 8W




CONSOLE ILLUMINATION LAMP (if equipped)

Removal

The console illumination lamp (1) is replaced as part of the map lamp assembly (2). Refer to [INL-77, "Removal and Installation"](#).

←: Vehicle front




Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Remove overhead console. Refer to [INT-17, "Removal and Installation"](#).
2. Rotate console illumination lamp bulb (1) counterclockwise, then pull straight out away from map lamp assembly (2) to remove.



BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Interior Lamp/Illumination

INFOID:000000004917268

Item	Wattage (W)*
Map Lamp	8
Vanity mirror lamp	1.8
Glove box lamp	3.4
Step lamp	3.8
Personal lamp	6
Footwell lamp	3.4
Cargo lamp	8
Console illumination lamp	-

*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P