

SECTION **PG**

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTION	2	GROUND	31	A
PRECAUTIONS	2	Ground Distribution	31	B
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	HARNESS	41	C
Precaution Necessary for Steering Wheel Rotation After Battery Disconnect	2	Harness Layout	41	D
Precaution for Power Generation Variable Voltage Control System	3	ELECTRICAL UNITS LOCATION	63	E
PREPARATION	4	Electrical Units Location	63	F
PREPARATION	4	HARNESS CONNECTOR	66	G
Special Service Tool	4	Description	66	H
Commercial Service Tool	4	STANDARDIZED RELAY	69	I
BASIC INSPECTION	5	Description	69	J
BATTERY	5	FUSE BLOCK - JUNCTION BOX (J/B)	71	K
How to Handle Battery	5	Terminal Arrangement	71	L
Work Flow	7	FUSE, FUSIBLE LINK AND RELAY BOX	72	PG
INSPECTION AND ADJUSTMENT	8	Terminal Arrangement	72	N
ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL	8	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	74	O
ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement	8	IPDM E/R Terminal Arrangement - Type A	74	P
COMPONENT DIAGNOSIS	9	IPDM E/R Terminal Arrangement - Type B	75	
POWER SUPPLY ROUTING CIRCUIT	9	ON-VEHICLE REPAIR	76	
Wiring Diagram — Battery Power Supply —	9	BATTERY	76	
Wiring Diagram — Accessory Power Supply —	18	Removal and Installation	76	
Wiring Diagram — Ignition Power Supply —	22	SERVICE DATA AND SPECIFICATIONS (SDS)	77	
Fuse	30	SERVICE DATA AND SPECIFICATIONS (SDS)	77	
Fusible Link	30	Battery	77	

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005153282

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000005212330

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

Precaution for Power Generation Variable Voltage Control System

INFOID:000000004918857

CAUTION:

For this model, the battery current sensor that is installed to the negative battery cable measures the charging/discharging current of the battery and performs various engine controls. If an electrical component is connected directly to the negative battery terminal, the current flowing through that component will not be measured by the battery current sensor. This condition may cause a malfunction of the engine control system and battery discharge may occur. Do not connect an electrical component or ground wire directly to the battery terminal.

A
B
C
D
E
F
G
H
I
J
K
L

PG

N
O
P

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool

INFOID:000000004918858

Tool number (Kent-Moore No.) Tool name	Description
— (—) Model GR-8 Multitasking Battery Diagnostic Station	Tests batteries, starting and charging systems. For operating instructions, refer to diagnostic station instruction manual.




AWI1A1239ZZ

Commercial Service Tool

INFOID:000000004918859

Tool name	Description
Power tool	Loosening bolts and nuts



PBIC0190E

BATTERY

< BASIC INSPECTION >

BASIC INSPECTION

BATTERY

How to Handle Battery

INFOID:000000004918860


CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.


- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".



- When the vehicle is not going to be used over a long period of time, disconnect the battery cable from the negative terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.



CHECKING ELECTROLYTE LEVEL

WARNING:


Never allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, never touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

BATTERY

< BASIC INSPECTION >

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




Sulphation

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.


To determine if a battery has been “sulphated”, note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.



Hydrometer Temperature Correction

Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024

BATTERY

< BASIC INSPECTION >

Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Never “quick charge” a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Never turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 55 °C (131 °F), stop charging. Always charge battery at a temperature below 55 °C (131 °F).

Charging Rates

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

Do not charge at more than 50 ampere rate.

NOTE:

The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.

Work Flow

INFOID:000000004918861

TROUBLE DIAGNOSIS WITH MULTITASKING BATTERY DIAGNOSTIC STATION

Refer to diagnostic station instruction manual.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000005188409

Required Procedure After Battery Disconnection

System	Item	Reference
Engine Control	Idle Air Volume Learning	Refer to EC-23, "Idle Air Volume Learning" .
Brake Control	Steering Angle Sensor Neutral Position	Refer to BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement" .
Roof	Sunroof Memory Reset/Initialization	Refer to RF-5, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement" .
Seats	Automatic Drive Positioner System Initialization	Refer to Owner's Manual.
Audio-Visual System	Audio (Radio Preset)	Refer to Owner's Manual.
	Navigation System	Refer to Owner's Manual.
	Rear View Monitor Guiding Line Adjustment	Refer to AV-277, "REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Special Repair Requirement" .

POWER SUPPLY ROUTING CIRCUIT


< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram —Battery Power Supply —

INFOID:000000004918863




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

4W : WITH 4-WHEEL DRIVE
T7 : TRAILER TOW 7 PIN




* : THIS FUSE IS LOCATED IN THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) BOX.

ABMWA0406GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >




ABMWA0407GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >




ABMWA0408GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

BATTERY POWER SUPPLY CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1N	Y/R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1P	G	-
13P	P	-
16P	R	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W/B	-

Connector No.	M37
Connector Name	FUSE BLOCK (J/B)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1S	W	-

Connector No.	M38
Connector Name	FUSE BLOCK (J/B)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2R	W	-

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4Q	Y/R	-

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

Connector No.	M66
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	M60
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1T	R/Y	-

Connector No.	E30
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	-



Terminal No.	Color of Wire	Signal Name
7	W	-

Connector No.	E27
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B/R	-
2	B/Y	-

Connector No.	E7
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	W	-
4	R	-

ABMIA1119GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



9	8	7	6	5	4	3		
18	17	16	15	14	13	12	11	10

Terminal No.	Color of Wire	Signal Name
3	BR	IGN COIL
4	W/L	ECM
6	L	ETC
7	W/B	ECM RLY CONT
10	G	DTRL RLY SUPPLY

Connector No.	E118
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



1	2
---	---

Terminal No.	Color of Wire	Signal Name
1	B/Y	F/L_USM
2	R	F/L_MAIN

Connector No.	E33
Connector Name	WIRE TO WIRE
Connector Color	BLACK



1

Terminal No.	Color of Wire	Signal Name
1	W	-


Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



51	50	49		
56	55	54	53	52

Terminal No.	Color of Wire	Signal Name
49	R/L	ILLUMINATION
50	W/R	FR FOG LAMP LH
51	W/R	FR FOG LAMP RH
52	L	H/LAMP LO LH
54	R/Y	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L/W	H/LAMP HI RH

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
47	O	ETC RLY CONT

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



29	28	27	26	25		
36	35	34	33	32	31	30

Terminal No.	Color of Wire	Signal Name
30	W	ECM BAT


AWMIA0877GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
10G	W/B	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	R/L	TAIL_LAMP
59	B	GND(POWER)
61	BR	TRAILER RLY SUPPLY

Connector No.	F27
Connector Name	STARTER MOTOR
Connector Color	BLACK

Connector No.	E204
Connector Name	GENERATOR
Connector Color	-



Connector No.	E202
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	-



Terminal No.	Color of Wire	Signal Name
2	B/R	-

Terminal No.	Color of Wire	Signal Name
1	B/R	-

Terminal No.	Color of Wire	Signal Name
5	B/R	-

ABMIA0061GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Wiring Diagram —Accessory Power Supply—

INFOID:000000004918864

ACCESSORY POWER SUPPLY




ABMWA0409GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

ACCESSORY POWER SUPPLY CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7N	B	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	V	-
10P	O	-
11P	G/W	-
12P	L/W	-

Connector No.	M26
Connector Name	IGNITION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
B	G	-
ACC	V	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	75G	Color of Wire	G	Signal Name	-
--------------	-----	---------------	---	-------------	---

Connector No.	M37
Connector Name	FUSE BLOCK (J/B)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1S	W	-

ABMIA1122GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

POWER SUPPLY ROUTING CIRCUIT


< COMPONENT DIAGNOSIS >

Connector No.	M66
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	1	Color of Wire	W	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	M60
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	6T	Color of Wire	O	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	6Q	Color of Wire	V	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	E33
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	1	Color of Wire	W	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E7
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	GRAY




Terminal No.	3	Color of Wire	W	Signal Name	-
--------------	---	---------------	---	-------------	---

ABMIA1123GB


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	J-2
Connector Name	FUSE BLOCK (J/B) (ACCESSORY RELAY)
Connector Color	-



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	75G	Color of Wire	G	Signal Name	-
--------------	-----	---------------	---	-------------	---

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

ABMIA1124GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >




ABMWA0410GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


ABMWA0412GB

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

IGNITION POWER SUPPLY CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M26
Connector Name	IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2N	W/R	-
3N	SB	-
5N	Y/G	-
7N	B	-
8N	L/R	-

Terminal No.	Color of Wire	Signal Name
5P	O/L	-
6P	W/L	-
7P	LG	-
9P	R/B	-
14P	O	-

Terminal No.	Color of Wire	Signal Name
IG1	B/R	-
IG2	R	-
ST	BR	-
B	G	-
R	LG	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
75G	G	-
77G	B/R	-

Connector No.	M37
Connector Name	FUSE BLOCK (J/B)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1S	W	-

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	M66
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1Q	G/R	-
2Q	R	-
3Q	Y/G	-
5Q	G	-
7Q	B/R	-

Connector No.	M38
Connector Name	FUSE BLOCK (J/B)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1R	B/R	-

Connector No.	E33
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	E27
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	B/Y	-

Connector No.	E7
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	W	-
4	R	-

ABMIA1126GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



21	20	19
24	23	22

Terminal No.	Color of Wire	Signal Name
22	G	F/L MOTOR FAN
23	GR/W	HEATED MIRROR
24	L	MOTOR FAN2

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



9	8	7	6	5	4	3
18	17	16	15	14	13	12
11	10					

Terminal No.	Color of Wire	Signal Name
8	R/B	O2 SENSOR
11	Y/B	A/C COMPRESSOR
12	L/W	IGN SW (IG)
13	B/Y	FUEL PUMP
14	Y/R	A/T CU IGN SUPPLY
15	LG/B	ABS IGN SUPPLY
16	G	REVERSE LAMP
17	W	INJECTOR

Connector No.	E118
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



1	2
---	---

Terminal No.	Color of Wire	Signal Name
1	B/Y	F/L_USM
2	R	F/L_MAIN

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60

Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)
60	B/W	RR DEF

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
46	GR	FUEL PUMP RLY CONT

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



29	28	27	26	25
36	35	34	33	32
31	30			


Terminal No.	Color of Wire	Signal Name
27	W/B	TTOW REV LAMP
32	L	FR WIPER LO
35	L/B	FR WIPER HI

ABMIA1127GB


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Connector No.	J-1
Connector Name	FUSE BLOCK (J/B) (REAR BLOWER MOTOR RELAY)
Connector Color	-



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
75G	G	-
77G	B/R	-

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

Fuse

INFOID:000000004918866

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



Fusible Link


INFOID:000000004918867

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

1 : Fusible link

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



GROUND



< COMPONENT DIAGNOSIS >

GROUND

Ground Distribution

INFOID:000000004918868

MAIN HARNESS




A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

ABMIA1128GB


GROUND

< COMPONENT DIAGNOSIS >



CONNECTOR NUMBER	CONNECT TO
M17	Steering angle sensor
M20	BCM (body control module) (Terminal No. 67)
M21	NATS antenna amp.
M22	Data link connector (Terminal No. 4)
M22	Data link connector (Terminal No. 5)
M23	Combination meter (Terminal No. 52)
M24	Combination meter (Terminal No. 9)
M28	Combination switch
M35	Air bag diagnosis sensor unit (Terminal No. 2)
M42	AV control unit (Terminal No. 20) (with base audio system)
M44	AV control unit (Terminal No. 54) (with base audio system)
M46	AV control unit (Terminal No. 85) (with base audio system)
M47	Sonar buzzer
M50	A/C auto amp. (Terminal No. 36)
M51	Trailer tow relay 1
M70	Intelligent key unit (Terminal No. 12)
M107	Front blower relay
M112	BOSE speaker amp. (Terminal No. 12)
M122	Variable blower control (front)
M139	Diode-1
M160	AV control unit (Terminal No. 20) (with BOSE audio system without NAVI)
M165	AV control unit (Terminal No. 65) (with BOSE audio system with NAVI)
M165	AV control unit (Terminal No. 67) (with BOSE audio system with NAVI)
M165	AV control unit (Terminal No. 86) (with BOSE audio system with NAVI)
M165	AV control unit (Terminal No. 87) (with BOSE audio system with NAVI)
M166	AV control unit (Terminal No. 85) (with BOSE audio system without NAVI)
M171	AV control unit (Terminal No. 54) (with BOSE audio system without NAVI)


Preceding page




ABMIA1129GB

GROUND

< COMPONENT DIAGNOSIS >



Preceding page



CONNECTOR NUMBER	CONNECT TO
(M3)	Fuse block (J/B)
(M13)	Front passenger air bag off indicator
(M53)	Front power socket LH
(M54)	Front power socket RH
(M55)	Hazard switch
(M59)	Glove box lamp
(M81)	Shift lock control unit (Terminal No. 8)
(M93)	Display unit (Terminal No. 1)(without NAVI)
(M95)	Rear power vent window switch
(M98)	A/C and AV switch assembly
(M181)	AV control unit (Terminal No. 20) (with Bose audio system with NAVI)
(M188)	Display unit (Terminal No. 13) (with NAVI)
(M188)	Display unit (Terminal No. 1) (with NAVI)
(M203)	A/T shift selector (Terminal No. 2) (with intelligent key system)
(M203)	A/T shift selector (Terminal No. 8) (with intelligent key system)
(M204)	A/T shift selector (Terminal No. 2) (without intelligent key system)
(M204)	A/T shift selector (Terminal No. 8) (without intelligent key system)
(M205)	DVD player (Terminal No. 5)
(M207)	Console power socket
(M282)	Front heated seat switch RH
(M283)	VDC off switch
(M285)	Front heated seat switch LH
(M288)	Tow mode switch (Terminal No.2)
(M288)	Tow mode switch (Terminal No.6)
(M280)	Heated steering wheel switch
(R3)	Vanity lamp LH
(R7)	Auto anti-dazzling inside mirror
(R8)	Vanity lamp RH
(R102)	Front room/map lamp assembly
(R4)	Sunroof motor assembly
(D105)	Power window and door lock/unlock switch RH
(D106)	Door mirror RH (door mirror defogger) (Terminal No.6) (without automatic drive positioner)
(D107)	Door mirror RH (door mirror defogger) (Terminal No.11) (with automatic drive positioner)
(D116)	Front door request switch RH




ABMIA1130GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND

< COMPONENT DIAGNOSIS >

ENGINE ROOM HARNESS




CONNECTOR NUMBER	CONNECT TO
(E16)	ECM (Terminal No. 115)
(E16)	ECM (Terminal No. 116)
(E142)	Transfer control unit (Terminal No. 6)
(E143)	Transfer control unit (Terminal No. 45)
(F9)	A/T assembly (Terminal No. 10)
(F9)	A/T assembly (Terminal No. 5)
(F11)	Crankshaft position sensor (POS)
(F23)	Camshaft position sensor (PHASE)
(F50)	Electric throttle control actuator (throttle position sensor shield)
(F54)	ECM (Terminal No. 1)
(F56)	Transfer terminal cord assembly
(F62)	Intake valve timing control position sensor (bank 1)
(F64)	Intake valve timing control position sensor (bank 2)
(F5)	Air fuel ratio (A/F) sensor 1 (bank 2) shield
(F65)	Air fuel ratio (A/F) sensor 1 (bank 1) shield
(F102)	Knock sensor (bank 1) shield
(F104)	Knock sensor (bank 2) shield

CONNECTOR NUMBER	CONNECT TO
(E3)	Horn
(E6)	Front combination lamp LH (Terminal No.4) (with daytime light system)
(E8)	Dropping resistor
(E11)	Front combination lamp LH (Terminal No. 3) (without daytime light system)
(E11)	Front combination lamp LH (Terminal No. 4) (without daytime light system)
(E17)	Fuel pump control module (FPCM) (Terminal No. 1)
(E21)	Brake fluid level switch
(E102)	Front fog lamp RH
(E103)	Daytime light relay
(E113)	Cooling fan motor
(E116)	Condenser-2
(C5)	Fuel level sensor unit and fuel pump (without flex fuel)
(C106)	License plate lamp LH
(C107)	License plate lamp RH


ABMIA1131GB

GROUND

< COMPONENT DIAGNOSIS >



Preceding page



CONNECTOR NUMBER	CONNECT TO
(E46)	Transfer shift high relay (Terminal No. 2)
(E46)	Transfer shift high relay (Terminal No. 4)
(E47)	Transfer shift low relay (Terminal No. 2)
(E47)	Transfer shift low relay (Terminal No. 4)
(E130)	Compressor motor relay
(E140)	Trailer tow relay 2
(E142)	Transfer control unit (Terminal No. 3)
(E156)	Trailer turn relay LH
(E157)	Trailer turn relay RH
(F55)	ATP switch
(F57)	Transfer motor
(F58)	Transfer control device (Terminal No. 22)
(F59)	Wait detection switch
(F60)	Neutral-4LO switch
(C2)	Trailer
(C9)	Suspension air compressor (Terminal No. 1)
(C9)	Suspension air compressor (Terminal No. 3)






CONNECTOR NUMBER	CONNECT TO
(E23)	Front wiper motor
(E101)	Front fog lamp LH
(E106)	Washer fluid level switch
(E107)	Front combination lamp RH (headlamp) (Terminal No.3) (without daytime light system)
(E107)	Front combination lamp RH (headlamp) (Terminal No.4) (without daytime light system)
(E108)	Front combination lamp RH (headlamp) (Terminal No.3) (with daytime light system)
(E108)	Front combination lamp RH (headlamp) (Terminal No.4) (with daytime light system)
(E122)	IPDM E/R (intelligent power distribution module engine room) (Terminal No. 38)
(E124)	IPDM E/R (intelligent power distribution module engine room) (Terminal No. 59)

ABMIA1132GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND



< COMPONENT DIAGNOSIS >



ABMIA1133GB

GROUND

< COMPONENT DIAGNOSIS > ENGINE CONTROL HARNESS






A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND

< COMPONENT DIAGNOSIS >

BODY HARNESS






ABMIA1135GB

GROUND

< COMPONENT DIAGNOSIS >

BODY NO. 2 HARNESS





ABMIA1136GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND

< COMPONENT DIAGNOSIS >

BACK DOOR NO. 2 RH HARNESS



ABMIA1137GB

HARNESS

< COMPONENT DIAGNOSIS >

HARNESS


Harness Layout

INFOID:000000004918869

HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:


- Main Harness, Console Sub-harness, Console Switch Sub-harness and Optical Sensor Sub-harness
- Engine Room Harness and Engine Room Sub-harness
- Engine Room Harness (Passenger Compartment)
- Engine Control Harness and Engine Control Sub-harness
- Chassis Harness and Rear Sonar Sensor Sub-harness
- Body Harness, Left Front Seat Harness and Third Row Power Folding Seat Sub-harness
- Body No. 2 Harness and Right Front Seat Harness
- Room Lamp Harness, Room Lamp Sub-harness A and Room Lamp Sub-harness B
- Back Door Harness, Back Door No. 2 Harness, Back Door RH Harness, Back Door LH Harness and Back Door No. 2 RH Harness



To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.


OUTLINE



HARNESS

< COMPONENT DIAGNOSIS >

MAIN HARNESS



ABMIA1139GB

G4	M1	W/16	: To R1	E3	M81	GR/10	: Shift lock control unit
F4	M2	W/12	: To R2	A3	M82	W/2	: Circuit breaker-2
G2	M3	W/8	: Fuse block (J/B)	A2	M83	BR/6	: Pedal adjusting switch (without automatic drive positioner)
G2	M4	W/16	: Fuse block (J/B)	G4	M84	W/16	: To B101

HARNESSES

< COMPONENT DIAGNOSIS >

A3	M6	W/10	: To E10	B3	M87	B/5	: Rear power vent window relay (open)	A
A2	M7	B/5	: Passenger select unlock relay	B3	M89	B/5	: Rear power vent window relay (close)	A
A3	M8	W/16	: To D2	A3	M91	W/16	: To E26	B
A2	M9	BR/24	: To D1	A2	M92	GR/6	: Power liftgate switch	B
A3	M10	Y/4	: To E29	D1	M93	W/24	: Display unit (without NAVI)	C
A3	M11	B/1	: Parking brake switch	A2	M95	W/6	: Rear power vent window switch	C
C3	M12	GR/6	: Key switch and ignition knob switch	A2	M96	BR/6	: Pedal adjusting switch (with automatic drive positioner)	D
D3	M13	BR/2	: Front passenger air bag OFF indicator	C2	M98	W/16	: A/C and AV switch assembly	D
B3	M15	W/4	: Steering lock solenoid	C3	M99	BR/2	: Foot lamp LH	E
B2	M17	W/8	: Steering angle sensor	F4	M100	BR/2	: Foot lamp RH	E
C2	M18	W/40	: BCM (body control module)	E3	M104	W/4	: Aux jack	F
C2	M19	W/15	: BCM (body control module)	F2	M105	Y/2	: Front passenger air bag module	F
C2	M20	B/15	: BCM (body control module)	F2	M106	O/2	: Front passenger air bag module	F
C3	M21	W/4	: NATS antenna amp.	F3	M107	B/5	: Front blower relay	G
C3	M22	W/16	: Data link connector	D5	M108	B/6	: Yaw rate/ side/ decel G sensor	G
B1	M23	W/12	: Combination meter	A1	M109	BR/2	: Front tweeter LH	H
C1	M24	W/40	: Combination meter	D2	M110	BR/2	: Center speaker	H
F2	M25	B/4	: Remote keyless entry receiver	F2	M111	BR/2	: Front tweeter RH	I
B2	M26	W/6	: Ignition switch	C2	M112	BR/14	: BOSE speaker amp.	I
B2	M27	W/4	: Key switch and key lock solenoid	C2	M113	BR/23	: BOSE speaker amp.	J
B2	M28	W/16	: Combination switch	A2	M116	GR/8	: Sonar system OFF switch	K
B2	M29	Y/6	: Combination switch (spiral cable)	B1	M118	B/2	: Front sonar buzzer	K
B3	M30	GR/8	: Combination switch (spiral cable)	F2	M120	W/4	: Remote keyless entry receiver	L
G4	M31	SMJ	: To E152	F4	M122	W/4	: Variable blower control (front)	L
C3	M32	W/4	: In-vehicle sensor	C3	M123	W/2	: Tire pressure warning check connector	PG
B3	M33	W/32	: Automatic drive positioner control unit	D2	M139	B/2	: Diode-1	PG
B3	M34	W/16	: Automatic drive positioner control unit	D1	M140	B/2	: Diode-2	PG
C5	M35	Y/28	: Air bag diagnosis sensor unit	C2	M141	GR/8	: 4WD shift switch	PG
G4	M36	SMJ	: To B149	E1	M142	B/6	: Mode door motor (front)	PG
G3	M37	B/1	: Fuse block (J/B)	E3	M143	B/6	: Air mix door motor (passenger)	PG
G3	M38	B/2	: Fuse block (J/B)	C1	M144	B/6	: Defroster door motor	PG
G3	M39	W/8	: Fuse block (J/B)	E3	M146	GR/2	: Intake sensor	PG
A3	M40	SMJ	: To B69	D3	M147	B/6	: Air mix door motor (driver)	PG
C3	M41	W/16	: Satellite radio tuner or pre-wiring for satellite radio tuner	B1	M150	W/2	: Ignition keyhole illumination	PG
D2	M42	W/20	: AV control unit (with base audio system)	G4	M157	W/20	: To B161	PG
D2	M43	W/12	: AV control unit (with base audio system)	A3	M158	W/10	: To D3	PG
D2	M44	W/24	: AV control unit (with base audio system)	D2	M160	W/20	: AV control unit (with Bose audio system-without NAVI)	PG
D2	M46	W/32	: AV control unit (with base audio system)	D2	M161	W/20	: AV control unit (with Bose audio system with NAVI)	PG
E3	M47	B/2	: Sonar buzzer	D2	M162	W/12	: AV control unit (with Bose audio system with NAVI)	PG
D2	M49	B/26	: A/C auto amp.	D2	M163	W/32	: AV control unit (with Bose audio system with NAVI)	PG

HARNESS


< COMPONENT DIAGNOSIS >

D2	M50	L/26	: A/C auto amp.	D3	M164	W/16	: AV control unit (with Bose audio system- without NAVI)
B3	M51	L/4	: Trailer tow relay 1	D2	M165	W/40	: AV control unit (with Bose audio system with NAVI)
B2	M52	W/2	: Combination switch (spiral cable)	D2	M166	W/32	: AV control unit (with Bose audio system- without NAVI)
D3	M53	B/3	: Front power socket LH	D1	M168	W/24	: Display unit (with NAVI)
E3	M54	B/3	: Front power socket RH	D2	M170	W/12	: AV control unit (with Bose audio system- without NAVI)
D2	M55	W/4	: Hazard switch	D2	M171	W/24	: AV control unit (with Bose audio system- without NAVI)
D4	M56	W/16	: To M201	Console sub-harness			
A3	M57	—	: Body ground	D4	M201	W/16	: To M56
F2	M58	B/6	: Intake door motor	D4	M202	BR/24	: To M64
F3	M59	BR/2	: Glove box lamp	D4	M203	W/12	: A/T shift selector (with intelligent key system)
G3	M60	W/6	: Fuse block (J/B)	D4	M204	W/12	: A/T shift selector (without intelligent key system)
C3	M61	—	: Body ground	D5	M205	W/32	: DVD player
F4	M62	B/2	: Front blower motor	C5	M207	B/3	: Console power socket
D4	M63	BR/20	: To M251	C4	M208	BR/20	: To M69
D4	M64	BR/24	: To M202	C5	M209	W/2	: Center console area antenna (rear)
F2	M65	W/4	: To M301	C4	M210	GR/2	: Center console area antenna (front)
G3	M66	B/1	: To E33	Console switch sub-harness			
C3	M69	BR/20	: To M208	D4	M251	BR/20	: To M63
A2	M70	W/40	: Intelligent key unit	D4	M252	BR/6	: Front heated seat switch RH
A2	M71	L/4	: Heated steering relay	C4	M253	GR/6	: VDC OFF switch
E3	M72	W/12	: AV control unit (with Bose audio system-without NAVI)	C3	M255	W/6	: Front heated seat switch LH
D3	M73	BR/6	: Back-up lamp relay	C4	M256	B/2	: A/T shift selector
G3	M74	BR/20	: To D102	C4	M258	GR/8	: Tow mode switch
G3	M75	W/10	: To D101	C4	M260	W/6	: Heated steering wheel switch
A3	M76	W/6	: Electric brake (pre-wiring)	Optical sensor sub-harness			
E2	M77	Y/4	: Front passenger air bag module (service replacement)	F2	M301	W/4	: To M65
E2	M79	—	: Body ground	F2	M302	W/4	: Optical sensor
C1	M80	B/2	: Resistor				

HARNESS

< COMPONENT DIAGNOSIS >

ENGINE ROOM HARNESS



ABMIA0076GB


C4	E1	GR/2	: Ambient sensor	E3	E114	B/6	: Delta stroke motor
D3	E2	W/16	: To F32	D1	E116	W/2	: Condenser-2
C3	E3	B/2	: Horn	D3	E117	GR/2	: Front wheel sensor RH
C3	E4	Y/2	: Crash zone sensor	D3	E118	B/2	: IPDM E/R (intelligent power distribution module engine room)

HARNESSES

< COMPONENT DIAGNOSIS >

C1	E5	W/24	: To F14	C1	E119	W/16	: IPDM E/R (intelligent power distribution module engine room)
D4	E6	B/6	: Front combination lamp LH (with daytime light system)	D1	E120	W/6	: IPDM E/R (intelligent power distribution module engine room)
C2	E7	GR/2	: Fusible link box (battery)	D1	E120	W/6	: IPDM E/R (intelligent power distribution module engine room)
B2	E8	GR/2	: Dropping resistor	E1	E121	BR/12	: IPDM E/R (intelligent power distribution module engine room)
C2	E9	—	: Body ground	C1	E122	W/12	: IPDM E/R (intelligent power distribution module engine room)
D4	E11	B/6	: Front combination lamp LH (without daytime light system)	D1	E123	BR/8	: IPDM E/R (intelligent power distribution module engine room)
D3	E12	B/5	: Stop lamp relay	D1	E124	B/6	: IPDM E/R (intelligent power distribution module engine room)
D4	E14	—	: Body ground	F3	E125	B/47	: ABS actuator and electric unit (control unit)
B2	E15	—	: Body ground	D4	E126	—	: Body ground
C1	E16	B/40	: ECM	C2	E130	W/2	: Compressor motor relay
E4	E18	GR/2	: Front wheel sensor LH	C3	E131	W/2	: Compressor motor relay
D1	E19	W/16	: To F33	C2	E135	GR/2	: Transfer dropping resistor
E3	E21	GR/2	: Brake fluid level switch	C1	E140	BR/6	: Trailer tow relay 2
E2	E23	GR/6	: Front wiper motor	B2	E153	W/2	: Transfer motor relay
D4	E24	—	: Body ground	B2	E154	W/2	: Transfer motor relay
F3	E25	BR/3	: Intelligent key warning buzzer	D3	E156	L/4	: Trailer turn relay LH
C3	E27	BR/2	: Fusible link box (battery)	D3	E157	L/4	: Trailer turn relay RH
C2	E30	/1	: Fusible link box (battery)	D5	E158	B/3	: Front sonar sensor LH outer
E3	E31	GR/3	: Front pressure sensor	D5	E159	GR/3	: To E164
E3	E32	GR/3	: Rear pressure sensor	B4	E160	GR/3	: To E165
C1	E39	W/2	: To F34	C3	E161	B/3	: Battery current sensor
D3	E40	B/3	: To E201	B4	E162	B/3	: Front sonar sensor LH inner
D3	E41	SMJ	: To C1	C5	E163	B/3	: Front sonar sensor RH inner
E1	E46	B/5	: Transfer shift high relay	D5	E164	GR/3	: To E159
D2	E47	B/5	: Transfer shift low relay	A4	E165	GR/3	: To E160
C3	E48	B/3	: Refrigerant pressure sensor	A3	E166	B/3	: Front sonar sensor RH outer
E3	E49	B/6	: Active booster	Engine room sub-harness			
D1	E69	L/4	: Transfer shut off relay	D3	E201	B/3	: To E40
D5	E101	B/2	: Front fog lamp LH	C1	E202	/1	: Fusible link box (battery)
A3	E102	B/2	: Front fog lamp RH	C1	E203	—	: Engine ground
C3	E103	B/5	: Daytime light relay	C3	E204	/1	: Generator
D4	E105	BR/2	: Front and rear washer motor	C3	E205	B/3	: Generator
E4	E106	BR/2	: Washer fluid level switch	C3	E206	/1	: Generator
B3	E107	B/6	: Front combination lamp RH				
B3	E108	B/6	: Front combination lamp RH (without daytime light system)				
C5	E113	W/2	: Cooling fan motor				

ENGINE ROOM HARNESS (PASSENGER COMPARTMENT)



HARNESS

< COMPONENT DIAGNOSIS >

A3	E10	W/10	: To M6					A
G3	E17	W/4	: Fuel pump control module (FPCM)					
C4	E20	B/8	: Accelerator pedal position (APP) sensor					B
A3	E26	W/16	: To M91					
A3	E29	Y/4	: To M10					C
G3	E33	B/1	: To M66					
A3	E34	W/24	: To B40					
A4	E35	W/12	: To B41					D
A4	E36	W/2	: To B42					
B3	E37	BR/2	: ASCD brake switch					E
B3	E38	B/2	: Stop lamp switch					
B3	E109	GR/2	: Pedal adjusting motor assembly (with automatic drive positioner)					F
C4	E110	GR/3	: Pedal adjusting motor assembly					
G4	E139	W/8	: To B107					
F3	E142	W/24	: Transfer control unit					G
F3	E143	GR/24	: Transfer control unit					
G3	E152	SMJ	: To M31					H
B3	E167	GR/2	: Pedal adjusting motor (without automatic drive positioner)					I

PG


N

O

P

HARNESS

< COMPONENT DIAGNOSIS > ENGINE CONTROL HARNESS



ABMIA1142GB

D5	F3	B/1	: A/C Compressor	D4	F42	GR/2	: Fuel injector No. 5
D5	F4	GR/1	: Oil pressure switch	D3	F45	GR/2	: Fuel injector No. 7
D2	F5	GR/4	: Air fuel ratio (A/F) sensor 1 (bank 2)	B4	F46	B/3	: Power steering pressure sensor
C4	F6	GR/3	: Ignition coil No. 2 (with power transistor)	E4	F47	GR/3	: Ignition coil No. 1 (with power transistor)
C3	F7	GR/3	: Ignition coil No. 4 (with power transistor)	E4	F48	GR/3	: Ignition coil No. 3 (with power transistor)

HARNESS


< COMPONENT DIAGNOSIS >

C3	F8	GR/3	: Ignition coil No. 6 (with power transistor)	E4	F49	GR/3	: Ignition coil No. 5 (with power transistor)	A	
E2	F9	G/10	: A/T assembly	D4	F50	W/6	: Electric throttle control actuator	B	
C2	F10	—	: Engine ground	E4	F51	GR/3	: Ignition coil No. 7 (with power transistor)	B	
D3	F11	B/3	: Crankshaft position sensor (POS)	D2	F52	GR/3	: Ignition coil No. 8 (with power transistor)	C	
E1	F12	G/4	: Heated oxygen sensor 2 (bank 2)	E5	F53	B/6	: Mass air flow sensor	D	
F2	F13	G/4	: Heated oxygen sensor 2 (bank 1)	B2	F54	B/81	: ECM	E	
B2	F14	W/24	: To E5	F1	F55	B/2	: ATP switch	F	
D4	F15	GR/2	: EVAP canister purge volume control solenoid valve	F2	F56	B/8	: Transfer terminal cord assembly	G	
E5	F16	—	: Engine ground	G1	F57	B/2	: Transfer motor	H	
C4	F18	GR/2	: Fuel injector No. 2	F2	F58	GR/6	: Transfer control device	I	
D4	F20	GR/2	: Fuel injector No. 4	F1	F59	B/2	: Wait detection switch	J	
F4	F21	GR/2	: Condenser-1	F1	F60	GR/2	: Neutral-4LO switch	K	
D3	F22	GR/2	: Fuel injector No. 6	D5	F61	G/2	: Intake valve timing control solenoid valve (bank 1)	L	
D5	F23	B/3	: Camshaft position sensor (phase)	D5	F62	B/3	: Intake valve timing control position sensor (bank 1)	PG	
D4	F26	B/6	: To F101	C4	F63	G/2	: Intake valve timing control solenoid valve (bank 2)	N	
E3	F27	/1	: Starter motor	C4	F64	B/3	: Intake valve timing control position sensor (bank 2)	O	
E3	F28	GR/1	: Starter motor	E3	F65	GR/4	: Air fuel ratio (A/F) sensor 1 (bank 1)	P	
D4	F30	GR/2	: Fuel injector No. 1	C2	F68	GR/2	: Water valve		
D3	F31	GR/2	: Fuel injector No. 8	Engine control sub-harness					
B2	F32	W/16	: To E2	C3	F101	B/6	: To F26		
C2	F33	W/16	: To E19	C3	F102	B/2	: Knock sensor (bank 1)		
C2	F34	W/2	: To E39	C3	F103	GR/2	: Engine coolant temperature sensor		
B3	F39	—	: Fusible link (battery)	C3	F104	B/2	: Knock sensor (bank 2)		
D4	F41	GR/2	: Fuel injector No. 3						

HARNESS

< COMPONENT DIAGNOSIS >

CHASSIS HARNESS



ABMIA0079GB

G2	C1	SMJ	: To E41	C4	C11	BR/2	: Rear wheel sensor LH
B5	C2	B/7	: Trailer	D2	C12	GR/5	: Fuel level sensor unit and fuel pump (with flex fuel)
A3	C3	GR/8	: To C101	Rear sonar sensor sub-harness			
C3	C4	GR/3	: Evap control system pressure sensor	A4	C101	GR/8	: To C3

HARNESS

< COMPONENT DIAGNOSIS >

D2	C5	GR/5	: Fuel level sensor unit and fuel pump (without flex fuel)	A3	C102	B/3	: Rear sonar sensor LH outer	A
C3	C6	B/2	: Evap canister vent control valve	B4	C103	B/3	: Rear sonar sensor LH inner	
B4	C7	GR/2	: Rear bumper antenna	B4	C104	B/3	: Rear sonar sensor RH inner	B
C4	C8	B/3	: Height sensor	C5	C105	B/3	: Rear sonar sensor RH outer	
B4	C9	B/4	: Suspension air compressor	A5	C106	GR/2	: License plate lamp LH	
C4	C10	BR/2	: Rear wheel sensor RH	B5	C107	GR/2	: License plate lamp RH	C

D

E

F

G

H

I

J

K

L

PG

N


O

P

HARNESS

< COMPONENT DIAGNOSIS >

BODY HARNESS



ABMIA1143GB

G3	B3	W/16	: Suspension control unit	Front seat LH harness		
D4	B6	W/18	: To D201	C3	B200	W/16 : To B37 (with automatic drive positioner)
C5	B7	—	: Body ground	D5	B202	W/32 : Driver seat control unit
D4	B8	W/3	: Front door switch LH	D5	B203	W/16 : Driver seat control unit
C4	B9	Y/12	: Air bag diagnosis sensor unit	C4	B204	GR/5 : Sliding motor LH (with automatic drive positioner)

HARNESSES


< COMPONENT DIAGNOSIS >

E5	B10	Y/2	: Front LH side air bag module	D3	B205	W/4	: Reclining motor LH (with automatic drive positioner)	A
E5	B14	Y/2	: Front LH seat belt pre-tensioner	C4	B206	GR/5	: Lifting motor (front) (with automatic drive positioner)	B
E5	B15	Y/2	: LH side air bag (satellite) sensor	D4	B207	GR/5	: Lifting motor (rear) (with automatic drive positioner)	C
E3	B18	W/3	: Rear door switch LH	D4	B208	W/10	: Power seat switch LH (with automatic drive positioner)	D
G1	B19	—	: Body ground	D4	B209	W/3	: Front seat heater LH	E
F2	B24	W/16	: Sonar control unit (rear)	D3	B211	W/2	: To B45 (without automatic drive positioner)	F
B4	B32	W/6	: To B124	C5	B212	GR/2	: Sliding motor LH (without automatic drive positioner)	G
G2	B35	B/3	: Rear combination lamp LH	D3	B213	W/2	: Reclining motor LH (without automatic drive positioner)	H
D3	B37	W/16	: To B200 (with automatic drive positioner)	C4	B214	GR/2	: Lifting motor (front) (without automatic drive positioner)	I
C4	B38	Y/2	: LH side front curtain air bag module	D4	B215	GR/2	: Lifting motor (rear) (without automatic drive positioner)	J
C5	B40	W/24	: To E34	D4	B216	W/10	: Power seat switch LH (without automatic drive positioner)	K
C5	B41	W/12	: To E35	Third row power folding seat sub-harness				L
C5	B42	W/2	: To E36	F2	B400	W/10	: To B75	M
B4	B43	W/16	: To B111	E3	B401	GR/12	: Third row power folding seat control unit	N
D3	B45	W/2	: To B211 (without automatic drive positioner)	E3	B402	W/10	: Third row power folding seat control unit	O
F1	B48	W/18	: To D401	E3	B403	GR/4	: Third row power folding seat motor LH	P
F1	B49	W/2	: To D402	E2	B404	W/4	: To B425	PG
G2	B52	W/2	: Rear power vent window motor LH	E2	B425	W/4	: To B404	
F2	B54	Y/2	: LH side rear curtain air bag module	E3	B426	GR/4	: Third row power folding seat motor RH	
G3	B55	W/26	: Back door control unit					
F2	B56	GR/16	: Sonar control unit (front and rear)					
G2	B57	GR/10	: Sonar control unit (front and rear)					
G1	B63	W/6	: Back door close switch					
B5	B69	SMJ	: To M40					
G2	B70	B/3	: Rear combination lamp LH					
G5	B71	B/2	: Back-up lamp LH					
D5	B72	BR/6	: Subwoofer					
F3	B73	W/16	: Rear view camera control unit					
C4	B74	Y/4	: Seat belt buckle pre-tensioner assembly LH					
F2	B75	W/10	: To B400					
F2	B76	GR/2	: Luggage area antenna					

HARNESS

< COMPONENT DIAGNOSIS >

BODY NO. 2 HARNESS



ABMIA0081GB

F5	B101	W/16	: To M84	A1	B140	W/6	: To D601
A3	B105	B/3	: Rear combination lamp RH	E5	B141	W/8	: Bluetooth control unit
D4	B106	W/18	: To D301	E5	B142	W/32	: Bluetooth control unit
F4	B107	W/8	: To E139	E2	B145	W/16	: To R200
E4	B108	W/3	: Front door switch RH	E2	B146	BR/24	: To R201

HARNESS

< COMPONENT DIAGNOSIS >


F4	B111	W/16	: To B43	F4	B149	SMJ	: To M36
E3	B113	Y/12	: Air bag diagnosis sensor unit	B3	B150	W/2	: Rear power vent window motor RH
D5	B114	Y/2	: RH side air bag (satellite) sensor	B2	B153	W/2	: Cargo lamp
C4	B116	W/3	: Rear door switch RH	E5	B154	W/2	: To B303
F5	B117	—	: Body ground	B3	B155	B/6	: Air mix door motor (rear)
E5	B118	W/3	: Front seat heater RH	B3	B156	B/6	: Mode door motor (rear)
A3	B119	W/2	: Condenser-3	E4	B157	Y/4	: Seat belt buckle pre-tensioner assembly RH
A2	B120	W/2	: Condenser-4	F4	B161	W/20	: To M157
F4	B124	W/6	: To B32	C3	B162	BR/6	: Third row power folding seat switch passenger side (front)
E4	B126	Y/2	: Front RH side air bag module	A3	B163	W/6	: Third row power folding seat switch passenger side (rear)
D4	B127	Y/2	: Front RH seat belt pre-tensioner	C3	B164	W/6	: Third row power folding seat switch driver side (front)
C3	B128	Y/2	: RH side rear curtain air bag module	A3	B165	BR/6	: Third row power folding seat switch driver side (rear)
F4	B129	Y/2	: RH side front curtain air bag module	B2	B166	B/2	: Rear sonar buzzer
A3	B130	B/3	: Rear combination lamp RH	Front seat RH harness			
A3	B132	—	: Body ground	E4	B303	W/2	: To B154
A4	B133	W/4	: Variable blower control (rear)	F4	B308	W/6	: Power seat switch RH
B4	B134	W/2	: Rear blower motor	E4	B309	GR/2	: Sliding motor RH
A4	B135	B/2	: Back-up lamp RH	E4	B350	Y/8	: To B136
D4	B136	W/8	: To B350	E4	B351	B/18	: Occupant classification system control unit
D4	B137	W/3	: Belt tension sensor	E4	B352	B/3	: Occupant classification system sensor
B3	B138	B/3	: Rear cargo power socket	E4	B372	W/2	: Reclining motor RH
A2	B139	W/16	: To D602				

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESSES

< COMPONENT DIAGNOSIS >

ROOM LAMP HARNESS



ABMIA0082GB


A4	R1	W/16	: To M1	C3	R107	W/8	: To R9
A4	R2	W/12	: To M2	C2	R108	B/6	: Rear air control (front)
D3	R3	W/2	: Vanity lamp LH	D2	R109	W/4	: Microphone
C3	R4	W/10	: Sunroof motor assembly	Room lamp sub-harness B			
C2	R6	W/16	: To R101	D1	R200	W/16	: To B145

HARNESS

< COMPONENT DIAGNOSIS >

C3	R7	GR/10	: Auto anti-dazzling inside mirror	D1	R201	BR/24	: To B146
B3	R8	W/2	: Vanity lamp RH	C2	R202	W/12	: Video monitor
D3	R9	W/8	: To R107	D1	R203	W/3	: Personal lamp 2ND row
Room lamp sub-harness A				D2	R204	W/16	: Rear audio remote control unit
C2	R101	W/16	: To R6	E1	R205	W/3	: Personal lamp 3RD row
C3	R102	GR/8	: Front room/map lamp assembly	D2	R209	B/6	: Rear air control (rear)
D3	R104	GR/6	: Sunroof switch	E1	R210	W/2	: Over head console area antenna

FRONT DOOR LH HARNESS




ABMIA0083GB

D1	BR/24	: To M9	D9	GR/6	: Front power window motor LH
D2	W/16	: To M8	D10	BR/16	: Door mirror remote control switch (with automatic drive positioner)
D3	W/10	: To M158	D11	W/2	: Front step lamp LH
D4	W/16	: Door mirror LH (with automatic drive positioner)	D12	W/2	: Front door speaker LH
D5	W/8	: Seat memory switch	D13	W/16	: Door mirror remote control switch (without automatic drive positioner)
D6	W/6	: Door mirror LH (without automatic drive positioner)	D14	B/6	: Front door lock assembly LH
D7	W/16	: Main power window and door lock/unlock switch	D15	GR/2	: Front outside antenna LH
D8	W/3	: Main power window and door lock/unlock switch	D16	GR/2	: Front door request switch LH

HARNESS

< COMPONENT DIAGNOSIS >

FRONT DOOR RH HARNESS




ABMIA0084GB

D101	W/10	: To M75	D109	W/2	: Front step lamp RH
D102	BR/20	: To M74	D112	W/2	: Front door speaker RH
D104	GR/6	: Front power window motor RH	D114	B/6	: Front door lock actuator RH
D105	W/16	: Power window and door lock/unlock switch RH	D115	GR/2	: Front outside antenna RH
D106	W/6	: Door mirror RH (without automatic drive positioner)	D116	GR/2	: Front door request switch RH
D107	W/16	: Door mirror RH (with automatic drive positioner)			

HARNESS

< COMPONENT DIAGNOSIS >

REAR DOOR LH HARNESS



ABMIA1144GB


D201	W/18	: To B6			
D203	W/8	: Rear power window switch LH			
D204	GR/2	: Rear power window motor LH			
D205	B/6	: Rear door lock actuator LH			
D206	W/2	: Rear step lamp LH			
D207	BR/2	: Rear door speaker LH (with Bose audio system)			
D208	BR/2	: Rear door tweeter LH			
D209	W/2	: Rear door speaker LH (with base audio system)			

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS

< COMPONENT DIAGNOSIS >

REAR DOOR RH HARNESS




ABMIA1145GB

D301	W/18	: To B106			
D303	W/8	: Rear power window switch RH			
D304	GR/2	: Rear power window motor RH			
D305	B/6	: Rear door lock actuator RH			
D306	W/2	: Rear step lamp RH			
D307	BR/2	: Rear door speaker RH (with Bose audio system)			
D308	BR/2	: Rear door tweeter RH			
D309	W/2	: Rear door speaker RH (with base audio system)			

HARNESS

< COMPONENT DIAGNOSIS >

BACK DOOR HARNESS



ABMIA0085GB

Back door No. 2 LH harness				Back door RH harness			
E2	D401	W/18	: To B48	B3	D701	W/16	: To D606
E2	D402	W/2	: To B49	A3	D702	W/6	: To D605
D2	D403	GR/2	: High-mounted stop lamp	D3	D704	W/6	: Rear wiper motor
G3	D405	W/18	: To D501	C4	D706	GR/2	: Back door handle switch

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESSES

< COMPONENT DIAGNOSIS >

F2	D406	B/1	: Rear window defogger	D2	D707	B/1	: Glass hatch ajar switch
Back door LH harness				D3	D708	W/4	: Back door lock actuator
G3	D501	W/18	: To D405	B4	D715	BR/2	: Pinch strip RH
E3	D502	W/3	: Back door switch	B4	D716	BR/2	: Back door speaker RH
E4	D503	W/8	: Back door latch				
E4	D504	W/4	: Rear view camera				
F4	D514	BR/2	: Back door warning chime				
F4	D517	BR/2	: Pinch strip LH				
F4	D518	BR/2	: Back door speaker LH				
Back door No. 2 RH harness							
C2	D601	W/6	: To B140				
C2	D602	W/16	: To B139				
D2	D603	—	: Body ground				
B2	D604	B/1	: Rear window defogger				
A3	D605	W/6	: To D702				
B3	D606	W/16	: To D701				

ELECTRICAL UNITS LOCATION


< COMPONENT DIAGNOSIS >

ELECTRICAL UNITS LOCATION

Electrical Units Location

INFOID:000000004918870

ENGINE COMPARTMENT




A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P



ABMIA1146GB

ELECTRICAL UNITS LOCATION

< COMPONENT DIAGNOSIS > PASSENGER COMPARTMENT










A Instrument panel side RH



ABMIA1147GB

ELECTRICAL UNITS LOCATION

< COMPONENT DIAGNOSIS >



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

ABMIA1148GB

HARNESS CONNECTOR

< COMPONENT DIAGNOSIS >

HARNESS CONNECTOR

Description

INFOID:000000004918871

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.

HARNESS CONNECTOR


< COMPONENT DIAGNOSIS >

- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.


CAUTION:

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNES CONNECTOR

< COMPONENT DIAGNOSIS >

- Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.




- | | | |
|--|--|---|
| <p>1. Control unit with single lever</p> <p>A. Fasten</p> <p>B. Loosen</p> <p>C. Lever</p> | <p>2. Control unit with dual lever</p> <p>A. Fasten</p> <p>B. Loosen</p> <p>C. Lever</p> | <p>3. SMJ connector</p> <p>A. Fasten</p> <p>B. Loosen</p> <p>C. Lever</p> |
|--|--|---|

HARNES CONNECTOR (DIRECT-CONNECT SRS COMPONENT TYPE)

- SRS direct-connect type harness connectors are used on certain SRS components such as air bag modules and seat belt pre-tensioners.
- Always pull up to release black locking tab prior to removing connector from SRS components.
- Always push down to lock black locking tab after installing connector to SRS components. When locked, the black locking tab is level with the connector housing.

CAUTION:

- Do not pull the harness or wires when removing connectors from SRS components.



STANDARDIZED RELAY

< COMPONENT DIAGNOSIS >


STANDARDIZED RELAY

Description

INFOID:000000004918872

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS

- 1M 1 Make
- 2M 2 Make
- 1T 1 Transfer
- 1M-1B 1 Make 1 Break

















SEL882H

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

STANDARDIZED RELAY

< COMPONENT DIAGNOSIS >

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W


FUSE BLOCK - JUNCTION BOX (J/B)

< COMPONENT DIAGNOSIS >

FUSE BLOCK - JUNCTION BOX (J/B)

Terminal Arrangement

INFOID:000000004918873



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

ABMIA1149GB

FUSE, FUSIBLE LINK AND RELAY BOX

< COMPONENT DIAGNOSIS >


FUSE, FUSIBLE LINK AND RELAY BOX

Terminal Arrangement


INFOID:000000004918874

FUSE AND FUSIBLE LINK BOX

FUSIBLE LINK BOX (BATTERY)



FUSE AND FUSIBLE LINK BOX




ABMIA1166GB

FUSE, FUSIBLE LINK AND RELAY BOX

< COMPONENT DIAGNOSIS >

FUSE AND RELAY BOX



A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P

ABMIA1150GB


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< COMPONENT DIAGNOSIS >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Terminal Arrangement - Type A

INFOID:000000005369254




WKIA5852E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< COMPONENT DIAGNOSIS >

IPDM E/R Terminal Arrangement - Type B

INFOID:000000005369255



NOTE:

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

AAMIA0364GB

BATTERY

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

BATTERY

Removal and Installation

INFOID:000000004918875

REMOVAL


1. Disconnect the negative battery terminal (1) and positive battery terminal (2).

CAUTION:

Remove negative battery terminal first.

⇐ : **Front**

2. Remove the battery cover.
3. Remove the battery clamp bolt (3) and battery clamp.
4. Remove the battery.



AWBIA0504ZZ

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing, install the positive battery terminal first.

Battery clamp bolt : 14.7 N·m (1.5 kg-m, 11 ft-lb)

Battery terminal nut : 3.5 N·m (0.36 kg-m, 31 in-lb)

Reset electronic systems as necessary. Refer to [PG-8. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Battery

INFOID:000000004918876

	Standard battery	Heavy duty battery (LE models and FFV equipped vehicles)
Type	Gr. 24	Gr. 27F
Capacity (20 HR) minimum V-AH	72	80
Cold cranking current A (For reference value)	650	710

A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P