

SECTION **SE**  
SEAT

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

CONTENTS

<b>BASIC INSPECTION</b> .....	3	<b>THIRD ROW POWER FOLDING SEAT</b> .....	27
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	3	Wiring Diagram .....	27
Work Flow .....	3	<b>SYMPTOM DIAGNOSIS</b> .....	33
<b>INSPECTION AND ADJUSTMENT</b> .....	5	<b>THIRD ROW POWER FOLDING SEAT</b> .....	33
Preliminary Check .....	5	Symptom Table .....	33
<b>SYSTEM DESCRIPTION</b> .....	6	<b>NONE OF THE THIRD ROW POWER FOLDING SEATS WILL OPERATE WITH ANY SWITCH.</b> .....	34
<b>THIRD ROW POWER FOLDING SEAT</b> .....	6	None of the Third Row Power Folding Seats Will Operate With Any Third Row Power Folding Seat Switch .....	34
System Description .....	6	<b>ONLY ONE THIRD ROW POWER FOLDING SEAT WILL OPERATE.</b> .....	35
Component Parts Location .....	7	Only One Third Row Power Folding Seat Will Operate .....	35
Component Description .....	7	<b>THIRD ROW POWER FOLDING SEAT WILL OPERATE IN ONLY ONE DIRECTION.</b> .....	37
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	8	Third Row Power Folding Seat Will Operate in Only One Direction .....	37
<b>HEATED SEAT</b> .....	8	<b>THIRD ROW POWER FOLDING SEAT WILL STOP SHORT OF IT'S FULLY UP OR DOWN POSITION.</b> .....	39
Description .....	8	Third Row Power Folding Seat Stops Short of it's Fully Up or Down Position .....	39
<b>THIRD SEAT</b> .....	9	<b>THIRD ROW POWER FOLDING SEAT MAKES EXCESSIVE NOISE WHILE MOVING.</b> .....	40
Power Supply and Ground Circuit Check for Third Row Power Folding Seat Control Unit .....	9	Third Row Power Folding Seat Makes Excessive Noise While Moving .....	40
Third Row Power Folding Seat Switch .....	10	<b>SQUEAK AND RATTLE TROUBLE DIAGNOSES</b> .....	41
Third Row Power Folding Seat Motor .....	10	Work Flow .....	41
<b>ECU DIAGNOSIS INFORMATION</b> .....	12	Generic Squeak and Rattle Troubleshooting .....	43
<b>THIRD ROW POWER FOLDING SEAT CONTROL UNIT</b> .....	12		
Reference Value .....	12		
DTC Index .....	13		
Fail Safe .....	14		
<b>WIRING DIAGRAM</b> .....	15		
<b>POWER SEAT</b> .....	15		
Wiring Diagram - Driver Side Without Automatic Drive Positioner .....	15		
Wiring Diagram - Passenger Side .....	19		
<b>HEATED SEAT</b> .....	23		
Wiring Diagram .....	23		

Diagnostic Worksheet .....	45	<b>THIRD SEAT .....</b>	<b>61</b>
<b>PRECAUTION .....</b>	<b>47</b>	W/O Power Folding .....	61
<b>PRECAUTIONS .....</b>	<b>47</b>	Exploded View .....	61
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	47	LH Side Seat .....	64
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect .....	47	RH Side Seat .....	64
Precaution for Work .....	48	Power Folding .....	66
<b>PREPARATION .....</b>	<b>49</b>	Exploded View .....	66
<b>PREPARATION .....</b>	<b>49</b>	LH Side Seat .....	68
Special Service Tool .....	49	Power Seat Cross Beam .....	68
Commercial Service Tool .....	49	RH Side Seat .....	72
<b>REMOVAL AND INSTALLATION .....</b>	<b>50</b>	<b>UNIT DISASSEMBLY AND ASSEMBLY ...</b>	<b>74</b>
<b>FRONT SEAT .....</b>	<b>50</b>	<b>FRONT SEAT .....</b>	<b>74</b>
Exploded View .....	50	Exploded View .....	74
Removal and Installation For Front Seats .....	53	Disassembly and Assembly .....	78
Removal and Installation For Seat Slide/Recline Switch (Passenger Seat) .....	53	<b>SECOND SEAT .....</b>	<b>81</b>
<b>SECOND SEAT .....</b>	<b>56</b>	Exploded View .....	81
Exploded View .....	56	<b>THIRD SEAT .....</b>	<b>86</b>
Second Row Outboard .....	60	W/O Power Folding .....	86
Second Row Center .....	60	Exploded View .....	86
		LH Side Seat .....	89
		Power Folding .....	90
		Exploded View .....	90
		LH Side Seat .....	92

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006143686

WORK FLOW



DETAILED FLOW

#### 1. CUSTOMER INFORMATION

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2

#### 2. PRELIMINARY CHECK

Perform preliminary check. Refer to [SE-5, "Preliminary Check"](#).

>> GO TO 3

#### 3. SELF-DIAGNOSIS

Perform self-diagnosis. Refer to [SE-13, "DTC Index"](#).

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

>> GO TO 4

## 4.SYMPTOM

---

Check for symptoms. Refer to [SE-33. "Symptom Table"](#).

>> GO TO 5

## 5.MALFUNCTIONING PARTS

---

Repair or replace the applicable parts.

>> GO TO 6

## 6.SYSTEM OPERATION

---

Check system operation.

>> GO TO 7

## 7.SELF-DIAGNOSIS

---

Perform self-diagnosis. Refer to [SE-13. "DTC Index"](#).

Are any DTCs displayed?

YES >> GO TO 5

NO >> Inspection End.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### Preliminary Check

INFOID:000000006143687

### 1. FOREIGN OBJECTS

Check the following:

- objects on or behind the seats that could cause binding
- objects under the seats that may be interfering with the seat's moving parts

Are there any foreign objects that could be causing interference with the seats?

YES >> Remove objects.

NO >> GO TO 2.

### 2. WIRING CONNECTIONS

1. Disconnect third row power folding seat control unit and seat motor harness connectors.
2. Check terminals for damage or loose connections.
3. Reconnect harness connectors.

Are any connectors damaged or loose?

YES >> Repair or replace damaged parts.

NO >> GO TO 3.

### 3. POWER AND GROUND

Check power supply and ground circuits for third row power folding seat control unit. Refer to [SE-9, "Power Supply and Ground Circuit Check for Third Row Power Folding Seat Control Unit"](#).

Is the inspection result normal?

YES >> Refer to [SE-13, "DTC Index"](#).

NO >> Repair or replace as necessary.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# THIRD ROW POWER FOLDING SEAT

< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### THIRD ROW POWER FOLDING SEAT


#### System Description

INFOID:000000006143688

The third row power folding seat system is capable of allowing a user to fold up or down either the left or right third row seat using a set of front or rear mounted switches.


#### THIRD ROW POWER FOLDING SEAT CONTROL UNIT

The third row power folding seat control unit is located in the control unit/cross beam assembly underneath the LH third row seat. It receives signals from the third row power folding seat switches, TCM and the Hall effect switches mounted in the LH and RH seat motors. The control unit has self-diagnosis capability through chime codes and may be accessed by turning the ignition switch ON and OFF three times. The control unit drives the LH and RH seat motors to fold them up and down.




#### THIRD ROW POWER FOLDING SEAT SWITCH

The third row power folding seat switches are located in pairs on the luggage side finisher RH. A switch must be held in order for the seat to move.



#### THIRD ROW POWER FOLDING SEAT MOTORS

The third row power folding seat motors are located in the seat motor/hinge assembly. There are two motors, one for LH and one for RH seat folding operations. Power and ground are provided to the motors by the third row power folding seat control unit. The control unit reverses polarity to the motors to raise or lower the seat. The motors also contain Hall effect switches. These switches send signals back to the control unit which help it determine fully open and closed positions.




# THIRD ROW POWER FOLDING SEAT

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000006143689



1. Third row power folding seat control unit B401, B402
2. A/T assembly F9
3. Third row power folding seat switches
  - A: Third row power folding seat switch driver side (front) B164
  - B: Third row power folding seat switch passenger side (front) B162
  - C: Third row power folding seat switch driver side (rear) B165
  - D: Third row power folding seat switch passenger side (rear) B163
4. Third row power folding seat motors
  - A: RH (40%) seat B426
  - B: LH (60%) seat B403

## Component Description

INFOID:000000006143690

Component	Function
Third row power folding seat control unit	<ul style="list-style-type: none"> <li>• Receive inputs from third row power folding seat switches and A/T assembly (transmission range switch)</li> <li>• Drive third row power folding seat motors</li> <li>• Performs self-diagnostics</li> </ul>
A/T assembly	Provide transmission range switch signal to third row power folding seat control unit
Third row power folding seat switches	Provide fold up/fold down ground signals to third row power folding seat control unit
Third row power folding seat motors	<ul style="list-style-type: none"> <li>• Fold seats up and down</li> <li>• Provide feedback signals to third row power folding seat control unit</li> </ul>

# HEATED SEAT

< DTC/CIRCUIT DIAGNOSIS >


## DTC/CIRCUIT DIAGNOSIS

### HEATED SEAT

#### Description

INFOID:000000006143693

- When handling seat, be extremely careful not to scratch heating unit.
- Front passenger seat cushion and seatbacks equipped with airbags cannot be disassembled. They are replaced as assemblies only.
- Do not use any organic solvent, such as thinner, benzene, alcohol, etc. to clean trim.





# THIRD SEAT

< DTC/CIRCUIT DIAGNOSIS >

## THIRD SEAT

### Power Supply and Ground Circuit Check for Third Row Power Folding Seat Control Unit

INFOID:000000006143695

Regarding Wiring Diagram information, refer to [SE-27, "Wiring Diagram"](#).

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse or Fusible Link	Location
Third row power folding seat control unit	Battery	F	Fuse and fusible link box
		19	Fuse block (J/B)
	Ignition switch ON or START	14	


Are any fuses or fusible links blown?

YES >> Install new fuse. Eliminate cause of malfunction if fuse blows again.

NO >> GO TO 2

#### 2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect third row power folding seat control unit connectors B401 and B402.
2. Check voltage between third row power folding seat control unit harness connectors B401, B402 terminals 1, 8, 13, 14 and ground.



Terminals		Ignition switch position			
(+)		(-)	OFF	ON	START
Connector	Terminal		0V	Battery voltage	Battery voltage
A: B401	1	Ground	Battery voltage		
	8		0V	Battery voltage	
B: B402	13		Battery voltage		
	14		Battery voltage		

Are the inspection results normal?


YES >> GO TO 3

NO >> Check harness for open between third row power folding seat control unit and fuse or fusible link.

#### 3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between third row power folding seat control unit harness connector B402 terminals 16, 18, 21 and ground.

Terminals		Continuity
(+)		
Connector	Terminal	(-)



# THIRD SEAT

## < DTC/CIRCUIT DIAGNOSIS >

B402	16	Ground	Yes
	18		
	21		

### Do all terminals have ground?

- YES >> Inspection End.  
 NO >> Repair or replace harness.

## Third Row Power Folding Seat Switch

INFOID:000000006143696


### 1. CHECK THIRD ROW POWER FOLDING SEAT SWITCH OPERATION

1. Turn ignition switch OFF.
2. Disconnect third row power folding seat switch.
3. Check continuity between third row power folding seat switch terminals 2, 3 and 4.

Terminals		Condition	Continuity
2	4	Press switch button to fold up.	Yes
3	4	Press switch button to fold down.	Yes

### Do you have continuity?

- YES >> Inspection End.  
 NO >> Replace third row power folding seat switch. Refer to [INT-20. "Removal and Installation"](#).



## Third Row Power Folding Seat Motor


INFOID:000000006143697

### 1. CHECK MOTOR OPERATION

1. Turn ignition switch OFF.
2. Disconnect third row power folding seat motor connector B403 or B426.
3. Check operation by applying battery voltage to motor terminals 3 and 4.

#### CAUTION:

- Do not operate motor for more than 3 seconds.
- Be careful not to overheat the harness.
- Third row power folding seat control unit may have to relearn fold up/down positions after testing.



#### LH (60%) seat

Terminal	Motor	Seat
3 (Battery positive) - 4 (Battery negative)	Rotates counter-clockwise	Up
4 (Battery positive) - 3 (Battery negative)	Rotates clockwise	Down

#### RH (40%) seat

Terminal	Motor	Seat
3 (Battery positive) - 4 (Battery negative)	Rotates counter-clockwise	Down
4 (Battery positive) - 3 (Battery negative)	Rotates clockwise	Up

### Does the motor rotate in both directions?

- YES >> GO TO 2.  
 NO >> Replace third row power folding seat motor. Refer to [SE-66. "Exploded View"](#).

### 2. CHECK RESISTANCE IN MOTOR

## THIRD SEAT

### < DTC/CIRCUIT DIAGNOSIS >


Check resistance between motor terminals 3 and 4.

**3 - 4 : Approx. 0.5  $\Omega$**

Is the resistance reading of the motor normal?

YES >> Inspection End.

NO >> Replace third row power folding seat motor. Refer to [SE-66](#). "[Exploded View](#)".



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD ROW POWER FOLDING SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


## ECU DIAGNOSIS INFORMATION

### THIRD ROW POWER FOLDING SEAT CONTROL UNIT

Reference Value

INFOID:000000006143698

#### TERMINAL LAYOUT



#### PHYSICAL VALUES

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx.)
+	-		Signal name	Input/ Output		
1	Ground	Y/R	Battery	Input	—	Battery voltage
3	Ground	LG	40% seat switch signal (down)	Output	Push either third row power folding seat switch RH (down)	0
					Third row power folding seat switch (RH) released	Battery voltage
4	Ground	V	60% seat switch signal (down)	Output	Push either third row power folding seat switch LH (down)	0
					Third row power folding seat switch (LH) released	Battery voltage
7	Ground	G/R	Park signal	Input	A/T selector lever in P or N	Battery voltage
					A/T selector lever not in P or N	0
8	Ground	O/L	Ignition signal	Input	Ignition switch ON or START	Battery voltage
					Ignition switch OFF	0
9	Ground	G/B	40% seat Hall signal	Input	—	9V
10	Ground	O/B	60% seat Hall signal	Input	—	9V
11	Ground	SB	40% seat switch signal (up)	Output	Push either third row power folding seat switch RH (up)	0
					Third row power folding seat switch (RH) released	Battery voltage
12	Ground	O	60% seat switch signal (up)	Output	Push either third row power folding seat switch LH (up)	0
					Third row power folding seat switch (LH) released	Battery voltage
13	Ground	W	Battery	Input	—	Battery voltage
14	Ground	W	Battery	Input	—	Battery voltage
15	Ground	Y/B	Hall switch ground	—	—	—
16	Ground	B	Switch ground	—	—	—
17	Ground	W/L	60% Seat motor	Output	—	Battery voltage
18	Ground	B	Ground	—	—	—
19	Ground	R/W	60% Seat motor	Output	—	Battery voltage

# THIRD ROW POWER FOLDING SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx.)
+	-		Signal name	Input/ Output		
20	Ground	G/W	40% Seat motor	Output	—	Battery voltage
21	Ground	B	Ground	—	—	—
22	Ground	V	40% Seat motor	Output	—	Battery voltage

## DTC Index

INFOID:000000006143700

### NOTE:

To initiate a chime code sequence cycle, turn the ignition switch ON and OFF 3 times within 5 seconds. The first digit will chime, then a pause, followed by the second digit. For example, a code 13 will have 1 chime, followed by a pause, and then 3 chimes. The third row power folding seat control unit will clear all codes that have been corrected after 255 ignition cycles.

DTC	Malfunction	Service Procedure
11	LH seat has traveled past normal fold down position	1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a> .
12	LH seat has traveled past normal fold up position	2. Check third row power folding seat motor LH Hall signal and ground circuits. Refer to <a href="#">SE-39. "Third Row Power Folding Seat Stops Short of it's Fully Up or Down Position"</a> . 3. Replace third row power folding seat motor LH. Refer to <a href="#">SE-66. "Exploded View"</a> .
13	LH seat actuation cycle has taken too long and timed out	1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a> . 2. Check third row power folding seat motor LH motor circuits. Refer to <a href="#">SE-35. "Only One Third Row Power Folding Seat Will Operate"</a> . 3. Replace third row power folding seat motor LH. Refer to <a href="#">SE-66. "Exploded View"</a> .
14	Third row power folding seat control unit NVRAM data for LH seat position has been corrupted	Replace third row power folding seat control unit. Refer to <a href="#">SE-68. "Power Seat Cross Beam"</a> .
15	Power supply to third row power folding seat control unit has been interrupted during LH seat fold up/down cycle	1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a> . 2. Replace third row power folding seat control unit. Refer to <a href="#">SE-68. "Power Seat Cross Beam"</a> .
21	RH seat has traveled past normal fold down position	1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a> .
22	RH seat has traveled past normal fold up position	2. Check third row power folding seat motor RH Hall signal and ground circuits. Refer to <a href="#">SE-39. "Third Row Power Folding Seat Stops Short of it's Fully Up or Down Position"</a> . 3. Replace third row power folding seat motor RH. Refer to <a href="#">SE-66. "Exploded View"</a> .
23	RH seat actuation cycle has taken too long and timed out	1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a> . 2. Check third row power folding seat motor RH motor circuits. Refer to <a href="#">SE-35. "Only One Third Row Power Folding Seat Will Operate"</a> . 3. Replace third row power folding seat motor RH. Refer to <a href="#">SE-66. "Exploded View"</a> .
24	Third row power folding seat control unit NVRAM data for RH seat position has been corrupted	Replace third row power folding seat control unit. Refer to <a href="#">SE-68. "Power Seat Cross Beam"</a> .

# THIRD ROW POWER FOLDING SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

DTC	Malfunction	Service Procedure
25	Power supply to third row power folding seat control unit has been interrupted during RH seat fold up/down cycle	<ol style="list-style-type: none"><li>1. Perform Preliminary Check. Refer to <a href="#">SE-5. "Preliminary Check"</a>.</li><li>2. Replace third row power folding seat control unit. Refer to <a href="#">SE-68. "Power Seat Cross Beam"</a>.</li></ol>
33	System normal or END of chime codes	—

### Fail Safe

INFOID:000000006143701

The third row power folding seat will not operate under the following conditions:

- Power supply to the third row power folding seat control unit falls below 9.0V
- One of the third row power folding seat switches is stuck closed
- The A/T selector lever is not in PARK position and the ignition switch is ON

# POWER SEAT

< WIRING DIAGRAM >

## WIRING DIAGRAM


### POWER SEAT

#### Wiring Diagram - Driver Side Without Automatic Drive Positioner

INFOID:000000006418092

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER

◀ PP ▶ - WITH FRONT PASSENGER POWER SEAT




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

ABJWA0027GB

POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
10G	W/B	-



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
5J	L/B	-



Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

ABJIA0287GB



# POWER SEAT

< WIRING DIAGRAM >


Connector No.	B45
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	B/W	-

Terminal No.	Color of Wire	Signal Name
10G	W/B	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B211
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Terminal No.	Color of Wire	Signal Name
5J	L/B	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABJIA0288GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT

< WIRING DIAGRAM >

Connector No.	B212
Connector Name	SLIDING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	R	-
2	Y	-

Connector No.	B213
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	G	-

Connector No.	B214
Connector Name	LIFTING MOTOR (FRONT) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B/Y	-
2	R/Y	-

Connector No.	B215
Connector Name	LIFTING MOTOR (REAR) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	W/G	-

Connector No.	B216
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	R	-
4	Y	-

Terminal No.	Color of Wire	Signal Name
5	G	-
6	L	-
7	V	-
8	W/G	-
9	B/Y	-
10	R/Y	-

# POWER SEAT


< WIRING DIAGRAM >

## Wiring Diagram - Passenger Side

INFOID:000000006418093

### POWER SEAT FOR PASSENGER SIDE

AD : WITH AUTOMATIC DRIVE POSITIONER  
 XA : WITHOUT AUTOMATIC DRIVE POSITIONER



ABJWA0094GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# POWER SEAT

< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE CONNECTORS


Terminal No.	Color of Wire	Signal Name
10G	W/B	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5M	L/B	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

ABJIA0502GB

# POWER SEAT

< WIRING DIAGRAM >



Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	10G	Color of Wire	W/B	Signal Name	-
--------------	-----	---------------	-----	-------------	---

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	5M	Color of Wire	W/L	Signal Name	-
--------------	----	---------------	-----	-------------	---

Connector No.	B308
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE

Connector No.	B303
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	B154
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-
3	G	-
4	W	-
5	B	-
6	R	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	W/L	-
2	B	-

ABJIA0312GB

A B C D E F G H I SE K L M N O P

# POWER SEAT

< WIRING DIAGRAM >

Connector No.	B372
Connector Name	RECLINING MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	B309
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-

ABJIA0313GB

# HEATED SEAT


< WIRING DIAGRAM >

## HEATED SEAT

Wiring Diagram

INFOID:000000006418091

HEATED SEAT



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


ABJWA0091GB

# HEATED SEAT

< WIRING DIAGRAM >

## HEATED SEAT CONNECTORS

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
76M	GR/B	-
77M	GR/L	-

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5Q	G	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	GR	-
6J	L/B	-

Connector No.	M63
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
4	G	-
5	GR	-
6	L/B	-
12	GR/L	-
13	GR/B	-
16	B	-


ABJIA0111GB



# HEATED SEAT

## < WIRING DIAGRAM >

Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
4	G	-
5	GR	-
6	L/B	-
12	GR/L	-
13	GR/B	-
16	B	-

Connector No.	M252
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G	-
2	GR/L	-
3	GR/B	-
4	B	-

Connector No.	M255
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	GR	-
3	L/B	-
4	B	-

Connector No.	B37
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	-
5	GR	-
6	B	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	GR	-
6J	L/B	-

ABJIA0291GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
76M	GR/B	-
77M	GR/L	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B118
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR/L	LO
2	B	E
3	GR/B	HI

Connector No.	B209
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	LO
2	P	E
3	O	HI

Connector No.	B200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	O	-
5	GR	-
6	P	-

ABJIA0302GB


# THIRD ROW POWER FOLDING SEAT

< WIRING DIAGRAM >

## THIRD ROW POWER FOLDING SEAT

### Wiring Diagram

INFOID:000000006418095



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABJWA0208GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD ROW POWER FOLDING SEAT

< WIRING DIAGRAM >


## POWER FOLD THIRD ROW SEAT CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5P	O/L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	W/B	-
16G	B/R	-

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4Q	Y/R	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
15J	O/L	-
53J	Y/R	-
56J	B/R	-
80J	W/B	-


ABJIA0500GB

# THIRD ROW POWER FOLDING SEAT


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
10G	W/B	-
16G	B/R	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
19	B/R	-

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
8	G	START-RLY

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	B/R	-

Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
9	B/R	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD ROW POWER FOLDING SEAT

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
15J	O/L	-
53J	Y/R	-
56J	GR/R	-
80J	W	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
3	LG	-
4	SB	-
5	V	-

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
3	LG	-
4	SB	-
5	V	-

Terminal No.	Color of Wire	Signal Name
2	Y/R	-
3	O/L	-
4	B	-
5	GR/R	-
6	SB	-
7	O	-
8	LG	-
9	V	-
10	B	-

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-

ABJIA0501GB

# THIRD ROW POWER FOLDING SEAT

< WIRING DIAGRAM >

Connector No.	B164
Connector Name	THIRD ROW POWER FOLDING SEAT SWITCH DRIVER SIDE (FRONT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	O	-
3	V	-
4	BR	-

Connector No.	B163
Connector Name	THIRD ROW POWER FOLDING SEAT SWITCH PASSENGER SIDE (REAR)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	SB	-
3	LG	-
4	BR	-

Connector No.	B162
Connector Name	THIRD ROW POWER FOLDING SEAT SWITCH PASSENGER SIDE (FRONT)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	SB	-
3	LG	-
4	BR	-

Connector No.	B401
Connector Name	THIRD ROW POWER FOLDING SEAT CONTROL UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y/R	BAT LOG
2	-	-
3	LG	40 SW DN
4	V	60 SW DN
5	-	-
6	-	-
7	G/R	PARK
8	O/L	IGN
9	G/B	HALL+
10	O/B	HALL+
11	SB	40 SW UP
12	O	60 SW UP

Connector No.	B400
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	Y/R	-
3	O/L	-
4	B	-
5	G/R	-
6	SB	-
7	O	-
8	LG	-
9	V	-
10	B	-

Connector No.	B165
Connector Name	THIRD ROW POWER FOLDING SEAT SWITCH DRIVER SIDE (REAR)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	O	-
3	V	-
4	BR	-

ABJIA0303GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD ROW POWER FOLDING SEAT

< WIRING DIAGRAM >

Connector No.	B404
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y/B	-
2	G/B	-
3	V	-
4	G/W	-

Connector No.	B403
Connector Name	THIRD ROW POWER FOLDING SEAT MOTOR LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	Y/B	-
3	R/W	-
4	W/L	-

Connector No.	B402
Connector Name	THIRD ROW POWER FOLDING SEAT CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	W	BAT
14	W	BAT
15	Y/B	HALL-
16	B	SW REF
17	W/L	60 DWN
18	B	GND
19	R/W	60 UP
20	G/W	40 UP
21	B	GND
22	V	40 DWN

Connector No.	B426
Connector Name	THIRD ROW POWER FOLDING SEAT MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	G/B	-
2	Y/B	-
3	G/W	-
4	V	-

Connector No.	B425
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y/B	-
2	G/B	-
3	V	-
4	G/W	-

ABJIA0304GB



# THIRD ROW POWER FOLDING SEAT

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### THIRD ROW POWER FOLDING SEAT

#### Symptom Table

INFOID:000000006143702

Symptom	Reference
None of the third row power folding seats will operate with any switch.	Refer to <a href="#">SE-34, "None of the Third Row Power Folding Seats Will Operate With Any Third Row Power Folding Seat Switch"</a> .
Only one third row power folding seat will operate.	Refer to <a href="#">SE-35, "Only One Third Row Power Folding Seat Will Operate"</a> .
Third row power folding seat will operate in only one direction.	Refer to <a href="#">SE-37, "Third Row Power Folding Seat Will Operate in Only One Direction"</a> .
Third row power folding seat will stop short of its fully up or down position.	Refer to <a href="#">SE-39, "Third Row Power Folding Seat Stops Short of it's Fully Up or Down Position"</a> .
Third row power folding seat makes excessive noise while moving.	Refer to <a href="#">SE-40, "Third Row Power Folding Seat Makes Excessive Noise While Moving"</a> .
Seats make squeak or rattle noise.	Refer to <a href="#">SE-41, "Work Flow"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# NONE OF THE THIRD ROW POWER FOLDING SEATS WILL OPERATE WITH ANY SWITCH.

< SYMPTOM DIAGNOSIS >

## NONE OF THE THIRD ROW POWER FOLDING SEATS WILL OPERATE WITH ANY SWITCH.

None of the Third Row Power Folding Seats Will Operate With Any Third Row Power Folding Seat Switch

INFOID:000000006143703

Regarding Wiring Diagram information, refer to [SE-27, "Wiring Diagram"](#).

### 1. PRELIMINARY CHECK

Perform preliminary check. Refer to [SE-5, "Preliminary Check"](#).

Are inspection results normal?

YES >> GO TO 2.

NO >> Perform repairs as necessary.


### 2. THIRD ROW POWER FOLDING SEAT SWITCH GROUND

1. Turn ignition switch OFF.
2. Disconnect any third row power folding seat connector.
3. Check continuity between third row power folding seat switch harness connector terminal 4 and ground.

Is there continuity?

YES >> GO TO 3.


NO >> Repair ground circuit.



### 3. TRANSMISSION RANGE SWITCH SIGNAL

1. Confirm A/T selector lever is in PARK position.
2. Turn ignition switch ON.
3. Check voltage between third row power folding seat control unit harness connector B401 terminal 7 and ground.

Terminals		Ignition switch	
(+)		(-)	ON
Third row power folding seat control unit	Terminal No.		
B401	7	Ground	Battery voltage



Is there battery voltage?

YES >> Replace third row power folding seat control unit. Refer to [SE-68, "Power Seat Cross Beam"](#).

NO >> Repair circuit as necessary.

# ONLY ONE THIRD ROW POWER FOLDING SEAT WILL OPERATE.

< SYMPTOM DIAGNOSIS >

## ONLY ONE THIRD ROW POWER FOLDING SEAT WILL OPERATE.

### Only One Third Row Power Folding Seat Will Operate

INFOID:000000006143704

Regarding Wiring Diagram information, refer to [SE-27. "Wiring Diagram"](#).

#### 1. PRELIMINARY CHECK

Perform preliminary check. Refer to [SE-5. "Preliminary Check"](#).

Are inspection results normal?

YES >> GO TO 2.

NO >> Perform repairs as necessary.

#### 2. THIRD ROW POWER FOLDING SEAT

Determine which seat is malfunctioning.

Is the affected seat the LH (60%) side?


YES >> GO TO 3.

NO >> GO TO 4.

#### 3. THIRD ROW POWER FOLDING SEAT SWITCH DRIVER SIDE


1. Turn ignition switch OFF.
2. Disconnect either the front or rear third row power folding seat switch driver side connector.
3. Check continuity between the third row power folding seat switch driver side harness connector B164 or B165 terminal 4 and ground.

Terminals		Continuity	
(+)			
Third row power folding seat switch driver side	Terminal No.	(-)	
B164 or B165	4	Ground	Yes



4. Check continuity between any third row power folding seat switch driver side harness connector B164 or B165 terminal 2, 3 and third row power folding seat control unit harness connector B401 terminals 4, 12.

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B401	4	B164 or B165	3	Yes
	12		2	



Are inspection results normal?

YES >> GO TO 5.

NO >> Repair circuits as necessary.

#### 4. THIRD ROW POWER FOLDING SEAT SWITCH PASSENGER SIDE


1. Turn ignition switch OFF.
2. Disconnect either the front or rear third row power folding seat switch passenger side connector.

# ONLY ONE THIRD ROW POWER FOLDING SEAT WILL OPERATE.

## < SYMPTOM DIAGNOSIS >


3. Check continuity between the third row power folding seat switch passenger side harness connector B162 or B163 terminal 4 and ground.

Terminals			Continuity
(+)		(-)	
Third row power folding seat switch driver side	Terminal No.		
B162 or B163	4	Ground	Yes



4. Check continuity between any third row power folding seat switch passenger side harness connector B162 or B163 terminals 2, 3 and third row power folding seat control unit harness connector B401 terminals 3, 11.

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B401	3	B162 or B163	3	Yes
	11		2	



### Is there continuity?

- YES >> GO TO 5.  
NO >> Repair circuits as necessary.

## 5. THIRD ROW POWER FOLDING SEAT MOTOR

Check operation of affected third row power folding seat motor. Refer to [SE-10, "Third Row Power Folding Seat Motor"](#).


### Are inspection results normal?

- YES >> GO TO 6.  
NO >> Replace third row power folding seat motor. Refer to [SE-66, "Exploded View"](#).

## 6. CHECK CIRCUITS BETWEEN MOTOR AND CONTROL UNIT

Check continuity between third row power folding seat motor harness connector B403 or B426 terminals 3, 4 and third row power folding seat control unit terminals 17, 19 (LH) or 20, 22 (RH).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B402	17 (LH), 22 (RH)	B403 (LH) or B426 (RH)	4	Yes
	19 (LH), 20 (RH)		3	



### Are inspection results normal?

- YES >> Replace third row power folding seat control unit. Refer to [SE-68, "Power Seat Cross Beam"](#).  
NO >> Repair circuits as necessary.

# THIRD ROW POWER FOLDING SEAT WILL OPERATE IN ONLY ONE DIRECTION.

< SYMPTOM DIAGNOSIS >

## THIRD ROW POWER FOLDING SEAT WILL OPERATE IN ONLY ONE DIRECTION.

### Third Row Power Folding Seat Will Operate in Only One Direction

INFOID:000000006143705

Regarding Wiring Diagram information, refer to [SE-27. "Wiring Diagram"](#).

#### 1. PRELIMINARY CHECK

Perform preliminary check. Refer to [SE-5. "Preliminary Check"](#).

Are inspection results normal?

YES >> GO TO 2.

NO >> Perform repairs as necessary.

#### 2. THIRD ROW POWER FOLDING SEAT

Determine which seat is malfunctioning.


Is the affected seat the LH (60%) side?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3. THIRD ROW POWER FOLDING SEAT SWITCH DRIVER SIDE

1. Turn ignition switch OFF.
2. Disconnect any third row power folding seat switch driver side connector.
3. Check continuity between third row power folding seat switch driver side harness connector B164 or B165 terminal 2, 3 and third row power folding seat control unit harness connector B401 terminals 4, 12.



Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B401	4	B164 or B165	3	Yes
	12		2	


Is there continuity?

YES >> Replace third row power folding seat control unit. Refer to [SE-68. "Power Seat Cross Beam"](#).

NO >> Repair circuits as necessary.

#### 4. THIRD ROW POWER FOLDING SEAT SWITCH PASSENGER SIDE

1. Turn ignition switch OFF.
2. Disconnect either the front or rear third row power folding seat switch passenger side connector.
3. Check continuity between third row power folding seat switch passenger side harness connector B162 or B163 terminals 2, 3 and third row power folding seat control unit harness connector B401 terminals 3, 11.



Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B401	3	B162 or B163	3	Yes
	11		2	

## THIRD ROW POWER FOLDING SEAT WILL OPERATE IN ONLY ONE DIRECTION.

< SYMPTOM DIAGNOSIS >

---

Is there continuity?

- YES >> Replace third row power folding seat control unit. Refer to [SE-68, "Power Seat Cross Beam"](#).
- NO >> Repair circuits as necessary.

# THIRD ROW POWER FOLDING SEAT WILL STOP SHORT OF IT'S FULLY UP OR DOWN POSITION.

< SYMPTOM DIAGNOSIS >

## THIRD ROW POWER FOLDING SEAT WILL STOP SHORT OF IT'S FULLY UP OR DOWN POSITION.

Third Row Power Folding Seat Stops Short of it's Fully Up or Down Position

INFOID:000000006143706

Regarding Wiring Diagram information, refer to [SE-27. "Wiring Diagram"](#).

### 1. PRELIMINARY CHECK

Perform preliminary check. Refer to [SE-5. "Preliminary Check"](#).

Are inspection results normal?

- YES >> GO TO 2.
- NO >> Perform repairs as necessary.

### 2. CHECK HISTORY


Check to see if a previous normal seat folding operation was interrupted due to low voltage condition.

Was voltage interrupted?

- YES >> Perform learn procedure by operating affected seat until seat reaches full open/closed position.
- NO >> GO TO 3.

### 3. THIRD ROW POWER FOLDING SEAT MOTOR

1. Turn ignition switch OFF.
2. Disconnect third row power folding seat motor harness connector and third row power folding seat control unit harness connector.
3. Check continuity between third row power folding seat motor harness connector B403 (LH) or B426 (RH) terminals 1, 2 and third row power folding seat control unit harness connector terminals 10, 15 (LH) or 9, 15 (RH).



Terminals				Continuity
Connector	Terminal	Connector	Terminal	
A: B401	9 (RH)	C: B426 (RH)	1	Yes
	10 (LH)	C: B403 (LH)		
B: B402	15 (LH/RH)	C: B426 (RH)	2	
		C: B403 (LH)		

Is there continuity?

- YES >> Replace affected third row power folding seat motor. Refer to [SE-66. "Exploded View"](#).
- NO >> Repair circuits as necessary.

# THIRD ROW POWER FOLDING SEAT MAKES EXCESSIVE NOISE WHILE MOVING.

< SYMPTOM DIAGNOSIS >

---

## THIRD ROW POWER FOLDING SEAT MAKES EXCESSIVE NOISE WHILE MOVING.

Third Row Power Folding Seat Makes Excessive Noise While Moving

INFOID:000000006143707

### 1. PRELIMINARY CHECK

---

Perform preliminary check. Refer to [SE-5, "Preliminary Check"](#).

Are inspection results normal?

- YES >> Inspect shaft assembly for binding. If OK, replace affected third row power folding seat motor.  
Refer to [SE-66, "Exploded View"](#).
- NO >> Perform repairs as necessary.




# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000006143708



SBT842

### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-45, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
  - tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - placing a piece of paper between components that you suspect are causing the noise.
  - looking for loose components and contact marks.  
Refer to [SE-43, "Generic Squeak and Rattle Troubleshooting"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - separate components by repositioning or loosening and retightening the component, if possible.
  - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

### **CAUTION:**

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

**Always check with the Parts Department for the latest parts information.**

**The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.**

**URETHANE PADS [1.5 mm (0.059 in) thick]**

**Insulates connectors, harness, etc.**

**76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)**

**INSULATOR (Foam blocks)**

**Insulates components from contact. Can be used to fill space behind a panel.**

**73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)**

**INSULATOR (Light foam block)**

**80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)**

**FELT CLOTH TAPE**

**Used to insulate where movement does not occur. Ideal for instrument panel applications.**

**68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.**

**UHMW (TEFLON) TAPE**

**Insulates where slight movement is present. Ideal for instrument panel applications.**

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

### SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

### SILICONE SPRAY

Use when grease cannot be applied.

### DUCT TAPE

Use to eliminate movement.

### CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Generic Squeak and Rattle Troubleshooting

INFOID:000000006143709

Refer to Table of Contents for specific component removal and installation information.

### INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

#### CAUTION:

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

### CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

### DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

### TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lense loose.
3. Loose screws at console attachment points.

### SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000006143710




Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

\_\_\_\_\_

\_\_\_\_\_

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> Anytime                      | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> When it is raining or wet     |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions       |
| <input type="checkbox"/> Only when it is hot outside  | <input type="checkbox"/> Other:                        |

### III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about \_\_\_\_ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: \_\_\_\_\_
- After driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

LAIA0071E

VIN: \_\_\_\_\_ Customer Name \_\_\_\_\_

W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006143711

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000006143712

#### **NOTE:**

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# PRECAUTIONS

## < PRECAUTION >

---

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

### Precaution for Work

INFOID:000000006669441

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
  - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.  
Then rub with a soft and dry cloth.
  - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.



# PREPARATION

< PREPARATION >




## PREPARATION

### PREPARATION

#### Special Service Tool


INFOID:000000006143714

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear   SIIA0993E	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit   SIIA0994E	Repairing the cause of noise
— (J-46534) Trim Tool Set   AWJIA0483ZZ	Removing trim components

#### Commercial Service Tool

INFOID:000000006143715

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear   SIIA0995E	Locating the noise

# FRONT SEAT

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION


### FRONT SEAT

Exploded View

INFOID:000000006143716

#### Driver Seat

SEC. 870



: N-m (kg-m, ft-lb)

LIIA1578E

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

---

- |                                |   |                                 |   |
|--------------------------------|---|---------------------------------|---|
| 1. Headrest                    | 2. Headrest holder with multi-position lock | 3. Seatback assembly            | A |
| 4. Lumbar switch bezel         | 5. Power seat switch escutcheon             | 6. Recliner switch knob         |   |
| 7. Slide switch knob           | 8. Driver power seat frame assembly         | 9. LH outer leg cover           | B |
| 10. Driver seat wiring harness | 11. Bolt cover                              | 12. Seat cushion outer finisher |   |
| 13. Outer pedestal finisher    | 14. Seat cushion front finisher             | 15. Seat cushion inner finisher |   |
| 16. Seat cushion frame         | 17. Seat cushion heating element            | 18. Seat cushion pad            | C |
| 19. Seat cushion trim cover    | 20. Armrest assembly                        | 21. Headrest holder             |   |
| 22. Seat slide/ recline switch | 23. Power lumbar switch                     |                                 |   |

D

E

F

G

H

I

**SE**

K

L

M

N

O


P

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

### Passenger Seat

SEC. 870



WIA0476E

- |                                       |   |  |
|---------------------------------------|---|--|
| 1. Headrest                           | 2. Headrest holder with multi-position lock | 3. Seatback board                      |
| 4. Armrest assembly                   | 5. Lumbar switch bezel                      | 6. Fold flat link bar                  |
| 7. Outboard reclining arm outer cover | 8. Outboard reclining arm inner cover       | 9. Inboard reclining arm inner cover   |
| 10. Latch cover                       | 11. LH outer leg cover                      | 12. Outboard reclining arm inner cover |
| 13. Seat cushion inner cover          | 14. Passenger seat wiring harness           | 15. Inner front leg cover              |
| 16. Power seat frame assembly         | 17. NVH assembly                            | 18. Seat cushion front finisher        |

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |                                  |                                 |                                |
|----------------------------------|---------------------------------|--------------------------------|
| 19. Outer pedestal finisher      | 20. Seat cushion outer finisher | 21. Seat cushion assembly      |
| 22. Power seat switch escutcheon | 23. Slide switch knob           | 24. Recliner switch knob       |
| 25. Seatback assembly            | 26. Headrest holder             | 27. Seat slide/ recline switch |
| 28. Power lumbar switch          |                                 |                                |

## Removal and Installation For Front Seats

INFOID:000000006143717

### REMOVAL

#### CAUTION:

- When removing or installing the seat trim, handle it carefully to keep dirt out and avoid damage.
- Before removing the front seat, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After front side air bag module inflates, front seatback assembly must be replaced.
- Front passenger seat is equipped with an Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove the trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.

1. Position the seat until the four body mounting bolts are accessible. Remove the bolt covers and the bolts.

#### NOTE:

- If disassembling the seat after removal, set the front/rear cushion lifters to the top position.
2. Disconnect both battery cables and wait at least 3 minutes.
  3. Disconnect the side air bag module harness connector.
  4. Remove the four body mounting bolts.
  5. Disconnect the power seat harness connectors and remove the seat from the vehicle.

#### CAUTION:

When removing and installing the seat, use shop cloths to protect the vehicle from damage.

### INSTALLATION


Installation is in the reverse order of removal.

## Removal and Installation For Seat Slide/Recline Switch (Passenger Seat)

INFOID:000000006765678

### REMOVAL


1. Remove the passenger seat. Refer to [SE-53, "Removal and Installation For Front Seats"](#).
2. Place the seat, back side down, on a work bench
3. Unhook the under seat flap.




## FRONT SEAT

### < REMOVAL AND INSTALLATION >


4. Remove the two seat switch knobs (1) and seat switch bezel (2).



5. Remove the four bolts securing the seat pan to the seat frame.




6. Disconnect the OCS electrical connector (1) and seat switch electrical connector (2).




## FRONT SEAT

### < REMOVAL AND INSTALLATION >

7. Detach the two seat switch harness clips (1) from the seat pan.



8. Remove outboard J-clip.
9. Reposition the seat cover side panel to access the seat switch. Remove the two screws (A) and seat switch (1).



### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SECOND SEAT


< REMOVAL AND INSTALLATION >

## SECOND SEAT

Exploded View

INFOID:00000006143718

Second Row RH



W1IA049E

- |                    |                             |                                 |
|--------------------|-----------------------------|---------------------------------|
| 1. Headrest        | 2. Seatback pad             | 3. Seatback frame               |
| 4. Rear seat bezel | 5. RH Headrest guide (free) | 6. LH Headrest guide (locked)   |
| 7. Seat back panel | 8. Seat actuator assembly   | 9. Reclining device inner cover |



## SECOND SEAT

### < REMOVAL AND INSTALLATION >

---

10. Reclining device inner mid cover	11. Armrest assembly	12. Armrest bolt cover	
13. Armrest trim cover	14. Latch assembly	15. Seat cushion mat springs	A
16. Seat cushion mat	17. Seat cushion frame assembly	18. Seat support trim cover	
19. Seat support pad assembly	20. Lower rear seat cover	21. Lower rear seat cover inner	B
22. Outboard cushion floor latch	23. Seat cushion support frame assembly	24. Lower rear seat cover outer	B
25. Seat cushion pad	26. Inner inboard reclining device cover	27. Outer inboard reclining device cover	C
28. Seat latch and recliner release	29. Reclining device outer mid cover	30. Reclining device lever	C
31. Reclining device outer cover	32. Seatback trim cover	33. Seat cushion trim cover	

D

E

F

G

H

I

**SE**

K

L

M

N


O


P

# SECOND SEAT

## < REMOVAL AND INSTALLATION >

### Second row LH



 N·m (kg-m, ft-lb)

WIA0411E

- |  |                                      |  |
|--|--------------------------------------|--|
| 1. Seatback panel                        | 2. RH headrest guide (free)          | 3. LH headrest guide (locked)            |
| 4. Rear seat bezel                       | 5. Seatback pad                      | 6. Seatback trim cover                   |
| 7. Headrest                              | 8. Seat latch and recliner release   | 9. Reclining device outer cover          |
| 10. Reclining device lever               | 11. Reclining device outer mid cover | 12. Outer inboard reclining device cover |
| 13. Inner inboard reclining device cover | 14. Seat cushion trim cover          | 15. Seat cushion pad                     |
| 16. Seat cushion frame assembly          | 17. Lower rear seat cover outer      | 18. Outboard cushion floor latch         |


# SECOND SEAT

## < REMOVAL AND INSTALLATION >

- |   |                                 |                                  |
|---|---------------------------------|----------------------------------|
| 19. Seat cushion support frame assembly | 20. Inboard cushion floor latch | 21. Lower rear seat cover inner  |
| 22. Lower rear seat cover               | 23. Seat support pad assembly   | 24. Seat support trim cover      |
| 25. Seat cushion mat                    | 26. Seat cushion mat springs    | 27. Latch assembly               |
| 28. Armrest assembly                    | 29. Armrest trim cover          | 30. Reclining device outer cover |
| 31. Reclining device inner mid cover    | 32. Seatback frame              | 33. Seat actuator assembly       |

### Second row center

SEC. 861



A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

BIIA0020E

# SECOND SEAT

## < REMOVAL AND INSTALLATION >


- |                                 |                                      |                             |
|---------------------------------|--------------------------------------|-----------------------------|
| 1. Seatback pad                 | 2. Armrest finisher                  | 3. Headrest                 |
| 4. Seat belt retractor cover    | 5. Seat belt bezel                   | 6. RH headrest guide (free) |
| 7. LH headrest guide (locking)  | 8. Seatback board                    | 9. Seat bracket cover       |
| 10. Armrest pivot bracket cover | 11. Seatback frame                   | 12. Seat cushion frame      |
| 13. Latch assembly              | 14. Lower rear pivot bracket support | 15. Outer hinge cover       |
| 16. Center seat base assembly   | 17. Link and pivot bracket apron     | 18. Seat cushion pad        |
| 19. Seat cushion trim cover     | 20. Cushion stop bumper              | 21. Inner lever cover       |
| 22. Seat hinge assembly         | 23. Seat lever assembly              | 24. Outer lever cover       |
| 25. Seat lock cover             | 26. Armrest cover                    | 27. Armrest bracket         |
| 28. Armrest pad                 | 29. Cup holder                       | 30. Seatback trim cover     |
| 31. Seat belt assembly          |                                      |                             |

### Second Row Outboard

INFOID:000000006143719

#### REMOVAL

1. Remove seat base trim cover.
2. Lift handle and tilt seat forward.
3. Remove seat anchor nuts, bolts and seat assembly.



#### INSTALLATION


Installation is in the reverse order of removal.

### Second Row Center

INFOID:000000006143720

#### REMOVAL

1. Tilt the seat cushion forward.
2. Remove the seat anchor bolts.
3. Tilt the seat cushion back and remove the seat.



#### INSTALLATION

Installation is in the reverse order of removal.

# THIRD SEAT

< REMOVAL AND INSTALLATION >

## THIRD SEAT

W/O Power Folding


Exploded View

INFOID:000000006143721

INFOID:000000006143722

Third seat LH

SEC. 882



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## THIRD SEAT

### < REMOVAL AND INSTALLATION >

---


- |                             |                             |                              |
|-----------------------------|-----------------------------|------------------------------|
| 1. LH third seat assembly   | 2. Seatback assembly        | 3. Seatback trim cover       |
| 4. Seat cushion assembly    | 5. Seat cushion pad         | 6. Seat cushion trim cover   |
| 7. Flex mat springs         | 8. Flex mat                 | 9. Front link covers         |
| 10. RH hinge cover          | 11. Seat cushion frame      | 12. LH hinge cover           |
| 13. Seatback frame assembly | 14. Seatback cable assembly | 15. Release handle bezel     |
| 16. Seatback board          | 17. Seatback pad            | 18. Headrest holder, locking |
| 19. Headrest holder, free   | 20. Headrest                |                              |

# THIRD SEAT

## < REMOVAL AND INSTALLATION >

### Third seat RH

SEC. 882



- |                             |                             |                              |
|-----------------------------|-----------------------------|------------------------------|
| 1. RH third seat assembly   | 2. Seatback assembly        | 3. Seatback pad              |
| 4. Seatback trim cover      | 5. Seat cushion assembly    | 6. Seat cushion trim cover   |
| 7. Seat cushion pad         | 8. Flex mat springs         | 9. Flex mat                  |
| 10. Front link covers       | 11. Seat cushion frame      | 12. RH hinge cover           |
| 13. LH hinge cover          | 14. Seatback frame assembly | 15. Seatback board           |
| 16. Seatback cable assembly | 17. Release handle bezel    | 18. Headrest holder, locking |
| 19. Headrest holder, free   | 20. Headrest                |                              |

LIIA2323E

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD SEAT

## < REMOVAL AND INSTALLATION >

### LH Side Seat


INFOID:000000006143723

#### REMOVAL

1. Remove the storage bin. Refer to [INT-20](#).
2. Remove the lower base trim covers.
3. Remove front link nuts and the LH hinge front bolt.


**Front link nuts** : 45 N·m (4.6 Kg-m, 33 ft-lb)

**LH hinge front bolt** : 45 N·m (4.6 Kg-m, 33 ft-lb)



4. Remove the seat cushion side facing push pin and release elastic band from seat belt buckle.
5. Partially lift seatback upright, then remove seat belt buckle (2) from between hinge cover (1) and seat cushion side facing (3).

  - ⇐ : Vehicle front



6. Retract the seat into the cargo floor position.
7. Remove the seat hinge rear bolt (A) and seat belt buckle bolt (B) from the seat assembly.


**Seat hinge rear bolt** : 45 N·m (4.6 Kg-m, 33 ft-lb)

**Seat belt buckle bolt** : [SB-8, "Removal and Installation of Third Row Seat Belt"](#)

#### **CAUTION:**

**Discard the seat belt buckle bolt and use a new bolt for installation.**

8. Remove the seat assembly.



#### INSTALLATION

Installation is in the reverse order of removal.

### RH Side Seat

INFOID:000000006143724

#### REMOVAL

1. Remove the storage bin. Refer to [INT-20](#).
2. Remove the lower base trim covers.




# THIRD SEAT

## < REMOVAL AND INSTALLATION >

3. Remove front link nuts (A) and RH hinge front bolt (B).

**Front link nuts : 45 N·m (4.6 Kg-m, 33 ft-lb)**

**RH hinge front bolt : 45 N·m (4.6 Kg-m, 33 ft-lb)**




4. Remove the seat cushion side facing push pin and release elastic band from seat belt buckle..

5. Partially lift seatback upright, then remove seat belt buckle (2) from between hinge cover (1) and seat cushion side facing (3).

• ← : Vehicle front


6. Retract the seat into the cargo floor position.



7. Remove the rear bolts from the seat assembly.

**Seat hinge rear bolt : 45 N·m (4.6 Kg-m, 33 ft-lb)**

8. Remove the seat assembly.



## INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# THIRD SEAT

< REMOVAL AND INSTALLATION >

Power Folding


INFOID:000000006143725

Exploded View

INFOID:000000006143726

Third seat RH

SEC. 882



ALIA0070GB

- |                     |                             |                            |
|---------------------|-----------------------------|----------------------------|
| 1. Headrest         | 2. Headrest holder, locking | 3. Headrest holder, free   |
| 4. Seatback board   | 5. Seatback pad             | 6. Seatback frame assembly |
| 7. Seatback cushion | 8. Seatback trim cover      | 9. RH hinge cover          |


# THIRD SEAT

## < REMOVAL AND INSTALLATION >

- |                                 |                     |                             |
|---------------------------------|---------------------|-----------------------------|
| 10. Seat motor/hinge assembly   | 11. Seat cushion    | 12. Seat cushion trim cover |
| 13. Front link covers           | 14. Flex mat        | 15. Flex mat springs        |
| 16. Seat cushion frame assembly | 17. Side link cover | 18. LH hinge cover          |

### Third seat LH

SEC. 882



- |                     |                             |                            |
|---------------------|-----------------------------|----------------------------|
| 1. Headrest         | 2. Headrest holder, locking | 3. Headrest holder, free   |
| 4. Seatback board   | 5. Seatback pad             | 6. Seatback frame assembly |
| 7. Seatback cushion | 8. Seatback trim cover      | 9. Seat cushion            |

ALIIA0071GB

# THIRD SEAT

## < REMOVAL AND INSTALLATION >


- |  |                                 |                               |
|--|---------------------------------|-------------------------------|
| 10. Seat cushion trim cover            | 11. Front link covers           | 12. Flex mat                  |
| 13. Flex mat springs                   | 14. Seat cushion frame assembly | 15. Seat motor/hinge assembly |
| 16. Control module/cross beam assembly | 17. LH hinge cover              | 18. Side link cover           |
| 19. RH hinge cover                     |                                 |                               |

### LH Side Seat


INFOID:000000006143727

#### REMOVAL

1. Remove the storage bin. Refer to [INT-20](#).
2. Remove the lower base trim covers.
3. Remove front link nuts and the LH hinge front bolt.



4. Remove seat cushion side facing push pin and release elastic band from seat belt buckle.
5. Partially lift seatback upright, then remove seat belt buckle (2) from between hinge cover (1) and seat cushion side facing (3).
  - ⇐ : Vehicle front




6. Retract the seat into the cargo floor position.
7. Remove the seat hinge rear bolt (A) and seat belt buckle bolt (B) from the seat assembly.

**Seat belt buckle bolt** : Refer to [SB-8, "Removal and Installation of Third Row Seat Belt"](#)

#### **CAUTION:**

**Discard the seat belt buckle bolt and use a new bolt for installation.**

8. Disconnect the seat harness.
9. Remove the seat assembly.



#### INSTALLATION

Installation is in the reverse order of removal.

### Power Seat Cross Beam


INFOID:000000006143728

#### REMOVAL


# THIRD SEAT

## < REMOVAL AND INSTALLATION >


1. Remove the lower seat mount bolts.
2. Fold the seat cushion up.




3. Remove the harness connectors from the seat control unit.



4. Press the front release tab and remove the seat control unit.



5. Remove the screws (2) from the power seat motor cover assembly.




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


## THIRD SEAT

### < REMOVAL AND INSTALLATION >


6. Disconnect the wiring harness from the power seat motor cover clips (A).
7. Remove the power seat motor cover.



8. Release the power motor cross-beam clip and open the hinged strap.



9. Remove the power motor cross-beam screws.




10. Remove the power motor cross-beam.

**NOTE:**

The cable and conduit will be removed with the cross-beam.

11. Remove the cable and conduit from the cross-beam retainers.




### Installation


# THIRD SEAT

## < REMOVAL AND INSTALLATION >


1. Install the cable into the drive motor and slide the conduit on the motor ferrule.
  - ⇐ : Vehicle front




2. Install the cable (A) into the RH seat motor.
  - ⇐ : Vehicle front




3. Install the power motor cross-beam right side screws



4. Starting at the right side, snap the cable and conduit into the power seat cross-beam retainers.



5. Snap the hinged strap retainer around the motor assembly.




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


## THIRD SEAT

### < REMOVAL AND INSTALLATION >


6. Replace the power seat motor cover.




7. Install the seat harness to the power seat motor cover clips (A).



8. Install the seat control unit and connect the seat control unit harness connectors.



9. Install the lower seat mount bolts.



INFOID:000000006143729

## RH Side Seat

### REMOVAL


1. Remove the storage bin. Refer to [INT-20](#).
2. Remove the lower base trim covers.




# THIRD SEAT

## < REMOVAL AND INSTALLATION >


3. Remove front link nuts (A) and RH hinge front bolt (B).



4. Remove the seat cushion side facing push pin and release elastic band from seat belt buckle.
5. Partially lift seatback upright, then remove seat belt buckle (2) from between hinge cover (1) and seat cushion side facing (3).
  - ← : Vehicle front
6. Retract the seat into the cargo floor position.



7. Remove the rear bolts from the seat assembly.
8. Disconnect the seat harness.
9. Remove the seat assembly.



## INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

## UNIT DISASSEMBLY AND ASSEMBLY


### FRONT SEAT

Exploded View

INFOID:000000006143730

#### Driver Seat

SEC. 870



⊗ : N-m (kg-m, ft-lb)

ALJIA0566GB

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

---

1. Headrest	2. Headrest holder with multi-position lock	3. Seatback board	A
4. Seatback assembly	5. Pin	6. Front seatback knob	
7. Lumbar switch bezel	8. Power seat switch escutcheon	9. Recliner switch knob	B
10. Slide switch knob	11. Driver power seat frame assembly	12. Front seat slide motor	
13. Front seat motor	14. LH recliner cover	15. Recliner rod	
16. RH recliner cover	17. Power seat control assembly	18. LH outer leg cover	C
19. Driver seat wiring harness	20. Bolt cover	21. Seat cushion outer finisher	
22. Outer pedestal finisher	23. Seat cushion front finisher	24. Seat cushion inner finisher	
25. Seat cushion frame	26. Seat cushion heating element	27. Seat cushion pad	D
28. Seat cushion trim cover	29. Armrest assembly	30. Seat slide/ recline switch	
31. Power lumbar switch			E

E

F

G

H

I

**SE**

K

L

M

N

O


P


# FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

## Passenger Seat Manual

SEC. 870



 : N·m (kg·m, ft·lb)

ALJIA0567GB

- |                                       |                                       |   |
|---------------------------------------|---------------------------------------|---|
| 1. Headrest                           | 2. Front seat back lever              | 3. Headrest holder/Headrest holder with multi-position lock |
| 4. Seatback board                     | 5. Seatback assembly                  | 6. Armrest assembly   |
| 7. Outboard reclining arm outer cover | 8. Outboard reclining arm inner cover | 9. Inboard reclining arm inner cover                        |
| 10. Latch cover                       | 11. LH outer leg cover                | 12. Outboard reclining arm inner cover                      |
| 13. Seat cushion inner cover          | 14. Power seat frame assembly         | 15. NVH assembly  |



# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |                              |                             |     |
|------------------------------|-----------------------------|-----|
| 16. Front seat rear finisher | 17. Outer pedestal finisher | 18. |
| 19. Recliner knob            | 20. Seat cushion assembly   |     |

### Passenger Seat Power

SEC. 870



: 49 (5.0, 36)

: N·m (kg·m, ft·lb)

ALJIA0568GB

- |                                       |                                       |   |
|---------------------------------------|---------------------------------------|---|
| 1. Headrest                           | 2. Front seat back lever              | 3. Headrest holder/Headrest holder with multi-position lock |
| 4. Seatback board                     | 5. Seatback assembly                  | 6. Armrest assembly   |
| 7. Outboard reclining arm outer cover | 8. Outboard reclining arm inner cover | 9. Inboard reclining arm inner cover                        |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |                              |                                    |  |
|------------------------------|------------------------------------|--|
| 10. Latch cover              | 11. LH outer leg cover             | 12. Outboard reclining arm inner cover |
| 13. Seat cushion inner cover | 14. Front seat harness             | 15. Front seat adjuster assembly       |
| 16. Front seat rear finisher | 17. Outer pedestal finisher        | 18. Seat cushioner outer finisher      |
| 19. Seat cushion assembly    | 20. Front seat slide knob & switch | 21. Front seat reclining knob & switch |
| 22. Front seat switch cover  | 23. Front seat switch              |  |

## Disassembly and Assembly

INFOID:000000006143731

### SEATBACK TRIM AND PAD

#### Disassembly


#### **CAUTION:**

- Only complete seatback assemblies can be replaced on vehicles equipped with side air bags.
- When removing or installing the seat trim, handle it carefully to keep dirt out and avoid damage.


1. Remove the seatback assembly. Refer to [SE-50. "Exploded View"](#).
2. Remove the headrest.
3. From inside of the seatback, squeeze the headrest holder tabs at the base of the stay pipe and pull the up to remove.

#### **NOTE:**

Before installing the headrest holder, check its orientation (front/rear and right/left).



4. Remove the snap ring and the lumbar support lever knob (if equipped).



5. Remove the seatback trim and pad assembly.
6. Remove the hog rings to separate the seatback trim from the pad.

#### Assembly

Assembly is in the reverse order of disassembly.

### SEAT CUSHION TRIM AND PAD

#### Disassembly


#### **CAUTION:**

- Front passenger seat is equipped with an Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove the trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.
- When removed, the passenger seat cushion must always be placed pan side UP to prevent damage.
- During installation, the wire harness clips must be reinstalled in the holes they were originally in. Do not add additional clips.

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- **The Occupant Classification System control module can only be replaced as part of the seat cushion assembly.**
1. Remove the recline release lever.
  2. Remove four bolts and the seat cushion assembly.
    - On the fold flat passenger seat it is necessary to unclip the rear flap j-clip from the seat pan.



3. On the drivers seat only, remove the seat cushion trim and pad.
4. On the drivers seat only, remove the hog rings to separate the trim cover from the pad.


### Assembly

Assembly is in the reverse order of disassembly.


## PASSENGER SEATBACK BOARD - SOFT SEATBACK

### Removal

1. The seatback board is attached to the seat frame with the following:
  - 2 top tabs (A)
  - 4 side tabs (B)
  - 2 bottom clips (C) (must be replaced)
2. Move seat to forward position.




3. Hold the seatback board as shown and pull the top of the seatback board away from the seat back frame.



## FRONT SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >

4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Pull the lower part of the seatback board to disengage the bottom clips from the seatback frame.




#### Installation

Installation is in the reverse order of removal.


### PASSENGER SEATBACK BOARD - HARD SEATBACK

#### Removal


1. The seatback board is attached to the seat frame with the following:
  - 2 top tabs (A)
  - 2 side tabs (B)
  - 2 bottom clips (C) (must be replaced)
2. Move seat to forward position.



3. Hold the seatback board as shown and pull the bottom of the seatback board away from the seat back frame.



4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Lift the upper part of the seatback board to disengage the top tabs from the seatback frame.



#### Installation

Installation is in the reverse order of removal.



# SECOND SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

## SECOND SEAT

Exploded View

INFOID:000000006143732

Second Row RH



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

- |                    |                             |                                 |
|--------------------|-----------------------------|---------------------------------|
| 1. Headrest        | 2. Seatback pad             | 3. Seatback frame               |
| 4. Rear seat bezel | 5. RH Headrest guide (free) | 6. LH Headrest guide (locked)   |
| 7. Seat back panel | 8. Seat actuator assembly   | 9. Reclining device inner cover |

N-m (kg-m, ft-lb)

WIA0409E

## SECOND SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >


---


- |                                      |  |  |
|--------------------------------------|--|--|
| 10. Reclining device inner mid cover | 11. Armrest assembly                     | 12. Armrest bolt cover                   |
| 13. Armrest trim cover               | 14. Latch assembly                       | 15. Seat cushion mat springs             |
| 16. Seat cushion mat                 | 17. Seat cushion frame assembly          | 18. Seat support trim cover              |
| 19. Seat support pad assembly        | 20. Lower rear seat cover                | 21. Lower rear seat cover inner          |
| 22. Outboard cushion floor latch     | 23. Seat cushion support frame assembly  | 24. Lower rear seat cover outer          |
| 25. Seat cushion pad                 | 26. Inner inboard reclining device cover | 27. Outer inboard reclining device cover |
| 28. Seat latch and recliner release  | 29. Reclining device outer mid cover     | 30. Reclining device lever               |
| 31. Reclining device outer cover     | 32. Seatback trim cover                  | 33. Seat cushion trim cover              |

# SECOND SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Second row LH



 N-m (kg-m, ft-lb)

WIA0411E

- |  |                                      |  |
|--|--------------------------------------|--|
| 1. Seatback panel                        | 2. RH headrest guide (free)          | 3. LH headrest guide (locked)            |
| 4. Rear seat bezel                       | 5. Seatback pad                      | 6. Seatback trim cover                   |
| 7. Headrest                              | 8. Seat latch and recliner release   | 9. Reclining device outer cover          |
| 10. Reclining device lever               | 11. Reclining device outer mid cover | 12. Outer inboard reclining device cover |
| 13. Inner inboard reclining device cover | 14. Seat cushion trim cover          | 15. Seat cushion pad                     |
| 16. Seat cushion frame assembly          | 17. Lower rear seat cover outer      | 18. Outboard cushion floor latch         |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# SECOND SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |   |                                 |                                  |
|---|---------------------------------|----------------------------------|
| 19. Seat cushion support frame assembly | 20. Inboard cushion floor latch | 21. Lower rear seat cover inner  |
| 22. Lower rear seat cover               | 23. Seat support pad assembly   | 24. Seat support trim cover      |
| 25. Seat cushion mat                    | 26. Seat cushion mat springs    | 27. Latch assembly               |
| 28. Armrest assembly                    | 29. Armrest trim cover          | 30. Reclining device outer cover |
| 31. Reclining device inner mid cover    | 32. Seatback frame              | 33. Seat actuator assembly       |

### Second row center

SEC. 861



BIIA0020E

## SECOND SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >

---

1. Seatback pad	2. Armrest finisher	3. Headrest	A
4. Seat belt retractor cover	5. Seat belt bezel	6. RH headrest guide (free)	
7. LH headrest guide (locked)	8. Seatback board	9. Seat bracket cover	
10. Armrest pivot bracket cover	11. Seatback frame	12. Seat cushion frame	B
13. Latch assembly	14. Lower rear pivot bracket support	15. Outer hinge cover	
16. Center seat base assembly	17. Link and pivot bracket apron	18. Seat cushion pad	
19. Seat cushion trim cover	20. Cushion stop bumper	21. Inner lever cover	C
22. Seat hinge assembly	23. Seat lever assembly	24. Outer lever cover	
25. Seat lock cover	26. Armrest cover	27. Armrest bracket	
28. Armrest pad	29. Cup holder	30. Seatback trim cover	D
31. Seat belt assembly			

E

F

G

H

I

**SE**

K

L

M

N

O

P

# THIRD SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

## THIRD SEAT

W/O Power Folding


INFOID:000000006143733

Exploded View

INFOID:000000006143734

Third seat LH

SEC. 882



LIIA2322E

# THIRD SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

---

- |                             |                             |                              |   |
|-----------------------------|-----------------------------|------------------------------|---|
| 1. LH third seat assembly   | 2. Seatback assembly        | 3. Seatback trim cover       | A |
| 4. Seat cushion assembly    | 5. Seat cushion pad         | 6. Seat cushion trim cover   |   |
| 7. Flex mat springs         | 8. Flex mat                 | 9. Front link covers         |   |
| 10. RH hinge cover          | 11. Seat cushion frame      | 12. LH hinge cover           | B |
| 13. Seatback frame assembly | 14. Seatback cable assembly | 15. Release handle bezel     |   |
| 16. Seatback board          | 17. Seatback pad            | 18. Headrest holder, locking |   |
| 19. Headrest holder, free   | 20. Headrest                |                              | C |

D

E

F

G

H

I

**SE**

K

L

M

N

O


P

# THIRD SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Third seat RH

SEC. 882



LIIA2323E

- |                             |                             |                              |
|-----------------------------|-----------------------------|------------------------------|
| 1. RH third seat assembly   | 2. Seatback assembly        | 3. Seatback pad              |
| 4. Seatback trim cover      | 5. Seat cushion assembly    | 6. Seat cushion trim cover   |
| 7. Seat cushion pad         | 8. Flex mat springs         | 9. Flex mat                  |
| 10. Front link covers       | 11. Seat cushion frame      | 12. RH hinge cover           |
| 13. LH hinge cover          | 14. Seatback frame assembly | 15. Seatback board           |
| 16. Seatback cable assembly | 17. Release handle bezel    | 18. Headrest holder, locking |
| 19. Headrest holder, free   | 20. Headrest                |                              |



# THIRD SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

---

LH Side Seat

INFOID:000000006143735

DISASSEMBLY AND ASSEMBLY

**CAUTION:**

**Discard the seat belt buckle bolt and use a new bolt for installation.**

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

# THIRD SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Power Folding


INFOID:000000006143736

Exploded View

INFOID:000000006143737

Third seat LH

SEC. 882



- |                     |                             |                            |
|---------------------|-----------------------------|----------------------------|
| 1. Headrest         | 2. Headrest holder, locking | 3. Headrest holder, free   |
| 4. Seatback board   | 5. Seatback pad             | 6. Seatback frame assembly |
| 7. Seatback cushion | 8. Seatback trim cover      | 9. Seat cushion            |

ALIIA0071GB

# THIRD SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >


- |  |                                 |                               |
|--|---------------------------------|-------------------------------|
| 10. Seat cushion trim cover            | 11. Front link covers           | 12. Flex mat                  |
| 13. Flex mat springs                   | 14. Seat cushion frame assembly | 15. Seat motor/hinge assembly |
| 16. Control module/cross beam assembly | 17. LH hinge cover              | 18. Side link cover           |
| 19. RH hinge cover                     |                                 |                               |

**CAUTION:**

Discard the seat belt buckle bolt and use a new bolt for installation.

### Third seat RH

SEC. 882



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## THIRD SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >

---

- |                                 |                             |                             |
|---------------------------------|-----------------------------|-----------------------------|
| 1. Headrest                     | 2. Headrest holder, locking | 3. Headrest holder, free    |
| 4. Seatback board               | 5. Seatback pad             | 6. Seatback frame assembly  |
| 7. Seatback cushion             | 8. Seatback trim cover      | 9. RH hinge cover           |
| 10. Seat motor/hinge assembly   | 11. Seat cushion            | 12. Seat cushion trim cover |
| 13. Front link covers           | 14. Flex mat                | 15. Flex mat springs        |
| 16. Seat cushion frame assembly | 17. Side link cover         | 18. LH hinge cover          |

### LH Side Seat

INFOID:000000006143738

### DISASSEMBLY AND ASSEMBLY

#### **CAUTION:**

**Discard the seat belt buckle bolt and use a new bolt for installation.**