

EXL

SECTION EXL

EXTERIOR LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

CONTENTS

| | | | |
|--|----|---|-------|
| BASIC INSPECTION | 4 | Component Parts Location | 16 |
| DIAGNOSIS AND REPAIR WORKFLOW | 4 | Component Description | 17 |
| Work Flow | 4 | TRAILER TOW | 18 |
| SYSTEM DESCRIPTION | 7 | System Diagram | 18 |
| HEADLAMP (HALOGEN TYPE) | 7 | System Description | 18 |
| System Diagram | 7 | Component Parts Location | 19 |
| System Description | 7 | Component Description | 19 |
| Component Parts Location | 7 | COMBINATION SWITCH READING SYSTEM | ...20 |
| Component Description | 7 | System Diagram | 20 |
| DAYTIME RUNNING LIGHT SYSTEM | 9 | System Description | 20 |
| System Diagram | 9 | Component Parts Location | 23 |
| System Description | 9 | DIAGNOSIS SYSTEM (BCM) | 24 |
| Component Parts Location | 9 | COMMON ITEM | 24 |
| Component Description | 10 | COMMON ITEM : CONSULT Function (BCM - | |
| AUTO LIGHT SYSTEM | 11 | COMMON ITEM) | 24 |
| System Diagram | 11 | BUZZER | 25 |
| System Description | 11 | BUZZER : CONSULT Function (BCM - BUZZER)... | 25 |
| Component Parts Location | 12 | HEADLAMP | 25 |
| Component Description | 12 | HEADLAMP : CONSULT Function (BCM - HEAD | |
| FRONT FOG LAMP | 13 | LAMP) | 25 |
| System Diagram | 13 | FLASHER | 26 |
| System Description | 13 | FLASHER : CONSULT Function (BCM - FLASH- | |
| Component Parts Location | 13 | ER) | 26 |
| Component Description | 13 | COMB SW | 26 |
| TURN SIGNAL AND HAZARD WARNING | | COMB SW : CONSULT Function (BCM - COMB | |
| LAMPS | 14 | SW) | 26 |
| System Diagram | 14 | BCM | 27 |
| System Description | 14 | BCM : CONSULT Function (BCM - BCM) | 27 |
| Component Parts Location | 14 | BATTERY SAVER | 27 |
| Component Description | 15 | BATTERY SAVER : CONSULT Function (BCM - | |
| PARKING, LICENSE PLATE AND TAIL | | BATTERY SAVER) | 27 |
| LAMPS | 16 | DIAGNOSIS SYSTEM (IPDM E/R) | 29 |
| System Diagram | 16 | | |
| System Description | 16 | | |

| | | | |
|---|-----------|---|------------|
| Diagnosis Description | 29 | Physical Values | 65 |
| CONSULT Function (IPDM E/R) | 31 | Fail Safe | 68 |
| DTC/CIRCUIT DIAGNOSIS | 33 | DTC Index | 69 |
| POWER SUPPLY AND GROUND CIRCUIT | 33 | WIRING DIAGRAM | 70 |
| BCM (BODY CONTROL MODULE) | 33 | HEADLAMP | 70 |
| BCM (BODY CONTROL MODULE) : Diagnosis | | Wiring Diagram | 70 |
| Procedure | 33 | DAYTIME LIGHT SYSTEM | 74 |
| IPDM E/R (INTELLIGENT POWER DISTRIBUTION | | Wiring Diagram | 74 |
| MODULE ENGINE ROOM) | 34 | AUTO LIGHT SYSTEM | 80 |
| IPDM E/R (INTELLIGENT POWER DISTRIBUTION | | Wiring Diagram | 80 |
| MODULE ENGINE ROOM) : Diagnosis Pro- | | FRONT FOG LAMP SYSTEM | 88 |
| cedure | 34 | Wiring Diagram | 88 |
| HEADLAMP (HI) CIRCUIT | 36 | TURN SIGNAL AND HAZARD WARNING | |
| Description | 36 | LAMP SYSTEM | 92 |
| Component Function Check | 36 | Wiring Diagram | 92 |
| Diagnosis Procedure | 36 | PARKING, LICENSE PLATE AND TAIL | |
| Component Inspection | 38 | LAMPS SYSTEM | 100 |
| HEADLAMP (LO) CIRCUIT | 39 | Wiring Diagram | 100 |
| Description | 39 | STOP LAMP | 106 |
| Component Function Check | 39 | Wiring Diagram | 106 |
| Diagnosis Procedure | 39 | BACK-UP LAMP | 110 |
| FRONT FOG LAMP CIRCUIT | 41 | Wiring Diagram | 110 |
| Description | 41 | TRAILER TOW | 114 |
| Component Function Check | 41 | Wiring Diagram | 114 |
| Diagnosis Procedure | 41 | SYMPTOM DIAGNOSIS | 121 |
| PARKING LAMP CIRCUIT | 43 | EXTERIOR LIGHTING SYSTEM SYMPTOMS. | 121 |
| Description | 43 | Symptom Table | 121 |
| Component Function Check | 43 | NORMAL OPERATING CONDITION | 123 |
| Diagnosis Procedure | 43 | Description | 123 |
| TURN SIGNAL LAMP CIRCUIT | 47 | BOTH SIDE HEADLAMPS DO NOT SWITCH | |
| Description | 47 | TO HIGH BEAM | 124 |
| Component Function Check | 47 | Description | 124 |
| Diagnosis Procedure | 47 | Diagnosis Procedure | 124 |
| OPTICAL SENSOR | 50 | BOTH SIDE HEADLAMPS (LO) ARE NOT | |
| Description | 50 | TURNED ON | 125 |
| Component Function Check | 50 | Description | 125 |
| Diagnosis Procedure | 50 | Diagnosis Procedure | 125 |
| ECU DIAGNOSIS INFORMATION | 52 | PARKING, LICENSE PLATE AND TAIL | |
| BCM (BODY CONTROL MODULE) | 52 | LAMPS ARE NOT TURNED ON | 126 |
| Reference Value | 52 | Description | 126 |
| Terminal Layout | 55 | Diagnosis Procedure | 126 |
| Physical Values | 55 | BOTH SIDE FRONT FOG LAMPS ARE NOT | |
| Fail Safe | 61 | TURNED ON | 127 |
| DTC Inspection Priority Chart | 61 | Description | 127 |
| DTC Index | 61 | Diagnosis Procedure | 127 |
| IPDM E/R (INTELLIGENT POWER DISTRIBUTION | | | |
| MODULE ENGINE ROOM) | 63 | | |
| Reference Value | 63 | | |
| Terminal Layout | 64 | | |

| | | | | |
|--|-----|--|-----|---|
| PRECAUTION | 128 | Removal and Installation | 136 | |
| PRECAUTIONS | 128 | FRONT FOG LAMP | 137 | A |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 128 | Bulb Replacement | 137 | |
| Precaution Necessary for Steering Wheel Rotation After Battery Disconnect | 128 | Removal and Installation | 137 | B |
| Precaution for Work | 129 | LIGHTING & TURN SIGNAL SWITCH | 138 | |
| PREPARATION | 130 | Removal and Installation | 138 | C |
| PREPARATION | 130 | HAZARD SWITCH | 139 | |
| Special Service Tool | 130 | Removal and Installation | 139 | D |
| REMOVAL AND INSTALLATION | 131 | LICENSE PLATE LAMP | 140 | |
| ADJUSTMENT AND INSPECTION | 131 | Bulb Replacement | 140 | E |
| HEADLAMP | 131 | Removal and Installation | 140 | |
| HEADLAMP : Aiming Adjustment | 131 | PUDDLE LAMP | 141 | F |
| HEADLAMP : Headlamp Aiming | 131 | Removal and Installation | 141 | |
| FRONT FOG LAMP | 132 | Bulb Replacement | 141 | G |
| FRONT FOG LAMP : Aiming Adjustment | 132 | HIGH-MOUNTED STOP LAMP | 143 | |
| UNIT REMOVAL AND INSTALLATION ... | 134 | Bulb Replacement | 143 | H |
| HEADLAMP | 134 | Removal and Installation | 143 | |
| Bulb Replacement | 134 | REAR COMBINATION LAMP | 144 | I |
| Removal and Installation | 134 | Bulb Replacement | 144 | |
| Disassembly and Assembly | 135 | Removal and Installation | 144 | J |
| AUTO LIGHT SYSTEM | 136 | SERVICE DATA AND SPECIFICATIONS (SDS) | 145 | K |
| | | BULB SPECIFICATIONS | 145 | |
| | | Bulb Specifications | 145 | |

EXL

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009822249

OVERALL SEQUENCE



AWLIA1837GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2.

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 5.

NO >> GO TO 11.

11.REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3.


HEADLAMP (HALOGEN TYPE)

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

HEADLAMP (HALOGEN TYPE)

System Diagram




System Description

INFOID:000000009822251

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 2nd position, the BCM (body control module) receives input requesting the headlamps and park lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the headlamp high and headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.

Component Parts Location

INFOID:000000009822252



1. BCM M18, M20 (view with instrument panel removed)
2. IPDM E/R E122, E123, E124
3. Combination switch (lighting and turn-signal switch) M28
4. Combination meter M24

Component Description

INFOID:000000009822253

LOW BEAM OPERATION

HEADLAMP (HALOGEN TYPE)

< SYSTEM DESCRIPTION >

When the combination switch (lighting and turn signal switch) is in 2ND position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R via the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil which supplies power to the low beam headlamps.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

With the combination switch (lighting and turn signal switch) in the 2ND position and placed in HIGH position, the BCM receives input requesting the headlamp high beams to illuminate. The flash to pass feature can be used any time and also sends a signal to the BCM. This input is communicated to the IPDM E/R via the CAN communication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil which supplies power to the high beam headlamps.

The combination meter receives a high beam request signal (ON) via the CAN communication lines and turns the high beam indicator lamp ON.

EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting and turn signal switch) in the 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the headlamps remain illuminated for 45 seconds unless the lighting switch position is changed. If the lighting switch position is changed, then the headlamps are turned off.


This setting can be changed by CONSULT. Refer to [BCS-25, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

DAYTIME RUNNING LIGHT SYSTEM

System Diagram




System Description

INFOID:000000009822255

The headlamp system for Canada vehicles is equipped with a daytime light relay that activates the high beam headlamps at approximately half illumination whenever the engine is operating. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Component Parts Location

INFOID:000000009822256



ALLIA0380ZZ

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------------|---|--|
| 1. IPDM E/R E119, E122, E123, E124 | 2. Parking brake switch M11 | 3. BCM M18, M20 (view with instrument panel removed) |
| 4. Daytime running light relay E103 | 5. Combination switch (lighting and turn signal switch) M28 | 6. Combination meter M24 |

Component Description

INFOID:000000009822257

After starting the engine with the parking brake released and the combination switch (lighting and turn signal switch) in the OFF or 1ST position, the headlamp high beam automatically turns on at a reduced intensity. With the combination switch (lighting and turn signal switch) in the 2nd position or with autolamps ON, the headlamps function the same as conventional light systems.

OPERATION


The BCM monitors inputs from the parking brake switch and the combination switch (lighting and turn signal switch) to determine when to activate the daytime light system. The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The IPDM E/R grounds the daytime light relay which in turn, provides power to the ground side of the LH high beam lamp. Power flows backward through the LH high beam lamp to the IPDM E/R, through the high beam fuses, through the RH high beam lamp circuit to the RH high beam lamp and on to ground. The high beam lamps are wired in series which causes them to illuminate at a reduced intensity.

AUTO LIGHT SYSTEM

< SYSTEM DESCRIPTION >

AUTO LIGHT SYSTEM

System Diagram



System Description

INFOID:000000009822259

- BCM (Body Control Module) controls auto light operation according to signals from optical sensor, combination switch (lighting and turn signal switch) and ignition switch.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate, tail and headlamps according to CAN communication signals from BCM.
- Optical sensor detects ambient brightness of 800 to 2,500 lux. And optical sensor converts light (lux) to voltage, then sends the optical sensor signal to BCM.

OUTLINE

The auto light control system has an optical sensor that detects outside brightness.

When the combination switch (lighting and turn signal switch) is in AUTO position, it automatically turns ON/OFF the parking, license plate, tail and headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [EXL-27, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

AUTO LIGHT SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000009822260



AWNIA1606ZZ

- | | | |
|---|--|--|
| 1. BCM M18, M19, M20 (view with instrument panel removed) | 2. IPDM E/R E122, E123, E124 | 3. Optical sensor M302 |
| 4. Front door switch LH B8 RH B108 | 5. Rear door switch LH B18 RH B116 | 6. Back door switch D502 (without power back door) Back door latch (door ajar switch) D503 (with power back door) |
| 7. Combination switch (lighting and turn signal switch) M28 | | |

Component Description

INFOID:000000009822261

AUTO LIGHT OPERATION

The auto light system operates the low beam and high beam headlamps, parking lamps, tail lamps and license plate lamps. The BCM monitors the combination switch (lighting and turn signal switch) position as a part of the BCM combination switch reading function. When the combination switch (lighting and turn signal switch) is in the AUTO position, the BCM automatically turns the lamps ON/OFF according to ambient light brightness.

NOTE:


Timing for when lamps turn ON/OFF can be changed by the function setting of CONSULT. Refer to [EXL-27, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

FRONT FOG LAMP

< SYSTEM DESCRIPTION >

FRONT FOG LAMP

System Diagram




System Description

INFOID:000000009822263

The front fog lamps are activated with the combination switch (lighting and turn signal switch). The combination switch (lighting and turn signal switch) signal to the BCM is monitored with the BCM combination switch reading function. When the fog lamps are turned ON with the combination switch (lighting and turn signal switch), the BCM sends a front fog lamp request signal via CAN communication lines to the IPDM E/R. The IPDM E/R grounds the front fog lamp relay coil to activate the front fog lamps.

Component Parts Location

INFOID:000000009822264



1. BCM M18, M20 (view with instrument panel removed)
2. IPDM E/R E122, E123, E124
3. Combination switch (lighting and turn signal switch) M28

Component Description

INFOID:000000009822265

FRONT FOG LAMP OPERATION

When the combination switch (lighting and turn signal switch) is in front fog lamp ON position and also in 1ST or 2ND position or AUTO position (headlamp is ON), the BCM detects FR FOG ON and the HEAD LAMP1, 2 ON or the AUTO LIGHT ON. The BCM sends a front fog lamp request ON signal via the CAN communication lines to the IPDM E/R. The IPDM E/R then turns ON the front fog lamp relay sending power to the front fog lamps.


TURN SIGNAL AND HAZARD WARNING LAMPS

< SYSTEM DESCRIPTION >

TURN SIGNAL AND HAZARD WARNING LAMPS

System Diagram

INFOID:000000009822266



System Description

INFOID:000000009822267

TURN SIGNAL OPERATION

When the combination switch (lighting and turn signal switch) is in LH or RH position with the ignition switch in ON position, the BCM detects the TURN RH or TURN LH ON request. The BCM outputs the flasher signal to the respective turn signal lamp. The BCM also sends a turn indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the appropriate turn signal indicator and audible buzzer.

HAZARD LAMP OPERATION

When the hazard switch is in ON position, the BCM detects the hazard switch signal ON. The BCM outputs the flasher signal (right and left). The BCM sends a hazard indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the hazard indicator and audible buzzer.


REMOTE KEYLESS ENTRY OPERATION

The remote keyless entry receiver transmits a hazard request signal to the BCM, then BCM controls hazard lamps.

Refer to [SEC-11. "System Description"](#).

Component Parts Location

INFOID:000000009822268



1. Combination meter M24
2. Combination switch (lighting and turn signal switch) M28
3. Hazard switch M55
4. BCM M18, M20 (view with instrument panel removed)

TURN SIGNAL AND HAZARD WARNING LAMPS

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000009822269

| Part name | Description |
|--|---|
| BCM | Controls turn signal and hazard flasher operation. |
| Combination switch (lighting and turn signal switch) | Lighting and turn signal switch requests are output to the BCM. |
| Hazard switch | Hazard flasher request signal is output to the BCM. |
| Combination meter | Outputs turn and hazard indicator as requested by the BCM. |

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


PARKING, LICENSE PLATE AND TAIL LAMPS

< SYSTEM DESCRIPTION >

PARKING, LICENSE PLATE AND TAIL LAMPS

System Diagram

INFOID:000000009822270



System Description

INFOID:000000009822271

PARKING, LICENCE PLATE AND TAIL LAMPS OPERATION

When the combination switch (lighting and turn signal switch) is in 1ST position, BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which sends power to the parking and instrument illumination circuits.

EXTERIOR LAMP BATTERY SAVER CONTROL


With the combination switch (lighting and turn signal switch) in the 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the headlamps remain illuminated for 45 seconds unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the headlamps are turned off.

This setting can be changed by CONSULT. Refer to [EXL-27, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

Component Parts Location

INFOID:000000009822272



1. BCM M18, M20 (view with instrument panel removed)
2. IPDM E/R E122, E124

3. Combination switch (lighting and turn signal switch) M28

PARKING, LICENSE PLATE AND TAIL LAMPS

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000009822273

| Part name | Description |
|--|--|
| BCM | <ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Sends parking light request signal to the IPDM E/R. |
| IPDM E/R | Activates the tail lamp relay upon request of the BCM. |
| Combination switch (lighting and turn signal switch) | Outputs lighting requests to the BCM. |

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O


P

TRAILER TOW

< SYSTEM DESCRIPTION >

TRAILER TOW

System Diagram



System Description

INFOID:000000009822275

TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow relay 1 located behind the left side of the instrument panel (IP). With the combination switch (lighting and turn signal switch) in the 1st position, the BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which activates the trailer tow relay 1 and sends power to the trailer connector.

TRAILER TURN SIGNAL LAMP OPERATION

The trailer turn signal lamps are controlled by the BCM. When the turn signal switch is in the LH or RH position with the ignition switch ON, the combination switch (lighting and turn signal switch) sends a signal to the BCM. The BCM detects the TURN RH or TURN LH ON request. The BCM sends a control signal to the respective trailer turn relay which sends power to the trailer connector.

TRAILER HAZARD LAMP OPERATION

The trailer hazard lamps are controlled by the BCM. When the hazard switch is pressed, the BCM detects the the hazard ON request. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER BRAKE LAMP OPERATION


The trailer brake lamps are controlled by the BCM. When the brake pedal is depressed, the stop lamp switch sends the brake signal to the BCM. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER TOW

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000009822276



- | | | |
|--|------------------------------------|---|
| 1. BCM M18, M19, M20 (view with instrument panel removed) | 2. IPDM E/R E119, E122, E123, E124 | 3. Combination switch (lighting and turn signal switch) M28 |
| 4. Trailer tow relay 1 M51 (view with steering member removed) | 5. Battery | 6. Trailer turn relay LH E156 |
| 7. Trailer turn relay RH E157 | 8. Trailer tow relay 2 E140 | 9. Stop lamp switch E38 |

Component Description

INFOID:000000009822277

| Part name | Description |
|--|---|
| BCM | <ul style="list-style-type: none"> Receives lighting and turn signal requests from combination switch. Receives stop lamp signal requests from stop lamp switch. Sends lighting signal request to the IPDM E/R to control the tail lamp relay via CAN communication. Sends turn/hazard/brake control signal to the trailer turn relays. |
| IPDM E/R | Activates the tail lamp relay upon request from the BCM via CAN communication. |
| Combination switch (lighting and turn signal switch) | Outputs lighting and turn signal requests to the BCM. |

A
B
C
D
E
F
G
H
I
J
K

EXL

M

N

O

P


COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >

COMBINATION SWITCH READING SYSTEM

System Diagram

INFOID:000000009822278



System Description


INFOID:000000009822279

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5) and reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



Combination switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|-----------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | INT VOLUME 1 | RR WASHER | — | HEADLAMP 2 | HI BEAM |

COMBINATION SWITCH READING SYSTEM


< SYSTEM DESCRIPTION >

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|--------------|------------|---------|-----------|
| OUTPUT 4 | RR WIPER INT | INT VOLUME 3 | AUTO LIGHT | — | TAIL LAMP |
| OUTPUT 5 | INT VOLUME 2 | RR WIPER ON | — | FR FOG | — |

COMBINATION SWITCH READING FUNCTION


Description

- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

- BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.
- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
 - It reads this change of the voltage as the status signal of the combination switch.



Operation Example


In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON

COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal “5D” when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal “5D” is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal “5AD” when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal “5AD” is detected.

WIPER INTERMITTENT DIAL POSITION SETTING (FRONT WIPER INTERMITTENT OPERATION)

BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2, and 3 switches.


COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >

| Wiper intermittent dial position | Intermittent operation delay interval | INT VOLUME switch ON/OFF status | | |
|----------------------------------|---------------------------------------|---------------------------------|--------------|--------------|
| | | INT VOLUME 1 | INT VOLUME 2 | INT VOLUME 3 |
| 1 | Short ↑ | ON | ON | ON |
| 2 | | ON | ON | OFF |
| 3 | | ON | OFF | OFF |
| 4 | | OFF | OFF | OFF |
| 5 | ↓ Long | OFF | OFF | ON |
| 6 | | OFF | ON | ON |
| 7 | | OFF | ON | OFF |

Component Parts Location

INFOID:000000009822280



1. BCM M18, M19, M20 (view with instrument panel removed)
2. Combination switch (lighting and turn signal switch) M28
3. Combination switch (wiper and washer switch) M28

EXL

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:00000000982281

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description |
|------------------------|--|
| ECU Identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM. |
| CAN Diag Support Mntr | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions.

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | ECU Identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock | DOOR LOCK | | × | × | × | × | | |
| Rear window defogger | REAR DEFOGGER | | | × | × | | | |
| Warning chime | BUZZER | | | × | × | | | |
| Interior room lamp timer | INT LAMP | | | × | × | × | | |
| Remote keyless entry system | MULTI REMOTE ENT | | | × | × | × | | |
| Exterior lamp | HEADLAMP | | | × | × | × | | |
| Wiper and washer | WIPER | | | × | × | × | | |
| Turn signal and hazard warning lamps | FLASHER | | | × | × | | | |
| Air conditioner | AIR CONDITIONER | | | × | | | | |
| Intelligent Key system | INTELLIGENT KEY | | | × | | | | |
| Combination switch | COMB SW | | | × | | | | |
| BCM | BCM | × | × | | | × | × | × |
| Immobilizer | IMMU | | × | × | × | | | |
| Interior room lamp battery saver | BATTERY SAVER | | | × | × | × | | |
| Back door open | TRUNK | | | × | × | | | |
| Vehicle security system | THEFT ALM | | | × | × | × | | |
| RAP system | RETAINED PWR | | | × | × | × | | |
| Signal buffer system | SIGNAL BUFFER | | | × | × | | | |
| TPMS | AIR PRESSURE MONITOR | | × | × | × | × | | |
| Panic alarm system | PANIC ALARM | | | | × | | | |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000009822282

DATA MONITOR

| Monitor Item [Unit] | Description |
|-----------------------|---|
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| LIGHT SW 1ST [On/Off] | Indicates condition of combination switch. |
| BUCKLE SW [On/Off] | Indicates condition of seat belt buckle switch. |

ACTIVE TEST

| Test Item | Description |
|---------------------|---|
| SEAT BELT WARN TEST | This test is able to check seat belt warning operation [On/Off]. |
| LIGHT WARN ALM | This test is able to check light reminder warning operation [On/Off]. |
| IGN KEY WARN ALM | This test is able to check key warning chime operation [On/Off]. |

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000009822283

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| ACC ON SW [On/Off] | Indicates condition of ignition switch ACC position. |
| HI BEAM SW [On/Off] | Indicates condition of combination switch. |
| HEAD LAMP SW 1 [On/Off] | |
| HEAD LAMP SW 2 [On/Off] | |
| LIGHT SW 1ST [On/Off] | |
| AUTO LIGHT SW [On/Off] | |
| PASSING SW [On/Off] | |
| FR FOG SW [On/Off] | |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| BACK DOOR SW [On/Off] | Indicates condition of back door switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of combination switch. |
| TURN SIGNAL L [On/Off] | |
| CARGO LAMP SW [ON/OFF] | Indicates condition of cargo lamp switch. |
| OPTICAL SENSOR [V] | Indicates voltage signal from optical sensor. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| TAIL LAMP | This test is able to check tail lamp operation [Off/On]. |
| HEAD LAMP | This test is able to check head lamp operation [Off/Lo/Hi]. |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------------------|--|
| FR FOG LAMP | This test is able to check front fog lamp operation [Off/On]. |
| DAYTIME RUNNING LIGHT | This test is able to check daytime running light operation [Off/On]. |
| CARGO LAMP | This test is able to check cargo lamp operation [Off/On]. |
| CORNERING LAMP | This test is able to check turn signal lamp operation [Off/LH/RH]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------|--|--|
| BATTERY SAVER SET | Off | Exterior lamp battery saver function OFF. |
| | On* | Exterior lamp battery saver function ON. |
| CUSTOM A/LIGHT SETTING | MODE4 | Less sensitive setting than normal setting (Turns ON later than normal operation). |
| | MODE3 | More sensitive setting than MODE 2 (Turns ON earlier than MODE 2). |
| | MODE2 | More sensitive setting than normal setting (Turns ON earlier than normal operation). |
| | MODE1* | Normal. |
| ILL DELAY SET | MODE8 | Sets delay timer function operation time (All doors closed). |
| | 180 sec | |
| | MODE7 | |
| | 150 sec | |
| | MODE6 | |
| | 120 sec | |
| | MODE5 | |
| | 90 sec | |
| MODE4 | Sets delay timer function operation time (All doors closed). | |
| 60 sec | | |
| MODE3 | | |
| 30 sec | | |
| MODE2 | Sets delay timer function operation time (All doors closed). | |
| OFF | | |
| MODE1* | 45 sec | |

*: Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000009822284

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| HAZARD SW [On/Off] | Indicates condition of hazard switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of turn signal function of combination switch. |
| TURN SIGNAL L [On/Off] | |
| BRAKE SW [On/Off] | Indicates condition of brake switch. |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000009822285

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description | |
|-------------------------|--|---|
| TURN SIGNAL R [On/Off] | Indicates condition of turn signal operation of combination switch. | A |
| TURN SIGNAL L [On/Off] | | |
| HI BEAM SW [On/Off] | Indicates condition of hi beam operation of combination switch. | B |
| HEAD LAMP SW 1 [On/Off] | Indicates condition of headlamp operation of combination switch. | C |
| HEAD LAMP SW 2 [On/Off] | | |
| LIGHT SW 1ST [On/Off] | Indicates condition of lighting operation of combination switch. | |
| PASSING SW [On/Off] | Indicates condition of passing switch operation of combination switch. | |
| AUTO LIGHT SW [On/Off] | Indicates condition of auto light operation of combination switch. | D |
| FR FOG SW [On/Off] | Indicates condition of front fog light operation of combination switch. | |
| FR WIPER HI [On/Off] | Indicates condition of front wiper operation of combination switch. | E |
| FR WIPER LOW [On/Off] | | |
| FR WIPER INT [On/Off] | | |
| FR WASHER SW [On/Off] | Indicates condition of front washer operation of combination switch. | F |
| INT VOLUME [1 - 7] | Indicates condition of intermittent wiper operation of combination switch. | |
| RR WIPER ON [On/Off] | Indicates condition of rear wiper operation of combination switch. | G |
| RR WIPER INT [On/Off] | | |
| RR WASHER SW [On/Off] | Indicates condition of rear washer operation of combination switch. | |

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000009822286

ECU IDENTIFICATION

The BCM part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [BCS-44, "DTC Index"](#).

WORK SUPPORT

| Support Item | Setting | Description | |
|---------------------|---------|---|-----|
| RESET SETTING VALUE | Reset | Returns BCM to initial value in factory shipment. | EXL |
| | Cancel | Cancels the reset function. | |

CONFIGURATION

Refer to [BCS-4, "CONFIGURATION \(BCM\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-49, "CAN Diagnostic Support Monitor"](#).

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000009822287

DATA MONITOR

| Monitor Item [Unit] | Description | |
|---------------------|---|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. | |
| KEY ON SW [On/Off] | Indicates condition of key switch. | |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. | |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. | |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. | |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|---------------------------|--|
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| BACK DOOR SW [On/Off] | Indicates condition of back door switch. |
| KEY CYL LK SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| I-KEY LOCK* [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| I-KEY UNLOCK* [On/Off] | Indicates condition of unlock signal from Intelligent Key. |
| KEYLESS LOCK** [On/Off] | Indicates condition of lock signal from keyfob. |
| KEYLESS UNLOCK** [On/Off] | Indicates condition of unlock signal from keyfob. |

* : with Intelligent Key

** : without Intelligent Key

ACTIVE TEST

| Test item | Description |
|---------------|--|
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | | Description |
|---------------------|---------|--------|---|
| ROOM LAMP TIMER SET | MODE2 | 60 min | Sets the interior room lamp battery saver timer operating time. |
| | MODE1* | 10 min | |

*: Initial setting

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000009822288

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure low/coolant pressure high warning indicator
- Oil pressure gauge
- Rear window defogger
- Front wipers (HI, LO)
- Tail, license and parking lamps
- Front fog lamps (if equipped)
- Headlamps (HI, LO)
- A/C compressor (magnetic clutch)
- Cooling fan

Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).
NOTE:
When auto active test is performed with hood opened, sprinkle water on windshield before hand.
2. Turn ignition switch OFF.
3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-74, "Description"](#) (with Intelligent Key system), [DLK-271, "Description"](#) (without Intelligent Key system).
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 7 steps are repeated 3 times.



| Operation sequence | Inspection Location | Operation |
|--------------------|----------------------|-------------------------------------|
| 1 | Rear window defogger | 10 seconds |
| 2 | Front wipers | LO for 5 seconds → HI for 5 seconds |


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Operation sequence | Inspection Location | Operation |
|--------------------|---------------------------------|---|
| 3 | Tail, license and parking lamps | 10 seconds |
| 4 | Front fog lamps (if equipped) | 10 seconds |
| 5 | Headlamps | LO for 10 seconds → HI on-off for 5 seconds |
| 6 | A/C compressor | ON ⇔ OFF 5 times |
| 7 | Cooling fan | 10 seconds |

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

| Symptom | Inspection contents | Possible cause | |
|--|--|----------------|--|
| Oil pressure low/coolant temperature high warning indicator does not operate | Perform auto active test. Does the oil pressure low/coolant temperature high warning indicator operate? | YES | <ul style="list-style-type: none"> • IPDM E/R signal input circuit • ECM signal input circuit • CAN communication signal between ECM and combination meter |
| | | NO | <ul style="list-style-type: none"> • CAN communication signal between IPDM E/R, BCM and combination meter |
| Oil pressure gauge does not operate | Perform auto active test. Does the oil pressure gauge operate? | YES | IPDM E/R signal input circuit |
| | | NO | <ul style="list-style-type: none"> • CAN communication signal between IPDM E/R, BCM and combination meter |
| Rear window defogger does not operate | Perform auto active test. Does the rear window defogger operate? | YES | BCM signal input circuit |
| | | NO | <ul style="list-style-type: none"> • Harness or connector between A/C and AV switch assembly and AV control unit • CAN communication signal between BCM and IPDM E/R |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Symptom | Inspection contents | Possible cause | |
|--|--|----------------|---|
| Any of the following components do not operate <ul style="list-style-type: none"> • Front wipers • Tail lamps • License plate lamps • Parking lamps • Front fog lamps (if equipped) • Headlamps (HI, LO) | Perform auto active test. Does the applicable system operate? | YES | BCM signal input system |
| | | NO | <ul style="list-style-type: none"> • Lamp or front wiper motor malfunction • Lamp or front wiper motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R (integrated relay malfunction) |
| A/C compressor does not operate | Perform auto active test. Does the A/C compressor operate? | YES | <ul style="list-style-type: none"> • BCM signal input circuit • CAN communication signal between BCM and ECM • CAN communication signal between ECM and IPDM E/R |
| | | NO | <ul style="list-style-type: none"> • Magnetic clutch malfunction • Harness or connector between IPDM E/R and magnetic clutch • IPDM E/R (integrated relay malfunction) |
| Cooling fan does not operate | Perform auto active test. Does the cooling fan operate? | YES | <ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R |
| | | NO | <ul style="list-style-type: none"> • Cooling fan motor malfunction • Harness or connector between IPDM E/R and cooling fan • IPDM E/R (integrated relay malfunction) |

CONSULT Function (IPDM E/R)

INFOID:000000009822289

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

| Direct Diagnostic Mode | Description |
|------------------------|---|
| Self Diagnostic Result | The IPDM E/R self diagnostic results are displayed. |
| Data Monitor | The IPDM E/R input/output data is displayed in real time. |
| Active Test | The IPDM E/R activates outputs to test components. |
| CAN Diag Support Mntr | The result of transmit/receive diagnosis of CAN communication is displayed. |

SELF DIAGNOSTIC RESULT

Refer to [PCS-24, "DTC Index"](#).

DATA MONITOR

| Monitor Item [Unit] | Main Signals | Description |
|-------------------------|--------------|---|
| MOTOR FAN REQ [1/2/3/4] | × | Indicates cooling fan speed signal received from ECM on CAN communication line |
| AC COMP REQ [On/Off] | × | Indicates A/C compressor request signal received from ECM on CAN communication line |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Main Signals | Description |
|-------------------------------|--------------|--|
| TAIL&CLR REQ [On/Off] | × | Indicates position light request signal received from BCM on CAN communication line |
| HL LO REQ [On/Off] | × | Indicates low beam request signal received from BCM on CAN communication line |
| HL HI REQ [On/Off] | × | Indicates high beam request signal received from BCM on CAN communication line |
| FR FOG REQ [On/Off] | × | Indicates front fog light request signal received from BCM on CAN communication line |
| FR WIP REQ [Stop/1LOW/Low/Hi] | × | Indicates front wiper request signal received from BCM on CAN communication line |
| WIP AUTO STOP [STOP P/ACT P] | × | Indicates condition of front wiper auto stop signal |
| WIP PROT [Off/BLOCK] | × | Indicates condition of front wiper fail-safe operation |
| ST RLY REQ [On/Off] | | Indicates starter request signal received from ECM on CAN communication line |
| IGN RLY [On/Off] | × | Indicates condition of ignition relay |
| RR DEF REQ [On/Off] | × | Indicates rear defogger request signal received from AV control unit on CAN communication line |
| OIL P SW [Open/Close] | | Indicates condition of oil pressure switch |
| DTRL REQ [Off] | | Indicates daytime light request signal received from BCM on CAN communication line |
| THFT HRN REQ [On/Off] | | Indicates theft warning horn request signal received from BCM on CAN communication line |
| HORN CHIRP [On/Off] | | Indicates horn reminder signal received from BCM on CAN communication line |

ACTIVE TEST

| Test item | Description |
|----------------|--|
| REAR DEFOGGER | This test is able to check rear defogger operation [On/Off]. |
| FRONT WIPER | This test is able to check wiper motor operation [Hi/Lo/Off]. |
| MOTOR FAN | This test is able to check cooling fan operation [4/3/2/1]. |
| EXTERNAL LAMPS | This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off]. |
| HORN | This test is able to check horn operation [On]. |

CAN DIAG SUPPORT MNTR

Refer to [LAN-49. "CAN Diagnostic Support Monitor"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000009822290

Regarding Wiring Diagram information, refer to [BCS-46, "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

| Terminal No. | Signal name | Fuses and fusible link No. |
|--------------|----------------------|----------------------------|
| 57 | Battery power supply | 22 (15A) |
| 70 | | F (50A) |
| 11 | Ignition ACC or ON | 4 (10A) |
| 38 | Ignition ON or START | 59 (10A) |

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

| Connector | Terminals | | Power source | Condition | Voltage (V) (Approx.) |
|-----------|-----------|--------|-----------------------|-----------------------------|-----------------------|
| | (+) | (-) | | | |
| M18 | 11 | Ground | ACC power supply | Ignition switch ACC or ON | Battery voltage |
| | 38 | Ground | Ignition power supply | Ignition switch ON or START | Battery voltage |
| M20 | 57 | Ground | Battery power supply | Ignition switch OFF | Battery voltage |
| | 70 | Ground | Battery power supply | Ignition switch OFF | Battery voltage |



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M20 | 67 | | Yes |

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000009822291

Regarding Wiring Diagram information, refer to [PCS-25. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible link are not blown.

| Terminal No. | Signal name | Fuses and fusible link No. |
|--------------|-----------------------------|----------------------------|
| 1 | Battery | A, D |
| 2 | Battery | C |
| 12 | Ignition switch ON or START | 59 |

Is the fuse blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
 NO >> GO TO 2

2. CHECK BATTERY POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R.
- Check voltage between IPDM E/R harness connectors and ground.

| Terminals | | (-) | Ignition switch position | | |
|-----------|----------|--------|--------------------------|-----------------|-----------------|
| (+) | | | OFF | ON | START |
| Connector | Terminal | | | | |
| E118 | 1 | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 2 | | Battery voltage | Battery voltage | Battery voltage |
| E119 | 12 | | 0V | Battery voltage | Battery voltage |

Is the measurement value normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.

POWER SUPPLY AND GROUND CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between IPDM E/R harness connectors (A, B) and ground.

| IPDM E/R | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| E122 (A) | 38 | | Yes |
| E124 (B) | 59 | | |

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (HI) CIRCUIT

Description

INFOID:000000009822292

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp high relay based on inputs from the BCM via the CAN communication lines. When the headlamp high relay is energized, power flows through fuses 34 and 35, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp high beam.

Component Function Check

INFOID:000000009822293

1. CHECK HEADLAMP (HI) OPERATION

⊗ WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Ⓟ WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test item operating, check that the headlamp switches to high beam.

Hi : Headlamp switches to the high beam.

Off : Headlamp OFF

Does the headlamp switch to high beam?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-36, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822294

Regarding Wiring Diagram information, refer to [EXL-70, "Wiring Diagram"](#).

1. CHECK HEADLAMP (HI) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

| Unit | Location | Fuse No. | Capacity |
|------------------|----------|----------|----------|
| Headlamp HI (LH) | IPDM E/R | 35 | 10A |
| Headlamp HI (RH) | IPDM E/R | 34 | 10A |

Is the fuse open?


YES >> Repair the harness and replace the fuse.

NO >> GO TO 2.

2. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Turn the high beam headlamps ON.
5. With the high beam headlamps ON, check the voltage between the combination lamp connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|-----|---------|
| Connector | Terminal | | |
| | | | |



ALLIA0386GB

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| | | | | |
|----|---------------------|---|--------|-----------------|
| LH | E11 (without DTRL) | 2 | Ground | Battery voltage |
| | E6 (with DTRL) | | | |
| RH | E107 (without DTRL) | | | |
| | E108 (with DTRL) | | | |

Are the voltage readings as specified?


YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HEADLAMP (HI) CIRCUIT FOR OPEN

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector E123.
- Check continuity between the IPDM E/R harness connector (A) and the front combination lamp harness connector (B).

| A | | B | | Continuity |
|-----------|----------|----------------|---------------------|------------|
| Connector | Terminal | Connector | Terminal | |
| LH | E123 | 55 | E11 (without DTRL) | 2 |
| | | E6 (with DTRL) | | |
| RH | E123 | 56 | E107 (without DTRL) | 2 |
| | | | E108 (with DTRL) | |



Does continuity exist?


YES >> Replace IPDM E/R. Refer to [PCS-31. "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

4. CHECK FRONT COMBINATION LAMP (HI) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal and ground.

| Connector | | Terminal | — | Continuity |
|-----------|---------------------|----------|--------|------------|
| LH | E11 (without DTRL) | 3 | Ground | Yes |
| | E6 (with DTRL) | | | |
| RH | E107 (without DTRL) | | | |
| | E108 (with DTRL) | | | |



Does continuity exist?

YES >> Inspect the headlamp bulb.

NO (Except LH with DTRL)>> Repair the harness.

NO (LH with DTRL)>> GO TO 5.

5. CHECK CONTINUITY BETWEEN FRONT COMBINATION LAMP LH (HI) AND DAYTIME LIGHT RELAY

- Disconnect daytime light relay connector.
- Check continuity between front combination lamp LH harness connector and daytime light relay harness connector.

| Front combination lamp LH | | Daytime light relay | | Continuity |
|---------------------------|----------|---------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E6 | 3 | E103 | 3 | Yes |

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harness or connector.

6. CHECK DAYTIME LIGHT RELAY GROUND CIRCUIT

Check continuity between daytime light relay harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| Daytime light relay | | Ground | Continuity |
|---------------------|----------|--------|------------|
| Connector | Terminal | | |
| E103 | 4 | | Yes |

Does continuity exist?

YES >> GO TO 7.

NO >> Repair the harness or connector.

7. CHECK DAYTIME LIGHT RELAY

Check daytime light relay. Refer to [EXL-38, "Component Inspection"](#).

Is the inspection result normal?

YES >> Inspect daytime light relay circuit for short. If OK, replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Replace daytime light relay.

Component Inspection

INFOID:000000009822295

1. CHECK DAYTIME LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime light relay.
3. Check the continuity between daytime light relay terminals under the following conditions.

| Terminals | Condition | Continuity |
|-----------|---|------------|
| 3 and 5 | 12V direct current supply between terminals 1 and 2 | Yes |
| | No current supply | No |
| 3 and 4 | 12V direct current supply between terminals 1 and 2 | No |
| | No current supply | Yes |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace daytime light relay.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (LO) CIRCUIT

Description

INFOID:000000009822296

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp low relay based on inputs from the BCM via the CAN communication lines. When the headlamp low relay is energized, power flows through fuses 40 and 41, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp low beam.

Component Function Check

INFOID:000000009822297

1. CHECK HEADLAMP (LO) OPERATION

⊗ WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Ⓜ WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test items operating, check that the headlamp is turned ON.

Lo : Headlamp ON

Off : Headlamp OFF

Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-39, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822298

Regarding Wiring Diagram information, refer to [EXL-70, "Wiring Diagram"](#).

1. CHECK HEADLAMP (LO) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

| Unit | Location | Fuse No. | Capacity |
|------------------|----------|----------|----------|
| Headlamp LO (LH) | IPDM E/R | 40 | 15A |
| Headlamp LO (RH) | IPDM E/R | 41 | 15A |

Is the fuse open?


YES >> Repair the harness and replace the fuse.

NO >> GO TO 2.

2. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Turn the low beam headlamps ON.
5. With the low beam headlamps ON, check the voltage between the combination lamp connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|-----|---------|
| Connector | Terminal | | |
| | | | |



HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| | | | | |
|----|---------------------|---|--------|-----------------|
| LH | E11 (without DTRL) | 1 | Ground | Battery voltage |
| | E6 (with DTRL) | | | |
| RH | E107 (without DTRL) | | | |
| | E108 (with DTRL) | | | |

Is voltage reading as specified?


YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HEADLAMP (LO) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E123.
3. Check continuity between the IPDM E/R harness connector (A) and the front combination lamp harness connector (B).

| A | | B | | Continuity | |
|-----------|----------|-----------|----------|------------|-----|
| Connector | Terminal | Connector | Terminal | | |
| LH | E123 | E11 | 52 | 1 | Yes |
| RH | | | 54 | E107 | |



Does continuity exist?


YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

4. CHECK FRONT COMBINATION LAMP (LO) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal and ground.

| Connector | | Terminal | — | Continuity |
|-----------|---------------------|----------|--------|------------|
| LH | E11 (without DTRL) | 4 | Ground | Yes |
| | E6 (with DTRL) | | | |
| RH | E107 (without DTRL) | | | |
| | E108 (with DTRL) | | | |



Does continuity exist?

YES >> Inspect the headlamp bulb.

NO >> Repair the harness.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT FOG LAMP CIRCUIT

Description

INFOID:000000009822299

The IPDM E/R (intelligent power distribution module engine room) controls the front fog lamp relay based on inputs from the BCM via the CAN communication lines. When the front fog lamp relay is energized, power flows from the front fog lamp relay in the IPDM E/R to the front fog lamps.

Component Function Check

INFOID:000000009822300

1. CHECK FRONT FOG LAMP OPERATION

⊗ WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

Ⓜ WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, Check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Is the front fog lamp turned ON?

- YES >> Front fog lamp circuit is normal.
 NO >> Refer to [EXL-41, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822301

Regarding Wiring Diagram information, refer to [EXL-88, "Wiring Diagram"](#).

1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not open.

| Unit | Location | Fuse No. | Capacity |
|----------------|----------|----------|----------|
| Front fog lamp | IPDM E/R | 56 | 15A |


Is the fuse open?

- YES >> Repair the harness and replace the fuse.
 NO >> GO TO 2.

2. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front fog lamp connector.
3. Turn the ignition switch ON.
4. Turn the front fog lamps ON.
5. Check the voltage between the fog lamp connector and ground.

| (+) Connector | | Terminal | (-) Ground | Voltage |
|---------------|------|----------|------------|-----------------|
| LH | E101 | 1 | Ground | Battery voltage |
| RH | E102 | 1 | | |



Are the voltage readings as specified?

- YES >> GO TO 4.
 NO >> GO TO 3.


FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E123.
3. Check continuity between the IPDM E/R harness connector (A) and the front fog lamp harness connector (B).

| A | | B | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| LH | E123 | 50 | E101 | Yes |
| RH | | 51 | E102 | |



Does continuity exist?


YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

4. CHECK FRONT FOG LAMP GROUND CIRCUIT

1. Disconnect the front fog lamp connector.
2. Check continuity between the front fog lamp harness connector and ground.

| Connector | Terminal | — | Continuity |
|-----------|----------|--------|------------|
| LH | E101 | Ground | Yes |
| RH | E102 | | |



Does continuity exist?

YES >> Inspect the fog lamp bulb.

NO >> Repair the harness.

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Description

INFOID:000000009822302

The IPDM E/R (intelligent power distribution module engine room) controls the tail lamp relay based on inputs from the BCM via the CAN communication lines. When the tail lamp relay is energized, power flows through fuse 37, located in the IPDM E/R. Power then flows to the front and rear combination lamps.

Component Function Check

INFOID:000000009822303

1. CHECK PARKING LAMP OPERATION

WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON
Off : Parking lamp OFF

Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-43, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822304

Regarding Wiring Diagram information, refer to [EXL-100, "Wiring Diagram"](#).

1. CHECK PARKING LAMP FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuse is not open.

| Unit | Location | Fuse No. | Capacity |
|---------------|----------|----------|----------|
| Parking lamps | IPDM E/R | 37 | 10A |

Is the fuse open?

- YES >> Repair the harness and replace the fuse.
NO >> GO TO 2.

2. CHECK TAIL LAMP RELAY OUTPUT (VOLTAGE)


1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector, rear combination lamp connector and license plate lamp connector.
3. Turn the ignition switch ON.
4. Turn the parking lamps ON.

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. With the parking lamps ON, check voltage between the front combination lamp connectors and ground.


| (+) | | | Terminal | (-) | Voltage |
|--------------|----|------|----------|--------|-----------------|
| Connector | | | | | |
| With DTRL | LH | E6 | 6 | Ground | Battery voltage |
| | RH | E108 | | | |
| Without DTRL | LH | E11 | | | |
| | RH | E107 | | | |



ALLIA0393ZZ

6. With the parking lamps ON, check voltage between the rear combination lamp connectors and ground.


| (+) | | | Terminal | (-) | Voltage |
|-----------|------|---|----------|-----------------|---------|
| Connector | | | | | |
| LH | B70 | 2 | Ground | Battery voltage | |
| RH | B130 | | | | |



ALLIA0394ZZ

7. With the parking lamps ON, check voltage between the license plate lamp connector and ground.

| (+) | | | Terminal | (-) | Voltage |
|-----------|------|---|----------|-----------------|---------|
| Connector | | | | | |
| LH | C106 | 1 | Ground | Battery voltage | |
| RH | C107 | | | | |



AWLIA1597ZZ


Are voltage readings as specified?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT (OPEN)

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector E124.
- Check continuity between the IPDM E/R harness connector (A) and the front combination lamp harness connector (B).

| A | | | B | | | Continuity |
|-----------|----------|----|--------------|----------|---|------------|
| Connector | Terminal | | Connector | Terminal | | |
| LH | E124 | 57 | With DTRL | E6 | 6 | Yes |
| RH | | | | E108 | | |
| LH | E124 | 57 | Without DTRL | E11 | | |
| RH | | | | E107 | | |




ALLIA0396ZZ

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


4. Check continuity between the IPDM E/R harness connector (A) and the rear combination lamp harness connector (B).

| A | | | B | | Continuity |
|-----------|----------|-----------|----------|---|------------|
| Connector | Terminal | Connector | Terminal | | |
| LH | E124 | 57 | B70 | 2 | Yes |
| RH | | | B130 | | |



5. Check continuity between the IPDM E/R harness connector (A) and license plate lamp connector (B).

| A | | B | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E124 | 57 | C106 | 1 | Yes |
| | | C107 | | |



Are continuity test results as specified?


YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

4. CHECK PARKING, LICENSE AND TAIL LAMP GROUND CIRCUITS


1. Check continuity between the front combination lamp harness connectors E11 and E107 terminal 4 and ground.

| Connector | | | Terminal | — | Continuity |
|--------------|----|------|----------|--------|------------|
| With DTRL | LH | E6 | 4 | Ground | Yes |
| | RH | E108 | | | |
| Without DTRL | LH | E11 | | | |
| | RH | E107 | | | |



2. Check continuity between the rear combination lamp harness connectors B70 and B130 terminal 3 and ground.

| Connector | | Terminal | — | Continuity |
|-----------|------|----------|--------|------------|
| LH | B70 | 3 | Ground | Yes |
| RH | B130 | | | |



PARKING LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between the license plate lamp harness connectors and ground.

| Connector | Terminal | — | Continuity |
|-----------|----------|--------|------------|
| C106 | 2 | Ground | Yes |
| C107 | | | |

Does continuity exist?

- YES >> Inspect the parking lamp bulb.
NO >> Repair the harness.



TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:000000009822305

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:000000009822306

1.CHECK TURN SIGNAL LAMP

④ WITH CONSULT

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

- LH** : Turn signal lamp LH blinking
- RH** : Turn signal lamp RH blinking
- Off** : The turn signal lamp OFF

Does the turn signal lamp blink?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-47, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822307

Regarding Wiring Diagram information, refer to [EXL-92, "Wiring Diagram"](#).

1.CHECK TURN SIGNAL LAMP BULB


Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

Is the bulb OK?

- YES >> GO TO 2.
- NO >> Replace the bulb.

2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

While operating the turn signal switch, check the voltage between the BCM harness connector M20 and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|---|
| Connector | Terminal | | |
| M20 | LH 60 | Ground |  |
| | RH 61 | | |

PKID0926E

Is voltage reading as specified?

- YES >> GO TO 3.
- NO >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN


1. Turn the ignition switch OFF.
2. Disconnect BCM connector M20, front combination lamp connector, door mirror connector (if equipped with turn signal in the mirrors) and the rear combination lamp connector.
3. Check continuity between the BCM harness connector (A) and the front combination lamp connector (B).

| A | | B | | Continuity |
|-----------|----------|-----------|---------------------|------------|
| Connector | Terminal | Connector | Terminal | |
| Front LH | M20 | 60 | Without DTRL E11 | 5 Yes |
| Front RH | | 61 | E107 | |
| Front LH | | 60 | With DTRL E6 | |
| Front RH | | 61 | E108 | |




4. Check continuity between the BCM harness connector (A) and the rear combination lamp connector (B).

| A | | B | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| Rear LH | M20 | 60 | B35 | 4 Yes |
| Rear RH | | 61 | B105 | |



5. Check continuity between the BCM harness connector (A) and the door mirror connector (B) (if equipped with turn signals in the mirrors).

| A | | B | | Continuity |
|----------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| Door mirror LH | M20 | 60 | D4 | 15 Yes |
| Door mirror RH | | 61 | D107 | |



Are continuity test results as specified?

- YES >> GO TO 4.
NO >> Repair the harnesses or connectors.


4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector M20 and ground.

| Connector | Terminal | — | Continuity |
|-----------|----------|----|--------------|
| LH | M20 | 60 | Ground No |
| RH | | 61 | |

Does continuity exist?

- YES >> Repair the harnesses or connectors.
NO >> GO TO 5.




TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. CHECK TURN SIGNAL LAMP GROUND CIRCUIT


1. Check continuity between the front combination lamp harness connector and ground.

| Connector | | | Terminal | — | Continuity |
|--------------|----------|------|----------|--------|------------|
| Without DTRL | Front LH | E11 | 4 | Ground | Yes |
| | Front RH | E107 | | | |
| With DTRL | Front LH | E6 | | | |
| | Front RH | E108 | | | |




2. Check continuity between the rear combination lamp harness connector and ground.

| Connector | | Terminal | — | Continuity |
|-----------|------|----------|--------|------------|
| Rear LH | B35 | 6 | Ground | Yes |
| Rear RH | B105 | | | |



3. Check continuity between the door mirrors and ground (if equipped with turn signals in the mirrors).

| Connector | | Terminal | — | Continuity |
|----------------|------|----------|--------|------------|
| Door mirror RH | D107 | 11 | Ground | Yes |
| Door mirror LH | D4 | | | |



Are continuity test results as specified?

- YES >> Replace the malfunctioning lamp.
 NO >> Repair the harnesses or connectors.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

OPTICAL SENSOR

Description

INFOID:000000009822308

The optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to the BCM.

Component Function Check

INFOID:000000009822309

1. CHECK OPTICAL SENSOR SIGNAL BY CONSULT

Ⓜ WITH CONSULT

1. Turn the ignition switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEAD LAMP) DATA MONITOR item.
3. Turn the lighting switch to AUTO.
4. With the optical sensor illuminating, check the monitor status.

| Monitor item | Condition | Voltage |
|----------------|-------------------------|----------------|
| OPTICAL SENSOR | When illuminating | 3.1V or more * |
| | When shutting off light | 0.6V or less |

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the item status normal?

- YES >> Optical sensor is normal.
NO >> Refer to [EXL-50. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009822310

Regarding Wiring Diagram information, refer to [EXL-80. "Wiring Diagram"](#).

1. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector M18 and optical sensor connector M302.
3. Check continuity between BCM harness connector M18 (A) terminal 18 and optical sensor harness connector M302 (B) terminal 3.

| A | | B | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M18 | 18 | M302 | 3 | Yes |


4. Check continuity between BCM harness connector M18 (A) terminal 18 and ground.

| A | | — | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M18 | 18 | Ground | No |

Are continuity test results as specified?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK OPTICAL SENSOR SIGNAL CIRCUIT



OPTICAL SENSOR


< DTC/CIRCUIT DIAGNOSIS >

1. Check continuity between BCM harness connector M20 (A) terminal 58 and optical sensor harness connector M302 (B) terminal 4.

| A | | B | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M20 | 58 | M302 | 4 | Yes |

2. Check continuity between BCM harness connector M20 (A) terminal 58 and ground.

| A | | — | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M20 | 58 | Ground | No |



Are the continuity test results as specified?

- YES >> Replace the optical sensor. Refer to [EXL-136, "Removal and Installation"](#).
 NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000009822311

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|---------------|--|-------------------------------|
| ACC ON SW | Ignition switch OFF or ON | Off |
| | Ignition switch ACC | On |
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AIR PRESS FL | Front left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS FR | Front right tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RL | Rear left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RR | Rear right tire air pressure value | kPa, kg/cm ² , psi |
| AUTO LIGHT SW | Lighting switch OFF | Off |
| | Lighting switch AUTO | On |
| BACK DOOR SW | Back door closed | Off |
| | Back door opened | On |
| BRAKE SW | Brake pedal released | Off |
| | Brake pedal applied | On |
| BUCKLE SW | Seat belt buckle unfastened | Off |
| | Seat belt buckle fastened | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CARGO LAMP SW | Cargo lamp switch OFF | Off |
| | Cargo lamp switch ON | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the LOCK side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the UNLOCK side | On |
| DOOR SW-AS | Front door RH closed | Off |
| | Front door RH opened | On |
| DOOR SW-DR | Front door LH closed | Off |
| | Front door LH opened | On |
| DOOR SW-RL | Rear door LH closed | Off |
| | Rear door LH opened | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------------------|--|--------------|-----|
| DOOR SW-RR | Rear door RH closed | Off | A |
| | Rear door RH opened | On | |
| FAN ON SIG | Blower motor fan switch OFF | Off | B |
| | Blower motor fan switch ON | On | |
| FR FOG SW | Front fog lamp switch OFF | Off | C |
| | Front fog lamp switch ON | On | |
| FR WASHER SW | Front washer switch OFF | Off | |
| | Front washer switch ON | On | D |
| FR WIPER LOW | Front wiper switch OFF | Off | |
| | Front wiper switch LO | On | |
| FR WIPER HI | Front wiper switch OFF | Off | E |
| | Front wiper switch HI | On | |
| FR WIPER INT | Front wiper switch OFF | Off | F |
| | Front wiper switch INT | On | |
| FR WIPER STOP | Any position other than front wiper stop position | Off | |
| | Front wiper stop position | On | G |
| HAZARD SW | When hazard switch is not pressed | Off | |
| | When hazard switch is pressed | On | |
| HEAD LAMP SW1 | Headlamp switch OFF | Off | H |
| | Headlamp switch 1st | On | |
| HEAD LAMP SW2 | Headlamp switch OFF | Off | I |
| | Headlamp switch 1st | On | |
| HI BEAM SW | High beam switch OFF | Off | J |
| | High beam switch HI | On | |
| ID REGST FL1 | ID registration of front left tire incomplete | YET | |
| | ID registration of front left tire complete | DONE | K |
| ID REGST FR1 | ID registration of front right tire incomplete | YET | |
| | ID registration of front right tire complete | DONE | |
| ID REGST RL1 | ID registration of rear left tire incomplete | YET | EXL |
| | ID registration of rear left tire complete | DONE | |
| ID REGST RR1 | ID registration of rear right tire incomplete | YET | |
| | ID registration of rear right tire complete | DONE | M |
| IGN ON SW | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | N |
| IGN SW CAN | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | 1 - 7 | O |
| I-KEY LOCK ¹ | LOCK button of Intelligent Key is not pressed | Off | |
| | LOCK button of Intelligent Key is pressed | On | P |
| I-KEY PANIC ¹ | PANIC button of Intelligent Key is not pressed | Off | |
| | PANIC button of Intelligent Key is pressed | On | |
| I-KEY PW DWN ¹ | UNLOCK button of Intelligent Key is not pressed | Off | |
| | UNLOCK button of Intelligent Key is pressed for greater than 3 seconds and driver's window operating in DOWN direction | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|-----------------------------|--|-----------------------------------|
| I-KEY UNLOCK ¹ | UNLOCK button of Intelligent Key is not pressed | Off |
| | UNLOCK button of Intelligent Key is pressed | On |
| KEY CYL LK-SW | Door key cylinder LOCK position | Off |
| | Door key cylinder other than LOCK position | On |
| KEY CYL UN-SW | Door key cylinder UNLOCK position | Off |
| | Door key cylinder other than UNLOCK position | On |
| KEY ON SW | Mechanical key is removed from key cylinder | Off |
| | Mechanical key is inserted to key cylinder | On |
| KEYLESS LOCK ² | LOCK button of key fob is not pressed | Off |
| | LOCK button of key fob is pressed | On |
| KEYLESS PANIC ² | PANIC button of key fob is not pressed | Off |
| | PANIC button of key fob is pressed | On |
| KEYLESS UNLOCK ² | UNLOCK button of key fob is not pressed | Off |
| | UNLOCK button of key fob is pressed | On |
| LIGHT SW 1ST | Lighting switch OFF | Off |
| | Lighting switch 1st | On |
| OIL PRESS SW | <ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running | Off |
| | Ignition switch ON | On |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5V |
| | Dark outside of the vehicle | Close to 0V |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| PUSH SW ¹ | Return to ignition switch to LOCK position | Off |
| | Press ignition switch | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER INT | Rear wiper switch OFF | Off |
| | Rear wiper switch INT | On |
| RR WIPER ON | Rear wiper switch OFF | Off |
| | Rear wiper switch ON | On |
| RR WIPER STOP | Rear wiper stop position | Off |
| | Other than rear wiper stop position | On |
| RR WIPER STP2 | Rear wiper stop position | Off |
| | Other than rear wiper stop position | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| VEHICLE SPEED | While driving | Equivalent to speedometer reading |
| WARNING LAMP | Low tire pressure warning lamp in combination meter OFF | Off |
| | Low tire pressure warning lamp in combination meter ON | On |

1: With Intelligent Key


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

2: With remote keyless entry system

Terminal Layout

INFOID:000000009822312



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P





Physical Values

LIIA2443E

INFOID:000000009822313

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 1 | BR/W | Ignition keyhole illumination | Output | OFF | Door is locked (SW OFF) | Battery voltage |
| | | | | | Door is unlocked (SW ON) | 0V |
| 2 | SB | Combination switch input 5 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 3 | G/Y | Combination switch input 4 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 4 | Y | Combination switch input 3 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 5 | G/B | Combination switch input 2 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 6 | V | Combination switch input 1 | | | | |
| 9 | R/G | Stop lamp switch | Input | OFF | Brake pedal depressed | Battery voltage |
| | | | | | Brake pedal released | 0V |
| 10 | G | Hazard lamp flash | Input | OFF | ON (opening or closing) | 0V |
| | | | | | OFF (other than above) | Battery voltage |
| 11 | O | Ignition switch (ACC or ON) | Input | ACC or ON | Ignition switch ACC or ON | Battery voltage |
| 12 | R/L | Front door switch RH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 13 | GR | Rear door switch RH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 15 | L/W | Tire pressure warning check connector | Input | OFF | — | 5V |
| 18 | P | Remote keyless entry receiver and optical sensor (ground) | Output | OFF | — | 0V |

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|--|---------------------|---------------------|---|--|
| | | | | Ignition switch | Operation or condition | |
| 19 | V/W | Remote keyless entry receiver (power supply) | Output | OFF | Ignition switch OFF | <p style="text-align: right;">LIIA1893E</p> |
| 20 | G/W | Remote keyless entry receiver (signal) | Input | OFF | Stand-by (keyfob buttons released) | <p style="text-align: right;">LIIA1894E</p> |
| | | | | | When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed) | <p style="text-align: right;">LIIA1895E</p> |
| 21 | G | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 22 | W/V | BUS | — | — | Ignition switch ON or power window timer operates | <p style="text-align: right;">PIIA2344E</p> |
| 23 | G/O | Security indicator lamp | Output | OFF | Goes OFF → illuminates (Every 2.4 seconds) | Battery voltage → 0V |
| 25 | BR | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 26 | Y/L | Rear wiper auto stop switch 2 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | 0V |
| | | | | | Forward sweep (counterclockwise direction) | Fluctuating |
| | | | | | B Position (full counterclockwise stop position) | Battery voltage |
| | | | | | Reverse sweep (clockwise direction) | Fluctuating |
| 27 | W/R | Compressor ON signal | Input | ON | A/C switch OFF | 5V |
| | | | | | A/C switch ON | 0V |

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|-----------------|------------|-------------------------------------|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 28 | L/R | Front blower monitor | Input | ON | Front blower motor OFF | Battery voltage |
| | | | | | Front blower motor ON | 0V |
| 29 | W/B | Hazard switch | Input | OFF | ON | 0V |
| | | | | | OFF | 5V |
| 32 | R/G | Combination switch output 5 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 33 | R/Y | Combination switch output 4 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 34 | L | Combination switch output 3 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 35 | O/B | Combination switch output 2 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 36 | R/W | Combination switch output 1 | | | | |
| 37 ¹ | B/R | Key switch and ignition knob switch | Input | OFF | Intelligent Key inserted | Battery voltage |
| | | | | | Intelligent Key removed | 0V |
| 37 ² | B/R | Key switch and key lock solenoid | Input | OFF | Key inserted | Battery voltage |
| | | | | | Key removed | 0V |
| 38 | W/L | Ignition switch (ON) | Input | ON | — | Battery voltage |
| 39 | L | CAN-H | — | — | — | — |
| 40 | P | CAN-L | — | — | — | — |
| 41 | GR/R | Rear window defogger switch | Input | ON | Rear window defogger switch ON | 0V |
| | | | | | Rear window defogger switch OFF | 5V |
| 42 | GR | Glass hatch ajar switch | Input | ON | Glass hatch open | 0 |
| | | | | | Glass hatch closed | Battery |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 43 | R/B | Back door switch (without power back door) or back door latch (door ajar switch) (with power back door) | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 44 | O | Rear wiper auto stop switch 1 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | Battery voltage |
| | | | | | Forward sweep (counterclockwise direction) | Fluctuating |
| | | | | | B Position (full counterclockwise stop position) | 0V |
| | | | | | Reverse sweep (clockwise direction) | Fluctuating |
| 47 | SB | Front door switch LH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 48 | R/Y | Rear door switch LH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 49 | R | Cargo lamp | Output | OFF | Any door open (ON) | 0V |
| | | | | | All doors closed (OFF) | Battery voltage |
| 51 | Y/B | Trailer turn signal (right) | Output | ON | Turn right ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 52 | G/B | Trailer turn signal (left) | Output | ON | Turn left ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 54 | Y | Rear wiper output circuit 2 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | 0V |
| | | | | | Forward sweep (counterclockwise direction) | 0V |
| | | | | | B Position (full counterclockwise stop position) | Battery voltage |
| | | | | | Reverse sweep (clockwise direction) | Battery voltage |
| 55 | SB | Rear wiper output circuit 1 | Output | ON | OFF | 0 |
| | | | | | ON | Battery voltage |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|--|---------------------|---------------------|---|--|
| | | | | Ignition switch | Operation or condition | |
| 56 | R/G | Battery saver output | Output | OFF | 10 minutes after ignition switch is turned OFF | 0V |
| | | | | ON | — | Battery voltage |
| 57 | Y/R | Battery power supply | Input | OFF | — | Battery voltage |
| 58 | W/R | Optical sensor | Input | ON | When optical sensor is illuminated | 3.1V or more |
| | | | | | When optical sensor is not illuminated | 0.6V or less |
| 59 | G | Front door lock assembly LH actuator (unlock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (unlock) | Battery voltage |
| 60 | G/B | Turn signal (left) | Output | ON | Turn left ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 61 | G/Y | Turn signal (right) | Output | ON | Turn right ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 62 | R/W | Step lamp LH and RH | Output | OFF | ON (any door open) | 0V |
| | | | | | OFF (all doors closed) | Battery voltage |
| 63 | L | Interior room/map lamp | Output | OFF | Any door switch | ON (open) 0V OFF (closed) Battery voltage |
| | | | | | | |
| 65 | V | All door lock actuators (lock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (lock) | Battery voltage |
| 66 | G/Y | Front door lock actuator RH, rear door lock actuators LH/RH and back door lock actuator (unlock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (unlock) | Battery voltage |
| 67 | B | Ground | Input | ON | — | 0V |
| 68 | W/L | Power window power supply (RAP) | Output | — | Ignition switch ON | Battery voltage |
| | | | | | Within 45 seconds after ignition switch OFF | Battery voltage |
| | | | | | More than 45 seconds after ignition switch OFF | 0V |
| | | | | | When front door LH or RH is open or power window timer operates | 0V |
| 69 | W/R | Power window power supply | Output | — | — | Battery voltage |
| 70 | W/B | Battery power supply | Input | OFF | — | Battery voltage |

1: With Intelligent Key system

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

2: With remote keyless entry system

Fail Safe

INFOID:000000009822314

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|---|
| U1000: CAN COMM CIRCUIT | Inhibit engine cranking | When the BCM re-establishes communication with the other modules. |

DTC Inspection Priority Chart

INFOID:000000009822315

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|--|
| 1 | <ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT |
| 2 | <ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM B2013: STRG COMM 1 B2552: INTELLIGENT KEY B2590: NATS MALFUNCTION |
| 3 | <ul style="list-style-type: none"> C1729: VHCL SPEED SIG ERR C1735: IGNITION SIGNAL |
| 4 | <ul style="list-style-type: none"> C1708: [NO DATA] FL C1709: [NO DATA] FR C1710: [NO DATA] RR C1711: [NO DATA] RL C1712: [CHECKSUM ERR] FL C1713: [CHECKSUM ERR] FR C1714: [CHECKSUM ERR] RR C1715: [CHECKSUM ERR] RL C1716: [PRESSDATA ERR] FL C1717: [PRESSDATA ERR] FR C1718: [PRESSDATA ERR] RR C1719: [PRESSDATA ERR] RL C1720: [CODE ERR] FL C1721: [CODE ERR] FR C1722: [CODE ERR] RR C1723: [CODE ERR] RL C1724: [BATT VOLT LOW] FL C1725: [BATT VOLT LOW] FR C1726: [BATT VOLT LOW] RR C1727: [BATT VOLT LOW] RL |

DTC Index

INFOID:000000009822316

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|--|-----------|------------------------------------|---|---|
| No DTC is detected. further testing may be required. | — | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | — | BCS-29 |
| B2013: STRG COMM 1 | — | — | — | SEC-30 |
| B2190: NATS ANTENNA AMP | — | — | — | SEC-33 (with I- Key), SEC-140 (without I-Key) |
| B2191: DIFFERENCE OF KEY | — | — | — | SEC-36 (with I- Key), SEC-143 (without I-Key) |
| B2192: ID DISCORD BCM-ECM | — | — | — | SEC-37 (with I- Key), SEC-144 (without I-Key) |
| B2193: CHAIN OF BCM-ECM | — | — | — | SEC-39 (with I- Key), SEC-146 (without I-Key) |
| B2552: INTELLIGENT KEY | — | — | — | SEC-41 |
| B2590: NATS MALFUNCTION | — | — | — | SEC-42 |
| C1708: [NO DATA] FL | — | — | — | WT-13 |
| C1709: [NO DATA] FR | — | — | — | WT-15 |
| C1710: [NO DATA] RR | — | — | — | WT-15 |
| C1711: [NO DATA] RL | — | — | — | WT-15 |
| C1712: [CHECKSUM ERR] FL | — | — | — | WT-15 |
| C1713: [CHECKSUM ERR] FR | — | — | — | WT-15 |
| C1714: [CHECKSUM ERR] RR | — | — | — | WT-15 |
| C1715: [CHECKSUM ERR] RL | — | — | — | WT-15 |
| C1716: [PRESSDATA ERR] FL | — | — | — | WT-17 |
| C1717: [PRESSDATA ERR] FR | — | — | — | WT-15 |
| C1718: [PRESSDATA ERR] RR | — | — | — | WT-15 |
| C1719: [PRESSDATA ERR] RL | — | — | — | WT-15 |
| C1720: [CODE ERR] FL | — | — | — | WT-15 |
| C1721: [CODE ERR] FR | — | — | — | WT-15 |
| C1722: [CODE ERR] RR | — | — | — | WT-15 |
| C1723: [CODE ERR] RL | — | — | — | WT-15 |
| C1724: [BATT VOLT LOW] FL | — | — | — | WT-15 |
| C1725: [BATT VOLT LOW] FR | — | — | — | WT-15 |
| C1726: [BATT VOLT LOW] RR | — | — | — | WT-15 |
| C1727: [BATT VOLT LOW] RL | — | — | — | WT-15 |
| C1729: VHCL SPEED SIG ERR | — | — | — | WT-19 |
| C1735: IGN_CIRCUIT_OPEN | — | — | — | WT-20 |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000009822317

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | | Value/Status |
|---------------|--|---|--------------|
| MOTOR FAN REQ | Engine idle speed | Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc. | 1, 2, 3, 4 |
| A/C COMP REQ | A/C switch OFF | | Off |
| | A/C switch ON | | On |
| TAIL&CLR REQ | Lighting switch OFF | | Off |
| | Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated) | | On |
| HL LO REQ | Lighting switch OFF | | Off |
| | Lighting switch 2ND HI or AUTO (Light is illuminated) | | On |
| HL HI REQ | Lighting switch OFF | | Off |
| | Lighting switch HI | | On |
| FR FOG REQ | Lighting switch 2ND or AUTO (Light is illuminated) | Front fog lamp switch OFF | Off |
| | | <ul style="list-style-type: none"> Front fog lamp switch ON Daytime light activated (Canada only) | On |
| FR WIP REQ | Ignition switch ON | Front wiper switch OFF | Stop |
| | | Front wiper switch INT | 1LOW |
| | | Front wiper switch LO | Low |
| | | Front wiper switch HI | Hi |
| WIP AUTO STOP | Ignition switch ON | Front wiper stop position | STOP P |
| | | Any position other than front wiper stop position | ACT P |
| WIP PROT | Ignition switch ON | Front wiper operates normally | Off |
| | | Front wiper stops at fail-safe operation | BLOCK |
| ST RLY REQ | Ignition switch OFF or ACC | | Off |
| | Ignition switch START | | On |
| IGN RLY | Ignition switch OFF or ACC | | Off |
| | Ignition switch ON | | On |
| RR DEF REQ | Rear defogger switch OFF | | Off |
| | Rear defogger switch ON | | On |
| OIL P SW | Ignition switch OFF, ACC or engine running | | Open |
| | Ignition switch ON | | Close |
| DTRL REQ | Not operated | | Off |
| | Daytime Running Lights ON | | On |
| THFT HRN REQ | Not operated | | Off |
| | <ul style="list-style-type: none"> Panic alarm is activated Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM | | On |


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|--------------|---|--------------|
| HORN CHIRP | Not operated | Off |
| | Door locking with keyfob or Intelligent Key (if equipped) (horn chirp mode) | On |

Terminal Layout

INFOID:000000009822318



NOTE:

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

AAMIA0386GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Physical Values




INFOID:00000009822319

PHYSICAL VALUES

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value (Approx.) |
|----------|------------|------------------------------------|---------------------|---------------------|--------------------------------------|---------------------------|
| | | | | Ignition switch | Operation or condition | |
| 1 | B/Y | Battery power supply | Input | OFF | — | Battery voltage |
| 2 | R | Battery power supply | Input | OFF | — | Battery voltage |
| 3 | BR | ECM relay | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 4 | W/L | ECM relay | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 6 | L | Throttle control motor relay | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 7 | W/B | ECM relay control | Input | — | Ignition switch ON or START | 0V |
| | | | | | Ignition switch OFF or ACC | Battery voltage |
| 8 | R/B | Fuse 54 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 10 | G | Fuse 45 (Canada only) | Output | ON | Daytime light system active | 0V |
| | | | | | Daytime light system inactive | Battery voltage |
| 11 | Y/B | A/C compressor | Output | ON or START | A/C switch ON or defrost A/C switch | Battery voltage |
| | | | | | A/C switch OFF or defrost A/C switch | 0V |
| 12 | L/W | Ignition switch supplied power | Input | — | OFF or ACC | 0V |
| | | | | | ON or START | Battery voltage |
| 13 | B/Y | Fuel pump relay | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 14 | Y/R | Fuse 49 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 15 | LG/B | Fuse 50 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 16 | G | Fuse 51 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 17 | W | Fuse 55 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 19 | W/R | Starter motor | Output | START | — | Battery voltage |
| 21 | BR | Ignition switch supplied power | Input | — | OFF or ACC | 0V |
| | | | | | START | Battery voltage |
| 22 | G | Battery power supply | Output | OFF | — | Battery voltage |
| 23 | GR/W | Door mirror defogger output signal | Output | — | When rear defogger switch is ON | Battery voltage |
| | | | | | When rear defogger switch is OFF | 0V |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value (Approx.) |
|----------|------------|---|---------------------|---------------------|--|--|
| | | | | Ignition switch | Operation or condition | |
| 24 | L | Cooling fan relay | Output | — | Conditions correct for cooling fan operation | Battery voltage |
| | | | | | Conditions not correct for cooling fan operation | 0V |
| 27 | W/B | Fuse 38 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 30 | W | Fuse 53 | Output | — | Ignition switch ON or START | Battery voltage |
| | | | | | Ignition switch OFF or ACC | 0V |
| 32 | L | Wiper low speed signal | Output | ON or START | Wiper switch OFF | 0V |
| | | | | | Wiper switch LO or INT | Battery voltage |
| 35 | L/B | Wiper high speed signal | Output | ON or START | Wiper switch OFF, LO, INT | 0V |
| | | | | | Wiper switch HI | Battery voltage |
| 37 | Y | Power generation command signal | Output | — | Ignition switch ON |  <p style="text-align: right;">JPMIA0001GB</p> <p style="text-align: center;">6.3 V</p> |
| | | | | | 40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE" |  <p style="text-align: right;">JPMIA0002GB</p> <p style="text-align: center;">3.8 V</p> |
| | | | | | 40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE" |  <p style="text-align: right;">JPMIA0003GB</p> <p style="text-align: center;">1.4 V</p> |
| 38 | B | Ground | Input | — | — | 0V |
| 39 | L | CAN-H | — | ON | — | — |
| 40 | P | CAN-L | — | ON | — | — |
| 42 | GR | Oil pressure switch | Input | — | Engine running | Battery voltage |
| | | | | | Engine stopped | 0V |
| 43 | L/Y | Wiper auto stop signal | Input | ON or START | Wiper switch OFF, LO, INT | Battery voltage |
| 44 | BR | Daytime light relay control (Canada only) | Input | ON | Daytime light system active | 0V |
| | | | | | Daytime light system inactive | Battery voltage |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value (Approx.) | |
|----------|--------------------|--------------------------------------|---------------------|---------------------|--|---------------------------|-----------------|
| | | | | Ignition switch | Operation or condition | | |
| 45 | G/W | Horn relay control | Input | ON | When door locks are operated using keyfob or Intelligent Key (if equipped) (OFF → ON)* | Battery voltage → 0V | |
| 46 | GR | Fuel pump relay control | Input | — | Ignition switch ON or START | 0V | |
| | | | | | Ignition switch OFF or ACC | Battery voltage | |
| 47 | O | Throttle control motor relay control | Input | — | Ignition switch ON or START | 0V | |
| | | | | | Ignition switch OFF or ACC | Battery voltage | |
| 48 | B/R | Starter relay (inhibit switch) | Input | ON or START | Selector lever in "P" or "N" | 0V | |
| | | | | | Selector lever any other position | Battery voltage | |
| 49 | R/L | Trailer tow relay illumination | Output | ON | Lighting switch must be in the 1st position | OFF | 0V |
| | | | | | | ON | Battery voltage |
| 50 | W/R | Front fog lamp (LH) | Output | ON or START | Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch | OFF | 0V |
| | | | | | | ON | Battery voltage |
| 51 | W/R | Front fog lamp (RH) | Output | ON or START | Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch | OFF | 0V |
| | | | | | | ON | Battery voltage |
| 52 | L | LH low beam head-lamp | Output | — | Lighting switch in 2nd position | Battery voltage | |
| 54 | R/Y | RH low beam head-lamp | Output | — | Lighting switch in 2nd position | Battery voltage | |
| 55 | G | LH high beam head-lamp | Output | — | Lighting switch in 2nd position and placed in HIGH or PASS position | Battery voltage | |
| 56 | Y (With DTRL) | RH high beam head-lamp | Output | — | Lighting switch in 2nd position and placed in HIGH or PASS position | Battery voltage | |
| 56 | L/W (Without DTRL) | RH high beam head-lamp | Output | — | Lighting switch in 2nd position and placed in HIGH or PASS position | Battery voltage | |
| 57 | R/L | Parking, license, and tail lamp | Output | ON | Lighting switch 1st position | OFF | 0V |
| | | | | | | ON | Battery voltage |
| 59 | B | Ground | Input | — | — | 0V | |
| 60 | B | Rear window defogger relay | Output | ON or START | Rear defogger switch ON | Battery voltage | |
| | | | | | Rear defogger switch OFF | 0V | |
| 61 | BR | Fuse 32 | Output | OFF | — | Battery voltage | |

*: When horn reminder is ON

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Fail Safe

INFOID:000000009822320

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

| Control part | Fail-safe in operation |
|--------------|---|
| Cooling fan | <ul style="list-style-type: none">• Turns ON the cooling fan relay when the ignition switch is turned ON• Turns OFF the cooling fan relay when the ignition switch is turned OFF |

If No CAN Communication Is Available With BCM

| Control part | Fail-safe in operation |
|--|---|
| Headlamp | <ul style="list-style-type: none">• Turns ON the headlamp low relay when the ignition switch is turned ON• Turns OFF the headlamp low relay when the ignition switch is turned OFF• Headlamp high relay OFF |
| <ul style="list-style-type: none">• Parking lamps• License plate lamps• Tail lamps | <ul style="list-style-type: none">• Turns ON the tail lamp relay when the ignition switch is turned ON• Turns OFF the tail lamp relay when the ignition switch is turned OFF |
| Front wiper | <ul style="list-style-type: none">• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating. |
| Rear window defogger | Rear window defogger relay OFF |
| A/C compressor | A/C relay OFF |
| Front fog lamps (if equipped) | Front fog lamp relay OFF |

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

| Ignition switch | Ignition relay | Tail lamp relay |
|-----------------|----------------|-----------------|
| ON | ON | — |
| OFF | OFF | — |

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

| Ignition switch | Front wiper switch | Auto stop signal |
|-----------------|--------------------|--|
| ON | OFF | Front wiper stop position signal cannot be input 10 seconds. |
| | ON | The signal does not change for 10 seconds. |

NOTE:

This operation status can be confirmed on the IPDM E/R "DATA MONITOR" that displays "Block" for the item "WIP PROT" while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:00000000982321

| CONSULT display | Fail-safe | TIME ^{NOTE} | | Refer to |
|--|-----------|----------------------|--------|------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — |
| U1000: CAN COMM CIRCUIT | × | CRNT | 1 – 39 | PCS-16 |

NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ··· 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP


< WIRING DIAGRAM >

WIRING DIAGRAM

HEADLAMP

Wiring Diagram

INFOID:000000009822322



ABLWA1910GB

HEADLAMP

< WIRING DIAGRAM >


HEADLAMP CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5P | O/L | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | ACCESSORY |
| 9 | B | GND |
| 11 | L | CAN-H |
| 12 | P | CAN-L |
| 24 | O/L | RUN/START |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |


ABLIA4173GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP

< WIRING DIAGRAM >


| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6T | O | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | W/L | - |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|--|
| Connector No. | E11 |
| Connector Name | FRONT COMBINATION LAMP LH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | G | - |
| 3 | B | - |
| 4 | B | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 4 | L | - |
| 10 | P | - |
| 11 | P | - |
| 13 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

ABLIA4127GB

HEADLAMP


< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E107 |
| Connector Name | FRONT COMBINATION LAMP RH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/Y | - |
| 2 | L/W | - |
| 3 | B | - |
| 4 | B | - |

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|--|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 52 | L | H/LAMP LO LH |
| 54 | R/Y | H/LAMP LO RH |
| 55 | G | H/LAMP HI LH |
| 56 | L/W | H/LAMP HI RH (WITHOUT DAYTIME LIGHT SYSTEM) |

| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 59 | B | GND (POWER) |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | L/W | - |

ABLIA4128GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL


DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

DAYTIME LIGHT SYSTEM

Wiring Diagram


INFOID:00000009822323



ABLWA1907GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >



ABLWA1908GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

DAYTIME LIGHT SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|----|
| 7P | 6P | 5P | 4P | 3P | 2P | 1P | |
| 16P | 15P | 14P | 13P | 12P | 11P | 10P | 9P |



| |
|---|
| 1 |
|---|

| | |
|-----------------|----------------------|
| Connector No. | M11 |
| Connector Name | PARKING BRAKE SWITCH |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5P | O/L | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

| Connector No. | M28 |
|-----------------|--------------------|
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |




| Connector No. | M24 |
|-----------------|-------------------|
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | ACCESSORY |
| 9 | B | GND |
| 11 | L | CAN-H |
| 12 | P | CAN-L |
| 23 | G | PARK BRAKE |
| 24 | O/L | RUN/START |

| Connector No. | M60 |
|-----------------|------------------|
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | W/L | - |

| Connector No. | M31 |
|-----------------|--------------|
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



ABLIA4121GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|---|
| Connector No. | E6 |
| Connector Name | FRONT COMBINATION LAMP LH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | G | - |
| 3 | Y/G | - |
| 4 | B | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 4 | L | - |
| 10 | P | - |
| 11 | P | - |
| 13 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 10 | G | DTRL RLY SUPPLY |

| | |
|-----------------|---|
| Connector No. | E108 |
| Connector Name | FRONT COMBINATION LAMP RH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/Y | - |
| 2 | Y | - |
| 3 | B | - |
| 4 | B | - |

| | |
|-----------------|---------------------|
| Connector No. | E103 |
| Connector Name | DAYTIME LIGHT RELAY |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | G | - |
| 3 | Y/G | - |
| 4 | B | - |
| 5 | G | - |

ABLIA4122GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| | | |
|----|----|----|
| 58 | 59 | 57 |
| 62 | 61 | 60 |

| | | | | | |
|--------------|----|---------------|---|-------------|-------------|
| Terminal No. | 59 | Color of Wire | B | Signal Name | GND (POWER) |
|--------------|----|---------------|---|-------------|-------------|

| | |
|-----------------|--|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| | | |
|----|----|----------|
| 51 | 50 | 49 |
| 56 | 55 | 54 53 52 |

| | | | | | |
|--------------|-----|--|---|-------------|--------------|
| Terminal No. | 52 | Color of Wire | L | Signal Name | H/LAMP LO LH |
| 54 | R/Y | H/LAMP LO RH | | | |
| 55 | G | H/LAMP HI LH | | | |
| 56 | Y | H/LAMP HI RH (WITH DAYTIME LIGHT SYSTEM) | | | |

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |




| | | | | | |
|----|----|----|----|----|----|
| 42 | 41 | 40 | 39 | 38 | 37 |
| 48 | 47 | 46 | 45 | 44 | 43 |

| | | | | | |
|--------------|----|---------------|---|-------------|--------------|
| Terminal No. | 38 | Color of Wire | B | Signal Name | GND (SIGNAL) |
| 39 | L | CAN-H | | | |
| 40 | P | CAN-L | | | |
| 44 | BR | DTRL RLY CONT | | | |

| | | | | | |
|--------------|-----|---------------|---|-------------|---|
| Terminal No. | 31G | Color of Wire | L | Signal Name | - |
| 32G | P | - | | | |
| 96G | W/B | - | | | |
| 99G | L/W | - | | | |

| | |
|-----------------|---------------|
| Connector No. | E152 |
| Connector Name | WIRES TO WIRE |
| Connector Color | WHITE |



ABLIA4123GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM

Wiring Diagram

INFOID:00000009822324



ABLWA1905GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM CONNECTORS

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 12 | R/L | DOOR SW (AS) |
| 13 | GR | DOOR SW (RR) |
| 18 | P | KEYLESS AND AUTO LIGHT SENSOR GND |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| 50 | 51 | 52 | 53 | 54 | 55 | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 43 | R/B | BACK DOOR SW |
| 47 | SB | DOOR SW (DR) |
| 48 | R/Y | DOOR SW (RL) |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------|
| 58 | W/R | AUTO LIGHT SENSOR INPUT 2 |
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| | | | | | | | |
|----|----|----|---|---|---|---|---|
| 12 | 13 | 10 | 9 | 8 | 7 | | |
| 14 | 11 | 1 | 2 | 3 | 4 | 5 | 6 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

ABLIA4172GB


A B C D E F G H I J K L M N O P

EXL

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | W/L | - |

| | |
|-----------------|--------------|
| Connector No. | M65 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | W/R | - |
| 4 | P | - |

| | |
|-----------------|--------------|
| Connector No. | M36 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 15A | R/B | - |
| 21A | R/L | - |
| 26A | GR | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |



| | |
|-----------------|--------------|
| Connector No. | M40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 21J | R/Y | - |
| 30J | SB | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|----------------|
| Connector No. | M302 |
| Connector Name | OPTICAL SENSOR |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | P | - |
| 4 | W/R | - |

| | |
|-----------------|--------------|
| Connector No. | M301 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | W/R | - |
| 4 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 10 | P | - |
| 11 | P | - |

| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 57 | R/L | TAIL LAMP |
| 59 | B | GND (POWER) |

| | |
|-----------------|--|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 52 | L | H/LAMP LO LH |
| 54 | R/Y | H/LAMP LO RH |
| 55 | G | H/LAMP HI LH |
| 56 | L/W | H/LAMP HI RH (WITHOUT DAYTIME LIGHT SYSTEM) |
| 56 | Y | H/LAMP HI RH (WITH DAYTIME LIGHT SYSTEM) |

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |


ABLIA4113GB

A B C D E F G H I J K EXL M N O P

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|----------------------|
| Connector No. | B8 |
| Connector Name | FRONT DOOR SWITCH LH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|--------------|
| Connector No. | B48 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | B | - |
| 15 | R/W | - |

| | |
|-----------------|--------------|
| Connector No. | B43 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 10 | R/W | - |

| | |
|-----------------|---------------------|
| Connector No. | B18 |
| Connector Name | REAR DOOR SWITCH LH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/Y | - |

ABLIA4114GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|----------------------|
| Connector No. | B108 |
| Connector Name | FRONT DOOR SWITCH RH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/L | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 21J | R/Y | - |
| 30J | SB | - |

| | |
|-----------------|--------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|---------------------|
| Connector No. | B116 |
| Connector Name | REAR DOOR SWITCH RH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | GR | - |

| | |
|-----------------|--------------|
| Connector No. | B111 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 10 | R/W | - |


ABLIA4115GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|--------------|
| Connector No. | D401 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | B | - |
| 15 | R/W | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 15A | R/W | - |
| 21A | R/L | - |
| 26A | GR | - |

| | |
|-----------------|--------------|
| Connector No. | B149 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|------------------|
| Connector No. | D502 |
| Connector Name | BACK DOOR SWITCH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | - |
| 3 | R/W | - |

| | |
|-----------------|--------------|
| Connector No. | D501 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | B | - |
| 15 | R/W | - |

| | |
|-----------------|--------------|
| Connector No. | D405 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | B | - |
| 15 | R/W | - |


ABLIA4116GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

| | |
|-----------------|-----------------|
| Connector No. | D503 |
| Connector Name | BACK DOOR LATCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | R/W | - |
| 8 | B | - |

ABLIA4117GB

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

FRONT FOG LAMP SYSTEM

Wiring Diagram

INFOID:000000009822325

FRONT FOG LAMP




ABLWA1909GB

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >


FRONT FOG LAMP CONNECTORS

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | W/L | - |

ABLIA4124GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|-------------------|
| Connector No. | E101 |
| Connector Name | FRONT FOG LAMP LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 2 | B | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 10 | P | - |
| 11 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

| | |
|-----------------|--|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------|
| 50 | W/R | FR FOG LAMP LH |
| 51 | W/R | FR FOG LAMP RH |

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|-------------------|
| Connector No. | E102 |
| Connector Name | FRONT FOG LAMP RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 2 | B | - |


ABLIA3274GB

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 59 | B | GND (POWER) |

ABLIA4126GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:00000009822326



ABLWA1915GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| | |
|-----------------|--------------|
| Connector No. | M8 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5P | O/L | - |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | B | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 29 | W/B | HAZARD SW |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 60 | G/B | FLASHER OUTPUT (LEFT) |
| 61 | G/Y | FLASHER OUTPUT (RIGHT) |
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

ABLIA4142GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |

| Terminal No. | Wire | Signal Name |
|--------------|------|-------------|
| 1 | O | ACCESSORY |
| 8 | Y/R | BATTERY |
| 9 | B | GND |
| 11 | L | CAN-H |
| 12 | P | CAN-L |
| 24 | O/L | RUN/START |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |




| | | | | | | | |
|----|----|----|---|---|---|---|---|
| 12 | 13 | 10 | 9 | 8 | 7 | | |
| 14 | 11 | 1 | 2 | 3 | 4 | 5 | 6 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|------------------|
| Connector No. | M39 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| | | | | |
|----|----|----|----|----|
| 30 | 20 | 10 | | |
| 80 | 70 | 60 | 50 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4Q | Y/R | - |

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | M74 |
| Connector Name | WIRE TO WIRE |
| Connector Color | BROWN |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12 | G/Y | - |

| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6T | O | - |

| | |
|-----------------|---------------|
| Connector No. | M55 |
| Connector Name | HAZARD SWITCH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | - |
| 2 | W/B | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

| | |
|-----------------|--------------|
| Connector No. | M158 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | G/B | - |

| | |
|-----------------|--------------|
| Connector No. | M75 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | B | - |

ABLIA4144GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E11 |
| Connector Name | FRONT COMBINATION LAMP LH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 5 | G/B | - |

| | |
|-----------------|---|
| Connector No. | E6 |
| Connector Name | FRONT COMBINATION LAMP LH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 5 | G/B | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | L | - |
| 10 | P | - |
| 13 | P | - |

| | |
|-----------------|---|
| Connector No. | E108 |
| Connector Name | FRONT COMBINATION LAMP RH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 5 | G/Y | - |

| | |
|-----------------|--|
| Connector No. | E107 |
| Connector Name | FRONT COMBINATION LAMP RH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 5 | G/Y | - |

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 15 | G/B | - |


ABLIA4145GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 38G | G/B | - |
| 39G | G/Y | - |
| 96G | W/B | - |
| 99G | L/W | - |

| Connector No. | E152 |
|-----------------|--------------|
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Connector No. | E139 |
|-----------------|--------------|
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | G/Y | - |




| Connector No. | B105 |
|-----------------|--------------------------|
| Connector Name | REAR COMBINATION LAMP RH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | G/Y | - |
| 6 | B | - |

| Connector No. | B40 |
|-----------------|--------------|
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 15 | G/B | - |

| Connector No. | B35 |
|-----------------|--------------------------|
| Connector Name | REAR COMBINATION LAMP LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | G/B | - |
| 6 | B | - |

ABLI4146GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | D3 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 3 | Color of Wire | G/B | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|--------------|
| Connector No. | D2 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|----|---------------|---|-------------|---|
| Terminal No. | 14 | Color of Wire | B | Signal Name | - |
|--------------|----|---------------|---|-------------|---|

| | |
|-----------------|--------------|
| Connector No. | B107 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 2 | Color of Wire | G/Y | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|--------------|
| Connector No. | D102 |
| Connector Name | WIRE TO WIRE |
| Connector Color | BROWN |



| | | | | | |
|--------------|----|---------------|-----|-------------|---|
| Terminal No. | 12 | Color of Wire | G/Y | Signal Name | - |
|--------------|----|---------------|-----|-------------|---|

| | |
|-----------------|--------------|
| Connector No. | D101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|---|-------------|---|
| Terminal No. | 3 | Color of Wire | B | Signal Name | - |
|--------------|---|---------------|---|-------------|---|

| | |
|-----------------|--|
| Connector No. | D4 |
| Connector Name | DOOR MIRROR LH (WITH AUTOMATIC DRIVE POSITIONER) |
| Connector Color | WHITE |



| | | | | | |
|--------------|----|---------------|-----|-------------|---|
| Terminal No. | 11 | Color of Wire | B | Signal Name | - |
| Terminal No. | 15 | Color of Wire | G/B | Signal Name | - |


ABLIA4147GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

| | |
|-----------------|--|
| Connector No. | D107 |
| Connector Name | DOOR MIRROR RH (WITH AUTOMATIC DRIVE POSITIONER) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 11 | B | - |
| 15 | G/Y | - |

ABLIA4148GB


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram

INFOID:000000009822327



ABLWA1911GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

PARKING, LICENSE PLATE AND TAIL LAMPS CONNECTORS

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| | | | | | | | |
|----|----|----|---|---|---|---|---|
| 12 | 13 | 10 | 9 | 8 | 7 | | |
| 14 | 11 | 1 | 2 | 3 | 4 | 5 | 6 |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | W/L | - |

ABLIA4130GB


A B C D E F G H I J K L M N O P

EXL

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|---|
| Connector No. | E6 |
| Connector Name | FRONT COMBINATION LAMP LH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 6 | R/L | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 10 | P | - |
| 11 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

| | |
|-----------------|--------------|
| Connector No. | E41 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 45C | B | - |
| 46C | R/L | - |

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12 | R/L | - |

| | |
|-----------------|--|
| Connector No. | E11 |
| Connector Name | FRONT COMBINATION LAMP LH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 6 | R/L | - |

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---|
| Connector No. | E108 |
| Connector Name | FRONT COMBINATION LAMP RH (WITH DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 6 | R/L | - |

| | |
|-----------------|--|
| Connector No. | E107 |
| Connector Name | FRONT COMBINATION LAMP RH (WITHOUT DAYTIME LIGHT SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | - |
| 6 | R/L | - |

| | |
|-----------------|--------------|
| Connector No. | E139 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | R/L | - |

| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 57 | R/L | TAIL LAMP |
| 59 | B | GND (POWER) |


ABLIA2725GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|--------------|
| Connector No. | C1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 45C | B | - |
| 46C | R/L | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|-----------------------|
| Connector No. | C106 |
| Connector Name | LICENSE PLATE LAMP LH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 2 | B | - |

| | |
|-----------------|--------------|
| Connector No. | C101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 5 | B | - |

| | |
|-----------------|--------------|
| Connector No. | C3 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 5 | B | - |

ABLIA4131GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--------------------------|
| Connector No. | B70 |
| Connector Name | REAR COMBINATION LAMP LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/L | - |
| 3 | B | - |

| | |
|-----------------|--------------|
| Connector No. | B40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12 | R/L | - |

| | |
|-----------------|-----------------------|
| Connector No. | C107 |
| Connector Name | LICENSE PLATE LAMP RH |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 2 | B | - |

| | |
|-----------------|--------------------------|
| Connector No. | B130 |
| Connector Name | REAR COMBINATION LAMP RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/L | - |
| 3 | B | - |

| | |
|-----------------|--------------|
| Connector No. | B107 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | R/L | - |

ABLIA4174GB


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

STOP LAMP

< WIRING DIAGRAM >

STOP LAMP CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 36G | R/Y | - |

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R/B | - |

| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1T | R/Y | - |

| | |
|-----------------|-----------------|
| Connector No. | E12 |
| Connector Name | STOP LAMP RELAY |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/Y | - |
| 2 | L/W | - |
| 3 | R/G | - |
| 4 | R/B | - |
| 5 | - | - |

| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/Y | - |
| 2 | R/G | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

ABLIA4132GB

STOP LAMP


< WIRING DIAGRAM >

| | |
|-----------------|---|
| Connector No. | E125 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 35 | L/W | BRL OUT |
| 41 | R/B | BLS |

| | |
|-----------------|--------------|
| Connector No. | E139 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | R/B | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 36G | R/Y | - |

| | |
|-----------------|--------------|
| Connector No. | B40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R/B | - |

| | |
|-----------------|--------------|
| Connector No. | B48 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R/B | - |
| 14 | B | - |

| | |
|-----------------|--------------------------|
| Connector No. | B70 |
| Connector Name | REAR COMBINATION LAMP LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/B | - |
| 3 | B | - |

STOP LAMP


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | D401 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R/B | - |
| 14 | B | - |

| | |
|-----------------|--------------------------|
| Connector No. | B130 |
| Connector Name | REAR COMBINATION LAMP RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/B | - |
| 3 | B | - |

| | |
|-----------------|--------------|
| Connector No. | B107 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | R/B | - |

| | |
|-----------------|------------------------|
| Connector No. | D403 |
| Connector Name | HIGH-MOUNTED STOP LAMP |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/B | - |
| 2 | B | - |

ABLIA4134GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BACK-UP LAMP

< WIRING DIAGRAM >


BACK-UP LAMP

Wiring Diagram

INFOID:000000009822329

AI : WITH AUTO ANTI-DAZZLING INSIDE MIRROR

BACK-UP LAMP



* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.


ABLWA1906GB

BACK-UP LAMP

< WIRING DIAGRAM >

BACK-UP LAMP CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 64G | R | - |
| 94G | G/W | - |
| 95G | G | - |
| 97G | Y/R | - |
| 98G | W/B | - |

| | |
|-----------------|--------------------|
| Connector No. | M73 |
| Connector Name | BACK-UP LAMP RELAY |
| Connector Color | BROWN |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | R | - |
| 3 | G | - |
| 5 | G/W | - |
| 6 | W/B | - |
| 7 | Y/R | - |

| | |
|-----------------|--------------|
| Connector No. | E5 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R | - |

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | G/W | - |

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 16 | G | REVERSE LAMP |

ABLIA4118GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

BACK-UP LAMP


< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E121 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |




| | | | | | |
|--------------|----|---------------|-----|-------------|---------------|
| Terminal No. | 27 | Color of Wire | W/B | Signal Name | TTOW REV LAMP |
|--------------|----|---------------|-----|-------------|---------------|

| | |
|-----------------|--------------|
| Connector No. | E139 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 4 | Color of Wire | G/W | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|-----|---------------|-----|-------------|---|
| Terminal No. | 64G | Color of Wire | R | Signal Name | - |
| Terminal No. | 94G | Color of Wire | G/W | Signal Name | - |
| Terminal No. | 95G | Color of Wire | G | Signal Name | - |
| Terminal No. | 97G | Color of Wire | Y/R | Signal Name | - |
| Terminal No. | 98G | Color of Wire | W/B | Signal Name | - |

| | |
|-----------------|--------------|
| Connector No. | F9 |
| Connector Name | AVT ASSEMBLY |
| Connector Color | GREEN |




| | | | | | |
|--------------|---|---------------|---|-------------|---|
| Terminal No. | 7 | Color of Wire | R | Signal Name | - |
|--------------|---|---------------|---|-------------|---|

ABLIA4119GB

BACK-UP LAMP

< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | B40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|----|---------------|----|-------------|---|
| Terminal No. | 14 | Color of Wire | GW | Signal Name | — |
|--------------|----|---------------|----|-------------|---|

| | |
|-----------------|-----------------------------------|
| Connector No. | F502 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | GRAY |



| | | | | | |
|--------------|---|---------------|---|-------------|--------------|
| Terminal No. | 7 | Color of Wire | R | Signal Name | REV LAMP RLY |
|--------------|---|---------------|---|-------------|--------------|

| | |
|-----------------|--------------|
| Connector No. | F14 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|----|---------------|---|-------------|---|
| Terminal No. | 13 | Color of Wire | R | Signal Name | — |
|--------------|----|---------------|---|-------------|---|

| | |
|-----------------|-----------------|
| Connector No. | B135 |
| Connector Name | BACK-UP LAMP RH |
| Connector Color | BLACK |



| | | | | | |
|--------------|---|---------------|----|-------------|---|
| Terminal No. | 1 | Color of Wire | GW | Signal Name | — |
| 2 | B | B | B | — | — |

| | |
|-----------------|--------------|
| Connector No. | B107 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 4 | Color of Wire | G/W | Signal Name | — |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|-----------------|
| Connector No. | B71 |
| Connector Name | BACK-UP LAMP LH |
| Connector Color | BLACK |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 1 | Color of Wire | G/W | Signal Name | — |
| 2 | B | B | B | — | — |

ABLIA4120GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL


TRAILER TOW

< WIRING DIAGRAM >

TRAILER TOW

Wiring Diagram

INFOID:00000009822330



ABLWA1913GB

TRAILER TOW

< WIRING DIAGRAM >

TRAILER TOW CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| | | | |
|----|---|---|---|
| 4 | 3 | 2 | 1 |
| 10 | 9 | 8 | 7 |
| 6 | 5 | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | BR/W | - |
| 4 | R/G | - |
| 9 | R | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | INPUT 5 |
| 3 | G/Y | INPUT 4 |
| 4 | Y | INPUT 3 |
| 5 | G/B | INPUT 2 |
| 6 | V | INPUT 1 |
| 32 | R/G | OUTPUT 5 |
| 33 | R/Y | OUTPUT 4 |
| 34 | L | OUTPUT 3 |
| 35 | O/B | OUTPUT 2 |
| 36 | R/W | OUTPUT 1 |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |

| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| 50 | 51 | 52 | 53 | 54 | 55 | | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------------|
| 51 | Y/B | TRAILER FLASHER OUTPUT (RIGHT) |
| 52 | G/B | TRAILER FLASHER OUTPUT (LEFT) |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |

| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| | | | | | |
|----|----|----|---|---|---|
| 12 | 13 | 10 | 9 | 8 | 7 |
| 14 | 11 | 1 | 2 | 3 | 4 |
| 5 | 6 | | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/W | - |
| 2 | O/B | - |
| 3 | L | - |
| 4 | R/Y | - |
| 5 | R/G | - |
| 6 | V | - |
| 7 | G/B | - |
| 8 | SB | - |
| 9 | G/Y | - |
| 10 | Y | - |

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TRAILER TOW

< WIRING DIAGRAM >


| | |
|-----------------|---------------------|
| Connector No. | M51 |
| Connector Name | TRAILER TOW RELAY 1 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 2 | B | - |
| 3 | BR | - |
| 5 | R | - |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 36G | R/Y | - |
| 47G | R/L | - |
| 57G | G/B | - |
| 58G | Y/B | - |
| 92G | R | - |
| 93G | BR | - |
| 96G | W/B | - |
| 99G | W/L | - |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | - |
| 2 | R/G | - |
| 3 | BR/W | - |
| 4 | R/L | - |
| 5 | R | - |
| 6 | - | - |

| | |
|-----------------|-----------------------------|
| Connector No. | M76 |
| Connector Name | ELECTRIC BRAKE (PRE-WIRING) |
| Connector Color | WHITE |



| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1T | R/Y | - |

ABLIA4136GB

TRAILER TOW


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | E10 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | BRW | - |
| 4 | R/G | - |
| 9 | R | - |

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 10 | P | - |
| 11 | P | - |


| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 6 | L | - |
| 10 | P | - |
| 15 | P | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1C | G/B | - |
| 5C | R | - |
| 6C | BR/W | - |
| 7C | B | - |
| 8C | Y/R | - |
| 9C | W/L | - |
| 17C | Y/B | - |

| | |
|-----------------|--------------|
| Connector No. | E41 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/Y | - |
| 2 | R/G | - |


ABLIA4137GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TRAILER TOW


< WIRING DIAGRAM >

| | |
|-----------------|--|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |




| Terminal No. | Color of Wire | R/L | Signal Name |
|--------------|---------------|-----|--------------|
| 49 | | | ILLUMINATION |

| | |
|-----------------|--|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 16 | G | REVERSE LAMP |

| | |
|-----------------|---------------------|
| Connector No. | E140 |
| Connector Name | TRAILER TOW RELAY 2 |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | B | - |
| 3 | Y | - |
| 5 | W/L | - |
| 6 | Y | - |
| 7 | W/L | - |

| | |
|-----------------|--|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------|
| 59 | B | GND (POWER) |
| 61 | BR | TRAIL RLY SUPPLY |

ABLIA4138GB

TRAILER TOW

< WIRING DIAGRAM >


| | |
|-----------------|-----------------------|
| Connector No. | E156 |
| Connector Name | TRAILER TURN RELAY LH |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G/B | - |
| 2 | B | - |
| 3 | G/B | - |
| 5 | L | - |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 31G | L | - |
| 32G | P | - |
| 36G | R/Y | - |
| 47G | R/L | - |
| 57G | G/B | - |
| 58G | Y/B | - |
| 92G | R | - |
| 93G | BR | - |
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1C | G/B | - |
| 5C | R | - |
| 6C | BR/W | - |
| 7C | B | - |
| 8C | Y/R | - |
| 9C | W/L | - |
| 17C | Y/B | - |

| | |
|-----------------|--------------|
| Connector No. | C1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| | |
|-----------------|-----------------------|
| Connector No. | E157 |
| Connector Name | TRAILER TURN RELAY RH |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y/B | - |
| 2 | B | - |
| 3 | Y/B | - |
| 5 | L | - |

ABLIA4139GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

TRAILER TOW

< WIRING DIAGRAM >

| | |
|-----------------|--------------------|
| Connector No. | C15 |
| Connector Name | TRAILER RECEPTACLE |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------|
| 1 | - | STOP/TURN LH |
| 2 | - | GROUND |
| 3 | - | ELECTRIC BRAKE |
| 4 | - | STOP/TURN RH |
| 5 | - | BATTERY |
| 6 | - | RUNNING LAMPS |
| 7 | - | BACK-UP LAMPS |

| | |
|-----------------|---------|
| Connector No. | C2 |
| Connector Name | TRAILER |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G/B | - |
| 2 | B | - |
| 3 | BR/W | - |
| 4 | Y/B | - |
| 5 | W/L | - |
| 6 | R | - |
| 7 | Y/R | - |

ABLIA4140GB

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009822331

CAUTION:

Perform the self-diagnosis with **CONSULT** before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

| Symptom | | Possible cause | Inspection item | |
|--|---------------------------------------|---|---|--------------------------------------|
| Headlamp does not switch to the high beam. | One side | <ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and the front combination lamp • Front combination lamp (High beam relay) • IPDM E/R | Headlamp (HI) circuit Refer to EXL-36 . | |
| | Both sides | Symptom diagnosis "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to EXL-124 . | | |
| High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.) | | <ul style="list-style-type: none"> • Combination meter • BCM | <ul style="list-style-type: none"> • Combination meter. Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) Active test "HEADLAMP" | |
| Headlamp does not switch to the low beam. | One side | Front combination lamp (Low beam relay) | — | |
| | Both sides | <ul style="list-style-type: none"> • Combination switch (lighting and turn signal switch) • Harness between the combination switch (lighting and turn signal switch) and BCM • BCM | Combination switch (lighting and turn signal switch) Refer to BCS-51 . | |
| | | High beam request signal | <ul style="list-style-type: none"> • BCM • IPDM E/R | IPDM E/R Data monitor "HL HI REQ" |
| | | IPDM E/R | — | — |
| Headlamp does not turn ON. | One side | <ul style="list-style-type: none"> • Fuse • Bulb • Harness between IPDM E/R and the front combination lamp • Front combination lamp • IPDM E/R | Headlamp (LO) circuit Refer to EXL-39 . | |
| | Both sides | Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-125 , "Description". | | |
| Headlamp does not turn OFF. | When the ignition switch is turned ON | <ul style="list-style-type: none"> • BCM • Combination switch (lighting and turn signal switch) | Combination switch (lighting and turn signal switch) Refer to BCS-51 . | |
| Headlamp is not turned ON/OFF with the lighting switch AUTO. | | <ul style="list-style-type: none"> • Combination switch (lighting and turn signal switch) • Harness between the combination switch (lighting and turn signal switch) and BCM • BCM | Combination switch (lighting and turn signal switch) Refer to BCS-51 . | |
| | | <ul style="list-style-type: none"> • Optical sensor • Harness between the optical sensor and BCM • BCM | Optical sensor Refer to EXL-50 . | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

| Symptom | Possible cause | Inspection item |
|--|--|--|
| Daytime light system does not activate. | <ul style="list-style-type: none"> • Either high beam bulb • Parking brake switch • Combination switch (lighting and turn signal switch) • BCM • IPDM E/R • Daytime light relay • Harness between IPDM E/R and daytime light relay. | Daytime light system description. Refer to EXL-9. "System Description" . |
| Front fog lamp is not turned ON. | One side | <ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and the front combination lamp • Front combination lamp • IPDM E/R Front fog lamp circuit Refer to EXL-41 . |
| | Both side | Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-127 . |
| Parking lamp is not turned ON. | One side | <ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Harness between IPDM E/R and the front/rear combination lamp • Front/rear combination lamp • IPDM E/R Parking lamp circuit Refer to EXL-43 . |
| | Both sides | Symptom diagnosis "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-126 . |
| Turn signal lamp does not blink. | Indicator lamp is normal. (The applicable side performs the high flasher activation). | <ul style="list-style-type: none"> • Harness between BCM and each turn signal lamp • Turn signal lamp bulb • Door mirror (if equipped with turn signals in the door mirrors) Turn signal lamp circuit Refer to EXL-47 . |
| Turn signal indicator lamp does not blink. | One side | Combination meter — |
| | Both sides (Always) | <ul style="list-style-type: none"> • Turn signal indicator lamp signal • Combination meter • BCM • Combination meter. Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER" |
| | Both sides (Does blink when activating the hazard warning lamp with the ignition switch OFF) | <ul style="list-style-type: none"> • The combination meter power supply and the ground circuit • Combination meter Combination meter Power supply and the ground circuit Refer to MWI-32 . |

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000009822332

AUTO LIGHT SYSTEM

The auto light system may not turn the headlamp ON/OFF immediately after passing a dark area or a bright area (short tunnel, sky bridge, shadowed area etc.). This is normal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:000000009822333

The headlamps (both sides) do not switch to high beam when the combination switch (lighting and turn signal switch) is in the HI or PASS setting.

Diagnosis Procedure

INFOID:000000009822334

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-51. "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

| Monitor item | Condition | | Monitor status |
|--------------|--|-----------------------|----------------|
| HL HI REQ | Combination switch (lighting and turn signal switch) (2ND) | HI or PASS | ON |
| | | Except for HI or PASS | OFF |

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-54. "Removal and Installation"](#).

3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-36. "Description"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-31. "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000009822335

The headlamps (both sides) do not turn ON in any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000009822336

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-51, "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

| Monitor item | Condition | Monitor status | |
|--------------|--|----------------|-----|
| HL LO REQ | Combination switch (lighting and turn signal switch) | 2ND | ON |
| | | OFF | OFF |

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).

3.HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-39, "Description"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000009822337

The parking, license plate and tail lamps do not turn ON in with any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000009822338

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-51. "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

| Monitor item | Condition | Monitor status |
|-------------------|---|----------------|
| TAIL & CLR REQ | Combination switch (lighting and turn signal switch) | 1ST ON |
| | | OFF OFF |

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-54. "Removal and Installation"](#).

3.PARK LAMP CIRCUIT INSPECTION

Check the parking lamp circuit. Refer to [EXL-43. "Description"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-31. "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000009822339

The front fog lamps do not turn ON in any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000009822340

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-51, "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

| Monitor item | Condition | Monitor status | |
|--------------|--|----------------|-----|
| FR FOG REQ | Combination switch (lighting and turn signal switch) (2ND) | ON | ON |
| | | OFF | OFF |

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).

3.FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-41, "Description"](#).

Is the front fog lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009822341

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000009822342

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Work

INFOID:000000009822343

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009822344

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|--------------------------|
| — (J-46534) Trim tool set | Removing trim components |



AWJIA0483ZZ

ADJUSTMENT AND INSPECTION

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

ADJUSTMENT AND INSPECTION

HEADLAMP

HEADLAMP : Aiming Adjustment

INFOID:000000009822345

CAUTION:


Do not use organic solvent (thinner, gasoline etc.)

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following:

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that the vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in drivers seat.
- Adjust aiming in the vertical direction by turning the adjustment screw.
- When performing adjustment, if necessary, cover the opposite headlamp.



1. Front combination lamp

A. Suitable tool

B. Adjusting screw

HEADLAMP : Headlamp Aiming

INFOID:000000009822346

NOTE:

Set the screen so that it is perpendicular to the road.

1. Position the screen.
2. Make the distance between the headlamp center and the screen 7.62 m (25 ft).
3. Start the engine and illuminate the headlamp (LO).

CAUTION:

Do not cover the lens surface with tape, etc. because it is made of plastic.


NOTE:

Block the light from the headlamp that is not being adjusted with a thick fabric or similar object, so that it does not reach the screen.

ADJUSTMENT AND INSPECTION

< REMOVAL AND INSTALLATION >

- Use the adjustment screw to adjust the low beams on the screen, so that it is within the aiming adjustment area.



- | | | |
|-------------------------------------|---------------------------------------|--|
| A. Right | B. Left | C. Center of headlamp bulb (H-V point) |
| D. Cutoff line | E. Screen | F. Aim evaluation segment |
| G. Step | H. Horizontal center line of headlamp | J. 103 mm (4.06 in) |
| K. 37 mm (1.46 in) | L. 7.62 m (25 ft) | M. 399 mm (15.71 in) |
| N. 133 mm (5.24 in) | P. 53.2 mm (2.09 in) | Q. 466 mm (18.35 in) |
| R. 200 mm (7.87 in) | S. RH headlamp aiming screen | T. LH headlamp aiming screen |
| V. Vertical center line of headlamp | | |

FRONT FOG LAMP

FRONT FOG LAMP : Aiming Adjustment

INFOID:00000009822347

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

Before performing aiming adjustment, check the following.


- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

NOTE:


ADJUSTMENT AND INSPECTION

< REMOVAL AND INSTALLATION >


Access adjustment screw from underneath front bumper. Use a suitable tool to adjust. Turn screw clockwise to raise pattern and counterclockwise to lower pattern.



1. Set the distance between the screen and the center of the fog lamp lens as shown.
2. Turn front fog lamps ON.



3. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP

< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

HEADLAMP

Bulb Replacement

INFOID:000000009822348

HEADLAMP - LOW/HIGH BEAM

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

Removal

1. Remove front combination lamp. Refer to [EXL-134, "Removal and Installation"](#).
2. Disconnect the harness connector.
3. Rotate headlamp bulb counterclockwise and remove.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb securely to ensure watertightness.

FRONT TURN SIGNAL/PARKING LAMP

Removal

1. Remove front combination lamp. Refer to [EXL-134, "Removal and Installation"](#).
2. Rotate bulb socket counterclockwise and remove.
3. Pull bulb to remove from the socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

FRONT SIDE MARKER LAMP

Removal

1. Remove front combination lamp. Refer to [EXL-134, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and remove.
3. Pull bulb to remove from the socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

Removal and Installation

INFOID:000000009822349

FRONT COMBINATION LAMP


Removal

1. Partially remove fender protector (front edge). Refer to [EXT-27, "Removal and Installation"](#).
2. Remove front grille. Refer to [EXT-23, "Removal and Installation"](#).

HEADLAMP

< UNIT REMOVAL AND INSTALLATION >

3. Remove the bolts (A), disconnect the harness connector from the front combination lamp (1) and remove.



Installation

Installation is in the reverse order of removal.


NOTE:

After installation perform headlamp aiming adjustment. Refer to [EXL-131. "HEADLAMP : Aiming Adjustment"](#).

Disassembly and Assembly

INFOID:000000009822350

FRONT COMBINATION LAMP



- | | | |
|------------------------------|----------------------------------|-----------------------------|
| 1. Headlamp bulb (high beam) | 2. Wiring harness | 3. Front combination lamp |
| 4. Side marker lamp bulb | 5. Turn signal/parking lamp bulb | 6. Headlamp bulb (low beam) |

Disassembly

1. Rotate high beam bulb counterclockwise and remove.
2. Rotate low beam bulb counterclockwise and remove.
3. Rotate turn signal/parking lamp bulb socket counterclockwise and remove.
4. Rotate side marker lamp bulb socket counterclockwise and remove.

Assembly

Assembly is in the reverse order of disassembly.

CAUTION:

After installing, be sure to install the bulb sockets securely to ensure watertightness.

AUTO LIGHT SYSTEM

< UNIT REMOVAL AND INSTALLATION >

AUTO LIGHT SYSTEM


Removal and Installation

INFOID:000000009822351

OPTICAL SENSOR

Removal

1. Remove defroster grille. Refer to [IP-11. "Exploded View"](#).
2. Disconnect the harness connector from the optical sensor.
3. Rotate the optical sensor counterclockwise and remove from defroster grille.



Installation

Installation is in the reverse order of removal.

FRONT FOG LAMP

< UNIT REMOVAL AND INSTALLATION >

FRONT FOG LAMP

Bulb Replacement

INFOID:000000009822352

FRONT FOG LAMP

Removal


WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Disconnect the harness connector from the front fog lamp bulb.
2. Rotate front fog lamp bulb counterclockwise and remove.



Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.


Removal and Installation

INFOID:000000009822353

FRONT FOG LAMP

Removal

1. Disconnect the harness connector from the front fog lamp bulb (1).
2. Remove the bolts (A) and the front fog lamp (2).



Installation

Installation is in the reverse order of removal.

NOTE:

After installing, perform fog lamp aiming adjustment. Refer to [EXL-132, "FRONT FOG LAMP : Aiming Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LIGHTING & TURN SIGNAL SWITCH

< UNIT REMOVAL AND INSTALLATION >


LIGHTING & TURN SIGNAL SWITCH

Removal and Installation

INFOID:000000009822354

REMOVAL

1. Remove steering column cover. Refer to [IP-14. "Removal and Installation"](#).
2. While pressing tabs, pull lighting and turn signal switch toward driver door and disconnect from the base.



INSTALLATION

Installation is in the reverse order of removal.

HAZARD SWITCH

< UNIT REMOVAL AND INSTALLATION >


HAZARD SWITCH

Removal and Installation

INFOID:000000009822355

REMOVAL

1. Remove cluster lid C. Refer to [IP-15. "Removal and Installation"](#).
2. While pressing the tab, push out the hazard switch.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LICENSE PLATE LAMP

< UNIT REMOVAL AND INSTALLATION >

LICENSE PLATE LAMP

Bulb Replacement

INFOID:000000009822356

LICENSE PLATE LAMP

Removal

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- **Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.**
- **Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.**

1. Remove license plate lamp. Refer to [EXL-140, "Removal and Installation"](#).
2. Rotate bulb socket counterclockwise and remove.
3. Pull bulb from socket.

Installation

Installation is in the reverse order of removal.

Removal and Installation

INFOID:000000009822357

LICENSE PLATE LAMP

Removal

1. Using a suitable tool, first release the tab which is forward in vehicle, then pry outward to release the second tab.
2. Disconnect the harness connector and remove the license plate lamp from the rear bumper.

Installation

Installation is in the reverse order of removal.

PUDDLE LAMP

< UNIT REMOVAL AND INSTALLATION >

PUDDLE LAMP

Removal and Installation

INFOID:000000009822358

REMOVAL


WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.


CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Release pawl (1) on outer edge of puddle lamp housing.



2. Lower outer edge and slide puddle lamp housing out of door mirror.
3. Rotate puddle lamp socket (1) counterclockwise to remove from puddle lamp housing (2).



INSTALLATION


Installation is in the reverse order of removal.

Bulb Replacement

INFOID:000000009822359

REMOVAL

1. Remove puddle lamp. Refer to [EXL-141, "Removal and Installation"](#).
2. Pull puddle lamp bulb (2) straight out from puddle lamp socket (1) to remove.



INSTALLATION

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PUDDLE LAMP

< UNIT REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

HIGH-MOUNTED STOP LAMP

< UNIT REMOVAL AND INSTALLATION >

HIGH-MOUNTED STOP LAMP

Bulb Replacement

INFOID:000000009822360

REMOVAL AND INSTALLATION

NOTE:


High-mounted stop lamp bulbs are not serviceable.

Removal and Installation

INFOID:000000009822361

REMOVAL

1. Remove back door upper finisher. Refer to [INT-26, "Removal and Installation"](#).
2. Remove nuts and high-mounted stop lamp assembly.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

REAR COMBINATION LAMP

< UNIT REMOVAL AND INSTALLATION >

REAR COMBINATION LAMP

Bulb Replacement

INFOID:000000009822362

REMOVAL

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Remove rear combination lamp. Refer to [EXL-144, "Removal and Installation"](#).
2. Rotate bulb socket counterclockwise and remove.
3. Pull bulb from socket.

INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation

INFOID:000000009822363

REMOVAL

1. Remove rear combination lamp bolts.
2. Pull rear combination lamp to remove.
3. Disconnect the harness connector from the rear combination lamp.



INSTALLATION

Installation is in the reverse order of removal.

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Bulb Specifications

INFOID:000000009822364

| Item | | Wattage (W)* |
|-------------------------------------|------------------------|--------------|
| Front combination lamp | Headlamp (HI/LO) | 65/55 |
| | Parking lamp/Turn lamp | 28/8 |
| | Side marker lamp | 3.8 |
| Front fog lamp (if equipped) | | 55 |
| Side turn signal lamp (if equipped) | | - |
| Puddle lamp (if equipped) | | 9 |
| Rear combination lamp | Stop lamp/Tail lamp | 27/8 |
| | Rear turn signal lamp | 18 |
| | Back-up lamp | 18 |
| License plate lamp | | 5 |
| High-mounted stop lamp | | - |

*: Always check with the Parts Department for the latest parts information.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P