

WT
SECTION
ROAD WHEELS & TIRES

A
B
C
D

WT

CONTENTS

| | |
|---|---|
| <p>BASIC INSPECTION 3</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 3</p> <p style="padding-left: 20px;">Repair Work Flow3</p> <p>INSPECTION AND ADJUSTMENT 5</p> <p style="padding-left: 20px;">Preliminary Check5</p> <p style="padding-left: 20px;">Transmitter Wake Up Operation5</p> <p style="padding-left: 20px;">ID Registration Procedure6</p> <p>SYSTEM DESCRIPTION 8</p> <p>TPMS 8</p> <p style="padding-left: 20px;">System Diagram8</p> <p style="padding-left: 20px;">System Description8</p> <p style="padding-left: 20px;">System Component10</p> <p>DIAGNOSIS SYSTEM (BCM)11</p> <p style="padding-left: 20px;">CONSULT Function (BCM - COMMON ITEM) 11</p> <p style="padding-left: 20px;">CONSULT Function (BCM - AIR PRESSURE MONITOR) 12</p> <p>DTC/CIRCUIT DIAGNOSIS13</p> <p>C1708 - C1711 DATA FROM TRANSMITTER NOT BEING RECEIVED13</p> <p style="padding-left: 20px;">Description 13</p> <p style="padding-left: 20px;">DTC Logic 13</p> <p style="padding-left: 20px;">Diagnosis Procedure 13</p> <p style="padding-left: 20px;">Special Repair Requirement 14</p> <p>C1712 - C1715, C1720 - C1723, C1724 - C1727 TRANSMITTER MALFUNCTION15</p> <p style="padding-left: 20px;">Description 15</p> <p style="padding-left: 20px;">DTC Logic 15</p> <p style="padding-left: 20px;">Diagnosis Procedure 15</p> <p style="padding-left: 20px;">Special Repair Requirement 16</p> <p>C1716 - C1719 TRANSMITTER PRESSURE MALFUNCTION17</p> <p style="padding-left: 20px;">Description 17</p> <p style="padding-left: 20px;">DTC Logic 17</p> | <p style="padding-left: 20px;">Diagnosis Procedure17</p> <p style="padding-left: 20px;">Special Repair Requirement18</p> <p>C1729 VEHICLE SPEED SIGNAL19</p> <p style="padding-left: 20px;">Description 19</p> <p style="padding-left: 20px;">DTC Logic 19</p> <p style="padding-left: 20px;">Diagnosis Procedure 19</p> <p style="padding-left: 20px;">Special Repair Requirement 19</p> <p>C1735 IGNITION SIGNAL20</p> <p style="padding-left: 20px;">Description20</p> <p style="padding-left: 20px;">DTC Logic20</p> <p style="padding-left: 20px;">Diagnosis Procedure20</p> <p style="padding-left: 20px;">Special Repair Requirement21</p> <p>ECU DIAGNOSIS INFORMATION22</p> <p>BCM (BODY CONTROL MODULE)22</p> <p style="padding-left: 20px;">Reference Value22</p> <p style="padding-left: 20px;">Terminal Layout25</p> <p style="padding-left: 20px;">Physical Values25</p> <p style="padding-left: 20px;">Self-Diagnosis (With CONSULT)31</p> <p style="padding-left: 20px;">Self-Diagnosis (Without CONSULT)31</p> <p>WIRING DIAGRAM33</p> <p>TIRE PRESSURE MONITORING SYSTEM33</p> <p style="padding-left: 20px;">Wiring Diagram33</p> <p>SYMPTOM DIAGNOSIS38</p> <p>TPMS38</p> <p style="padding-left: 20px;">Symptom Table38</p> <p>LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON39</p> <p style="padding-left: 20px;">Low Tire Pressure Warning Lamp Does Not Come On When Ignition Switch Is Turned On39</p> <p>LOW TIRE PRESSURE WARNING LAMP STAYS ON40</p> |
|---|---|

F
G
H
I
J
K
L
M
N
O
P

| | | | |
|--|-----------|---|-----------|
| Low Tire Pressure Warning Lamp Stays On When Ignition Switch Is Turned On | 40 | Precaution Necessary for Steering Wheel Rotation After Battery Disconnect | 46 |
| LOW TIRE PRESSURE WARNING LAMP BLINKS | 41 | Precaution for Work | 47 |
| Low Tire Pressure Warning Lamp Flashes When Ignition Switch Is Turned On | 41 | PREPARATION | 48 |
| HAZARD WARNING LAMPS FLASH | 42 | PREPARATION | 48 |
| Hazard Warning Lamps Flash When Ignition Switch Is Turned On | 42 | Special Service Tool | 48 |
| "TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST | 43 | Commercial Service Tool | 48 |
| "TIRE PRESSURE" Information in Display Unit Does Not Exist | 43 | PERIODIC MAINTENANCE | 49 |
| ID REGISTRATION CANNOT BE COMPLETED | 44 | WHEEL | 49 |
| ID Registration Cannot Be Completed | 44 | Inspection | 49 |
| NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING | 45 | WHEEL AND TIRE ASSEMBLY | 50 |
| NVH Troubleshooting Chart | 45 | Balancing Wheels | 50 |
| PRECAUTION | 46 | Rotation | 51 |
| PRECAUTIONS | 46 | UNIT REMOVAL AND INSTALLATION | 53 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 46 | TRANSMITTER | 53 |
| | | Transmitter (Pressure Sensor) | 53 |
| | | SERVICE DATA AND SPECIFICATIONS (SDS) | 55 |
| | | SERVICE DATA AND SPECIFICATIONS (SDS) | 55 |
| | | Road Wheel | 55 |
| | | Tire | 55 |

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Repair Work Flow

INFOID:000000009824369

WORK FLOW



[WT-5. "Preliminary Check"](#)

[WT-31. "Self-Diagnosis \(With CONSULT\)"](#)
[WT-31. "Self-Diagnosis \(Without CONSULT\)"](#)

[WT-38. "Symptom Table"](#)

DETAILED FLOW

1. CUSTOMER INFORMATION

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2

2. PRELIMINARY CHECK

Perform preliminary check. Refer to [WT-5. "Preliminary Check"](#).

>> GO TO 3

A
B
C
D
E
WT
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

3.SELF-DIAGNOSIS

Perform SELF-DIAGNOSIS. Refer to [WT-31, "Self-Diagnosis \(With CONSULT\)"](#) or [WT-31, "Self-Diagnosis \(Without CONSULT\)"](#).

>> GO TO 4

4.SYMPTOM

Check for symptoms. Refer to [WT-38, "Symptom Table"](#).

>> GO TO 5

5.MALFUNCTIONING PARTS

Repair or replace the applicable parts.

>> GO TO 6

6.DRIVE TEST

1. Perform a drive test.
2. Check the low tire pressure warning lamp.

>> GO TO 7

7.SELF-DIAGNOSIS

Perform SELF-DIAGNOSIS. Refer to [WT-31, "Self-Diagnosis \(With CONSULT\)"](#) or [WT-31, "Self-Diagnosis \(Without CONSULT\)"](#).

Are any DTC's displayed?

- YES >> GO TO 5
NO >> Inspection End

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

Preliminary Check

INFOID:000000009824370

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

1. TIRE PRESSURE

Check all tire pressures. Refer to [WT-55, "Tire"](#).

Do tire pressures match specification?

- YES >> GO TO 2.
NO >> Adjust tire pressures to specified value.

2. LOW TIRE PRESSURE WARNING LAMP

Check low tire pressure warning lamp activation.

Does the low tire pressure warning lamp activate for one second when ignition switch is turned ON?

- YES >> GO TO 3.
NO >> GO TO [WT-39, "Low Tire Pressure Warning Lamp Does Not Come On When Ignition Switch Is Turned On"](#).

3. BCM CONNECTOR

1. Disconnect BCM harness connectors.
2. Check terminals for damage or loose connections.
3. Reconnect harness connectors.

Are BCM connectors damaged or loose?

- YES >> Repair or replace damaged parts.
NO >> GO TO 4.

4. TRANSMITTER ACTIVATION TOOL

Check battery in transmitter activation tool.

Is transmitter activation tool battery fully charged?

- YES >> Perform self-diagnosis. Refer to [WT-31, "Self-Diagnosis \(With CONSULT\)"](#) or [WT-31, "Self-Diagnosis \(Without CONSULT\)"](#).
NO >> Replace battery in transmitter activation tool.

Transmitter Wake Up Operation

INFOID:000000009824371

NOTE:

This procedure must be done after replacement of a TPMS transmitter or BCM. New replacement transmitters are provided "asleep" and must first be "woken up" using Transmitter Activation Tool J-45295 or Signal Tech II Tool J-50190 before ID registration can be performed. Use the following procedure when using the Transmitter Activation Tool J-45295.

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.


- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

INSPECTION AND ADJUSTMENT


< BASIC INSPECTION >

1. Turn ignition switch ON. Push the transmitter activation tool against the tire near the front left transmitter. Press the button for 5 seconds. The hazard warning lamps flash per the following diagram.

Tool number : (J-45295)



2. Repeat this procedure for each tire in the following order: FL, FR, RR, RL.
3. When the BCM finishes assigning each tire ID, the BCM flashes the hazard warning lamps and sends flashing indicator status by CAN according to the following time chart.



4. After completing wake up of all transmitters, make sure low tire pressure warning lamp goes out.

ID Registration Procedure

INFOID:000000009824372

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

ID REGISTRATION WITH TRANSMITTER ACTIVATION TOOL

NOTE:

This procedure must be done after replacement of a TPMS transmitter or BCM. New replacement transmitters are provided "asleep" and must first be "woken up" using Transmitter Activation Tool J-45295 or Signal Tech II Tool J-50190 before ID registration can be performed. Use the following procedure when using the Transmitter Activation Tool J-45295.


1. Connect CONSULT.
2. Select "ID REGIST" under BCM.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

- Push the transmitter activation tool against the tire near the front left transmitter. Press the button for 5 seconds.

Tool number : (J-45295)



- Register the IDs in order from FR LH, FR RH, RR RH and RR LH. When ID registration of each wheel has been completed, the hazard warning lamps flash.

| Step | Activation tire position | Hazard warning lamp | CONSULT |
|------|--------------------------|---------------------|----------------------|
| 1 | Front LH | 2 times flashing | "YET" ↓ "DONE" |
| 2 | Front RH | | |
| 3 | Rear RH | | |
| 4 | Rear LH | | |

- After completing all ID registrations, press "END" to complete the procedure.

NOTE:

Be sure to register all of the IDs in order from FR LH, FR RH, RR RH, to RR LH, or the self-diagnostic results display will not function properly.

ID REGISTRATION WITHOUT TRANSMITTER ACTIVATION TOOL

NOTE:

This procedure must be done after replacement of a TPMS transmitter or BCM. New replacement transmitters are provided "asleep" and must first be "woken up" using Transmitter Activation Tool J-45295 or Signal Tech II Tool J-50190 before ID registration can be performed.

- Connect CONSULT.
- Select "ID REGIST" under BCM.
- Adjust the tire pressures to the values shown in the table and drive the vehicle at 40 km/h (25 MPH) or more for a few minutes.

| Tire position | Tire pressure kPa (kg/cm ² , psi) |
|---------------|--|
| Front LH | 250 (2.5, 36) |
| Front RH | 230 (2.3, 33) |
| Rear RH | 210 (2.1, 30) |
| Rear LH | 190 (1.9, 27) |

- After completing all ID registrations, press "END" to complete the procedure.

| Activation tire position | CONSULT |
|--------------------------|----------------------|
| Front LH | "YET" ↓ "DONE" |
| Front RH | |
| Rear RH | |
| Rear LH | |

- Inflate all tires to proper pressure. Refer to [WT-55, "Tire"](#).

TPMS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

TPMS

System Diagram

INFOID:000000009824373




System Description

INFOID:000000009824374

BODY CONTROL MODULE (BCM)


The BCM is shown with the lower instrument panel LH removed. The BCM reads the air pressure signal received by the remote keyless entry receiver, and controls the low tire pressure warning lamp as shown below. It also has a self-diagnosis function to detect a system malfunction.

| Condition | Low tire pressure warning lamp |
|---|---|
| System normal | On for 1 second after ignition ON |
| Tire less than 193 kPa (2.0 kg/cm ² , 28 psi) [Flat tire] | ON |
| TPMS malfunction | After key ON, flashes once per second for 1 minute, then stays ON |



TRANSMITTER

A sensor-transmitter integrated with a valve is installed in each wheel, and transmits a detected air pressure signal in the form of a radio wave. The radio signal is received by the remote keyless entry receiver.




REMOTE KEYLESS ENTRY RECEIVER

TPMS


< SYSTEM DESCRIPTION >

The remote keyless entry receiver is shown with the instrument panel RH removed. The remote keyless entry receiver receives the air pressure signal transmitted by the transmitter in each wheel.




COMBINATION METER

The combination meter receives tire pressure status from the BCM using CAN communication. When a low tire pressure condition is sensed by the BCM, the combination meter low tire pressure warning lamp is activated. A CHECK TIRE PRESSURE warning message will also be displayed in the vehicle information display. Refer to the Owner's Manual for additional information.



TIRE PRESSURE WARNING CHECK CONNECTOR

The tire pressure warning check connector can be grounded in order to initiate self-diagnosis without a CONSULT. Refer to [WT-31, "Self-Diagnosis \(Without CONSULT\)"](#). The tire pressure warning check connector is located behind the lower portion of the instrument panel LH.




DISPLAY UNIT

Displays the air pressure of each tire.

NOTE:

After the ignition switch is turned on, the pressure values will not be displayed until the data of each wheel is received.



DESCRIPTION

During driving, the tire pressure monitoring system receives the signal transmitted from the transmitter installed in each wheel, and turns on the low tire pressure warning lamp when the tire pressure becomes low. The control unit (BCM) for this system has pressure judgement and self-diagnosis functions.

FUNCTION


When the tire pressure monitoring system detects low inflation pressure or an internal malfunction, the low tire pressure warning lamp in the combination meter comes on. The malfunction is indicated by the low tire pressure warning lamp flashing.

TPMS

< SYSTEM DESCRIPTION >

System Component

INFOID:000000009824375



AWEIA0003ZZ

- | | | |
|---|---|--------------------------|
| 1. AV control unit M44, M46 (base audio system without NAVI) AV control unit M166, M171 (Bose audio system without NAVI) AV control unit M165 (with NAVI) | 2. Tire pressure warning check connector M123 | 3. Transmitter |
| 4. BCM M18, M20 | 5. Transmitter | 6. Combination meter M24 |
| 7. Display unit M93 (without NAVI) Display unit M168 (with NAVI) | 8. Remote keyless entry receiver M120 | |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009824376

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description |
|------------------------|--|
| ECU Identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM. |
| CAN Diag Support Mntr | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions.

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | ECU Identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock | DOOR LOCK | | × | × | × | × | | |
| Rear window defogger | REAR DEFOGGER | | | × | × | | | |
| Warning chime | BUZZER | | | × | × | | | |
| Interior room lamp timer | INT LAMP | | | × | × | × | | |
| Remote keyless entry system | MULTI REMOTE ENT | | | × | × | × | | |
| Exterior lamp | HEADLAMP | | | × | × | × | | |
| Wiper and washer | WIPER | | | × | × | × | | |
| Turn signal and hazard warning lamps | FLASHER | | | × | × | | | |
| Air conditioner | AIR CONDITIONER | | | × | | | | |
| Intelligent Key system | INTELLIGENT KEY | | | × | | | | |
| Combination switch | COMB SW | | | × | | | | |
| BCM | BCM | × | × | | | × | × | × |
| Immobilizer | IMMU | | × | × | × | | | |
| Interior room lamp battery saver | BATTERY SAVER | | | × | × | × | | |
| Back door open | TRUNK | | | × | × | | | |
| Vehicle security system | THEFT ALM | | | × | × | × | | |
| RAP system | RETAINED PWR | | | × | × | × | | |
| Signal buffer system | SIGNAL BUFFER | | | × | × | | | |
| TPMS | AIR PRESSURE MONITOR | | × | × | × | × | | |
| Panic alarm system | PANIC ALARM | | | | × | | | |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000009824377

SELF DIAGNOSTIC RESULT

NOTE:

Before performing Self Diagnostic Result, be sure to register the ID, or else the actual malfunction may be different from that displayed on CONSULT.

Refer to [BCS-44, "DTC Index"](#).

DATA MONITOR

| Monitor Item | Condition | Specification |
|---------------|--|--|
| VEHICLE SPEED | Drive vehicle. | Vehicle speed (km/h or mph) |
| AIR PRESS FL | <ul style="list-style-type: none">• Drive vehicle for a few minutes.or• Ignition switch ON and activation tool is transmitting activation signals. | Tire pressure (kPa, kg/cm ² or psi). |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |
| ID REGST FL1 | Ignition switch ON. | Registration ID: Green. No registration: Red. |
| ID REGST FR1 | | |
| ID REGST RR1 | | |
| ID REGST RL1 | | |
| WARNING LAMP | Ignition switch ON. | Low tire pressure warning lamp on: ON. Low tire pressure warning lamp off: OFF. |
| BUZZER | Ignition switch ON. | Buzzer in combination meter on: ON. Buzzer in combination meter off: OFF. |

ACTIVE TEST

| Test Item | Description |
|-------------------|---|
| WARNING LAMP | This test is able to check tire pressure warning lamp operation [On/Off]. |
| ID REGIST WARNING | This test is able to check ID regist warning chime operation [On/Off]. |
| FLAT TIRE WARNING | This test is able to check flat tire warning chime operation [On/Off]. |
| HORN | This test is able to check horn operation [On]. |
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

WORK SUPPORT

| Support Item | Description |
|--------------|--|
| ID REGIST | Refer to WT-6, "ID Registration Procedure" . |
| ID READ | The registered ID number is displayed. |

C1708 - C1711 DATA FROM TRANSMITTER NOT BEING RECEIVED

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

C1708 - C1711 DATA FROM TRANSMITTER NOT BEING RECEIVED

Description

INFOID:000000009824378

Tire pressure data for one or more transmitters is not being received by the BCM.

DTC Logic

INFOID:000000009824379

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DTC DETECTION LOGIC

| DTC | CONSULT | DTC detecting condition |
|-------|------------------|--|
| C1708 | [NO - DATA] - FL | Data from FL transmitter cannot be received. |
| C1709 | [NO - DATA] - FR | Data from FR transmitter cannot be received. |
| C1710 | [NO - DATA] - RR | Data from RR transmitter cannot be received. |
| C1711 | [NO - DATA] - RL | Data from RL transmitter cannot be received. |

DTC CONFIRMATION PROCEDURE

1.ID REGISTRATION AND VEHICLE DRIVING

1. Carry out ID registration of all transmitters.
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

- YES >> Inspection End.
NO >> Refer to [WT-13, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009824380

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

MALFUNCTION CODE NO. 21, 22, 23 OR 24 (DTC C1708, C1709, C1710 OR C1711)

1.CHECK BCM

Drive for several minutes. Check all tire pressures with CONSULT.

Are all tire pressures displayed as 0 kPa?

- YES >> GO TO 2
NO >> GO TO 3

2.CHECK TIRE PRESSURE RECEIVER CONNECTOR

Check tire pressure receiver connector for damage or loose connection.

Is tire pressure receiver connector damaged or loose?

- YES >> Repair or replace tire pressure receiver connector.

C1708 - C1711 DATA FROM TRANSMITTER NOT BEING RECEIVED

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace BCM, then GO TO 3. Refer to [BCS-54, "Removal and Installation"](#).

3. PERFORM ID REGISTRATION

Carry out ID registration of all transmitters. Refer to [WT-6, "ID Registration Procedure"](#).

Is there a tire that cannot register ID?

YES >> Replace malfunctioning transmitter, then GO TO 5. Refer to [WT-53, "Transmitter \(Pressure Sensor\)"](#).

NO >> GO TO 4

4. DRIVE VEHICLE

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

YES >> Inspection End.

NO >> GO TO 5

5. ID REGISTRATION AND VEHICLE DRIVING

1. Carry out ID registration of all transmitters. Refer to [WT-6, "ID Registration Procedure"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

YES >> Inspection End.

NO >> Proceed to the inspection applicable to DTC.

Special Repair Requirement

INFOID:000000009824381

Perform preliminary check. Refer to [WT-5, "Preliminary Check"](#).

C1712 - C1715, C1720 - C1723, C1724 - C1727 TRANSMITTER MALFUNCTION

< DTC/CIRCUIT DIAGNOSIS >

C1712 - C1715, C1720 - C1723, C1724 - C1727 TRANSMITTER MALFUNCTION

Description

INFOID:000000009824382

One or more transmitters are malfunctioning internally.

DTC Logic

INFOID:000000009824383

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DTC DETECTION LOGIC

| DTC | CONSULT | DTC detecting condition |
|-------|--------------------------|---|
| C1712 | [CHECKSUM - ERR] - FL | Checksum data from FL transmitter is malfunctioning. |
| C1713 | [CHECKSUM - ERR] - FR | Checksum data from FR transmitter is malfunctioning. |
| C1714 | [CHECKSUM - ERR] - RR | Checksum data from RR transmitter is malfunctioning. |
| C1715 | [CHECKSUM - ERR] - RL | Checksum data from RL transmitter is malfunctioning. |
| C1720 | [CODE - ERR] - FL | Function code data from FL transmitter is malfunctioning. |
| C1721 | [CODE - ERR] - FR | Function code data from FR transmitter is malfunctioning. |
| C1722 | [CODE - ERR] - RR | Function code data from RR transmitter is malfunctioning. |
| C1723 | [CODE - ERR] - RL | Function code data from RL transmitter is malfunctioning. |
| C1724 | [BATT - VOLT - LOW] - FL | Battery voltage of FL transmitter drops. |
| C1725 | [BATT - VOLT - LOW] - FR | Battery voltage of FR transmitter drops. |
| C1726 | [BATT - VOLT - LOW] - RR | Battery voltage of RR transmitter drops. |
| C1727 | [BATT - VOLT - LOW] - RL | Battery voltage of RL transmitter drops. |

DTC CONFIRMATION PROCEDURE

1. DRIVE VEHICLE

1. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
2. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

YES >> Inspection End.

NO >> Refer to [WT-15, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009824384

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

MALFUNCTION CODE NO. 31, 32, 33, 34, 41, 42, 43, 44, 45, 46, 47 OR 48 (DTC C1712, C1713, C1714, C1715, C1720, C1721, C1722, C1723, C1724, C1725, C1726 OR C1727)

1. PERFORM ID REGISTRATION

C1712 - C1715, C1720 - C1723, C1724 - C1727 TRANSMITTER MALFUNCTION

< DTC/CIRCUIT DIAGNOSIS >

1. Carry out ID registration of all transmitters. Refer to [WT-6, "ID Registration Procedure"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.

>> GO TO 2

2. REPLACE TRANSMITTER

1. Check low tire pressure warning lamp again for flashing, replace malfunctioning transmitter. Refer to [WT-53, "Transmitter \(Pressure Sensor\)"](#).
2. Carry out ID registration of all transmitters.

Can ID registration of all transmitters be completed?

YES >> GO TO 3

NO >> GO TO [WT-13, "Diagnosis Procedure"](#).

3. DRIVE VEHICLE

1. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
2. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

YES >> Inspection End.

NO >> Replace malfunctioning transmitter, and perform Step 3 again.

Special Repair Requirement

INFOID:000000009824385

Perform preliminary check. Refer to [WT-5, "Preliminary Check"](#).

C1716 - C1719 TRANSMITTER PRESSURE MALFUNCTION

< DTC/CIRCUIT DIAGNOSIS >

C1716 - C1719 TRANSMITTER PRESSURE MALFUNCTION

Description

INFOID:000000009824386

Air pressure data from one or more transmitters is out of range.

DTC Logic

INFOID:000000009824387

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DTC DETECTION LOGIC

| DTC | CONSULT | DTC detecting condition |
|-------|----------------------|--|
| C1716 | [PRESSDATA - ERR] FL | Air pressure data from FL transmitter is malfunctioning. |
| C1717 | [PRESSDATA - ERR] FR | Air pressure data from FR transmitter is malfunctioning. |
| C1718 | [PRESSDATA - ERR] RR | Air pressure data from RR transmitter is malfunctioning. |
| C1719 | [PRESSDATA - ERR] RL | Air pressure data from RL transmitter is malfunctioning. |

DTC CONFIRMATION PROCEDURE

1.ID REGISTRATION AND VEHICLE DRIVING

1. Carry out ID registration of all transmitters.
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

- YES >> Inspection End.
NO >> Refer to [WT-17, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009824388

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

MALFUNCTION CODE NO. 35, 36, 37 OR 38 (DTC C1716, C1717, C1718 OR C1719)

1.CHECK ALL TIRE PRESSURES

Check all tire pressures. Refer to [WT-55, "Tire"](#).

Are there any tires with pressure of 64 psi or more?

- YES >> Adjust tire pressure to specified value.
NO >> GO TO 2

2.ID REGISTRATION AND VEHICLE DRIVING

1. Carry out ID registration of all transmitters. Refer to [WT-6, "ID Registration Procedure"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
3. Check all tire pressures with CONSULT within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

Does "DATA MONITOR ITEM" display 64 psi or more?

C1716 - C1719 TRANSMITTER PRESSURE MALFUNCTION

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace transmitter. Refer to [WT-53. "Transmitter \(Pressure Sensor\)"](#). GO TO 3.
NO >> GO TO 3

3.ID REGISTRATION AND VEHICLE DRIVING

1. Carry out ID registration of all transmitters.
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Check all tire pressures with CONSULT within 5 minutes.

Does "DATA MONITOR ITEM" display tire pressure as normal without any warning lamp?

- YES >> Inspection End.
NO >> Proceed to the inspection applicable to DTC.

Special Repair Requirement

INFOID:000000009824389

Perform preliminary check. Refer to [WT-5. "Preliminary Check"](#).

C1729 VEHICLE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

C1729 VEHICLE SPEED SIGNAL

Description

INFOID:000000009824390

The vehicle speed signal is not being detected by the BCM.

DTC Logic

INFOID:000000009824391

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DTC DETECTION LOGIC

| DTC | CONSULT | DTC detecting condition |
|-------|--------------------|-----------------------------------|
| C1729 | VHCL SPEED SIG ERR | Vehicle speed signal is in error. |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

1. On "SELECT DIAG MODE", select the "SELF-DIAG RESULT" screen.
2. Check display contents on "SELF DIAG RESULT" screen.

Is the "CAN COMM CIRCUIT" displayed in the self-diagnosis display?

- YES >> Refer to [WT-19. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009824392

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

MALFUNCTION CODE NO. 52 (DTC C1729)

1. CHECK SELF-DIAGNOSTIC RESULTS

1. On "SELECT DIAG MODE", select the "SELF-DIAG RESULT" screen.
2. Check display contents on "SELF DIAG RESULT" screen.

Is the "CAN COMM CIRCUIT" displayed in the self-diagnosis display?

- YES >> Perform trouble diagnosis for CAN communication system. Refer to [LAN-14. "Trouble Diagnosis Flow Chart"](#).
NO >> Check combination meter. Refer to [MWI-27. "CONSULT Function \(METER/M&A\)"](#).

Special Repair Requirement

INFOID:000000009824393

Perform preliminary check. Refer to [WT-5. "Preliminary Check"](#).

C1735 IGNITION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

C1735 IGNITION SIGNAL

Description

INFOID:000000009824394

The BCM monitors the IGN ON signal on the CAN line and compares it to its direct IGN ON signal. When these two signals do not match, the BCM sets C1735.

DTC Logic

INFOID:000000009824395

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DTC DETECTION LOGIC

| DTC | CONSULT | DTC detecting condition |
|-------|---------------------------------|---|
| C1735 | IGNITION SIGNAL LINE - BCM/TPMS | BCM has detected a mismatch between IGN ON signals. |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

1. On SELECT DIAG MODE, select the SELF-DIAG RESULT screen.
2. Check display contents on SELF DIAG RESULT screen.

Is C1735 displayed in the self-diagnosis display?

- YES >> Refer to [WT-20, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009824396

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

MALFUNCTION CODE NO. 54 (DTC C1735)

1. CAN IGNITION SIGNAL

Check BCM IGN RLY signal with CONSULT. Refer to [BCS-35, "Reference Value"](#).

Are the inspection results normal with the ignition switch ON?

- YES >> GO TO 2.
NO >> Check CAN system. Refer to [LAN-46, "CAN System Specification Chart"](#).

2. BCM POWER SUPPLY

Check BCM power supply (ignition ON). Refer to [BCS-30, "Diagnosis Procedure"](#).

Is the power supply with the ignition switch ON normal?

- YES >> GO TO 3.
NO >> Repair power supply as necessary.

3. DRIVE VEHICLE

Clear DTC and then test drive the vehicle and check the low tire pressure warning lamp.

Does the vehicle operate without any low tire pressure warning lamp?

- YES >> Inspection End.
NO >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).

C1735 IGNITION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

Special Repair Requirement

INFOID:000000009824397

Perform preliminary check. Refer to [WT-5. "Preliminary Check"](#).

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000009824398

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|---------------|--|-------------------------------|
| ACC ON SW | Ignition switch OFF or ON | Off |
| | Ignition switch ACC | On |
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AIR PRESS FL | Front left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS FR | Front right tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RL | Rear left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RR | Rear right tire air pressure value | kPa, kg/cm ² , psi |
| AUTO LIGHT SW | Lighting switch OFF | Off |
| | Lighting switch AUTO | On |
| BACK DOOR SW | Back door closed | Off |
| | Back door opened | On |
| BRAKE SW | Brake pedal released | Off |
| | Brake pedal applied | On |
| BUCKLE SW | Seat belt buckle unfastened | Off |
| | Seat belt buckle fastened | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CARGO LAMP SW | Cargo lamp switch OFF | Off |
| | Cargo lamp switch ON | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the LOCK side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the UNLOCK side | On |
| DOOR SW-AS | Front door RH closed | Off |
| | Front door RH opened | On |
| DOOR SW-DR | Front door LH closed | Off |
| | Front door LH opened | On |
| DOOR SW-RL | Rear door LH closed | Off |
| | Rear door LH opened | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------------------|--|--------------|----|
| DOOR SW-RR | Rear door RH closed | Off | A |
| | Rear door RH opened | On | |
| FAN ON SIG | Blower motor fan switch OFF | Off | B |
| | Blower motor fan switch ON | On | |
| FR FOG SW | Front fog lamp switch OFF | Off | C |
| | Front fog lamp switch ON | On | |
| FR WASHER SW | Front washer switch OFF | Off | |
| | Front washer switch ON | On | D |
| FR WIPER LOW | Front wiper switch OFF | Off | |
| | Front wiper switch LO | On | |
| FR WIPER HI | Front wiper switch OFF | Off | WT |
| | Front wiper switch HI | On | |
| FR WIPER INT | Front wiper switch OFF | Off | F |
| | Front wiper switch INT | On | |
| FR WIPER STOP | Any position other than front wiper stop position | Off | |
| | Front wiper stop position | On | G |
| HAZARD SW | When hazard switch is not pressed | Off | |
| | When hazard switch is pressed | On | H |
| HEAD LAMP SW1 | Headlamp switch OFF | Off | |
| | Headlamp switch 1st | On | I |
| HEAD LAMP SW2 | Headlamp switch OFF | Off | |
| | Headlamp switch 1st | On | J |
| HI BEAM SW | High beam switch OFF | Off | |
| | High beam switch HI | On | K |
| ID REGST FL1 | ID registration of front left tire incomplete | YET | |
| | ID registration of front left tire complete | DONE | L |
| ID REGST FR1 | ID registration of front right tire incomplete | YET | |
| | ID registration of front right tire complete | DONE | M |
| ID REGST RL1 | ID registration of rear left tire incomplete | YET | |
| | ID registration of rear left tire complete | DONE | N |
| ID REGST RR1 | ID registration of rear right tire incomplete | YET | |
| | ID registration of rear right tire complete | DONE | O |
| IGN ON SW | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | P |
| IGN SW CAN | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | 1 - 7 | |
| I-KEY LOCK ¹ | LOCK button of Intelligent Key is not pressed | Off | |
| | LOCK button of Intelligent Key is pressed | On | |
| I-KEY PANIC ¹ | PANIC button of Intelligent Key is not pressed | Off | |
| | PANIC button of Intelligent Key is pressed | On | |
| I-KEY PW DWN ¹ | UNLOCK button of Intelligent Key is not pressed | Off | |
| | UNLOCK button of Intelligent Key is pressed for greater than 3 seconds and driver's window operating in DOWN direction | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|-----------------------------|--|-----------------------------------|
| I-KEY UNLOCK ¹ | UNLOCK button of Intelligent Key is not pressed | Off |
| | UNLOCK button of Intelligent Key is pressed | On |
| KEY CYL LK-SW | Door key cylinder LOCK position | Off |
| | Door key cylinder other than LOCK position | On |
| KEY CYL UN-SW | Door key cylinder UNLOCK position | Off |
| | Door key cylinder other than UNLOCK position | On |
| KEY ON SW | Mechanical key is removed from key cylinder | Off |
| | Mechanical key is inserted to key cylinder | On |
| KEYLESS LOCK ² | LOCK button of key fob is not pressed | Off |
| | LOCK button of key fob is pressed | On |
| KEYLESS PANIC ² | PANIC button of key fob is not pressed | Off |
| | PANIC button of key fob is pressed | On |
| KEYLESS UNLOCK ² | UNLOCK button of key fob is not pressed | Off |
| | UNLOCK button of key fob is pressed | On |
| LIGHT SW 1ST | Lighting switch OFF | Off |
| | Lighting switch 1st | On |
| OIL PRESS SW | <ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running | Off |
| | Ignition switch ON | On |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5V |
| | Dark outside of the vehicle | Close to 0V |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| PUSH SW ¹ | Return to ignition switch to LOCK position | Off |
| | Press ignition switch | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER INT | Rear wiper switch OFF | Off |
| | Rear wiper switch INT | On |
| RR WIPER ON | Rear wiper switch OFF | Off |
| | Rear wiper switch ON | On |
| RR WIPER STOP | Rear wiper stop position | Off |
| | Other than rear wiper stop position | On |
| RR WIPER STP2 | Rear wiper stop position | Off |
| | Other than rear wiper stop position | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| VEHICLE SPEED | While driving | Equivalent to speedometer reading |
| WARNING LAMP | Low tire pressure warning lamp in combination meter OFF | Off |
| | Low tire pressure warning lamp in combination meter ON | On |

1: With Intelligent Key


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

2: With remote keyless entry system

Terminal Layout

INFOID:000000009824399



A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P





Physical Values

LIIA2443E

INFOID:000000009824400

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 1 | BR/W | Ignition keyhole illumination | Output | OFF | Door is locked (SW OFF) | Battery voltage |
| | | | | | Door is unlocked (SW ON) | 0V |
| 2 | SB | Combination switch input 5 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 3 | G/Y | Combination switch input 4 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 4 | Y | Combination switch input 3 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 5 | G/B | Combination switch input 2 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 6 | V | Combination switch input 1 | | | | |
| 9 | R/G | Stop lamp switch | Input | OFF | Brake pedal depressed | Battery voltage |
| | | | | | Brake pedal released | 0V |
| 10 | G | Hazard lamp flash | Input | OFF | ON (opening or closing) | 0V |
| | | | | | OFF (other than above) | Battery voltage |
| 11 | O | Ignition switch (ACC or ON) | Input | ACC or ON | Ignition switch ACC or ON | Battery voltage |
| 12 | R/L | Front door switch RH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 13 | GR | Rear door switch RH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 15 | L/W | Tire pressure warning check connector | Input | OFF | — | 5V |
| 18 | P | Remote keyless entry receiver and optical sensor (ground) | Output | OFF | — | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|--|---------------------|---------------------|---|--|
| | | | | Ignition switch | Operation or condition | |
| 19 | V/W | Remote keyless entry receiver (power supply) | Output | OFF | Ignition switch OFF | <p style="text-align: right;">LIIA1893E</p> |
| 20 | G/W | Remote keyless entry receiver (signal) | Input | OFF | Stand-by (keyfob buttons released) | <p style="text-align: right;">LIIA1894E</p> |
| | | | | | When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed) | <p style="text-align: right;">LIIA1895E</p> |
| 21 | G | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 22 | W/V | BUS | — | — | Ignition switch ON or power window timer operates | <p style="text-align: right;">PIIA2344E</p> |
| 23 | G/O | Security indicator lamp | Output | OFF | Goes OFF → illuminates (Every 2.4 seconds) | Battery voltage → 0V |
| 25 | BR | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 26 | Y/L | Rear wiper auto stop switch 2 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | 0V |
| | | | | | Forward sweep (counterclockwise direction) | Fluctuating |
| | | | | | B Position (full counterclockwise stop position) | Battery voltage |
| | | | | | Reverse sweep (clockwise direction) | Fluctuating |
| 27 | W/R | Compressor ON signal | Input | ON | A/C switch OFF | 5V |
| | | | | | A/C switch ON | 0V |

A

B

C

D

WT

F

G

H

I

J

K

L

M





N

O

P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|-----------------|------------|-------------------------------------|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 28 | L/R | Front blower monitor | Input | ON | Front blower motor OFF | Battery voltage |
| | | | | | Front blower motor ON | 0V |
| 29 | W/B | Hazard switch | Input | OFF | ON | 0V |
| | | | | | OFF | 5V |
| 32 | R/G | Combination switch output 5 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 33 | R/Y | Combination switch output 4 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 34 | L | Combination switch output 3 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 35 | O/B | Combination switch output 2 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 36 | R/W | Combination switch output 1 | | | | |
| 37 ¹ | B/R | Key switch and ignition knob switch | Input | OFF | Intelligent Key inserted | Battery voltage |
| | | | | | Intelligent Key removed | 0V |
| 37 ² | B/R | Key switch and key lock solenoid | Input | OFF | Key inserted | Battery voltage |
| | | | | | Key removed | 0V |
| 38 | W/L | Ignition switch (ON) | Input | ON | — | Battery voltage |
| 39 | L | CAN-H | — | — | — | — |
| 40 | P | CAN-L | — | — | — | — |
| 41 | GR/R | Rear window defogger switch | Input | ON | Rear window defogger switch ON | 0V |
| | | | | | Rear window defogger switch OFF | 5V |
| 42 | GR | Glass hatch ajar switch | Input | ON | Glass hatch open | 0 |
| | | | | | Glass hatch closed | Battery |

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 43 | R/B | Back door switch (without power back door) or back door latch (door ajar switch) (with power back door) | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 44 | O | Rear wiper auto stop switch 1 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | Battery voltage |
| | | | | | Forward sweep (counterclockwise direction) | Fluctuating |
| | | | | | B Position (full counterclockwise stop position) | 0V |
| | | | | | Reverse sweep (clockwise direction) | Fluctuating |
| 47 | SB | Front door switch LH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 48 | R/Y | Rear door switch LH | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 49 | R | Cargo lamp | Output | OFF | Any door open (ON) | 0V |
| | | | | | All doors closed (OFF) | Battery voltage |
| 51 | Y/B | Trailer turn signal (right) | Output | ON | Turn right ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 52 | G/B | Trailer turn signal (left) | Output | ON | Turn left ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 54 | Y | Rear wiper output circuit 2 | Input | ON | Rise up position (rear wiper arm on stopper) | 0V |
| | | | | | A Position (full clockwise stop position) | 0V |
| | | | | | Forward sweep (counterclockwise direction) | 0V |
| | | | | | B Position (full counterclockwise stop position) | Battery voltage |
| | | | | | Reverse sweep (clockwise direction) | Battery voltage |
| 55 | SB | Rear wiper output circuit 1 | Output | ON | OFF | 0 |
| | | | | | ON | Battery voltage |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) | |
|----------|------------|--|---------------------|---------------------|---|--|----|
| | | | | Ignition switch | Operation or condition | | |
| 56 | R/G | Battery saver output | Output | OFF | 10 minutes after ignition switch is turned OFF | 0V | |
| | | | | ON | — | Battery voltage | |
| 57 | Y/R | Battery power supply | Input | OFF | — | Battery voltage | |
| 58 | W/R | Optical sensor | Input | ON | When optical sensor is illuminated | 3.1V or more | |
| | | | | | When optical sensor is not illuminated | 0.6V or less | |
| 59 | G | Front door lock assembly LH actuator (unlock) | Output | OFF | OFF (neutral) | 0V | |
| | | | | | ON (unlock) | Battery voltage | |
| 60 | G/B | Turn signal (left) | Output | ON | Turn left ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> | |
| 61 | G/Y | Turn signal (right) | Output | ON | Turn right ON |  <p style="text-align: right; font-size: small;">SKIA3009J</p> | |
| 62 | R/W | Step lamp LH and RH | Output | OFF | ON (any door open) | 0V | |
| | | | | | OFF (all doors closed) | Battery voltage | |
| 63 | L | Interior room/map lamp | Output | OFF | Any door switch | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage | |
| 65 | V | All door lock actuators (lock) | Output | OFF | OFF (neutral) | 0V | |
| | | | | | ON (lock) | Battery voltage | |
| 66 | G/Y | Front door lock actuator RH, rear door lock actuators LH/RH and back door lock actuator (unlock) | Output | OFF | OFF (neutral) | 0V | |
| | | | | | ON (unlock) | Battery voltage | |
| 67 | B | Ground | Input | ON | — | 0V | |
| 68 | W/L | Power window power supply (RAP) | Output | — | Ignition switch ON | Battery voltage | |
| | | | | | Within 45 seconds after ignition switch OFF | Battery voltage | |
| | | | | | More than 45 seconds after ignition switch OFF | 0V | |
| | | | | | When front door LH or RH is open or power window timer operates | 0V | |
| 69 | W/R | Power window power supply | Output | — | — | Battery voltage | |
| 70 | W/B | Battery power supply | Input | OFF | — | Battery voltage | |

1: With Intelligent Key system

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

2: With remote keyless entry system

Self-Diagnosis (With CONSULT)

INFOID:000000009824401

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

FUNCTION

Self-Diagnostic Results Mode

| Diagnostic item | Diagnostic item is detected when ... | Reference page |
|--|--|-----------------------|
| LOW - PRESSURE - FL [C1704] LOW - PRESSURE - FR [C1705] LOW - PRESSURE - RR [C1706] LOW - PRESSURE - RL [C1707] | Tire pressures dropped below specified value. Refer to WT-8 , " System Description ". | — |
| [NO-DATA] - FL [C1708] [NO-DATA] - FR [C1709] [NO-DATA] - RR [C1710] [NO-DATA] - RL [C1711] | Data from FL transmitter cannot be received. Data from FR transmitter cannot be received. Data from RR transmitter cannot be received. Data from RL transmitter cannot be received. | WT-13 |
| [CHECKSUM- ERR] - FL [C1712] [CHECKSUM- ERR] - FR [C1713] [CHECKSUM- ERR] - RR [C1714] [CHECKSUM- ERR] - RL [C1715] | Checksum data from FL transmitter is malfunctioning. Checksum data from FR transmitter is malfunctioning. Checksum data from RR transmitter is malfunctioning. Checksum data from RL transmitter is malfunctioning. | WT-15 |
| [PRESSDATA- ERR] - FL [C1716] [PRESSDATA- ERR] - FR [C1717] [PRESSDATA- ERR] - RR [C1718] [PRESSDATA- ERR] - RL [C1719] | Air pressure data from FL transmitter is malfunctioning. Air pressure data from FR transmitter is malfunctioning. Air pressure data from RR transmitter is malfunctioning. Air pressure data from RL transmitter is malfunctioning. | WT-17 |
| [CODE- ERR] - FL [C1720] [CODE- ERR] - FR [C1721] [CODE- ERR] - RR [C1722] [CODE- ERR] - RL [C1723] | Function code data from FL transmitter is malfunctioning. Function code data from FR transmitter is malfunctioning. Function code data from RR transmitter is malfunctioning. Function code data from RL transmitter is malfunctioning. | WT-15 |
| [BATT - VOLT - LOW] - FL [C1724] [BATT - VOLT - LOW] - FR [C1725] [BATT - VOLT - LOW] - RR [C1726] [BATT - VOLT - LOW] - RL [C1727] | Battery voltage of FL transmitter drops. Battery voltage of FR transmitter drops. Battery voltage of RR transmitter drops. Battery voltage of RL transmitter drops. | WT-15 |
| VHCL_SPEED_SIG_ERR [C1729] | Vehicle speed signal is in error. | WT-19 |
| IGN_CIRCUIT_OPEN [C1735] | Vehicle ignition signal is in error. | WT-20 |

NOTE:

Before performing the self-diagnosis, be sure to register the ID or else the actual malfunction location may be different from that displayed on CONSULT.

Self-Diagnosis (Without CONSULT)

INFOID:000000009824402

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs


SELF DIAGNOSTIC PROCEDURE (WITHOUT CONSULT)

1. Turn ignition switch ON.
2. Ground the tire pressure warning check connector to initiate self diagnosis.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

3. Compare the flashing pattern with the flash code chart below.



NOTE:

The system is normal when the low tire pressure warning lamp flashes 5 times and continues repeating. Self-diagnosis results are erased automatically by turning the ignition switch "OFF".

| Flash Code | Malfunction part | Reference page |
|----------------------|--|-----------------------|
| 15 16 17 18 | Tire pressure dropped below specified value. Refer to WT-8. "System Description" . | — |
| 21 22 23 24 | Transmitter no data (FL) Transmitter no data (FR) Transmitter no data (RR) Transmitter no data (RL) | WT-13 |
| 31 32 33 34 | Transmitter checksum error (FL) Transmitter checksum error (FR) Transmitter checksum error (RR) Transmitter checksum error (RL) | WT-15 |
| 35 36 37 38 | Transmitter pressure data error (FL) Transmitter pressure data error (FR) Transmitter pressure data error (RR) Transmitter pressure data error (RL) | WT-17 |
| 41 42 43 44 | Transmitter function code error (FL) Transmitter function code error (FR) Transmitter function code error (RR) Transmitter function code error (RL) | WT-15 |
| 45 46 47 48 | Transmitter battery voltage low (FL) Transmitter battery voltage low (FR) Transmitter battery voltage low (RR) Transmitter battery voltage low (RL) | WT-15 |
| 52 | Vehicle speed signal | WT-19 |
| 54 | Vehicle ignition signal | WT-20 |

TIRE PRESSURE MONITORING SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

TIRE PRESSURE MONITORING SYSTEM

Wiring Diagram

INFOID:000000009824403



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >

TIRE PRESSURE MONITORING SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|
| 7P | 6P | 5P | 4P | 3P | 2P | 1P |
| 11P | 15P | 14P | 13P | 12P | 11P | 10P |
| 9P | 8P | | | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5P | O/L | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------------|
| 15 | L/W | TPMS MODE TRIGGER SW |
| 18 | P | KEYLESS AND AUTO LIGHT SENSOR GND |
| 19 | V/W | KEYLESS TUNER POWER SUPPLY OUTPUT |
| 20 | G/W | KEYLESS TUNER SIGNAL |
| 38 | W/L | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 67 | B | GND (POWER) |
| 70 | W/B | BAT (FL) |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | ACCESSORY |
| 8 | Y/R | BATTERY |
| 9 | B | GND |
| 11 | L | CAN-H |
| 12 | P | CAN-L |
| 24 | O/L | RUN/START |

ABEIA0172GB

TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|------------------|
| Connector No. | M39 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4Q | Y/R | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 96G | W/B | - |
| 99G | W/L | - |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6T | O | - |

| | |
|-----------------|--|
| Connector No. | M46 |
| Connector Name | AV CONTROL UNIT (WITH BASE AUDIO SYSTEM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 86 | L | CAN-H |
| 87 | P | CAN-L |

| | |
|-----------------|--|
| Connector No. | M44 |
| Connector Name | AV CONTROL UNIT (WITH BASE AUDIO SYSTEM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 44 | LG | DISP IT |
| 55 | SHIELD | SHIELD |
| 56 | V | IT DISP |

ABEIA0173GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

TIRE PRESSURE MONITORING SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|---------------------------------------|
| Connector No. | M123 |
| Connector Name | TIRE PRESSURE WARNING CHECK CONNECTOR |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L/W | - |
| 2 | - | - |

| | |
|-----------------|-------------------------------|
| Connector No. | M120 |
| Connector Name | REMOTE KEYLESS ENTRY RECEIVER |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | G/W | - |
| 4 | V/W | - |

| | |
|-----------------|-----------------------------|
| Connector No. | M93 |
| Connector Name | DISPLAY UNIT (WITHOUT NAVI) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 11 | V | IT DISP |
| 22 | LG | DISP IT |
| 23 | SHIELD | SHIELD |

| | |
|-----------------|--------------------------|
| Connector No. | M168 |
| Connector Name | DISPLAY UNIT (WITH NAVI) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | LG | DISP IT |
| 10 | V | IT DISP |
| 22 | SHIELD | SHIELD |

| | |
|-----------------|---|
| Connector No. | M166 |
| Connector Name | AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 86 | L | CAN-H |
| 87 | P | CAN-L |

| | |
|-----------------|--|
| Connector No. | M165 |
| Connector Name | AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 61 | V | IT DISP |
| 62 | P | CAN-L |
| 76 | SHIELD | SHIELD |
| 77 | LG | DISP IT |
| 78 | L | CAN-H |

ABEIA0174GB

TIRE PRESSURE MONITORING SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|---------------------|
| Connector No. | M176 |
| Connector Name | JOINT CONNECTOR-M11 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | L | - |
| 10 | P | - |
| 13 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M175 |
| Connector Name | JOINT CONNECTOR-M10 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | L | - |
| 6 | L | - |
| 10 | P | - |
| 13 | P | - |
| 15 | P | - |

| | |
|-----------------|--|
| Connector No. | M171 |
| Connector Name | AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 44 | LG | DISP IT |
| 55 | SHIELD | SHIELD |
| 56 | V | IT DISP |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



ABEIA0175GB

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TPMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

TPMS

Symptom Table

INFOID:000000009824404

| Symptom | Reference |
|--|-----------------------|
| Low tire pressure warning lamp does not come on when ignition switch is turned ON. | WT-39 |
| Low tire pressure warning lamp stays on when ignition switch is turned ON. | WT-40 |
| Low tire pressure warning lamp flashes when ignition switch is turned ON. | WT-41 |
| Hazard warning lamps flash when ignition switch is turned ON. | WT-42 |
| Tire pressure information in display unit does not exist. | WT-43 |
| ID registration cannot be completed. | WT-44 |

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

Low Tire Pressure Warning Lamp Does Not Come On When Ignition Switch Is Turned On

INFOID:000000009824405

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DIAGNOSTIC PROCEDURE

1. SELF-DIAGNOSTIC RESULT CHECK

Using CONSULT, check display contents of BCM in SELF-DIAGNOSIS.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

- YES >> Malfunction in CAN communication system. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
NO >> GO TO 2

2. CHECK COMBINATION METER

Check combination meter operation. Refer to [MWI-27, "CONSULT Function \(METER/M&A\)"](#).

Is the inspection result normal?

- YES >> GO TO 3
NO >> Replace combination meter. Refer to [MWI-98, "Removal and Installation"](#).

3. CHECK LOW TIRE PRESSURE WARNING LAMP

Disconnect BCM harness connector.

Does the low tire pressure warning lamp activate?

- YES >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).
NO >> Check combination meter operation.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

LOW TIRE PRESSURE WARNING LAMP STAYS ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP STAYS ON

Low Tire Pressure Warning Lamp Stays On When Ignition Switch Is Turned On

INFOID:000000009824406

DIAGNOSTIC PROCEDURE

1. BCM CONNECTORS

1. Turn ignition switch OFF.
2. Disconnect BCM harness connectors.
3. Check terminals for damage or loose connections.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace damaged parts.

2. BCM POWER SUPPLY AND GROUND CIRCUITS

Check BCM power supply and ground circuits. Refer to [BCS-30. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-54. "Removal and Installation"](#).
NO >> Repair BCM circuits.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP BLINKS

Low Tire Pressure Warning Lamp Flashes When Ignition Switch Is Turned On

INFOID:000000009824407


Regarding Wiring Diagram information, refer to [WT-33. "Wiring Diagram"](#).

NOTE:

If low tire pressure warning lamp flashes as shown, the system is normal.

Flash Mode A

- This mode shows transmitter status is OFF-mode.
Carry out transmitter wake up operation. Refer to [WT-5. "Transmitter Wake Up Operation"](#).



DIAGNOSTIC PROCEDURE

1. CHECK BCM CONNECTORS

1. Turn ignition switch OFF.
2. Disconnect BCM harness connectors.
3. Check terminals for damage or loose connections.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace damaged parts.


2. CHECK TIRE PRESSURE WARNING CHECK CONNECTOR CIRCUIT

Check continuity between BCM harness connector M18 terminal 15 and ground.

Continuity should not exist.

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-54. "Removal and Installation"](#).
- NO >> Repair circuit for short to ground.



HAZARD WARNING LAMPS FLASH

< SYMPTOM DIAGNOSIS >

HAZARD WARNING LAMPS FLASH

Hazard Warning Lamps Flash When Ignition Switch Is Turned On

INFOID:000000009824408

DIAGNOSTIC PROCEDURE

1. CHECK BCM GROUND CIRCUIT

Check BCM ground circuit. Refer to [BCS-30, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).
- NO >> Repair BCM ground circuit.

"TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST

< SYMPTOM DIAGNOSIS >

"TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST

"TIRE PRESSURE" Information in Display Unit Does Not Exist

INFOID:000000009824409

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DIAGNOSTIC PROCEDURE

1. SELF-DIAGNOSTIC RESULT CHECK

Using CONSULT, check display contents in self-diagnostic results.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

- YES >> Malfunction in CAN communication system. Refer to [LAN-14. "Trouble Diagnosis Flow Chart"](#).
NO >> GO TO 2.

2. CHECK DISPLAY UNIT

Perform display unit self-diagnosis. Refer to [AV-318. "AV CONTROL UNIT : CONSULT Function"](#) (with NAVI) or [AV-143. "AV CONTROL UNIT : CONSULT Function"](#) (without NAVI).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-54. "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

ID REGISTRATION CANNOT BE COMPLETED

ID Registration Cannot Be Completed

INFOID:000000009824410

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

DIAGNOSTIC PROCEDURE

1. PERFORM ID REGISTRATION OF ALL TRANSMITTERS

Carry out ID registration of all transmitters. Refer to [WT-6, "ID Registration Procedure"](#).

Can ID registration of all transmitters be completed?

- YES >> Inspection End.
NO >> Refer to [WT-13, "Diagnosis Procedure"](#).

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000009824411

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom | | Possible cause and SUSPECTED PARTS | | | | | | | | | | | | | Reference page | | |
|------------|-------------------------------|------------------------------------|-----------|-------------------------|------------------|-----------------------|----------------|---------------------|----------------------------|---------------------------------|-------------------------------|-------|------------|-------|----------------|----------|---|
| | | Out-of-round | Imbalance | Incorrect tire pressure | Uneven tire wear | Deformation or damage | Non-uniformity | Incorrect tire size | FRONT AND REAR FINAL DRIVE | FRONT AXLE AND FRONT SUSPENSION | REAR AXLE AND REAR SUSPENSION | TIRES | ROAD WHEEL | BRAKE | | STEERING | |
| TIRES | Noise | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | WT-49 |
| | Shake | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | WT-50 |
| | Vibration | | | x | | | | | x | | x | x | | | | | WT-55 |
| | Shimmy | x | x | x | x | x | x | x | x | | x | x | x | x | x | x | WT-51 |
| | Shudder | x | x | x | x | x | x | x | x | | x | x | x | x | x | x | — |
| | Poor quality ride or handling | x | x | x | x | x | x | x | x | | x | x | x | | | | — |
| | | | | | | | | | | | | | | | | | WT-55 |
| ROAD WHEEL | Noise | x | x | | | x | | | x | x | x | x | x | x | x | | DLN-207, "NVH Troubleshooting Chart" (FFD) DLN-240, "NVH Troubleshooting Chart" (RFD) |
| | Shake | x | x | | | x | | | x | x | x | x | x | x | x | | FAX-5, "NVH Troubleshooting Chart" (FAX) FSU-5, "NVH Troubleshooting Chart" (FSU) |
| | Shimmy, shudder | x | x | | | x | | | x | x | x | x | x | x | x | | RAX-5, "NVH Troubleshooting Chart" (RAX) RSU-5, "NVH Troubleshooting Chart" (RSU) |
| | Poor quality ride or handling | x | x | | | x | | | x | x | x | x | x | x | x | | Refer to TIRES in this chart. Refer to ROAD WHEEL in this chart. BR-6, "NVH Troubleshooting Chart" ST-9, "NVH Troubleshooting Chart" |

x: Applicable

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009824412

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000009824413

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Work

INFOID:000000009824414

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
- Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
- Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:00000000982415

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|---|---|
| KV991B1000 (J-45295) Transmitter activation tool  WEIA0144E | <ul style="list-style-type: none"> • Transmitter wake up operation • ID registration procedure |
| — (J-50190) Signal Tech II  ALEIA0131ZZ | <ul style="list-style-type: none"> • Activate and display TPMS transmitter IDs • Display tire pressure reported by the TPMS transmitter • Read TPMS DTCs • Register TPMS transmitter IDs • Check Intelligent Key relative signal strength • Confirm vehicle Intelligent Key antenna signal strength |

Commercial Service Tool

INFOID:00000000982416

| Tool name | Description |
|---|----------------------------------|
| Power tool  PIIB1407E | Loosening nuts, screws and bolts |

WHEEL

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

WHEEL


Inspection

INFOID:000000009824417

ALUMINUM WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from wheel and mount wheel on a balancer machine.
 - b. Set dial indicator as shown.

Wheel runout (Dial indicator value):
Refer to [WT-55, "Road Wheel"](#).




STEEL WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks, and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from wheel and mount on a balancer machine.
 - b. Set two dial indicators as shown.
 - c. Set each dial indicator to 0.
 - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
 - e. Calculate runout at each point as shown.

Radial runout = (A+B)/2
Lateral runout = (C+D)/2

- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout. In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout. If the total runout value exceeds the limit, replace the steel wheel.

Wheel runout : Refer to [WT-55, "Road Wheel"](#)



WHEEL AND TIRE ASSEMBLY

< PERIODIC MAINTENANCE >

WHEEL AND TIRE ASSEMBLY

Balancing Wheels

INFOID:000000009824418

BALANCING WHEELS (ADHESIVE WEIGHT TYPE)

Preparation Before Adjustment

Remove inner and outer balance weights from the road wheel using releasing agent. Remove double-faced adhesive tape from the road wheel.

CAUTION:

- **Be careful not to scratch the road wheel during removal.**
- **After removing double-faced adhesive tape, wipe clean all traces of releasing agent from the road wheel.**

Wheel Balance Adjustment

CAUTION:

- **DO NOT use center hole cone-type clamping machines to hold the wheel assembly during tire removal/installation or balancing or damage to the wheel paint, cladding or chrome may result. Use only rim-type or universal lug-type clamping machines to hold the wheel assembly during servicing.**
- If a balancer machine has an adhesive weight mode setting, select the adhesive weight mode setting and skip Step 2. below. If a balancer machine only has the clip-on (rim flange) weight mode setting, follow Step 2. to calculate the correct size adhesive weight.

1. Set road wheel on balancer machine using the center hole as a guide. Start the balancer machine.
2. For balancer machines that only have a clip-on (rim flange) weight mode setting, follow this step to calculate the correct size adhesive weight to use. When inner and outer imbalance values are shown on the balancer machine indicator, multiply outer imbalance value by 5/3 (1.67) to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install in to the designated outer position of, or at the designated angle in relation to the road wheel.

- a. Indicated imbalance value $\times 5/3 =$ balance weight to be installed

Calculation example:

$23 \text{ g (0.81 oz)} \times 5/3 (1.67) = 38.33 \text{ g (1.35 oz)} \Rightarrow 40 \text{ g (1.41 oz)}$
balance weight (closer to calculated balance weight value)


NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

$37.4 \Rightarrow 35 \text{ g (1.23 oz)}$

$37.5 \Rightarrow 40 \text{ g (1.41 oz)}$



WHEEL AND TIRE ASSEMBLY

< PERIODIC MAINTENANCE >


3. Install balance weight in the position shown.

CAUTION:

- Do not install the inner balance weight before installing the outer balance weight.
- Before installing the balance weight, be sure to clean the mating surface of the road wheel.
- When installing balance weight (1) to road wheel, set it into the grooved area (A) on the inner wall of the road wheel as shown so that the balance weight center (B) is aligned with the balancer machine indication position (angle) (C).

CAUTION:

- Always use genuine NISSAN adhesive balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



4. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown.

CAUTION:

- Do not install one balance weight sheet on top another.

5. Start balancer machine again.


6. Install balance weight on inner side of road wheel in the balancer machine indication position (angle).

CAUTION:

- Do not install more than two balance weights.

7. Start balancer machine. Make sure that inner and outer residual imbalance values are 5 g (0.17 oz) each or below.

8. If either residual imbalance value exceeds 5 g (0.17 oz), repeat installation procedures.



| Wheel balance | Dynamic (At flange) | Static (At flange) |
|-----------------------------|--|--------------------|
| Maximum allowable imbalance | Refer to WT-55, "Road Wheel" . | |

Rotation

INFOID:000000009824419


TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-10, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#) (FOR USA AND CANADA), [MA-13, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (FOR MEXICO).
- Rotate the wheel and tires front to back in the pattern as shown. When installing the wheel and tires, tighten the wheel nuts diagonally to the specified torque.

Wheel nut tightening torque : 133 N·m (14 kg·m, 98 ft·lb)

CAUTION:

- Do not include the spare wheel and tire when rotating the wheel and tires.



WHEEL AND TIRE ASSEMBLY

< PERIODIC MAINTENANCE >

- **When installing the wheel nuts, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.**
- **Be careful not to tighten the wheel nuts to a torque exceeding specification to prevent strain on the disc rotor.**
- **Use genuine NISSAN wheel nuts for aluminum wheels.**

TRANSMITTER

< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

TRANSMITTER

Transmitter (Pressure Sensor)


INFOID:000000009824420

REMOVAL

CAUTION:

- **DO NOT** use center hole cone-type clamping machines to hold the wheel assembly during tire removal/installation or balancing or damage to the wheel paint, cladding or chrome may result. Use only rim-type or universal lug-type clamping machines to hold the wheel assembly during servicing.

1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
2. Gently bounce tire so that transmitter falls to bottom of tire. Place wheel and tire assembly on tire changing machine and break both tire beads. Make sure that the transmitter remains at the bottom of the tire while breaking the bead.




3. Turn tire so that valve hole is at bottom, and gently bounce the tire to make sure transmitter is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270 degrees from mounting/dismounting head.
4. Lubricate tire well with a suitable non-silicone lubricant, and remove top side of tire. Reach inside the tire and remove the transmitter.

CAUTION:

Do not use silicone lubricant. Use of silicone lubricant will deteriorate the tire and wheel.

5. Remove the second side of the tire as normal.




INSTALLATION

CAUTION:

- **DO NOT** use center hole cone-type clamping machines to hold the wheel assembly during tire removal/installation or balancing or damage to the wheel paint, cladding or chrome may result. Use only rim-type or universal lug-type clamping machines to hold the wheel assembly during servicing.

1. Place first side of tire onto rim.



A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TRANSMITTER


< UNIT REMOVAL AND INSTALLATION >

2. Mount transmitter on rim and slowly tighten transmitter nut to specification.

CAUTION:

- Do not over tighten transmitter nut.
- Do not use silicone lubricant. Use of silicone lubricant will deteriorate the tire and wheel.
- Do not reuse seal.

Transmitter nut : 7.7 N·m (0.79 kg·m, 68 in·lb)



3. Place wheel on turntable of tire machine. Make sure that transmitter is 270 degrees from mounting/dismounting head.

NOTE:

Do not touch transmitter with mounting head.

4. Lubricate tire well with a suitable non-silicone lubricant, and install second side of tire as normal. Make sure that tire does not rotate relative to rim.

CAUTION:

Do not use silicone lubricant. Use of silicone lubricant will deteriorate the tire and wheel.


5. Inflate tire and balance the wheel and tire assembly. Refer to [WT-50, "Balancing Wheels"](#).

6. Install wheel and tire assembly in appropriate wheel position on vehicle.

NOTE:

If replacing transmitter, transmitter wake up operation must be performed. Refer to [WT-5, "Transmitter Wake Up Operation"](#).

7. Adjust neutral position of steering angle sensor. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Road Wheel

INFOID:000000009824421

| Wheel type | | Aluminum | Steel | |
|-----------------------------|-------------------------|------------------------------------|---------------------|---------------------|
| | | | Inside | Outside |
| Maximum radial runout limit | Lateral mm (in) | 0.3 (0.012) or less | 1.0 (0.039) or less | 0.9 (0.035) or less |
| | Radial mm (in) | 0.3 (0.012) or less | 0.8 (0.031) or less | 0.4 (0.016) or less |
| Maximum residual imbalance | Dynamic (at rim flange) | Less than 5 g (0.18 oz) (per side) | | |
| | Static (at rim flange) | Less than 10 g (0.35 oz) | | |

Tire

INFOID:000000009824422

Unit: kPa (kg/cm², psi)

| Tire size | Air pressure | |
|------------|-------------------|---------------|
| | Conventional tire | Spare tire |
| P265/70R18 | 250 (2.5, 36) | 250 (2.5, 36) |
| P275/60R20 | 250 (2.5, 36) | 250 (2.5, 36) |