

# SECTION **SRC**

## SRS AIRBAG CONTROL SYSTEM

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

### CONTENTS

<p><b>BASIC INSPECTION</b> ..... 3</p> <p><b>DIAGNOSIS AND REPAIR WORK FLOW</b> ..... 3</p> <p style="padding-left: 20px;">Work Flow .....3</p> <p><b>INTERMITTENTS INCIDENT</b> ..... 5</p> <p style="padding-left: 20px;">Inspection Procedure .....5</p> <p style="padding-left: 20px;">Trouble Diagnosis with CONSULT .....5</p> <p><b>SYSTEM DESCRIPTION</b> ..... 6</p> <p><b>SRS AIR BAG SYSTEM</b> ..... 6</p> <p style="padding-left: 20px;">SRS Configuration .....6</p> <p style="padding-left: 20px;">SRS Component Parts Location .....7</p> <p style="padding-left: 20px;">Driver Air Bag Module .....7</p> <p style="padding-left: 20px;">Front Passenger Air Bag Module .....8</p> <p style="padding-left: 20px;">Front Side Air Bag .....8</p> <p style="padding-left: 20px;">Side Curtain Air Bag .....8</p> <p style="padding-left: 20px;">Front Seat Belt Pre-tensioner with Load Limiter .....8</p> <p style="padding-left: 20px;">Front Door Satellite Sensor .....9</p> <p style="padding-left: 20px;">SRS Component Connectors .....9</p> <p><b>OCCUPANT CLASSIFICATION SYSTEM</b> .....11</p> <p style="padding-left: 20px;">System Diagram .....11</p> <p style="padding-left: 20px;">Occupant Classification System (OCS) .....11</p> <p><b>PASSENGER SEAT BELT WARNING SYSTEM</b> .....13</p> <p style="padding-left: 20px;">System Diagram .....13</p> <p style="padding-left: 20px;">System Description .....13</p> <p style="padding-left: 20px;">Component Parts Location .....13</p> <p><b>ON BOARD DIAGNOSTIC (OBD) SYSTEM</b> .....14</p> <p style="padding-left: 20px;">Trouble Diagnosis Introduction .....14</p> <p style="padding-left: 20px;">SRS Operation Check .....14</p> <p style="padding-left: 20px;">Trouble Diagnosis without CONSULT .....16</p> <p style="padding-left: 20px;">CONSULT Function (AIR BAG) .....16</p> <p style="padding-left: 20px;">Self-Diagnosis Function (Without CONSULT) .....16</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> .....18</p>	<p><b>B1049 – B1052, B1054 – B1057 DRIVER AIR-BAG MODULE</b> .....18</p> <p style="padding-left: 20px;">Description .....18</p> <p style="padding-left: 20px;">DTC Logic .....18</p> <p style="padding-left: 20px;">Diagnosis Procedure .....19</p> <p><b>B1065 – B1068, B1070 – B1073 PASSENGER AIRBAG MODULE</b> .....21</p> <p style="padding-left: 20px;">Description .....21</p> <p style="padding-left: 20px;">DTC Logic .....21</p> <p style="padding-left: 20px;">Diagnosis Procedure .....22</p> <p><b>B1134 – B1137 SIDE AIRBAG MODULE LH</b> ...24</p> <p style="padding-left: 20px;">Description .....24</p> <p style="padding-left: 20px;">DTC Logic .....24</p> <p style="padding-left: 20px;">Diagnosis Procedure .....24</p> <p><b>B1129 – B1132 SIDE AIRBAG MODULE RH</b> ...27</p> <p style="padding-left: 20px;">Description .....27</p> <p style="padding-left: 20px;">DTC Logic .....27</p> <p style="padding-left: 20px;">Diagnosis Procedure .....27</p> <p><b>B1198 – B1201 SIDE CURTAIN AIR BAG MODULE LH (FRONT)</b> .....30</p> <p style="padding-left: 20px;">Description .....30</p> <p style="padding-left: 20px;">DTC Logic .....30</p> <p style="padding-left: 20px;">Diagnosis Procedure .....30</p> <p><b>B1193 – B1196 SIDE CURTAIN AIR BAG MODULE RH (FRONT)</b> .....33</p> <p style="padding-left: 20px;">Description .....33</p> <p style="padding-left: 20px;">DTC Logic .....33</p> <p style="padding-left: 20px;">Diagnosis Procedure .....33</p> <p><b>B1150 – B1153 SIDE CURTAIN AIR BAG MODULE LH (REAR)</b> .....36</p> <p style="padding-left: 20px;">Description .....36</p> <p style="padding-left: 20px;">DTC Logic .....36</p> <p style="padding-left: 20px;">Diagnosis Procedure .....36</p> <p><b>B1145 – B1148 SIDE CURTAIN AIR BAG MODULE RH (REAR)</b> .....39</p>
---	--

Description .....	39	DTC Logic .....	66
DTC Logic .....	39	Diagnosis Procedure .....	66
Diagnosis Procedure .....	39		
<b>B1086 – B1089 SEAT BELT PRE-TENSIONER LH .....</b>	<b>42</b>	<b>B1XXX AIR BAG DIAGNOSIS SENSOR UNIT..</b>	<b>68</b>
Description .....	42	Description .....	68
DTC Logic .....	42	DTC Logic .....	68
Diagnosis Procedure .....	42	Diagnosis Procedure .....	68
<b>B1081 – B1084 SEAT BELT PRE-TENSIONER RH .....</b>	<b>45</b>	<b>B1023 PASSENGER AIR BAG OFF INDICATOR .....</b>	<b>70</b>
Description .....	45	Description .....	70
DTC Logic .....	45	DTC Logic .....	70
Diagnosis Procedure .....	45	Diagnosis Procedure .....	70
<b>B1182 - B1185 SEAT BELT BUCKLE PRE-TENSIONER LH .....</b>	<b>48</b>	<b>B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM .....</b>	<b>72</b>
Description .....	48	Description .....	72
DTC Logic .....	48	DTC Logic .....	72
Diagnosis Procedure .....	48	Diagnosis Procedure .....	73
<b>B1177 - B1180 SEAT BELT BUCKLE PRE-TENSIONER RH .....</b>	<b>51</b>	<b>B1209 – B1211 COLLISION DETECTION .....</b>	<b>75</b>
Description .....	51	Description .....	75
DTC Logic .....	51	DTC Logic .....	75
Diagnosis Procedure .....	51	Diagnosis Procedure .....	75
<b>B1033 – B1035 CRASH ZONE SENSOR .....</b>	<b>54</b>	<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>76</b>
Description .....	54	<b>DIAGNOSIS SENSOR UNIT .....</b>	<b>76</b>
DTC Logic .....	54	Trouble Diagnosis with CONSULT .....	76
Diagnosis Procedure .....	54	Trouble Diagnosis without CONSULT .....	80
<b>B1118 – B1120 SATELLITE SENSOR LH .....</b>	<b>56</b>	<b>WIRING DIAGRAM .....</b>	<b>85</b>
Description .....	56	<b>SRS AIR BAG CONTROL SYSTEM .....</b>	<b>85</b>
DTC Logic .....	56	Wiring Diagram .....	85
Diagnosis Procedure .....	56	<b>SYMPTOM DIAGNOSIS .....</b>	<b>97</b>
<b>B1113 – B1115 SATELLITE SENSOR RH .....</b>	<b>58</b>	<b>SRS AIR BAG SYSTEM .....</b>	<b>97</b>
Description .....	58	"AIR BAG" Warning Lamp Does Not Turn Off .....	97
DTC Logic .....	58	"AIR BAG" Warning Lamp Does Not Turn On .....	97
Diagnosis Procedure .....	58	<b>PASSENGER SEAT BELT WARNING SYSTEM .....</b>	<b>99</b>
<b>B1343 - B1349 FRONT DOOR SATELLITE SENSOR LH .....</b>	<b>60</b>	Seat Belt Warning System Does Not Function .....	99
Description .....	60	<b>PRECAUTION .....</b>	<b>100</b>
DTC Logic .....	60	<b>PRECAUTIONS .....</b>	<b>100</b>
Diagnosis Procedure .....	61	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	100
<b>B1336 - B1342 FRONT DOOR SATELLITE SENSOR RH .....</b>	<b>63</b>	Precaution for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service .....	100
Description .....	63	Occupant Classification System Precaution .....	100
DTC Logic .....	63	Precaution Necessary for Steering Wheel Rotation After Battery Disconnect .....	100
Diagnosis Procedure .....	64		
<b>B1350 FRONT DOOR SATELLITE SENSORS .....</b>	<b>66</b>		
Description .....	66		

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000011289792

OVERALL SEQUENCE



SRC

AWHIA0310GB

\*1 [SRC-14. "Trouble Diagnosis Introduction"](#)

\*2 [SRC-14. "SRS Operation Check"](#)

\*3 [SRC-5. "Trouble Diagnosis with CONSULT"](#)

\*4 [SRC-16. "Self-Diagnosis Function \(Without CONSULT\)"](#)

#### DETAILED WORK FLOW

##### 1. CUSTOMER INFORMATION

Get detailed information from the customer about the symptom.

>> GO TO 2

##### 2. PRELIMINARY CHECK

Perform preliminary check. Refer to [SRC-14. "Trouble Diagnosis Introduction"](#).

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

---

>> GO TO 3

## 3. TECHNICAL SERVICE BULLETINS

---

Check for technical service bulletins.

>> GO TO 4

## 4. USER MODE

---

Perform self-diagnosis using the "AIR BAG" warning lamp in User mode. Refer to [SRC-14, "SRS Operation Check"](#).

>> GO TO 5

## 5. SELF-DIAGNOSIS

---

Perform SELF-DIAGNOSIS. Refer to [SRC-5, "Trouble Diagnosis with CONSULT"](#) (with CONSULT) or [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#) (without CONSULT).

>> GO TO 6

## 6. REPLACE PART

---

Replace the malfunctioning part.

>> GO TO 7

## 7. FINAL CHECK

---

Check SRS using Diagnosis mode and User mode.

Does Diagnosis mode and User mode indicate SRS normal?

YES >> Inspection End.

NO >> GO TO 5

# INTERMITTENTS INCIDENT

< BASIC INSPECTION >

## INTERMITTENTS INCIDENT

### Inspection Procedure

INFOID:0000000011289793

### INTERMITTENT TROUBLE

An intermittent incident may have occurred in the past but is not being detected currently. This DTC will not be detected on SELF DIAG [CURRENT], but may be viewed on SELF DIAG [PAST] using CONSULT.

### Trouble Diagnosis with CONSULT

INFOID:0000000011289794

### DIAGNOSTIC PROCEDURE 4

Check SRS Repair History

#### **1**.CONSIDER POSSIBILITY THAT SELF-DIAGNOSTIC RESULT WAS NOT ERASED AFTER REPAIR

Check repair history of the SRS.

Have any previous repairs been made to the SRS?

- Yes >> Self-diagnostic result "SELF-DIAG [PAST]" (previously stored in the memory) might not be erased after repair. Go to "DIAGNOSTIC PROCEDURE 3". Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).
- No >> Go to "DIAGNOSTIC PROCEDURE 2". Refer to [SRC-14, "SRS Operation Check"](#).

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### SRS AIR BAG SYSTEM

#### SRS Configuration

INFOID:000000011289795



The air bag deploys if the air bag diagnosis sensor unit is activated while the ignition switch is in the ON or START position.

The collision modes for which supplemental restraint systems are activated are different among the SRS systems. For example, the driver air bag module, front passenger air bag module, seat belt buckle pre-tensioner assemblies and the front seat belt pre-tensioners are activated in a frontal collision but not in a side collision. SRS configurations for some collision modes are as follows:


SRS configuration	Frontal collision	Left side collision	Right side collision	Rollover
Driver air bag module	x	—	—	—
Front passenger air bag module	x	—	—	—
Front LH seat belt pre-tensioner	x	—	—	x
Seat belt buckle pre-tensioner assembly LH	x	—	—	x
Front RH seat belt pre-tensioner	x	—	—	x
Seat belt buckle pre-tensioner assembly RH	x	—	—	x
Front LH side air bag module	—	x	—	—
Front RH side air bag module	—	—	x	—
LH side curtain air bag module	—	x	—	x
RH side curtain air bag module	—	—	x	x

# SRS AIR BAG SYSTEM

< SYSTEM DESCRIPTION >

## SRS Component Parts Location

INFOID:000000011289796




- |   |  |  |
|---|--|--|
| 1. Side curtain air bag modules                 | 2. Front RH side air bag module                | 3. RH side air bag (satellite) sensor                      |
| 4. Front RH seat belt pre-tensioner             | 5. Belt tension sensor                         | 6. Seat belt buckle pre-tensioner assembly RH (LH similar) |
| 7. Occupant classification system sensor        | 8. Occupant classification system control unit | 9. Front passenger air bag off indicator                   |
| 10. Front passenger air bag module              | 11. Crash zone sensor                          | 12. Air bag warning lamp                                   |
| 13. Spiral cable                                | 14. Driver air bag module                      | 15. Front LH seat belt pre-tensioner                       |
| 16. LH side air bag (satellite) sensor          | 17. Air bag diagnosis sensor unit              | 18. Front LH side air bag module                           |
| 19. Front door satellite sensor RH (LH similar) |  |  |

### Driver Air Bag Module

INFOID:000000011289797

The driver air bag module is dual stage and located in the steering wheel assembly. It operates with the SRS system in a frontal collision exceeding a specified level.



WHIA0325E

A  
B  
C  
D  
E  
F  
G  
SRC  
I  
J  
K  
L  
M  
N  
O  
P


# SRS AIR BAG SYSTEM

## < SYSTEM DESCRIPTION >

### Front Passenger Air Bag Module

INFOID:000000011289798

The front passenger air bag module is located behind the instrument panel assembly. It operates with the SRS system in a frontal collision exceeding a specified level. Refer to [SRC-6, "SRS Configuration"](#) for more information.




WHIA0332E

### Front Side Air Bag

INFOID:000000011289799

Front side air bag modules are built into the front seatback assemblies. Vehicles with side air bags are equipped with labels as shown.



WHIA0327E

### Side Curtain Air Bag

INFOID:000000011289800

Side curtain air bag modules are located above the vehicle headlining. Vehicles with side curtain air bags are equipped with labels as shown.



WHIA0041E


### Front Seat Belt Pre-tensioner with Load Limiter

INFOID:000000011289801

The seat belt pre-tensioner system with load limiter is installed for both the driver's seat and the front passenger's seat. It operates simultaneously with the SRS air bag system in the event of a frontal collision with an impact exceeding a specified level.

When the frontal collision with an impact exceeding a specified level occurs, seat belt slack resulting from clothing or other factors is immediately taken up by the pre-tensioner. Vehicle passengers are securely restrained.

When passengers in a vehicle are thrown forward in a collision and the restraining force of the seat belt exceeds a specified level, the load limiter permits the specified extension of the seat belt by the twisting of the ELR shaft, and a relaxation of the chest-area seat belt web tension while maintaining force.



WHIA0324E




# SRS AIR BAG SYSTEM

## < SYSTEM DESCRIPTION >

### Front Door Satellite Sensor

INFOID:000000011516841

The front door satellite sensors are located in the driver and passenger doors. The front door satellite sensors send signals to the air bag diagnosis sensor unit during a side collision. These sensors may be identified by yellow connectors.



### SRS Component Connectors

INFOID:000000011289802


#### DIRECT CONNECT

The following SRS components use direct-connect style harness connectors.

- Driver air bag module
- Front passenger air bag module
- LH side front curtain air bag module
- LH side rear curtain air bag module
- RH side front curtain air bag module
- RH side rear curtain air bag module
- Front LH seat belt pre-tensioner
- Front RH seat belt pre-tensioner
- Seat belt buckle pre-tensioner assembly LH
- Seat belt buckle pre-tensioner assembly RH

Always pull up to release locking tab prior to removing connector from SRS component.

Always push down to lock black locking tab after installing connector to SRS component. When locked, the black locking tab is level with the connector housing.



#### SLIDE DOUBLE LOCKING

- A new style slide double locking type connector is used on certain systems and components, especially those related to airbag control systems.
- The slide double locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide double locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.


**CAUTION:**

A  
B  
C  
D  
E  
F  
G  
SRC  
I  
J  
K  
L  
M  
N  
O  
P

# SRS AIR BAG SYSTEM

## < SYSTEM DESCRIPTION >

- Do not pull the harness or wires when disconnecting the connector.




# OCCUPANT CLASSIFICATION SYSTEM

< SYSTEM DESCRIPTION >

## OCCUPANT CLASSIFICATION SYSTEM

### System Diagram



A  
B  
C  
D  
E  
F  
G

SRC

### Occupant Classification System (OCS)

INFOID:000000011289804

The occupant classification system (OCS) identifies different size occupants, out of position occupants, and detects if child seat is present in the front passenger seat. The OCS receives inputs from the occupant classification sensor (located inside the passenger seat cushion assembly) and belt tension sensor (part of the passenger front seat belt assembly and located at the belt anchor location). Depending on classification of the passenger, the OCS sends a signal to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit uses this signal and the seat belt buckle switch RH signal to determine deployment or non deployment of the passenger front air bag in the event of a collision. Depending on the signals received, the air bag diagnosis sensor unit can disable the passenger front air bag completely.

**NOTE:**

In case of customer concern, CONSULT can be used to confirm the passenger air bag status (readiness).

**Passenger Air Bag Status Conditions**

Front Passenger Seat (Condition)	PASS AIR BAG OFF Indicator (Status)	Passenger Air Bag Status (Readiness)	CONSULT Display
Seat occupied	OFF	Active (enabled)	ON
Seat occupied <sup>NOTE</sup>	ON	Deactivated (disabled)	OFF
Seat empty	OFF	Deactivated (disabled)	OFF


**NOTE:**

I  
J  
K  
L  
M  
N  
O  
P

# OCCUPANT CLASSIFICATION SYSTEM

## < SYSTEM DESCRIPTION >

Passenger does not meet Occupant Classification System specifications for passenger air bag activation.




# PASSENGER SEAT BELT WARNING SYSTEM

< SYSTEM DESCRIPTION >

## PASSENGER SEAT BELT WARNING SYSTEM

### System Diagram


INFOID:000000011289805



### System Description

INFOID:000000011289806

The passenger seat belt warning system will remind the driver if the driver or front passenger seat belt should be buckled by turning on the seat belt warning light (1). The system works in conjunction with the occupant classification system. Refer to [SRC-11, "Occupant Classification System \(OCS\)"](#).



ALHIA0056ZZ

### Passenger Seat Belt Warning System Operation

Driver seat status (Ignition switch ON)	Passenger seat status	Seat belt buckle switch LH status	Seat belt buckle switch RH status	Seat belt warning lamp
Seat occupied	Seat occupied	Buckled	Buckled	Off
			Unbuckled	On
	Seat unoccupied	Unbuckled	—	Off
			On	

### Component Parts Location

INFOID:000000011289807

Refer to [SRC-7, "SRS Component Parts Location"](#).

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

### Trouble Diagnosis Introduction

INFOID:000000011289808

#### CAUTION:

- Do not use electrical test equipment on any circuit related to the SRS unless instructed to do so in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.
- Do not attempt to repair, splice or modify SRS wiring harnesses. If a harness is damaged, replace it with a new one.
- Keep ground connections clean.

#### DIAGNOSIS FUNCTION

The SRS self-diagnosis results can be read by using "AIR BAG" warning lamp and/or CONSULT.

The User mode is exclusively prepared for the customer (driver). This mode warns the driver of a system malfunction through the operation of the "AIR BAG" warning lamp.

The Diagnosis mode allows the technician to locate and inspect the malfunctioning part.

The mode applications for the "AIR BAG" warning lamp and CONSULT are as follows:

	User mode	Diagnosis mode	Display type
"AIR BAG" warning lamp	X	X	ON-OFF operation
CONSULT	—	X	Monitoring

#### HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a malfunction. It is important to fully understand the symptoms or conditions for a customer complaint.

##### Information From Customer

WHAT - Vehicle model

WHEN - Date, Frequencies

WHERE - Road conditions

HOW - Operating conditions, Symptoms

##### Preliminary Check

Check that the following parts are in good order.

- Battery (Refer to [PG-72, "How to Handle Battery"](#).)
- Fuse (Refer to [SRC-85, "Wiring Diagram"](#).)
- System component-to-harness connections

#### SRS Operation Check

INFOID:000000011289809

#### DIAGNOSTIC PROCEDURE 1

Checking SRS Operation Using "AIR BAG" Warning Lamp—User Mode





1. Turn the ignition switch from OFF to ON, and check that the air bag warning lamp blinks.
2. Compare the SRS air bag warning lamp blinking pattern with the examples.



# ON BOARD DIAGNOSTIC (OBD) SYSTEM

## < SYSTEM DESCRIPTION >

### SRS Air bag warning lamp examples

"AIR BAG" warning lamp (User mode)	SRS condition	Reference item
 <p style="text-align: right;">SHIA0011E</p>	<ul style="list-style-type: none"> <li>No malfunction is detected.</li> <li>No further action is necessary.</li> </ul>	<p style="text-align: center;">—</p>
 <p style="text-align: right;">SHIA0012E</p>	<p>The system is malfunctioning and needs to be repaired as indicated.</p>	<p>Go to DIAGNOSTIC PROCEDURE 2 that follows (with CONSULT) or <a href="#">SRC-16, "Trouble Diagnosis without CONSULT"</a> (without CONSULT).</p>
 <p style="text-align: right;">SHIA0013E</p>	<ul style="list-style-type: none"> <li>Air bag is deployed.</li> <li>Seat belt pre-tensioner is deployed.</li> </ul>	<p>Go to COLLISION DIAGNOSIS <a href="#">SR-5, "For Frontal Collision"</a> or <a href="#">SR-7, "For Side and Rollover Collision"</a>.</p>
 <p style="text-align: right;">SHIA0014E</p>	<ul style="list-style-type: none"> <li>Air bag diagnosis sensor unit is malfunctioning.</li> <li>Air bag power supply circuit is malfunctioning.</li> <li>SRS air bag warning lamp circuit is malfunctioning.</li> </ul>	<p>Go to <a href="#">SRC-97, ""AIR BAG" Warning Lamp Does Not Turn Off"</a>.</p>

## DIAGNOSTIC PROCEDURE 2

- Connect CONSULT.
- Diagnostic code is displayed on "SELF-DIAG [CURRENT]".  
If no malfunction is detected on "SELF-DIAG [CURRENT]", but malfunction is detected in "SRS Operation Check" using the "AIR BAG" warning lamp, the following cases may exist:
  - "SELF-DIAG [PAST]" memory might not be erased.
  - The SRS system malfunctions intermittently.
 Perform DIAGNOSTIC PROCEDURE 4. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

## Trouble Diagnosis without CONSULT

INFOID:000000011289810

### DIAGNOSTIC PROCEDURE 6

Inspect SRS Malfunction Using "AIR BAG" Warning Lamp—Diagnosis Mode

**NOTE:**

SRS will not enter Diagnosis mode if no malfunction is detected in User mode.

1. Turn ignition switch ON.
2. After "AIR BAG" warning lamp lights for 7 seconds, turn ignition switch OFF within 1 second.
3. Wait more than 3 seconds.
4. Repeat steps 1 to 3 two more times (3 times total).
5. Turn ignition switch ON.

SRS is now in Diagnosis mode. Refer to [SRC-80, "Trouble Diagnosis without CONSULT"](#).

### CONSULT Function (AIR BAG)

INFOID:000000011289811

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

AIR BAG diagnostic mode	Description
SELF-DIAG [CURRENT]	A current Self-diagnosis result (also indicated by the number of warning lamp flashes in the Diagnosis mode) is displayed on the CONSULT screen in real time. This refers to a malfunctioning part requiring repairs.
SELF-DIAG [PAST]	Diagnosis results previously stored in the memory are displayed on the CONSULT screen. The stored results will remain until memory erasing is executed.
TROUBLE DIAG RECORD	With TROUBLE DIAG RECORD, diagnosis results previously erased by a reset operation can be displayed on the CONSULT screen.
ECU DISCRIMINATED NO.	Air bag diagnosis sensor unit ECU discriminated number (identification number) or part number is displayed. Air bag diagnosis sensor unit has individual ECU discriminated number (identification number) or part number based on model and equipment.
PASSENGER AIR BAG	The STATUS (readiness) of the front passenger air bag module is displayed. The STATUS displayed (ON/OFF) depends on the signals supplied to the occupant classification system control module and air bag diagnosis sensor unit. Refer to <a href="#">SRC-11, "Occupant Classification System (OCS)"</a> for more information.

### Self-Diagnosis Function (Without CONSULT)

INFOID:000000011289812


- The reading of these results is accomplished using one of two modes — "User mode" and "Diagnosis mode".
- After a malfunction is repaired, turn the ignition switch OFF for at least one second, then back ON. Diagnosis mode returns to the User mode. At that time, the self-diagnostic result is cleared.



# ON BOARD DIAGNOSTIC (OBD) SYSTEM

## < SYSTEM DESCRIPTION >

### HOW TO CHANGE SELF-DIAGNOSIS MODE



### DIAGNOSTIC PROCEDURE 3

#### Final Check of SRS Using CONSULT—Diagnosis Mode

1. Connect CONSULT.
2. If no DTC is detected on "SELF-DIAG [CURRENT]", repair of SRS is completed. Go to step 3.  
If any DTC is detected on "SELF-DIAG [CURRENT]", the malfunctioning part has not been repaired completely or another malfunctioning part is being detected. Perform DIAGNOSTIC PROCEDURE 2. Refer to [SRC-14, "SRS Operation Check"](#).
3. Touch "ERASE".  
**NOTE:**  
**Touch "ERASE" to clear the memory of the malfunction ("SELF-DIAG [PAST]").**  
If the memory of the malfunction in "SELF-DIAG [PAST]" is not erased, the User mode shows the system malfunction by the operation of the warning lamp even if the malfunction is repaired completely.
4. Touch "BACK" key of CONSULT. Touch "SELF-DIAG [PAST]".
5. Check that no malfunction is detected on "SELF-DIAG [PAST]".
6. Touch "BACK" key of CONSULT to return to User mode from Diagnosis mode.
7. Turn ignition switch OFF and then turn off and disconnect CONSULT.
8. Go to [SRC-14, "SRS Operation Check"](#).

### DIAGNOSTIC PROCEDURE 4

#### Check SRS Repair History

#### 1. CONSIDER POSSIBILITY THAT SELF-DIAGNOSTIC RESULT WAS NOT ERASED AFTER REPAIR

#### Check repair history of the SRS.

#### Have any previous repairs been made to the SRS?

- Yes >> Self-diagnostic result "SELF-DIAG [PAST]" (previously stored in the memory) might not be erased after repair. Perform DIAGNOSTIC PROCEDURE 3. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).
- No >> Perform DIAGNOSTIC PROCEDURE 2. Refer to [SRC-14, "SRS Operation Check"](#).

# B1049 – B1052, B1054 – B1057 DRIVER AIRBAG MODULE

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### B1049 – B1052, B1054 – B1057 DRIVER AIRBAG MODULE

#### Description

INFOID:000000011289813

#### DTC B1049 – B1052, B1054 – B1057 DRIVER AIRBAG MODULE

The driver air bag module is dual stage and wired to the air bag diagnosis sensor unit through the spiral cable. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the driver air bag module including the spiral cable.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

#### DTC Logic

INFOID:000000011289814

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
DRIVER AIRBAG MODULE [OPEN]	B1049	Driver air bag module circuit (DR1) is open (including the spiral cable).	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Inspect spiral cable. 4. Replace the air bag diagnosis sensor unit. 5. Replace the driver air bag module. 6. Replace the related harness.
	B1054	Driver air bag module circuit (DR2) is open (including the spiral cable).	
DRIVER AIRBAG MODULE [VB-SHORT]	B1050	Driver air bag module circuit (DR1) is shorted to a power supply circuit (including the spiral cable).	
	B1055	Driver air bag module circuit (DR2) is shorted to a power supply circuit (including the spiral cable).	
DRIVER AIRBAG MODULE [GND-SHORT]	B1051	Driver air bag module circuit (DR1) is shorted to ground (including the spiral cable).	
	B1056	Driver air bag module circuit (DR2) is shorted to ground (including the spiral cable).	
DRIVER AIRBAG MODULE [SHORT]	B1052	Driver air bag module circuits (DR1) are shorted to each other (including the spiral cable).	
	B1057	Driver air bag module circuits (DR2) are shorted to each other (including the spiral cable).	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-19, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

# B1049 – B1052, B1054 – B1057 DRIVER AIRBAG MODULE

## < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> Inspection End.  
NO >> Refer to [SRC-19, "Diagnosis Procedure"](#).

A

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1. CHECK SELF-DIAG RESULT

---

B

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

C

#### Is the DTC detected?

- YES >> Refer to [SRC-19, "Diagnosis Procedure"](#).  
NO >> Inspection End.

D

## Diagnosis Procedure

INFOID:0000000011289815

E

### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

F

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

G

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

SRC

I

### 2. CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

#### Is DTC still current?

- YES >> GO TO 3.  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

L

### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

M

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

N

### 4. CHECK SPIRAL CABLE CIRCUIT

---

O

1. Turn ignition switch OFF.
2. Disconnect driver air bag module connector and combination switch (spiral cable) connector.
3. Check continuity between driver air bag module harness connector and combination switch (spiral cable) harness connector.

P

# B1049 – B1052, B1054 – B1057 DRIVER AIRBAG MODULE

## < DTC/CIRCUIT DIAGNOSIS >

Driver air bag module		Combination switch (spiral cable)		Continuity
Connector	Terminal	Connector	Terminal	
M101	10	M29	30	YES
	11		23	
M103	12		28	
	13		23	

4. Check continuity between driver air bag module harness connector and ground.

Driver air bag module		Ground	Continuity
Connector	Terminal		
M101	10		NO
	11		
M103	12		
	13		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace combination switch (spiral cable). Refer to [SR-14. "Removal and Installation"](#).

## 5. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 6. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7. FRONT DRIVER AIR BAG MODULE

1. Replace the driver air bag module. Refer to [SR-12. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 8.

NO >> Clear DTC. Inspection End.

## 8. RELATED HARNESS

Replace the related harness.

>> **END**

# B1065 – B1068, B1070 – B1073 PASSENGER AIRBAG MODULE

< DTC/CIRCUIT DIAGNOSIS >

## B1065 – B1068, B1070 – B1073 PASSENGER AIRBAG MODULE

### Description

INFOID:000000011289816

### DTC B1065 – B1068, B1070 – B1073 PASSENGER AIR BAG MODULE

The passenger air bag module is dual stage and wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the passenger air bag module.

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289817

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
ASSIST A/B MODULE [OPEN]	B1065	Front passenger air bag module circuit (AS1) is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front passenger air bag module. 5. Replace the related harness.
	B1070	Front passenger air bag module circuit (AS2) is open.	
ASSIST A/B MODULE [VB-SHORT]	B1066	Front passenger air bag module circuit (AS1) is shorted to a power supply circuit.	
	B1071	Front passenger air bag module circuit (AS2) is shorted to a power supply circuit.	
ASSIST A/B MODULE [GND-SHORT]	B1067	Front passenger air bag module circuit (AS1) is shorted to ground.	
	B1072	Front passenger air bag module circuit (AS2) is shorted to ground.	
ASSIST A/B MODULE [SHORT]	B1068	Front passenger air bag module circuits (AS1) are shorted to each other.	
	B1073	Front passenger air bag module circuits (AS2) are shorted to each other.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF-DIAG RESULT

- Turn ignition switch ON.
- Check for DTC using CONSULT.

Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-22, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-22, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF-DIAG RESULT

- Turn ignition switch ON.
- Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

**NOTE:**

# B1065 – B1068, B1070 – B1073 PASSENGER AIRBAG MODULE

## < DTC/CIRCUIT DIAGNOSIS >

---

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

### Is the DTC detected?

- YES >> Refer to [SRC-22, "Diagnosis Procedure"](#).  
NO >> Inspection End.

## Diagnosis Procedure

INFOID:000000011289818

### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 2  
NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 3  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 4  
NO >> Replace the harness.

### 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 5  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 6  
NO >> Clear DTC. Inspection End.

### 6. FRONT PASSENGER AIR BAG MODULE

---

1. Replace the front passenger air bag module. Refer to [SR-17, "Removal and Installation"](#).
2. Turn ignition switch ON.

## B1065 – B1068, B1070 – B1073 PASSENGER AIRBAG MODULE

< DTC/CIRCUIT DIAGNOSIS >

---

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

**7**.RELATED HARNESS

---

Replace the related harness.

>> **END**

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1134 – B1137 SIDE AIRBAG MODULE LH

< DTC/CIRCUIT DIAGNOSIS >

## B1134 – B1137 SIDE AIRBAG MODULE LH

### Description

INFOID:000000011289819

#### DTC B1134 – B1137 FRONT LH SIDE AIR BAG MODULE

The front LH side air bag module is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the front LH side air bag module.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289820

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
SIDE MODULE LH [OPEN]	B1134	Front LH side air bag module circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front LH side air bag module. 5. Replace the related harness.
SIDE MODULE LH [VB-SHORT]	B1135	Front LH side air bag module circuit is shorted to a power supply circuit.	
SIDE MODULE LH [GND-SHORT]	B1136	Front LH side air bag module circuit is shorted to ground.	
SIDE MODULE LH [SHORT]	B1137	Front LH side air bag module circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-24, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-24, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-24, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289821

##### 1.HARNESS CONNECTOR



## B1134 – B1137 SIDE AIRBAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

Is the inspection result normal?

C

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

Is DTC still current?

F

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

G

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

Is the inspection result normal?

I

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

Is DTC still current?

L

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

Is DTC still current?

N

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SIDE AIR BAG MODULE LH

---

O

1. Replace the side air bag module LH. Refer to [SR-21. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

P

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

## **B1134 – B1137 SIDE AIRBAG MODULE LH**

< DTC/CIRCUIT DIAGNOSIS >

---

>> **END**

# B1129 – B1132 SIDE AIRBAG MODULE RH

< DTC/CIRCUIT DIAGNOSIS >

## B1129 – B1132 SIDE AIRBAG MODULE RH

### Description

INFOID:000000011289822

### DTC B1129 – B1132 FRONT RH SIDE AIR BAG MODULE

The front RH side air bag module is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the front RH side air bag module.

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289823

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
SIDE MODULE RH [OPEN]	B1129	Front RH side air bag module circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front RH side air bag module. 5. Replace the related harness.
SIDE MODULE RH [VB-SHORT]	B1130	Front RH side air bag module circuit is shorted to a power supply circuit.	
SIDE MODULE RH [GND-SHORT]	B1131	Front RH side air bag module circuit is shorted to ground.	
SIDE MODULE RH [SHORT]	B1132	Front RH side air bag module circuits are shorted to each other.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-27, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-27, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-27, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289824

#### 1. HARNESS CONNECTOR

## B1129 – B1132 SIDE AIRBAG MODULE RH

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SIDE AIR BAG MODULE RH

---

1. Replace the side air bag module RH. Refer to [SR-21. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

# B1129 – B1132 SIDE AIRBAG MODULE RH

< DTC/CIRCUIT DIAGNOSIS >

---

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1198 – B1201 SIDE CURTAIN AIR BAG MODULE LH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

## B1198 – B1201 SIDE CURTAIN AIR BAG MODULE LH (FRONT)

### Description

INFOID:000000011289825

#### DTC B1198 – B1201 LH SIDE CURTAIN AIR BAG MODULE (FRONT)

The LH side curtain air bag module (front) is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the LH side curtain air bag module (front).

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289826

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FR CURTN MODULE LH [OPEN]	B1198	LH side curtain air bag module (front) circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the LH side curtain air bag module (front). 5. Replace the related harness.
FR CURTN MODULE LH [VB-SHORT]	B1199	LH side curtain air bag module (front) circuit is shorted to a power supply circuit.	
FR CURTN MODULE LH [GND-SHORT]	B1200	LH side curtain air bag module (front) circuit is shorted to ground.	
FR CURTN MODULE LH [SHORT]	B1201	LH side curtain air bag module (front) circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-30, "Diagnosis Procedure"](#).  
YES (Past DTC)>>GO TO 2.  
NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.  
NO >> Refer to [SRC-30, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-30, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289827

##### 1.HARNESS CONNECTOR

# B1198 – B1201 SIDE CURTAIN AIR BAG MODULE LH (FRONT)

## < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

### Is the inspection result normal?

C

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

### Is DTC still current?

F

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

G

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

### Is the inspection result normal?

I

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

L

## 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

### Is DTC still current?

N

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.SIDE CURTAIN AIR BAG MODULE LH (FRONT)

---

O

1. Replace the side curtain air bag module LH (front). Refer to [SR-20. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

P

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

# **B1198 – B1201 SIDE CURTAIN AIR BAG MODULE LH (FRONT)**

< DTC/CIRCUIT DIAGNOSIS >

---

>> **END**



# B1193 – B1196 SIDE CURTAIN AIR BAG MODULE RH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

## B1193 – B1196 SIDE CURTAIN AIR BAG MODULE RH (FRONT)

### Description

INFOID:0000000011289828

### DTC B1193 – B1196 RH SIDE CURTAIN AIR BAG MODULE (FRONT)

The RH side curtain air bag module (front) is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the RH side curtain air bag module (front).

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:0000000011289829

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FR CURTN MODULE RH [OPEN]	B1193	RH side curtain air bag module (front) circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the RH side curtain air bag module (front). 5. Replace the related harness.
FR CURTN MODULE RH [VB-SHORT]	B1194	RH side curtain air bag module (front) circuit is shorted to a power supply circuit.	
FR CURTN MODULE RH [GND-SHORT]	B1195	RH side curtain air bag module (front) circuit is shorted to ground.	
FR CURTN MODULE RH [SHORT]	B1196	RH side curtain air bag module (front) circuits are shorted to each other.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-33, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-33, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-33, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011289830

#### 1. HARNESS CONNECTOR

## B1193 – B1196 SIDE CURTAIN AIR BAG MODULE RH (FRONT)

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SIDE CURTAIN AIR BAG MODULE RH (FRONT)

---

1. Replace the side curtain air bag module RH (front). Refer to [SR-20. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

# B1193 – B1196 SIDE CURTAIN AIR BAG MODULE RH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

---

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1150 – B1153 SIDE CURTAIN AIR BAG MODULE LH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

## B1150 – B1153 SIDE CURTAIN AIR BAG MODULE LH (REAR)

### Description

INFOID:000000011289831

#### DTC B1150 – B1153 LH SIDE CURTAIN AIR BAG MODULE (REAR)

The LH side curtain air bag module (rear) is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the LH side curtain air bag module (rear).

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289832

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
CURTAIN MODULE LH [OPEN]	B1150	LH side curtain air bag module (rear) circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the LH side curtain air bag module (rear). 5. Replace the related harness.
CURTAIN MODULE LH [VB-SHORT]	B1151	LH side curtain air bag module (rear) circuit is shorted to a power supply circuit.	
CURTAIN MODULE LH [GND-SHORT]	B1152	LH side curtain air bag module (rear) circuit is shorted to ground.	
CURTAIN MODULE LH [SHORT]	B1153	LH side curtain air bag module (rear) circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-36, "Diagnosis Procedure"](#).  
YES (Past DTC)>>GO TO 2.  
NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.  
NO >> Refer to [SRC-36, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-36, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289833

##### 1. HARNESS CONNECTOR

# B1150 – B1153 SIDE CURTAIN AIR BAG MODULE LH (REAR)

## < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

### Is the inspection result normal?

C

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

### Is DTC still current?

F

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

G

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

### Is the inspection result normal?

I

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

L

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

### Is DTC still current?

N

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SIDE CURTAIN AIR BAG MODULE LH (REAR)

---

O

1. Replace the side curtain air bag module LH (rear). Refer to [SR-20. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

P

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

# **B1150 – B1153 SIDE CURTAIN AIR BAG MODULE LH (REAR)**

< DTC/CIRCUIT DIAGNOSIS >

---

>> **END**

# B1145 – B1148 SIDE CURTAIN AIR BAG MODULE RH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

## B1145 – B1148 SIDE CURTAIN AIR BAG MODULE RH (REAR)

### Description

INFOID:0000000011289834

### DTC B1145 – B1148 RH SIDE CURTAIN AIR BAG MODULE (REAR)

The RH side curtain air bag module (rear) is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the RH side curtain air bag module (rear).

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:0000000011289835

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
CURTAIN MODULE RH [OPEN]	B1145	RH side curtain air bag module (rear) circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the RH side curtain air bag module (rear). 5. Replace the related harness.
CURTAIN MODULE RH [VB-SHORT]	B1146	RH side curtain air bag module (rear) circuit is shorted to a power supply circuit.	
CURTAIN MODULE RH [GND-SHORT]	B1147	RH side curtain air bag module (rear) circuit is shorted to ground.	
CURTAIN MODULE RH [SHORT]	B1148	RH side curtain air bag module (rear) circuits are shorted to each other.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-39, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-39, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-39, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011289836

#### 1. HARNESS CONNECTOR

## B1145 – B1148 SIDE CURTAIN AIR BAG MODULE RH (REAR)

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SIDE CURTAIN AIR BAG MODULE RH (REAR)

---

1. Replace the side curtain air bag module RH (rear). Refer to [SR-20. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.



# B1145 – B1148 SIDE CURTAIN AIR BAG MODULE RH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

---

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1086 – B1089 SEAT BELT PRE-TENSIONER LH

< DTC/CIRCUIT DIAGNOSIS >

## B1086 – B1089 SEAT BELT PRE-TENSIONER LH

### Description

INFOID:000000011289837

#### DTC B1086 – B1089 SEAT BELT PRE-TENSIONER LH

The seat belt pre-tensioner LH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the seat belt pre-tensioner LH.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289838

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
PRE-TEN FRONT LH [OPEN]	B1086	LH seat belt pre-tensioner circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front LH seat belt pre-tensioner. 5. Replace the related harness.
PRE-TEN FRONT LH [VB-SHORT]	B1087	LH seat belt pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN FRONT LH [GND-SHORT]	B1088	LH seat belt pre-tensioner circuit is shorted to ground.	
PRE-TEN FRONT LH [SHORT]	B1089	LH seat belt pre-tensioner circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-42, "Diagnosis Procedure"](#).  
YES (Past DTC)>>GO TO 2.  
NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.  
NO >> Refer to [SRC-42, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-42, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289839

##### 1. HARNESS CONNECTOR

# B1086 – B1089 SEAT BELT PRE-TENSIONER LH

## < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

### Is the inspection result normal?

C

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

### Is DTC still current?

F

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

G

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

### Is the inspection result normal?

I

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

L

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

### Is DTC still current?

N

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SEAT BELT PRE-TENSIONER LH

---

O

1. Replace the seat belt pre-tensioner LH. Refer to [SR-23, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

P

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

## **B1086 – B1089 SEAT BELT PRE-TENSIONER LH**

< DTC/CIRCUIT DIAGNOSIS >

---

>> **END**

# B1081 – B1084 SEAT BELT PRE-TENSIONER RH

< DTC/CIRCUIT DIAGNOSIS >

## B1081 – B1084 SEAT BELT PRE-TENSIONER RH

### Description

INFOID:000000011289840

#### DTC B1081 – B1084 SEAT BELT PRE-TENSIONER RH

The seat belt pre-tensioner RH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the seat belt pre-tensioner RH.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289841

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
PRE-TEN FRONT RH [OPEN]	B1081	RH seat belt pre-tensioner circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front RH seat belt pre-tensioner. 5. Replace the related harness.
PRE-TEN FRONT RH [VB-SHORT]	B1082	RH seat belt pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN FRONT RH [GND-SHORT]	B1083	RH seat belt pre-tensioner circuit is shorted to ground.	
PRE-TEN FRONT RH [SHORT]	B1084	RH seat belt pre-tensioner circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-45, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-45, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-45, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289842

##### 1.HARNES CONNECTOR

## B1081 – B1084 SEAT BELT PRE-TENSIONER RH

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SEAT BELT PRE-TENSIONER RH

---

1. Replace the seat belt pre-tensioner RH. Refer to [SR-23. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

# B1081 – B1084 SEAT BELT PRE-TENSIONER RH

< DTC/CIRCUIT DIAGNOSIS >

---

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1182 - B1185 SEAT BELT BUCKLE PRE-TENSIONER LH

< DTC/CIRCUIT DIAGNOSIS >

## B1182 - B1185 SEAT BELT BUCKLE PRE-TENSIONER LH

### Description

INFOID:000000011289843

#### DTC B1182 – B1185 SEAT BELT BUCKLE PRE-TENSIONER LH

The seat belt buckle pre-tensioner LH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the seat belt buckle pre-tensioner LH.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289844

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
PRE-TEN2 FRONT LH [OPEN]	B1182	LH seat belt buckle pre-tensioner circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front LH seat belt buckle pre-tensioner. 5. Replace the related harness.
PRE-TEN2 FRONT LH [VB-SHORT]	B1183	LH seat belt buckle pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN2 FRONT LH [GND-SHORT]	B1184	LH seat belt buckle pre-tensioner circuit is shorted to ground.	
PRE-TEN2 FRONT LH [SHORT]	B1185	LH seat belt buckle pre-tensioner circuits are shorted to each other.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-48, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-48, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-48, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289845

##### 1.HARNES CONNECTOR



# B1182 - B1185 SEAT BELT BUCKLE PRE-TENSIONER LH

## < DTC/CIRCUIT DIAGNOSIS >

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

### Is the inspection result normal?

C

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

### Is DTC still current?

F

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

G

## 3.WIRING HARNESS

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

### Is the inspection result normal?

I

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

L

## 5.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

### Is DTC still current?

N

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.SEAT BELT BUCKLE PRE-TENSIONER LH

O

1. Replace the seat belt buckle pre-tensioner LH. Refer to [SR-23. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

P

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

Replace the related harness.

# **B1182 - B1185 SEAT BELT BUCKLE PRE-TENSIONER LH**

< DTC/CIRCUIT DIAGNOSIS >

---

>> **END**

# B1177 - B1180 SEAT BELT BUCKLE PRE-TENSIONER RH

< DTC/CIRCUIT DIAGNOSIS >

## B1177 - B1180 SEAT BELT BUCKLE PRE-TENSIONER RH

### Description

INFOID:000000011289846

### DTC B1177 – B1180 SEAT BELT BUCKLE PRE-TENSIONER RH

The seat belt buckle pre-tensioner RH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the seat belt buckle pre-tensioner RH.

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289847

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
PRE-TEN2 FRONT RH [OPEN]	B1177	RH seat belt buckle pre-tensioner circuit is open.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the front RH seat belt buckle pre-tensioner. 5. Replace the related harness.
PRE-TEN2 FRONT RH [VB-SHORT]	B1178	RH seat belt buckle pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN2 FRONT RH [GND-SHORT]	B1179	RH seat belt buckle pre-tensioner circuit is shorted to ground.	
PRE-TEN2 FRONT RH [SHORT]	B1180	RH seat belt buckle pre-tensioner circuits are shorted to each other.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-51, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-51, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-51, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289848

#### 1.HARNES CONNECTOR

## B1177 - B1180 SEAT BELT BUCKLE PRE-TENSIONER RH

### < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43. "Intermittent Incident"](#).

## 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6. SEAT BELT BUCKLE PRE-TENSIONER RH

---

1. Replace the seat belt buckle pre-tensioner RH. Refer to [SR-23. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7. RELATED HARNESS

---

Replace the related harness.

# B1177 - B1180 SEAT BELT BUCKLE PRE-TENSIONER RH

< DTC/CIRCUIT DIAGNOSIS >

---

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1033 – B1035 CRASH ZONE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B1033 – B1035 CRASH ZONE SENSOR

### Description

INFOID:000000011289849

#### DTC B1033 – B1035 CRASH ZONE SENSOR

The crash zone sensor is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor for opens and shorts in detected lines to the crash zone sensor.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289850

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
CRASH ZONE SEN [UNIT FAIL]	B1033	Crash zone sensor has malfunctioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the crash zone sensor. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.
	B1034		
CRASH ZONE SEN [COMM FAIL]	B1035	Crash zone sensor communication error.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-54, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-54, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-54, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289851

##### 1.HARNES CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

# B1033 – B1035 CRASH ZONE SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

---

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 5.CRASH ZONE SENSOR

---

1. Replace the crash zone sensor. Refer to [SR-22, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> **END**

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

**SRC**

# B1118 – B1120 SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

## B1118 – B1120 SATELLITE SENSOR LH

### Description

INFOID:000000011289852

#### DTC B1118 – B1120 SATELLITE SENSOR LH

The satellite sensor LH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the satellite sensor LH for internal failures and it's circuits for communication errors.

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289853

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
SATELLITE SENS LH [UNIT FAIL]	B1118	LH side air bag satellite sensor has mal- functioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the LH side air bag satellite sensor. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.
	B1119		
SATELLITE SENS LH [COMM FAIL]	B1120	LH side air bag satellite sensor communi- cation error.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-56, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-56, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-56, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289854

#### 1.HARNES CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection



# B1118 – B1120 SATELLITE SENSOR LH

## < DTC/CIRCUIT DIAGNOSIS >

---

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 5.SATELLITE SENSOR LH

---

1. Replace the satellite sensor LH. Refer to [SR-27, "Removal and Installation - Side Air Bag \(Satellite\) Sensor"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> END

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1113 – B1115 SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

## B1113 – B1115 SATELLITE SENSOR RH

### Description

INFOID:000000011289855

#### DTC B1113 – B1115 SATELLITE SENSOR RH

The satellite sensor RH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the satellite sensor RH for internal failures and it's circuits for communication errors.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289856

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
SATELLITE SENS RH [UNIT FAIL]	B1113	RH side air bag satellite sensor has mal- functioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the RH side air bag satellite sensor.
	B1114		
SATELLITE SENS RH [COMM FAIL]	B1115	RH side air bag satellite sensor communi- cation error.	4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-58, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-58, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-58, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289857

##### 1.HARNES CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

# B1113 – B1115 SATELLITE SENSOR RH

## < DTC/CIRCUIT DIAGNOSIS >

---

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 5.SATELLITE SENSOR RH

---

1. Replace the satellite sensor RH. Refer to [SR-27, "Removal and Installation - Side Air Bag \(Satellite\) Sensor"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> END

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1343 - B1349 FRONT DOOR SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

## B1343 - B1349 FRONT DOOR SATELLITE SENSOR LH

### Description

INFOID:000000011517746

#### DTC B1343 – B1349 FRONT DOOR SATELLITE SENSOR LH

The front door satellite sensor LH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the front door satellite sensor LH for internal failures and it's circuits for communication errors.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011517747

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FR-LH DOOR SATEL SENS [UNIT FAIL]	B1343	Front door satellite sensor LH has malfunctioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the front door satellite sensor LH. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.
	B1344		
FR-LH DOOR SATEL SENS [COM FAIL]	B1345	Front door satellite sensor LH communication error.	
	B1347		
	B1348		
B1349			
FR-LH DOOR SATEL SENS [MIS-INSTALLATION]	B1346	Front door satellite sensor LH is out of specification.	

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-61, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-61, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Trouble Diagnosis without CONSULT"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-61, "Diagnosis Procedure"](#).

NO >> Inspection End.

# B1343 - B1349 FRONT DOOR SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

## Diagnosis Procedure

INFOID:000000011517748

### 1. HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 3. WIRING HARNESS

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

### 4. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 5. FRONT DOOR SATELLITE SENSOR LH

Replace the front door satellite sensor LH. Refer to [SR-28, "Removal and Installation - Front Door Satellite Sensor"](#).

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

## **B1343 - B1349 FRONT DOOR SATELLITE SENSOR LH**

< DTC/CIRCUIT DIAGNOSIS >

---

### **7.RELATED HARNESS**

---

Replace the related harness.

**>> END**

# B1336 - B1342 FRONT DOOR SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

## B1336 - B1342 FRONT DOOR SATELLITE SENSOR RH

### Description

INFOID:000000011517749

### DTC B1336 – B1342 FRONT DOOR SATELLITE SENSOR RH

The front door satellite sensor RH is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the front door satellite sensor RH for internal failures and it's circuits for communication errors.

### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011517750

### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FR-RH DOOR SATEL SENS [UNIT FAIL]	B1336	Front door satellite sensor RH has mal- functioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the front door satellite sensor RH. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.
	B1337		
FR-RH DOOR SATEL SENS [COM FAIL]	B1338	Front door satellite sensor RH communica- tion error.	
	B1340		
	B1341		
	B1342		
FR-RH DOOR SATEL SENS [MIS-INSTALLATION]	B1339	Front door satellite sensor RH is out of specification.	

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-64, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-64, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Trouble Diagnosis without CONSULT"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-64, "Diagnosis Procedure"](#).

NO >> Inspection End.

# B1336 - B1342 FRONT DOOR SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

## Diagnosis Procedure

INFOID:000000011517751

### 1. HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 3. WIRING HARNESS

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

### 4. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-43, "Intermittent Incident"](#).

### 5. FRONT DOOR SATELLITE SENSOR RH

Replace the front door satellite sensor RH. Refer to [SR-28, "Removal and Installation - Front Door Satellite Sensor"](#).

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.



# B1336 - B1342 FRONT DOOR SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

---

## 7.RELATED HARNESS

---

Replace the related harness.

>> END

A

B

C

D

E

F

G

**SRC**

I

J

K

L

M

N

O

P

# B1350 FRONT DOOR SATELLITE SENSORS

< DTC/CIRCUIT DIAGNOSIS >

## B1350 FRONT DOOR SATELLITE SENSORS

### Description

INFOID:000000011517752

#### DTC B1350 FRONT DOOR SATELLITE SENSORS LH/RH

The front door satellite sensors LH/RH are wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the front door satellite sensors LH/RH for internal failures and check if the sensors are within specification.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011517753

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FR DOOR SATEL SENS	B1350	Front door satellite sensors LH/RH are malfunctioning or are out of specification.	<ol style="list-style-type: none"><li>1. Visually check the wiring harness connections.</li><li>2. Replace the harnesses if they have visible damage.</li><li>3. Replace the front door satellite sensor LH and RH.</li><li>4. Replace the air bag diagnosis sensor unit.</li><li>5. Replace the related harnesses.</li></ol>

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

- YES (Current DTC)>>Refer to [SRC-66, "Diagnosis Procedure"](#).  
YES (Past DTC)>>GO TO 2.  
NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

- YES >> Inspection End.  
NO >> Refer to [SRC-66, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Trouble Diagnosis without CONSULT"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

- YES >> Refer to [SRC-66, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011517754

##### 1.HARNES CONNECTOR

# B1350 FRONT DOOR SATELLITE SENSORS

## < DTC/CIRCUIT DIAGNOSIS >

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

A

### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

B

### Is the inspection result normal?

C

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

D

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

E

### Is DTC still current?

F

YES >> GO TO 3.

NO >> Refer to [GI-43. "Intermittent Incident"](#).

G

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

SRC

### Is the inspection result normal?

I

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

J

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

K

### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-43. "Intermittent Incident"](#).

L

## 5.FRONT DOOR SATELLITE SENSOR

---

Replace the front door satellite sensor LH and RH. Refer to [SR-28. "Removal and Installation - Front Door Satellite Sensor"](#).

M

### Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

N

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

O

### Is DTC still current?

P

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> **END**

# B1XXX AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B1XXX AIR BAG DIAGNOSIS SENSOR UNIT

### Description

INFOID:000000011289858

#### DTC B1XXX AIR BAG DIAGNOSIS SENSOR UNIT

The air bag diagnosis sensor unit will run self diagnostics when the ignition switch is turned ON. It has the potential to set many diagnostic trouble codes which will conform to the B1XXX format, but will not match any other SRS diagnostic trouble codes. Refer to [SRC-76, "Trouble Diagnosis with CONSULT"](#).

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289859

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
CONTROL UNIT	B1XXX	Air bag diagnosis sensor unit is malfunctioning.	<ol style="list-style-type: none"><li>1. Visually check the wiring harness connection.</li><li>2. Replace the harness if it has visible damage.</li><li>3. Replace the air bag diagnosis sensor unit.</li><li>4. Replace the related harness.</li></ol>

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-68, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-68, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

Is the DTC detected?

YES >> Refer to [SRC-68, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289860

##### 1. HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

# B1XXX AIR BAG DIAGNOSIS SENSOR UNIT

## < DTC/CIRCUIT DIAGNOSIS >

---

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.RELATED HARNESS

---

Replace the related harness.

>> **END**

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1023 PASSENGER AIR BAG OFF INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

## B1023 PASSENGER AIR BAG OFF INDICATOR

### Description

INFOID:000000011289861

#### DTC B1023 FRONT PASSENGER AIR BAG OFF INDICATOR

The front passenger air bag off indicator is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit monitors the front passenger air bag off indicator and circuit for failures.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289862

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
PASS A/B INDCTR CKT	B1023	Front passenger air bag off indicator is malfunctioning.	<ol style="list-style-type: none"><li>1. Visually check the wiring harness connection.</li><li>2. Replace the harness if it has visible damage.</li><li>3. Replace the front passenger air bag off indicator.</li><li>4. Replace the air bag diagnosis sensor unit.</li><li>5. Replace the related harness.</li></ol>

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-70, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-70, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-70, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000011289863

##### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal

# B1023 PASSENGER AIR BAG OFF INDICATOR

## < DTC/CIRCUIT DIAGNOSIS >

---

- Poor connection

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 2

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 3

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

YES >> GO TO 4

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 5

NO >> Refer to [GI-43, "Intermittent Incident"](#).

## 5.PASSENGER AIR BAG OFF INDICATOR

---

1. Replace the passenger air bag off indicator. Refer to [IP-15, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 6

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

YES >> GO TO 7

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> END

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM

### Description

INFOID:000000011289864

#### DTC B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM (OCS)

The OCS control unit is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the OCS for failures and interruptions in communication between the OCS control unit and the air bag diagnosis sensor unit.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289865

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
OCCUPANT SENS C/U [UNIT FAIL]	B1017	The OCS control unit is malfunctioning.	1. Replace the OCS control unit.
	B1020		
	B1021		
OCCUPANT SENS [UNIT FAIL]	B1018	The OCS sensor mat is malfunctioning.	
BELT TENSION SENS [UNIT FAIL]	B1019	The OCS is malfunctioning.	
OCCUPANT SENS C/U [COMM FAIL]	B1022	Communication between the OCS control unit and the air bag diagnosis sensor unit is interrupted.	1. Visually check the wiring harness connections to the OCS control unit and the seat sub-harness. 2. Replace the harness if it has visible damage. 3. Replace the OCS control unit. 4. Replace the air bag diagnosis sensor unit.

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-73, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2. ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-73, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "Self-Diagnosis Function \(Without CONSULT\)"](#).

##### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?



# B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> Refer to [SRC-73, "Diagnosis Procedure"](#).  
NO >> Inspection End.

A

## Diagnosis Procedure

INFOID:0000000011289866

### 1. HARNESS CONNECTOR

B

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

C

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

D

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

E

F

### 2. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

G

#### Is DTC still current?

- YES >> GO TO 3.  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

SRC

### 3. WIRING HARNESS

I

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

J

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

K

### 4. CONFIRM DTC

L

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

M

#### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-43, "Intermittent Incident"](#).

N

### 5. REPLACE OCS CONTROL UNIT

1. Replace the OCS control unit. Refer to [SR-26, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

O

#### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

P

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

## **B1017 – B1022 OCCUPANT CLASSIFICATION SYSTEM**

< DTC/CIRCUIT DIAGNOSIS >

---

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

**7**.RELATED HARNESS

---

Replace the related harness.

>> **END**

# B1209 – B1211 COLLISION DETECTION

< DTC/CIRCUIT DIAGNOSIS >

## B1209 – B1211 COLLISION DETECTION

### Description

INFOID:000000011289867

#### DTC B1209 - B1211 COLLISION DETECTION

The air bag diagnosis sensor unit will set this DTC if it has detected a collision which has resulted in a deployment of one or more air bags or pre-tensioners. If this DTC is detected after a SRS repair, the air bag diagnosis sensor unit has not yet been replaced. This DTC can not be erased.

#### PART LOCATION

Refer to [SRC-7, "SRS Component Parts Location"](#).

### DTC Logic

INFOID:000000011289868

#### DTC DETECTION LOGIC

With CONSULT

CONSULT name	DTC	DTC detecting condition	Repair order
FRONTAL COLLISION DETECTION	B1209	Driver and/or front passenger air bag modules are deployed.	Refer to <a href="#">SR-5, "For Frontal Collision"</a> .
SIDE COLLISION DETECTION	B1210	Side and/or curtain air bag modules are deployed.	Refer to <a href="#">SR-7, "For Side and Rollover Collision"</a> .
ROLLOVER DETECTION	B1211	Curtain air bag module and seat belt pretensioner are deployed	

SRC

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.INSPECTION START

Turn ignition switch ON.

>> GO TO 2.

##### 2.CHECK SELF-DIAG RESULT

Check for the DTC on CONSULT.

Is the DTC detected?

YES >> Refer to [SRC-75, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000011289869

Refer to [SR-5, "For Frontal Collision"](#) or [SR-7, "For Side and Rollover Collision"](#).

# DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### DIAGNOSIS SENSOR UNIT

Trouble Diagnosis with CONSULT

INFOID:0000000011289870

#### DIAGNOSTIC CODE CHART

##### NOTE:

Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using air bag warning lamp or CONSULT each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

CONSULT name	DTC	DTC detecting condition	Repair order	
DRIVER AIRBAG MODULE [OPEN]	B1049	Driver air bag module circuit (DR1) is open (including the spiral cable).	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Inspect spiral cable circuit.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the driver air bag module.</li> <li>6. Replace the related harness.</li> </ol>	
	B1054	Driver air bag module circuit (DR2) is open (including the spiral cable).		
DRIVER AIRBAG MODULE [VB-SHORT]	B1050	Driver air bag module circuit (DR1) is shorted to a power supply circuit (including the spiral cable).		
	B1055	Driver air bag module circuit (DR2) is shorted to a power supply circuit (including the spiral cable).		
DRIVER AIRBAG MODULE [GND-SHORT]	B1051	Driver air bag module circuit (DR1) is shorted to ground (including the spiral cable).		
	B1056	Driver air bag module circuit (DR2) is shorted to ground (including the spiral cable).		
DRIVER AIRBAG MODULE [SHORT]	B1052	Driver air bag module circuits (DR1) are shorted to each other (including the spiral cable).		
	B1057	Driver air bag module circuits (DR2) are shorted to each other (including the spiral cable).		
ASSIST A/B MODULE [OPEN]	B1065	Front passenger air bag module circuit (AS1) is open.		<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front passenger air bag module.</li> <li>5. Replace the related harness.</li> </ol>
	B1070	Front passenger air bag module circuit (AS2) is open.		
ASSIST A/B MODULE [VB-SHORT]	B1066	Front passenger air bag module circuit (AS1) is shorted to a power supply circuit.		
	B1071	Front passenger air bag module circuit (AS2) is shorted to a power supply circuit.		
ASSIST A/B MODULE [GND-SHORT]	B1067	Front passenger air bag module circuit (AS1) is shorted to ground.		
	B1072	Front passenger air bag module circuit (AS2) is shorted to ground.		
ASSIST A/B MODULE [SHORT]	B1068	Front passenger air bag module circuits (AS1) are shorted to each other.		
	B1073	Front passenger air bag module circuits (AS2) are shorted to each other.		

## DIAGNOSIS SENSOR UNIT

### < ECU DIAGNOSIS INFORMATION >

CONSULT name	DTC	DTC detecting condition	Repair order
SIDE MODULE LH [OPEN]	B1134	Front LH side air bag module circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front LH side air bag module.</li> <li>5. Replace the related harness.</li> </ol>
SIDE MODULE LH [VB-SHORT]	B1135	Front LH side air bag module circuit is shorted to a power supply circuit.	
SIDE MODULE LH [GND-SHORT]	B1136	Front LH side air bag module circuit is shorted to ground.	
SIDE MODULE LH [SHORT]	B1137	Front LH side air bag module circuits are shorted to each other.	
SIDE MODULE RH [OPEN]	B1129	Front RH side air bag module circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front RH side air bag module.</li> <li>5. Replace the related harness.</li> </ol>
SIDE MODULE RH [VB-SHORT]	B1130	Front RH side air bag module circuit is shorted to a power supply circuit.	
SIDE MODULE RH [GND-SHORT]	B1131	Front RH side air bag module circuit is shorted to ground.	
SIDE MODULE RH [SHORT]	B1132	Front RH side air bag module circuits are shorted to each other.	
FR CURTN MODULE LH [OPEN]	B1198	LH side curtain air bag module (front) circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the LH side curtain air bag module (front).</li> <li>5. Replace the related harness.</li> </ol>
FR CURTN MODULE LH [VB-SHORT]	B1199	LH side curtain air bag module (front) circuit is shorted to a power supply circuit.	
FR CURTN MODULE LH [GND-SHORT]	B1200	LH side curtain air bag module (front) circuit is shorted to ground.	
FR CURTN MODULE LH [SHORT]	B1201	LH side curtain air bag module (front) circuits are shorted to each other.	
FR CURTN MODULE RH [OPEN]	B1193	RH side curtain air bag module (front) circuit is open.	
FR CURTN MODULE RH [VB-SHORT]	B1194	RH side curtain air bag module (front) circuit is shorted to a power supply circuit.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the RH side curtain air bag module (front).</li> <li>5. Replace the related harness.</li> </ol>
FR CURTN MODULE RH [GND-SHORT]	B1195	RH side curtain air bag module (front) circuit is shorted to ground.	
FR CURTN MODULE RH [SHORT]	B1196	RH side curtain air bag module (front) circuits are shorted to each other.	
CURTAIN MODULE LH [OPEN]	B1150	LH side curtain air bag module (rear) circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the LH side curtain air bag module (rear).</li> <li>5. Replace the related harness.</li> </ol>
CURTAIN MODULE LH [VB-SHORT]	B1151	LH side curtain air bag module (rear) circuit is shorted to a power supply circuit.	
CURTAIN MODULE LH [GND-SHORT]	B1152	LH side curtain air bag module (rear) circuit is shorted to ground.	
CURTAIN MODULE LH [SHORT]	B1153	LH side curtain air bag module (rear) circuits are shorted to each other.	
CURTAIN MODULE RH [OPEN]	B1145	RH side curtain air bag module (rear) circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the RH side curtain air bag module (rear).</li> <li>5. Replace the related harness.</li> </ol>
CURTAIN MODULE RH [VB-SHORT]	B1146	RH side curtain air bag module (rear) circuit is shorted to a power supply circuit.	
CURTAIN MODULE RH [GND-SHORT]	B1147	RH side curtain air bag module (rear) circuit is shorted to ground.	
CURTAIN MODULE RH [SHORT]	B1148	RH side curtain air bag module (rear) circuits are shorted to each other.	

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## DIAGNOSIS SENSOR UNIT

### < ECU DIAGNOSIS INFORMATION >

CONSULT name	DTC	DTC detecting condition	Repair order
PRE-TEN FRONT LH [OPEN]	B1086	LH seat belt pre-tensioner circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front LH seat belt pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>
PRE-TEN FRONT LH [VB-SHORT]	B1087	LH seat belt pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN FRONT LH [GND-SHORT]	B1088	LH seat belt pre-tensioner circuit is shorted to ground.	
PRE-TEN FRONT LH [SHORT]	B1089	LH seat belt pre-tensioner circuits are shorted to each other.	
PRE-TEN FRONT RH [OPEN]	B1081	RH seat belt pre-tensioner circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front RH seat belt pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>
PRE-TEN FRONT RH [VB-SHORT]	B1082	RH seat belt pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN FRONT RH [GND-SHORT]	B1083	RH seat belt pre-tensioner circuit is shorted to ground.	
PRE-TEN FRONT RH [SHORT]	B1084	RH seat belt pre-tensioner circuits are shorted to each other.	
PRE-TEN2 FRONT LH [OPEN]	B1182	LH seat belt buckle pre-tensioner circuit is open.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front LH seat belt buckle pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>
PRE-TEN2 FRONT LH [VB-SHORT]	B1183	LH seat belt buckle pre-tensioner circuit is shorted to a power supply circuit.	
PRE-TEN2 FRONT LH [GND-SHORT]	B1184	LH seat belt buckle pre-tensioner circuit is shorted to ground.	
PRE-TEN2 FRONT LH [SHORT]	B1185	LH seat belt buckle pre-tensioner circuits are shorted to each other.	
PRE-TEN2 FRONT RH [OPEN]	B1177	RH seat belt buckle pre-tensioner circuit is open.	
PRE-TEN2 FRONT RH [VB-SHORT]	B1178	RH seat belt buckle pre-tensioner circuit is shorted to a power supply circuit.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front RH seat belt buckle pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>
PRE-TEN2 FRONT RH [GND-SHORT]	B1179	RH seat belt buckle pre-tensioner circuit is shorted to ground.	
PRE-TEN2 FRONT RH [SHORT]	B1180	RH seat belt buckle pre-tensioner circuits are shorted to each other.	
CRASH ZONE SEN [UNIT FAIL]	B1033	Crash zone sensor has malfunctioned.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the crash zone sensor.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>
	B1034		
CRASH ZONE SEN [COMM FAIL]	B1035	Crash zone sensor communication error.	
SATELLITE SENS LH [UNIT FAIL]	B1118	LH side air bag satellite sensor has malfunctioned.	
	B1119		
SATELLITE SENS LH [COMM FAIL]	B1120	LH side air bag satellite sensor communication error.	
SATELLITE SENS RH [UNIT FAIL]	B1113	RH side air bag satellite sensor has malfunctioned.	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the RH side air bag satellite sensor.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>
	B1114		
SATELLITE SENS RH [COMM FAIL]	B1115	RH side air bag satellite sensor communication error.	

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

CONSULT name	DTC	DTC detecting condition	Repair order	
FR-LH DOOR SATEL SENS [UNIT FAIL]	B1343	Front door satellite sensor LH has mal- functioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the front door satellite sensor LH. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.	A
	B1344			B
FR-LH DOOR SATEL SENS [COM FAIL]	B1345	Front door satellite sensor LH communication error.		C
	B1347			D
	B1348			E
	B1349			F
FR-LH DOOR SATEL SENS [MIS-INSTALLATION]	B1346	Front door satellite sensor LH is out of specification.		G
FR-RH DOOR SATEL SENS [UNIT FAIL]	B1336	Front door satellite sensor RH has mal- functioned.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the front door satellite sensor RH. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.	
	B1337			
FR-RH DOOR SATEL SENS [COM FAIL]	B1338	Front door satellite sensor RH communication error.		
	B1340			
	B1341			
	B1342			
FR-RH DOOR SATEL SENS [MIS-INSTALLATION]	B1339	Front door satellite sensor RH is out of specification.		
FR DOOR SATEL SENS	B1350	Front door satellite sensor LH/RH have malfunctioned.	1. Visually check the wiring harness connection. 2. Replace the harnesses if they have visible damage. 3. Replace both front door satellite sensors LH and RH. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harnesses.	SRC
CONTROL UNIT	B1XXX	Air bag diagnosis sensor unit is malfunc- tioning.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the related harness.	I
OCCUPANT SENS C/U [UNIT FAIL]	B1017	The OCS control unit is malfunctioning.	1. Replace the OCS control unit.	J
	B1020			K
	B1021			L
OCCUPANT SENS [UNIT FAIL]	B1018	The OCS sensor mat is malfunctioning.		
BELT TENSION SENS [UNIT FAIL]	B1019	The OCS is malfunctioning.		
OCCUPANT SENS C/U [COMM FAIL]	B1022	Communication between the OCS con- trol unit and the air bag diagnosis sensor unit is interrupted.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the OCS control unit. 4. Replace the air bag diagnosis sensor unit.	M
PASS A/B INDCTR CKT	B1023	Front passenger air bag OFF indicator is malfunctioning.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the front passenger air bag OFF in- dicator. 4. Replace the air bag diagnosis sensor unit. 5. Replace the related harness.	N
FRONTAL COLLISION DE- TECTION	B1209	Driver and/or front passenger air bag modules are deployed.	Refer to <a href="#">SR-5. "For Frontal Collision"</a> .	O
SIDE COLLISION DETEC- TION	B1210	Side and/or curtain air bag modules are deployed.	Refer to <a href="#">SR-7. "For Side and Rollover Collision"</a> .	P
ROLLOVER DETECTION	B1211	Curtain air bag module and seat belt pre-tensioner are deployed.		

# DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

## Trouble Diagnosis without CONSULT

INFOID:000000011289871

### WARNING LAMP FLASH CODE CHART

**NOTE:**

Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using air bag warning lamp each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

<p>&lt;Diagnosis results (previously stored in the memory) might not be erased after repair or intermittent malfunctions have been detected in the past.&gt;</p>	
<p>Flash pattern</p> <p>a through b are repeated.</p>	<p>Repair order</p> <ol style="list-style-type: none"> <li>1. Go to DIAGNOSTIC PROCEDURES 2 and 3.</li> </ol>
<p>&lt;Driver air bag module&gt;</p>	
<p>Flash pattern</p> <p>a through d are repeated. d: Two flashes indicate malfunctioning driver air bag module circuits.</p>	<p>Repair order</p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Inspect the spiral cable circuit.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace driver air bag module.</li> <li>6. Replace the related harness.</li> </ol>
<p>&lt;Air bag diagnosis sensor unit&gt;</p>	
<p>Flash pattern</p> <p>a through d are repeated. d: Seven flashes indicate malfunctioning diagnosis sensor unit circuit.</p>	<p>Repair order</p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the related harness.</li> </ol>
<p>&lt;Front passenger air bag module&gt;</p>	
<p>Flash pattern</p> <p>a through d are repeated. d: Eight flashes indicate malfunctioning front passenger air bag module circuit.</p>	<p>Repair order</p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace front passenger air bag module.</li> <li>5. Replace the related harness.</li> </ol>



# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

<Crash zone sensor>	
Flash pattern	Repair order
<p>a through d are repeated. d: Six flashes indicate malfunctioning crash zone sensor circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the crash zone sensor.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

WHIA0200E

<Front RH seat belt pre-tensioner>	
Flash pattern	Repair order
<p>a through d are repeated. d: One flash indicates malfunctioning front RH seat belt pre-tensioner circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace front RH seat belt pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0604GB

<Front LH seat belt pre-tensioner>	
Flash pattern	Repair order
<p>a through d are repeated. d: Three flashes indicate malfunctioning front LH seat belt pre-tensioner circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace front LH seat belt pre-tensioner.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0605GB

<Seat belt buckle pre-tensioner assembly RH>	
Flash pattern	Repair order
<p>a through d are repeated. d: Twelve flashes indicate malfunctioning seat belt buckle pre-tensioner assembly RH circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the seat belt buckle pre-tensioner assembly RH.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0615GB

<Seat belt buckle pre-tensioner assembly LH>	
Flash pattern	Repair order
<p>a through d are repeated. d: Thirteen flashes indicate malfunctioning seat belt buckle pre-tensioner assembly LH circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace seat belt buckle pre-tensioner assembly LH.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0616GB

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

<RH side air bag (Satellite) sensor>	
<p><b>Flash pattern</b></p> <p>a through f are repeated. f: Three flashes indicate malfunctioning RH side air bag (Satellite) sensor circuit.</p>	<p><b>Repair order</b></p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the RH side air bag (Satellite) sensor.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

WHIA0203E

<LH side air bag (Satellite) sensor>	
<p><b>Flash pattern</b></p> <p>a through f are repeated. f: Four flashes indicate malfunctioning LH side air bag (Satellite) sensor.</p>	<p><b>Repair order</b></p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the LH side air bag (Satellite) sensor.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

WHIA0204E

<Front door satellite sensor RH>	
<p><b>Flash pattern</b></p> <p>a through f are repeated. f: Nine flashes indicate malfunctioning front door satellite sensor RH.</p>	<p><b>Repair order</b></p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the front door satellite sensor RH.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0334GB

<Front door satellite sensor LH>	
<p><b>Flash pattern</b></p> <p>a through f are repeated. f: Ten flashes indicate malfunctioning front door satellite sensor LH.</p>	<p><b>Repair order</b></p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the front door satellite sensor LH.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0335GB

<Front door satellite sensors LH/RH>	
<p><b>Flash pattern</b></p> <p>a through f are repeated. f: Twenty flashes indicate malfunctioning front door satellite sensors LH/RH</p>	<p><b>Repair order</b></p> <ol style="list-style-type: none"> <li>1. Visually check the wiring harness connections.</li> <li>2. Replace the harnesses if they have visible damage.</li> <li>3. Replace both front door satellite sensors LH and RH.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harnesses.</li> </ol>

AWHIA0276GB

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

<Front RH side air bag module>	
Flash pattern	Repair order
<p>a through f are repeated. f: One flash indicate malfunctioning front RH side air bag module circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front RH side air bag module.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0305GB

<Front LH side air bag module>	
Flash pattern	Repair order
<p>a through f are repeated. f: Two flashes indicate malfunctioning front LH side air bag module circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace the front LH side air bag module.</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0304GB

<LH side curtain air bag module (front)>	
Flash pattern	Repair order
<p>a through f are repeated. f: Eight flashes indicate malfunctioning LH side curtain air bag module (front) circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace LH side curtain air bag module (front).</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0329GB

<RH side curtain air bag module (front)>	
Flash pattern	Repair order
<p>a through f are repeated. f: Seven flashes indicate malfunctioning RH side curtain air bag module (front) circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace RH side curtain air bag module (front).</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0330GB

<LH side curtain air bag module (rear)>	
Flash pattern	Repair order
<p>a through f are repeated. f: Six flashes indicate malfunctioning LH side curtain air bag module (rear) circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace LH side curtain air bag module (rear).</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0331GB

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

<RH side curtain air bag module (rear)>	
Flash pattern	Repair order
<p>a through f are repeated. f: Five flashes indicate malfunctioning RH side curtain air bag module (rear) circuit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace the air bag diagnosis sensor unit.</li> <li>4. Replace RH side curtain air bag module (rear).</li> <li>5. Replace the related harness.</li> </ol>

AWHIA0332GB

<Occupant classification system>	
Flash pattern	Repair order
<p>a through d are repeated. d: Five flashes indicate malfunctioning occupant classification system control unit.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace occupant classification system control unit.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> </ol>

AWHIA0606GB

<Front passenger air bag off indicator>	
Flash pattern	Repair order
<p>a through d are repeated. d: Eleven flashes indicate malfunctioning front passenger air bag off indicator.</p>	<ol style="list-style-type: none"> <li>1. Visually check the wiring harness connection.</li> <li>2. Replace the harness if it has visible damage.</li> <li>3. Replace front passenger air bag off indicator.</li> <li>4. Replace the air bag diagnosis sensor unit.</li> <li>5. Replace the related harness.</li> </ol>

WHIA0212E

# SRS AIR BAG CONTROL SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### SRS AIR BAG CONTROL SYSTEM

#### Wiring Diagram

INFOID:000000011289872



ABHWA0308GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

(NX) : EXCEPT FOR MEXICO



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABHWA0338GB

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

## SRS AIR BAG CONTROL SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5P	O/L	-
6P	W/L	-

Connector No.	M13
Connector Name	FRONT PASSENGER AIR BAG OFF INDICATOR
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	B	-
3	R/Y	-

Connector No.	M22
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	G/W	-

Connector No.	M23
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	P/L	PASS SEAT BELT

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	ACCESSORY
2	P	AIR BAG
9	B	GND
24	O/L	RUN/START
27	O/B	SEAT BELT

Connector No.	M29
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
23	Y/B	-
28	Y/L	-
30	Y	-




ABH1A1022GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >



ABH1A1023GB



# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	M77
Connector Name	FRONT PASSENGER AIR BAG MODULE (SERVICE REPLACEMENT)
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	Y/G	-
2	Y/R	-
3	Y/BR	-
4	Y/V	-

Connector No.	M60
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6T	O	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20J	O/B	-

Connector No.	M101
Connector Name	DRIVER AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
10	W	-
11	BR	-

Connector No.	M86
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
2	SHIELD	-
3	P	-
4	L	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
2	SHIELD	-
3	Y	-
4	BR	-

ABHIA1024GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	M106
Connector Name	FRONT PASSENGER AIR BAG MODULE
Connector Color	ORANGE



Terminal No.	Color of Wire	Signal Name
3	Y/BR	-
4	Y/V	-

Connector No.	M105
Connector Name	FRONT PASSENGER AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y/G	-
2	Y/R	-

Connector No.	M103
Connector Name	DRIVER AIR BAG MODULE
Connector Color	ORANGE




Terminal No.	Color of Wire	Signal Name
12	R	-
13	BR	-

Connector No.	E4
Connector Name	CRASH ZONE SENSOR
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	-
2	O	-

Connector No.	M179
Connector Name	JOINT CONNECTOR-M01
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
10	O	-
11	O	-


ABH1A1025GB

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
28G	SHIELD	-
29G	B	-
30G	W	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B10
Connector Name	FRONT LH SIDE AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y/G	-
2	Y/R	-

Terminal No.	Color of Wire	Signal Name
17	R/Y	P-LH2 (-)
30	O/B	BUCKLE SW LH
33	Y/G	S-LH1(+)
34	Y/R	S-LH1(-)
37	Y	C-LH1(+)
38	BR	C-LH1(-)
41	LG	C-LH2(+)
42	B/Y	C-LH2(-)
49	Y/G	SAT SEN LH(+)
50	Y/L	SAT SEN LH(-)
56	SHIELD	SHIELD GND

Connector No.	B9
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
12	Y/G	P-LH1 (+)
13	Y/R	P-LH1 (-)
16	BR/Y	P-LH2 (+)

ABHIA1026GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	B14
Connector Name	FRONT LH SEAT BELT PRE-TENSIONER
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y/G	-
2	Y/R	-

Connector No.	B15
Connector Name	LH SIDE AIR BAG (SATELLITE) SENSOR
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y/G	-
2	Y/L	-

Connector No.	B38
Connector Name	LH SIDE FRONT CURTAIN AIR BAG MODULE
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B/Y	-

Connector No.	B54
Connector Name	LH SIDE REAR CURTAIN AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABH1A1027GB

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
26	P/B	ODS IN
29	L	BUCKLE SW RH
31	Y	S-RH1 (+)
32	Y/B	S-RH1 (-)
35	G	INF CURTAIN RH (+)
36	L	INF CURTAIN RH (-)
39	G	INF CURTAIN2 RH (+)
40	L	INF CURTAIN2 RH (-)
47	W	SAT SENS RH (+)
48	O	SAT SENS RH (-)
55	SHIELD	GND

Connector No.	B113
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
10	Y	P-RH1 (+)
11	Y/B	P-RH1 (-)
14	G/Y	P-RH2 (+)
15	L/Y	P-RH2 (-)

Connector No.	B74
Connector Name	SEAT BELT BUCKLE PRE-TENSIONER ASSEMBLY LH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	B	-
3	BR/Y	-
4	R/Y	-

Connector No.	B127
Connector Name	FRONT RH SEAT BELT PRE-TENSIONER
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y/B	-

Connector No.	B126
Connector Name	FRONT RH SIDE AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y/B	-

Connector No.	B114
Connector Name	RH SIDE AIR BAG (SATELLITE) SENSOR
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	-
2	O	-

ABHIA1028GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	B128
Connector Name	RH SIDE REAR CURTAIN AIR BAG MODULE
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	B129
Connector Name	RH SIDE FRONT CURTAIN AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	B136
Connector Name	WIRES TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B/Y	-
2	P/B	-
4	W/L	-
5	B	-
6	Y/W	-
8	Y/B	-

Connector No.	B137
Connector Name	BELT TENSION SENSOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y/W	-
2	B/Y	-
3	Y/B	-

Connector No.	B149
Connector Name	WIRES TO WIRE
Connector Color	WHITE





ABH1A1029GB

# SRS AIR BAG CONTROL SYSTEM



< WIRING DIAGRAM >

Connector No.	B350
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	BR/W	-
4	L/B	-
5	G/B	-
6	P/L	-
8	R	-

Connector No.	B157
Connector Name	SEAT BELT BUCKLE PRE-TENSIONER ASSEMBLY RH
Connector Color	YELLOW

Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	G/Y	-
4	L/Y	-



Connector No.	B352
Connector Name	OCCUPANT CLASSIFICATION SYSTEM SENSOR
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	G	-
2	Y/R	-
3	O	-

Terminal No.	Color of Wire	Signal Name
9	L/B	IGN
10	-	-
11	-	-
12	-	-
13	-	-
14	R/Y	BTS (-)
15	O	(-)
16	P/L	BTS (+)
17	-	-
18	BR/W	ODS LED

Connector No.	B351
Connector Name	OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	R	BTS SIG
5	G/B	GND
6	Y/R	SIG
7	G	(+)
8	-	-

ABHIA1030GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	D103
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
2	SHIELD	-
3	Y	-
4	BR	-

Connector No.	D18
Connector Name	FRONT DOOR SATELLITE SENSOR LH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	D17
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
2	SHIELD	-
3	P	-
4	L	-

Connector No.	D117
Connector Name	FRONT DOOR SATELLITE SENSOR RH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-

ABHIA1031GB



# SRS AIR BAG SYSTEM

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### SRS AIR BAG SYSTEM

#### "AIR BAG" Warning Lamp Does Not Turn Off

INFOID:000000011289873

##### DIAGNOSTIC PROCEDURE

##### 1.CHECK CONDITION OF AIR BAG MODULE

Inspect for any deployed air bag modules or seat belt pre-tensioners.

Are any air bag modules or seat belt pre-tensioners deployed?

- YES >> Refer to [SR-5, "For Frontal Collision"](#) or [SR-7, "For Side and Rollover Collision"](#).
- NO >> GO TO 2

##### 2.CHECK THE AIR BAG FUSE

Check 10A fuse [No. 13, located in the fuse block (J/B)].

Is the fuse blown?

- Yes >> GO TO 3
- No >> GO TO 4

##### 3.CHECK AIR BAG FUSE AGAIN

Replace 10A fuse [No. 13, located in the fuse block (J/B)] and turn ignition switch ON.

Does the fuse blow again?

- YES >> Replace harness.
- NO >> Inspection End.

##### 4.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Connect CONSULT.

Is "AIR BAG" displayed on CONSULT?

- YES >> GO TO 5
- NO >> Visually inspect the air bag diagnosis sensor unit harness connections. If the connections are OK, replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).

##### 5.CHECK HARNESS CONNECTION

Check for loose connections between the combination meter and the air bag diagnosis sensor unit.

Are there any loose connections?

- Yes >> Properly connect the combination meter and air bag diagnosis sensor unit harness connectors. If "AIR BAG" warning lamp still does not turn off, replace the wiring harness.
- No >> Replace air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).

#### "AIR BAG" Warning Lamp Does Not Turn On

INFOID:000000011289874

##### DIAGNOSTIC PROCEDURE

##### 1.CHECK METER FUSE

Check the 10A fuse [No. 14, located in the fuse block (J/B)].

Is the fuse blown?

- Yes >> GO TO 2
- No >> GO TO 3

##### 2.REPLACE METER FUSE AND CHECK AGAIN

Replace 10A fuse [No. 14, located in the fuse block (J/B)] and turn ignition switch ON.

Does the fuse blow again?

- Yes >> Replace harness.
- No >> Inspection End.

##### 3.CHECK HARNESS CONNECTIONS BETWEEN AIR BAG DIAGNOSIS SENSOR UNIT AND COMBINA-

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## SRS AIR BAG SYSTEM

< SYMPTOM DIAGNOSIS >

---

COMBINATION METER

---

Inspect the harness and connectors between the air bag diagnosis sensor unit and the combination meter.

Do the harness or connectors have any visible damage?

- Yes >> Replace harness.
- No >> GO TO 4

### 4. CHECK COMBINATION METER

---

Disconnect the air bag diagnosis sensor unit harness connectors and turn ignition switch ON.

Does "AIR BAG" warning lamp turn on?

- Yes >> Replace the air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).
- No >> Replace the combination meter. Refer to [MWI-99, "Removal and Installation"](#).

# PASSENGER SEAT BELT WARNING SYSTEM

< SYMPTOM DIAGNOSIS >

## PASSENGER SEAT BELT WARNING SYSTEM

### Seat Belt Warning System Does Not Function

INFOID:000000011289875

#### 1. SEAT BELT WARNING LIGHT

Turn ignition switch ON.

Does the seat belt warning lamp come ON?

YES >> GO TO 2

NO >> • Check 10A fuse [No. 14, located in the fuse block (J/B)].

• Check seat belt buckle switch LH.

• Check harness between combination meter and seat belt buckle switch LH.

• Check combination meter. Refer to [MWI-27, "CONSULT Function \(METER/M&A\)"](#).

#### 2. SEAT BELT BUCKLE LH

Fasten the seat belt buckle LH.

Does the seat belt warning lamp go OFF?

YES >> GO TO 3

NO >> • Check seat belt buckle switch LH.

• Check harness between combination meter and seat belt buckle switch LH.

#### 3. OCCUPANT CLASSIFICATION SYSTEM

Have a helper sit in the passenger seat.

Does the seat belt warning lamp go ON?

YES >> GO TO 4

NO >> • Check occupant classification system. Refer to [SRC-11, "Occupant Classification System \(OCS\)"](#).

• Check harness between occupant classification control unit and air bag diagnosis sensor unit.

#### 4. SEAT BELT BUCKLE RH

Fasten the seat belt buckle RH.

Does the seat belt warning lamp go OFF?

YES >> System OK.

NO >> • Check seat belt buckle switch RH.

• Check harness between seat belt buckle switch RH and air bag diagnosis sensor unit.

• Replace air bag diagnosis sensor unit. Refer to [SR-24, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011289876

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service

INFOID:000000011289877

- Do not use electrical test equipment to check SRS circuits unless instructed to in this Service Manual.
- Before servicing the SRS, turn ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.  
For approximately 3 minutes after the cables are removed, it is still possible for the air bag and seat belt pretensioner to deploy. Therefore, do not work on any SRS connectors or wires until at least 3 minutes have passed.
- The air bag diagnosis sensor unit must always be installed with the arrow mark "←" pointing toward the front of the vehicle for proper operation. Also check air bag diagnosis sensor unit for cracks, deformities or rust before installation and replace as required.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place driver and front passenger air bag modules with the pad side facing upward and seat mounted front side air bag module standing with the stud bolt side facing down.
- Conduct self-diagnosis to check entire SRS for proper function after replacing any components.
- After air bag inflates, the front instrument panel assembly should be replaced if damaged.

#### Occupant Classification System Precaution

INFOID:000000011289878

Replace occupant classification system control unit and passenger front seat cushion as an assembly.

#### Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000011289879

#### **NOTE:**

# PRECAUTIONS

## < PRECAUTION >

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

## OPERATION PROCEDURE

1. Connect both battery cables.

### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P