

SECTION **WCS**

WARNING CHIME SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

CONTENTS

<p>BASIC INSPECTION 3</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 3</p> <p style="padding-left: 20px;">Work Flow3</p> <p>SYSTEM DESCRIPTION 5</p> <p>WARNING CHIME SYSTEM 5</p> <p>WARNING CHIME SYSTEM5</p> <p style="padding-left: 20px;">WARNING CHIME SYSTEM : System Diagram5</p> <p style="padding-left: 20px;">WARNING CHIME SYSTEM : System Description5</p> <p style="padding-left: 20px;">WARNING CHIME SYSTEM : Component Parts Location6</p> <p style="padding-left: 20px;">WARNING CHIME SYSTEM : Component Description7</p> <p>LIGHT REMINDER WARNING CHIME7</p> <p style="padding-left: 20px;">LIGHT REMINDER WARNING CHIME : System Diagram7</p> <p style="padding-left: 20px;">LIGHT REMINDER WARNING CHIME : System Description7</p> <p style="padding-left: 20px;">LIGHT REMINDER WARNING CHIME : Component Parts Location8</p> <p style="padding-left: 20px;">LIGHT REMINDER WARNING CHIME : Component Description8</p> <p>SEAT BELT WARNING CHIME8</p> <p style="padding-left: 20px;">SEAT BELT WARNING CHIME : System Diagram9</p> <p style="padding-left: 20px;">SEAT BELT WARNING CHIME : System Description9</p> <p style="padding-left: 20px;">SEAT BELT WARNING CHIME : Component Parts Location10</p> <p style="padding-left: 20px;">SEAT BELT WARNING CHIME : Component Description10</p> <p>PARKING BRAKE RELEASE WARNING CHIME....10</p> <p style="padding-left: 20px;">PARKING BRAKE RELEASE WARNING CHIME : System Diagram10</p>	<p>PARKING BRAKE RELEASE WARNING CHIME : System Description10</p> <p>PARKING BRAKE RELEASE WARNING CHIME : Component Parts Location11</p> <p>PARKING BRAKE RELEASE WARNING CHIME : Component Description12</p> <p>KEY WARNING CHIME12</p> <p style="padding-left: 20px;">KEY WARNING CHIME : System Diagram12</p> <p style="padding-left: 20px;">KEY WARNING CHIME : System Description12</p> <p style="padding-left: 20px;">KEY WARNING CHIME : Component Parts Location13</p> <p style="padding-left: 20px;">KEY WARNING CHIME : Component Description...13</p> <p>DIAGNOSIS SYSTEM (METER)14</p> <p style="padding-left: 20px;">CONSULT Function (METER/M&A)14</p> <p>DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)17</p> <p>COMMON ITEM17</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)17</p> <p>BUZZER18</p> <p style="padding-left: 20px;">BUZZER : CONSULT Function (BCM - BUZZER)...18</p> <p>DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)20</p> <p>COMMON ITEM20</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)20</p> <p>BUZZER20</p> <p style="padding-left: 20px;">BUZZER : CONSULT Function (BCM - BUZZER)...20</p> <p>DTC/CIRCUIT DIAGNOSIS22</p> <p>POWER SUPPLY AND GROUND CIRCUIT22</p> <p>COMBINATION METER22</p> <p style="padding-left: 20px;">COMBINATION METER : Diagnosis Procedure22</p>
--	---

WCS

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)	22	WITH INTELLIGENT KEY : DTC Index	81
BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure	22	WITHOUT INTELLIGENT KEY	83
BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)	23	WITHOUT INTELLIGENT KEY : Reference Value...	83
BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure	23	WITHOUT INTELLIGENT KEY : Wiring Diagram - BCM -	97
METER BUZZER CIRCUIT	25	WITHOUT INTELLIGENT KEY : Fail-safe	105
Description	25	WITHOUT INTELLIGENT KEY :	
Component Function Check	25	DTC Inspection Priority Chart	106
Diagnosis Procedure	25	WITHOUT INTELLIGENT KEY : DTC Index	106
SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT	26	SYMPTOM DIAGNOSIS	108
Description	26	THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	108
Component Function Check	26	Description	108
Diagnosis Procedure	26	Diagnosis Procedure	108
Component Inspection	27	THE LIGHT REMINDER WARNING DOES NOT SOUND	109
WARNING CHIME SYSTEM	28	Description	109
Wiring Diagram - WARNING CHIME -	28	Diagnosis Procedure	109
ECU DIAGNOSIS INFORMATION	33	THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	110
COMBINATION METER	33	Description	110
Reference Value	33	Diagnosis Procedure	110
Wiring Diagram - METER -	39	THE KEY WARNING DOES NOT SOUND (WITHOUT INTELLIGENT KEY)	111
Fail-Safe	46	Description	111
DTC Index	47	Diagnosis Procedure	111
BCM (BODY CONTROL MODULE)	48	PRECAUTION	112
WITH INTELLIGENT KEY	48	PRECAUTIONS	112
WITH INTELLIGENT KEY : Reference Value	48	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	112
WITH INTELLIGENT KEY : Wiring Diagram - BCM -	68	Precautions for Removing of Battery Terminal	112
WITH INTELLIGENT KEY : Fail-safe	79		
WITH INTELLIGENT KEY :			
DTC Inspection Priority Chart	80		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009945492

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

3. CHECK CONSULT SELF-DIAGNOSIS RESULTS

1. Connect CONSULT and perform self-diagnosis. Refer to [MWI-62, "DTC Index"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M

WCS

O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

2. When DTC is detected, follow the instructions below:

- Record DTC and Freeze Frame Data.

Are self-diagnosis results normal?

YES >> GO TO 4.

NO >> GO TO 5.

4.NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 5.

5.REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM : System Diagram

INFOID:000000009945493




WARNING CHIME SYSTEM : System Description

INFOID:000000009945494

COMBINATION METER

- The buzzer (1) for the warning chime system is integrated in the combination meter.
- The combination meter sounds the alarm buzzer installed in the combination meter when receiving the buzzer output signal transmitted from each unit.



BCM

BCM receives signals from various units and transmits a buzzer output signal to the combination meter via CAN communication if it judges that the warning buzzer should be activated.

WARNING CHIME FUNCTION LIST

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS


WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

Warning functions	Out line	Warning judgment unit	Refer to
Parking brake release warning chime	With ignition switch in the ON position, when the during the parking brake operation and the vehicle speed is 7 km/h (4.3 MPH) or more, the parking brake release warning chime will sound.	Combination meter	WCS-10. "PARKING BRAKE RELEASE WARNING CHIME : System Description"
Light reminder warning chime	With ignition switch in the OFF or ACC position, when the driver side door is open and the lighting switch is the 1st or 2nd position, the light reminder warning chime will sound.	BCM	WCS-7. "LIGHT REMINDER WARNING CHIME : System Description"
Seat belt warning chime	With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime will sound for approximately 6 seconds.	BCM	WCS-9. "SEAT BELT WARNING CHIME : System Description"
Key warning chime	With the key inserted into the ignition key cylinder, and the ignition switch except in ON or START position, when driver side door open, the key warning chime will sound.	BCM	WCS-12. "KEY WARNING CHIME : System Description"

WARNING CHIME SYSTEM : Component Parts Location

INFOID:000000009945495



JPNIA1685ZZ

1. Parking brake switch
2. ABS actuator and electric unit (control unit)
Refer to [BRC-12. "Component Parts Location"](#).
3. Combination meter
4. BCM
Refer to [BCS-10. "Component Parts Location"](#).
5. Seat belt buckle switch (driver side)

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

WARNING CHIME SYSTEM : Component Description


INFOID:000000009945496

Unit	Description
Combination meter	<ul style="list-style-type: none"> Receives a buzzer output signal from the BCM with CAN communication line and sounds the buzzer. Judges whether the parking brake is released from the vehicle speed signal received from the ABS actuator and electric unit (control unit) with CAN communication line and the parking brake switch signal from the parking brake switch, and sounds the buzzer if necessary. Receives the seat belt buckle switch signal (driver side) from the seat belt buckle switch (driver side) and transmits it to BCM with CAN communication line.
BCM	Based on the signals received from various units and switches, transmits the buzzer output signal to the combination meter via CAN communication.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to combination meter via CAN communication.
Seat belt buckle switch (driver side)	Transmits a seat belt buckle switch signal (driver side) to the combination meter.
Combination switch (Lighting switch)	Transmits the combination switch signal to BCM.
Driver side door switch	Transmits the driver side door switch signal to BCM.
Key switch	Transmits the key switch signal to BCM.
Parking brake switch	Transmits the parking brake switch signal to combination meter.

LIGHT REMINDER WARNING CHIME

LIGHT REMINDER WARNING CHIME : System Diagram

INFOID:000000009945497



LIGHT REMINDER WARNING CHIME : System Description

INFOID:000000009945498

DESCRIPTION

With ignition switch in the OFF or ACC position, when the driver side door is open and the lighting switch is the 1st or 2nd position, the light reminder warning chime will sound.

WARNING CHIME OPERATION CONDITIONS

The BCM transmits the buzzer output signal to combination meter with CAN communication line when all of the following operation conditions are met. When combination meter receives buzzer output signal, it sounds the buzzer.

Operation conditions		Signal name	Signal source
Ignition switch	OFF or ACC position	Ignition switch signal	—
Combination switch (Lighting switch)	1st or 2nd position	Combination switch signal	Combination switch (Lighting switch)
Driver side door	Open (driver side door switch ON)	Driver side door switch signal	Driver side door switch

WARNING CHIME CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P


WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

Operation conditions		Signal name	Signal source
Ignition switch	ON	Ignition switch signal	—
Combination switch (Lighting switch)	OFF	Combination switch signal	Combination switch (Lighting switch)
Driver side door	Close (driver side door switch OFF)	Driver side door switch signal	Driver side door switch

LIGHT REMINDER WARNING CHIME : Component Parts Location

INFOID:000000009945499



JPNIA1685ZZ

1. Parking brake switch
 2. ABS actuator and electric unit (control unit)
Refer to [BRC-12, "Component Parts Location"](#).
 3. Combination meter
 4. Refer to [BCS-10, "Component Parts Location"](#).
 5. Seat belt buckle switch (driver side)
- BCM

LIGHT REMINDER WARNING CHIME : Component Description

INFOID:000000009945500

Unit	Description
Combination meter	Receives a buzzer output signal from the BCM and sounds the buzzer.
BCM	Judges the light reminder warning conditions from the signals provided by various switches and transmits a buzzer output signal to the combination meter via CAN communication line if necessary.
Combination switch (Lighting switch)	Transmits the combination switch signal to BCM.
Driver side door switch	Transmits the driver side door switch signal to BCM.


SEAT BELT WARNING CHIME

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

SEAT BELT WARNING CHIME : System Diagram

INFOID:000000009945501



SEAT BELT WARNING CHIME : System Description

INFOID:000000009945502

DESCRIPTION

With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime will sound for approximately 6 seconds.

WARNING OPERATION CONDITIONS

The BCM transmits the buzzer output signal to combination meter with CAN communication line when all of the following operation conditions are met. When combination meter receives buzzer output signal, it sounds the buzzer.

Operation conditions		Signal name	Signal source
Ignition switch	ON	Ignition switch signal	—
Seat belt (driver side)	Unfastened (driver side seat belt buckle switch ON)	Seat belt buckle switch signal (driver side) (CAN communication)	Seat belt buckle switch (driver side) via combination meter

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.

Operation conditions		Signal name	Signal source
Ignition switch	OFF	Ignition switch signal	—
Seat belt (driver side)	Fastened (driver side seat belt buckle switch OFF)	Seat belt buckle switch signal (driver side) (CAN communication)	Seat belt buckle switch (driver side) via combination meter
6 seconds after the start of warning sound		—	—


A
B
C
D
E
F
G
H
I
J
K
L
M
WCS
O
P

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

SEAT BELT WARNING CHIME : Component Parts Location

INFOID:000000009945503



1. Parking brake switch
 2. ABS actuator and electric unit (control unit)
Refer to [BRC-12, "Component Parts Location"](#).
 3. Combination meter
 4. Refer to [BCS-10, "Component Parts Location"](#).
 5. Seat belt buckle switch (driver side)
- BCM

SEAT BELT WARNING CHIME : Component Description


INFOID:000000009945504

Unit	Description
Combination meter	<ul style="list-style-type: none"> Receives the seat belt buckle switch signal (driver side) from the seat belt buckle switch (driver side) and transmits it to BCM via CAN communication. Receives a buzzer output signal from the BCM and sounds the buzzer.
BCM	Judges the seat belt warning condition according to the seat belt buckle switch signal (driver side) received from the combination meter via CAN communication and transmits a buzzer output signal to the combination meter via CAN communication if necessary.
Seat belt buckle switch (driver side)	Transmits the seat belt buckle switch signal (driver side) to the combination meter.

PARKING BRAKE RELEASE WARNING CHIME

PARKING BRAKE RELEASE WARNING CHIME : System Diagram

INFOID:000000009945505



PARKING BRAKE RELEASE WARNING CHIME : System Description

INFOID:000000009945506

DESCRIPTION

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

Parking brake release warning chime judges the remaining parking brake according to the vehicle speed signal received from the ABS actuator and electric unit (control unit) via CAN communication and the parking brake switch signal from parking brake switch to sound the warning buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled.

Operation conditions		Signal name	Signal source
Ignition switch	ON	Ignition switch signal	—
Parking brake	During the operation (parking brake switch ON)	Parking brake switch signal	Parking brake switch
Vehicle speed	Approximately 7 km/h (4.3 MPH) or more	Vehicle speed signal (CAN communication)	ABS actuator and electric unit (control unit)


WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled.

Operation conditions		Signal name	Signal source
Ignition switch	OFF	Ignition switch signal	—
Parking brake	Release condition (parking brake switch OFF)	Parking brake switch signal	Parking brake switch
Vehicle speed	Approximately 3 km/h (1.9 MPH) or more	Vehicle speed signal (CAN communication)	ABS actuator and electric unit (control unit)

PARKING BRAKE RELEASE WARNING CHIME : Component Parts Location

INFOID:000000009945507



1. Parking brake switch
 2. BCM
 3. Combination meter
 4. Refer to [BCS-10, "Component Parts Location"](#).
 5. Seat belt buckle switch (driver side)
2. ABS actuator and electric unit (control unit)
Refer to [BRC-12, "Component Parts Location"](#).

WCS

WARNING CHIME SYSTEM


< SYSTEM DESCRIPTION >

PARKING BRAKE RELEASE WARNING CHIME : Component Description INFOID:000000009945508

Unit	Description
Combination meter	Judges the remaining parking brake according to the vehicle speed signal received from the ABS actuator and electric unit (control unit) via CAN communication and the parking brake switch signal from parking brake switch and sounds the warning buzzer.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.

KEY WARNING CHIME

KEY WARNING CHIME : System Diagram



KEY WARNING CHIME : System Description

INFOID:000000009945510

DESCRIPTION

With ignition switch in the OFF or ACC position, when the driver side door is open (driver side door switch ON) and the key inserted into the ignition key cylinder (key switch ON), the warning chime will sound.

WARNING OPERATION CONDITIONS

The BCM transmits the buzzer output signal to combination meter with CAN communication line when all of the following operation conditions are met. When combination meter receives buzzer output signal, it sounds the buzzer.

Operation conditions		Signal name	Signal source
Ignition switch	OFF or ACC position	Ignition switch signal	—
Key switch	ON (state that inserted key in key cylinder)	Key switch signal	Key switch
Driver side door	Open (driver side door switch ON)	Driver side door switch signal	Driver side door switch

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.


Operation conditions		Signal name	Signal source
Ignition switch	ON	Ignition switch signal	—
Key switch	OFF (state that removed key from key cylinder)	Key switch signal	Key switch
Driver side door	Close (driver side door switch OFF)	Driver side door switch signal	Driver side door switch

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

KEY WARNING CHIME : Component Parts Location

INFOID:000000009945511



1. Parking brake switch
2. Refer to [BCS-10, "Component Parts Location"](#).
BCM
3. Combination meter
4. Refer to [BRC-12, "Component Parts Location"](#).
ABS actuator and electric unit (control unit)
5. Seat belt buckle switch (driver side)

KEY WARNING CHIME : Component Description

INFOID:000000009945512

Unit	Description
Combination meter	Receives a buzzer output signal from the BCM and sounds the buzzer.
BCM	Judges the key warning conditions from the signals provided by various switches and transmits a buzzer output signal to the combination meter via CAN communication if necessary.
Key switch	Transmits the key switch signal to BCM.
Driver side door switch	Transmits the driver side door switch signal to BCM.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (METER)

CONSULT Function (METER/M&A)

INFOID:000000010244837

CONSULT APPLICATION ITEMS

CONSULT can perform the following diagnosis modes via CAN communication and the combination meter.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	The combination meter checks the conditions and displays memorized errors.
	Data Monitor	Displays the combination meter input/output data in real time.
	Warning History	Lighting history of the warning lamp and indicator lamp can be checked.

SELF DIAG RESULT

Refer to [MWI-62. "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h or mph]		Odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM via CAN communication. NOTE: 8191.875 is displayed when the malfunction signal is received.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°C]	X	Value of engine coolant temperature signal is received from ECM via CAN communication. NOTE: 215 is displayed when the malfunction signal is input.
FUEL CAP W/L [On/Off]		Status of fuel filler cap warning display detected from fuel filler cap warning display signal received from ECM via CAN communication.
ABS W/L [On/Off]		Status of ABS warning lamp detected from ABS warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.
VDC/TCS IND [On/Off]		Status of VDC OFF indicator lamp detected from VDC OFF indicator lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.
SLIP IND [On/Off]		Status of VDC warning lamp detected from VDC warning lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.
BRAKE W/L [On/Off]		Status of brake warning lamp detected from brake warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.
DOOR W/L [On/Off]		Status of door warning detected from door switch signal received from BCM via CAN communication.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description	A
HI-BEAM IND [On/Off]		Status of high beam indicator lamp detected from high beam request signal is received from BCM via CAN communication.	A
TURN IND [On/Off]		Status of turn indicator lamp detected from turn indicator signal is received from BCM via CAN communication.	B
LIGHT IND [On/Off]		Status of light indicator lamp detected from position light request signal is received from BCM via CAN communication.	C
OIL W/L [On/Off]		Status of oil pressure warning lamp detected from oil pressure switch signal is received from BCM via CAN communication.	D
MIL [On/Off]		Status of malfunction indicator lamp detected from malfunctioning indicator lamp signal is received from ECM via CAN communication.	D
CRUISE IND [On/Off]		Status of CRUISE indicator lamp detected from CRUISE indicator lamp signal is received from ECM via CAN communication.	E
SPORT IND [On/Off]		Status of OD OFF indicator lamp detected from OD OFF indicator signal is received from TCM via can communication.	E
FUEL W/L [On/Off]		Low-fuel warning lamp status detected by the identified fuel level.	F
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp detected from tire pressure signal is received from BCM via CAN communication.	G
KEY G/Y W/L [On/Off]		Status of KEY warning lamp (G/Y) detected from KEY warning lamp signal is received from BCM via CAN communication.	G
KEY KNOB W/L [On/Off]		Status of shift P warning lamp detected from shift P warning lamp signal is received from BCM via CAN communication.	H
EPS W/L [On/Off]		Status of EPS warning lamp detected from EPS warning lamp signal is received from EPS control unit via CAN communication.	I
e-4WD W/L [Off]		This item is displayed, but cannot be monitored.	I
LCD [NIGN B&P, IGN B&P, SFT P, NO KY]		Status of engine start operation indicator lamp, shift P warning lamp and KEY warning lamp, detected from engine start operation indicator lamp signal, shift P warning lamp signal and KEY warning lamp signal are received from BCM via CAN communication.	J
SHIFT IND [P, R, N, D, L]		Status of shift position, detected from shift position signal received from TCM via CAN communication.	K
O/D OFF SW [On/Off]		Status of overdrive control switch detected from CVT shift selector.	L
PKB SW [On/Off]		Status of parking brake switch.	L
BUCKLE SW [On/Off]		Status of seat belt buckle switch (driver side).	M
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.	WCS
A/C AMP CONN [On/Off]		Status of A/C auto amp. connection recognition signal.	WCS
DISTANCE [km]		Value of possible driving distance calculated by combination meter.	O
OUTSIDE TEMP [°C or °F]		Ambient air temperature value converted from ambient sensor signal received from ambient sensor. NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)	P
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit via CAN communication.	P

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.
TPMS PRESS L [On/Off]		Status of low tire pressure warning judged from low tire pressure warning lamp signal received from BCM with CAN communication line.

NOTE:

Some items are not available according to vehicle specification.

WARNING HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “Warning History” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “TIME” above is:
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO Warning History: Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- Warning History is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

Display Item

Display item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC/TCS IND	Lighting history of VDC OFF indicator lamp.
SLIP IND	Lighting history of VDC warning lamp.
BRAKE W/L	Lighting history of brake warning lamp.
DOOR W/L	Lighting history of door warning lamp.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp.
CRUISE IND	Lighting history of CRUISE indicator lamp.
SPORT IND	Lighting history of OD OFF indicator lamp.
FUEL W/L	Lighting history of low fuel level warning lamp.
AIR PRES W/L	Lighting history of low tire pressure warning lamp.
KEY G/Y W/L	Lighting history of KEY warning lamp (G/Y).
EPS W/L	Lighting history of EPS warning lamp.
CHAGE W/L	Lighting history of charge warning lamp.

NOTE:

In items displayed on the CONSULT screen, only those listed in the above table are used.

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000010244840

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Automatic air conditioner	AIR CONDITONER		×	
<ul style="list-style-type: none"> Intelligent Key system Engine start system 	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK"* to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*) to low power consumption mode
	LOCK		Power supply position is "LOCK"*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

NOTE:

*: Power position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (CVT models), and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000009945515

CONSULT APPLICATION ITEMS

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Test item	Diagnosis mode	Description
BUZZER	Data Monitor	Displays BCM input data in real time.
	Active Test	Operation of electrical loads can be checked by sending driving signal to them.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item [Unit]	Description
PUSH SW [On/Off]	Status of push-button ignition switch judged by BCM.
UNLK SEN-DR [On/Off]	Status of unlock sensor judged by BCM.
VEH SPEED 1 [km/h]	Value of vehicle speed signal received from combination meter with CAN communication line.
TAIL LAMP SW [On/Off]	Status of lighting switch judged by BCM using the combination switch readout function.
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM using the combination switch readout function.
DOOR SW-DR [On/Off]	Status of driver side door switch judged by BCM.
CDL LOCK SW [On/Off]	Status of door lock unlock switch judged by BCM.

ACTIVE TEST

Display item [Unit]	Description
SEAT BELT WARN TEST	The seat belt warning chime operation can be checked by operating the relevant function (On/Off).
ID REGIST WARNING	The ID regist warning chime operation can be checked by operating the relevant function (On/Off).
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010244841

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp control	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
Manual air conditioner	AIR CONDITONER		×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	×
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×
Panic alarm system	PANIC ALARM			×

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000009945517

CONSULT APPLICATION ITEMS

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Test item	Diagnosis mode	Description
BUZZER	Data Monitor	Displays BCM input data in real time.
	Active Test	Operation of electrical loads can be checked by sending driving signal to them.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item [Unit]	Description
IGN ON SW [On/Off]	Status of ignition switch judged by BCM.
KEY ON SW [On/Off]	Status of key switch judged by BCM.
DOOR SW-DR [km/h]	Status of driver side door switch judged by BCM.
REVERSE SW CAN [On/Off]	This item is displayed, but cannot be monitored.
TAIL LAMP SW [On/Off]	Status of lighting switch judged by BCM using the combination switch readout function.
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM using the combination switch readout function.
BUCKLE SW [On/Off]	Status of seatbelt buckle switch (driver side) received from combination meter with CAN communication line.
VEHICLE SPEED [km/h]	Value of vehicle speed signal received from combination meter with CAN communication line.

ACTIVE TEST

Display item [Unit]	Description
IGN KEY WARN ALM	The key warning chime operation can be checked by operating the relevant function (On/Off).
SEAT BELT WARN TEST	The seat belt warning chime operation can be checked by operating the relevant function (On/Off).
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000009945518

1. CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	10
Ignition switch ACC or ON	20
Ignition switch ON or START	3

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

Terminals		Ignition switch position	Voltage (Approx.)
(+)	(-)		
Combination meter		OFF ACC ON	Battery voltage
Connector	Terminal		
M34	27		
	15		
	28		
Ground			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M34	22		Existed
	23		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:0000000010244842

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Signal name	Fuse and fusible link No.
Battery power supply	G
	8

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground Battery voltage
Connector	Terminal	
M70	70	
	57	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Existed
M70	67		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)

BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000010244843

1.CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Signal name	Fuses and fusible link No.
Battery power supply	8
	G
ACC power supply	20
Ignition power supply	2

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

A
B
C
D
E
F
G
H
I
J
K
L
M
WCS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
BCM					
Connector	Terminal	Ground	OFF	ACC	ON
M67	70		Battery voltage	Battery voltage	Battery voltage
	57		Battery voltage	Battery voltage	Battery voltage
M65	11		Approx. 0 V	Battery voltage	Battery voltage
	38	Approx. 0 V	Approx. 0 V	Battery voltage	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Existed
M67	67		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

METER BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

METER BUZZER CIRCUIT

Description

INFOID:000000009945521

- The buzzer for warning chime system is installed in the combination meter.
- The combination meter sounds the alarm buzzer based on the signals transmitted from various units.

Component Function Check

INFOID:000000009945522

1. CHECK OPERATION OF METER BUZZER

1. Select "BUZZER" of "BCM" on CONSULT.
2. Perform "LIGHT WARN ALM" of "Active Test".

Does meter buzzer beep?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUZZER" monitor value.

"BUZZER"

Under the condition of buzzer input : On

Except above : Off

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace BCM. Refer to [BCS-88, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-155, "Removal and Installation"](#) (without Intelligent Key system).

Diagnosis Procedure

INFOID:000000009945523

1. CHECK POWER SUPPLY OF COMBINATION METER

Check power supply of combination meter. Refer to [WCS-22, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair power supply circuit of combination meter.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

Description

INFOID:000000009945524

Transmits a seat belt buckle switch signal (driver side) to the combination meter.

Component Function Check

INFOID:000000009945525

1. CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUCKLE SW" monitor value.

"BUCKLE SW"

When seat belt is fastened : Off

When seat belt is unfastened : On

>> INSPECTION END

Diagnosis Procedure

INFOID:000000009945526

1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector terminal and ground.

Terminals		Condition	Voltage (Pyrex.)	
(+)	(-)			
Combination meter				
Connector	Terminal	Ground	When seat belt is fastened	12 V
M34	9		When seat belt is unfastened	0 V

Is the inspection result normal?

YES >> Replace combination meter

NO >> GO TO 2.

2. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and seat belt buckle switch (driver side) connector.
3. Check continuity between combination meter harness connector and seat belt buckle switch (driver side) harness connector.

Terminals				Continuity
Combination meter		Seat belt buckle switch (driver side)		
Connector	Terminal	Connector	Terminal	
M34	9	B22	1	Exist

4. Check harness continuity between combination meter harness connector and ground.

Terminals		Ground	Continuity
Combination meter			
Connector	Terminal		
M34	9		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (driver side) harness connector and ground.

Terminals		Ground	Continuity
Seat belt buckle switch (driver side)			
Connector	Terminal		
B22	2		Exist

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009945527

1. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch (driver side) connector.
3. Check continuity between terminals.

Terminals		Condition	Continuity
Seat belt buckle switch (driver side)			
1	2	When seat belt is fastened	Not existed
		When seat belt is unfastened	Exist

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (driver side). Refer to [SB-8. "SEAT BELT BUCKLE : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS


WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME SYSTEM

Wiring Diagram - WARNING CHIME -

INFOID:000000009945528



2012/07/30


JRNWC2705GB

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

Connector No.	B5
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	GR	-
3	V	-
4	W	-
5	LG	-
6	R	-
7	O	-
8	GR	-
9	P	-
10	P	-
11	P	-
12	W	-

Connector No.	B22
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	O	-
2	B	-

Connector No.	B34
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH04FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-


Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	B0A22FB-AH24-RH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND (MTR)
2	Y	BAT (MTR)
3	L	BAT (SOL)
4	B	GND (SOL)
5	Y	DS FL
6	W	DP RL
7	O	DP RR
8	L	DP FR
9	R	DS FR
10	R	DS RL
11	LG	K LINE
12	GR	CANL
13	P	CANH
14	BR	DP FL
15	G	DS RL
16	V	IGN
17	SB	DS RR
18	W	STOP LAMP SW
19	W	VDC OFF SW
20	W	VDC OFF SW
21	P	-

25	R	CAN-H
26	L	CAN-H


Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	W	-
3	SB	-
4	G	-
5	P	-
6	L	- [With NAVI]
7	Y	- [Without NAVI]
8	O	-
9	W	-
10	SB	-
11	V	-
12	R	-
13	GR	-
14	P	-
15	Y	-
16	BR	-
17	SB	-
18	R	-
19	V	-
20	P	-
21	L	- [With M/T]
22	O	- [With M/T]
23	W	- [With CVT]
24	LG	- [With CVT]
25	L	-
26	O	-
27	G	-
28	P	-
29	L	-
30	L	-
31	W	-
32	R	-
33	GR	-
34	P	-
35	Y	-
36	BR	-
37	SB	-
38	R	-
39	V	-
40	P	-
41	L	- [With M/T]
42	O	- [With M/T]
43	W	- [With CVT]
44	LG	- [With CVT]
45	L	-
46	O	-
47	G	-
48	P	-
49	L	-
50	B	-
51	BR	- [With M/T]
52	SB	- [With CVT]
53	SB	-
54	O	- [With M/T]
55	W	- [With CVT]
56	LG	-
57	L	-
58	O	-
59	O	-
60	O	-
61	G	-

62	W	-
63	L	-
64	GR	- [With CVT]
65	V	- [With M/T]
66	P	-
67	SHIELD	-
68	GR	-
69	LG	-
70	P	-
71	V	-
72	Y	-
73	LG	-
74	O	-
75	G	-
76	P	-
77	L	-
78	L	-
79	L	-
80	L	-
81	L	-
82	W	-
83	RR	-
84	B	-
85	W	-
86	Y	-
87	V	-
88	R	-
89	Y	-
90	V	-
91	LG	-
92	R	-
93	SB	-
94	SB	-
95	SB	-
96	LG	-
97	R	-
98	SB	-
99	G	-
100	P	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color Of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	GRR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

8	O	-
14	P	-
16	LG/R	-

Connector No.	M11
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A




Terminal No.	1	SB	Signal Name [Specification]	-
--------------	---	----	-----------------------------	---

Connector No.	M24
Connector Name	KEY SWITCH
Connector Type	TR06MGY



Terminal No.	1	R/W	Signal Name [Specification]	-
2	LG/R	-	-	-

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TH0FTV-NH



Terminal No.	1	O/B	Signal Name [Specification]	WASHER (RR) OUTPUT 4
2	GR	-	-	WASHER (FR) OUTPUT 3
3	RG	-	-	IGN (GN) GROUND
4	W	-	-	INPUT 3
5	L/Y	-	-	OUTPUT 5
6	B	-	-	INPUT 4
7	W	-	-	INPUT 1
8	BR/W	-	-	INPUT 2
9	R/L	-	-	OUTPUT 1
10	Y/L	-	-	OUTPUT 2
11	L/O	-	-	-
12	L/R	-	-	-
13	LG	-	-	-
14	G	-	-	-


Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH0FTV-NH



Terminal No.	1	L	Signal Name [Specification]	CANH
2	P	-	-	CANH
3	V	-	-	VEHICLE SPEED SIGNAL (2-PULSE)
4	V	-	-	VEHICLE SPEED SIGNAL (8-PULSE) (from NAVI)
6	BR/Y	-	-	FUEL LEVEL SENSOR SIGNAL

7	R/G	AIR BAG SIGNAL
8	P	OVERDRIVE CONTROL SWITCH SIGNAL
9	O	SEAT BELT BRAKE SWITCH SIGNAL (DRIVER SIDE)
10	SB	PARKING BRAKE SWITCH SIGNAL
11	GR	BRAKE FLUID LEVEL SWITCH SIGNAL
13	BR	ILLUMINATION CONTROL SIGNAL
15	L/Y	ACC POWER SUPPLY
18	R/Y	SECURITY SIGNAL
19	PU/W	AMBIENT SENSOR SIGNAL
20	R/W	AMBIENT SENSOR GROUND
21	B	GROUND
22	B	GROUND
23	B	GROUND
24	PU	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
27	LG/R	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	BR	PASSENGER SEAT BELT WARNING SIGNAL
31	R	ACCUMULATOR CHARGE RECOGNITION SIGNAL
35	BR	ENGINE COOLANT TEMPERATURE SIGNAL
38	GR	ALTERNATOR SIGNAL

Connector No.	M59
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	IN029V-EX



Terminal No.	1	R/L	Signal Name [Specification]	IGN
2	B	-	-	GROUND
3	Y	-	-	DR 1 (+)
4	Y/R	-	-	DR 1 (-) DR 2 (-)
5	L/Y	-	-	DR 2 (+)
6	Y/G	-	-	AS 1 (+)
7	Y/B	-	-	AS 1 (-)
8	Y/L	-	-	AS 2 (+)
9	G/Y	-	-	AS 2 (-)
18	LG	-	-	EC2S (+)
19	V	-	-	EC2S (-)
22	SHIELD	-	-	SHIELD
23	R/G	-	-	AIR BAG W/L

24	BR	SEAT BELT W/L
25	R/B	CUTOFF TELLTALE
59	L	CANH
60	P	CANH

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH0FTV-NH



Terminal No.	2	BR/W	Signal Name [Specification]	COMBI SW INPUT 5
3	GR	-	-	COMBI SW INPUT 4
4	L/Y	-	-	COMBI SW INPUT 3
5	G	-	-	COMBI SW INPUT 2
6	L/R	-	-	COMBI SW INPUT 1
7	W/R	-	-	KEY CYL UNLOCK SW
8	W/B	-	-	KEY CYL LOCK SW
9	R	-	-	STOP LAMP SW
10	W/L	-	-	REAR WINDOW DEFROGGER SW
11	L/Y	-	-	ACC POWER SUPPLY
12	SB	-	-	PASSENGER DOOR SW
13	GR/L	-	-	REAR RH DOOR SW
18	V	-	-	RECEIVER / SENSOR GND
19	BR	-	-	KEYLESS ENTRY RECEIVER POWER SUPPLY
20	G/Y	-	-	KEYLESS ENTRY RECEIVER COMM
21	P/L	-	-	NAVS ANTENNA AMP.
23	R/Y	-	-	SECURITY INDICATOR LAMP
25	LG	-	-	NAVS ANTENNA AMP.
26	GR	-	-	THERMO CONTROL AMP.
27	Y/G	-	-	A/C SW
28	GW	-	-	BLOWER FAN SW
29	L/W	-	-	HAZARD SW
31	G/Y	-	-	FR DEFROSTER SW
32	LG	-	-	COMBI SW OUTPUT 5
33	Y/L	-	-	COMBI SW OUTPUT 4
34	W	-	-	COMBI SW OUTPUT 3
35	R/L	-	-	COMBI SW OUTPUT 2
36	L/O	-	-	COMBI SW OUTPUT 1
37	R/W	-	-	KEY SWITCH
38	O	-	-	IGNITION POWER SUPPLY

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

39	L	CANH
40	P	CANL

Connector No. M66
 Connector Name BCM (BODY CONTROL MODULE)
 Connector Type FEAO9FB-FHAG-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
43	W	BACK DOOR SW
44	LG	REAR WIPER STOP POSITION
45	GR	CENTRAL DOOR LOCK SW
46	BR	CENTRAL DOOR UNLOCK SW
47	BR/Y	DRIVER DOOR SW
48	W/G	REAR LH DOOR SW
50	SB	A/C INDICATOR OUTPUT
54	LG	REAR WIPER OUTPUT

Connector No. M67
 Connector Name BCM (BODY CONTROL MODULE)
 Connector Type FEAO9FB-FHAG-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	L/B	DRIVER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/L	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	G	PASSENGER DOOR, REAR DOOR UNLOCK OUTPUT


67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (FL)

Connector No. M68
 Connector Name BCM (BODY CONTROL MODULE)
 Connector Type TH40FB-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1
7	W/R	KEY CYL UNLOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW 1
12	GR	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
14	L/G	OPTICAL SENSOR
15	W/L	REAR WINDOW DEFOGGER SW
17	R/G	OPTICAL SENSOR POWER SUPPLY
18	V	SENSOR GND
21	P/L	NAVS ANTENNA AMP.
23	R/Y	SECURITY INDICATOR LAMP
25	LG	NAVS ANTENNA AMP.
27	O	A/C SW
28	GW	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/B	DR DOOR UNLOCK SENSOR
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	G/O	SHIFT P
38	G/Y	RECEIVER COMM
39	L	CANH
40	P	CANL

Connector No. M69
 Connector Name BCM (BODY CONTROL MODULE)
 Connector Type FEAO9FB-FHAG-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
43	W	BACK DOOR SW
44	LG	REAR WIPER STOP POSITION
45	SB	PASSENGER DOOR SW
46	GR/L	REAR RH DOOR SW
47	BR/Y	DRIVER DOOR SW
48	W/G	REAR LH DOOR SW
50	R/W	BK DR LOCK ACT RELAY CONT
51	W	BACK DOOR REQUEST SW
54	LG	REAR WIPER OUTPUT
55	G	REAR DOOR UNLOCK OUTPUT


Connector No. M70
 Connector Name BCM (BODY CONTROL MODULE)
 Connector Type FEAO9FB-FHAG-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	G	PASSENGER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/L	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	L/B	DRIVER DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)

69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (FL)

Connector No. M77
 Connector Name WIRE TO WIRE
 Connector Type TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BO	-
2	R	-
3	GR	-
4	G/B	-
5	L	-
6	L	-
7	W/R	-
8	GW	-
9	Y/L	-
10	W	-
31	GR/L	-
32	L/B	-
33	R/Y	-
34	SB	-
35	BR	-
36	G	-
39	L/R	-
44	G/O	-
45	LG/R	-
46	GR/W	-
48	L/O	-
51	B/W	-
53	R/L	-
54	O	-
57	GR	-
59	V	-
60	R/W	-
61	P/W	-
62	W/L	-
63	W/B	-
67	Y/R	-
69	LG	-

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P




JRNWD0656GB

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME	
70	SHIELD
71	P/B
72	R/G
73	R
74	L/Y
76	W/G
77	GR/R
78	O
79	LG
80	P
81	L
82	GR
83	G/R
84	B
91	R
92	O
93	Y
94	R/B
95	L/W
96	Y
97	I
98	BR/W
99	W
100	G/R

Connector No.	M80
Connector Name	WIRE TO WIRE
Connector Type	THRETERMINAL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/B	-
2	GR/L	-
5	W	-
6	W/L	-
8	BR/Y	-
9	R/Y	-
11	O	-
13	BR/W	-
14	W/B	-
16	W/G	-

JRNWD0657GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

COMBINATION METER

Reference Value

INFOID:0000000010244838

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h or mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	Engine running	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
FUEL CAP W/L	Ignition switch ON	Fuel filler cap warning display ON	On
		Fuel filler cap warning display OFF	Off
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	VDC warning lamp ON	On
		VDC warning lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning lamp ON	On
		Door warning lamp OFF	Off
HI-BEAM IND	Ignition switch ON	High-beam indicator lamp ON	On
		High-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn signal indicator lamp ON	On
		Turn signal indicator lamp OFF	Off
LIGHT IND	Ignition switch ON	Tail lamp indicator lamp ON	On
		Tail lamp indicator lamp OFF	Off
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
MIL	Ignition switch ON	Malfunction indicator lamp ON	On
		Malfunction indicator lamp OFF	Off
CRUISE IND	Ignition switch ON	CRUISE indicator lamp ON	On
		CRUISE indicator lamp OFF	Off
SPORT IND	Ignition switch ON	OD OFF indicator lamp ON	On
		OD OFF indicator lamp OFF	Off
FUEL W/L	Ignition switch ON	Low-fuel warning displayed	On
		Low-fuel warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On
		Low tire pressure lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	KEY warning lamp (G/Y) ON	On
		KEY warning lamp (G/Y) OFF	Off
KEY KNOB W/L	Ignition switch ON	Shift P warning lamp ON	On
		Shift P warning lamp OFF	Off
EPS W/L	Ignition switch ON	EPS warning lamp ON	On
		EPS warning lamp OFF	Off
e-4WD W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
LCD	Ignition switch LOCK or ACC	Engine start operation indicator lamp ON	NIGN B&P
	Ignition switch ON	Engine start operation indicator lamp ON	IGN B&P
	Ignition switch LOCK	Shift P warning lamp ON	SFT P
	Ignition switch ON	KEY warning lamp blinking	NO KY
SHIFT IND	Ignition switch ON	Shift position indicator P display	P
		Shift position indicator R display	R
		Shift position indicator N display	N
		Shift position indicator D display	D
		Shift position indicator L display	L
O/D OFF SW	Ignition switch ON	Overdrive control switch ON	On
		Overdrive control switch OFF	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt (driver side) not fastened	On
		Seat belt (driver side) fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
A/C AMP CONN	Ignition switch ON	Other than the following	On
		Receives A/C auto amp. connection recognition signal	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by combination meter

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
OUTSIDE TEMP [°C or °F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low fuel warning displayed	On
		Low fuel warning not displayed	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off
TPMS PRESS L	Ignition switch ON	Low tire pressure warning display ON	On
		Low tire pressure warning display OFF	Off

NOTE:

Some items are not available according to vehicle specification.

TERMINAL LAYOUT



PHYSICAL VALUES




Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (L)	—	CAN-H	—	—	—	—
2 (P)	—	CAN-L	—	—	—	—
3 (V)	Ground	Vehicle speed signal (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p> <p style="text-align: right;">JSNIA0015GB</p>
4 (V/R) ^{*1} (L) ^{*2}	Ground	Vehicle speed signal (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p> <p style="text-align: right;">JSNIA0012GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
6 (BR/Y)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—  JPNIA1546ZZ
7 (R/G)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON 5 V
				Ignition switch OFF	Air bag warning lamp OFF 0 V
8 (P)	Ground	Overdrive control switch signal	Input	Ignition switch ON	Overdrive control switch ON 4 V
				Ignition switch OFF	Overdrive control switch OFF 0 V
9 (O)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened. 12 V
				Ignition switch OFF	When driver seat belt is unfastened. 0 V
10 (SB)	Ground	Parking brake switch signal	Input	Engine idling	Parking brake applied. 0 V
				Engine idling	Parking brake released. 5 V
11 (G/R)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal 12 V
				Ignition switch ON	Brake fluid level is less than LOW level 0 V
13 (B/R)	Ground	Illumination control signal	Output	Ignition switch ON	<ul style="list-style-type: none"> Lighting switch 1ST When meter illumination is maximum  JPNIA1687GB
				Ignition switch ON	<ul style="list-style-type: none"> Lighting switch 1ST When meter illumination is step 11  JPNIA1686GB
				Ignition switch ON	<ul style="list-style-type: none"> Lighting switch 1ST When meter illumination is minimum 12 V
15 (L/Y)	Ground	ACC power supply	Input	Ignition switch ACC	— Battery voltage
18 (R/Y)	Ground	Security signal	Input	Ignition switch ON	Security warning lamp ON 0 V
				Ignition switch OFF	Security warning lamp OFF 12 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
19 (PU/W)	Ground	Ambient sensor signal	Input	Ignition switch ON Changes depending to ambient temperature.	<p style="text-align: center;">JSNIA0014GB</p>	
20 (R/W)	Ground	Ambient sensor ground	—	Ignition switch ON —	0 V	
21 (B)	Ground	Ground	—	Ignition switch ON —	0 V	
22 (B)	Ground	Ground	—	Ignition switch ON —	0 V	
23 (B)	Ground	Ground	—	Ignition switch ON —	0 V	
24 (PU)	Ground	Fuel level sensor signal ground	—	Ignition switch ON —	0 V	
25 (B)	Ground	VDC ground	—	Ignition switch ON —	0 V	
27 (LG/R)	Ground	Battery power supply	Input	Ignition switch OFF —	Battery voltage	
28 (GR)	Ground	Ignition signal	Input	Ignition switch ON —	Battery voltage	
29 (BR)	Ground	Passenger seat belt warning signal	Input	Ignition switch ON	<ul style="list-style-type: none"> When getting in the passenger seat. When passenger seat belt is fastened. 	12 V
					<ul style="list-style-type: none"> When getting in the passenger seat. When passenger seat belt is unfastened. 	0 V
31 (R)	Ground	A/C auto amp. connection recognition signal	Input	Ignition switch ON —	5 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Input/ Output	Condition	Value (Approx.)
+	-	Signal name				
35 (BR)	Ground	Engine coolant temperature signal	Output	Ignition switch ON	Engine idling [Approximately 20°C (68°F)]	
					Engine idling [Approximately 80°C (176°F)]	<div style="text-align: center;">0 V</div> 
38 (GR)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	12 V


- *1: With NAVI
- *2: Without NAVI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:000000010244839



2013/09/19

JRNWD0572GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

- : With CVT
- : With Intelligent Key
- : Without Intelligent Key




JRNWD0573GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	TH24MV-AH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	O	-
4	D	-
5	W	-
6	SB	-
7	GR	-
8	SB	-
9	GR	-
10	SB	-
11	G	-
12	SB	-
13	L	-
14	R	-
15	GR	-
16	BR	-
17	L	-
18	L	-
19	LG	-
20	Y	-
21	Y	-
22	BR	-
23	O	-
24	O	-

Connector No.	B5
Connector Name	WIRE TO WIRE
Connector Type	TH16MV-AH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	GR	-
3	V	-
4	W	-
5	W	-
6	LG	-
7	R	-
8	O	-
9	GR	-
10	P	-
11	P	-
12	W	-
13	W	-
14	W	-
15	W	-
16	W	-

Connector No.	B13
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	HE22FY-1V-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
10	Y	PRH (+)
11	Y	PRH (-)
26	V	ODS INPUT
29	LG	RH BUCKLE SW INPUT
31	Y	SRH (+)
32	Y	SRH (-)
35	P	GRN (+)
36	L	GRN (-)
47	G	SATELLITE RH (+)

48	R	SATELLITE RH (-)
----	---	------------------



Connector No.	B22
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW

Connector No.	B23
Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	B40
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP
Connector Type	ED5FCY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BR	-
3	B	-
4	P	-
5	L	-

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Type	SAAG36MB-RS10-S1Z2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	LG	-
3	Y	-
4	W	-
7	Y	-
8	SB	-
9	L	-
10	V	-
11	P	-
12	BR	-
13	LG	-
14	Y	-
15	SB	-
16	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



JRNWD0648GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

17	W	-	-
18	O	-	-
21	G	-	-
22	Y	-	-
23	SB	-	-
24	W	-	-
25	BR	-	-
26	BY	-	-
27	GR	-	-
28	P	-	-
29	V	-	-
30	G	-	-
31	G	-	-
32	O	-	-
33	W	-	-
34	Y	-	-
35	V	-	-
36	P	-	-
37	LG	-	-
39	SB	-	-
40	GR	-	-
41	O	-	-
42	V	-	-
43	LG	-	-
44	R	-	-
46	W	-	-
47	G	-	-
48	BR	-	-


Connector No.	E13
Connector Name	IPD/ER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	IHT2FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
24	G	-
25	Y	-
26	P	-
27	L	-
28	P	-


30	SB	-	-
31	W	-	-
33	O	-	-
34	R	-	-

Connector No.	E16
Connector Name	ECM
Connector Type	RH24FB-R28-LRH



Terminal No.	Color Of Wire	Signal Name [Specification]
83	P	CAN COMMUNICATION LINE
84	L	CAN COMMUNICATION LINE
88	LG	DATA LINK CONNECTOR
93	L	IGNITION SWITCH
94	SB	ASC/D STEERING SWITCH
95	BR	SENSOR GROUND
99	W	STOP LAMP SWITCH
100	SB	ASC/D BRAKE SWITCH
102	O	SENSOR POWER SUPPLY
103	G	ACCELERATOR PEDAL POSITION SENSOR 2
104	R	SENSOR GROUND
105	G	POWER SUPPLY FOR ECM
106	V	SENSOR POWER SUPPLY
107	B	ECM GROUND
108	B	ECM GROUND
109	B	ECM GROUND
110	BR	ACCELERATOR PEDAL POSITION SENSOR 1
111	Y	SENSOR GROUND
112	B	ECM GROUND

Connector No.	E18
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	TR24FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	LINE PRESSURE SOLENOID VALVE
2	LG	SECONDARY PRESSURE SOLENOID VALVE
3	BR	TRIPLE-COMBIERATURE SOLENOID VALVE
4	O	LOCK-UP SELECT SOLENOID VALVE
5	L	CANH
6	P	CANH
10	R	IGNITION POWER SUPPLY
11	W	STEP MOTOR A
12	L	STEP MOTOR B
13	SB	ROM ASSY (SEL 2)
14	P	ROM ASSY (SEL 1)
15	V	ROM ASSY (SEL 3)
16	BR	P RANGE SW
18	BR	IGNITION POWER SUPPLY
19	R	STEP MOTOR C
20	SB	STEP MOTOR C
21	Y	STEP MOTOR D
22	GR	R RANGE SW

Connector No.	E36
Connector Name	MSI ACTUATOR AND ELECTRIC JANT (CONTROL JANT)
Connector Type	BAAZ2FB-AH24-RH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND (MTR)
2	Y	BAT (MTR)
3	L	BAT (SOL)

4	B	GND (SOL)
5	Y	DIS FL
6	W	DP RL
8	O	DP RR
9	L	DP FR
10	R	DS FR
11	LG	K LINE
14	GR	CANH
15	P	CANH
16	BR	DP FL
17	G	DS RL
18	V	IGN
19	SB	DS RR
20	W	STOP LAMP SW
21	P	VOC OFF SW
25	R	CANH
26	L	CANH

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	BY	-

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER

Connector No.	E53
Connector Name	AMBIENT SENSOR
Connector Type	RS02FB



Terminal No.	Wire	Signal Name [Specification]
1	G	AMBIENT SENSOR SIGNAL
2	O	SENSOR GROUND


Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Wire	Signal Name [Specification]
1	V	-
2	W	-
3	SB	-
4	G	-
5	P	-
6	L	- [With NAVI]
7	Y	- [Without NAVI]
8	O	-
9	W	-
10	SB	-
31	V	-
32	R	-
33	GR	-
34	P	-
35	Y	-
36	BR	-
39	SB	-

44	R	-
45	V	-
46	P	-
48	L	- [With M/T]
51	B	- [With M/T]
51	BR	- [With CVT]
53	SB	-
54	O	- [With M/T]
54	W	- [With CVT]
57	LG	-
59	L	-
60	O	-
61	G	-
62	W	-
63	L	-
67	GR	- [With CVT]
67	V	- [With M/T]
69	P	-
70	SHIELD	-
71	GR	-
72	LG	-
73	P	-
74	V	-
76	Y	-
77	LG	-
78	O	-
79	G	-
80	P	-
81	L	-
82	W	-
83	BR	-
84	B	-
91	W	-
92	Y	-
93	Y	-
94	R	-
95	V	-
96	LG	-
97	R	-
98	SB	-
99	G	-
100	P	-

Connector No.	F1
Connector Name	WIRE TO WIRE
Connector Type	SAA3RFB-RS10-SJZZ



Terminal No.	Wire	Signal Name [Specification]
1	SB	-
2	LG	-
3	R	-
4	V	-
7	V	-
8	G	-
9	SB	-
10	L	-
11	Y	-
12	GR	-
13	BR	-
14	G	-
15	W	-
16	Y	-
17	P	-
18	BR	-
21	G	-
22	L	-
23	W	-
24	R	-
25	R	-
26	B	-
27	SB	-
28	V	-
29	V	-
30	BR	-
31	GR	-
32	BR	-
33	W	-
34	LG	-
35	V	-
36	Y	-
37	W	-
39	G	-
40	P	-
41	O	-

42	G	-
43	R	-
44	P	-
46	GR	-
47	Y	-
48	BR	-

Connector No.	F15
Connector Name	ALTERNATOR
Connector Type	HS03FB



Terminal No.	Wire	Signal Name [Specification]
3	LG	-
4	G	-
5	O	-

Connector No.	F42
Connector Name	ALTERNATOR
Connector Type	24340_79906



Terminal No.	Wire	Signal Name [Specification]
2	BY	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

JRNWD0650GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER

Connector No.	F63
Connector Name	OIL PRESSURE SWITCH
Connector Type	E0TFCY-RS-AR



Terminal No.	1	BR	Signal Name [Specification]	-
--------------	---	----	-----------------------------	---

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BDT6FY



Connector No.	M11
Connector Name	PARKING BRAKE SWITCH
Connector Type	P0TBEA



Terminal No.	1	SB	Signal Name [Specification]	-
--------------	---	----	-----------------------------	---

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH0FV-MH



Terminal No.	Color Of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	GR/R	-
8	O	-
14	P	-
16	LG/R	-


24	PU	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
27	LG/R	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	BR	PASSENGER SEAT BELT WARNING SIGNAL
31	R	AC AUTO AMP CONNECTION RECOGNITION SIGNAL
35	BR	ENGINE COOLANT TEMPERATURE SIGNAL
38	GR	ALTERNATOR SIGNAL

Connector No.	M37
Connector Name	EPS CONTROL UNIT
Connector Type	TH08FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	CAN-L
2	L	CAN-H
4	O	IGN


Connector No.	M50
Connector Name	AC AUTO AMP
Connector Type	TK20FY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	ILLUMINATION POWER SUPPLY
2	R	AC AUTO AMP CONNECTION RECOGNITION SIGNAL
3	R	INTAKE DOOR MOTOR PBR POWER SUPPLY
4	LG/R	BATTERY POWER SUPPLY
5	O	IGNITION POWER SUPPLY
6	R/W	SENSOR GROUND
9	Y	IGNITION POWER SUPPLY

11	BR	ILLUMINATION GROUND
12	L	FRE DRIVE SIGNAL
13	G	REC DRIVE SIGNAL
16	B	GROUND
17	BR	AMIX DRIVE SIGNAL 4
18	SB	AMIX DRIVE SIGNAL 3
19	GR	AMIX DRIVE SIGNAL 2
20	P	AMIX DRIVE SIGNAL 1

Connector No.	M51
Connector Name	AC AUTO AMP
Connector Type	TK18FY



Terminal No.	Color Of Wire	Signal Name [Specification]
21	BR	WATER TEMPERATURE SIGNAL
22	P/W	AMBIENT SENSOR SIGNAL
23	O	INTAKE SENSOR SIGNAL
24	G	IN-VEHICLE SENSOR SIGNAL
25	P	SINLOAD SENSOR SIGNAL
26	SB	INTAKE DOOR MOTOR PBR F/B SIGNAL
27	R	REAR WINDOW DEFOGGER F/B SIGNAL
29	GR	MODE DRIVE SIGNAL 4
30	W	MODE DRIVE SIGNAL 3
31	Y	MODE DRIVE SIGNAL 2
32	V	MODE DRIVE SIGNAL 1
33	W/L	REAR WINDOW DEFOGGER ON SIGNAL
34	Y/G	A/C ON SIGNAL
35	GW	BLOWER FAN ON SIGNAL
36	GR/R	POWER TRANSISTOR CONTROL SIGNAL

JRNWD0651GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

Connector No.	M57
Connector Name	CVT SHIFT SELECTOR
Connector Type	TH08FW-NH




Terminal No.	Wire	Signal Name [Specification]
1	P	-
2	B	-
3	W	-
4	B/R	-
5	LG	-
6	B	-

Connector No.	M58
Connector Name	CVT SHIFT SELECTOR
Connector Type	TH08FW-NH




Terminal No.	Wire	Signal Name [Specification]
1	P	-
2	B	-
3	W	-
4	B/R	-
5	LG	-
6	B	-
7	Y/R	-
8	GY	-

Connector No.	M59
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NI28FY-EX



Terminal No.	Wire	Signal Name [Specification]
1	R/L	IGN
2	B	GROUND
3	Y	DR 1 (+)
4	Y/R	DR 1 (R2 (-))
5	L/Y	DR 2 (+)
6	Y/G	AS 1 (+)
7	Y/B	AS 1 (-)
8	Y/L	AS 2 (+)
9	GY	AS 2 (-)
18	LG	ECZS (+)
19	V	ECZS (-)
22	SHIELD	SHIELD
23	R/G	AIR BAG W/L
24	BR	SEAT BELT W/L
25	R/B	CUTOFF TELLTALE
59	L	CANH
60	P	CANH


Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



Terminal No.	Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1

5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1
7	W/R	KEY CYL UNLOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW
10	L/Y	REAR WINDOW DEFROGGER SW
11	L/Y	ACC POWER SUPPLY
12	SB	PASSENGER DOOR SW
13	GR/L	REAR RH DOOR SW
18	V	RECEIVER / SENSOR GND
19	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
20	GY	KEYLESS ENTRY RECEIVER COMM
21	P/L	NATS ANTENNA AMP
25	LG	NATS ANTENNA AMP
26	GR	THEIRMO CONTROL AMP
27	Y/G	A/C SW
28	GW	BLOWER FAN SW
29	UW	HAZARD SW
31	GY	FR DEFROSTER SW
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	R/W	KEY SWITCH
38	O	IGNITION POWER SUPPLY
39	L	CANH
40	P	CANH

Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1

7	W/R	KEY CYL UNLOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW 1
12	GR	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
14	L/G	OPTICAL SENSOR
15	W/L	REAR WINDOW DEFROGGER SW
17	R/G	OPTICAL SENSOR POWER SUPPLY
18	V	SENSOR GND
21	P/L	NATS ANTENNA AMP
23	R/Y	SECURITY INDICATOR LAMP
25	LG	NATS ANTENNA AMP
27	O	A/C SW
28	GW	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/B	DR DOOR UNLOCK SENSOR
32	LG	COMBI SW OUTPUT 2
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 1
36	L/O	COMBI SW OUTPUT 2
37	G/O	SHIFT P
38	GY	RECEIVER COMM
39	L	CANH
40	P	CANH

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH89FW-GS16-TM4



Terminal No.	Wire	Signal Name [Specification]
1	B/O	-
2	R	-
3	G/R	-
4	G/B	-
5	L	-
6	L	-
7	W/R	-
8	GW	-
9	Y/L	-

JRNWD0652GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS


COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER	10	W	-	11	W	-	12	W	-	13	W	-	14	W	-	15	W	-	16	W	-	17	W	-	18	W	-	19	W	-	20	W	-	21	W	-	22	W	-	23	W	-	24	W	-																																																																																																																																										
31	GR/L	-	-	32	L/B	-	-	33	R/Y	-	-	34	S/B	-	-	35	B/R	-	-	36	G	-	-	39	L/R	-	-	44	G/O	-	-	45	LG/R	-	-	46	GR/W	-	-	48	L/O	-	-	51	B/W	-	-	53	R/L	-	-	54	O	-	-	57	GR	-	-	59	V	-	-	60	R/W	-	-	61	PU/W	-	-	62	W/L	-	-	63	W/B	-	-	67	Y/R	-	-	69	LG	-	-	70	SHIELD	-	-	71	P/B	-	-	72	R/G	-	-	73	R	-	-	74	LY	-	-	76	W/G	-	-	77	GR/R	-	-	78	O	-	-	79	LG	-	-	80	P	-	-	81	L	-	-	82	GR	-	-	83	G/R	-	-	84	B	-	-	91	R	-	-	92	O	-	-	93	Y	-	-	94	R/B	-	-	95	L/W	-	-	96	Y	-	-	97	L	-	-	98	BR/W	-	-	99	W	-	-	100	G/R	-	-


Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/B	-
2	GR/L	-
5	W	-
6	W/L	-
8	BR/Y	-
9	R/Y	-
11	O	-
13	BR/W	-
14	W/B	-
16	W/G	-

Connector No.	M79	WIRE TO WIRE
Connector Name	TH24FW-NH	
Connector Type	TH24FW-NH	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W/G	-
2	LY	-
3	R	-
4	P/B	-
6	W	-
8	S/B	-
9	LG	-
10	GR/B	-
11	G/B	-
12	G/R	-
13	R/G	-
15	R/L	-
16	GR/R	-
17	BR/Y	-
18	PU	-
20	GR/L	-
22	L	-
23	Y/L	-
24	GW	-

Connector No.	M80	WIRE TO WIRE
Connector Name	TH16FW-NH	
Connector Type	TH16FW-NH	



Fail-Safe

FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

JRNWD0653GB

INFOID:000000010282693

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Function		Specifications	
Speedometer		Reset to zero by suspending communication.	A
Tachometer			B
Engine coolant temperature gauge			C
Illumination control		When suspending communication, changes to nighttime mode.	
Shift position indicator		The indicator turns OFF by suspending communication.	
Information display	Instantaneous fuel warning	<ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated. 	D
	Average fuel consumption		E
	Possible driving distance	The display turns OFF by suspending communication.	
	Average vehicle speed		
	Low tire pressure warning		
Buzzer		The buzzer turns off by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON by suspending communication.	F
	VDC warning lamp		G
	EPS warning lamp		H
	Brake warning lamp		I
	Malfunction indicator lamp		J
	Low tire pressure warning lamp	The lamp turns OFF by suspending communication.	K
	VDC OFF indicator lamp		L
	High beam indicator lamp		
	Turn signal indicator lamp		
	Door warning lamp		
	Light indicator lamp		
	Engine start operation indicator lamp		
	Shift P warning lamp		
	Oil pressure warning lamp		
	CRUISE indicator lamp		
O/D OFF indicator lamp			
Key warning lamp			

DTC Index

INFOID:000000009945532

Display contents of CONSULT	Diagnostic item is detected when ...	Refer to	
CAN COMM CIRCUIT [U1000]	When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-34. "Diagnosis Procedure"	WCS
CONTROL UNIT (CAN) [U1010]	When detecting error during the initial diagnosis of the CAN controller of combination meter.	MWI-35. "Diagnosis Procedure"	O
VEHICLE SPEED [B2205]	The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-36. "Diagnosis Procedure"	P
ENGINE SPEED [B2267]	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-37. "Diagnosis Procedure"	
WATER TEMP [B2268]	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-38. "Diagnosis Procedure"	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) WITH INTELLIGENT KEY

WITH INTELLIGENT KEY : Reference Value

INFOID:000000010244846

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
FR FOG SW	Front fog lamp switch OFF	Off	A
	Front fog lamp switch ON	On	
DOOR SW-DR	Driver door closed	Off	B
	Driver door opened	On	
DOOR SW-AS	Passenger door closed	Off	C
	Passenger door opened	On	
DOOR SW-RR	Rear RH door closed	Off	D
	Rear RH door opened	On	
DOOR SW-RL	Rear LH door closed	Off	E
	Rear LH door opened	On	
DOOR SW-BK	Back door closed	Off	F
	Back door opened	On	
CDL LOCK SW	Other than power door lock switch LOCK	Off	G
	Power door lock switch LOCK	On	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off	H
	Power door lock switch UNLOCK	On	
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off	I
	Driver door key cylinder LOCK position	On	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off	J
	Driver door key cylinder UNLOCK position	On	
HAZARD SW	Hazard switch is OFF	Off	K
	Hazard switch is ON	On	
REAR DEF SW	Rear window defogger switch OFF	Off	L
	Rear window defogger switch ON	On	
TR/BD OPEN SW	NOTE: The item is indicated, but not monitored.	Off	M
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off	
FAN ON SIG	Blower fan OFF	Off	
	Blower fan ON	On	
AIR COND SW	Air conditioner OFF (A/C switch indicator OFF)	Off	
	Air conditioner ON (A/C switch indicator ON)	On	
RKE-LOCK	LOCK button of the key is not pressed	Off	
	LOCK button of the key is pressed	On	
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off	
	UNLOCK button of the key is pressed	On	
RKE-TR/BD	BACK DOOR OPEN button of the key is not pressed	Off	
	BACK DOOR OPEN button of the key is pressed	On	
RKE-PANIC	PANIC button of the key is not pressed	Off	
	PANIC button of the key is pressed	On	
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off	
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On	
OPTI SEN (DTCT)	Bright outside of the vehicle	Close to 5 V	
	Dark outside of the vehicle	Close to 0 V	

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
OPTI SEN (FILT)	Bright outside of the vehicle (Lighting switch AUTO)	Close to 5 V
	Dark outside of the vehicle (Lighting switch AUTO)	Close to 1.50 V
OPTICAL SENSOR	NOTE: The item is indicated, but not monitored.	Off
RAIN SENSOR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
CLUCH SW	The clutch pedal is not depressed.	Off
	The clutch pedal is depressed	On
BRAKE SW 1	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
BRAKE SW 2	The brake pedal is depressed when No. 9 fuse is blown	Off
	The brake pedal is not depressed when No. 9 fuse is blown, or No. 9 fuse is normal	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is locked	Off
	Driver door is unlocked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
SFT N -MET	Selector lever in any position other than N	Off	A
	Selector lever in N position	On	
ENGINE STATE	Engine stopped	Stop	B
	While the engine stalls	Stall	
	At engine cranking	Crank	C
	Engine running	Run	
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off	D
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off	
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off	E
VEH SPEED 1	While driving	Equivalent to speedometer reading	
VEH SPEED 2	While driving	Equivalent to speedometer reading	F
DOOR STAT-DR	Driver door is locked	LOCK	
	Wait with selective UNLOCK operation (5 seconds)	READY	G
	Driver door is unlocked	UNLOCK	
DOOR STAT-AS	Passenger door is locked	LOCK	H
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Passenger door is unlocked	UNLOCK	
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Selector lever is in the P position except for M/T models)	Reset	I
	Ignition switch ON	Set	
PRMT ENG STRT	The engine start is prohibited	Reset	J
	The engine start is permitted	Set	
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset	K
RKE OPE COUN1	During the operation of the key	Operation frequency of the key	L
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—	
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet	M
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done	
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet	
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done	O
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet	
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done	P
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet	
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done	

WCS

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
NOT REGISTERED	BCM detects registered key ID, or BCM does not detect key ID.	ID OK
	BCM detects non-registration key ID.	ID NG
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



NOTE:

- Connector color
- M68, M70: Black
- M69, M71: White

PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
2 (BR/W)	Ground	Combination switch INPUT 5	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Turn signal switch RH	<p style="text-align: right; font-size: small;">PKIB4958J</p>	
					Lighting switch HI		
					Lighting switch 1ST		1.0 V
					Lighting switch 2ND	<p style="text-align: right; font-size: small;">JPMIA0342JP</p>	2.0 V
3 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Turn signal switch LH	<p style="text-align: right; font-size: small;">PKIB4958J</p>	
					Lighting switch PASS		
					Lighting switch 2ND		1.0 V
					Front fog lamp switch ON	<p style="text-align: right; font-size: small;">PKIB4956J</p>	0.8 V
4 (L/Y)	Ground	Combination switch INPUT 3	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Front wiper switch LO	<p style="text-align: right; font-size: small;">PKIB4958J</p>	
					Front wiper switch MIST		
					Front wiper switch INT		
					Lighting switch AUTO		1.0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
5 (G)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch (Wiper intermittent dial 4)	
					Rear washer ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	
Rear wiper switch ON (Wiper intermittent dial 4)		0.8 V				
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Wiper intermittent dial 3 (All switch OFF)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 	
Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 6 • Wiper intermittent dial 7 		0.8 V				

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
7 (W/R)	Ground	Door key cylinder switch UNLOCK	Input	Door key cylin- der switch	NEUTRAL position	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
					UNLOCK position	0 V
8 (W/B)	Ground	Door key cylinder switch LOCK	Input	Door key cylin- der switch	NEUTRAL position	12 V
					LOCK position	0 V
9 (R)	Ground	Stop lamp switch 1	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
12 (GR)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch	NEUTRAL position	 <small>JPMIA0012GB</small> 1.0 - 1.5 V
					LOCK position	0 V
13 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch	NEUTRAL position	 <small>JPMIA0012GB</small> 1.0 - 1.5 V
					UNLOCK position	0 V
14 (L/G)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
15 (W/L)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	Not pressed	 <small>JPMIA0012GB</small> 1.0 - 1.5 V
					Pressed	0 V
17 (R/G)	Ground	Optical sensor pow- er supply	Output	Ignition switch	OFF, ACC	0 V
					ON	5 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
18 (V)	Ground	Sensor ground	Input	Ignition switch ON	0 V	
21 (P/L)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key: Intelligent Key battery is re- moved	Brake pedal: Depressed NOTE: Waveform varies each time when brake pedal is depressed	 <p style="text-align: right; font-size: small;">JMKIA6232JP</p>
					Brake pedal: Not de- pressed	12 V
23 (R/Y)	Ground	Security indicator lamp	Output	Security indica- tor	ON	0 V
					Blinking (Ignition switch OFF)	 <p style="text-align: right; font-size: small;">JPMIA0590GB</p>
				OFF	Battery voltage	
25 (LG)	Ground	NATS antenna amp.	Input/ Output	During waiting	Brake pedal: Depressed NOTE: Waveform varies each time when brake pedal is depressed	 <p style="text-align: right; font-size: small;">JMKIA6233JP</p>
					Brake pedal: Not de- pressed	12 V
27 (O)	Ground	A/C ON	Input	A/C	OFF (A/C switch indicator: OFF)	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p>
					ON (A/C switch indicator: ON)	1.0 - 1.5 V
28 (G/W)	Ground	Blower fan switch	Input	Fan switch	Blower fan switch OFF	0 V
					Blower fan switch ON	 <p style="text-align: right; font-size: small;">PKIB4960J</p>
					7.0 - 8.0 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
29 (L/W)	Ground	Hazard switch	Input	Hazard switch	OFF ON	12 V 0 V	
				31 (G/B)	Ground	Front door lock assembly driver side (Unlock sensor)	Input
UNLOCK status (Unlock sensor switch ON)	0 V						
32 (LG)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	<p style="text-align: right;">PKIB4960J</p>	7.0 - 8.0 V
					Front fog lamp switch ON (Wiper intermittent dial 4)	<p style="text-align: right;">PKIB4960J</p>	1.0 V
					Rear wiper switch ON (Wiper intermittent dial 4)		
Any of the condition below with all switch OFF							
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 							
33 (Y/L)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	<p style="text-align: right;">PKIB4960J</p>	7.0 - 8.0 V
					Lighting switch 1ST (Wiper intermittent dial 4)	<p style="text-align: right;">PKIB4958J</p>	1.2 V
					Lighting switch AUTO (Wiper intermittent dial 4)		
					Rear wiper switch INT (Wiper intermittent dial 4)		
Any of the condition below with all switch OFF							
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 							

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
34 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the condition below with all switch OFF						
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 						
35 (R/L)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND	 <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						
36 (L/O)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Turn signal switch RH	 <p style="text-align: center;">1.2 V</p>
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
Front washer switch ON						

A
B
C
D
E
F
G
H
I
J
K
L
M
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
37 (G/O)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
38 (G/Y)	Ground	Receiver communication	Input/ Output	Ignition switch OFF (Remote keyless entry communication)	Waiting	12 V
					When operating either button on Intelligent Key	 JMMIA0572GB
				Ignition switch ON (TPMS communication)	Waiting	 JMMIA0573GB
					When receiving signal from tire pressure sensor	 JMMIA0574GB
39 (L)	Ground	CAN-H	Input/ Output	—	—	
40 (P)	Ground	CAN-L	Input/ Output	—	—	
43 (W)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed)	 PKIB4960J 9.5 - 10.0 V
					ON (When back door opened)	0 V
44 (LG)	Ground	Rear wiper stop position	Input	Ignition switch ON	Rear wiper stop position	12 V
					Any position other than rear wiper stop position	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
45 (SB)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)
					ON (When passenger door opened)
46 (GR/L)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closed)
					ON (When rear RH door opened)
47 (BR/Y)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)
					ON (When driver door opened)
48 (W/G)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closed)
					ON (When rear door LH opened)
50 (R/W)	Ground	Back door lock actuator relay control	Output	Back door	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
51 (W)	Ground	Back door request switch	Input	Back door request switch	ON (Pressed)
					OFF (Not pressed)
54 (LG)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)
					ON (Activated)



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
55 (G)	Ground	Rear door UNLOCK	Output	Rear door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
56 (L)	Ground	Interior room lamp power supply	Output		Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
					Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
57 (Y)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
59 (G)	Ground	Passenger door UNLOCK	Output	Passenger door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
60 (W/B)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 <p style="text-align: right; font-size: small;">PKIC6370E</p>
						6.0 V
61 (W/L)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">PKIC6370E</p>
						6.0 V
63 (BR)	Ground	Interior room lamp control signal	Output	Interior room lamp	OFF	12 V
					ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
66 (L/B)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON		0 V
68 (L)	Ground	P/W power supply (IGN)	Output	Ignition switch ON		12 V
69 (P)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		12 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
70 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
72 (SB)	Ground	A/C indicator	Output	A/C indicator	OFF	12 V
					ON	0 V
75 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	12 V
76 (L/O)	Ground	Push-button ignition switch (push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
					Not pressed	12 V
78 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch ON	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMKIA5954GB</p>
					When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p style="text-align: right; font-size: small;">JMKIA5955GB</p>
79 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operated with ignition switch ON	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMKIA5954GB</p>
					When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p style="text-align: right; font-size: small;">JMKIA5955GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
80 (BR/Y)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMkia5954GB</p>
				When the passenger door request switch is operated with ignition switch ON	<p style="text-align: right; font-size: small;">JMkia5955GB</p>
81 (L/Y)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMkia5954GB</p>
				When the passenger door request switch is operated with ignition switch ON	<p style="text-align: right; font-size: small;">JMkia5955GB</p>
82 (W/B)	Ground	Back door antenna (+)	Output	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMkia5954GB</p>
				When the back door request switch is operated with ignition switch ON	<p style="text-align: right; font-size: small;">JMkia5955GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
83 (B/W)	Ground	Back door antenna (-)	Output	When the back door request switch is operated with ignition switch ON	<p>When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)</p>  <p style="text-align: right; font-size: small;">JMKIA5954GB</p>
				When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
84 (Y/G)	Ground	Room antenna (+) (Instrument center)	Output	Ignition switch ON	<p>When Intelligent Key is not in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMKIA5951GB</p>
				When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
85 (Y/L)	Ground	Room antenna (-) (Instrument center)	Output	Ignition switch ON	<p>When Intelligent Key is not in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMKIA5951GB</p>
				When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
86 (P)	Ground	Luggage room antenna (+)	Output	Ignition switch ON	When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA5951GB</p>
					When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
87 (L)	Ground	Luggage room antenna (-)	Output	Ignition switch ON	When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA5951GB</p>
					When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
90 (W/L)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON	12 V
					OFF	0 V
91 (Y)	Ground	ACC/ON indicator lamp	Output	Ignition switch	OFF	Battery voltage
					ACC or ON	0.5 V
92 (BR/R)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right; font-size: small;">JPMIA1554GB</p> <p style="text-align: center;">6.0 - 7.0 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
93 (GR/W)	Ground	Intelligent Key warn- ing buzzer	Output	Intelligent Key warning buzzer	Sounding	0 V
					Not sounding	12 V
96 (BR/W)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
97 (L/R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
98 (BR)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V
99 (W/R)	Ground	Ignition relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
100 (G)	Ground	Passenger door re- quest switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	12 V
102 (G)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
103 (G/Y)	Ground	Front defroster switch	Input	Ignition switch ON	A/C mode defroster ON position	0 V
					Other than A/C mode de- froster ON position	
104 (Y/R)	Ground	CVT shift selector (detention switch) power supply	Output	Ignition switch ON		12 V
105 (B/O)	Ground	Stop lamp switch 2	Input	Ignition switch OFF		Battery voltage
106 (Y/B)	Ground	Blower fan motor re- lay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V

A
B
C
D
E
F
G
H
I
J
K
L
M


WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

WITH INTELLIGENT KEY : Wiring Diagram - BCM -

INFOID:000000010244847




JRMWE7712GB

2013/09/19

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE7713GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JRMWE7714GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





















JRMWE7715GB

A
B
C
D
E
F
G
H
I
J
K
L
M
WCS
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)			
Connector No.	B11	Connector Name	LUGGAGE ROOM LAMP
Terminal No.	1	Wire	Y
Terminal No.	3	Wire	L
Connector Type	CJ04FW	Signal Name [Specification]	-
 			
Connector No.	B27	Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Terminal No.	1	Wire	Y
Terminal No.	3	Wire	L
Connector Type	TH04FW-NH	Signal Name [Specification]	-
 			
Connector No.	B53	Connector Name	REAR DOOR SWITCH RH
Terminal No.	3	Wire	LG
Connector Type	TH04FW-NH	Signal Name [Specification]	-
 			
Connector No.	B59	Connector Name	REAR COMBINATION LAMP RH
Terminal No.	1	Wire	R
Terminal No.	2	Wire	G
Terminal No.	3	Wire	W
Connector Type	RS08FB-FR	Signal Name [Specification]	-
 			
Connector No.	B34	Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Terminal No.	1	Wire	Y
Terminal No.	3	Wire	B
Terminal No.	4	Wire	W
Terminal No.	5	Wire	R
Terminal No.	6	Wire	V
Connector Type	TH04FW-NH	Signal Name [Specification]	-
 			
Connector No.	B71	Connector Name	REAR DOOR SWITCH LH
Terminal No.	1	Wire	Y
Terminal No.	3	Wire	B
Terminal No.	4	Wire	W
Terminal No.	5	Wire	R
Terminal No.	6	Wire	V
Connector Type	TH04FW-NH	Signal Name [Specification]	-
 			
Connector No.	B75	Connector Name	BACK DOOR SWITCH
Terminal No.	2	Wire	L
Terminal No.	3	Wire	W
Connector Type	TH04FW-NH	Signal Name [Specification]	-
 			
Connector No.	B80	Connector Name	REAR COMBINATION LAMP LH
Terminal No.	1	Wire	R
Terminal No.	2	Wire	G
Terminal No.	3	Wire	Y
Terminal No.	4	Wire	B
Terminal No.	5	Wire	P
Terminal No.	6	Wire	GR
Connector Type	RS08FB-FR	Signal Name [Specification]	-
 			
Connector No.	B82	Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Terminal No.	1	Wire	R
Terminal No.	2	Wire	G
Connector Type	IK02FL	Signal Name [Specification]	-
 			



JRMWE7818GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	V	-
4	Y	-
5	V	-
6	LG	-
7	BR	-
8	W	-
9	V	-
10	L	-
11	GR	-
12	SB	-
13	W	-
14	G	-
15	G	-
16	W	-

Connector No.	D6
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS03FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
17	B	-
18	GR	-
19	P	-

Connector No.	D9
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0FCY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	SB	-
3	G	-
4	B	-
5	L	-
6	W	-

Connector No.	D11
Connector Name	FRONT DOOR REQUEST SWITCH (DRIVER SIDE)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-

Connector No.	D12
Connector Name	OUTSIDE KEY ANTENNA (DRIVER SIDE)
Connector Type	RK02MGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	V	-

Connector No.	D25
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS12FM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	B	-
6	Y	-
7	R	-
8	L	-
11	SB	-
12	W	-

Connector No.	D31
Connector Name	FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
5	V	-
6	Y	-

Connector No.	D28
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	ED0FCY-RS

Terminal No.	Color Of Wire	Signal Name [Specification]
5	V	-
6	Y	-

Connector No.	D31
Connector Name	FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)
Connector Type	RK02FGY

















Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	LG	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)																
<table border="1"> <tr><td>Connector No.</td><td>D32</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>RK02MGY</td></tr> </table>  	Connector No.	D32	Connector Name	OUTSIDE KEY ANTENNA (PASSENGER SIDE)	Connector Type	RK02MGY	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	P	-	2	V	-
Connector No.	D32															
Connector Name	OUTSIDE KEY ANTENNA (PASSENGER SIDE)															
Connector Type	RK02MGY															
Terminal Color Of No.	Wire	Signal Name [Specification]														
1	P	-														
2	V	-														
<table border="1"> <tr><td>Connector No.</td><td>D33</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FM-CS</td></tr> </table>  	Connector No.	D33	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FM-CS	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	P	-	2	V	-
Connector No.	D33															
Connector Name	REAR POWER WINDOW SWITCH RH															
Connector Type	NS08FM-CS															
Terminal Color Of No.	Wire	Signal Name [Specification]														
1	P	-														
2	V	-														
<table border="1"> <tr><td>Connector No.</td><td>D34</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH LH</td></tr> <tr><td>Connector Type</td><td>NS08FM-CS</td></tr> </table>  	Connector No.	D34	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Type	NS08FM-CS	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>5</td><td>W</td><td>-</td></tr> <tr><td>6</td><td>P</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	5	W	-	6	P	-
Connector No.	D34															
Connector Name	REAR POWER WINDOW SWITCH LH															
Connector Type	NS08FM-CS															
Terminal Color Of No.	Wire	Signal Name [Specification]														
5	W	-														
6	P	-														
<table border="1"> <tr><td>Connector No.</td><td>D35</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table>  	Connector No.	D35	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	E06FGY-RS	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>5</td><td>W</td><td>-</td></tr> <tr><td>6</td><td>P</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	5	W	-	6	P	-
Connector No.	D35															
Connector Name	REAR DOOR LOCK ASSEMBLY RH															
Connector Type	E06FGY-RS															
Terminal Color Of No.	Wire	Signal Name [Specification]														
5	W	-														
6	P	-														
<table border="1"> <tr><td>Connector No.</td><td>D65</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY LH</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table>  	Connector No.	D65	Connector Name	REAR DOOR LOCK ASSEMBLY LH	Connector Type	E06FGY-RS	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	V	-	2	G	-
Connector No.	D65															
Connector Name	REAR DOOR LOCK ASSEMBLY LH															
Connector Type	E06FGY-RS															
Terminal Color Of No.	Wire	Signal Name [Specification]														
1	V	-														
2	G	-														
<table border="1"> <tr><td>Connector No.</td><td>D107</td></tr> <tr><td>Connector Name</td><td>BACK DOOR REQUEST SWITCH</td></tr> <tr><td>Connector Type</td><td>RK02FGY</td></tr> </table>  	Connector No.	D107	Connector Name	BACK DOOR REQUEST SWITCH	Connector Type	RK02FGY	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	W	-	2	B	-
Connector No.	D107															
Connector Name	BACK DOOR REQUEST SWITCH															
Connector Type	RK02FGY															
Terminal Color Of No.	Wire	Signal Name [Specification]														
1	W	-														
2	B	-														
<table border="1"> <tr><td>Connector No.</td><td>D106</td></tr> <tr><td>Connector Name</td><td>BACK DOOR LOCK ASSEMBLY</td></tr> <tr><td>Connector Type</td><td>FEA04FB-FHA2-LC</td></tr> </table>  	Connector No.	D106	Connector Name	BACK DOOR LOCK ASSEMBLY	Connector Type	FEA04FB-FHA2-LC	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>GR</td><td>-</td></tr> <tr><td>3</td><td>Y</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	2	GR	-	3	Y	-
Connector No.	D106															
Connector Name	BACK DOOR LOCK ASSEMBLY															
Connector Type	FEA04FB-FHA2-LC															
Terminal Color Of No.	Wire	Signal Name [Specification]														
2	GR	-														
3	Y	-														
<table border="1"> <tr><td>Connector No.</td><td>D108</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (BACK DOOR)</td></tr> <tr><td>Connector Type</td><td>RK02MGY</td></tr> </table>  	Connector No.	D108	Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)	Connector Type	RK02MGY	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	BR	-	2	R	-
Connector No.	D108															
Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)															
Connector Type	RK02MGY															
Terminal Color Of No.	Wire	Signal Name [Specification]														
1	BR	-														
2	R	-														

JRMWE7820GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)

Connector No.	D112
Connector Name	REAR WIPER MOTOR
Connector Type	CJ04FW-TV



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
3	BR	-
4	LG	-

Connector No.	E10
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	M06FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	-
4	P	-
5	LG	-
6	SB	-
7	Y	-
8	V	-

Connector No.	E11
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	M06FELC



Terminal No.	Color Of Wire	Signal Name [Specification]
9	BR	-
10	Y	-
13	W	-

Connector No.	E12
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FBR-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
18	Y	-
19	BR	-
21	W	-
22	V	-

Connector No.	E13
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH12FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
24	G	-
25	Y	-
26	P	-
27	L	-
28	P	-
30	SB	-
31	W	-
33	O	-
34	R	-

Connector No.	E15
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS16FM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
47	BR	-
49	W	-
50	GR	-
51	R	-
52	P	-
54	GR	-
55	P	-
56	SB	-
57	G	- [With M/T]
58	LG	- [With CVT]
59	R	-

59	Y	-
60	V	-
61	W	-
62	L	-

Connector No.	E17
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH10FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
64	R	-
66	L	-
69	O	-

Connector No.	E23
Connector Name	SIDE TURN SIGNAL LAMP LH
Connector Type	ISL02FFW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)

Connector No.	E25
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Type	RK09FBR



Terminal No.	1	3
Color	V	P
Wire	-	-
Signal Name [Specification]	-	-

Connector No.	E27
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	RS02FB



Terminal No.	1	3
Color	V	P
Wire	-	-
Signal Name [Specification]	-	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



Terminal No.	1	2	3	4
Color	V	W	O	G
Wire	-	-	-	-
Signal Name [Specification]	-	-	-	-

Connector No.	F21
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	RK08FG



Terminal No.	1	2	3	4	5	6	7	8
Color	R	W	R	GR	SB	W	Y	G
Wire	-	-	-	-	-	-	-	-
Signal Name [Specification]	-	-	-	-	-	-	-	-

Connector No.	E10
Connector Name	SIDE TURN SIGNAL LAMP RH
Connector Type	STL02FW



Terminal No.	1	2
Color	W	BY
Wire	-	-
Signal Name [Specification]	-	-

Connector No.	E46
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	RS02FB



Terminal No.	1	2
Color	W	BY
Wire	-	-
Signal Name [Specification]	-	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	24311-ED000

Terminal No.	1
Color	W
Wire	-
Signal Name [Specification]	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BDT6FW
















Terminal No.	4	5	6	7	8
Color	B	L	O	P	LG/R
Wire	-	-	-	-	-
Signal Name [Specification]	-	-	-	-	-

JRMWE7822GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)			
Connector No.	M10	Connector No.	M26
Connector Name	IGNITION RELAY	Connector Name	NATS ANTENNA-AMP.
Connector Type	MS02FL-M2-LC	Connector Type	TH04FW-NH
			
			
Terminal No.	Wire	Signal Name [Specification]	
1	B	-	
2	W/B	-	
3	W/B	-	
5	L	-	
Connector No. M17			
Connector Name OPTICAL SENSOR			
Connector Type TK03FW			
			
			
Terminal No.	Wire	Signal Name [Specification]	
1	R/G	POWER	
2	L/B	OUTPUT	
3	V	GROUND	
Connector No. M45			
Connector Name HAZARD SWITCH			
Connector Type TK04FW			
			
			
Terminal No.	Wire	Signal Name [Specification]	
1	B	-	
2	L/W	-	
3	W	-	
4	BR	-	
Connector No. M51			
Connector Name A/C AUTO AMP.			
Connector Type TK16FSY			
			
			
Terminal No.	Wire	Signal Name [Specification]	
21	BR	WATER TEMPERATURE SIGNAL	
22	PU/W	AMBIENT SENSOR SIGNAL	
23	O	INTAKE SENSOR SIGNAL	
24	G	IN-VEHICLE SENSOR SIGNAL	
25	P	SUNLOAD SENSOR SIGNAL	
26	SB	INTAKE DOOR MOTOR PBR FIB SIGNAL	
27	R	REAR WINDOW DEFOGGER FIB SIGNAL	
29	GR	MODE DRIVE SIGNAL 4	
30	W	MODE DRIVE SIGNAL 3	
31	Y	MODE DRIVE SIGNAL 2	
32	V	MODE DRIVE SIGNAL 1	
33	W/L	REAR WINDOW DEFOGGER ON SIGNAL	
34	Y/G	A/C ON SIGNAL	
35	G/W	BLOWER PAN ON SIGNAL	
36	GR/R	POWER TRANSISTOR CONTROL SIGNAL	
Connector No. M34			
Connector Name COMBINATION METER			
Connector Type TH04FW-NH			
			
			
Terminal No.	Wire	Signal Name [Specification]	
1	L	CANH	
2	P	CANH	
3	V	VEHICLE SPEED SIGNAL (2-PULSE)	
4	V	VEHICLE SPEED SIGNAL (8-PULSE) (MAIN/WAL)	
4	VR	VEHICLE SPEED SIGNAL (8-PULSE) (MAIN/WAL)	
6	BRY	FUEL LEVEL SENSOR SIGNAL	
7	R/G	AIR BAG SIGNAL	
8	P	OVERDRIVE CONTROL SWITCH SIGNAL	
9	O	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)	
10	SB	PARKING BRAKE SWITCH SIGNAL	
11	GR	BRAKE FLUID LEVEL SWITCH SIGNAL	
13	BR	ILLUMINATION CONTROL SIGNAL	
15	L/Y	ACC POWER SUPPLY	
18	R/Y	SECURITY SIGNAL	
19	PU/W	AMBIENT SENSOR SIGNAL	
20	RAW	AMBIENT SENSOR GROUND	
21	B	GROUND	
22	B	GROUND	
23	B	GROUND	
24	PU	FUEL LEVEL SENSOR GROUND	
25	B	VDC GROUND	
27	LG/R	BATTERY POWER SUPPLY	
28	GR	IGNITION SIGNAL	
29	BR	PASSENGER SEAT BELT WARNING SIGNAL	
31	R	A/C AUTO AMP CONNECTION RECOGNITION SIGNAL	
35	BR	ENGINE COOLANT TEMPERATURE SIGNAL	
38	GR	ALTERNATOR SIGNAL	
Connector No. M27			
Connector Name COMBINATION SWITCH			
Connector Type TH04FW-NH			
			
			
Terminal No.	Wire	Signal Name [Specification]	
1	O/B	WASHER (RR)	
2	GR	OUTPUT 4	
3	R/G	WASHER (FR)	
4	W	IGN	
5	L/Y	OUTPUT 3	
6	B	GROUND	
7	W	INPUT 3	
8	BR/W	OUTPUT 5	
9	R/L	INPUT 2	
10	Y/L	INPUT 4	
11	L/O	INPUT 1	
12	LR	OUTPUT 1	
13	LG	INPUT 5	
14	G	OUTPUT 2	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P




BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)

Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH





Terminal No.	Wire	Signal Name [Specification]
1	P	-
2	B	-
3	W	-
4	BR	-
5	LG	-
6	B	-
7	YR	-
8	GY	-



Terminal No.	Wire	Signal Name [Specification]
17	RIG	OPTICAL SENSOR POWER SUPPLY
18	V	SENSOR GND
21	PIL	NATS ANTENNA AMP.
23	RY	SECURITY INDICATOR LAMP
25	LG	NATS ANTENNA AMP.
27	O	A/C SW
28	GW	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/B	DR DOOR UNLOCK SENSOR
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	G/O	SHIFT P
38	GY	RECEIVER COMM
39	I	CAN-H
40	P	CAN-L


Connector No.	M69
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA


Terminal No.	Wire	Signal Name [Specification]
43	W	BACK DOOR SW
44	LG	REAR WIPER STOP POSITION
45	SB	PASSENGER DOOR SW
46	GR/L	REAR RH DOOR SW
47	BRY	DRIVER DOOR SW
48	W/G	REAR LH DOOR SW
50	RAW	BK DR LOCK ACT RELAY CONT
51	W	BACK DOOR REQUEST SW
54	LG	REAR WIPER OUTPUT
55	G	REAR DOOR UNLOCK OUTPUT

BCM (BODY CONTROL MODULE)

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA





Terminal No.	Wire	Signal Name [Specification]
58	I	58
59	I	59
60	I	60
61	I	61
62	I	62
63	I	63
64	I	64
65	I	65
66	I	66
67	I	67
68	I	68
69	I	69
70	I	70



Terminal No.	Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	G	PASSENGER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/B	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	L/B	DRIVER DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (F/L)



Connector No.	M71
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH

Terminal No.	Wire	Signal Name [Specification]
72	SB	A/C INDICATOR OUTPUT
75	SB	DRIVER DOOR REQUEST SW
76	L/O	PUSH SW
78	LG	DRIVER DOOR ANT+
79	V	DRIVER DOOR ANT-
80	BRY	PASSENGER DOOR ANT+
81	LY	PASSENGER DOOR ANT-
82	W/B	BACK DOOR ANT+

BCM (BODY CONTROL MODULE)



Connector No.	M72
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	24335-C9900

Terminal No.	Wire	Signal Name [Specification]
1	BR	-
2	BR/R	-

BCM (BODY CONTROL MODULE)

Connector No.	M73
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	24335-C9900





Terminal No.	Wire	Signal Name [Specification]
1	BR	-
2	BR/R	-

JRMWE7824GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



WITH INTELLIGENT KEY : Fail-safe

FAIL-SAFE CONTROL BY DTC
 BCM performs fail-safe control when any DTC are detected.

JRMWE7825GB

INFOID:0000000010244848

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2198: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter relay control signal • Starter relay status signal (CAN)
B260F: ENG STATE SIG LOST	Inhibit engine cranking	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B26F1: IGN RELAY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch ON signal (CAN: Transmitted from BCM): ON • Ignition switch ON signal (CAN: Transmitted from IPDM E/R): ON
B26F2: IGN RELAY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch ON signal (CAN: Transmitted from BCM): OFF • Ignition switch ON signal (CAN: Transmitted from IPDM E/R): OFF
B26F3: START CONT RLY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> • Starter control relay signal (CAN: Transmitted from BCM): OFF • Starter control relay signal (CAN: Transmitted from IPDM E/R): OFF
B26F4: START CONT RLY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> • Starter control relay signal (CAN: Transmitted from BCM): ON • Starter control relay signal (CAN: Transmitted from IPDM E/R): ON
B26F7: BCM	Inhibit engine cranking by Intelligent Key system	When room antenna and luggage room antenna functions normally

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

WITH INTELLIGENT KEY : DTC Inspection Priority Chart

INFOID:000000010244849

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC	A
3	<ul style="list-style-type: none"> • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI-SCANNING • B2198: NATS ANTENNA AMP 	B
4	<ul style="list-style-type: none"> • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2608: STARTER RELAY • B260F: ENG STATE SIG LOST • B2614: BCM • B2615: BCM • B2616: BCM • B2618: BCM • B261A: PUSH-BTN IGN SW • B26F1: IGN RELAY OFF • B26F2: IGN RELAY ON • B26F3: START CONT RLY ON • B26F4: START CONT RLY OFF • B26F6: BCM • B26F7: BCM • B26F8: BCM • B26FC: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED 	C D E F G H
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL 	I J K L
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA 	M
7	<ul style="list-style-type: none"> • B2626: OUTSIDE ANTENNA • B2627: OUTSIDE ANTENNA • B2628: OUTSIDE ANTENNA 	N

WITH INTELLIGENT KEY : DTC Index

INFOID:000000010244850

WCS

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [WCS-17. "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)".](#)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-40
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-41
U0415: VEHICLE SPEED	—	—	×	—	BCS-42
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-38
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-40
B2195: ANTI-SCANNING	×	—	—	—	SEC-41
B2198: NATS ANTENNA AMP	×	—	—	—	SEC-42
B2555: STOP LAMP	—	×	×	—	SEC-46
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-48
B2557: VEHICLE SPEED	—	×	×	—	SEC-50
B2562: LOW VOLTAGE	—	×	—	—	BCS-43
B2601: SHIFT POSITION	—	×	×	—	SEC-51
B2602: SHIFT POSITION	—	×	×	—	SEC-54
B2603: SHIFT POSI STATUS	—	×	×	—	SEC-57
B2604: PNP/CLUTCH SW	—	×	×	—	SEC-62
B2605: PNP/CLUTCH SW	—	×	×	—	SEC-65
B2608: STARTER RELAY	×	×	×	—	SEC-67
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-69
B2614: BCM	—	×	×	—	PCS-77
B2615: BCM	—	×	×	—	PCS-80
B2616: BCM	—	×	×	—	PCS-83
B2618: BCM	—	×	×	—	PCS-86
B261A: PUSH-BTN IGN SW	—	×	×	—	PCS-87
B2621: INSIDE ANTENNA	—	×	—	—	DLK-44
B2622: INSIDE ANTENNA	—	×	—	—	DLK-46
B2626: OUTSIDE ANTENNA	—	×	—	—	DLK-50
B2627: OUTSIDE ANTENNA	—	×	—	—	DLK-48
B2628: OUTSIDE ANTENNA	—	×	—	—	DLK-52
B26F1: IGN RELAY OFF	×	×	×	—	PCS-89
B26F2: IGN RELAY ON	×	×	×	—	PCS-91
B26F3: START CONT RLY ON	×	×	×	—	SEC-70
B26F4: START CONT RLY OFF	×	×	×	—	SEC-71
B26F6: BCM	—	×	×	—	PCS-93
B26F7: BCM	×	×	×	—	SEC-73
B26F8: BCM	—	×	×	—	SEC-74
B26FC: KEY REGISTRATION	—	×	×	—	SEC-75

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1704: LOW PRESSURE FL	—	—	—	×	WT-26
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	WT-28
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-31
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-33

WITHOUT INTELLIGENT KEY

WITHOUT INTELLIGENT KEY : Reference Value

INFOID:0000000010244852

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
LOCK STATUS	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ACC ON SW	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
SHOCK SENSOR	NOTE: The item is indicated, but not monitored.	NORMAL
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
REVERSE SW CAN	NOTE: The item is indicated, but not used.	Off
		On
TAIL LAMP SW	Lighting switch OFF	Off
	Lighting switch 1ST	On
FR FOG SW	NOTE: The item is indicated, but not monitored.	Off
BUCKLE SW	The seat belt (driver side) is fastened. [Seat belt switch (driver side) OFF]	Off
	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) ON]	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
KYLS TRNK/HAT	NOTE: The item is indicated, but not monitored.	Off
KEYLESS PANIC	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
HI BEAM SW	Lighting switch OFF	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Lighting switch OFF	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Lighting switch OFF	Off
	Lighting switch 2ND	On
AUTO LIGHT SW	NOTE: The item is indicated, but not monitored.	Off
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
PKB SW	Parking brake switch is OFF	Off	A
	Parking brake switch is ON	On	
ENGINE RUN	Engine stopped	Off	B
	Engine running	On	
OPTI SEN (DTCT)	NOTE: The item is indicated, but not monitored.	Close to 5 V	C
OPTI SEN (FILT)	NOTE: The item is indicated, but not monitored.	Close to 5 V	
LIG SEN COND	NOTE: The item is indicated, but not monitored.	OFF	D
IGN SW CAN	Ignition switch OFF or ACC	Off	
	Ignition switch ON	On	E
FR WIPER HI	Front wiper switch OFF	Off	
	Front wiper switch HI	On	F
FR WIPER LOW	Front wiper switch OFF	Off	
	Front wiper switch LO	On	
FR WIPER INT	Front wiper switch OFF	Off	G
	Front wiper switch INT	On	
FR WASHER SW	Front washer switch OFF	Off	
	Front washer switch ON	On	H
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	
FR WIPER STOP	Any position other than front wiper stop position	Off	I
	Front wiper stop position	On	
RR WIPER ON	Rear wiper switch OFF	Off	
	Rear wiper switch ON	On	J
RR WIPER INT	Rear wiper switch OFF	Off	
	Rear wiper switch INT	On	K
RR WASHER SW	Rear washer switch OFF	Off	
	Rear washer switch ON	On	
RR WIPER STOP	Rear wiper stop position	Off	L
	Other than rear wiper stop position	On	
RAIN SENSOR	NOTE: The item is indicated, but not monitored.	Off	M
HAZARD SW	Hazard switch OFF	Off	
	Hazard switch ON	On	WCS
FAN ON SIG	Blower control dial OFF	Off	
	Other than blower control dial OFF	On	
AIR COND SW	A/C switch OFF	Off	O
	A/C switch ON	On	
THERMO AMP	Ignition switch ON	Off	P
	Evaporator is extremely low temperature	On	
FR DEF SW	Other than A/C mode defroster ON position	Off	
	A/C mode defroster ON position	On	
KEYLESS TRUNK	NOTE: The item is indicated, but not monitored.	Off	

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
TRNK OPNR SW	NOTE: The item is indicated, but not monitored.	Off
TRNK OPN MNTR	NOTE: The item is indicated, but not monitored.	Off
HOOD SW	Close the hood	Off
	Open the hood	On
TRANSPONDER	Other than the ignition switch is ON by key registered to BCM.	Off
	The ignition switch is ON by key registered to BCM.	On
INTELLI KEY	NOTE: The item is indicated, but not used.	Off
AUTO RELOCK	NOTE: The item is indicated, but not monitored.	Off
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	Off
	Ignition switch ON	On
BRAKE SW	Brake pedal is not depressed	Off
	Brake pedal is depressed	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT







NOTE:

- M65, M66: White
- M67: Black

PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
2 (BR/W)	Ground	Combination switch INPUT 5	Input	All switch OFF	0 V
				Turn signal switch RH	
				Lighting switch HI	
				Lighting switch 1ST	
				Lighting switch 2ND	
3 (GR)	Ground	Combination switch INPUT 4	Input	All switch OFF	0 V
				Turn signal switch LH	
				Lighting switch PASS	
				Lighting switch 2ND	
				Front wiper switch LO	
			Front wiper switch MIST		
			Front wiper switch INT		

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
5 (G)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	A
					Front washer switch (Wiper intermittent dial 4)		B
					Rear washer switch ON (Wiper intermittent dial 4)		C
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 		1.0 V
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	Rear wiper switch ON (Wiper intermittent dial 4)		E
					0.8 V	F	
					All switch OFF (Wiper intermittent dial 4)	0 V	G
					Front wiper switch HI (Wiper intermittent dial 4)		H
Rear wiper switch INT (Wiper intermittent dial 4)	I						
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	Wiper intermittent dial 3 (All switch OFF)		J
					1.0 V	K	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 		L
					1.9 V	M	
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 6 • Wiper intermittent dial 7 		O
					0.8 V	P	

WCS





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
7 (W/R)	Ground	Door key cylinder switch UNLOCK	Input	Door key cylin- der switch	NEUTRAL position	 7.0 - 8.0 V
					UNLOCK position	0 V
8 (W/B)	Ground	Door key cylinder switch LOCK	Input	Door key cylin- der switch	NEUTRAL position	12 V
					LOCK position	0 V
9 (R)	Ground	Stop lamp switch	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
10 (W/L)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	OFF (Not pressed)	12 V
					ON (Pressed)	0 V
11 (L/Y)	Ground	Ignition switch ACC	Input	Ignition switch OFF		0 V
				Ignition switch ACC or ON		Battery voltage
12 (SB)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 7.0 - 8.0 V
					ON (When passenger door opened)	0 V
13 (GR/L)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closed)	 7.0 - 8.0 V
					ON (When rear RH door opened)	0 V
18 (V)	Ground	Receiver ground	Input	Ignition switch ON		0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
19 (BR)	Ground	Remote keyless entry receiver power supply	Input	Insert mechanical key into ignition key cylinder	0 V
				Remove mechanical key from ignition key cylinder (Any door opened)	5 V
				Remove mechanical key from ignition key cylinder (Any door closed)	 <small>JPMIA0338JP</small>
20 (G/Y)	Ground	Remote keyless entry receiver communication	Input	Insert mechanical key into ignition key cylinder	0 V
				Waiting	 <small>PIIB7728J</small>
				Signal receiving	 <small>PIIB7729J</small>
21 (P/L)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder	Pointer of tester should move
				Other than above	0 V
23 (R/Y)	Ground	Security indicator	Input	ON	0 V
				Blinking (Ignition switch OFF)	 <small>JPMIA0014GB</small>
				OFF	12 V
25 (LG)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder	Pointer of tester should move
				Other than above	0 V
26 (GR)	Ground	Thermo control amp.	Input	Ignition switch ON	0 V
				Evaporator is extremely low temperature	12 V

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
27 (Y/G)	Ground	A/C switch	Input	A/C switch	OFF	 <small>JPMIA0012GB</small> 1.0 - 1.5 V
					ON	0 V
28 (G/W)	Ground	Blower fan switch	Input	Fan switch	Blower fan switch OFF	 <small>PKIB4960J</small> 7.0 - 8.0 V
					Blower fan switch ON	0 V
29 (L/W)	Ground	Hazard switch	Input	Hazard switch	OFF	Battery voltage
					ON	0 V
31 (G/Y)	Ground	Front defroster switch	Input	Ignition switch ON	A/C mode defroster ON position	0 V
					Other than A/C mode defroster ON position	 <small>JPMIA0589GB</small> 8.0 - 9.0 V
32 (LG)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>PKIB4960J</small> 7.0 - 8.0 V
					Rear wiper switch ON (Wiper intermittent dial 4)	 <small>PKIB4956J</small> 1.0 V
					Any of the condition below with all switch OFF	<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
33 (Y/L)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 						
34 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 						
35 (R/L)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						





A
B
C
D
E
F
G
H
I
J
K
L
M

WCS

O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
36 (L/O)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 7.0 - 8.0 V
					Turn signal switch RH	 1.2 V
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
		Front washer switch ON				
37 (R/W)	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage	
				Remove mechanical key from ignition key cylinder	0 V	
38 (O)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
39 (L)	Ground	CAN-H	Input/ Output	—	—	
40 (P)	Ground	CAN-L	Input/ Output	—	—	
43 (W)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed) ON (When back door opened)	 7.0 - 8.0 V 0 V
44 (LG)	Ground	Rear wiper stop po- sition	Input	Ignition switch ON	Rear wiper stop position	12 V
					Any position other than rear wiper stop position	0 V
45 (GR)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch	NEUTRAL position	 1.0 - 1.5 V
					LOCK position	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
46 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch	NEUTRAL position  1.0 - 1.5 V
				UNLOCK position	0 V
47 (BR/Y)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)  7.0 - 8.0 V
				ON (When driver door opened)	0 V
48 (W/G)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closed)  7.0 - 8.0 V
				ON (When rear LH door opened)	0 V
50 (SB)	Ground	A/C indicator	Output	A/C indicator	OFF 12 V
				ON 0 V	
54 (LG)	Ground	Rear wiper	Output	Ignition switch ON	Rear wiper switch OFF 0 V
				Rear wiper switch ON 12 V	
56 (L)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
57 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
59 (L/B)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated) 12 V
				Other than UNLOCK (Actuator is not activated) 0 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
60 (W/B)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	 6.0 V
61 (W/L)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	 6.0 V
63 (BR)	Ground	Interior room lamp control signal	Output	Interior room lamp	OFF 12 V
				ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated) 12 V
				Other than LOCK (Actuator is not activated)	0 V
66 (G)	Ground	Passenger door and rear door UNLOCK	Output	Passenger door and rear door	UNLOCK (Actuator is activated) 12 V
				Other than UNLOCK (Actuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON	0 V
68 (L)	Ground	P/W power supply (IGN)	Output	Ignition switch ON	12 V
69 (P)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
70 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

WITHOUT INTELLIGENT KEY : Wiring Diagram - BCM -

INFOID:000000010244853



2013/09/19


JRMWE7716GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JRMWE7717GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JRMWE7718GB



A
B
C
D
E
F
G
H
I
J
K
L
M
WCS
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)

Connector No.	B11
Connector Name	LUGGAGE ROOM LAMP
Connector Type	CJ04FW

Terminal No.	Wire	Signal Name [Specification]
1	Y	-
3	L	-



Connector No.	B27
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	TH04FW-NH

Terminal No.	Wire	Signal Name [Specification]
1	Y	-
3	L	-



Terminal No.	Wire	Signal Name [Specification]
1	Y	-
3	B	-
4	W	-
5	R	-
6	V	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH-LH
Connector Type	TH04FW-NH



Terminal No.	Wire	Signal Name [Specification]
1	Y	-
3	B	-
4	W	-
5	R	-
6	V	-

Connector No.	B34
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH04FW-NH

Terminal No.	Wire	Signal Name [Specification]
1	Y	-
3	B	-
4	W	-
5	R	-
6	V	-



Connector No.	B53
Connector Name	REAR DOOR SWITCH-RH
Connector Type	TH04FW-NH

Terminal No.	Wire	Signal Name [Specification]
3	LG	-



Terminal No.	Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	O	-
5	Y	-
6	V	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	GR	-
12	SB	-
13	W	-
14	G	-
16	W	-

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	INSTRVW-CS

Terminal No.	Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	O	-
5	Y	-
6	V	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	GR	-
12	SB	-
13	W	-
14	G	-
16	W	-

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Type	RS08FB-FR

Terminal No.	Wire	Signal Name [Specification]
2	L	-
3	W	-

JRMWE7826GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

















BCM (BODY CONTROL MODULE)				(WITHOUT INTELLIGENT KEY)			
Connector No.	D6	Connector Name	POWER WINDOW MAIN SWITCH	Connector No.	D25	Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS03FV-CS	Connector Type	NS03FV-CS	Connector Type	NS12FV-CS	Connector Type	NS08FV-CS
Terminal Color Of No.	Wire	Signal Name [Specification]		Terminal Color Of No.	Wire	Signal Name [Specification]	
17	B	-		1	GR	-	
18	GR	-		2	BR	-	
19	P	-		3	D	-	
				6	Y	-	
				7	R	-	
				8	L	-	
				11	SB	-	
				12	W	-	
Connector No.	D9	Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)	Connector No.	D28	Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	ED06FY-RS	Connector Type	ED06FY-RS	Connector Type	ED06FY-RS	Connector Type	ED06FY-RS
Terminal Color Of No.	Wire	Signal Name [Specification]		Terminal Color Of No.	Wire	Signal Name [Specification]	
1	V	-		5	V	-	
2	SB	-		6	Y	-	
3	G	-					
4	B	-					
5	L	-					
6	W	-					
Connector No.	D13	Connector Name	REAR POWER WINDOW SWITCH RH	Connector No.	D43	Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FV-CS	Connector Type	NS08FV-CS	Connector Type	NS08FV-CS	Connector Type	NS08FV-CS
Terminal Color Of No.	Wire	Signal Name [Specification]		Terminal Color Of No.	Wire	Signal Name [Specification]	
1	L	-		1	L	-	
2	BR	-		2	BR	-	
3	O	-		3	O	-	
4	G	-		4	G	-	
5	R	-		5	R	-	
Connector No.	D15	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector No.	D65	Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	ED06FY-RS	Connector Type	ED06FY-RS	Connector Type	ED06FY-RS	Connector Type	ED06FY-RS
Terminal Color Of No.	Wire	Signal Name [Specification]		Terminal Color Of No.	Wire	Signal Name [Specification]	
5	W	-		1	V	-	
6	P	-		2	G	-	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)		E11		E13		E27	
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
D106	BACK DOOR LOCK ASSEMBLY	E11	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	E13	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	E27	FRONT TURN SIGNAL LAMP LH
FEA04FB-FHA2-LC		M08FB-LC		TH12FM-NH		RS02FB	
							
Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
2 GR	-	9 B/W	-	24 G	-	1 L	-
3 Y	-	10 L	-	25 Y	-	2 B/W	-
		13 W	-	26 P	-		
				27 L	-		
				28 B	-		
				30 SB	-		
				31 W	-		
				33 O	-		
				34 R	-		
Connector No. D112	REAR WIPER MOTOR	Connector No. E12	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector No. E40	SIDE TURN SIGNAL LAMP RH	Connector No. E40	SIDE TURN SIGNAL LAMP RH
CJ04FH-TV		NS08FBR-CS		STL02FW		STL02FW	
							
Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
1 P	-	18 Y	-	1 W	-	1 W	-
3 BR	-	19 B/W	-	2 B/Y	-	2 B/Y	-
4 LG	-	21 W	-				
		22 V	-				

JRMWE7828GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)			
Connector No.	M27	Connector Name	COMBINATION SWITCH
Connector Type	TH40FW-NH		
Terminal No.	Color	Wire	Signal Name [Specification]
1	O/B		WASHER (BR)
2	GR		OUTPUT 4
3	RG		WASHER (FR)
4	W		IGS
5	Y		OUTPUT 3
6	B		GROUND
7	W		INPUT 3
8	BRW		OUTPUT 5
9	R/L		INPUT 2
10	Y/L		INPUT 4
11	L/O		INPUT 1
12	L/R		OUTPUT 1
13	LG		INPUT 5
14	G		OUTPUT 2
Connector No.	M24	Connector Name	KEY SWITCH
Connector Type	TK06MGY		
Terminal No.	Color	Wire	Signal Name [Specification]
1	R/W		-
2	LG/R		-
Connector No.	M26	Connector Name	NATS ANTENNA AMP.
Connector Type	TH40FW-NH		
Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		BAT
2	P/L		CLK
3	B		GND [Without Intelligent Key]
4	B		DATA [With Intelligent Key]
5	B		GND [With Intelligent Key]
6	L		DATA [Without Intelligent Key]
7	GR/R		-
8	O		-
14	P		-
16	LG/R		-
Connector No.	M4	Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW		
Terminal No.	Color	Wire	Signal Name [Specification]
1	V		-
2	W		-
3	O		-
4	G		-
Connector No.	M25	Connector Name	STOP LAMP SWITCH
Connector Type	M02FE-LC		
Terminal No.	Color	Wire	Signal Name [Specification]
1	W		-
2	BY		-
Connector No.	M34	Connector Name	COMBINATION METER
Connector Type	TH40FW-NH		
Terminal No.	Color	Wire	Signal Name [Specification]
1	L		CANH
2	P		CANL
3	V		VEHICLE SPEED SIGNAL (2-PULSE)
4	L		VEHICLE SPEED SIGNAL (6-PULSE) [ImmorNav]
5	V/R		VEHICLE SPEED SIGNAL (8-PULSE) [With NAV]
6	BRY		FUEL LEVEL SENSOR SIGNAL

JRMWE7829GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)

7	R/G	AIR BAG SIGNAL
8	P	OVERDRIVE CONTROL SWITCH SIGNAL
9	O	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
10	SB	PARKING BRAKE SWITCH SIGNAL
11	G/R	BRAKE FLUID LEVEL SWITCH SIGNAL
13	G/R	ILLUMINATION CONTROL SIGNAL
15	L/Y	ACC POWER SUPPLY
18	R/Y	SECURITY SIGNAL
19	PL/W	AMBIENT SENSOR SIGNAL
20	R/W	AMBIENT SENSOR GROUND
21	B	GROUND
22	B	GROUND
23	B	GROUND
24	PU	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
27	LG/R	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	BR	PASSENGER SEAT BELT WARNING SIGNAL
31	B	ACCUMULATOR ELECTROLYTE SIGNAL
35	BR	ENGINE COOLANT TEMPERATURE SIGNAL
38	GR	ALTERNATOR SIGNAL

Connector No.	M44
Connector Name	THERMO CONTROL AMP.
Connector Type	506FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	B	-
4	V	-
5	B/W	-

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	L/W	-
3	W	-
4	B/R	-

Connector No.	M55
Connector Name	A/C CONTROL
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
4	R	-
5	W/L	-
6	G/Y	-
8	G	-
9	B/R	-
10	B/W	-
11	V	-
12	Y/R	-
13	SB	-
14	Y	-
15	B	-
16	L	-

Connector No.	M61
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TK04FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	G/Y	-
4	BR	-


Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1
7	W/R	KEY CYL UNLOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW
10	W/L	REAR WINDOW DEFOGGER SW
11	L/Y	ACC POWER SUPPLY
12	SB	PASSENGER DOOR SW
13	GR/L	REAR RH DOOR SW
18	V	RECEIVER / SENSOR GND
19	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
20	G/Y	KEYLESS ENTRY RECEIVER COMM
21	P/L	NAIS ANTENNA AMP
23	P/Y	SECURITY INDICATOR LAMP

25	LG	NAIS ANTENNA AMP.
26	GR	THERMO CONTROL AMP.
27	Y/G	A/C SW
28	G/W	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/Y	FR DEFROSTER SW
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	R/W	KEY SWITCH
38	O	IGNITION POWER SUPPLY
39	L	CANH
40	P	CANL

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08FW-FH46-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
43	W	BACK DOOR SW
44	LG	REAR WIPER STOP POSITION
45	GR	CENTRAL DOOR LOCK SW
46	BR	CENTRAL DOOR UNLOCK SW
47	B/Y	DRIVER DOOR SW
48	W/G	REAR LH DOOR SW
50	SB	A/C INDICATOR OUTPUT
54	LG	REAR WIPER OUTPUT


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
J
K
L
M
WCS
O
P

BCM (BODY CONTROL MODULE)


Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHAG-SA



35	37	39	41	43	
65	66	67	68	69	70

Terminal No.	Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	L/B	DRIVER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/B	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	G	PASSENGER DOOR REAR DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (F/L)

Connector No.	M73
Connector Name	FAN SWITCH
Connector Type	M06FW-LC




1	2	3
4	5	6

Terminal Color Of No.	Wire	Signal Name [Specification]
1	R	-
2	W	-
3	B	-
4	Y	-
5	Y	-
6	GW	-

(WITHOUT INTELLIGENT KEY)


Connector No.	R4
Connector Name	MAP LAMP
Connector Type	GAA06FW



4	3	2
---	---	---

Terminal Color Of No.	Wire	Signal Name [Specification]
2	LG	-
3	B	-
4	Y	-

Connector No.	R6
Connector Name	ROOM LAMP
Connector Type	G02FW



0	2	1
---	---	---

Terminal Color Of No.	Wire	Signal Name [Specification]
1	Y	-
2	BR	-

WITHOUT INTELLIGENT KEY : Fail-safe

FAIL-SAFE CONTROL BY DTC
 BCM performs fail-safe control when any DTC are detected.

JRMWE7831GB
 INFOID:000000010244854

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal.

When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. Pass more than 1 minute after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

WITHOUT INTELLIGENT KEY : DTC Inspection Priority Chart

INFOID:000000010244855

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING
3	C1735: IGN CIRCUIT OPEN
4	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1729: VHCL SPEED SIG ERR

WITHOUT INTELLIGENT KEY : DTC Index

INFOID:000000010244856

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Tire pressure monitor warn- ing lamp ON	Reference
U1000: CAN COMM	—	—	BCS-120
U1010: CONTROL UNIT (CAN)	—	—	BCS-121
B2190: NATS ANTENNA AMP	×	—	SEC-197
B2191: DIFFERENCE OF KEY	×	—	SEC-200
B2192: ID DISCORD BCM-ECM	×	—	SEC-201
B2193: CHAIN OF BCM-ECM	×	—	SEC-202
B2195: ANTI SCANNING	×	—	SEC-203
C1704: LOW PRESSURE FL	—	×	WT-26
C1705: LOW PRESSURE FR	—	×	
C1706: LOW PRESSURE RR	—	×	
C1707: LOW PRESSURE RL	—	×	WT-28
C1708: [NO DATA] FL	—	×	
C1709: [NO DATA] FR	—	×	
C1710: [NO DATA] RR	—	×	
C1711: [NO DATA] RL	—	×	WT-31
C1716: [PRESS DATA ERR] FL	—	×	
C1717: [PRESS DATA ERR] FR	—	×	
C1718: [PRESS DATA ERR] RR	—	×	
C1719: [PRESS DATA ERR] RL	—	×	WT-33
C1729: VHCL SPEED SIG ERR	—	×	
C1735: IGN CIRCUIT OPEN	—	—	BCS-122

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:000000009945543

- The parking brake warning buzzer sounds continuously during vehicle travel though the parking brake is released.
- The parking brake warning buzzer does not sound at all even though driving the vehicle with the parking brake applied.

Diagnosis Procedure

INFOID:000000009945544

1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

When parking brake is applied : ON

When parking brake is released : OFF

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-93, "Removal and Installation"](#)
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Perform check for the parking brake switch signal circuit. Refer to [BRC-79, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK PARKING BRAKE SWITCH

Perform a unit check for the parking brake switch. Refer to [BRC-79, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-93, "Removal and Installation"](#)
NO >> Replace parking brake switch. Refer to [PB-4, "Exploded View"](#).

THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE LIGHT REMINDER WARNING DOES NOT SOUND

Description

INFOID:000000009945545

Light reminder warning chime does not sound even though headlamp is illuminated.

Diagnosis Procedure

INFOID:000000009945546

1. CHECK COMBINATION SWITCH (LIGHTING SWITCH) OPERATION

Check that the headlamps operate normally by operating the combination switch (lighting switch).

Do they operate normally?

YES >> GO TO 2.

NO >> Refer to [EXL-178, "Symptom Table"](#).

2. CHECK DRIVER SIDE DOOR SWITCH SIGNAL CIRCUIT

Perform the check for the driver side door switch signal circuit. Refer to [DLK-55, "Diagnosis Procedure"](#) (with Intelligent Key system) or [DLK-249, "Diagnosis Procedure"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK DRIVER SIDE DOOR SWITCH

Perform a unit check for the driver side door switch. Refer to [DLK-58, "Component Inspection"](#) (with Intelligent Key system) or [DLK-251, "Component Inspection"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-88, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-155, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Replace driver side door switch. Refer to [DLK-225, "Removal and Installation"](#) (with Intelligent Key system) or [DLK-378, "Removal and Installation"](#) (without Intelligent Key system).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:000000009945547

- Seat belt reminder warning does not sound.
- Seat belt reminder warning sounds continuously.

Diagnosis Procedure

INFOID:000000009945548

1. CHECK SEAT BELT WARNING LAMP

1. Turn ignition switch ON.
2. Check the operation of the seat belt warning lamp in the combination meter.

Seat belt (driver side) fastened : OFF

Seat belt (driver side) unfastened : ON

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK BCM OUTPUT SIGNAL

Check if the seat belt reminder warning chime is activated by performing BCM active test. Refer to [WCS-18, "BUZZER : CONSULT Function \(BCM - BUZZER\)"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3. CHECK COMBINATION METER INPUT SIGNAL

Check if buzzer switches to proper condition (On/Off) on data monitor of combination meter. Refer to [MWI-30, "CONSULT Function \(METER/M&A\)"](#).

Buzzer active condition : On

Buzzer non-active condition : Off

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-93, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-88, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-155, "Removal and Installation"](#) (without Intelligent Key system).

4. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

Perform the check for the seat belt buckle switch (driver side) circuit. Refer to [WCS-26, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Perform a unit check for the seat belt buckle switch (driver side). Refer to [WCS-27, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-93, "Removal and Installation"](#).

NO >> Replace seat belt buckle (driver side). Refer to [SB-8, "SEAT BELT BUCKLE : Removal and Installation"](#).

THE KEY WARNING DOES NOT SOUND (WITHOUT INTELLIGENT KEY)

< SYMPTOM DIAGNOSIS >

THE KEY WARNING DOES NOT SOUND (WITHOUT INTELLIGENT KEY)

Description

INFOID:000000009945549

The key warning chime does not sound, when all of the following conditions are fulfilled.

- Key inserted into the key cylinder (key switch signal ON).
- Ignition switch is in ACC or OFF (ignition switch signal OFF).
- Driver side door is open (driver side door switch ON)

Diagnosis Procedure

INFOID:000000009945550

1. CHECK BCM INPUT SIGNAL

1. Connect CONSULT.
2. Select the "Data Monitor" of "BCM (BUZZER)" and check the "KEY ON SW" monitor value. Refer to [WCS-20. "BUZZER : CONSULT Function \(BCM - BUZZER\)".](#)

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-155. "Removal and Installation".](#)
NO >> GO TO 2.

2. CHECK KEY SWITCH SIGNAL CIRCUIT

Check the key switch signal circuit. Refer to [DLK-267. "Diagnosis Procedure".](#)

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-155. "Removal and Installation".](#)
NO >> Check applicable parts, and repair or replace corresponding parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009945551

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing of Battery Terminal

INFOID:000000010244939

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

