

STR

SECTION STR
STARTING SYSTEM

CONTENTS

BASIC INSPECTION	2	STARTING SYSTEM	12
DIAGNOSIS AND REPAIR WORKFLOW	2	Wiring Diagram - STARTING SYSTEM (WITH INTELLIGENT KEY) -	12
Work Flow	2	Wiring Diagram - STARTING SYSTEM (WITHOUT INTELLIGENTKEY) -	16
SYSTEM DESCRIPTION	5		
STARTING SYSTEM	5	SYMPTOM DIAGNOSIS	20
M/T	5	STARTING SYSTEM	20
M/T : System Diagram	5	Symptom Table	20
M/T : System Description	5		
M/T : Component Parts Location	6	PRECAUTION	21
M/T : Component Description	6		
CVT	6	PRECAUTIONS	21
CVT : System Diagram (With Intelligent Key)	7	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	21
CVT : System Diagram (Without Intelligent Key)	7		
CVT : System Description (With Intelligent Key)	7	PREPARATION	22
CVT : System Description (Without Intelligent Key)	8		
CVT : Component Parts Location	8	PREPARATION	22
CVT : Component Description (With Intelligent Key)	8	Special Service Tools	22
CVT : Component Description (Without Intelligent Key)	9	Commercial Service Tools	22
DTC/CIRCUIT DIAGNOSIS	10	REMOVAL AND INSTALLATION	23
B TERMINAL CIRCUIT	10	STARTER MOTOR	23
Description	10	Exploded View	23
Diagnosis Procedure	10	Removal and Installation	24
S CONNECTOR CIRCUIT	11	Inspection	25
Description	11	SERVICE DATA AND SPECIFICATIONS (SDS)	26
Diagnosis Procedure	11		
		SERVICE DATA AND SPECIFICATIONS (SDS)	26
		Starter Motor	26

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005492258

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NOTE:

To ensure a complete and thorough diagnosis, the battery, starter motor and alternator test segments must be done as a set from start to finish.

1. DIAGNOSIS WITH STARTING/CHARGING SYSTEM TESTER

Perform the starting system test with Starting/Charging System Tester (SST: J-44373). For details and operating instructions, refer to Technical Service Bulletin.

STR

Test result

C

D

E

F

G

H

I

J

K

L

M

N

O

P

CRANKING VOLTAGE NORMAL>>GO TO 2.

CRANKING VOLTAGE LOW>>GO TO 5.

CHARGE BATTERY>>Perform the slow battery charging procedure. (Initial rate of charge is 10A for 12 hours.) Perform battery test again. Refer to Technical Service Bulletin.

REPLACE BATTERY>>Before replacing battery, clean the battery cable clamps and battery posts. Perform battery test again. Refer to Technical Service Bulletin. If second test result is "REPLACE BATTERY", then do so. Perform battery test again to confirm repair.

2. CRANKING CHECK

Check that the starter motor operates correctly.

Does the engine crank normally?

YES >> GO TO 3.

NO >> GO TO 4.

3. ENGINE START CHECK

Check that the engine starts.

Does the engine start?

YES >> Starter motor is OK. INSPECTION END

NO >> Starter motor is OK. Perform further diagnosis of engine mechanical or engine control system. Refer EM and EC sections. Once resolved, perform battery test again.

4. STARTER MOTOR ACTIVATION

Check that the starter motor operates.

Does the starter motor turn?

YES >> Check ring gear and starter motor drive pinion. Once resolved, perform battery test again.

NO >> GO TO 7.

5. COMPARISON BETWEEN ENGINE COOLANT AND CRANKING VOLTAGE

Compare the engine coolant temperature and the cranking voltage with the specifications.

Minimum Specification of Cranking Voltage Referencing Coolant Temperature

Engine coolant temperature [°C (°F)]	Voltage [V]
-30 to -20 (-22 to -4)	8.6
-19 to -10 (-2 to 14)	9.1
-9 to 0 (16 to 32)	9.5
More than 1 (More than 34)	9.9

Is the voltage less than the specified value?

YES >> GO TO 7.

NO >> GO TO 6.

6. STARTER OPERATION

Check the starter operation status.

Does the starter motor turn smoothly?

YES >> Starter motor is OK. INSPECTION END

NO >> GO TO 7.

7. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [STR-10, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 8.

NO >> Repair as needed.

8. "S" CONNECTOR CIRCUIT INSPECTION

Check "S" connector circuit. Refer to [STR-11, "Diagnosis Procedure"](#).

Is "S" connector circuit normal?

YES >> GO TO 9.

NO >> Repair as needed.

9. ENGINE ROTATION STATUS

Check that the engine can be rotated by hand.

Does the engine turn freely by hand?

YES >> Replace starter motor.

NO >> Perform further diagnosis of engine mechanical or powertrain mechanism. Once resolved, perform battery test again. Refer to Technical Service Bulletin.

STARTING SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

STARTING SYSTEM

M/T

A

M/T : System Diagram

STR

INFOID:000000005492259

C

D

E


F

G

H

I

J



K

L

M

N

O

P

M/T : System Description

INFOID:000000005492260


- When the clutch interlock switch is turned ON, power is supplied to starter control relay. And IPDM E/R (CPU) detect clutch interlock switch condition by the inputted signal.
- When starter operating condition is satisfied, IPDM E/R turns starter control relay ON by starter control relay control signal.
- When engine cranking condition is satisfied, then battery power is supplied to starter motor ("S" terminal) through starter control relay.

STARTING SYSTEM

< SYSTEM DESCRIPTION >

M/T : Component Parts Location

INFOID:000000005492261



JSBIA0050ZZ

1. IPDM E/R
Refer to [PCS-6, "Component Parts Location".\(WITH I-KEY\)](#)
Refer to [PCS-36, "Component Parts Location".\(WITHOUT I-KEY\)](#)
2. Starter motor
3. Clutch interlock switch
- A. Engine
- B. Clutch pedal
- ↖ :Vehicle front

M/T : Component Description

INFOID:000000005492262

Component part	Description
Clutch interlock switch	The switch turns ON and electric power is supplied to the starter control relay inside IPDM E/R when the clutch pedal is depressed.
IPDM E/R	CPU inside IPDM E/R controls the starter control relay.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.


CVT

STARTING SYSTEM

< SYSTEM DESCRIPTION >

CVT : System Diagram (With Intelligent Key)


INFOID:000000005492263



A
STR
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CVT : System Diagram (Without Intelligent Key)

INFOID:000000005492264



CVT : System Description (With Intelligent Key)

INFOID:000000005492265

- When selector lever is P or N, power is supplied to starter relay and starter control relay by Transmission range switch. And BCM and IPDM E/R (CPU) detect selector lever P/N condition by the inputted signal.

STARTING SYSTEM

< SYSTEM DESCRIPTION >

- When starter operating condition is satisfied, IPDM E/R turns starter control relay ON by starter control relay control signal.
- When engine cranking condition is satisfied, BCM turns starter relay ON by starter control relay control signal.
- Then battery power is supplied to starter motor ("S" terminal) through starter control relay and starter relay.


CVT : System Description (Without Intelligent Key)

INFOID:0000000005492266

- When selector lever is P or N, power is supplied to starter control relay by Transmission range switch. And IPDM E/R (CPU) detect selector lever P/N condition by the inputted signal.
- When engine cranking condition is satisfied, then battery power is supplied to starter motor ("S" terminal) through starter control relay.

CVT : Component Parts Location

INFOID:0000000005492267



1. BCM (Without Intelligent Key)
Refer to [BCS-87, "Component Parts Location"](#).
2. Transmission range switch
Refer to [TM-70, "Component Parts Location"](#).
3. IPDM E/R
Refer to [PCS-6, "Component Parts Location"](#).(With I Key)
Refer to [PCS-36, "Component Parts Location"](#).(Without I Key)
4. Starter motor
- A. Engine

⬅ :Vehicle front

CVT : Component Description (With Intelligent Key)

INFOID:0000000005492268

Component part	Description
Transmission range switch	Transmission range switch supplies power to the starter relay and starter control relay inside IPDM E/R when the selector lever is shifted to the P or N position.
BCM	BCM controls the starter relay inside IPDM E/R.
IPDM E/R	CPU inside IPDM E/R controls the starter control relay.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

STARTING SYSTEM

< SYSTEM DESCRIPTION >

CVT : Component Description (Without Intelligent Key)

INFOID:000000005492269

A

Component part	Description
Transmission range switch	Transmission range switch supplies power to the starter relay inside IPDM E/R when the selector lever is shifted to the P or N position.
IPDM E/R	CPU inside IPDM E/R controls the starter control relay.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B TERMINAL CIRCUIT

Description

INFOID:000000005492270

The "B" terminal is constantly supplied with battery power.

Diagnosis Procedure

INFOID:000000005492271

CAUTION:

Perform diagnosis under the condition that engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

1.CHECK "B" TERMINAL CIRCUIT

1. Turn ignition switch OFF.
2. Check that starter motor "B" terminal connection is clean and tight.
3. Check voltage between starter motor "B" terminal and ground.

Terminals		(-)	Voltage (Approx.)
(+)	Terminal		
Starter motor "B" terminal	F11	2	Ground
			Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check harness between battery and starter motor for open circuit.

2.CHECK BATTERY CABLE CONNECTION STATUS (VOLTAGE DROP TEST)

1. Shift CVT selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
2. Check voltage between battery positive terminal and starter motor "B" terminal.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Starter motor "B" terminal	Terminal		
Battery positive terminal	F11	2	When the ignition switch is in START position Less than 0.5 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check harness between the battery and the starter motor for poor continuity.

3.CHECK GROUND CIRCUIT STATUS (VOLTAGE DROP TEST)

1. Shift CVT selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
2. Check voltage between starter motor case and battery negative terminal.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Starter motor case	Battery negative terminal	When the ignition switch is in START position	Less than 0.2 V

Is the inspection result normal?

- YES >> "B" terminal circuit is OK. Further inspection is necessary. Refer to [STR-2, "Work Flow"](#).
NO >> Check the starter motor case and ground for poor continuity.

S CONNECTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

S CONNECTOR CIRCUIT

Description

INFOID:0000000005492272

A

The starter motor magnetic switch is supplied with power when the ignition switch is turned to the START position while the selector lever is in the P or N position for CVT models or the clutch pedal is depressed for M/T models.

STR

Diagnosis Procedure

INFOID:0000000005492273

C

CAUTION:

Perform diagnosis under the condition that engine cannot start by the following procedure.

D

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

E

1.CHECK "S" CONNECTOR CIRCUIT

F

1. Turn ignition switch OFF.
2. Disconnect starter motor connector.
3. Shift CVT selector lever to "P" or "N" position. (CVT models)
Keep depressing clutch pedal fully. (M/T models)
4. Check voltage between starter motor harness connector and ground.

G

Terminals		Condition	Voltage (Approx.)	
(+)	(-)			
Starter motor harness connector	Terminal			
F10	1	Ground	When the ignition switch is in START position	Battery voltage

H

Is the inspection result normal?

I

J

YES >> "S" connector circuit is OK. Further inspection is necessary. Refer to [STR-2, "Work Flow"](#).

K

NO >> GO TO 2.

L

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

M

1. Disconnect IPDM E/R connector.
2. Check continuity between starter motor harness connector and IPDM E/R harness connector.

N

Starter motor harness connector		IPDM E/R harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
F10	1	E10	3	Existed

O

Is the inspection result normal?

P

YES >> Further inspection is necessary. Refer to [STR-2, "Work Flow"](#).

NO >> Repair the harness.

STARTING SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

STARTING SYSTEM

Wiring Diagram - STARTING SYSTEM (WITH INTELLIGENT KEY) -

INFOID:0000000005492274

STARTING SYSTEM (WITH INTELLIGENT KEY)



2009/02/27


JCBWM1301GE

STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

STARTING SYSTEM (WITH INTELLIGENT KEY)


Connector No.	EB	44 R	-
Connector Name	WIRE TO WIRE	46 W	-
Connector Type	SAA36WB-RS10-Su2Z	47 G	-
		48 BR	-



Connector No.	E10	17 []	16 []
Connector Name	SPDR E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	20 []	15 []
Connector Type	MOB1W-LC	21 []	19 []



Connector No.	E12	17 []	16 []
Connector Name	SPDR E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	20 []	15 []
Connector Type	NSD16BR-CS	21 []	19 []



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-	18	Y	-
2	LG	-	19	B/W	-
3	Y	-	20	W	-
4	W	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
32	O	-	43	R	-
33	W	-	43	R	-
34	Y	-	43	R	-
35	V	-	43	R	-
36	P	-	43	R	-
37	LG	-	43	R	-
38	SB	-	43	R	-
40	GR	-	43	R	-
41	O	-	43	R	-
42	V	-	43	R	-
43	R	-	43	R	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-	18	Y	-
4	SB	-	19	B/W	-
5	LG	-	20	W	-
6	SB	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
32	O	-	43	R	-
33	W	-	43	R	-
34	Y	-	43	R	-
35	V	-	43	R	-
36	P	-	43	R	-
37	LG	-	43	R	-
38	SB	-	43	R	-
40	GR	-	43	R	-
41	O	-	43	R	-
42	V	-	43	R	-
43	R	-	43	R	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-	18	Y	-
4	SB	-	19	B/W	-
5	LG	-	20	W	-
6	SB	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
32	O	-	43	R	-
33	W	-	43	R	-
34	Y	-	43	R	-
35	V	-	43	R	-
36	P	-	43	R	-
37	LG	-	43	R	-
38	SB	-	43	R	-
40	GR	-	43	R	-
41	O	-	43	R	-
42	V	-	43	R	-
43	R	-	43	R	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-	18	Y	-
4	SB	-	19	B/W	-
5	LG	-	20	W	-
6	SB	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
32	O	-	43	R	-
33	W	-	43	R	-
34	Y	-	43	R	-
35	V	-	43	R	-
36	P	-	43	R	-
37	LG	-	43	R	-
38	SB	-	43	R	-
40	GR	-	43	R	-
41	O	-	43	R	-
42	V	-	43	R	-
43	R	-	43	R	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-	18	Y	-
4	SB	-	19	B/W	-
5	LG	-	20	W	-
6	SB	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
32	O	-	43	R	-
33	W	-	43	R	-
34	Y	-	43	R	-
35	V	-	43	R	-
36	P	-	43	R	-
37	LG	-	43	R	-
38	SB	-	43	R	-
40	GR	-	43	R	-
41	O	-	43	R	-
42	V	-	43	R	-
43	R	-	43	R	-


Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-	18	Y	-
4	SB	-	19	B/W	-
5	LG	-	20	W	-
6	SB	-	21	W	-
7	Y	-	22	V	-
8	SB	-	23	V	-
9	L	-	24	P	-
10	V	-	25	GR	-
11	P	-	26	GR	-
12	BR	-	27	R	-
13	LG	-	28	R	-
14	Y	-	29	Y	-
15	SB	-	30	Y	-
16	L	-	31	W	-
17	W	-	32	W	-
18	O	-	33	O	-
21	G	-	34	R	-
23	SB	-	35	R	-
24	W	-	36	P	-
25	BR	-	37	LG	-
26	B	-	38	SB	-
27	GR	-	40	GR	-
28	P	-	41	O	-
29	V	-	42	V	-
30	G	-	43	R	-
31	G	-	43	R	-
3					

STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

STARTING SYSTEM (WITH INTELLIGENT KEY)

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No	Color of Wire	Signal Name [Specification]
1	V	-
2	W	-

- 1 -

Connector No.	F11
Connector Name	STARTER MOTOR
Connector Type	-



Terminal No.	Color of Wire	Signal Name [Specification]
2	B/R	-

Connector No.	FZ1
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	RK08FG



Terminal No.	Color	Signal Name [Specification]
No. of Wires		
1	V	-
2	BR	-
3	R	-
4	GR	-
5	SB	-
6	W	-
7	Y	-
8	G	-

51 B - [With M/T]

1		Terminal No.		Color of Wire	Signal Name [Specification]
		1	R		
53	SB	-	-	SB	-
54	W	-	-	[With CXT]	[With M.T.]
54	O	-	-	[With M.T.]	-
57	LG	-	-	-	-
59	L	-	-	R	-
60	O	-	-	Y	-
61	G	-	-	V	-
62	W	-	-	G	-
63	L	-	-	G	-
67	GR	-	-	SB	-
67	V	-	-	[With CXT]	[With M.T.]
67	G	-	-	-	-



STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

STR

C

D

E

F

G

H

I

J

M


Z

O

P

STARTING SYSTEM (WITH INTELLIGENT KEY)

Connector No.	Connected No.	Color	Wire to Wire
MT1	M77	R	73
Connector Name	BCM (BODY CONTROL MODULE)	L'Y	74
Connector Type	TH46FW-NH	W/G	76



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal Color No.	Color Name [Specification]
71	R	TIRE PRESS RECEIVER COMM	1	B/O
72	R/W	DR/LOCK ACT RELAY CONT	2	R
75	SB	DRIVER DOOR REQUEST SW	3	G/R
76	G	PASSENGER DOOR REQUEST SW	4	G/B
77	W	BACK DOOR REQUEST SW	5	L
78	LG	DRIVER DOOR ANT+	6	L
79	V	DRIVER DOOR ANT-	7	W/R
80	BR/Y	PASSENGER DOOR ANT+	8	G/W
81	L'Y	PASSENGER DOOR ANT-	9	Y/L
82	W/B	BACK DOOR ANT+	10	W
83	B/W	BACK DOOR ANT-	21	G/R/L
84	Y/G	ROOM ANT+	32	L/B
85	Y/L	ROOM ANT-	33	R/Y
86	P	LUGGAGE ROOM ANT+	34	SB
87	L	LUGGAGE ROOM ANT-	35	BR
89	W/L	PUSH-BUTTON IGNITION SW/L POWER	36	G
91	Y	ACC/ON/IND	37	L/R
92	BR/R	PUSH-BUTTON IGNITION SW/L GND	44	G/O
93	GR/W	I-KEY WARN BUZZER	45	L/G/R
94	Y/R	S/L UNIT COMM	46	G/R/W
95	W/G	S/L UNIT POWER SUPPLY	47	B/Y
96	G	ACC RELAY CONT	48	L/O
97	L/R	STARTER RELAY CONT	49	L/W
98	BR	IGN RELAY (P/D/E/R) CONT	50	P/L
99	W/R	IGN RELAY CONT	51	B/W
100	L/O	PUSH SW	53	R/L
102	G	SHIFT N/P	54	O
104	Y/R	CVT SHIFT SELECTOR POWER SUPPLY	57	G/R
105	B/O	STOP LAMP SW 2	59	Y
106	Y/B	BLOWER FAN MOTOR RELAY CONT	60	R/W
107	L/W	S/L CONDITION I	61	V/W
108	P/L	S/L CONDITION 2	62	W/L
109	BR/W	TIRE PRESS POWER SUPPLY	63	W/B
110	P/L	SHEILD	67	Y/R
			69	G
			70	P/B
			72	R/G

JCBWM1613Gf


STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

Wiring Diagram - STARTING SYSTEM (WITHOUT INTELLIGENTKEY) -

INFOID:000000005492275

STARTING SYSTEM (WITHOUT INTELLIGENT KEY)



2009/02/27

JCBWM1304GE

STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

STR

C

D

M

G

I

—

—

X


Z

O

P

STARTING SYSTEM (WITHOUT INTELLIGENT KEY)

Connector No.	E8	44 R	—
Connector Name	WIRE TO WIRE	46 W	—
Connector Type	SAA36WB-RS10-Su2Z	47 G	—
		48 BR	—



Terminal Color No. Signal Name [Specification]

1	BR	—	—
2	LG	—	—
3	Y	—	—
4	W	—	—
7	Y	—	—
8	SB	—	—
9	L	—	—
10	V	—	—
11	P	—	—
12	BR	—	—
13	LG	—	—
14	Y	—	—
15	SB	—	—
16	L	—	—
17	W	—	—
18	O	—	—
21	G	—	—
23	SB	—	—
24	W	—	—
25	BR	—	—
26	B	—	—
27	GR	—	—
28	P	—	—
29	V	—	—
30	G	—	—
31	G	—	—
32	O	—	—
33	W	—	—
34	Y	—	—
35	V	—	—
36	P	—	—
37	LG	—	—
39	SB	—	—
40	GR	—	—
41	O	—	—
42	V	—	—
43	R	— [With CVT]	— [With M/T]
43	LG	—	—



Terminal Color No. Signal Name [Specification]

19	20	21	22	23	24	25
26	27	28	29	30	31	32
33	34	35	36	37	38	39
40	41	42	43	44	45	46



20	21	22	23	24	25	26
27	28	29	30	31	32	33
34	35	36	37	38	39	40
41	42	43	44	45	46	47

Terminal Color No. Signal Name [Specification]

17	18	19	20	21	22	23
24	25	26	27	28	29	30
31	32	33	34	35	36	37
38	39	40	41	42	43	44

Terminal Color No. Signal Name [Specification]

16	17	18	19	20	21	22
23	24	25	26	27	28	29
30	31	32	33	34	35	36
37	38	39	40	41	42	43

Terminal Color No. Signal Name [Specification]

15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35
36	37	38	39	40	41	42

Terminal Color No. Signal Name [Specification]

14	15	16	17	18	19	20
21	22	23	24	25	26	27
28	29	30	31	32	33	34
35	36	37	38	39	40	41

Terminal Color No. Signal Name [Specification]

13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30	31	32	33
34	35	36	37	38	39	40

Terminal Color No. Signal Name [Specification]

12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30	31	32
33	34	35	36	37	38	39

Terminal Color No. Signal Name [Specification]

11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31
32	33	34	35	36	37	38

Terminal Color No. Signal Name [Specification]

10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31	32	33	34	35	36	37

Terminal Color No. Signal Name [Specification]

9	10	11	12	13	14	15
16	17	18	19	20	21	22
23	24	25	26	27	28	29
30	31	32	33	34	35	36

Terminal Color No. Signal Name [Specification]

8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
31	32	33	34	35	36	37

Terminal Color No. Signal Name [Specification]

7	8	9	10	11	12	13
14	15	16	17	18	19	20
21	22	23	24	25	26	27
30	31	32	33	34	35	36

Terminal Color No. Signal Name [Specification]

6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
31	32	33	34	35	36	37

Terminal Color No. Signal Name [Specification]

5	6	7	8	9	10	11
12	13	14	15	16	17	18
23	24	25	26	27	28	29
30	31	32	33	34	35	36

Terminal Color No. Signal Name [Specification]

4	5	6	7	8	9	10
11	12	13	14	15	16	17
22	23	24	25	26	27	28
29	30	31	32	33	34	35

Terminal Color No. Signal Name [Specification]

3	4	5	6	7	8	9
10	11	12	13	14	15	16
21	22	23	24	25	26	27
28	29	30	31	32	3	

STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

STARTING SYSTEM (WITHOUT INTELLIGENT KEY)

Connector No.	E106	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE	70	SHIELD	-	46	GR	-
Connector Name	TH8DMW-CS16-TM4	71	GR	-	47	Y	-
Connector Type	SAAB-RS10-SUZ2	72	LG	-	48	BR	-
		73	P	-			
		74	V	-			
		76	Y	-			
		77	LG	-			
		78	O	-			
		79	G	-			
		80	P	-			
		81	L	-			
		82	W	-			
		83	BR	-			
		84	B	-	1	SB	-
		87	GR	-	2	LG	-
		91	W	-	3	R	-
		92	Y	-	4	Y	-
		93	Y	-	7	V	-
		94	R	-	8	G	-
		95	V	-	9	SB	-
		96	LG	-	10	L	-
		97	R	-	11	Y	-
		98	SB	-	12	GR	-
		99	G	-	13	BR	-
		100	P	-	14	G	-
		102	R	-	15	W	-
		133	GR	-	16	Y	-
		34	P	-	17	P	-
		35	Y	-	18	BR	-
		36	BR	-	21	G	-
		39	SB	-	23	W	-
		44	R	-	24	R	-
		45	V	-	25	R	-
		46	P	-	26	B	-
		47	W	-	27	SB	-
		48	L	-	28	V	-
		49	Y	-	29	V	-
		50	W	-	30	BR	-
		51	BR	- [With CVT]	31	GR	-
		53	SB	- [With M/T]	32	BR	-
		54	W	- [With CVT]	33	W	-
		54	O	- [With M/T]	34	LG	-
		57	LG	-	35	V	-
		59	L	-	36	Y	-
		60	O	-	37	W	-
		61	G	-	39	G	-
		62	W	-	40	P	-
		63	L	-	41	O	-
		67	GR	- [With CVT]	42	G	-
		67	V	- [With M/T]	43	R	-
		69	P	-	44	P	-

JCBWM1615Gf

STARTING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

STARTING SYSTEM (WITHOUT INTELLIGENT KEY)

Connector No.	F21	Connector No.	M77
Connector Name	TRANSMISSION RANGE SWITCH	Connector Name	WIRE TO WIRE
Connector Type	RK0DFG	Connector Type	TH80FW-CS16-TM4
			

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-	1	Br/O	-
2	BR	-	2	R	-
3	R	-	3	Gr/R	-
4	GR	-	4	Gr/B	-
5	SB	-	5	L	-
6	W	-	6	1	-
7	Y	-	7	W/R	-
8	G	-	8	Gr/W	-
			9	Y/L	-
			10	W	-
			31	Gr/L	-
			32	L/B	-
			33	RY	-
			34	SB	-
			35	BR	-
			36	G	-
			39	L/R	-
			44	GO	-
			45	LG/R	-
			46	GR/W	-
			47	BR/Y	-
			48	L/O	-
			49	L/W	-
			50	P/L	-
1	L	-	51	Br/W	-
2	G	-	53	RL/L	-
3	W/R	-	54	O	-
4	Y/B	-	57	GR	-
5	W	-	59	Y	-

Connector No.	M29	Connector Name	IGNITION SWITCH
Connector Name		Connector Type	MD80FW-LC
Connector Type			

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	G	-
3	W/R	-
4	Y/B	-
5	W	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	WB	-
3	Y/R	-
4	LG	-
5	SFIELD	-
6	P/B	-
7	RG	-

JCBWM1616Gf

STARTING SYSTEM

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

STARTING SYSTEM

Symptom Table

INFOID:000000005492276

Symptom	Reference
No normal cranking	Refer to STR-2, "Work Flow".
Starter motor does not rotate	

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005492277

STR

A

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

C

D

E

F

G

H

I

J

K

L

M

N

O

P

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Special Service Tools

INFOID:000000005492278

Tool number (Kent-Moore No.) Tool name	Description
— (J-44373 Model MCR620) Starting/Charging System Tester	 SEL403X Tests starting and charging systems. For operating instructions, refer to Technical Service Bulletin.

Commercial Service Tools

INFOID:000000005492279

Tool name	Description
Power tool	 PIIB1407E Loosening bolts, nuts and screws

STARTER MOTOR

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION STARTER MOTOR

Exploded View

INFOID:000000005492280

STR

REMOVAL



1. "S" terminal harness
2. "B" terminal harness
3. Starter motor
4. Cylinder block

↙: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

DISASSEMBLY

STARTER MOTOR

< REMOVAL AND INSTALLATION >

Type: S114-902



- 1. Magnetic switch assembly
- 2. Dust cover kit
- 3. Shift lever set
- 4. Center bracket (A)
- 5. Yoke assembly
- 6. Armature assembly
- 7. Brush holder assembly
- 8. Thrust washer
- 9. Rear cover assembly
- 10. Internal gear
- 11. Planetary gear
- 12. Pinion shaft
- 13. Packing
- 14. Thrust washer
- 15. Center bracket (P)
- 16. E-ring
- 17. Pinion assembly
- 18. Pinion stopper
- 19. Pinion stopper clip
- 20. Gear case assembly

: High-temperature grease point

Refer to [GI-4, "Components"](#) for symbols not described on the above.

NOTE:

Apply high-temperature grease to lubricate the bearing, gears and frictional surface when assembling the starter.

Removal and Installation

INFOID:000000005492281

REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove air duct (inlet). Refer to [EM-24, "Exploded View"](#).
3. Remove radiator reservoir tank.
4. Disconnect oil pressure switch connector.
5. Remove "B" terminal nut and "B" terminal harness.
6. Remove "S" terminal nut and "S" terminal harness.
7. Remove starter motor mounting bolts.
8. Remove starter motor upward from the vehicle.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to tighten "B" terminal nut carefully.

STARTER MOTOR

< REMOVAL AND INSTALLATION >

Inspection

INFOID:000000005492282

A

INSPECTION AFTER DISASSEMBLY

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Starter Motor

INFOID:000000005492283

Type		S114-902
		HITACHI make
		Reduction gear type
System voltage	[V]	12
No-load	Terminal voltage [V]	11
	Current [A]	Less than 110
	Revolution [rpm]	More than 3,000
Minimum diameter of commutator	[mm (in)]	28.0 (1.102)
Minimum length of brush	[mm (in)]	10.5 (0.413)
Brush spring tension	[N (kg, lb)]	16.2 (1.65, 3.6)
Clearance between bearing metal and armature shaft	[mm (in)]	Less than 0.2 (0.008)
Clearance between pinion front edge and pinion stopper	[mm (in)]	0.3 - 2.5 (0.012 – 0.098)