

SECTION **BRC**

BRAKE CONTROL SYSTEM

A
B
C
D
E

CONTENTS

| | | |
|--|----|--|
| VDC/TCS/ABS | | |
| BASIC INSPECTION | 4 | |
| DIAGNOSIS AND REPAIR WORKFLOW | 4 | |
| Work Flow | 4 | |
| Diagnostic Work Sheet | 7 | |
| ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 8 | |
| Description | 8 | |
| Special Repair Requirement | 8 | |
| ADJUSTMENT OF STEERING ANGLE SEN- SOR NEUTRAL POSITION | 9 | |
| Description | 9 | |
| Special Repair Requirement | 9 | |
| SYSTEM DESCRIPTION | 11 | |
| VDC | 11 | |
| System Diagram | 11 | |
| System Description | 11 | |
| Component Parts Location | 12 | |
| Component Description | 13 | |
| TCS | 14 | |
| System Diagram | 14 | |
| System Description | 14 | |
| Component Parts Location | 15 | |
| Component Description | 16 | |
| ABS | 17 | |
| System Diagram | 17 | |
| System Description | 17 | |
| Component Parts Location | 18 | |
| Component Description | 19 | |
| EBD | 20 | |
| System Diagram | 20 | |
| System Description | 20 | |
| Component Parts Location | 21 | |
| Component Description | 22 | |
| DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)] | 23 | |
| CONSULT Function | 23 | |
| DTC/CIRCUIT DIAGNOSIS | 28 | |
| C1101, C1102, C1103, C1104 WHEEL SEN- SOR | 28 | |
| Description | 28 | |
| DTC Logic | 28 | |
| Diagnosis Procedure | 28 | |
| Special Repair Requirement | 30 | |
| C1105, C1106, C1107, C1108 WHEEL SEN- SOR | 31 | |
| Description | 31 | |
| DTC Logic | 31 | |
| Diagnosis Procedure | 31 | |
| Special Repair Requirement | 35 | |
| C1109 POWER AND GROUND SYSTEM | 36 | |
| Description | 36 | |
| DTC Logic | 36 | |
| Diagnosis Procedure | 36 | |
| Special Repair Requirement | 37 | |
| C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 38 | |
| DTC Logic | 38 | |
| Diagnosis Procedure | 38 | |
| Special Repair Requirement | 38 | |
| C1111 ABS MOTOR, MOTOR RELAY SYS- TEM | 39 | |
| Description | 39 | |
| DTC Logic | 39 | |
| Diagnosis Procedure | 39 | |
| Special Repair Requirement | 40 | |

BRC

G
H
I
J
K
L
M
N
O
P

| | | | |
|---|-----------|---|-----------|
| C1115 WHEEL SENSOR | 41 | C1155 BRAKE FLUID LEVEL SWITCH | 67 |
| Description | 41 | Description | 67 |
| DTC Logic | 41 | DTC Logic | 67 |
| Diagnosis Procedure | 41 | Diagnosis Procedure | 67 |
| Special Repair Requirement | 45 | Component Inspection | 69 |
| C1116 STOP LAMP SWITCH | 46 | Special Repair Requirement | 69 |
| Description | 46 | C1164, C1165 CV SYSTEM | 70 |
| DTC Logic | 46 | Description | 70 |
| Diagnosis Procedure | 46 | DTC Logic | 70 |
| Component Inspection | 49 | Diagnosis Procedure | 70 |
| Special Repair Requirement | 50 | Special Repair Requirement | 71 |
| C1120, C1122, C1124, C1126 IN ABS SOL | 51 | C1166, C1167 SV SYSTEM | 72 |
| Description | 51 | Description | 72 |
| DTC Logic | 51 | DTC Logic | 72 |
| Diagnosis Procedure | 51 | Diagnosis Procedure | 72 |
| Special Repair Requirement | 52 | Special Repair Requirement | 73 |
| C1121, C1123, C1125, C1127 OUT ABS SOL.. | 53 | U1000 CAN COMM CIRCUIT | 74 |
| Description | 53 | Description | 74 |
| DTC Logic | 53 | DTC Logic | 74 |
| Diagnosis Procedure | 53 | Diagnosis Procedure | 74 |
| Special Repair Requirement | 54 | Special Repair Requirement | 74 |
| C1130 ENGINE SIGNAL | 55 | U1002 SYSTEM COMM (CAN) | 75 |
| Description | 55 | Description | 75 |
| DTC Logic | 55 | DTC Logic | 75 |
| Diagnosis Procedure | 55 | Diagnosis Procedure | 75 |
| Special Repair Requirement | 55 | Special Repair Requirement | 76 |
| C1140 ACTUATOR RELAY SYSTEM | 57 | POWER SUPPLY AND GROUND CIRCUIT | 77 |
| Description | 57 | Description | 77 |
| DTC Logic | 57 | Diagnosis Procedure | 77 |
| Diagnosis Procedure | 57 | PARKING BRAKE SWITCH | 79 |
| Special Repair Requirement | 58 | Description | 79 |
| C1142 PRESS SENSOR | 59 | Diagnosis Procedure | 79 |
| Description | 59 | Component Inspection | 79 |
| DTC Logic | 59 | VDC OFF SWITCH | 81 |
| Diagnosis Procedure | 59 | Description | 81 |
| Special Repair Requirement | 60 | Diagnosis Procedure | 81 |
| C1143 STEERING ANGLE SENSOR | 61 | Component Inspection | 82 |
| Description | 61 | Special Repair Requirement | 82 |
| DTC Logic | 61 | ABS WARNING LAMP | 83 |
| Diagnosis Procedure | 61 | Description | 83 |
| Special Repair Requirement | 62 | Component Function Check | 83 |
| C1144 INCOMPLETE STEERING ANGLE | | Diagnosis Procedure | 83 |
| SENSOR ADJUSTMENT | 63 | Special Repair Requirement | 83 |
| Description | 63 | BRAKE WARNING LAMP | 84 |
| DTC Logic | 63 | Description | 84 |
| Diagnosis Procedure | 63 | Component Function Check | 84 |
| Special Repair Requirement | 63 | Diagnosis Procedure | 84 |
| C1145, C1146 YAW RATE/SIDE G SENSOR... | 64 | Special Repair Requirement | 84 |
| Description | 64 | VDC OFF INDICATOR LAMP | 86 |
| DTC Logic | 64 | Description | 86 |
| Diagnosis Procedure | 64 | Component Function Check | 86 |
| Special Repair Requirement | 66 | | |

| | | | | |
|--|------------|---|------------|-----|
| Diagnosis Procedure | 86 | Precaution for Brake Control | 103 | |
| Special Repair Requirement | 86 | Precautions for Harness Repair | 103 | A |
| VDC WARNING LAMP | 87 | PREPARATION | 105 | |
| Description | 87 | PREPARATION | 105 | B |
| Component Function Check | 87 | Commercial Service Tools | 105 | |
| Diagnosis Procedure | 87 | REMOVAL AND INSTALLATION | 106 | C |
| Special Repair Requirement | 87 | WHEEL SENSOR | 106 | |
| ECU DIAGNOSIS INFORMATION | 88 | FRONT WHEEL SENSOR | 106 | D |
| ABS ACTUATOR AND ELECTRIC UNIT | | FRONT WHEEL SENSOR : Exploded View | 106 | |
| (CONTROL UNIT) | 88 | FRONT WHEEL SENSOR : Removal and Instal- | 106 | E |
| Reference Value | 88 | lation | 106 | |
| Wiring Diagram | 92 | REAR WHEEL SENSOR | 107 | |
| Fail-Safe | 92 | REAR WHEEL SENSOR : Exploded View | 107 | |
| DTC Inspection Priority Chart | 93 | REAR WHEEL SENSOR : Removal and Installa- | 107 | BRC |
| DTC Index | 94 | tion | 107 | |
| SYMPTOM DIAGNOSIS | 95 | SENSOR ROTOR | 108 | |
| EXCESSIVE ABS FUNCTION OPERATION | | FRONT SENSOR ROTOR | 108 | G |
| FREQUENCY | 95 | FRONT SENSOR ROTOR : Removal and Instal- | 108 | |
| Diagnosis Procedure | 95 | lation | 108 | H |
| UNEXPECTED PEDAL REACTION | 96 | FRONT SENSOR ROTOR : Disassembly and As- | 108 | |
| Diagnosis Procedure | 96 | sembly | 108 | |
| THE BRAKING DISTANCE IS LONG | 97 | REAR SENSOR ROTOR | 108 | I |
| Diagnosis Procedure | 97 | REAR SENSOR ROTOR : Removal and Installa- | 108 | |
| ABS FUNCTION DOES NOT OPERATE | 98 | tion | 108 | J |
| Diagnosis Procedure | 98 | REAR SENSOR ROTOR : Disassembly and As- | 108 | |
| PEDAL VIBRATION OR ABS OPERATION | | sembly | 108 | |
| SOUND OCCURS | 99 | ABS ACTUATOR AND ELECTRIC UNIT | | K |
| Diagnosis Procedure | 99 | (CONTROL UNIT) | 109 | |
| VEHICLE JERKS DURING VDC/TCS/ABS | | Exploded View | 109 | |
| CONTROL | 100 | Removal and Installation | 109 | L |
| Diagnosis Procedure | 100 | Adjustment | 110 | |
| NORMAL OPERATING CONDITION | 101 | YAW RATE/SIDE G SENSOR | 111 | |
| Description | 101 | Exploded View | 111 | M |
| PRECAUTION | 102 | Removal and Installation | 111 | |
| PRECAUTIONS | 102 | STEERING ANGLE SENSOR | 112 | |
| Precaution for Supplemental Restraint System | | Exploded View | 112 | N |
| (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | | Removal and Installation | 112 | |
| SIONER" | 102 | Adjustment | 112 | |
| Precaution for Procedure without Cowl Top Cover. | 102 | VDC OFF SWITCH | 113 | O |
| Precaution for Brake System | 102 | Removal and Installation | 113 | |
| | | | | P |

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000008452613

PRECAUTIONS FOR DIAGNOSIS


If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-9, "Description"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

OVERALL SEQUENCE



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis work sheet. Refer to [BRC-7, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

2. PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is there any DTC displayed?

- YES >> Record or print self-diagnosis results and freeze frame data (FFD). GO TO 3.
- NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC for "ABS" with CONSULT. Refer to [BRC-94, "DTC Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-101, "Description"](#).

Is the symptom a normal operation?

- YES >> INSPECTION END
- NO >> GO TO 5.

5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: refer to [BRC-83, "Description"](#).
- Brake warning lamp: refer to [BRC-84, "Description"](#).
- VDC OFF indicator lamp: refer to [BRC-86, "Description"](#).
- VDC warning lamp: refer to [BRC-87, "Description"](#).

Is ON/OFF timing normal?

- YES >> GO TO 6.
- NO >> GO TO 2.

6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom for "ABS" with CONSULT.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT.

>> GO TO 9.

9. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

- YES >> INSPECTION END
- NO >> GO TO 3.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Diagnostic Work Sheet

INFOID:000000008452614

| | | | |
|---------------------------|---|---|---|
| Customer name MR/MS | Model & Year | VIN | |
| Engine # | Trans. | Mileage | |
| Incident Date | Manuf. Date | In Service Date | |
| Symptoms | <input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle) | <input type="checkbox"/> Warning / Indicator activate | <input type="checkbox"/> Firm pedal operation Large stroke pedal operation |
| | <input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating) | <input type="checkbox"/> ABS does not work (Wheels lock when braking) | <input type="checkbox"/> Lack of sense of acceleration |
| Engine conditions | <input type="checkbox"/> When starting <input type="checkbox"/> After starting | | |
| Road conditions | <input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes | | |
| Driving conditions | <input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped | | |
| Applying brake conditions | <input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually | | |
| Other conditions | <input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions | | |

SFIA3265E

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< BASIC INSPECTION >

[VDC/TCS/ABS]

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000008452615

After replacing the ABS actuator and electric unit (control unit), perform the neutral position adjustment for the steering angle sensor.

Special Repair Requirement

INFOID:000000008452616

1.PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-9. "Special Repair Requirement"](#).

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[VDC/TCS/ABS]

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Description

INFOID:000000008452617

When doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

×: Required –: Not required

| Situation | Adjustment of steering angle sensor neutral position |
|---|--|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | × |
| Removing/Installing steering angle sensor | × |
| Replacing steering angle sensor | × |
| Removing/Installing steering components | × |
| Replacing steering components | × |
| Removing/Installing suspension components | × |
| Replacing suspension components | × |
| Removing/Installing tire | — |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | × |

Special Repair Requirement

INFOID:000000008452618

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

To adjust neutral position of steering angle sensor, make sure to use CONSULT.
(Adjustment cannot be done without CONSULT.)

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT.
2. Select "START".

CAUTION:

Never touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT, and check steering angle sensor signal.

STR ANGLE SIG : 0±2.5°

Is the steering angle within the specified range?

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[VDC/TCS/ABS]

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT. Refer to [BRC-23. "CONSULT Function"](#).

Are the memories erased?

YES >> INSPECTION END


NO >> Check the items indicated by the self-diagnosis.

SYSTEM DESCRIPTION

VDC

System Diagram

INFOID:000000008452619




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

System Description

INFOID:000000008452620

- Vehicle Dynamics Control system detects driver's steering operation amount and brake pedal travel from steering angle sensor and pressure sensor. Using information from yaw rate/side G sensor and wheel sensor, VDC judges driving condition (conditions of under steer and over steer) to improve vehicle driving stability by controlling brake application to 4 wheels and engine output.
- During VDC operation, it informs driver of system operation by flashing VDC warning lamp.
- Electrical system diagnosis by CONSULT is available.



- | | | |
|---|----------------------------------|---|
| 1. ABS actuator and electric unit (control unit) | 2. Front wheel sensor | 3. Steering angle sensor |
| 4. Yaw rate/side G sensor | 5. Rear wheel sensor | |
| A. Engine room right side | B. Steering knuckle | C. VDC OFF switch: IP-12, "Exploded View" |
| D. ABS warning lamp, brake warning lamp, VDC OFF indicator lamp, VDC warning lamp: MWI-6, "METER SYSTEM : System Description" | E. Back of spiral cable assembly | F. Under front (left side) seat |
| G. Rear axle | | |

Component Description

INFOID:000000008452622

| Component parts | | Reference |
|---|---------------------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-39, "Description" |
| | Motor | |
| | Actuator relay (main relay) | BRC-57, "Description" |
| | Solenoid valve | BRC-51, "Description" |
| | Pressure sensor | BRC-59, "Description" |
| | VDC switch-over valve (CV1, CV2) | BRC-70, "Description" |
| | VDC switch-over valve (SV1, SV2) | BRC-72, "Description" |
| Wheel sensor | BRC-28, "Description" | |
| Yaw rate/side G sensor | BRC-64, "Description" | |
| Steering angle sensor | BRC-61, "Description" | |
| VDC OFF switch | BRC-81, "Description" | |
| ABS warning lamp | BRC-83, "Description" | |
| Brake warning lamp | BRC-84, "Description" | |
| VDC OFF indicator lamp | BRC-86, "Description" | |
| VDC warning lamp | BRC-87, "Description" | |


A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

TCS

System Diagram


INFOID:000000008452623



System Description

INFOID:000000008452624

- Traction Control System is a function that electronically controls engine torque, brake fluid pressure and A/T gear position to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels (rear wheels), it compares wheel speed signals from all 4 wheels. At this time, LH and RH rear brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, TCS informs driver of system operation by flashing VDC warning lamp.
- Electrical system diagnosis by CONSULT is available.



- | | | |
|---|----------------------------------|---|
| 1. ABS actuator and electric unit (control unit) | 2. Front wheel sensor | 3. Steering angle sensor |
| 4. Yaw rate/side G sensor | 5. Rear wheel sensor | |
| A. Engine room right side | B. Steering knuckle | C. VDC OFF switch: IP-12, "Exploded View" |
| D. ABS warning lamp, brake warning lamp, VDC OFF indicator lamp, VDC warning lamp: MWI-6, "METER SYSTEM : System Description" | E. Back of spiral cable assembly | F. Under front (left side) seat |
| G. Rear axle | | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

Component Description


INFOID:000000008452626

| Component parts | | Reference |
|---|---------------------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-39, "Description" |
| | Motor | |
| | Actuator relay (main relay) | BRC-57, "Description" |
| | Solenoid valve | BRC-51, "Description" |
| | Pressure sensor | BRC-59, "Description" |
| | VDC switch-over valve (CV1, CV2) | BRC-70, "Description" |
| | VDC switch-over valve (SV1, SV2) | BRC-72, "Description" |
| Wheel sensor | BRC-28, "Description" | |
| Yaw rate/side G sensor | BRC-64, "Description" | |
| Steering angle sensor | BRC-61, "Description" | |
| VDC OFF switch | BRC-81, "Description" | |
| ABS warning lamp | BRC-83, "Description" | |
| Brake warning lamp | BRC-84, "Description" | |
| VDC OFF indicator lamp | BRC-86, "Description" | |
| VDC warning lamp | BRC-87, "Description" | |

ABS

System Diagram

INFOID:000000008452627




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

System Description

INFOID:000000008452628

- Anti-Lock Braking System detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT is available.



- | | | |
|---|----------------------------------|---|
| 1. ABS actuator and electric unit (control unit) | 2. Front wheel sensor | 3. Steering angle sensor |
| 4. Yaw rate/side G sensor | 5. Rear wheel sensor | |
| A. Engine room right side | B. Steering knuckle | C. VDC OFF switch: IP-12, "Exploded View" |
| D. ABS warning lamp, brake warning lamp, VDC OFF indicator lamp, VDC warning lamp: MWI-6, "METER SYSTEM : System Description" | E. Back of spiral cable assembly | F. Under front (left side) seat |
| G. Rear axle | | |

JPFIC0062ZZ

Component Description

INFOID:000000008452630

| Component parts | | Reference |
|---|---------------------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-39, "Description" |
| | Motor | |
| | Actuator relay (main relay) | BRC-57, "Description" |
| | Solenoid valve | BRC-51, "Description" |
| | Pressure sensor | BRC-59, "Description" |
| | VDC switch-over valve (CV1, CV2) | BRC-70, "Description" |
| | VDC switch-over valve (SV1, SV2) | BRC-72, "Description" |
| Wheel sensor | BRC-28, "Description" | |
| Yaw rate/side G sensor | BRC-64, "Description" | |
| Steering angle sensor | BRC-61, "Description" | |
| VDC OFF switch | BRC-81, "Description" | |
| ABS warning lamp | BRC-83, "Description" | |
| Brake warning lamp | BRC-84, "Description" | |
| VDC OFF indicator lamp | BRC-86, "Description" | |
| VDC warning lamp | BRC-87, "Description" | |


A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

EBD

System Diagram


INFOID:000000008452631



System Description

INFOID:000000008452632

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT is available.



- | | | |
|---|----------------------------------|---|
| 1. ABS actuator and electric unit (control unit) | 2. Front wheel sensor | 3. Steering angle sensor |
| 4. Yaw rate/side G sensor | 5. Rear wheel sensor | |
| A. Engine room right side | B. Steering knuckle | C. VDC OFF switch: IP-12, "Exploded View" |
| D. ABS warning lamp, brake warning lamp, VDC OFF indicator lamp, VDC warning lamp: MWI-6, "METER SYSTEM : System Description" | E. Back of spiral cable assembly | F. Under front (left side) seat |
| G. Rear axle | | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

Component Description

INFOID:000000008452634

| Component parts | | Reference |
|---|---------------------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-39, "Description" |
| | Motor | |
| | Actuator relay (main relay) | BRC-57, "Description" |
| | Solenoid valve | BRC-51, "Description" |
| | Pressure sensor | BRC-59, "Description" |
| | VDC switch-over valve (CV1, CV2) | BRC-70, "Description" |
| | VDC switch-over valve (SV1, SV2) | BRC-72, "Description" |
| Wheel sensor | BRC-28, "Description" | |
| Yaw rate/side G sensor | BRC-64, "Description" | |
| Steering angle sensor | BRC-61, "Description" | |
| VDC OFF switch | BRC-81, "Description" | |
| ABS warning lamp | BRC-83, "Description" | |
| Brake warning lamp | BRC-84, "Description" | |
| VDC OFF indicator lamp | BRC-86, "Description" | |
| VDC warning lamp | BRC-87, "Description" | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT Function

INFOID:000000008452635

FUNCTION

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

| Diagnostic test mode | Function |
|------------------------|--|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT. |
| Self diagnostic result | Self-diagnostic results can be read and erased quickly. |
| Data monitor | Input/Output data in the ABS actuator and electric unit (control unit) can be read. |
| Active test | CONSULT drives some actuators apart from ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range. |
| ECU identification | ABS actuator and electric unit (control unit) part number can be read. |

WORK SUPPORT

| Item | Description |
|----------------------------|--|
| ST ANGLE SENSOR ADJUSTMENT | Adjusts the neutral position of the steering angle sensor. |

SELF DIAGNOSTIC RESULT

Operation Procedure

Before performing the self-diagnosis, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

Display Item List

Refer to [BRC-94. "DTC Index"](#).

How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC warning lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, ABS warning lamp, VDC warning lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driven at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or in case of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

DATA MONITOR MODE

Display Item List

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

×: Applicable ▼: Optional item

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks |
|--------------------------------------|---------------------|--------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| FR LH SENSOR [km/h (MPH)] | × | × | Wheel speed |
| FR RH SENSOR [km/h (MPH)] | × | × | |
| RR LH SENSOR [km/h (MPH)] | × | × | |
| RR RH SENSOR [km/h (MPH)] | × | × | |
| BATTERY VOLT (V) | × | × | Battery voltage supplied to the ABS actuator and electric unit (control unit) |
| STOP LAMP SW (On/Off) | × | × | Stop lamp switch signal status |
| OFF SW (On/Off) | × | × | VDC OFF switch |
| GEAR | × | × | Gear position determined by TCM |
| SLCT LVR POSI | × | × | Shift lever position determined by TCM |
| YAW RATE SEN (d/s) | × | × | Yaw rate detected by yaw rate/side G sensor |
| FR RH IN SOL (On/Off) (Note) | ▼ | × | Operation status of each solenoid valve |
| FR RH OUT SOL (On/Off) (Note) | ▼ | × | |
| FR LH IN SOL (On/Off) (Note) | ▼ | × | |
| FR LH OUT SOL (On/Off) (Note) | ▼ | × | |
| RR RH IN SOL (On/Off) (Note) | ▼ | × | |
| RR RH OUT SOL (On/Off) (Note) | ▼ | × | |
| RR LH IN SOL (On/Off) (Note) | ▼ | × | |
| RR LH OUT SOL (On/Off) (Note) | ▼ | × | |
| MOTOR RELAY (On/Off) | ▼ | × | Motor and motor relay operation |
| ACTUATOR RLY (On/Off) (Note) | ▼ | × | Actuator relay operation |
| ABS WARN LAMP (On/Off) | ▼ | × | ABS warning lamp |
| OFF LAMP (On/Off) | ▼ | × | VDC OFF indicator lamp |
| SLIP/VDC LAMP (On/Off) | ▼ | × | VDC warning lamp |
| PRESS SENSOR (bar) | × | ▼ | Brake fluid pressure detected by pressure sensor |
| ACCEL POS SIG (%) | × | ▼ | Throttle actuator opening/closing is displayed (Linked with accelerator pedal) |
| SIDE G-SENSOR (m/s ²) | × | ▼ | Transverse G detected by yaw rate/side G sensor |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks |
|---------------------------|---------------------|--------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| STR ANGLE SIG (°) | × | ▼ | Steering angle detected by steering angle sensor |
| ENGINE RPM [tr/min (rpm)] | × | ▼ | Engine speed |
| FLUID LEV SW (On/Off) | × | ▼ | Brake fluid level switch signal status |
| EBD WARN LAMP (On/Off) | ▼ | ▼ | Brake warning lamp |
| CV1 (On/Off) | ▼ | ▼ | VDC switch-over valve |
| CV2 (On/Off) | ▼ | ▼ | |
| SV1 (On/Off) | ▼ | ▼ | |
| SV2 (On/Off) | ▼ | ▼ | |
| EBD SIGNAL (On/Off) | ▼ | ▼ | EBD operation |
| ABS SIGNAL (On/Off) | ▼ | ▼ | ABS operation |
| TCS SIGNAL (On/Off) | ▼ | ▼ | TCS operation |
| VDC SIGNAL (On/Off) | ▼ | ▼ | VDC operation |
| EBD FAIL SIG (On/Off) | ▼ | ▼ | EBD fail-safe signal |
| ABS FAIL SIG (On/Off) | ▼ | ▼ | ABS fail-safe signal |
| TCS FAIL SIG (On/Off) | ▼ | ▼ | TCS fail-safe signal |
| VDC FAIL SIG (On/Off) | ▼ | ▼ | VDC fail-safe signal |
| CRANKING SIG (On/Off) | ▼ | ▼ | Crank operation |
| PARK BRAKE SW (On/Off) | × | ▼ | Parking brake switch signal status |
| V/R OUTPUT (On/Off) | ▼ | ▼ | Solenoid valve relay activated |
| M/R OUTPUT (On/Off) | ▼ | ▼ | Actuator motor and motor relay activated |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ACTIVE TEST MODE

CAUTION:

- **Never perform active test while driving vehicle.**
- **Make sure to completely bleed air from brake system.**
- **The active test cannot be started when ABS warning lamp, VDC warning lamp and brake warning lamp are ON.**
- **ABS warning lamp, VDC warning lamp and brake warning lamp are ON during active test.**

NOTE:

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT is displayed, to perform test again.

Test Item

ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that solenoid valve operates as shown in the table below.

| Test item | Display item | Display (Note) | | |
|-----------|---------------|----------------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | CV2 | Off | Off | Off |
| | SV2 | Off | Off | Off |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | CV1 | Off | Off | Off |
| | SV1 | Off | Off | Off |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | CV1 | Off | Off | Off |
| | SV1 | Off | Off | Off |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | CV2 | Off | Off | Off |
| | SV2 | Off | Off | Off |

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ABS SOLENOID VALVE (ACT)

- Select "Up", "ACT UP" and "ACT KEEP" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that solenoid valve operates as shown in the table below.

| Test item | Display item | Display (Note) | | |
|--------------------------|---------------|----------------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | CV2 | Off | On | On |
| | SV2 | Off | On* | Off |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | CV1 | Off | On | On |
| | SV1 | Off | On* | Off |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Test item | Display item | Display (Note) | | |
|--------------------------|---------------|----------------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | CV1 | Off | On | On |
| | SV1 | Off | On* | Off |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | Off | Off | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | CV2 | Off | On | On |
| | SV2 | Off | On* | Off |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT. Make sure motor relay and actuator relay operates as shown in table below.

| Test item | Display item | Display | |
|-----------|---------------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY (Note) | On | On |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

Description

INFOID:000000008452636

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452637

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|--|
| C1101 | RR RH SENSOR-1 | Circuit of rear RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)• Sensor rotor |
| C1102 | RR LH SENSOR-1 | Circuit of rear LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1103 | FR RH SENSOR-1 | Circuit of front RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1104 | FR LH SENSOR-1 | Circuit of front LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-28, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452638

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check wheel sensor for damage.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.

C1101, C1102, C1103, C1104 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 3.

NO >> INSPECTION END

3.CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 4.

4.PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.

2. Turn the ignition switch OFF, and wait 10 seconds or more.

3. Start the engine.

4. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

5. Stop the vehicle.

6. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK TERMINAL

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts and GO TO 6.

6.PERFORM SELF-DIAGNOSIS (2)

1. Connect ABS actuator and electric unit (control unit) harness connector.

2. Connect wheel sensor harness connector.

3. Erase self-diagnosis result for "ABS".

4. Turn the ignition switch OFF, and wait 10 seconds or more.

5. Start the engine.

6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

7. Stop the vehicle.

8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 7.

NO >> INSPECTION END

7.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector.

3. Disconnect wheel sensor harness connector.

4. Check continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Measurement connector and terminal for power supply circuit | | | | |
|---|----------|----------------|----------|------------|
| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| E36 | 9 | E39 (Front RH) | 1 | Existed |
| | 16 | E22 (Front LH) | | |
| | 8 | B41 (Rear RH) | | |
| | 6 | B44 (Rear LH) | | |

| Measurement connector and terminal for signal circuit | | | | |
|---|----------|----------------|----------|------------|
| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| E36 | 10 | E39 (Front RH) | 2 | Existed |
| | 5 | E22 (Front LH) | | |
| | 19 | B41 (Rear RH) | | |
| | 17 | B44 (Rear LH) | | |

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts and GO TO 8.

8.PERFORM SELF-DIAGNOSIS (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
7. Stop the vehicle.
8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 9.

NO >> INSPECTION END

9.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000008452639

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR

Description

INFOID:000000008452640

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452641

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|--|--|
| C1105 | RR RH SENSOR-2 | When the circuit in the rear RH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)• Sensor rotor |
| C1106 | RR LH SENSOR-2 | When the circuit in the rear LH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |
| C1107 | FR RH SENSOR-2 | When the circuit in the front RH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |
| C1108 | FR LH SENSOR-2 | When the circuit in the front LH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107", or "C1108" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-31, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452642

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK TIRE

1. Turn the ignition switch OFF.
2. Check tire air pressure, wear and size. Refer to [WT-51, "Tire Air Pressure"](#).

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Adjust air pressure or replace tire and GO TO 3.

3.CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 4.
- NO >> GO TO 5.

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 5.
- NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check wheel sensor for damage.
3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

- Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 7.
- NO >> GO TO 19.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

7.PERFORM SELF-DIAGNOSIS (2)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 19.

NO >> INSPECTION END

8.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 9.

9.CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10.PERFORM SELF-DIAGNOSIS (3)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12.CHECK DATA MONITOR (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 13.

NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (4)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 14.

NO >> INSPECTION END

14.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | | | Continuity |
|---|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 9, 10 | E36 | 1, 4 | Not existed |
| | 16, 5 | | | |
| | 8, 19 | | | |
| | 6, 17 | | | |

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace error-detected parts and GO TO 15.

15.CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 16.

NO >> GO TO 17.

16.PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 17.

NO >> INSPECTION END

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

17. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

18. PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19. REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-108, "FRONT SENSOR ROTOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-108, "REAR SENSOR ROTOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000008452643

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 POWER AND GROUND SYSTEM

Description

INFOID:000000008452644

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452645

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------------------|---|---|
| C1109 | BATTERY VOLTAGE [ABNORMAL] | When the ABS actuator and electric unit (control unit) power supply voltage is lower than normal. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) • Fuse |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1109" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452646

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 18 | Ground | Approx. 0 V |

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 18 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R harness connector.

C1109 POWER AND GROUND SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R harness connector.

| ABS actuator and electric unit (control unit) | | IPDM E/R | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 18 | E15 | 60 | Existed |

Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-18, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND

Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452647

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000008452648

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1110 | CONTROLLER FAILURE | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | ABS actuator and electric unit (control unit) |
| C1153 | EMERGENCY BRAKE | When ABS actuator and electric unit (control unit) is malfunctioning. (Pressure increase is too much or too little) | |
| C1170 | VARIANT CODING | In a case where VARIANT CODING is different. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1110", "C1153" or "C1170" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-38, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452649

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

CAUTION:

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

Special Repair Requirement

INFOID:000000008452650

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

Description

INFOID:000000008452651

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

MOTOR RELAY

Activates or deactivates motor according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452652

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1111 | PUMP MOTOR | During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| | | During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1111" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452653

1. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 40A fusible link (F).
4. Check voltage between the ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 2 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452654

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1115 WHEEL SENSOR

Description

INFOID:000000008452655

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452656

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|---------------------------------|---|--|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | When wheel sensor input signal is malfunctioning. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)• Sensor rotor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-41, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452657

CAUTION:

For wheel sensor, never check between terminals.

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK TIRE

1. Turn the ignition switch OFF.
2. Check tire air pressure, wear and size. Refer to [WT-51, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Adjust air pressure or replace tire and GO TO 3.

3. CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 4.

NO >> GO TO 5.

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check wheel sensor for damage.
3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

• Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Exploded View"](#).

• Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 7.

NO >> GO TO 19.

7.PERFORM SELF-DIAGNOSIS (2)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

8.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 9.

9.CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.

2. Turn the ignition switch OFF, and wait 10 seconds or more.

3. Start the engine.

4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10.PERFORM SELF-DIAGNOSIS (3)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

2. Stop the vehicle.

3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11.CHECK TERMINAL

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12.CHECK DATA MONITOR (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.

2. Connect wheel sensor harness connector.

3. Erase self-diagnosis result for "ABS" with CONSULT.

4. Turn the ignition switch OFF, and wait 10 seconds or more.

5. Start the engine.

6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 13.

NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (4)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

2. Stop the vehicle.

3. Perform self-diagnosis for "ABS" with CONSULT.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1115" detected?

- YES >> GO TO 14.
 NO >> INSPECTION END

14.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

Measurement connector and terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 9 | E39 (Front RH) | 1 | Existed |
| | 16 | E22 (Front LH) | | |
| | 8 | B41 (Rear RH) | | |
| | 6 | B44 (Rear LH) | | |

Measurement connector and terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 10 | E39 (Front RH) | 2 | Existed |
| | 5 | E22 (Front LH) | | |
| | 19 | B41 (Rear RH) | | |
| | 17 | B44 (Rear LH) | | |

5. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | | | Continuity |
|---|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 9, 10 | E36 | 1, 4 | Not existed |
| | 16, 5 | | | |
| | 8, 19 | | | |
| | 6, 17 | | | |

Is the inspection result normal?

- YES >> GO TO 15.
 NO >> Repair or replace error-detected parts and GO TO 15.

15.CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

- YES >> GO TO 16.
 NO >> GO TO 17.

< DTC/CIRCUIT DIAGNOSIS >

16.PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 17.

NO >> INSPECTION END

17.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 - Front: Refer to [BRC-106, "FRONT WHEEL SENSOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-107, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

18.PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19.REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-108, "FRONT SENSOR ROTOR : Removal and Installation"](#).
 - Rear: Refer to [BRC-108, "REAR SENSOR ROTOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000008452658

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SWITCH

Description

INFOID:000000008452659

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452660

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1116 | STOP LAMP SW | When a stop lamp switch signal is not input where the brake pedal is depressed. | <ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1116" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-46, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452661

NOTE:

DTC "C1116" may be detected when the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle. This is not a malfunction.

1. INTERVIEW FROM THE CUSTOMER

Check if the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle.

Is there such a history?

- YES >> GO TO 2.
NO >> GO TO 3.

2. PERFORM SELF-DIAGNOSIS

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

CAUTION:

Never start the vehicle.

4. Depress the brake pedal several times.
5. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1116" detected?

- YES >> GO TO 3.
NO >> INSPECTION END

3. STOP LAMP FOR ILLUMINATION

Depress brake pedal and check that stop lamp turns ON.

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Does stop lamp turn ON?

YES >> GO TO 5.

NO >> Check stop lamp system. Refer to [EXL-68, "Diagnosis Procedure"](#). GO TO 4.

4.CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

CAUTION:

Never start the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order with CONSULT. Check that data monitor displays "On" or "Off" when brake pedal is depress or release. Refer to [BRC-88, "Reference Value"](#).
5. Select "ABS", "DATA MONITOR" and "pressure sensor" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depress. Refer to [BRC-88, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5.CHECK STOP LAMP SWITCH CLEARANCE

1. Turn the ignition switch OFF.
2. Check stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Adjust stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#). GO TO 6.

6.CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

CAUTION:

Never start the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order with CONSULT. Check that data monitor displays "On" or "Off" when brake pedal is depress or release. Refer to [BRC-88, "Reference Value"](#).
5. Select "ABS", "DATA MONITOR" and "pressure sensor" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depress. Refer to [BRC-88, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 7.

7.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-49, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace stop lamp switch. Refer to [BR-17, "Exploded View"](#). GO TO 8.

8.CHECK DATA MONITOR (3)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

CAUTION:

Never start the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order with CONSULT. Check that data monitor displays "On" or "Off" when brake pedal is depress or release. Refer to [BRC-88, "Reference Value"](#).
5. Select "ABS", "DATA MONITOR" and "pressure sensor" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depress. Refer to [BRC-88, "Reference Value"](#).

Is the inspection result normal?

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END
NO >> GO TO 9.

9. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
4. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
5. Disconnect stop lamp switch harness connector.
6. Check stop lamp switch harness connector for disconnection or looseness.
7. Check stop lamp switch pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 11.
NO >> Repair or replace error-detected parts. GO TO 10.

10. CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect stop lamp switch harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
CAUTION:
Never start the vehicle.
6. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order with CONSULT. Check that data monitor displays "On" or "Off" when brake pedal is depress or release. Refer to [BRC-88, "Reference Value"](#).
7. Select "ABS", "DATA MONITOR" and "pressure sensor" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depress. Refer to [BRC-88, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END
NO >> GO TO 11.

11. CHECK STOP LAMP SWITCH CIRCUIT (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage |
|---|----------|--------|---------------------------|-----------------|
| Connector | Terminal | | | |
| E36 | 20 | Ground | Brake pedal depressed | Battery voltage |
| | | | Brake pedal not depressed | Approx. 0 V |

4. Turn the ignition switch ON.
5. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage |
|---|----------|--------|---------------------------|-----------------|
| Connector | Terminal | | | |
| E36 | 20 | Ground | Brake pedal depressed | Battery voltage |
| | | | Brake pedal not depressed | Approx. 0 V |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).
NO >> Repair or replace error-detected parts. GO TO 12.

12. CHECK STOP LAMP SWITCH CIRCUIT (2)

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between ABS actuator and electric unit (control unit) harness connector and stop lamp switch harness connector.

| ABS actuator and electric unit (control unit) | | Stop lamp switch | | Continuity |
|---|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 20 | E114*1 | 2 | Existed |
| | | E115*2 | | |

*1: With M/T

*2: With CVT

4. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 20 | Ground | Not existed |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts. GO TO 13.

13.CHECK DATA MONITOR (5)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect stop lamp switch harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
CAUTION:
Never start the vehicle.
6. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order with CONSULT. Check that data monitor displays "On" or "Off" when brake pedal is depress or release. Refer to [BRC-88, "Reference Value"](#).
7. Select "ABS", "DATA MONITOR" and "pressure sensor" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depress. Refer to [BRC-88, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

Component Inspection

INFOID:000000008452662

1.CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch harness connector terminals.

| Stop lamp switch | Condition | Continuity |
|------------------|--|-------------|
| Terminal | | |
| 1 - 2 | Release stop lamp switch (When brake pedal is depressed.) | Existed |
| | Push stop lamp switch (When brake pedal is released.) | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-17, "Exploded View"](#).

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Special Repair Requirement

INFOID:000000008452663

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000008452664

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452665

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|---|
| C1120 | FR LH IN ABS SOL | When the control unit detects a malfunction in the front LH inlet solenoid circuit. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| C1122 | FR RH IN ABS SOL | When the control unit detects a malfunction in the front RH inlet solenoid circuit. | |
| C1124 | RR LH IN ABS SOL | When the control unit detects a malfunction in the rear LH inlet solenoid circuit. | |
| C1126 | RR RH IN ABS SOL | When the control unit detects a malfunction in the rear RH inlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-51, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452666

1. CHECK SOLENOID POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 30A fusible link (K).
4. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK SOLENOID GROUND

Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452667

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000008452668

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452669

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|---|
| C1121 | FR LH OUT ABS SOL | When the control unit detects a malfunction in the front LH outlet solenoid circuit. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| C1123 | FR RH OUT ABS SOL | When the control unit detects a malfunction in the front RH outlet solenoid circuit. | |
| C1125 | RR LH OUT ABS SOL | When the control unit detects a malfunction in the rear LH outlet solenoid circuit. | |
| C1127 | RR RH OUT ABS SOL | When the control unit detects a malfunction in the rear RH outlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-53, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452670

1. CHECK SOLENOID POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 30A fusible link (K).
4. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK SOLENOID GROUND

Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452671

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1130 ENGINE SIGNAL

Description

INFOID:000000008452672

ABS actuator and electric unit (control unit) and ECM exchange the engine signal with CAN communication line.

DTC Logic

INFOID:000000008452673

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|--|
| C1130 | ENGINE SIGNAL 1 | Major engine components are malfunctioning. | <ul style="list-style-type: none"> Harness or connector ABS actuator and electric unit (control unit) ECM CAN communication line |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1130" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-55, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452674

1. PERFORM ECM SELF-DIAGNOSIS

Perform self-diagnosis for "ENGINE" with CONSULT.

Is any DTC detected?

- YES >> Check the DTC. Refer to [EC-117, "CONSULT Function"](#) (Except for California), [EC-588, "CONSULT Function"](#) (For California).
 NO >> GO TO 2.

2. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

1. Erase self-diagnosis results for "ABS" with CONSULT.
2. Turn the ignition switch OFF.
3. Start the engine. Drive the vehicle for a while.
4. Make sure that malfunction indicator lamp (MIL) turns OFF.
5. Stop the engine. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1130" detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).
 NO >> Check ABS actuator and electric unit (control unit) harness connector terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452675

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

C1130 ENGINE SIGNAL

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1140 ACTUATOR RELAY SYSTEM

Description

INFOID:000000008452676

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452677

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|--|
| C1140 | ACTUATOR RLY | When the control unit detects a malfunction in the actuator relay system. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1140" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-57, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452678

1. CHECK ACTUATOR RELAY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 30A fusible link (K).
4. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK ACTUATOR RELAY GROUND

Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3.

C1140 ACTUATOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace error-detected parts.

3. CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452679

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1142 PRESS SENSOR

Description

INFOID:000000008452680

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

DTC Logic

INFOID:000000008452681

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|---|---|
| C1142 | PRESS SEN CIRCUIT | Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning. | <ul style="list-style-type: none"> • Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit) • Brake system |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1142" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-59, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452682

1. CHECK STOP LAMP SWITCH

Check stop lamp switch system. Refer to [BRC-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK BRAKE SYSTEM

1. Check brake fluid leakage: refer to [BR-10, "Inspection"](#).
2. Check brake piping: refer to [BR-22, "FRONT : Inspection"](#) (front), [BR-24, "REAR : Inspection"](#) (rear).
3. Check brake pedal: refer to [BR-7, "Inspection and Adjustment"](#).
4. Check master cylinder: refer to [BR-12, "Inspection"](#).
5. Check brake booster: refer to [BR-13, "Inspection"](#).
6. Check front disc brake: refer to [BR-38, "BRAKE CALIPER ASSEMBLY : Inspection"](#).
7. Check rear drum brake: refer to [BR-41, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace error-detected parts.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

C1142 PRESS SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Check ABS actuator and electric unit (control unit) harness connector terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452683

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1143 STEERING ANGLE SENSOR

Description

INFOID:000000008452684

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000008452685

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|--|--|
| C1143 | ST ANG SEN CIRCUIT | Steering angle sensor is malfunctioning. | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1143" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-61, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452686

1. CHECK STEERING ANGLE SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect steering angle sensor harness connector.
3. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage |
|-----------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M30 | 4 | Ground | Approx. 0 V |

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage |
|-----------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| M30 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK STEERING ANGLE SENSOR CIRCUIT

1. Turn the ignition switch OFF.

C1143 STEERING ANGLE SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect IPDM E/R harness connector.
3. Check continuity between steering angle sensor harness connector and IPDM E/R harness connector.

| Steering angle sensor | | IPDM E/R | | Continuity |
|-----------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M30 | 4 | E15 | 60 | Existed |

Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-18. "Wiring Diagram - IGNITION POWER SUPPLY -"](#)

NO >> Repair or replace error-detected parts.

3.CHECK STEERING ANGLE SENSOR GROUND

Check continuity between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M30 | 1 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK DATA LINE

Check "STRG BRANCH LINE CIRCUIT". Refer to [LAN-37. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts. Refer to [BRC-103. "Precautions for Harness Repair"](#).

5.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check steering angle sensor pin terminals for damage or loose connection with harness connector.
2. Check IPDM E/R pin terminals for damage or loose connection with harness connector.
3. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452687

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

Description

INFOID:000000008452688

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000008452689

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|--|
| C1144 | ST ANG SEN SIGNAL | Neutral position of steering angle sensor is not finished. | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Select "ABS", "WORK SUPPORT" and "ST ANG SEN ADJUSTMENT" in order with CONSULT, and perform adjust the neutral position of steering angle sensor.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1144" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-63. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452690

1. CHECK STEERING ANGLE SENSOR

Check steering angle sensor. Refer to [BRC-61. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).
NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452691

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1145, C1146 YAW RATE/SIDE G SENSOR

Description

INFOID:000000008452692

The yaw rate/side G sensor detects the yaw rate/side G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000008452693

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1145 | YAW RATE SENSOR | Yaw rate sensor is malfunctioning, or the yaw rate sensor signal line is open or shorted. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side G sensor |
| C1146 | SIDE G-SEN CIRCUIT | Side G sensor is malfunctioning, or circuit of side G sensor is open or shorted. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1145" or "C1146" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452694

CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc., when VDC function is off (VDC OFF switch "ON") may cause yaw rate/side G sensor system to indicate a malfunction. However, this is not a malfunction, if normal operation can be resumed after restarting engine. Then erase memory of self-diagnosis.
- If vehicle is on turn-table at entrance to parking garage, or on other moving surface, VDC OFF indicator lamp may illuminate and CONSULT self-diagnosis may indicate yaw rate sensor system malfunction. However, in this case there is no malfunction in yaw rate sensor system. Take vehicle off of turn-table or other moving surface, and start the engine. Results will return to normal.

INSPECTION PROCEDURE

1. CHECK YAW RATE/SIDE G SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect yaw rate/side G sensor harness connector.
3. Check voltage between yaw rate/side G sensor harness connector and ground.

| Yaw rate/side G sensor | | — | Voltage |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B38 | 4 | Ground | Approx. 0 V |

4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Check voltage between yaw rate/side G sensor harness connector and ground.

C1145, C1146 YAW RATE/SIDE G SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

| Yaw rate/side G sensor | | — | Voltage |
|------------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| B38 | 4 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK YAW RATE/SIDE G SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check continuity between yaw rate/side G sensor harness connector and IPDM E/R harness connector.

| Yaw rate/side G sensor | | IPDM E/R | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B38 | 4 | E15 | 60 | Existed |

Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-18. "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

3.CHECK YAW RATE/SIDE G SENSOR GROUND

Check continuity between yaw rate/side G sensor harness connector and ground.

| Yaw rate/side G sensor | | — | Continuity |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B38 | 1 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK YAW RATE/SIDE G SENSOR CIRCUIT

Check continuity between yaw rate/side G sensor harness connector and ABS actuator electric unit (control unit) harness connector.

| Yaw rate/side G sensor | | ABS actuator electric unit (control unit) | | Continuity |
|------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B38 | 2 | E36 | 14 | Existed |
| | 3 | | 25 | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check yaw rate/side G sensor pin terminals for damage or loose connection with harness connector.
2. Check IPDM E/R pin terminals for damage or loose connection with harness connector.
3. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6.REPLACE YAW RATE/SIDE G SENSOR

C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

1. Replace yaw rate/side G sensor. Refer to [BRC-111, "Exploded View"](#).
2. Erase self-diagnosis results for "ABS" with CONSULT.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1145" or "C1146" detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000008452695

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BRAKE FLUID LEVEL SWITCH

Description

INFOID:000000008452696

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000008452697

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1155 | BR FLUID LEVEL LOW | Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted. | <ul style="list-style-type: none">• Harness or connector• Brake fluid• Brake fluid level switch• Combination meter |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-67, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452698

1. CHECK BRAKE FLUID LEVEL

1. Turn the ignition switch OFF.
2. Check brake fluid level. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill brake fluid. Refer to [BR-10, "Refilling"](#).

2. PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> INSPECTION END
NO >> GO TO 3.

3. CHECK BRAKE FLUID LEVEL SWITCH

Check brake fluids level switch. Refer to [BRC-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace reservoir tank. Refer to [BR-25, "Exploded View"](#). GO TO 4.

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

4. PERFORM SELF-DIAGNOSIS (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> INSPECTION END
NO >> GO TO 5.

5. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check brake fluid level switch harness connector for disconnection or looseness.
4. Check brake fluid level switch pin terminals for damage or loose connection with harness connector.
5. Disconnect combination meter harness connector.
6. Check combination meter harness connector for disconnection or looseness.
7. Check combination meter pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace error-detected parts. GO TO 6.

6. PERFORM SELF-DIAGNOSIS (3)

1. Connect brake fluid level switch harness connector.
2. Connect combination meter harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Turn the ignition switch ON.

CAUTION:

Never start the engine.

6. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> INSPECTION END
NO >> GO TO 7.

7. CHECK BRAKE FLUID LEVEL SWITCH HARNESS

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect combination meter harness connector.
4. Check continuity between brake fluid level switch harness connector and combination meter harness connector.

| Brake fluid level switch | | Combination meter | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E37 | 1 | M34 | 11 | Existed |

5. Check continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| E37 | 1 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Repair or replace error-detected parts. GO TO 8.

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

8. CHECK BRAKE FLUID LEVEL SWITCH GROUND

Check continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E37 | 2 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts. GO TO 9.

9. CHECK COMBINATION METER

Check combination meter. Refer to [MWI-30, "CONSULT Function \(METER/M&A\)"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace combination meter. Refer to [MWI-90, "Exploded View"](#).

Component Inspection

INFOID:000000008452699

BRC

1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check continuity between brake fluid level switch harness connector.

| Brake fluid level switch | Condition | Continuity |
|--------------------------|--|-------------|
| Terminal | | |
| 1 - 2 | When brake fluid is full in the reservoir tank. | Not existed |
| | When brake fluid is empty in the reservoir tank. | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace reservoir tank. Refer to [BR-25, "Exploded View"](#).

Special Repair Requirement

INFOID:000000008452700

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1164, C1165 CV SYSTEM

Description

INFOID:000000008452701

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

DTC Logic

INFOID:000000008452702

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|--|
| C1164 | CV 1 | VDC switch-over solenoid valve (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| C1165 | CV 2 | VDC switch-over solenoid valve (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1164" or "C1165" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-70, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452703

1. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 30A fusible link (K).
4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452704

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

C1166, C1167 SV SYSTEM

Description

INFOID:000000008452705

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:000000008452706

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1166 | SV 1 | VDC switch-over solenoid valve (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | <ul style="list-style-type: none"> Harness or connector ABS actuator and electric unit (control unit) |
| C1167 | SV 2 | VDC switch-over solenoid valve (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1166" or "C1167" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-72. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452707

1. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the 30A fusible link (K).
4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace damaged parts.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Existed |
| | 4 | | |

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace damaged parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452708

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008452709

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000008452710

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|--|
| U1000 | CAN COMM CIRCUIT | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more. | <ul style="list-style-type: none">CAN communication lineABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-74, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452711

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [LAN-13, "Trouble Diagnosis Flow Chart"](#).
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000008452712

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

U1002 SYSTEM COMM (CAN)

Description

INFOID:000000008452713

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000008452714

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| U1002 | SYSTEM COMM | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or less. | <ul style="list-style-type: none"> • CAN communication line • ABS actuator and electric unit (control unit) |

A
B
C
D
E
BRC

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1002" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-75, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008452715

CAUTION:

- **Never apply 7.0 V or more to the measurement terminal.**
- **Use a tester with open terminal voltage of 7.0 V or less.**
- **Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.**

1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

1. Select "ABS" and "CAN Diagnosis Support Monitor" in order with CONSULT.
2. Check malfunction history between each control unit connected to ABS actuator and electric unit (control unit).

Check the result of "PAST"?

All items are "OK">>Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
"TRANSMIT DIAG" is other than "OK">>GO TO 2.

A control unit other than ABS actuator and electric unit (control unit) is anything other than "OK">>GO TO 3.

2. CHECK TRANSMITTING SIDE UNIT

Check the ABS actuator and electric unit (control unit) harness connector terminals No. 15 and 26 for damage or loose connection.

Is the inspection result normal?

- YES >> Erase self-diagnosis results. Then perform self-diagnosis for "ABS" with CONSULT.
- NO >> Recheck terminals for damage or loose connection. Refer to [BRC-103, "Precautions for Harness Repair"](#).

G
H
I
J
K
L
M
N
O
P

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK APPLICABLE CONTROL UNIT

Check terminals of each CAN communication line harness connector for damage or loose connection.

Is the inspection result normal?

- YES >> Erase self-diagnosis results. Then perform self-diagnosis for applicable control unit with CONSULT.
- NO >> Recheck terminals for damage or loose connection. Refer to [BRC-103. "Precautions for Harness Repair"](#).

Special Repair Requirement

INFOID:000000008452716

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-9. "Special Repair Requirement"](#).

>> END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:000000008452717

Supplies power to ABS actuator and electric unit (control unit).

Diagnosis Procedure

INFOID:000000008452718

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 18 | Ground | Approx. 0 V |

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 18 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Check the 10A fuse (57).
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R harness connector.

| ABS actuator and electric unit (control unit) | | IPDM E/R | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 18 | E15 | 60 | Existed |

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 18 | Ground | No existed |

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-18, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E41 | 2 | Ground | Battery voltage |
| | 3 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1 | Ground | Existed |
| | 4 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).

NO >> Repair or replace error-detected parts.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Description

INFOID:000000008452719

Operate the parking brake lever, and brake warning lamp in the combination meter turns ON/OFF correctly.

Diagnosis Procedure

INFOID:000000008452720

1.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Disconnect combination meter harness connector.
4. Check continuity between parking brake switch harness connector and combination meter harness connector.

| Parking brake switch | | Combination meter | | Continuity |
|----------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M11 | 1 | M34 | 10 | Existed |

5. Check continuity between parking brake switch harness connector and ground.

| Parking brake switch | | — | Continuity |
|----------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M11 | 1 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2.CHECK PARKING BRAKE SWITCH

Check the parking brake switch. Refer to [BRC-79, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace parking brake switch. Refer to [PB-4, "Exploded View"](#).

3.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check parking brake switch pin terminals for damage or loose connection with harness connector.
2. Check combination meter pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace error-detected parts.

4.CHECK PARKING BRAKE SWITCH SIGNAL

Select "ABS", "DATA MONITOR" and "PARK BRAKE SW" in order with CONSULT, and perform the parking brake switch inspection.

| Condition | PARK BRAKE SW (DATA MONITOR) |
|---------------------------------|------------------------------|
| Parking brake lever is active | On |
| Parking brake lever is inactive | Off |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Check combination meter.

Component Inspection

INFOID:000000008452721

1.CHECK PARKING BRAKE SWITCH

PARKING BRAKE SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Check continuity between parking brake switch harness connector.

| Parking brake switch | | Condition | Continuity |
|----------------------|--------|--|-------------|
| Terminal | — | When the parking brake switch is operated. | Existed |
| 1 | Ground | When the parking brake switch is not operated. | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-4. "Exploded View"](#).

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Description

INFOID:000000008452722

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

Diagnosis Procedure

INFOID:000000008452723

1. CHECK VDC OFF SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect VDC OFF switch harness connector.
4. Check the continuity between VDC OFF switch harness connector and ABS actuator and electric unit (control unit) harness connector.

| ABS actuator and electric unit (control unit) | | VDC OFF switch | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 21 | M5 | 1 | Existed |

5. Check the continuity between VDC OFF switch harness connector and ground.

| VDC OFF switch | | — | Continuity |
|----------------|----------|--------|-------------|
| Connector | Terminal | | |
| M5 | 1 | Ground | Not existed |
| | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-82, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace VDC OFF switch. Refer to [BRC-113, "Removal and Installation"](#).

3. CHECK TERMINALS AND HARNESS CONNECTORS

1. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check VDC OFF switch pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace error-detected parts.

4. CHECK VDC OFF SWITCH SIGNAL

Select "ABS", "DATA MONITOR" and "OFF SW" in order with CONSULT, and perform the VDC OFF switch inspection.

| Condition | OFF SW (DATA MONITOR) |
|--|-----------------------|
| Press the VDC OFF switch when VDC OFF indicator lamp is OFF. | On |
| Press the VDC OFF switch when VDC OFF indicator lamp is ON. | Off |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Component Inspection

INFOID:000000008452724

1. CHECK VDC OFF SWITCH

1. Turn the ignition switch OFF.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector.

| VDC OFF switch Terminal | Condition | Continuity |
|----------------------------|--------------------------------------|-------------|
| 1 - 2 | When VDC OFF switch is hold pressed. | Existed |
| | When releasing VDC OFF switch. | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace VDC OFF switch. Refer to [BRC-113. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000008452725

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Description

INFOID:000000008452726

×: ON –: OFF

| Condition | ABS warning lamp |
|---|------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × |
| 1 second later after turning ignition switch ON | – |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000008452727

1. CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

CAUTION:

Never start the engine.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-83, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008452728

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check item displayed by self-diagnosis.

2. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-29, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452729

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

BRAKE WARNING LAMP

Description

INFOID:000000008452730

×: ON –: OFF

| Condition | Brake warning lamp (Note 1) |
|---|-----------------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × (Note 2) |
| 1 second later after turning ignition switch ON | × (Note 2) |
| ABS function is malfunctioning. | – |
| EBD function is malfunctioning. | × |

NOTE:

- 1: Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting the engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000008452731

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

CAUTION:

Never start the engine.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-84, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

NOTE:

Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-79, "Component Inspection"](#).

Diagnosis Procedure

INFOID:000000008452732

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check item displayed by self-diagnosis.

2. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-29, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452733

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Description

INFOID:000000008452734

×: ON –: OFF

| Condition | VDC OFF indicator lamp |
|--|------------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × |
| 1 second later after turning ignition switch ON | – |
| VDC OFF switch turned ON. (VDC function is OFF.) | × |
| VDC/TCS function is malfunctioning. | × |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000008452735

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

CAUTION:

Never start the engine.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-86. "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-82. "Component Inspection"](#).

Diagnosis Procedure

INFOID:000000008452736

1.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-29. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452737

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9. "Special Repair Requirement"](#)

>> END

VDC WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC WARNING LAMP

Description

INFOID:000000008452738

×: ON △: Blink -: OFF

| Condition | VDC warning lamp |
|---|------------------|
| Ignition switch OFF | - |
| For 1 second after turning ignition switch ON | × |
| 1 second later after turning ignition switch ON | - |
| VDC/TCS is activated while driving | △ |
| VDC/TCS function is malfunctioning. | × |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000008452739

1. CHECK VDC WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

CAUTION:

Never start the engine.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-87, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008452740

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-29, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109, "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000008452741

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-9, "Special Repair Requirement"](#)

>> END

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000008452742

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor item | Display content | Data monitor | |
|---------------|---|--|--|
| | | Condition | Reference value in normal operation |
| FR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 1\%$ or less) |
| RR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| RR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| BATTERY VOLT | Battery voltage supplied to the ABS actuator and electric unit (control unit) | Ignition switch ON | 10 – 16 V |
| STOP LAMP SW | Stop lamp switch signal status | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| OFF SW | VDC OFF switch ON/OFF | VDC OFF switch ON (When VDC OFF indicator lamp is ON) | On |
| | | VDC OFF switch OFF (When VDC OFF indicator lamp is OF) | Off |
| GEAR | Gear position determined by TCM | 1st gear | 0 |
| | | 2nd gear | 1 |
| | | 3rd gear | 2 |
| | | 4th gear | 3 |
| | | 5th gear | 4 |
| | | 6th gear | 5 |
| | | 7th gear | 6 |
| | | 8th gear | 7 |
| | | Other | 0 |
| SLCT LVR POSI | Sift lever position determined by TCM | Ignition switch ON | P, R, N, D |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------------------|---|--|-------------------------------------|
| | | Condition | Reference value in normal operation |
| YAW RATE SEN | Yaw rate detected by yaw rate/side G sensor | Vehicle stopped | Approx. 0 d/s |
| | | Turning right | Negative value |
| | | Turning left | Positive value |
| FR RH IN SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR RH OUT SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH IN SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH OUT SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH IN SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH OUT SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH IN SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH OUT SOL (Note 2) | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| MOTOR RELAY | Motor and motor relay operation | When the motor relay and motor are operating | On |
| | | When the motor relay and motor are not operating | Off |
| ACTUATOR RLY (Note 2) | Actuator relay operation | When the actuator relay is operating | On |
| | | When the actuator relay is not operating | Off |
| ABS WARN LAMP (Note 3) | ABS warning lamp | When ABS warning lamp is ON | On |
| | | When ABS warning lamp is OFF | Off |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------|--|---|--|
| | | Condition | Reference value in normal operation |
| OFF LAMP | VDC OFF indicator lamp (Note 3) | When VDC OFF indicator lamp is ON | On |
| | | When VDC OFF indicator lamp is OFF | Off |
| SLIP/VDC LAMP | VDC warning lamp (Note 3) | When VDC warning lamp is ON | On |
| | | When VDC warning lamp is OFF | Off |
| PRESS SENSOR | Brake fluid pressure detected by pressure sensor | With ignition switch turned ON and brake pedal released | Approx. 0 bar |
| | | With ignition switch turned ON and brake pedal depressed | -40 to 300 bar |
| ACCEL POS SIG | Throttle actuator opening/closing is displayed (linked with accelerator pedal) | Accelerator pedal not depressed (ignition switch is ON) | 0 % |
| | | Depress accelerator pedal (ignition switch is ON) | 0 - 100 % |
| SIDE G-SENSOR | Transverse G detected by side G sensor | Vehicle stopped | Approx. 0 m/s ² |
| | | Turning right | Negative value |
| | | Turning left | Positive value |
| STR ANGLE SIG | Steering angle detected by steering angle sensor | Driving straight | ±2.5° |
| | | Turn 90° to right | Approx. +90° |
| | | Turn 90° to left | Approx. -90° |
| ENGINE RPM | With engine running | With engine stopped | 0 [tr/min (rpm)] |
| | | Engine running | Almost in accordance with tachometer display |
| FLUID LEV SW | Brake fluid level switch signal status | When brake fluid level switch ON | On |
| | | When brake fluid level switch OFF | Off |
| EBD WARN LAMP | Brake warning lamp (Note 3) | When brake warning lamp is ON | On |
| | | When brake warning lamp is OFF | Off |
| CV1 | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| CV2 | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| SV1 | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| SV2 | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------|--|--|-------------------------------------|
| | | Condition | Reference value in normal operation |
| EBD SIGNAL | EBD operation | EBD is active | On |
| | | EBD is inactive | Off |
| ABS SIGNAL | ABS operation | ABS is active | On |
| | | ABS is inactive | Off |
| TCS SIGNAL | TCS operation | TCS is active | On |
| | | TCS is inactive | Off |
| VDC SIGNAL | VDC operation | VDC is active | On |
| | | VDC is inactive | Off |
| EBD FAIL SIG | EBD fail-safe signal | In EBD fail-safe | On |
| | | EBD is normal | Off |
| ABS FAIL SIG | ABS fail-safe signal | In ABS fail-safe | On |
| | | ABS is normal | Off |
| TCS FAIL SIG | TCS fail-safe signal | In TCS fail-safe | On |
| | | TCS is normal | Off |
| VDC FAIL SIG | VDC fail-safe signal | In VDC fail-safe | On |
| | | VDC is normal | Off |
| CRANKING SIG | Crank operation | Crank is active | On |
| | | Crank is inactive | Off |
| PARK BRAKE SW | Parking brake switch signal status | Parking brake switch is active | On |
| | | Parking brake switch is inactive | Off |
| V/R OUTPUT | Solenoid valve relay activated | When the solenoid valve relay is active (When ignition switch OFF) | On |
| | | When the solenoid valve relay is not active (in the fail-safe mode) | Off |
| M/R OUTPUT | Actuator motor and motor relay activated | When the actuator motor and motor relay are active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator motor and motor relay are inactive | Off |

NOTE:

- 1: Confirm tire pressure is normal.
- 2: A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.
- 3: On and off timing for warning lamp and indicator lamp.
 - ABS warning lamp: refer to [BRC-83, "Description"](#).
 - Brake warning lamp: refer to [BRC-84, "Description"](#).
 - VDC OFF indicator lamp: refer to [BRC-86, "Description"](#).
 - VDC warning lamp: refer to [BRC-87, "Description"](#).


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Wiring Diagram

INFOID:000000008452743

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



Fail-Safe

VDC, TCS

INFOID:000000008452744

JCFWM0746GB

2010/10/14

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

If VDC/TCS/ABS system malfunction electrically, VDC warning lamp are turned ON, and the condition of vehicle is the same as the condition of vehicles without VDC and TCS control.

CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for “ABS” with CONSULT.

ABS, EBD SYSTEM

If ABS malfunction electrically, ABS warning lamp, VDC warning lamp will turn ON. If EBD malfunction electrically, brake warning lamp, ABS warning lamp, and VDC warning lamp will turn ON. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail safe function.

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for “Ignition switch ON” and “The first starting” are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

DTC Inspection Priority Chart

INFOID:000000008452745

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | Detected items (DTC) |
|----------|--|
| 1 | <ul style="list-style-type: none"> • U1000 CAN COMM CIRCUIT • U1002 SYSTEM COMM |
| 2 | <ul style="list-style-type: none"> • C1110 CONTROLLER FAILURE • C1153 EMERGENCY BRAKE • C1170 VARIANT CORDING |
| 3 | <ul style="list-style-type: none"> • C1130 ENGINE SIGNAL 1 • C1144 ST ANG SEN SIGNAL |
| 4 | <ul style="list-style-type: none"> • C1109 BATTERY VOLTAGE [ABNORMAL] • C1111 PUMP MOTOR • C1140 ACTUATOR RLY |
| 5 | <ul style="list-style-type: none"> • C1101 RR RH SENSOR-1 • C1102 RR LH SENSOR-1 • C1103 FR RH SENSOR-1 • C1104 FR LH SENSOR-1 • C1105 RR RH SENSOR-2 • C1106 RR LH SENSOR-2 • C1107 FR RH SENSOR-2 • C1108 FR LH SENSOR-2 • C1115 ABS SENSOR [ABNORMAL SIGNAL] • C1116 STOP LAMP SW • C1120 FR LH IN ABS SOL • C1121 FR LH OUT ABS SOL • C1122 FR RH IN ABS SOL • C1123 FR RH OUT ABS SOL • C1124 RR LH IN ABS SOL • C1125 RR LH OUT ABS SOL • C1126 RR RH IN ABS SOL • C1127 RR RH OUT ABS SOL • C1142 PRESS SEN CIRCUIT • C1143 ST ANG SEN CIRCUIT • C1145 YAW RATE SENSOR • C1146 SIDE G-SEN CIRCUIT • C1164 CV 1 • C1165 CV 2 • C1166 SV 1 • C1167 SV 2 |
| 6 | <ul style="list-style-type: none"> • C1155 BR FLUID LEVEL LOW |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

DTC Index

INFOID:000000008452746

| DTC | Items (CONSULT screen terms) | Reference |
|-------|------------------------------|-------------------------------------|
| C1101 | RR RH SENSOR-1 | BRC-28, "DTC Logic" |
| C1102 | RR LH SENSOR-1 | |
| C1103 | FR RH SENSOR-1 | |
| C1104 | FR LH SENSOR-1 | |
| C1105 | RR RH SENSOR-2 | BRC-31, "DTC Logic" |
| C1106 | RR LH SENSOR-2 | |
| C1107 | FR RH SENSOR-2 | |
| C1108 | FR LH SENSOR-2 | |
| C1109 | BATTERY VOLTAGE [ABNORMAL] | BRC-36, "DTC Logic" |
| C1110 | CONTROLLER FAILURE | BRC-38, "DTC Logic" |
| C1111 | PUMP MOTOR | BRC-39, "DTC Logic" |
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | BRC-41, "DTC Logic" |
| C1116 | STOP LAMP SW | BRC-46, "DTC Logic" |
| C1120 | FR LH IN ABS SOL | BRC-51, "DTC Logic" |
| C1121 | FR LH OUT ABS SOL | BRC-53, "DTC Logic" |
| C1122 | FR RH IN ABS SOL | BRC-51, "DTC Logic" |
| C1123 | FR RH OUT ABS SOL | BRC-53, "DTC Logic" |
| C1124 | RR LH IN ABS SOL | BRC-51, "DTC Logic" |
| C1125 | RR LH OUT ABS SOL | BRC-53, "DTC Logic" |
| C1126 | RR RH IN ABS SOL | BRC-51, "DTC Logic" |
| C1127 | RR RH OUT ABS SOL | BRC-53, "DTC Logic" |
| C1130 | ENGINE SIGNAL 1 | BRC-55, "DTC Logic" |
| C1140 | ACTUATOR RLY | BRC-57, "DTC Logic" |
| C1142 | PRESS SEN CIRCUIT | BRC-59, "DTC Logic" |
| C1143 | ST ANG SEN CIRCUIT | BRC-61, "DTC Logic" |
| C1144 | ST ANG SEN SIGNAL | BRC-63, "DTC Logic" |
| C1145 | YAW RATE SENSOR | BRC-64, "DTC Logic" |
| C1146 | SIDE G-SEN CIRCUIT | |
| C1153 | EMERGENCY BRAKE | BRC-38, "DTC Logic" |
| C1155 | BR FLUID LEVEL LOW | BRC-67, "DTC Logic" |
| C1164 | CV 1 | BRC-70, "DTC Logic" |
| C1165 | CV 2 | |
| C1166 | SV 1 | |
| C1167 | SV 2 | BRC-72, "DTC Logic" |
| C1170 | VARIANT CORDING | BRC-38, "DTC Logic" |
| U1000 | CAN COMM CIRCUIT | BRC-74, "DTC Logic" |
| U1002 | SYSTEM COMM | BRC-75, "DTC Logic" |

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

SYMPTOM DIAGNOSIS

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000008452747

1.CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-43. "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2.CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front: refer to [FAX-6. "Inspection"](#).
- Rear: refer to [RAX-4. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Wheel sensor harness connector connection.
- Wheel sensor harness inspection.
- Sensor rotor installation for damage.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace wheel sensor or sensor rotor.

- Front wheel sensor: refer to [BRC-106. "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear wheel sensor: refer to [BRC-107. "REAR WHEEL SENSOR : Exploded View"](#).
- Front sensor rotor: refer to [BRC-108. "FRONT SENSOR ROTOR : Removal and Installation"](#).
- Rear sensor rotor: refer to [BRC-108. "REAR SENSOR ROTOR : Removal and Installation"](#).

4.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned OFF for approximately 1 second after the ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

UNEXPECTED PEDAL REACTION

[VDC/TCS/ABS]

< SYMPTOM DIAGNOSIS >

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000008452748

1. CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >>
- Bleed air from brake tube and hose. Refer to [BR-11, "Bleeding Brake System"](#).
 - Check brake fluid leakage. Refer to [BR-10, "Inspection"](#).
 - Check brake pedal, brake booster, and master cylinder for mount play, looseness, etc.
 - Brake pedal: refer to [BR-18, "Inspection and Adjustment"](#).
 - Brake master cylinder: refer to [BR-27, "Inspection"](#).
 - Brake booster: refer to [BR-29, "Inspection and Adjustment"](#).
 - Front disc brake: refer to [BR-38, "BRAKE CALIPER ASSEMBLY : Inspection"](#).
 - Rear drum brake: refer to [BR-41, "Inspection and Adjustment"](#).

NO >> GO TO 2.

2. CHECK FUNCTION

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. Check if braking force is normal in this condition. Connect harness connector after inspection.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000008452749

CAUTION:

The stopping distance on slippery road surfaces might be longer when the ABS is operating than when the ABS is not operating.

1. CHECK FUNCTION

1. Turn the ignition switch OFF
2. Disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect harness connector.

Is the inspection result normal?

- YES >> Normal
NO >> Check brake system.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000008452750

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned OFF for approximately 1 second after the ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000008452751

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal. Refer to [BR-18, "Inspection and Adjustment"](#).

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Diagnosis Procedure

INFOID:000000008452752

1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Check corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT.

3.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector, and terminal for deformation, disconnection, looseness, etc.
3. Securely connect harness connectors and perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> If poor contact, damage, open or short circuit of harness connector is found, repair or replace.

4.CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-109. "Exploded View"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000008452753

| Symptom | Result |
|---|---|
| Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated. | This is a normal condition due to the VDC, TCS or ABS activation. |
| Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads. | |
| The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn. | |
| The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts. | This is a normal, and it is caused by the ABS operation check. |
| Depending on the road conditions, the driver may experience a sluggish feel. | This is normal, because TCS places the highest priority on the optimum traction (stability). |
| TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal. | |
| The ABS warning lamp and VDC warning lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running. | In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory. |
| VDC may not operate normally or the ABS warning lamp and VDC warning lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course). | |
| A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is OFF (VDC OFF indicator lamp illuminated). | |
| The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer. | Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.) |
| VDC warning lamp may simultaneously turn ON when low tire pressure warning lamp turns ON. | This is not a VDC system error but results from characteristic change of tire. |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008452754

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008452755

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for Brake System

INFOID:000000008452756

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.


- Brake fluid use refer to [MA-10, "Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.

PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

- Never use mineral oils such as gasoline or light oil. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a crow-foot (A) and torque wrench (B).
- Always conform the specified tightening torque when installing the brake pipes.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the affected part. If a malfunction is detected, replace part with a new one.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.



Precaution for Brake Control

INFOID:0000000008452757

- Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated.
- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- VDC system may not operate normally or a VDC warning lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

Precautions for Harness Repair


INFOID:0000000008452758

COMMUNICATION LINE

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



PRECAUTIONS


[VDC/TCS/ABS]

< PRECAUTION >

- Bypass connection is never allowed at the repaired area.

NOTE:

- Bypass connection may cause communication error as spliced wires that are separate from the main line or twisted lines lose noise immunity.
- Replace the applicable harness as an assembly if error is detected on the shield lines of communication line.



PREPARATION

< PREPARATION >

[VDC/TCS/ABS]


PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000008452759

| Tool name | Description |
|------------|--------------------------|
| Power tool | Loosening bolts and nuts |



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]


REMOVAL AND INSTALLATION

WHEEL SENSOR

FRONT WHEEL SENSOR

FRONT WHEEL SENSOR : Exploded View

INFOID:000000008452760



1. Front LH wheel sensor
2. Front LH wheel sensor harness connector

A. Color line

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000008452761

REMOVAL

1. Remove the fender protector. Refer to [EXT-21, "FENDER PROTECTOR : Exploded View"](#).
2. Remove the wheel sensor from steering knuckle.

CAUTION:

Never twist sensor harness as much as possible, when removing it. Pull wheel sensors out without pulling sensor harness.

3. Remove the wheel sensor harness from vehicle.

CAUTION:

Never twist sensor harness as much as possible, when removing it. Pull wheel sensors out without pulling sensor harness.

INSTALLATION

Note the following, and install in the reverse order of the removal.

- Make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor.

WHEEL SENSOR

< REMOVAL AND INSTALLATION >


[VDC/TCS/ABS]

- Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount. Replace the wheel sensor if necessary.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

REAR WHEEL SENSOR

REAR WHEEL SENSOR : Exploded View

INFOID:000000008452762



1. Rear LH wheel sensor

2. Rear LH wheel sensor harness connector

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

REAR WHEEL SENSOR : Removal and Installation

INFOID:000000008452763

REMOVAL

1. Remove wheel sensor from wheel hub and bearing assembly.
CAUTION:
Never twist sensor harness as much as possible, when removing it. Pull wheel sensors out without pulling sensor harness.
2. Remove wheel sensor harness from vehicle.
CAUTION:
Never twist sensor harness as much as possible, when removing it. Pull wheel sensors out without pulling sensor harness.

INSTALLATION

Note the following, and install in the reverse order of the removal.

- Make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor.
- Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount. Replace the wheel sensor if necessary.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SENSOR ROTOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000008452764

CAUTION:

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly.

REMOVAL

Remove the wheel hub and bearing assembly. Refer to [FAX-8, "Exploded View"](#).

INSTALLATION

Install the wheel hub and bearing assembly. Refer to [FAX-8, "Exploded View"](#).

FRONT SENSOR ROTOR : Disassembly and Assembly

INFOID:000000008452765

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly.

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000008452766

CAUTION:

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly.

REMOVAL

Remove the wheel hub and bearing assembly. Refer to [RAX-5, "Exploded View"](#).

INSTALLATION

Install the wheel hub and bearing assembly. Refer to [RAX-5, "Exploded View"](#).

REAR SENSOR ROTOR : Disassembly and Assembly

INFOID:000000008452767

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000008452768



A
B
C
D
E
F
G
H
I
J
K
L

BRC

- | | | |
|--|--------------------------------------|------------------------------------|
| 1. ABS actuator and electric unit (control unit) | 2. Harness connector | 3. Bushing |
| 4. Bracket | | |
| A. To front LH brake caliper | B. To rear RH wheel cylinder | C. To Rear LH wheel cylinder |
| D. To front RH brake caliper | E. To master cylinder secondary side | F. To master cylinder primary side |

← Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000008452769

REMOVAL

1. Disconnect the battery cable from negative terminal.
2. Remove cowl top cover and extension cowl top. Refer to [EXT-19, "Exploded View"](#).
3. Drain brake fluid. Refer to [BR-10, "Draining"](#).
4. Disconnect ABS actuator and electric unit (control unit) harness connector.
5. Loosen brake tube flare nuts, and then remove brake tubes from ABS actuator and electric unit (control unit). Refer to [BR-20, "FRONT : Exploded View"](#).
CAUTION:
Never scratch the flare nut and the brake tube.
6. Remove ABS actuator and electric unit (control unit) and bracket from vehicle.
CAUTION:
 - Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
 - Never remove actuator by holding harness.
7. Remove bracket and bush from ABS actuator and electric unit (control unit).

M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

INSTALLATION

Note the following, and install in the reverse order of removal.

- Install, use flare nut crowfoot and torque wrench. Refer to [BR-20, "FRONT : Exploded View"](#).

CAUTION:

Never scratch the flare nut and the brake tube.

- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never install actuator by holding harness.
- Installing harness connector in the ABS actuator and electric unit (control unit), make sure harness connector is securely locked.

Adjustment

INFOID:000000008452770

ADJUSTMENT AFTER INSTALLATION

1. Refill with new brake fluid and perform the air bleeding. Refer to [BR-11, "Bleeding Brake System"](#).

CAUTION:

Never reuse drained brake fluid.

2. When replacing ABS actuator and electric unit (control unit), make sure adjust neutral position of steering angle sensor. Refer to [BRC-9, "Description"](#).

YAW RATE/SIDE G SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

YAW RATE/SIDE G SENSOR

Exploded View

INFOID:000000008452771



1. Yaw rate/side G sensor

← Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000008452772

REMOVAL

CAUTION:

- **Never drop or strike yaw rate/side G sensor, or never use power tool etc., because yaw rate/side G sensor is sensitive to the impact.**

1. Remove front (left side) seat. Refer to [SE-15, "Exploded View"](#).
2. Remove dash side finisher and front kicking plate inner. Refer to [INT-16, "Exploded View"](#).
3. Remove floor trim. Refer to [INT-19, "Exploded View"](#).
4. Disconnect yaw rate/side G sensor harness connector.
5. Remove yaw rate/side G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

- **Never drop or strike yaw rate/side G sensor, or never use power tool etc., because yaw rate/side G sensor is sensitive to the impact.**

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

STEERING ANGLE SENSOR

Exploded View

INFOID:000000008452773



1. Steering angle sensor

↔: Vehicle front

Refer to [GI-4, "Components"](#) for the symbols in the figure.

Removal and Installation

INFOID:000000008452774

REMOVAL

1. Remove spiral cable assembly. Refer to [SR-13, "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never reuse steering angle sensor.

Adjustment

INFOID:000000008452775

Make sure to adjust neutral position of steering angle sensor. Refer to [BRC-9, "Description"](#).

VDC OFF SWITCH

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

VDC OFF SWITCH

Removal and Installation

INFOID:000000008452776

REMOVAL

1. Remove Instrument lower panel LH. Refer to [IP-12, "Exploded View"](#).
2. Remove VDC OFF switch.

INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P