

CO

SECTION

ENGINE COOLING SYSTEM

CONTENTS

SYSTEM DESCRIPTION	2	REMOVAL AND INSTALLATION	15	
DESCRIPTION	2	RADIATOR	15	
Engine Cooling System	2	Exploded View	15	
Engine Cooling System Schematic	3	Removal and Installation	15	
SYMPTOM DIAGNOSIS	4	Inspection	17	
OVERHEATING CAUSE ANALYSIS	4	COOLING FAN	18	
Troubleshooting Chart	4	Exploded View	18	
PRECAUTION	6	Removal and Installation	18	
PRECAUTIONS	6	Disassembly and Assembly	19	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	6	Inspection	19	
Precautions Necessary for Steering Wheel Rotation After Battery Disconnection	6	WATER PUMP	20	
PREPARATION	8	Exploded View	20	
PREPARATION	8	Removal and Installation	20	
Commercial Service Tools	8	Inspection	20	
PERIODIC MAINTENANCE	9	THERMOSTAT	22	
ENGINE COOLANT	9	Exploded View	22	
Inspection	9	Removal and Installation	22	
Draining	9	Inspection	23	
Refilling	10	WATER OUTLET	24	
Flushing	11	Exploded View	24	
RADIATOR	13	Removal and Installation	24	
RADIATOR CAP	13	Inspection	25	
RADIATOR CAP : Inspection	13	SERVICE DATA AND SPECIFICATIONS (SDS)	26	
RADIATOR	13	SERVICE DATA AND SPECIFICATIONS (SDS)	26	
RADIATOR : Inspection	13	Periodical Maintenance Specification	26	
		Radiator	26	
		Thermostat	26	
		Water Control Valve	26	

DESCRIPTION

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

DESCRIPTION


Engine Cooling System

INFOID:000000008450503

M/T models



CVT models





DESCRIPTION

< SYSTEM DESCRIPTION >

Engine Cooling System Schematic

INFOID:000000008450504

A
CO
C
D
E
F
G
H
I
J
K
L
M
N
O
P



OVERHEATING CAUSE ANALYSIS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

OVERHEATING CAUSE ANALYSIS

Troubleshooting Chart

INFOID:000000008450505

Symptom		Check items	
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt
		Thermostat and water control valve stuck closed	—
		Damaged fins	Dust contamination or paper clogging
			Physical damage
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)
	Reduced air flow	Cooling fan does not operate	Fan assembly
		High resistance to fan rotation	
		Damaged fan blades	
	Damaged radiator shroud	—	—
	Improper engine coolant mixture ratio	—	—
	Poor engine coolant quality	—	Engine coolant viscosity
	Insufficient engine coolant	Cooling hose	Loose clamp
			Cracked hose
		Water pump	Poor sealing
		Radiator cap	Loose
			Poor sealing
		Radiator	O-ring for damage, deterioration or improper fitting
			Cracked radiator tank
			Cracked radiator core
		Reservoir tank	Cracked reservoir tank
	Overflowing reservoir tank	Exhaust gas leakage into cooling system	Cylinder head deterioration
			Cylinder head gasket deterioration

OVERHEATING CAUSE ANALYSIS

< SYMPTOM DIAGNOSIS >

	Symptom		Check items	
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load
				Driving in low gear for extended time
				Driving at extremely high speed
			Power train system malfunction	—
			Installed improper size wheels and tires	
			Dragging brakes	
			Improper ignition timing	
	Blocked or restricted air flow	Blocked bumper	—	—
		Blocked radiator grille	Installed car brassiere	
			Mud contamination or paper clogging	
		Blocked radiator	—	
		Blocked condenser	Blocked air flow	
		Installed large fog lamp		

A

CO

C

D

E

F

G

H

I

J

K

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008450506

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation After Battery Disconnection

INFOID:000000008450507

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the ignition switch to ACC position.
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.

PRECAUTIONS

< PRECAUTION >

4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT.

A

CO

C

D

E

F

G

H

I

J

K

L

M

N

O

P

PREPARATION



< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000008450508

Tool name	Description
<p>Radiator cap tester</p>  <p>PBIC1982E</p>	<p>Checking radiator and radiator cap</p>
<p>Radiator cap tester adapter</p>  <p>S-NT564</p>	<p>Adapting radiator cap tester to radiator cap and radiator filler neck</p> <p>a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)</p>

ENGINE COOLANT

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

ENGINE COOLANT

Inspection

INFOID:0000000008450509

LEVEL

- Check that the reservoir tank engine coolant level is within the "MIN" to "MAX" when the engine is cool.


A : MAX

B : MIN

- Adjust the engine coolant level if necessary.

CAUTION:

Refill Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent in its quality mixed with water (distilled or demineralized). Refer to [MA-10, "Fluids and Lubricants"](#).



LEAKAGE

- To check for leakage, apply pressure to the cooling system with the radiator cap tester (commercial service tool) (A) and the radiator cap tester adapter (commercial service tool) (B).

Testing pressure: Refer to [CO-26, "Radiator"](#).

WARNING:

Never remove radiator cap when engine is hot. Serious burns may occur from high-pressure engine coolant escaping from engine cooling system.


CAUTION:

Higher test pressure than specified may cause radiator damage.

NOTE:

In a case that engine coolant decreases, replenish radiator with engine coolant.

- If anything is found, repair or replace damaged parts.



Draining

INFOID:0000000008450510

WARNING:

- Never remove radiator cap when engine is hot. Serious burns may occur from high-pressure engine coolant escaping from radiator.
- Wrap a thick cloth around the radiator cap. Slowly turn it a quarter of a turn to release built-up pressure. Then turn it all the way.


- Remove engine under cover.
- Open radiator drain plug (A) at the bottom of radiator, and then remove radiator cap.

← : Vehicle front

CAUTION:

Perform this step when engine is cold.

- When draining all of engine coolant in the system, open water drain plugs on cylinder block. Refer to [EM-89, "Disassembly and Assembly"](#).



- Remove reservoir tank if necessary, and drain engine coolant and clean reservoir tank before installing. Refer to [CO-15, "Exploded View"](#).

ENGINE COOLANT

< PERIODIC MAINTENANCE >

4. Check drained engine coolant for contaminants such as rust, corrosion or discoloration. If contaminated, flush the engine cooling system. Refer to [CO-11, "Flushing"](#).

Refilling

INFOID:000000008450511

CAUTION:

- Do not reuse O-rings.
- Do not put additive such as waterleak preventive, since it may cause cooling waterway clogging.
- When refilling use Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent in its quality mixed with water (distilled or demineralized). Refer to [MA-10, "Fluids and Lubricants"](#).

1. Install reservoir tank if removed and radiator drain plug.

CAUTION:


Be sure to clean drain plug and install with new O-ring.

Radiator drain plug : Refer to [CO-15, "Exploded View"](#).

- If water drain plugs on cylinder block are removed, close and tighten them. Refer to [EM-89, "Disassembly and Assembly"](#).
2. Check that each hose clamp has been firmly tightened.
 3. Remove air duct (between air cleaner case and electric throttle control actuator). Refer to [EM-24, "Exploded View"](#).
 4. Disconnect heater hose (1) at position (◀) in the figure.

◀ : Vehicle front

- Enhance heater hose as high as possible.




5. Fill radiator (1) to specified level.

CAUTION:

Never adhere the engine coolant to electronic equipments (alternator etc.).

- Pour coolant slowly of less than 2 ℓ (2-1/8 US qt, 1-3/4 Imp qt) a minute to allow air in system to escape.
- When engine coolant overflows disconnected heater hose, connect heater hose, and continue filling the engine cooling system.



Engine coolant capacity

(With reservoir tank at "MAX" level)

Refer to [CO-26, "Periodical Maintenance Specification"](#).

6. Refill reservoir tank to "MAX" level line with engine coolant.


A : MAX

B : MIN

Reservoir tank engine coolant capacity

(At "MAX" level)

Refer to [CO-26, "Periodical Maintenance Specification"](#).



ENGINE COOLANT

< PERIODIC MAINTENANCE >

7. Install air duct (between air cleaner case and electric throttle control actuator). Refer to [EM-24, "Exploded View"](#).
8. Install radiator cap.
9. Warm up engine until opening thermostat. Standard for warming-up time is approximately 10 minutes at 3,000 rpm.
 - Check thermostat opening condition by touching radiator hose (lower) to see a flow of warm water.**CAUTION:**
Watch water temperature gauge so as not to overheat engine.
10. Stop the engine and cool down to less than approximately 50°C (122°F).
 - Cool down using fan to reduce the time.
 - If necessary, refill radiator up to filler neck with engine coolant.**CAUTION:**
Never adhere the engine coolant to electronic equipments (alternator etc.).
11. Refill reservoir tank to "MAX" level line with engine coolant.
12. Repeat steps 5 through 10 two or more times with radiator cap installed until engine coolant level no longer drops.
13. Check cooling system for leakage with engine running.
14. Warm up the engine, and check for sound of engine coolant flow while running engine from idle up to 3,000 rpm with heater temperature controller set at several position between "COOL" and "WARM".
 - Sound may be noticeable at heater unit.
15. Repeat step 14 three times.
16. If sound is heard, bleed air from cooling system by repeating step 5 through 10 until reservoir tank level no longer drops.

Flushing

INFOID:000000008450512


1. Install reservoir tank if removed and radiator drain plug.
CAUTION:
Be sure to clean drain plug and install with new O-ring.

Radiator drain plug : Refer to [CO-15, "Exploded View"](#).

- If water drain plugs on cylinder block are removed, close and tighten them. Refer to [EM-89, "Disassembly and Assembly"](#).
2. Remove air duct (between air cleaner case and electric throttle control actuator). Refer to [EM-24, "Exploded View"](#).
 3. Disconnect heater hose (1) at position (↔) in the figure.

↔ : Vehicle front

- Enhance heater as high as possible.



4. Fill radiator and reservoir tank with water and reinstall radiator cap.
 - When engine coolant over flows disconnected heater hose, connect heater hose, and continue filling the engine coolant.
5. Install air duct (between air cleaner case and electric throttle control actuator). Refer to [EM-24, "Exploded View"](#).
6. Run the engine and warm it up to normal operating temperature.
7. Rev the engine two or three times under no-load.
8. Stop the engine and wait until it cools down.
9. Drain water from the system. Refer to [CO-9, "Draining"](#).

ENGINE COOLANT

< PERIODIC MAINTENANCE >

10. Repeat steps 1 through 9 until clear water begins to drain from radiator.

RADIATOR

< PERIODIC MAINTENANCE >

RADIATOR

RADIATOR CAP


RADIATOR CAP : Inspection

INFOID:000000008450513


- Check valve seat (A) of radiator cap.

B : Metal plunger

- Check that valve seat is swollen to the extent that the edge of the plunger cannot be seen when watching it vertically from the top.
- Check that valve seat has no soil and damage.




- Pull negative-pressure valve to open it, and that it close completely when released.
- Check that there is no dirt or damage on the valve seat of radiator cap negative-pressure valve.
- Check that there are no unusualness in the opening and closing conditions of negative-pressure valve.



- Check radiator cap relief pressure.

Standard and Limit : Refer to [CO-26, "Radiator"](#).

- When connecting radiator cap to the radiator cap tester (commercial service tool) (A) and the radiator cap tester adapter (commercial service tool) (B), apply engine coolant to the cap seal surface.



- Replace radiator cap if there is an unusualness related to the above three.

CAUTION:

When installing radiator cap, thoroughly wipe out the radiator filler neck to remove any waxy residue or foreign material.

RADIATOR

RADIATOR : Inspection

INFOID:000000008450514

Check radiator for mud or clogging. If necessary, clean radiator as follows.

CAUTION:

- **Be careful not to bend or damage radiator fins.**
 - **When radiator is cleaned without removal, remove all surrounding parts such as radiator cooling fan assembly and horns. Then tape harness and harness connectors to prevent water from entering.**
1. Apply water by hose to the back side of the radiator core vertically downward.
 2. Apply water again to all radiator core surfaces once per minute.
 3. Stop washing if any stains no longer flow out from radiator.

RADIATOR

< PERIODIC MAINTENANCE >

4. Blow air into the back side of radiator core vertically downward.
 - Use compressed air lower than 490 kPa (5 kg/cm², 71 psi) and keep distance more than 30 cm (11.81 in).
5. Blow air again into all the radiator core surfaces once per minute until no water sprays out.

RADIATOR


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

RADIATOR

Exploded View

INFOID:000000008450515



- | | | |
|--------------------------|----------------------------|----------------------------|
| 1. Reservoir tank cap | 2. Reservoir tank | 3. Radiator hose (upper) |
| 4. Clamp | 5. Mounting rubber (upper) | 6. Radiator cap |
| 7. Reservoir tank hose | 8. Radiator | 9. Mounting rubber (lower) |
| 10. O-ring | 11. Drain plug | 12. Radiator hose (lower) |
| 13. Cooling fan assembly | | |

A. To water outlet

B. To water inlet

⊗ : Always replace after every disassembly.

⊙ : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000008450516

REMOVAL

WARNING:

- Never remove radiator cap when engine is hot. Serious burns may occur from high-pressure engine coolant escaping from engine cooling system.
- Wrap a thick cloth around the radiator cap. Slowly turn it a quarter of a turn to release built-up pressure. Then turn it all the way.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Drain engine coolant from radiator. Refer to [CO-9, "Draining"](#).


RADIATOR

< REMOVAL AND INSTALLATION >

CAUTION:

- Perform this step when the engine is cold.
- Never spill engine coolant on drive belt.

2. Remove air duct (inlet) and resonator assembly. Refer to [EM-24, "Exploded View"](#).
3. Remove reservoir tank as follows:
 - a. Disconnect reservoir tank hose.
 - b. Release the tab (A) in the direction shown by the arrow (←).
 - c. Lift up and remove the reservoir tank with tab released.



4. Remove radiator hose (upper and lower).
5. Disconnect harness connector from fan motor, and move harness aside.
6. Remove cooling fan assembly.

CAUTION:

Be careful not to damage or scratch the radiator core.


7. Remove the following parts.
 - Front grille assembly: Refer to [EXT-17, "Exploded View"](#).
 - Front bumper fascia assembly: Refer to [EXT-11, "Exploded View"](#).
 - Front combination lamp assembly (RH and LH): Refer to [EXL-168, "Exploded View"](#).
8. Remove radiator core support (upper). Refer to [DLK-162, "Exploded View"](#) (WITH INTELLIGENT KEY STSTEM) or [DLK-294, "Exploded View"](#) (WITHOUT INTELLIGENT KEY STSTEM).
9. Pull up and remove the radiator assembly (1).

2 : Condenser assembly

← : Vehicle front

CAUTION:

Be careful not to damage radiator core and condenser assembly core.



INSTALLATION


CAUTION:

Do not reuse O-rings.

Note the following, and install in the reverse order of removal.

NOTE:

- Insert the radiator hose (1) all the way to the stopper (2) or by 33 mm (1.30 in) (hose without a stopper).



RADIATOR

< REMOVAL AND INSTALLATION >

Unit mm (in)


A. Radiator side

B. Engine side

- For the orientation of the hose clamp pawl, refer to the figure.

Radiator hose	Hose end	Paint mark	Position of hose clamp*
Radiator hose (upper)	Radiator side	Upper	A
	Engine side	Upper	B
Radiator hose (lower)	Radiator side	Lower	C
	Engine side	Upper	D

*Refer to the illustrations for the specific position each hose clamp tab.




E. View E

f. 45°

↖ : Vehicle upper


- The angle (b) created by the hose clamp pawl and the specified line (A) must be within $\pm 30^\circ$ as shown in the figure.



- To install hose clamps (1), check that the dimension (A) from the end of the paint mark (2) on the radiator hose to the hose clamp is within the reference value.

Dimension "A"

3 mm (0.12 in)



Inspection

INFOID:000000008450517

INSPECTION AFTER INSTALLATION


- Check for leakage of engine coolant using the radiator cap tester adapter (commercial service tool) and the radiator cap tester (commercial service tool). Refer to [CO-9. "Inspection"](#).
- Start and warm up the engine. Check visually that there is no leakage of engine coolant.

< REMOVAL AND INSTALLATION >

COOLING FAN


Exploded View


INFOID:0000000008450518



1. Fan motor 2. Fan shroud 3. Cooling fan

A. Apply on fan motor shaft

 : Apply genuine high strength thread locking sealant or equivalent.


 : N·m (kg-m, in-lb)

Removal and Installation

INFOID:0000000008450519

REMOVAL

1. Drain engine coolant from radiator. Refer to [CO-9, "Draining"](#).
CAUTION:
 - **Perform this step engine is cold.**
 - **Never spill engine coolant on drive belt.**
2. Remove air duct (inlet) and resonator assembly. Refer to [EM-24, "Exploded View"](#).
3. Remove reservoir tank as follows:
 - a. Disconnect reservoir tank hose.
 - b. Release the tab (A) in the direction shown by the arrow (←).
 - c. Lift up and remove the reservoir tank with the tab released.



4. Remove radiator hose (upper). Refer to [CO-15, "Exploded View"](#).
5. Disconnect harness connector from fan motor, and move harness to aside.
6. Remove cooling fan assembly.

COOLING FAN

< REMOVAL AND INSTALLATION >

Be careful not to damage or scratch on radiator core when removing.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

Only use genuine parts for fan shroud mounting bolt and observe the specified torque (to prevent radiator from being damaged).

NOTE:

Cooling fan is controlled by ECM. For details, refer to [EC-79. "System Diagram"](#).

Disassembly and Assembly

INFOID:0000000008450520

DISASSEMBLY

1. Remove cooling fan mounting nut, and then remove the cooling fan.
2. Remove fan motor.

ASSEMBLY

Note the following, and assemble in the reverse order of disassembly.

- Apply genuine high strength thread locking sealant on fan motor shaft.

Inspection

INFOID:0000000008450521

INSPECTION AFTER DISASSEMBLY

Cooling Fan

Inspect cooling fan for crack or unusual bend.

- If anything is found, replace cooling fan.

A

CO

C

D

E

F

G

H

I

J

K

L

M

N

O

P


WATER PUMP

< REMOVAL AND INSTALLATION >


WATER PUMP

Exploded View

INFOID:0000000008450522



1. Water pump 2. Gasket

 : Always replace after every disassembly.

Removal and Installation

INFOID:0000000008450523

REMOVAL

1. Drain engine coolant from radiator. Refer to [CO-9, "Draining"](#).
CAUTION:
 - Perform this step when the engine is cold.
 - Never spill engine coolant on drive belt.
2. Remove front fender protector (RH). Refer to [EXT-21, "FENDER PROTECTOR : Exploded View"](#).
3. Remove drive belt. Refer to [EM-13, "Removal and Installation"](#).
4. Remove water pump.
 - Engine coolant leakage from cylinder block, so have a receptacle ready below.**CAUTION:**
 - Handle water pump vane so that it does not contact any other parts.
 - Water pump cannot be disassembled and should be replaced as a unit.

INSTALLATION


Install in the reverse order of removal.

Inspection

INFOID:0000000008450524

INSPECTION AFTER REMOVAL

- Check visually that there is no significant dirt or rusting on water pump body and vane (A).
- Check that there is no looseness in vane shaft, and that it turns smoothly when rotated by hand.
- Replace water pump, if necessary.



WATER PUMP

< REMOVAL AND INSTALLATION >

INSPECTION AFTER INSTALLATION

- Check for leakage of engine coolant using the radiator cap tester adapter (commercial service tool) and the radiator cap tester (commercial service tool). Refer to [CO-9, "Inspection"](#).
- Start and warm up the engine. Check visually that there is no leakage of engine coolant.

A
CO
C
D
E
F
G
H
I
J
K
L
M
N
O
P


THERMOSTAT

< REMOVAL AND INSTALLATION >

THERMOSTAT

Exploded View

INFOID:000000008450525



- | | | |
|----------------|------------------------|--------------------------|
| 1. Gasket | 2. Thermostat housing | 3. Clamp |
| 4. Water hose | 5. Rubber ring | 6. Thermostat |
| 7. Water inlet | 8. Clamp | 9. Radiator hose (lower) |
| A. CVT models | B. To CVT fluid cooler | C. To radiator |

⊗ : Always replace after every disassembly.

⌘ : N·m (kg-m, ft-lb)

Removal and Installation

INFOID:000000008450526

REMOVAL

1. Drain engine coolant from radiator. Refer to [CO-9, "Draining"](#).
CAUTION:
Perform this step when engine is cold.
2. Remove air duct (inlet) and resonator assembly. Refer to [EM-24, "Exploded View"](#).
3. Add paint mark, then disconnect radiator hose (lower) from water inlet. Refer to [CO-15, "Exploded View"](#).
4. Remove water inlet and thermostat.
 - Engine coolant leakage from cylinder block, so have a receptacle ready below.
5. Remove thermostat housing with the following procedure:
 - a. Remove A/C compressor with A/C piping connected, and temporarily fasten it on vehicle with a rope. Refer to [HA-31, "Exploded View"](#). (Models with A/C)
 - b. Remove water pump. Refer to [CO-20, "Exploded View"](#).
 - c. Remove alternator. Refer to [CHG-25, "Exploded View"](#).

INSTALLATION


Note the following, and install in the reverse order of removal.

Thermostat

THERMOSTAT


< REMOVAL AND INSTALLATION >

- Install thermostat with making rubber ring (1) groove fit to thermostat flange (A) with the whole circumference.



- Install thermostat (1) with jiggle valve (A) facing upwards.

2 : Thermostat housing



Inspection

INFOID:000000008450527


INSPECTION AFTER REMOVAL

Thermostat

- Place a thread (A) so that it is caught in the valves of thermostat (1). Immerse fully in a container (B) filled with water. Heat while stirring.
- The valve opening temperature is the temperature at which the valve opens and falls from the thread.
- Continue heating. Check the full open valve lift amount.
- After checking the maximum valve lift amount, lower the water temperature and check the valve closing temperature.

Standard: Refer to [CO-26, "Thermostat"](#).

- If out of the standard, replace thermostat.



INSPECTION AFTER INSTALLATION

- Check for leakage of engine coolant using the radiator cap tester adapter (commercial service tool) and the radiator cap tester (commercial service tool). Refer to [CO-9, "Inspection"](#).
- Start and warm up the engine. Check visually that there is no leakage of engine coolant.


WATER OUTLET

< REMOVAL AND INSTALLATION >

WATER OUTLET

Exploded View

INFOID:000000008450528



- | | | |
|--------------------------------------|------------------------------------------|------------------|
| 1. Engine coolant temperature sensor | 2. Washer | 3. Water hose |
| 4. Clamp | 5. Water hose | 6. Gasket |
| 7. Water control valve | 8. Rubber ring | 9. Clamp |
| 10. Radiator hose (upper) | 11. Water hose | 12. Clamp |
| 13. Clamp | 14. Heater hose | 15. Water outlet |
| 16. Heater hose | | |
| A. To heater | B. To electric throttle control actuator | C. To radiator |
| D. CVT models | E. To CVT fluid cooler | |

← : Engine front

⊗ : Always replace after every disassembly.

⌘ : N·m (kg-m, ft-lb)

Removal and Installation

INFOID:000000008450529

REMOVAL

- Drain engine coolant from radiator. Refer to [CO-9, "Draining"](#).
CAUTION:
 - Perform this step when engine is cold.
 - Never spill engine coolant on drive belt.
- Remove air duct (inlet) and resonator assembly and each air ducts. Refer to [EM-24, "Exploded View"](#).
- Disconnect radiator hose (upper). Refer to [CO-15, "Exploded View"](#).

WATER OUTLET


< REMOVAL AND INSTALLATION >

4. Disconnect harness connector from engine coolant temperature sensor.
5. Remove water hoses.
6. Remove heater hoses.
7. Remove water outlet.
8. Remove engine coolant temperature sensor from water outlet, if necessary.


INSTALLATION

Note the following, and install in the reverse order of removal.

- Install water control valve with making rubber ring (1) groove fit to water control valve flange (A) with the whole circumference.



- Install water control valve (2) with the arrow (A) facing up and the frame center part (B) facing upwards.



1 : Water outlet

Inspection

INFOID:000000008450530


INSPECTION AFTER REMOVAL

Water Control Valve

- Place a thread (A) so that it is caught in the valves of water control valve (1). Immerse fully in a container (B) filled with water. Heat while stirring.
- The valve opening temperature is the temperature at which the valve opens and falls from the thread.
- Continue heating. Check the continuous valve lifting toward maximum valve lift.

NOTE:

- The maximum valve lift amount standard temperature for water control valve is the reference value.
- After checking the maximum valve lift amount, lower the water temperature and check the valve closing temperature.



Standard: Refer to [CO-26, "Water Control Valve"](#).

- If out of the standard, replace water control valve.

INSPECTION AFTER INSTALLATION

- Check for leakage of engine coolant using the radiator cap tester adapter (commercial service tool) and the radiator cap tester (commercial service tool). Refer to [CO-9, "Inspection"](#).
- Start and warm up the engine. Check visually that there is no leakage of engine coolant.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Periodical Maintenance Specification

INFOID:0000000008450531

ENGINE COOLANT CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

Engine coolant capacity (With reservoir tank at "MAX" level)	CVT models	7.1 (7-1/2, 6-1/4)
	M/T models	6.8 (7-1/4, 6)
Reservoir tank engine coolant capacity (At "MAX" level)		0.7 (3/4, 5/8)

Radiator

INFOID:0000000008450532

Unit: kPa (kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 (0.6, 9)
Leakage testing pressure		98 (1.0, 14)

Thermostat

INFOID:0000000008450533

Standard

Valve opening temperature	80.5 - 83.5°C (177 - 182°F)
Maximum valve lift	8.0 mm/95°C (0.315 in/203°F)
Valve closing temperature	77°C (171°F)

Water Control Valve

INFOID:0000000008450534

Standard

Valve opening temperature	93.5 - 96.5°C (200 - 206°F)
Maximum valve lift	8.0 mm/108°C (0.315 in/226°F)
Valve closing temperature	90°C (194°F)