

SECTION **DEF**  
**DEFOGGER**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

CONTENTS

<b>BASIC INSPECTION</b> .....	3	<b>WITHOUT INTELLIGENT KEY</b> .....	15
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	3	WITHOUT INTELLIGENT KEY : Diagnosis De-	
Work Flow .....	3	scription .....	15
<b>SYSTEM DESCRIPTION</b> .....	4	WITHOUT INTELLIGENT KEY : CONSULT Func-	
<b>REAR WINDOW DEFOGGER SYSTEM</b> .....	4	tion (IPDM E/R) .....	17
System Diagram .....	4	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	20
System Description .....	4	<b>REAR WINDOW DEFOGGER SWITCH</b> .....	20
Component Parts Location .....	4	<b>WITH AUTO A/C</b> .....	20
Component Description .....	5	WITH AUTO A/C : Component Function Check .....	20
<b>DIAGNOSIS SYSTEM (BCM) (WITH INTELLI-</b>		WITH AUTO A/C : Diagnosis Procedure .....	20
<b>GENENT KEY SYSTEM)</b> .....	6	WITH AUTO A/C : Component Inspection .....	21
<b>COMMON ITEM</b> .....	6	<b>WITH MANUAL A/C</b> .....	21
COMMON ITEM : CONSULT Function (BCM -		WITH MANUAL A/C : Component Function Check	
COMMON ITEM) .....	6	.....	21
<b>REAR WINDOW DEFOGGER</b> .....	7	WITH MANUAL A/C : Diagnosis Procedure .....	21
REAR WINDOW DEFOGGER : CONSULT Func-		WITH MANUAL A/C : Component Inspection .....	23
tion (BCM - REAR DEFOGGER) .....	7	<b>REAR WINDOW DEFOGGER RELAY</b> .....	24
<b>DIAGNOSIS SYSTEM (BCM) (WITHOUT IN-</b>		Component Function Check .....	24
<b>TELLIGENT KEY SYSTEM)</b> .....	9	Diagnosis Procedure .....	24
<b>COMMON ITEM</b> .....	9	<b>REAR WINDOW DEFOGGER</b> .....	25
COMMON ITEM : CONSULT Function (BCM -		Component Function Check .....	25
COMMON ITEM) .....	9	Diagnosis Procedure .....	25
<b>REAR WINDOW DEFOGGER</b> .....	9	<b>REAR WINDOW DEFOGGER FEEDBACK</b>	
REAR WINDOW DEFOGGER : CONSULT Func-		<b>SIGNAL</b> .....	27
tion (BCM - REAR DEFOGGER) .....	9	<b>WITH AUTO A/C</b> .....	27
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	11	WITH AUTO A/C : Component Function Check .....	27
<b>WITH INTELLIGENT KEY</b> .....	11	WITH AUTO A/C : Diagnosis Procedure .....	27
WITH INTELLIGENT KEY : Diagnosis Description		<b>WITH MANUAL A/C</b> .....	27
.....	11	WITH MANUAL A/C : Component Function Check	
WITH INTELLIGENT KEY : CONSULT Function		.....	27
(IPDM E/R) .....	13	WITH MANUAL A/C : Diagnosis Procedure .....	27
<b>WITHOUT INTELLIGENT KEY</b> .....	15	<b>REAR WINDOW DEFOGGER SYSTEM</b> .....	28

Wiring Diagram - DEFOGGER CONTROL SYSTEM - .....	28	WITH INTELLIGENT KEY : DTC Index .....	104
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>33</b>	<b>WITHOUT INTELLIGENT KEY .....</b>	<b>104</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>33</b>	WITHOUT INTELLIGENT KEY : Reference Value.	104
<b>WITH INTELLIGENT KEY .....</b>	<b>33</b>	WITHOUT INTELLIGENT KEY : Wiring Diagram	
WITH INTELLIGENT KEY : Reference Value .....	33	— IPDM E/R — .....	110
WITH INTELLIGENT KEY : Wiring Diagram - BCM - .....	53	WITHOUT INTELLIGENT KEY : Fail-Safe .....	113
WITH INTELLIGENT KEY : Fail-safe .....	64	WITHOUT INTELLIGENT KEY : DTC Index .....	115
WITH INTELLIGENT KEY :		<b>SYMPTOM DIAGNOSIS .....</b>	<b>116</b>
DTC Inspection Priority Chart .....	65	<b>REAR WINDOW DEFOGGER DOES NOT OPERATE .....</b>	<b>116</b>
WITH INTELLIGENT KEY : DTC Index .....	66	Description .....	116
<b>WITHOUT INTELLIGENT KEY .....</b>	<b>68</b>	Diagnosis Procedure .....	116
WITHOUT INTELLIGENT KEY : Reference Value..	68	<b>REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE .....</b>	<b>117</b>
WITHOUT INTELLIGENT KEY : Wiring Diagram - BCM - .....	82	Diagnosis Procedure .....	117
WITHOUT INTELLIGENT KEY : Fail-safe .....	90	<b>PRECAUTION .....</b>	<b>118</b>
WITHOUT INTELLIGENT KEY :		<b>PRECAUTIONS .....</b>	<b>118</b>
DTC Inspection Priority Chart .....	91	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	118
WITHOUT INTELLIGENT KEY : DTC Index .....	91	Precaution for Procedure without Cowl Top Cover.	118
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	<b>93</b>	Precautions for Removing of Battery Terminal ....	119
<b>WITH INTELLIGENT KEY .....</b>	<b>93</b>	<b>REMOVAL AND INSTALLATION .....</b>	<b>120</b>
WITH INTELLIGENT KEY : Reference Value .....	93	<b>FILAMENT .....</b>	<b>120</b>
WITH INTELLIGENT KEY : Wiring Diagram — IPDM E/R — .....	99	Inspection and Repair .....	120
WITH INTELLIGENT KEY : Fail-Safe .....	102		

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000009945420

#### DETAILED FLOW

#### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

#### 2.CHECK FOR DTC

Perform self diagnosis with CONSULT.

Is any DTC detected?

YES-1 >> BCM: Refer to [BCS-82. "DTC Index"](#) (With Intelligent Key System), [BCS-150. "DTC Index"](#) (Without Intelligent Key System).

YES-2 >> IPDM E/R: Refer to [PCS-32. "DTC Index"](#) (With Intelligent Key System), [PCS-62. "DTC Index"](#) (Without Intelligent Key System).

NO >> GO TO 3.

#### 3.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

#### 4.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

#### 5.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

#### 6.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

#### 7.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P


# REAR WINDOW DEFOGGER SYSTEM

< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### REAR WINDOW DEFOGGER SYSTEM

#### System Diagram



#### System Description

INFOID:000000009945422

#### OPERATION DESCRIPTION


- BCM detects that the rear window defogger switch turns ON while the ignition switch is ON, and then transmits the rear window defogger control signal to IPDM E/R via CAN communication for approximately 15 minutes.
- IPDM E/R turns rear window defogger relay ON when it receives the rear window defogger control signal.
- The power is supplied to the rear window defogger when the rear window defogger relay turns ON.
- When rear window defogger is activated, indicator lamp on rear window defogger switch turns ON.

#### TIMER FUNCTION

- BCM transmits the rear window defogger control signal to IPDM E/R for approximately 15 minutes when the rear window defogger switch is turns ON while ignition switch is ON. Then, IPDM E/R activates rear window defogger.
- The timer is cancelled if the rear window defogger switch is pressed again during timer operation. BCM stops the output of rear window defogger control signal. The same action occurs during timer operation if the ignition switch is OFF.

#### Component Parts Location

INFOID:000000009945423



# REAR WINDOW DEFOGGER SYSTEM

## < SYSTEM DESCRIPTION >

1. IPDM E/R  
Refer to [PCS-5, "Component Parts Location"](#) (with Intelligent Key System) or [PCS-36, "Component Parts Location"](#) (without Intelligent Key System)
2. BCM  
Refer to [BCS-10, "Component Parts Location"](#) (with Intelligent Key System) or [BCS-95, "Component Parts Location"](#) (without Intelligent Key System)
3.
  - A/C auto amp.\*1 (rear window defogger switch)
  - A/C control\*2 (rear window defogger switch)
4. Rear window defogger connector

\*1: For models with auto A/C

\*2: For models with manual A/C

## Component Description

INFOID:000000009945424

BCM	<ul style="list-style-type: none"> <li>• Transmits rear window defogger control signal to IPDM E/R via CAN communication.</li> <li>• Performs the timer control of rear window defogger</li> </ul>
Rear window defogger relay	Operates rear window defogger with IPDM E/R control
IPDM E/R	Turns rear window defogger relay ON when rear window defogger control signal is received
<ul style="list-style-type: none"> <li>• A/C auto amp.*1</li> <li>• A/C control*2</li> </ul>	<ul style="list-style-type: none"> <li>• The rear window defogger switch is installed</li> <li>• Turns the indicator lamp ON when detecting the operation of rear window defogger</li> </ul>
Rear window defogger	Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up

\*1: For models with auto A/C

\*2: For models with manual A/C

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010245769

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Automatic air conditioner	AIR CONDITONER		×	
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description		
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected		A
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected		
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)	B
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)	C
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"	
	ACC>ON		While turning power supply position from "ACC" to "IGN"	D
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)	
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)	E
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)	F
	ACC>OFF		While turning power supply position from "ACC" to "OFF"	
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*	G
	OFF>ACC		While turning power supply position from "OFF" to "ACC"	
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"	
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode	H
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*) to low power consumption mode	I
	LOCK		Power supply position is "LOCK"*	
	OFF		Power supply position is "OFF" (Ignition switch OFF)	J
	ACC		Power supply position is "ACC" (Ignition switch ACC)	
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)	K
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)	
CRANKING	Power supply position is "CRANKING" (At engine cranking)	DEF		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>		M

### NOTE:

\*: Power position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (CVT models), and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## REAR WINDOW DEFOGGER

### REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000009945426

## DATA MONITOR

### NOTE:

## DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

### < SYSTEM DESCRIPTION >

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Description
PUSH SW	Indicates [ON/OFF] condition of push switch.
REAR DEF SW	This is displayed even when it is not equipped.

### ACTIVE TEST

Test Item	Description
REAR DEFOGGER	Rear window defogger operates when "ON" on CONSULT screen is touched.



# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010245773

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp control	INT LAMP	x	x	x
Remote keyless entry system	MULTI REMOTE ENT	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER		x	x
Manual air conditioner	AIR CONDITONER		x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU	x	x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door	TRUNK		x	
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	x
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x
Panic alarm system	PANIC ALARM			x

## REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000009945428

### DATA MONITOR

# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

---

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
REAR DEF SW	Displays "Press (ON)/other (OFF)" status determined with the rear window defogger switch.

## ACTIVE TEST

Test Item	Description
REAR DEFOGGER	Rear window defogger operates when "ON" on CONSULT screen is touched.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R) WITH INTELLIGENT KEY

### WITH INTELLIGENT KEY : Diagnosis Description

INFOID:000000010246423

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Rear window defogger
- Front wiper (LO, HI)
- Parking lamps
- Side marker lamp
- License plate lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

##### NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

##### CAUTION:

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-55, "Component Function Check"](#).
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.


Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test
1	Rear window defogger	10 seconds
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"><li>• Parking lamps</li><li>• Side marker lamps</li><li>• License plate lamps</li><li>• Tail lamps</li><li>• Front fog lamps</li></ul>	10 seconds
4	Headlamps	LO for 10 seconds → HI ON ↔ OFF 5 times

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Operation sequence	Inspection location	Operation
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	LO for 5 seconds → HI for 5 seconds

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps (HI, LO)</li> <li>• Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• A/C amp. signal input circuit</li> <li>• CAN communication signal between A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Symptom	Inspection contents		Possible cause
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• Cooling fan motor</li> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• IPDM E/R</li> </ul>

## WITH INTELLIGENT KEY : CONSULT Function (IPDM E/R)

INFOID:000000010246424

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-32, "DTC Index"](#).

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1/2/3/4]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the clutch interlock switch (M/T models) or shift position (CVT models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INH1 RLY [Off/ ST ON/INH1 ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		<b>NOTE:</b> The item is indicated, but not monitored.
DTRL REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.

### ACTIVE TEST

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Operates the cooling fan relay (LO operation).
	3	Operates the cooling fan relay (HI operation).
	4	

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Test item	Operation	Description
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

## WITHOUT INTELLIGENT KEY

### WITHOUT INTELLIGENT KEY : Diagnosis Description

INFOID:000000010246426

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Rear window defogger
- Front wiper (LO, HI)
- Parking lamps
- Side marker lamp
- License plate lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)  
**NOTE:**  
 When auto active test is performed with hood opened, sprinkle water on windshield beforehand.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.  
**CAUTION:**  
**Close passenger door.**
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-55, "Component Function Check"](#).
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.


Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test
1	Rear window defogger	10 seconds
2	Front wiper	LO for 5 seconds → HI for 5 seconds

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Operation sequence	Inspection location	Operation
3	<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> </ul>	10 seconds
4	Headlamps	LO for 10 seconds → HI ON ↔ OFF 5 times
5	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
6	Cooling fan	LO for 5 seconds → HI for 5 seconds

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• Side marker lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps (HI, LO)</li> <li>• Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>



## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• A/C amp. signal input circuit</li> <li>• CAN communication signal between A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Cooling fan motor</li> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• IPDM E/R</li> </ul>

### WITHOUT INTELLIGENT KEY : CONSULT Function (IPDM E/R)

INFOID:0000000010246427

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-62, "DTC Index"](#).

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
MOTOR FAN REQ [1/2/3/4]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position (CVT models) judged by IPDM E/R.
ST RLY-REQ [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
DTRL REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.

### ACTIVE TEST

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Operates the cooling fan relay (LO operation).
	3	Operates the cooling fan relay (HI operation).
	4	

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Test item	Operation	Description
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF

# REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### REAR WINDOW DEFOGGER SWITCH WITH AUTO A/C

#### WITH AUTO A/C : Component Function Check

INFOID:000000009945433

#### 1. CHECK FUNCTION

1. Check ("REAR DEF SW") in BCM - REAR DEFOGGER "DATA MONITOR" mode by using CONSULT.
2. Operate rear window defogger switch and check the status on CONSULT screen.

Monitor Item	Condition		status
REAR DEF SW	rear window defogger switch	Pressed	On
		Released	Off

Is the inspection result normal?

- YES >> Rear window defogger switch function is OK.  
 NO >> Refer to [DEF-20, "WITH AUTO A/C : Diagnosis Procedure"](#).

#### WITH AUTO A/C : Diagnosis Procedure

INFOID:000000009945434

#### 1. CHECK AUTO A/C


Check the operating condition of auto A/C

Does auto A/C operate normally?

- YES >> GO TO 2.  
 NO >> Perform auto A/C diagnosis. Refer to [HAC-114, "Diagnosis Chart By Symptom"](#).

#### 2. CHECK BCM OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check signal between A/C auto amp. harness connector and ground using oscilloscope.

(+)		(-)	Voltage (V) (Approx.)
A/C auto amp.			
Connector	Terminal		
M51	33	Ground	 <p style="text-align: right;">JPMIA0012GB</p>

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 3.

#### 3. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and A/C auto amp. harness connector.

BCM		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M68	15	M51	33	Existed

3. Check continuity between BCM harness connector and ground.

# REAR WINDOW DEFOGGER SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M68	15		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-88, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 4.CHECK REAR WINDOW DEFOGGER SWITCH

Refer to [DEF-21, "WITH AUTO A/C : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Replace A/C auto amp. Refer to [HAC-122, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

Is the inspection result normal?

>> INSPECTION END

## WITH AUTO A/C : Component Inspection

INFOID:000000009945435

### 1.CHECK REAR WINDOW DEFOGGER SWITCH

- Turn ignition switch OFF.
- Disconnect A/C auto amp. connector.
- Check continuity between A/C auto amp. terminals.

A/C auto amp.		Condition	Continuity
Terminal			
16	33	Rear window defogger switch	Pressed
			Released
			Existed
			Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace A/C auto amp. Refer to [HAC-122, "Removal and Installation"](#).

## WITH MANUAL A/C

## WITH MANUAL A/C : Component Function Check

INFOID:000000009945436

### 1.CHECK FUNCTION

- Check ("REAR DEF SW") in BCM - REAR DEFOGGER "DATA MONITOR" mode by using CONSULT.
- Operate rear window defogger switch and check the status on CONSULT screen.

Monitor Item	Condition	status
REAR DEF SW	rear window defogger switch	Pressed
		Released
		On
		Off

Is the inspection result normal?

- YES >> Rear window defogger switch function is OK.  
 NO >> Refer to [DEF-21, "WITH MANUAL A/C : Diagnosis Procedure"](#).

## WITH MANUAL A/C : Diagnosis Procedure

INFOID:000000009945437

### 1.CHECK MANUAL A/C

Check the operating condition of manual A/C

Does manual A/C operate normally?

# REAR WINDOW DEFOGGER SWITCH


## < DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 2.  
 NO >> Perform manual A/C diagnosis. Refer to [HAC-196, "Diagnosis Chart By Symptom"](#).

### 2. CHECK BCM OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/C control connector.
3. Check voltage between A/C control harness connector and ground.

With Intelligent Key System

(+)		(-)	Voltage (V) (Approx.)
A/C control			
Connector	Terminal		
M53	5	Ground	 <small>JPMIA0012GB</small>

Without Intelligent Key System

(+)		(-)	Voltage (V) (Approx.)
A/C control			
Connector	Terminal		
M53	5	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 3.

### 3. CHECK REAR WINDOW DEFOGGER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and A/C control harness connector.

With Intelligent Key System

BCM		A/C control		Continuity
Connector	Terminal	Connector	Terminal	
M68	15	M53	5	Existed

Without Intelligent Key System

BCM		A/C control		Continuity
Connector	Terminal	Connector	Terminal	
M65	10	M53	5	Existed

3. Check continuity between BCM harness connector and ground.

With Intelligent Key System

BCM		Ground	Continuity
Connector	Terminal		
M68	15		Not existed

Without Intelligent Key System

BCM		Ground	Continuity
Connector	Terminal		
M65	10		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-88, "Removal and Installation"](#) (with Intelligent Key System) or [BCS-155, "Removal and Installation"](#) (without Intelligent Key System).  
 NO >> Repair or replace harness.

# REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 4.CHECK REAR WINDOW DEFOGGER SWITCH

Refer to [DEF-23. "WITH MANUAL A/C : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace A/C control. Refer to [HAC-203. "Removal and Installation"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

Is the inspection result normal?

>> INSPECTION END

## WITH MANUAL A/C : Component Inspection

INFOID:000000009945438

## 1.CHECK REAR WINDOW DEFOGGER SWITCH

1. Turn ignition switch OFF.
2. Disconnect A/C control connector.
3. Check continuity between A/C control terminals.

A/C control Terminal		Condition	Continuity
5	15		Rear window defogger switch
			Released Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace A/C control. Refer to [HAC-203. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

DEF

# REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER RELAY

### Component Function Check

INFOID:000000009945439

#### 1.CHECK FUNCTION

1. Perform IPDM E/R Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger relay function is OK.  
NO >> Refer to [DEF-24, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000009945440

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check the 15A fuse (No. 41 and No. 42 located in IPDM E/R).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

#### 2.CHECK IPDM E/R OUTPUT SIGNAL

1. Perform IPDM E/R Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	CONSULT Active Test condition	Voltage (V) (Approx.)	
Connector	Terminal				
E11	13	Ground	REAR DEFOGGER	ON	Battery voltage
				OFF	0

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#) (with Intelligent Key System) or [PCS-64, "Removal and Installation"](#) (without Intelligent Key System).



# REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER

### Component Function Check

INFOID:000000009945441

#### 1.CHECK FUNCTION

1. Perform IPDM E/R Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger relay function is OK.  
NO >> Refer to [DEF-24. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000009945442

#### 1.CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Turn ignition switch ON.
4. Check voltage between rear window defogger harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
D103	1	Ground	Rear window defogger switch	ON	Battery voltage
				OFF	0

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 4.

#### 2.CHECK REAR WINDOW DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear window defogger harness connector and ground.

Rear window defogger		Ground	Continuity
Connector	Terminal		
D104	2		Existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK FILAMENT

Refer to [DEF-120. "Inspection and Repair"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair filament.

#### 4.CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect following connector.
  - IPDM E/R connector
  - Door mirror (both sides) connector
  - A/C auto amp. connector (for models with auto A/C)
  - A/C control connector (for models with manual A/C)
3. Check continuity between IPDM E/R harness connector and rear window defogger harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

## REAR WINDOW DEFOGGER

### < DTC/CIRCUIT DIAGNOSIS >

---

IPDM E/R		Rear window defogger		Continuity
Connector	Terminal	Connector	Terminal	
E11	13	D103	1	Existed

---

4. Check continuity between IPDM E/R connector and ground.

---

IPDM E/R		Ground	Continuity
Connector	Terminal		
E11	13		Not existed

---

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 5. CHECK INTERMITTENT INCIDENT

---

Refer to [GI-40, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness or connector.

# REAR WINDOW DEFOGGER FEEDBACK SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER FEEDBACK SIGNAL WITH AUTO A/C

WITH AUTO A/C : Component Function Check

INFOID:000000009945449

### 1. CHECK REAR WINDOW DEFOGGER FEEDBACK SIGNAL

Check that the indicator lamps of rear window defogger switch are illuminated when turning the rear window defogger switch ON.

Is the inspection result normal?

- OK >> Rear window defogger feedback signal is OK.
- NG >> Refer to [DEF-27, "WITH AUTO A/C : Diagnosis Procedure"](#).

WITH AUTO A/C : Diagnosis Procedure

INFOID:000000009945450

### 1. CHECK REAR WINDOW DEFOGGER FEEDBACK SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Turn ignition switch ON.
4. Check voltage between A/C auto amp. harness connector and ground.

A/C auto amp.		Ground	Condition		Voltage (V) (Approx.)
Connector	Terminal		Rear window defogger switch	ON	Battery voltage
M51	27			ON	Battery voltage
			OFF	0	

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-122, "Removal and Installation"](#).
- NO >> Repair or replace harness.

WITH MANUAL A/C

WITH MANUAL A/C : Component Function Check

INFOID:000000009945451

### 1. CHECK REAR WINDOW DEFOGGER FEEDBACK SIGNAL

Check that the indicator lamps of rear window defogger switch are illuminated when turning the rear window defogger switch ON.

Is the inspection result normal?

- OK >> Rear window defogger feedback signal is OK.
- NG >> Refer to [DEF-27, "WITH MANUAL A/C : Diagnosis Procedure"](#).

WITH MANUAL A/C : Diagnosis Procedure

INFOID:000000009945452

### 1. CHECK REAR WINDOW DEFOGGER FEEDBACK SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/C control connector.
3. Turn ignition switch ON.
4. Check voltage between A/C control harness connector ground.

A/C control		Ground	Condition		Voltage (V) (Approx.)
Connector	Terminal		Rear window defogger switch	ON	Battery voltage
M53	4			ON	Battery voltage
			OFF	0	

Is the inspection result normal?

- YES >> Replace A/C control. Refer to [HAC-203, "Removal and Installation"](#).
- NO >> Repair or replace harness.


# REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER SYSTEM

### Wiring Diagram - DEFOGGER CONTROL SYSTEM -





















INFOID:000000009945453



# REAR WINDOW DEFOGGER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### DEFOGGER

Connector No. B8	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD4MMV-LC					
					
Connector No. B9	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD4MMV-LC					
					
Connector No. B19	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD4MMV-LC					
					
Connector No. D101	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD2MMV-LC					
					
Connector No. D103	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name REAR WINDOW DEFOGGER					
Connector Type P01FEA					
					
Connector No. D104	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name REAR WINDOW DEFOGGER					
Connector Type P01FEA					
					
Connector No. D123	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD2FW-LC					
					
Connector No. D126	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name WIRE TO WIRE					
Connector Type MD4FW-LC					
					
Connector No. E11	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)					
Connector Type MD8FEL-CC					
					
Connector No. E12	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]	Terminal Color Of No. Wire	Signal Name [Specification]
Connector Name POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)					
Connector Type NS88FBR-CS					
					

JRLWD0844GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P



# REAR WINDOW DEFOGGER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### DEFOGGER

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
4	R	-
5	W/L	-
6	G/Y	-
8	G	-
9	B/R	-
10	B/W	-
11	V	-
12	Y/R	-
13	SB	-
14	Y	-
15	B	-
16	L	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



27	Y/G	A/C SW
28	G/W	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/Y	FR DEFROSTER SW
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	R/W	KEY SWITCH
38	O	IGNITION POWER SUPPLY
39	L	CANH
40	P	CANL

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FH4G-SA



Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1
7	W/R	KEY CYL LOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW 1
12	GR	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
14	L/G	OPTICAL SENSOR
15	W/L	REAR WINDOW DEFOGGER SW
17	R/G	OPTICAL SENSOR POWER SUPPLY
18	V	SENSOR GND
21	P/L	NATS ANTENNA AMP.
23	R/Y	SECURITY INDICATOR LAMP
25	LG	NATS ANTENNA AMP.
27	O	A/C SW
28	G/W	BLOWER FAN SW
29	L/W	HAZARD SW
31	G/B	DR DOOR UNLOCK SENSOR
32	LG	COMBI SW OUTPUT 5
33	Y/L	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R/L	COMBI SW OUTPUT 2
36	L/O	COMBI SW OUTPUT 1
37	G/O	SHIFT P
38	G/Y	RECEIVER COMM
39	L	CANH
40	P	CANL

Terminal No.	Color Of Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	L/B	DRIVER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/L	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	G	PASSENGER DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (F/L)


Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR/W	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	L/Y	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	L/R	COMBI SW INPUT 1
7	W/R	KEY CYL LOCK SW
8	W/B	KEY CYL LOCK SW
9	R	STOP LAMP SW
10	W/L	REAR WINDOW DEFOGGER SW
11	L/Y	ACC POWER SUPPLY
12	SB	PASSENGER DOOR SW
13	GR/L	REAR RH DOOR SW
18	V	RECEIVER / SENSOR GND
19	PR	KEYLESS ENTRY RECEIVER POWER SUPPLY
20	G/Y	KEYLESS ENTRY RECEIVER COMM
21	P/L	NATS ANTENNA AMP
23	R/Y	SECURITY INDICATOR LAMP
25	LG	NATS ANTENNA AMP
26	GR	THERMO CONTROL AMP

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FH4G-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (FUSE)
59	G	PASSENGER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/L	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	L/B	DRIVER DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (F/L)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-GS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/O	-
2	R	-
3	G/R	-
4	G/B	-
5	L	-
6	L	-
7	W/R	-
8	G/W	-

JRLWD0846GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# REAR WINDOW DEFOGGER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >



DEFOGGER		Connector No.	M89
9	Y/L		
10	W		
31	GR/L		WIRE TO WIRE
32	L/B		
33	R/Y		M04FY-LC
34	SB		
35	BR		
36	G		
39	L/R		
44	G/O		
45	LG/R		
46	GR/W		
48	L/O		
51	BA/W		
53	R/L		
54	O		
57	GR		
59	Y		
60	RM/W		
61	RM/W		
62	W/L		
63	WB		
67	Y/R		
69	LG		
70	SHIELD		
71	P/B		
72	R/G		
73	R		
74	L/Y		
76	W/G		
77	GR/R		
78	O		
79	LG		
80	P		
81	L		
82	GR		
83	G/R		
84	B		
91	R		
92	O		
93	Y		
94	R/B		
95	L/W		
96	Y		
97	L		
98	BR/W		
99	W		
100	G/R		

Terminal No.	2	R
Color Of Wire		
Signal Name [Specification]		

Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Type	M04FY-LC

JRLWD0847GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### BCM (BODY CONTROL MODULE) WITH INTELLIGENT KEY

#### WITH INTELLIGENT KEY : Reference Value

INFOID:000000010245783

#### VALUES ON THE DIAGNOSIS TOOL

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

##### CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TR/BD OPEN SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
FAN ON SIG	Blower fan OFF	Off
	Blower fan ON	On
AIR COND SW	Air conditioner OFF (A/C switch indicator OFF)	Off
	Air conditioner ON (A/C switch indicator ON)	On
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	BACK DOOR OPEN button of the key is not pressed	Off
	BACK DOOR OPEN button of the key is pressed	On
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
OPTI SEN (DTCT)	Bright outside of the vehicle	Close to 5 V	A
	Dark outside of the vehicle	Close to 0 V	
OPTI SEN (FILT)	Bright outside of the vehicle (Lighting switch AUTO)	Close to 5 V	B
	Dark outside of the vehicle (Lighting switch AUTO)	Close to 1.50 V	
OPTICAL SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	C
RAIN SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
REQ SW -DR	Driver door request switch is not pressed	Off	D
	Driver door request switch is pressed	On	
REQ SW -AS	Passenger door request switch is not pressed	Off	E
	Passenger door request switch is pressed	On	
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	F
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
REQ SW -BD/TR	Back door request switch is not pressed	Off	G
	Back door request switch is pressed	On	
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off	H
	Push-button ignition switch (push switch) is pressed	On	
CLUCH SW	The clutch pedal is not depressed.	Off	I
	The clutch pedal is depressed	On	
BRAKE SW 1	The brake pedal is not depressed	Off	J
	The brake pedal is depressed	On	
BRAKE SW 2	The brake pedal is depressed when No. 9 fuse is blown	Off	K
	The brake pedal is not depressed when No. 9 fuse is blown, or No. 9 fuse is normal	On	
DETE/CANCL SW	Selector lever in P position	Off	L
	Selector lever in any position other than P	On	
SFT PN/N SW	Selector lever in any position other than P and N	Off	DEF
	Selector lever in P or N position	On	
S/L -LOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off	M
S/L -UNLOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
S/L RELAY-F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off	N
UNLK SEN -DR	Driver door is locked	Off	O
	Driver door is unlocked	On	
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off	P
	Push-button ignition switch (push-switch) is pressed	On	
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off	
	Ignition switch in ON position	On	
DETE SW -IPDM	Selector lever in any position other than P	Off	
	Selector lever in P position	On	
SFT PN -IPDM	Selector lever in any position other than P and N	Off	
	Selector lever in P or N position	On	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L RELAY-REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Selector lever is in the P position except for M/T models)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet	A
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done	B
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet	C
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done	
NOT REGISTERED	BCM detects registered key ID, or BCM does not detect key ID.	ID OK	D
	BCM detects non-registration key ID.	ID NG	
TP 4	The ID of fourth key is not registered to BCM	Yet	E
	The ID of fourth key is registered to BCM	Done	
TP 3	The ID of third key is not registered to BCM	Yet	F
	The ID of third key is registered to BCM	Done	
TP 2	The ID of second key is not registered to BCM	Yet	G
	The ID of second key is registered to BCM	Done	
TP 1	The ID of first key is not registered to BCM	Yet	H
	The ID of first key is registered to BCM	Done	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	I
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	J
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	K
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	
ID REGST FL1	ID of front LH tire transmitter is registered	Done	
	ID of front LH tire transmitter is not registered	Yet	
ID REGST FR1	ID of front RH tire transmitter is registered	Done	
	ID of front RH tire transmitter is not registered	Yet	
ID REGST RR1	ID of rear RH tire transmitter is registered	Done	DEF
	ID of rear RH tire transmitter is not registered	Yet	
ID REGST RL1	ID of rear LH tire transmitter is registered	Done	M
	ID of rear LH tire transmitter is not registered	Yet	
WARNING LAMP	Tire pressure indicator OFF	Off	N
	Tire pressure indicator ON	On	
BUZZER	Tire pressure warning alarm is not sounding	Off	O
	Tire pressure warning alarm is sounding	On	P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT






**NOTE:**

- Connector color
- M68, M70: Black
- M69, M71: White

**PHYSICAL VALUES**

# BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
2 (BR/W)	Ground	Combination switch INPUT 5	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch RH	
					Lighting switch HI	
					Lighting switch 1ST	
					Lighting switch 2ND	
3 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch LH	
					Lighting switch PASS	
					Lighting switch 2ND	
					Front fog lamp switch ON	
4 (L/Y)	Ground	Combination switch INPUT 3	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Front wiper switch LO	
					Front wiper switch MIST	
					Front wiper switch INT	
					Lighting switch AUTO	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
5 (G)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	
					Front washer switch (Wiper intermittent dial 4) Rear washer ON (Wiper intermittent dial 4) Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4958J</p>	1.0 V
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4956J</p>	0.8 V
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	
					Front wiper switch HI (Wiper intermittent dial 4) Rear wiper switch INT (Wiper intermittent dial 4) Wiper intermittent dial 3 (All switch OFF)	 <p style="text-align: right; font-size: small;">PKIB4958J</p>	1.0 V
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4952J</p>	1.9 V
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4956J</p>	0.8 V




# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
7 (W/R)	Ground	Door key cylinder switch UNLOCK	Input	Door key cylinder switch	NEUTRAL position
				UNLOCK position	8.0 - 8.5 V
8 (W/B)	Ground	Door key cylinder switch LOCK	Input	Door key cylinder switch	NEUTRAL position
				LOCK position	0 V
9 (R)	Ground	Stop lamp switch 1	Input	Stop lamp switch	OFF (Brake pedal is not depressed)
				ON (Brake pedal is de- pressed)	Battery voltage
12 (GR)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch	NEUTRAL position
				LOCK position	0 V
13 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch	NEUTRAL position
				UNLOCK position	0 V
14 (L/G)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle
				When dark outside of the vehicle	Close to 0 V
15 (W/L)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	Not pressed
				Pressed	0 V
17 (R/G)	Ground	Optical sensor pow- er supply	Output	Ignition switch	OFF, ACC
				ON	5 V


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P




JPMIA0587GB  
8.0 - 8.5 V



JPMIA0012GB  
1.0 - 1.5 V








JPMIA0012GB  
1.0 - 1.5 V



JPMIA0012GB  
1.0 - 1.5 V






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
18 (V)	Ground	Sensor ground	Input	Ignition switch ON	0 V	
21 (P/L)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key: Intelligent Key battery is re- moved	Brake pedal: Depressed <b>NOTE:</b> Waveform varies each time when brake pedal is depressed	
				Brake pedal: Not de- pressed	12 V	
23 (R/Y)	Ground	Security indicator lamp	Output	Security indica- tor	ON	0 V
				Blinking (Ignition switch OFF)		
25 (LG)	Ground	NATS antenna amp.	Input/ Output	During waiting	Brake pedal: Depressed <b>NOTE:</b> Waveform varies each time when brake pedal is depressed	
				Brake pedal: Not de- pressed	12 V	
27 (O)	Ground	A/C ON	Input	A/C	OFF (A/C switch indicator: OFF)	
				ON (A/C switch indicator: ON)	1.0 - 1.5 V	
28 (G/W)	Ground	Blower fan switch	Input	Fan switch	Blower fan switch OFF	0 V
				Blower fan switch ON		
					7.0 - 8.0 V	

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
29 (L/W)	Ground	Hazard switch	Input	Hazard switch	OFF 12 V
					ON 0 V
31 (G/B)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sen- sor switch OFF)  7.0 - 8.0 V
					UNLOCK status (Unlock sensor switch ON) 0 V
32 (LG)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)  7.0 - 8.0 V
					Front fog lamp switch ON (Wiper intermittent dial 4)
					Rear wiper switch ON (Wiper intermittent dial 4)
		Any of the condition below with all switch OFF		 1.0 V	
				• Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7	
33 (Y/L)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)  7.0 - 8.0 V
					Lighting switch 1ST (Wiper intermittent dial 4)
					Lighting switch AUTO (Wiper intermittent dial 4)
					Rear wiper switch INT (Wiper intermittent dial 4)
		Any of the condition below with all switch OFF		 1.2 V	
				• Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
34 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the condition below with all switch OFF						
<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>						
35 (R/L)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND	 <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						
36 (L/O)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: center;">7.0 - 8.0 V</p>
					Turn signal switch RH	 <p style="text-align: center;">1.2 V</p>
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
Front washer switch ON						

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
37 (G/O)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
38 (G/Y)	Ground	Receiver communication	Input/ Output	Ignition switch OFF (Remote keyless entry communication)	Waiting	12 V
					When operating either button on Intelligent Key	
				Ignition switch ON (TPMS communication)	Waiting	
					When receiving signal from tire pressure sensor	
39 (L)	Ground	CAN-H	Input/ Output	—	—	
40 (P)	Ground	CAN-L	Input/ Output	—	—	
43 (W)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed)	
					ON (When back door opened)	0 V
44 (LG)	Ground	Rear wiper stop position	Input	Ignition switch ON	Rear wiper stop position	12 V
					Any position other than rear wiper stop position	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
45 (SB)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 7.0 - 8.0 V
				ON (When passenger door opened)	0 V	
46 (GR/L)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closed)	 7.0 - 8.0 V
				ON (When rear RH door opened)	0 V	
47 (BR/Y)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	 7.0 - 8.0 V
				ON (When driver door opened)	0 V	
48 (W/G)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closed)	 7.0 - 8.0 V
				ON (When rear door LH opened)	0 V	
50 (R/W)	Ground	Back door lock actuator relay control	Output	Back door	LOCK (Actuator is activated)	0 V
					Other than LOCK (Actuator is not activated)	Battery voltage
51 (W)	Ground	Back door request switch	Input	Back door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	12 V
54 (LG)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Activated)	12 V

# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
55 (G)	Ground	Rear door UNLOCK	Output	Rear door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
56 (L)	Ground	Interior room lamp power supply	Output		Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
					Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
57 (Y)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
59 (G)	Ground	Passenger door UNLOCK	Output	Passenger door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
60 (W/B)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	
61 (W/L)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	
63 (BR)	Ground	Interior room lamp control signal	Output	Interior room lamp	OFF	12 V
					ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
66 (L/B)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON		0 V
68 (L)	Ground	P/W power supply (IGN)	Output	Ignition switch ON		12 V
69 (P)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		12 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
70 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
72 (SB)	Ground	A/C indicator	Output	A/C indicator	OFF	12 V
					ON	0 V
75 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	12 V
76 (L/O)	Ground	Push-button ignition switch (push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
					Not pressed	12 V
78 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch ON	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>
					When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
79 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operated with ignition switch ON	When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>
					When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>



# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
80 (BR/Y)	Ground	Passenger door antenna (+)	Output	When the Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	
				When the passenger door request switch is operated with ignition switch ON	
81 (L/Y)	Ground	Passenger door antenna (-)	Output	When the Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	
				When the passenger door request switch is operated with ignition switch ON	
82 (W/B)	Ground	Back door antenna (+)	Output	When the Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	
				When the back door request switch is operated with ignition switch ON	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
83 (B/W)	Ground	Back door antenna (-)	Output	When the back door request switch is operated with ignition switch ON	<p>When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)</p>  <p style="text-align: right; font-size: small;">JMkia5954GB</p>
				When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMkia5955GB</p>
84 (Y/G)	Ground	Room antenna (+) (Instrument center)	Output	Ignition switch ON	<p>When Intelligent Key is not in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMkia5951GB</p>
				When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMkia3839GB</p>
85 (Y/L)	Ground	Room antenna (-) (Instrument center)	Output	Ignition switch ON	<p>When Intelligent Key is not in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMkia5951GB</p>
				When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMkia3839GB</p>

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
86 (P)	Ground	Luggage room antenna (+)	Output	Ignition switch ON	When Intelligent Key is not in the antenna detection area  <small>JMKIA5951GB</small>
				Ignition switch ON	When Intelligent Key is in the antenna detection area  <small>JMKIA3839GB</small>
87 (L)	Ground	Luggage room antenna (-)	Output	Ignition switch ON	When Intelligent Key is not in the antenna detection area  <small>JMKIA5951GB</small>
				Ignition switch ON	When Intelligent Key is in the antenna detection area  <small>JMKIA3839GB</small>
90 (W/L)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON 12 V OFF 0 V
91 (Y)	Ground	ACC/ON indicator lamp	Output	Ignition switch	OFF Battery voltage
				Ignition switch	ACC or ON 0.5 V
92 (BR/R)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF 0 V
				Tail lamp	ON <b>NOTE:</b> When the illumination brightening/dimming level is in the neutral position  <small>JPMIA1554GB</small> 6.0 - 7.0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
93 (GR/W)	Ground	Intelligent Key warn- ing buzzer	Output	Intelligent Key warning buzzer	Sounding	0 V
					Not sounding	12 V
96 (BR/W)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
97 (L/R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
98 (BR)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V
99 (W/R)	Ground	Ignition relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
100 (G)	Ground	Passenger door re- quest switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	12 V
102 (G)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
103 (G/Y)	Ground	Front defroster switch	Input	Ignition switch ON	A/C mode defroster ON position	0 V
					Other than A/C mode de- froster ON position	 <p style="text-align: right; font-size: small;">JPMIA0589GB 8.0 - 9.0 V</p>
104 (Y/R)	Ground	CVT shift selector (detention switch) power supply	Output	Ignition switch ON		12 V
105 (B/O)	Ground	Stop lamp switch 2	Input	Ignition switch OFF		Battery voltage
106 (Y/B)	Ground	Blower fan motor re- lay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## WITH INTELLIGENT KEY : Wiring Diagram - BCM -

INFOID:000000010245784




BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE7714GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >























JRMWE7715GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

















BCM (BODY CONTROL MODULE)			(WITH INTELLIGENT KEY)		
Connector No.	B11		Connector No.	B34	
Connector Name	LUGGAGE ROOM LAMP		Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	
Connector Type	CJ04FV		Connector Type	TH04FV-NH	
					
Terminal No.	1	Y	Terminal No.	1	Y
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Terminal No.	3	L	Terminal No.	3	LG
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Connector No.	B27		Connector No.	B53	
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)		Connector Name	REAR DOOR SWITCH RH	
Connector Type	TH04FV-NH		Connector Type	TH04FV-NH	
					
Terminal No.	3	SB	Terminal No.	3	LG
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Connector No.	B80		Connector No.	B82	
Connector Name	REAR COMBINATION LAMP LH		Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)	
Connector Type	RS06FB-FR		Connector Type	RK02FL	
					
Terminal No.	1	Y	Terminal No.	1	R
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Terminal No.	3	B	Terminal No.	2	G
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Terminal No.	4	W	Terminal No.	3	W
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Terminal No.	5	R	Terminal No.	2	L
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Terminal No.	6	V	Terminal No.	3	W
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Connector No.	B71		Connector No.	B75	
Connector Name	REAR DOOR SWITCH LH		Connector Name	BACK DOOR SWITCH	
Connector Type	TH04FV-NH		Connector Type	TH04FV-NH	
					
Terminal No.	3	W	Terminal No.	3	W
Color Of Wire			Color Of Wire		
Signal Name [Specification]			Signal Name [Specification]		
Connector No.	B59		Connector No.	B59	
Connector Name	REAR COMBINATION LAMP RH		Connector Name	REAR COMBINATION LAMP RH	
Connector Type	RS06FB-FR		Connector Type	RS06FB-FR	
					

JRMWE7181GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

















< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)																																																																	
<table border="1"> <tr><td>Connector No.</td><td>D5</td></tr> <tr><td>Connector Name</td><td>POWER WINDOW MAIN SWITCH</td></tr> <tr><td>Connector Type</td><td>NS16FW-CS</td></tr> </table>  	Connector No.	D5	Connector Name	POWER WINDOW MAIN SWITCH	Connector Type	NS16FW-CS	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>LG</td><td>-</td></tr> <tr><td>3</td><td>O</td><td>-</td></tr> <tr><td>4</td><td>Y</td><td>-</td></tr> <tr><td>5</td><td>V</td><td>-</td></tr> <tr><td>6</td><td>LG</td><td>-</td></tr> <tr><td>7</td><td>V</td><td>-</td></tr> <tr><td>8</td><td>BR</td><td>-</td></tr> <tr><td>9</td><td>V</td><td>-</td></tr> <tr><td>10</td><td>L</td><td>-</td></tr> <tr><td>11</td><td>GR</td><td>-</td></tr> <tr><td>12</td><td>SB</td><td>-</td></tr> <tr><td>13</td><td>W</td><td>-</td></tr> <tr><td>14</td><td>G</td><td>-</td></tr> <tr><td>15</td><td>G</td><td>-</td></tr> <tr><td>16</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	R	-	2	LG	-	3	O	-	4	Y	-	5	V	-	6	LG	-	7	V	-	8	BR	-	9	V	-	10	L	-	11	GR	-	12	SB	-	13	W	-	14	G	-	15	G	-	16	W	-	<table border="1"> <tr><td>Connector No.</td><td>D6</td></tr> <tr><td>Connector Name</td><td>POWER WINDOW MAIN SWITCH</td></tr> <tr><td>Connector Type</td><td>NS03FW-CS</td></tr> </table>  	Connector No.	D6	Connector Name	POWER WINDOW MAIN SWITCH	Connector Type	NS03FW-CS
Connector No.	D5																																																																
Connector Name	POWER WINDOW MAIN SWITCH																																																																
Connector Type	NS16FW-CS																																																																
Terminal No.	Wire	Signal Name [Specification]																																																															
1	R	-																																																															
2	LG	-																																																															
3	O	-																																																															
4	Y	-																																																															
5	V	-																																																															
6	LG	-																																																															
7	V	-																																																															
8	BR	-																																																															
9	V	-																																																															
10	L	-																																																															
11	GR	-																																																															
12	SB	-																																																															
13	W	-																																																															
14	G	-																																																															
15	G	-																																																															
16	W	-																																																															
Connector No.	D6																																																																
Connector Name	POWER WINDOW MAIN SWITCH																																																																
Connector Type	NS03FW-CS																																																																
<table border="1"> <tr><td>Connector No.</td><td>D9</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>ED0FFGY-RS</td></tr> </table>  	Connector No.	D9	Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)	Connector Type	ED0FFGY-RS	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>SB</td><td>-</td></tr> <tr><td>3</td><td>G</td><td>-</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	V	-	2	SB	-	3	G	-	4	B	-	5	L	-	6	W	-	<table border="1"> <tr><td>Connector No.</td><td>D11</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR REQUEST SWITCH (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>RK02FGY</td></tr> </table>  	Connector No.	D11	Connector Name	FRONT DOOR REQUEST SWITCH (DRIVER SIDE)	Connector Type	RK02FGY																														
Connector No.	D9																																																																
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)																																																																
Connector Type	ED0FFGY-RS																																																																
Terminal No.	Wire	Signal Name [Specification]																																																															
1	V	-																																																															
2	SB	-																																																															
3	G	-																																																															
4	B	-																																																															
5	L	-																																																															
6	W	-																																																															
Connector No.	D11																																																																
Connector Name	FRONT DOOR REQUEST SWITCH (DRIVER SIDE)																																																																
Connector Type	RK02FGY																																																																
<table border="1"> <tr><td>Connector No.</td><td>D12</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>RK02MGY</td></tr> </table>  	Connector No.	D12	Connector Name	OUTSIDE KEY ANTENNA (DRIVER SIDE)	Connector Type	RK02MGY	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	P	-	2	V	-	<table border="1"> <tr><td>Connector No.</td><td>D25</td></tr> <tr><td>Connector Name</td><td>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>NS12FM-CS</td></tr> </table>  	Connector No.	D25	Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)	Connector Type	NS12FM-CS																																										
Connector No.	D12																																																																
Connector Name	OUTSIDE KEY ANTENNA (DRIVER SIDE)																																																																
Connector Type	RK02MGY																																																																
Terminal No.	Wire	Signal Name [Specification]																																																															
1	P	-																																																															
2	V	-																																																															
Connector No.	D25																																																																
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)																																																																
Connector Type	NS12FM-CS																																																																
<table border="1"> <tr><td>Connector No.</td><td>D28</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>ED0FFGY-RS</td></tr> </table>  	Connector No.	D28	Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)	Connector Type	ED0FFGY-RS	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>5</td><td>V</td><td>-</td></tr> <tr><td>6</td><td>Y</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	5	V	-	6	Y	-	<table border="1"> <tr><td>Connector No.</td><td>D31</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>RK02FGY</td></tr> </table>  	Connector No.	D31	Connector Name	FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)	Connector Type	RK02FGY																																										
Connector No.	D28																																																																
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)																																																																
Connector Type	ED0FFGY-RS																																																																
Terminal No.	Wire	Signal Name [Specification]																																																															
5	V	-																																																															
6	Y	-																																																															
Connector No.	D31																																																																
Connector Name	FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)																																																																
Connector Type	RK02FGY																																																																
<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td><td>-</td></tr> <tr><td>2</td><td>BR</td><td>-</td></tr> <tr><td>3</td><td>B</td><td>-</td></tr> <tr><td>6</td><td>Y</td><td>-</td></tr> <tr><td>7</td><td>R</td><td>-</td></tr> <tr><td>8</td><td>L</td><td>-</td></tr> <tr><td>11</td><td>SB</td><td>-</td></tr> <tr><td>12</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	GR	-	2	BR	-	3	B	-	6	Y	-	7	R	-	8	L	-	11	SB	-	12	W	-	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>B</td><td>-</td></tr> <tr><td>2</td><td>LG</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	B	-	2	LG	-	<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td><td>-</td></tr> <tr><td>2</td><td>BR</td><td>-</td></tr> <tr><td>3</td><td>B</td><td>-</td></tr> <tr><td>6</td><td>Y</td><td>-</td></tr> <tr><td>7</td><td>R</td><td>-</td></tr> <tr><td>8</td><td>L</td><td>-</td></tr> <tr><td>11</td><td>SB</td><td>-</td></tr> <tr><td>12</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	1	GR	-	2	BR	-	3	B	-	6	Y	-	7	R	-	8	L	-	11	SB	-	12	W	-
Terminal No.	Wire	Signal Name [Specification]																																																															
1	GR	-																																																															
2	BR	-																																																															
3	B	-																																																															
6	Y	-																																																															
7	R	-																																																															
8	L	-																																																															
11	SB	-																																																															
12	W	-																																																															
Terminal No.	Wire	Signal Name [Specification]																																																															
1	B	-																																																															
2	LG	-																																																															
Terminal No.	Wire	Signal Name [Specification]																																																															
1	GR	-																																																															
2	BR	-																																																															
3	B	-																																																															
6	Y	-																																																															
7	R	-																																																															
8	L	-																																																															
11	SB	-																																																															
12	W	-																																																															
<table border="1"> <tr><td>Terminal No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>17</td><td>B</td><td>-</td></tr> <tr><td>18</td><td>GR</td><td>-</td></tr> <tr><td>19</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Wire	Signal Name [Specification]	17	B	-	18	GR	-	19	P	-																																																					
Terminal No.	Wire	Signal Name [Specification]																																																															
17	B	-																																																															
18	GR	-																																																															
19	P	-																																																															

JRMWE7819GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)																																																			
<table border="1"> <tr><td>Connector No.</td><td>D32</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>RK02MGY</td></tr> </table>  	Connector No.	D32	Connector Name	OUTSIDE KEY ANTENNA (PASSENGER SIDE)	Connector Type	RK02MGY	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td></tr> <tr><td>Color</td><td>P</td><td>V</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	Color	P	V	Wire	-	-	Signal Name [Specification]	-	-	<table border="1"> <tr><td>Connector No.</td><td>D43</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FM-CS</td></tr> </table>  	Connector No.	D43	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FM-CS	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr> <tr><td>Color</td><td>L</td><td>BR</td><td>O</td><td>G</td><td>R</td></tr> <tr><td>Wire</td><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	3	4	5	Color	L	BR	O	G	R	Wire	-	-	-	-	-	Signal Name [Specification]	-	-	-	-	-
Connector No.	D32																																																		
Connector Name	OUTSIDE KEY ANTENNA (PASSENGER SIDE)																																																		
Connector Type	RK02MGY																																																		
Terminal No.	1	2																																																	
Color	P	V																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	
Connector No.	D43																																																		
Connector Name	REAR POWER WINDOW SWITCH RH																																																		
Connector Type	NS08FM-CS																																																		
Terminal No.	1	2	3	4	5																																														
Color	L	BR	O	G	R																																														
Wire	-	-	-	-	-																																														
Signal Name [Specification]	-	-	-	-	-																																														
<table border="1"> <tr><td>Connector No.</td><td>D45</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>ED0FCY-RS</td></tr> </table>  	Connector No.	D45	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	ED0FCY-RS	<table border="1"> <tr><td>Terminal No.</td><td>5</td><td>6</td></tr> <tr><td>Color</td><td>W</td><td>P</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	5	6	Color	W	P	Wire	-	-	Signal Name [Specification]	-	-	<table border="1"> <tr><td>Connector No.</td><td>D63</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH LH</td></tr> <tr><td>Connector Type</td><td>NS08FM-CS</td></tr> </table>  	Connector No.	D63	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Type	NS08FM-CS	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr> <tr><td>Color</td><td>L</td><td>BR</td><td>O</td><td>G</td><td>R</td></tr> <tr><td>Wire</td><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	3	4	5	Color	L	BR	O	G	R	Wire	-	-	-	-	-	Signal Name [Specification]	-	-	-	-	-
Connector No.	D45																																																		
Connector Name	REAR DOOR LOCK ASSEMBLY RH																																																		
Connector Type	ED0FCY-RS																																																		
Terminal No.	5	6																																																	
Color	W	P																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	
Connector No.	D63																																																		
Connector Name	REAR POWER WINDOW SWITCH LH																																																		
Connector Type	NS08FM-CS																																																		
Terminal No.	1	2	3	4	5																																														
Color	L	BR	O	G	R																																														
Wire	-	-	-	-	-																																														
Signal Name [Specification]	-	-	-	-	-																																														
<table border="1"> <tr><td>Connector No.</td><td>D65</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY LH</td></tr> <tr><td>Connector Type</td><td>ED0FCY-RS</td></tr> </table>  	Connector No.	D65	Connector Name	REAR DOOR LOCK ASSEMBLY LH	Connector Type	ED0FCY-RS	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td></tr> <tr><td>Color</td><td>V</td><td>G</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	Color	V	G	Wire	-	-	Signal Name [Specification]	-	-	<table border="1"> <tr><td>Connector No.</td><td>D106</td></tr> <tr><td>Connector Name</td><td>BACK DOOR LOCK ASSEMBLY</td></tr> <tr><td>Connector Type</td><td>FEA04FB-FHA2-LC</td></tr> </table>  	Connector No.	D106	Connector Name	BACK DOOR LOCK ASSEMBLY	Connector Type	FEA04FB-FHA2-LC	<table border="1"> <tr><td>Terminal No.</td><td>2</td><td>3</td></tr> <tr><td>Color</td><td>GR</td><td>Y</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	2	3	Color	GR	Y	Wire	-	-	Signal Name [Specification]	-	-												
Connector No.	D65																																																		
Connector Name	REAR DOOR LOCK ASSEMBLY LH																																																		
Connector Type	ED0FCY-RS																																																		
Terminal No.	1	2																																																	
Color	V	G																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	
Connector No.	D106																																																		
Connector Name	BACK DOOR LOCK ASSEMBLY																																																		
Connector Type	FEA04FB-FHA2-LC																																																		
Terminal No.	2	3																																																	
Color	GR	Y																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	
<table border="1"> <tr><td>Connector No.</td><td>D107</td></tr> <tr><td>Connector Name</td><td>BACK DOOR REQUEST SWITCH</td></tr> <tr><td>Connector Type</td><td>RK02FGY</td></tr> </table>  	Connector No.	D107	Connector Name	BACK DOOR REQUEST SWITCH	Connector Type	RK02FGY	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td></tr> <tr><td>Color</td><td>W</td><td>B</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	Color	W	B	Wire	-	-	Signal Name [Specification]	-	-	<table border="1"> <tr><td>Connector No.</td><td>D108</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (BACK DOOR)</td></tr> <tr><td>Connector Type</td><td>RK02MGY</td></tr> </table>  	Connector No.	D108	Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)	Connector Type	RK02MGY	<table border="1"> <tr><td>Terminal No.</td><td>1</td><td>2</td></tr> <tr><td>Color</td><td>BR</td><td>R</td></tr> <tr><td>Wire</td><td>-</td><td>-</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td><td>-</td></tr> </table>	Terminal No.	1	2	Color	BR	R	Wire	-	-	Signal Name [Specification]	-	-												
Connector No.	D107																																																		
Connector Name	BACK DOOR REQUEST SWITCH																																																		
Connector Type	RK02FGY																																																		
Terminal No.	1	2																																																	
Color	W	B																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	
Connector No.	D108																																																		
Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)																																																		
Connector Type	RK02MGY																																																		
Terminal No.	1	2																																																	
Color	BR	R																																																	
Wire	-	-																																																	
Signal Name [Specification]	-	-																																																	

JRMWE7820GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

**BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)**


Connector No.	D112	Connector No.	E11	Connector No.	E13	Connector No.	E17
Connector Name	REAR WIPER MOTOR	Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	CJ04FM-TV	Connector Type	M06FELC	Connector Type	TH12FM-NH	Connector Type	TH10FB-NH




H.S.



H.S.




H.S.



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
3	BR	-
4	LG	-


Connector No.	E10
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	M06FW-LC



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	-
4	P	-
5	LG	-
6	SB	-
7	Y	-
8	V	-


Connector No.	E12
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FBR-CS



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
18	Y	-
19	BR	-
21	W	-
22	V	-

Connector No.	E15
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS16FTV-CS




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
47	BR	-
49	W	-
50	GR	-
51	R	-
52	P	-
54	GR	-
55	P	-
56	SB	-
57	G	- [With M/T]
58	LG	- [With CVT]
59	R	-

Terminal No.	64	63
Color Of Wire	-	-
Signal Name [Specification]	-	-

Connector No.	E23
Connector Name	SIDE TURN SIGNAL LAMP LH
Connector Type	STL02FW



































H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BR	-

JRMWE7821GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)																																																																																
<table border="1"> <tr><td>Connector No.</td><td>E25</td></tr> <tr><td>Connector Name</td><td>INTELLIGENT KEY WARNING BUZZER</td></tr> <tr><td>Connector Type</td><td>RK03FBR</td></tr> </table>  	Connector No.	E25	Connector Name	INTELLIGENT KEY WARNING BUZZER	Connector Type	RK03FBR	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>3</td><td>P</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	V	-	3	P	-	<table border="1"> <tr><td>Connector No.</td><td>E27</td></tr> <tr><td>Connector Name</td><td>FRONT TURN SIGNAL LAMP LH</td></tr> <tr><td>Connector Type</td><td>RS02FB</td></tr> </table>  	Connector No.	E27	Connector Name	FRONT TURN SIGNAL LAMP LH	Connector Type	RS02FB																																																									
Connector No.	E25																																																																															
Connector Name	INTELLIGENT KEY WARNING BUZZER																																																																															
Connector Type	RK03FBR																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	V	-																																																																														
3	P	-																																																																														
Connector No.	E27																																																																															
Connector Name	FRONT TURN SIGNAL LAMP LH																																																																															
Connector Type	RS02FB																																																																															
<table border="1"> <tr><td>Connector No.</td><td>E25</td></tr> <tr><td>Connector Name</td><td>INTELLIGENT KEY WARNING BUZZER</td></tr> <tr><td>Connector Type</td><td>RK03FBR</td></tr> </table>  	Connector No.	E25	Connector Name	INTELLIGENT KEY WARNING BUZZER	Connector Type	RK03FBR	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>3</td><td>P</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	V	-	3	P	-	<table border="1"> <tr><td>Connector No.</td><td>E27</td></tr> <tr><td>Connector Name</td><td>FRONT TURN SIGNAL LAMP LH</td></tr> <tr><td>Connector Type</td><td>RS02FB</td></tr> </table>  	Connector No.	E27	Connector Name	FRONT TURN SIGNAL LAMP LH	Connector Type	RS02FB																																																									
Connector No.	E25																																																																															
Connector Name	INTELLIGENT KEY WARNING BUZZER																																																																															
Connector Type	RK03FBR																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	V	-																																																																														
3	P	-																																																																														
Connector No.	E27																																																																															
Connector Name	FRONT TURN SIGNAL LAMP LH																																																																															
Connector Type	RS02FB																																																																															
<table border="1"> <tr><td>Connector No.</td><td>E40</td></tr> <tr><td>Connector Name</td><td>SIDE TURN SIGNAL LAMP RH</td></tr> <tr><td>Connector Type</td><td>STL02FW</td></tr> </table>  	Connector No.	E40	Connector Name	SIDE TURN SIGNAL LAMP RH	Connector Type	STL02FW	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>BY</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	W	-	2	BY	-	<table border="1"> <tr><td>Connector No.</td><td>E46</td></tr> <tr><td>Connector Name</td><td>FRONT TURN SIGNAL LAMP RH</td></tr> <tr><td>Connector Type</td><td>RS02FB</td></tr> </table>  	Connector No.	E46	Connector Name	FRONT TURN SIGNAL LAMP RH	Connector Type	RS02FB																																																									
Connector No.	E40																																																																															
Connector Name	SIDE TURN SIGNAL LAMP RH																																																																															
Connector Type	STL02FW																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	W	-																																																																														
2	BY	-																																																																														
Connector No.	E46																																																																															
Connector Name	FRONT TURN SIGNAL LAMP RH																																																																															
Connector Type	RS02FB																																																																															
<table border="1"> <tr><td>Connector No.</td><td>E40</td></tr> <tr><td>Connector Name</td><td>SIDE TURN SIGNAL LAMP RH</td></tr> <tr><td>Connector Type</td><td>STL02FW</td></tr> </table>  	Connector No.	E40	Connector Name	SIDE TURN SIGNAL LAMP RH	Connector Type	STL02FW	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>BY</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	W	-	2	BY	-	<table border="1"> <tr><td>Connector No.</td><td>E46</td></tr> <tr><td>Connector Name</td><td>FRONT TURN SIGNAL LAMP RH</td></tr> <tr><td>Connector Type</td><td>RS02FB</td></tr> </table>  	Connector No.	E46	Connector Name	FRONT TURN SIGNAL LAMP RH	Connector Type	RS02FB																																																									
Connector No.	E40																																																																															
Connector Name	SIDE TURN SIGNAL LAMP RH																																																																															
Connector Type	STL02FW																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	W	-																																																																														
2	BY	-																																																																														
Connector No.	E46																																																																															
Connector Name	FRONT TURN SIGNAL LAMP RH																																																																															
Connector Type	RS02FB																																																																															
<table border="1"> <tr><td>Connector No.</td><td>E115</td></tr> <tr><td>Connector Name</td><td>STOP LAMP SWITCH</td></tr> <tr><td>Connector Type</td><td>M04FW-LC</td></tr> </table>  	Connector No.	E115	Connector Name	STOP LAMP SWITCH	Connector Type	M04FW-LC	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>O</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	V	-	2	W	-	3	O	-	4	G	-	<table border="1"> <tr><td>Connector No.</td><td>E21</td></tr> <tr><td>Connector Name</td><td>TRANSMISSION RANGE SWITCH</td></tr> <tr><td>Connector Type</td><td>RK08FG</td></tr> </table>  	Connector No.	E21	Connector Name	TRANSMISSION RANGE SWITCH	Connector Type	RK08FG																																																			
Connector No.	E115																																																																															
Connector Name	STOP LAMP SWITCH																																																																															
Connector Type	M04FW-LC																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	V	-																																																																														
2	W	-																																																																														
3	O	-																																																																														
4	G	-																																																																														
Connector No.	E21																																																																															
Connector Name	TRANSMISSION RANGE SWITCH																																																																															
Connector Type	RK08FG																																																																															
<table border="1"> <tr><td>Connector No.</td><td>E115</td></tr> <tr><td>Connector Name</td><td>STOP LAMP SWITCH</td></tr> <tr><td>Connector Type</td><td>M04FW-LC</td></tr> </table>  	Connector No.	E115	Connector Name	STOP LAMP SWITCH	Connector Type	M04FW-LC	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>O</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	V	-	2	W	-	3	O	-	4	G	-	<table border="1"> <tr><td>Connector No.</td><td>E21</td></tr> <tr><td>Connector Name</td><td>TRANSMISSION RANGE SWITCH</td></tr> <tr><td>Connector Type</td><td>RK08FG</td></tr> </table>  	Connector No.	E21	Connector Name	TRANSMISSION RANGE SWITCH	Connector Type	RK08FG																																																			
Connector No.	E115																																																																															
Connector Name	STOP LAMP SWITCH																																																																															
Connector Type	M04FW-LC																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	V	-																																																																														
2	W	-																																																																														
3	O	-																																																																														
4	G	-																																																																														
Connector No.	E21																																																																															
Connector Name	TRANSMISSION RANGE SWITCH																																																																															
Connector Type	RK08FG																																																																															
<table border="1"> <tr><td>Connector No.</td><td>M1</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (JIB)</td></tr> <tr><td>Connector Type</td><td>24311-ED000</td></tr> </table>  	Connector No.	M1	Connector Name	FUSE BLOCK (JIB)	Connector Type	24311-ED000	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	W	-	<table border="1"> <tr><td>Connector No.</td><td>M4</td></tr> <tr><td>Connector Name</td><td>DATA LINK CONNECTOR</td></tr> <tr><td>Connector Type</td><td>BD16FW</td></tr> </table>  	Connector No.	M4	Connector Name	DATA LINK CONNECTOR	Connector Type	BD16FW																																																												
Connector No.	M1																																																																															
Connector Name	FUSE BLOCK (JIB)																																																																															
Connector Type	24311-ED000																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	W	-																																																																														
Connector No.	M4																																																																															
Connector Name	DATA LINK CONNECTOR																																																																															
Connector Type	BD16FW																																																																															
<table border="1"> <tr><td>Connector No.</td><td>M1</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (JIB)</td></tr> <tr><td>Connector Type</td><td>24311-ED000</td></tr> </table>  	Connector No.	M1	Connector Name	FUSE BLOCK (JIB)	Connector Type	24311-ED000	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	W	-	<table border="1"> <tr><td>Connector No.</td><td>M4</td></tr> <tr><td>Connector Name</td><td>DATA LINK CONNECTOR</td></tr> <tr><td>Connector Type</td><td>BD16FW</td></tr> </table>  	Connector No.	M4	Connector Name	DATA LINK CONNECTOR	Connector Type	BD16FW																																																												
Connector No.	M1																																																																															
Connector Name	FUSE BLOCK (JIB)																																																																															
Connector Type	24311-ED000																																																																															
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	W	-																																																																														
Connector No.	M4																																																																															
Connector Name	DATA LINK CONNECTOR																																																																															
Connector Type	BD16FW																																																																															
<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> <tr><td>5</td><td>B</td><td>-</td></tr> <tr><td>6</td><td>L</td><td>-</td></tr> <tr><td>7</td><td>GR/R</td><td>-</td></tr> <tr><td>8</td><td>O</td><td>-</td></tr> <tr><td>14</td><td>P</td><td>-</td></tr> <tr><td>16</td><td>LG/R</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	4	B	-	5	B	-	6	L	-	7	GR/R	-	8	O	-	14	P	-	16	LG/R	-	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> <tr><td>5</td><td>B</td><td>-</td></tr> <tr><td>6</td><td>L</td><td>-</td></tr> <tr><td>7</td><td>GR/R</td><td>-</td></tr> <tr><td>8</td><td>O</td><td>-</td></tr> <tr><td>14</td><td>P</td><td>-</td></tr> <tr><td>16</td><td>LG/R</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	4	B	-	5	B	-	6	L	-	7	GR/R	-	8	O	-	14	P	-	16	LG/R	-	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>R</td><td>-</td></tr> <tr><td>4</td><td>GR</td><td>-</td></tr> <tr><td>5</td><td>SB</td><td>-</td></tr> <tr><td>6</td><td>W</td><td>-</td></tr> <tr><td>7</td><td>Y</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	R	-	2	W	-	3	R	-	4	GR	-	5	SB	-	6	W	-	7	Y	-	8	G	-			
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
4	B	-																																																																														
5	B	-																																																																														
6	L	-																																																																														
7	GR/R	-																																																																														
8	O	-																																																																														
14	P	-																																																																														
16	LG/R	-																																																																														
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
4	B	-																																																																														
5	B	-																																																																														
6	L	-																																																																														
7	GR/R	-																																																																														
8	O	-																																																																														
14	P	-																																																																														
16	LG/R	-																																																																														
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	R	-																																																																														
2	W	-																																																																														
3	R	-																																																																														
4	GR	-																																																																														
5	SB	-																																																																														
6	W	-																																																																														
7	Y	-																																																																														
8	G	-																																																																														
<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>R</td><td>-</td></tr> <tr><td>4</td><td>GR</td><td>-</td></tr> <tr><td>5</td><td>SB</td><td>-</td></tr> <tr><td>6</td><td>W</td><td>-</td></tr> <tr><td>7</td><td>Y</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	R	-	2	W	-	3	R	-	4	GR	-	5	SB	-	6	W	-	7	Y	-	8	G	-	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> <tr><td>5</td><td>B</td><td>-</td></tr> <tr><td>6</td><td>L</td><td>-</td></tr> <tr><td>7</td><td>GR/R</td><td>-</td></tr> <tr><td>8</td><td>O</td><td>-</td></tr> <tr><td>14</td><td>P</td><td>-</td></tr> <tr><td>16</td><td>LG/R</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	4	B	-	5	B	-	6	L	-	7	GR/R	-	8	O	-	14	P	-	16	LG/R	-	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>R</td><td>-</td></tr> <tr><td>4</td><td>GR</td><td>-</td></tr> <tr><td>5</td><td>SB</td><td>-</td></tr> <tr><td>6</td><td>W</td><td>-</td></tr> <tr><td>7</td><td>Y</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	R	-	2	W	-	3	R	-	4	GR	-	5	SB	-	6	W	-	7	Y	-	8	G	-
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	R	-																																																																														
2	W	-																																																																														
3	R	-																																																																														
4	GR	-																																																																														
5	SB	-																																																																														
6	W	-																																																																														
7	Y	-																																																																														
8	G	-																																																																														
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
4	B	-																																																																														
5	B	-																																																																														
6	L	-																																																																														
7	GR/R	-																																																																														
8	O	-																																																																														
14	P	-																																																																														
16	LG/R	-																																																																														
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																														
1	R	-																																																																														
2	W	-																																																																														
3	R	-																																																																														
4	GR	-																																																																														
5	SB	-																																																																														
6	W	-																																																																														
7	Y	-																																																																														
8	G	-																																																																														

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

**BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY)**

Connector No.	M10
Connector Name	IGNITION RELAY
Connector Type	MS02FL-M2-LC

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	W/B	-
3	W/B	-
5	L	-

Connector No. M17  
Connector Name OPTICAL SENSOR  
Connector Type TK03FW

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R/G	POWER
2	L/B	OUTPUT
3	V	GROUND

Connector No.	M26
Connector Name	NATS ANTENNA AMP.
Connector Type	TH04FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BAT
2	PIL	CLK
3	B	GND (Without Intelligent Key)
3	LG	DATA (With Intelligent Key)
4	B	GND (With Intelligent Key)
4	LG	DATA (Without Intelligent Key)

Connector No. M27  
Connector Name COMBINATION SWITCH  
Connector Type TH06FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	O/B	WASHER (RR)
2	GR	OUTPUT 4
3	R/G	WASHER (FR)
4	W	IGN
5	L/Y	OUTPUT 3
6	B	GROUND
7	W	INPUT 3
8	BR/W	OUTPUT 5
9	R/L	INPUT 2
10	Y/L	INPUT 4
11	L/O	INPUT 1
12	L/R	OUTPUT 1
13	LG	INPUT 5
14	G	OUTPUT 2

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH00FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CANH
2	P	CANL
3	V	VEHICLE SPEED SIGNAL (2-PULSE)
4	L	VEHICLE SPEED SIGNAL (4-PULSE (IMMEDIATE))
4	V/R	VEHICLE SPEED SIGNAL (8 PULSE (WITH 2AV))
6	BR/Y	FUEL LEVEL SENSOR SIGNAL
7	R/G	AIR BAG SIGNAL
8	P	OVERDRIVE CONTROL SWITCH SIGNAL
9	O	SEAT BELT Buckle Switch Signal (DRIVER SEAT)
10	SB	PARKING BRAKE SWITCH SIGNAL
11	GR	BRAKE FLUID LEVEL SWITCH SIGNAL
13	BR	ILLUMINATION CONTROL SIGNAL
15	L/Y	ACC POWER SUPPLY
18	R/Y	SECURITY SIGNAL
19	PU/W	AMBIENT SENSOR SIGNAL
20	R/W	AMBIENT SENSOR GROUND
21	B	GROUND
22	B	GROUND
23	B	GROUND
24	PU	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
27	LG/R	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	BR	PASSENGER SEAT BELT WARNING SIGNAL
31	R	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL
35	BR	ENGINE COOLANT TEMPERATURE SIGNAL
38	GR	ALTERNATOR SIGNAL

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	L/W	-
3	W	-
4	B/R	-

Connector No. M51  
Connector Name A/C AUTO AMP.  
Connector Type TK16FSY


Terminal No.	Color Of Wire	Signal Name [Specification]
21	BR	WATER TEMPERATURE SIGNAL
22	PU/W	AMBIENT SENSOR SIGNAL
23	O	INTAKE SENSOR SIGNAL
24	G	IN-VEHICLE SENSOR SIGNAL
25	P	SUNLOAD SENSOR SIGNAL
26	SB	INTAKE DOOR MOTOR PBR F/B SIGNAL
27	R	REAR WINDOW DEFROGGER F/B SIGNAL
29	GR	MODE DRIVE SIGNAL 4
30	W	MODE DRIVE SIGNAL 3
31	Y	MODE DRIVE SIGNAL 2
32	V	MODE DRIVE SIGNAL 1
33	W/L	REAR WINDOW DEFROGGER ON SIGNAL
34	Y/G	A/C COIL SIGNAL
35	G/W	BLOWER FAN ON SIGNAL
36	GR/R	POWER TRANSISTOR CONTROL SIGNAL

JRMWE7823GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JRMWE7825GB

INFOID:0000000010245785

WITH INTELLIGENT KEY : Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.



## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2198: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B260F: ENG STATE SIG LOST	Inhibit engine cranking	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B26F1: IGN RELAY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch ON signal (CAN: Transmitted from BCM): ON</li> <li>• Ignition switch ON signal (CAN: Transmitted from IPDM E/R): ON</li> </ul>
B26F2: IGN RELAY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch ON signal (CAN: Transmitted from BCM): OFF</li> <li>• Ignition switch ON signal (CAN: Transmitted from IPDM E/R): OFF</li> </ul>
B26F3: START CONT RLY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Starter control relay signal (CAN: Transmitted from BCM): OFF</li> <li>• Starter control relay signal (CAN: Transmitted from IPDM E/R): OFF</li> </ul>
B26F4: START CONT RLY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Starter control relay signal (CAN: Transmitted from BCM): ON</li> <li>• Starter control relay signal (CAN: Transmitted from IPDM E/R): ON</li> </ul>
B26F7: BCM	Inhibit engine cranking by Intelligent Key system	When room antenna and luggage room antenna functions normally

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

**NOTE:**

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

### WITH INTELLIGENT KEY : DTC Inspection Priority Chart

INFOID:0000000010245786

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC
3	<ul style="list-style-type: none"> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI-SCANNING</li> <li>• B2198: NATS ANTENNA AMP</li> </ul>
4	<ul style="list-style-type: none"> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP/CLUTCH SW</li> <li>• B2605: PNP/CLUTCH SW</li> <li>• B2608: STARTER RELAY</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2614: BCM</li> <li>• B2615: BCM</li> <li>• B2616: BCM</li> <li>• B2618: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B26F1: IGN RELAY OFF</li> <li>• B26F2: IGN RELAY ON</li> <li>• B26F3: START CONT RLY ON</li> <li>• B26F4: START CONT RLY OFF</li> <li>• B26F6: BCM</li> <li>• B26F7: BCM</li> <li>• B26F8: BCM</li> <li>• B26FC: KEY REGISTRATION</li> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• U0415: VEHICLE SPEED</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> </ul>
6	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2622: INSIDE ANTENNA</li> </ul>
7	<ul style="list-style-type: none"> <li>• B2626: OUTSIDE ANTENNA</li> <li>• B2627: OUTSIDE ANTENNA</li> <li>• B2628: OUTSIDE ANTENNA</li> </ul>

### WITH INTELLIGENT KEY : DTC Index

INFOID:000000010245787

**NOTE:**

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-20, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condi- tion	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page	
No DTC is detected. further testing may be required.	—	—	—	—	—	A
U1000: CAN COMM	—	—	—	—	<a href="#">BCS-40</a>	B
U1010: CONTROL UNIT (CAN)	—	—	—	—	<a href="#">BCS-41</a>	C
U0415: VEHICLE SPEED	—	—	×	—	<a href="#">BCS-42</a>	D
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-38</a>	E
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-40</a>	F
B2195: ANTI-SCANNING	×	—	—	—	<a href="#">SEC-41</a>	G
B2198: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-42</a>	H
B2555: STOP LAMP	—	×	×	—	<a href="#">SEC-46</a>	I
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-48</a>	J
B2557: VEHICLE SPEED	—	×	×	—	<a href="#">SEC-50</a>	K
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-43</a>	DEF
B2601: SHIFT POSITION	—	×	×	—	<a href="#">SEC-51</a>	M
B2602: SHIFT POSITION	—	×	×	—	<a href="#">SEC-54</a>	N
B2603: SHIFT POSI STATUS	—	×	×	—	<a href="#">SEC-57</a>	O
B2604: PNP/CLUTCH SW	—	×	×	—	<a href="#">SEC-62</a>	P
B2605: PNP/CLUTCH SW	—	×	×	—	<a href="#">SEC-65</a>	
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-67</a>	
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-69</a>	
B2614: BCM	—	×	×	—	<a href="#">PCS-77</a>	
B2615: BCM	—	×	×	—	<a href="#">PCS-80</a>	
B2616: BCM	—	×	×	—	<a href="#">PCS-83</a>	
B2618: BCM	—	×	×	—	<a href="#">PCS-86</a>	
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">PCS-87</a>	
B2621: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-44</a>	
B2622: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-46</a>	
B2626: OUTSIDE ANTENNA	—	×	—	—	<a href="#">DLK-50</a>	
B2627: OUTSIDE ANTENNA	—	×	—	—	<a href="#">DLK-48</a>	
B2628: OUTSIDE ANTENNA	—	×	—	—	<a href="#">DLK-52</a>	
B26F1: IGN RELAY OFF	×	×	×	—	<a href="#">PCS-89</a>	
B26F2: IGN RELAY ON	×	×	×	—	<a href="#">PCS-91</a>	
B26F3: START CONT RLY ON	×	×	×	—	<a href="#">SEC-70</a>	
B26F4: START CONT RLY OFF	×	×	×	—	<a href="#">SEC-71</a>	
B26F6: BCM	—	×	×	—	<a href="#">PCS-93</a>	
B26F7: BCM	×	×	×	—	<a href="#">SEC-73</a>	
B26F8: BCM	—	×	×	—	<a href="#">SEC-74</a>	
B26FC: KEY REGISTRATION	—	×	×	—	<a href="#">SEC-75</a>	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-26</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	<a href="#">WT-28</a>
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-31</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-33</a>

### WITHOUT INTELLIGENT KEY

### WITHOUT INTELLIGENT KEY : Reference Value

INFOID:0000000010245797

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
LOCK STATUS	<b>NOTE:</b> The item is indicated, but not monitored.	Off

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
ACC ON SW	Ignition switch OFF	Off	A
	Ignition switch ACC or ON	On	
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off	B
	"LOCK" button of key fob is pressed	On	
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off	C
	"UNLOCK" button of key fob is pressed	On	
SHOCK SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	NORMAL	D
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off	
	Driver door key cylinder LOCK position	On	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off	E
	Driver door key cylinder UNLOCK position	On	
VEHICLE SPEED	While driving	Equivalent to speedometer reading	F
REAR DEF SW	Rear window defogger switch OFF	Off	
	Rear window defogger switch ON	On	
REVERSE SW CAN	<b>NOTE:</b> The item is indicated, but not used.	Off	G
		On	
TAIL LAMP SW	Lighting switch OFF	Off	H
	Lighting switch 1ST	On	
FR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	I
BUCKLE SW	The seat belt (driver side) is fastened. [Seat belt switch (driver side) OFF]	Off	
	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) ON]	On	
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	J
KYLS TRNK/HAT	<b>NOTE:</b> The item is indicated, but not monitored.	Off	K
KEYLESS PANIC	PANIC button of key fob is not pressed	Off	
	PANIC button of key fob is pressed	On	DEF
HI BEAM SW	Lighting switch OFF	Off	
	Lighting switch HI	On	
HEAD LAMP SW 1	Lighting switch OFF	Off	M
	Lighting switch 2ND	On	
HEAD LAMP SW 2	Lighting switch OFF	Off	N
	Lighting switch 2ND	On	
AUTO LIGHT SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	O
PASSING SW	Other than lighting switch PASS	Off	
	Lighting switch PASS	On	
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	P
TURN SIGNAL R	Turn signal switch OFF	Off	
	Turn signal switch RH	On	
TURN SIGNAL L	Turn signal switch OFF	Off	
	Turn signal switch LH	On	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
PKB SW	Parking brake switch is OFF	Off
	Parking brake switch is ON	On
ENGINE RUN	Engine stopped	Off
	Engine running	On
OPTI SEN (DTCT)	<b>NOTE:</b> The item is indicated, but not monitored.	Close to 5 V
OPTI SEN (FILT)	<b>NOTE:</b> The item is indicated, but not monitored.	Close to 5 V
LIG SEN COND	<b>NOTE:</b> The item is indicated, but not monitored.	OFF
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
RR WIPER ON	Rear wiper switch OFF	Off
	Rear wiper switch ON	On
RR WIPER INT	Rear wiper switch OFF	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper stop position	Off
	Other than rear wiper stop position	On
RAIN SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch OFF	Off
	Hazard switch ON	On
FAN ON SIG	Blower control dial OFF	Off
	Other than blower control dial OFF	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
THERMO AMP	Ignition switch ON	Off
	Evaporator is extremely low temperature	On
FR DEF SW	Other than A/C mode defroster ON position	Off
	A/C mode defroster ON position	On
KEYLESS TRUNK	<b>NOTE:</b> The item is indicated, but not monitored.	Off

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
TRNK OPNR SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	A
TRNK OPN MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	B
HOOD SW	Close the hood	Off	C
	Open the hood	On	
TRANSPONDER	Other than the ignition switch is ON by key registered to BCM.	Off	D
	The ignition switch is ON by key registered to BCM.	On	
INTELLI KEY	<b>NOTE:</b> The item is indicated, but not used.	Off	E
AUTO RELOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off	F
OIL PRESS SW	<ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• Engine running</li> </ul>	Off	F
	Ignition switch ON	On	
BRAKE SW	Brake pedal is not depressed	Off	G
	Brake pedal is depressed	On	


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



**NOTE:**




- M65, M66: White
- M67: Black

PHYSICAL VALUES



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
2 (BR/W)	Ground	Combination switch INPUT 5	Input	All switch OFF	0 V
				Turn signal switch RH	
				Lighting switch HI	
				Lighting switch 1ST	
				Lighting switch 2ND	
3 (GR)	Ground	Combination switch INPUT 4	Input	All switch OFF	0 V
				Turn signal switch LH	
				Lighting switch PASS	
				Lighting switch 2ND	
4 (L/Y)	Ground	Combination switch INPUT 3	Input	All switch OFF	0 V
				Front wiper switch LO	
				Front wiper switch MIST	
				Front wiper switch INT	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
5 (G)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	
Rear wiper switch ON (Wiper intermittent dial 4)		0.8 V				
6 (L/R)	Ground	Combination switch INPUT 1	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Wiper intermittent dial 3 (All switch OFF)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> </ul>	
Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>		0.8 V				

# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
7 (W/R)	Ground	Door key cylinder switch UNLOCK	Input	Door key cylinder switch	NEUTRAL position	 <p style="text-align: center;">7.0 - 8.0 V</p>
					UNLOCK position	
8 (W/B)	Ground	Door key cylinder switch LOCK	Input	Door key cylinder switch	NEUTRAL position	12 V
					LOCK position	0 V
9 (R)	Ground	Stop lamp switch	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
10 (W/L)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	OFF (Not pressed)	12 V
					ON (Pressed)	0 V
11 (L/Y)	Ground	Ignition switch ACC	Input	Ignition switch OFF		0 V
				Ignition switch ACC or ON		Battery voltage
12 (SB)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 <p style="text-align: center;">7.0 - 8.0 V</p>
					ON (When passenger door opened)	
13 (GR/L)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closed)	 <p style="text-align: center;">7.0 - 8.0 V</p>
					ON (When rear RH door opened)	
18 (V)	Ground	Receiver ground	Input	Ignition switch ON		0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
19 (BR)	Ground	Remote keyless entry receiver power supply	Input	Insert mechanical key into ignition key cylinder	0 V
				Remove mechanical key from ignition key cylinder (Any door opened)	5 V
				Remove mechanical key from ignition key cylinder (Any door closed)	 <p style="text-align: right; font-size: small;">JPMA0338JP</p>
20 (G/Y)	Ground	Remote keyless entry receiver communication	Input	Insert mechanical key into ignition key cylinder	0 V
				Waiting	 <p style="text-align: right; font-size: small;">PIIB7728J</p>
				Signal receiving	 <p style="text-align: right; font-size: small;">PIIB7729J</p>
21 (P/L)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder	Pointer of tester should move
				Other than above	0 V
23 (R/Y)	Ground	Security indicator	Input	ON	0 V
				Blinking (Ignition switch OFF)	 <p style="text-align: right; font-size: small;">JPMA0014GB</p>
				OFF	12 V
25 (LG)	Ground	NATS antenna amp.	Input/ Output	Just after inserting ignition key in key cylinder	Pointer of tester should move
				Other than above	0 V
26 (GR)	Ground	Thermo control amp.	Input	Ignition switch ON	0 V
				Evaporator is extremely low temperature	12 V

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
27 (Y/G)	Ground	A/C switch	Input	A/C switch	OFF	 <small>JPMIA0012GB</small> 1.0 - 1.5 V
				A/C switch	ON	0 V
28 (G/W)	Ground	Blower fan switch	Input	Fan switch	Blower fan switch OFF	 <small>PKIB4960J</small> 7.0 - 8.0 V
				Fan switch	Blower fan switch ON	0 V
29 (L/W)	Ground	Hazard switch	Input	Hazard switch	OFF	Battery voltage
				Hazard switch	ON	0 V
31 (G/Y)	Ground	Front defroster switch	Input	Ignition switch	ON	0 V
				Ignition switch	Other than A/C mode defroster ON position	 <small>JPMIA0589GB</small> 8.0 - 9.0 V
32 (LG)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>PKIB4960J</small> 7.0 - 8.0 V
				Combination switch	Rear wiper switch ON (Wiper intermittent dial 4)	0 V
				Combination switch	Any of the condition below with all switch OFF	 <small>PKIB4956J</small> 1.0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
33 (Y/L)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	
34 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>						
35 (R/L)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						

# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
36 (L/O)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 7.0 - 8.0 V
					Turn signal switch RH	 1.2 V
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
Front washer switch ON						
37 (R/W)	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage	
				Remove mechanical key from ignition key cylinder	0 V	
38 (O)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
39 (L)	Ground	CAN-H	Input/ Output	—	—	
40 (P)	Ground	CAN-L	Input/ Output	—	—	
43 (W)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed)	 7.0 - 8.0 V
					ON (When back door opened)	0 V
44 (LG)	Ground	Rear wiper stop po- sition	Input	Ignition switch ON	Rear wiper stop position	12 V
					Any position other than rear wiper stop position	0 V
45 (GR)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch	NEUTRAL position	 1.0 - 1.5 V
					LOCK position	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)



## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
46 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch	NEUTRAL position	 1.0 - 1.5 V
					UNLOCK position	0 V
47 (BR/Y)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	 7.0 - 8.0 V
					ON (When driver door opened)	0 V
48 (W/G)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closed)	 7.0 - 8.0 V
					ON (When rear LH door opened)	0 V
50 (SB)	Ground	A/C indicator	Output	A/C indicator	OFF	12 V
					ON	0 V
54 (LG)	Ground	Rear wiper	Output	Ignition switch ON	Rear wiper switch OFF	0 V
					Rear wiper switch ON	12 V
56 (L)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V	
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V	
57 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
59 (L/B)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
60 (W/B)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	
61 (W/L)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	
63 (BR)	Ground	Interior room lamp control signal	Output	Interior room lamp	OFF 12 V
				ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activat- ed) 12 V
				Other than LOCK (Actua- tor is not activated)	0 V
66 (G)	Ground	Passenger door and rear door UNLOCK	Output	Passenger door and rear door	UNLOCK (Actuator is acti- vated) 12 V
				Other than UNLOCK (Ac- tuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON	0 V
68 (L)	Ground	P/W power supply (IGN)	Output	Ignition switch ON	12 V
69 (P)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
70 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## WITHOUT INTELLIGENT KEY : Wiring Diagram - BCM -

INFOID:000000010245798




2013/09/19

JRMWE7716GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE7717GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





JRMWE7718GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



### BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)

**Connector No. B11**  
**Connector Name** LUGGAGE ROOM LAMP  
**Connector Type** CJ04FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
3	L	-

**Connector No. B27**  
**Connector Name** FRONT DOOR SWITCH (PASSENGER SIDE)  
**Connector Type** TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
3	L	-

**Connector No. B34**  
**Connector Name** FRONT DOOR SWITCH (DRIVER SIDE)  
**Connector Type** TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
3	B	-
4	W	-
5	R	-
6	V	-

**Connector No. B53**  
**Connector Name** REAR DOOR SWITCH RH  
**Connector Type** TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-

**Connector No. B59**  
**Connector Name** REAR COMBINATION LAMP RH  
**Connector Type** RS06FB-FR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	O	-
5	Y	-
6	V	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	GB	-
12	SB	-
13	W	-
15	G	-
16	W	-

**Connector No. B80**  
**Connector Name** REAR COMBINATION LAMP LH  
**Connector Type** RS06FB-FR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
3	B	-
4	B	-
5	R	-
6	GR	-

**Connector No. B71**  
**Connector Name** REAR DOOR SWITCH LH  
**Connector Type** TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-

**Connector No. B75**  
**Connector Name** BACK DOOR SWITCH  
**Connector Type** TH04FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	-
3	W	-

**Connector No. D5**  
**Connector Name** POWER WINDOW MAIN SWITCH  
**Connector Type** NST6FW-CS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	O	-
5	Y	-
6	V	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	GB	-
12	SB	-
13	W	-
15	G	-
16	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

JRMWE7826GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)		
Connector No.	D6	POWER WINDOW MAIN SWITCH
Connector Name	NS08FMV-CS	
Terminal No.	Wire	Signal Name [Specification]
17	B	-
18	GR	-
19	P	-
Connector No.	D9	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Name	E06F-GY-RS	
Terminal No.	Wire	Signal Name [Specification]
1	V	-
2	SB	-
3	G	-
4	B	-
5	L	-
6	W	-
Connector No.	D13	REAR POWER WINDOW SWITCH RH
Connector Name	NS08FMV-CS	
Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	O	-
4	G	-
5	R	-
Connector No.	D15	REAR DOOR LOCK ASSEMBLY RH
Connector Name	E06F-GY-RS	
Terminal No.	Wire	Signal Name [Specification]
5	W	-
6	P	-
Connector No.	D25	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Name	NS12FMV-CS	
Terminal No.	Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	B	-
4	Y	-
7	R	-
8	L	-
11	SB	-
12	W	-
Connector No.	D28	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Name	E06F-GY-RS	
Terminal No.	Wire	Signal Name [Specification]
5	V	-
6	Y	-
Connector No.	D43	REAR POWER WINDOW SWITCH LH
Connector Name	NS08FMV-CS	
Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	O	-
4	G	-
5	R	-
Connector No.	D45	REAR DOOR LOCK ASSEMBLY LH
Connector Name	E06F-GY-RS	
Terminal No.	Wire	Signal Name [Specification]
5	W	-
6	P	-
Connector No.	D63	REAR POWER WINDOW SWITCH LH
Connector Name	NS08FMV-CS	
Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	O	-
4	G	-
5	R	-
Connector No.	D65	REAR DOOR LOCK ASSEMBLY LH
Connector Name	E06F-GY-RS	
Terminal No.	Wire	Signal Name [Specification]
1	V	-
2	G	-

JRMWE7827GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)

Connector No.	D106
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	FEA04FB-FH2-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	Y	-

Connector No.	D112
Connector Name	REAR WIPER MOTOR
Connector Type	CJ04FM-TV



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
3	BR	-
4	LG	-

Connector No.	E11
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	M06FELC



Terminal No.	Color Of Wire	Signal Name [Specification]
9	BTW	-
10	BTW	-
13	W	-

Connector No.	E12
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FBCS



Terminal No.	Color Of Wire	Signal Name [Specification]
18	Y	-
19	BTW	-
21	W	-
22	V	-

Connector No.	E13
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH12FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
24	G	-
25	Y	-
26	P	-
27	L	-
28	P	-
30	SB	-
31	W	-
33	O	-
34	R	-

Connector No.	E23
Connector Name	SIDE TURN SIGNAL LAMP LH
Connector Type	STL02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BR	-

Connector No.	E27
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BTW	-

Connector No.	E40
Connector Name	SIDE TURN SIGNAL LAMP RH
Connector Type	STL02FW























Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	BY	-

JRMWE7828GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)		(WITHOUT INTELLIGENT KEY)	
Connector No.	E146	Connector No.	E115
Connector Name	FRONT TURN SIGNAL LAMP RH	Connector Name	STOP LAMP SWITCH
Connector Type	RS02FB	Connector Type	M04FW-LC
			
Terminal No.	Wire	Signal Name [Specification]	
1	W	-	
2	BY	-	
Connector No.	E114	Connector No.	M26
Connector Name	STOP LAMP SWITCH	Connector Name	NATS ANTENNA AMP.
Connector Type	M02PE-LC	Connector Type	TH04FW-NH
			
Terminal No.	Wire	Signal Name [Specification]	
1	W	-	
2	BY	-	
3	O	-	
4	G	-	
Connector No.	E148	Connector No.	M24
Connector Name	FRONT TURN SIGNAL LAMP LH	Connector Name	KEY SWITCH
Connector Type	RS02FB	Connector Type	TK06MGY
			
Terminal No.	Wire	Signal Name [Specification]	
1	V	-	
2	W	-	
3	O	-	
4	G	-	
Connector No.	E149	Connector No.	M27
Connector Name	STOP LAMP SWITCH	Connector Name	COMBINATION SWITCH
Connector Type	M02PE-LC	Connector Type	TH04FW-NH
			
Terminal No.	Wire	Signal Name [Specification]	
1	V	-	
2	W	-	
3	O	-	
4	G	-	
Connector No.	E150	Connector No.	M34
Connector Name	STOP LAMP SWITCH	Connector Name	COMBINATION METER
Connector Type	M02PE-LC	Connector Type	TH04FW-NH
			
Terminal No.	Wire	Signal Name [Specification]	
1	V	-	
2	W	-	
3	O	-	
4	G	-	
5	B	-	
6	L	-	
7	GR/R	-	
8	O	-	
14	P	-	
16	LG/R	-	
Terminal No.	Wire	Signal Name [Specification]	
1	O/B	WASHER (RR)	
2	GR	OUTPUT 4	
3	RG	WASHER (FR)	
4	W	IGN	
5	LY	OUTPUT 3	
6	B	GROUND	
7	V	INPUT 3	
8	BRW	OUTPUT 5	
9	R/L	INPUT 2	
10	Y/L	INPUT 4	
11	L/O	INPUT 1	
12	L/R	OUTPUT 1	
13	LG	INPUT 5	
14	G	OUTPUT 2	
Terminal No.	Wire	Signal Name [Specification]	
1	Y	BAT	
2	P/L	CLK	
3	B	GND (Without Intelligent Key)	
3	LG	DATA (With Intelligent Key)	
4	B	GND (With Intelligent Key)	
4	LG	DATA (Without Intelligent Key)	
Terminal No.	Wire	Signal Name [Specification]	
1	L	CANH	
2	P	CANL	
3	V	VEHICLE SPEED SIGNAL (2-PULSE)	
4	L	VEHICLE SPEED SIGNAL (8-PULSE) (Without NAV)	
4	VR	VEHICLE SPEED SIGNAL (8-PULSE) (With NAV)	
6	BRY	FUEL LEVEL SENSOR SIGNAL	

JRMWE7829GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY)

Connector No.	Signal Name	Terminal No.	Wire	Color	Specification
7	R/G				AIR BAG SIGNAL
8	P				OVERDRIVE CONTROL SWITCH SIGNAL
9	O				SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
10	SB				PARKING BRAKE SWITCH SIGNAL
11	G/R				BRAKE FLUID LEVEL SWITCH SIGNAL
13	B/R				ILLUMINATION CONTROL SIGNAL
15	L/Y				ACC POWER SUPPLY
18	R/Y				SECURITY SIGNAL
19	P/W				AMBIENT SENSOR SIGNAL
20	R/W				AMBIENT SENSOR GROUND
21	B				GROUND
22	B				GROUND
23	B				GROUND
24	P/U				FUEL LEVEL SENSOR GROUND
25	B				VDC GROUND
27	L/G/R				BATTERY POWER SUPPLY
28	GR				IGNITION SIGNAL
29	BR				PASSENGER SEAT BELT WARNING SIGNAL
31	R				AC AUTO AMP CONNECTOR (ELECTRICAL SOURCE)
35	BR				ENGINE COOLANT TEMPERATURE SIGNAL
38	GR				ALTERNATOR SIGNAL

Connector No.	M44
Connector Name	THERMO CONTROL AMP.
Connector Type	SUBFW



Terminal No.	Color Of Wire	Signal Name	Specification
1	Y		
2	GR		
3	B		
4	V		
5	B/W		

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color Of Wire	Signal Name	Specification
1	B		
2	L/W		
3	W		
4	B/R		

Connector No.	M53
Connector Name	A/C CONTROL
Connector Type	THH6FW-NH




Terminal No.	Color Of Wire	Signal Name	Specification
1	W		
4	R		
5	W/L		
6	G/Y		
8	G		
9	B/R		
10	B/W		
11	V		
12	Y/R		
13	SB		
14	Y		
15	B		
16	L		

Connector No.	M61
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TK04FW



Terminal No.	Color Of Wire	Signal Name	Specification
1	V		
2	G/Y		
4	BR		


Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name	Specification
2	BR/W	COMBI SW INPUT 5	
3	GR	COMBI SW INPUT 4	
4	L/Y	COMBI SW INPUT 3	
5	G	COMBI SW INPUT 2	
6	L/R	COMBI SW INPUT 1	
7	W/R	KEY CYL LOCK SW	
8	W/B	KEY CYL LOCK SW	
9	R	STOP LAMP SW	
10	W/L	REAR WINDOW DEFOGGER SW	
11	L/Y	ACC POWER SUPPLY	
12	SB	PASSENGER DOOR SW	
13	GB/L	REAR RH DOOR SW	
14	V	RECEIVER / SENSOR GND	
19	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY	
20	G/Y	KEYLESS ENTRY RECEIVER COMM	
21	P/L	NAIS ANTENNA AMP.	
23	R/Y	SECURITY INDICATOR LAMP	

Terminal No.	Color Of Wire	Signal Name	Specification
25	LG	NAIS ANTENNA AMP.	
26	GR	THERMO CONTROL AMP.	
27	Y/G	A/C SW	
28	G/W	BLOWER FAN SW	
29	L/W	HAZARD SW	
31	G/Y	FR DEFROSTER SW	
32	LG	COMBI SW OUTPUT 5	
33	Y/L	COMBI SW OUTPUT 4	
34	W	COMBI SW OUTPUT 3	
35	R/L	COMBI SW OUTPUT 2	
36	L/O	COMBI SW OUTPUT 1	
37	R/W	KEY SWITCH	
38	O	IGNITION POWER SUPPLY	
39	L	CANH	
40	P	CANL	

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FE409FW-FH46-SA



Terminal No.	Color Of Wire	Signal Name	Specification
43	W	BACK DOOR SW	
44	LG	REAR WIPER STOP POSITION	
45	GR	CENTRAL DOOR LOCK SW	
46	BR	CENTRAL DOOR UNLOCK SW	
47	B/R	DRIVER DOOR SW	
48	W/G	REAR LH DOOR SW	
50	SB	A/C INDICATOR OUTPUT	
54	LG	REAR WIPER OUTPUT	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



### BCM (BODY CONTROL MODULE)

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHAG-SA

Terminal No.	Wire	Signal Name [Specification]
56	L	INTERIOR ROOM LAMP POWER SUPPLY
57	Y	BAT (ELISE)
59	L/B	DRIVER DOOR UNLOCK OUTPUT
60	W/B	TURN SIGNAL LH OUTPUT
61	W/L	TURN SIGNAL RH OUTPUT
63	BR	ROOM LAMP TIMER CONTROL
65	V	ALL DOOR LOCK OUTPUT
66	G	PASSENGER DOOR REAR DOOR UNLOCK OUTPUT
67	B	GROUND
68	L	POWER WINDOW POWER SUPPLY (IGN)
69	P	POWER WINDOW POWER SUPPLY (BAT)
70	Y	BAT (FL)



Connector No.	M73
Connector Name	FAN SWITCH
Connector Type	M08FW-LC

Terminal No.	Wire	Signal Name [Specification]
1	R	-
2	W	-
3	B	-
4	Y	-
5	L	-
6	GW	-



### (WITHOUT INTELLIGENT KEY)

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	GAA06FW

Terminal No.	Wire	Signal Name [Specification]
2	LG	-
3	B	-
4	Y	-

Connector No.	R6
Connector Name	ROOM LAMP
Connector Type	C02FW

Terminal No.	Wire	Signal Name [Specification]
1	Y	-
2	BR	-

## WITHOUT INTELLIGENT KEY : Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

JRMWE7831GB

INFOID:0000000010245799

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal.

When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. Pass more than 1 minute after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### WITHOUT INTELLIGENT KEY : DTC Inspection Priority Chart

INFOID:0000000010245800

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> <li>• U1000: CAN COMM</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI SCANNING</li> </ul>
3	C1735: IGN CIRCUIT OPEN
4	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1729: VHCL SPEED SIG ERR</li> </ul>

### WITHOUT INTELLIGENT KEY : DTC Index

INFOID:0000000010245801

#### NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Tire pressure monitor warn- ing lamp ON	Reference
U1000: CAN COMM	—	—	<a href="#">BCS-120</a>
U1010: CONTROL UNIT (CAN)	—	—	<a href="#">BCS-121</a>
B2190: NATS ANTENNA AMP	×	—	<a href="#">SEC-197</a>
B2191: DIFFERENCE OF KEY	×	—	<a href="#">SEC-200</a>
B2192: ID DISCORD BCM-ECM	×	—	<a href="#">SEC-201</a>
B2193: CHAIN OF BCM-ECM	×	—	<a href="#">SEC-202</a>
B2195: ANTI SCANNING	×	—	<a href="#">SEC-203</a>
C1704: LOW PRESSURE FL	—	×	<a href="#">WT-26</a>
C1705: LOW PRESSURE FR	—	×	
C1706: LOW PRESSURE RR	—	×	
C1707: LOW PRESSURE RL	—	×	
C1708: [NO DATA] FL	—	×	<a href="#">WT-28</a>
C1709: [NO DATA] FR	—	×	
C1710: [NO DATA] RR	—	×	
C1711: [NO DATA] RL	—	×	
C1716: [PRESS DATA ERR] FL	—	×	<a href="#">WT-31</a>
C1717: [PRESS DATA ERR] FR	—	×	
C1718: [PRESS DATA ERR] RR	—	×	
C1719: [PRESS DATA ERR] RL	—	×	
C1729: VHCL SPEED SIG ERR	—	×	<a href="#">WT-33</a>
C1735: IGN CIRCUIT OPEN	—	—	<a href="#">BCS-122</a>

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

WITH INTELLIGENT KEY

WITH INTELLIGENT KEY : Reference Value

INFOID:0000000010246439

VALUES ON THE DIAGNOSIS TOOL

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1/2/3/4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND, HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	<ul style="list-style-type: none"> <li>Selector lever in any position other than P or N (CVT models)</li> <li>Release clutch pedal (M/T models)</li> </ul>	Off
		<ul style="list-style-type: none"> <li>Selector lever in P or N position (CVT models)</li> <li>Depress clutch pedal (M/T models)</li> </ul>	On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ST RLY CONT	Ignition switch ON	Off
	At engine cranking	On
IHBT RLY -REQ	Ignition switch ON	Off
	At engine cranking	On
ST/INHI RLY	Ignition switch ON	Off
	At engine cranking	INHI ON → ST ON
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN
DETENT SW	Ignition switch ON <ul style="list-style-type: none"> <li>• Pull the selector lever with selector lever in P position</li> <li>• Selector lever in any position other than P</li> </ul>	Off
	Release the selector lever with selector lever in P position <b>NOTE:</b> Fixed On for M/T models	On
S/L RLY -REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L STATE	<b>NOTE:</b> The item is indicated, but not monitored.	UNLOCK
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
OIL P SW	Ignition switch OFF, ACC or engine running	Open
	Ignition switch ON	Close
HOOD SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
THFT HRN REQ	Not operation	Off
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On
HORN CHIRP	Not operating	Off
	Door locking with Intelligent Key (horn chirp mode)	On

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT





## PHYSICAL VALUES

Terminal NO. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
3 (BR)	Ground	Starter motor	Output	Ignition switch ON	0 V
				At engine cranking	Battery voltage
4 (P)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
5 (LG)	Ground	Cooling fan relay-1 power supply	Output	Cooling fan OFF	0 V
				Cooling fan operated	Battery voltage
7 (Y)	Ground	Cooling fan relay-2 power supply	Output	Cooling fan OFF	0 V
				Cooling fan LO operated	9.0 V
				Cooling fan HI operated	Battery voltage
8 (V)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
9 (B/W)	Ground	Ground	—	Ignition switch ON	0 V
10 (L)	Ground	Cooling fan motor ground	Output	Cooling fan OFF	0 V
				Cooling fan LO operated	5.0 V
				Cooling fan HI operated	0 V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
13 (W)	Ground	Rear window defogger	Output	Ignition switch OFF	Rear window defogger switch OFF	0 V
				Ignition switch ON	Rear window defogger switch ON	Battery voltage
19 (B/W)	Ground	Ground	—	Ignition switch ON		0 V
21 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND OFF	Front fog lamp switch OFF	0 V
				Lighting switch 2ND ON	Front fog lamp switch ON	Battery voltage
22 (V)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND OFF	Front fog lamp switch OFF	0 V
				Lighting switch 2ND ON	Front fog lamp switch ON	Battery voltage
24 (G)	Ground	Oil pressure switch	Input	Ignition switch OFF	Engine stopped	0 V
				Ignition switch ON	Engine running	Battery voltage
25 (Y)	Ground	Front wiper auto stop	Input	Ignition switch OFF	Front wiper stop position	0 V
				Ignition switch ON	Any position other than front wiper stop position	Battery voltage
26 (P)	Ground	CAN-L	Input/ Output	—		—
27 (L)	Ground	CAN-H	Input/ Output	—		—
30 (SB)	Ground	Starter relay control	Output	At engine cranking		0 V
				Ignition switch ON		Battery voltage
31 (W)	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		0 - 1.5 V
				Approximately 1 second or more after turning the ignition switch ON		Battery voltage
33 (O)	Ground	Power generation command signal	Output	Ignition switch ON		Battery voltage
				40 % is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"  JPMIA0002GB		3.8 V
				80 % is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"  JPMIA0003GB		1.4 V
34 (R)	Ground	Horn relay control	Output	The horn is deactivated		Battery voltage
				The horn is activated		0 V



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
36 (O)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
37 (V)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
38 (G)	Ground	Tail lamp (RH) & illuminations	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
39 (V)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage
40 (R)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		Battery voltage
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		0 - 1.5 V
41 (SB)	Ground	Tail lamp (LH) & license plate lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
43 (G)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
44 (P)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
45 (Y)	Ground	TCM power supply	Output	Ignition switch OFF		Battery voltage
46 (O)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch LO	Battery voltage
47 (BR)	Ground	Transmission range switch <sup>*1</sup>	Input	Select lever in any position other than P or N (Ignition switch ON)		0 V
				Select lever P or N (Ignition switch ON)		Battery voltage
		Clutch interlock switch <sup>*2</sup>		Release the clutch pedal		0 V
				Depress the clutch pedal		Battery voltage
49 (W)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>• Lighting switch HI</li> <li>• Lighting switch PASS</li> </ul>	
50 (GR)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>• Lighting switch HI</li> <li>• Lighting switch PASS</li> </ul>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
51 (R)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
52 (P)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
54 (GR)	Ground	Throttle control motor relay power supply	Output		Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
					<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ig- nition switch OFF)</li> </ul>	Battery voltage
55 (P)	Ground	Fuel pump power sup- ply	Output		Approximately 1 second or more than after turning the ignition switch ON	0 V
					<ul style="list-style-type: none"> <li>Approximately 1 second after turn- ing the ignition switch ON</li> <li>Engine running</li> </ul>	Battery voltage
56 (SB)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is oper- ating)	Battery voltage
57 (G)	Ground	Throttle control motor relay control	Output		Ignition switch ON → OFF	0 - 1.0 V ↓ Battery voltage ↓ 0 V
					Ignition switch ON	0 - 1.0 V
58 (R)	Ground	Ignition relay power supply	Output		Ignition switch OFF	0 V
					Ignition switch ON	Battery voltage
59 (Y)	Ground	Ignition relay power supply	Output		Ignition switch OFF	0 V
					Ignition switch ON	Battery voltage
60 (V)	Ground	Ignition relay power supply	Output		Ignition switch OFF	0 V
					Ignition switch ON	Battery voltage
61 (W)	Ground	Ignition relay power supply	Output		Ignition switch OFF	0 V
					Ignition switch ON	Battery voltage
62 (L)	Ground	Ignition relay power supply	Output		Ignition switch OFF	0 V
					Ignition switch ON	Battery voltage
64*1 (R)	Ground	CVT shift selector (Detention switch)	Input	Ignition switch ON	Select lever P	0 V
					Select lever in any posi- tion other than P	Battery voltage
66 (L)	Ground	Push-button ignition switch	Input		Press the push-button ignition switch	0 V
					Release the push-button ignition switch	Battery voltage
69 (O)	Ground	Ignition relay monitor	Input		Ignition switch OFF or ACC	Battery voltage
					Ignition switch ON	0 V

\*1: CVT models

\*2: M/T models


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## WITH INTELLIGENT KEY : Wiring Diagram — IPDM E/R —

INFOID:000000010246440

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) (WITH INTELLIGENT KEY)




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

2013/09/19

JRMWE7720GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< ECU DIAGNOSIS INFORMATION >



JRMWE7721GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



















JRMWE7722GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) (WITH INTELLIGENT KEY)			
Connector No.	E9	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	
Connector Name	L02FB-MC		
Connector Type			
 			
Terminal No.	Wire	Signal Name [Specification]	
1	R	-	
2	G	-	
<b>Connector No.</b> E10 <b>Connector Name</b> IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM) <b>Connector Type</b> M06FB-LC			
 			
Terminal No.	Wire	Signal Name [Specification]	
3	BR	-	
4	P	-	
5	LG	-	
6	SB	-	
7	Y	-	
8	V	-	
Connector No.	E11	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	
Connector Name	M06FB-LC		
Connector Type			
 			
Terminal No.	Wire	Signal Name [Specification]	
9	BAW	-	
10	L	-	
13	W	-	
<b>Connector No.</b> E12 <b>Connector Name</b> IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM) <b>Connector Type</b> NS08FB-RCS			
 			
Terminal No.	Wire	Signal Name [Specification]	
18	Y	-	
19	BAW	-	
21	W	-	
22	V	-	
Connector No.	E13	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	
Connector Name	TH12FB-NH		
Connector Type			
 			
Terminal No.	Wire	Signal Name [Specification]	
24	G	-	
25	Y	-	
26	P	-	
27	L	-	
28	B	-	
30	SB	-	
31	W	-	
33	O	-	
34	R	-	
<b>Connector No.</b> E14 <b>Connector Name</b> IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM) <b>Connector Type</b> NS12FB-RCS			
 			
Terminal No.	Wire	Signal Name [Specification]	
36	O	-	
37	V	-	
38	G	-	
39	V	-	
40	R	-	
41	SB	-	
43	G	-	
44	B	-	
45	Y	-	
46	O	-	
Connector No.	E15	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	
Connector Name	NS18FB-LCS		
Connector Type			
 			
Terminal No.	Wire	Signal Name [Specification]	
47	BR	-	
49	W	-	
50	GR	-	
51	R	-	
52	B	-	
54	GR	-	
55	P	-	
56	SB	-	
57	G	-	
58	LG	- [With M/T]	
59	R	- [With CVT]	
60	V	-	
61	W	-	
62	L	-	
<b>Connector No.</b> E17 <b>Connector Name</b> IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM) <b>Connector Type</b> TH10FB-NH			
 			
Terminal No.	Wire	Signal Name [Specification]	
64	R	-	
66	L	-	
69	O	-	

JRMWE7835GB

INFOID:000000010246441

### WITH INTELLIGENT KEY : Fail-Safe

#### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>The cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 turn ON when the ignition switch is turned ON (Cooling fan HI operation)</li> <li>The cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 turn OFF when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

### If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>Side marker lamps</li> <li>License plate lamps</li> <li>Illuminations</li> <li>Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>Detects DTC "B2098: IGN RELAY ON"</li> <li>Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal. When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### WITH INTELLIGENT KEY : DTC Index

INFOID:0000000010246442

### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Refer to
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-15</a>
B2098: IGN RELAY ON CIRC	×	<a href="#">PCS-16</a>
B2099: IGN RELAY OFF CIRC	—	<a href="#">PCS-18</a>
B210B: STR CONT RLY ON CIRC	—	<a href="#">SEC-76</a>
B210C: STR CONT RLY OFF CIRC	—	<a href="#">SEC-77</a>
B210D: STARTER RLY ON CIRC	—	<a href="#">SEC-78</a>
B210E: STARTER RLY OFF CIRC	—	<a href="#">SEC-79</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-81</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-83</a>

## WITHOUT INTELLIGENT KEY

### WITHOUT INTELLIGENT KEY : Reference Value

INFOID:0000000010246444

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1/2/3/4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND, HI or AUTO (Light is illuminated)		On



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status	
HL HI REQ	Lighting switch OFF		Off	A
	Lighting switch HI		On	
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off	B
		Front fog lamp switch ON	On	
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop	C
		Front wiper switch INT	1LOW	
		Front wiper switch LO	Low	D
		Front wiper switch HI	Hi	
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P	E
		Any position other than front wiper stop position	ACT P	
WIP PROT	Ignition switch ON	Front wiper operates normally	Off	F
		Front wiper stops at fail-safe operation	BLOCK	
IGN RLY	Ignition switch OFF or ACC		Off	G
	Ignition switch ON		On	
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N (CVT models)	Off	H
		Selector lever in P or N position (CVT models)	On	
ST RLY -REQ	Ignition switch OFF or ACC		Off	I
	Ignition switch ON		On	
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off	J
OIL P SW	Ignition switch OFF, ACC or engine running		Open	
	Ignition switch ON		Close	
HOOD SW	<b>NOTE:</b> The item is indicated, but not monitored.		Off	K
THFT HRN REQ	Not operation		Off	
	<ul style="list-style-type: none"> <li>Panic alarm is activated</li> <li>Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>		On	DEF
HORN CHIRP	Not operating		Off	M
	Door locking with key fob (horn chirp mode)		On	

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT





JPMIA1512ZZ

## PHYSICAL VALUES

Terminal NO. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
3 (BR)	Ground	Starter motor	Output	Ignition switch ON	0 V
				At engine cranking	Battery voltage
5 (LG)	Ground	Cooling fan relay-1 power supply	Output	Cooling fan OFF	0 V
				Cooling fan operated	Battery voltage
6 (SB)	Ground	Ignition switch START	Output	Any position other ignition switch START	0 V
				Ignition switch START	Battery voltage
7 (Y)	Ground	Cooling fan relay-2 power supply	Output	Cooling fan OFF	0 V
				Cooling fan LO operated	9.0 V
				Cooling fan HI operated	Battery voltage
8 (V)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
9 (B/W)	Ground	Ground	—	Ignition switch ON	0 V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
10 (L)	Ground	Cooling fan motor ground	Output	Cooling fan OFF		0 V
				Cooling fan LO operated		5.0 V
				Cooling fan HI operated		0 V
13 (W)	Ground	Rear window defogger	Output	Ignition switch OFF	Rear window defogger switch OFF	0 V
				Ignition switch ON	Rear window defogger switch ON	Battery voltage
18 (Y)	Ground	Ignition switch	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
19 (B/W)	Ground	Ground	—	Ignition switch ON		0 V
21 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
				Front fog lamp switch ON		Battery voltage
22 (V)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
				Front fog lamp switch ON		Battery voltage
24 (G)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped	0 V
				Engine running		Battery voltage
25 (Y)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
				Any position other than front wiper stop position		Battery voltage
26 (P)	Ground	CAN-L	Input/ Output	—		—
27 (L)	Ground	CAN-H	Input/ Output	—		—
31 (W)	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		0 - 1.5 V
				Approximately 1 second or more after turning the ignition switch ON		Battery voltage
33 (O)	Ground	Power generation command signal	Output	Ignition switch ON		Battery voltage
				40 % is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 <p style="text-align: right; font-size: small;">JPMIA0002GB</p>
				80 % is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 <p style="text-align: right; font-size: small;">JPMIA0003GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DEF

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
34 (R)	Ground	Horn relay control	Output	The horn is deactivated		Battery voltage
				The horn is activated		0 V
36 (O)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
37 (V)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
38 (G)	Ground	Tail lamp (RH) & illuminations	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
39 (V)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage
40 (R)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		Battery voltage
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		0 - 1.5 V
41 (SB)	Ground	Tail lamp (LH) & license plate lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
43 (G)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
44 (P)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
45 (Y)	Ground	TCM power supply	Output	Ignition switch OFF		Battery voltage
46 (O)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch LO	Battery voltage
47 (BR)	Ground	Transmission range switch <sup>*1</sup>	Input	Select lever in any position other than P or N (Ignition switch ON)		0 V
				Select lever P or N (Ignition switch ON)		Battery voltage
		Clutch interlock switch <sup>*2</sup>	Input	Release the clutch pedal		0 V
				Depress the clutch pedal		Battery voltage
49 (W)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal NO. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
50 (GR)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
51 (R)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
52 (P)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
54 (GR)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
					<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	Battery voltage
55 (P)	Ground	Fuel pump power supply	Output	Approximately 1 second or more than after turning the ignition switch ON		0 V
					<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>	Battery voltage
56 (SB)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
57 (G)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF		0 - 1.0 V ↓ Battery voltage ↓ 0 V
					Ignition switch ON	0 - 1.0 V
58 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
					Ignition switch ON	Battery voltage
59 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
					Ignition switch ON	Battery voltage
60 (V)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
					Ignition switch ON	Battery voltage
61 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
					Ignition switch ON	Battery voltage
62 (L)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
					Ignition switch ON	Battery voltage

\*2: CVT models

\*3: M/T models


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## WITHOUT INTELLIGENT KEY : Wiring Diagram — IPDM E/R —

INFOID:000000010246445

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) (WITHOUT INTELLIGENT KEY)




2013/09/19

JRMWE723GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< ECU DIAGNOSIS INFORMATION >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >





# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Connector No.	IE9	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	LO2FB-MC	Terminal No.	Wire	Signal Name [Specification]
					1	R	-
					2	G	-
Connector No.	E10	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	M06FW-LC	3	BR	-
Connector Type					4	P	-
					5	LG	-
					6	SB	-
					7	Y	-
					8	V	-
Terminal No.	Wire	Signal Name [Specification]					
3	BR	-					
4	P	-					
5	LG	-					
6	SB	-					
7	Y	-					
8	V	-					
Connector No.	E11	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	M06FEL-C	9	BR	-
Connector Type					10	Y	-
					13	W	-
Terminal No.	Wire	Signal Name [Specification]					
9	BR	-					
10	Y	-					
13	W	-					
Connector No.	E12	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	NS08FBR-CS	18	Y	-
Connector Type					19	BR	-
					21	W	-
					22	V	-
Terminal No.	Wire	Signal Name [Specification]					
18	Y	-					
19	BR	-					
21	W	-					
22	V	-					
Connector No.	E13	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	TH12FM-NH	24	G	-
Connector Type					25	Y	-
					26	P	-
					27	L	-
					28	P	-
					30	SB	-
					31	W	-
					33	O	-
					34	R	-
Terminal No.	Wire	Signal Name [Specification]					
24	G	-					
25	Y	-					
26	P	-					
27	L	-					
28	P	-					
30	SB	-					
31	W	-					
33	O	-					
34	R	-					
Connector No.	E14	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	NS12FBR-CS	36	O	-
Connector Type					37	V	-
					38	G	-
					39	V	-
					40	R	-
					41	SB	-
					43	G	-
					44	P	-
					45	Y	-
					46	O	-
Terminal No.	Wire	Signal Name [Specification]					
36	O	-					
37	V	-					
38	G	-					
39	V	-					
40	R	-					
41	SB	-					
43	G	-					
44	P	-					
45	Y	-					
46	O	-					
Terminal No.	Wire	Signal Name [Specification]					
36	O	-					
37	V	-					
38	G	-					
39	V	-					
40	R	-					
41	SB	-					
43	G	-					
44	P	-					
45	Y	-					
46	O	-					
Connector No.	E15	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	NS16FM-CS	47	BR	-
Connector Type					49	W	-
					50	GR	-
					51	R	-
					52	P	-
					54	GR	-
					55	P	-
					56	SB	-
					57	G	-
					58	LG	- [With M/T]
					58	R	- [With CVT]
					59	Y	-
					60	V	-
					61	W	-
					62	L	-
Terminal No.	Wire	Signal Name [Specification]					
47	BR	-					
49	W	-					
50	GR	-					
51	R	-					
52	P	-					
54	GR	-					
55	P	-					
56	SB	-					
57	G	-					
58	LG	- [With M/T]					
58	R	- [With CVT]					
59	Y	-					
60	V	-					
61	W	-					
62	L	-					

### WITHOUT INTELLIGENT KEY : Fail-Safe

#### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

JRMWE7836GB

INFOID:000000010246446

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>The cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 turn ON when the ignition switch is turned ON (Cooling fan HI operation)</li> <li>The cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 turn OFF when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

### If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>Side marker lamps</li> <li>License plate lamps</li> <li>Illuminations</li> <li>Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Rear window defogger relay	Rear window defogger relay OFF
Horn	Horn OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit of the ignition relay inside and ignition switch status from BCM via CAN communication.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the ignition switch status from BCM via CAN communication.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition switch status from BCM		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>Detects DTC "B2098: IGN RELAY ON"</li> <li>Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### WITHOUT INTELLIGENT KEY : DTC Index

INFOID:0000000010246447

### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Refer to
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-15</a>
B2098: IGN RELAY ON CIRC	×	<a href="#">PCS-16</a>
B2099: IGN RELAY OFF CIRC	—	<a href="#">PCS-47</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF

# REAR WINDOW DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## SYMPTOM DIAGNOSIS

### REAR WINDOW DEFOGGER DOES NOT OPERATE

#### Description

INFOID:000000009945472

For models without door mirror defogger.

#### Diagnosis Procedure

INFOID:000000009945473

#### 1. CHECK REAR WINDOW DEFOGGER SWITCH

---

Check rear window defogger switch.

- With auto A/C: Refer to [DEF-20, "WITH AUTO A/C : Component Function Check"](#).
- Without manual A/C: Refer to [DEF-21, "WITH MANUAL A/C : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR WINDOW DEFOGGER RELAY

---

Check rear window defogger relay.

Refer to [DEF-24, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK REAR WINDOW DEFOGGER

---

Check rear window defogger.

Refer to [DEF-25, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

### Diagnosis Procedure

INFOID:000000009945484

#### 1. CHECK REAR WINDOW DEFOGGER FEEDBACK SIGNAL

Check rear window defogger feedback signal.

- With auto A/C: Refer to [DEF-27, "WITH AUTO A/C : Component Function Check"](#).
- With manual A/C: Refer to [DEF-27, "WITH MANUAL A/C : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

DEF

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009945485

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000010193898

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



# PRECAUTIONS

## < PRECAUTION >

### Precautions for Removing of Battery Terminal

INFOID:000000010246468

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

**NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


**NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

**NOTE:**

The removal of 12V battery may cause a DTC detection error.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# FILAMENT

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION


### FILAMENT

#### Inspection and Repair


INFOID:000000009945486

#### INSPECTION


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



#### REPAIR

##### REPAIR EQUIPMENT

- Conductive silver composition (Dupont No. 4817 or equivalent)




# FILAMENT

## < REMOVAL AND INSTALLATION >


- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

### REPAIRING PROCEDURE


1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen. Shake silver composition container before use.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited. Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P