

RF

SECTION
ROOF

A
B
C
D
E

F
G
H
I
J

RF
L
M
N
O

P

CONTENTS

BASIC INSPECTION	3	Component Function Check	12
DIAGNOSIS AND REPAIR WORKFLOW	3	Diagnosis Procedure	12
WorkFlow	3	Component Inspection	13
INSPECTION AND ADJUSTMENT	4	DOOR SWITCH	14
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	4	Description	14
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	4	Component Function Check	14
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	4	Diagnosis Procedure	14
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Reference Value	4	Component Inspection	15
SYSTEM DESCRIPTION	5	ECU DIAGNOSIS INFORMATION	16
SUNROOF SYSTEM	5	BCM (BODY CONTROL MODULE)	16
System Diagram	5	Reference Value	16
System Description	5	Wiring Diagram - BCM -	40
Component Parts Location	6	Fail-safe	54
Component Description	6	DTC Inspection Priority Chart	55
DIAGNOSIS SYSTEM (BCM)	7	DTC Index	56
COMMON ITEM	7	SUNROOF SYSTEM	59
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	7	SUNROOF MOTOR ASSEMBLY	59
RETAINED PWR	8	SUNROOF MOTOR ASSEMBLY : Reference Val- ue	59
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	8	SUNROOF MOTOR ASSEMBLY : Wiring Dia- gram - SUNROOF -	60
DTC/CIRCUIT DIAGNOSIS	10	SYMPTOM DIAGNOSIS	66
POWER SUPPLY AND GROUND CIRCUIT	10	SUNROOF DOES NOT OPERATE PROPER- LY	66
SUNROOF MOTOR ASSEMBLY	10	Description	66
SUNROOF MOTOR ASSEMBLY : Description	10	Diagnosis Procedure	66
SUNROOF MOTOR ASSEMBLY : Diagnosis Proce- dure	10	AUTO OPERATION DOES NOT OPERATE	68
SUNROOF SWITCH	12	Description	68
Description	12	Diagnosis Procedure	68
POWER WINDOW RETAINED POWER OP- ERATION DOES NOT OPERATE PROPERLY	69	POWER WINDOW RETAINED POWER OP- ERATION DOES NOT OPERATE PROPERLY	69
Diagnosis Procedure	69	Description	69
Diagnosis Procedure	69	Diagnosis Procedure	69

SUNROOF DOES NOT OPERATE ANTI-PINCH FUNCTION	70	GLASS LID	80
Diagnosis Procedure	70	Exploded View	80
SQUEAK AND RATTLE TROUBLE DIAGNOSES	71	Removal and Installation	80
Work Flow	71	Adjustment	81
Inspection Procedure	73		
Diagnostic Worksheet	75		
PRECAUTION	77	SUNROOF MOTOR ASSEMBLY	83
PRECAUTIONS	77	Exploded View	83
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	77	Removal and Installation	83
Precautions Necessary for Steering Wheel Rotation After Battery Disconnection	77	SUNROOF UNIT ASSEMBLY	85
PREPARATION	79	Exploded View	85
PREPARATION	79	Removal and Installation	86
Special Service Tool	79	Disassembly and Assembly	87
Commercial Service Tool	79		
REMOVAL AND INSTALLATION	80	SUNSHADE	88
		Exploded View	88
		Removal and Installation	88
		WIND DEFLECTOR	90
		Exploded View	90
		Removal and Installation	90
		SUNROOF SWITCH	91
		Exploded View	91
		Removal and Installation	91

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

WorkFlow

INFOID:000000008288829

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

RF

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000008288830

MEMORY RESET PROCEDURE

1. Please observe the following instructions at confirming the sunroof operation.

NOTE:

Do not disconnect the electronic power while the sunroof is operating or within after the sunroof stops (to wipe-out the memory of lid position and operating friction).

2. Initialization of system should be conducted after the following conditions.

- When the sunroof motor is changed.
- When the sunroof does not operate normally. (Incomplete initialization conditions)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000008288831

INITIALIZATION PROCEDURE

If the sunroof does not close or open automatically, use the following procedure to return sunroof operation to normal.

1. Press the tilt up switch and start the tilt up operation.
2. Release the tilt up switch once, press the tilt up switch again, press and hold the switch until lid pops up.
3. The glass lid moves slight toward tilt up direction then stop. (Press and hold the switch during this operation)
4. Release the switch again, and press the tilt up switch within the first 10 seconds. (Press and hold the switch)
5. After 4 seconds, the glass lid will be automatically operated in sequence of tilt down, slide open and slide close.
6. After the glass lid stops, release the switch 0.5 second later. (Press and hold the switch during this operation)
7. If slide switch operates normally, this initialization is done.

ANTI-PINCH FUNCTION

1. Full open the sunroof.
2. Place a wooden piece (wooden hammer handle,etc.) at near fully closed position.
3. Close the sunroof completely with auto-slide close.

Check that sunroof lowers for approximately 150 mm (5.91in) or 2 seconds with out pinching a wooden piece and stops.

CAUTION:

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Depending on environment and driving conditions, if a similar impact or load is applied to the sunroof it may lower.
- Check that auto-slide operation before inspection when system initialization is performed.
- Perform initial setting when auto-slide operation or anti-pinch function does not operate normally.

SUNROOF SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

SUNROOF SYSTEM

System Diagram

INFOID:0000000008288832

SUNROOF



System Description

INFOID:0000000008288833

SUNROOF OPERATION

- Sunroof motor assembly operates with the power supply that is output from BCM while ignition switch is ON or retained power is operating.
- Tilt up/down & slide open/close signals from sunroof switch enables operate sunroof motor to move arbitrarily.
- Sunroof motor assembly receives a vehicle speed signal from unified meter and A/C amp. and controls the sunroof motor torque of tilt-down at the time of high speed operation.

AUTO OPERATION

Sunroof AUTO feature makes it possible to slide open and slide close or tilt up and tilt down the sunroof without holding the sunroof switch in the slide open/tilt down or slide close/tilt up position.

RETAINED POWER OPERATION

Retained power operation is an additional power supply function that enables sunroof system to operate during 45 seconds even when ignition switch is turned OFF.

RETAINED POWER FUNCTION CANCEL CONDITIONS

- Front door CLOSE (door switch OFF) → OPEN (door switch ON).
- When ignition switch is ON again.
- When timer time passes. (45 seconds)

ANTI-PINCH FUNCTION

The CPU of sunroof motor assembly monitors the sunroof motor operation and the sunroof position (fully-closed or other) by the signals from sunroof motor.

When sunroof motor detects an interruption during the following slide close and tilt down operation, sunroof switch controls the motor for open and the sunroof will operate until full up position (when tilt down operate) or 150 mm (5.91 in) or more in an open direction (when slide close operate):

- Close operation and tilt down when ignition switch is in the "ON" position

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O


P

SUNROOF SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:0000000008288834



JMKIA0031ZZ

- | | | |
|-------------------------------------|------------------------------------|-------------------------------|
| 1. BCM | 2. Sunroof motor assembly | 3. Unified meter and A/C amp. |
| 4. Sunroof switch | 5. Front door switch (driver side) | |
| A. Dash side lower (passenger side) | B. View with headlining removed | C. Behind cluster lid C |

Component Description

INFOID:0000000008288835

Component	Function
BCM	Supplies the power supply to sunroof motor assembly. Controls retained power.
Sunroof switch	Transmits tilt up/down & slides open/close operation signal to sunroof motor assembly.
Sunroof motor assembly	It is sunroof motor and CPU integrated type that enables tilt up/down & slide open/close by sunroof switch operation
Front door switch	Detects door open/close condition and transmits to BCM.
Unified meter and A/C amp.	Transmits vehicle speed signal to sunroof motor assembly.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000010500391

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none">• Read and save the vehicle specification.• Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	AIR PRESSURE MONITOR	x	x	x

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"**)
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK"** to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Except emergency stop operation)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"**
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"**.) to low power consumption mode
	LOCK	Power supply position is "LOCK"**
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:0000000008288837

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of driver side door switch.
DOOR SW-AS	Indicates [ON/OFF] condition of passenger side door switch.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT SUNROOF MOTOR ASSEMBLY

SUNROOF MOTOR ASSEMBLY : Description

INFOID:0000000008288838

- BCM supplies power.
- It is sunroof motor and CPU integrated type.
- Tilt up/down & slide open/close by sunroof switch operation.

SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure

INFOID:0000000008288839

SUNROOF MOTOR ASSEMBLY

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector.
3. Turn ignition switch ON.
4. Check voltage between sunroof motor assembly harness connector and ground.

(+) Sunroof motor assembly		(-)	Voltage (V) (Approx.)
Connector	Terminal		
R4	9	Ground	Battery voltage
	7		

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 3.

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunroof motor assembly harness connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R4	10		Exists

Is the inspection result normal?

YES >> INSPECTION END
NO >> Repair or replace harness or connector.

3.CHECK SUNROOF MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and sunroof motor assembly harness connector.

BCM		Sunroof motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M118	2	R4	7	Exists
	3		9	

4. Check continuity between BCM harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M118	2		
	3		Not exist

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).
NO >> Repair or replace harness or connector.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SUNROOF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SUNROOF SWITCH

Description

INFOID:0000000008288840

Tilt up/down & slide open/close by sunroof switch operation.

Component Function Check

INFOID:0000000008288841

1.CHECK SUNROOF MOTOR OPERATION

Check tilt up/down & slide open/close operations with sunroof switch.

Is the inspection result normal?

YES >> Sunroof switch is OK.

NO >> Refer to [RF-12, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000008288842

SUNROOF SWITCH

1.CHECK SUNROOF SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof switch connector.
3. Turn ignition switch ON.
4. Check voltage between sunroof switch harness connector and ground.

(+) Sunroof switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
R16	1	Ground	Battery voltage
	3		

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunroof switch harness connector and ground.

Sunroof switch		Ground	Continuity
Connector	Terminal		Exist
R16	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

3.CHECK SUNROOF SWITCH

Check sunroof switch.

Refer to [RF-13, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sunroof switch (built in map lamp assembly). Refer to [RF-91, "Removal and Installation"](#).

4.CHECK SUNROOF SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector.
3. Check continuity between sunroof switch assembly harness connector and sunroof switch harness connector.

SUNROOF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Sunroof switch		Sunroof motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
R16	1	R4	5	Exist
	3		1	

4. Check continuity between sunroof switch assembly harness connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R4	5		Not exist
	1		

Is the inspection result normal?

- YES >> Replace sunroof motor assembly. Refer to [RF-83, "Removal and Installation"](#).
NO >> Repair or replace harness or connector.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008288843

SUNROOF SWITCH

1.CHECK SUNROOF SWITCH

1. Turn ignition switch OFF.
2. Disconnect sunroof switch connector.
3. Check continuity sunroof switch terminals.

Terminals		Condition	Continuity
1	2	Sunroof switch is operated TILT DOWN or SLIDE OPEN	Exists
		Other than above	Not exist
3		Sunroof switch is operated TILT UP or SLIDE CLOSE	Exists
		Other than above	Not exist

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sunroof switch (built in map lamp assembly). Refer to [RF-91, "Removal and Installation"](#).

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

Description

INFOID:0000000008288844

Detects door open/closed condition.

Component Function Check

INFOID:0000000008288845

1.CHECK FUNCTION

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in "Data Monitor" mode with CONSULT.

Monitor item	Door condition	Display
DOOR SW-DR	CLOSE → OPEN	OFF → ON
DOOR SW-AS		

Is the inspection result normal?

YES >> Door switch is OK.


NO >> Refer to [RF-14, "Diagnosis Procedure".](#)

Diagnosis Procedure

INFOID:0000000008288846

1.CHECK FRONT DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunction front door switch connector.
3. Check signal between malfunction front door switch harness connector and ground with oscilloscope.



Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and malfunction door switch harness connector.

BCM		Front door switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	124	B216	2	Exists
	150			

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	124		Not exist
	150		

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-96, "Removal and Installation"](#).
NO >> Repair or replace harness.

A

3.CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [RF-15, "Component Inspection"](#).

B

Is the inspection result normal?

C

- YES >> GO TO 4.
NO >> Replace malfunction front door switch. Refer to [DLK-270, "Removal and Installation"](#).

D

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

E

>> INSPECTION END

F

Component Inspection

INFOID:0000000008288847

G

1.CHECK FRONT DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunction front door switch connector.
3. Check malfunction front door switch.

H

I

J

(+)		Front door switch	(-)	Condition	Continuity	
Connector	Terminal					
Driver side	B16	2	Ground part of door switch	Door switch pressed	Not exist	
				Door switch released	Exists	
Passenger side	B216	2		Door switch pressed	Not exist	
				Door switch released	Exists	

Is the inspection result normal?

RF

L

M

N

O

P

- YES >> Front door switch is OK.
NO >> Replace malfunction front door switch. Refer to [DLK-270, "Removal and Installation"](#).

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000008788495

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
REVERSE SW	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On

A
B
C
D
E
F
G
H
I
J
RF
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	NOTE: The item is indicated, but not monitored.	Off
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Shift position is in the P position)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

RF

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT




PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
RF
L
M
N
O
P

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (W)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					0 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	
13 (B)	Ground	Ground	—	Ignition switch ON	
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC









BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
23 (G)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
34 (SB)	Ground	Luggage room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment  JKMKA0062GB
				When Intelligent Key is not in the passenger compartment  JKMKA0063GB
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment  JKMKA0062GB
				When Intelligent Key is not in the passenger compartment  JKMKA0063GB
38 (B)	Ground	Back door antenna (-)	Output When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area  JKMKA0062GB
				When Intelligent Key is not in the antenna detection area  JKMKA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
60 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
64 (V)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (BG)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
					Not in stop position	0 V

A
B
C
D
E
F
G
H
I
J

RF

L

M





N

O

P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
66 (R)	Ground	Back door switch	Input	Back door switch
				OFF (Door close)  <small>JPMIA0011GB</small> <small>11.8 V</small>
67 (GR)	Ground	Back door opener switch	Input	Back door opener switch
				Pressed  <small>JPMIA0011GB</small> <small>11.8 V</small>
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch
				OFF (Door close)  <small>JPMIA0011GB</small> <small>11.8 V</small>
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch
				OFF (Door close)  <small>JPMIA0011GB</small> <small>11.8 V</small>
				ON (Door open) <small>0 V</small>
				ON (Door open) <small>0 V</small>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
75 (GR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

J

RF

L

M

N


O

P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is oper- ated with ignition switch OFF
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is not in the antenna detection area
				When Intelligent Key is in the passenger compart- ment
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	When Intelligent Key is not in the passenger compart- ment
				When Intelligent Key is in the passenger compart- ment




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB





JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch OFF or ACC ON 0 V Battery voltage
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting  JKMKIA0064GB
				When operating either button on the key  JKMKIA0065GB

A

B

C

D

E

F

G

H

I

J

RF

L

M




N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
87 (BR)	Ground	Combination switch INPUT 5	Input	 All switches OFF (Wiper intermittent dial 4)  Front fog lamp switch ON (Wiper intermittent dial 4)  Rear wiper switch ON (Wiper intermittent dial 4) Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7
				JPMIA0041GB 1.4 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
				JPMIA0040GB 1.3 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Lighting switch HI (Wiper intermittent dial 4)	 JPMIA0036GB 1.3 V
				Lighting switch 2ND (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear washer switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 JPMIA0040GB 1.3 V
90 (P)	Ground	CAN-L	Input/ Output	—	—
91 (L)	Ground	CAN-H	Input/ Output	—	—

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

RF






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 (V) 15 10 5 0 1 s
					ON	6.5 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
					ON (Pressed)	1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
					ON (Pressed)	1.0 V
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
				Turn signal switch LH	 JPMIA0037GB 1.3 V
				Turn signal switch RH	 JPMIA0036GB 1.3 V
				Front wiper switch LO	 JPMIA0038GB 1.3 V
				Front washer switch ON	 JPMIA0039GB 1.3 V

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P
RF







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input Combination switch	All switches OFF (Wiper intermittent dial 4)
				 1.4 V JPMIA0041GB
				Lighting switch AUTO (Wiper intermittent dial 4)
				 1.3 V JPMIA0038GB
				Lighting switch 1ST (Wiper intermittent dial 4)
				 1.3 V JPMIA0036GB
				Rear wiper switch INT (Wiper intermittent dial 4)
				 1.3 V JPMIA0040GB
				Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
				 1.3 V JPMIA0039GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 <small>JPMIA0041GB</small> 1.4 V
					Lighting switch PASS	 <small>JPMIA0037GB</small> 1.3 V
					Lighting switch 2ND	 <small>JPMIA0036GB</small> 1.3 V
					Front wiper switch INT	 <small>JPMIA0038GB</small> 1.3 V
					Front wiper switch HI	 <small>JPMIA0040GB</small> 1.3 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	ON	0 V
					OFF	 <small>JPMIA0012GB</small> 1.1 V

A

B

C

D

E

F

G

H

I

J

RF

L

M




N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 <small>JPMIA0012GB</small> 1.1 V	
					UNLOCK status (Unlock switch sensor ON)	0 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 <small>JPMIA0011GB</small> 11.8 V	
					ON (Door open)	0 V	
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 <small>JPMIA0013GB</small> 10.2 V	
				Ignition switch OFF or ACC		Battery voltage	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	<p>NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  <p>JPMIA0159GB</p>
					OFF	0 V
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (BG)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 <p>OCC3881D</p>
					When receiving the signal from the transmitter	 <p>OCC3880D</p>
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 <p>JPMIA0014GB</p> <p>11.3 V</p>
					OFF	Battery voltage

A

B

C

D

E

F

G

H

I

J

RF

L

M

N


O

P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
142 (BG)	Ground	Combination switch OUTPUT 5	Combination switch (Wiper intermittent dial 4)	All switches OFF
				Lighting switch 1ST
				Lighting switch HI
				Lighting switch 2ND
				Turn signal switch RH
143 (P)	Ground	Combination switch OUTPUT 1	Combination switch	0 V
				All switches OFF (Wiper intermittent dial 4)
				Front wiper switch HI (Wiper intermittent dial 4)
				Rear wiper switch INT (Wiper intermittent dial 4)
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7
144 (G)	Ground	Combination switch OUTPUT 2	Combination switch	0 V
				All switches OFF (Wiper intermittent dial 4)
				Front washer switch ON (Wiper intermittent dial 4)
				Rear wiper switch ON (Wiper intermittent dial 4)
				Rear washer switch ON (Wiper intermittent dial 4)
145 (L)	Ground	Combination switch OUTPUT 3	Combination switch (Wiper intermittent dial 4)	0 V
				All switches OFF
				Front wiper switch INT
				Front wiper switch LO
				Lighting switch AUTO




JPMIA0031GB



JPMIA0032GB





JPMIA0033GB



JPMIA0034GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J RF	
	+	-	Signal name	Input/ Output		
146 (SB)	Ground	Combination switch OUTPUT 4	Combination switch (Wiper intermittent dial 4)	All switches OFF Front fog lamp switch ON Lighting switch 2ND Lighting switch PASS Turn signal switch LH	0 V	
					 JPMIA0035GB	
					10.7 V	
					 JPMIA0011GB	
					11.8 V	
150 (LG)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	0 V
					ON (Door open)	0 V
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V
					Not activated	Battery voltage


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:0000000008788496

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




2013/11/22

JRMWE9529GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE9530GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- RF : With sunroof
- PM : With automatic drive positioner
- OP : Without automatic drive positioner




* : This connector is not shown in "Harness Layout".

JRMWE9531GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE9532GB

RF

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







JRMWE9533GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B16</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B228</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>FRONT DOOR SWITCH (DRIVER SIDE)</td> <td>1 B</td> <td>-</td> <td>Connector Name</td> <td>INSIDE KEY ANTENNA (LUGGAGE ROOM)</td> <td>1 R</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>A03FW</td> <td>2 L</td> <td>-</td> <td>Connector Type</td> <td>RK02FGY</td> <td>2 V</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B16	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B228	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	1 B	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)	1 R	-	Connector Type	A03FW	2 L	-	Connector Type	RK02FGY	2 V	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B242</th> <th style="text-align: left;">Connector Name</th> <th style="text-align: left;">FUEL LID LOCK ACTUATOR</th> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Type</td> <td>MOFH4C</td> <td></td> <td></td> <td>1</td> <td>R</td> <td>-</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>2</td> <td>V</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B242	Connector Name	FUEL LID LOCK ACTUATOR	Terminal No.	Color Of Wire	Signal Name [Specification]	Connector Type	MOFH4C			1	R	-					2	V	-			
Connector No.	B16	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B228	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	1 B	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)	1 R	-																																										
Connector Type	A03FW	2 L	-	Connector Type	RK02FGY	2 V	-																																										
Connector No.	B242	Connector Name	FUEL LID LOCK ACTUATOR	Terminal No.	Color Of Wire	Signal Name [Specification]																																											
Connector Type	MOFH4C			1	R	-																																											
				2	V	-																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B216</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B229</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>FRONT DOOR SWITCH (PASSENGER SIDE)</td> <td>1 V</td> <td>-</td> <td>Connector Name</td> <td>INSIDE KEY ANTENNA (LUGGAGE SIDE)</td> <td>1 V</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>A03FW</td> <td>2 SB</td> <td>-</td> <td>Connector Type</td> <td>RK02FW</td> <td>2 SB</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B216	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B229	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	1 V	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE SIDE)	1 V	-	Connector Type	A03FW	2 SB	-	Connector Type	RK02FW	2 SB	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B216</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B229</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>FRONT DOOR SWITCH (PASSENGER SIDE)</td> <td>1 V</td> <td>-</td> <td>Connector Name</td> <td>INSIDE KEY ANTENNA (LUGGAGE SIDE)</td> <td>1 V</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>A03FW</td> <td>2 SB</td> <td>-</td> <td>Connector Type</td> <td>RK02FW</td> <td>2 SB</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B216	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B229	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	1 V	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE SIDE)	1 V	-	Connector Type	A03FW	2 SB	-	Connector Type	RK02FW	2 SB	-
Connector No.	B216	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B229	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	1 V	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE SIDE)	1 V	-																																										
Connector Type	A03FW	2 SB	-	Connector Type	RK02FW	2 SB	-																																										
Connector No.	B216	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B229	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	1 V	-	Connector Name	INSIDE KEY ANTENNA (LUGGAGE SIDE)	1 V	-																																										
Connector Type	A03FW	2 SB	-	Connector Type	RK02FW	2 SB	-																																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B23</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B223</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>REAR DOOR SWITCH LH</td> <td>1 L</td> <td>-</td> <td>Connector Name</td> <td>REAR DOOR SWITCH RH</td> <td>1 L</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>A03FW</td> <td>2 V</td> <td>-</td> <td>Connector Type</td> <td>A03FW</td> <td>2 V</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B23	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B223	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	REAR DOOR SWITCH LH	1 L	-	Connector Name	REAR DOOR SWITCH RH	1 L	-	Connector Type	A03FW	2 V	-	Connector Type	A03FW	2 V	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B23</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B223</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>REAR DOOR SWITCH LH</td> <td>1 L</td> <td>-</td> <td>Connector Name</td> <td>REAR DOOR SWITCH RH</td> <td>1 L</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>A03FW</td> <td>2 V</td> <td>-</td> <td>Connector Type</td> <td>A03FW</td> <td>2 V</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B23	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B223	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	REAR DOOR SWITCH LH	1 L	-	Connector Name	REAR DOOR SWITCH RH	1 L	-	Connector Type	A03FW	2 V	-	Connector Type	A03FW	2 V	-
Connector No.	B23	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B223	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	REAR DOOR SWITCH LH	1 L	-	Connector Name	REAR DOOR SWITCH RH	1 L	-																																										
Connector Type	A03FW	2 V	-	Connector Type	A03FW	2 V	-																																										
Connector No.	B23	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B223	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	REAR DOOR SWITCH LH	1 L	-	Connector Name	REAR DOOR SWITCH RH	1 L	-																																										
Connector Type	A03FW	2 V	-	Connector Type	A03FW	2 V	-																																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B47</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B47</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>DIODE</td> <td>1 LG</td> <td>-</td> <td>Connector Name</td> <td>DIODE</td> <td>1 GR</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>24335_C3900</td> <td>2 BR</td> <td>-</td> <td>Connector Type</td> <td>24335_C3900</td> <td>2 BR</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	DIODE	1 LG	-	Connector Name	DIODE	1 GR	-	Connector Type	24335_C3900	2 BR	-	Connector Type	24335_C3900	2 BR	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B47</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> <th style="text-align: left;">Connector No.</th> <th style="text-align: left;">B47</th> <th style="text-align: left;">Terminal Color Of Wire</th> <th style="text-align: left;">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>DIODE</td> <td>1 LG</td> <td>-</td> <td>Connector Name</td> <td>DIODE</td> <td>1 GR</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td>24335_C3900</td> <td>2 BR</td> <td>-</td> <td>Connector Type</td> <td>24335_C3900</td> <td>2 BR</td> <td>-</td> </tr> </tbody> </table>  <p>H.S.</p>	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector Name	DIODE	1 LG	-	Connector Name	DIODE	1 GR	-	Connector Type	24335_C3900	2 BR	-	Connector Type	24335_C3900	2 BR	-
Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	DIODE	1 LG	-	Connector Name	DIODE	1 GR	-																																										
Connector Type	24335_C3900	2 BR	-	Connector Type	24335_C3900	2 BR	-																																										
Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]	Connector No.	B47	Terminal Color Of Wire	Signal Name [Specification]																																										
Connector Name	DIODE	1 LG	-	Connector Name	DIODE	1 GR	-																																										
Connector Type	24335_C3900	2 BR	-	Connector Type	24335_C3900	2 BR	-																																										




JRMWE9716GB

A B C D E F G H I J K L M N O P Q R

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B414</td></tr> <tr><td>Connector Name</td><td>POWER SEAT SWITCH</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table> 	Connector No.	B414	Connector Name	POWER SEAT SWITCH	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B451</td></tr> <tr><td>Connector Name</td><td>DRIVER SEAT CONTROL UNIT</td></tr> <tr><td>Connector Type</td><td>TH20FW</td></tr> </table> 	Connector No.	B451	Connector Name	DRIVER SEAT CONTROL UNIT	Connector Type	TH20FW	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D3</td></tr> <tr><td>Connector Name</td><td>DOOR MIRROR (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>TH24NW-NH</td></tr> </table> 	Connector No.	D3	Connector Name	DOOR MIRROR (DRIVER SIDE)	Connector Type	TH24NW-NH																																																																										
Connector No.	B414																																																																																													
Connector Name	POWER SEAT SWITCH																																																																																													
Connector Type	NS10FW-CS																																																																																													
Connector No.	B451																																																																																													
Connector Name	DRIVER SEAT CONTROL UNIT																																																																																													
Connector Type	TH20FW																																																																																													
Connector No.	D3																																																																																													
Connector Name	DOOR MIRROR (DRIVER SIDE)																																																																																													
Connector Type	TH24NW-NH																																																																																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 G</td><td>R</td></tr> <tr><td>2 B</td><td>-</td></tr> <tr><td>3 GR</td><td>B</td></tr> <tr><td>4 P</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>6 V</td><td>-</td></tr> <tr><td>7 LY</td><td>-</td></tr> <tr><td>8 L</td><td>-</td></tr> <tr><td>9 U/R</td><td>-</td></tr> <tr><td>10 G/W</td><td>-</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1 G	R	2 B	-	3 GR	B	4 P	-	5 W	-	6 V	-	7 LY	-	8 L	-	9 U/R	-	10 G/W	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 L/W</td><td>RY</td></tr> <tr><td>2 RY</td><td>CANH</td></tr> <tr><td>3 W/G</td><td>PULSE (RECLINING)</td></tr> <tr><td>4 P/B</td><td>PULSE (FR LIFTING)</td></tr> <tr><td>5 BR</td><td>SLIDING SW (BACKWARD)</td></tr> <tr><td>6 SB</td><td>RECLINING SW (BACKWARD)</td></tr> <tr><td>7 LG/R</td><td>FRONT LIFTING SW (DOWNWARD)</td></tr> <tr><td>8 GR/B</td><td>REAR LIFTING SW (DOWNWARD)</td></tr> <tr><td>9 O</td><td>VCC</td></tr> <tr><td>10 Y/R</td><td>TX</td></tr> <tr><td>11 V</td><td>CANL</td></tr> <tr><td>12 LY</td><td>P RANGE SW</td></tr> <tr><td>13 Y</td><td>PULSE (SLIDING)</td></tr> <tr><td>14 GR</td><td>PULSE (FR LIFTING)</td></tr> <tr><td>15 Y</td><td>SLIDING SW (FORWARD)</td></tr> <tr><td>16 RG</td><td>RECLINING SW (UPWARD)</td></tr> <tr><td>17 W/B</td><td>FRONT LIFTING SW (UPWARD)</td></tr> <tr><td>18 G</td><td>REAR LIFTING SW (UPWARD)</td></tr> <tr><td>19 B</td><td>SENSOR GND</td></tr> <tr><td>20 Y</td><td>GND (SIGNAL)</td></tr> <tr><td>21 GR</td><td>POWER SW</td></tr> <tr><td>22 BR</td><td>-</td></tr> <tr><td>23 Y</td><td>-</td></tr> <tr><td>24 V</td><td>-</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1 L/W	RY	2 RY	CANH	3 W/G	PULSE (RECLINING)	4 P/B	PULSE (FR LIFTING)	5 BR	SLIDING SW (BACKWARD)	6 SB	RECLINING SW (BACKWARD)	7 LG/R	FRONT LIFTING SW (DOWNWARD)	8 GR/B	REAR LIFTING SW (DOWNWARD)	9 O	VCC	10 Y/R	TX	11 V	CANL	12 LY	P RANGE SW	13 Y	PULSE (SLIDING)	14 GR	PULSE (FR LIFTING)	15 Y	SLIDING SW (FORWARD)	16 RG	RECLINING SW (UPWARD)	17 W/B	FRONT LIFTING SW (UPWARD)	18 G	REAR LIFTING SW (UPWARD)	19 B	SENSOR GND	20 Y	GND (SIGNAL)	21 GR	POWER SW	22 BR	-	23 Y	-	24 V	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 R</td><td>-</td></tr> <tr><td>2 B</td><td>-</td></tr> <tr><td>3 GR</td><td>-</td></tr> <tr><td>4 P</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>6 V</td><td>-</td></tr> <tr><td>7 LY</td><td>-</td></tr> <tr><td>8 L</td><td>-</td></tr> <tr><td>9 G/W</td><td>-</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1 R	-	2 B	-	3 GR	-	4 P	-	5 W	-	6 V	-	7 LY	-	8 L	-	9 G/W	-
Terminal Color Of No.	Signal Name [Specification]																																																																																													
1 G	R																																																																																													
2 B	-																																																																																													
3 GR	B																																																																																													
4 P	-																																																																																													
5 W	-																																																																																													
6 V	-																																																																																													
7 LY	-																																																																																													
8 L	-																																																																																													
9 U/R	-																																																																																													
10 G/W	-																																																																																													
Terminal Color Of No.	Signal Name [Specification]																																																																																													
1 L/W	RY																																																																																													
2 RY	CANH																																																																																													
3 W/G	PULSE (RECLINING)																																																																																													
4 P/B	PULSE (FR LIFTING)																																																																																													
5 BR	SLIDING SW (BACKWARD)																																																																																													
6 SB	RECLINING SW (BACKWARD)																																																																																													
7 LG/R	FRONT LIFTING SW (DOWNWARD)																																																																																													
8 GR/B	REAR LIFTING SW (DOWNWARD)																																																																																													
9 O	VCC																																																																																													
10 Y/R	TX																																																																																													
11 V	CANL																																																																																													
12 LY	P RANGE SW																																																																																													
13 Y	PULSE (SLIDING)																																																																																													
14 GR	PULSE (FR LIFTING)																																																																																													
15 Y	SLIDING SW (FORWARD)																																																																																													
16 RG	RECLINING SW (UPWARD)																																																																																													
17 W/B	FRONT LIFTING SW (UPWARD)																																																																																													
18 G	REAR LIFTING SW (UPWARD)																																																																																													
19 B	SENSOR GND																																																																																													
20 Y	GND (SIGNAL)																																																																																													
21 GR	POWER SW																																																																																													
22 BR	-																																																																																													
23 Y	-																																																																																													
24 V	-																																																																																													
Terminal Color Of No.	Signal Name [Specification]																																																																																													
1 R	-																																																																																													
2 B	-																																																																																													
3 GR	-																																																																																													
4 P	-																																																																																													
5 W	-																																																																																													
6 V	-																																																																																													
7 LY	-																																																																																													
8 L	-																																																																																													
9 G/W	-																																																																																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B434</td></tr> <tr><td>Connector Name</td><td>POWER SEAT SWITCH</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table> 	Connector No.	B434	Connector Name	POWER SEAT SWITCH	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D6</td></tr> <tr><td>Connector Name</td><td>POWER WINDOW MAIN SWITCH</td></tr> <tr><td>Connector Type</td><td>NST16FW-CS</td></tr> </table> 	Connector No.	D6	Connector Name	POWER WINDOW MAIN SWITCH	Connector Type	NST16FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 R</td><td>-</td></tr> <tr><td>2 B</td><td>-</td></tr> <tr><td>3 GR</td><td>-</td></tr> <tr><td>4 P</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>6 V</td><td>-</td></tr> <tr><td>7 LY</td><td>-</td></tr> <tr><td>8 L</td><td>-</td></tr> <tr><td>9 G/W</td><td>-</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1 R	-	2 B	-	3 GR	-	4 P	-	5 W	-	6 V	-	7 LY	-	8 L	-	9 G/W	-																																																												
Connector No.	B434																																																																																													
Connector Name	POWER SEAT SWITCH																																																																																													
Connector Type	NS10FW-CS																																																																																													
Connector No.	D6																																																																																													
Connector Name	POWER WINDOW MAIN SWITCH																																																																																													
Connector Type	NST16FW-CS																																																																																													
Terminal Color Of No.	Signal Name [Specification]																																																																																													
1 R	-																																																																																													
2 B	-																																																																																													
3 GR	-																																																																																													
4 P	-																																																																																													
5 W	-																																																																																													
6 V	-																																																																																													
7 LY	-																																																																																													
8 L	-																																																																																													
9 G/W	-																																																																																													

JRMWE9717GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)	
5 O	-
6 Y	-
7 BR	-
8 L	-
9 O	-
10 Y	-
11 G	-
13 P	-
14 V	-
15 B	-


Connector No.	D13
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWCH)
Connector Type	RK02FL
Terminal Color Of Wire	Signal Name [Specification]
1 Y	-
2 B	-




Connector No.	D9
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS03FWCS
Terminal Color Of Wire	Signal Name [Specification]
1 Y	-
2 B	-



Connector No.	D14
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	RK02NGY
Terminal Color Of Wire	Signal Name [Specification]
1 Y	-
2 B	-



Connector No.	D12
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW
Terminal Color Of Wire	Signal Name [Specification]
1 O	-
2 SB	-



Terminal Color Of Wire	Signal Name [Specification]
1 R	-
2 SB	-

JRMWE9718GB

P

A

B

C

D

E

G

H

RF

L

M




N

O

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D44</td></tr> <tr><td>Connector Name</td><td>FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA</td></tr> <tr><td>Connector Type</td><td>RK02NGY</td></tr> </table>  <p>H.S.</p>	Connector No.	D44	Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA	Connector Type	RK02NGY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D54</td></tr> <tr><td>Connector Name</td><td>FRONT OUTSIDE HANDLE LH/OUTSIDE KEY ANTENNA</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>  <p>H.S.</p>	Connector No.	D54	Connector Name	FRONT OUTSIDE HANDLE LH/OUTSIDE KEY ANTENNA	Connector Type	E06FCY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	P	Y	-	2	V	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	P	Y	-	2	V	-	-																								
Connector No.	D44																																																														
Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA																																																														
Connector Type	RK02NGY																																																														
Connector No.	D54																																																														
Connector Name	FRONT OUTSIDE HANDLE LH/OUTSIDE KEY ANTENNA																																																														
Connector Type	E06FCY-RS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	P	Y	-																																																												
2	V	-	-																																																												
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	P	Y	-																																																												
2	V	-	-																																																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D74</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS09FW-CS</td></tr> </table>  <p>H.S.</p>	Connector No.	D74	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS09FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D75</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>  <p>H.S.</p>	Connector No.	D75	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	E06FCY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td><td>-</td></tr> <tr><td>3</td><td>G</td><td>-</td><td>-</td></tr> <tr><td>4</td><td>L</td><td>-</td><td>-</td></tr> <tr><td>5</td><td>W</td><td>-</td><td>-</td></tr> <tr><td>6</td><td>B</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	W	Y	-	2	V	-	-	3	G	-	-	4	L	-	-	5	W	-	-	6	B	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td><td>-</td></tr> <tr><td>3</td><td>V</td><td>-</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	Y	Y	-	2	B	-	-	3	V	-	-	4	G	-	-
Connector No.	D74																																																														
Connector Name	REAR POWER WINDOW SWITCH RH																																																														
Connector Type	NS09FW-CS																																																														
Connector No.	D75																																																														
Connector Name	REAR DOOR LOCK ASSEMBLY RH																																																														
Connector Type	E06FCY-RS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	W	Y	-																																																												
2	V	-	-																																																												
3	G	-	-																																																												
4	L	-	-																																																												
5	W	-	-																																																												
6	B	-	-																																																												
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	Y	Y	-																																																												
2	B	-	-																																																												
3	V	-	-																																																												
4	G	-	-																																																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D110</td></tr> <tr><td>Connector Name</td><td>USAGE ROOM LAMP (BACK DOOR SIDE)</td></tr> <tr><td>Connector Type</td><td>TK03FW</td></tr> </table>  <p>H.S.</p>	Connector No.	D110	Connector Name	USAGE ROOM LAMP (BACK DOOR SIDE)	Connector Type	TK03FW	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D113</td></tr> <tr><td>Connector Name</td><td>BACK DOOR LOCK ASSEMBLY</td></tr> <tr><td>Connector Type</td><td>NS09FW-CS</td></tr> </table>  <p>H.S.</p>	Connector No.	D113	Connector Name	BACK DOOR LOCK ASSEMBLY	Connector Type	NS09FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td><td>-</td></tr> <tr><td>3</td><td>G</td><td>-</td><td>-</td></tr> <tr><td>4</td><td>P</td><td>-</td><td>-</td></tr> <tr><td>5</td><td>O</td><td>-</td><td>-</td></tr> <tr><td>6</td><td>B</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	W	Y	-	2	V	-	-	3	G	-	-	4	P	-	-	5	O	-	-	6	B	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td><td>-</td></tr> <tr><td>3</td><td>V</td><td>-</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	Y	Y	-	2	B	-	-	3	V	-	-	4	G	-	-
Connector No.	D110																																																														
Connector Name	USAGE ROOM LAMP (BACK DOOR SIDE)																																																														
Connector Type	TK03FW																																																														
Connector No.	D113																																																														
Connector Name	BACK DOOR LOCK ASSEMBLY																																																														
Connector Type	NS09FW-CS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	W	Y	-																																																												
2	V	-	-																																																												
3	G	-	-																																																												
4	P	-	-																																																												
5	O	-	-																																																												
6	B	-	-																																																												
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	Y	Y	-																																																												
2	B	-	-																																																												
3	V	-	-																																																												
4	G	-	-																																																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D55</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY LH</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>  <p>H.S.</p>	Connector No.	D55	Connector Name	REAR DOOR LOCK ASSEMBLY LH	Connector Type	E06FCY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D76</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>  <p>H.S.</p>	Connector No.	D76	Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE	Connector Type	E06FCY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>LG</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	P	Y	-	2	LG	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>G</td><td>-</td><td>-</td></tr> <tr><td>5</td><td>V</td><td>-</td><td>-</td></tr> <tr><td>6</td><td>G</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]	1	V	Y	-	2	G	-	-	5	V	-	-	6	G	-	-																
Connector No.	D55																																																														
Connector Name	REAR DOOR LOCK ASSEMBLY LH																																																														
Connector Type	E06FCY-RS																																																														
Connector No.	D76																																																														
Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE																																																														
Connector Type	E06FCY-RS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	P	Y	-																																																												
2	LG	-	-																																																												
Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]																																																												
1	V	Y	-																																																												
2	G	-	-																																																												
5	V	-	-																																																												
6	G	-	-																																																												

JRMWE9719GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>D114</td></tr> <tr><td>Connector Name</td><td>BACK DOOR OPENER SWITCH</td></tr> <tr><td>Connector Type</td><td>TKOZM1ER-P</td></tr> </table>  	Connector No.	D114	Connector Name	BACK DOOR OPENER SWITCH	Connector Type	TKOZM1ER-P	<table border="1"> <tr><td>Connector No.</td><td>D116</td></tr> <tr><td>Connector Name</td><td>BACK DOOR OPENER REQUEST-SWITCH</td></tr> <tr><td>Connector Type</td><td>TKOZM1ER-P</td></tr> </table>  	Connector No.	D116	Connector Name	BACK DOOR OPENER REQUEST-SWITCH	Connector Type	TKOZM1ER-P	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td></tr> <tr><td>2</td><td>B</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td></tr> <tr><td>2</td><td>B</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	GR	2	B	Terminal Color Of No.	Signal Name [Specification]	1	Y	2	B	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td></tr> <tr><td>2</td><td>B</td></tr> <tr><td>3</td><td>R</td></tr> <tr><td>4</td><td>B/W</td></tr> <tr><td>5</td><td>L</td></tr> <tr><td>7</td><td>-</td></tr> <tr><td>12</td><td>B/W</td></tr> <tr><td>13</td><td>Y</td></tr> <tr><td>16</td><td>LG</td></tr> <tr><td>19</td><td>W</td></tr> <tr><td>25</td><td>G</td></tr> <tr><td>26</td><td>R</td></tr> <tr><td>27</td><td>BG</td></tr> <tr><td>28</td><td>L</td></tr> <tr><td>30</td><td>CR</td></tr> <tr><td>36</td><td>G</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td></tr> <tr><td>2</td><td>R</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	Y	2	B	3	R	4	B/W	5	L	7	-	12	B/W	13	Y	16	LG	19	W	25	G	26	R	27	BG	28	L	30	CR	36	G	Terminal Color Of No.	Signal Name [Specification]	1	BR	2	R	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td></tr> <tr><td>3</td><td>O</td></tr> <tr><td>4</td><td>B</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td></tr> <tr><td>2</td><td>BR</td></tr> <tr><td>3</td><td>SB</td></tr> <tr><td>4</td><td>BR</td></tr> <tr><td>5</td><td>G</td></tr> <tr><td>46</td><td>R</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	G	3	O	4	B	Terminal Color Of No.	Signal Name [Specification]	1	GR	2	BR	3	SB	4	BR	5	G	46	R																																														
Connector No.	D114																																																																																																																																							
Connector Name	BACK DOOR OPENER SWITCH																																																																																																																																							
Connector Type	TKOZM1ER-P																																																																																																																																							
Connector No.	D116																																																																																																																																							
Connector Name	BACK DOOR OPENER REQUEST-SWITCH																																																																																																																																							
Connector Type	TKOZM1ER-P																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	GR																																																																																																																																							
2	B																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	Y																																																																																																																																							
2	B																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	Y																																																																																																																																							
2	B																																																																																																																																							
3	R																																																																																																																																							
4	B/W																																																																																																																																							
5	L																																																																																																																																							
7	-																																																																																																																																							
12	B/W																																																																																																																																							
13	Y																																																																																																																																							
16	LG																																																																																																																																							
19	W																																																																																																																																							
25	G																																																																																																																																							
26	R																																																																																																																																							
27	BG																																																																																																																																							
28	L																																																																																																																																							
30	CR																																																																																																																																							
36	G																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	BR																																																																																																																																							
2	R																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	G																																																																																																																																							
3	O																																																																																																																																							
4	B																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	GR																																																																																																																																							
2	BR																																																																																																																																							
3	SB																																																																																																																																							
4	BR																																																																																																																																							
5	G																																																																																																																																							
46	R																																																																																																																																							
<table border="1"> <tr><td>Connector No.</td><td>E5</td></tr> <tr><td>Connector Name</td><td>FRONT INTERMITTENT POWER DISTRIBUTION N/CODULE ENGINE ROOM</td></tr> <tr><td>Connector Type</td><td>TH20FW-CS12-M4-IV</td></tr> </table>  	Connector No.	E5	Connector Name	FRONT INTERMITTENT POWER DISTRIBUTION N/CODULE ENGINE ROOM	Connector Type	TH20FW-CS12-M4-IV	<table border="1"> <tr><td>Connector No.</td><td>E28</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP RH</td></tr> <tr><td>Connector Type</td><td>TSQ8FB-FR</td></tr> </table>  	Connector No.	E28	Connector Name	FRONT COMBINATION LAMP RH	Connector Type	TSQ8FB-FR	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>B</td></tr> <tr><td>3</td><td>BY</td></tr> <tr><td>4</td><td>B/W</td></tr> <tr><td>5</td><td>BG</td></tr> <tr><td>6</td><td>V</td></tr> <tr><td>7</td><td>BR</td></tr> <tr><td>8</td><td>P</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td></tr> <tr><td>2</td><td>BR</td></tr> <tr><td>3</td><td>SB</td></tr> <tr><td>4</td><td>BR</td></tr> <tr><td>5</td><td>CANL</td></tr> <tr><td>6</td><td>GROUND</td></tr> <tr><td>7</td><td>DS FL</td></tr> <tr><td>8</td><td>DS RL</td></tr> <tr><td>9</td><td>DS RR</td></tr> <tr><td>10</td><td>DS FR</td></tr> <tr><td>11</td><td>VAC</td></tr> <tr><td>12</td><td>P</td></tr> <tr><td>13</td><td>SHIELD</td></tr> <tr><td>14</td><td>GROUND</td></tr> <tr><td>15</td><td>UST</td></tr> <tr><td>16</td><td>P</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	2	B	3	BY	4	B/W	5	BG	6	V	7	BR	8	P	Terminal Color Of No.	Signal Name [Specification]	1	GR	2	BR	3	SB	4	BR	5	CANL	6	GROUND	7	DS FL	8	DS RL	9	DS RR	10	DS FR	11	VAC	12	P	13	SHIELD	14	GROUND	15	UST	16	P	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td></tr> <tr><td>2</td><td>G</td></tr> <tr><td>3</td><td>R</td></tr> <tr><td>4</td><td>B</td></tr> <tr><td>5</td><td>Y</td></tr> <tr><td>6</td><td>BG</td></tr> <tr><td>7</td><td>BR</td></tr> <tr><td>9</td><td>B</td></tr> <tr><td>10</td><td>W</td></tr> <tr><td>12</td><td>L</td></tr> <tr><td>14</td><td>P</td></tr> <tr><td>15</td><td>CANL</td></tr> <tr><td>16</td><td>GROUND</td></tr> <tr><td>17</td><td>UST</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	BR	2	G	3	R	4	B	5	Y	6	BG	7	BR	9	B	10	W	12	L	14	P	15	CANL	16	GROUND	17	UST	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td></tr> <tr><td>2</td><td>SB</td></tr> <tr><td>3</td><td>BR</td></tr> <tr><td>4</td><td>G</td></tr> <tr><td>5</td><td>BR</td></tr> <tr><td>6</td><td>SB</td></tr> <tr><td>7</td><td>BR</td></tr> <tr><td>8</td><td>SB</td></tr> <tr><td>9</td><td>BR</td></tr> <tr><td>10</td><td>SB</td></tr> <tr><td>11</td><td>BR</td></tr> <tr><td>12</td><td>SB</td></tr> <tr><td>13</td><td>BR</td></tr> <tr><td>14</td><td>SB</td></tr> <tr><td>15</td><td>BR</td></tr> <tr><td>16</td><td>SB</td></tr> <tr><td>17</td><td>BR</td></tr> <tr><td>18</td><td>SB</td></tr> <tr><td>19</td><td>BR</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	BR	2	SB	3	BR	4	G	5	BR	6	SB	7	BR	8	SB	9	BR	10	SB	11	BR	12	SB	13	BR	14	SB	15	BR	16	SB	17	BR	18	SB	19	BR
Connector No.	E5																																																																																																																																							
Connector Name	FRONT INTERMITTENT POWER DISTRIBUTION N/CODULE ENGINE ROOM																																																																																																																																							
Connector Type	TH20FW-CS12-M4-IV																																																																																																																																							
Connector No.	E28																																																																																																																																							
Connector Name	FRONT COMBINATION LAMP RH																																																																																																																																							
Connector Type	TSQ8FB-FR																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
2	B																																																																																																																																							
3	BY																																																																																																																																							
4	B/W																																																																																																																																							
5	BG																																																																																																																																							
6	V																																																																																																																																							
7	BR																																																																																																																																							
8	P																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	GR																																																																																																																																							
2	BR																																																																																																																																							
3	SB																																																																																																																																							
4	BR																																																																																																																																							
5	CANL																																																																																																																																							
6	GROUND																																																																																																																																							
7	DS FL																																																																																																																																							
8	DS RL																																																																																																																																							
9	DS RR																																																																																																																																							
10	DS FR																																																																																																																																							
11	VAC																																																																																																																																							
12	P																																																																																																																																							
13	SHIELD																																																																																																																																							
14	GROUND																																																																																																																																							
15	UST																																																																																																																																							
16	P																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	BR																																																																																																																																							
2	G																																																																																																																																							
3	R																																																																																																																																							
4	B																																																																																																																																							
5	Y																																																																																																																																							
6	BG																																																																																																																																							
7	BR																																																																																																																																							
9	B																																																																																																																																							
10	W																																																																																																																																							
12	L																																																																																																																																							
14	P																																																																																																																																							
15	CANL																																																																																																																																							
16	GROUND																																																																																																																																							
17	UST																																																																																																																																							
Terminal Color Of No.	Signal Name [Specification]																																																																																																																																							
1	BR																																																																																																																																							
2	SB																																																																																																																																							
3	BR																																																																																																																																							
4	G																																																																																																																																							
5	BR																																																																																																																																							
6	SB																																																																																																																																							
7	BR																																																																																																																																							
8	SB																																																																																																																																							
9	BR																																																																																																																																							
10	SB																																																																																																																																							
11	BR																																																																																																																																							
12	SB																																																																																																																																							
13	BR																																																																																																																																							
14	SB																																																																																																																																							
15	BR																																																																																																																																							
16	SB																																																																																																																																							
17	BR																																																																																																																																							
18	SB																																																																																																																																							
19	BR																																																																																																																																							

JRMWE9720GB

A B C D E F G H I J K L M N O P Q R

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
25 Y	BUS-L	1	L	1	POWER SUPPLY
26 LG	DP FL	2	W	2	POWER SUPPLY/MEMORY BACK-UP
27 GR	DS RL	3	Y	3	CANH
28 G	UZ	4	SB	4	K LINE
29 LG	DS RR			5	GROUND
30 SB	BLS			6	POWER SUPPLY
31 R	VDC OFF SW			7	BACK-UP LAMP RELAY
35 L	CANH			8	CANL
45 B	BLSH			9	STARTER RELAY
				10	GROUND

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
2 B	-	1	L	1	POWER SUPPLY
3 BY	-	2	W	2	-
4 BW	-	3	Y	3	-
5 V	-	4	SB	4	-
6 G	-			5	-
7 P	-			6	-
8 BG	-			7	-

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 V	-	1	L	1	M1
2 B	-	2	W	2	POWER BLOCK (J/B)
3 P	-	3	Y	3	-
4 SB	-	4	SB	4	-
6 P	-	5	9	5	-
7 R	-	6	8	6	-
		7	7	7	-
		8	6	8	-
		9	5	9	-
		10	4	10	-

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1F SB	-	2	BR	2	POWER SUPPLY/MEMORY BACK-UP
2F W	-	3	O	3	CANH
4F G	-	4	V	4	K LINE
5F B	-	5	B	5	GROUND
6F Y	-	6	Y	6	POWER SUPPLY
7F R	-	7	R	7	BACK-UP LAMP RELAY
8F L	-	8	LG	8	CANL
9F R	-	9	GR	9	STARTER RELAY
		10	B	10	GROUND

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 Y	-	1A	GR	-	-
3 V	-	2A	G	-	-
		3A	L	-	-
		4A	P	4	[For push button]
		5A	V	5	-
		6A	Y	6	-
		7A	R	7	-
		8A	L	8	-

JRMWE9721GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M2	Connector No.	M9	Connector No.	M24	Connector No.	M33
Connector Name	FUSE BLOCK (JB)	Connector Name	DIODE	Connector Name	DATA LINK CONNECTOR	Connector Name	COMBINATION SWITCH
Connector Type	NS10FW-CS	Connector Type	24355.C9900	Connector Type	BD16FW	Connector Type	TH16FW-NH
Terminal Color Of No. Wire	Signal Name [Specification]						
3B P	-	1 R	-	3 LG	-	1 P	-
4B G	-	2 W	-	4 B	-	2 SB	FR WASHER
5B BG	-	5 BG	-	5 B	-	3 GR	FR WASHER
6B Y	-	6 L	-	6 L	-	4 G	IGN
7B P	-	7 V	-	7 V	-	5 L	OUTPUT 3
8B R	-	8 G	-	8 G	-	6 B	GROUND
9B SB	-	11 SB	-	11 SB	-	7 V	INPUT 3
10B	-	14 P	-	14 P	-	8 BG	INPUT 5
11B	-	16 Y	-	16 Y	-	9 Y	INPUT 2
Connector No.	M3	Connector No.	M27	Connector No.	M50	Connector No.	M50
Connector Name	FUSE BLOCK (JB)	Connector Name	FOOT LAMP (DRIVER SIDE)	Connector Name	PUSH-BUTTON IGNITION SWITCH	Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	NS12FW-CS	Connector Type	A02FW	Connector Type	TRKFBR	Connector Type	TRKFBR
Terminal Color Of No. Wire	Signal Name [Specification]						
12 BAT	BAT	1 R	BAT	2 GR	CLOCK	1 B	-
13 BAT	-	3 W	DATA	3 W	DATA	2 W	-
14 BAT	-	5 Y	ILL BAT	5 Y	ILL BAT	3 W	-
15 BAT	-	6 LG	GROUND	6 LG	GROUND	4 BR	-
16 BAT	-	7 B	KEY SWITCH SIGNAL	7 B	KEY SWITCH SIGNAL	5 GR	-
17 BAT	-	11 BR	-	11 BR	-	6 Y	-

JRMWE9722GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M67	Connector No.	M72
Connector Name	UNIFIED METER AND A/C AMP.	Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH32FW-NH	Connector Type	TH16FW-NH
Connector No.	M53	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	COMBINATION METER	No.	No.
Connector Type	TH40FW-NH	Wire	Signal Name [Specification]
1	GR	1	V
2	LG	2	Y
3	GR	3	R
5	B	4	G
6	P	5	Y
7	BR	6	SB
10	G	8	LG
15	B	9	B
16	B	14	Y
19	B	16	G
20	R	17	-
21	BG	21	ECV SIGNAL
22	B	61	A/C LAN SIGNAL
24	BR	63	-
25	Y	65	BG
26	R	69	L
27	V	70	R
28	W	71	B
29	SB	72	P
30	G		CANL
31	L		
33	B		
36	LG		
37	SB		
38	L		
39	P		
40	BG		

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.	Signal Name [Specification]	No.	Signal Name [Specification]
41	ACC POWER SUPPLY	1	GROUND
42	FUEL LEVEL SENSOR SIGNAL	3	ACC
43	IN-VEHICLE SENSOR SIGNAL	4	ILL. CONT.
44	AMBIENT SENSOR SIGNAL	5	Y
45	SUN LOAD SENSOR SIGNAL	6	SB
46	BG	8	LG
47	DISK ELECT SIGNAL	9	SM GND
53	IGNITION POWER SUPPLY	14	DISK ELECT SIGNAL
54	BATTERY POWER SUPPLY	16	HAZARD ON
55	B		
56	L		
57	W		
58	BR		
59	GR		
60	L		
61	BR		
62	SB		
63	R		
65	BG		
69	L		
70	R		
71	B		
72	P		

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.	Signal Name [Specification]	No.	Signal Name [Specification]
1	GROUND	1	GROUND
2	Y	2	SIGNAL OUTPUT
4	LG	4	BATTERY

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.	Signal Name [Specification]	No.	Signal Name [Specification]
1	POWER	1	Y
2	OUTPUT	2	P
3	GROUND	3	B

JRMWE9723GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS

Connector No.	M113
Connector Name	FOOT LAMP (PASSENGER SIDE)
Connector Type	A02FW



Terminal Color Of Wire	Signal Name [Specification]
1 R	INTERIOR ROOM LAMP POWER SUPPLY
2 BR	PASSENGER DOOR UNLOCK OUTPUT
4 G	STEP LAMP CONN
5 L	ALL DOOR FUEL LID LOCK OUTPUT
7 Y	BACK DOOR ANT-1
8 V	DRIVER DOOR FUEL LID UNLOCK OUTPUT
9 G	IGNRELAY (IPDM ECR) CONN
10 BR	STARTER RELAY CONN
11 R	REAR DOOR UNLOCK OUTPUT
13 B	BAT (FUSE)
14 W	GROUND
15 Y	PUSH+BUTTON IGNITION SW LL GND
17 W	ACC IND
18 BG	TURN SIGNAL RH (FRONT)
19 V	TURN SIGNAL LH (FRONT)
21	INT ROOM LAMP CONN
23	REAR LH DOOR SW
25	REAR RH DOOR SW
26	R
3	R




Terminal Color Of Wire	Signal Name [Specification]
1 W	BAT (FIL)
2 W	POWER WINDOW POWER SUPPLY(BAT)
3 Y	POWER WINDOW POWER SUPPLY(RAP)



BCM (BODY CONTROL MODULE)


Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal Color Of Wire	Signal Name [Specification]
34 SB	LUGGAGE ROOM ANT-
35 V	LUGGAGE ROOM ANT+
38 B	BACK DOOR ANT-
39 W	BACK DOOR ANT+
47 Y	IGNRELAY (IPDM ECR) CONN
52 SB	STARTER RELAY CONN
60 BR	REAR DOOR UNLOCK OUTPUT
61 W	BACK DOOR OPENER REQUEST SW
64 V	I-KEY WARM BUZZER (ENG ROOM)
65 BG	REAR WIPER STOP POSITION
66 R	BACK DOOR SW
67 CR	BACK DOOR OPENER SW
68 BR	REAR RH DOOR SW
69 R	REAR LH DOOR SW

BCM (BODY CONTROL MODULE)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-VH



Terminal Color Of Wire	Signal Name [Specification]
1 P	STOP LAMP SW 1
16 SB	STOP LAMP SW 2
18 P	STOP LAMP SW 3



Terminal Color Of Wire	Signal Name [Specification]
74 SB	PASSENGER DOOR ANT-
75 GR	PASSENGER DOOR ANT+
76 V	DRIVER DOOR ANT-
77 LG	DRIVER DOOR ANT+
78 Y	ROOM ANT-
79 BR	ROOM ANT+

Terminal Color Of Wire	Signal Name [Specification]
80 GR	NATS ANT AMP
81 W	NATS ANT AMP
82 R	IGNRELAY (EBI) CONN
83 Y	KEYLESS ENTRY RECEIVER COMM
87 BR	COMBI SW INPUT 5
88 V	COMBI SW INPUT 3
89 CANL	PUDLE LAMP CONN
90 L	KEY SLOT LLL CONN
91 CANH	ON/IND
93 V	ACC RELAY CONN
94 Y	ACC RELAY CONN
95 BG	A/T SHIFT SELECTOR POWER SUPPLY
96 GR	A/T SHIFT SELECTOR POWER SUPPLY
99 R	SHIFT P
100 G	PASSENGER DOOR REQUEST SW
101 SB	DRIVER DOOR REQUEST SW
102 BG	BLOWER FAN MOTOR RELAY CONN
103 LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
107 LG	COMBI SW INPUT 1
108 R	COMBI SW INPUT 4
109 Y	COMBI SW INPUT 2
110 G	HAZARD SW




Terminal Color Of Wire	Signal Name [Specification]
131 P	OFFICIAL SENSOR
132 SB	STOP LAMP SW 1
133 W	STOP LAMP SW 2
134 BR	STOP LAMP SW 3
135 V	DR DOOR UNLOCK SENSOR
136 W	KEY SLOT SW
137 LG	IGN/IB
138 BR	PASSENGER DOOR SW
139 SB	POWER WINDOW SW COMM
140 BR	PUSH+BUTTON IGNITION SW LL POWER
141 BR	LOCK IND
142 BG	REVERSE SENSOR SW CONN
143 Y	REVERSE SENSOR POWER SUPPLY

JRMWE9724GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>M129</td><td>Connector No.</td><td>R4</td></tr> <tr><td>Connector Name</td><td>OPTION CONNECTOR (1)</td><td>Connector Name</td><td>SUNROOF MOTOR ASSEMBLY</td></tr> <tr><td>Connector Type</td><td>TH08MW-NH</td><td>Connector Type</td><td>YEAT10F/Y</td></tr> </table>  <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>3 O</td><td>ROOM LAMP BAT SAVING(POWER)</td></tr> <tr><td>6 R</td><td>ROOM LAMP OUT-ON</td></tr> </table> <table border="1"> <tr><td>Connector No.</td><td>M131</td><td>Connector No.</td><td>R42FGY</td></tr> <tr><td>Connector Name</td><td>INSIDE KEY/ANTENNA(INSTRUMENT CENTER)</td><td>Connector Name</td><td>FRONT FOG LAMP</td></tr> <tr><td>Connector Type</td><td>FR20FGY</td><td>Connector Type</td><td>FR20FGY</td></tr> </table> 	Connector No.	M129	Connector No.	R4	Connector Name	OPTION CONNECTOR (1)	Connector Name	SUNROOF MOTOR ASSEMBLY	Connector Type	TH08MW-NH	Connector Type	YEAT10F/Y	Terminal Color Of Wire	Signal Name [Specification]	3 O	ROOM LAMP BAT SAVING(POWER)	6 R	ROOM LAMP OUT-ON	Connector No.	M131	Connector No.	R42FGY	Connector Name	INSIDE KEY/ANTENNA(INSTRUMENT CENTER)	Connector Name	FRONT FOG LAMP	Connector Type	FR20FGY	Connector Type	FR20FGY	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 GR</td><td>SW-BIT1</td></tr> <tr><td>5 P</td><td>SW-BIT-</td></tr> <tr><td>7 BR</td><td>SB</td></tr> <tr><td>8 L</td><td>SPEED SENSOR(2P)</td></tr> <tr><td>9 Y</td><td>IMERITION</td></tr> <tr><td>10 G</td><td>GROUND</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 BR</td><td>-</td></tr> <tr><td>2 Y</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 GR	SW-BIT1	5 P	SW-BIT-	7 BR	SB	8 L	SPEED SENSOR(2P)	9 Y	IMERITION	10 G	GROUND	Terminal Color Of Wire	Signal Name [Specification]	1 BR	-	2 Y	-
Connector No.	M129	Connector No.	R4																																																
Connector Name	OPTION CONNECTOR (1)	Connector Name	SUNROOF MOTOR ASSEMBLY																																																
Connector Type	TH08MW-NH	Connector Type	YEAT10F/Y																																																
Terminal Color Of Wire	Signal Name [Specification]																																																		
3 O	ROOM LAMP BAT SAVING(POWER)																																																		
6 R	ROOM LAMP OUT-ON																																																		
Connector No.	M131	Connector No.	R42FGY																																																
Connector Name	INSIDE KEY/ANTENNA(INSTRUMENT CENTER)	Connector Name	FRONT FOG LAMP																																																
Connector Type	FR20FGY	Connector Type	FR20FGY																																																
Terminal Color Of Wire	Signal Name [Specification]																																																		
1 GR	SW-BIT1																																																		
5 P	SW-BIT-																																																		
7 BR	SB																																																		
8 L	SPEED SENSOR(2P)																																																		
9 Y	IMERITION																																																		
10 G	GROUND																																																		
Terminal Color Of Wire	Signal Name [Specification]																																																		
1 BR	-																																																		
2 Y	-																																																		

JRMWE9725GB

INFOID:0000000008788497

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000008788498

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
4	<ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2623: INSIDE ANTENNA

DTC Index

INFOID:0000000008788499

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	BCS-41
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-42
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-43
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-40

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-43
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-44
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-45
B2195: ANTI SCANNING	×	—	—	—	SEC-46
B2553: IGNITION RELAY	—	×	—	—	PCS-50
B2555: STOP LAMP	—	×	—	—	SEC-47
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-49
B2557: VEHICLE SPEED	×	×	×	—	SEC-51
B2560: STARTER CONT RELAY	×	×	×	—	SEC-52
B2562: LOW VOLTAGE	—	×	—	—	BCS-44
B2601: SHIFT POSITION	×	×	×	—	SEC-53
B2602: SHIFT POSITION	×	×	×	—	SEC-56
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-59
B2604: PNP SW	×	×	×	—	SEC-62
B2605: PNP SW	×	×	×	—	SEC-64
B2608: STARTER RELAY	×	×	×	—	SEC-66
B260A: IGNITION RELAY	×	×	×	—	PCS-52
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-68
B2614: ACC RELAY CIRC	—	×	×	—	PCS-54
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-57
B2616: IGN RELAY CIRC	—	×	×	—	PCS-60
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-71
B2618: BCM	×	×	×	—	PCS-63
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-73
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	SEC-76
B2621: INSIDE ANTENNA	—	×	—	—	DLK-58
B2623: INSIDE ANTENNA	—	×	—	—	DLK-60
B26E1: ENG STATE NO RES	×	×	×	—	SEC-69
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-70
C1704: LOW PRESSURE FL	—	—	—	×	WT-23
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	WT-25
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	

A
B
C
D
E
F
G
H
I
J

RF
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-28
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-30
C1734: CONTROL UNIT	—	—	—	×	WT-32

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >


SUNROOF SYSTEM

SUNROOF MOTOR ASSEMBLY

SUNROOF MOTOR ASSEMBLY : Reference Value

INFOID:00000000828853

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description	Condition	Voltage (V) (Approx.)
+	-	Signal name		
1 (GR)	Ground	Sunroof close switch (BIT 1) signal	Input	Sunroof switch in following position • TILT UP • SLIDE CLOSE
				Other than above
5 (P)	Ground	Sunroof open switch (BIT 0) signal	Input	Sunroof switch in following position • TILT DOWN • SLIDE OPEN
				Other than above
7 (BR)	Ground	Sunroof power supply	Input	—
8 (L)	Ground	Vehicle speed signal (2-pulse)	Input	Speedometer operated [When vehicle speed is approx.40km/h (25MPH)]
				 ELF1080D
9 (Y)	Ground	RAP signal	Input	Ignition switch ON
				Within 45 second after ignition switch is turned to OFF.
				When driver side or passenger side door is opened during retained power operation.
10 (G)	Ground	Ground	—	—

SUNROOF SYSTEM


< ECU DIAGNOSIS INFORMATION >

SUNROOF MOTOR ASSEMBLY : Wiring Diagram - SUNROOF -

INFOID:0000000008288854

SUNROOF

Refer to "Connector Information" in "HOW TO READ WIRING DIAGRAMS" in "CENTRAL INFORMATION"



2013/11/22

JRKWD1068GB

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >

SUNROOF

Connector No.	B1	Signal Name [Specification]	Terminal Color Of Wire No.	Color Name [Specification]
Connector Name	WIRE TO WIRE		75	W
Connector Type	TH90FW-CS16-TM4		76	BR
Connector No.	B16	Signal Name [Specification]	77	R
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)		78	P
Connector Type	A03FW		79	GR
Connector No.	B201	Signal Name [Specification]	80	V
Connector Name	WIRE TO WIRE		81	Y
Connector Type	TH90FW-CS16-TM4		82	SB
Terminal Color Of Wire No.	2	Signal Name [Specification]	83	BR
Signal Name [Specification]			84	BR
Terminal Color Of Wire No.	3	Signal Name [Specification]	85	Y
Signal Name [Specification]			86	SB
Terminal Color Of Wire No.	5	Signal Name [Specification]	87	P
Signal Name [Specification]			88	LG
Terminal Color Of Wire No.	6	Signal Name [Specification]	89	GR
Signal Name [Specification]			90	BR
Terminal Color Of Wire No.	7	Signal Name [Specification]	91	LG
Signal Name [Specification]			92	BR
Terminal Color Of Wire No.	8	Signal Name [Specification]	93	BR
Signal Name [Specification]			94	SB
Terminal Color Of Wire No.	12	Signal Name [Specification]	95	GR
Signal Name [Specification]			96	Y
Terminal Color Of Wire No.	13	Signal Name [Specification]	97	W
Signal Name [Specification]			98	GR
Terminal Color Of Wire No.	14	Signal Name [Specification]	99	GR
Signal Name [Specification]			100	L
Terminal Color Of Wire No.	15	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	17	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	18	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	19	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	20	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	21	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	22	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	24	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	27	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	28	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	29	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	30	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	31	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	32	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	33	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	34	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	35	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	36	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	37	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	38	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	39	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	44	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	45	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	46	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	47	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	49	Signal Name [Specification]		
Signal Name [Specification]				
Terminal Color Of Wire No.	50	Signal Name [Specification]		
Signal Name [Specification]				

JRKWD1315GB

P

O

M

L

RF

—

T

M

C

D

N

T

G

A

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >

SUNROOF

Connector No.	B216	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	23	G	-	-
Connector Type	A03FW	24	P	-	-
		25	Y	-	-
		26	V	-	-
		27	W	-	-
		28	G	-	-
		31	BG	-	-
		32	W	-	-
		33	B	-	-
		34	R	-	-
		35	G	-	-
		36	SHIELD	-	-
		37	V	-	-
		38	BR	-	-
		39	BG	-	-
		41	W	-	-
		42	G	-	-
		43	BR	-	-
		45	W	-	-
		49	L	-	-
		50	P	-	-
		51	L	-	-
		54	BG	-	-
		57	BR	-	-
		59	W	-	-
		60	LG	-	-
		61	C	-	-
		62	SB	-	-
		63	W	-	-
		64	B	-	-
		65	G	-	-
		66	R	-	-
		67	SHIELD	-	-
		68	Y	-	-
		69	LG	-	-
		70	W	-	-
		71	R	-	-
		72	Y	-	-
		73	B	-	-
		74	BR	-	-
		74	L	-	-
		75	G	-	-
		75	W	-	-
		76	W	-	-
		76	Y	-	-
		77	P	-	-
		77	R	-	-
		78	BR	-	-
		78	L	-	-
		79	V	-	-
		79	L	-	-
		80	SB	-	-
		81	R	-	-
		82	SB	-	-
		83	BG	-	-
		84	G	-	-
		85	L	-	-
		86	P	-	-
		87	V	-	-
		89	GR	-	-
		90	SHIELD	-	-
		91	W	-	-
		92	Y	-	-
		93	V	-	-
		94	LG	-	-
		95	BG	-	-
		96	P	-	-
		97	R	-	-
		98	SHIELD	-	-
		99	L	-	-
		100	P	-	-

JRKWD1316GB

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >

SUNROOF

Terminal No.	Color Of Wire	Signal Name [Specification]
3	SB	-
43	BG	-
45	W	-
49	L	-
50	P	-
51	BR	-
54	Y	-
57	G	-
59	W	-
60	L	-
61	G	-
62	SB	-
63	G	-
64	B	-
65	W	-
66	R	-
67	SHIELD	-
68	Y	-
69	GR	-
70	LG	-
71	LG	-
72	Y	-
73	SB	-
74	BR	-
74	L	-
75	G	-
76	GR	-
76	W	-
77	P	-
77	R	-
78	L	-
78	R	-
79	W	-
79	Y	-
80	SB	-
81	SB	-
82	SB	-
83	V	-
84	G	-
85	L	-
86	P	-
87	W	-
89	GR	-
90	SHIELD	-
91	W	-
92	Y	-
93	BR	-
94	P	-
95	GR	-
96	W	-
97	L	-
44	L	-
45	GR	-
46	LG	-
47	SB	-
49	Y	-
50	R	-
60	P	-
61	L	-
62	SHIELD	-
63	R	-
64	G	-
65	SHIELD	-
66	SB	-
67	V	-
68	LG	-
69	SHIELD	-
70	W	-
73	G	-
74	R	-
75	W	-
76	W	-
77	B	-
78	P	-
79	GR	-
83	BG	-
85	LG	-
86	R	-
87	Y	-
88	W	-
89	BR	-
90	BG	-
91	G	-
92	V	-
93	BR	-
94	V	-
95	G	-
96	Y	-
98	W	-
99	R	-
30	SHIELD	-
31	L	-
32	P	-
33	SB	-
34	L	-
35	P	-
36	L	-
37	P	-
38	BR	-
39	Y	-
44	L	-

JRKWD1317GB

P

Z

M

L

RF

I

T

M

N

D

C

E

B

A

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >

SUNROOF

Connector No.	M66	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	UNIFIED METER AND A/C AMP.	7 BR	-	58 G	-
Connector Type	TH40FW-NH	8 Y	-	59 SHIELD	-
		9 B	-	60 V	-
		10 R	-	61 LG	-
		11 V	-	62 BR	-
		12 R	-	63 L	-
		13 LG	-	64 LG	-
		14 R	- [With NAVI] - [Without NAVI]	65 B	-
		14 Y	- [With NAVI] - [Without NAVI]	66 R	-
		15 SHIELD	-	67 W	-
		16 BR	- [Without NAVI] - [With NAVI]	68 SHIELD	-
		16 G	- [With NAVI]	69 V	-
		18 B	-	70 Y	-
		71 SB	-	72 W	-
		73 G	-	74 W	-
		75 W	-	76 V	-
		80 V	-	81 SB	-
		82 V	-	83 P	-
		84 R	-	85 L	-
		86 BG	-	87 L	-
		88 P	-	89 Y	-
		90 G	-	91 Y	-
		92 G	-	93 BR	-
		94 G	-	95 W	-
		96 G	-	97 Y	-
		98 BR	-	99 P	- [Without BOSE audio] - [With BOSE audio]
		100 W	-	99 V	- [Without BOSE audio] - [With BOSE audio]
		100 L	-	100 L	- [Without BOSE audio] - [With BOSE audio]
		100 SB	-	100 SB	- [Without BOSE audio] - [With BOSE audio]
		101 L	-	101 P	-
		102 G	-	102 V	-
		103 BR	-	103 Y	-
		104 V	-	104 Y	-
		105 BR	-	105 G	-
		106 BR	-	106 BR	-
		107 LG	-	107 R	-
		108 Y	-	108 B	-
		109 Y	-	109 W	-
		110 V	-	110 V	-
		111 V	-	111 V	-
		112 V	-	112 V	-
		113 V	-	113 V	-
		114 V	-	114 V	-
		115 V	-	115 V	-
		116 V	-	116 V	-
		117 V	-	117 V	-
		118 V	-	118 V	-
		119 V	-	119 V	-

JRKWD1318GB

SUNROOF SYSTEM

< ECU DIAGNOSIS INFORMATION >

SUNROOF

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
13	P	OPTICAL SENSOR	1	G	-
16	SB	STOP LAMP SW 1	2	SHIELD	-
18	P	STOP LAMP SW 2	3	L	-
19	SB	DR. DOOR UNLOCK SENSOR	4	BR	- (With automatic drive positioner)
121	BR	KEY SLOT SWN	4	W	- (Without automatic drive positioner)
123	W	IGN/TIB	5	G	-
124	LG	PASSENGER DOOR SW	7	BR	-
132	BR	POWER DOOR SW	8	Y	-
133	W	PUSH-BUTTON IGNITION SW/ILL POWER	9	B	-
134	GR	LOCK IND	10	Y	-
137	BG	RECEIVERSENSOR GND	11	V	-
138	Y	RECEIVERSENSOR POWER SUPPLY	12	BR	-
139	L	TIRE PRESSURE RECEIVER COMM	13	R	-
140	GR	SHIFT NAP	14	W	-
141	G	SECURITY IND/LAMP CONT	15	SHIELD	-
142	BG	COMBI SW OUTPUT 5	16	B	-
143	P	COMBI SW OUTPUT 1	18	B	-
144	G	COMBI SW OUTPUT 2			
145	L	COMBI SW OUTPUT 3			
146	SB	COMBI SW OUTPUT 4			
	LG	COMBI SW OUTPUT 5			

Connector No.	R4
Connector Name	SUNROOF MOTOR ASSEMBLY
Connector Type	YEA10FGY


Terminal No.	Color Of Wire	Signal Name (Specification)
1	-	-
2	-	-
3	-	-

100

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	SHIELD	-




Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

110



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-



SUNROOF DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SUNROOF DOES NOT OPERATE PROPERLY

Description

INFOID:0000000008288855

Sunroof does not operate normally.

- Glass lid does not slide or tilt.
- Judder occurs during sliding operation of glass lid
- Sliding or tilting operation of glass lid is slow.

Diagnosis Procedure

INFOID:0000000008288856

1.CHECK GLASS LID

Check the following items.

- Cracks, damage, or deformation of weather-strip.
- Sticking of weather-strip.
- Loose or missing glass lid mounting bolt.
- Misalignment of glass lid.

Refer to [RF-81, "Adjustment"](#).

Is the check result normal?

YES >> GO TO 2.

NO >> Repair or replace applicable parts.

2.CHECH SUNROOF FRAME ASSEMBLY

Check the following items.

- Damage, deformation, or trapped foreign material of slide rail.
- Insufficient application of grease to sliding section of slide rail.

Refer to [RF-86, "Removal and Installation"](#).

Is the check result normal?

YES >> GO TO 3.

NO >> Repair or replace applicable parts.

3.CHECK SUNSHADE

Check sunshade for damage, deformation, or interference with other parts.

Is the check result normal?

YES >> GO TO 4.

NO >> Repair or replace applicable parts.

4.CHECK WINDOW DEFLECTOR

Check window deflector for deformation and interference.

Is the check result normal?

YES >> GO TO 5.

NO >> Repair or replace applicable parts.

5.CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY AND GROUND CIRCUIT

Check sunroof motor assembly power supply and ground circuit.

Refer to [RF-10, "SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CHECK SUNROOF SWITCH

Check sunroof switch.

Refer to [RF-12, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace sunroof switch. Refer to [RF-91, "Removal and Installation"](#).

SUNROOF DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

7. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> INSPECTION END.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

AUTO OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE

Description

INFOID:0000000008288857

Auto operation does not operate

- Auto operation of glass lid does not operate.
- Glass lid stops halfway.
- Anti-pinch function operates.

Diagnosis Procedure

INFOID:0000000008288858

1. CHECK GLASS LID

Check the following items.

- Cracks, damage, or deformation of weather-strip.
- Sticking of weather-strip.
- Loose or missing glass lid mounting bolt.
- Misalignment of glass lid.

Refer to [RF-81. "Adjustment"](#).

Is the check result normal?

YES >> GO TO 2.

NO >> Repair or replace applicable parts.

2. CHECK WINDOW DEFLECTOR

Check window deflector for deformation and interference.

Is the check result normal?

YES >> GO TO 3.

NO >> Repair or replace applicable parts.

3. CHECK SUNROOF FRAME ASSEMBLY

Check the following items.

- Damage, deformation, or trapped foreign material of slide rail.
- Insufficient application of grease to sliding section of slide rail.

Refer to [RF-86. "Removal and Installation"](#).

Is the check result normal?

YES >> GO TO 4.

NO >> Repair or replace applicable parts.

4. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-4. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunroof motor assembly. Refer to [GI-42. "Intermittent Incident"](#).

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000008288859

1.CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY AND GROUND CIRCUIT

Check sunroof motor assembly power supply and ground circuit.

Refer to [RF-10, "SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-63, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SUNROOF DOES NOT OPERATE ANTI-PINCH FUNCTION

< SYMPTOM DIAGNOSIS >

SUNROOF DOES NOT OPERATE ANTI-PINCH FUNCTION

Diagnosis Procedure

INFOID:0000000008288860

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-4, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement".](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunroof motor assembly. Refer to [RF-83, "Removal and Installation".](#)


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:0000000008288861



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [RF-75, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - Placing a piece of paper between components that you suspect are causing the noise.
 - Looking for loose components and contact marks.

Refer to [RF-73. "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-50397) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000008288862

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted under hood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000000828863







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only about _____ mph | <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns: left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> buzz (like a bumble bee) |

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000008288864

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation After Battery Disconnection

INFOID:0000000008288865

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the ignition switch to ACC position.
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

-
4. Perform the necessary repair operation.
 5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
 6. Perform self-diagnosis check of all control units using CONSULT.

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool



INFOID:0000000008288866

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locates the noise
(J-50397) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairs the cause of noise

Commercial Service Tool

INFOID:0000000008288867

Tool name	Description
Engine ear  SIIA0995E	Locates the noise
Remover tool  JMKIA3050ZZ	Removes the clips, pawls and metal clips

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P

GLASS LID


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

GLASS LID

Exploded View

INFOID:0000000008288868



- | | | |
|----------------------------|----------------------------|---------------------------|
| 1. Glass lid | 2. TORX bolt | 3. Inner blind (LH/RH) |
| 4. Drain hose (front) | 5. Drain connector (front) | 6. Sunroof motor assembly |
| 7. Sunroof bracket (LH/RH) | 8. Drain hose (rear) | 9. Drain connector (rear) |
| 10. Sunroof unit assembly | | |

▲ : Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:0000000008288869

REMOVAL


CAUTION:

Always work with a helper.

GLASS LID

< REMOVAL AND INSTALLATION >

1. Remove the inner blind upper side, and then fold the inner blind so that the TORX bolts can be seen.
2. Remove the TORX bolts (A), and then remove the glass lid.



3. Remove the glass lid from the vehicle.

INSTALLATION

CAUTION:

After installing the glass lid, perform the leak test and check that there is no malfunction.


NOTE:

After installation perform fitting adjustment. Refer to [RF-81, "Adjustment"](#).

Install in the reverse order of removal.

Adjustment

INFOID:0000000008288870



PIIB3117J

LID WEATHER-STRIP OVERLAP ADJUSTMENT AND SURFACE MISMATCH ADJUSTMENT

1. Remove the side trim upper side, and then fold the side trim so that the TORX bolts can be seen.
2. After loosening glass lid from TORX bolts (left and right), tilt down glass lid.
3. Adjust glass lid from outside of vehicle so it resembles "A - A" "B - B" "C - C" as shown in the figure.

	a	b
A - A	0.6 – 2.2 mm (0.024 – 0.087 in)	-1.5 – 1.5 mm (-0.059 – 0.059 in)
B - B	0.6 – 2.2 mm (0.024 – 0.087 in)	-1.5 – 1.5 mm (-0.059 – 0.059 in)
C - C	0.6 – 2.2 mm (0.024 – 0.087 in)	-1.5 – 1.5 mm (-0.059 – 0.059 in)

4. To prevent glass lid from moving after adjustment, first tighten the TORX bolts of front left, and then tighten the TORX bolts of rear right.
5. Tighten remaining TORX bolts, being careful to prevent glass lid from moving.
6. Tilt glass lid up and down several times to check that it moves smoothly.

NOTE:

GLASS LID

< REMOVAL AND INSTALLATION >

After adjustment the sunroof unit assembly, perform additional service. Refer to [RF-4, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).


SUNROOF MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

SUNROOF MOTOR ASSEMBLY

Exploded View

INFOID:0000000008288871



- | | | |
|----------------------------|----------------------------|---------------------------|
| 1. Glass lid | 2. TORX bolt | 3. Inner blind (LH/RH) |
| 4. Drain hose (front) | 5. Drain connector (front) | 6. Sunroof motor assembly |
| 7. Sunroof bracket (LH/RH) | 8. Drain hose (rear) | 9. Drain connector (rear) |
| 10. Sunroof unit assembly | | |

▲ : Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:0000000008288872

REMOVAL


CAUTION:

- Before removing sunroof motor, check that glass lid is fully closed.
 - After removing sunroof motor, do not attempt to rotate sunroof motor assembly as a single unit.
1. Remove the headlining. Refer to [INT-32, "SUNROOF : Removal and Installation"](#).

SUNROOF MOTOR ASSEMBLY

< REMOVAL AND INSTALLATION >

2. Disconnect connector (A) and from sunroof motor assembly (1). Remove sunroof motor assembly mounting bolts (B), and then remove sunroof motor assembly.



INSTALLATION

CAUTION:

Before installing the sunroof motor assembly, be sure to place the link and wire assembly in the symmetrical and fully closed position.

1. Move the sunroof motor assembly laterally by little so that the gear is completely engaged into the wire on the sunroof unit assembly and mounting surface becomes parallel. Then tighten the sunroof motor assembly with bolts.
2. Install the headlining. Refer to [INT-32, "SUNROOF : Removal and Installation"](#).

SUNROOF UNIT ASSEMBLY


< REMOVAL AND INSTALLATION >

SUNROOF UNIT ASSEMBLY

Exploded View

INFOID:0000000008288873

REMOVAL



- | | | |
|----------------------------|----------------------------|---------------------------|
| 1. Glass lid | 2. TORX bolt | 3. Inner blind (LH/RH) |
| 4. Drain hose (front) | 5. Drain connector (front) | 6. Sunroof motor assembly |
| 7. Sunroof bracket (LH/RH) | 8. Drain hose (rear) | 9. Drain connector (rear) |
| 10. Sunroof unit assembly | | |


▲ : Indicates that the part is connected at points with same symbol in actual vehicle.

DISASSEMBLY

SUNROOF UNIT ASSEMBLY

< REMOVAL AND INSTALLATION >

SEC. 736



JMKIA2042ZZ

- | | | |
|------------------|-------------------|-----------------------------|
| 1. Rear drain | 2. Wind deflector | 3. Sunshade stopper (LH/RH) |
| 4. Sunroof frame | 5. Sunshade | |

Removal and Installation

INFOID:0000000008288874

REMOVAL

CAUTION:

- Always work with a helper.
- Fully close the glass lid, before removal, then never operate sunroof motor assembly after removal.
- When taking sunroof unit assembly out, use cloths to protect the seats and trim from damage.

1. Remove the headlining. Refer to [INT-32, "SUNROOF : Removal and Installation"](#).
2. Remove the glass lid. Refer to [RF-80, "Removal and Installation"](#).
3. Remove the sunroof motor assembly. Refer to [RF-83, "Removal and Installation"](#).
4. Disconnect drain hoses.
5. Remove the assistance grip brackets.
6. Remove the sunroof brackets (LH/RH).

SUNROOF UNIT ASSEMBLY

< REMOVAL AND INSTALLATION >

7. Remove nuts from the front end and side rail, and then remove sunroof unit assembly from roof panel.
8. Remove sunroof unit assembly through the back door while being careful not to damage the seats and trim.

INSTALLATION

CAUTION:

After installing the sunroof unit assembly and glass lid, perform the leak test and check that there is no malfunction.

1. Bring sunroof unit into back door.
2. Temporarily tighten the mounting nuts to the side rail of sunroof unit assembly.
3. Temporarily tighten the mounting nuts to the front end of sunroof unit assembly.
4. Temporarily tighten the mounting bolts to the sunroof brackets (LH/RH)
5. Tighten the installation points diagonally excluding the installation points of the sunroof brackets around the roof opening.
6. Tighten the mounting nuts to the front end and side rail.
7. Tighten the sunroof bracket bolts of the vehicle side, and then tighten the bolt of the rail side.
8. Install the assistance grip bracket.
9. Install the sunroof motor assembly. Refer to [RF-83, "Removal and Installation"](#).
10. Install the glass lid. Refer to [RF-80, "Removal and Installation"](#).

NOTE:

After installation, perform fitting adjustment. Refer to [RF-81, "Adjustment"](#).

11. Connect drain hoses.
12. Install the headlining. Refer to [INT-32, "SUNROOF : Removal and Installation"](#).

Disassembly and Assembly

INFOID:000000008288875

DISASSEMBLY

1. Remove the screw, and then rear drain.
2. Remove sunshade. Refer to [RF-88, "Removal and Installation"](#).

ASSEMBLY

Assemble in the reverse order of disassembly.

RF

L

M

N

O

P


SUNSHADE

< REMOVAL AND INSTALLATION >

SUNSHADE

Exploded View

INFOID:0000000008288876



- 1. Rear drain
- 2. Wind deflector
- 3. Sunshade stopper (LH/RH)
- 4. Sunroof frame
- 5. Sunshade

Removal and Installation

INFOID:0000000008288877


REMOVAL

1. Remove the headlining. Refer to [INT-32, "SUNROOF : Removal and Installation"](#).

SUNSHADE

< REMOVAL AND INSTALLATION >

2. Remove the sunshade stopper (LH/RH) (1) from the sunroof frame end.



3. Remove the sunshade from the rear end of sunroof frame.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D

E

F

G

H

I

J

RF

L

M

N

O

P


WIND DEFLECTOR

< REMOVAL AND INSTALLATION >

WIND DEFLECTOR

Exploded View

INFOID:0000000008288878



- | | | |
|------------------|-------------------|-----------------------------|
| 1. Rear drain | 2. Wind deflector | 3. Sunshade stopper (LH/RH) |
| 4. Sunroof frame | 5. Sunshade | |

Removal and Installation

INFOID:0000000008288879

Removal

1. Open the glass lid to see the wind deflector installation point on the sun roof slide rail.
2. Remove the wind deflector.
 - Remove the spring from sunroof frame groove.
 - Turn the wind deflector and remove it from sunroof frame.

Installation

Install in the reverse order of removal.

SUNROOF SWITCH

< REMOVAL AND INSTALLATION >

SUNROOF SWITCH

Exploded View

INFOID:0000000008288880

Refer to [INL-102, "Exploded View".](#)

Removal and Installation

INFOID:0000000008288881

Removal

Remove the sunroof switch. Refer to [INL-102, "Removal and Installation".](#)

Installation

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

RF

L

M

N

O

P