

SECTION **DLK** DOOR & LOCK

CONTENTS

INTELLIGENT KEY SYSTEM	
BASIC INSPECTION	7
DIAGNOSIS AND REPAIR WORKFLOW	7
Work Flow	7
INSPECTION AND ADJUSTMENT	10
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	10
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	10
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	10
SYSTEM DESCRIPTION	11
POWER DOOR LOCK SYSTEM	11
System Diagram	11
System Description	11
Component Parts Location	13
Component Description	14
INTELLIGENT KEY SYSTEM	15
INTELLIGENT KEY SYSTEM	15
INTELLIGENT KEY SYSTEM : System Diagram....	15
INTELLIGENT KEY SYSTEM : System Description	15
INTELLIGENT KEY SYSTEM : Component Parts Location	17
INTELLIGENT KEY SYSTEM : Component Description	19
DOOR LOCK FUNCTION	19
DOOR LOCK FUNCTION : System Diagram	19
DOOR LOCK FUNCTION : System Description	19
DOOR LOCK FUNCTION : Component Parts Location	22
DOOR LOCK FUNCTION : Component Description	24
BACK DOOR OPEN FUNCTION	24
BACK DOOR OPEN FUNCTION : System Diagram	24
BACK DOOR OPEN FUNCTION : System Description	24
BACK DOOR OPEN FUNCTION : Component Parts Location	26
BACK DOOR OPEN FUNCTION : Component Description	28
REMOTE KEYLESS ENTRY FUNCTION	28
REMOTE KEYLESS ENTRY FUNCTION : System Diagram	28
REMOTE KEYLESS ENTRY FUNCTION : System Description	28
REMOTE KEYLESS ENTRY FUNCTION : Component Parts Location	31
REMOTE KEYLESS ENTRY FUNCTION : Component Description	33
WELCOME LIGHT FUNCTION	33
WELCOME LIGHT FUNCTION : System Description	33
WELCOME LIGHT FUNCTION : Component Parts Location	34
KEY REMINDER FUNCTION	36
KEY REMINDER FUNCTION : System Description	36
KEY REMINDER FUNCTION : Component Parts Location	37
WARNING FUNCTION	39
WARNING FUNCTION : System Description	39
WARNING FUNCTION : Component Parts Location	44
BACK DOOR OPENER SYSTEM	47
System Diagram	47
System Description	47
Component Parts Location	48
Component Description	48

DLK

INTEGRATED HOMELINK TRANSMITTER	49	DRIVER SIDE : Component Function Check	70
Component Description	49	DRIVER SIDE : Diagnosis Procedure	70
DIAGNOSIS SYSTEM (BCM)	50	PASSENGER SIDE	70
COMMON ITEM	50	PASSENGER SIDE : Description	70
COMMON ITEM : CONSULT-III Function (BCM -		PASSENGER SIDE :	
COMMON ITEM)	50	Component Function Check	70
DOOR LOCK	51	PASSENGER SIDE : Diagnosis Procedure	70
DOOR LOCK : CONSULT-III Function (BCM -		DOOR LOCK ACTUATOR	72
DOOR LOCK)	51	DRIVER SIDE	72
INTELLIGENT KEY	52	DRIVER SIDE : Description	72
INTELLIGENT KEY : CONSULT-III Function		DRIVER SIDE : Component Function Check	72
(BCM - INTELLIGENT KEY)	53	DRIVER SIDE : Diagnosis Procedure	72
TRUNK	56	PASSENGER SIDE	72
TRUNK : CONSULT-III Function (BCM - TRUNK)..	56	PASSENGER SIDE : Description	73
DTC/CIRCUIT DIAGNOSIS	57	PASSENGER SIDE :	
U1000 CAN COMM CIRCUIT	57	Component Function Check	73
Description	57	PASSENGER SIDE : Diagnosis Procedure	73
DTC Logic	57	REAR LH	73
Diagnosis Procedure	57	REAR LH : Description	73
U1010 CONTROL UNIT (CAN)	58	REAR LH : Component Function Check	74
DTC Logic	58	REAR LH : Diagnosis Procedure	74
Diagnosis Procedure	58	REAR RH	74
Special Repair Requirement	58	REAR RH : Description	74
B2621 INSIDE KEY ANTENNA 1	59	REAR RH : Component Function Check	74
Description	59	REAR RH : Diagnosis Procedure	75
DTC Logic	59	FUEL LID LOCK ACTUATOR	76
Diagnosis Procedure	59	Description	76
B2622 INSIDE KEY ANTENNA 2	61	Component Function Check	76
Description	61	Diagnosis Procedure	76
DTC Logic	61	BACK DOOR OPENER ACTUATOR	77
Diagnosis Procedure	61	Description	77
B2623 INSIDE KEY ANTENNA 3	63	Component Function Check	77
Description	63	Diagnosis Procedure	77
DTC Logic	63	KEY CYLINDER SWITCH	79
Diagnosis Procedure	63	Description	79
POWER SUPPLY AND GROUND CIRCUIT	65	Component Function Check	79
BCM (BODY CONTROL MODULE)	65	Diagnosis Procedure	79
BCM (BODY CONTROL MODULE) : Diagnosis		Component Inspection	80
Procedure	65	REMOTE KEYLESS ENTRY RECEIVER	81
DOOR SWITCH	66	Description	81
Description	66	Component Function Check	81
Component Function Check	66	Diagnosis Procedure	81
Diagnosis Procedure	66	BACK DOOR OPENER SWITCH	84
Component Inspection	68	Description	84
DOOR LOCK AND UNLOCK SWITCH	70	Component Function Check	84
DRIVER SIDE	70	Diagnosis Procedure	84
DRIVER SIDE : Description	70	Component Inspection	85
		DOOR REQUEST SWITCH	86
		Description	86
		Component Function Check	86

Diagnosis Procedure	86	KEY WARNING LAMP	107	
Component Inspection	87	Description	107	A
BACK DOOR REQUEST SWITCH	88	Component Function Check	107	
Description	88	Diagnosis Procedure	107	
Component Function Check	88	HAZARD FUNCTION	108	B
Diagnosis Procedure	88	Description	108	
Component Inspection	89	Component Function Check	108	C
UNLOCK SENSOR	90	Diagnosis Procedure	108	
Description	90	INTEGRATED HOMELINK TRANSMITTER ..	109	
Component Function Check	90	Description	109	D
Diagnosis Procedure	90	Component Function Check	109	
Component Inspection	91	Diagnosis Procedure	109	
OUTSIDE KEY ANTENNA	92	POWER DOOR LOCK SYSTEM	111	E
Description	92	Wiring Diagram - POWER DOOR LOCK SYSTEM		
Component Function Check	92	-	111	
Diagnosis Procedure	92	INTELLIGENT KEY SYSTEM	119	F
INTELLIGENT KEY WARNING BUZZER	95	Wiring Diagram - INTELLIGENT KEY SYSTEM - ..	119	
Description	95	INTEGRATED HOMELINK TRANSMITTER		G
Component Function Check	95	SYSTEM	131	
Diagnosis Procedure	95	Wiring Diagram - INTEGRATED HOMELINK		
Component Inspection	96	TRANSMITTER SYSTEM -	131	H
INTELLIGENT KEY	97	ECU DIAGNOSIS INFORMATION	133	
Description	97	BCM (BODY CONTROL MODULE)	133	I
Component Function Check	97	Reference Value	133	
Diagnosis Procedure	97	Wiring Diagram - BCM -	157	
Component Inspection	97	Fail-safe	163	J
Special Repair Requirement	98	DTC Inspection Priority Chart	165	
KEY SLOT	99	DTC Index	167	
Description	99	SYMPTOM DIAGNOSIS	170	DLK
Component Function Check	99	DOOR DOES NOT LOCK/UNLOCK WITH		
Diagnosis Procedure	99	DOOR LOCK AND UNLOCK SWITCH	170	L
Component Inspection	100	ALL DOOR	170	
KEY SLOT INDICATOR	101	ALL DOOR : Description	170	M
Description	101	ALL DOOR : Diagnosis Procedure	170	
Component Function Check	101	DRIVER SIDE	170	
Diagnosis Procedure	101	DRIVER SIDE : Description	170	N
Component Inspection	102	DRIVER SIDE : Diagnosis Procedure	170	
HORN FUNCTION	103	PASSENGER SIDE	171	
Description	103	PASSENGER SIDE : Description	171	O
Component Function Check	103	PASSENGER SIDE : Diagnosis Procedure	171	
Diagnosis Procedure	103	REAR LH	171	P
COMBINATION METER DISPLAY FUNC-		REAR LH : Description	171	
TION	105	REAR LH : Diagnosis Procedure	171	
Description	105	REAR RH	171	
Component Function Check	105	REAR RH : Description	171	
Diagnosis Procedure	105	REAR RH : Diagnosis Procedure	171	
BUZZER (COMBINATION METER)	106			
Description	106			
Component Function Check	106			
Diagnosis Procedure	106			

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION	173
Description	173
Diagnosis Procedure	173
DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH	174
ALL DOOR	174
ALL DOOR : Description	174
ALL DOOR : Diagnosis Procedure	174
DRIVER SIDE	174
DRIVER SIDE : Description	174
DRIVER SIDE : Diagnosis Procedure	174
PASSENGER SIDE	175
PASSENGER SIDE : Description	175
PASSENGER SIDE : Diagnosis Procedure	175
BACK DOOR	175
BACK DOOR : Description	175
BACK DOOR : Diagnosis Procedure	175
DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY	177
Description	177
Diagnosis Procedure	177
BACK DOOR DOES NOT OPENED	178
Description	178
Diagnosis Procedure	178
SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH DOOR REQUEST SWITCH	179
Description	179
Diagnosis Procedure	179
SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH INTELLIGENT KEY ...	180
Description	180
Diagnosis Procedure	180
VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE	181
Diagnosis Procedure	181
IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE	182
Diagnosis Procedure	182
P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE	183
Diagnosis Procedure	183
AUTO DOOR LOCK OPERATION DOES NOT OPERATE	184
Description	184
Diagnosis Procedure	184

POWER WINDOW DOWN FUNCTION DOES NOT OPERATE WITH KEY CYLINDER OPERATION	185
Diagnosis Procedure	185
POWER WINDOW DOWN FUNCTION DOES NOT WORK WHEN OPERATING WITH INTELLIGENT KEY	186
Description	186
Diagnosis Procedure	186
WELCOME LIGHT FUNCTION DOES NOT OPERATE	187
Description	187
Diagnosis Procedure	187
PANIC ALARM FUNCTION DOES NOT OPERATE	188
Description	188
Diagnosis Procedure	188
HAZARD AND HORN REMINDER DOES NOT OPERATE	189
Description	189
Diagnosis Procedure	189
HAZARD AND BUZZER REMINDER DOES NOT OPERATE	190
Description	190
Diagnosis Procedure	190
KEY REMINDER FUNCTION DOES NOT OPERATE	191
Description	191
Diagnosis Procedure	191
KEY WARNING DOES NOT OPERATE	192
Description	192
Diagnosis Procedure	192
OFF POSITION WARNING DOES NOT OPERATE	193
Description	193
Diagnosis Procedure	193
P POSITION WARNING DOES NOT OPERATE	194
Description	194
Diagnosis Procedure	194
ACC WARNING DOES NOT OPERATE	196
Description	196
Diagnosis Procedure	196
TAKE AWAY WARNING DOES NOT OPERATE	197
DOOR IS OPEN	197
DOOR IS OPEN : Description	197
DOOR IS OPEN : Diagnosis Procedure	197

ANY DOOR OPEN TO ALL DOORS CLOSED	198	PREPARATION	214
ANY DOOR OPEN TO ALL DOORS CLOSED :		PREPARATION	214
Description	198	Special Service Tools	214
ANY DOOR OPEN TO ALL DOORS CLOSED :		Commercial Service Tools	214
Diagnosis Procedure	198	REMOVAL AND INSTALLATION	215
PUSH-BUTTON IGNITION SWITCH OPERATION.	198	HOOD	215
PUSH-BUTTON IGNITION SWITCH OPERA-		HOOD ASSEMBLY	215
TION : Description	199	HOOD ASSEMBLY : Exploded View	215
PUSH-BUTTON IGNITION SWITCH OPERA-		HOOD ASSEMBLY : Removal and Installation	215
TION : Diagnosis Procedure	199	HOOD ASSEMBLY : Adjustment	217
INTELLIGENT KEY IS REMOVED FROM KEY		HOOD HINGE	218
SLOT	199	HOOD HINGE : Exploded View	219
INTELLIGENT KEY IS REMOVED FROM KEY		HOOD HINGE : Removal and Installation	219
SLOT : Description	199	HOOD STAY	220
INTELLIGENT KEY IS REMOVED FROM KEY		HOOD STAY : Exploded View	220
SLOT : Diagnosis Procedure	200	HOOD STAY : Removal and Installation	220
INTELLIGENT KEY LOW BATTERY WARN-		HOOD STAY : Disposal	221
ING DOES NOT OPERATE	201	RADIATOR CORE SUPPORT	222
Description	201	Exploded View	222
Diagnosis Procedure	201	Removal and Installation	222
DOOR LOCK OPERATION WARNING DOES		FRONT FENDER	225
NOT OPERATE WITH DOOR REQUEST		Exploded View	225
SWITCH	202	Removal and Installation	225
Description	202	FRONT DOOR	227
Diagnosis Procedure	202	DOOR ASSEMBLY	227
KEY ID WARNING DOES NOT OPERATE	203	DOOR ASSEMBLY : Exploded View	227
Description	203	DOOR ASSEMBLY : Removal and Installation	227
Diagnosis Procedure	203	DOOR ASSEMBLY : Adjustment	228
INTELLIGENT KEY LOW BATTERY WARN-		DOOR STRIKER	229
ING DOES NOT OPERATE	204	DOOR STRIKER : Exploded View	229
Description	204	DOOR STRIKER : Removal and Installation	229
Diagnosis Procedure	204	DOOR HINGE	229
INTEGRATED HOMELINK TRANSMITTER		DOOR HINGE : Exploded View	230
DOES NOT OPERATE	205	DOOR HINGE : Removal and Installation	230
Description	205	DOOR CHECK LINK	230
Diagnosis Procedure	205	DOOR CHECK LINK : Exploded View	231
SQUEAK AND RATTLE TROUBLE DIAG-		DOOR CHECK LINK : Removal and Installation ..	231
NOSES	206	REAR DOOR	232
Work Flow	206	DOOR ASSEMBLY	232
Inspection Procedure	208	DOOR ASSEMBLY : Exploded View	232
Diagnostic Worksheet	210	DOOR ASSEMBLY : Removal and Installation	232
PRECAUTION	212	DOOR ASSEMBLY : Adjustment	233
PRECAUTIONS	212	DOOR STRIKER	234
Precaution for Supplemental Restraint System		DOOR STRIKER : Exploded View	234
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		DOOR STRIKER : Removal and Installation	234
SIONER"	212	DOOR HINGE	234
Precaution Necessary for Steering Wheel Rota-		DOOR HINGE : Exploded View	235
tion after Battery Disconnect	212		
Precaution for Procedure without Cowl Top Cover.	213		
Work	213		

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR HINGE : Removal and Installation	235	OUTSIDE HANDLE	256
DOOR CHECK LINK	235	OUTSIDE HANDLE : Exploded View	257
DOOR CHECK LINK : Exploded View	236	OUTSIDE HANDLE : Removal and Installation ...	257
DOOR CHECK LINK : Removal and Installation ..	236	BACK DOOR LOCK	259
BACK DOOR	237	Exploded View	259
BACK DOOR ASSEMBLY	237	Removal and Installation	259
BACK DOOR ASSEMBLY : Exploded View	237	FUEL FILLER LID OPENER	260
BACK DOOR ASSEMBLY : Removal and Installa- tion	237	Exploded View	260
BACK DOOR ASSEMBLY : Adjustment	239	Removal and Installation	260
BACK DOOR STRIKER	240	DOOR SWITCH	261
BACK DOOR STRIKER : Exploded View	240	Exploded View	261
BACK DOOR STRIKER : Removal and Installa- tion	240	Removal and Installation	261
BACK DOOR HINGE	241	INSIDE KEY ANTENNA	262
BACK DOOR HINGE : Exploded View	241	INSTRUMENT CENTER	262
BACK DOOR HINGE : Removal and Installation ..	241	INSTRUMENT CENTER : Exploded View	262
BACK DOOR STAY	242	INSTRUMENT CENTER : Removal and Installa- tion	262
BACK DOOR STAY : Exploded View	242	CONSOLE	262
BACK DOOR STAY : Removal and Installation ...	242	CONSOLE : Exploded View	262
BACK DOOR STAY : Disposal	243	CONSOLE : Removal and Installation	262
BACK DOOR WEATHER-STRIP	243	LUGGAGE ROOM	263
BACK DOOR WEATHER-STRIP : Exploded View ..	244	LUGGAGE ROOM : Exploded View	263
BACK DOOR WEATHER-STRIP : Removal and Installation	244	LUGGAGE ROOM : Removal and Installation	263
HOOD LOCK	245	OUTSIDE KEY ANTENNA	264
Exploded View	245	DRIVER SIDE	264
Removal and Installation	245	DRIVER SIDE : Exploded View	264
Inspection	247	DRIVER SIDE : Removal and Installation	264
FRONT DOOR LOCK	248	PASSENGER SIDE	264
DOOR LOCK	248	PASSENGER SIDE : Exploded View	264
DOOR LOCK : Exploded View	248	PASSENGER SIDE : Removal and Installation ...	264
DOOR LOCK : Removal and Installation	248	BACK DOOR	264
INSIDE HANDLE	250	BACK DOOR : Exploded View	264
INSIDE HANDLE : Exploded View	250	BACK DOOR : Removal and Installation	264
INSIDE HANDLE : Removal and Installation	251	INTELLIGENT KEY WARNING BUZZER	265
OUTSIDE HANDLE	251	Exploded View	265
OUTSIDE HANDLE : Exploded View	251	Removal and Installation	265
OUTSIDE HANDLE : Removal and Installation	251	KEY SLOT	266
REAR DOOR LOCK	254	Exploded View	266
DOOR LOCK	254	Removal and Installation	266
DOOR LOCK : Exploded View	254	REMOTE KEYLESS ENTRY RECEIVER	267
DOOR LOCK : Removal and Installation	254	Exploded View	267
INSIDE HANDLE	255	Removal and Installation	267
INSIDE HANDLE : Exploded View	256	INTELLIGENT KEY BATTERY	268
INSIDE HANDLE : Removal and Installation	256	Removal and Installation	268


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004343358

OVERALL SEQUENCE

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DETAILED FLOW

JMKIA3620GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[INTELLIGENT KEY SYSTEM]

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2.CHECK FOR DTC

1. Check DTC for BCM.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT-III.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3.

Symptom is described, DTC is not displayed>>GO TO 4.

Symptom is not described, DTC is displayed>>GO TO 5.

3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [DLK-165. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-40. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7.

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[INTELLIGENT KEY SYSTEM]

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check voltage of related BCM terminals using CONSULT-III.

8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9.

9.FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction has been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 7.

YES (Symptom remains)>>GO TO 6.

NO >> INSPECTION END

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[INTELLIGENT KEY SYSTEM]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:0000000004343359

Perform the system initialization when replacing BCM, replacing Intelligent Key or registering an additional Intelligent Key.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement


INFOID:0000000004343360

Refer to the CONSULT-III operation manual for the initialization procedure.

SYSTEM DESCRIPTION

POWER DOOR LOCK SYSTEM

System Diagram



System Description

INFOID:0000000004343362

DOOR LOCK FUNCTION

- The door lock and unlock switch (driver side) is build into power window main switch.
- The door lock and unlock switch (passenger side) is build into front power window switch (passenger side).
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors and fuel lid lock actuator are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors and fuel lid lock actuator are unlocked.

Door Key Cylinder

- With the door key inserted in the door key cylinder on driver side, turning it to “LOCK”, will lock door lock actuator of all doors and fuel lid lock actuator.
- With the door key inserted in the door key cylinder on driver side, turning it to “UNLOCK” once unlocks the driver side door lock actuator and fuel lid lock actuator; turning it to “UNLOCK” again within 60 seconds after the first unlock operation unlocks all of the other doors. - (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using “DOOR LOCK-UNLOCK SET” mode in “WORK SUPPORT”. Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

KEY REMINDER FUNCTION

When door lock and unlock switch are operated while Intelligent Key is inserted into key slot and any door is open, door locks once but immediately unlocks. This operation prevents Intelligent Key from being left in the vehicle.

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (LOCK OPERATION)

The interlock door lock function is the function that locks all doors linked with the vehicle speed or shift position. It has 2 types as follows.

Vehicle Speed Sensing Auto Door Lock*1

All doors are locked when the vehicle speed reaches 15 MPH (24 km/h) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the unified meter and A/C amp. via CAN communication becomes 24 km/h (15 miles) or more.

P Range Interlock Door Lock

All doors are locked when shifting the selector lever from the P position to any position other than P.

POWER DOOR LOCK SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is in the ON position and the shift signal received from the TCM via CAN communication is shifted from the P position to any position other than P.

Setting change of Automatic Door Lock/Unlock Function

The lock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT-III

The ON/OFF switching of the automatic door lock function and the type selection of the automatic door lock/unlock function can be performed at the WORK SUPPORT setting of CONSULT-III.

Without CONSULT- III

The automatic door lock function ON/OFF can be switched by performing the following operation.

1. Close all doors (door switch OFF)
2. Turn ignition switch ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the ignition switch ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (UNLOCK OPERATION)

The automatic door lock/unlock function is the function that unlocks all doors linked with the key position or shift position. It has 2 types as follows.

IGN OFF Interlock Door Unlock*1

All doors are unlocked when the power supply position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

P Range Interlock Door Unlock

All doors are unlocked when shifting the selector lever from any position other than the P to P position.

BCM outputs the unlock signal to all door lock actuators when it detects that the ignition switch is in the ON position and the shift signal received from TCM via CAN communication is shifted from any position other than the P to P position.

Setting change of Automatic Door Lock/Unlock Function

The unlock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT- III

The ON/OFF switching of the automatic door lock/unlock function and the type selection of the automatic door lock/unlock function can be performed at the WORK SUPPORT setting of CONSULT-III.

Without CONSULT- III

The automatic door lock/unlock function ON/OFF can be switched by performing the following operation.

1. Close all doors below (door switch OFF)
2. Turn ignition switch ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power supply position ON.
4. The switching is completed when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

*1: This function is set to ON before delivery.


POWER DOOR LOCK SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Component Parts Location

INFOID:000000004343363



1. BCM M118, M119, M121, M122, M123
4. Key cylinder switch
[Front door lock assembly (driver side) D15]

2. A/T assembly connector F51
5. Door lock and unlock switch
(Power window main switch D8, D9)

3. Key slot M22
6. Door lock and unlock switch
[Front power window switch (passenger) D38]

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|---|--|
| 7. Front door switch (driver side) B16 | 8. Door lock actuator
[Front door lock assembly (driver side) D15] | 9. Fuel lid lock actuator B242 |
| 10. Unified meter and A/C amp.
M66, M67 | | |
| A. Dash side lower (passenger side) | B. A/T assembly (TCM is built in A/T assembly) | C. View with front door finisher (LH) is removed |
| D. View with luggage side finisher lower (RH) is removed | | |

Component Description

INFOID:000000004343364

Item	Function
BCM	Controls the door lock function and room lamp function.
Door lock and unlock switch	Input lock or unlock signal to BCM.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Key cylinder switch	<ul style="list-style-type: none"> Input lock or unlock signal to power window main switch. Power window main switch transmits door lock/unlock signal to BCM.
Key slot	Input key insert/remove signal to BCM.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer. Transmits vehicle speed signal to BCM via CAN communication line.
TCM	Transmit shift position signal to BCM via CAN communication line.
Push-button ignition switch	Input push-button ignition switch ON/OFF condition to BCM.

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >


[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM : System Diagram

INFOID:000000004343365



INTELLIGENT KEY SYSTEM : System Description

INFOID:000000004343366

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communications between the Intelligent Key and the vehicle (BCM).

CAUTION:

The driver should always carry the Intelligent Key

- The settings for each function can be changed with the CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with the CONSULT-III.

Function	Description	Refer
Door lock function	Lock/unlock can be performed by pressing the request switch.	DLK-19
Remote keyless entry function	Lock/unlock can be performed by pressing the remote controller button of the Intelligent Key.	DLK-28
Back door open function	The back door can be opened by carrying the Intelligent Key and pressing the back door opener switch.	DLK-24

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Function	Description	Refer
Welcome light function	The puddle lamp and room automatically turn ON, if the Intelligent Key is in the door outside key antenna detection area.	DLK-33
Key reminder function	The key reminder buzzer sounds a warning if the door is locked with the key left inside the vehicle.	DLK-36
Warning function	If an action that does not meet the operating condition of the Intelligent Key system is taken, the buzzer goes off to inform the driver.	DLK-39
Engine start function	The engine be turned on while carrying the Intelligent Key.	SEC-9


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM : Component Parts Location

INFOID:000000004343367



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote key less entry receiver M104

3. Key slot M22
6. A/T shift selector (detention switch) M137

JMK1A222ZZ


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

JMKIA2223ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

10. Back door request switch D116

- A. View with luggage floor finisher front is removed B. View with back door finisher inner is removed

INTELLIGENT KEY SYSTEM : Component Description


INFOID:000000004343368

Item	Function
BCM	Controls the Intelligent Key system.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Request switch	Input lock/unlock operation to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Unified meter and A/C amp.	<ul style="list-style-type: none">Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer.Transmits vehicle speed signal to BCM via CAN communication line.
Combination meter	Display, buzzer (combination meter) and KEY warning lamp are installed to combination meter.
Back door opener switch	Input back door opener switch operation signal to BCM.
Back door opener actuator	Opens the back door with the back door open signal from BCM.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

DOOR LOCK FUNCTION

DOOR LOCK FUNCTION : System Diagram

INFOID:000000004343369



DOOR LOCK FUNCTION : System Description

INFOID:000000004343370

Only when pressing the request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

OPERATION DESCRIPTION

- When the BCM detects that each door request switch is pressed, it starts the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM lock/unlock each door (except back door) and fuel lid lock actuator and sounds Intelligent Key buzzer warning (lock: 2 time, unlock: 1 times) at the same time as a reminder.

OPERATION CONDITION


If the following conditions are satisfied, door lock/unlock operation is performed if the request switch is operated.

Operation	Operation condition
Lock operation	<ul style="list-style-type: none">• All doors are closed• P position warning is activated• Panic alarm is not activated• Intelligent Key is outside the vehicle• Intelligent Key is within outside key antenna detection area
Unlock Operation	<ul style="list-style-type: none">• Panic alarm is not activated• Intelligent Key is outside the vehicle• Intelligent Key is within outside key antenna detection area *

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles and (1) and the back door request switch (2). However, this operating range depends on the ambient conditions.



SELECTIVE UNLOCK FUNCTION

When an LOCK signal is sent from door request switch (driver side or passenger side), all doors and fuel lid will be locked.

When an UNLOCK signal is sent from door request switch (driver side or passenger side) once, driver's door and fuel lid will be unlocked.

Then, if an UNLOCK signal is sent from door request switch (driver side and passenger side) again within 60 seconds, all other door will be unlocked.

HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, BCM honks Intelligent Key warning buzzer as a reminder and blinks.

Operating Function of Hazard and Buzzer Reminder

Operation	Hazard warning lamp flash	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice

How to Change Hazard and Buzzer Reminder Mode

Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

AUTO DOOR LOCK FUNCTION

When all doors are locked, ignition switch is in OFF position and key switch is OFF (Intelligent Key is not inserted in key slot), doors are unlocked with door request switch

When BCM does not receive the following signals within 60 seconds, all doors and fuel lid are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON (ignition switch is pressed)
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by "AUTO LOCK SET" mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

INTERIOR ROOM LAMP CONTROL

Intelligent Key system turns on interior lamp by receiving UNLOCK signal from door request switch. For detailed description, refer to [INL-5, "System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Door lock function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Door request switch	Door lock actuator and fuel lid lock actuator	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamp	Push-button ignition switch
Door lock/unlock function by request switch	×	×	×	×	×	×	×	×			×		
Hazard and buzzer reminder function for door lock/unlock operation									×	×	×	×	
Selective unlock function by request switch (Driver side)	×				×	×	×	×			×		
Selective unlock function by request switch (Passenger side)	×				×	×	×	×			×		
Selective unlock function by request switch (back door)	×				×		×	×			×		
Auto door lock function	×	×		×	×	×					×		×

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

DOOR LOCK FUNCTION : Component Parts Location

INFOID:000000004343371



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote keyless entry receiver M104

3. Key slot M22
6. A/T shift selector (detention switch) M137

JMKIA2222ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

7. Front door switch (driver side) B16

10. Back door opener switch D114

13. Intelligent Key warning buzzer E57

A. Dash side lower (passenger side)

D. View with center console assembly removed

G. View with front bumper is removed
8. Front door lock assembly (driver side) D15

11. Horn (high) E61, E62


B. Engine room dash panel (RH)

E. View with front door finisher (LH) is removed
9. Fuel lid lock actuator B242

12. Horn (low) E69, E70

C. Behind the instrument lower panel (driver side)

F. View luggage side finisher lower (RH) is removed



1. Push-button ignition switch (push switch) M50

4. Inside key antenna (console) M146

7. Front outside handle LH (outside key antenna) D14
2. Inside key antenna (instrument center) M131

5. Inside key antenna (luggage room) B228

8. Outside key antenna (back door) D118
3. Unified meter and A/C amp. M66, M67

6. Front outside handle LH (request switch) D13

9. Back door lock assembly D113

10. Back door opener request switch
D116

A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

DOOR LOCK FUNCTION : Component Description


INFOID:0000000004343372

Item	Function
BCM	Controls the door lock function.
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door.
Door switch	Input door open/close condition to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Request switch	Input lock/unlock operation to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna	Detects if Intelligent Key is outside the vehicle.
Inside key antenna	Detects if Intelligent Key is inside the vehicle.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer. Transmits vehicle speed signal to BCM via CAN communication line.
Combination meter	Display, buzzer (combination meter) and KEY warning lamp are installed to combination meter.
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound.

BACK DOOR OPEN FUNCTION

BACK DOOR OPEN FUNCTION : System Diagram

INFOID:0000000004343373



BACK DOOR OPEN FUNCTION : System Description

INFOID:0000000004343374

This section describes the operation of the back door opener switch. The operation of the back door request switch is the same as the door lock function. Refer to [DLK-19, "DOOR LOCK FUNCTION : System Description"](#).

- The back door opener function can open the back door by pressing the back door opener switch while carrying the Intelligent Key. At this time, all doors other than the back door and fuel lid are locked.
- The back door opener function can open the back door by pressing the back door opener switch with all doors and fuel lid are unlocked by the door request switch or remote controller.

BACK DOOR OPEN

- When the BCM detects that back door opener switch is pressed, it starts the outside key antenna (back door) and inside key antenna and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the back door.

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM open the back door and sounds Intelligent Key buzzer warning at the same time as a reminder.


OPERATION CONDITION

If the following conditions are satisfied, the back door can be opened.

- Back door is closed
- Intelligent Key is outside of vehicle
- Intelligent Key is within out side key antenna detection area

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of back door open function is in the range of approximately 80 cm (31.50 in) surrounding the back door opener switch (1). However, this operating range depends on the ambient conditions.



HAZARD AND BUZZER REMINDER FUNCTION

Back door opening operation by back door opener switch, the hazard warning lamps and born will blink or honk as a reminder.

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Door lock function	Intelligent Key	Key slot	Remote keyless entry receiver	Door switch	Door request switch	Door lock actuator and fuel lid lock actuator	Inside key antenna	Outside key antenna (Rear bumper)	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamp	Back door opener switch
Back door open function by back door opener switch (Carrying Intelligent Key)	×	×	×	×	×	×	×	×		×	×		×
Hazard and buzzer reminder function for door lock/unlock operation									×	×	×	×	

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

BACK DOOR OPEN FUNCTION : Component Parts Location

INFOID:000000004343375



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote keyless entry receiver M104

3. Key slot M22
6. A/T shift selector (detention switch) M137


JMKIA2222ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

10. Back door opener request switch
D116

A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

BACK DOOR OPEN FUNCTION : Component Description


INFOID:0000000004343376

Item	Function
BCM	Controls the back door open function and room lamp function.
Back door opener switch	Input press/degrees signal to BCM.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Intelligent Key	Transmits button operation to remote keyless entry receiver.
Outside key antenna (back door)	Detects if Intelligent Key is outside the vehicle.

REMOTE KEYLESS ENTRY FUNCTION

REMOTE KEYLESS ENTRY FUNCTION : System Diagram

INFOID:0000000004343377



REMOTE KEYLESS ENTRY FUNCTION : System Description

INFOID:0000000004343378

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION

Remote keyless entry system controls operation of the

- Door lock/unlock
- Selective unlock
- Hazard and horn reminder
- Auto door lock
- Panic alarm
- Power window down
- Interior lamp

OPERATION AREA

To ensure the Intelligent Key works effectively, use within 1 m (3ft) range of each doors, however the operable range may differ according to surroundings.

DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal is transmits from Intelligent Key to BCM via remote keyless entry receiver.

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- When BCM receives the door lock/unlock signal, it operates door lock actuator and fuel lid lock actuator, flashes the hazard lamp (lock: 2 time, unlock: 1 times) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 2 time) as a reminder

OPERATION CONDITION

Operation	Operation condition
Lock	All doors closed
Unlock	Intelligent Key is out of key slot

SELECTIVE UNLOCK FUNCTION

When an LOCK signal is transmitted from Intelligent Key, all doors and fuel lid will be locked.

When an UNLOCK signal is transmitted from Intelligent Key once, driver's door and fuel lid will be unlocked.

Then, if an UNLOCK signal is transmitted from Intelligent Key again within 60 seconds, all other door will be unlocked.

HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM flashes hazard warning lamps as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating Function of Hazard and Horn Reminder

	C mode		S mode	
Intelligent Key operation	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—
Horn sound	Once	—	—	—

Hazard and horn reminder does not operate if any door switch is ON (any door is OPEN).


How to Change Hazard and Horn Reminder Mode

With CONSULT-III

Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Without CONSULT-III

When LOCK and UNLOCK signals are sent from the Intelligent Key for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



AUTO DOOR LOCK FUNCTION

When all doors and fuel lid are locked, ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), doors and fuel lid are unlocked with Intelligent Key button. When BCM does not receive the following signals within 60 seconds, all doors and fuel lid are locked.

- Door switch is ON (door is opened)
- Door is locked
- Ignition switch is ON
- Key switch is ON (Intelligent Key is inserted in key slot)

Auto door lock mode can be changed by "AUTO LOCK SET" mode in "WORK SUPPORT". Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

PANIC ALARM FUNCTION

When ignition switch is OFF (ignition switch is not pressed) and key switch is OFF (Intelligent Key is not inserted in key slot), BCM receives PANIC ALARM signal from Intelligent Key.

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

BCM turns on and off headlamp intermittently and transmits theft warning horn signal to IPDM E/R. Then, IPDM E/R turns on and off horn intermittently.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off:

- After 25 seconds
- When BCM receives any signal from Intelligent Key

Panic alarm function mode can be changed by "PANIC ALARM SET" mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

KEYLESS POWER WINDOW DOWN (OPEN) FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, Keyless power window down (open) function cannot be operated.

Keyless power window down operation mode can be changed by "PW DOWN SET" mode in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

INTERIOR ROOM LAMP CONTROL

Intelligent Key system turns on interior lamp by receiving UNLOCK signal from Intelligent Key. For detailed description, refer to [INL-5, "System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Key slot	Door request switch	Door switch	Door lock actuator and fuel lid lock actuator	CAN communication system	BCM	Combination meter	Hazard warning lamp	Horn	IPDM E/R	Headlamp
Door lock/unlock function by remote control button	×	×		×	×		×					
Hazard and horn reminder function	×					×	×	×	×	×	×	
Selective unlock function	×			×	×		×					
Auto door lock function	×	×		×			×					
Panic alarm function	×		×			×	×			×	×	×


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

REMOTE KEYLESS ENTRY FUNCTION : Component Parts Location

INFOID:000000004343379



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote key less entry receiver M104


3. Key slot M22
6. A/T shift selector (detention switch) M137

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

JMKIA2223ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

10. Back door opener request switch
D116

A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

REMOTE KEYLESS ENTRY FUNCTION : Component Description

INFOID:000000004343380

Item	Function
BCM	Controls the door lock function and room lamp function.
IPDM E/R	Horn sounds and headlamp blinks via CAN communication between BCM.
Door lock actuator	Outputs lock/unlock signal from BCM and locks/unlocks each door.
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM.
Unified meter and A/C amp.	<ul style="list-style-type: none">• Receive buzzer signal from BCM via CAN communication line, and sounds the buzzer.• Transmits vehicle speed signal to BCM via CAN communication line.
Combination meter	Display, buzzer (combination meter) and KEY warning lamp are installed to combination meter.
Intelligent Key	Transmits button operation to remote keyless entry receiver.

WELCOME LIGHT FUNCTION

WELCOME LIGHT FUNCTION : System Description

INFOID:000000004343381

CONDITION OF SEARCHING

If all following conditions are satisfied, BCM search Intelligent Key by outside key antenna (front outside handle LH/RH and back door). BCM has timer to search for 14 days (every 0.3 sec.). If run the engine, the timer will be reset.

Function	Condition
Welcome light function	<ul style="list-style-type: none">• System setting is active.• All doors are closed.• Ignition position is OFF.• There is no Intelligent Key inside vehicle.• Shift position is P position.• All doors are closed and locked (or auto lock timer is running).

OPERATION PROCEDURE

BCM search outside key antenna (front outside handle LH/RH and back door) detection area. If registered Intelligent Key is detected, BCM turn ON the room lamp and puddle lamp.

For detailed description after turning ON the lamps, refer to [INL-5, "System Description"](#).

SYSTEM SETTING PROCEDURE

Setting of welcome light function can be changed by following procedure. (for system setting by CONSULT-III: refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).)

1. Confirm Intelligent Key is removed from key slot.
2. Turn ignition switch ON and press and hold request switch (driver side) more than 5 seconds.
3. Confirm sounds of buzzer (combination meter).

Pi, Pi, Pi... (approx. 1.2 sec.): Welcome light function is OFF.

Pi, Pi, Pi...(approx. 2.4 sec.): Welcome light function is ON.


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

WELCOME LIGHT FUNCTION : Component Parts Location

INFOID:000000004343382



JMKIA222ZZ

1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote key less entry receiver M104


3. Key slot M22
6. A/T shift selector (detention switch) M137

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

10. Back door opener request switch
D116


A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

KEY REMINDER FUNCTION

KEY REMINDER FUNCTION : System Description

INFOID:000000004343383



Key reminder is the function that prevents the key from being left in the vehicle.
Key reminder has the following 3 functions.

Key remainder function	Operation condition	Operation
Driver door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none"> Door lock operation is performed Driver side door is opened Driver side door is in lock state 	All doors and fuel lid unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle Any door is opened All doors are locked by door lock and unlock switch or door lock knob 	<ul style="list-style-type: none"> All doors and fuel lid unlock Honk Intelligent Key warning buzzer
Back door is closed	Right after back door is closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside vehicle All doors (except back door) are closed All doors (except back door) are locked 	<ul style="list-style-type: none"> All doors and fuel lid unlock Back door can open with back door opener switch Honk Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation will be perform in these cases.

CAUTION:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function will not operate when the Intelligent Key is on the instrument panel, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.
- Key reminder function is operated when the back door is open/closed and the buzzers sound, if the following operations are performed, the key reminder function is cleared and buzzer sounds are stopped.
 - Remote controller door lock button operation of Intelligent Key
 - Remote controller door unlock button operation of Intelligent Key
 - When the back door is closed, the Intelligent Key is not inside the vehicle
 - When any door is open


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

KEY REMINDER FUNCTION : Component Parts Location

INFOID:000000004343384



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote key less entry receiver M104

3. Key slot M22
6. A/T shift selector (detention switch) M137


JMK1A222ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

JMKIA2223ZZ

10. Back door opener request switch
D116

A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

WARNING FUNCTION

WARNING FUNCTION : System Description

INFOID:000000004343385

OPERATION DESCRIPTION

The warning function are as follows and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, KEY warning lamp, key slot illumination and information display in combination meter.

- Intelligent Key system malfunction
- OFF position warning
- P position warning
- ACC warning
- Take away warning
- Door lock operation warning
- Key warning
- Intelligent Key insert information
- Engine start information
- Steering lock information
- Intelligent key low battery warning
- Key ID warning

OPERATION CONDITION

Once the following condition from below is established, alert or warning will be executed.

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM, "KEY" warning lamp will illuminate.
OFF position warning	For internal	<ul style="list-style-type: none"> • Ignition switch: ACC position. • Door switch (driver side): ON (Door is open).
	For external	<p>OFF position warning (For internal) is in active mode, driver side door has been closed.</p> <p>NOTE: OFF position (For external) active only when each of the sequence has occurred as below: P position warning → ACC warning → OFF position warning (For internal) → OFF position warning (For internal)</p>
P position warning		<ul style="list-style-type: none"> • Shift position: Except P position. • Engine is running to stopped (Ignition switch is ON to OFF).
ACC warning		<ul style="list-style-type: none"> • During P position warning is in active mode, shift position has changed P position. • Ignition switch: ACC position.
Take away warning	Door is open to close	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Door switch: ON to OFF (Door is open to close). • Intelligent Key can not be detected inside the vehicle.
	Door is open	<ul style="list-style-type: none"> • Door switch: ON (Door is open). • Key ID verification every 5 seconds when registered Intelligent Key can not be detected inside the vehicle.
	Push button-ignition switch operation	<ul style="list-style-type: none"> • Ignition switch: Except LOCK position. • Press push-button ignition switch. • Intelligent Key can not be detected inside the vehicle.
	Intelligent Key is removed from key slot	<ul style="list-style-type: none"> • When Intelligent Key is removed from key slot, Intelligent Key can not be detected inside the vehicle.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >



[INTELLIGENT KEY SYSTEM]

Warning/Information functions		Operation procedure
Door lock operation warning	Request switch operation	When request switch is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • All door is closed. • All door is unlocked. • Intelligent Key is inside vehicle.
	Intelligent Key button operation	When Intelligent Key button is pushed (lock operation) under the following conditions. <ul style="list-style-type: none"> • Door switch: ON (Any door is open). • For 3 seconds after Intelligent Key is removed from key slot.
Key warning		<ul style="list-style-type: none"> • Ignition switch is OFF position. • Driver side door switch: ON (Driver side door is open). • Intelligent Key is inserted in key slot.
Intelligent Key insert information		<ul style="list-style-type: none"> • Door switch: ON to OFF (Door is open to close). • Ignition switch: OFF to ON position. • Intelligent Key is out of key slot. • Intelligent Key can not be detected inside the vehicle.
Engine start information	Ignition switch is ON position	<ul style="list-style-type: none"> • Ignition switch: ON position. • Shift position: P position. • Engine is stopped.
	Ignition switch is except ON position	<ul style="list-style-type: none"> • Ignition switch: Except ON position. • Shift position: P position. • Intelligent Key is inserted in key slot or Intelligent Key can be detected inside the vehicle.
Steering lock information		When steering lock can not be released after ignition switch is turned ON.
Intelligent Key low battery warning		When Intelligent Key is low battery, BCM is detected after ignition switch is turned ON.
Key ID warning		When registered intelligent Key can not be detected inside the vehicle after ignition switch is turned ON.

WARNING METHOD

The following table shows the alarm or warning methods with chime.






Information display (combination meter), "KEY" indicator or key slot illumination when the warning conditions are met.

Warning/Information functions		"KEY" warning lamp	Information display (combination meter)	Key slot indicator	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction		Illuminate	—	—	—	—
OFF position warning	For internal	—	—	—	Activate	—
	For external	—	—	—	—	Activate
P position warning		—	 JMKIA0037GB	—	Activate	—
ACC warning		—	 JMKIA0047GB	—	—	—

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]



Warning/Information functions		“KEY” warn- ing lamp	Information display (combination meter)	Key slot in- dicator	Warning chime	
					Combination meter buzzer	Intelligent Key warning buzzer
Take away warning	Door is open to close	—		Blink	Activate	Activate
	Door is open	—		Blink	—	—
	Push-ignition switch operation	—		Blink	Activate	—
	Take away through window	—		Blink	Activate	—
	Intelligent Key is removed from key slot	—	JMKIA0036GB	Blink	—	—
Door lock operation warning	Request switch operation	—	—	—	—	Activate
	Intelligent Key operation	—	—	—	—	Activate
Key ID warning		—		—	—	—
			JMKIA0036GB			
Key warning		—		Blink	Activate	—
			JMKIA0035GB			
Intelligent Key insert information		—		Blink	—	—
			JMKIA0034GB			
Engine start information		—		—	—	—
			JMKIA0032GB			

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Warning/Information functions	“KEY” warning lamp	Information display (combination meter)	Key slot indicator	Warning chime	
				Combination meter buzzer	Intelligent Key warning buzzer
Steering lock information	—	 JMKIA0033GB	—	—	—
Intelligent Key low battery warning	—	 JMKIA0048GB	—	—	—

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Detention switch	“KEY” warning lamp
Intelligent Key system malfunction											×	×				×
OFF position warning	For internal				×					×	×	×				
	For external				×				×			×				
P position warning				×						×	×	×	×		×	
ACC warning				×						×	×	×	×		×	
Take away warning	Door is open or close	×			×		×		×	×	×	×	×	×		
	Door is open	×			×		×				×	×	×	×		
	Push-ignition switch operation	×		×			×			×	×	×	×	×		
	Intelligent Key is removed from key slot	×	×				×				×	×	×	×		
Door lock operation warning		×	×		×	×	×	×	×			×				
Key ID warning		×	×	×			×				×	×	×			
Key warning		×	×		×					×	×	×	×	×		
Intelligent Key insert information		×	×	×	×		×				×	×	×	×		
Engine start information	Ignition switch is ON position	×	×	×			×				×	×	×		×	
	Ignition switch is except ON position	×	×	×			×				×	×	×			

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Warning function	Intelligent Key	Key slot	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter warning buzzer	CAN communication system	BCM	Combination meter display	Key slot illumination	Detention switch	"KEY" warning lamp
Steering lock information			×							×	×	×			
Intelligent Key low battery warning	×					×				×	×	×			

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

WARNING FUNCTION : Component Parts Location

INFOID:000000004343386



1. BCM M118, M119, M120, M121, M122, M123
4. IPDM E/R E5, E6

2. Combination meter M53
5. Remote key less entry receiver M104

3. Key slot M22
6. A/T shift selector (detention switch) M137


JMKIA222ZZ

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

- | | | |
|--|--|---|
| 7. Front door switch (driver side) B16 | 8. Front door lock assembly (driver side) D15 | 9. Fuel lid lock actuator B242 |
| 10. Back door opener switch D114 | 11. Horn (high) E61, E62 | 12. Horn (low) E69, E70 |
| 13. Intelligent Key warning buzzer E57 | | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (RH) | C. Behind the instrument lower panel (driver side) |
| D. View with center console assembly removed | E. View with front door finisher (LH) is removed | F. View luggage side finisher lower (RH) is removed |
| G. View with front bumper is removed | | |



- | | | |
|--|--|---|
| 1. Push-button ignition switch (push switch) M50 | 2. Inside key antenna (instrument center) M131 | 3. Unified meter and A/C amp. M66, M67 |
| 4. Inside key antenna (console) M146 | 5. Inside key antenna (luggage room) B228 | 6. Front outside handle LH (request switch) D13 |
| 7. Front outside handle LH (outside key antenna) D14 | 8. Outside key antenna (back door) D118 | 9. Back door lock assembly D113 |

INTELLIGENT KEY SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

10. Back door opener request switch
D116


A. View with luggage floor finisher
front is removed

B. View with back door finisher inner is re-
moved

BACK DOOR OPENER SYSTEM

System Diagram

INFOID:0000000004672376



System Description

INFOID:0000000004672377

BACK DOOR OPENER OPERATION

When back door opener switch is pressed, BCM opens back door opener actuator.

NOTE:

Back door opener actuator is not for locking the back door. The function is only to open the back door.

OPERATION CONDITION

If the following conditions are satisfied, back door opener operation is performed.

Back door opener switch operation	Operation condition
Back door open	<ul style="list-style-type: none">• All door is unlocked.*• Vehicle speed is less than 5 km/h (3 MPH).

*: Except UNLOCK by door lock knob operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


BACK DOOR OPENER SYSTEM

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Component Parts Location

INFOID:000000004672378



- 1. BCM M118, M119, M120, M121, M122
- 2. Unified meter and A/C amp. M66, M67
- 3. Back door lock assembly D113
- 4. Back door opener switch D114
- A. Behind the center console

Component Description

INFOID:000000004672379

Item	Function
BCM	Controls the back door opener function.
Back door opener switch	Input back door opener switch operation signal to BCM.
Back door opener actuator	Opens the back door with the back door open signal from BCM.
Unified meter and A/C amp.	Transmits vehicle speed signal to BCM via CAN communication.

INTEGRATED HOMELINK TRANSMITTER

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

INTEGRATED HOMELINK TRANSMITTER

Component Description

INFOID:000000004343387

Item	Function
Homelink universal transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004343388

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT*1	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*2			
<ul style="list-style-type: none"> Intelligent Key system Engine start system 	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door opener system	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

NOTE:

- *1: At model with Intelligent Key system this item is displayed, but is not used.
- *2: This item is displayed, but is not used.

DIAGNOSIS SYSTEM (BCM)

[INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

DOOR LOCK

DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)

INFOID:000000004343389

BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Diagnosis mode	Function Description
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.

WORK SUPPORT

Monitor item	Description
DOOR LOCK-UNLOCK SET	Selective unlock function mode can be changed to operate (WITH) or not operate (WITHOUT) with this mode.
AUTOMATIC DOOR LOCK SELECT	Automatic door lock function mode can be selected from the following in this mode. <ul style="list-style-type: none"> VH SPD: All doors are locked when vehicle speed more than 24km/h (15MPH) P RANGE: All doors are locked when shifting the selector lever from P position to other than the P position
AUTOMATIC DOOR UNLOCK SELECT	Automatic door unlock function mode can be selected from the following in the mode. <ul style="list-style-type: none"> MODE 1: All doors are unlocked when the power supply position is changed from ON to OFF MODE 2: All doors are unlocked when shifting the selector lever from any position other than the P to P position MODE 3: Driver side door is unlocked when the power supply position is changed from ON to OFF MODE 4: Driver side door is unlocked when shifting the selector lever from any position other than the P to P position
AUTOMATIC LOCK/UNLOCK SET	Automatic door lock/unlock function mode can be selected from the following in this mode. <ul style="list-style-type: none"> Off: non-operational Unlock Only: door unlock operation only Lock Only: door lock operation only Lock/Unlock: lock/unlock operation

DATA MONITOR

Monitor Item	Contents
REQ SW-DR	Indicated [ON/OFF] condition of door request switch (driver side).
REQ SW-AS	Indicated [ON/OFF] condition of door request switch (passenger side).
REQ SW-BD/TR	Indicated [ON/OFF] condition of back door request switch.
DOOR SW-DR	Indicated [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicated [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicated [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicated [ON/OFF] condition of rear door switch LH.
DOOR SW-BK	Indicated [ON/OFF] condition of back door switch.
CDL LOCK SW	Indicated [ON/OFF] condition of lock signal from door lock unlock switch.
CDL UNLOCK SW	Indicated [ON/OFF] condition of unlock signal from door lock unlock switch.
KEY CYL LK-SW	Indicated [ON/OFF] condition of lock signal from door key cylinder.
KEY CYL UN-SW	Indicated [ON/OFF] condition of unlock signal from door key cylinder.

ACTIVE TEST

Test item	Description
DOOR LOCK	<p>This test is able to check door lock/unlock operation.</p> <ul style="list-style-type: none"> The all door lock actuators are locked when "ALL LCK" on CONSULT-III screen is touched. The all door lock actuators are unlocked when "ALL UNLK" on CONSULT-III screen is touched. The door lock actuator (driver side) is unlocked when "DR UNLK" on CONSULT-III screen is touched. The door lock actuator (passenger side) is unlocked when "AS UNLK" on CONSULT- III screen is touched. The door lock actuator (rear LH and RH) is unlocked when "OTR ULK" on CONSULT-III screen is touched.

INTELLIGENT KEY

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY) INFOID:000000004343390

WORK SUPPORT

Monitor item	Description
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode.
AUTO LOCK SET	Auto door lock time can be changed in this mode. <ul style="list-style-type: none"> • MODE 1: 1 minute • MODE 2: 5 minutes • MODE 3: 30 seconds • MODE 4: 2 minutes
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch (driver side, passenger side and back door) mode can be changed to operate (ON) or not operate (OFF) in this mode.
ENGINE START BY I-KEY	Engine start function mode can be changed to operate (ON) or not operate (OFF) with this mode.
TRUNK/GLASS HATCH OPEN	Buzzer reminder function mode by back door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
PANIC ALARM SET	Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE 1: 0.5 sec. • MODE 2: Non-operation • MODE 3: 1.5 sec.
PW DOWN SET	Unlock button pressing time on Intelligent Key button can be selected from the following with this mode. <ul style="list-style-type: none"> • MODE 1: 3 sec. • MODE 2: Non-operation • MODE 3: 5 sec.
TAKE OUT FROM WIN WARN	NOTE: This item is displayed, but cannot be supported.
TRUNK OPEN DELAY	NOTE: This item is displayed, but cannot be supported.
LO- BATT OF KEY FOB WARN	Intelligent Key low battery warning mode can be changed to operate (ON) or not operate (OFF) with this mode.
ANTI KEY LOCK IN FUNCTI	Key reminder function mode can be changed to operate (ON) or not operate (OFF) with this mode.
HAZARD ANSWER BACK	Hazard reminder function mode can be selected from the following with this mode. <ul style="list-style-type: none"> • LOCK ONLY: Door lock operation only • UNLOCK ONLY: Door unlock operation only • LOCK/UNLOCK: Lock/unlock operation • OFF: Non-operation
ANS BACK I-KEY LOCK	Buzzer reminder function (lock operation) mode by door request switch (driver side and passenger side) can be selected from the following with this mode. <ul style="list-style-type: none"> • Horn chirp: Sound horn • Buzzer: Sound Intelligent Key warning buzzer • OFF: Non-operation
ANS BACK I-KEY UNLOCK	Buzzer reminder function (unlock operation) mode by door request switch can be changed to operate (ON) or not operate (OFF) with this mode.
SHORT CRANKING OUTPUT	Starter motor can operate during the times below. <ul style="list-style-type: none"> • 70 msec. • 100 msec. • 200 msec.
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis.
HORN WITH KEYLESS LOCK	Horn reminder function mode by Intelligent Key button can be changed to operate (ON) or not operate (OFF) with this mode.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Monitor item	Description
WELCOME LIGHT OP SET	Welcome light function mode can be changed to operate (WITH) or not operate (WITHOUT) with this mode.
WELCOME LIGHT SELECT	Welcome light function mode can be selected from the following with this mode. <ul style="list-style-type: none"> • Without room lamp • With room lamp • Without paddle lamp • With paddle lamp

SELF-DIAG RESULT

Refer to [DLK-167. "DTC Index"](#).

DATA MONITOR

Monitor Item	Condition
REQ SW -DR	Indicates [ON/OFF] condition of door request switch (driver side).
REQ SW -AS	Indicates [ON/OFF] condition of door request switch (passenger side).
REQ SW -RR	NOTE: This item is displayed, but cannot be monitored.
REQ SW -RL	NOTE: This item is displayed, but cannot be monitored.
REQ SW -BD/TR	Indicates [ON/OFF] condition of back door request switch.
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY2 -F/B	Indicates [ON/OFF] condition of ignition relay 2.
CLUCH SW	NOTE: This item is displayed, but cannot be monitored.
BRAKE SW 1	Indicates [ON/OFF] condition of brake switch power supply.
BRAKE SW 2	Indicates [ON/OFF] condition of brake switch.
DETE/CANCL SW	Indicates [ON/OFF] condition of P position.
SFT PN/N SW	Indicates [ON/OFF] condition of P or N position.
S/L -LOCK	Indicates [ON/OFF] condition of steering lock unit (LOCK).
S/L -UNLOCK	Indicates [ON/OFF] condition of steering lock unit (UNLOCK).
S/L RELAY -F/B	Indicates [ON/OFF] condition of ignition switch.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
PUSH SW -IPDM	Indicates [ON/OFF] condition of push-button ignition switch.
IGN RLY1 -F/B	Indicates [ON/OFF] condition of ignition relay 1.
DETE SW -IPDM	Indicates [ON/OFF] condition of P position.
SFT PN -IPDM	Indicates [ON/OFF] condition of P or N position.
SFT P -MET	Indicates [ON/OFF] condition of P position.
SFT N -MET	Indicates [ON/OFF] condition of N position.
ENGINE STATE	Indicates [STOP/START/CRANK/RUN] condition of engine states.
S/L LOCK-IPDM	Indicates [ON/OFF] condition of steering lock unit (LOCK).
S/L UNLK-IPDM	Indicates [ON/OFF] condition of steering lock unit (UNLOCK).
S/L RELAY-REQ	Indicates [ON/OFF] condition of steering lock relay.
VEH SPEED 1	Display the vehicle speed signal received from unified meter and A/C amp. by numerical value [Km/h].
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or CVT by numerical value [Km/h].
DOOR STAT-DR	Indicates [LOCK/READY/UNLOCK] condition of driver side door status.
DOOR STAT-AS	Indicates [LOCK/READY/UNLOCK] condition of passenger side door status.
ID OK FLAG	Indicates [SET/RESET] condition of key ID.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Monitor Item	Condition
PRMT ENG STRT	Indicates [SET/RESET] condition of engine start possibility.
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored.
KEY SW -SLOT	Indicates [ON/OFF] condition of key slot.
TRNK/HAT MNTR	NOTE: This item is displayed, but cannot be monitored.
RKE-LOCK	Indicates [ON/OFF] condition of LOCK signal from Intelligent Key.
RKE-UNLOCK	Indicates [ON/OFF] condition of UNLOCK signal from Intelligent Key.
RKE-TR/BD	NOTE: This item is displayed, but cannot be monitored.
RKE-PANIC	Indicates [ON/OFF] condition of PANIC button of Intelligent Key.
RKE-P/W OPEN	Indicates [ON/OFF] condition of P/W DOWN signal from Intelligent Key.
RKE-MODE CHG	Indicates [ON/OFF] condition of MODE CHANGE signal from Intelligent Key.
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored.

ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check interior room lamp operation. The interior room lamp will be activated after "ON" on CONSULT-III screen is touched.
PW REMOTO DOWN SET	This test is able to check power window down operation. The power window down will be activated after "ON" on CONSULT-III screen is touched.
INSIDE BUZZER	This test is able to check warning chime in combination meter operation. <ul style="list-style-type: none"> Take away warning chime sounds when "TAKE OUT" on CONSULT-III screen is touched. Key warning chime sounds when "KEY WARN" on CONSULT-III screen is touched. P position warning chime sounds when "P RNG WARN" on CONSULT-III screen is touched. ACC warning chime sounds when "ACC WARN" on CONSULT-III screen is touched.
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation. The Intelligent Key warning buzzer will be activated after "ON" on CONSULT-III screen is touched.
INDICATOR	This test is able to check warning lamp operation. <ul style="list-style-type: none"> "KEY" Warning lamp illuminates when "KEY ON" on CONSULT-III screen is touched. "KEY" Warning lamp flashes when "KEY IND" on CONSULT-III screen is touched.
INT LAMP	This test is able to check interior room lamp operation. The interior room lamp will be activated after "ON" on CONSULT-III screen is touched.
LCD	This test is able to check meter display information <ul style="list-style-type: none"> Engine start information displays when "BP N" on CONSULT-III screen is touched. Engine start information displays when "BP I" on CONSULT-III screen is touched. Key ID warning displays when "ID NG" on CONSULT-III screen is touched. Steering lock information displays when "ROTAT" on CONSULT-III screen is touched. P position warning displays when "SFT P" on CONSULT-III screen is touched. Intelligent Key insert information displays when "INSRT" on CONSULT-III screen is touched. Intelligent Key low battery warning displays when "BATT" on CONSULT-III screen is touched. Take away through window warning displays when "NO KY" on CONSULT-III screen is touched. Take away warning display when "OUTKY" on CONSULT-III screen is touched. OFF position warning display when "LK WN" on CONSULT-III screen is touched.
TRUNK/GLASS HATCH	This test is able to check back door opener actuator open operation. This actuator opens when "ON" on CONSULT-III screen is touched.
FLASHER	This test is able to check hazard warning lamp operation. The hazard warning lamps will be activated after "ON" on CONSULT-III screen is touched.
HORN	This test is able to check horn operation. The horn will be activated after "ON" on CONSULT-III screen is touched.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[INTELLIGENT KEY SYSTEM]

Test item	Description
P RANGE	This test is able to check A/T shift selector power supply A/T shift selector power is supplied when "ON" on CONSULT-III screen is touched.
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation. Push-ignition switch illumination illuminates when "ON" on CONSULT-III screen is touched.
LOCK INDICATOR	This test is able to check LOCK indicator in push-ignition switch operation. LOCK indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched;
ACC INDICATOR	This test is able to check ACC indicator in push-ignition switch operation. Indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.
IGNITION ON IND	This test is able to check ON indicator in push-ignition switch operation. Indicator in push-ignition switch illuminates when "ON" on CONSULT-III screen is touched.
KEY SLOT ILLUMI	This test is able to check key slot illumination operation. Key slot illumination flash when "ON" on CONSULT-III screen is touched.
TRUNK/BACK DOOR	NOTE: This item is displayed, but cannot be tested.

TRUNK

TRUNK : CONSULT-III Function (BCM - TRUNK)

INFOID:000000004343391

BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.

DATA MONITOR

Monitor Item	Contents
PUSH SW	Indicates [ON/OFF] condition of push-button ignition switch.
UNLK SEN -DR	Indicates [ON/OFF] condition of driver door UNLOCK status.
VEH SPEED 1	Indicates [Km/h] condition of vehicle speed signal from combination meter.
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored.
TR CANCEL SW	NOTE: This item is displayed, but cannot be monitored.
TR/BD OPEN SW	Indicates [ON/OFF] condition of back door opener switch.
TRNK/HAT MNTR	NOTE: This item is displayed, but cannot be monitored.
RKE-TR/BD*	NOTE: This item is displayed, but cannot be monitored.

ACTIVE TEST

Test item	Description
TRUNK/GLASS HATCH	This test is able to check back door opener actuator open operation. This actuator opens when ""

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000004343392

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-26, "CAN System Specification Chart"](#).

DTC Logic

INFOID:0000000004343393

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detection condition	Possible cause
U1000	CAN COMM CIRCUIT	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:0000000004343394

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-40, "Intermittent Incident"](#).

DLK

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:0000000004343395

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detection condition	Possible cause
U1010	CONTROL UNIT (CAN)	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:0000000004343396

1.REPLACE BCM

When DTC [U1010] is detected, replace BCM.

>> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#)

Special Repair Requirement

INFOID:0000000004343397

1.REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to CONSULT-III operation manual NATS-IVIS/NVIS.

>> Work end.

B2621 INSIDE KEY ANTENNA 1

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

B2621 INSIDE KEY ANTENNA 1

Description

INFOID:0000000004343398

- Detects whether Intelligent Key is inside the vehicle.
- Installed in the instrument center.

DTC Logic

INFOID:0000000004343399

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2621	INSIDE ANTENNA 1 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none">• Inside key antenna (instrument center)• Between BCM and Inside key antenna (instrument center)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is inside key antenna DTC detected?



- YES >> Refer to [DLK-59, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (instrument center) is OK.

Diagnosis Procedure

INFOID:0000000004343400

1.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM					
Connector	Terminal				
Instrument center	M122	78, 79	Ground	Place Intelligent Key inside the vehicle.	
				Place Intelligent Key outside the vehicle.	

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 2.

2.CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM and inside key antenna connector.

A

B

C

D

E

F

G

H

I

J

L

M

N

O

P

DLK

B2621 INSIDE KEY ANTENNA 1

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

2. Check continuity between BCM harness connector and inside key antenna (instrument center) harness connector.

BCM		Inside key antenna (instrument center)		Continuity
Connector	Terminal	Connector	Terminal	
M122	78	M131	2	Existed
	79		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	78		Not existed
	79		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (instrument center). (New antenna or other antenna)
2. Connect BCM and inside key antenna (instrument center) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
Instrument center M122	78, 79	Ground	Place Intelligent Key inside the vehicle.	 JMKIA0062GB
			Place Intelligent Key outside the vehicle.	 JMKIA0063GB

Is the inspection result normal?

YES >> Replace inside key antenna (instrument center). Refer to [DLK-262, "INSTRUMENT CENTER : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

B2622 INSIDE KEY ANTENNA 2

Description

INFOID:000000004343401

- Detects whether Intelligent Key is inside the vehicle.
- Installed in the console.

DTC Logic

INFOID:000000004343402

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none"> • Inside key antenna (console) • Between BCM ~ Inside key antenna (console)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is inside key antenna DTC detected?



- YES >> Refer to [DLK-61, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (console) is OK.

Diagnosis Procedure

INFOID:000000004343403

1.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM					
Connector		Terminal			
Console	M122	72, 73	Ground	Place Intelligent Key inside the vehicle.	 <p>JMKIA0062GB</p>
				Place Intelligent Key outside the vehicle.	 <p>JMKIA0063GB</p>

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 2.

2.CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM and inside key antenna (console) connector.
2. Check continuity between BCM harness connector and inside key antenna harness connector.

B2622 INSIDE KEY ANTENNA 2

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BCM		Inside key antenna (console)		Continuity
Connector	Terminal	Connector	Terminal	
M122	72	M146	2	Existed
	73		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	72		Not existed
	73		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (console). (New antenna or other antenna)
2. Connect BCM and inside key antenna (console) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+) BCM			(-)	Condition	Signal (Reference value)
Connector	Terminal				
Console	M122	72, 73	Ground	Place Intelligent Key inside the vehicle.	 <p style="text-align: right;">JMKIA0062GB</p>
				Place Intelligent Key outside the vehicle.	 <p style="text-align: right;">JMKIA0063GB</p>

Is the inspection result normal?

YES >> Replace inside key antenna (console). Refer to [DLK-262, "CONSOLE : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

B2623 INSIDE KEY ANTENNA 3

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

B2623 INSIDE KEY ANTENNA 3

Description

INFOID:000000004343404

Detects whether Intelligent Key is inside the vehicle.
Installed in the luggage room.

DTC Logic

INFOID:000000004343405

DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3 CIRCUIT	An excessive high or low voltage from inside antenna is sent to BCM.	<ul style="list-style-type: none">Inside key antenna (luggage room)Between BCM ~ Inside key antenna (luggage room)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "Work Support" of "INTELLIGENT KEY".
2. Perform "INTELLIGENT KEY" Self Diagnostic Result.

Is inside key antenna DTC detected?



- YES >> Refer to [DLK-63, "Diagnosis Procedure"](#).
NO >> Inside key antenna (luggage room) is OK.

Diagnosis Procedure

INFOID:000000004343406

1.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
Luggage room	M121	34, 35	Ground	 JMKIA0062GB
			Place Intelligent Key outside the vehicle.	 JMKIA0063GB

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 2.

2.CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM and inside key antenna (luggage room) connector.

B2623 INSIDE KEY ANTENNA 3

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

2. Check continuity between BCM harness connector and inside key antenna (luggage room) harness connector.

BCM		Inside key antenna		Continuity
Connector	Terminal	Connector	Terminal	
M121	34	B228	2	Existed
	35		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	34		Not existed
	35		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (luggage room). (New antenna or other antenna)
2. Connect BCM and inside key antenna (luggage room) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+) BCM			(-)	Condition	Signal (Reference value)
Connector	Terminal				
Luggage room	M121	34, 35	Ground	Place Intelligent Key inside the vehicle.	 JMKIA0062GB
				Place Intelligent Key outside the vehicle.	 JMKIA0063GB

Is the inspection result normal?

YES >> Replace inside key antenna (luggage room). Refer to [DLK-263, "LUGGAGE ROOM : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER SUPPLY AND GROUND CIRCUIT

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000004343407

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not fusing.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	K (40 A)
11		10 (10 A)

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (Approx.)
BCM			
Connector	Terminal		
M118	1	Ground	Battery voltage
M119	11		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

DOOR SWITCH

Description

INFOID:000000004343408

Detects door open/close condition.

Component Function Check

INFOID:000000004343409

1.CHECK FUNCTION

With CONSULT-III

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR" and "DOOR SW-BK") in Data Monitor" mode with CONSULT-III.

Monitor item	Condition
DOOR SW-DR	CLOSE → OPEN: OFF → ON
DOOR SW-AS	
DOOR SW-RL	
DOOR SW-RR	
DOOR SW-BK	

Is the inspection result normal?

- YES >> Door switch is OK.
NO >> Refer to [DLK-66. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343410






1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground with oscilloscope.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

(+)			(-)	Signal (Reference value)
Door switch				
Connector	Terminal			
Driver side	B16	2	Ground	 JPMIA0011GB
Passenger side	B216	2		 JPMIA0011GB
Rear LH	B23	2		 JPMIA0011GB
Rear RH	B223	2		 JPMIA0011GB
Back door	D113	3		 JPMIA0011GB

Is the inspection result normal?

YES-1 >> Back door: GO TO 3.

YES-2 >> Other doors: GO TO 4.

NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and door switch harness connector.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BCM		Door switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	150	B16 (Driver side)	2	Existed
	124	B216 (Passenger side)		
M121	69	B23 (Rear LH)		
	68	B223 (Rear RH)		
	66	D113 (Back door)	3	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Not existed
M123	150 (Driver side)		
	124 (Passenger side)		
M121	69 (Rear LH)		
	68 (Rear RH)		
	66 (Back door)		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly (back door switch) harness connector and ground.

Back door lock assembly (back door switch)		Ground	Continuity
Connector	Terminal		Existed
D113	4		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR SWITCH

Refer to [DLK-68, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning door switch.

- Door switch: Refer to [DLK-261, "Removal and Installation"](#).

- Back door lock assembly (back door switch): Refer to [DLK-259, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004343411

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door switch connector.
3. Check door switch terminals.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Door switch			Condition		Continuity
Terminal					
Each door	2	Ground part of door switch	Door switch	Pressed	Not existed
				Released	Existed
Back door	3	4		Pressed	Not existed
				Released	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> Replace malfunction door switch. Refer to [DLK-261, "Removal and Installation"](#).

NO-2 >> Replace back door lock assembly. Refer to [DLK-259, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

DOOR LOCK AND UNLOCK SWITCH

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004343412

Transmits door lock/unlock operation to BCM.

DRIVER SIDE : Component Function Check

INFOID:000000004343413

1.CHECK FUNCTION

With CONSULT-III

Check ("CDL LOCK SW ", "CDL UNLOCK SW") in Data Monitor mode with CONSULT-III.

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-70, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004343414

1.CHECK POWER WINDOW SWITCH

1. Turn ignition switch ON.
2. Check power window operation.

Does power window (driver side) operate?

YES >> Replace power window main switch.

NO >> Refer to [PWC-90, "Diagnosis Procedure"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004343415

Transmits door lock/unlock operation to BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000004343416

1.CHECK FUNCTION

With CONSULT-III

Check ("CDL LOCK SW ", "CDL UNLOCK SW") in Data Monitor mode with CONSULT-III.

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-70, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004343417

1.CHECK POWER WINDOW SWITCH

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

1. Turn ignition switch ON.
2. Check passenger side power window operation.

Does power window (passenger side) operate?

YES >> Replace power window switch (passenger side)

NO >> Refer to [PWC-92, "WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR LOCK ACTUATOR

[INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:00000000434318

Locks/unlocks the door with the signal from BCM.

DRIVER SIDE : Component Function Check

INFOID:00000000434319

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-72, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:00000000434320

1.CHECK OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check voltage between front door lock assembly (driver side) harness connector and ground.

(+) Front door lock assembly (driver side)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
D15	1	Ground	Door lock and unlock switch	Lock	0 → Battery voltage → 0
	2			Unlock	0 → Battery voltage → 0

Is the inspection result normal?

YES >> Replace front door lock assembly (driver side). Refer to [DLK-227, "DOOR ASSEMBLY : Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

BCM		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M119	8	D15	1	Existed
	9		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	8		Not existed
	9		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

PASSENGER SIDE : Description

INFOID:000000004343421

Locks/unlocks the door with the signal from BCM.

PASSENGER SIDE : Component Function Check

INFOID:000000004343422

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
NO >> Refer to [DLK-73. "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004343423

1.CHECK DOOR LOCK ACTUATOR SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (passenger side).
3. Check voltage between front door lock assembly (passenger side) harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
Front door lock assembly (passenger side)					
Connector	Terminal				
D45	1	Ground	Door lock and unlock switch	Unlock	0 → Battery voltage → 0
	2			Lock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> Replace front door lock assembly (passenger side). Refer to [DLK-227. "DOOR ASSEMBLY : Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (passenger side) harness connector.

BCM		Front door lock assembly (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M119	5	D45	1	Existed
	8		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	5		Not existed
	8		

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR LH

REAR LH : Description

INFOID:000000004343424

Locks/unlocks the door with the signal from BCM.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

REAR LH : Component Function Check

INFOID:000000004343425

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
NO >> Refer to [DLK-74, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000004343426

1.CHECK DOOR LOCK ACTUATOR SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear door lock assembly LH.
3. Check voltage between rear door lock assembly LH harness connector and ground.

(+) Rear door lock assembly LH		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal				
D55	1	Ground	Door lock and unlock switch	Lock	0 → Battery voltage → 0
	2			Unlock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> Replace rear door lock assembly LH. Refer to [DLK-232, "DOOR ASSEMBLY : Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rear door lock assembly LH harness connector.

BCM		Rear door lock assembly LH		Continuity
Connector	Terminal	Connector	Terminal	
M119	8	D55	1	Existed
	10		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	8		Not existed
	10		

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR RH

REAR RH : Description

INFOID:000000004343427

Locks/unlocks the door with the signal from BCM.

REAR RH : Component Function Check

INFOID:000000004343428

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").

DOOR LOCK ACTUATOR

[INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

2. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

- YES >> Door lock actuator is OK.
NO >> Refer to [DLK-75. "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000004343429

1. CHECK DOOR LOCK ACTUATOR SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear door lock assembly RH.
3. Check voltage between rear door lock assembly RH harness connector and ground.

(+) (Rear door lock assembly RH)		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal				
D75	1	Ground	Door lock and unlock switch	Unlock	0 → Battery voltage → 0
	2			Lock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> Replace rear door lock assembly RH. Refer to [DLK-232. "DOOR ASSEMBLY : Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rear door lock assembly RH harness connector.

BCM		Rear door lock assembly RH		Continuity
Connector	Terminal	Connector	Terminal	
M119	8	D75	2	Existed
	10		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	8		Not Existed
	10		

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
NO >> Repair or replace harness.

FUEL LID LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

FUEL LID LOCK ACTUATOR

Description

INFOID:000000004343430

Locks/unlocks the fuel filler lid with the signal from BCM.

Component Function Check

INFOID:000000004343431

1.CHECK FUNCTION

1. Use CONSULT-III to perform Active Test ("DOOR LOCK").
2. Touch "ALL LOCK" or "ALL UNLOCK" to check that it works normally.

Is the inspection result normal?

- YES >> Fuel lid lock actuator is OK.
NO >> Refer to [DLK-76. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343432

1.CHECK FUEL LID LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect fuel lid lock actuator connector.
3. Check voltage between fuel lid lock actuator harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
Fuel lid lock actuator					
Connector	Terminal				
B242	1	Ground	Door lock and unlock switch	Unlock	0 → Battery voltage → 0
	2			Lock	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> Replace fuel lid lock actuator. Refer to [DLK-260. "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK FUEL LID LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and fuel lid lock actuator harness connector.

BCM		Fuel lid lock actuator		Continuity
Connector	Terminal	Connector	Terminal	
M119	8	B242	2	Existed
	9		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	8		Not existed
	9		

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
NO >> Repair or replace harness.

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BACK DOOR OPENER ACTUATOR

Description

INFOID:0000000004343433

Back door opener actuator open back door from BCM.

Component Function Check

INFOID:0000000004343434

1.CHECK FUNCTION

1. Perform Active Test ("TRUNK/GLASS HATCH") with CONSULT-III.
2. Touch "OPEN" and check that back door opens.

Is the inspection result normal?

- YES >> Back door opener actuator is OK.
NO >> Refer to [DLK-77. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343435

1.CHECK OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly.
3. Check voltage between back door lock assembly harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
Back door lock assembly					
Connector	Terminal				
D113	1	Ground	Back door opener switch	ON	0 → Battery voltage → 0

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR OPENER ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door lock assembly (back door opener actuator) harness connector.

BCM		Back door lock assembly		Continuity
Connector	Terminal	Connector	Terminal	
M120	23	D113	1	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	23		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER ACTUATOR GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Back door lock assembly		Ground	Continuity
Connector	Terminal		
D113	2		Existed

Is the inspection normal?

- YES >> Replace back door lock assembly. Refer to [DLK-259, "Removal and Installation"](#)
NO >> Repair or replace harness.

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY CYLINDER SWITCH

Description

INFOID:00000000434336

Power window main switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signals.

Component Function Check

INFOID:00000000434337

1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check ("KEY CYL LK-SW", "KEY CYL UN-SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

- YES >> Key cylinder switch is OK.
NO >> Refer to [DLK-79, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:00000000434338

1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect front door lock assembly (driver side).
- Check voltage between front door lock assembly (driver side) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Front door lock assembly (driver side)			
Connector	Terminal		
D15	5	Ground	5
	6		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT

- Disconnect power window main switch connector.
- Check continuity between power window main switch harness connector and front door lock assembly (driver side) harness connector.

Power window main switch		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	4	D15	6	Existed
	6		5	

- Check continuity between power window main switch harness connector and ground.

KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	4		Not existed
	6		

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-104, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

Front door lock assembly (driver side)		Ground	Continuity
Connector	Terminal		
D15	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-80, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side). Refer to [DLK-227, "DOOR ASSEMBLY : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:0000000043439

1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) terminals.
3. Check front door lock assembly (driver side) terminals.

Front door lock assembly (driver side)		Key position	Continuity
Terminal			
5	4	Unlock	Existed
		Neutral / Lock	Not existed
6		Lock	Existed
		Neutral / Unlock	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side). Refer to [DLK-227, "DOOR ASSEMBLY : Removal and Installation"](#).

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

REMOTE KEYLESS ENTRY RECEIVER

Description

INFOID:000000004343440

Receives Intelligent Key operation and transmits to BCM.

Component Function Check

INFOID:000000004343441

1.CHECK FUNCTION

With CONSULT-III

Check remote keyless entry receiver ("RKE OPE COUN1") in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating Intelligent Key.

Is the inspection result normal?

YES >> Remote keyless entry receiver is OK.



NO >> Refer to [DLK-81, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343442

1.CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

- Turn ignition switch OFF.
- Check signal between remote keyless entry receiver harness connector and ground with oscilloscope.

(+) Remote keyless entry receiver		(-)	Condition	Signal (Reference value)
Connector	Terminal			
M104	2	Ground	During waiting	 JMKIA0064GB
			When operating either button on the Intelligent Key	 JMKIA0065GB

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 1

- Disconnect BCM connector and remote keyless entry receiver connector.
- Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M122	83	M104	2	Existed

- Check continuity between BCM harness connector and ground.

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M122	83		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Disconnect remote keyless entry receiver.
2. Check voltage between remote keyless entry receiver harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Remote keyless entry receiver			
Connector	Terminal		
M104	4	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 2

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M122	103	M104	4	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	103		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

Check continuity between remote keyless entry receiver harness connector and ground.

Remote keyless entry receiver		Ground	Continuity
Connector	Terminal		
M104	1		Existed

Is the inspection result normal?

YES >> Replace remote keyless entry receiver. Refer to [DLK-267, "Removal and Installation"](#).

NO >> GO TO 6.

6.CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 3

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M123	137	M104	1	Existed

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BACK DOOR OPENER SWITCH

Description

INFOID:000000004343443

Output back door open signal to BCM.

Component Function Check

INFOID:000000004343444

1.CHECK FUNCTION

Check back door opener switch ("TR/BD OPEN SW") in "Data Monitor mode with CONSULT-III.

Monitor item	Condition
TR/BD OPEN SW	Back door opener switch is pressed: ON
	Back door opener switch is released: OFF

Is the inspection result normal?


- YES >> Back door opener switch is OK.
NO >> Refer to [DLK-84, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343445

1.CHECK BACK DOOR OPEN INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect back door opener switch connector.
- Check signal between back door opener switch harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D114	1	Ground	 JPMIA0011GB

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR OPENER SWITCH CIRCUIT

- Disconnect BCM connector.
- Check continuity between BCM harness connector and back door opener switch assembly harness connector.

BCM		Back door opener switch		Continuity
Connector	Terminal	Connector	Terminal	
M121	67	D114	1	Existed

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	67		Not existed

Is the inspection result normal?

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER SWITCH GROUND CIRCUIT

Check continuity between back door opener switch harness connector and ground.

Back door opener switch		Ground	Continuity
Connector	Terminal		
D114	2		Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK BACK DOOR OPENER SWITCH

Refer to [DLK-85. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace back door opener switch. Refer to [EXT-48. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004343446

1.CHECK BACK DOOR OPENER SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door opener switch connector.
3. Check continuity between back door opener switch terminals.

Back door opener switch		Condition		Continuity
Terminal				
1	2	Back door opener switch	Pressed	Existed
			Released	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace back door opener switch. Refer to [EXT-48. "Removal and Installation"](#).

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

DOOR REQUEST SWITCH

Description

INFOID:000000004343447

Transmits lock/unlock operation to BCM.

Component Function Check

INFOID:000000004343448

1.CHECK FUNCTION

Check door request switch ("REQ SW -DR" or "REQ SW -AS") in Data Monitor mode.

Monitor item	Condition
REQ SW -DR REQ SW -AS	Door request switch is pressed: ON
	Door request switch is released: OFF

Is the inspection result normal?


- YES >> Door request switch is OK.
NO >> Refer to [DLK-86, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343449

1.CHECK BCM OUTPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect malfunctioning front outside handle (request switch) connector.
- Check signal between malfunctioning front outside handle (request switch) harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Front outside handle (request switch)			
Connector	Terminal		
LH	D13	Ground	
RH	D43		

JPMIA0016GB

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR REQUEST SWITCH CIRCUIT

- Disconnect BCM connector.
- Check continuity between BCM harness connector and malfunctioning front outside handle (request switch) harness connector.

BCM		Front outside handle (request switch)		Continuity
Connector	Terminal	Connector	Terminal	
M122	101	LH	D13	Existed
	100	RH	D43	

- Check continuity between BCM harness connector and ground.

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M122	101		Not existed
	100		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between malfunctioning front outside handle (request switch) harness connector and ground.

Front outside handle (request switch)			Ground	Continuity
Connector		Terminal		
LH	D13	2		Existed
RH	D43			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR REQUEST SWITCH

Refer to [DLK-87, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning front outside handle (request switch). Refer to [DLK-251, "OUTSIDE HAN-DLE : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004343450

DLK

1.CHECK DOOR REQUEST SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning front outside handle (request switch) connector.
3. Check continuity between malfunctioning front outside handle (request switch) terminals.

Front outside handle (request switch)		Condition		Continuity
Terminal				
1	2	Door request switch	Pressed	Existed
			Released	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning front outside handle (request switch). Refer to [DLK-251, "OUTSIDE HAN-DLE : Removal and Installation"](#).

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BACK DOOR REQUEST SWITCH

Description

INFOID:000000004343451

Transmits lock/unlock operation to BCM.

Component Function Check

INFOID:000000004343452

1.CHECK FUNCTION

Check back door opener request switch ("REQ SW -BD/TR ") in Data Monitor mode.

Monitor item	Condition
REQ SW -BD/TR	Back door opener request switch is pressed: ON
	Back door opener request switch is released: OFF

Is the inspection result normal?


- YES >> Back door opener request switch is OK.
NO >> Refer to [DLK-88, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343453

1.CHECK BCM OUTPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect back door opener request switch connector.
- Check signal between back door opener request switch harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Back door opener request switch Connector	Terminal		
D116	1	Ground	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR OPENER REQUEST SWITCH CIRCUIT

- Disconnect BCM connector.
- Check continuity between BCM harness connector and back door opener request switch harness connector.

BCM		Back door opener request switch		Continuity
Connector	Terminal	Connector	Terminal	
M121	61	D116	1	Existed

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	61		Not existed

Is the inspection result normal?

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

YES >> Replace BCM. Refer to [BCS-85. "Exploded View"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER REQUEST SWITCH GROUND CIRCUIT

Check continuity between back door opener request switch harness connector and ground.

Back door opener request switch		Ground	Continuity
Connector	Terminal		
D116	2		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR OPENER REQUEST SWITCH

Refer to [DLK-89. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener request switch. Refer to [EXT-48. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004343454

1.CHECK BACK DOOR OPENER REQUEST SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door opener request switch connector.
3. Check continuity between back door opener request switch assembly terminals.

Back door opener request switch		Condition		Continuity
Terminal				
1	2	Back door opener request switch	Pressed	Existed
			Released	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door opener request switch. Refer to [EXT-48. "Removal and Installation"](#).

DLK

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

UNLOCK SENSOR

Description

INFOID:000000004343455

Detects door lock condition of driver door.

Component Function Check

INFOID:000000004343456

1.CHECK FUNCTION

Check unlock sensor ("UNLK SEN -DR") in "Data Monitor" mode.

Monitor item	Condition
UNLK SEN -DR	Front door lock (driver side) LOCK: OFF
	Front door lock (driver side) UNLOCK: ON

Is the inspection result normal?

YES >> Unlock sensor is OK.


NO >> Refer to [DLK-90, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343457

1.CHECK BCM OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check signal between front door lock assembly (driver side) harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Front door lock assembly (driver side)			
Connector	Terminal		
D15	3	Ground	 JPMA0012GB

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK UNLOCK SENSOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

BCM		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M123	119	D15	3	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	119		Not existed

UNLOCK SENSOR

[INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

Front door lock assembly (driver side)		Ground	Continuity
Connector	Terminal		
D15	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK UNLOCK SENSOR

Refer to [DLK-91, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side). Refer to [DLK-248, "DOOR LOCK : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:0000000004343458

1.CHECK UNLOCK SENSOR

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check front door lock assembly (driver side) terminals.

Front door lock assembly (driver side)		Condition		Continuity
Terminal				
3	4	Front door lock assembly (driver side)	Unlock	Existed
			Lock	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front lock assembly (driver side). Refer to [DLK-248, "DOOR LOCK : Removal and Installation"](#).

OUTSIDE KEY ANTENNA

Description

INFOID:000000004343459

- Detects whether Intelligent Key is outside the vehicle.
- Integrated in front outside handle (driver side, passenger side) and installed in rear bumper.

Component Function Check

INFOID:000000004343460

1.CHECK DOOR REQUEST SWITCH

Check door request switch. Refer to [DLK-86, "Component Function Check"](#) (front door) or [DLK-88, "Component Function Check"](#) (back door).

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Check front door opener request switch. Refer to [DLK-86, "Component Function Check"](#).

NO-2 >> Check back door request switches. Refer to [DLK-88, "Component Function Check"](#).

2.CHECK FUNCTION

Be sure that Intelligent Key is in each outside key antenna detection area.

Does door lock/unlock when each request switch is pressed?

YES >> Outside key antenna is OK.



NO >> Refer to [DLK-92, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343461

1.CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+) BCM			(-)	Condition		Signal (Reference value)
Connector	Terminal					
M122	RH	74, 75	Ground	Request switch is pushed	When Intelligent Key is in the antenna de- tection area.	 <p>JMKIA0062GB</p>
	LH	76, 77				
M121	Back door	38, 39			When Intelligent Key is not in the antenna detection area.	 <p>JMKIA0063GB</p>

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#)

NO >> GO TO 2.

2.CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and malfunctioning outside key antenna connector.
2. Check continuity between BCM harness connector and malfunctioning outside key antenna harness connector.

OUTSIDE KEY ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BCM		Outside key antenna		Continuity
Connector	Terminal	Connector	Terminal	
M122	74	D44 (RH)	2	Existed
	75		1	
	76	D14 (LH)	2	
	77		1	
M121	38	D118 (back door)	2	
	39		1	

3. Check continuity between BCM harness connector and ground.

BCM			Continuity
Connector	Terminal		
M122	74	Ground	Not existed
	75		
	76		
	77		
M121	38		
	39		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace malfunctioning outside key antenna. (New antenna or other antenna)
2. Connect BCM connector and malfunctioning outside key antenna (New antenna or other antenna) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+)			(-)	Condition		Signal (Reference value)			
BCM									
Connector		Terminal	Ground	Door request switch is pushed					
M122	RH	74, 75						When Intelligent Key is in the antenna de- tection area.	
	LH	76, 77							
M121	Back door	38, 39		When Intelligent Key is not in the antenna detection area.					

JMKIA0062GB

JMKIA0063GB

Is the inspection result normal?

YES-1 >> Replace malfunctioning front outside handle (LH or RH). Refer to [DLK-251. "OUTSIDE HANDLE : Removal and Installation"](#).

YES-2 >> Replace outside key antenna (Back door). Refer to [DLK-264. "BACK DOOR : Removal and Installation"](#).

OUTSIDE KEY ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

NO >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY WARNING BUZZER

Description

INFOID:0000000004343462

Answers back and warns for an inappropriate operation.

Component Function Check

INFOID:0000000004343463

1.CHECK FUNCTION

Check Intelligent Key warning buzzer ("OUTSIDE BUZZER") in Active Test mode.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer (engine room) is OK.
NO >> Refer to [DLK-95, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343464

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No.6, located in fuse block (J/B)].

Is fuse fusing?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.
NO >> GO TO 2.

2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Disconnect Intelligent Key warning buzzer connector.
2. Check voltage between Intelligent Key warning buzzer harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Intelligent Key warning buzzer			
Connector	Terminal		
E57	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and Intelligent Key warning buzzer harness connector.

BCM		Intelligent Key warning buzzer		Continuity
Connector	Terminal	Connector	Terminal	
M121	64	E57	3	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	64		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTELLIGENT KEY WARNING BUZZER

Check [DLK-96, "Component Inspection"](#).

Is the inspection result normal?

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

- YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-265, "Removal and Installation"](#).

Component Inspection

INFOID:000000004343465

1. CHECK INTELLIGENT KEY WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Connect battery power supply directly to Intelligent Key warning buzzer terminals and check the operation.

Intelligent Key warning buzzer		Operation
Terminal		
(+)	(-)	
1	3	Buzzer sounds

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-265, "Removal and Installation"](#).

INTELLIGENT KEY

Description

INFOID:0000000004343466

The following functions are available when having and carrying electronic ID.

- Door lock/unlock
- Engine start

Remote control entry function and panic alarm function are available when operating on button.

Component Function Check

INFOID:0000000004343467

1.CHECK FUNCTION

Check remote keyless entry receiver ("RKE OPE COUN1") in Data Monitor mode with CONSULT-III.

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating on the Intelligent Key.

Is the inspection result normal?

- YES >> Intelligent Key is OK.
 NO >> Refer to [DLK-97, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343468


1.CHECK INTELLIGENT KEY BATTERY

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA.

Standard : Approx. 2.5 - 3.0V

Is the measurement value within the specification?

- YES >> Replace Intelligent Key.
 NO >> Replace Intelligent Key battery. Refer to [DLK-97, "Component Inspection"](#).



Component Inspection


INFOID:0000000004343469

1. REPLACE INTELLIGENT KEY BATTERY

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.
2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.

INTELLIGENT KEY

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.


CAUTION:

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.

Is the inspection result normal?

YES >> Intelligent Key is OK.

NO >> Check remote keyless entry receiver. Refer to [DLK-81](#).
["Component Function Check"](#).



INFOID:000000004343470

Special Repair Requirement

Refer to CONSULT-III Operation Manual NATS-IVIS/NVIS.

KEY SLOT

Description

INFOID:000000004343471

- Detect whether Intelligent Key is inserted.
- Immobilizer antenna amp checks Intelligent Key transponder.

Component Function Check

INFOID:000000004343472

1.CHECK FUNCTION

Check key slot ("KEY SW -SLOT") in Data Monitor mode using CONSULT-III.

Monitor item	Condition
KEY SW-SLOT	Key is inserted in key slot: ON
	Key is removed from key slot: OFF

Is the inspection result normal?

- YES >> Key slot is OK.
 NO >> Refer to [DLK-99, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343473

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No.9, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK KEY SLOT POWER SUPPLY CIRCUIT

1. Disconnect key slot connector.
2. Check voltage between slot harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Key slot			
Connector	Terminal		
M22	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK KEY SLOT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and key slot harness connector.

BCM		Key slot		Continuity
Connector	Terminal	Connector	Terminal	
M123	121	M22	11	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	121		Not existed

Is the inspection result normal?

- YES >> GO TO 4.

KEY SLOT

[INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

4.CHECK KEY SLOT

Refer to [DLK-100, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace key slot. Refer to [DLK-266, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:00000000434374

1.CHECK KEY SLOT

1. Turn ignition switch OFF.
2. Disconnect key slot connector.
3. Check continuity between key slot terminals.

Key slot		Condition		Continuity
Terminal				
1	11	Intelligent Key	Inserted in key slot	Existed
			Removed in key slot	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace key slot. Refer to [DLK-266, "Removal and Installation"](#).

KEY SLOT INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY SLOT INDICATOR

Description

INFOID:0000000004343475

Blinks when Intelligent Key insertion is required.

Component Function Check

INFOID:0000000004343476

1.CHECK FUNCTION

Check key slot indicator ("KEY SLOT ILLUMI") Active Test mode.

Is the inspection result normal?

YES >> Key slot function is OK.

NO >> Refer to [DLK-101. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343477

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No. 6, located in fuse block (J/B)].

Is fuse fusing?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK KEY SLOT POWER SUPPLY CIRCUIT

1. Disconnect key slot connector.
2. Check voltage between key slot harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Key slot			
Connector	Terminal		
M22	5	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK KEY SLOT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and key slot harness connector.

BCM		Key slot		Continuity
Connector	Terminal	Connector	Terminal	
M122	92	M22	6	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	92		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK KEY SLOT

Refer to [DLK-102. "Component Inspection"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

KEY SLOT INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> Replace key slot. Refer to [DLK-266, "Removal and Installation"](#).

Component Inspection

INFOID:0000000004343478

1. CHECK KEY SLOT ILLUMINATION

1. Turn ignition switch OFF.
2. Disconnect key slot connector.
3. Connect battery power supply directly to key slot terminals.

Key slot		Operation
Terminal		
(+)	(-)	
5	6	Key slot illuminates

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace key slot. Refer to [DLK-266, "Removal and Installation"](#).

HORN FUNCTION

Description

INFOID:000000004343479

Perform answer-back for each operation with horn.

Component Function Check

INFOID:000000004343480

1.CHECK FUNCTION

1. Select "HORN" in "ACTIVE TEST" mode with CONSULT-III.
2. Check the horn (high/low) operation.

Test item		Description	
HORN	ON	Horn relay	ON (for 20 ms)

Is the operation normal?

YES >> Horn function is OK.

NO >> Refer to [DLK-103. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343481

1.CHECK HORN SWITCH

Check horn function with horn switch

Do the horns sound?

YES >> GO TO 2.

NO >> Refer to [HRN-2. "Wiring Diagram - HORN -"](#).

2.CHECK HORN RELAY POWER SUPPLY

1. Turn ignition switch ON.
2. Perform "ACTIVE TEST" ("HORN") with CONSULT-III.
3. Check voltage between malfunctioning horn relay harness connector and ground.

(+)			(-)	Test item		Voltage (V) (Approx.)
Horn relay						
Connector		Terminal				
E11	Low	1	Ground	HORN	ON	Battery voltage → 0 → Battery voltage
E18	High	3			Other than above	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK HORN RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and horn relay connector.
3. Check continuity between IPDM E/R harness connector and malfunctioning horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
E6	44	E11	1	Existed
	45	E18	3	

4. Check continuity between driver seat control unit harness connector and ground.

HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

IPDM E/R		Ground	Continuity
Connector	Terminal		
E6	44		Not existed
	45		

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-33. "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

Is the inspection result normal?

>> INSPECTION END

COMBINATION METER DISPLAY FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

COMBINATION METER DISPLAY FUNCTION

Description

INFOID:0000000004343482

Displays each operation method guide and warning for system malfunction.

Component Function Check

INFOID:0000000004343483

1.CHECK FUNCTION

Check the operation with ("LCD") in the Active Test.

Is each warning displayed on meter display?

Is the inspection result normal?

YES >> Meter display is OK.

NO >> Refer to [DLK-105, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343484

1.CHECK COMBINATION METER

Refer to [MWI-100, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check combination meter. Refer to [MWI-4, "Work flow"](#).

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BUZZER (COMBINATION METER)

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BUZZER (COMBINATION METER)

Description

INFOID:000000004343485

Performs operation method guide and warning with buzzer.

Component Function Check

INFOID:000000004343486

1.CHECK FUNCTION

1. Check the operation with "INSIDE BUZZER" in the Active Test.
2. Touch "TAKE OUT", "KNOB" or "KEY" on screen.

Is the inspection result normal?

- Yes >> Warning buzzer into combination meter is OK.
- No >> Refer to [DLK-106, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343487

1.CHECK METER BUZZER CIRCUIT

Refer to [WCS-23, "Component Function Check"](#).

Is the inspection result normal?

- Yes >> GO TO 2.
- No >> Repair or replace harness.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

KEY WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY WARNING LAMP

Description

INFOID:0000000004343488

Performs operation method guide and warning together with buzzer.

Component Function Check

INFOID:0000000004343489

1.CHECK FUNCTION

Check the operation with "INDICATOR" in "Active Test" mode with CONSULT-III.

Test item	Condition	
INDICATOR	RED ON	Key warning lamp (red) illuminates
	RED IND	Key warning lamp (red) flashes

Is the inspection result normal?

YES >> Key warning lamp in combination meter is OK.

NO >> Refer to [DLK-107, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000004343490

1.CHECK KEY WARNING LAMP

Refer to [MWI-38, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

DLK

HAZARD FUNCTION

Description

INFOID:000000004343491

Perform answer-back for each operation with number of blinks.

Component Function Check

INFOID:000000004343492

1.CHECK FUNCTION

Check hazard warning lamp ("FLASHER") in Active Test.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [DLK-108, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004343493

1.CHECK HAZARD SWITCH CIRCUIT

Refer to [EXL-103, "Wiring Diagram - TURN AND HAZARD WARNING LAMPS -"](#) (For xenon type) or [EXL-274, "Wiring Diagram - TURN AND HAZARD WARNING LAMPS -"](#) (For halogen type)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

INTEGRATED HOMELINK TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTEGRATED HOMELINK TRANSMITTER

Description

INFOID:000000004343494

Integrated Homelink Transmitter can store and transmit a maximum of 3 radio signals. Allows operation of garage doors, gates, home and office lighting, entry door locks and security system, etc. Integrated Homelink Transmitter power supply uses vehicle battery, which enables it to maintain every program in case battery is discharged or removed.

Component Function Check

INFOID:000000004343495

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn ignition switch OFF.

2. Does red light of transmitter illuminate when any transmitter button is pressed?

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [DLK-109, "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

YES >> Receiver or hand-held transmitter malfunction, not vehicle related.

NO >> Replace auto anti-dazzling inside mirror (homelink universal transceiver). Refer to [MIR-101, "Removal and Installation"](#) (with ADP) or [MIR-122, "Removal and Installation"](#) (Without ADP).

Diagnosis Procedure

INFOID:000000004343496

1.CHECK POWER SUPPLY

DLK

1. Turn ignition switch OFF.

2. Disconnect auto anti-dazzling inside mirror (homelink universal transceiver) connector.

3. Check voltage between auto anti-dazzling inside mirror (home link universal transceiver) harness connector and ground.

Auto anti-dazzling inside mirror (Homelink universal transceiver) connector	Terminal		Condition	Voltage (V) (Approx.)
R3	10	Ground	Ignition switch position: OFF	Battery voltage
	6		Ignition switch position: ON	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- 10A fuse [No. 3 located in the fuse block (J/B)]
- 10A fuse [No. 6 located in the fuse block (J/B)]
- Harness for open or short between fuse and auto anti-dazzling inside mirror (homelink universal transceiver).

2.CHECK GROUND CIRCUIT

Check continuity between auto anti-dazzling inside mirror (homelink universal transceiver) harness connector and ground.

INTEGRATED HOMELINK TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Auto anti-dazzling inside mirror (Homelink universal transceiver) connector	Terminal	Ground	Continuity
R3	8		Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


[INTELLIGENT KEY SYSTEM]

POWER DOOR LOCK SYSTEM

Wiring Diagram - POWER DOOR LOCK SYSTEM -

INFOID:000000004343497

POWER DOOR LOCK SYSTEM



2008/08/28

JCKWA1903GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]



★: This connector is not shown in "Harness Layout".

JCKWA1904GB

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER DOOR LOCK SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-CS16-TM4



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255	256	257	258	259	260	261	262	263	264	265	266	267	268	269	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307	308	309	310	311	312	313	314	315	316	317	318	319	320	321	322	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348	349	350	351	352	353	354	355	356	357	358	359	360	361	362	363	364	365	366	367	368	369	370	371	372	373	374	375	376	377	378	379	380	381	382	383	384	385	386	387	388	389	390	391	392	393	394	395	396	397	398	399	400	401	402	403	404	405	406	407	408	409	410	411	412	413	414	415	416	417	418	419	420	421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	436	437	438	439	440	441	442	443	444	445	446	447	448	449	450	451	452	453	454	455	456	457	458	459	460	461	462	463	464	465	466	467	468	469	470	471	472	473	474	475	476	477	478	479	480	481	482	483	484	485	486	487	488	489	490	491	492	493	494	495	496	497	498	499	500	501	502	503	504	505	506	507	508	509	510	511	512	513	514	515	516	517	518	519	520	521	522	523	524	525	526	527	528	529	530	531	532	533	534	535	536	537	538	539	540	541	542	543	544	545	546	547	548	549	550	551	552	553	554	555	556	557	558	559	560	561	562	563	564	565	566	567	568	569	570	571	572	573	574	575	576	577	578	579	580	581	582	583	584	585	586	587	588	589	590	591	592	593	594	595	596	597	598	599	600	601	602	603	604	605	606	607	608	609	610	611	612	613	614	615	616	617	618	619	620	621	622	623	624	625	626	627	628	629	630	631	632	633	634	635	636	637	638	639	640	641	642	643	644	645	646	647	648	649	650	651	652	653	654	655	656	657	658	659	660	661	662	663	664	665	666	667	668	669	670	671	672	673	674	675	676	677	678	679	680	681	682	683	684	685	686	687	688	689	690	691	692	693	694	695	696	697	698	699	700	701	702	703	704	705	706	707	708	709	710	711	712	713	714	715	716	717	718	719	720	721	722	723	724	725	726	727	728	729	730	731	732	733	734	735	736	737	738	739	740	741	742	743	744	745	746	747	748	749	750	751	752	753	754	755	756	757	758	759	760	761	762	763	764	765	766	767	768	769	770	771	772	773	774	775	776	777	778	779	780	781	782	783	784	785	786	787	788	789	790	791	792	793	794	795	796	797	798	799	800	801	802	803	804	805	806	807	808	809	810	811	812	813	814	815	816	817	818	819	820	821	822	823	824	825	826	827	828	829	830	831	832	833	834	835	836	837	838	839	840	841	842	843	844	845	846	847	848	849	850	851	852	853	854	855	856	857	858	859	860	861	862	863	864	865	866	867	868	869	870	871	872	873	874	875	876	877	878	879	880	881	882	883	884	885	886	887	888	889	890	891	892	893	894	895	896	897	898	899	900	901	902	903	904	905	906	907	908	909	910	911	912	913	914	915	916	917	918	919	920	921	922	923	924	925	926	927	928	929	930	931	932	933	934	935	936	937	938	939	940	941	942	943	944	945	946	947	948	949	950	951	952	953	954	955	956	957	958	959	960	961	962	963	964	965	966	967	968	969	970	971	972	973	974	975	976	977	978	979	980	981	982	983	984	985	986	987	988	989	990	991	992	993	994	995	996	997	998	999	1000
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	------

Terminal No.	Color of Wire	Signal Name [Specification]
74	L	-
85	V	-
86	LG	-
92	BR	-
93	G	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS5



10	9	8	7	6	5	4	3	2	1
18	17	16	15	14	13	12	11		

Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	BR	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B27
Connector Name	WIRE TO WIRE
Connector Type	M03MW-LC



1	2	3
4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
5	L	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-CS16-TM4



0	1	2	3	4	5
6	7	8	9	10	11
12	13	14	15	16	17
18	19	20	21	22	23
24	25	26	27	28	29
30	31	32	33	34	35
36	37	38	39	40	41
42	43	44	45	46	47
48	49	50	51	52	53
54	55	56	57	58	59
60	61	62	63	64	65
66	67	68	69	70	71
72	73	74	75	76	77
78	79	80	81	82	83
84	85	86	87	88	89
90	91	92	93	94	95
96	97	98	99	100	101

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER DOOR LOCK SYSTEM

Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B242
Connector Name	FUEL LID LOCK ACTUATOR
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
3	V	-
11	P	-
12	LG	-
13	B	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
6	Y	-
14	V	-

Connector No.	D9
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS03FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0GY-RS




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	P	-
4	B	-
5	Y	-
6	V	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
9	V	-
12	P	-
13	LG	-
14	B	-

Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-
16	V	-

JCKWA1906GB

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER DOOR LOCK SYSTEM

Connector No.	D43
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	E08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	LG	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NSS



Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	V	-

Connector No.	D55
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	E08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NSS



Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	O	-

Connector No.	D75
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	E08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	M06FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
5	V	-

Connector No.	D113
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS04FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	V	-
4	B	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH06FW-CSI6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

JCKWA1907GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]


POWER DOOR LOCK SYSTEM

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RKJDFG-DGY



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	P	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TKS6FW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	F151
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FBGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	GAN-H
2	L/Y	GAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NSJ6FW-M2




Terminal No.	Color of Wire	Signal Name [Specification]
4A	P	-
7A	R	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NSJ0FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
6B	Y	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
3	V	-
11	G	-
12	V	-
13	B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
74	R	-
85	LG	-
86	R	-
92	V	-
93	BR	-

JCKWA1908GB

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]


POWER DOOR LOCK SYSTEM

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT
5	Y	ILL BAT
6	LG	ILL
7	B	GND
11	BR	KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMMUNICATION SIGNAL (AMP->METER)
27	LG	COMMUNICATION SIGNAL (METER->AMP)

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
56	L	CAN-H
72	P	CAN-L

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38MW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CSI6-7M4



Terminal No.	Color of Wire	Signal Name [Specification]
23	BR	-
24	LG	-
91	V	-
92	G	-
96	G	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M63FB-LG



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

JCKWA1909GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER DOOR LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER DOOR LOCK SYSTEM

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



4	5	6	7	8	9	10		
11	12	13	14	15	16	17	18	19

Terminal No.	Color of Wire	Signal Name [Specification]
5	L	PASSENGER DOOR UNLOCK OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GND

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	-
12	L	-
13	V	-
14	B	-

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29	30	31	32	33	34

Terminal No.	Color of Wire	Signal Name [Specification]
66	R	BACK DOOR SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29	30	31	32	33	34

Terminal No.	Color of Wire	Signal Name [Specification]
90	P	GAN-L
91	L	GAN-H
92	LG	KEY SLOT ILL

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH




5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29	30	31	32	33	34

Terminal No.	Color of Wire	Signal Name [Specification]
121	BR	KEY SLOT SW
124	LG	PASSENGER DOOR SW
132	V	POWER WINDOW SW COMM
150	LG	DRIVER DOOR SW

INTELLIGENT KEY SYSTEM

Wiring Diagram - INTELLIGENT KEY SYSTEM -

INFOID:000000004343498




2008/08/28


JCKWA1911GB

DLK

[INTELLIGENT KEY SYSTEM]

[INTELLIGENT KEY SYSTEM]





JCKWA1913GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK


INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
34	L	-
35	P	-
36	L	-
37	P	-
73	Y	-
74	L	-
75	W	-
76	BR	-
77	R	-
79	GR	-
85	V	-


86	LG	-
92	BR	-
93	G	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	AG3FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8




Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	BR	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	AG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B27
Connector Name	WIRE TO WIRE
Connector Type	M06MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
4	Y	-
5	L	-

Connector No.	B28
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
3	W	-
4	B	-
23	BR	-
24	R	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
15	P	-
16	L	-
23	BR	-
24	GR	-
91	V	-
92	R	-
96	G	-

JCKWA1914GB


INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM

Connector No.	B216
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS3



Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	V	-

Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B228
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Connector Type	PK02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	P	-

Connector No.	B242
Connector Name	FUEL LID LOCK ACTUATOR
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
11	P	-
12	LG	-
13	B	-
33	L	-
53	SB	-
54	O	-
55	Y	-

Connector No.	D13
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Type	PK02FL



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	D14
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	PK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	SB	-

JCKWA1915GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]


INTELLIGENT KEY SYSTEM

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	EO6FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	P	-
3	L	-
4	B	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
12	P	-
13	LG	-
14	B	-
22	V	-
23	P	-
24	W	-

Connector No.	D43
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Type	RK02FL



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	D44
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	V	-

Connector No.	D46
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	EO6GY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	LG	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NS5



Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	V	-

Connector No.	D55
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	EO6FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	TK10MP-NS5



Terminal No.	Color of Wire	Signal Name [Specification]
14	G	-
15	O	-

JCKWA1916GB

INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM

Connector No.	D75
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	E08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	M06FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
4	Y	-
5	V	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
3	W	-
4	B	-
23	BR	-
24	R	-

Connector No.	D113
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS04FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	B	-
3	V	-
4	B	-

Connector No.	D114
Connector Name	BACK DOOR OPENER SWITCH
Connector Type	TK02MBR-P



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	B	-

Connector No.	D116
Connector Name	BACK DOOR OPENER REQUEST SWITCH
Connector Type	TK02MBR-P



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	D118
Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)
Connector Type	PK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	ES
Connector Name	MODULE R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
12	B/W	-

JCKWA1917GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

Connector No.	E6
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH08FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
44	W	-
45	G	-

Connector No.	E11
Connector Name	HORN RELAY 1
Connector Type	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	LG	-
3	G	-

Connector No.	E18
Connector Name	HORN RELAY 2
Connector Type	M03FW-R-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	G	-

Connector No.	E57
Connector Name	INTELLIGENT KEY WARNING BUZZER (ENGINE ROOM)
Connector Type	FK03FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
3	GR	-

Connector No.	E61
Connector Name	HORN (HIGH)
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-

Connector No.	E62
Connector Name	HORN (HIGH)
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-

Connector No.	E69
Connector Name	HORN (LOW)
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-

Connector No.	E70
Connector Name	HORN (LOW)
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-

JCKWA1918GB


INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
47	LG	-
48	GR	-
81	P	-
82	L	-
91	W	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	GR	-
2A	G	-
4A	P	-
5A	V	-
7A	R	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
12C	O	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH00MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
11	G	-
12	V	-
13	B	-
33	SB	-
53	V	-
54	LG	-
55	SB	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
47	Y	-
48	V	-
81	P	-
82	L	-
91	W	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
34	L	-
35	P	-
36	L	-
37	P	-
73	G	-
74	R	-
75	W	-
76	W	-
77	B	-
79	GR	-
85	LG	-

88	R	-
92	V	-
93	BR	-

JCKWA1919GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]


INTELLIGENT KEY SYSTEM

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT
5	Y	ILL BAT
6	LG	ILL
7	B	GND
11	BR	KEY SWITCH SIGNAL

Connector No.	M68
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH10FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMMUNICATION SIGNAL (AMP->METER)
14	BR	COMMUNICATION SIGNAL (LCD->AMP)
27	LG	COMMUNICATION SIGNAL (METER->AMP)
34	Y	COMMUNICATION SIGNAL (AMP->LCD)

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
53	G	IGNITION POWER SUPPLY
55	B	GROUND
56	L	CAN-H
71	B	GROUND
72	P	CAN-L

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
4	BR	-

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JA04AFB



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	GND
2	Y	SIGNAL OUTPUT
4	LG	BATTERY

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
15	B	GND
21	O	IGN
22	B	GND
24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH60MP-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
15	SB	-
16	V	-
23	BR	-
24	LG	-
91	V	-
92	G	-
96	G	-

INTELLIGENT KEY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY SYSTEM

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FE-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	O	POWER WINDOW POWER SUPPLY (RAP)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSENGER DOOR UNLOCK OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)
19	V	ROOM LAMP TIMER CONTROL

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	G	BACK DOOR OPEN OUTPUT
25	G	TURN SIGNAL LH (REAR)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
61	W	BACK DOOR OPENER REQUEST SW
64	V	I-KEY WARN BUZZER (ENG ROOM)
66	R	BACK DOOR SW
67	GR	BACK DOOR OPENER SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4UFB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	GR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
83	Y	KEYLESS ENTRY RECEIVER COMM
89	BR	PUSH SW
90	P	CAN-L

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name [Specification]
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
124	LG	PASSENGER DOOR SW
137	O	RECEIVER/SENSOR GND
150	LG	DRIVER DOOR SW

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MM-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
12	L	-
13	V	-
14	B	-
22	SB	-
23	GR	-
24	G	-

JCKWA1921GB


INTELLIGENT KEY SYSTEM

Connector No.	M131
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
10	GR	-
11	R	-

Connector No.	M146
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-

INTEGRATED HOMELINK TRANSMITTER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


[INTELLIGENT KEY SYSTEM]

INTEGRATED HOMELINK TRANSMITTER SYSTEM

Wiring Diagram - INTEGRATED HOMELINK TRANSMITTER SYSTEM -

INFOID:0000000004343499

INTEGRATED HOMELINK TRANSMITTER



2008/08/28

JCKWA1923GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTEGRATED HOMELINK TRANSMITTER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTEGRATED HOMELINK TRANSMITTER

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	2A
Color of Wire	G
Signal Name [Specification]	—

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	6B
Color of Wire	Y
Signal Name [Specification]	—

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NS




Terminal No.	9
Color of Wire	B
Signal Name [Specification]	—
Terminal No.	12
Color of Wire	Y
Signal Name [Specification]	—
Terminal No.	13
Color of Wire	BR
Signal Name [Specification]	—

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS



Terminal No.	9
Color of Wire	B
Signal Name [Specification]	—
Terminal No.	12
Color of Wire	G
Signal Name [Specification]	—
Terminal No.	13
Color of Wire	BR
Signal Name [Specification]	—

Connector No.	R3
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Type	TH10FB-NH



Terminal No.	6
Color of Wire	BR
Signal Name [Specification]	IGN
Terminal No.	8
Color of Wire	B
Signal Name [Specification]	GND
Terminal No.	10
Color of Wire	G
Signal Name [Specification]	BAT

JCKWA1924GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004921472

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Monitor Item	Condition	Value/Status
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Monitor Item	Condition	Value/Status
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK.	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK.	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Monitor Item	Condition	Value/Status	
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet	A
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done	B
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet	C
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done	
TP 4	The ID of fourth key is not registered to BCM	Yet	D
	The ID of fourth key is registered to BCM	Done	
TP 3	The ID of third key is not registered to BCM	Yet	E
	The ID of third key is registered to BCM	Done	
TP 2	The ID of second key is not registered to BCM	Yet	F
	The ID of second key is registered to BCM	Done	
TP 1	The ID of first key is not registered to BCM	Yet	
	The ID of first key is registered to BCM	Done	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	G
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	H
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	I
ID REGST FL1	ID of front LH tire transmitter is registered	Done	J
	ID of front LH tire transmitter is not registered	Yet	
ID REGST FR1	ID of front RH tire transmitter is registered	Done	DLK
	ID of front RH tire transmitter is not registered	Yet	
ID REGST RR1	ID of rear RH tire transmitter is registered	Done	L
	ID of rear RH tire transmitter is not registered	Yet	
ID REGST RL1	ID of rear LH tire transmitter is registered	Done	M
	ID of rear LH tire transmitter is not registered	Yet	
WARNING LAMP	Tire pressure indicator OFF	Off	N
	Tire pressure indicator ON	On	
BUZZER	Tire pressure warning alarm is not sounding	Off	O
	Tire pressure warning alarm is sounding	On	


P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

TERMINAL LAYOUT




PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	Battery voltage
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)	Battery voltage
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	NOTE: When the illumination brighten- ing/dimming level is in the neutral position  <small>JSNIA0010GB</small>
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON	Battery voltage
					ACC	0 V

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 6.5 V
18 (O)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 6.5 V
23 (G)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 6.5 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
34 (SB)	Ground	Luggage room antenna (-)	Output	Ignition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p>JMKIA0063GB</p>
35 (V)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p>JMKIA0063GB</p>
38 (B)	Ground	Back door antenna (-)	Output	When the back door opener request switch is operated with ignition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p>JMKIA0063GB</p>

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When the back door opener re- quest switch is operated with ig- nition switch ON	When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
61 (W)	Ground	Back door opener re- quest switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
64 (V)	Ground	Intelligent Key warn- ing buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 JPMIA0016GB 1.0 V
					Not in stop position	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]







Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
66 (R)	Ground	Back door switch	Input	Back door switch	OFF (Door close)	 <p>JPMIA0011GB 11.8 V</p>
					ON (Door open)	0 V
67 (G)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 <p>JPMIA0011GB 11.8 V</p>
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	 <p>JPMIA0011GB 11.8 V</p>
					ON (Door open)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (Door close)	 <p>JPMIA0011GB 11.8 V</p>
					ON (Door open)	0 V

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	 <p>JMKIA0063GB</p>
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	 <p>JMKIA0063GB</p>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	 <p>JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p>JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
75 (GR)	Ground	Passenger door antenna (+)	Output	When the passenger door request switch is operated with ignition switch OFF	<p>JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p>JMKIA0063GB</p>
76 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operated with ignition switch OFF	<p>JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p>JMKIA0063GB</p>
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF	<p>JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p>JMKIA0063GB</p>

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB
80 (GR)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
83 (Y)	Ground	Remote keyless entry receiver communica- tion	Input/ Output	During waiting	 JMKIA0064GB
				When operating either button on the key	 JMKIA0065GB
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	
				All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Front fog lamp switch ON (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear wiper switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	 JPMIA0040GB 1.3 V

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)  JPMIA0041GB 1.4 V
					Lighting switch HI (Wiper intermittent dial 4)  JPMIA0036GB 1.3 V
					Lighting switch 2ND (Wiper intermittent dial 4)  JPMIA0037GB 1.3 V
					Rear washer switch ON (Wiper intermittent dial 4)  JPMIA0039GB 1.3 V
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3  JPMIA0040GB 1.3 V
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (push switch)	Pressed 0 V
				Not pressed	Battery voltage
90 (P)	Ground	CAN-L	Input/ Output	—	—
91 (L)	Ground	CAN-H	Input/ Output	—	—

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	0 V
					Blinking	 6.5 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	ON	Battery voltage
					OFF or ACC	Battery voltage
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	ON	0 V
					OFF	Battery voltage
95 (O)	Ground	ACC relay control	Output	Ignition switch	ACC or ON	Battery voltage
					OFF	0 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—	—	Battery voltage
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	ON	Battery voltage
					OFF or ACC	0 V

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N






O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 <p>JPMIA0041GB</p> <p>1.4 V</p>
					Turn signal switch LH	 <p>JPMIA0037GB</p> <p>1.3 V</p>
					Turn signal switch RH	 <p>JPMIA0036GB</p> <p>1.3 V</p>
					Front wiper switch LO	 <p>JPMIA0038GB</p> <p>1.3 V</p>
					Front washer switch ON	 <p>JPMIA0039GB</p> <p>1.3 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>JPMIA0041GB 1.4 V</p>
					<p>Lighting switch AUTO (Wiper intermittent dial 4)</p>  <p>JPMIA0038GB 1.3 V</p>
					<p>Lighting switch 1ST (Wiper intermittent dial 4)</p>  <p>JPMIA0036GB 1.3 V</p>
					<p>Rear wiper switch INT (Wiper intermittent dial 4)</p>  <p>JPMIA0040GB 1.3 V</p>
					<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6  <p>JPMIA0039GB 1.3 V</p>







A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermit- tent dial 4)	<p>All switches OFF</p>  <p>1.4 V</p>
					<p>Lighting switch PASS</p>  <p>1.3 V</p>
					<p>Lighting switch 2ND</p>  <p>1.3 V</p>
					<p>Front wiper switch INT</p>  <p>1.3 V</p>
					<p>Front wiper switch HI</p>  <p>1.3 V</p>
110 (G)	Ground	Hazard switch	Input	Hazard switch	<p>ON</p> <p>0 V</p>
				OFF	 <p>1.1 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]




Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	–	Signal name	Input/ Output			
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage
					LOCK or UNLOCK	
					For 15 seconds after UN- LOCK	Battery voltage
					15 seconds or later after UNLOCK	0 V
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not de- pressed) and ICC brake hold relay OFF		0 V
				Stop lamp switch ON (Brake pedal is de- pressed) or ICC brake hold relay ON		Battery voltage
119 (SB)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 1.1 V
					UNLOCK status (Unlock switch sensor ON)	0 V
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage
				When the key is not inserted into key slot		0 V
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 11.8 V
					ON (Door open)	0 V
132 (V)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 10.2 V
				Ignition switch OFF or ACC		Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button igni- tion switch illumi- nation	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level. 
					OFF	0 V
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB 11.3 V
					OFF	Battery voltage
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	 JPMIA0031GB 10.7 V
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	 JPMIA0032GB 10.7 V
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> Wiper intermittent dial 1 Wiper intermittent dial 2 Wiper intermittent dial 3 Wiper intermittent dial 6 Wiper intermittent dial 7 	

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N






O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[INTELLIGENT KEY SYSTEM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front wiper switch INT	
					Front wiper switch LO	
					Lighting switch AUTO	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
149 (W)	Ground	Tire pressure warn- ing check switch	Input	Ignition switch ON		
150 (LG)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	
					ON (Door open)	0 V
151 (G)	Ground	Rear window defog- ger relay control	Output	Rear window de- fogger	Active	0 V
					Not activated	Battery voltage

[INTELLIGENT KEY SYSTEM]


Wiring Diagram - BCM -

A
B
C
D
E
F
G
H
I
J
OLK
L
M
N
O
P



[INTELLIGENT KEY SYSTEM]

[INTELLIGENT KEY SYSTEM]




*****: This connector is not shown in "Harness Layout".

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

RF : With sunroof
PM : With automatic drive positioner
OP : Without automatic drive positioner



BCM (BODY CONTROL MODULE)
(M119) (M120) (M121) (M122) (M123)



* : This connector is not shown in "Harness Layout".


JCMWA3121GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[INTELLIGENT KEY SYSTEM]



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]



JCMWA3123GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]


BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12PW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	G	BACK DOOR OPEN OUTPUT
25	G	TURN SIGNAL LH (REAR)
26	G	REAR WIPER OUTPUT

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03EB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	O	POWER WINDOW POWER SUPPLY (RAP)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (IPDM E/R) CONT
52	SB	STARTER RELAY CONT
61	W	BACK DOOR OPENER REQUEST SW
64	V	I-KEY WARN BUZZER (ENG ROOM)
65	O	REAR WIPER STOP POSITION
66	R	BACK DOOR SW
67	GR	BACK DOOR OPENER SW

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GND
14	W	PUSH-BUTTON IGNITION SW ILL GND
15	Y	ASC IND
17	W	TURN SIGNAL RH (FRONT)

68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

JCMWA3124GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

138	Y	RECEIVER/SENSOR POWER SUPPLY
139	L	TIRE PRESSURE RECEIVER COMM
140	GR	SHIFT N/P
141	G	SECURITY INDICATOR OUTPUT
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESS WARNING CHECK SW
150	LG	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



131	130	129	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
151	150	149	148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132

Terminal No.	Color of Wire	Signal Name [Specification]
113	P	OPTICAL SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	V	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW ILL POWER
134	GR	LOCK IND
137	O	RECEIVER/SENSOR GND

83	Y	KEYLESS ENTRY RECEIVER COMM
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
94	Y	FUDDLE LAMP CONT
95	O	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	Y	S/L UNIT COMM

BCM (BODY CONTROL MODULE)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	74	73	72
111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96	95	94	93	92

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> Steering lock relay signal (Request signal) Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> BCM steering lock control status Steering lock condition No. 1 signal status Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> Steering lock unit status signal (CAN) is received normally The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> Steering condition No. 1 signal: LOCK (0 V) Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- More than 1 minute is passed after the rear wiper stops.
- Turn rear wiper switch OFF.
- Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000004921475

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none">• U1000: CAN COMM CIRCUIT• U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none">• B2190: NATS ANTENNA AMP• B2191: DIFFERENCE OF KEY• B2192: ID DISCORD BCM-ECM• B2193: CHAIN OF BCM-ECM• B2195: ANTI SCANNING
4	<ul style="list-style-type: none">• B2013: ID DISCORD BCM-S/L• B2014: CHAIN OF S/L-BCM• B2553: IGNITION RELAY• B2555: STOP LAMP• B2556: PUSH-BTN IGN SW• B2557: VEHICLE SPEED• B2560: STARTER CONT RELAY• B2601: SHIFT POSITION• B2602: SHIFT POSITION• B2603: SHIFT POSI STATUS• B2604: PNP SW• B2605: PNP SW• B2606: S/L RELAY• B2607: S/L RELAY• B2608: STARTER RELAY• B2609: S/L STATUS• B260A: IGNITION RELAY• B260B: STEERING LOCK UNIT• B260C: STEERING LOCK UNIT• B260D: STEERING LOCK UNIT• B260F: ENG STATE SIG LOST• B2612: S/L STATUS• B2614: ACC RELAY CIRC• B2615: BLOWER RELAY CIRC• B2616: IGN RELAY CIRC• B2617: STARTER RELAY CIRC• B2618: BCM• B2619: BCM• B261A: PUSH-BTN IGN SW• B261E: VEHICLE TYPE• B26E9: S/L STATUS• B26EA: KEY REGISTRATION• C1729: VHCL SPEED SIG ERR• U0415: VEHICLE SPEED SIG

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

Priority	DTC
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA

DTC Index

INFOID:000000004921476

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-16. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	BCS-37
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-38
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-39
B2013: ID DISCORD BCM-S/L	×	×	—	—	SEC-48
B2014: CHAIN OF S/L-BCM	×	×	—	—	SEC-49
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-41
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-44
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-45
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-46
B2195: ANTI SCANNING	×	—	—	—	SEC-47
B2553: IGNITION RELAY	—	×	—	—	PCS-49

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2555: STOP LAMP	—	×	—	—	SEC-52
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-54
B2557: VEHICLE SPEED	×	×	×	—	SEC-56
B2560: STARTER CONT RELAY	×	×	×	—	SEC-57
B2562: LOW VOLTAGE	—	×	—	—	BCS-40
B2601: SHIFT POSITION	×	×	×	—	SEC-58
B2602: SHIFT POSITION	×	×	×	—	SEC-61
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-63
B2604: PNP SW	×	×	×	—	SEC-66
B2605: PNP SW	×	×	×	—	SEC-68
B2606: S/L RELAY	×	×	×	—	SEC-70
B2607: S/L RELAY	×	×	×	—	SEC-71
B2608: STARTER RELAY	×	×	×	—	SEC-73
B2609: S/L STATUS	×	×	×	—	SEC-75
B260A: IGNITION RELAY	×	×	×	—	PCS-51
B260B: STEERING LOCK UNIT	—	×	×	—	SEC-79
B260C: STEERING LOCK UNIT	—	×	×	—	SEC-80
B260D: STEERING LOCK UNIT	—	×	×	—	SEC-81
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-82
B2612: S/L STATUS	×	×	×	—	SEC-86
B2614: ACC RELAY CIRC	—	×	×	—	PCS-53
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-56
B2616: IGN RELAY CIRC	—	×	×	—	PCS-59
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-90
B2618: BCM	×	×	×	—	PCS-62
B2619: BCM	×	×	×	—	SEC-92
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-93
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	SEC-96
B2621: INSIDE ANTENNA	—	×	—	—	DLK-59
B2622: INSIDE ANTENNA	—	×	—	—	DLK-61
B2623: INSIDE ANTENNA	—	×	—	—	DLK-63
B26E1: ENG STATE NO RES	×	×	×	—	SEC-83
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	—	SEC-84
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-85
C1704: LOW PRESSURE FL	—	—	—	×	WT-17
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[INTELLIGENT KEY SYSTEM]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1708: [NO DATA] FL	—	—	—	×	WT-19
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	—	×	WT-22
C1713: [CHECKSUM ERR] FR	—	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-25
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1720: [CODE ERR] FL	—	—	—	×	WT-27
C1721: [CODE ERR] FR	—	—	—	×	
C1722: [CODE ERR] RR	—	—	—	×	
C1723: [CODE ERR] RL	—	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	—	×	WT-30
C1725: [BATT VOLT LOW] FR	—	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-33
C1734: CONTROL UNIT	—	—	—	×	WT-34

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

SYMPTOM DIAGNOSIS

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

ALL DOOR

ALL DOOR : Description

INFOID:000000004672391

All doors do not lock/unlock using door lock and unlock switch.

ALL DOOR : Diagnosis Procedure

INFOID:000000004672392

1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [DLK-65. "BCM \(BODY CONTROL MODULE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DOOR LOCK AND UNLOCK SWITCH

Check door lock and unlock switch.

• Driver side: Refer to [DLK-70. "DRIVER SIDE : Component Function Check"](#).

• Passenger side: Refer to [DLK-70. "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK DOOR LOCK ACTUATOR

Check door lock actuator (driver side).

Refer to [DLK-72. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004672393

Driver side door does not lock/unlock using door lock and unlock switch.

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004672394

1.CHECK DOOR LOCK ACTUATOR

Check door lock actuator (driver side).

Refer to [DLK-72. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004672395

Passenger side door does not lock/unlock using door lock and unlock switch.

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004672396

1.CHECK DOOR LOCK ACTUATOR

Check door lock actuator (passenger side).

Refer to [DLK-73, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR LH

REAR LH : Description

INFOID:000000004672409

Rear LH side door does not lock/unlock using door lock and unlock switch.

REAR LH : Diagnosis Procedure

INFOID:000000004672410

1.CHECK DOOR LOCK ACTUATOR

Check door lock actuator (rear LH).

Refer to [DLK-74, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR RH

REAR RH : Description

INFOID:000000004672411

Rear RH side door does not lock/unlock using door lock and unlock switch.

REAR RH : Diagnosis Procedure

INFOID:000000004672412

1.CHECK DOOR LOCK ACTUATOR

Check door lock actuator (rear RH).

Refer to [DLK-74, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).
- NO >> GO TO 1.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

Description

INFOID:000000004672397

All doors do not lock/unlock using driver side door key cylinder.

Diagnosis Procedure

INFOID:000000004672398

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-170, "ALL DOOR : Diagnosis Procedure"](#).

2.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-79, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

ALL DOOR

ALL DOOR : Description

INFOID:000000004672399

All doors do not lock/unlock using all door request switches.

NOTE:

Check door request switch operation in the door lock condition. Refer to [DLK-19, "DOOR LOCK FUNCTION : System Description"](#).

ALL DOOR : Diagnosis Procedure

INFOID:000000004672400

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-177, "Description"](#).

2.CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

Check "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004672401

All doors do not lock/unlock using driver side door request switch.

NOTE:

Check door request switch operation in the door lock condition. Refer to [DLK-19, "DOOR LOCK FUNCTION : System Description"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004672402

1.CHECK DRIVER SIDE DOOR REQUEST SWITCH

Check driver side door request switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA (LH)

Check outside key antenna (LH).

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

[INTELLIGENT KEY SYSTEM]

< SYMPTOM DIAGNOSIS >

Is the result normal?

YES >> Check Intermittent Incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004672403

All doors do not lock/unlock using passenger side door request switch.

NOTE:

Check door request switch operation in the door lock condition. Refer to [DLK-19, "DOOR LOCK FUNCTION : System Description"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004672404

1.CHECK PASSENGER SIDE DOOR REQUEST SWITCH

Check passenger side door request switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA (RH)

Check outside key antenna (RH).

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check Intermittent Incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

BACK DOOR

BACK DOOR : Description

INFOID:000000004672405

All doors do not lock/unlock using back door request switch.

NOTE:

Check door request switch operation in the door lock condition. Refer to [DLK-19, "DOOR LOCK FUNCTION : System Description"](#).

BACK DOOR : Diagnosis Procedure

INFOID:000000004672406

1.CHECK BACK DOOR REQUEST SWITCH

Check back door request switch.

Refer to [DLK-88, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA (REAR BUMPER)

Check outside key antenna (rear bumper).

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check Intermittent Incident. Refer to [GI-40, "Intermittent Incident"](#).
NO >> GO TO 1.

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

Description

INFOID:000000004672407

All doors do not lock/unlock using Intelligent Key.

NOTE:

Check Intelligent Key remote operation in the door lock condition. Refer to [DLK-28, "REMOTE KEYLESS ENTRY FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004672408

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-170, "ALL DOOR : Diagnosis Procedure"](#).

2.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver.

Refer to [DLK-81, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-97, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK KEY SLOT

Check key slot.

Refer to [DLK-99, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR DOES NOT OPENED

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

BACK DOOR DOES NOT OPENED

Description

INFOID:000000004672413

NOTE:

Before performing the diagnosis in the following procedure, check the operation condition. Refer to [DLK-24, "BACK DOOR OPEN FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004672414

1.CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK BACK DOOR OPENER ACTUATOR

Check back door opener actuator.

Refer to [DLK-77, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK VEHICLE SPEED SIGNAL

Check combination meter.

Refer to [MWI-50, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH DOOR REQUEST SWITCH

Description

INFOID:000000004343519

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- Intelligent Key is removed from key slot.
- Ignition switch is in OFF position.
- No Intelligent Keys are inside the vehicle.

Diagnosis Procedure

INFOID:000000004343520

1.CHECK DOOR LOCK FUNCTION

Check door lock function by door request switch.

Does door lock/unlock with door request switch?

YES >> GO TO 2.

NO-1 >> Go to [DLK-174, "DRIVER SIDE : Description"](#) (driver side).

NO-2 >> Go to [DLK-175, "PASSENGER SIDE : Description"](#) (passenger side).

NO-3 >> Go to [DLK-175, "BACK DOOR : Description"](#) (back door).

2.CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "DOOR LOCK-UNLOCK SET" in "WORK SUPPORT".

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

DLK

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE WITH INTELLIGENT KEY

Description

INFOID:000000004343521

NOTE:

- Before performing the diagnosis in the following procedure, check “Work Flow”. Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- Intelligent key is removed from key slot.
- All doors are closed.

Diagnosis Procedure

INFOID:000000004343522

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Go to [DLK-170, "ALL DOOR : Description"](#).

2.CHECK “DOOR LOCK-UNLOCK SET” SETTING IN “WORK SUPPORT”

Check “DOOR LOCK-UNLOCK SET” setting in “WORK SUPPORT”.

Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set “DOOR LOCK-UNLOCK SET” of “WORK SUPPORT”.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004343523

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Go to [DLK-170, "ALL DOOR : Description"](#).

2.CHECK VEHICLE SPEED SIGNAL

Check combination meter.

Refer to [SEC-56, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004343524

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Go to [DLK-170, "ALL DOOR : Description"](#).

2.CHECK BCM

Check DTC for BCM.

Refer to [DLK-167, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004343525

1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Go to [DLK-170, "ALL DOOR : Description"](#).

2.CHECK TCM

Check DTC for TCM.

Refer to [TM-110, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

Description

INFOID:000000004343526

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).

Diagnosis Procedure

INFOID:000000004343527

1.CHECK "AUTO LOCK SET" SETTING IN "WORK SUPPORT"

Check "AUTO LOCK SET" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTO LOCK SET" setting in "WORK SUPPORT".

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

POWER WINDOW DOWN FUNCTION DOES NOT OPERATE WITH KEY CYLINDER OPERATION

< SYMPTOM DIAGNOSIS > [INTELLIGENT KEY SYSTEM]

POWER WINDOW DOWN FUNCTION DOES NOT OPERATE WITH KEY CYLINDER OPERATION

Diagnosis Procedure

INFOID:000000004343528

1.CHECK DOOR KEY CYLINDER OPERATION

Check door key cylinder operation.

Does door lock/unlock with door key cylinder switch operation?

YES >> GO TO 2.

NO >> Go to [DLK-173, "Description"](#).

2.CHECK POWER WINDOW OPERATION

Check power window operation.

Does power window up/down with power window main switch?

YES >> GO TO 3.

NO >> Go to [PWC-90, "Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J

L
M
N
O
P

DLK

POWER WINDOW DOWN FUNCTION DOES NOT WORK WHEN OPERATING WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

POWER WINDOW DOWN FUNCTION DOES NOT WORK WHEN OPERATING WITH INTELLIGENT KEY

Description

INFOID:000000004343529

NOTE:

- Before performing the diagnosis in the following procedure, check “Work Flow”. Refer to [DLK-7, "Work Flow"](#).

Diagnosis Procedure

INFOID:000000004343530

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent key button?

YES >> GO TO 2.

NO >> Go to [DLK-177, "Description"](#).

2.CHECK POWER WINDOW OPERATION

Check power window operation.

Does power window up/down with power window main switch?

YES >> GO TO 3.

NO >> Go to [PWC-90, "Diagnosis Procedure"](#).

3.CHECK “PW DOWN SET” SETTING IN “WORK SUPPORT”

Check “PW DOWN SET” setting in “WORK SUPPORT”.

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set “PW DOWN SET” setting in “WORK SUPPORT”.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

WELCOME LIGHT FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

WELCOME LIGHT FUNCTION DOES NOT OPERATE

Description

INFOID:000000004343531

NOTE:

- Before performing the diagnosis following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATION CONDITIONS)

- Intelligent Key system (door lock function) is normal.
- All operation conditions are satisfied. Refer to [DLK-33, "WELCOME LIGHT FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343532

1.CHECK WELCOME LIGHT FUNCTION SETTING

Check "WELCOME LIGHT OP SET" and "WELCOME LIGHT SELECT" setting in "WORK SUPPORT". Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the function active?

YES >> GO TO 2.

NO >> Set "WELCOME LIGHT OP SET" and "WELCOME LIGHT SELECT" setting in "WORK SUPPORT".

2.CHECK DOOR LOCK FUNCTION

Check Intelligent Key system (door lock function).

Does the door lock/unlock with door request switch (driver side)?

YES >> GO TO 3.

NO >> Go to [DLK-174, "DRIVER SIDE : Description"](#).

3.CHECK INTERIOR ROOM LAMP CONTROL SYSTEM

Check interior room lamp control system. Refer to [INL-5, "System Description"](#).

Does the room lamp and puddle lamp turn ON?

YES >> GO TO 4.

NO >> Go to [INL-99, "Symptom Table"](#).

4.REPLACE BCM

Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

>> GO TO 5.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> INSPECTION END

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

PANIC ALARM FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

PANIC ALARM FUNCTION DOES NOT OPERATE

Description

INFOID:000000004343533

NOTE:

- Before performing the diagnosis following procedure, check “Work Flow”. Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATION CONDITIONS)

- Ignition switch is in OFF or LOCK position.
- Intelligent Key is removed from key slot.

Diagnosis Procedure

INFOID:000000004343534

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent key button?

YES >> GO TO 2.

NO >> Go to [DLK-177, "Description"](#).

2.CHECK VEHICLE SECURITY ALARM OPERATION

Check vehicle security alarm operation.

Does alarm (headlamp and horn) active?

YES >> GO TO 3.

NO >> Go to [SEC-198, "Description"](#).

3.CHECK “PANIC ALARM SET” SETTING IN “WORK SUPPORT”

Check “PANIC ALARM SET” setting in “WORK SUPPORT”.

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set “PANIC ALARM SET” setting in “WORK SUPPORT”.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

HAZARD AND HORN REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

HAZARD AND HORN REMINDER DOES NOT OPERATE

Description

INFOID:000000004343535

NOTE:

- Before performing the diagnosis following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATION CONDITIONS)

- Ignition switch is in OFF or LOCK position.
- Intelligent Key is removed from key slot.

Diagnosis Procedure

INFOID:000000004343536

1.CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

Check "HAZARD ANSWER BACK" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "HAZARD ANSWER BACK" setting in "WORK SUPPORT".

2.CHECK "HORN WITH KEYLESS LOCK" SETTING IN "WORK SUPPORT".

Check "HORN WITH KEYLESS LOCK" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "HORN WITH KEYLESS LOCK" setting in "WORK SUPPORT".

3.CHECK HAZARD WARNING LAMP

Check hazard warning lamp.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK HORN

Check horn.

Refer to [DLK-103, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

Description

INFOID:000000004343537

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- Intelligent Key is removed from key slot.
- Ignition switch is in OFF position.
- No Intelligent Keys are inside the vehicle.

Diagnosis Procedure

INFOID:000000004343538

1.CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

Check "HAZARD ANSWER BACK" setting in "WORK SUPPORT".

Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "HAZARD ANSWER BACK" in "WORK SUPPORT".

2.CHECK "ANS BACK I-KEY LOCK" SETTING IN "WORK SUPPORT"

Check "ANS BACK I-KEY LOCK" setting in "WORK SUPPORT".

Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "ANS BACK I-KEY LOCK" in "WORK SUPPORT".

3.CHECK "ANS BACK I-KEY UNLOCK" SETTING IN "WORK SUPPORT"

Check "ANS BACK I-KEY UNLOCK" setting in "WORK SUPPORT".

Refer to [DLK-51, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "ANS BACK I-KEY UNLOCK" in "WORK SUPPORT".

4.CHECK HAZARD WARNING LAMP

Check hazard warning lamp.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-95, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

KEY REMINDER FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY REMINDER FUNCTION DOES NOT OPERATE

Description

INFOID:000000004343539

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).
- Understand the operation when does it work, refer to [DLK-36. "KEY REMINDER FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343540

1.CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

Check "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".

Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".

2.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-66. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59. "DTC Logic"](#) (instrument center).

Refer to [DLK-61. "DTC Logic"](#) (console).

Refer to [DLK-63. "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-90. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY WARNING DOES NOT OPERATE

Description

INFOID:000000004343541

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

Diagnosis Procedure

INFOID:000000004343542

1.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK KEY SLOT

Check key slot.

Refer to [DLK-99, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK KEY SLOT ILLUMINATION

Check key slot illumination.

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

OFF POSITION WARNING DOES NOT OPERATE

Description

INFOID:000000004343543

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39. "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

Diagnosis Procedure

INFOID:000000004343544

1.CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-167. "DTC Index"](#).

2.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-95. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

P POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

P POSITION WARNING DOES NOT OPERATE

Description

INFOID:000000004343545

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

Diagnosis Procedure

INFOID:000000004343546

1.CHECK TRANSMISSION RANGE SWITCH

Check DTC for BCM.

Refer to [DLK-167, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-95, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59, "DTC Logic"](#) (instrument center).

Refer to [DLK-61, "DTC Logic"](#) (console).

Refer to [DLK-63, "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

P POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

7.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).
- NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

ACC WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

ACC WARNING DOES NOT OPERATE

Description

INFOID:000000004343547

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

Diagnosis Procedure

INFOID:000000004343548

1.CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-167, "DTC Index"](#).

2.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK COMBINATION METER DISPLAY FUNCTION

Check combination meter display function.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

TAKE AWAY WARNING DOES NOT OPERATE

DOOR IS OPEN

DOOR IS OPEN : Description

INFOID:000000004343549

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

DOOR IS OPEN : Diagnosis Procedure

INFOID:000000004343550

1.CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-167, "DTC Index"](#).

2.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-95, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59, "DTC Logic"](#) (instrument center).

Refer to [DLK-61, "DTC Logic"](#) (console).

Refer to [DLK-63, "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

7. CHECK KEY SLOT ILLUMINATION

Check key slot illumination.

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace the malfunctioning parts.

8. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

ANY DOOR OPEN TO ALL DOORS CLOSED

ANY DOOR OPEN TO ALL DOORS CLOSED : Description

INFOID:000000004343551

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

ANY DOOR OPEN TO ALL DOORS CLOSED : Diagnosis Procedure

INFOID:000000004343552

1. CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59, "DTC Logic"](#) (instrument center).

Refer to [DLK-61, "DTC Logic"](#) (console).

Refer to [DLK-63, "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

PUSH-BUTTON IGNITION SWITCH OPERATION

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

PUSH-BUTTON IGNITION SWITCH OPERATION : Description

INFOID:000000004343553

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39. "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

PUSH-BUTTON IGNITION SWITCH OPERATION : Diagnosis Procedure

INFOID:000000004343554

1.CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-167. "DTC Index"](#).

2.CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-66. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-106. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59. "DTC Logic"](#) (instrument center).

Refer to [DLK-61. "DTC Logic"](#) (console).

Refer to [DLK-63. "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

INTELLIGENT KEY IS REMOVED FROM KEY SLOT

INTELLIGENT KEY IS REMOVED FROM KEY SLOT : Description

INFOID:000000004343557

NOTE:

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).
- Door lock function is normal.

INTELLIGENT KEY IS REMOVED FROM KEY SLOT : Diagnosis Procedure

INFOID:000000004343558

1.CHECK KEY SLOT

Check key slot.

Refer to [DLK-99, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59, "DTC Logic"](#) (instrument center).

Refer to [DLK-61, "DTC Logic"](#) (console).

Refer to [DLK-63, "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK KEY SLOT ILLUMINATION

Check key slot illumination.

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

Description

INFOID:000000004343559

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39. "WARNING FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343560

1.CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

Check "LO- BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

Refer to [DLK-53. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "LO- BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

2.CHECK INTELLIGENT KEY BATTERY

Check Intelligent Key battery.

Refer to [DLK-97. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-105. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59. "DTC Logic"](#) (instrument center).

Refer to [DLK-61. "DTC Logic"](#) (console).

Refer to [DLK-63. "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK KEY SLOT ILLUMINATION

Check key slot illumination.

Refer to [DLK-101. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR LOCK OPERATION WARNING DOES NOT OPERATE WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

DOOR LOCK OPERATION WARNING DOES NOT OPERATE WITH DOOR REQUEST SWITCH

Description

INFOID:000000004343561

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343562

1.CHECK DOOR LOCK FUNCTION

Check door lock function by door request switch.

Does door lock/unlock with door request switch?

YES >> GO TO 2.

NO-1 >> Go to [DLK-174, "DRIVER SIDE : Description"](#) (driver side).

NO-2 >> Go to [DLK-175, "PASSENGER SIDE : Description"](#) (passenger side).

NO-3 >> Go to [DLK-175, "BACK DOOR : Description"](#) (back door).

2.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-66, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-95, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to [DLK-59, "DTC Logic"](#) (instrument center).

Refer to [DLK-61, "DTC Logic"](#) (console).

Refer to [DLK-63, "DTC Logic"](#) (luggage room).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

KEY ID WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

KEY ID WARNING DOES NOT OPERATE

Description

INFOID:000000004343563

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39. "WARNING FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343564

1.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-97. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK COMBINATION METER DISPLAY FUNCTION

Check combination meter display function.

Refer to [DLK-105. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

Description

INFOID:000000004343565

NOTE:

- Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7, "Work Flow"](#).
- Warning functions operating condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-39, "WARNING FUNCTION : System Description"](#).

Diagnosis Procedure

INFOID:000000004343566

1.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-97, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK COMBINATION METER DISPLAY FUNCTION

Check combination meter display function.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

INTEGRATED HOMELINK TRANSMITTER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

INTEGRATED HOMELINK TRANSMITTER DOES NOT OPERATE

Description

INFOID:000000004343567

NOTE:

Before performing the diagnosis in the following procedure, check "Work Flow". Refer to [DLK-7. "Work Flow"](#).

Diagnosis Procedure

INFOID:000000004343568

1.CHECK INTEGRATED HOMELINK TRANSMITTER

Check integrated homelink transmitter.

Refer to [DLK-109. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000004649266



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [DLK-210, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis ear: J-39570, Engine ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that is are suspected to be the cause of the noise.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
 - Placing a piece of paper between components that are suspected to be the cause of the noise.
 - Looking for loose components and contact marks.
Refer to [DLK-208. "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through the authorized Nissan Parts Department.

CAUTION:

Never use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that is be visible or does not fit. Will only last a few months.

SILICONE SPRAY

Used when grease cannot be applied.

DUCT TAPE

Used to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000004649267

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seats in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

Diagnostic Worksheet

INFOID:000000004649268







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[INTELLIGENT KEY SYSTEM]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- ☐ through driveways
- ☐ over rough roads
- ☐ over speed bumps
- ☐ only about ____ mph
- ☐ on acceleration
- ☐ coming to a stop
- ☐ on turns: left, right or either (circle)
- ☐ with passengers or cargo
- ☐ other: _____
- ☐ after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- ☐ squeak (like tennis shoes on a clean floor)
- ☐ creak (like walking on an old wooden floor)
- ☐ rattle (like shaking a baby rattle)
- ☐ knock (like a knock at the door)
- ☐ tick (like a clock second hand)
- ☐ thump (heavy, muffled knock noise)
- ☐ buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004343572

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000004343573

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >


[INTELLIGENT KEY SYSTEM]

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

Precaution for Procedure without Cowl Top Cover

INFOID:000000004343574

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



INFOID:000000004343575

Work

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operational.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

DLK

PREPARATION

< PREPARATION >

[INTELLIGENT KEY SYSTEM]



PREPARATION

PREPARATION

Special Service Tools




INFOID:000000004343576

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locates the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairs the cause of noise

Commercial Service Tools

INFOID:000000004343577

Tool name	Description
Engine ear  SIIA0995E	Locates the noise
Remover tool  JMK1A3050ZZ	Removes the clips, pawls and metal clips
Power tool  PIIB1407E	


REMOVAL AND INSTALLATION

HOOD

HOOD ASSEMBLY

HOOD ASSEMBLY : Exploded View

INFOID:000000004343578



- | | | |
|-----------------------|-------------------|---------------------|
| 1. Hood assembly | 2. Bumper rubber | 3. Seal |
| 4. Radiator core seal | 5. Hood insulator | 6. Hood hinge cover |
| 7. Hood hinge | 8. Stud ball | 9. Hood stay |
| 10. Hood seal (front) | | |

(L) : Apply Genuine High Strength Locking Sealant or equivalent.

Refer to [GI-4, "Components"](#) for symbols in the figure.

HOOD ASSEMBLY : Removal and Installation

INFOID:000000004343579

CAUTION:


Operate with 2 workers, because of its heavy weight.

REMOVAL

1. Remove hood hinge cover (LH/RH) (1).

NOTE:

While pushing the pawls, pull hood hinge cover in the direction of the arrow.



HOOD

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

2. Remove washer nozzle, washer tube. Refer to [WW-104. "Removal and Installation"](#).
3. Support hood lock assembly with a proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the hood open when removing the hood stay.

4. Remove the metal clip (3) located on the connection between the hood stay (1) and the stud ball (2) (hood side), by using a flattened-blade screwdriver (A).
5. Disengage the stud ball from the hood stay (hood side).




6. Remove hinge mounting nuts on the hood to remove the hood assembly.
7. Remove following parts after removing the hood assembly.
 - Radiator core seal
 - Hood insulator
 - Hood bumper rubber
 - Hood seal (front)
 - Hood striker

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Before installing hood seal (front)(1), apply double-faced adhesive tape (2).
- Check that both ends of hood seal (front) is below than front combination lamp (3).



- Before installing hood hinge, apply anticorrosive agent onto the mounting surface of the vehicle body.
- After installing, perform hood fitting adjustment. Refer to [DLK-217. "HOOD ASSEMBLY : Adjustment"](#).
- After installing, perform front washer nozzle and tube inspection and adjustment. Refer to [WW-104. "Inspection and Adjustment"](#).


HOOD

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

HOOD ASSEMBLY : Adjustment

INFOID:000000004343580



- | | | |
|---------------------------|-----------------|------------------------|
| 1. Hood assembly | 2. Hood striker | 3. Hood bumper rubber |
| 4. Hood hinge | 5. Front grill | 6. Front bumper fascia |
| 7. Front combination lamp | 8. Front fender | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and the surface height between hood and each part visually and by touching. (Fitting standard dimension in the table below should be satisfied.

If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion				Standard	Difference (LH/RH, MAX)
Hood – Front grille	A – A	E	Clearance	2.6 – 7.4 (0.102 – 0.291)	—
		F	Clearance	1.5 – 5.5 (0.059 – 0.217)	2.5 (0.098)
Hood – Front bumper fascia	B – B	G	Surface height	–1.0 – 3.0 (–0.039 – 0.118)	2.0 (0.079)

HOOD

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

Portion				Standard	Difference (LH/RH, MAX)
Hood – Front combination lamp	C – C	H	Clearance	1.5 – 5.5 (0.059 – 0.217)	2.0 (0.079)
		I	Surface height	–2.0 – 2.0 (–0.079 – 0.079)	2.1 (0.083)
Hood – Front fender	D – D	J	Clearance	2.5 – 4.5 (0.098 – 0.177)	2.0 (0.079)
		K	Surface height	–1.0 – 1.0 (–0.039 – 0.039)	—
Hood striker – Bumper rubber	—	L	Clearance	32.5 – 33.5 (1.280 – 1.319)	—

1. Remove striker and adjust the surface height of hood, front bumper fascia and front fender according to the fitting standard dimension, by rotating hood bumper rubbers.
2. Adjust the height difference of striker, hood bumper rubber according to the fitting standard dimension.
3. Loosen hood hinge mounting nuts on the hood.
4. Adjust the clearance of hood, front bumper fascia, front grill and front fender according to the fitting standard dimension, for the hood.
5. Check that hood lock primary latch is securely engaged with striker by dropping hood from approximately 200 mm (7.874 in) height or pressing lightly on the hood.

CAUTION:

Never drop hood from a height of 300 mm (11.811 in) or more.

6. Install as static closing face of hood is 94 – 490 N·m (9.6 – 50.0 kg·m).

NOTE:

- Exercise vertical force on right side and left side of hood lock.
- Never press simultaneously both sides.

7. After adjustment tighten hood hinge mounting nuts to the specified torque.

HOOD HINGE


HOOD

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

HOOD HINGE : Exploded View

INFOID:000000004650127



- | | | |
|-----------------------|-------------------|---------------------|
| 1. Hood assembly | 2. Bumper rubber | 3. Seal |
| 4. Radiator core seal | 5. Hood insulator | 6. Hood hinge cover |
| 7. Hood hinge | 8. Stud ball | 9. Hood stay |
| 10. Hood seal (front) | | |

(L) : Apply Genuine High Strength Locking Sealant or equivalent.

Refer to [GI-4, "Components"](#) for symbols in the figure.

HOOD HINGE : Removal and Installation


INFOID:000000004343582

REMOVAL

1. Remove hood hinge cover (LH/RH) (1).

NOTE:

While pushing the pawls, pull hood hinge cover in the direction of the arrow.



2. Remove hood assembly. Refer to [DLK-215, "HOOD ASSEMBLY : Removal and Installation"](#).
3. Remove front fender. Refer to [DLK-225, "Removal and Installation"](#).
4. Remove hood hinge mounting bolts, and then remove hood hinge.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

HOOD

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

- Before installation of hood hinge, apply anticorrosive agent onto the surface of the vehicle body.
- Before installation of hood hinge, drop genuine high strength locking sealant or equivalent into bolt hole of hood hinge (body side).
- After installation, apply touch-up paint (the body color) onto the head of the hinge mounting bolts and nuts.
- After installation, perform hood fitting adjustment. Refer to [DLK-217. "HOOD ASSEMBLY : Adjustment"](#).


HOOD STAY

HOOD STAY : Exploded View

INFOID:000000004650132



- | | | |
|-----------------------|-------------------|---------------------|
| 1. Hood assembly | 2. Bumper rubber | 3. Seal |
| 4. Radiator core seal | 5. Hood insulator | 6. Hood hinge cover |
| 7. Hood hinge | 8. Stud ball | 9. Hood stay |
| 10. Hood seal (front) | | |

 (L) : Apply Genuine High Strength Locking Sealant or equivalent.

Refer to [GI-4. "Components"](#) for symbols in the figure.

HOOD STAY : Removal and Installation

INFOID:000000004343584

REMOVAL

1. Support hood lock assembly with a proper material to prevent it from falling.

WARNING:


Body injury may occur if no supporting rod is holding the hood open when removing the hood stay.

HOOD

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

2. Remove the metal clip (3) located on the connection between the hood stay (1) and the stud ball (2) (hood side), by using a flat-bladed screwdriver (A).
3. Disengage the stud ball from the hood stay (hood side).
4. Repeat the same operation to disengage the stud ball from the hood stay (body side), then remove the hood stay.



INSTALLATION

Install in the reverse order of removal.


HOOD STAY : Disposal

INFOID:000000004650135

1. Fix hood stay (1) using a vise (C).
2. Using hacksaw (A) slowly make 2 holes in the hood stay, in numerical order as shown in the figure.


CAUTION:

- When cutting a hole on hood stay, always cover a hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20 mm (0.787 in)

B: Cut at the groove.



RADIATOR CORE SUPPORT


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

RADIATOR CORE SUPPORT

Exploded View

INFOID:000000004343585



- | | | |
|----------------------|------------------------------|------------------------------|
| 1. Hood lock cover | 2. Hood lock bracket (LH/RH) | 3. Head lamp bracket (LH/RH) |
| 4. Air guide (LH/RH) | 5. Hood lock stay assembly | 6. Radiator core support |

Removal and Installation

INFOID:000000004343586

REMOVAL

1. Use a refrigerant collecting equipment to discharge the refrigerant. Refer to [HA-25, "Collection and Charge"](#).
2. Drain engine coolant from radiator. Refer to [CO-7, "Draining"](#).
3. Remove engine under cover. Refer to [EXT-31, "Removal and Installation"](#).
4. Remove front grille. Refer to [EXT-20, "Removal and Installation"](#).
5. Remove front bumper fascia, energy absorber, reinforcement. Refer to [EXT-13, "Removal and Installation"](#).
6. Remove mounting bolts of hood lock cover.
7. Disconnect harness clip and hood lock cable from hood lock cover.
8. Remove hood lock cover.


RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

9. Remove front combination lamp (LH/RH). Refer to [EXL-192, "Removal and Installation"](#) (XENON TYPE) or [EXL-351, "Removal and Installation"](#) (HALOGEN TYPE).
10. Disconnect hood lock switch connector (A) from head lamp bracket (RH) (1).
11. Remove mounting bolts and remove hood lock bracket (2) (LH/RH).

← : Bolt



12. Disconnect hood lock cable from hood lock (LH/RH).
13. Disassembly hood lock from hood lock bracket (LH/RH).
14. Disconnect all clamp of hood cable from radiator core support assembly.
15. Disconnect harness connector of refrigerant pressure sensor. Refer to [HAC-151, "Removal and Installation"](#).
16. Disconnect harness connector of ambient sensor. Refer to [HAC-145, "Removal and Installation"](#).
17. Remove air guide (LH).
18. Remove ICC sensor integrated unit (with intelligent cruise control model). Refer to [CCS-180, "Removal and Installation"](#).
19. Remove horn (Hi/Lo). Refer to [HRN-6, "Removal and Installation"](#).
20. Remove intelligent key warning buzzer. Refer to [DLK-265, "Removal and Installation"](#).
21. Disconnect harness clamp from hood lock stay.
22. Remove mounting bolt and nut, and remove hood lock stay.
23. Remove washer tank. Refer to [WW-101, "Removal and Installation"](#).
24. Remove power steering oil cooler. Refer to [ST-50, "2WD : Exploded View"](#) (2WD) or [ST-51, "AWD : Exploded View"](#) (AWD).
25. Remove air guide (RH).
26. Remove mounting bolt of power steering oil cooler pipe bracket. Refer to [ST-50, "2WD : Exploded View"](#) (2WD) or [ST-51, "AWD : Exploded View"](#) (AWD).
27. Remove air cleaner box (LH/RH). Refer to [EM-27, "Removal and Installation"](#).
28. Remove front under side cover (LH). Refer to [EXT-31, "Removal and Installation"](#).
29. Remove radiator upper hose and lower hose at radiator side. Refer to [CO-12, "Removal and Installation"](#).
30. Remove mounting bolts of condenser assembly from radiator core support assembly. Refer to [HA-49, "CONDENSER : Removal and Installation"](#).
31. Disconnect AT fluid cooler hose (upper/lower) from fan shroud and remove AT fluid cooler hose (upper/lower) from radiator. Refer to [TM-191, "2WD : Removal and Installation"](#) (2WD) or [TM-193, "AWD : Removal and Installation"](#) (AWD).
32. Remove condenser assembly. Refer to [HA-49, "CONDENSER : Removal and Installation"](#).
33. Remove radiator. Refer to [CO-12, "Removal and Installation"](#).
34. Disconnect harness connector of crash zone sensor. Refer to [SR-21, "Removal and Installation"](#).
35. Disconnect harness connector of cooling fan control module. Refer to [CO-15, "Removal and Installation"](#).
36. Disconnect all harness clip from radiator core support assembly.
37. Remove mounting bolts, and then remove radiator core support assembly.
CAUTION:
Operate with two workers, because of its heavy weight.
38. Remove the following parts after removing radiator core support assembly.
 - Head lamp bracket
 - Cooling fan (LH/RH): Refer to [CO-15, "Removal and Installation"](#).
 - Crash zone sensor: Refer to [SR-21, "Removal and Installation"](#).
 - Ambient sensor: Refer to [HAC-145, "Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Replenish the following parts.
 - Refrigerant: Refer to [HA-25, "Collection and Charge"](#).
 - Engine coolant: Refer to [CO-8, "Refilling"](#).
 - AT fluid: Refer to [TM-142, "Changing"](#).
 - Power steering oil: Refer to [ST-11, "Inspection"](#).
- Adjust the following parts.
 - ICC sensor integrated unit (with intelligent cruse control model): Refer to [CCS-13, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(ICC SENSOR INTEGRATED UNIT\) : Description"](#).
 - Front combination lamp: Refer to [EXL-188, "Aiming Adjustment Procedure"](#) (XENON TYPE) or [EXL-348, "Aiming Adjustment Procedure"](#) (HALOGEN TYPE).
 - Around view monitor (BOSE AUDIO WITH NAVIGATION): Refer to [AV-173, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Special Repair Requirement"](#)

FRONT FENDER


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

FRONT FENDER

Exploded View

INFOID:000000004343587



1. Front fender cover

2. Hood seal assembly (side)

3. Front fender

△ : Pawl

Removal and Installation

INFOID:000000004343588


DLK

CAUTION:

Use a shop cloth to protect the body from being damaged during removal and installation.

REMOVAL

1. Remove the following parts.
 - LH side
Brake master cylinder cover and hood ledge cover (LH): Refer to [EXT-23. "Removal and Installation"](#).
 - RH side
Battery cover and hood ledge cover (RH): Refer to [EXT-23. "Removal and Installation"](#).
2. Remove clips as shown in the figure by arrows, and remove hood seal assembly (side).



1. Hood seal assembly (side)

2. Cowl top cover

FRONT FENDER

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

3. Remove fender protector. Refer to [EXT-25, "FENDER PROTECTOR : Removal and Installation"](#).
4. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
5. Remove front combination lamp. Refer to [EXL-192, "Removal and Installation"](#) (XENON TYPE) or [EXL-351, "Removal and Installation"](#) (HALOGEN TYPE).
6. Remove front fender cover.
7. Remove fillet molding. Refer to [EXT-32, "Removal and Installation"](#).
8. Remove center mod guard. Refer to [EXT-29, "Removal and Installation"](#).
9. Remove mounting bolts except bolt of windshield side.
10. Loosen the mounting bolt (windshield glass side), then pull the front fender upward to remove it.

CAUTION:

- The mounting bolt (windshield glass side) can not be removed because there is not enough space, between the front fender and the windshield glass.
- A viscous urethane foam is installed on the back surface of front fender. When removing the front fender, peel of the urethane foam bit at a time, and carefully to remove it.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- After installation, check front fender adjustment. Refer to [DLK-217, "HOOD ASSEMBLY : Adjustment"](#) and [DLK-228, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply the touch-up paint (the body color) onto the head of front fender mounting bolts.
- Adjust the following part.
 - Front combination lamp: Refer to [EXL-188, "Aiming Adjustment Procedure"](#) (XENON TYPE) or [EXL-348, "Aiming Adjustment Procedure"](#) (HALOGEN TYPE).
 - Around view monitor (BOSE AUDIO WITH NAVIGATION): Refer to [AV-173, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Special Repair Requirement"](#)

FRONT DOOR


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

FRONT DOOR DOOR ASSEMBLY

DOOR ASSEMBLY : Exploded View

INFOID:000000004343589



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR ASSEMBLY : Removal and Installation

INFOID:000000004343590

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing front door assembly, support door with a jack and cloth to protect door and body.

REMOVAL

1. Remove mounting bolts of door check link on the vehicle.
2. Remove front door harness grommet, and then pull out the harness from the vehicle.
3. Disconnect front door harness connector.
4. Remove door hinge mounting nuts (door side), and then remove door assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check front door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment. Refer to [DLK-228, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.


FRONT DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR ASSEMBLY : Adjustment

INFOID:000000004343591



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. TORX bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and surface height between front door and each part by visually and touching.
If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion		Clearance	Surface height
Front fender – Front door	A – A	2.6 – 4.6 (0.102 – 0.181)	- 1.0 – 1.0 (- 0.039 – 0.039)
Front door – Rear door	B – B	2.6 – 4.6 (0.102 – 0.181)	- 1.0 – 1.0 (- 0.039 – 0.039)

1. Remove front fender. Refer to [DLK-225, "Removal and Installation"](#).
2. Loosen door hinge mounting nuts on door side.
3. Adjust the surface height of front door according to the fitting standard dimension.
4. Temporarily tighten door hinge mounting nuts on door side.
5. Loosen door hinge mounting bolts on body side.

FRONT DOOR

[INTELLIGENT KEY SYSTEM]

< REMOVAL AND INSTALLATION >

6. Raise front door at rear end to adjust clearance of the front door according to the fitting standard dimension.
7. After adjustment tighten bolts and nuts to the specified torque.
8. Install front fender. Refer to [DLK-225, "Removal and Installation"](#).


DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Exploded View

INFOID:000000004650136



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR STRIKER : Removal and Installation

INFOID:000000004343593

REMOVAL

Remove TORX bolts, and then remove door striker.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check front door open/close, lock/unlock operation after installation.
- After installation, check to perform the fitting adjustment. Refer to [DLK-228, "DOOR ASSEMBLY : Adjustment"](#).

DOOR HINGE


FRONT DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR HINGE : Exploded View

INFOID:000000004653326



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR HINGE : Removal and Installation

INFOID:000000004343595

REMOVAL

1. Remove front fender. Refer to [DLK-225, "Removal and Installation"](#)
2. Remove front door assembly. Refer to [DLK-227, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove front door hinge mounting bolts, and then remove front door hinge.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check front door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment. Refer to [DLK-228, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.

DOOR CHECK LINK


FRONT DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR CHECK LINK : Exploded View

INFOID:000000004653327



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR CHECK LINK : Removal and Installation

INFOID:000000004343597

DLK

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14, "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Fully close the front door window.
3. Remove front door speaker. Refer to [AV-155, "Removal and Installation"](#) (base audio without navigation) or [AV-577, "Removal and Installation"](#) (BOSE audio with navigation).
4. Remove mounting bolts of door check link on the vehicle.
5. Remove mounting bolts of door check link on door panel.
6. Take door check link out from the hole of door panel.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check front door open/close operation after installation.

REAR DOOR


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

REAR DOOR DOOR ASSEMBLY

DOOR ASSEMBLY : Exploded View

INFOID:000000004343598



- | | | |
|--------------------|-----------------------|-----------------------|
| 1. Rear door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Seal rubber | 6. Bumper rubber |
| 7. Door check link | 8. Door hinge (lower) | 9. Door hinge (upper) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR ASSEMBLY : Removal and Installation

INFOID:000000004343599

CAUTION:

- Perform work with 2 workers, because of it's heavy weight.
- When removing and installing rear door assembly, support door with a jack and cloth to protect door and body.

REMOVAL

1. Remove mounting bolts of door check link on the vehicle.
2. Remove rear door harness grommet, and then pull out door harness from the vehicle.
3. Disconnect rear door harness connector.
4. Remove door hinge mounting nuts (door side), and then remove rear door assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check rear door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment. Refer to [DLK-233, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.


REAR DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR ASSEMBLY : Adjustment

INFOID:000000004343600



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. TORX bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and surface height between rear door and each part by visually and touching.
If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion		Clearance	Surface height
Front door – Rear door	B – B	2.6 – 4.6 (0.102 – 0.181)	-1.0 – 1.0 (-0.039 – 0.039)
Rear door – Body side outer	C – C	2.6 – 4.6 (0.102 – 0.181)	-1.0 – 1.0 (-0.039 – 0.039)

- Remove center pillar lower garnish. Refer to [INT-20, "Removal and Installation"](#).
- Loosen door hinge mounting nuts on door side.
- Adjust the surface height of rear door according to the fitting standard dimension.
- Temporarily tighten door hinge mounting nuts on door side.
- Loosen door hinge mounting nuts and bolts on body side.
- Raise rear door at rear end to adjust clearance of rear door according to the fitting standard dimension.

REAR DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

7. After adjustment tighten bolts and nuts to the specified torque.

8. Install center pillar lower garnish. Refer to [.INT-20, "Removal and Installation"](#)


DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Exploded View

INFOID:00000000465328



- | | | |
|--------------------|-----------------------|-----------------------|
| 1. Rear door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Seal rubber | 6. Bumper rubber |
| 7. Door check link | 8. Door hinge (lower) | 9. Door hinge (upper) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR STRIKER : Removal and Installation

INFOID:000000004343602

REMOVAL

Remove TORX bolts, and then remove door striker.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check rear door open/close, lock/unlock operation after installation.
- After installation, check to perform the fitting adjustment. Refer to [DLK-233, "DOOR ASSEMBLY : Adjustment"](#).

DOOR HINGE


REAR DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR HINGE : Exploded View

INFOID:000000004653329



- | | | |
|--------------------|-----------------------|-----------------------|
| 1. Rear door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Seal rubber | 6. Bumper rubber |
| 7. Door check link | 8. Door hinge (lower) | 9. Door hinge (upper) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR HINGE : Removal and Installation

INFOID:000000004343604

REMOVAL

1. Remove center pillar lower garnish. Refer to [INT-20, "Removal and Installation"](#).
2. Remove rear door assembly. Refer to [DLK-232, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove rear door hinge mounting bolts and nuts (body side), and then remove door hinge.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check rear door open/close operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- When removing and installing rear door assembly, perform the fitting adjustment. Refer to [DLK-233, "DOOR ASSEMBLY : Adjustment"](#).
- After installing, apply the touch-up paint (the body color) onto the head of door hinge mounting nuts.

DOOR CHECK LINK


REAR DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR CHECK LINK : Exploded View

INFOID:000000004653330



- | | | |
|--------------------|-----------------------|-----------------------|
| 1. Rear door panel | 2. Grommet | 3. Door striker |
| 4. TORX bolt | 5. Seal rubber | 6. Bumper rubber |
| 7. Door check link | 8. Door hinge (lower) | 9. Door hinge (upper) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR CHECK LINK : Removal and Installation

INFOID:000000004343606

REMOVAL

1. Remove rear door finisher. Refer to [INT-17, "Removal and Installation"](#).
2. Fully close the rear door window.
3. Remove rear door speaker. Refer to [AV-156, "Removal and Installation"](#) (BOSE audio without navigation) or [AV-578, "Removal and Installation"](#) (BOSE audio with navigation).
4. Remove mounting bolts of the check link on the vehicle.
5. Remove mounting bolts of the check link on door panel.
6. Take door check link out from the hole of door panel.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check rear door open/close operation after installation.

BACK DOOR

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

BACK DOOR

BACK DOOR ASSEMBLY

BACK DOOR ASSEMBLY : Exploded View

INFOID:000000004343607



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |
- A : Center mark

Refer to [GI-4, "Components"](#) for symbols in the figure.

BACK DOOR ASSEMBLY : Removal and Installation

INFOID:000000004343608

CAUTION:

Operate with two workers, because of its heavy weight.

NOTE:

The back door harness constitute the back door assembly.

REMOVAL


1. Remove back door finisher inner, back door plate, back door hinge cover. Refer to [INT-38, "Removal and Installation"](#).
2. Remove clips of head lining at rear end. Refer to [INT-27, "NORMAL ROOF : Removal and Installation"](#) (NORMAL ROOF) or [INT-30, "SUNROOF : Removal and Installation"](#) (SUNROOF).

BACK DOOR

[INTELLIGENT KEY SYSTEM]


< REMOVAL AND INSTALLATION >

3. Disconnect harness connectors and bolts as shown in the figure by arrows.
4. Remove grommet (LH) (1), and then pull harness out of vehicle at roof panel (2) hole.



5. Remove grommet (RH), and then disconnect washer tube (1).

← : Detaching points



6. Pull washer tube out of back door.
7. Support back door lock with the proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the back door open when removing the back door stay.

8. Remove back door stay. Refer to [DLK-242, "BACK DOOR STAY : Removal and Installation"](#).
9. Remove back door hinge mounting bolts on back door and remove back door assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Check back door open/close, lock/unlock operation after installation.
- After installation, perform fitting adjustment. Refer to [DLK-239, "BACK DOOR ASSEMBLY : Adjustment"](#).


BACK DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

BACK DOOR ASSEMBLY : Adjustment

INFOID:000000004343609



- | | | |
|-----------------------|------------------|--------------------|
| 1. Back door assembly | 2. Bumper rubber | 3. Back door hinge |
| 4. Back door striker | 5. Roof | 6. Body side outer |
| 7. Rear bumper fascia | | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and the surface height between back door and each part by visually and touching.
If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion			Standard
Back door – Roof	A – A	E	Clearance
		F	Surface height
Back door – Body side outer	B – B	G	Clearance
		H	Surface height
Back door – Rear bumper fascia	C – C	I	Clearance
		J	Surface height
Back door – Rear bumper fascia	D – D	K	Clearance

BACK DOOR

[INTELLIGENT KEY SYSTEM]

< REMOVAL AND INSTALLATION >

1. Remove back door hinge cover. Refer to [INT-38, "Removal and Installation"](#).
2. Loosen back door hinge mounting bolts (back door side).
3. Loosen bumper rubber (side/lower).
4. Remove luggage rear plate mask. Refer to [INT-35, "Removal and Installation"](#).
5. Loosen back door striker mounting bolts.
6. Lift up back door approximately 100 – 150 mm (3.937 – 5.906 in) height then close it lightly and check that it is engaged firmly with back door closed.
7. Check the clearance and surface height.
8. Finally tighten back door hinge, bumper rubber, and back door striker.
9. Install back door hinge cover and luggage rear plate mask. Refer to [INT-38, "Removal and Installation"](#) and [INT-35, "Removal and Installation"](#)


BACK DOOR STRIKER ADJUSTMENT

Adjust back door striker so that it becomes parallel with back door lock insertion direction.

BACK DOOR STRIKER

BACK DOOR STRIKER : Exploded View

INFOID:0000000004653331



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |

A : Center mark

Refer to GI-4, "Components" for symbols in the figure.

BACK DOOR STRIKER : Removal and Installation

INFOID:0000000004343611

REMOVAL

1. Remove luggage rear plate mask. Refer to [INT-35, "Removal and Installation"](#).
2. Remove mounting bolts, and then remove back door striker.

BACK DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

INSTALLATION

Install in the reverse order of removal.


CAUTION:

- Check back door open/close operation after installation.
- When removing and installing back door striker, check to perform the fitting adjustment. Refer to [DLK-239, "BACK DOOR ASSEMBLY : Adjustment"](#).

BACK DOOR HINGE

BACK DOOR HINGE : Exploded View

INFOID:000000004653332



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |

A : Center mark

Refer to [GI-4, "Components"](#) for symbols in the figure.

BACK DOOR HINGE : Removal and Installation

INFOID:000000004343613

REMOVAL

1. Remove luggage side lower finisher and luggage side upper finisher. Refer to [INT-35, "Removal and Installation"](#).
2. Using a remover tool, remove headlining clip at the rear side of headlining, and then remove rear side of headlining. Refer to [INT-27, "NORMAL ROOF : Removal and Installation"](#) (NORMAL ROOF), [INT-30, "SUNROOF : Removal and Installation"](#) (SUNROOF).
3. Remove back door assembly. Refer to [DLK-237, "BACK DOOR ASSEMBLY : Removal and Installation"](#).
4. Remove back door hinge mounting nuts (body side), and then remove back door hinge.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

BACK DOOR

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

- Check back door open/close operation after installation.
- Check back door hinge rotating part for poor lubrication. If necessary, apply body grease.
- When removing and installing back door assembly, perform the fitting adjustment. Refer to [DLK-239, "BACK DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of back door hinge mounting nuts.

BACK DOOR STAY

BACK DOOR STAY : Exploded View

INFOID:000000004653333



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |

A : Center mark

Refer to [GI-4, "Components"](#) for symbols in the figure.

BACK DOOR STAY : Removal and Installation

INFOID:000000004343615

REMOVAL

1. Support back door lock with the proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the back door open when removing the back door stay.


2. Remove mounting bolts of back door stay (body side).

BACK DOOR

[INTELLIGENT KEY SYSTEM]

< REMOVAL AND INSTALLATION >

3. Remove the metal clip (3) located on the connection between the back door stay (1) and the stud ball (2) (back door side) by using a flattened-blade screwdriver (A).
4. Remove back door stay (back door side).



5. Remove mounting bolts of stud ball assembly, and then remove stud ball assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check back door open/close operation after installation.


BACK DOOR STAY : Disposal

INFOID:000000004653335

1. Fix back door stay (1) using a vise (C).
2. Using hacksaw (A) slowly make 2 holes in the back door stay, in numerical order as shown in the figure.


CAUTION:

- When cutting a hole on back door stay, always cover a hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20 mm (0.787 in)

B: Cut at the groove.



BACK DOOR WEATHER-STRIP


BACK DOOR

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

BACK DOOR WEATHER-STRIP : Exploded View

INFOID:00000000465334



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |

A : Center mark

Refer to [GI-4, "Components"](#) for symbols in the figure.

BACK DOOR WEATHER-STRIP : Removal and Installation

INFOID:000000004343617

REMOVAL

Pull up and remove engagement with body from weather-strip joint.

CAUTION:

Never pull strongly on weather-strip.

INSTALLATION

- Working from the upper section, align weather-strip mark with vehicle center position mark and install weather-strip onto the vehicle.
- For the lower section, align weather-strip seam with center of back door striker.
- Pull weather-strip gently to ensure that there is no loose section.

NOTE:

Check that weather-strip is fit tightly at each corner and luggage rear plate.

- Install mounting bolts of power back door drive assembly (Back door side).

HOOD LOCK


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

HOOD LOCK

Exploded View

INFOID:000000004343618



- | | | |
|--|------------------------------------|--------------------------------------|
| 1. Hood striker (LH/RH) | 2. Hood lock cover (LH/RH) | 3. Hood lock (LH/RH) |
| 4. Secondary latch | 5. Hood lock control cable (front) | 6. Hood lock control cable protector |
| 7. Hood lock control cable protector cover | 8. Hood lock control cable (rear) | 9. Hood lock opener |

⊖ : Clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000004343619


REMOVAL

CAUTION:

Check wiring of hood lock control before removal.

1. Remove mounting clips, of front grille upper side and front bumper fascia. Refer to [EXT-20, "Removal and Installation"](#) and [EXT-13, "Removal and Installation"](#).

◀ : Clip




2. Remove mounting bolts of hood lock cover.
3. Disconnect harness clip and hood lock cable from hood lock cover.
4. Remove hood lock cover.

HOOD LOCK

[INTELLIGENT KEY SYSTEM]

< REMOVAL AND INSTALLATION >


5. Remove air cleaner case assembly (LH). Refer to [EM-27. "Removal and Installation"](#).
6. Disconnect hood lock switch connector from head lamp bracket (RH).




← : hood lock switch connector

7. Remove mounting bolts and remove hood lock bracket (LH/RH).
8. Disconnect hood lock cable from hood lock (LH/RH).
9. Disassembly hood lock from hood lock bracket (LH/RH).
10. Remove fender protector (LH). Refer to [EXT-25. "FENDER PROTECTOR : Removal and Installation"](#).
11. Remove clips of hood seal assembly (side) (LH) (1).

← : Clip



12. Rotate hood lock control cable protector (1) toward the arrow direction, then remove it from front combination lamp assembly (2).



13. Remove hood lock control cable cover from hood lock control cable protector.
14. Disconnect hood lock control cable from hood lock control cable protector.
15. Remove mounting bolts and remove hood lock opener.
16. Remove grommet on the lower dash, pull hood lock control cable toward the passenger compartment.

CAUTION:

While pulling, never to damage (peeling) the outside of the hood lock control cable.

INSTALLATION

Install in the reverse order of removal.

CAUTION:


- **Never to bend cable too much, keeping the radius 100 mm (3.937 in) or more.**

HOOD LOCK

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

- Check that cable is not offset from the positioning grommet, and apply the sealant to the grommet (at * mark) properly.



- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood fitting adjustment. Refer to [DLK-217, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-247, "Inspection"](#).

Inspection

INFOID:0000000004343620

NOTE:

If the hood lock cable is bent or deformed, replace it.

1. Check that secondary latch is properly engaged with secondary striker [6.8 mm (0.268 in)] by hood weight.
2. While operating hood opener, carefully check that the front end of hood is raised by approximately 20.0 mm (0.787 in). Also check that hood opener returns to the original position.
3. Check that hood opener operating is condition 49 N (5.0 kg, 11.0 lb) or below.
4. Install so that static closing force of hood is 94 – 490 N·m (9.6 – 50.0 kg-m, 69 – 361 ft – lb).

NOTE:

- Exert vertical force on right side and left side of hood lock.
 - Never press simultaneously both sides.
5. Check the hood lock lubrication condition. If necessary, apply body grease to hood lock.

DLK

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

FRONT DOOR LOCK

DOOR LOCK

DOOR LOCK : Exploded View

INFOID:000000004343621



- | | | |
|---|-----------------------|-------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. TORX bolt |
| 4. Key rod (driver side) | 5. Door lock assembly | 6. Inside handle |
| 7. Outside handle bracket | 8. Front gasket | 9. Outside handle |

↔ : Vehicle front

Refer to [GI-4. "Components"](#) for symbols in the figure.

DOOR LOCK : Removal and Installation

INFOID:000000004343622

REMOVAL

1. Remove front door finisher. Refer to [INT-11. "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14. "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Remove front door glass. Refer to [GW-16. "Removal and Installation"](#).
3. Remove front door module assembly. Refer to [GW-19. "Removal and Installation"](#).
4. Disconnect door antenna and door request switch connector and remove harness clamp (with Intelligent Key system model) on outside handle bracket.

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

5. Remove door side grommet, and loosen TORX bolt from grommet hole.


CAUTION:

Never remove TORX bolt forcibly.


← : TORX bolt




6. Reach in to separate key rod (2) connection [on the door key cylinder assembly (1)] (driver side).



7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).



8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



9. Remove front gasket and rear gasket.


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

FRONT DOOR LOCK

[INTELLIGENT KEY SYSTEM]

< REMOVAL AND INSTALLATION >

10. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



11. Reach in to separate outside handle cable connection on outside handle bracket.
12. Remove door lock assembly TORX bolts.
13. Disconnect door lock actuator connector, and then remove door lock assembly.
14. Remove key rod from door lock assembly.

INSTALLATION

Install in the reverse order of removal.


CAUTION:

- When installing each rod, rotate rod holder until a click is felt.
- Check door open/close, lock/unlock operation after installation.

INSIDE HANDLE

INSIDE HANDLE : Exploded View

INFOID:000000004653391



- | | | |
|---|-----------------------|-------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. TORX bolt |
| Outside handle escutcheon (passenger side) | | |
| 4. Key rod (driver side) | 5. Door lock assembly | 6. Inside handle |
| 7. Outside handle bracket | 8. Front gasket | 9. Outside handle |

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

↩ : Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

INSIDE HANDLE : Removal and Installation

INFOID:000000004343624

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14, "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Disconnect inside handle cable, and then remove the inside handle.
3. Remove inside handle mounting screws.

INSTALLATION

Install in the reverse order of removal.


CAUTION:

Check door open/close, lock/unlock operation after installation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Exploded View

INFOID:000000004653392



- | | | |
|---|-----------------------|-------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. TORX bolt |
| Outside handle escutcheon (passenger side) | | |
| 4. Key rod (driver side) | 5. Door lock assembly | 6. Inside handle |
| 7. Outside handle bracket | 8. Front gasket | 9. Outside handle |

↩ : Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

OUTSIDE HANDLE : Removal and Installation

INFOID:000000004343626

REMOVAL

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

1. Remove front door finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14, "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Remove front door glass. Refer to [GW-16, "Removal and Installation"](#).
3. Remove front door module assembly. Refer to [GW-19, "Removal and Installation"](#).
4. Disconnect door antenna and door request switch connector and remove harness clamp (models with Intelligent Key system) on outside handle bracket.
5. Remove door side grommet, and loosen TORX bolt from grommet hole.


CAUTION:

Never remove TORX bolt forcibly.


← : TORX bolt




6. Reach in to separate key rod (2) connection [on the door key cylinder assembly (1)] (driver side).



7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).



8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.




9. Remove front gasket and rear gasket.

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

10. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



11. Reach in to separate outside handle cable connection on outside handle bracket.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- When installing each rod, rotate rod holder until a click is felt.
- Check door open/close, lock/unlock operation after installation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REAR DOOR LOCK

< REMOVAL AND INSTALLATION >


[INTELLIGENT KEY SYSTEM]

REAR DOOR LOCK

DOOR LOCK

DOOR LOCK : Exploded View

INFOID:000000004343627



- | | | |
|------------------------------|-------------------|---------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket | 3. TORX bolt |
| 4. Door lock assembly | 5. Inside handle | 6. Outside handle bracket |
| 7. Front gasket | 8. Outside handle | |

◀ : Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

DOOR LOCK : Removal and Installation

INFOID:000000004343628


REMOVAL

1. Remove rear door finisher. Refer to [INT-17, "Removal and Installation"](#).
2. Remove sealing screen. Refer to [GW-22, "Removal and Installation"](#).
3. Fully close the rear door glass.
4. Remove door side grommet, and loosen TORX bolt from grommet hole.

CAUTION:

Never remove TORX bolt forcibly.

◀ : TORX bolt




REAR DOOR LOCK


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]


5. While pulling outside handle, remove outside handle escutcheon.



6. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



7. Remove front gasket and rear gasket.
8. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



9. Reach in to separate outside handle cable connection on outside handle bracket.
10. Remove door lock mounting bolts.
11. Remove door lock assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check door open/close, lock/unlock operation after installation.

INSIDE HANDLE

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

INSIDE HANDLE : Exploded View

INFOID:000000004653455



- | | | |
|------------------------------|-------------------|---------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket | 3. TORX bolt |
| 4. Door lock assembly | 5. Inside handle | 6. Outside handle bracket |
| 7. Front gasket | 8. Outside handle | |

↖ : Vehicle front

Refer to [GI-4. "Components"](#) for symbols in the figure.

INSIDE HANDLE : Removal and Installation

INFOID:000000004343630

REMOVAL

1. Remove rear door finisher. Refer to [INT-17. "Removal and Installation"](#).
2. Disconnect inside handle cable, and then remove inside handle.
3. Remove inside handle mounting screws.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check door open/close, lock/unlock operation after installation.

OUTSIDE HANDLE


REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

OUTSIDE HANDLE : Exploded View

INFOID:000000004653456



- | | | |
|------------------------------|-------------------|---------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket | 3. TORX bolt |
| 4. Door lock assembly | 5. Inside handle | 6. Outside handle bracket |
| 7. Front gasket | 8. Outside handle | |

↶ : Vehicle front

Refer to [GI-4. "Components"](#) for symbols in the figure.

OUTSIDE HANDLE : Removal and Installation

INFOID:000000004343632


REMOVAL

1. Remove door side grommet, and loosen TORX bolt from grommet hole.

CAUTION:

Never remove TORX bolt forcibly.

⬅ : TORX bolt




REAR DOOR LOCK


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]


2. While pulling outside handle, remove outside handle escutcheon.



3. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



4. Remove rear door finisher. Refer to [INT-17, "Removal and Installation"](#).
5. Remove sealing screen. Refer to [GW-22, "Removal and Installation"](#).
6. Fully close rear door glass.
7. Remove front gasket and rear gasket.
8. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



9. Reach in to separate outside handle cable connection on outside handle bracket.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check door open/close, lock/unlock operation after installation.

BACK DOOR LOCK


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

BACK DOOR LOCK

Exploded View

INFOID:000000004653372



- | | | |
|----------------------------------|---------------------------------|------------------------------------|
| 1. Back door hinge cover (LH/RH) | 2. Back door hinge (LH/RH) | 3. Back door weather-strip |
| 4. Back door stay (LH/RH) | 5. Bumper rubber (side) (LH/RH) | 6. Back door seal (side) (LH/RH) |
| 7. Bumper rubber (lower) (LH/RH) | 8. Back door striker | 9. Back door lock assembly |
| 10. Back door assembly | 11. Stud ball assembly (LH/RH) | 12. Back door seal (upper) (LH/RH) |
- A : Center mark

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000004343634

REMOVAL

1. Remove back door finisher inner. Refer to [INT-38, "Removal and Installation"](#).
2. Disconnect back door lock assembly and back door opener switch connectors.
3. Remove back door lock mounting bolts, and then remove back door lock assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check back door open/close, lock/unlock operation after installation.

FUEL FILLER LID OPENER


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

FUEL FILLER LID OPENER

Exploded View

INFOID:000000004343635



- 1. Fuel filler lid opener actuator
- 2. Lock nut
- 3. Fuel filler lid assembly
- 4. Lock and cable assembly


△ : Pawl

Removal and Installation

INFOID:000000004343636

NOTE:

When fuel filler lid opener actuator (1) is a defective operation, pull the rod to open fuel filler lid.



REMOVAL

1. Remove mounting screws, and then remove fuel filler lid.
2. Pull and remove lock & cable assembly forward, while pushing the pawls.
3. Rotate lock nut counterclockwise, and then remove lock nut.
4. Push fuel filler lid opener actuator behind the vehicle, while pushing the pawl.
5. Remove luggage side finisher lower (RH). Refer to [INT-35, "Removal and Installation"](#).
6. Disconnect harness connector and remove fuel filler lid opener actuator.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

After installation, apply the touch-up paint (the body color) onto the head of the mounting screws.

DOOR SWITCH


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

DOOR SWITCH

Exploded View

INFOID:0000000004343637




1. Door switch

Removal and Installation

INFOID:0000000004343638

REMOVAL

1. Remove the door switch mounting screw (A), and then remove door switch (1).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

INSIDE KEY ANTENNA


< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

INSIDE KEY ANTENNA INSTRUMENT CENTER

INSTRUMENT CENTER : Exploded View

INFOID:000000004343639




1. Inside key antenna (instrument center)

INSTRUMENT CENTER : Removal and Installation

INFOID:000000004343640

REMOVAL

1. Remove the console finisher assembly. Refer to [IP-23, "Removal and Installation"](#).
2. Remove the key antenna mounting screw (instrument center) (A), and then remove inside key antenna (instrument center) (1).



INSTALLATION

Install in the reverse order of removal.

CONSOLE

CONSOLE : Exploded View

INFOID:000000004343641

Refer to [IP-23, "Exploded View"](#).

CONSOLE : Removal and Installation

INFOID:000000004343642

REMOVAL


1. Remove the console pocket and rear finisher. Refer to [IP-23, "Removal and Installation"](#).

INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

2. Remove the inside key antenna mounting screw (A), and then remove inside key antenna (console) (1).



INSTALLATION

Install in the reverse order of removal.

LUGGAGE ROOM

LUGGAGE ROOM : Exploded View

INFOID:000000004343643


Refer to [INT-34, "Exploded View"](#).

LUGGAGE ROOM : Removal and Installation

INFOID:000000004343644

REMOVAL

1. Remove the luggage floor finisher front. Refer to [INT-35, "Removal and Installation"](#).
2. Remove the inside key antenna (luggage room) mounting clip (A), and then remove inside key antenna (luggage room) (1).



INSTALLATION

Install in the reverse order of removal.

< REMOVAL AND INSTALLATION >

OUTSIDE KEY ANTENNA DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:0000000004343645

Refer to [DLK-251, "OUTSIDE HANDLE : Exploded View"](#).

DRIVER SIDE : Removal and Installation

INFOID:0000000004343646

REMOVAL

Remove the front outside handle LH. Refer to [DLK-251, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

PASSENGER SIDE

PASSENGER SIDE : Exploded View

INFOID:0000000004343647

Refer to [DLK-251, "OUTSIDE HANDLE : Exploded View"](#).

PASSENGER SIDE : Removal and Installation

INFOID:0000000004343648

REMOVAL

Remove the front outside handle RH. Refer to [DLK-251, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

BACK DOOR

BACK DOOR : Exploded View

INFOID:0000000004343649


Refer to [INT-38, "Exploded View"](#).

BACK DOOR : Removal and Installation

INFOID:0000000004343650

REMOVAL

1. Remove the back door finisher inner. Refer to [EXT-48, "Removal and Installation"](#).
2. Remove the outside key antenna (back door) mounting bolts (A), and then remove outside key antenna (back door) (1).



JMKIA2283ZZ

INSTALLATION

Install in the reverse order of removal.

INTELLIGENT KEY WARNING BUZZER

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

INTELLIGENT KEY WARNING BUZZER

Exploded View

INFOID:000000004343651


Refer to [EXT-12. "Exploded View"](#).

Removal and Installation

INFOID:000000004343652

REMOVAL

1. Remove the fender protector. Refer to [EXT-25. "FENDER PRO-TECTOR : Removal and Installation"](#).
2. Remove the Intelligent Key warning buzzer mounting bolt (A), and then remove the Intelligent Key warning buzzer (1).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY SLOT

Exploded View

INFOID:000000004343653


Refer to [IP-12. "Exploded View"](#).

Removal and Installation

INFOID:000000004343654

REMOVAL

1. Remove the instrument lower panel LH (2). Refer to [IP-13. "Removal and Installation"](#).
2. Disconnect key slot connector.
3. Remove the key slot mounting screw (A), and then remove key slot (1).



INSTALLATION

Install in the reverse order of removal.

REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >

[INTELLIGENT KEY SYSTEM]

REMOTE KEYLESS ENTRY RECEIVER

Exploded View

INFOID:000000004343655


Refer to [IP-12. "Exploded View"](#).

Removal and Installation

INFOID:000000004343656

REMOVAL

1. Remove the instrument lower panel RH. Refer to [IP-13. "Removal and Installation"](#).
2. Remove the remote keyless entry receiver mounting screw (A), and then remove remote keyless entry receiver (1).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY BATTERY

Removal and Installation


INFOID:000000004343657

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.

2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.

Battery replacement

**:Coin-type lithium battery
(CR2025)**

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.

