

SECTION MIR

MIRRORS

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

WITH ADP

BASIC INSPECTION	3
DIAGNOSIS AND REPAIR WORKFLOW	3
Work Flow	3
SYSTEM DESCRIPTION	4
DOOR MIRROR SYSTEM	4
System Diagram	4
System Description	4
Component Parts Location	6
Component Description	6
INSIDE MIRROR SYSTEM	7
System Description	7
Component Description	7
DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)	8
Diagnosis Description	8
CONSULT-III Function	8
DTC/CIRCUIT DIAGNOSIS	11
DOOR MIRROR REMOTE CONTROL SWITCH	11
MIRROR SWITCH	11
MIRROR SWITCH : Description	11
MIRROR SWITCH : Component Function Check	11
MIRROR SWITCH : Diagnosis Procedure	11
MIRROR SWITCH : Component Inspection	12
CHANGEOVER SWITCH	13
CHANGEOVER SWITCH : Description	13
CHANGEOVER SWITCH : Component Function Check	13
CHANGEOVER SWITCH : Diagnosis Procedure	13
CHANGEOVER SWITCH : Component Inspection	14

DOOR MIRROR SYSTEM	16
Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -	16
AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM	22
Wiring Diagram - INSIDE MIRROR SYSTEM -	22
ECU DIAGNOSIS INFORMATION	24
DRIVER SEAT CONTROL UNIT	24
Reference Value	24
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	29
Fail Safe	38
DTC Index	39
AUTOMATIC DRIVE POSITIONER CONTROL UNIT	40
Reference Value	40
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	44
BCM (BODY CONTROL MODULE)	54
Reference Value	54
Wiring Diagram - BCM -	78
Fail-safe	84
DTC Inspection Priority Chart	86
DTC Index	88
SYMPTOM DIAGNOSIS	91
DOOR MIRROR DOES NOT OPERATE	91
Diagnosis Procedure	91
REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE	92
Diagnosis Procedure	92
SQUEAK AND RATTLE TROUBLE DIAGNOSES	93
Work Flow	93

MIR

Inspection Procedure	95	DOOR MIRROR SYSTEM	110
Diagnostic Worksheet	97	Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -	110
PRECAUTION	99		
PRECAUTIONS	99		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	99		
PREPARATION	100		
PREPARATION	100		
Commercial Service Tools	100		
REMOVAL AND INSTALLATION	101		
INSIDE MIRROR	101		
Exploded View	101		
Removal and Installation	101		
OUTSIDE MIRROR	103		
DOOR MIRROR ASSEMBLY	103		
DOOR MIRROR ASSEMBLY : Exploded View	103		
DOOR MIRROR ASSEMBLY : Removal and In- stallation	103		
DOOR MIRROR ASSEMBLY : Disassembly and Assembly	103		
GLASS MIRROR	104		
GLASS MIRROR : Exploded View	104		
GLASS MIRROR : Disassembly and Assembly ...	104		
DOOR MIRROR COVER	105		
DOOR MIRROR COVER : Exploded View	105		
DOOR MIRROR COVER : Disassembly and As- sembly	106		
DOOR MIRROR REMOTE CONTROL			
SWITCH	107		
Exploded View	107		
Removal and Installation	107		
WITHOUT ADP			
SYSTEM DESCRIPTION	108		
DOOR MIRROR SYSTEM	108		
Component Description	108		
INSIDE MIRROR SYSTEM	109		
System Description	109		
Component Description	109		
DTC/CIRCUIT DIAGNOSIS	110		
DOOR MIRROR SYSTEM	110		
Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -	110		
AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM	112		
Wiring Diagram - INSIDE MIRROR SYSTEM - ...	112		
SYMPTOM DIAGNOSIS	114		
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	114		
Work Flow	114		
Inspection Procedure	116		
Diagnostic Worksheet	118		
PRECAUTION	120		
PRECAUTIONS	120		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	120		
PREPARATION	121		
PREPARATION	121		
Commercial Service Tools	121		
REMOVAL AND INSTALLATION	122		
INSIDE MIRROR	122		
Exploded View	122		
Removal and Installation	122		
OUTSIDE MIRROR	124		
DOOR MIRROR ASSEMBLY	124		
DOOR MIRROR ASSEMBLY : Exploded View ...	124		
DOOR MIRROR ASSEMBLY : Removal and In- stallation	124		
DOOR MIRROR ASSEMBLY : Disassembly and Assembly	124		
GLASS MIRROR	125		
GLASS MIRROR : Exploded View	125		
GLASS MIRROR : Disassembly and Assembly ..	125		
DOOR MIRROR COVER	126		
DOOR MIRROR COVER : Exploded View	126		
DOOR MIRROR COVER : Disassembly and As- sembly	127		
DOOR MIRROR REMOTE CONTROL			
SWITCH	128		
Exploded View	128		
Removal and Installation	128		

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004712327

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2. CHECK DTC

Perform self-diagnosis for automatic drive positioner (ADP) with CONSULT-III.

Is any DTC detected?

YES >> Refer to [ADP-139, "DTC Index"](#)

NO >> GO TO 3.

3. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

4. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

5. IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

6. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

DOOR MIRROR SYSTEM

System Diagram

INFOID:000000004712328



System Description

INFOID:000000004712329

MANUAL FUNCTION

Description

- Automatic drive positioner control unit controls door mirror.
- Automatic drive positioner control unit inputs changeover switch signal and perform the LH/RH control of door mirror motor supplying electric power when changeover switch is operated.
- Automatic drive positioner control unit inputs mirror switch signal and supplies electric power to door mirror.
- The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

- Ignition switch: ON or ACC
- Changeover switch: Select either left or right

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Description

- Select one of the door mirror faces by change over switch, and then set the selected mirror face downward/inward.
- When the ignition switch is ON position and A/T shift selector is in R position, the TCM sends the R signal to the driver seat control unit. The R signal is transmitted to the automatic drive positioner control unit from the driver seat control unit via UART communication. When the R signal is detected, the automatic device positioner control unit activated the mirror motor.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

DOOR MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

- Ignition switch: ON
- Changeover switch: Select either left or right
- A/T shift selector: R position

During the reverse interlock door mirror system, if all of the above conditions are not satisfied, mirror face returns to original angle.

Mirror Angle Memory Function

- During the reverse interlock door mirror operation, the mirror angle can be changed. After adjustment, the mirror face positions can be memorized (2 positions). For memory setting.
- Initial setting is downward 7°, inward 1° (both of left and right).
- When the driver's seat, outside mirror and steering column are not in the memorized position, the outside mirror will move with the initial tilt-down angle, if the reverse tilt-down position is stored. Linking Intelligent Key to a stored memory position.

Memory Procedure

1. Apply the parking brake.
2. Push the ignition switch to the ON position. (Do not start the engine.)
3. Push the memory switch 1 or 2 fully for at least 1 second to operate the automatic drive positioner.
4. Turn the door mirror control switch (changeover switch) to L (left).
5. Depress the brake pedal.
6. Move the A/T shift selector to R position (reverse).
7. Adjust the mirror to the desired viewing position for backing up by operating the door mirror control switch (mirror switch).
8. Push the SET switch and, within 5 seconds, push the memory switch 1 or 2 selected in step 3 fully for at least 1 second.
The indicator light for the pushed memory switch will come on and stay pushing the switch. After the indicator light goes off, the selected mirror position is stored in the selected memory (1 or 2).
9. Turn the door mirror control switch (changeover switch) to R (right).
Repeat the above procedure to adjust the right mirror position and store in the selected memory.

AUTOMATIC DRIVE POSITIONER SYSTEM LINKED OPERATION

Description

Door mirror control is included in automatic drive positioner system. Refer to automatic drive positioner system for more details.

Refer to [ADP-13. "AUTOMATIC DRIVE POSITIONER SYSTEM : System Description"](#).

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P


DOOR MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITH ADP]

Component Parts Location

INFOID:000000004712330



JMLIA0129ZZ

- | | | |
|---|--|--|
| 1. Door mirror remote control switch D17 | 2. Door mirror (driver side) D3 | 3. Door mirror (passenger side) D33 |
| 4. Automatic drive positioner control unit M51, M52 | 5. Driver seat control unit B451, B452 | 6. AT assembly connector (TCM) F51 |
| 7. BCM M118, M119, M122 | | |
| A. View with instrument driver lower panel removed | B. Back side of the seat cushion | C. AT assembly (TCM is built in AT assembly) |
| D. Dash side lower (passenger side) | | |

Component Description

INFOID:000000004712331

Component	Function
Automatic drive positioner control unit	Door mirror is supplied with power after receiving the input of the MIRROR SWITCH and CHANGEOVER SWITCH.
Door mirror remote control switch	Mirror switch It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.
	Changeover switch It transmits the LH/RH control of door mirror that supplies power to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.
Door mirror	It makes mirror face operate from side to side and up and down via integrated motor.
BCM	The ignition switch signal (ACC/ON) is transmitted to driver seat control unit via CAN communication.
Driver seat control unit	The ignition switch signal (ACC/ON) is transmitted to automatic drive positioner control unit via UART communication.
TCM	The A/T shift position signal is transmitted to driver seat control unit via CAN communication.

INSIDE MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

INSIDE MIRROR SYSTEM

System Description

INFOID:0000000004712332

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:0000000004712333

Component	Function
Auto anti-dazzling inside mirror	It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

Diagnosis Description

INFOID:000000004712334

The auto drive positioner system can be checked and diagnosed for component operation with CONSULT-III.

DIAGNOSTIC MODE

Diagnostic mode [AUTO DRIVE POS.]	Description
WORK SUPPORT	Changes the setting of each function.
SELF-DIAG RESULTS	Performs self-diagnosis for the auto drive positioner system and displays the results.
DATA MONITOR	Displays input signals transmitted from various switches and sensors to driver seat control unit in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Drive each output device.
ECU PART NUMBER	Displays part numbers of driver seat control unit parts.

CONSULT-III Function

INFOID:000000004712335

SELF-DIAGNOSIS RESULTS

Refer to [ADP-139, "DTC Index"](#).

DATA MONITOR

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
SET SW	"ON/OFF"	×	×	ON/OFF status judged from the setting switch signal.
MEMORY SW 1	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 1 signal.
MEMORY SW 2	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 2 signal.
SLIDE SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (forward) signal.
SLIDE SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (backward) signal.
RECLN SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (forward) signal.
RECLN SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (backward) signal.
LIFT FR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (up) signal.
LIFT FR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (down) signal.
LIFT RR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (up) signal.
LIFT RR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (down) signal.
MIR CON SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (up) signal.
MIR CON SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (down) signal.
MIR CON SW-RH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (passenger side) signal.
MIR CON SW-LH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (driver side) signal.

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
MIR CHNG SW-R	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to right) signal.
MIR CHNG SW-L	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to left) signal.
TILT SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (up) signal.
TILT SW-DOWN	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (down) signal.
TELESCO SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (forward) signal.
TELESCO SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (backward) signal.
DETENT SW	"ON/OFF"	×	×	The selector lever position "OFF (P position) / ON (other than P position)" judged from the detention switch signal.
STARTER SW	"ON/OFF"	×	×	Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal.
SLIDE PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
RECLN PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
LIFT FR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
LIFT RR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
MIR/SEN RH U-D	"V"	—	×	Voltage input from door mirror sensor (passenger side) up/down is displayed.
MIR/SEN RH R-L	"V"	—	×	Voltage input from door mirror sensor (passenger side) left/right is displayed.
MIR/SEN LH U-D	"V"	—	×	Voltage input from door mirror sensor (driver side) up/down is displayed.
MIR/SEN LH R-L	"V"	—	×	Voltage input from door mirror sensor (driver side) left/right is displayed.
TILT SEN	"V"	—	×	Voltage input from tilt sensor is displayed.
TELESCO SEN	"V"	—	×	Voltage input from telescopic sensor is displayed.

ACTIVE TEST

CAUTION:

When driving vehicle, do not perform active test.

Test item	Description
SEAT SLIDE	Activates/deactivates the sliding motor.
SEAT RECLINING	Activates/deactivates the reclining motor.
SEAT LIFTER FR	Activates/deactivates the lifting motor (front).
SEAT LIFTER RR	Activates/deactivates the lifting motor (rear).
TILT MOTOR	Activates/deactivates the tilt motor.
TELESCO MOTOR	Activates/deactivates the telescopic motor.
MIRROR MOTOR RH	Activates/deactivates the mirror motor (passenger side).

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

Test item	Description
MIRROR MOTOR LH	Activates/deactivates the mirror motor (driver side).
MEMORY SW INDCTR	Turns ON/OFF the memory indicator.

WORK SUPPORT

Work item	Content	Item
SEAT SLIDE VOLUME SET	The amount of seat sliding for entry/exit assist can be selected from 3 items.	40 mm
		80 mm
		150 mm
EXIT TILT SETTING	Entry/exit assist (steering column) can be selected: ON (operated) – OFF (not operated)	ON
		OFF
EXIT SEAT SLIDE SETTING	Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated)	ON
		OFF

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR REMOTE CONTROL SWITCH MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:000000004712336

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

MIRROR SWITCH : Component Function Check

INFOID:000000004712337

1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in "DATA MONITOR" mode with CONSULT-III.

Monitor item	Condition
MIR CON SW-UP/DN	When operating the mirror switch toward the up or down side. : ON
	Other than above. : OFF
MIR CON SW-RH/LH	When operating the mirror switch toward the right or left side. : ON
	Other than above. : OFF

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [MIR-11, "MIRROR SWITCH : Diagnosis Procedure".](#)

MIRROR SWITCH : Diagnosis Procedure

INFOID:000000004712338

1. CHECK MIRROR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror remote control switch			
Connector	Terminal		
D17	4	Ground	5
	12		
	13		
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK MIRROR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	3	D17	15	Existed
	4		13	
	19		12	
	20		4	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	3		Not existed
	4		
	19		
	20		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK MIRROR SWITCH

Check door mirror remote control switch (mirror switch).

Refer to [MIR-12, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace door mirror remote control switch (mirror switch). Refer to [MIR-107, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

MIRROR SWITCH : Component Inspection

INFOID:00000000471239

1.CHECK MIRROR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Door mirror remote control switch		Condition		Continuity
Connector	Terminal			
D17	4	7	Mirror switch	RIGHT
	13			Other than above
	15			LEFT
	12			Other than above
				UP
				Other than above
				DOWN
				Other than above

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-107, "Removal and Installation"](#).

CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:000000004712340

Changover switch is integrated into door mirror remote control switch.

Changover switch has three positions (L, N and R).

It changes door mirror motor operation by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:000000004712341

1.CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in "DATA MONITOR" mode with CONSULT-III.

Monitor item	Condition
MIR CHNG SW-R/L	When operating the changeover toward the right or left side. : ON
	Other than above. : OFF

Is the inspection result normal?

YES >> Changover switch function is OK.

NO >> Refer to [MIR-13, "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:000000004712342

1.CHECK CHANGEOVER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

(+) Door mirror remote control switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D17	10	Ground	5
	11		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK CHANGEOVER SWITCH CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	2	D17	11	Existed
	18		10	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	2		Existed
	18		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK CHANGEOVER SWITCH

Check door mirror remote control switch (changeover switch).

Refer to [MIR-14, "CHANGEOVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace door mirror remote control switch (changeover switch). Refer to [MIR-107, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

CHANGEOVER SWITCH : Component Inspection

INFOID:000000004712343

1.CHECK CHANGEOVER SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Door mirror remote control switch		Condition		Continuity
Connector	Terminal			
D17	10	7	Changeover switch	LEFT
	11			Other than above
				RIGHT
				Other than above

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-107, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR SYSTEM

[WITH ADP]


< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -

INFOID:0000000004712412

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)



JCLWA2499GB


2008/08/28

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
MIR



JCLWA2500GB

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No. B11

Connector Name WIRE TO WIRE

Connector Type TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-	1	L/W	RX
3	L	-	3	R/Y	CAN-H
17	LG	-	17	Y/R	TX
19	P	-	19	V	CAN-L
32	B	-	32	B/W	GND(SIGNAL)
40	BR	-			
48	B	-			

Connector No. B11

Connector Name WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)

Connector Type NS16FW-CS

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
59	40	[17]	1	3	19
60	33	21	48	32	20
61	32	30	62	31	32
63	34	35	64	36	37
65	38	39	66	39	40
67	41	42	68	42	43
69	44	45	70	44	45
71	46	47	72	46	47
73	48	49	74	48	49
75	50	51	76	50	51
77	52	53	78	52	53
79	54	55	80	54	55
81	56	57	82	56	57
83	58	59	84	58	59
85	60	61	86	60	61

Connector No. B452

Connector Name DRIVER SEAT CONTROL UNIT

Connector Type NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	35	36
34	36	[37]
35	36	38
36	37	39
40	41	42
41	42	43
42	43	44
43	44	45
44	45	46
45	46	47
46	47	48

Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BATT(C/B)
40	R/W	BATT(USE)
48	B	GND(POWER)



Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	RX
3	R/Y	CAN-H
17	Y/R	TX
19	V	CAN-L
32	B/W	GND(SIGNAL)

Terminal No.	Color of Wire	Signal Name [Specification]
45	Y	- [With automatic drive positioner]
46	P	- [With automatic drive positioner]
49	GR	-



Terminal No.	Color of Wire	Signal Name [Specification]
15	14	[13]
16	12	11
17	10	9
18	8	[7]
19	7	6
20	5	4
21	4	3
22	2	1



Terminal No.	Color of Wire	Signal Name [Specification]
23	O	-
24	P	-
25	V	-
26	Y	-
27	G	-
28	BR	-
29	GR	-
30	Y	-
31	V	-
32	BR	-
33	GR	-
34	Y	-
35	V	-
36	BR	-
37	GR	-
38	Y	-
39	V	-
40	BR	-
41	GR	-
42	Y	-
43	V	-
44	BR	-
45	GR	-
46	Y	-
47	V	-
48	BR	-
49	GR	-
50	Y	-
51	V	-
52	BR	-
53	GR	-
54	Y	-
55	V	-
56	BR	-
57	GR	-
58	Y	-
59	V	-



JCLWA2501GB


DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >


DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	D17	Connector No.	D31
Connector Name	DOOR MIRROR REMOTE CONTROL	Connector Name	WIRE TO WIRE
Connector Type	TK16FR	Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-	43	Y	-
7	B	-	44	P	-
10	GR	-	45	W	-
11	L	-	46	G	-
12	P	-	52	Y	-
13	W	-	53	Y	-
15	Y	-	54	W	-

Connector No.	D33	Connector No.	E106
Connector Name	DOOR MIRROR (PASSENGER SIDE)	Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH	Connector Type	TH80FW-CS16-TM4



Terminal No.	1	Signal Name [Specification]	Terminal No.	1	Signal Name [Specification]
	2	-		2	-
	3	-		3	-
	4	-		4	-
	5	-		5	-
	6	-		6	-
	7	-		7	-
	8	-		8	-
	9	-		9	-
	10	-		10	-
	11	-		11	-
	12	-		12	-
	13	-		13	-
	14	-		14	-
	15	-		15	-
	16	-		16	-

Terminal No.	1	Signal Name [Specification]	Terminal No.	1	Signal Name [Specification]
	2	-		2	-
	3	-		3	-
	4	-		4	-
	5	-		5	-
	6	-		6	-
	7	-		7	-
	8	-		8	-
	9	-		9	-
	10	-		10	-
	11	-		11	-
	12	-		12	-
	13	-		13	-
	14	-		14	-
	15	-		15	-
	16	-		16	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
MIR

DOOR MIRROR SYSTEM

[WITH ADP]


< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M5		
Connector Name	WIRE TO WIRE		
Connector Type	TH40MW-CS15		

45	G		-
46	SB		[With automatic drive positioner]
49	P		

Connector No.	M7		
Connector Name	WIRE TO WIRE		
Connector Type	TH80MW-CS16-TM4		



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
13	B	-	-
21	LG	-	-
22	L	-	-
23	G	-	-
24	Y	-	-
25	GR	-	-
26	W	-	-
30	Y	-	-
36	LG	-	-
43	BR	-	-
44	V	-	-

Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
45	G		[With automatic drive positioner]
46	SB		
49	P		


Connector No.	M52		
Connector Name	AUTOMATIC DRIVE POSITIONER		
Connector Type	NS16IW-CS		



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
3	SB	-	[With automatic drive positioner]
34	L		
35	P		
38	BR		
39	Y		
49	V		




Connector No.	M51		
Connector Name	AUTOMATIC DRIVE POSITIONER		
Connector Type	TH32IW-NH		



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
20	BR	MIRROR SW (RIGHTWARD)	
21	L	MIRROR SENSOR (RH HORIZONTAL)	
22	G	MIRROR SENSOR (LH HORIZONTAL)	
26	Y	RX (UART)	
30	R	MIRROR MOTOR (RH COMMON)	
31	LG	MIRROR MOTOR (LH HORIZONTAL)	
32	L	MIRROR MOTOR (LH VERTICAL)	



Connector No.	M24		
Connector Name	DATA LINK CONNECTOR		
Connector Type	BD16FW		



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
33	W	POWER SUPPLY (SENSOR)	POWER SUPPLY (SENSOR)
34	R	BAT (FUSE)	BAT (C/B)
39	SB		GND SIGNAL
40	B		GND SIGNAL
41	Y		GND SIGNAL
48	B		GND/POWER

JCLWA2503GB

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M116	Connector No.	M118
Connector Name	WIRE TO WIRE	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TK36WW-NS10	Connector Type	M03FB-LC
			

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SB	-

Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Signal Name [Specification]
BAT (F/L) BAT (F/L) GND

Connector No.	M122	Connector No.	M124
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	WIRE TO WIRE
Connector Type	TH40FB-NH	Connector Type	TH40WW-CS15

Terminal No.	Color of Wire	Signal Name [Specification]
91	P	CAN-L
90	L	CAN-H

Signal Name [Specification]
CAN-L CAN-H

Terminal No.	Color of Wire	Signal Name [Specification]
43	L	-
44	Y	-
45	R	-
46	W	-
52	R	-
53	G	-
54	W	-

Signal Name [Specification]
-

JCLWA2504GB

A B C D E F G H I J K L M N O P MIR M Z O P

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

Wiring Diagram - INSIDE MIRROR SYSTEM -

INFOID:0000000004712344

PM : With automatic drive positioner
OP : Without automatic drive positioner

INSIDE MIRROR



2008/08/28

JCLWA2507GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

INSIDE MIRROR

Connector No.	M1	Connector No.	M2
Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE
Connector Type	NS30FW-M2	Connector Type	TK10FW-NS8
			

Terminal No.	1	Signal Name [Specification]	10
Color of Wire	Y	Signal Name [Specification]	9
Terminal No.	2	Signal Name [Specification]	12
Color of Wire	G	Signal Name [Specification]	13
			

Terminal No.	1	Signal Name [Specification]	7
Color of Wire	BR	Signal Name [Specification]	6
Terminal No.	2	Signal Name [Specification]	8
Color of Wire	B	Signal Name [Specification]	9
Terminal No.	3	Signal Name [Specification]	10
Color of Wire	BR	Signal Name [Specification]	11
Terminal No.	4	Signal Name [Specification]	12
Color of Wire	Y	Signal Name [Specification]	13
Terminal No.	5	Signal Name [Specification]	14
Color of Wire	BR	Signal Name [Specification]	15
Terminal No.	6	Signal Name [Specification]	16
Color of Wire	BR	Signal Name [Specification]	17
Terminal No.	7	Signal Name [Specification]	18
Color of Wire	BR	Signal Name [Specification]	19
Terminal No.	8	Signal Name [Specification]	20
Color of Wire	BR	Signal Name [Specification]	21
			

JCLWA2508GB

A B C D E F G H I J K L M N O P

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

ECU DIAGNOSIS INFORMATION DRIVER SEAT CONTROL UNIT

Reference Value

INFOID:000000004712413

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item		Condition	Value/Status
SET SW	Set switch	Push	ON
		Release	OFF
MEMORY SW1	Memory switch 1	Push	ON
		Release	OFF
MEMORY SW2	Memory switch 2	Push	ON
		Release	OFF
SLIDE SW-FR	Sliding switch (front)	Operate	ON
		Release	OFF
SLIDE SW-RR	Sliding switch (rear)	Operate	ON
		Release	OFF
RECLN SW-FR	Reclining switch (front)	Operate	ON
		Release	OFF
RECLN SW-RR	Reclining switch (rear)	Operate	ON
		Release	OFF
LIFT FR SW-UP	Lifting switch front (up)	Operate	ON
		Release	OFF
LIFT FR SW-DN	Lifting switch front (down)	Operate	ON
		Release	OFF
LIFT RR SW-UP	Lifting switch rear (up)	Operate	ON
		Release	OFF
LIFT RR SW-DN	Lifting switch rear (down)	Operate	ON
		Release	OFF
MIR CON SW-UP	Mirror switch	Up	ON
		Other than above	OFF
MIR CON SW-DN	Mirror switch	Down	ON
		Other than above	OFF
MIR CON SW-RH	Mirror switch	Right	ON
		Other than above	OFF
MIR CON SW-LH	Mirror switch	Left	ON
		Other than above	OFF
MIR CHNG SW-R	Changeover switch	Right	ON
		Other than above	OFF
MIR CHNG SW-L	Changeover switch	Left	ON
		Other than above	OFF
TILT SW-UP	Tilt switch	Up	ON
		Other than above	OFF
TILT SW-DOWN	Tilt switch	Down	ON
		Other than above	OFF

DRIVER SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
TELESCO SW-FR	Telescopic switch	Forward
		OFF
TELESCO SW-RR	Tilt switch	Backward
		OFF
DETENT SW	AT selector lever	P position
		ON
STARTER SW	Ignition position	Cranking
		OFF
SLIDE PULSE	Seat sliding	Forward
		The numeral value decreases *1
		Backward
RECLN PULSE	Seat reclining	The numeral value increases *1
		Forward
		No change to numeral value *1
LIFT FR PULSE	Seat lifter (front)	Backward
		The numeral value decreases *1
		Other than above
LIFT RR PULSE	Seat lifter (rear)	Up
		The numeral value increases *1
		Down
MIR/SEN RH U-D	Door mirror (passenger side)	Other than above
		No change to numeral value *1
		Up
MIR/SEN RH R-L	Door mirror (passenger side)	The numeral value decreases *1
		Down
		The numeral value increases *1
MIR/SEN LH U-D	Door mirror (driver side)	Other than above
		No change to numeral value *1
		Up
MIR/SEN LH R-L	Door mirror (driver side)	The numeral value increases *1
		Down
		No change to numeral value *1
TILT SEN	Tilt position	Change between 1.2 (close to top) 3.4 (close to bottom)
TELESCO SEN	Telescopic position	Change between 3.4 (close to top) 0.8 (close to bottom)

*1: The value at the position attained when the battery is connected is regarded as 32768.

TERMINAL LAYOUT






JMJA0199ZZ

PHYSICAL VALUES

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >




[WITH ADP]

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx)
+	-		Signal name	Input/Output		
1	Ground	L/W	UART communication (RX)	Input	Ignition switch ON	 2mSec/div 2V/div
3	—	R/Y	CAN-H	—	—	—
9	Ground	W/G	Reclining sensor signal	Input	Seat reclining	Operate
						 10mSec/div 2V/div
10	Ground	P/B	Lifting sensor (rear) signal	Input	Seat lifting (rear)	Operate
						 10mSec/div 2V/div
11	Ground	BR	Sliding switch backward signal	Input	Sliding switch	Operate (backward)
						0
12	Ground	SB	Reclining switch backward signal	Input	Reclining switch	Operate (backward)
						0
13	Ground	LG/R	Lifting switch (front) down signal	Input	Lifting switch (front)	Operate (down)
						0
14	Ground	G/B	Lifting switch (rear) down signal	Input	Lifting switch (rear)	Operate (down)
						0
16	Ground	O	Sensor power supply	Output	—	5
17	Ground	Y/R	UART communication (TX)	Output	Ignition switch ON	 10mSec/div 2V/div
19	—	V	CAN-L	—	—	—

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx)
+	-		Signal name	Input/ Output			
		L/Y	Detention switch	Input	A/T selector lever	P position	0
21	Ground					Except P position	 20mSec/div 5V/div
		R	Sliding sensor signal	Input	Seat sliding	Operate	 10mSec/div 2V/div
24	Ground					Stop	0 or 5
		Y/B	Lifting sensor (front) signal	Input	Seat lifting (front)	Operate	 10mSec/div 2V/div
25	Ground					Stop	0 or 5
		Y	Sliding switch forward signal	Input	Sliding switch	Operate (forward)	0
26	Ground					Release	Battery voltage
		R/G	Reclining switch forward signal	Input	Reclining switch	Operate (forward)	0
27	Ground					Release	Battery voltage
		W/B	Lifting switch (front) up signal	Input	Seat lifting switch (front)	Operate (up)	0
28	Ground					Release	Battery voltage
		P/L	Lifting switch (rear) up signal	Input	Seat lifting switch (rear)	Operate (up)	0
29	Ground					Release	Battery voltage
31	Ground	GR	Sensor ground	—	—		0
32	Ground	B/W	Ground (signal)	—	—		0
33	Ground	R	Power source (C/B)	Input	—		Battery voltage
		W/R	Sliding motor forward output signal	Output	Seat sliding	Operate (forward)	Battery voltage
35	Ground					Release	0
		G/Y	Reclining motor forward output signal	Output	Seat reclining	Operate (forward)	Battery voltage
36	Ground					Release	0

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx)
+	-		Signal name	Input/ Output			
37	Ground	G/W	Lifting motor (front) down output signal	Output	Seat lifting (front)	Operate (down)	Battery voltage
						Stop	0
38	Ground	L/Y	Lifting motor (rear) up output signal	Output	Seat lifting (rear)	Operate (up)	Battery voltage
						Stop	0
39	Ground	R/B	Lifting motor (rear) down output signal	Output	Seat lifting (rear)	Operate (down)	Battery voltage
						Stop	0
40	Ground	R/W	Power source (Fuse)	Input	—		Battery voltage
42	Ground	W/B	Sliding motor backward output signal	Output	Seat sliding	Operate (back-ward)	Battery voltage
						Stop	0
44	Ground	P	Reclining motor backward output signal	Output	Seat reclining	Operate (back-ward)	Battery voltage
						Stop	0
45	Ground	L/R	Lifting motor (front) up output signal	Output	Seat lifting (front)	Operate (up)	Battery voltage
						Stop	0
48	Ground	B	Ground (power)	—	—		0

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -



DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JCJWA0774GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JGJWA0775GE

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH30FW-CS16-TM4
	

Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	-
34	L	-
35	P	-
38	BR	-
39	LG	-
49	G	-
50	Y	-
85	V	-

Connector No.	B11
Connector Name	WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS16FW-CS

1	59	40	17	1	3	19
2	60	33	21	48	32	20
3	61	87	32	3	3	3
4	62	94	33	3	3	3
5	63	95	35	3	3	3



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-
17	LG	-
19	P	-
21	Y	-
32	B	-
33	SB	-
40	BR	-
48	B	-

Connector No.	B453
Connector Name	SLIDING SENSOR
Connector Type	6098 0241



1	33	34	35	36	37	38	39
2	40	41	42	43	44	45	46

Connector No.	B452
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS16FW-CS



1	21	24	25	26	27	28	29	30	31	32
2	L/Y	R	Y/B	Y	R/G	W/B	P/L	GR	B/W	
3	SB	-	-	-	-	-	-	-	-	
4	L	-	-	-	-	-	-	-	-	
5	P	-	-	-	-	-	-	-	-	
6	BR	-	-	-	-	-	-	-	-	
7	LG	-	-	-	-	-	-	-	-	
8	G	-	-	-	-	-	-	-	-	
9	Y	-	-	-	-	-	-	-	-	
10	V	-	-	-	-	-	-	-	-	

Terminal No.	Color of Wire	Signal Name [Specification]
21	L/Y	P RANGE SW
24	R	PULSE(SLIDING)
25	Y/B	PULSE(LIFTING)
26	Y	SLIDING(SW FORWARD)
27	R/G	RECLINING(SW FORWARD)
28	W/B	FRONT LIFTING(SW UPWARD)
29	P/L	REAR LIFTING(SW UPWARD)
30	GR	SENSOR(GND)
31	B/W	GND(SIGNAL)

Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BAT(C/B)
35	W/R	SLIDING(MOTOR FORWARD)
36	G/Y	RECLINING(MOTOR FORWARD)
37	G/W	FRONT LIFTING(MOTOR DOWNWARD)
38	L/Y	REAR LIFTING(MOTOR UPWARD)
39	R/B	REAR LIFTING(MOTOR BACKWARD)
40	R/W	BAT(USE)
42	W/B	SLIDING(MOTOR BACKWARD)
44	P	RECLINING(MOTOR BACKWARD)
45	L/R	FRONT LIFTING(MOTOR UPWARD)
48	B	GND(POWER)

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B454
Connector Name	RECLINING MOTOR
Connector Type	NS056FW-CS



Connector No.	B455
Connector Name	LIFTING MOTOR (FRONT) (DRIVER SIDE)
Connector Type	NS06FW-CS



Connector No.	B456
Connector Name	LIFTING MOTOR (REAR) (DRIVER SIDE)
Connector Type	NS06FBR-CS




Connector No.	B459
Connector Name	POWER SEAT SWITCH (DRIVER'S SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NISIOWW-CS



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wires	Signal Name [Specification]
9	W/G	-	16	O	-
16	O	-	25	Y/B	-
31	GR	-	31	GR	-
36	G/Y	-	37	G/W	-
44	P	-	45	L/R	-

Terminal No.	Color of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
31	GR	-
38	L/Y	-
39	R/B	-


Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
12	SB	-
3	LGR	-
14	G/B	-
26	Y	-
27	R/G	-
28	W/B	-
29	P/L	-
32	B/W	-




Connector No.	B461
Connector Name	SLIDING MOTOR (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	6098-0739



39	O	-
40	BR	-
41	L	-
42	GR	- [With automatic drive positioner]
43	BR	- [With automatic drive positioner]
44	W	- [With automatic drive positioner]
45	Y	- [With automatic drive positioner]
46	P	- [With automatic drive positioner]
49	CD	-



Terminal No.	Color of Wire	Signal Name [Specification]
35	W/R	-
42	W/B	-



39	O	-
40	BR	-
41	L	-
42	GR	-
43	BR	[With automatic drive positioner]
44	W	[With automatic drive positioner]
45	Y	[With automatic drive positioner]
46	P	[With automatic drive positioner]
49	GR	-



JCJWA0777GB

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	D3	Connector No.	D5
Connector Name	DOOR MIRROR (DRIVER SIDE)	Connector Name	SEAT MEMORY SWITCH
Connector Type	TH24MW-NH	Connector Type	A08FW
			




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	GR	-
4	B	-
5	R	-
6	O	-
7	P	-

Connector No.	D17	Connector No.	D31
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)	Connector Name	WIRE TO WIRE
Connector Type	TK16FBR	Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	17
16	17	18
17	18	19
18	19	20
19	20	21
20	21	22
21	22	23
22	23	24

Connector No.	F17	Connector No.	F103
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TK36FW-NS10	Connector Type	TK36FW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	Y	-
44	P	-
52	Y	-
53	G	-
54	W	-

Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	L	-
12	P	-
13	W	-
15	Y	-



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	L	-
12	P	-
15	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
43	Y	-
44	P	-
52	Y	-
53	G	-
54	W	-

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	CAN-H
2	LY	CAN-L

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M31
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-	1	W	-
2	GR	-	2	P	-
3	G	-	3	O	-
4	Y	-	4	Y	-
5	W	-			

Connector No.	M51
Connector Name	AUTOMATIC DRIVE POSITIONER
Connector Type	TH32FW-NH



1	2	3	4	5	6
2	3	4	5	6	7
3	4	5	6	7	8
4	5	6	7	8	9
5	6	7	8	9	10
6	7	8	9	10	11
7	8	9	10	11	12
8	9	10	11	12	13
9	10	11	12	13	14
10	11	12	13	14	15
11	12	13	14	15	16
12	13	14	15	16	17
13	14	15	16	17	18
14	15	16	17	18	19
15	16	17	18	19	20
16	17	18	19	20	21
17	18	19	20	21	22
18	19	20	21	22	23
19	20	21	22	23	24
20	21	22	23	24	25
21	22	23	24	25	26
22	23	24	25	26	27
23	24	25	26	27	28
24	25	26	27	28	29
25	26	27	28	29	30
26	27	28	29	30	31
27	28	29	30	31	32

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TK04FW



1	Y	TILT SW (UPWARD)	27	G	TELESCOPIC SW (BACKWARD)
2	LG	MIRROR SELECT SW (RH)	30	R	MIRROR MOTOR (RH COMMON)
3	G	MIRROR SW (UPWARD)	31	LG	MIRROR MOTOR (LH VERTICAL)
4	V	MIRROR SW (LEFTWARD)	32	L	MIRROR MOTOR (LH HORIZONTAL)
5	R	MIRROR SENSOR (RH VERTICAL)			TELESCOPIC SENSOR
6	GR	MIRROR SENSOR (LH VERTICAL)			SET SW
7	O	TILT SENSOR	26	Y	TELESCOPIC SW (BACKWARD)
9	L	ADDRESSI	27	G	MIRROR SELECT SW (RH)
10	V	TX (UART)	30	R	MIRROR MOTOR (RH COMMON)
11	GR	TELESCOPIC SW (FRONTWARD)	31	LG	MIRROR MOTOR (LH VERTICAL)
12	O	INDI	32	L	MIRROR MOTOR (LH HORIZONTAL)

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS30FW-V-CS



1	W	POWER SUPPLY (SENSOR)	33	W	POWER SUPPLY (SENSOR)
2	SB	BAT (FUSE)	34	R	BAT (FUSE)
3	SB	TELESCOPIC SW (UPWARD)	35	L	TELESCOPIC SW (UPWARD)
4	G	TELESCOPIC MOTOR (FORWARD)	36	GR	TELESCOPIC MOTOR (FORWARD)
5	SB	BAT (C/B)	39	SB	BAT (C/B)
6	GR	GRDI (SENSOR)	40	B	GRDI (SENSOR)
7	O	TILT MOTOR DOWNWARD	41	Y	TILT MOTOR DOWNWARD
9	L	TELESCOPIC SW (FRONTWARD)	42	O	TELESCOPIC SW (FRONTWARD)
10	V	TELESCOPIC SW (FRONTWARD)	44	G	TELESCOPIC SW (FRONTWARD)
11	GR	INDI	48	B	GRID (POWER)

Connector No.	M62
Connector Name	AUTOMATIC DRIVE POSITIONER
Connector Type	MO2FW-P-LC



1	W	POWER SUPPLY (SENSOR)	33	W	POWER SUPPLY (SENSOR)
2	SB	BAT (FUSE)	34	R	BAT (FUSE)
3	SB	TELESCOPIC SW (UPWARD)	35	L	TELESCOPIC SW (UPWARD)
4	G	TELESCOPIC MOTOR (FORWARD)	36	GR	TELESCOPIC MOTOR (FORWARD)
5	SB	BAT (C/B)	39	SB	BAT (C/B)
6	GR	GRDI (SENSOR)	40	B	GRDI (SENSOR)
7	O	TILT MOTOR DOWNWARD	41	Y	TILT MOTOR DOWNWARD
9	L	TELESCOPIC SW (FRONTWARD)	42	O	TELESCOPIC SW (FRONTWARD)
10	V	TELESCOPIC SW (FRONTWARD)	44	G	TELESCOPIC SW (FRONTWARD)
11	GR	INDI	48	B	GRID (POWER)

JCJWA0780GB


DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	CAN-H
8	P	CAN-L

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	4	8
4	6	10
6	8	12
8	10	14
10	12	16
12	14	47
14	45	48
16	47	49
18	51	52
20	53	54
22	55	56
24	57	58
26	59	60
28	61	62
30	63	64
32	65	66
34	67	68
36	69	70
38	71	72

Connector No.	M83
Connector Name	AV CONTROL UNIT (WITHOUT NAVI)
Connector Type	TH32FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
47	46	45
49	48	44
51	50	42
53	52	44
55	54	46
57	56	48
59	58	50
61	59	51
63	60	53
65	62	55
67	64	57
69	66	59
71	70	61
73	72	63
75	74	65
77	76	67
79	78	69
81	80	71
83	82	73
85	84	75
87	86	77
89	88	79
91	90	81
93	92	83
95	94	85
97	96	87
99	98	89
101	100	91
103	102	93
105	104	95
107	106	97
109	108	99
111	110	101

Connector No.	M85
Connector Name	AV CONTROL UNIT (WITHOUT NAVI)
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
47	46	45
49	48	44
51	50	42
53	52	44
55	54	46
57	56	48
59	58	50
61	59	51
63	60	53
65	62	55
67	64	57
69	66	59
71	70	61
73	72	63
75	74	65
77	76	67
79	78	69
81	80	71
83	82	73
85	84	75
87	86	77
89	88	79
91	90	81
93	92	83
95	94	85
97	96	87
99	98	89
101	100	91
103	102	93
105	104	95
107	106	97
109	108	99
111	110	101

Connector No.	M116
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M0DFB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
86	L	CAN-H
87	P	CAN-L
88	V	AV COMM (H)
89	Y	AV COMM (L)

Connector No.	M88
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
62	64	66
64	66	68
66	68	70
68	70	72
69	71	
71		
72		
73		
75		
77		
79		
81		
83		
85		
87		
89		
91		
93		
95		
97		
99		
101		
103		
105		
107		
109		
111		

Connector No.	M118
Connector Name	WIRE TO WIRE
Connector Type	TK3MMW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
44	SB	MODE CHANGE SIGNAL
50	LG	AV COMM (H)
51	V	AV COMM (L)
52	L	CAN-H
53	P	CAN-L

O
P

Z
M

A
B
C
D
E
F
G
H
I
J
K
L
MIR

JCJWA0781GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER		H.S.		H.S.		H.S.		H.S.	
Connector No.	N119	Terminal No.	Color of Wire	Signal Name [Specification]		Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	90	P	BAT (FUSE)	90	BR	KEY SLOT SW		
Connector Type	NS16FW-CS	91	L	GND	91	LG	DRIVER DOOR SW		
		96	QR	ATT SHIFT SELECTOR POWER SUPPLY	121	BR	CAN-L		
		99	R	SHIFT P	150	LG	CAN-H		
AUTOMATIC DRIVE POSITIONER		H.S.		H.S.		H.S.		H.S.	
Connector No.	M122	Terminal No.	Color of Wire	Signal Name [Specification]		Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	1	1	1		1	1	1	
Connector Type	TH40FB-NH	2	2	2		2	2	2	
		3	3	3		3	3	3	
		4	4	4		4	4	4	
		5	5	5		5	5	5	
		6	6	6		6	6	6	
		7	7	7		7	7	7	
		8	8	8		8	8	8	
		9	9	9		9	9	9	
		10	10	10		10	10	10	
		11	11	11		11	11	11	
		12	12	12		12	12	12	
		13	13	13		13	13	13	
		14	14	14		14	14	14	
		15	15	15		15	15	15	
		16	16	16		16	16	16	
		17	17	17		17	17	17	
		18	18	18		18	18	18	
		19	19	19		19	19	19	
AUTOMATIC DRIVE POSITIONER		H.S.		H.S.		H.S.		H.S.	
Connector No.	M123	Terminal No.	Color of Wire	Signal Name [Specification]		Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	1	1	1		1	1	1	
Connector Type	TH40FW-NH	2	2	2		2	2	2	
		3	3	3		3	3	3	
		4	4	4		4	4	4	
		5	5	5		5	5	5	
		6	6	6		6	6	6	
		7	7	7		7	7	7	
		8	8	8		8	8	8	
		9	9	9		9	9	9	
		10	10	10		10	10	10	
		11	11	11		11	11	11	
		12	12	12		12	12	12	
		13	13	13		13	13	13	
		14	14	14		14	14	14	
		15	15	15		15	15	15	
		16	16	16		16	16	16	
		17	17	17		17	17	17	
		18	18	18		18	18	18	
		19	19	19		19	19	19	
AUTOMATIC DRIVE POSITIONER		H.S.		H.S.		H.S.		H.S.	
Connector No.	M124	Terminal No.	Color of Wire	Signal Name [Specification]		Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	WIRE TO WIRE	1	1	1		1	1	1	
Connector Type	TH40AW-GS-5	2	2	2		2	2	2	
		3	3	3		3	3	3	
		4	4	4		4	4	4	
		5	5	5		5	5	5	
		6	6	6		6	6	6	
		7	7	7		7	7	7	
		8	8	8		8	8	8	
		9	9	9		9	9	9	
		10	10	10		10	10	10	
		11	11	11		11	11	11	
		12	12	12		12	12	12	
		13	13	13		13	13	13	
		14	14	14		14	14	14	
		15	15	15		15	15	15	
		16	16	16		16	16	16	
		17	17	17		17	17	17	
		18	18	18		18	18	18	
		19	19	19		19	19	19	

IC IWA0782GB

Fail Safe

INFOID:0000000004712415

The fail-safe mode may be activated if the following symptoms are observed.

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Operating in fail-safe mode	Malfunction Item	Related DTC	Diagnosis
Only manual functions operate normally.	CAN communication	U1000	ADP-44
	Tilt sensor	B2118	ADP-49
	Telescopic sensor	B2119	ADP-52
	Detent switch	B2126	ADP-55
Only manual functions, except door mirror, operate normally.	UART communication	B2128	ADP-57
Only manual functions, except seat sliding, operate normally.	Seat sliding output	B2112	ADP-45
Only manual functions, except seat reclining, operate normally.	Seat reclining output	B2113	ADP-47

DTC Index

INFOID:0000000004712416

CONSULT-III display	Timing ^{*1}		Item	Reference page
	Current malfunction	Previous malfunction		
CAN COMM CIRCUIT [U1000]	0	1-39	CAN communication	ADP-44
SEAT SLIDE [B2112]	0	1-39	Seat slide motor output	ADP-45
SEAT RECLINING [B2113]	0	1-39	Seat reclining motor output	ADP-47
TIILT SENSOR [B2118]	0	1-39	Tilt sensor input	ADP-49
TELESCO SENSOR [B2119]	0	1-39	Telescopic sensor input	ADP-52
DETENT SW [B2126]	0	1-39	Detention switch condition	ADP-55
UART COMM [B2128]	0	1-39	UART communication	ADP-57

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value

INFOID:0000000004712417

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)	
		Signal name	Input/Out-put			
1	Ground	Y	Tilt switch up signal	Input	Tilt switch	Operate (up)
						Other than above
2	Ground	LG	Changeover switch RH signal	Input	Changeover switch position	RH
						Neutral or LH
3	Ground	G	Mirror switch up signal	Input	Mirror switch	Operated (up)
						Other than above
4	Ground	V	Mirror switch left signal	Input	Mirror switch	Operated (left)
						Other than above
5	Ground	R	Door mirror sensor (RH) up/down signal	Input	Door mirror RH position	Change between 3.4 (close to peak) 0.6 (close to valley)
6	Ground	GR	Door mirror sensor (LH) up/down signal	Input	Door mirror LH position	Change between 3.4 (close to peak) 0.6 (close to valley)
7	Ground	O	Tilt sensor signal	Input	Tilt position	Change between 1.2 (close to top) 3.4 (close to bottom)
9	Ground	L	Memory switch 1 signal	Input	Memory switch 1	Push
						Other than above
10	Ground	V	UART communication (TX)	Output	Ignition switch ON	 2mSec/div 2V/div

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx.)		
+	-		Signal name	Input/Out-put					
11	Ground	GR	Telescopic switch forward signal	Input	Telescopic switch	Operate (forward)	0		
						Other than above	5		
12	Ground	O	Memory indictor 1 signal	Out-put	Memory indictor 1	Illuminate	0		
						Other than above	Battery voltage		
13	Ground	P	Memory indictor 2 signal	Out-put	Memory indictor 2	Illuminate	0		
						Other than above	Battery voltage		
14	Ground	W	Door mirror motor (RH) up output signal	Out-put	Door mirror RH	Operate (up)	Battery voltage		
						Other than above	0		
15	Ground	G	Door mirror motor (RH) left output signal	Out-put	Door mirror RH	Operate (left)	Battery voltage		
						Other than above	0		
16	Ground	Y	Door mirror motor (LH) down output signal	Out-put	Door mirror (LH)	Operate (down)	Battery voltage		
						Other than above	0		
			Door mirror motor (LH) right output signal			Operate (right)	Battery voltage		
						Other than above	0		
17	Ground	W	Tilt switch down signal	Input	Tilt switch	Operate (down)	0		
						Other than above	5		
18	Ground	P	Changeover switch LH signal	Input	Changeover switch position	LH	0		
						Neutral or RH	5		
19	Ground	SB	Mirror switch down signal	Input	Mirror switch	Operate (down)	0		
						Other than above	5		
20	Ground	BR	Mirror switch right signal	Input	Mirror switch	Operate (right)	0		
						Other than above	5		
21	Ground	L	Door mirror sensor (RH) left/right signal	Input	Door mirror RH position		Change between 3.4 (close to left edge) 0.6 (close to right edge)		
22	Ground	G	Door mirror sensor (LH) left/right signal	Input	Door mirror LH position		Change between 0.6 (close to left edge) 3.4 (close to right edge)		
23	Ground	P	Telescopic sensor signal	Input	Telescopic position		Change between 0.8 (close to top) 3.4 (close to bottom)		

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N


O

P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx.)		
+	-		Signal name	Input/ Out- put					
24	Ground	R	Set switch signal	Input	Set switch	Push	0		
						Other than above	5		
25	Ground	SB	Memory switch 2 signal	Input	Memory switch 2	Push	0		
						Other than above	5		
26	Ground	Y	UART communication (RX)	Input	Ignition switch ON		 10mSec/div 2V/div JMJIA0121ZZ		
27	Ground	G	Telescopic switch back-ward signal	Input	Telescopic switch	Operate (back-ward)	0		
						Other than above	5		
30	Ground	R	Door mirror motor (RH) down output signal	Output	Door mirror (RH)	Operate (down)	Battery voltage		
			Door mirror motor (RH) right output signal			Other than above	0		
						Operate (right)	Battery voltage		
						Other than above	0		
31	Ground	LG	Door mirror motor (LH) up output signal	Output	Door mirror (LH)	Operate (up)	Battery voltage		
						Other than above	0		
32	Ground	L	Door mirror motor (LH) left output signal	Output	Door mirror (LH)	Operate (left)	Battery voltage		
						Other than above	0		
33	Ground	W	Sensor power supply	Input	—		5		
34	Ground	R	Power source (Fuse)	Input	—		Battery voltage		
35	Ground	L	Tilt motor up output signal	Output	Steering tilt	Operate (up)	Battery voltage		
						Other than above	0		
36	Ground	GR	Telescopic motor forward output signal	Output	Steering telescopic	Operate (forward)	Battery voltage		
						Other than above	0		
39	Ground	SB	Power source (C/B)	—	—		Battery voltage		
40	Ground	B	Ground	—	—		0		
41	Ground	Y	Sensor ground	—	—		0		

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx.)
+	-		Signal name	Input/ Out- put		
42	Ground	O	Tilt motor down output signal	Out-put	Steering tilt	Battery voltage
						0
44	Ground	G	Telescopic motor backward output signal	Out-put	Steering tele- scopic	Battery voltage
						0
48	Ground	B	Ground	—	—	0

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O


P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -




JCJWA0773GB

INFOID:000000004712418

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCJWA0774GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCJWA0775GB


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH30FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	-	1	G	-
34	L	-	3	L	-
35	P	-	17	LG	-
38	BR	-	19	P	-
39	LG	-	21	Y	-
49	G	-	32	B	-
50	Y	-	33	SB	-
55	V	-	40	BR	-
48	-	-	48	-	-

Connector No.	B11
Connector Name	WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH30FW-CS



21	L/Y	P RANGE SW
24	R	PULSE(SLIDING)
25	Y/B	PULSE(LIFTING)
26	Y	SLIDING(SW FORWARD)
27	R/G	RECLINING(SW FORWARD)
28	W/B	FRONT LIFTING(SW UPWARD)
29	P/L	REAR LIFTING(SW UPWARD)
31	GR	SENSOR GND
32	B/W	GND(SIGNAL)

33	34	35	36	37	38	39
40	41	42	43	44	45	47
48	B	-	-	-	-	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	AD37W

Connector No.	B453
Connector Name	SLIDING SENSOR
Connector Type	6098 0241

24	31	16
H.S.	-	-
-	-	-
-	-	-
-	-	-

33	34	35	36	37	38	39
40	41	42	43	44	45	47
48	B	-	-	-	-	-

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

Connector No.	B454	Connector No.	B459
Connector Name	RECLINING MOTOR	Connector Name	POWER SEAT SWITCH (DRIVER SIDE)
Connector Type	NS30FVW-CS	Connector Type	NS10FW-CS
			



Terminal No.	Color of Wire	Signal Name [Specification]
9	W/G	-
16	O	O
25	Y/B	-
31	GR	-
36	GR/Y	-
37	G/W	-
44	P	-
45	L/R	-

Connector No.	B456	Connector No.	B458
Connector Name	LIFTING MOTOR (FRONT) / DRIVER SIDE)	Connector Name	LIFTING MOTOR (REAR) / DRIVER SIDE)
Connector Type	NS30FVW-CS	Connector Type	NS30FVW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
25	Y/B	-
31	GR	-
38	L/Y	-
39	R/B	-

Connector No.	B459	Connector No.	B459
Connector Name	POWER SEAT SWITCH (DRIVER SIDE)	Connector Name	POWER SEAT SWITCH (DRIVER SIDE)
Connector Type	NS10FW-CS	Connector Type	NS10FW-CS



11	BR	-
12	SB	-
13	LG/R	-
14	G/B	-
26	Y	-
27	R/G	-
28	W/B	-
29	P/L	-
32	B/W	-

Connector No.	B461	Connector No.	D1
Connector Name	SLIDING MOTOR (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)	Connector Name	WIRE TO WIRE
Connector Type	6098-0239	Connector Type	TH14DFVW-CS15



39	O	-
40	BR	-
41	L	-
42	GR	- [With automatic drive positioner]
43	BR	- [With automatic drive positioner]
44	W	- [With automatic drive positioner]
45	Y	- [With automatic drive positioner]
46	P	- [With automatic drive positioner]
49	GR	-

Connector No.	B460	Connector No.	B460
Connector Name	WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)	Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS	Connector Type	NS10FW-CS



15	14	[Specification]
16	13	[Specification]
17	12	[Specification]
18	11	[Specification]
19	10	[Specification]
20	9	[Specification]
21	8	[Specification]
22	7	[Specification]
23	6	[Specification]
24	5	[Specification]
25	4	[Specification]
26	3	[Specification]
27	2	[Specification]
28	1	[Specification]
45	44	[Specification]
46	43	[Specification]
47	42	[Specification]
48	41	[Specification]
49	40	[Specification]
50	39	[Specification]
51	38	[Specification]
52	37	[Specification]
53	36	[Specification]
54	35	[Specification]
55	34	[Specification]
56	33	[Specification]
57	32	[Specification]
58	31	[Specification]
59	30	[Specification]
60	29	[Specification]
61	28	[Specification]
62	27	[Specification]
63	26	[Specification]
64	25	[Specification]
65	24	[Specification]
66	23	[Specification]
67	22	[Specification]
68	21	[Specification]
69	20	[Specification]
70	19	[Specification]
71	18	[Specification]
72	17	[Specification]
73	16	[Specification]
74	15	[Specification]

13	B	-
21	O	-
22	P	-
23	BR	-
24	V	-
25	GR	-
26	Y	-
30	G	-
36	L	-
37	R	-
38	P	-

JCJWA0777GB


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH24MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
10	G	- (With automatic drive positioner)	1	L	-
11	P	-	2	BR	-
12	O	- (With automatic drive positioner)	3	GR	-
21	GR	-	4	B	-
22	BR	-	5	R	-
23	Y	-	6	O	-
24	V	-	7	P	-

Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Type	A08FW




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	3	-	4	5	-
2	5	-	5	6	-
3	6	-	6	7	-
4	7	-	7	1	-
5	1	-	8	2	-
6	2	-	9	3	-
7	3	-	10	4	-
8	4	-	11	5	-
9	5	-	12	6	-
10	6	-	13	7	-
11	7	-	14	8	-
12	8	-	15	9	-
13	9	-	16	10	-
14	10	-	17	11	-

Connector No.	D17
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH WITH AUTOMATIC DRIVE POSITIONER
Connector Type	TK16FR




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
15	15	-	4	43	-
14	14	-	5	44	Y
13	13	-	6	45	P
12	12	-	7	46	W
11	11	-	8	52	Y
10	10	-	9	53	G
9	9	-	10	54	W
8	8	-			
7	7	-			
6	6	-			
5	5	-			
4	4	-			
3	3	-			
2	2	-			
1	1	-			

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
15	15	-	4	43	-
14	14	-	5	44	Y
13	13	-	6	45	P
12	12	-	7	46	W
11	11	-	8	52	Y
10	10	-	9	53	G
9	9	-	10	54	W
8	8	-			
7	7	-			
6	6	-			
5	5	-			
4	4	-			
3	3	-			
2	2	-			
1	1	-			

Connector No.	F103
Connector Name	A-T ASSEMBLY
Connector Type	TK36FW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
5	5	-	4	43	-
4	4	-	5	44	Y
3	3	-	6	45	P
2	2	-	7	46	W
1	1	-	8	52	Y
10	10	-	9	53	G
9	9	-	10	54	W
8	8	-			
7	7	-			
6	6	-			
5	5	-			
4	4	-			
3	3	-			
2	2	-			
1	1	-			

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
16	16	-	5	43	-
15	15	-	6	44	Y
14	14	-	7	45	P
13	13	-	8	46	W
12	12	-	9	52	Y
11	11	-	10	53	G
10	10	-	11	54	W
9	9	-			
8	8	-			
7	7	-			
6	6	-			
5	5	-			
4	4	-			
3	3	-			
2	2	-			
1	1	-			

JCJWA0778GB

M

Z

P

O

M

A

C

D

T

G

I

K

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

AUTOMATIC DRIVE POSITIONER

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NSD6FW-M2
	

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	CAN-H
2	LY	CAN-L

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
21	LG	-
22	L	-
23	G	-
24	Y	-
25	GR	-
26	W	-
30	Y	-
36	LG	-
37	BR	-
38	P	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Connector No.	M2
Connector Name	KEY SWITCH SIGNAL
Connector Type	BD16FW

JCJWA0779GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M51
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TK04FW-GY



Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TK04FW




Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS30FW-V-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	GR	-
3	G	-
4	Y	-
5	W	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	O	-
4	L	-

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32



Connector No.	M52
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NS30FW-V-CS



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

JCJWA0780GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

Connector No.	Connector Name	Connector Type	Diagram	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M67	UNIFIED METER AND A/C AMP.	TH32FW-NH		1 2 3 4 5 6 7 8 9 10 11 12 13 14	L G V Y	AV COMM (H) AV COMM (L)	41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56	41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56	AV CONTROL UNIT (WITHOUT NAVI)
M72	MULTIFUNCTION SWITCH	TH16FW-NH		1 2 3 4 5 6 7 8 9 10 11 12	L G V Y	AV COMM (H) AV COMM (L)	41 42 43 44 45 46 47 48 49 50 51 52	AV CONTROL UNIT (WITHOUT NAVI)	
M83	AV CONTROL UNIT (WITHOUT NAVI)	TH12FW-NH		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36	Br L P W Y	AV CONTROL UNIT (WITHOUT NAVI)	41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72	AV CONTROL UNIT (WITHOUT NAVI)	
M85	AV CONTROL UNIT (WITHOUT NAVI)	TH32FW-NH		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36	Br L P W Y	AV CONTROL UNIT (WITHOUT NAVI)	41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72	AV CONTROL UNIT (WITHOUT NAVI)	
M88	AV CONTROL UNIT (WITH NAVI)	TH12FW-NH		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71	Br L P W Y	AV CONTROL UNIT (WITH NAVI)	62 63 64 65 66 67 68 69 70 71	AV CONTROL UNIT (WITH NAVI)	
M116	WIRE TO WIRE	TK35MW-NS10		1 2 3 4 5 6 7 8 9 10	Br L P W Y	WIRE TO WIRE	44 50 55 56	CAN-H CAN-L	CAN-H CAN-L
M118	BCM (BODY CONTROL MODULE)	M05FB-LC		1 2	Br L P W Y	BCM (BODY CONTROL MODULE)	86 87 88 89	L P LG V	L P AV COMM (H) AV COMM (L)

JCJWA0781GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M119
Connector Name	BCM(BODY CONTROL MODULE)
Connector Type	NS16FVY-CS




Connector No.	M122
Connector Name	BCM(BODY CONTROL MODULE)
Connector Type	TH40FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (FUSE)
13	B	GND
90	P	
91	L	CAN-L
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHTF P

Terminal No.	Color of Wire	Signal Name [Specification]
121	BR	KEY SLOT SW
150	LG	DRIVER DOOR SW
44	Y	
45	R	
46	W	
52	R	
53	G	
54	W	

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40NW-CS15




Connector No.	M123
Connector Name	BCM(BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	
9	9	
10	10	
11	11	
12	12	
13	13	
14	14	
15	15	

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40NW-CS15



A

B

C

D

E

F

G

H

K

MIR

M

Z

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000004919126

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK.	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK.	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

TERMINAL LAYOUT



PHYSICAL VALUES


A
B
C
D
E
F
G
H
I
J
K
L
MIR
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC







JSNIA0010GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (O)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
23 (G)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
34 (SB)	Ground	Luggage room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment
				 JKMKA0062GB
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compartment
				 JKMKA0063GB
38 (B)	Ground	Back door antenna (-)	Output When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 JKMKA0062GB
				When Intelligent Key is not in the antenna detection area
				 JKMKA0063GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
64 (V)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	 JPMIA0016GB 1.0 V
					Not in stop position	0 V

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
66 (R)	Ground	Back door switch	Input	Back door switch
				OFF (Door close)
				 JPMIA0011GB 11.8 V
				ON (Door open)
				0 V
67 (G)	Ground	Back door opener switch	Input	Back door opener switch
				Pressed
				 JPMIA0011GB 11.8 V
				Not pressed
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch
				OFF (Door close)
				 JPMIA0011GB 11.8 V
				ON (Door open)
				0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch
				OFF (Door close)
				 JPMIA0011GB 11.8 V
				ON (Door open)
				0 V

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 JMKA0062GB
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 JMKA0063GB
74 (SB)	Ground	Passenger door an- tenna (-)	Output When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area
				 JMKA0062GB
				When Intelligent Key is not in the antenna detection area
				 JMKA0063GB

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O


P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
75 (GR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF



JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB



JMKIA0062GB




JMKIA0063GB

BCM (BODY CONTROL MODULE)


[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				When Intelligent Key is not in the passenger compart- ment
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				When Intelligent Key is not in the passenger compart- ment
80 (GR)	Ground	NATS antenna amp (Built in key slot)	Input/ Output During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (Built in key slot)	Input/ Output During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output Ignition switch	OFF or ACC ON
				0 V Battery voltage




JMKIA0062GB



JMKIA0063GB



JMKIA0062GB



JMKIA0063GB

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N







O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	 During waiting
				 When operating either button on the key
87 (BR)	Ground	Combination switch INPUT 5	Input	 All switches OFF (Wiper intermittent dial 4) 1.4 V
				 Front fog lamp switch ON (Wiper intermittent dial 4) 1.3 V
				 Rear wiper switch ON (Wiper intermittent dial 4) 1.3 V
				 Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 1.3 V

BCM (BODY CONTROL MODULE)

[WITH ADP]




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Lighting switch HI (Wiper intermittent dial 4)	 JPMIA0036GB 1.3 V
				Lighting switch 2ND (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear washer switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 JPMIA0040GB 1.3 V
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni-tion switch (push switch)	Pressed
					Not pressed
90 (P)	Ground	CAN-L	Input/ Output	—	
91 (L)	Ground	CAN-H	Input/ Output	—	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	0 V
					Blinking	 (V) 15 10 5 0 1 s
					ON	6.5 V JPMIA0015GB
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
						1.0 V JPMIA0016GB
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
						1.0 V JPMIA0016GB
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF	Battery voltage
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	Battery voltage 0 V
107 (LG)	Ground	Combination switch INPUT 1	Input	All switches OFF	 (V) 15 10 5 0 2 ms <small>JPMIA0041GB</small> 1.4 V
				Turn signal switch LH	 (V) 15 10 5 0 2 ms <small>JPMIA0037GB</small> 1.3 V
				Turn signal switch RH	 (V) 15 10 5 0 2 ms <small>JPMIA0036GB</small> 1.3 V
				Front wiper switch LO	 (V) 15 10 5 0 2 ms <small>JPMIA0038GB</small> 1.3 V
				Front washer switch ON	 (V) 15 10 5 0 2 ms <small>JPMIA0039GB</small> 1.3 V

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N






O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input Combination switch	All switches OFF (Wiper intermittent dial 4)
				 1.4 V JPMIA0041GB
				Lighting switch AUTO (Wiper intermittent dial 4)
				 1.3 V JPMIA0038GB
				Lighting switch 1ST (Wiper intermittent dial 4)
				 1.3 V JPMIA0036GB
				Rear wiper switch INT (Wiper intermittent dial 4)
				 1.3 V JPMIA0040GB
				Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
				 1.3 V JPMIA0039GB

BCM (BODY CONTROL MODULE)

[WITH ADP]



< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
109 (Y)	Ground	Combination switch INPUT 2	Input Combination switch (Wiper intermittent dial 4)	All switches OFF	 (V) 15 10 5 0 2 ms
				Lighting switch PASS	 (V) 15 10 5 0 2 ms
				Lighting switch 2ND	 (V) 15 10 5 0 2 ms
				Front wiper switch INT	 (V) 15 10 5 0 2 ms
				Front wiper switch HI	 (V) 15 10 5 0 2 ms
110 (G)	Ground	Hazard switch	Input Hazard switch	ON	0 V
				OFF	 (V) 15 10 5 0 10 ms

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage	
					LOCK or UNLOCK	 (V) 15 10 5 0 50 ms	
					For 15 seconds after UN-LOCK	Battery voltage	
					15 seconds or later after UNLOCK	0 V	
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 (V) 15 10 5 0 10 ms	
					UNLOCK status (Unlock switch sensor ON)	1.1 V 0 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
124 (LG)	Ground	Passenger door switch	Input	 JPMIA0011GB 11.8 V
132 (V)	Ground	Power window switch communication	Input/ Output	 JPMIA0013GB 10.2 V
				Ignition switch OFF or ACC
133 (W)	Ground	Push-button ignition switch illumination	Output	 JPMIA0159GB 9.5 V
				ON (Tail lamps ON)
				OFF
134 (GR)	Ground	LOCK indicator lamp	Output	 MIR
137 (O)	Ground	Receiver and sensor ground	Input	 M N
138 (Y)	Ground	Receiver and sensor power supply	Output	 O P

BCM (BODY CONTROL MODULE)

[WITH ADP]





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB 11.3 V
					OFF	Battery voltage
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	 JPMIA0031GB 10.7 V
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF	
					<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	 JPMIA0032GB 10.7 V

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	(V)  JPMIA0033GB
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	10.7 V
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front wiper switch INT	(V)  JPMIA0034GB
					Front wiper switch LO	
					Lighting switch AUTO	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	(V)  JPMIA0035GB
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	10.7 V
149 (W)	Ground	Tire pressure warning check switch	Input	Ignition switch ON		(V)  JPMIA0011GB
150 (LG)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	(V)  JPMIA0011GB
					ON (Door open)	
151 (G)	Ground	Rear window defogger relay control	Output	Rear window de-fogger	Active	0 V
					Not activated	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
MIR
M
N
O
P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Wiring Diagram - BCM -

INFOID:000000004919127




JCMWA3119GB

2008/08/28

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >



* : This connector is not shown in "Harness Layout".

JCMWAWA3120GB


A B C D E F G H I J K L M N O P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JCMWA3121GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCMWA3122GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Z

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCMWA3123GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MOSFB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
5	L	OUTLET 3
7	Y	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(RAP)
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY	4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSANGER DOOR UNLOCK OUTPUT	5	L	PASSANGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT	7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL ID LOCK OUTPUT	8	V	ALL DOOR FUEL ID LOCK OUTPUT
9	G	DRIVER DOOR FUEL ID UNLOCK OUTPUT	9	G	DRIVER DOOR FUEL ID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT	10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)	11	R	BAT (FUSE)
13	B	GND	13	B	GND
14	W	PUSH-BUTTON IGNITION SWILL GND	14	W	PUSH-BUTTON IGNITION SWILL GND
15	Y	ACCO IND	15	Y	ACCO IND
17	W	TURN SIGNAL RH (FRONT)	17	W	TURN SIGNAL RH (FRONT)

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	21	TURN SIGNAL RH (REAR)
25	26	BACK DOOR OPEN OUTPUT
26	27	TURN SIGNAL LH (REAR)
27	28	REAR WIPER OUTPUT
29	30	
31	32	

Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	Y	LUGGAGE ROOM ANT-
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT-
47	Y	IGN RELAY (PDM E/R) CONT-
52	SB	STARTER RELAY CONT
61	W	BACK DOOR OPENER REQUEST SW
64	V	I-KEY WARN BUZZER (ENG ROOM)
65	O	REAR WIPER STOP POSITION
66	R	BACK DOOR SW
67	GR	BACK DOOR OPENER SW

JCMWA3124GB

A
B
C
D
M
T
G
I
—
K
Z
MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)	
Connector No.	M122
Connector Name	BCM(BODY CONTROL MODULE)
Connector Type	TH40F6-NH
83	Y
87	BR
88	V
89	BR
90	P
91	L
92	LG
93	V
94	Y
95	O
96	GR
97	L
98	P
99	R
100	G
101	SB
102	O
103	LG
106	W
107	LG
108	R
109	Y
110	G
111	Y

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-	73	G	ROOM ANT2+
73	G	ROOM ANT2+	74	SB	ROOM ANT2-
74	SB	PASSENGER DOOR ANT-	75	GR	PASSENGER DOOR ANT+
75	GR	PASSENGER DOOR ANT+	76	V	DRIVER DOOR ANT-
76	V	DRIVER DOOR ANT-	77	LG	DRIVER DOOR ANT+
77	LG	DRIVER DOOR ANT+	78	Y	ROOM ANT1-
78	Y	ROOM ANT1-	79	BR	ROOM ANT1+
79	BR	IMMOB ANTENA CONTROL	80	GR	IMMOB ANTENA SIGNAL
81	W	IMMOB ANTENA SIGNAL	82	R	IGN RELAY (F/B) CONT

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
98	P	S/L CONDITION 1	99	R	S/L CONDITION 2
99	R	SHIFT P	100	G	PASSENGER DOOR REQUEST SW
100	G	DRIVER DOOR REQUEST SW	101	SB	DRIVER DOOR REQUEST SW
101	SB	BLOWER FAN MOTOR RELAY CONT	102	O	BLOWER FAN MOTOR RELAY CONT
102	O	KETLESS ENTRY RECEIVER POWER SUPPLY	103	LG	KETLESS ENTRY RECEIVER POWER SUPPLY
103	LG	S/L UNIT POWER SUPPLY	106	W	S/L UNIT POWER SUPPLY
106	W	COMBI SW INPUT 1	107	LG	COMBI SW INPUT 1
107	LG	COMBI SW INPUT 2	108	R	COMBI SW INPUT 4
108	R	HAZARD SW	109	Y	COMBI SW INPUT 2
109	Y	S/L UNIT COMM	110	G	POWER WINDOW SW COMM
110	G	LOCK IND	111	Y	PUSH BUTTON IGNITION SW/TLL POWER
111	Y	RECEIVER/SENSOR GRID	134	GR	LOCK IND
134	GR	RECEIVER/SENSOR GRID	137	O	RECEIVER/SENSOR GRID

JCMWA3125GB

INFOID:0000000004919128

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Power position: IGN • Selector lever P/N position signal: Except P and N positions (0 V) • Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000004919129

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Priority	DTC	
1	B2562: LOW VOLTAGE	A
2	<ul style="list-style-type: none">• U1000: CAN COMM CIRCUIT• U1010: CONTROL UNIT (CAN)	B
3	<ul style="list-style-type: none">• B2190: NATS ANTENNA AMP• B2191: DIFFERENCE OF KEY• B2192: ID DISCORD BCM-ECM• B2193: CHAIN OF BCM-ECM• B2195: ANTI SCANNING	C
	<ul style="list-style-type: none">• B2013: ID DISCORD BCM-S/L• B2014: CHAIN OF S/L-BCM• B2553: IGNITION RELAY• B2555: STOP LAMP• B2556: PUSH-BTN IGN SW• B2557: VEHICLE SPEED• B2560: STARTER CONT RELAY• B2601: SHIFT POSITION• B2602: SHIFT POSITION• B2603: SHIFT POSI STATUS• B2604: PNP SW• B2605: PNP SW• B2606: S/L RELAY• B2607: S/L RELAY• B2608: STARTER RELAY• B2609: S/L STATUS• B260A: IGNITION RELAY• B260B: STEERING LOCK UNIT• B260C: STEERING LOCK UNIT• B260D: STEERING LOCK UNIT• B260F: ENG STATE SIG LOST• B2612: S/L STATUS• B2614: ACC RELAY CIRC• B2615: BLOWER RELAY CIRC• B2616: IGN RELAY CIRC• B2617: STARTER RELAY CIRC• B2618: BCM• B2619: BCM• B261A: PUSH-BTN IGN SW• B261E: VEHICLE TYPE• B26E9: S/L STATUS• B26EA: KEY REGISTRATION• C1729: VHCL SPEED SIG ERR• U0415: VEHICLE SPEED SIG	D
4		E
		F
		G
		H
		I
		J
		K
		MIR
		M
		N
		O
		P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Priority	DTC
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA

DTC Index

INFOID:000000004919130

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-16. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	BCS-37
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-38
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-39
B2013: ID DISCORD BCM-S/L	×	×	—	—	SEC-48
B2014: CHAIN OF S/L-BCM	×	×	—	—	SEC-49
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-41
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-44
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-45
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-46
B2195: ANTI SCANNING	×	—	—	—	SEC-47
B2553: IGNITION RELAY	—	×	—	—	PCS-49

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2555: STOP LAMP	—	×	—	—	SEC-52
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-54
B2557: VEHICLE SPEED	×	×	×	—	SEC-56
B2560: STARTER CONT RELAY	×	×	×	—	SEC-57
B2562: LOW VOLTAGE	—	×	—	—	BCS-40
B2601: SHIFT POSITION	×	×	×	—	SEC-58
B2602: SHIFT POSITION	×	×	×	—	SEC-61
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-63
B2604: PNP SW	×	×	×	—	SEC-66
B2605: PNP SW	×	×	×	—	SEC-68
B2606: S/L RELAY	×	×	×	—	SEC-70
B2607: S/L RELAY	×	×	×	—	SEC-71
B2608: STARTER RELAY	×	×	×	—	SEC-73
B2609: S/L STATUS	×	×	×	—	SEC-75
B260A: IGNITION RELAY	×	×	×	—	PCS-51
B260B: STEERING LOCK UNIT	—	×	×	—	SEC-79
B260C: STEERING LOCK UNIT	—	×	×	—	SEC-80
B260D: STEERING LOCK UNIT	—	×	×	—	SEC-81
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-82
B2612: S/L STATUS	×	×	×	—	SEC-86
B2614: ACC RELAY CIRC	—	×	×	—	PCS-53
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-56
B2616: IGN RELAY CIRC	—	×	×	—	PCS-59
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-90
B2618: BCM	×	×	×	—	PCS-62
B2619: BCM	×	×	×	—	SEC-92
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-93
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	SEC-96
B2621: INSIDE ANTENNA	—	×	—	—	DLK-59
B2622: INSIDE ANTENNA	—	×	—	—	DLK-61
B2623: INSIDE ANTENNA	—	×	—	—	DLK-63
B26E1: ENG STATE NO RES	×	×	×	—	SEC-83
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	—	SEC-84
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-85
C1704: LOW PRESSURE FL	—	—	—	×	WT-17
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	

A
B
C
D
E
F
G
H
I
J
K
MIR
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1708: [NO DATA] FL	—	—	—	×	WT-19
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	—	×	WT-22
C1713: [CHECKSUM ERR] FR	—	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-25
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1720: [CODE ERR] FL	—	—	—	×	WT-27
C1721: [CODE ERR] FR	—	—	—	×	
C1722: [CODE ERR] RR	—	—	—	×	
C1723: [CODE ERR] RL	—	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	—	×	WT-30
C1725: [BATT VOLT LOW] FR	—	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-33
C1734: CONTROL UNIT	—	—	—	×	WT-34

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004344760

1.CHECK AUTOMATIC DRIVE POSITIONER SYSTEM

Check door mirror operate with automatic drive positioner system.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check automatic drive positioner system operation. Refer to [ADP-12, "AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram"](#)

2.CHECK DOOR MIRROR REMOTE CONTROL SWITCH (MIRROR SWITCH)

Check mirror switch.

Refer to [MIR-11, "MIRROR SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH (CHANGEOVER SWITCH)

Check changeover switch.

Refer to [MIR-13, "CHANGEOVER SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH ADP]

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000004344761

1.CHECK DOOR MIRROR (MANUAL FUNCTION)

Check door mirror function with door mirror remote control switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DTC

Check DTC for TCM.

Refer to [TM-39, "Diagnosis Description"](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#)

NO >> GO TO 1.

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:0000000004344762



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-97, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

MIR

DUPPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to [MIR-95, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000004344763

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

Diagnostic Worksheet

INFOID:0000000004344764







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only about _____ mph | <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns: left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> buzz (like a bumble bee) |

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

- | | | | |
|--|--------------------------|--------------------------|-------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000004932827

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

PREPARATION

[WITH ADP]


<PREPARATION>

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000004344766

Tool name	Description
Remover tool  PIIB7923J	Remove the clip and pawl and metal clip

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View

INFOID:000000004344767


Base



1. Inside mirror
2. Mirror base

Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
2. Mirror base
3. Inside mirror cover
4. Harness connector
5. TORX bolt

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000004344768

REMOVAL

Base model

INSIDE MIRROR


[WITH ADP]

< REMOVAL AND INSTALLATION >

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:


When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

< REMOVAL AND INSTALLATION >

OUTSIDE MIRROR DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Exploded View

INFOID:000000004344769



- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |

Clip

Pawl

MIR

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:000000004344770

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14, "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Remove clips and remove corner cover.
3. Disconnect door mirror harness connector.
4. Remove door mirror mounting nuts, and remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-173, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Special Repair Requirement"](#).

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:000000004344771

DISASSEMBLY

OUTSIDE MIRROR

[WITH ADP]

< REMOVAL AND INSTALLATION >

1. Remove door mirror cover. Refer to [MIR-106, "DOOR MIRROR COVER : Disassembly and Assembly"](#)
2. Remove side camera after removing door mirror assembly (BOSE audio with navigation model). Refer to [AV-600, "Removal and Installation"\(RH\)](#) or [AV-599, "Removal and Installation"\(LH\)](#)
3. Remove base cover and puddle lamp.


ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Exploded View

INFOID:000000004684578



- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |

(○) : Clip

(△) : Pawl

GLASS MIRROR : Disassembly and Assembly

INFOID:000000004344773

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.


NOTE:

OUTSIDE MIRROR

[WITH ADP]

< REMOVAL AND INSTALLATION >

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassemble.


CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Exploded View

INFOID:0000000004684579



- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |
- : Clip
△ : Pawl

OUTSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITH ADP]

DOOR MIRROR COVER : Disassembly and Assembly

INFOID:000000004344775

CAUTION:

Do not damage the mirror bodies.

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-104, "GLASS MIRROR : Disassembly and Assembly"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITH ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:0000000004712410

Refer to [INT-11, "DRIVER SIDE : Exploded View"](#)


Removal and Installation

INFOID:0000000004712411

REMOVAL

1. Remove the power window main switch finisher (2). Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#)
2. Remove door mirror remote control switch (1) from power window main switch finisher using screwdriver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

SYSTEM DESCRIPTION**DOOR MIRROR SYSTEM****Component Description**

INFOID:000000004344778

Component	Function
Door mirror remote control switch	It supplies power to mirror motor through mirror switch and changeover switch.
Door mirror	It makes mirror face operate from side to side and up and down with the mirror control switch operation.

INSIDE MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT ADP]

INSIDE MIRROR SYSTEM

System Description

INFOID:0000000004344779

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:0000000004344780

Component	Function
Auto anti-dazzling inside mirror	It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -

INFOID:000000004344781

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)



2008/08/28

JCLWA2505GB

DOOR MIRROR SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
MIR

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
10	Y	- [Without automatic drive positioner]
11	P	-
12	L	- [Without automatic drive positioner]
13	B	-
14	P	-
15	O	-
16	L	-

Connector No.	D3
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH24MW-NH

Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
14	O	- [Without automatic drive positioner]
15	GR	- [Without automatic drive positioner]
16	G	- [Without automatic drive positioner]
17	V	- [Without automatic drive positioner]

Connector No.	D7
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	TK16FW

Terminal No.	Color of Wire	Signal Name [Specification]
15	Y	-
14	BR	-
13	GR	-
12	V	-
11	W	-
10	GR	- [Without automatic drive positioner]
9	Y	- [Without automatic drive positioner]
8	P	- [Without automatic drive positioner]
7	GR	- [Without automatic drive positioner]
6	V	- [Without automatic drive positioner]
5	W	- [Without automatic drive positioner]
4	GR	- [Without automatic drive positioner]
3	Y	- [Without automatic drive positioner]
2	P	- [Without automatic drive positioner]
1	GR	- [Without automatic drive positioner]

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	V	-
4	W	-
5	GR	-
6	Y	-
7	GR	-
8	V	-
9	W	-
10	GR	-
11	Y	-
12	GR	-
13	V	-
14	W	-
15	GR	-
16	Y	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	V	-
4	W	-
5	GR	-
6	Y	-
7	GR	-
8	V	-
9	W	-
10	GR	-
11	Y	-
12	GR	-
13	V	-
14	W	-
15	GR	-
16	Y	-

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	V	-
4	W	-
5	GR	-
6	Y	-
7	GR	-
8	V	-
9	W	-
10	GR	-
11	Y	-
12	GR	-
13	V	-
14	W	-
15	GR	-
16	Y	-

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

Wiring Diagram - INSIDE MIRROR SYSTEM -

INFOID:0000000004712649

PM : With automatic drive positioner
OP : Without automatic drive positioner

INSIDE MIRROR



2008/08/28

JCLWA2507GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

INSIDE MIRROR		
Connector No.	M1	M2
Connector Name	FUSE BLOCK (J/B)	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2	NS10FW-CS
		
Terminal No.	2A	3A
Color of Wire	G	2A 1A 2B 1B 3A 2A 3B 2B 4A 3A 4B 3B 5A 4A 5B 4B
Signal Name [Specification]	-	-

Connector No.	M2	M106
Connector Name	FUSE BLOCK (J/B)	WIRE TO WIRE
Connector Type	TK10MW-NS8	TK10FW-NS8
		
Terminal No.	1 2 3 4 5 11 12 13 14 15 6 7 8 9 10 16 17 18	10 9 8 7 6 18 17 16 15 14 5 4 3 2 1 13 12 11
Color of Wire	-	-
Signal Name [Specification]	-	-

Connector No.	R3	R6
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Type	TK10FB-NH	JAA07FB
		
Terminal No.	5 4 3 2 1 10 9 8 7 6	7 6 5 4 3 2 1
Color of Wire	BR	-
Signal Name [Specification]	IGN GND BAT	-

JCLWA2508GB

A B C D E F G H I J K L M N O P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >


[WITHOUT ADP]

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000004684604



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-118, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [MIR-116, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

MIR

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:0000000004684605

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

A

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

B

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

C

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

D

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

E

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

F

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

G

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

H

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

I

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

J

K

L

MIR

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

Diagnostic Worksheet

INFOID:000000004684606







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

A

B

C

D

E

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only about _____ mph | <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns: left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> buzz (like a bumble bee) |

F

G

H

I

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

MIR

Vehicle test driven with customer

M

- Noise verified on test drive

N

- Noise source located and repaired

- Follow up test drive performed to confirm repair

O

VIN: _____

Customer Name: _____

P

W.O.# _____

Date: _____

This form must be attached to Work Order

PIIB8742E

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004932829

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >


[WITHOUT ADP]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000004684603

Tool name	Description
Remover tool	 PIIB7923J Remove the clip and pawl and metal clip

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View

INFOID:000000004684592


Base



1. Inside mirror
2. Mirror base

Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
2. Mirror base
3. Inside mirror cover
4. Harness connector
5. TORX bolt

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000004684593

REMOVAL

Base model

INSIDE MIRROR


[WITHOUT ADP]

< REMOVAL AND INSTALLATION >

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

A
B
C
D

E

F

G

H

I

J

K

MIR

M

N

O

P

OUTSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

OUTSIDE MIRROR DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Exploded View

INFOID:000000004684594



- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |

○ : Clip

△ : Pawl

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:000000004684595

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#) (driver side) or [INT-14, "PASSENGER SIDE : Removal and Installation"](#) (passenger side).
2. Remove clips and remove corner cover.
3. Disconnect door mirror harness connector.
4. Remove door mirror mounting nuts, and remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-173, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Special Repair Requirement"](#).

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:000000004684596

DISASSEMBLY

OUTSIDE MIRROR

[WITHOUT ADP]

< REMOVAL AND INSTALLATION >

1. Remove door mirror cover. Refer to [MIR-127, "DOOR MIRROR COVER : Disassembly and Assembly"](#)
2. Remove side camera after removing door mirror assembly (BOSE audio with navigation model). Refer to [AV-600, "Removal and Installation"\(RH\)](#) or [AV-599, "Removal and Installation"\(LH\)](#)
3. Remove base cover and puddle lamp.


ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Exploded View

INFOID:0000000004684597



JMKIA2089ZZ

- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |

○ : Clip

△ : Pawl

MIR

GLASS MIRROR : Disassembly and Assembly

INFOID:0000000004684599

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.

NOTE:

O


P

OUTSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



JMLIA0056ZZ

4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassembly.


CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Exploded View

INFOID:0000000004684600



JMKIA2089ZZ

- | | | |
|--|---|-----------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Corner cover | |
- Clip : Clip
Pawl : Pawl

OUTSIDE MIRROR

[WITHOUT ADP]

< REMOVAL AND INSTALLATION >

DOOR MIRROR COVER : Disassembly and Assembly

INFOID:000000004684602

A

CAUTION:

Do not damage the mirror bodies.

B

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-125, "GLASS MIRROR : Disassembly and Assembly"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

C

ASSEMBLY

Assemble in the reverse order of disassemble.

D

CAUTION:

After installation, visually check that pawls are securely engaged.

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:0000000004344797

Refer to [INT-17, "Exploded View"](#)


Removal and Installation

INFOID:0000000004344798

REMOVAL

1. Remove the power window main switch finisher (2). Refer to [INT-11, "DRIVER SIDE : Exploded View"](#).
2. Remove door mirror remote control switch (1) from power window main switch finisher (2) using screwdriver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.