

SECTION **SE**  
SEAT

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

CONTENTS

|   |    |  |    |
|---|----|--|----|
| <b>BASIC INSPECTION</b> .....                                       | 4  | <b>POWER RETURN SWITCH</b> .....           | 15 |
| <b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....                          | 4  | <b>LH</b> .....                            | 15 |
| WorkFlow .....  | 4  | LH : Description .....                     | 15 |
| <b>SYSTEM DESCRIPTION</b> .....                                     | 5  | LH : Component Function Check .....        | 15 |
| <b>POWER SEAT</b> .....   | 5  | LH : Diagnosis Procedure .....             | 15 |
| System Description .....  | 5  | LH : Component Inspection .....            | 16 |
| Component Parts Location .....                                      | 5  | <b>RH</b> .....                            | 16 |
| Component Description .....   | 6  | RH : Description .....                     | 16 |
| <b>HEATED SEAT</b> .....  | 7  | RH : Component Function Check .....        | 16 |
| System Description .....  | 7  | RH : Diagnosis Procedure .....             | 16 |
| Component Parts Location .....                                      | 7  | RH : Component Inspection .....            | 17 |
| Component Description .....   | 7  | <b>REAR SEATBACK SWITCH</b> .....          | 19 |
| <b>LUMBAR SUPPORT</b> .....   | 8  | <b>LH</b> .....                            | 19 |
| System Description .....  | 8  | LH : Description .....                     | 19 |
| Component Parts Location .....                                      | 8  | LH : Component Function Check .....        | 19 |
| Component Description .....   | 8  | LH : Diagnosis Procedure .....             | 19 |
| <b>REAR SEATBACK RELEASE CONTROL</b> .....                          | 9  | LH : Component Inspection .....            | 20 |
| System Description .....  | 9  | <b>RH</b> .....                            | 20 |
| Component Parts Location .....                                      | 9  | RH : Description .....                     | 20 |
| Component Description .....   | 9  | RH : Component Function Check .....        | 20 |
| <b>REAR SEATBACK POWER RETURN SYSTEM</b> .....                      | 10 | RH : Diagnosis Procedure .....             | 20 |
| System Diagram .....  | 10 | RH : Component Inspection .....            | 21 |
| System Description .....  | 10 | <b>PRIMARY POSITION LIMIT SWITCH</b> ..... | 23 |
| Component Parts Location .....                                      | 13 | <b>LH</b> .....                            | 23 |
| Component Description .....   | 13 | LH : Description .....                     | 23 |
| <b>DTC/CIRCUIT DIAGNOSIS</b> .....                                  | 14 | LH : Component Function Check .....        | 23 |
| <b>POWER SUPPLY AND GROUND CIRCUIT</b> .....                        | 14 | LH : Diagnosis Procedure .....             | 23 |
| <b>REAR SEATBACK POWER RETURN CONTROL UNIT</b> .....                | 14 | LH : Component Inspection .....            | 24 |
| REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure ..... | 14 | <b>RH</b> .....                            | 24 |
|   |    | RH : Description .....                     | 24 |
|   |    | RH : Component Function Check .....        | 24 |
|   |    | RH : Diagnosis Procedure .....             | 25 |
|   |    | RH : Component Inspection .....            | 26 |
|   |    | <b>RETURN COMPLETE LIMIT SWITCH</b> .....  | 27 |

|   |           |   |           |
|---|-----------|---|-----------|
| <b>LH</b> .....                             | <b>27</b> | Reference Value .....                         | 58        |
| LH : Description .....                      | 27        | Wiring Diagram - REAR SEATBACK POWER RE-      |           |
| LH : Component Function Check .....         | 27        | TURN SYSTEM - .....                           | 61        |
| LH : Diagnosis Procedure .....              | 27        | Fail-safe .....                               | 67        |
| LH : Component Inspection .....             | 28        |   |           |
| <b>RH</b> .....                             | <b>28</b> | <b>SYMPTOM DIAGNOSIS</b> .....                | <b>69</b> |
| RH : Description .....                      | 28        | <b>REAR SEATBACK POWER RETURN SYS-</b>        |           |
| RH : Component Function Check .....         | 28        | <b>TEM DOES NOT OPERATE</b> .....             | <b>69</b> |
| RH : Diagnosis Procedure .....              | 29        | <b>BOTH SIDES</b> .....                       | <b>69</b> |
| RH : Component Inspection .....             | 30        | BOTH SIDES : Diagnosis Procedure .....        | 69        |
| <b>MOTOR SENSOR</b> .....                   | <b>31</b> | <b>LH</b> .....                               | <b>69</b> |
| <b>LH</b> .....                             | <b>31</b> | LH : Diagnosis Procedure .....                | 69        |
| LH : Description .....                      | 31        | <b>RH</b> .....                               | <b>70</b> |
| LH : Component Function Check .....         | 31        | RH : Diagnosis Procedure .....                | 70        |
| LH : Diagnosis Procedure .....              | 31        | <b>MALFUNCTION DETECTION BUZZER</b>           |           |
| <b>RH</b> .....                             | <b>33</b> | <b>SOUNDS DURING POWER RETURN MO-</b>         |           |
| RH : Description .....                      | 33        | <b>TOR INVERSE ROTATION</b> .....             | <b>72</b> |
| RH : Component Function Check .....         | 33        | <b>LH</b> .....                               | <b>72</b> |
| RH : Diagnosis Procedure .....              | 33        | LH : Diagnosis Procedure .....                | 72        |
| <b>POWER RETURN MOTOR</b> .....             | <b>36</b> | <b>RH</b> .....                               | <b>72</b> |
| <b>LH</b> .....                             | <b>36</b> | RH : Diagnosis Procedure .....                | 72        |
| LH : Description .....                      | 36        | <b>DOES NOT RETURN BUT MALFUNCTION</b>        |           |
| LH : Component Function Check .....         | 36        | <b>DETECTION BUZZER SOUNDS</b> .....          | <b>74</b> |
| LH : Diagnosis Procedure .....              | 36        | <b>LH</b> .....                               | <b>74</b> |
| <b>RH</b> .....                             | <b>37</b> | LH : Diagnosis Procedure .....                | 74        |
| RH : Description .....                      | 37        | <b>RH</b> .....                               | <b>74</b> |
| RH : Component Function Check .....         | 37        | RH : Diagnosis Procedure .....                | 74        |
| RH : Diagnosis Procedure .....              | 37        | <b>ANTI-PINCH FUNCTION DOES NOT OPER-</b>     |           |
| <b>VEHICLE SPEED SIGNAL CIRCUIT</b> .....   | <b>39</b> | <b>ATE</b> .....                              | <b>75</b> |
| Description .....                           | 39        | Diagnosis Procedure .....                     | 75        |
| Component Function Check .....              | 39        | <b>SQUEAK AND RATTLE TROUBLE DIAG-</b>        |           |
| Diagnosis Procedure .....                   | 39        | <b>NOSES</b> .....                            | <b>76</b> |
| <b>POWER SEAT</b> .....                     | <b>41</b> | Work Flow .....                               | 76        |
| Wiring Diagram - POWER SEAT FOR DRIVER      |           | Inspection Procedure .....                    | 78        |
| SIDE (WITHOUT AUTOMATIC DRIVE POSI-         |           | Diagnostic Worksheet .....                    | 80        |
| TIONER) - .....                             | 41        | <b>PRECAUTION</b> .....                       | <b>82</b> |
| Wiring Diagram - POWER SEAT FOR PASSEN-     |           | <b>PRECAUTIONS</b> .....                      | <b>82</b> |
| GER SIDE - .....                            | 44        | Precaution for Supplemental Restraint System  |           |
| <b>HEATED SEAT</b> .....                    | <b>47</b> | (SRS) "AIR BAG" and "SEAT BELT PRE-TEN-       |           |
| Wiring Diagram - HEATED SEAT - .....        | 47        | SIONER" .....                                 | 82        |
| <b>LUMBAR SUPPORT</b> .....                 | <b>51</b> | Precaution Necessary for Steering Wheel Rota- |           |
| Wiring Diagram - LUMBAR SUPPORT SYSTEM - .. | 51        | tion after Battery Disconnect .....           | 82        |
| <b>REAR SEATBACK RELEASE CONTROL</b> .....  | <b>54</b> | Service Notice .....                          | 83        |
| Wiring Diagram - REAR SEATBACK RELEASE      |           | Precaution for Work .....                     | 83        |
| CONTROL - .....                             | 54        | <b>PREPARATION</b> .....                      | <b>84</b> |
| <b>ECU DIAGNOSIS INFORMATION</b> .....      | <b>58</b> | <b>PREPARATION</b> .....                      | <b>84</b> |
| <b>REAR SEAT BACK POWER RETURN CON-</b>     |           | Special Service Tool .....                    | 84        |
| <b>TROL UNIT</b> .....                      | <b>58</b> |   |           |

|   |            |   |            |   |
|---|------------|---|------------|---|
| Commercial Service Tool .....           | 84         | Exploded View .....                       | 105        |   |
| <b>CLIP LIST .....</b>                  | <b>85</b>  | Removal and Installation .....            | 105        | A |
| Clip List .....                         | 85         | <b>LUMBAR SUPPORT SWITCH .....</b>        | <b>106</b> |   |
| <b>REMOVAL AND INSTALLATION .....</b>   | <b>86</b>  | Exploded View .....                       | 106        | B |
| <b>FRONT SEAT .....</b>                 | <b>86</b>  | Removal and Installation .....            | 106        |   |
| Exploded View .....                     | 86         | <b>HEATED SEAT SWITCH .....</b>           | <b>107</b> |   |
| Removal and Installation .....          | 89         | Exploded View .....                       | 107        | C |
| Disassembly and Assembly .....          | 90         | Removal and Installation .....            | 107        |   |
| <b>REAR SEAT .....</b>                  | <b>97</b>  | <b>POWER RETURN SWITCH .....</b>          | <b>108</b> |   |
| Exploded View .....                     | 97         | Exploded View .....                       | 108        | D |
| Removal and Installation .....          | 98         | Removal and Installation .....            | 108        |   |
| Disassembly and Assembly .....          | 100        | <b>REAR SEATBACK SWITCH .....</b>         | <b>109</b> | E |
| <b>REAR SEAT BACK POWER RETURN CON-</b> |            | Exploded View .....                       | 109        |   |
| <b>TROL UNIT .....</b>                  | <b>104</b> | Removal and Installation .....            | 109        |   |
| Exploded View .....                     | 104        | <b>REAR SEATBACK RELEASE SWITCH .....</b> | <b>110</b> | F |
| Removal and Installation .....          | 104        | Exploded View .....                       | 110        |   |
| <b>POWER SEAT SWITCH .....</b>          | <b>105</b> | Removal and Installation .....            | 110        | G |

**SE**

K  
L  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

WorkFlow

INFOID:000000004347345

DETAILED FLOW

#### 1.OBTAIN INFORMATION ABOUT SYMPTOM

---

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

#### 2.REPRODUCE THE MALFUNCTION INFORMATION

---

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

#### 3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

---

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

#### 4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

---

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

#### 5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

---

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

#### 6.FINAL CHECK

---

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 3.

# POWER SEAT

< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### POWER SEAT

#### System Description

INFOID:000000004347346

BCM can operate regardless of the ignition switch position, because battery power is supplied at all times to power seat switch.

#### SLIDING OPERATION

While operating the sliding switch located in power seat switch, sliding motor operates and makes possible the seat front and back position adjustment.

#### RECLINING OPERATION


While operating the reclining switch located in power seat switch, reclining motor operates and makes possible the seat back forward and backward position adjustment.

#### LIFTING OPERATION

While operating the lifting switch located in power seat switch, lifting motor operates and makes possible the seat cushion up and down position adjustment.

#### Component Parts Location

INFOID:000000004347347



1. Sliding switch and lifting switch (driver side) B414
  2. Reclining switch (driver side) B414
  3. Reclining motor (driver side) B415
  4. Lifting motor (rear) (driver side) B418
  5. Lifting motor (front) (driver side) B417
  6. Sliding motor (driver side) B416
- A. View with seat cushion pad and seat back pad are removed. B. Backside of seat cushion

# POWER SEAT

< SYSTEM DESCRIPTION >

## Component Description

INFOID:000000004347348

| Item                       | Function  |
|----------------------------|---|
| BCM                        | Supplies at all times the power received from battery to power seat switch                              |
| Power seat switch          | Built-in reclining switch, sliding switch and lifting switch, controls the power supplied to each motor |
| Reclining motor            | With the power supplied from power seat switch, operates forward and backward movement of seatback      |
| Sliding motor              | With the power supplied from power seat switch, operates forward and backward slide of seat             |
| Lifting motor (front/rear) | With the power supplied from power seat switch, operates up and down movement of seat cushion           |

# HEATED SEAT

< SYSTEM DESCRIPTION >

## HEATED SEAT

### System Description

INFOID:000000004347349


Heated seat is a system that operates when ignition switch is in ON position.

### HEATER OPERATION

- While operating the heated seat switch, seat cushion heater and seat back heater operate.
- Temperature of seat can be adjusted by operating on heated seat switch.

### Component Parts Location

INFOID:000000004347350



- |   |  |  |
|---|--|--|
| 1. Heated seat switch (driver side)<br>M172                           | 2. Heated seat switch (passenger side)<br>M173 | 3. Seat back heater<br>• Driver side B412<br>• Passenger side B432 |
| 4. Seat cushion heater<br>• Driver side B412<br>• Passenger side B432 | 5. Heated seat relay M70                       |  |
| A. Behind cluster lid C   |  |  |

### Component Description

INFOID:000000004347351

| Item                | Function  |
|---------------------|---|
| Heated seat switch  | <ul style="list-style-type: none"> <li>• Power is supplied to each heater</li> <li>• Depending on LOW/HIGH position of switch, operating heater number is changeable</li> </ul> |
| Seat cushion heater | Built-in seat cushion, heater operate with the power supplied from heater seat switch   |
| Seat back heater    | Built-in seatback, heater operate with the power supplied from heater seat switch   |

# LUMBAR SUPPORT

< SYSTEM DESCRIPTION >

## LUMBAR SUPPORT


### System Description

INFOID:000000004347352

- Lumbar support can operate regardless of the ignition switch position because battery power is supplied to it at all times.
- While operating the lumbar support switch, lumbar support motor operates which allows forward and backward operation of seatback support.

### Component Parts Location

INFOID:000000004347353



1. Lumbar support switch B457      2. Lumbar support motor B458

A. View with seat back pad is removed

### Component Description

INFOID:000000004347354

| Item                  | Function  |
|-----------------------|---|
| Lumbar support switch | Controls the power supplied to lumbar support motor   |
| Lumbar support motor  | With the power supplied from lumbar support switch, operates forward and backward movement of seatback support device |



# REAR SEATBACK RELEASE CONTROL

< SYSTEM DESCRIPTION >

## REAR SEATBACK RELEASE CONTROL


### System Description

INFOID:000000004347355

- Rear seatback release control is composed of rear seatback release switch and rear seatback release actuator
- When rear seatback release switch is pressed, the rear seatback release actuator operate in order to unlock the rear seatback lock
- When the rear seatback is unlocked, the spring located inside the rear seat device rebound, and the rear seatback return to the fall down position

### Component Parts Location

INFOID:000000004347356



- |   |  |   |
|---|--|---|
| 1. Rear seatback release switch (LH)<br>B49 | 2. Rear seatback release actuator (RH)<br>B506 | 3. Rear seatback release relay (LH)<br>B246 |
| 4. Rear seatback release relay (RH)<br>B247 |  |   |
| A. In seatback                              | B. Behind of rear seat (RH)                    |   |

### Component Description

INFOID:000000004347357

| Item                           | Function  |
|--------------------------------|---|
| Rear seatback release switch   | Release the rear seatback when it is locked   |
| Rear seatback release actuator | Pressed the rear seatback release switch to release the rear seatback when it is locked |


# REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

## REAR SEATBACK POWER RETURN SYSTEM

### System Diagram

INFOID:000000004347358



JMJIA1539GB

### System Description

INFOID:000000004347359

#### DESCRIPTION

##### Rear Seatback Release Control

- Rear seatback release control is composed of rear seatback release switch and rear seatback release actuator
- When rear seatback switch is pressed in release direction, the rear seatback release actuator operate in order to unlock the rear seatback lock
- When the rear seatback is unlocked, the spring located inside the rear seat device rebound, and the rear seatback return to the fall down position.

##### Rear Seatback Power Return System

- The rear seat back power return system is the system that enables the return operation of the left and right rear seatbacks independently by pressing and holding the power return switch or the rear seatback switch in the UP direction.
- As for the safety mechanism, the reverse operation is performed if the switch is released during the return operation. The anti-pitch function is installed so that the automatic reverse operation is performed if the pinching of foreign materials between the left and right rear seatbacks is detected.

#### OPERATION DESCRIPTION

The rear seatback power return system consists of the sector gear that transmits the movement information of rear seatback power return control unit, power return switch, power return motor, motor sensor, primary position limit switch, return complete limit switch and power return motor.

##### Return Operation Starting Condition

The rear seat back return operation starts when all of the following conditions are satisfied.

- Vehicle speed 2 km/h (1 MPH) or less
- Return complete limit switch: ON
- The battery voltage is normal

| Operation sequence | Rear seatback condition    | Sector gear condition          | Primary position limit switch | Return complete limit switch |
|--------------------|----------------------------|--------------------------------|-------------------------------|------------------------------|
| 1                  | Return completion position | Initial position               | OFF                           | OFF                          |
| 2                  | Fold-down position         | Initial position               | OFF                           | ON                           |
| 3                  | Active                     | Return non-completion position | OFF → ON                      | ON                           |

# REAR SEATBACK POWER RETURN SYSTEM

## < SYSTEM DESCRIPTION >

| Operation sequence | Rear seatback condition    | Sector gear condition      | Primary position limit switch | Return complete limit switch |
|--------------------|----------------------------|----------------------------|-------------------------------|------------------------------|
| 4                  | Return completion position | Return completion position | ON                            | OFF                          |
| 5                  |                            | Initial position           | OFF                           | OFF                          |

- In the condition that the rear seatback is raised (return completion position), the sector gear is in the initial position and the primary position limit switch and return complete limit switch are OFF.
- When the rear seatback to the fold-down position, the return complete limit switch turns ON, and the rear seatback power return control unit judges that the rear seatback is tilted (return non-completion position).
- When pressing and holding the power return switch or the rear seatback switch in the UP direction, the rear seatback power return control unit detects the power return ON signal and supplies the power to the power return motor. Then, the rear seatback power return control unit sounds the operation start buzzer.
- With the power supplied from the rear seat back power control unit, the power return motor rotates in the return direction. The rear seatback starts the return operation via the sector gear.
- When the sector gear starts rotating in the return direction, the primary position limit switch turns ON. The rear seatback power return control unit judges that the sector gear is in any position other than the initial position.
- When the rear seatback moves to the return position, the return complete limit switch turns OFF. The rear seatback power return control unit activates the return completion buzzer and stops the power return motor. Then, the rear seatback power return control unit reverses the power return motor after 0.2 seconds so that the sector gear returns to the initial position.
- When the sector gear returns to the initial position by reverse rotation of the power return motor, the primary position limit switch turns OFF. The rear seatback power return control unit stops the reverse operation of the power return motor. The return operation is completed.
- When releasing the switch during the return operation (both the primary position limit switch and return complete limit switch are ON), the rear seatback power return control unit detects the power switch OFF signal and returns the rear seatback to the fold-down position by the reverse rotation of the power return motor. When pushing the switch again during the reverse operation, the return operation restarts.

### NOTE:

Disconnect the battery with the sector gear in any position other than the initial position (primary position limit switch: ON). The sector gear is returned to the initial position when the battery is connected again.

### ANTI-PINCH OPERATION

When the pinch between RH/LH rear seatbacks is detected during the return operation, the malfunction detecting buzzer sounds and the rear seatback returns to the fold-down position.

- If there is a pinching of foreign materials between the left and right rear seatbacks during the return operation (both the primary position limit switch and return complete switch are ON), the voltage pulse of motor sensor changes.
- When inputting the pinching signal from the motor sensor, the rear seatback power return control unit sounds the malfunction detecting buzzer and stops the power return motor. Then, the rear seatback power return control unit reverses the power return motor after 0.2 second so that the rear seatback returns to the fold-down position.

### SECTOR GEAR REVERSE STARTING CONDITION

If any of the following conditions are satisfied, the sector gear may be reversed.

- Rear seatback return is completed (return complete limit switch: OFF)
- Release the power return switch before completing the return
- Pinch detection
- Lock detection of power return motor (Lock at normal rotation)
- The rear seatback return is not completed within 60 seconds
- Detect the battery voltage malfunction during the return operation
- Return to the normal condition after detecting the battery voltage malfunction during the return operation
- The primary position limit switch does not turn OFF → ON within the specified motor pulse number from starting the return operation.

### SECTOR GEAR REVERSE STOP CONDITION

If any of the following conditions are satisfied, the reverse operation stops.

- Sector gear initial position (primary position limit switch: OFF)
- Lock detection of power return motor (Lock during reverse operation)
- The sector gear initial position is not completed within 60 seconds

# REAR SEATBACK POWER RETURN SYSTEM

## < SYSTEM DESCRIPTION >

### NOTE:

The battery voltage indicates the voltage between battery voltage (system) terminal 17 and GND (system) terminal 32 of rear seatback power return control unit. It is normal when the voltage is  $7.5 \pm 10\%$  or more. If it is less than the specified value, there is a malfunction.

### POWER CONSUMPTION CONTROL SYSTEM

Rear seatback power return control unit incorporates a power consumption control function that reduces the power consumption according to the vehicle status.

#### Low Power Consumption Mode

If all of the following conditions are satisfied for 30 seconds period of time, the system shifts to the low power consumption mode.

- Power return switch or rear seatback switch is OFF
- Power return motor does not operate
- Vehicle speed 2 km/h (1 MPH) or less

If any of the following conditions are satisfied, the low power consumption mode is released.

- When the power return switch or rear seatback switch is pressed
- When the change occurs to the pulse of vehicle speed sensor

There are the following functions as the low power consumption mode.

- Turn the power supply of primary position limit switch and return complete limit switch to OFF
- Turn the power supply of the motor sensor to OFF when the power return motor is not operated

### BUZZER OPERATION PATTERN AND ORDER OF PRIORITY


| Operation type             | Sound pattern                                   | Priority |
|----------------------------|---|----------|
| Malfunction                | <p style="text-align: center;">JM/JIA1396ZZ</p> | 1        |
| Return operation completed | <p style="text-align: center;">JM/JIA1395ZZ</p> | 2        |
| Start return operation     | <p style="text-align: center;">JM/JIA1394ZZ</p> | 3        |

# REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000004347360



- |   |  |  |
|---|--|--|
| 1. Rear seatback power return control unit B226, B227 | 2. Rear seatback release relay (LH) B246     | 3. Rear seatback release relay (RH) B247 |
| 4. Power return switch (LH) M174                      | 5. Power return switch (RH) M175             | 6. Rear seatback switch (LH) B52         |
| 7. Primary position limit switch (RH) B505            | 8. Sector gear (RH)                          | 9. Power return motor assembly (RH) B504 |
| 10. Return complete limit switch (LH) B513            | 11. Rear seatback release actuator (LH) B513 | 12. Unified meter and A/C amp. M66, M67  |
| A. Behind of rear seat (RH)                           | B. In seat device                            | C. View with seatback pad is removed     |
| D. Behind cluster lid C                               |  |  |

## Component Description

INFOID:000000004347361

| Item                                    | Function  |
|---|---|
| Rear seatback power return control unit | Control the rear seatback power return system   |
| Power return motor                      | Operate the rear seatback   |
| Motor sensor                            | Detect the operation of power return motor  |
| Power return switch                     | Switch that performs the return operation   |
| Rear seatback switch                    | Performs the return operation or release the rear seatback when it is locked            |
| Rear seatback release actuator          | Pressed the rear seatback release switch to release the rear seatback when it is locked |
| Primary position limit switch           | Detect the initial position of sector gear  |
| Return complete limit switch            | Detect the return position of rear seatback   |
| Unified meter and A/C amp.              | Transmit the vehicle speed signal   |
| Sector gear                             | Transmit the operation of power return motor to rear seatback                           |

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### REAR SEATBACK POWER RETURN CONTROL UNIT

#### REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure

INFOID:000000004347362

### 1. CHECK FUSE

Check that the following fuses are not fusing.

| Terminal No. | Signal name          | Fuse No. |
|--------------|----------------------|----------|
| 16           | Battery power supply | 32 (30A) |
| 17           |                      | 6 (10A)  |

Is the fuse fusing?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seatback power return control unit connector.
3. Check voltage between rear seatback power return control unit harness connector and ground.

| (+)       |          | (-)    | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal |        |                   |
| B226      | 17       | Ground | Battery voltage   |
| B227      | 16       |        |                   |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CHECK GROUND CIRCUIT

Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                               | Terminal |        |            |
| B226                                    | 32       |        | Existed    |
| B227                                    | 13       |        |            |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

# POWER RETURN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## POWER RETURN SWITCH

LH

### LH : Description

INFOID:000000004347363

Switch that performs the return operation.

### LH : Component Function Check

INFOID:000000004347364

### 1.CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH).

Is the inspection result normal?

- YES >> Power return switch (LH) is OK.  
 NO >> Refer to [SE-15, "LH : Diagnosis Procedure"](#).

### LH : Diagnosis Procedure

INFOID:000000004347365

### 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power return switch (LH) connector.
3. Check voltage between power return switch (LH) harness connector and ground.

| (+)                      |          | (-)    | Voltage (V)<br>(Approx.) |
|--------------------------|----------|--------|--------------------------|
| Power return switch (LH) |          |        |                          |
| Connector                | Terminal | Ground | 5                        |
| B174                     | 1        |        |                          |

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

### 2.CHECK FRONT POWER RETURN SWITCH (LH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return switch (LH) harness connector.

| Rear seatback power return control unit |          | Power return switch (LH) |          | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector                               | Terminal | Connector                | Terminal |            |
| B226                                    | 28       | M174                     | 1        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| M226                                    | 28       |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 3.CHECK POWER RETURN SWITCH (LH) GROUND CIRCUIT

Check continuity power return switch (LH) harness connector and ground.

| Power return switch (LH) |          | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector                | Terminal |        |            |
| M174                     | 2        |        | Existed    |

# POWER RETURN SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

### 4.CHECK POWER RETURN SWITCH (LH)

Check power return switch (LH).  
Refer to [SE-16, "LH : Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace power return switch (LH). Refer to [SE-108, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## LH : Component Inspection

INFOID:000000004347366

### 1.CHECK FRONT POWER RETURN SWITCH (LH)

1. Turn ignition OFF.
2. Disconnect power return switch (LH) connector.
3. Check power return switch (LH) terminals.

| Power return switch (LH) connector | Terminal |   | Condition                            | Continuity  |
|------------------------------------|----------|---|--------------------------------------|-------------|
| M174                               | 1        | 2 | Power return switch (LH) is pressed  | Existed     |
|                                    |          |   | Power return switch (LH) is released | Not existed |

### Is the inspection result normal?

- YES >> Power return switch (LH) is OK.  
NO >> Replace power return switch (LH). Refer to [SE-108, "Removal and Installation"](#).

## RH

### RH : Description

INFOID:000000004347367

Switch that performs the return operation.

### RH : Component Function Check

INFOID:000000004347368

### 1.CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH).

### Is the inspection result normal?

- YES >> Power return switch (RH) is OK.  
NO >> Refer to [SE-16, "RH : Diagnosis Procedure"](#).

### RH : Diagnosis Procedure

INFOID:000000004347369

### 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power return switch (RH) connector.
3. Check voltage between power return switch (RH) harness connector and ground.

| (+)       |          | (-)    | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--------------------------|
| Connector | Terminal |        |                          |
| M175      | 1        | Ground | 5                        |

### Is the inspection result normal?



# POWER RETURN SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> GO TO 2.

### 2.CHECK POWER RETURN SWITCH (RH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return switch (RH) harness connector.

| Rear seatback power return control unit |          | Power return switch (RH) |          | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector                               | Terminal | Connector                | Terminal |            |
| B226                                    | 20       | M175                     | 1        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 20       |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
NO >> Repair or replace harness.

### 3.CHECK POWER RETURN SWITCH (RH) GROUND CIRCUIT

Check continuity power return switch (RH) harness connector and ground.

| Power return switch (RH) |          | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector                | Terminal |        |            |
| M175                     | 2        |        | Existed    |

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

### 4.CHECK POWER RETURN SWITCH (RH)

Check power return switch (RH).  
Refer to [SE-17, "RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace power return switch (RH). Refer to [SE-108, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## RH : Component Inspection

INFOID:000000004347370

### 1.CHECK POWER RETURN SWITCH (RH)

1. Turn ignition OFF.
2. Disconnect power return switch (RH) connector.
3. Check power return switch (RH) terminals.

| Power return switch (RH) connector | Terminal |   | Condition                            | Continuity  |
|------------------------------------|----------|---|--------------------------------------|-------------|
|                                    | 1        | 2 |                                      |             |
| M175                               | 1        | 2 | Power return switch (RH) is pressed  | Existed     |
|                                    |          |   | Power return switch (RH) is released | Not existed |

Is the inspection result normal?

- YES >> Power return switch (RH) is OK.

## POWER RETURN SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

---

NO >> Replace power return switch (RH). Refer to [SE-108. "Removal and Installation"](#).

# REAR SEATBACK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## REAR SEATBACK SWITCH

LH

### LH : Description

INFOID:000000004347371

Switch that performs the return operation or release operation.

### LH : Component Function Check

INFOID:000000004347372

### 1.CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the rear seatback switch (LH) in UP direction.

Is the inspection result normal?

- YES >> Rear seatback switch (LH) is OK.  
NO >> Refer to [SE-19, "LH : Diagnosis Procedure"](#).

### LH : Diagnosis Procedure

INFOID:000000004347373

### 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (LH) connector.
3. Check voltage between rear seatback switch (LH) harness connector and ground.

| (+)                       |          | (-)    | Voltage (V)<br>(Approx.) |
|---------------------------|----------|--------|--------------------------|
| Rear seatback switch (LH) |          |        |                          |
| Connector                 | Terminal | Ground | 5                        |
| B52                       | 2        |        |                          |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

### 2.CHECK REAR SEAT BACK SWITCH (LH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback switch (LH) harness connector.

| Rear seatback power return control unit |          | Rear seatback switch (LH) |          | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector                               | Terminal | Connector                 | Terminal |            |
| B226                                    | 28       | B52                       | 2        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 28       |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
NO >> Repair or replace harness.

### 3.CHECK REAR SEATBACK SWITCH (LH) GROUND CIRCUIT

Check continuity rear seatback switch (LH) harness connector and ground.

| Rear seatback switch (LH) |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| B52                       | 3        |        | Existed    |

# REAR SEATBACK SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

### 4.CHECK REAR SEATBACK SWITCH (LH)

Check rear seatback switch (LH).  
Refer to [SE-20, "LH : Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace rear seatback switch (LH). Refer to [SE-110, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## LH : Component Inspection

INFOID:000000004347374

### 1.CHECK REAR SEATBACK SWITCH (LH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (LH) connector.
3. Check rear seatback switch (LH) terminals.

| Rear seatback switch (LH) connector | Terminal |   | Condition   | Continuity  |
|-------------------------------------|----------|---|---|-------------|
| B52                                 | 2        | 3 | Rear seatback switch (LH) is pressed in UP direction  | Existed     |
|                                     |          |   | Rear seatback switch (LH) is released in UP direction | Not existed |

### Is the inspection result normal?

- YES >> Rear seatback switch (LH) is OK.
- NO >> Replace seatback return switch (LH). Refer to [SE-110, "Removal and Installation"](#).

## RH

### RH : Description

INFOID:000000004347375

Switch that performs the return operation or release operation.

### RH : Component Function Check

INFOID:000000004347376

### 1.CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the rear seatback switch (RH) in UP direction.

### Is the inspection result normal?

- YES >> Rear seatback switch (RH) is OK.
- NO >> Refer to [SE-20, "RH : Diagnosis Procedure"](#).

### RH : Diagnosis Procedure

INFOID:000000004347377

### 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (RH) connector.
3. Check voltage between rear seatback switch (RH) harness connector and ground.

# REAR SEATBACK SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

| (+)                       |          | (-)    | Voltage (V)<br>(Approx.) |
|---------------------------|----------|--------|--------------------------|
| Rear seatback switch (RH) |          |        |                          |
| Connector                 | Terminal | Ground | 5                        |
| B239                      | 2        |        |                          |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

## 2. CHECK REAR SEATBACK SWITCH (RH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback switch (RH) harness connector.

| Rear seatback power return control unit |          | Rear seatback switch (RH) |          | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector                               | Terminal | Connector                 | Terminal |            |
| B226                                    | 20       | B239                      | 2        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 20       |        | Not existed |

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-104. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 3. CHECK REAR SEATBACK SWITCH (RH) GROUND CIRCUIT

Check continuity rear seatback switch (RH) harness connector and ground.

| Rear seatback switch (RH) |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| B239                      | 3        |        | Existed    |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK REAR SEATBACK SWITCH (RH)

Check rear seatback switch (RH).

Refer to [SE-21. "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace rear seatback switch (RH). Refer to [SE-109. "Removal and Installation"](#).

## 5. CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

>> INSPECTION END

## RH : Component Inspection

INFOID:000000004347378

## 1. CHECK REAR SEATBACK SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (RH) connector.
3. Check rear seatback switch (RH) terminals.

## REAR SEATBACK SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

| Rear seatback switch (RH) connector | Terminal |   | Condition   | Continuity  |
|-------------------------------------|----------|---|---|-------------|
| B239                                | 2        | 3 | Rear seatback switch (RH) is pressed in UP direction  | Existed     |
|                                     |          |   | Rear seatback switch (RH) is released in UP direction | Not existed |

#### Is the inspection result normal?

YES >> Rear seatback switch (RH) is OK.

NO >> Replace rear seatback switch (RH). Refer to [SE-109. "Removal and Installation"](#).

# PRIMARY POSITION LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## PRIMARY POSITION LIMIT SWITCH

LH

### LH : Description

INFOID:000000004347379

Detect the initial position of sector gear (LH).

### LH : Component Function Check

INFOID:000000004347380

## 1.CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

- YES >> Primary position limit switch (LH) is OK.  
NO >> Refer to [SE-23, "LH : Diagnosis Procedure"](#).

### LH : Diagnosis Procedure

INFOID:000000004347381

## 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect primary position limit switch (LH) connector.
3. Check voltage between primary position limit switch (LH) connector and ground.

| (+)                                |          | (-)    | Voltage (V)<br>(Approx.) |
|------------------------------------|----------|--------|--------------------------|
| Primary position limit switch (LH) |          |        |                          |
| Connector                          | Terminal |        |                          |
| B512                               | 6        | Ground | Battery voltage          |

### NOTE:

It is not low power consumption mode.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

## 2.CHECK PRIMARY POSITION LIMIT SWITCH (LH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (LH) harness connector.

| Rear seatback power return control unit |          | Primary position limit switch (LH) |          | Continuity |
|---|----------|------------------------------------|----------|------------|
| Connector                               | Terminal | Connector                          | Terminal |            |
| B226                                    | 21       | B512                               | 6        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 21       |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
NO >> Repair or replace harness.

## 3.CHECK PRIMARY POSITION LIMIT SWITCH (LH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (LH) harness connector.

# PRIMARY POSITION LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

| Rear seatback power return control unit |          | Primary position limit switch (LH) |          | Continuity |
|---|----------|------------------------------------|----------|------------|
| Connector                               | Terminal | Connector                          | Terminal |            |
| B226                                    | 31       | B512                               | 9        | Existed    |

- Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 31       |        | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

### 4.CHECK PRIMARY POSITION LIMIT SWITCH (LH)

Check primary position limit switch (LH).  
Refer to [SE-24, "LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace primary position limit switch (LH) [seat device assembly (LH)]. Refer to [SE-97, "Exploded View"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## LH : Component Inspection

INFOID:000000004347382

### COMPONENT INSPECTION

#### 1.CHECK PRIMARY POSITION LIMIT SWITCH (LH)

- Turn ignition switch OFF.
- Disconnect primary position limit switch (LH) connector.
- Check primary position limit switch (LH) terminals.

| Primary position limit switch (LH) connector | Terminal |   | Condition                                      | Continuity  |
|--|----------|---|--|-------------|
|  | 6        | 9 |  |             |
| B512   |          |   | Primary position limit switch (LH) is pressed  | Existed     |
|  |          |   | Primary position limit switch (LH) is released | Not existed |

Is the inspection result normal?

- YES >> Primary position limit switch (LH) is OK.
- NO >> Replace primary position limit switch (LH) [seat device assembly (LH)]. Refer to [SE-97, "Exploded View"](#).

## RH

### RH : Description

INFOID:000000004347383

Detect the initial position of sector gear (RH).

### RH : Component Function Check

INFOID:000000004347384

#### 1.CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

- YES >> Primary position limit switch (RH) is OK.



# PRIMARY POSITION LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [SE-25. "RH : Diagnosis Procedure"](#).

### RH : Diagnosis Procedure

INFOID:000000004347385

#### 1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Connect primary position limit switch (RH) connector.
3. Check voltage between primary position limit switch (RH) harness connector and ground.

| (+)                                |          | (-)    | Voltage (V)<br>(Approx.) |
|------------------------------------|----------|--------|--------------------------|
| Primary position limit switch (RH) |          |        |                          |
| Connector                          | Terminal |        |                          |
| B505                               | 15       | Ground | Battery voltage          |

#### NOTE:

It is not low power consumption mode.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK PRIMARY POSITION LIMIT SWITCH (RH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (RH) harness connector.

| Rear seatback power return control unit |          | Primary position limit switch (RH) |          | Continuity |
|---|----------|------------------------------------|----------|------------|
| Connector                               | Terminal | Connector                          | Terminal |            |
| B226                                    | 22       | B505                               | 15       | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 22       |        | Not existed |

#### Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104. "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3. CHECK PRIMARY POSITION LIMIT SWITCH (RH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (RH) harness connector.

| Rear seatback power return control unit |          | Primary position limit switch (RH) |          | Continuity |
|---|----------|------------------------------------|----------|------------|
| Connector                               | Terminal | Connector                          | Terminal |            |
| B226                                    | 23       | B505                               | 14       | Existed    |

2. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 23       |        | Not existed |

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

#### 4. CHECK PRIMARY POSITION LIMIT SWITCH (RH)

# PRIMARY POSITION LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Check primary position limit switch (RH).  
Refer to [SE-26, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace primary position limit switch (RH) [seat device assembly (RH)]. Refer to [SE-97, "Exploded View"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## RH : Component Inspection

INFOID:000000004347386

### COMPONENT INSPECTION

#### 1.CHECK PRIMARY POSITION LIMIT SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect primary position limit switch (RH) connector.
3. Check primary position limit switch (RH) terminals.

| Primary position limit switch (RH) connector | Terminal |    | Condition                                      | Continuity  |
|--|----------|----|--|-------------|
| B505   | 14       | 15 | Primary position limit switch (RH) is pressed  | Existed     |
|  |          |    | Primary position limit switch (RH) is released | Not existed |

Is the inspection result normal?

YES >> Primary position limit switch (RH) is OK.

NO >> Replace primary position limit switch (RH) [seat device assembly (RH)]. Refer to [SE-97, "Exploded View"](#).

# RETURN COMPLETE LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## RETURN COMPLETE LIMIT SWITCH

LH

### LH : Description

INFOID:000000004347387

Detect the return completion position of rear seatback (LH).

### LH : Component Function Check

INFOID:000000004347388

## 1.CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

- YES >> Return complete limit switch (LH) is OK.  
NO >> Refer to [SE-27, "LH : Diagnosis Procedure"](#).

### LH : Diagnosis Procedure

INFOID:000000004347389

## 1.CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (LH) connector.
3. Check voltage between rear seatback lock assembly (LH) harness connector and ground.

| (+)       |          | (-)    | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--------------------------|
| Connector | Terminal |        |                          |
| B513      | 8        | Ground | Battery voltage          |

### NOTE:

It is not low power consumption mode.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

## 2.CHECK RETURN COMPLETE LIMIT SWITCH (LH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (LH) harness connector.

| Rear seatback power return control unit |          | Rear seatback lock assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B226                                    | 29       | B513                             | 8        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 29       |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
NO >> Repair or replace harness.

## 3.CHECK RETURN COMPLETE LIMIT SWITCH (LH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (LH) harness connector.

# RETURN COMPLETE LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

| Rear seatback power return control unit |          | Rear seatback lock assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B226                                    | 31       | B513                             | 9        | Existed    |

- Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 31       |        | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4.CHECK RETURN COMPLETE LIMIT SWITCH (LH)

Check return complete limit switch (LH).

Refer to [SE-28, "LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Replace return complete limit switch (LH) [rear seatback lock assembly (LH)]. Refer to [SE-97, "Exploded View"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## LH : Component Inspection

INFOID:000000004347390

### COMPONENT INSPECTION

#### 1.CHECK RETURN COMPLETE LIMIT SWITCH (LH)

- Turn ignition switch OFF.
- Disconnect rear seatback lock assembly (LH) connector.
- Check rear seatback lock assembly (LH) terminals.

| Rear seatback lock assembly (LH) connector | Terminal |   | Condition                                     | Continuity  |
|--|----------|---|---|-------------|
|  | 8        | 9 |   |             |
| B513                                       | 8        | 9 | Return complete limit switch (LH) is pressed  | Existed     |
|  |          |   | Return complete limit switch (LH) is released | Not existed |

Is the inspection result normal?

- YES >> Return complete limit switch (LH) is OK.  
 NO >> Replace return complete limit switch (LH) [rear seatback lock assembly (LH)]. Refer to [SE-97, "Exploded View"](#).

## RH

### RH : Description

INFOID:000000004347391

Detect the return completion position of rear seatback (RH).

### RH : Component Function Check

INFOID:000000004347392

#### 1.CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

- YES >> Return complete limit switch (RH) is OK.

# RETURN COMPLETE LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [SE-29. "RH : Diagnosis Procedure"](#).

### RH : Diagnosis Procedure

INFOID:000000004347393

#### 1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (RH) connector.
3. Check voltage between rear seatback lock assembly (RH) harness connector and ground.

| (+)                              |          | (-)    | Voltage (V)<br>(Approx.) |
|----------------------------------|----------|--------|--------------------------|
| Rear seatback lock assembly (RH) |          |        |                          |
| Connector                        | Terminal |        |                          |
| B506                             | 13       | Ground | Battery voltage          |

#### NOTE:

It is not low power consumption mode.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK RETURN COMPLETE LIMIT SWITCH (RH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (RH) harness connector.

| Rear seatback power return control unit |          | Rear seatback lock assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B226                                    | 30       | B506                             | 13       | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 30       |        | Not existed |

#### Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104. "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3. CHECK RETURN COMPLETE LIMIT SWITCH (RH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (RH) harness connector.

| Rear seatback power return control unit |          | Rear seatback lock assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B226                                    | 23       | B506                             | 14       | Existed    |

2. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 23       |        | Not existed |

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

#### 4. CHECK RETURN COMPLETE LIMIT SWITCH (RH)

# RETURN COMPLETE LIMIT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Check return complete limit switch (RH).  
Refer to [SE-30, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace return complete limit switch (RH) [rear seatback lock assembly (RH)]. Refer to [SE-97, "Exploded View"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

## RH : Component Inspection

INFOID:000000004347394

### COMPONENT INSPECTION

#### 1.CHECK RETURN COMPLETE LIMIT SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (RH) connector.
3. Check rear seatback lock assembly (RH) terminals.

| Rear seatback lock assembly (RH) connector | Terminal |    | Condition                                     | Continuity  |
|--|----------|----|---|-------------|
| B506                                       | 13       | 14 | Return complete limit switch (RH) is pressed  | Existed     |
|  |          |    | Return complete limit switch (RH) is released | Not existed |

Is the inspection result normal?

YES >> Return complete limit switch (RH) is OK.

NO >> Replace return complete limit switch (RH) [rear seatback lock assembly (RH)]. Refer to [SE-97, "Exploded View"](#).

# MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## MOTOR SENSOR

LH

### LH : Description

INFOID:000000004347395

Detect the operation condition of power return motor (LH).

### LH : Component Function Check

INFOID:000000004347396

## 1.CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?


- YES >> Motor sensor (LH) is OK.  
 NO >> Refer to [SE-31, "LH : Diagnosis Procedure"](#).

### LH : Diagnosis Procedure

INFOID:000000004347397

## 1.CHECK MOTOR SENSOR (LH) OUTPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between rear seatback power return control unit harness connector and ground.

| (+)       |          | (-)    | Condition                                    | Voltage (V)<br>(Approx.)  |
|-----------|----------|--------|--|---|
| Connector | Terminal |        |  |   |
| B227      | 10       | Ground | During the power return motor (LH) operation |  |
|           |          |        | When pinching between LH/RH seats occurs     | The above pulse width should be expanded  |

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> GO TO 2.

## 2.CHECK MOTOR SENSOR (LH) SIGNAL CIRCUIT

- Disconnect power return motor assembly (LH) connector and rear seatback power return control unit connector.
- Check continuity between power return motor assembly (LH) harness connector and rear seatback power return control unit harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 10       | B511                             | 4        | Existed    |

- Check continuity between power return motor assembly (LH) harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 10       |        | Not existed |

Is the inspection result normal?

# MOTOR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

### 3. CHECK MOTOR SENSOR (LH) POWER SUPPLY

1. Connect rear seatback power return control unit connector.
2. Check voltage between power return motor assembly (LH) harness connector and ground.

| (+)                              |          | (-)    | Condition                                | Voltage (V)<br>(Approx.) |
|----------------------------------|----------|--------|--|--------------------------|
| Power return motor assembly (LH) |          |        |  |                          |
| Connector                        | Terminal |        |  |                          |
| B511                             | 3        | Ground | When the power return switch is operated | Battery voltage          |

#### Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> GO TO 4.

### 4. CHECK MOTOR SENSOR (LH) POWER SUPPLY CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (LH) harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 11       | B511                             | 3        | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 11       |        | Not existed |

#### Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 5. CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 1

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between power return motor assembly harness connector and ground.

| Rear seatback power return control unit |          | Power return motor assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 9        | B511                             | 5        | Existed    |

#### Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness.

### 6. CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 2

1. Connect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                               | Terminal |        |            |
| B227                                    | 9        |        | Existed    |

#### Is the inspection result normal?

- YES >> Replace motor sensor (LH) [seat device assembly (LH)]. Refer to [SE-97, "Exploded View"](#).  
 NO >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).



# MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## 7.CHECK INTERMITTENT INCIDENT

Refer to [GI-40. "Intermittent Incident"](#).

>> INSPECTION END

RH

RH : Description

INFOID:000000004347398

Detect the operation condition of power return motor (RH).

RH : Component Function Check

INFOID:000000004347399

### 1.CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Motor sensor (RH) is OK.


NO >> Refer to [SE-33. "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000004347400

### 1.CHECK MOTOR SENSOR (RH) OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between rear seatback power return control unit harness connector and ground.

| (+)       |          | (-)    | Condition                                    | Voltage (V)<br>(Approx.)   |
|-----------|----------|--------|--|--|
| Connector | Terminal |        |  |  |
| B227      | 2        | Ground | During the power return motor (RH) operation |  <p>JMKIA0070GB</p> |
|           |          |        | When pinching between LH/RH seats occurs     | The above pulse width should be expanded   |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

### 2.CHECK MOTOR SENSOR (RH) SIGNAL CIRCUIT

1. Disconnect power return motor assembly (RH) connector and rear seatback power return control unit connector.
2. Check continuity between power return motor assembly (RH) harness connector and rear seatback power return control unit harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 2        | B504                             | 18       | Existed    |

3. Check continuity between power return motor assembly (RH) harness connector and ground.

# MOTOR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 2        |        | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

### 3.CHECK MOTOR SENSOR (RH) POWER SUPPLY

1. Connect rear seatback power return control unit connector.
2. Check voltage power return motor assembly (RH) harness connector and ground.

| (+)                              |          | (-)    | Condition                                | Voltage (V)<br>(Approx.) |
|----------------------------------|----------|--------|--|--------------------------|
| Power return motor assembly (RH) |          |        |  |                          |
| Connector                        | Terminal |        |  |                          |
| B504                             | 17       | Ground | When the power return switch is operated | Battery voltage          |

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> GO TO 4.

### 4.CHECK MOTOR SENSOR (RH) POWER SUPPLY CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (RH) harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 3        | B504                             | 17       | Existed    |

3. Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 3        |        | Not existed |

Is the inspection result normal?

- YES >> Replace rear seatback power return control unit. Refer to [SE-104. "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 5.CHECK MOTOR SENSOR (RH) GROUND CIRCUIT 1

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between power return motor assembly harness connector and power return motor assembly (RH) harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 1        | B504                             | 19       | Existed    |

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness.

### 6.CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 2

1. Connect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and ground.

# MOTOR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

| Rear seatback power return control unit |          | Ground | Continuity |
|---|----------|--------|------------|
| Connector                               | Terminal |        | Existed    |
| B227                                    | 1        |        |            |

Is the inspection result normal?

YES >> Replace motor sensor (RH) [seat device assembly (RH)]. Refer to [SE-97, "Exploded View"](#).

NO >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).

### 7. CHECK INTERMITTENT INCIDENT

Refer to [GI-40, "Intermittent Incident"](#).

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# POWER RETURN MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## POWER RETURN MOTOR

LH

LH : Description

INFOID:000000004347401

Operate the rear seatback.

LH : Component Function Check

INFOID:000000004347402

### 1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

- YES >> Power return motor (LH) is OK.  
 NO >> Refer to [SE-36, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000004347403

### 1. CHECK POWER RETURN MOTOR (LH) INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between power return motor assembly (LH) harness connector and ground.

| (+)       |          | (-)    | Condition  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--|--------------------------|
| Connector | Terminal |        |  |                          |
| B511      | 1        | Ground | During the power return motor (LH) reverse operation | Battery voltage          |
|           |          |        | Other than the above                                 | 0                        |
|           | 2        |        | During the power return motor (LH) return operation  | Battery voltage          |
|           |          |        | Other than the above                                 | 0                        |

Is the inspection result normal?

- YES >> Replace power return motor assembly (LH) [seat device assembly (LH)]. Refer to [SE-97, "Exploded View"](#).  
 NO >> GO TO 2.

### 2. CHECK POWER RETURN MOTOR (LH) CIRCUIT

- Disconnect rear seatback power return control unit connector and power return motor assembly (LH) connector.
- Check continuity between rear seatback power return control unit harness connector and power return motor assembly (LH) harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (LH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 5        | B511                             | 1        | Existed    |
|   | 6        |                                  | 2        |            |

- Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 5        |        | Not existed |
|   | 6        |        |             |

Is the inspection result normal?

# POWER RETURN MOTOR

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

RH

### RH : Description

INFOID:000000004347404

Operate the rear seatback.

### RH : Component Function Check

INFOID:000000004347405

## 1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

- YES >> Power return motor (RH) is OK.  
 NO >> Refer to [SE-37, "RH : Diagnosis Procedure"](#).

### RH : Diagnosis Procedure

INFOID:000000004347406

## 1. CHECK POWER RETURN MOTOR (RH) INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between power return motor assembly (RH) harness connector and ground.

| (+)       |          | (-)    | Condition  | Voltage (V)<br>(Approx.) |
|-----------|----------|--------|--|--------------------------|
| Connector | Terminal |        |  |                          |
| B504      | 20       | Ground | During the power return motor (RH) reverse operation | Battery voltage          |
|           |          |        | Other than the above                                 | 0                        |
|           | 21       |        | During the power return motor (RH) return operation  | Battery voltage          |
|           |          |        | Other than the above                                 | 0                        |

Is the inspection result normal?

- YES >> Replace power return motor assembly (RH) [seat device assembly (RH)]. Refer to [SE-97, "Exploded View"](#).  
 NO >> GO TO 2.

## 2. CHECK POWER RETURN MOTOR (RH) CIRCUIT

- Disconnect rear seatback power return control unit connector and power return motor assembly (RH) connector.
- Check continuity between rear seatback power return control unit harness connector and power return motor assembly (RH) harness connector.

| Rear seatback power return control unit |          | Power return motor assembly (RH) |          | Continuity |
|---|----------|----------------------------------|----------|------------|
| Connector                               | Terminal | Connector                        | Terminal |            |
| B227                                    | 7        | B504                             | 20       | Existed    |
|   | 8        |                                  | 21       |            |

- Check continuity between rear seatback power return control unit harness connector and ground.

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B227                                    | 7        |        | Not existed |
|   | 8        |        |             |

Is the inspection result normal?

## POWER RETURN MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> Replace rear seatback power return control unit. Refer to [SE-104. "Removal and Installation"](#).
- NO >> Repair or replace harness.

# VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## VEHICLE SPEED SIGNAL CIRCUIT

### Description

INFOID:000000004347407

Transmits vehicle speed signal to rear seatback power return control unit.

### Component Function Check

INFOID:000000004347408

#### 1. CHECK FUNCTION

Check that the rear seatback rises when pressing and holding the power return switch or rear seatback switch in UP direction.

Is the inspection result normal?

- YES >> Vehicle speed signal circuit is OK.
- NO >> Refer to [SE-39, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004347409

#### 1. CHECK VEHICLE SPEED OPERATION


1. Check speed meter operate normally.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Refer to [MWI-4, "Work flow"](#).

#### 2. CHECK VEHICLE SPEED INPUT SIGNAL

Check voltage between rear seatback power return control unit harness connector and ground.

| (+)       |          | (-)    | Condition                                     | Voltage (V)<br>(Approx.)   |
|-----------|----------|--------|---|--|
| Connector | Terminal |        |   |  |
| B226      | 24       | Ground | When vehicle speed is approx. 40 km/h (25MPH) | <p><b>NOTE:</b><br/>Maximum voltage may be 12V due to specifications (connected units)</p>  |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refer to [MWI-4, "Work flow"](#).

#### 3. CHECK VEHICLE SPEED SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seatback power return control unit connector and unified meter and A/C amp. connector.
3. Check continuity between power return control unit harness connector and unified meter and A/C amp. harness connector.

| Rear seatback power return control unit |          | Unified meter and A/C amp. |          | Continuity |
|---|----------|----------------------------|----------|------------|
| Connector                               | Terminal | Connector                  | Terminal |            |
| B226                                    | 24       | M66                        | 28       | Existed    |

4. Check continuity between rear seatback power return control unit harness connector and ground.

# VEHICLE SPEED SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

---

| Rear seatback power return control unit |          | Ground | Continuity  |
|---|----------|--------|-------------|
| Connector                               | Terminal |        |             |
| B226                                    | 24       |        | Not existed |

---

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4. CHECK INTERMITTENT INCIDENT

---

Refer to [GI-40. "Intermittent Incident"](#).

>> INSPECTION END



# POWER SEAT


< DTC/CIRCUIT DIAGNOSIS >

## POWER SEAT

Wiring Diagram - POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER) -

INFOID:000000004347410

### POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)



\*: This connector is not shown in "Harness Layout".

2008/08/28

JCJWA0749GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT

## < DTC/CIRCUIT DIAGNOSIS >

### POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)

|                |                 |
|----------------|-----------------|
| Connector No.  | B1              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | THBDFW-CS16-TM4 |



|              |   |    |                             |
|--------------|---|----|-----------------------------|
| Terminal No. | 3 | SB | Signal Name [Specification] |
|--------------|---|----|-----------------------------|

|                |   |
|----------------|---|
| Connector No.  | B10   |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MD4FW-LC  |




|              |   |    |                             |
|--------------|---|----|-----------------------------|
| Terminal No. | 1 | SB | Signal Name [Specification] |
| 2            | B |    |                             |

|                |   |
|----------------|---|
| Connector No.  | B411  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MD4MW-LC  |



|              |   |   |                             |
|--------------|---|---|-----------------------------|
| Terminal No. | 1 | R | Signal Name [Specification] |
| 2            | B |   |                             |

|                |  |
|----------------|--|
| Connector No.  | B414   |
| Connector Name | POWER SEAT SWITCH (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | NS2DFW-CS  |



|              |     |   |                             |
|--------------|-----|---|-----------------------------|
| Terminal No. | 1   | R | Signal Name [Specification] |
| 2            | B   |   |                             |
| 3            | G/Y |   |                             |
| 4            | P   |   |                             |
| 5            | W   |   |                             |
| 6            | V   |   |                             |
| 7            | L/Y |   |                             |
| 8            | L   |   |                             |
| 9            | L/R |   |                             |
| 10           | G/W |   |                             |

|                |  |
|----------------|--|
| Connector No.  | B415   |
| Connector Name | RECLINING MOTOR (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | NS22FW-CS  |



|              |   |     |                             |
|--------------|---|-----|-----------------------------|
| Terminal No. | 3 | G/Y | Signal Name [Specification] |
| 4            | P |     |                             |

|                |  |
|----------------|--|
| Connector No.  | B416   |
| Connector Name | SLIDING MOTOR (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | 6098-0239  |



|              |   |   |                             |
|--------------|---|---|-----------------------------|
| Terminal No. | 5 | W | Signal Name [Specification] |
| 6            | V |   |                             |

|                |   |
|----------------|---|
| Connector No.  | B417  |
| Connector Name | LEFT AS MOTOR (REAR) (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | NS22FW-CS   |



|              |     |     |                             |
|--------------|-----|-----|-----------------------------|
| Terminal No. | 9   | L/R | Signal Name [Specification] |
| 10           | G/W |     |                             |

|                |  |
|----------------|--|
| Connector No.  | B418   |
| Connector Name | RIGHT AS MOTOR (REAR) (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | NS22FW-CS  |





|              |   |     |                             |
|--------------|---|-----|-----------------------------|
| Terminal No. | 7 | L/Y | Signal Name [Specification] |
| 8            | L |     |                             |

# POWER SEAT

## < DTC/CIRCUIT DIAGNOSIS >



### POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)

|                |                 |
|----------------|-----------------|
| Connector No.  | E106            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80FW-CS16-TM4 |



|                             |    |   |
|-----------------------------|----|---|
| Terminal No.                | 91 | W |
| Color of Wire               | W  |   |
| Signal Name [Specification] |    |   |

|                |                  |
|----------------|------------------|
| Connector No.  | M1               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2        |



|                             |    |   |
|-----------------------------|----|---|
| Terminal No.                | 7A | R |
| Color of Wire               | R  |   |
| Signal Name [Specification] |    |   |

|                |                 |
|----------------|-----------------|
| Connector No.  | M6              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MM-CS16-TM4 |



|                             |    |   |
|-----------------------------|----|---|
| Terminal No.                | 91 | W |
| Color of Wire               | W  |   |
| Signal Name [Specification] |    |   |

|                |                 |
|----------------|-----------------|
| Connector No.  | M7              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MM-CS16-TM4 |



|                             |   |   |
|-----------------------------|---|---|
| Terminal No.                | 3 | W                                       |
| Color of Wire               | W |   |
| Signal Name [Specification] |   |   |
|                             |   | -- [Without automatic drive positioner] |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M18                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03PE-LC                  |

|                             |           |                                 |
|-----------------------------|-----------|---------------------------------|
| Terminal No.                | 1         | W                               |
| Color of Wire               | W         |                                 |
| Signal Name [Specification] | BAT (F/L) |                                 |
|                             | 2         | Y                               |
|                             |           | POWER WINDOW POWER SUPPLY (BAT) |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M19                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS18FW-CS                 |

|                             |            |     |
|-----------------------------|------------|-----|
| Terminal No.                | 11         | R   |
| Color of Wire               | R          |     |
| Signal Name [Specification] | BAT (FUSE) |     |
|                             | 13         | B   |
|                             |            | GND |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

## Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -

INFOID:000000004347411

### POWER SEAT FOR PASSENGER SIDE



2008/08/28

JCJWA0752GB

# POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SEAT FOR PASSENGER SIDE

|                |                 |
|----------------|-----------------|
| Connector No.  | B201            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH02FW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 95           | G             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B211  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MC4FW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | G             | -                           |
| 2            | B             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B431  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MC4MW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R             | -                           |
| 2            | B             | -                           |

|                |                                    |
|----------------|------------------------------------|
| Connector No.  | B434                               |
| Connector Name | POWER SEAT SWITCH (PASSENGER SIDE) |
| Connector Type | NS10FW-CS                          |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R             | -                           |
| 2            | B             | -                           |
| 3            | G/Y           | -                           |
| 4            | P             | -                           |
| 5            | W             | -                           |
| 6            | V             | -                           |
| 7            | L/Y           | -                           |
| 8            | L             | -                           |
| 9            | L/R           | -                           |
| 10           | G/W           | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B435                             |
| Connector Name | RECLINING MOTOR (PASSENGER SIDE) |
| Connector Type | NS02FW-CS                        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | G/Y           | -                           |
| 4            | P             | -                           |

|                |                                |
|----------------|--------------------------------|
| Connector No.  | B436                           |
| Connector Name | SLIDING MOTOR (PASSENGER SIDE) |
| Connector Type | 6098-0293                      |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5            | W             | -                           |
| 6            | V             | -                           |

|                |  |
|----------------|--|
| Connector No.  | B437                                   |
| Connector Name | LIFTING MOTOR (FRONT) (PASSENGER SIDE) |
| Connector Type | NS02FW-CS                              |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 9            | L/R           | -                           |
| 10           | G/W           | -                           |

|                |                                       |
|----------------|---------------------------------------|
| Connector No.  | B438                                  |
| Connector Name | LIFTING MOTOR (REAR) (PASSENGER SIDE) |
| Connector Type | NS02FW-CS                             |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7            | L/Y           | -                           |
| 8            | L             | -                           |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT





## < DTC/CIRCUIT DIAGNOSIS >

### POWER SEAT FOR PASSENGER SIDE

|                |                 |                |                  |                |                 |
|----------------|-----------------|----------------|------------------|----------------|-----------------|
| Connector No.  | E106            | Connector No.  | M1               | Connector No.  | M117            |
| Connector Name | WIRE TO WIRE    | Connector Name | FUSE BLOCK (J/B) | Connector Name | WIRE TO WIRE    |
| Connector Type | TH8DFW-CS16-TM4 | Connector Type | NS08FW-M2        | Connector Type | TH80MM-CS16-TM4 |

|                             |    |                             |   |                             |    |                             |   |
|-----------------------------|----|-----------------------------|---|-----------------------------|----|-----------------------------|---|
| Terminal No.                | 91 | Color of Wire               | W | Terminal No.                | 91 | Color of Wire               | W |
| Signal Name [Specification] |    | Signal Name [Specification] |   | Terminal No.                | 95 | Color of Wire               | W |
| Signal Name [Specification] |    | Signal Name [Specification] |   | Signal Name [Specification] |    | Signal Name [Specification] |   |



|                |                           |                |                           |
|----------------|---------------------------|----------------|---------------------------|
| Connector No.  | M118                      | Connector No.  | M119                      |
| Connector Name | BCM (BODY CONTROL MODULE) | Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03PE-LC                  | Connector Type | NS18FW-CS                 |

|                             |                                |                             |            |                             |    |                             |   |
|-----------------------------|--------------------------------|-----------------------------|------------|-----------------------------|----|-----------------------------|---|
| Terminal No.                | 1                              | Color of Wire               | W          | Terminal No.                | 11 | Color of Wire               | R |
| Signal Name [Specification] | BAT (F/L)                      | Signal Name [Specification] | BAT (FUSE) | Terminal No.                | 13 | Color of Wire               | B |
| Signal Name [Specification] | POWER WINDOW POWER SUPPLY(BAT) | Signal Name [Specification] | GND        | Signal Name [Specification] |    | Signal Name [Specification] |   |



JCJWA0754GB


# HEATED SEAT

< DTC/CIRCUIT DIAGNOSIS >

## HEATED SEAT

### Wiring Diagram - HEATED SEAT -

INFOID:000000004347412



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT

## < DTC/CIRCUIT DIAGNOSIS >

### HEATED SEAT

|                |                 |
|----------------|-----------------|
| Connector No.  | B1              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80FW-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5            | GR            | -                           |
| 10           | O             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B10   |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MO4FW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 12           | GR            | -                           |

|                |  |
|----------------|--|
| Connector No.  | B11  |
| Connector Name | WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER) |
| Connector Type | HS16FW-CS                                      |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 48           | B             | -                           |
| 59           | GR            | -                           |
| 60           | O             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | B201            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80FW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7            | LG            | -                           |
| 8            | R             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B211  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MO4FW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 11           | V             | -                           |
| 12           | Y             | -                           |

|                |   |
|----------------|---|
| Connector No.  | B411  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MO4MW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 11           | Y             | -                           |
| 12           | Y/G           | -                           |

|                |                                   |
|----------------|-----------------------------------|
| Connector No.  | B412                              |
| Connector Name | SEAT CUSHION HEATER (DRIVER SIDE) |
| Connector Type | MO3FW-LC                          |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 11           | Y             | -                           |
| 12           | Y/G           | -                           |

|                |   |
|----------------|---|
| Connector No.  | B431  |
| Connector Name | WIRE TO WIRE (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| Connector Type | MO4MW-LC  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 11           | Y             | -                           |
| 12           | Y/G           | -                           |

JCJWA0759GB



# HEATED SEAT

## < DTC/CIRCUIT DIAGNOSIS >


### HEATED SEAT

|                |                                      |
|----------------|--------------------------------------|
| Connector No.  | B432                                 |
| Connector Name | SEAT CUSHION HEATER (PASSENGER SIDE) |
| Connector Type | MS3FW-LC                             |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | -                           |
| 11           | Y             | -                           |
| 12           | Y/G           | -                           |

|                |  |
|----------------|--|
| Connector No.  | B480   |
| Connector Name | WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER) |
| Connector Type | NS16MW-CS                                      |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 48           | B             | -                           |
| 59           | Y/G           | -                           |
| 60           | Y             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | E106            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80FW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 92           | L             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | M1               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2        |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2A           | G             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M8              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 92           | L             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M7              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5            | GR            | -                           |
| 10           | SB            | -                           |

|                |                   |
|----------------|-------------------|
| Connector No.  | M70               |
| Connector Name | HEATED SEAT RELAY |
| Connector Type | MS02FL-M2-LC      |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | B             | -                           |
| 2            | G             | -                           |
| 3            | G             | -                           |
| 5            | L             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M117            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7            | W             | -                           |
| 8            | G             | -                           |

JCJWA0760GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT

## < DTC/CIRCUIT DIAGNOSIS >

### HEATED SEAT

|                |              |
|----------------|--------------|
| Connector No.  | M135         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS08BER-CS   |



|   |   |   |
|---|---|---|
| 1 | 2 | 3 |
| 4 | 5 | 6 |
| 7 | 8 |   |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | -                           |
| 2            | G             | -                           |
| 3            | G             | -                           |
| 4            | B             | -                           |
| 5            | L             | -                           |
| 6            | B             | -                           |
| 7            | SB            | -                           |
| 8            | GR            | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | M171         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS08BER-CS   |



|   |   |   |
|---|---|---|
| 3 | 2 | 1 |
| 8 | 7 | 6 |
| 5 | 4 |   |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | -                           |
| 2            | G             | -                           |
| 3            | P             | -                           |
| 4            | B             | -                           |
| 5            | L             | -                           |
| 6            | V             | -                           |
| 7            | SB            | -                           |
| 8            | LG            | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | M172                             |
| Connector Name | HEATED SEAT SWITCH (DRIVER SIDE) |
| Connector Type | NS06FW-CS                        |



|   |   |
|---|---|
| 5 | 6 |
| 4 | 2 |
| 1 | 3 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | P             | -                           |
| 2            | LG            | -                           |
| 3            | SB            | -                           |
| 4            | V             | -                           |

|                |                                     |
|----------------|-------------------------------------|
| Connector No.  | M173                                |
| Connector Name | HEATED SEAT SWITCH (PASSENGER SIDE) |
| Connector Type | NS06FER-CS                          |



|   |   |
|---|---|
| 5 | 6 |
| 4 | 2 |
| 1 | 3 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | G             | -                           |
| 2            | L             | -                           |
| 3            | GR            | -                           |
| 4            | B             | -                           |

JCJWA0761GB


# LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

## LUMBAR SUPPORT

### Wiring Diagram - LUMBAR SUPPORT SYSTEM -

INFOID:000000004347413



\*: This connector is not shown in "Harness Layout".

LUMBAR SUPPORT

2008/08/28

JCJWA0755GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# LUMBAR SUPPORT

## < DTC/CIRCUIT DIAGNOSIS >

### LUMBAR SUPPORT

|                       |   |  |                    |                     |                             |                    |                     |                             |
|-----------------------|---|--|--------------------|---------------------|-----------------------------|--------------------|---------------------|-----------------------------|
| Connector No.<br>B1   | WIRE TO WIRE<br>TH80FW-CS16-TM4                             |  | Terminal No.<br>3  | Color of Wire<br>SB | Signal Name [Specification] | Terminal No.<br>3  | Color of Wire<br>SB | Signal Name [Specification] |
| Connector No.<br>B458 | LUMBAR SUPPORT MOTOR<br>C02FW                               |  | Terminal No.<br>58 | Color of Wire<br>W  | Signal Name [Specification] | Terminal No.<br>58 | Color of Wire<br>W  | Signal Name [Specification] |
| Connector No.<br>B457 | LUMBAR SUPPORT SWITCH<br>NS04FW-CS                          |  | Terminal No.<br>33 | Color of Wire<br>R  | Signal Name [Specification] | Terminal No.<br>48 | Color of Wire<br>B  | Signal Name [Specification] |
| Connector No.<br>B11  | WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)<br>NS16FW-CS |  | Terminal No.<br>33 | Color of Wire<br>SB | Signal Name [Specification] | Terminal No.<br>48 | Color of Wire<br>B  | Signal Name [Specification] |
| Connector No.<br>B460 | WIRE TO WIRE (WITH AUTOMATIC DRIVE POSITIONER)<br>NS18MW-CS |  | Terminal No.<br>33 | Color of Wire<br>R  | Signal Name [Specification] | Terminal No.<br>48 | Color of Wire<br>B  | Signal Name [Specification] |
| Connector No.<br>M7   | WIRE TO WIRE<br>TH80MW-CS16-TM4                             |  | Terminal No.<br>3  | Color of Wire<br>SB | Signal Name [Specification] | Terminal No.<br>3  | Color of Wire<br>SB | Signal Name [Specification] |
| Connector No.<br>M8   | WIRE TO WIRE<br>TH80MW-CS16-TM4                             |  | Terminal No.<br>91 | Color of Wire<br>W  | Signal Name [Specification] | Terminal No.<br>91 | Color of Wire<br>W  | Signal Name [Specification] |
| Connector No.<br>E06  | WIRE TO WIRE<br>TH80FW-CS16-TM4                             |  | Terminal No.<br>91 | Color of Wire<br>W  | Signal Name [Specification] | Terminal No.<br>91 | Color of Wire<br>W  | Signal Name [Specification] |

JCJWA0756GB

# LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

| LUMBAR SUPPORT |                 |
|----------------|-----------------|
| Connector No.  | M62             |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | MOEY-F-LC       |

| Terminal No. | Color of Wire | Signal Name (Specification) |
|--------------|---------------|-----------------------------|
| 1            | W             | -                           |
| 2            | SB            | -                           |



JCJWA0757GB

# REAR SEATBACK RELEASE CONTROL


< DTC/CIRCUIT DIAGNOSIS >

## REAR SEATBACK RELEASE CONTROL

Wiring Diagram - REAR SEATBACK RELEASE CONTROL -

INFOID:000000004347414

### REAR SEATBACK RELEASE CONTROL



\*: This connector is not shown in "Harness Layout".

2008/08/28

JCJWA0769GB

# REAR SEATBACK RELEASE CONTROL

## < DTC/CIRCUIT DIAGNOSIS >

### REAR SEATBACK RELEASE CONTROL

|                |                                   |
|----------------|-----------------------------------|
| Connector No.  | B49                               |
| Connector Name | REAR SEATBACK RELEASE SWITCH (LH) |
| Connector Type | TK08FW-IV                         |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | BR            | -                           |
| 3            | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B66          |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH    |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 16           | BR            | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | E201             |
| Connector Name | WIRE TO WIRE     |
| Connector Type | TH80FW-CS (P-TM) |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 10           | W             | -                           |
| 28           | Y             | -                           |

|                |                                   |
|----------------|-----------------------------------|
| Connector No.  | B233                              |
| Connector Name | REAR SEATBACK RELEASE SWITCH (RH) |
| Connector Type | TK08FW-IV                         |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | O             | -                           |
| 3            | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B224         |
| Connector Name | WIRE TO WIRE |
| Connector Type | MS16MW-CS    |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 10           | R             | -                           |
| 11           | W             | -                           |
| 12           | W             | -                           |
| 22           | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B243         |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH    |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 16           | BR            | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | E246                             |
| Connector Name | REAR SEATBACK RELEASE RELAY (LH) |
| Connector Type | MS02FL-M2                        |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | BR            | -                           |
| 2            | O             | -                           |
| 3            | W             | -                           |
| 5            | W             | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B247                             |
| Connector Name | REAR SEATBACK RELEASE RELAY (RH) |
| Connector Type | MS02FL-M2                        |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | O             | -                           |
| 2            | Y             | -                           |
| 3            | W             | -                           |
| 5            | W             | -                           |

JCJWA0770GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

## REAR SEATBACK RELEASE CONTROL

|                |              |
|----------------|--------------|
| Connector No.  | B501         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS10FW-CS    |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10           | B             | -                           |
| 11           | V/W           | -                           |
| 12           | W             | -                           |
| 22           | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B503         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS10FW-CS    |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10           | B             | -                           |
| 11           | V/W           | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B506                             |
| Connector Name | REAR SEATBACK LOCK ASSEMBLY (RH) |
| Connector Type | NS304FW-CS                       |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12           | W             | -                           |
| 22           | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B510         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS10MW-CS    |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10           | B             | -                           |
| 11           | W             | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B513                             |
| Connector Name | REAR SEATBACK LOCK ASSEMBLY (LH) |
| Connector Type | NS304FW-CS                       |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10           | B             | -                           |
| 11           | W             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | E105            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80PW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 96           | P             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | M2               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6B           | Y             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M6              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MP-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 95           | W             | -                           |

JCJWA0771GB




# REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## REAR SEATBACK RELEASE CONTROL

|                |                 |
|----------------|-----------------|
| Connector No.  | M117            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-C316-TM4 |



| Terminal No. | Color of Wire | Signal Name (Specification) |
|--------------|---------------|-----------------------------|
| 10           | W             | -                           |
| 28           | Y             | -                           |

JCJWA0772GB

# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


## ECU DIAGNOSIS INFORMATION

### REAR SEAT BACK POWER RETURN CONTROL UNIT

Reference Value

INFOID:000000004347415

#### TERMINAL LAYOUT



A. B227

B. B226



#### PHYSICAL VALUES

Rear seat back power return control unit

| Terminal No. |        | Wire color | Description                             |              | Condition   | Value (Approx.)                          |
|--------------|--------|------------|---|--------------|---|--|
| +            | -      |            | Signal name                             | Input/Output |   |  |
| 1            | Ground | V          | Ground (Motor sensor RH)                | —            | —   | 0  |
| 2            | Ground | Y          | Motor sensor (RH) input signal          | Input        | When the power return motor (RH) is operated                |  |
|              |        |            |   |              | When the pinch occurs                                       | The above pulse width should be expanded |
| 3            | Ground | G          | Motor sensor (RH) Power supply          | Input        | When the power return motor is operated                     | Battery voltage                          |
| 5            | Ground | W          | Power return motor (LH) backward signal | Output       | When the power return motor (LH) performs reverse operation | Battery voltage                          |
|              |        |            |   |              | Other than the above  | 0  |
| 6            | Ground | L          | Power return motor (LH) forward signal  | Output       | When the power return motor (LH) performs return operation  | Battery voltage                          |
|              |        |            |   |              | Other than the above  | 0  |
| 7            | Ground | W          | Power return motor (RH) backward signal | Output       | When the power return motor (RH) performs reverse operation | Battery voltage                          |
|              |        |            |   |              | Other than the above  | 0  |
| 8            | Ground | R          | Power return motor (RH) forward signal  | Output       | When the power return motor (RH) performs return operation  | Battery voltage                          |
|              |        |            |   |              | Other than the above  | 0  |

# REAR SEAT BACK POWER RETURN CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

| Terminal No. |        | Wire color | Description  |              | Condition  | Value (Approx.)   |
|--------------|--------|------------|--|--------------|--|---|
| +            | -      |            | Signal name  | Input/Output |  |   |
| 9            | Ground | P          | Ground (Motor sensor LH)   | —            | —  | 0   |
| 10           | Ground | BR         | Motor sensor (LH) input signal   | Input        | When the power return motor (LH) is operated   |    |
|              |        |            |  |              | When the pinch occurs  | The above pulse width should be expanded  |
| 11           | Ground | W          | Motor sensor (LH) Power supply   | Input        | When the power return motor is operated  | Battery voltage   |
| 13           | Ground | B          | Ground (power)   | —            | —  | 0   |
| 16           | Ground | W          | Battery power supply (power)   | Input        | —  | Battery voltage   |
| 17           | Ground | Y          | Battery power supply (system)  | Input        | —  | Battery voltage   |
| 20           | Ground | P          | Power return switch (RH) or rear seatback switch (RH) in UP direction input signal | Input        | When pressing the power return switch (RH) or rear seatback switch (RH) in UP direction      | 0   |
|              |        |            |  |              | Other than the above   | 5   |
| 21           | Ground | GR         | Primary position limit switch (LH) input signal                                    | Input        | When the sector gear (LH) is in the initial position (other than low power consumption mode) | Battery voltage   |
|              |        |            |  |              | Other than the above   | 0   |
| 22           | Ground | P          | Primary position limit switch (RH) input signal                                    | Input        | When the sector gear (RH) is in the initial position (other than low power consumption mode) | Battery voltage   |
|              |        |            |  |              | Other than the above   | 0   |
| 23           | Ground | L          | Ground (limit switch RH)   | —            | —  | 0   |
| 24           | Ground | BR         | Vehicle speed signal (8-pulse)   | Input        | When vehicle speed is approx.40 km/h (25MPH)   | <p style="text-align: center;"><b>NOTE:</b><br/>Maximum voltage may be 12 V due to specifications (connected units)</p>  |
|              |        |            |  |              |  | Other than the above  |
| 28           | Ground | LG         | Power return switch (LH) or rear seatback switch in UP direction input signal      | Input        | When pressing the power return switch (LH) or rear seatback switch in UP direction           | 0   |
|              |        |            |  |              | Other than the above   | 5   |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT BACK POWER RETURN CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

| Terminal No. |        | Wire color | Description                                    |              | Condition  | Value (Approx.) |
|--------------|--------|------------|--|--------------|--|-----------------|
| +            | -      |            | Signal name                                    | Input/Output |  |                 |
| 29           | Ground | G          | Return complete limit switch (LH) input signal | Input        | When the rear seatback (LH) is in the return completion position (other than low power consumption mode) | Battery voltage |
|              |        |            |  |              | Other than the above   | 0               |
| 30           | Ground | R          | Return complete limit switch (RH) input signal | Input        | When the rear seatback (RH) is in the return completion position (other than low power consumption mode) | Battery voltage |
|              |        |            |  |              | Other than the above   | 0               |
| 31           | Ground | L          | Ground (limit switch LH)                       | —            | —  | 0               |
| 32           | Ground | B          | Ground (system)                                | —            | —  | 0               |


# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - REAR SEATBACK POWER RETURN SYSTEM -

INFOID:000000004347416

### REAR SEATBACK POWER RETURN SYSTEM



\*: This connector is not shown in "Harness Layout".

2008/08/28


JCJWA0762GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

\*: This connector is not shown in "Harness Layout".




JCJWA0763GB

# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## REAR SEATBACK POWER RETURN SYSTEM

|                |                           |
|----------------|---------------------------|
| Connector No.  | B52                       |
| Connector Name | REAR SEATBACK SWITCH (LH) |
| Connector Type | TK08FW-TV                 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | BR            | -                           |
| 2            | O             | -                           |
| 3            | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B66          |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH2AMW-NH    |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 16           | BR            | -                           |
| 17           | O             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | E201             |
| Connector Name | WIRE TO WIRE     |
| Connector Type | TH80FW-CS (P-TM) |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10           | W             | -                           |
| 17           | BR            | -                           |
| 28           | Y             | -                           |
| 29           | Y             | -                           |
| 30           | GR            | -                           |

|                |   |
|----------------|---|
| Connector No.  | B226                                    |
| Connector Name | REAR SEATBACK POWER RETURN CONTROL UNIT |
| Connector Type | YAA16FW                                 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17           | Y             | BAT (SYSTEM)                |
| 20           | P             | FLIP UP SW RH               |
| 21           | GR            | PRIMARY POSITION L/S (LH)   |
| 22           | P             | PRIMARY POSITION L/S (RH)   |
| 23           | L             | GND (RH L/S)                |
| 24           | BR            | SPEED SP                    |
| 28           | LG            | FLIP UP SW LH               |
| 29           | G             | RETURN COMPLETE L/S (LH)    |
| 30           | R             | RETURN COMPLETE L/S (RH)    |
| 31           | L             | GND (LH L/S)                |
| 32           | B             | GND (SIGNAL)                |

|                |   |
|----------------|---|
| Connector No.  | B227                                    |
| Connector Name | REAR SEATBACK POWER RETURN CONTROL UNIT |
| Connector Type | SEA16FW                                 |



| Terminal No. | Color of Wire | Signal Name [Specification]       |
|--------------|---------------|-----------------------------------|
| 1            | V             | GND (RH SENSOR)                   |
| 2            | Y             | MOTOR SENSOR (RH)                 |
| 3            | G             | POWER SUPPLY (RH SENSOR) BACKWARD |
| 5            | W             | BACKWARD                          |
| 6            | L             | FORWARD                           |
| 7            | W             | BACKWARD                          |
| 8            | B             | FORWARD                           |
| 9            | P             | GND (LH SENSOR)                   |
| 10           | BR            | MOTOR SENSOR (LH)                 |
| 11           | W             | POWER SUPPLY (LP SENSOR) BACKWARD |
| 13           | B             | GND (POWER)                       |

|                |              |
|----------------|--------------|
| Connector No.  | E234         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS    |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | W             | -                           |
| 4            | BR            | -                           |
| 5            | P             | -                           |
| 6            | GR            | -                           |
| 8            | G             | -                           |
| 9            | L             | -                           |
| 10           | R             | -                           |
| 11           | W             | -                           |
| 12           | W             | -                           |
| 13           | R             | -                           |
| 14           | L             | -                           |

|              |    |   |   |
|--------------|----|---|---|
| Terminal No. | 15 | P | - |
| 17           | G  | - | - |
| 18           | Y  | - | - |
| 19           | V  | - | - |
| 22           | B  | - | - |

|    |   |             |
|----|---|-------------|
| 16 | W | BAT (POWER) |
|----|---|-------------|

JCJWA0764GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT BACK POWER RETURN CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

### REAR SEATBACK POWER RETURN SYSTEM

|                |              |
|----------------|--------------|
| Connector No.  | B235         |
| Connector Name | WIRE TO WIRE |
| Connector Type | M03MW-LC     |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | W             | -                           |
| 2            | L             | -                           |
| 20           | W             | -                           |
| 21           | R             | -                           |

|                |                           |
|----------------|---------------------------|
| Connector No.  | B239                      |
| Connector Name | REAR SEATBACK SWITCH (RH) |
| Connector Type | TK06FW-1V                 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | O             | -                           |
| 2            | P             | -                           |
| 3            | B             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B243         |
| Connector Name | WIRE TO WIRE |
| Connector Type | 1H24FW-NH    |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 16           | BR            | -                           |
| 17           | LG            | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B246                             |
| Connector Name | REAR SEATBACK RELEASE RELAY (LH) |
| Connector Type | MS26EL-M2                        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | BR            | -                           |
| 2            | O             | -                           |
| 3            | W             | -                           |
| 5            | W             | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B247                             |
| Connector Name | REAR SEATBACK RELEASE RELAY (RH) |
| Connector Type | MS26FL-M2                        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | O             | -                           |
| 2            | Y             | -                           |
| 3            | W             | -                           |
| 5            | W             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B501         |
| Connector Name | WIRE TO WIRE |
| Connector Type | MS16FW-CS    |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | G             | -                           |
| 4            | G/B           | -                           |
| 5            | G/R           | -                           |
| 6            | SB            | -                           |
| 8            | O             | -                           |
| 9            | V             | -                           |
| 10           | B             | -                           |
| 11           | V/W           | -                           |
| 12           | W             | -                           |
| 13           | L             | -                           |
| 14           | L/B           | -                           |

|    |      |   |
|----|------|---|
| 15 | L/W  | - |
| 17 | GR   | - |
| 18 | GR/B | - |
| 19 | GR/R | - |
| 22 | B    | - |

|                |              |
|----------------|--------------|
| Connector No.  | B502         |
| Connector Name | WIRE TO WIRE |
| Connector Type | MS4FW-LC     |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R             | -                           |
| 2            | R/W           | -                           |
| 20           | LG            | -                           |
| 21           | LG/B          | -                           |

JCJWA0765GB



# REAR SEAT BACK POWER RETURN CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

### REAR SEATBACK POWER RETURN SYSTEM

|                |              |
|----------------|--------------|
| Connector No.  | B503         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NSJUMW-CS    |



|    |    |   |   |
|----|----|---|---|
| 11 | 18 | 3 | 1 |
| 10 | 6  | 9 | 5 |
|    | 4  | 2 |   |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R             | -                           |
| 2            | R/W           | -                           |
| 3            | G             | -                           |
| 4            | G/B           | -                           |
| 5            | G/R           | -                           |
| 6            | SB            | -                           |
| 8            | O             | -                           |
| 9            | V             | -                           |
| 10           | B             | -                           |
| 11           | V/W           | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B504                             |
| Connector Name | POWER RETURN MOTOR ASSEMBLY (RH) |
| Connector Type | 6098-0245                        |



|    |    |
|----|----|
| 21 | 20 |
| 18 | 19 |
| 17 |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17           | GR            | MOTOR SENS BAT              |
| 18           | GR/B          | MOTOR SENS SIGNAL           |
| 19           | GR/R          | MOTOR SENS GND              |
| 20           | LG            | -                           |
| 21           | LG/B          | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | B510         |
| Connector Name | WIRE TO WIRE |
| Connector Type | NSJUMW-CS    |



|   |   |    |    |
|---|---|----|----|
| 1 | 3 | 8  | 11 |
| 2 | 4 | 5  | 9  |
|   | 6 | 10 |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | LG/B          | -                           |
| 2            | LG            | -                           |
| 3            | GR            | -                           |
| 4            | GR/B          | -                           |
| 5            | GR/R          | -                           |
| 6            | L/W           | -                           |
| 8            | L             | -                           |
| 9            | L/B           | -                           |
| 10           | B             | -                           |
| 11           | W             | -                           |

|                |                                    |
|----------------|------------------------------------|
| Connector No.  | B505                               |
| Connector Name | PRIMARY POSITION LIMIT SWITCH (RH) |
| Connector Type | TR02FW                             |



|    |    |
|----|----|
| 14 | 15 |
|    | 6  |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 14           | L/B           | -                           |
| 15           | L/W           | -                           |

|                |                                    |
|----------------|------------------------------------|
| Connector No.  | B512                               |
| Connector Name | PRIMARY POSITION LIMIT SWITCH (LH) |
| Connector Type | TR02FW                             |



|   |   |
|---|---|
| 9 | 6 |
|---|---|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6            | L/W           | -                           |
| 9            | L/B           | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B506                             |
| Connector Name | REAR SEATBACK LOCK ASSEMBLY (RH) |
| Connector Type | NSMFW-CS                         |



|    |    |    |    |
|----|----|----|----|
| 13 | 14 | 22 | 12 |
|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12           | W             | -                           |
| 13           | L             | -                           |
| 14           | L/B           | -                           |
| 22           | B             | -                           |

|                |                                  |
|----------------|----------------------------------|
| Connector No.  | B513                             |
| Connector Name | REAR SEATBACK LOCK ASSEMBLY (LH) |
| Connector Type | NSMFW-CS                         |



|   |   |    |    |
|---|---|----|----|
| 8 | 9 | 10 | 11 |
|---|---|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 8            | L             | -                           |
| 9            | L/B           | -                           |
| 10           | B             | -                           |
| 11           | W             | -                           |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


JCJWA0766GB

# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## REAR SEATBACK POWER RETURN SYSTEM

|                |                 |
|----------------|-----------------|
| Connector No.  | E106            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80FW-CS16-TM4 |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 96           | P             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | M2               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS        |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 6B           | Y             | -                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M6              |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 96           | W             | -                           |

|                |                            |
|----------------|----------------------------|
| Connector No.  | M66                        |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH40FW-NH                  |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 28           | R             | VEHICLE SPEED (3-PULSE)     |

|                |                            |
|----------------|----------------------------|
| Connector No.  | M67                        |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH32FW-NH                  |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 56           | L             | CAN-H                       |
| 72           | P             | CAN-L                       |

|                |                 |
|----------------|-----------------|
| Connector No.  | M17             |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 10           | W             | -                           |
| 17           | BR            | -                           |
| 28           | Y             | -                           |
| 29           | Y             | -                           |
| 30           | V             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | M134         |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH    |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 6            | V             | -                           |
| 8            | B             | -                           |
| 17           | B             | -                           |
| 19           | Y             | -                           |

|                |              |
|----------------|--------------|
| Connector No.  | M170         |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH    |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 6            | GR            | -                           |
| 8            | BR            | -                           |
| 17           | L             | -                           |
| 19           | Y             | -                           |

# REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## REAR SEATBACK POWER RETURN SYSTEM

|                |                          |
|----------------|--------------------------|
| Connector No.  | M174                     |
| Connector Name | POWER RETURN SWITCH (LH) |
| Connector Type | TKCAFV                   |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | Y             | -                           |
| 2            | BR            | -                           |

|                |                          |
|----------------|--------------------------|
| Connector No.  | M175                     |
| Connector Name | POWER RETURN SWITCH (RH) |
| Connector Type | TKCAFV-B                 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | -                           |
| 2            | L             | -                           |

## Fail-safe

Even if the automatic return control is inactivated, the fold-down and manual return operations can be performed

JCJWA0768GB

INFOID:000000004347417

# REAR SEAT BACK POWER RETURN CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

| Possible location of malfunction                | Diagnosis mode  | Corrective action   |
|---|---|---|
| Return complete limit switch "ON" malfunction   | The return completion position cannot be detected   | Detect the lock with the rear seatback power return control unit, and then reverse the power return motor   |
| Return complete limit switch "OFF" malfunction  | The automatic return cannot be performed because the return completion position is misrecognized                    | The manual return operation can be performed  |
| Primary position limit switch "ON" malfunction  | The initial position of the sector gear cannot be detected  | Detect the lock with the rear seatback power return control unit, and then stop the power return motor<br>* If the above condition is repeated for 4 times, stop the subsequent automatic return operation. However, the manual return operation can be performed |
| Primary position limit switch "OFF" malfunction | The initial position of the sector gear is misrecognized<br>(The sector gear reverse operation cannot be performed) | <ul style="list-style-type: none"> <li>Return the sector gear to the initial position if the primary position limit switch is not turned to ON after starting the return (Lock detection)</li> <li>The manual return operation can be performed</li> </ul>        |
| Sensor malfunction (fixed to High or Low)       | The motor lock is misrecognized because the pulse does not change   | <ul style="list-style-type: none"> <li>If the pulse does not change completely after starting the motor operation, return the sector gear to the initial position</li> <li>The manual return operation can be performed</li> </ul>                                |

# REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE BOTH SIDES

#### BOTH SIDES : Diagnosis Procedure

INFOID:000000004347418

#### 1. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [SE-14. "REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK VEHICLE SPEED SIGNAL CIRCUIT

Check vehicle speed signal circuit.

Refer to [SE-39. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

LH

#### LH : Diagnosis Procedure

INFOID:000000004347419

SE

#### 1. PERFORM POWER RETURN SWITCH AND REAR SEATBACK SWITCH

Perform power return switch and rear seatback switch.

From which power return switch (or rear seatback switch) does the seat return operation occur?

POWER RETURN SWITCH >> GO TO 2.

REAR SEATBACK SWITCH >> GO TO 3.

BOTH SIDES >> GO TO 4.

#### 2. CHECK POWER RETURN SWITCH (LH)

Check power return switch (LH).

Refer to [SE-15. "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK REAR SEATBACK SWITCH (LH)

Check rear seatback switch (LH).

Refer to [SE-19. "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK POWER RETURN MOTOR (LH)

Check power return motor (LH).

Refer to [SE-36. "LH : Component Function Check"](#).

Is the inspection result normal?

# REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

---

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

### 5.CHECK RETURN COMPLETE LIMIT SWITCH (LH)

---

Check return complete limit switch (LH).  
Refer to [SE-27, "LH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace the malfunctioning parts.

### 6.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).  
NO >> GO TO 1.

RH

## RH : Diagnosis Procedure

INFOID:000000004347420

### 1.PERFORM POWER RETURN SWITCH AND REAR SEATBACK SWITCH

---

Perform power return switch and rear seatback switch.

From which power return switch (or rear seatback switch) does the seat return operation occur?

- POWER RETURN SWITCH>>GO TO 2.  
REAR SEATBACK SWITCH>>GO TO 3.  
BOTH SIDES>>GO TO 4.

### 2.CHECK POWER RETURN SWITCH (RH)

---

Check power return switch (RH).  
Refer to [SE-16, "RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

### 3.CHECK REAR SEATBACK SWITCH (RH)

---

Check rear seatback switch (RH).  
Refer to [SE-20, "RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

### 4.CHECK POWER RETURN MOTOR (RH)

---

Check power return motor (RH).  
Refer to [SE-37, "RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

### 5.CHECK RETURN COMPLETE LIMIT SWITCH (RH)

---

Check return complete limit switch (RH).  
Refer to [SE-28, "RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace the malfunctioning parts.

### 6.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

# REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

---

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).  
NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

# MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION

< SYMPTOM DIAGNOSIS >

## MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION LH

LH : Diagnosis Procedure

INFOID:000000004347421

### 1.CHECK RETURN COMPLETE LIMIT SWITCH (LH)

Check return complete limit switch (LH).

Refer to [SE-27, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK PRIMARY POSITION LIMIT SWITCH (LH)

Check primary position limit switch (LH).

Refer to [SE-23, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CHECK POWER RETURN MOTOR (LH)

Check power return motor (LH).

Refer to [SE-36, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

RH

RH : Diagnosis Procedure

INFOID:000000004347422

### 1.CHECK RETURN COMPLETE LIMIT SWITCH (RH)

Check return complete limit switch (RH).

Refer to [SE-28, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK PRIMARY POSITION LIMIT SWITCH (RH)

Check primary position limit switch (RH).

Refer to [SE-24, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CHECK POWER RETURN MOTOR (RH)

Check power return motor (RH).

Refer to [SE-37, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.



# MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION

## < SYMPTOM DIAGNOSIS >

---

NO >> Repair or replace the malfunctioning parts.

## 4.CONFIRM THE OPERATION

---

Confirm the operation again.

### Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# DOES NOT RETURN BUT MALFUNCTION DETECTION BUZZER SOUNDS

< SYMPTOM DIAGNOSIS >

## DOES NOT RETURN BUT MALFUNCTION DETECTION BUZZER SOUNDS

LH

LH : Diagnosis Procedure

INFOID:000000004347423

### 1.CHECK PRIMARY POSITION LIMIT SWITCH (LH)

---

Check primary position limit switch (LH).

Refer to [SE-23, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK MOTOR SENSOR (LH)

---

Check motor sensor (LH).

Refer to [SE-31, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

RH

RH : Diagnosis Procedure

INFOID:000000004347424

### 1.CHECK PRIMARY POSITION LIMIT SWITCH (RH)

---

Check primary position limit switch (RH).

Refer to [SE-23, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK MOTOR SENSOR (RH)

---

Check motor sensor (RH).

Refer to [SE-33, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# ANTI-PINCH FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## ANTI-PINCH FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000004347425

#### 1.CHECK MOTOR SENSOR (LH)

Check motor sensor (LH).

Refer to [SE-31, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK MOTOR SENSOR (RH)

Check motor sensor (RH).

Refer to [SE-33, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-104, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE


# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000004347426



### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [SE-80, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - Removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
  - Tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - Feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - Placing a piece of paper between components that you suspect are causing the noise.
  - Looking for loose components and contact marks.  
Refer to [SE-78. "Inspection Procedure"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - Separate components by repositioning or loosening and retightening the component, if possible.
  - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

### **CAUTION:**

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

### **NOTE:**

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

Insulates where slight movement is present. Ideal for instrument panel applications.

### SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

### SILICONE SPRAY

Use when grease cannot be applied.

### DUCT TAPE

Use to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Inspection Procedure

INFOID:000000004347427

Refer to Table of Contents for specific component removal and installation information.

## INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

### **CAUTION:**

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

## CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

## DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

## TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted under hood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000004347428







### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E



# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> anytime                      | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> when it is raining or wet     |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions       |
| <input type="checkbox"/> only when it is hot outside  | <input type="checkbox"/> other:                        |

### III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about \_\_\_\_ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: \_\_\_\_\_
- after driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

#### Test Drive Notes:

---

---

---

|  | YES                      | NO                       | Initials of person performing |
|--|--------------------------|--------------------------|-------------------------------|
| Vehicle test driven with customer                  | <input type="checkbox"/> | <input type="checkbox"/> | _____                         |
| - Noise verified on test drive                     | <input type="checkbox"/> | <input type="checkbox"/> | _____                         |
| - Noise source located and repaired                | <input type="checkbox"/> | <input type="checkbox"/> | _____                         |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____                         |

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_  
W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

PIIB8742E

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004347429

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000004347430

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

# PRECAUTIONS

## < PRECAUTION >

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

## Service Notice

INFOID:000000004347431

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

## Precaution for Work

INFOID:000000004347432

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
  - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.  
Then rub with a soft and dry cloth.
  - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >



## PREPARATION

### PREPARATION

#### Special Service Tool



INFOID:000000004347433

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description                |
|---|----------------------------|
| (J39570)<br>Chassis ear<br><br><br>SIIA0993E                     | Locates the noise          |
| (J43980)<br>NISSAN Squeak and Rattle<br>Kit<br><br><br>SIIA0994E | Repairs the cause of noise |

#### Commercial Service Tool

INFOID:000000004347434

| Tool name  | Description                              |
|--|--|
| Engine ear<br><br><br>SIIA0995E     | Locates the noise                        |
| Remover tool<br><br><br>JMKIA3050ZZ | Removes the clips, pawls and metal clips |

# CLIP LIST

< PREPARATION >

## CLIP LIST

### Clip List

INFOID:000000006113823

| Shapes | Removal & Installation   | Shapes | Removal & Installation   |
|--------|--|--------|--|
|        | <p><b>Removal:</b><br/>Remove by bending up with flat-bladed screwdrivers or clip remover.</p>   |        | <p><b>Removal:</b></p>   |
|        | <p><b>Removal:</b><br/>Remove with a clip remover.</p>   |        | <p><b>Removal:</b></p>   |
|        | <p><b>Removal:</b><br/>Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p><b>Installation:</b></p> |        | <p><b>Removal:</b><br/>Holder portion of clip must be spread out to remove rod.</p>  |
|        | <p><b>Removal:</b><br/>Remove by bending up with flat-bladed screwdrivers or clip remover.</p>   |        | <p><b>Removal:</b></p> <ol style="list-style-type: none"> <li>Screw out with a Phillips screwdriver.</li> <li>Remove female portion with flat-bladed screwdriver.</li> </ol> |
|        | <p><b>Removal:</b></p>   |        | <p><b>Removal:</b></p> <p>Rotate 45° to remove.</p> <p><b>Installation:</b></p>  |
|        | <p><b>Removal:</b></p>   |        | <p><b>Removal:</b></p>   |

JMJIA3734GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION

### FRONT SEAT

Exploded View

INFOID:000000004347435

DRIVER'S SEAT



- |                     |  |   |
|---------------------|--|---|
| 1. Headrest         | 2. Headrest holder (locked)            | 3. Headrest holder (free)                     |
| 4. Seatback trim    | 5. Seatback pad                        | 6. Seat cushion trim                          |
| 7. Seat cushion pad | 8. Seat cushion inner finisher outside | 9. Seat cushion inner finisher inside (front) |

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |  |   |   |   |
|--|---|---|---|
| 10. Seat cushion inner finisher inside (rear)  | 11. Seat cushion inner lower finisher         | 12. Seat belt buckle                            | A |
| 13. Seat cushion front finisher                | 14. Front outer slide cover                   | 15. Front inner slide cover                     |   |
| 16. Seat harness                               | 17. Driver seat control unit                  | 18. Seat slide & lifter switch knob             | B |
| 19. Seat reclining switch knob                 | 20. Seat cushion outer finisher outside       | 21. Seat cushion outer lower finisher (outside) | B |
| 22. Seat cushion outer lower finisher (inside) | 23. Seat cushion outer finisher inside (rear) | 24. Seat cushion outer finisher inside (front)  | C |
| 25. Seat control switch                        | 26. Lumbar support switch                     | 27. Seat control harness                        | C |
| 28. Rear outer slide cover                     | 29. Rear inner slide cover                    | 30. Seat cushion frame                          |   |
| 31. Side air bag module                        | 32. Seatback frame                            | 33. Seatback board                              | D |
| 34. Seatback board clip                        | 35. Seatback silencer                         |   |   |

Refer to [GI-4. "Components"](#) for symbols in the figure.

## PASSENGER'S SEAT

### **CAUTION:**


**Never disassembly the component parts of only front passenger seat in the dotted lines shown in the figure below. (With occupant classification system control unit model)**

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# FRONT SEAT

## < REMOVAL AND INSTALLATION >



- |  |  |   |
|--|--|---|
| 1. Headrest                                    | 2. Headrest holder (locked)                    | 3. Headrest holder (free)                       |
| 4. Seatback trim                               | 5. Seatback pad                                | 6. Seatback silencer                            |
| 7. Seatback frame                              | 8. Seatback board                              | 9. Seatback board clip                          |
| 10. Side air bag module                        | 11. Seat slide & lifter switch knob            | 12. Seat reclining switch knob                  |
| 13. Seat cushion outer finisher outside        | 14. Seat cushion outer finisher inside (front) | 15. Seat cushion outer finisher inside (rear)   |
| 16. Seat control switch                        | 17. Seat control harness                       | 18. Seat cushion outer lower finisher (outside) |
| 19. Seat cushion outer lower finisher (inside) | 20. Rear outer slide cover                     | 21. Rear inner slide cover                      |
| 22. Seat harness                               | 23. Front outer slide cover                    | 24. Front inner slide cover                     |



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |   |  |   |
|---|--|---|
| 25. Seat cushion front finisher         | 26. Seat cushion frame                         | 27. Seat belt buckle                          |
| 28. Seat cushion inner finisher outside | 29. Seat cushion inner finisher inside (front) | 30. Seat cushion inner finisher inside (rear) |
| 31. Seat cushion inner finisher lower   | 32. Seat cushion trim                          | 33. Seat cushion pad                          |
| 34. Seat cushion assembly               |  |   |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation


INFOID:000000004347436


### REMOVAL

#### CAUTION:


**When removing and installing, use shop cloths to protect parts from damage.**


1. Remove the headrest.
2. Remove the front slide cover.
  - a. Front outer slide cover
    - Slide the seat to the rear-most position.
    - Pull up the front edge of the front slide cover to release the pawls.
    - Slide the front slide cover forward to release the pawls.

 : Pawl




- b. Front inner slide cover
      - Slide the seat to the rear-most position.
      - Pull up the front edge of the front slide cover to release the pawls.
      - Slide the front slide cover forward to release the pawls.


 : Pawl



3. Remove the mounting bolts on the front side of the front seat.
4. Remove the rear slide cover.

- a. Rear outer slide cover
    - Slide the seat to the front-most position.
    - Pull up the rear edge of the rear outer slide cover to release the pawls.
    - Open the front end of the rear outer slide cover to release the pawls.

 : Pawl





A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- b. Rear inner slide cover
- Slide the seat to the front-most position.
  - Pull up the rear edge of the rear inner slide cover to release the pawls.
  - Slide the rear inner slide cover rearward to release the pawls.

 : Pawl



5. Remove the mounting bolts on the rear side of the front seat.  
6. Set seatback in a standing position.  
7. Disconnect harness connector under the seat and remove harness securing clips.

**CAUTION:**

**Before removal, turn ignition switch OFF, disconnect battery negative terminal, and then wait for at least 3 minutes.**

8. Remove seat from the vehicle.

**CAUTION:**

- **When removing and installing, use shop cloths to protect parts from damage.**
- **When removing and installing, 2 workers are required so as to prevent it from dropping.**

## INSTALLATION

Install in the reverse order of removal.

**CAUTION:**

- **Before installation, turn ignition switch OFF, disconnect both battery cables, and then wait for at least 3 minutes.**
- **Clamp the harness in position.**

**NOTE:**

After installing the front seat, perform additional service when removing battery negative terminal. (Automatic drive positioner model only) Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).



## Disassembly and Assembly


INFOID:000000004347437

## SEATBACK

### Disassembly

1. Remove the seatback board.
- Remove the clips and pawls, and then pull out seatback board.
  - Pull down the seatback board to release the upper pawls.

 : Clip  
 : Pawl




2. Remove the seatback trim retainer and seatback trim band from seat cushion frame.  
3. Disconnect the harness connectors and remove the harness clamps.


# FRONT SEAT

## < REMOVAL AND INSTALLATION >


- Disconnect the reclining motor harness connector (A) and lumbar support harness connector (Driver's seat only) (B).



- Disconnect the seatback heater harness (C).




- Remove the harness clamps, and then side air bag module harness (D).



4. Remove the metal clips and pawls, and then pull out seat cushion front finisher.

- : Metal clip
- △ : Pawl



5. Remove the seat cushion outer finisher.


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT


## < REMOVAL AND INSTALLATION >

- Remove the seat slide and lifter (With lifter seat), reclining switch knob.
- Remove the clips, metal clips and pawls, and then pull out seat cushion outer finisher outside.
- Disconnect the slide & lifter, reclining and lumbar support switch (Driver's seat only) harness connectors.

- : Clip
- : Metal clip
- △ : Pawl




6. Remove the seat cushion outer finisher inside front (1) and rear (2).




7. Remove the metal clip and pawls, and then pull out seat cushion inner finisher outside.

- : Metal clip
- △ : Pawl



8. Remove the seat cushion inner finisher inside front (1) and rear (2).




9. Remove the seatback trim and seatback pad.


# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- Remove the headrest holder.  
**CAUTION:**  
**Before installing headrest holder check its orientation. (front/rear and right/left)**
- Remove the air bag module.
- Remove the seatback trim and seatback pad from the seatback frame.
- Remove the hog rings, and separate the seatback trim and seatback pad.



- Remove the seatback silencer.
- Remove the seatback frame.  
Remove the seatback frame mounting bolts (A) and then remove the seatback frame.



### Assembly

Assemble in the reverse order of disassembly.

### **CAUTION:**

**Install the hog rings of seatback trim in position, and then securely connect the trim or trim cord with the pad side wire.**

## SEAT CUSHION

### Disassembly



### **CAUTION:**

**Never disassemble front passenger seat cushion assembly.**

**Always replace as an assembly.**

**For front passenger seat service parts, refer to the service part catalogue.**

- Remove the seatback board.
  - Remove the clips and pawls, and then pull out seatback board.
  - Pull down the seatback board to release the upper pawls.




- Remove the seatback trim retainer and seatback trim band from seat cushion frame.
- Disconnect the harness connectors and remove the harness clamps.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# FRONT SEAT

## < REMOVAL AND INSTALLATION >


- Disconnect the reclining motor harness connector (A) and lumbar support harness connector (B) (Driver's seat only).



- Disconnect the seatback heater harness connector (C).




- Remove the side air bag module harness (D).



4. Remove the metal clips and pawls, and then pull out seat cushion front finisher.

- : Metal clip
- △ : Pawl



5. Remove the seat cushion outer finisher.



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- Remove the seat slide and lifter (With lifter seat), reclining switch knob.
- Remove the clip, metal clips and pawls, and then pull out seat cushion outer finisher outside.
- Disconnect the slide & lifter, reclining and lumbar support switch (Driver's seat only) harness connectors.


- : Clip
- : Metal clip
- △ : Pawl

6. Remove the seat cushion outer finisher inside front (1) and rear (2).




7. Remove the metal clip and pawls, and then pull out seat cushion inner finisher outside.


- : Metal clip
- △ : Pawl



8. Remove the seat cushion inner finisher inside front (1) and rear (2).



9. Remove the seatback assembly.  
Remove the seatback assembly mounting bolts (A).





A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## FRONT SEAT


### < REMOVAL AND INSTALLATION >


10. Remove the metal clips, and then pull out seat cushion outer lower finisher outside (1) and inside (2).

 : Metal clip




11. Remove the seat cushion inner lower finisher.

 : Metal clip



12. Remove the seat cushion trim and seat cushion pad. (Without occupant classification system control unit model)

- Disconnect the seat cushion heater unit harness connector (A).
- Remove the seat cushion trim retainer.
- Remove the hog rings, and separate the seat cushion trim and seat cushion pad.



13. Remove the seat belt buckle. [SB-8, "SEAT BELT BUCKLE : Exploded View"](#)

14. Remove the driver seat control unit. (Driver's power seat only) [ADP-207, "Exploded View"](#)

Assembly

Assemble in the reverse order of disassembly.

#### **CAUTION:**

**Install the hog rings of seat cushion trim in position, and then securely connect the trim or trim cord with the pad side wire.**



# REAR SEAT


< REMOVAL AND INSTALLATION >

## REAR SEAT

Exploded View

INFOID:000000004347438

REAR SEAT



JMJIA1584GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT

## < REMOVAL AND INSTALLATION >

- |  |   |  |
|--|---|--|
| 1. Rear center seat belt                 | 2. Center seat belt retractor cover       | 3. Seat belt guide (upper)               |
| 4. Seat belt guide (lower)               | 5. Rear seatback lock cover (RH)          | 6. Rear seatback lock knob (RH)          |
| 7. Rear seatback lock knob finisher (RH) | 8. Headrest holder (free)                 | 9. Headrest holder (locked)              |
| 10. Seat belt finisher                   | 11. Rear seatback trim (RH)               | 12. Rear seatback pad (RH)               |
| 13. Rear seatback board (RH)             | 14. Rear seatback board clip (RH)         | 15. Armrest trim                         |
| 16. Armrest pad                          | 17. Armrest frame                         | 18. Cup holder                           |
| 19. Armrest bracket cover (RH)           | 20. Armrest bracket (RH)                  | 21. Armrest bracket (LH)                 |
| 22. Armrest bracket cover (LH)           | 23. Rear seatback lock assembly (RH)      | 24. Rear seatback frame (RH)             |
| 25. Rear seat belt hook (RH)             | 26. Rear seatback hinge outer cover (RH)  | 27. Rear seatback hinge (RH)             |
| 28. Rear seatback hinge bracket (RH)     | 29. Rear seatback hinge bush (RH)         | 30. Reclining device outer cover (RH)    |
| 31. Reclining device assembly (RH)       | 32. Reclining device inner cover (RH)     | 33. Rear seat harness (RH)               |
| 34. Rear seat cushion trim               | 35. Rear seat cushion pad                 | 36. Rear seat cushion hook               |
| 37. Reclining device outer cover (LH)    | 38. Reclining device assembly (LH)        | 39. Reclining device inner cover (LH)    |
| 40. Reclining device bush                | 41. Rear seat harness (LH)                | 42. Rear seatback hinge outer cover (LH) |
| 43. Rear seatback hinge (LH)             | 44. Rear seat belt hook (LH)              | 45. Rear seatback lock assembly (LH)     |
| 46. Rear seatback frame (LH)             | 47. Rear seatback hinge bracket (LH)      | 48. Rear seatback hinge bush (LH)        |
| 49. Rear seatback lock cover (LH)        | 50. Rear seatback pad (LH)                | 51. Rear seatback trim (LH)              |
| 52. Rear seatback lock knob (LH)         | 53. Rear seatback lock knob finisher (LH) | 54. Headrest holder (locked)             |
| 55. Headrest holder (free)               | 56. Rear seatback board (LH)              | 57. Rear seatback board clip (LH)        |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation


INFOID:000000004347439

### REMOVAL

#### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove the seat cushion.
  - Pull the lock lever (1) at the front bottom of the seat cushion forward (1 for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward the remove
  - Remove the seat cushion from vehicle.




2. Remove the seatback.
  - Remove the luggage floor finisher front LH and RH. Refer to [INT-34, "Exploded View"](#).
  - Disconnect the rear seat harness connectors.
  - With power return seat model  
LH seatback

# REAR SEAT


## < REMOVAL AND INSTALLATION >

Disconnect the rear seat harness connectors (A).



RH seatback


Disconnect the rear seat harness connector (A).



- Without power return seat model


LH seatback

Disconnect the rear seat harness connectors (A).



RH seatback

Disconnect the rear seat harness connector (A).




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT


## < REMOVAL AND INSTALLATION >

- Push the seatback lock pin (A).
- Remove the seatback mounting nuts (B), (C) and bolt (D).
- Remove the center seat belt anchor bolt. (RH seatback only)  
Refer to [SB-11. "SEAT BELT RETRACTOR : Exploded View"](#).
- Remove the seatback from vehicle.



## INSTALLATION

1. Install the rear seatback mounting nuts (1), (2), (3).
2. Lock the seatback striker (4).
3. Install the rear seatback mounting bolt (5).
4. Pull the rear seatback lock pin (6).



## CAUTION:

- When removing and installing, use shop cloths to protect parts from damage.
- When removing and installing, 2 workers are required so as to prevent it from dropping.


## Disassembly and Assembly


INFOID:000000004347440

## SEATBACK


### Disassembly

1. Remove the clips, and then pull out seatback board.

 : Clip




2. Remove the armrest.
  - Remove the armrest hinge covers (1).




# REAR SEAT

## < REMOVAL AND INSTALLATION >


- Remove the arm rest mounting bolts (A), nuts (B) and hog rings (C), and then remove the armrest.




- Remove the seatback device assembly.
  - Remove the seatback trim fixing hog rings.
  - Disconnect the seatback lock harness connector.  
LH seatback  
Disconnect the seatback lock harness connector (A).



- RH seatback  
Disconnect the seatback lock harness connector (B).



- Remove the seatback device.  
Remove the seatback device mounting bolts (C).




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


## REAR SEAT


### < REMOVAL AND INSTALLATION >


4. Remove the hinge bracket mounting bolt (A), and then remove the hinge bracket (1).




5. Remove the seatback trim and pad.
  - Remove the metal clips and pawls, and then pull out seatback lock cover.

 : Metal clip


 : Pawl



- Remove the seatback hinge outer cover.



- Remove the seatback hinge.
  - Remove the seatback hinge mounting bolt (A).




- Turn seatback lock knob counterclockwise to remove.

## REAR SEAT

### < REMOVAL AND INSTALLATION >


- Push the seatback lock knob finisher pawl upward through the seatback pad and the seatback frame to remove it.



- Remove the headrest holder.


**CAUTION:**

**Before installing headrest holder check its orientation. (front/rear and right/left)**



- Remove the seatback trim and pad.
- Remove the hog rings to separate the seatback trim and seatback pad.

6. Remove the seatback lock assembly.  
Remove the seatback lock assembly mounting bolts.



7. Remove the rear center seat belt. Refer to [SB-11. "SEAT BELT RETRACTOR : Exploded View"](#)

#### Assembly

Assemble in the reverse order of disassembly.

**CAUTION:**

**Install the hog rings of seatback trim in position, and then securely connect the trim or trim cord with the seatback frame.**

#### SEAT CUSHION

##### Disassembly

Remove the hog rings to separate the trim and pad.

##### Assembly

Assemble in the reverse order of disassembly.

**CAUTION:**

**Install the hog rings of seat cushion trim in position, and then securely connect the trim or trim cord with the seat cushion pad wire.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# REAR SEAT BACK POWER RETURN CONTROL UNIT

< REMOVAL AND INSTALLATION >

## REAR SEAT BACK POWER RETURN CONTROL UNIT

Exploded View

INFOID:000000004347441



1. Rear seatback power return control unit

### Removal and Installation


INFOID:000000004347442

#### REMOVAL

**CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove the luggage floor finisher assembly (front). Refer to [INT-35, "Removal and Installation"](#).
2. Remove mounting nuts (A).
3. Remove rear seatback power return control unit (1).



#### INSTALLATION

Install in the reverse order of removal.

**CAUTION:**

**Be sure to clamp the harness to the right place.**



# POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

## POWER SEAT SWITCH

### Exploded View

INFOID:000000004347443

Refer to [SE-86. "Exploded View"](#).

### Removal and Installation


INFOID:000000004347444

#### REMOVAL

##### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove the seat cushion outer finisher (1). Refer to [SE-89. "Removal and Installation"](#).
2. Remove the screws (A).
3. Remove the power seat switch (2) from the seat cushion outer finisher.



#### INSTALLATION

Install in the reverse order of removal.

##### **CAUTION:**

**Be sure to clamp the harness to the right place.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# LUMBAR SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

## LUMBAR SUPPORT SWITCH

### Exploded View

INFOID:000000004347445

Refer to [SE-86. "Exploded View"](#).

### Removal and Installation


INFOID:000000004347446


#### REMOVAL

##### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove the seat cushion outer finisher (1). Refer to [SE-89. "Removal and Installation"](#).
2. Remove the lumbar support switch (2) from the seat cushion outer finisher. With flat bladed screw driver (A).

 : Pawl



#### INSTALLATION

Install in the reverse order of removal.

##### **CAUTION:**

**Be sure to clamp the harness to the right place.**

# HEATED SEAT SWITCH

< REMOVAL AND INSTALLATION >

## HEATED SEAT SWITCH

### Exploded View

INFOID:000000004347447

Refer to [IP-23. "Exploded View"](#).

### Removal and Installation


INFOID:000000004347448

#### REMOVAL

##### **CAUTION:**


**When removing and installing, use shop cloths to protect from damage.**

1. Remove the console body assembly. Refer to [IP-23. "Removal and Installation"](#)
2. Remove heated seat switch (1) from switch bracket. With flat bladed screw driver (A).

 : Pawl

##### **NOTE:**

The same procedure is also performed for passenger side.



#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I

SE

K  
L  
M  
N  
O  
P

# POWER RETURN SWITCH

< REMOVAL AND INSTALLATION >

## POWER RETURN SWITCH

### Exploded View

INFOID:000000004347449

Refer to [IP-23, "Exploded View"](#).

### Removal and Installation


INFOID:000000004347450


#### REMOVAL

##### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove the console body assembly. Refer to [IP-23, "Removal and Installation"](#)
2. Remove power return switch (1) from switch bracket. With flat bladed screw driver (A).

 : Pawl



#### INSTALLATION

Install in the reverse order of removal.


# REAR SEATBACK SWITCH

< REMOVAL AND INSTALLATION >

## REAR SEATBACK SWITCH

Exploded View

INFOID:000000004347451



1. Rear seatback switch
2. Luggage side finisher lower escutcheon

## Removal and Installation


INFOID:000000004347452


### REMOVAL

#### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the luggage side finisher lower escutcheon. Refer to [INT-35, "Removal and Installation"](#).
2. Remove rear power return switch (1) from luggage side finisher lower escutcheon. With flat bladed screw driver (A).

 : Pawl



### INSTALLATION

Install in the reverse order of removal.


# REAR SEATBACK RELEASE SWITCH

< REMOVAL AND INSTALLATION >

## REAR SEATBACK RELEASE SWITCH

Exploded View

INFOID:000000004347453



1. Rear seatback release switch
2. Luggage side finisher lower escutcheon

## Removal and Installation


INFOID:000000004347454


### REMOVAL

#### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the luggage side finisher lower escutcheon. Refer to [INT-35, "Removal and Installation"](#).
2. Remove rear power return switch (1) from luggage side finisher lower escutcheon. With flat bladed screw driver (A).

 : Pawl



### INSTALLATION

Install in the reverse order of removal.