

WT

SECTION

ROAD WHEELS & TIRES

A
B
C
D

WT

CONTENTS

| | | | | |
|--|----|---|-------|---|
| BASIC INSPECTION | 4 | DTC Logic | 17 | F |
| DIAGNOSIS AND REPAIR WORK FLOW | 4 | Diagnosis Procedure | 17 | |
| Repair Work Flow | 4 | Special Repair Requirement | 18 | |
| INSPECTION AND ADJUSTMENT | 6 | C1708, C1709, C1710, C1711 TRANSMITTER | ...19 | G |
| TRANSMITTER WAKE UP OPERATION | 6 | Description | 19 | H |
| TRANSMITTER WAKE UP OPERATION : De- | | DTC Logic | 19 | |
| scription | 6 | Diagnosis Procedure | 19 | |
| TRANSMITTER WAKE UP OPERATION : Spe- | | Special Repair Requirement | 20 | |
| cial Repair Requirement | 6 | C1712, C1713, C1714, C1715 TRANSMITTER | ...22 | I |
| ID REGISTRATION PROCEDURE | 6 | Description | 22 | J |
| ID REGISTRATION PROCEDURE : Description..... | 6 | DTC Logic | 22 | |
| ID REGISTRATION PROCEDURE : Special Re- | | Diagnosis Procedure | 22 | |
| pair Requirement | 6 | Special Repair Requirement | 24 | K |
| SYSTEM DESCRIPTION | 9 | C1716, C1717, C1718, C1719 TRANSMITTER | ...25 | L |
| TPMS | 9 | Description | 25 | |
| System Diagram | 9 | DTC Logic | 25 | M |
| System Description | 9 | Diagnosis Procedure | 25 | |
| Component Parts Location | 10 | Component Inspection | 26 | |
| Component Description | 10 | Special Repair Requirement | 26 | N |
| DIAGNOSIS SYSTEM (BCM) | 12 | C1720, C1721, C1722, C1723 TRANSMITTER | ...27 | O |
| COMMON ITEM | 12 | Description | 27 | |
| COMMON ITEM : CONSULT-III Function (BCM - | | DTC Logic | 27 | P |
| COMMON ITEM) | 12 | Diagnosis Procedure | 27 | |
| AIR PRESSURE MONITOR | 13 | Special Repair Requirement | 29 | |
| AIR PRESSURE MONITOR : Diagnosis Descrip- | | C1724, C1725, C1726, C1727 TRANSMITTER | ...30 | |
| tion | 13 | Description | 30 | |
| AIR PRESSURE MONITOR : CONSULT-III Func- | | DTC Logic | 30 | |
| tion (BCM - AIR PRESSURE MONITOR) | 15 | Diagnosis Procedure | 30 | |
| Special Repair Requirement | 17 | Special Repair Requirement | 32 | |
| DTC/CIRCUIT DIAGNOSIS | 17 | C1729 VEHICLE SPEED SIGNAL | 33 | |
| C1704, C1705, C1706, C1707 LOW TIRE | | | | |
| PRESSURE | 17 | | | |
| Description | 17 | | | |

| | | | |
|---|-----------|--|------------|
| Description | 33 | Description | 89 |
| DTC Logic | 33 | Diagnosis Procedure | 89 |
| Diagnosis Procedure | 33 | | |
| Special Repair Requirement | 33 | | |
| C1734 BCM | 34 | LOW TIRE PRESSURE WARNING LAMP | |
| Description | 34 | BLINKS | 91 |
| DTC Logic | 34 | Description | 91 |
| Diagnosis Procedure | 34 | Diagnosis Procedure | 91 |
| Special Repair Requirement | 35 | | |
| TIRE PRESSURE RECEIVER | 37 | TURN SIGNAL LAMP BLINKS | 93 |
| Description | 37 | Description | 93 |
| Component Function Check | 37 | Diagnosis Procedure | 93 |
| Diagnosis Procedure | 37 | | |
| TIRE PRESSURE WARNING CHECK | | ID REGISTRATION CANNOT BE COMPLET- | |
| SWITCH | 40 | ED | 94 |
| Description | 40 | Description | 94 |
| Component Function Check | 40 | Diagnosis Procedure | 94 |
| Diagnosis Procedure | 40 | | |
| LOW TIRE PRESSURE WARNING LAMP | 42 | NORMAL OPERATING CONDITION | 95 |
| Description | 42 | Description | 95 |
| Component Function Check | 42 | | |
| Diagnosis Procedure | 42 | NOISE, VIBRATION AND HARSHNESS | |
| | | (NVH) TROUBLESHOOTING | 96 |
| POWER SUPPLY AND GROUND CIRCUIT | 43 | NVH Troubleshooting Chart | 96 |
| BCM (BODY CONTROL MODULE) | 43 | | |
| BCM (BODY CONTROL MODULE) : Diagnosis | | PRECAUTION | 97 |
| Procedure | 43 | PRECAUTIONS | 97 |
| UNIFIED METER AND A/C AMP. | 43 | Precaution for Supplemental Restraint System | |
| UNIFIED METER AND A/C AMP. : Diagnosis Pro- | | (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | |
| cedure | 43 | SIONER" | 97 |
| | | Service Notice or Precautions | 97 |
| TPMS | 45 | | |
| Wiring Diagram - TIRE PRESSURE MONITOR- | | PREPARATION | 98 |
| ING SYSTEM - | 45 | PREPARATION | 98 |
| | | Special Service Tool | 98 |
| ECU DIAGNOSIS INFORMATION | 49 | Commercial Service Tool | 98 |
| BCM (BODY CONTROL MODULE) | 49 | | |
| Reference Value | 49 | PERIODIC MAINTENANCE | 99 |
| Wiring Diagram - BCM - | 73 | ROAD WHEEL | 99 |
| Fail-safe | 79 | Inspection | 99 |
| DTC Inspection Priority Chart | 81 | | |
| DTC Index | 83 | REMOVAL AND INSTALLATION | 100 |
| SYMPTOM DIAGNOSIS | 86 | ROAD WHEEL TIRE ASSEMBLY | 100 |
| TPMS | 86 | Adjustment | 100 |
| Symptom Table | 86 | | |
| LOW TIRE PRESSURE WARNING LAMP | | TRANSMITTER | 103 |
| DOES NOT TURN ON | 88 | Exploded View | 103 |
| Description | 88 | Removal and Installation | 103 |
| Diagnosis Procedure | 88 | | |
| LOW TIRE PRESSURE WARNING LAMP | | TIRE PRESSURE RECEIVER | 105 |
| DOES NOT TURN OFF | 89 | Exploded View | 105 |
| | | Removal and Installation | 105 |
| | | SERVICE DATA AND SPECIFICATIONS | |
| | | (SDS) | 106 |
| | | SERVICE DATA AND SPECIFICATIONS | |
| | | (SDS) | 106 |
| | | Road Wheel | 106 |

| | | | |
|-----------------|-----|-------------------------|-----|
| Wheel Nut | 106 | Tire Air Pressure | 106 |
|-----------------|-----|-------------------------|-----|

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Repair Work Flow

INFOID:000000004346931

DETAILED FLOW

1. VERIFY CUSTOMER COMPLAINTS

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2.

2. DETERMINE REFERENCE ITEM RELATED TO SYMPTOM

Check the symptom on the vehicle from the information obtained. (cruise test, warning lamp illumination or blinking, etc.)

Is the symptom confirmed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PRELIMINARY INSPECTION

1. Check all tire pressures. Refer to [WT-106, "Tire Air Pressure"](#).

2. Check the low tire pressure warning lamp for illumination or blinking. Refer to [WT-86, "Symptom Table"](#).

Is the malfunction finished?

YES >> INSPECTION END

NO >> GO TO 4.

4. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis. Record any DTCs and data displayed on CONSULT-III.

Is there any DTC displayed?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK SYMPTOM

Perform troubleshooting by symptom. Refer to [WT-86, "Symptom Table"](#).

Is the causal factor identified?

YES >> GO TO 7.

NO >> GO TO 9.

6. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [WT-83, "DTC Index"](#).

>> GO TO 7.

7. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the applicable part.

>> GO TO 8.

8. CHECK SELF-DIAGNOSIS RESULT

1. Erase DTCs. Refer to [WT-13, "AIR PRESSURE MONITOR : Diagnosis Description"](#).

2. Perform self-diagnosis again.

Is any DTC displayed?

YES >> GO TO 6.

NO >> GO TO 9.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

9. FINAL CHECK

1. Perform a cruise test.
2. Check the warning lamp for illumination or blinking.

Is the malfunction corrected?

YES >> INSPECTION END
NO >> GO TO 4.

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT TRANSMITTER WAKE UP OPERATION

TRANSMITTER WAKE UP OPERATION : Description

INFOID:000000004346932

This procedure must be done after replacement of a transmitter, BCM, or rotation of wheels.

TRANSMITTER WAKE UP OPERATION : Special Repair Requirement


INFOID:000000004346933

1. TRANSMITTER WAKE-UP PROCEDURE

1. Turn the ignition switch ON.
2. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
3. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

CAUTION:

Perform the wake-up procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



4. Check that the low tire pressure warning lamp blinks in the pattern shown as per the following. The pattern indicates that the transmitter wake-up procedure for the wheel is completed.

| Low tire pressure warning lamp blinking timing | | Activation tire position |
|--|--|--|
| ON OFF | | a : 0.3 sec. b : 1.3 sec. Front LH |
| ON OFF | | a : 0.3 sec. b : 1.3 sec. Front RH |
| ON OFF | | a : 0.3 sec. b : 1.3 sec. Rear RH |
| ON OFF | | a : 0.3 sec. b : 1.3 sec. Rear LH |
| ON OFF | | a : 2 sec. b : 0.2 sec. All tires |

SEIA0762E

5. Check that the turn signal lamps blink twice when the transmitter wake-up procedure for all wheels is completed.
6. Check that the low tire pressure warning lamp turns OFF, after the transmitter wake-up procedure is completed for all wheels and turns OFF.

Is the transmitter wake-up procedure completed?

YES >> Perform the transmitter ID registration procedure. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

NO >> Perform trouble diagnosis for the transmitter. Refer to [WT-13, "AIR PRESSURE MONITOR : Diagnosis Description"](#).

ID REGISTRATION PROCEDURE

ID REGISTRATION PROCEDURE : Description

INFOID:000000004346934

This procedure must be done after replacing or rotating wheels, replacing transmitter or BCM.

ID REGISTRATION PROCEDURE : Special Repair Requirement

INFOID:000000004346935

1. TRANSMITTER ID REGISTRATION PROCEDURE

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

④ With CONSULT-III.

1. Display the "WORK SUPPORT" screen and select "ID REGIST".

Is the transmitter activation tool (J-45295) used for the transmitter ID registration procedure?

YES >> GO TO 2.


NO >> GO TO 3.

2. TRANSMITTER ID REGISTRATION PROCEDURE (WITH THE TRANSMITTER ACTIVATION TOOL)

1. Turn the ignition switch ON.
2. Select the start button on the "ID REGIST" screen.
3. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
4. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

CAUTION:

Perform the ID registration procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



5. When ID registration is completed, check the following pattern at each wheel.

| Se-quence | ID registration position | Turn signal lamp | CONSULT-III |
|-----------|--------------------------|------------------|-----------------------|
| 1 | Front left wheel | 2 blinks | "Red" ↓ "Green" |
| 2 | Front right wheel | | |
| 3 | Rear right wheel | | |
| 4 | Rear left wheel | | |

6. After the ID registration procedure for all wheels is completed, press "END" to end ID registration, and check that ID registration for all wheels is completed.

Is the check result normal?

YES >> ID registration END.

NO >> Performs trouble-diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-13. "AIR PRESSURE MONITOR : Diagnosis Description"](#).

3. TRANSMITTER ID REGISTRATION PROCEDURE (WITHOUT THE TRANSMITTER ACTIVATION TOOL)

1. Adjust the tire pressure for all wheels to match the list below.

| Tire position | Tire pressure kPa (kg/cm ² , psi) |
|---------------|--|
| Front LH | 240 (2.4, 35) |
| Front RH | 220 (2.2, 31) |
| Rear RH | 200 (2.0, 29) |
| Rear LH | 180 (1.8, 26) |

2. Drive the vehicle at a speed at more than 40 km/h (25 MPH) for 3 minutes or more, then perform the transmitter ID registration procedure.
3. After ID registration for all wheels is completed, press "END" to end ID registration.

| ID registration position | CONSULT-III |
|--------------------------|-----------------------|
| Front LH | "Red" ↓ "Green" |
| Front RH | |
| Rear RH | |
| Rear LH | |

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

4. Adjust the tire pressures for all wheels to the specified value. Refer to [WT-106. "Tire Air Pressure"](#).

Is ID registrations for all wheels completed?

YES >> ID registration END.

NO >> Performs trouble-diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-13. "AIR PRESSURE MONITOR : Diagnosis Description"](#).

TPMS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

TPMS

System Diagram

INFOID:000000004346936



System Description

INFOID:000000004346937

DESCRIPTION


During driving, the TPMS (Tire Pressure Monitoring System) receives the signal transmitted from transmitter installed in each wheel. The BCM (Body Control Module) of this system has pressure judgment and trouble diagnosis functions. When the tire pressure monitoring system detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

TPMS

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000004346938



- | | | |
|---------------------------------------|-------------------------------------|------------------------------|
| 1. Transmitter | 2. BCM | 3. Tire pressure receiver |
| 4. Tire pressure warning check switch | 5. Low tire pressure warning lamp | |
| A. Wheel | B. Dash side lower (passenger side) | C. Instrument lower panel RH |
| D. Behind instrument lower panel LH | E. Inside combination meter | |

Component Description

INFOID:000000004346939

| Component parts | Function |
|------------------------------------|---|
| BCM (Body Control Module) | WT-34. "Description". |
| Transmitter | WT-19. "Description". |
| Tire pressure receiver | WT-37. "Description". |
| Tire pressure warning check switch | WT-40. "Description". |
| Turn signal lamp | ID registration of each wheel has been completed, turn signal lamp flashes. |

TPMS

< SYSTEM DESCRIPTION >

| Component parts | Function | |
|--------------------------------|--|---|
| Unified meter and A/C amp. | Transmits the vehicle speed signal via CAN communication to BCM. | A |
| | Receives the following signals via CAN communication for BCM. <ul style="list-style-type: none">• Tire pressure warning lamp signal• Hazard lamp signal• Buzzer signal | B |
| Low tire pressure warning lamp | Illuminates if malfunction is detected in electrical system of TPMS. | C |

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004346940

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

| Diagnosis mode | Function Description |
|--------------------------|---|
| Work Support | Changes the setting for each system function. |
| Self Diagnostic Result | Displays the diagnosis results judged by BCM. |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual. |
| Data Monitor | The BCM input/output signals are displayed. |
| Active Test | The signals used to activate each device are forcibly supplied from BCM. |
| Ecu Identification | The BCM part number is displayed. |
| Configuration | <ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

| System | Sub system selection item | Diagnosis mode | | |
|---|-----------------------------|----------------|--------------|-------------|
| | | Work Support | Data Monitor | Active Test |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp timer | INT LAMP | × | × | × |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | × | × | × |
| Turn signal and hazard warning lamps | FLASHER | × | × | × |
| — | AIR CONDITONER* | | | |
| <ul style="list-style-type: none"> Intelligent Key system Engine start system | INTELLIGENT KEY | × | × | × |
| Combination switch | COMB SW | | × | |
| Body control system | BCM | × | | |
| IVIS - NATS | IMMU | | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | × |
| — | TRUNK* | | × | × |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | | × | |
| Signal buffer system | SIGNAL BUFFER | | × | × |
| TPMS | TPMS (AIR PRESSURE MONITOR) | × | × | × |

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| CONSULT screen item | Indication/Unit | Description | | |
|---------------------|---|--|--|----|
| Vehicle Speed | km/h | Vehicle speed of the moment a particular DTC is detected | | A |
| Odo/Trip Meter | km | Total mileage (Odometer value) of the moment a particular DTC is detected | | B |
| Vehicle Condition | SLEEP>LOCK | Power position status of the moment a particular DTC is detected | While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK") | C |
| | SLEEP>OFF | | While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".) | D |
| | LOCK>ACC | | While turning power supply position from "LOCK" to "ACC" | WT |
| | ACC>ON | | While turning power supply position from "ACC" to "IGN" | F |
| | RUN>ACC | | While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.) | G |
| | CRANK>RUN | | While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it) | H |
| | RUN>URGENT | | While turning power supply position from "RUN" to "ACC" (Emergency stop operation) | I |
| | ACC>OFF | | While turning power supply position from "ACC" to "OFF" | J |
| | OFF>LOCK | | While turning power supply position from "OFF" to "LOCK" | K |
| | OFF>ACC | | While turning power supply position from "OFF" to "ACC" | L |
| | ON>CRANK | | While turning power supply position from "IGN" to "CRANKING" | M |
| | OFF>SLEEP | | While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode | N |
| | LOCK>SLEEP | | While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode | O |
| | LOCK | | Power supply position is "LOCK" (Ignition switch OFF with steering is locked.) | P |
| | OFF | | Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.) | |
| | ACC | | Power supply position is "ACC" (Ignition switch ACC) | |
| | ON | | Power supply position is "IGN" (Ignition switch ON with engine stopped) | |
| ENGINE RUN | Power supply position is "RUN" (Ignition switch ON with engine running) | | | |
| CRANKING | Power supply position is "CRANKING" (At engine cranking) | | | |
| IGN Counter | 0 - 39 | The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. | | |

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR : Diagnosis Description

INFOID:000000004346941

DESCRIPTION

During driving, the TPMS receives the signal transmitted from the transmitter installed in each wheel, when the tire pressure becomes low. The control unit (BCM) of this system has pressure judgment and trouble diagnosis functions.

When the TPMS detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

SELF DIAGNOSTIC PROCEDURE (WITH CONSULT-III)

④ With CONSULT-III

Touch "SELF-DIAG RESULT" display shows malfunction experienced since the last erasing operation. Refer to [WT-83, "DTC Index"](#).


DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

SELF DIAGNOSTIC PROCEDURE (WITHOUT CONSULT-III)

⊗ Without CONSULT-III

To start the self-diagnostic results mode, ground terminal of the tire pressure warning check connector. The malfunction location is indicated by the low tire pressure warning lamp blinking.



NOTE:

When the low tire pressure warning lamp blinks 5 Hz and continues repeating it, the system is normal.

| Blinking pattern | Items | Diagnostic items detected when... | Check item |
|------------------|--|--|------------|
| 15 | Tire pressure value (Front LH) | Front LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | WT-17 |
| 16 | Tire pressure value (Front RH) | Front RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |
| 17 | Tire pressure value (Rear RH) | Rear RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |
| 18 | Tire pressure value (Rear LH) | Rear LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |
| 21 | Transmitter no data (Front LH) | Data from front LH transmitter can not be receive. | WT-19 |
| 22 | Transmitter no data (Front RH) | Data from front RH transmitter can not be receive. | |
| 23 | Transmitter no data (Rear RH) | Data from rear RH transmitter can not be receive. | |
| 24 | Transmitter no data (Rear LH) | Data from rear LH transmitter can not be receive. | |
| 31 | Transmitter checksum error (Front LH) | Checksum data from front LH transmitter is malfunctioning. | WT-22 |
| 32 | Transmitter checksum error (Front RH) | Checksum data from front RH transmitter is malfunctioning. | |
| 33 | Transmitter checksum error (Rear RH) | Checksum data from rear RH transmitter is malfunctioning. | |
| 34 | Transmitter checksum error (Rear LH) | Checksum data from rear LH transmitter is malfunctioning. | |
| 35 | Transmitter pressure data error (Front LH) | Air pressure data from front LH transmitter is malfunction. | WT-25 |
| 36 | Transmitter pressure data error (Front RH) | Air pressure data from front RH transmitter is malfunction. | |
| 37 | Transmitter pressure data error (Rear RH) | Air pressure data from rear RH transmitter is malfunction. | |
| 38 | Transmitter pressure data error (Rear LH) | Air pressure data from rear LH transmitter is malfunction. | |
| 41 | Transmitter function code error (Front LH) | Function code data from front LH transmitter is malfunction. | WT-27 |
| 42 | Transmitter function code error (Front RH) | Function code data from front RH transmitter is malfunction. | |
| 43 | Transmitter function code error (Rear RH) | Function code data from rear RH transmitter is malfunction. | |
| 44 | Transmitter function code error (Rear LH) | Function code data from rear LH transmitter is malfunction. | |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Blinking pattern | Items | Diagnostic items detected when... | Check item | |
|------------------|--|---|-----------------------|----|
| 45 | Transmitter battery voltage low (Front LH) | Battery voltage of front LH transmitter drops. | WT-30 | A |
| 46 | Transmitter battery voltage low (Front RH) | Battery voltage of front RH transmitter drops. | | B |
| 47 | Transmitter battery voltage low (Rear RH) | Battery voltage of rear RH transmitter drops. | | C |
| 48 | Transmitter battery voltage low (Rear LH) | Battery voltage of rear LH transmitter drops. | | |
| 52 | Vehicle speed signal error | Vehicle speed signal error. | WT-33 | D |
| 53 | Control unit | Tire pressure monitoring system malfunction in BCM. | WT-34 | |
| No blinking | Tire pressure warning check switch | Tire pressure warning switch circuit is open. | - | WT |

NOTE:

NOTE: 182.7 kPa (1.9 kg/cm², 26 psi): Standard air pressure is for 230 kPa (2.3 kg/cm², 33 psi) vehicles.

ERASE SELF-DIAGNOSIS

With CONSULT-III

1. Perform applicable inspection of malfunctioning item and then repair or replace.
2. Turn ignition switch ON and select "SELF-DIAG RESULTS" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Touch "ERASE" on CONSULT-III screen to erase memory.

Without CONSULT-III

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned ON and OFF.
- However, this information is erased by turning ignition switch OFF after performing self-diagnostic or by erasing the memory using the CONSULT-III.

AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000004346942

WORK SUPPORT MODE

ID Read

The registered ID number is displayed.

ID Regist

Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

SELF-DIAG RESULTS MODE

Operation Procedure

Refer to [WT-83, "DTC Index"](#).

DATA MONITOR MODE

Screen of data monitor mode is displayed.

NOTE:

When malfunction is detected, CONSULT-III perform REAL-TIME DIAGNOSIS. Also, any malfunction detected while in this mode will be displayed at real time.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >


DTC/CIRCUIT DIAGNOSIS

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

Description

INFOID:000000004346943

When the tire pressure monitoring system detects low inflation pressure, the low tire pressure warning lamps in the combination meter comes on.



DTC Logic

INFOID:000000004346944

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|--|----------------------|
| C1704 | LOW PRESSURE FL | Front LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | Tire pressure is low |
| C1705 | LOW PRESSURE FR | Front RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |
| C1706 | LOW PRESSURE RR | Rear RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |
| C1707 | LOW PRESSURE RL | Rear LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE] | |

*: 182.7 kPa (1.9 kg/cm², 26 psi): Standard air pressure is for 230 kPa (2.3 kg/cm², 33 psi) vehicles.

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

④ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self-diagnosis.

Is DTC "C1704", "C1705", "C1706", "C1707" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-17. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346945

1. CHECK TIRE AIR PRESSURE

1. Check all tire air pressures.
2. Adjust all tire air pressures. Refer to [WT-106. "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

- YES >> GO TO 2.
NO >> Inspect or replace malfunctioning parts.

2. CHECK AIR PRESSURE SIGNAL

1. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

| Monitored item | Condition | Display value |
|----------------|--|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for 10 minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts (tire or wheel). Refer to [WT-97, "Service Notice or Precautions"](#).

Special Repair Requirement

INFOID:000000004346946

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1708, C1709, C1710, C1711 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1708, C1709, C1710, C1711 TRANSMITTER

Description

INFOID:000000004346947

The transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

↔ : Outside



DTC Logic

INFOID:000000004346948

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1708 | [NO DATA] FL | Data from front LH transmitter can not receive. | <ul style="list-style-type: none"> • Harness or connector (Tire pressure receiver, BCM) • ID registration is not finished • Transmitter malfunction • BCM malfunction |
| C1709 | [NO DATA] FR | Data from front RH transmitter can not receive. | |
| C1710 | [NO DATA] RR | Data from rear RH transmitter can not receive. | |
| C1711 | [NO DATA] RL | Data from rear LH transmitter can not receive. | |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self-diagnosis.

Is DTC "C1708", "C1709", "C1710", "C1711" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-19, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346949

1. CHECK AIR PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", "AIR PRESS RL".

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Are all tire pressures displayed 0 kPa?

- YES >> GO TO 2.
 NO >> GO TO 4.

2. CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector and tire pressure receiver harness connector.

C1708, C1709, C1710, C1711 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |
| | 138 | | 4 | |
| | 139 | | 2 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |
| | 138 | | |
| | 139 | | |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace damaged parts.

3.CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to [WT-37, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.
- NO >> Replace the tire pressure receiver.

4.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

- YES >> GO TO 5.
- NO >> Replace malfunctioning transmitter.

5.CHECK TIRE PRESSURE MONITORING SYSTEM

Ⓜ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

| Monitored item | Condition | Display value |
|----------------|--|---|
| AIR PRESS FL | Start the engine and drive at 40 km/h (25MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace BCM.

Special Repair Requirement

INFOID:000000004346950

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

- YES >> GO TO 2.

C1708, C1709, C1710, C1711 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

C1712, C1713, C1714, C1715 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1712, C1713, C1714, C1715 TRANSMITTER

Description

INFOID:000000004346951

The transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

↔ : Outside



DTC Logic

INFOID:000000004346952

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible case |
|-------|-------------------|---|--|
| C1712 | [CHECKSUM ERR] FL | Checksum data from front LH transmitter is malfunction. | <ul style="list-style-type: none"> • Tire pressure receiver malfunction • Transmitter malfunction • BCM malfunction • Harness or connector |
| C1713 | [CHECKSUM ERR] FR | Checksum data from front RH transmitter is malfunction. | |
| C1714 | [CHECKSUM ERR] RR | Checksum data from rear RH transmitter is malfunction. | |
| C1715 | [CHECKSUM ERR] RL | Checksum data from rear LH transmitter is malfunction. | |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Driving at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self-diagnosis.

Is DTC "C1712", "C1713", "C1714", "C1715" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-22, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346953

1. CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
3. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition | Display value |
|----------------|--|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for 10 minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2. CHECK AIR PRESSURE SIGNAL

C1712, C1713, C1714, C1715 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

④ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Are all tire pressures displayed 0 kPa?

- YES >> GO TO 3.
NO >> GO TO 5.

3.CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector and tire pressure receiver harness connector.
3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |
| | 138 | | 4 | |
| | 139 | | 2 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |
| | 138 | | |
| | 139 | | |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace damaged parts.

4.CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to [WT-37. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.
NO >> Replace the tire pressure receiver.

5.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

- YES >> GO TO 6.
NO >> Replace malfunctioning transmitter.

6.CHECK TIRE PRESSURE MONITORING SYSTEM

④ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

C1712, C1713, C1714, C1715 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000004346954

1. CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2. PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1716, C1717, C1718, C1719 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1716, C1717, C1718, C1719 TRANSMITTER

Description

INFOID:000000004346955

The transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

↔ : Outside



DTC Logic

INFOID:000000004346956

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible case |
|-------|--------------------|--|--|
| C1716 | [PRESSDATA ERR] FL | Air pressure data from front LH transmitter malfunction. | <ul style="list-style-type: none"> • ID registration is not finished • Transmitter malfunction |
| C1717 | [PRESSDATA ERR] FR | Air pressure data from front RH transmitter malfunction. | |
| C1718 | [PRESSDATA ERR] RR | Air pressure data from rear RH transmitter malfunction. | |
| C1719 | [PRESSDATA ERR] RL | Air pressure data from rear LH transmitter malfunction. | |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

ⓐ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self- diagnosis.

Is DTC "C1716", "C1717", "C1718", "C1719" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-25. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346957

1. CHECK TIRE PRESSURE

ⓐ With CONSULT-III

1. Adjust tire pressure to specified value. Refer to [WT-106. "Tire Air Pressure"](#).
2. Perform the ID registration of all transmitters. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
3. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
4. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is tire pressure indicated as 438.60 kPa (4.47kg/cm², 63.60 psi) on the "DATA MONITOR" screen?

- YES >> Replace malfunctioning transmitter.
 NO >> GO TO 2.

2. CHECK TIRE PRESSURE MONITORING SYSTEM

C1716, C1717, C1718, C1719 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
3. Check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition | Display value |
|----------------|--|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for 10 minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform the self-diagnosis, inspect detected malfunction. Refer to [WT-13, "AIR PRESSURE MONITOR : Diagnosis Description"](#).

Component Inspection

INFOID:000000004346958

1.CHECK TRANSMITTER

Ⓜ With CONSULT-III

1. Adjust tire pressure to specified value. Refer to [WT-106, "Tire Air Pressure"](#).
2. Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
3. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
4. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

| Monitored item | Condition | Display value |
|-----------------|---|---|
| AIR PRESSURE FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESSURE FR | | |
| AIR PRESSURE RR | | |
| AIR PRESSURE RL | | |

Is tire pressure indicated as 438.60 kPa (4.47 kg/cm², 63.60 psi) on the "DATA MONITOR" screen?

YES >> Replace malfunctioning transmitter.

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000004346959

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1720, C1721, C1722, C1723 TRANSMITTER

Description

INFOID:000000004346960

The transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

↔ : Outside



DTC Logic

INFOID:000000004346961

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible case |
|-------|---------------|--|--|
| C1720 | [CODE ERR] FL | Function code data from front LH transmitter is malfunction. | <ul style="list-style-type: none"> • Tire pressure receiver malfunction • Transmitter malfunction • BCM malfunction • Harness or connector |
| C1721 | [CODE ERR] FR | Function code data from front RH transmitter is malfunction. | |
| C1722 | [CODE ERR] RR | Function code data from rear RH transmitter is malfunction. | |
| C1723 | [CODE ERR] RL | Function code data from rear LH transmitter is malfunction. | |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Driving at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self-diagnosis.

Is DTC "C1720", "C1721", "C1722", "C1723" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-27. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346962

1. CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.
3. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition | Display value |
|----------------|--|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for 10 minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2. CHECK ALL TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Are all tire pressure displayed 0 kPa?

- YES >> GO TO 3.
 NO >> GO TO 5.

3. CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector and tire pressure receiver harness connector.
3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |
| | 138 | | 4 | |
| | 139 | | 2 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |
| | 138 | | |
| | 139 | | |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace damage parts.

4. CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to [WT-37, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.
 NO >> Replace the tire pressure receiver.

5. CHECK TIRE PRESSURE MONITORING SYSTEM

 With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 6.
NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

6.CHECK TRANSMITTER

Ⓜ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes after stopped vehicle.

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace malfunction transmitter.

Special Repair Requirement

INFOID:000000004346963

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

- YES >> GO TO 2.
NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1724, C1725, C1726, C1727 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1724, C1725, C1726, C1727 TRANSMITTER

Description

INFOID:000000004346964

The transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

⇐ : Outside



DTC Logic

INFOID:000000004346965

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible case |
|-------|--------------------|--|---|
| C1724 | [BATT VOLT LOW] FL | Battery voltage of front LH transmitter drops. | <ul style="list-style-type: none">• Transmitter malfunction• Tire pressure receiver malfunction• BCM malfunction• Harness or connector |
| C1725 | [BATT VOLT LOW] FR | Battery voltage of front RH transmitter drops. | |
| C1726 | [BATT VOLT LOW] RR | Battery voltage of rear RH transmitter drops. | |
| C1727 | [BATT VOLT LOW] RL | Battery voltage of rear LH transmitter drops. | |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Driving at a speed of 40 km/h (25 MPH) or more for 10 minutes.
2. Perform BCM self-diagnosis.

Is DTC "C1724", "C1725", "C1726", "C1727" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-30. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346966

1. CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a 40 km/h (25 MPH) or more for 10 minutes.
3. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK AIR PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

C1724, C1725, C1726, C1727 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Are all tire pressures displayed 0 kPa?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector and tire pressure receiver harness connector.
3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |
| | 138 | | 4 | |
| | 139 | | 2 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |
| | 138 | | |
| | 139 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to [WT-37, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

NO >> Replace the tire pressure receiver.

5. CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> Replace malfunctioning transmitter.

6. CHECK TIRE PRESSURE MONITORING SYSTEM

④ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

C1724, C1725, C1726, C1727 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at a 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000004346967

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106. "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1729 VEHICLE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

C1729 VEHICLE SPEED SIGNAL

Description

INFOID:000000004346968

BCM detects no vehicle speed signal.

DTC Logic

INFOID:000000004346969

DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition | Possible case |
|------------|------------------------|-----------------------------|---|
| C1729 | VHCL SPEED SIG ERR | Vehicle speed signal error. | <ul style="list-style-type: none">CAN communication errorUnified meter and A/C amp. mal-function |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

④ With CONSULT-III

- Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
- Perform BCM self-diagnosis.

Is DTC "C1729" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-33, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346970

1. CHECK UNIFIED METER AND A/C AMP. SELF-DIAGNOSIS

④ With CONSULT-III

Perform unified meter and A/C amp. self-diagnosis.

Is any DTC detected?

- YES >> Check the DTC.
NO >> Check unified meter and A/C amp. [HAC-102, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004346971

1. CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106, "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

- YES >> GO TO 2.
NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2. PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

C1734 BCM


< DTC/CIRCUIT DIAGNOSIS >

C1734 BCM

Description

INFOID:000000004346972

The BCM (1) reads the air pressure signal received by the tire pressure receiver, and controls the low tire pressure warning lamp and the buzzer operations. It also has a judgment function to detect a system malfunction.



DTC Logic

INFOID:000000004346973

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible case |
|-------|--------------|--|-----------------|
| C1734 | CONTROL UNIT | Tire pressure monitoring system malfunction in BCM | BCM malfunction |

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓟ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Perform BCM self-diagnosis with CONSULT-III "DATA MONITOR" within 15 minutes after stopped vehicle.

Is DTC "C1734" detected?

- YES >> Proceed to diagnosis procedure. Refer to [WT-34, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004346974

1. CHECK SELF-DIAGNOSTIC RESULTS

Ⓟ With CONSULT-III

1. On "SELECT DIAG" mode, select the "SELF-DIAG RESULT" screen.
2. Check display contents in self-diagnostic results.

Does self-diagnostic results indicate any malfunction?

- YES >> Perform trouble diagnosis. Refer to [WT-83, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK BCM POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check voltage between BCM harness connector terminals and ground.

| BCM | | — | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| M118 | 1 | Ground | Battery voltage |
| M119 | 11 | | |

Is the power supply normal?

- YES >> GO TO 3.
NO >> Check the following. If any items are damaged, repair or replace damage parts.
 - 40A fusible link [No. K located in the fuse block]. Refer to [PG-100, "Fuse and Fusible Link Arrangement"](#).

C1734 BCM

< DTC/CIRCUIT DIAGNOSIS >

- 10A fuse [No. 10 located in the fuse block (J/B)]. Refer to [PG-99. "Fuse, Connector and Terminal Arrangement"](#).
- Harness for short or open between battery and BCM harness connector M118 terminal 1.
- Harness for short or open between battery and BCM harness connector M119 terminal 11.
- Check Battery voltage.

3.CHECK BCM GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M119 | 13 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to power in harness or connectors.

4.CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Disconnect tire pressure receiver harness connector.
2. Check continuity between BCM harness connector and tire pressure receiver harness connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |
| | 138 | | 4 | |
| | 139 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |
| | 138 | | |
| | 139 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK BCM

Check BCM input/output signal. Refer to [WT-49. "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

6.CHECK BCM HARNESS CONNECTOR

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).

NO >> Repair or replace damaged parts.

Special Repair Requirement

INFOID:000000004346975

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-106. "Tire Air Pressure"](#).

Does all tire pressure data meet the specification?

C1734 BCM

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

>> END

TIRE PRESSURE RECEIVER


< DTC/CIRCUIT DIAGNOSIS >

TIRE PRESSURE RECEIVER

Description

INFOID:000000004346976

The tire pressure receiver (1) receives the air pressure signal transmitted by the transmitter in each wheel.



Component Function Check

INFOID:000000004346977

1. TIRE PRESSURE MONITORING SYSTEM OPERATION

Ⓜ With CONSULT-III

1. Drive at a speed 40 km/h (25 MPH) or more for 10 minutes.
2. Check tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start engine and drive at a 40 km/h (25MPH) or more for 10 minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> Perform BCM self-diagnosis. Refer to [WT-83, "DTC Index"](#).

NO-2 >> Proceed to diagnosis procedure. Refer to [WT-37, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004346978

1. CHECK TIRE PRESSURE RECEIVER SIGNAL

1. Turn the ignition switch ON.



CAUTION:

Never start the engine.

2. Check tire pressure receiver connector and ground signal with oscilloscope.

TIRE PRESSURE RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

| Tire pressure receiver | | — | Condition | Voltage (Approx.) |
|------------------------|----------|--------|--|---|
| Connector | Terminal | | | |
| M101 | 2 | Ground | Standby state |  OCC3881D |
| | | | When receiving the signal from the transmitter |  OCC3880D |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> GO TO 2.

2. CHECK TIRE PRESSURE RECEIVER INPUT VOLTAGE

1. Disconnect tire pressure receiver connector.
2. Check voltage between tire pressure receiver connector and ground.

| Tire pressure receiver | | — | Voltage (Approx.) |
|------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M101 | 4 | Ground | 5.0 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check BCM harness and connector.

3. CHECK TIRE PRESSURE RECEIVER GROUND CIRCUIT

1. Disconnect BCM harness connector.
2. Check continuity between BCM harness connector and tire pressure receiver connector.

| BCM | | Tire pressure receiver | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 137 | M101 | 1 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 137 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace damaged parts.

4. CHECK BCM CIRCUIT

Inspect the BCM circuit. Refer to [BCS-41, "Diagnosis Procedure"](#).

Is the BCM circuit normal?

- YES >> Replace tire pressure receiver.

TIRE PRESSURE RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

TIRE PRESSURE WARNING CHECK SWITCH

< DTC/CIRCUIT DIAGNOSIS >


TIRE PRESSURE WARNING CHECK SWITCH

Description

INFOID:000000004346979

The following item can be checked by grounding the tire pressure warning check switch harness connector terminal (1).


- The low tire pressure warning lamp in the combination meter blink according to the self-diagnostic results.



NOTE:

If low tire pressure warning lamp blinks as shown in the figure, the system is normal.

- This mode shows transmitter status is in OFF-mode.
Perform transmitter wake up operation. Refer to [WT-6, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



Component Function Check

INFOID:000000004346980

1. CHECK LOW TIRE PRESSURE WARNING LAMP OPERATION

Check if low tire pressure warning lamp blinks 1 second and then goes off after turning ignition switch ON.

Is inspection result normal?

YES >> GO TO 2.

NO >> Check low tire pressure warning lamp. Refer to [WT-42, "Diagnosis Procedure"](#).

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH OPERATION

1. Ground the tire pressure warning check switch harness connector terminal.

2. Check the low tire pressure warning lamp blinks.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [WT-40, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004346981

1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check voltage between tire pressure warning check switch connector and ground.

| Tire pressure warning check switch | | — | Voltage (Approx.) |
|------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M23 | 1 | Ground | 11.8 V |

Is the inspection result normal?

TIRE PRESSURE WARNING CHECK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector
3. Check continuity between BCM harness connector and tire pressure warning check switch connector.

| BCM | | Tire pressure warning check switch | | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | Existed |
| M123 | 149 | M23 | 1 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 149 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK BCM

Check BCM input/output signal. Refer to [WT-49, "Reference Value"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

LOW TIRE PRESSURE WARNING LAMP


< DTC/CIRCUIT DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP

Description

INFOID:000000004346982

The combination meter receives tire pressure status from the unified meter and A/C amp. via CAN communication.
When BCM judges from a transmitter signal that tire pressure is insufficient, BCM transmits a signal to unified meter and A/C amp. via CAN communication. unified meter and A/C amp. turns on the low tire pressure warning lamp mounted on the combination meter.



| Condition | Low tire pressure warning lamp |
|---|--|
| Ignition switch OFF | OFF |
| Ignition switch ON | Warning lamp turns on for 1second, then turns off. |
| Less than 182.7 kPa (1.9 kg/cm ² , 26 psi) [NOTE] | ON |
| Tire pressure monitoring system malfunction [Other diagnostic item] | Warning lamp blinks 1 min, then turns on. |

NOTE: Standard air pressure is for 230 kPa (2.3 kg/cm², 33 psi) vehicles.

Component Function Check

INFOID:000000004346983

1.CHECK LOW TIRE PRESSURE WARNING LAMP

Check if low tire pressure warning lamp blinks for 1 second and then goes off after turning the ignition switch ON.

Is inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [WT-42. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004346984

1.CHECK SELF DIAGNOSTIC RESULTS

Perform self-diagnosis of tire pressure monitoring system.

Is inspection result normal?

YES >> GO TO 2.

NO >> Check the DTC.

2.CHECK LOW TIRE PRESSURE WARNING LAMP

Check if low tire pressure warning lamp blinks 1 second and then goes off after turning the ignition switch ON.

Is inspection result normal?

YES >> INSPECTION END

NO >> Check combination meter.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000004346985

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Signal name | Fuse and fusible link No. |
|----------------------|---------------------------|
| Battery power supply | K |
| | 10 |

Is the fuse fusing?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connectors.
- Check voltage between BCM harness connector and ground.

| Terminals | | Voltage (Approx.) |
|-----------|----------|-------------------------------|
| (+) | (-) | |
| BCM | | Ground Battery voltage |
| Connector | Terminal | |
| M118 | 1 | |
| M119 | 11 | |

Is the measurement value normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M119 | 13 | | Existed |

Does continuity exist?

- YES >> INSPECTION END
NO >> Repair harness or connector.

UNIFIED METER AND A/C AMP.

UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000004346986

1. CHECK FUSE

Check for blown fuses.

| Power source | Fuse No. |
|-----------------------------|----------|
| Battery | 6 |
| Ignition switch ACC or ON | 19 |
| Ignition switch ON or START | 3 |

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector and ground.

| Terminals | | | Ignition switch position | Value (Approx.) |
|----------------------------|----------|----------------------|--------------------------|-----------------|
| (+) | | (-) | | |
| Unified meter and A/C amp. | Terminal | | Signal name | |
| M67 | 54 | Battery power supply | OFF | Battery voltage |
| | 41 | ACC power supply | ACC | Battery voltage |
| | 53 | Ignition signal | ON | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector and ground.

| Unified meter and A/C amp. | | Ground | Continuity |
|----------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M67 | 55 | | Existed |
| | 71 | | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.


TPMS

< DTC/CIRCUIT DIAGNOSIS >

TPMS

Wiring Diagram - TIRE PRESSURE MONITORING SYSTEM -

INFOID:000000004346987



2008/08/28


JCEWA0087GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT


TIRE PRESSURE MONITORING SYSTEM

| | |
|----------------|-----------------|
| Connector No. | E106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-GS16-TM4 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 91 | W | |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1A | GR | |
| 2A | G | |
| 7A | R | |

| | |
|----------------|-----------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MM-CS16-TM4 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 91 | W | |

| | |
|----------------|------------------------------------|
| Connector No. | M23 |
| Connector Name | TIRE PRESSURE WARNING CHECK SWITCH |
| Connector Type | TK02FW |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | |

| | |
|----------------|---------------------|
| Connector No. | M24 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 6 | L | |
| 14 | P | |

| | |
|----------------|-------------------|
| Connector No. | M53 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | LG | COMM (METER->AMP.) |
| 3 | GR | COMM (AMP->METER) |
| 24 | BR | COMM (LCD->AMP.) |
| 25 | Y | COMM (AMP->LCD) |

| | |
|----------------|----------------------------|
| Connector No. | M66 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH40FW-NH |



| | | |
|--------------|---------------|------------------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 7 | GR | COMMUNICATION SIGNAL (AMP->METER) |
| 14 | BR | COMMUNICATION SIGNAL (LCD->AMP.) |
| 27 | LG | COMMUNICATION SIGNAL (METER->AMP.) |
| 34 | Y | COMMUNICATION SIGNAL (AMP->LCD) |


| | |
|----------------|----------------------------|
| Connector No. | M67 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH32FW-NH |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 53 | G | IGNITION POWER SUPPLY |
| 54 | Y | BATTERY POWER SUPPLY |
| 55 | B | GROUND |
| 56 | L | CAN-H |
| 71 | B | GROUND |
| 72 | P | CAN-L |


TIRE PRESSURE MONITORING SYSTEM

| | |
|----------------|--------------------------------|
| Connector No. | M83 |
| Connector Name | AV CONTROL UNIT (WITHOUT NAVI) |
| Connector Type | TH24FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 44 | BR | COMM (DISP->CONT) |
| 55 | SHIELD | SHIELD |
| 56 | Y | COMM (CONT->DISP) |

| | |
|----------------|--------------------------------|
| Connector No. | M85 |
| Connector Name | AV CONTROL UNIT (WITHOUT NAVI) |
| Connector Type | TH32FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 86 | L | CAN-H |
| 87 | P | CAN-L |

| | |
|----------------|-----------------------------|
| Connector No. | M87 |
| Connector Name | AV CONTROL UNIT (WITH NAVI) |
| Connector Type | TH40FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 52 | L | CAN-H |
| 53 | P | CAN-L |

| | |
|----------------|-----------------------------|
| Connector No. | M88 |
| Connector Name | AV CONTROL UNIT (WITH NAVI) |
| Connector Type | TH12FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 70 | BR | COMM (CONT->DISP) |
| 71 | Y | COMM (DISP->CONT) |
| 72 | SHIELD | SHIELD |

| | |
|----------------|------------------------|
| Connector No. | M101 |
| Connector Name | TIRE PRESSURE RECEIVER |
| Connector Type | TK04FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | GND |
| 2 | L | SIGNAL |
| 4 | Y | BATTERY |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | MS03FB-LC |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | BAT (F/L) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | MS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11 | R | BAT (FUSE) |
| 13 | B | GND |


| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 90 | P | CAN-L |
| 91 | L | CAN-H |

TIRE PRESSURE MONITORING SYSTEM

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | THRUFG-NH |



| Terminal No. | Color of Wire | Signal Name (Specification) |
|--------------|---------------|------------------------------|
| 137 | O | RECEIVER SENSOR GND |
| 138 | Y | RECEIVER SENSOR POWER SUPPLY |
| 139 | L | TIRE PRESSURE RECEIVER COMM |
| 149 | W | TIRE PRESS WARNING CHECK SW |

JCEWA0090GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004919766

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------------|
| FR WIPER HI | Other than front wiper switch HI | Off |
| | Front wiper switch HI | On |
| FR WIPER LOW | Other than front wiper switch LO | Off |
| | Front wiper switch LO | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER INT | Other than front wiper switch INT | Off |
| | Front wiper switch INT | On |
| FR WIPER STOP | Front wiper is not in STOP position | Off |
| | Front wiper is in STOP position | On |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | Wiper intermittent dial position |
| RR WIPER ON | Other than rear wiper switch ON | Off |
| | Rear wiper switch ON | On |
| RR WIPER INT | Other than rear wiper switch INT | Off |
| | Rear wiper switch INT | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER STOP | Rear wiper is in STOP position | Off |
| | Rear wiper is not in STOP position | On |
| TURN SIGNAL R | Other than turn signal switch RH | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Other than turn signal switch LH | Off |
| | Turn signal switch LH | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| HI BEAM SW | Other than lighting switch HI | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|---------------|--|--------------|
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off |
| DOOR SW-DR | Driver door closed | Off |
| | Driver door opened | On |
| DOOR SW-AS | Passenger door closed | Off |
| | Passenger door opened | On |
| DOOR SW-RR | Rear RH door closed | Off |
| | Rear RH door opened | On |
| DOOR SW-RL | Rear LH door closed | Off |
| | Rear LH door opened | On |
| DOOR SW-BK | Back door closed | Off |
| | Back door opened | On |
| CDL LOCK SW | Other than power door lock switch LOCK | Off |
| | Power door lock switch LOCK | On |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | Off |
| | Power door lock switch UNLOCK | On |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off |
| | Driver door key cylinder LOCK position | On |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off |
| | Driver door key cylinder UNLOCK position | On |
| KEY CYL SW-TR | NOTE: The item is indicated, but not monitored. | Off |
| HAZARD SW | Hazard switch is OFF | Off |
| | Hazard switch is ON | On |
| REAR DEF SW | NOTE: The item is indicated, but not monitored. | Off |
| TR CANCEL SW | NOTE: The item is indicated, but not monitored. | Off |
| TR/BD OPEN SW | Back door opener switch OFF | Off |
| | While the back door opener switch is turned ON | On |
| TRNK/HAT MNTR | NOTE: The item is indicated, but not monitored. | Off |
| RKE-LOCK | LOCK button of the key is not pressed | Off |
| | LOCK button of the key is pressed | On |
| RKE-UNLOCK | UNLOCK button of the key is not pressed | Off |
| | UNLOCK button of the key is pressed | On |
| RKE-TR/BD | NOTE: The item is indicated, but not monitored. | Off |
| RKE-PANIC | PANIC button of the key is not pressed | Off |
| | PANIC button of the key is pressed | On |
| RKE-P/W OPEN | UNLOCK button of the key is not pressed | Off |
| | UNLOCK button of the key is pressed and held | On |
| RKE-MODE CHG | LOCK/UNLOCK button of the key is not pressed and held simultaneously | Off |
| | LOCK/UNLOCK button of the key is pressed and held simultaneously | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|----------------|--|--------------|----|
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V | A |
| | Dark outside of the vehicle | Close to 0 V | |
| REQ SW -DR | Driver door request switch is not pressed | Off | B |
| | Driver door request switch is pressed | On | |
| REQ SW -AS | Passenger door request switch is not pressed | Off | C |
| | Passenger door request switch is pressed | On | |
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off | D |
| REQ SW -RL | NOTE: The item is indicated, but not monitored. | Off | |
| REQ SW -BD/TR | Back door request switch is not pressed | Off | WT |
| | Back door request switch is pressed | On | |
| PUSH SW | Push-button ignition switch (push switch) is not pressed | Off | F |
| | Push-button ignition switch (push switch) is pressed | On | |
| IGN RLY2 -F/B | Ignition switch in OFF or ACC position | Off | G |
| | Ignition switch in ON position | On | |
| ACC RLY -F/B | NOTE: The item is indicated, but not monitored. | Off | |
| CLUCH SW | NOTE: The item is indicated, but not monitored. | Off | H |
| BRAKE SW 1 | The brake pedal is depressed when No. 7 fuse is blown | Off | I |
| | The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal | On | |
| BRAKE SW 2 | The brake pedal is not depressed | Off | J |
| | The brake pedal is depressed | On | |
| DETE/CANCL SW | Selector lever in P position | Off | K |
| | Selector lever in any position other than P | On | |
| SFT PN/N SW | Selector lever in any position other than P and N | Off | L |
| | Selector lever in P or N position | On | |
| S/L -LOCK | Steering is unlocked | Off | M |
| | Steering is locked | On | |
| S/L -UNLOCK | Steering is locked | Off | N |
| | Steering is unlocked | On | |
| S/L RELAY-F/B | Ignition switch in OFF or ACC position | Off | O |
| | Ignition switch in ON position | On | |
| UNLK SEN -DR | Driver door is unlocked | Off | P |
| | Driver door is locked | On | |
| PUSH SW -IPDM | Push-button ignition switch (push-switch) is not pressed | Off | |
| | Push-button ignition switch (push-switch) is pressed | On | |
| IGN RLY1 -F/B | Ignition switch in OFF or ACC position | Off | |
| | Ignition switch in ON position | On | |
| DETE SW -IPDM | Selector lever in any position other than P | Off | |
| | Selector lever in P position | On | |
| SFT PN -IPDM | Selector lever in any position other than P and N | Off | |
| | Selector lever in P or N position | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|---|-----------------------------------|
| SFT P -MET | Selector lever in any position other than P | Off |
| | Selector lever in P position | On |
| SFT N -MET | Selector lever in any position other than N | Off |
| | Selector lever in N position | On |
| ENGINE STATE | Engine stopped | Stop |
| | While the engine stalls | Stall |
| | At engine cranking | Crank |
| | Engine running | Run |
| S/L LOCK-IPDM | Steering is unlocked | Off |
| | Steering is locked | On |
| S/L UNLK-IPDM | Steering is locked | Off |
| | Steering is unlocked | On |
| S/L RELAY-REQ | Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK. | Off |
| | Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK. | On |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading |
| DOOR STAT-DR | Driver door is locked | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Driver door is unlocked | UNLOCK |
| DOOR STAT-AS | Passenger door is locked | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Passenger door is unlocked | UNLOCK |
| ID OK FLAG | Steering is locked | Reset |
| | Steering is unlocked | Set |
| PRMT ENG STRT | The engine start is prohibited | Reset |
| | The engine start is permitted | Set |
| PRMT RKE STRT | NOTE: The item is indicated, but not monitored. | Reset |
| KEY SW -SLOT | The key is not inserted into key slot | Off |
| | The key is inserted into key slot | On |
| RKE OPE COUN1 | During the operation of the key | Operation frequency of the key |
| RKE OPE COUN2 | NOTE: The item is indicated, but not monitored. | — |
| CONFIRM ID ALL | The key ID that the key slot receives does not accord with any key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with any key ID registered to BCM. | Done |
| CONFIRM ID4 | The key ID that the key slot receives does not accord with the fourth key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with the fourth key ID registered to BCM. | Done |
| CONFIRM ID3 | The key ID that the key slot receives does not accord with the third key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with the third key ID registered to BCM. | Done |

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|--------------|---|-------------------------------|----|
| CONFIRM ID2 | The key ID that the key slot receives does not accord with the second key ID registered to BCM. | Yet | A |
| | The key ID that the key slot receives accords with the second key ID registered to BCM. | Done | B |
| CONFIRM ID1 | The key ID that the key slot receives does not accord with the first key ID registered to BCM. | Yet | C |
| | The key ID that the key slot receives accords with the first key ID registered to BCM. | Done | |
| TP 4 | The ID of fourth key is not registered to BCM | Yet | D |
| | The ID of fourth key is registered to BCM | Done | |
| TP 3 | The ID of third key is not registered to BCM | Yet | WT |
| | The ID of third key is registered to BCM | Done | |
| TP 2 | The ID of second key is not registered to BCM | Yet | |
| | The ID of second key is registered to BCM | Done | |
| TP 1 | The ID of first key is not registered to BCM | Yet | F |
| | The ID of first key is registered to BCM | Done | |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front LH tire | G |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front RH tire | H |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear RH tire | I |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear LH tire | |
| ID REGST FL1 | ID of front LH tire transmitter is registered | Done | |
| | ID of front LH tire transmitter is not registered | Yet | J |
| ID REGST FR1 | ID of front RH tire transmitter is registered | Done | |
| | ID of front RH tire transmitter is not registered | Yet | |
| ID REGST RR1 | ID of rear RH tire transmitter is registered | Done | K |
| | ID of rear RH tire transmitter is not registered | Yet | |
| ID REGST RL1 | ID of rear LH tire transmitter is registered | Done | L |
| | ID of rear LH tire transmitter is not registered | Yet | |
| WARNING LAMP | Tire pressure indicator OFF | Off | |
| | Tire pressure indicator ON | On | M |
| BUZZER | Tire pressure warning alarm is not sounding | Off | |
| | Tire pressure warning alarm is sounding | On | N |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


TERMINAL LAYOUT



PHYSICAL VALUES

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) | |
|------------------------------|--------|---|--------|---|--|---|----|
| | | | | | | | |
| + | - | | | | | | |
| 1 (W) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage | A |
| 2 (Y) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | | Battery voltage | B |
| 3 (O) | Ground | P/W power supply (RAP) | Output | Ignition switch ON | | Battery voltage | C |
| 4 (LG) | Ground | Interior room lamp power supply | Output | Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply) | | 0 V | D |
| | | | | Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply) | | Battery voltage | WT |
| 5 (L) | Ground | Passenger door UN- LOCK | Output | Passenger door | UNLOCK (Actuator is activated) | Battery voltage | F |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V | |
| 7 (Y) | Ground | Step lamp | Output | Step lamp | ON | 0 V | G |
| | | | | | | OFF | |
| 8 (V) | Ground | All doors, fuel lid LOCK | Output | All doors | LOCK (Actuator is activated) | Battery voltage | H |
| | | | | | | Other than LOCK (Actuator is not activated) | |
| 9 (G) | Ground | Driver door, fuel lid UNLOCK | Output | Driver door | UNLOCK (Actuator is activated) | Battery voltage | I |
| | | | | | | Other than UNLOCK (Actuator is not activated) | |
| 10 (BR) | Ground | Rear RH door and rear LH door UN- LOCK | Output | Rear RH door and rear LH door | UNLOCK (Actuator is activated) | Battery voltage | J |
| | | | | | | Other than UNLOCK (Actuator is not activated) | |
| 11 (R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage | L |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0 V | |
| 14 (W) | Ground | Push-button ignition switch illumination ground | Output | Tail lamp | OFF | 0 V | M |
| | | | | | ON | NOTE: When the illumination brightening/dimming level is in the neutral position  | |
| 15 (Y) | Ground | ACC indicator lamp | Output | Ignition switch | OFF or ON | Battery voltage | O |
| | | | | | ACC | 0 V | |

JSNIA0010GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------|------------------|--|---|-----------------|
| + | - | Signal name | Input/ Output | | | |
| 17 (W) | Ground | Turn signal RH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch RH |  <p style="text-align: right; font-size: small;">PKID0926E</p> | 6.5 V |
| 18 (O) | Ground | Turn signal LH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch LH |  <p style="text-align: right; font-size: small;">PKID0926E</p> | 6.5 V |
| 19 (V) | Ground | Room lamp timer control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | ON | 0 V | |
| 20 (V) | Ground | Turn signal RH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch RH |  <p style="text-align: right; font-size: small;">PKID0926E</p> | 6.5 V |
| 23 (G) | Ground | Back door open | Output | Back door | OPEN (Back door opener actuator is activated) | Battery voltage |
| | | | | Other than OPEN (Back door opener actuator is not activated) | 0 V | |
| 25 (G) | Ground | Turn signal LH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch LH |  <p style="text-align: right; font-size: small;">PKID0926E</p> | 6.5 V |
| 26 (G) | Ground | Rear wiper | Output | Rear wiper | OFF (Stopped) | 0 V |
| | | | | ON (Operated) | Battery voltage | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 34 (SB) | Ground | Luggage room antenna (-) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compartment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 35 (V) | Ground | Luggage room antenna (+) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compartment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 38 (B) | Ground | Back door antenna (-) | Output | When the back door opener request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

A

B

C

D

WT

F

G

H

I

J

K

L

M





N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 39 (W) | Ground | Back door antenna (+) | Output | When the back door opener re- quest switch is operated with ig- nition switch OFF | When Intelligent Key is in the antenna detection area |  |
| | | | | | When Intelligent Key is not in the antenna detection area |  |
| 47 (Y) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 V |
| 52 (SB) | Ground | Starter relay control | Output | Ignition switch ON | When selector lever is in P or N position | Battery voltage |
| | | | | | When selector lever is not in P or N position | 0 V |
| 61 (W) | Ground | Back door opener re- quest switch | Input | Back door opener request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: center;">1.0 V</p> |
| 64 (V) | Ground | Intelligent Key warn- ing buzzer (Engine room) | Output | Intelligent Key warning buzzer (Engine room) | Sounding | 0 V |
| | | | | | Not sounding | Battery voltage |
| 65 (O) | Ground | Rear wiper stop posi- tion | Input | Rear wiper | In stop position |  <p style="text-align: center;">1.0 V</p> |
| | | | | | Not in stop position | 0 V |

BCM (BODY CONTROL MODULE)







< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------|------------------|-------------------------|---|
| | | Signal name | Input/ Output | | |
| + | - | | | | |
| 66 (R) | Ground | Back door switch | Input | Back door switch |  <p style="text-align: center;">11.8 V</p> |
| | | | | ON (Door open) | 0 V |
| 67 (G) | Ground | Back door opener switch | Input | Back door opener switch |  <p style="text-align: center;">11.8 V</p> |
| | | | | Pressed | 0 V |
| 68 (BR) | Ground | Rear RH door switch | Input | Rear RH door switch |  <p style="text-align: center;">11.8 V</p> |
| | | | | ON (Door open) | 0 V |
| 69 (R) | Ground | Rear LH door switch | Input | Rear LH door switch |  <p style="text-align: center;">11.8 V</p> |
| | | | | ON (Door open) | 0 V |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|
| + | - | Signal name | Input/ Output | | |
| 72 (R) | Ground | Room antenna 2 (-) (Center console) | Output | Ignition switch OFF | <p>When Intelligent Key is in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | <p>When Intelligent Key is not in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 73 (G) | Ground | Room antenna 2 (+) (Center console) | Output | Ignition switch OFF | <p>When Intelligent Key is in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | <p>When Intelligent Key is not in the passenger compartment</p>  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 74 (SB) | Ground | Passenger door antenna (-) | Output | When the passenger door request switch is operated with ignition switch OFF | <p>When Intelligent Key is in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | <p>When Intelligent Key is not in the antenna detection area</p>  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 75 (GR) | Ground | Passenger door antenna (+) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 76 (V) | Ground | Driver door antenna (-) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 77 (LG) | Ground | Driver door antenna (+) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

A

B

C

D

WT

F

G

H

I

J

K

L

M





N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|------------------------|---|---|
| + | - | Signal name | Input/ Output | | | |
| 78 (Y) | Ground | Room antenna 1 (-) (Instrument panel) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 79 (BR) | Ground | Room antenna 1 (+) (Instrument panel) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 80 (GR) | Ground | NATS antenna amp (Built in key slot) | Input/ Output | During waiting | Ignition switch is pressed while inserting the key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 81 (W) | Ground | NATS antenna amp (Built in key slot) | Input/ Output | During waiting | Ignition switch is pressed while inserting the key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 82 (R) | Ground | Ignition relay [Fuse block (J/B)] control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | ON | Battery voltage | |

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|---|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 83 (Y) | Ground | Remote keyless entry receiver communication | Input/ Output | During waiting | <p style="text-align: right; font-size: small;">JMKIA0064GB</p> |
| | | | | When operating either button on the key | <p style="text-align: right; font-size: small;">JMKIA0065GB</p> |
| 87 (BR) | Ground | Combination switch INPUT 5 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Front fog lamp switch ON (Wiper intermittent dial 4) <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|---|--|---|
| + | - | Signal name | Input/ Output | | | |
| 88 (V) | Ground | Combination switch INPUT 3 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  <p style="text-align: right;">JPMIA0041GB 1.4 V</p> |
| | | | | | Lighting switch HI (Wiper intermittent dial 4) |  <p style="text-align: right;">JPMIA0036GB 1.3 V</p> |
| | | | | | Lighting switch 2ND (Wiper intermittent dial 4) |  <p style="text-align: right;">JPMIA0037GB 1.3 V</p> |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) |  <p style="text-align: right;">JPMIA0039GB 1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF |  <p style="text-align: right;">JPMIA0040GB 1.3 V</p> |
| 89 (BR) | Ground | Push-button ignition switch (Push switch) | Input | Push-button igni- tion switch (push switch) | Pressed | 0 V |
| | | | | | Not pressed | Battery voltage |
| 90 (P) | Ground | CAN-L | Input/ Output | — | — | |
| 91 (L) | Ground | CAN-H | Input/ Output | — | — | |

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|-------------------------------|---------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 92 (LG) | Ground | Key slot illumination | Output | Key slot illumination | OFF | 0 V |
| | | | | | Blinking |  <p style="text-align: center;">6.5 V</p> |
| 93 (V) | Ground | ON indicator lamp | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 V |
| 94 (Y) | Ground | Puddle lamp control | Output | Puddle lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 95 (O) | Ground | ACC relay control | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | Battery voltage |
| 96 (GR) | Ground | A/T shift selector (Detention switch) power supply | Output | — | Battery voltage | |
| 97 (L) | Ground | Steering lock condition No. 1 | Input | Steering lock | LOCK status | 0 V |
| | | | | | UNLOCK status | Battery voltage |
| 98 (P) | Ground | Steering lock condition No. 2 | Input | Steering lock | LOCK status | Battery voltage |
| | | | | | UNLOCK status | 0 V |
| 99 (R) | Ground | Selector lever P position switch | Input | Selector lever | P position | 0 V |
| | | | | | Any position other than P | Battery voltage |
| 100 (G) | Ground | Passenger door request switch | Input | Passenger door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: center;">1.0 V</p> |
| 101 (SB) | Ground | Driver door request switch | Input | Driver door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: center;">1.0 V</p> |
| 102 (O) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|------------------------|---|
| + | - | Signal name | Input/ Output | | | |
| 103 (LG) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | | Battery voltage |
| 106 (W) | Ground | Steering lock unit power supply | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 V |
| 107 (LG) | Ground | Combination switch INPUT 1 | Input | Combination switch (Wiper intermittent dial 4) | All switches OFF |  <p style="text-align: right; margin-right: 20px;">JPMIA0041GB</p> |
| | | | | | Turn signal switch LH |  <p style="text-align: right; margin-right: 20px;">JPMIA0037GB</p> |
| | | | | | Turn signal switch RH |  <p style="text-align: right; margin-right: 20px;">JPMIA0036GB</p> |
| | | | | | Front wiper switch LO |  <p style="text-align: right; margin-right: 20px;">JPMIA0038GB</p> |
| | | | | | Front washer switch ON |  <p style="text-align: right; margin-right: 20px;">JPMIA0039GB</p> |

BCM (BODY CONTROL MODULE)







< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 108 (R) | Ground | Combination switch INPUT 4 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  <p style="text-align: right;">1.4 V</p> |
| | | | | | Lighting switch AUTO (Wiper intermittent dial 4) |  <p style="text-align: right;">1.3 V</p> |
| | | | | | Lighting switch 1ST (Wiper intermittent dial 4) |  <p style="text-align: right;">1.3 V</p> |
| | | | | | Rear wiper switch INT (Wiper intermittent dial 4) |  <p style="text-align: right;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF |  <p style="text-align: right;">1.3 V</p> |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|--|------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 109 (Y) | Ground | Combination switch INPUT 2 | Input | Combination switch (Wiper intermittent dial 4) | All switches OFF |  <p style="text-align: right;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Lighting switch PASS |  <p style="text-align: right;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Lighting switch 2ND |  <p style="text-align: right;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch INT |  <p style="text-align: right;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch HI |  <p style="text-align: right;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |
| 110 (G) | Ground | Hazard switch | Input | Hazard switch | ON | 0 V |
| | | | | | OFF |  <p style="text-align: right;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p> |

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|---|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 111 (Y) | Ground | Steering lock unit communication | Input/ Output | Steering lock | LOCK status | Battery voltage |
| | | | | | LOCK or UNLOCK | <p style="text-align: right; font-size: small;">JMKIA0066GB</p> |
| | | | | | For 15 seconds after UN- LOCK | Battery voltage |
| | | | | | 15 seconds or later after UNLOCK | 0 V |
| 113 (P) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle | Close to 5 V |
| | | | | When dark outside of the vehicle | Close to 0 V | |
| 116 (SB) | Ground | Stop lamp switch 1 | Input | — | Battery voltage | |
| 118 (P) | Ground | Stop lamp switch 2 (Without ICC) | Input | Stop lamp switch | OFF (Brake pedal is not depressed) | 0 V |
| | | | | | ON (Brake pedal is de- pressed) | Battery voltage |
| | | Stop lamp switch 2 (With ICC) | | Stop lamp switch OFF (Brake pedal is not de- pressed) and ICC brake hold relay OFF | 0 V | |
| | | | | Stop lamp switch ON (Brake pedal is de- pressed) or ICC brake hold relay ON | Battery voltage | |
| 119 (SB) | Ground | Front door lock as- sembly driver side (Unlock sensor) | Input | Driver door | LOCK status (Unlock sensor switch OFF) | <p style="text-align: right; font-size: small;">JPMIA0012GB</p> |
| | | | | | UNLOCK status (Unlock switch sensor ON) | 0 V |
| | | | | | 1.1 V | |
| 121 (BR) | Ground | Key slot switch | Input | When the key is inserted into key slot | Battery voltage | |
| | | | | When the key is not inserted into key slot | 0 V | |
| 123 (W) | Ground | IGN feedback | Input | Ignition switch | OFF or ACC | 0 V |
| | | | | ON | Battery voltage | |

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|--|---|---|
| + | - | Signal name | Input/ Output | | | |
| 124 (LG) | Ground | Passenger door switch | Input | Passenger door switch | OFF (Door close) |  <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p> |
| | | | | | ON (Door open) | 0 V |
| 132 (V) | Ground | Power window switch communication | Input/ Output | Ignition switch ON |  <p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p> | |
| | | | | | Ignition switch OFF or ACC | Battery voltage |
| 133 (W) | Ground | Push-button ignition switch illumination | Output | Push-button igni- tion switch illumina- tion | ON (Tail lamps OFF) | 9.5 V |
| | | | | | ON (Tail lamps ON) | <p>NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMIA0159GB</p> |
| 134 (GR) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 137 (O) | Ground | Receiver and sensor ground | Input | Ignition switch ON | 0 V | |
| 138 (Y) | Ground | Receiver and sensor power supply | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 5.0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|---|--|
| | | Signal name | Input/ Output | | |
| + | - | | | | |
| 139 (L) | Ground | Tire pressure receiver communication | Input/ Output | Ignition switch ON | Standby state  OCC3881D |
| | | | | When receiving the signal from the transmitter  OCC3880D | |
| 140 (GR) | Ground | Selector lever P/N position | Input | Selector lever | P or N position Battery voltage |
| | | | | Except P and N positions | 0 V |
| 141 (G) | Ground | Security indicator | Output | Security indicator | ON 0 V |
| | | | | Blinking  11.3 V JPMA0014GB | |
| | | | | OFF | Battery voltage |
| 142 (O) | Ground | Combination switch OUTPUT 5 | Output | Combination switch (Wiper intermittent dial 4) | All switches OFF 0 V |
| | | | | Lighting switch 1ST |  10.7 V JPMA0031GB |
| | | | | Lighting switch HI | |
| | | | | Lighting switch 2ND | |
| Turn signal switch RH | | | | | |
| 143 (P) | Ground | Combination switch OUTPUT 1 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) 0 V |
| | | | | Front wiper switch HI (Wiper intermittent dial 4) |  10.7 V JPMA0032GB |
| | | | | Rear wiper switch INT (Wiper intermittent dial 4) | |
| | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 | |

A

B

C

D

WT

F

G

H

I

J

K

L

M






N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | |
|------------------------------|--------|---|------------------|---|---|---|--------|
| | | Signal name | Input/ Output | | | | |
| + | - | | | | | | |
| 144 (G) | Ground | Combination switch OUTPUT 2 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) | 0 V | |
| | | | | | Front washer switch ON (Wiper intermittent dial 4) |  | |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) | | |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) | | |
| | | | | | Any of the conditions below with all switches OFF | | |
| | | | | | <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | 10.7 V | |
| 145 (L) | Ground | Combination switch OUTPUT 3 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V | |
| | | | | | Front wiper switch INT |  | |
| | | | | | Front wiper switch LO | | |
| | | | | | Lighting switch AUTO | | |
| 146 (SB) | Ground | Combination switch OUTPUT 4 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V | |
| | | | | | Front fog lamp switch ON |  | |
| | | | | | Lighting switch 2ND | | |
| | | | | | Lighting switch PASS | | |
| | | | | | Turn signal switch LH | | |
| 149 (W) | Ground | Tire pressure warn- ing check switch | Input | Ignition switch ON | |  | 11.8 V |
| 150 (LG) | Ground | Driver door switch | Input | Driver door switch | OFF (Door close) |  | 11.8 V |
| | | | | | ON (Door open) | 0 V | |
| 151 (G) | Ground | Rear window defog- ger relay control | Output | Rear window de- fogger | Active | 0 V | |
| | | | | | Not activated | Battery voltage | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000004919767




A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

2008/08/28

JCMWA3119GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




*: This connector is not shown in "Harness Layout".

JCMWA3120GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- ◊RF◊ : With sunroof
- ◊PM◊ : With automatic drive positioner
- ◊OP◊ : Without automatic drive positioner



BCM (BODY CONTROL MODULE)
 (M119) (M120) (M121) (M122) (M123)




JCMWA3121GB

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWA3123GB


A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|--------------------|
| Connector No. | M33 |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TH16FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | SB | OUTPUT 4 |
| 5 | L | OUTPUT 3 |
| 7 | V | INPUT 3 |
| 8 | O | OUTPUT 5 |
| 9 | Y | INPUT 2 |
| 10 | R | INPUT 4 |
| 11 | LG | INPUT 1 |
| 12 | P | OUTPUT 1 |
| 13 | BR | INPUT 5 |
| 14 | G | OUTPUT 2 |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03EB-LC |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (E/L) |
| 2 | Y | POWER WINDOW POWER SUPPLY(BAT) |
| 3 | O | POWER WINDOW POWER SUPPLY(IRAP) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 4 | LG | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | L | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | Y | STEP LAMP OUTPUT |
| 8 | V | ALL DOOR. FUEL LID LOCK OUTPUT |
| 9 | G | DRIVER DOOR. FUEL LID UNLOCK OUTPUT |
| 10 | BR | REAR DOOR UNLOCK OUTPUT |
| 11 | R | BAT (FUSE) |
| 13 | B | GND |
| 14 | W | PUSH-BUTTON (IGNITION SW ILL GND |
| 15 | Y | ACC IND |
| 17 | W | TURN SIGNAL RH (FRONT) |


| | | |
|----|---|-------------------------|
| 18 | O | TURN SIGNAL LH (FRONT) |
| 19 | V | ROOM LAMP TIMER CONTROL |

| | |
|----------------|---------------------------|
| Connector No. | M120 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS12PW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | V | TURN SIGNAL RH (REAR) |
| 23 | G | BACK DOOR OPEN OUTPUT |
| 25 | G | TURN SIGNAL LH (REAR) |
| 26 | G | REAR WIPER OUTPUT |

| | |
|----------------|---------------------------|
| Connector No. | M121 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FGY-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 34 | SB | LUGGAGE ROOM ANT- |
| 35 | V | LUGGAGE ROOM ANT+ |
| 38 | B | BACK DOOR ANT- |
| 39 | W | BACK DOOR ANT+ |
| 47 | Y | IGN RELAY (PDM/E/R) CONT |
| 52 | SB | STARTER RELAY CONT |
| 61 | W | BACK DOOR OPENER REQUEST SW |
| 64 | V | KEY WARN BUZZER (ENG ROOM) |
| 65 | O | REAR WIPER STOP POSITION |
| 66 | R | BACK DOOR SW |
| 67 | GR | BACK DOOR OPENER SW |

| | | |
|----|----|-----------------|
| 68 | BR | REAR RH DOOR SW |
| 69 | R | REAR LH DOOR SW |


JCMWA3124GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| | | |
|-----|----|---------------------------------|
| 133 | Y | RECEIVER/SENSOR POWER SUPPLY |
| 139 | L | TIRE PRESSURE RECEIVER COMM |
| 140 | GR | SHIFT N/P |
| 141 | G | SECURITY INDICATOR OUTPUT |
| 142 | G | COMBI SW OUTPUT 5 |
| 143 | P | COMBI SW OUTPUT 1 |
| 144 | G | COMBI SW OUTPUT 2 |
| 145 | L | COMBI SW OUTPUT 3 |
| 146 | SB | COMBI SW OUTPUT 4 |
| 149 | W | TIRE PRESS WARNING CHECK SW |
| 150 | LG | DRIVER DOOR SW |
| 151 | G | REAR WINDOW DEFOGGER RELAY CONT |

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FG-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------------|
| 113 | P | OPTICAL SENSOR |
| 116 | SB | STOP LAMP SW 1 |
| 118 | P | STOP LAMP SW 2 |
| 119 | SB | DR DOOR UNLOCK SENSOR |
| 121 | BR | KEY SLOT SW |
| 123 | W | IGN F/B |
| 124 | LG | PASSENGER DOOR SW |
| 132 | V | POWER WINDOW SW COMM |
| 133 | W | PUSH-BUTTON IGNITION SW ILL POWER |
| 134 | GR | LOCK IND |
| 137 | O | RECEIVER/SENSOR GND |

| | | |
|-----|----|-------------------------------------|
| 83 | Y | KEYLESS ENTRY RECEIVER COMM |
| 87 | BR | COMBI SW INPUT 5 |
| 88 | V | COMBI SW INPUT 3 |
| 89 | BR | PUSH SW |
| 90 | P | GAN-L |
| 91 | L | GAN-H |
| 92 | LG | ON IND |
| 93 | V | KEY SLOTTILL |
| 94 | Y | PUDDLE LAMP CONT |
| 95 | O | ACC RELAY CONT |
| 96 | GR | A/T SHIFT SELECTOR POWER SUPPLY |
| 97 | L | S/L CONDITION 1 |
| 98 | P | S/L CONDITION 2 |
| 99 | R | SHIFT P |
| 100 | G | PASSENGER DOOR REQUEST SW |
| 101 | SB | DRIVER DOOR REQUEST SW |
| 102 | O | BLOWER FAN MOTOR RELAY CONT |
| 103 | LG | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 106 | W | S/L UNIT POWER SUPPLY |
| 107 | LG | COMBI SW INPUT 1 |
| 108 | R | COMBI SW INPUT 4 |
| 109 | Y | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |
| 111 | Y | S/L UNIT COMM |

BCM (BODY CONTROL MODULE)

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 72 | R | ROOM ANT2- |
| 73 | G | ROOM ANT2+ |
| 74 | SB | PASSENGER DOOR ANT- |
| 75 | GR | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | LG | DRIVER DOOR ANT+ |
| 78 | Y | ROOM ANT1- |
| 79 | BR | ROOM ANT1+ |
| 80 | GR | IMMOBI ANTENNA CONTROL |
| 81 | W | IMMOBI ANTENNA SIGNAL |
| 82 | R | IGN RELAY (F/B) CONT |

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

JCMWA3125GB

INFOID:000000004919768

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|---|
| B2013: ID DISCORD BCM-S/L | Inhibit engine cranking | Erase DTC |
| B2014: CHAIN OF S/L-BCM | Inhibit engine cranking | Erase DTC |
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2557: VEHICLE SPEED | Inhibit steering lock | When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal |
| B2601: SHIFT POSITION | Inhibit steering lock | 500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN) |
| B2602: SHIFT POSITION | Inhibit steering lock | 5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more |
| B2603: SHIFT POSI STATUS | Inhibit steering lock | 500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V) |
| B2604: PNP SW | Inhibit steering lock | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF |
| B2605: PNP SW | Inhibit steering lock | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position <ul style="list-style-type: none"> - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON |
| B2606: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal) |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|--|
| B2607: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal) |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B2609: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B2612: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R) |
| B2617: STARTER RELAY CIRC | Inhibit engine cranking | 1 second after the starter motor relay control inside BCM becomes normal |
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B2619: BCM | Inhibit engine cranking | 1 second after the steering lock unit power supply output control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |
| B26E9: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage) |

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.
 BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.
 When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000004919769

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC |
|----------|--|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) |
| 3 | <ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING |
| 4 | <ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC | |
|----------|---|----------------------------------|
| 5 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT | A B C D WT F G |
| 6 | <ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA | H |

DTC Index

INFOID:000000004919770

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-16. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|--|-----------|--|---------------------------------|---------------------------------------|------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | — | — | BCS-37 |
| U1010: CONTROL UNIT (CAN) | — | — | — | — | BCS-38 |
| U0415: VEHICLE SPEED SIG | — | — | — | — | BCS-39 |
| B2013: ID DISCORD BCM-S/L | × | × | — | — | SEC-48 |
| B2014: CHAIN OF S/L-BCM | × | × | — | — | SEC-49 |
| B2190: NATS ANTENNA AMP | × | — | — | — | SEC-41 |
| B2191: DIFFERENCE OF KEY | × | — | — | — | SEC-44 |
| B2192: ID DISCORD BCM-ECM | × | — | — | — | SEC-45 |
| B2193: CHAIN OF BCM-ECM | × | — | — | — | SEC-46 |
| B2195: ANTI SCANNING | × | — | — | — | SEC-47 |
| B2553: IGNITION RELAY | — | × | — | — | PCS-49 |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|---------------------------|-----------|--|---------------------------------|---------------------------------------|------------------------|
| B2555: STOP LAMP | — | × | — | — | SEC-52 |
| B2556: PUSH-BTN IGN SW | — | × | × | — | SEC-54 |
| B2557: VEHICLE SPEED | × | × | × | — | SEC-56 |
| B2560: STARTER CONT RELAY | × | × | × | — | SEC-57 |
| B2562: LOW VOLTAGE | — | × | — | — | BCS-40 |
| B2601: SHIFT POSITION | × | × | × | — | SEC-58 |
| B2602: SHIFT POSITION | × | × | × | — | SEC-61 |
| B2603: SHIFT POSI STATUS | × | × | × | — | SEC-63 |
| B2604: PNP SW | × | × | × | — | SEC-66 |
| B2605: PNP SW | × | × | × | — | SEC-68 |
| B2606: S/L RELAY | × | × | × | — | SEC-70 |
| B2607: S/L RELAY | × | × | × | — | SEC-71 |
| B2608: STARTER RELAY | × | × | × | — | SEC-73 |
| B2609: S/L STATUS | × | × | × | — | SEC-75 |
| B260A: IGNITION RELAY | × | × | × | — | PCS-51 |
| B260B: STEERING LOCK UNIT | — | × | × | — | SEC-79 |
| B260C: STEERING LOCK UNIT | — | × | × | — | SEC-80 |
| B260D: STEERING LOCK UNIT | — | × | × | — | SEC-81 |
| B260F: ENG STATE SIG LOST | × | × | × | — | SEC-82 |
| B2612: S/L STATUS | × | × | × | — | SEC-86 |
| B2614: ACC RELAY CIRC | — | × | × | — | PCS-53 |
| B2615: BLOWER RELAY CIRC | — | × | × | — | PCS-56 |
| B2616: IGN RELAY CIRC | — | × | × | — | PCS-59 |
| B2617: STARTER RELAY CIRC | × | × | × | — | SEC-90 |
| B2618: BCM | × | × | × | — | PCS-62 |
| B2619: BCM | × | × | × | — | SEC-92 |
| B261A: PUSH-BTN IGN SW | — | × | × | — | SEC-93 |
| B261E: VEHICLE TYPE | × | × | × (Turn ON for 15 seconds) | — | SEC-96 |
| B2621: INSIDE ANTENNA | — | × | — | — | DLK-59 |
| B2622: INSIDE ANTENNA | — | × | — | — | DLK-61 |
| B2623: INSIDE ANTENNA | — | × | — | — | DLK-63 |
| B26E1: ENG STATE NO RES | × | × | × | — | SEC-83 |
| B26E9: S/L STATUS | × | × | × (Turn ON for 15 seconds) | — | SEC-84 |
| B26EA: KEY REGISTRATION | — | × | × (Turn ON for 15 seconds) | — | SEC-85 |
| C1704: LOW PRESSURE FL | — | — | — | × | WT-17 |
| C1705: LOW PRESSURE FR | — | — | — | × | |
| C1706: LOW PRESSURE RR | — | — | — | × | |
| C1707: LOW PRESSURE RL | — | — | — | × | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page | |
|---------------------------|-----------|--|------------------------------------|---|-----------------------|----|
| C1708: [NO DATA] FL | — | — | — | × | WT-19 | A |
| C1709: [NO DATA] FR | — | — | — | × | | B |
| C1710: [NO DATA] RR | — | — | — | × | | C |
| C1711: [NO DATA] RL | — | — | — | × | | D |
| C1712: [CHECKSUM ERR] FL | — | — | — | × | WT-22 | D |
| C1713: [CHECKSUM ERR] FR | — | — | — | × | | WT |
| C1714: [CHECKSUM ERR] RR | — | — | — | × | | E |
| C1715: [CHECKSUM ERR] RL | — | — | — | × | | F |
| C1716: [PRESSDATA ERR] FL | — | — | — | × | WT-25 | F |
| C1717: [PRESSDATA ERR] FR | — | — | — | × | | G |
| C1718: [PRESSDATA ERR] RR | — | — | — | × | | H |
| C1719: [PRESSDATA ERR] RL | — | — | — | × | | I |
| C1720: [CODE ERR] FL | — | — | — | × | WT-27 | G |
| C1721: [CODE ERR] FR | — | — | — | × | | H |
| C1722: [CODE ERR] RR | — | — | — | × | | I |
| C1723: [CODE ERR] RL | — | — | — | × | | J |
| C1724: [BATT VOLT LOW] FL | — | — | — | × | WT-30 | I |
| C1725: [BATT VOLT LOW] FR | — | — | — | × | | J |
| C1726: [BATT VOLT LOW] RR | — | — | — | × | | K |
| C1727: [BATT VOLT LOW] RL | — | — | — | × | | L |
| C1729: VHCL SPEED SIG ERR | — | — | — | × | WT-33 | J |
| C1734: CONTROL UNIT | — | — | — | × | WT-34 | K |

TPMS

< SYMPTOM DIAGNOSIS >











SYMPTOM DIAGNOSIS

TPMS

Symptom Table




INFOID:000000004346993

LOW TIRE PRESSURE WARNING LAMP SYMPTOM CHART

| Diagnosis Item | Symptom (Ignition switch ON) | Low tire pressure warning lamp | Cause | Action |
|--------------------------------|---|---|--|--|
| Low tire pressure warning lamp | Low tire pressure warning lamp comes on immediately and turns off after 1 second. |   ON 1 sec > stays OFF <small>SEIA0592E</small> | All wheel transmitters are "activated" (working). | None (system OK) |
| | Low tire pressure warning lamp blinks on for 2 seconds, then turns off for 0.2 seconds-repeats. |  Blinks:  ON 2 sec > OFF 0.2 sec <small>SEIA0593E</small> | All wheel transmitters are not activated. | Activate all wheel tire pressure transmitters. Refer to WT-6 , " TRANSMITTER WAKE UP OPERATION : Special Repair Requirement ". |
| | Low tire pressure warning lamp blinks 1 time. |  Blinks 1 time ON 0.3 sec > OFF 1.3 sec <small>SEIA0594E</small> | Tire pressure transmitter front LH is not activated. | Activate tire pressure transmitter front LH. Refer to WT-6 , " TRANSMITTER WAKE UP OPERATION : Special Repair Requirement ". |
| | Low tire pressure warning lamp blinks 2 times. |   Blinks 2 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0595E</small> | Tire pressure transmitter front RH is not activated. | Activate tire pressure transmitter front RH. Refer to WT-6 , " TRANSMITTER WAKE UP OPERATION : Special Repair Requirement ". |
| | Low tire pressure warning lamp blinks 3 times. |    Blinks 3 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0596E</small> | Tire pressure transmitter rear RH is not activated. | Activate tire pressure transmitter rear RH. Refer to WT-6 , " TRANSMITTER WAKE UP OPERATION : Special Repair Requirement ". |

TPMS

< SYMPTOM DIAGNOSIS >

| Diagnosis Item | Symptom (Ignition switch ON) | Low tire pressure warning lamp | Cause | Action |
|--------------------------------|--|--|--|---|
| Low tire pressure warning lamp | Low tire pressure warning lamp blinks 4 times. |  <p>Blinks 4 times ON 0.3 sec > OFF 0.3 sec SEIA0597E</p> | Tire pressure transmitter rear LH is not activated. | Activate tire pressure transmitter rear LH. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement" . |
| | Low tire pressure warning lamp comes on and does not turn off. |  <p>Comes ON and stays ON SEIA0598E</p> | Tire pressure is low. | Check tire pressure with CONSULT-III. Refer to WT-15, "AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)" . |
| | Low tire pressure warning lamp blinks on for 0.5 seconds then turns off for 0.5 seconds-repeats for 1 minute, and then stays on. |  <p>Blinks 1 min ON 0.5 sec > OFF 0.5 sec and stays ON SEIA0788E</p> | <p>The fuse for combination meter from battery is pulled out.</p> <p>BCM connector pulled out.</p> <p>Low tire pressure or tire pressure monitoring system malfunction.</p> | <p>Check the fuse for combination meter from battery. Install or replace (if needed).</p> <p>Check BCM connector. Reconnect if needed.</p> <ul style="list-style-type: none"> Perform CONSULT-III Self-Diagnosis. Refer to WT-15, "AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)". Perform ID Registration if needed. Refer to WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement". |
| Turn signal lamp | Turn signal lamp does not blink 2 times or buzzer does not sound after transmitter activation. | — | <ol style="list-style-type: none"> Tool J-45295 [SST] does not activated. Ignition OFF during activation. Tool J-45295 [SST] not positioned correctly. Transmitters already activated. | <ol style="list-style-type: none"> Install new battery. Check ignition is ON during activation. Position tool correctly during activation. Nothing. |

NOTE:

If more than one wheel transmitter is NOT activated, the low tire pressure warning lamp blinking patterns for those wheels will combine. (Example: one blink/OFF/three blinks = Tire pressure transmitter rear LH and rear RH are not activated.)

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000004346994

DESCRIPTION

The low tire pressure warning lamp illuminates for approximately 1 second and then turns OFF when the ignition switch is turned ON. This is to check that no abnormal condition is present in the tire pressure monitoring system.

The lamp bulb may be burnt out or the tire pressure monitoring system may be malfunctioning if the low tire pressure warning lamp does not illuminate when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000004346995

1. CHECK SELF-DIAGNOSIS RESULTS

Ⓜ With CONSULT-III

1. On the "SELECT DIAG" mode, select the "SELF-DIAG RESULTS" screen.
2. Check display contents in self-diagnostic results.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

YES >> Perform trouble diagnosis for CAN communication system. Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

NO >> GO TO 2.

2. CHECK COMBINATION METER

Check combination meter function. Refer to [MWI-40, "CONSULT-III Function \(METER/M&A\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK LOW TIRE PRESSURE WARNING LAMP

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connectors.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

Does low tire pressure warning lamp turn ON?

YES >> GO TO 4.

NO >> Check combination meter and repair or replace. Refer to [MWI-38, "Diagnosis Description"](#).

4. CHECK SYMPTOM

Check symptom again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK BCM

Check BCM input/output signal. Refer to [WT-49, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 6.

6. CHECK BCM HARNESS CONNECTOR

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Repair or replace damaged parts.

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:000000004346996

DESCRIPTION

The tire pressure monitoring system is checked and the warning lamp is illuminated for approximately 1 second when the ignition switch is turned ON. The low tire pressure warning lamp turns OFF after the system check finishes.

The system may be malfunctioning if the low tire pressure warning lamp does not turn off approximately 1 second after the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000004346997

1. CHECK SYSTEM FOR BCM

④ With CONSULT-III

1. On "SELF-DIAG" mode, select the "SELF-DIAG RESULTS" screen.
2. Check display contents in self-diagnostic results.

Does self-diagnostic results indicate any malfunction?

YES >> Perform trouble diagnosis. Refer to [WT-15, "AIR PRESSURE MONITOR : CONSULT-III Function \(BCM - AIR PRESSURE MONITOR\)"](#).

NO >> GO TO 2.

2. CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Does low tire pressure warning lamp turn OFF?

YES >> INSPECTION END

NO >> GO TO 3.

3. CHECK BCM POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check voltage between BCM harness connector and ground.

| BCM | | — | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal | | |
| M118 | 1 | Ground | Battery voltage |
| M119 | 11 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

- 40 A fusible link [No. K located in the fuse block]. Refer to [PG-100, "Fuse and Fusible Link Arrangement"](#).
- 10 A fuse [No. 10 located in the fuse block (J/B)]. Refer to [PG-99, "Fuse, Connector and Terminal Arrangement"](#).
- Harness for short or open between battery and BCM harness connector M118 terminal 1.
- Harness for short or open between battery and BCM harness connector M119 terminal 11.
- Check battery voltage.

4. CHECK BCM GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M119 | 13 | Ground | Existed |

Is the inspection result normal?

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 5.
- NO >> Repair or replace damaged parts.

5.CHECK SYMPTOM

Check symptom again.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 6.

6.CHECK BCM

Check BCM input/output signal. Refer to [WT-49. "Reference Value"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 7.

7.CHECK BCM HARNESS CONNECTOR

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
- NO >> Repair or replace damaged parts.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP BLINKS

Description

INFOID:000000004346998

DESCRIPTION

The low tire pressure warning lamp illuminates or blinks.


However, a check is necessary because the symptom may not be caused by a system malfunction. For example, the transmitter may not be initialized.

NOTE:

If low tire pressure warning lamp blinks as shown in the figure, the system is normal.

Blink Mode A

- This mode shows transmitter status is in OFF- mode. Perform transmitter wake up operation. Refer to [WT-6, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



Diagnosis Procedure

INFOID:000000004346999

1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- Turn the ignition switch ON.

CAUTION:

Never start the engine.

- Check voltage between tire pressure warning check switch connector and ground.

| Tire pressure warning check switch | | — | Voltage (Approx.) |
|------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M23 | 1 | Ground | 11.8 V |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Riper or replace damaged parts.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- Turn the ignition switch OFF.
- Disconnect BCM harness connector.
- Check continuity between BCM harness connector and tire pressure warning check switch connector.

| BCM | | Tire pressure warning check switch | | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 149 | M23 | 1 | Existed |

- Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 149 | Ground | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

3.CHECK BCM

Check BCM input/output signal. Refer to [WT-49. "Reference Value"](#).

Is the inspection result normal?

- YES >> Check tire pressure warning check switch. Refer to [WT-40. "Diagnosis Procedure"](#).
- NO >> Repair or replace the BCM.

TURN SIGNAL LAMP BLINKS

< SYMPTOM DIAGNOSIS >

TURN SIGNAL LAMP BLINKS

Description

INFOID:000000004347000

DESCRIPTION

The turn signal lamp blinks when the ignition switch is turned ON.
The BCM connector or circuit may have a malfunction.

Diagnosis Procedure

INFOID:000000004347001

1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check voltage between tire pressure warning check switch connector and ground.

| Tire pressure warning check switch | | — | Voltage (Approx.) |
|------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M23 | 1 | Ground | 11.8 V |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace damaged parts.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check continuity between BCM harness connector and tire pressure warning check switch connector.

| BCM | | Tire pressure warning check switch | | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 149 | M23 | 1 | Existed |

4. Check continuity between BCM harness connector and ground.

| BCM | | — | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 149 | Ground | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK SYMPTOM

Check again.

Does the turn signal lamp remain blinking?

YES >> Check turn signal lamp operation. Refer to [EXL-35. "FLASHER : CONSULT-III Function \(BCM - FLASHER\)"](#).

NO >> INSPECTION END

ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

ID REGISTRATION CANNOT BE COMPLETED

Description

INFOID:000000004347002

DESCRIPTION

The ID of the transmitter installed in each wheel cannot be registered in the tire pressure monitoring system. Inspect the transmitter or the tire pressure monitoring system circuit.

Diagnosis Procedure

INFOID:000000004347003

1. CHECK ID REGISTRATION

1. Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition | Display value |
|----------------|---|---|
| AIR PRESS FL | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR | | |
| AIR PRESS RR | | |
| AIR PRESS RL | | |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK TRANSMITTER

1. Perform trouble diagnosis for transmitters. Refer to [WT-19, "Diagnosis Procedure"](#).
2. Perform ID registration of all transmitters. Refer to [WT-6, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

- YES >> INSPECTION END
NO >> Replace the transmitter.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description


INFOID:000000004347004

LOW TIRE PRESSURE WARNING LAMP BLINKS

The tire pressure monitoring system is not malfunctioning if the low tire pressure warning lamp blinks in the pattern as shown in the figure.

The incident occurs because the transmitter of each wheel is not wake up.

Perform transmitter wake up operation. Refer to [WT-6, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000004347005

Use chart below to find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom | | Possible cause and SUSPECTED PARTS | | | | | | | | | | Reference page | | | | | | |
|---------|------------|------------------------------------|---|---|---|---|---|---|---|---|---|----------------|---|---|---|---|---|---|
| Symptom | TIRES | Noise | x | x | x | x | x | x | x | x | x | x | x | x | x | x | 2WD models: FSU-9 , FSU-7 AWD models: FSU-28 , FSU-26 WT-99 , "Inspection" WT-100 , "Adjustment" WT-106 , "Tire Air Pressure" WT-100 , "Adjustment" — — WT-106 , "Tire Air Pressure" NVH in DLN section. NVH in DLN section. NVH in FAX and FSU sections. NVH in RAX and RSU sections. Refer to TIRES in this chart. Refer to ROAD WHEEL in this chart. NVH in FAX, RAX section. NVH in BR section. NVH in ST section. | |
| | | Shake | x | x | x | x | x | x | x | x | x | x | x | x | x | x | | |
| | | Vibration | | | | x | | | | x | x | | x | x | | x | | |
| | | Shimmy | x | x | x | x | x | x | x | x | | | x | x | | x | | x |
| | | Judder | x | x | x | x | x | x | x | | x | | x | x | | x | | x |
| | | Poor quality ride or handling | x | x | x | x | x | x | x | | x | | x | x | | | | |
| | ROAD WHEEL | Noise | x | x | x | | | | x | | x | x | x | x | | x | x | |
| | | Shake | x | x | x | | | | x | | x | | x | x | | x | x | |
| | | Shimmy, Judder | x | x | x | | | | x | | | | x | x | | x | x | |
| | | Poor quality ride or handling | x | x | x | | | | x | | | | x | x | | | | |

x: Applicable

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004528619

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Service Notice or Precautions

INFOID:000000004347006

- Low tire pressure warning lamp blinks for 1min, then turns ON when occurring any malfunction except low tire pressure. Delete the memory with CONSULT-III, or register the ID to turn low tire pressure warning lamp OFF. Refer to [WT-13. "AIR PRESSURE MONITOR : Diagnosis Description"](#), [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
- ID registration is required when replacing or rotating wheels, replacing transmitter or BCM. Refer to [BCS-85. "Exploded View"](#).
- Replace grommet seal, valve core and cap of transmitter in TPMS every tire replacement by reaching wear limit of tire. Refer to [WT-103. "Exploded View"](#).

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000004347007

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|---|-----------------|
| — (J-45295) Transmitter activation tool  SEIA0462E | ID registration |

Commercial Service Tool

INFOID:000000004347008

| Tool name | Description |
|---|----------------------|
| Power tool  PBIC0190E | Loosening wheel nuts |

ROAD WHEEL

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE


ROAD WHEEL

Inspection

INFOID:000000004347009

ALUMINUM WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from aluminum wheel and mount on a tire balance machine.
 - b. Set dial indicator as shown in the figure.
 - c. If the lateral deflection (A) or vertical deflection (B) for radial runout value exceeds the limit, replace aluminum wheel.



Limit

A: Refer to [WT-106, "Road Wheel"](#).

B: Refer to [WT-106, "Road Wheel"](#).

STEEL WHEEL

1. Check tires for were and improper inflation.
2. Check wheels for deformation, clacks and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from steel wheel and mount wheel on a tire balance machine.
 - b. Set two dial indicators as shown in the illustration.
 - c. Set each dial indicator to "0".
 - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
 - e. Calculate runout at each point as shown below.

Lateral runout limit (A): $(1+2)/2$

Radial runout limit (B): $(3+4)/2$

- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout.

CAUTION:


In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout.

Limit

A: Refer to [WT-106, "Road Wheel"](#).

B: Refer to [WT-106, "Road Wheel"](#).

- g. If the total runout value exceeds limit, replace steel wheel.



ROAD WHEEL TIRE ASSEMBLY

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

ROAD WHEEL TIRE ASSEMBLY

Adjustment

INFOID:000000004347010

BALANCING WHEELS (BONDING WEIGHT TYPE)

Preparation Before Adjustment

Using releasing agent, remove double-faced adhesive tape from the road wheel.

CAUTION:

- **Be careful not to scratch the road wheel during removal.**
- **After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.**

Wheel Balance Adjustment

If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for road wheels.

1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by $5/3$ to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install to the designated outer position of, or at the designated angle in relation to the road wheel.

CAUTION:

- **Do not install the inner balance weight before installing the outer balance weight.**
- **Before installing the balance weight, be sure to clean the mating surface of the road wheel.**

- a. Indicated unbalance value $\times 5/3 =$ balance weight to be installed

Calculation example:

$23 \text{ g (0.81 oz)} \times 5/3 = 38.33 \text{ g (1.35 oz)} \Rightarrow 37.5 \text{ g (1.32 oz)}$ balance weight (closer to calculated balance weight value)


NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

$36.2 \Rightarrow 35 \text{ g (1.23 oz)}$

$36.3 \Rightarrow 37.5 \text{ g (1.32 oz)}$



- b. Installed balance weight in the position.


ROAD WHEEL TIRE ASSEMBLY

< REMOVAL AND INSTALLATION >

- When installing balance weight (1) to road wheels, set it into the grooved area (A) on the inner wall of the road wheel as shown in the figure so that the balance weight center (B) is aligned with the tire balance machine indication position (angle) (C).

CAUTION:

- Always use genuine NISSAN adhesion balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



- If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.

CAUTION:


Do not install one balance weight sheet on top of another.

- Start the tire balance machine again.
- Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).

CAUTION:

Do not install more than two balance weight.

- Start the tire balance machine. Make sure that inner and outer residual unbalance values are 5 g (0.17 oz) each or below.
- If either residual unbalance value exceeds 5 g (0.17 oz), repeat installation procedures.



Limit

Dynamic (At flange): Refer to [WT-106, "Road Wheel"](#).


Static (At flange): Refer to [WT-106, "Road Wheel"](#).

TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-4, "Explanation of General Maintenance"](#).
- When installing the wheel, tighten wheel nuts to the specified torque.

CAUTION:

- Do not include the T-type spare tire when rotating the tires.
- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.
- Use NISSAN genuine wheel nuts for aluminum wheels.



Wheel nuts tightening torque : Refer to [WT-106, "Road Wheel"](#).

ROAD WHEEL TIRE ASSEMBLY

< REMOVAL AND INSTALLATION >


- Perform the ID registration, after tire rotation. Refer to [WT-6. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

TRANSMITTER

< REMOVAL AND INSTALLATION >

TRANSMITTER

Exploded View



1. Transmitter
2. Grommet seal
3. Valve nut
4. Valve core
5. Cap


Refer to [GI-4, "Components"](#) for symbols in figure.

Removal and Installation


INFOID:000000004347012

REMOVAL

1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
2. Gently bounce tire so that transmitter falls to bottom of tire. Place on tire changing machine and break both tire beads ensuring that the transmitter remains at the bottom of the tire.



3. Turn tire so that valve hole is at bottom and bounce so that transmitter (1) is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270 degree from mounting/dismounting head (2).
4. Lubricate tire well and remove first side of the tire. Reach inside the tire and remove the transmitter.




INSTALLATION

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TRANSMITTER

< REMOVAL AND INSTALLATION >

1. Put first side of tire onto rim.



2. Mount transmitter on rim and tighten nut.

CAUTION:


Speed for tightening nut should be less than 10 rpm.

3. Place wheel on turntable of tire machine. Ensure that transmitter (1) is 270 degree from mounting head (2) when second side of tire is fitted.

NOTE:

Do not touch transmitter at mounting head.

4. Lubricate tire well and fit second side of tire as normal. Ensure that tire does not rotate relative to rim.
5. Inflate tire and fit to appropriate wheel position.




TIRE PRESSURE RECEIVER

< REMOVAL AND INSTALLATION >

TIRE PRESSURE RECEIVER

Exploded View

INFOID:000000004347013



1. Tire pressure receiver


←: Vehicle front

Removal and Installation

INFOID:000000004347014

REMOVAL

1. Remove the instrument lower cover. Refer to [IP-12, "Exploded View"](#).
2. Remove the instrument lower panel RH. Refer to [IP-12, "Exploded View"](#).
3. Disconnect tire pressure receiver (1) harness connector.
4. Remove Tire pressure receiver mounting screw.
5. Remove tire pressure receiver.



INSTALLATION

Install is the reverse order of removal.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Road Wheel

INFOID:000000004347015

ALUMINUM WHEEL (CONVENTIONAL)

| Item | | Limit |
|---------------------|---------------------|------------------------------------|
| Radial runout | Lateral deflection | Less than 0.3 mm (0.012 in) |
| | Vertical deflection | |
| Allowable unbalance | Dynamic (At flange) | Less than 5 g (0.17 oz) (one side) |
| | Static (At flange) | Less than 10 g (0.35 oz) |

ALUMINUM WHEEL (FOR TEMPORALLY USE)

| Item | | Limit |
|---------------------|---------------------|------------------------------------|
| Radial runout | Lateral deflection | Less than 1.5 mm (0.059 in) |
| | Vertical deflection | |
| Allowable unbalance | Dynamic (At flange) | Less than 5 g (0.17 oz) (one side) |
| | Static (At flange) | Less than 10 g (0.35 oz) |

Wheel Nut

INFOID:000000004347016

| Item | Standard |
|-----------------------------|-----------------------------|
| Wheel nut tightening torque | 108 N·m (11 kg-m, 80 ft-lb) |

Tire Air Pressure

INFOID:000000004347017

Unit: kPa (kg/cm², psi)

| Item | Standard | |
|----------------|---------------|------|
| | Front | Rear |
| P225/60R17 98V | 230 (2.3, 33) | |
| P225/55R18 97V | 230 (2.3, 33) | |
| T165/80R17 | 420 (4.2, 60) | |