

# DEF

SECTION DEF  
DEFOGGER

## CONTENTS

<b>BASIC INSPECTION .....</b>	3	<b>DOOR MIRROR DEFOGGER .....</b>	16
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	3	Description .....	16
Work Flow .....	3	Component Function Check .....	16
Diagnosis Procedure .....	16	Diagnosis Procedure .....	16
<b>SYSTEM DESCRIPTION .....</b>	4	<b>DRIVER SIDE DOOR MIRROR DEFOGGER ...</b>	17
<b>REAR WINDOW DEFOGGER SYSTEM .....</b>	4	Description .....	17
System Diagram .....	4	Component Function Check .....	17
System Description .....	4	Diagnosis Procedure .....	17
Component Parts Location .....	5	<b>PASSENGER SIDE DOOR MIRROR DEFOG- GER .....</b>	19
Component Description .....	5	Description .....	19
<b>DIAGNOSIS SYSTEM (BCM) .....</b>	7	Component Function Check .....	19
<b>COMMON ITEM .....</b>	7	Diagnosis Procedure .....	19
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	7	<b>REAR WINDOW DEFOGGER SYSTEM .....</b>	21
<b>REAR WINDOW DEFOGGER .....</b>	8	Wiring Diagram - DEFOGGER SYSTEM - .....	21
REAR WINDOW DEFOGGER : CONSULT-III Function (BCM - REAR DEFOGGER) .....	8	<b>ECU DIAGNOSIS INFORMATION .....</b>	28
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	10	<b>BCM (BODY CONTROL MODULE) .....</b>	28
<b>POWER SUPPLY AND GROUND CIRCUIT .....</b>	10	Reference Value .....	28
Diagnosis Procedure .....	10	Wiring Diagram - BCM - .....	52
<b>REAR WINDOW DEFOGGER SWITCH .....</b>	11	Fail-safe .....	58
Description .....	11	DTC Inspection Priority Chart .....	60
Component Function Check .....	11	DTC Index .....	61
Diagnosis Procedure .....	11	<b>SYMPTOM DIAGNOSIS .....</b>	64
<b>REAR WINDOW DEFOGGER RELAY .....</b>	12	<b>REAR WINDOW DEFOGGER DOES NOT OPERATE .....</b>	64
Description .....	12	Diagnosis Procedure .....	64
Component Function Check .....	12	<b>REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE. ....</b>	65
Diagnosis Procedure .....	12	Diagnosis Procedure .....	65
Component Inspection .....	13	<b>REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DE- FOGGERS OPERATE. ....</b>	66
<b>REAR WINDOW DEFOGGER .....</b>	14	Diagnosis Procedure .....	66
Description .....	14		
Component Function Check .....	14		
Diagnosis Procedure .....	14		

---

<b>DOOR MIRROR DEFOGGER DOES NOT OPERATE .....</b>	<b>67</b>	<b>REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE .....</b>	<b>69</b>
<b>BOTH SIDES .....</b>	<b>67</b>	Diagnosis Procedure .....	69
BOTH SIDES : Diagnosis Procedure .....	67		
<b>DRIVER SIDE .....</b>	<b>67</b>		
DRIVER SIDE : Diagnosis Procedure .....	67		
<b>PASSENGER SIDE .....</b>	<b>67</b>		
PASSENGER SIDE : Diagnosis Procedure .....	67		
<b>ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED .....</b>	<b>68</b>	<b>PRECAUTION .....</b>	<b>70</b>
Diagnosis Procedure .....	68		
<b>PRECAUTIONS .....</b>	<b>70</b>		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	70		
<b>REMOVAL AND INSTALLATION .....</b>	<b>71</b>		
<b>FILAMENT .....</b>	<b>71</b>		
Inspection and Repair .....	71		

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000006345700

#### DETAILED FLOW

##### 1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

##### 2. CHECK DTC

Perform self diagnosis with CONSULT-III

Is any DTC detected?

YES >> Refer to [BCS-80, "DTC Index"](#).

NO >> GO TO 3.

##### 3. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

##### 4. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

##### 5. IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

##### 6. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

##### 7. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# REAR WINDOW DEFOGGER SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### REAR WINDOW DEFOGGER SYSTEM

#### System Diagram

INFOID:000000006345701



#### System Description

INFOID:000000006345702

#### Operation Description

- Turn rear window defogger switch ON when the ignition switch is turned ON. Then multifunction switch (rear window defogger switch) transmits rear window defogger switch signal to AV control unit via AV communication. AV control unit transmits rear window defogger switch signal to BCM via CAN communication.
- BCM turns rear window defogger relay ON and transmits rear window defogger control signal to IPDM E/R via CAN communication when rear window defogger switch signal is received.
- Rear window defogger and door mirror defogger (with mirror defogger) are supplied with power and operate when rear window defogger relay turns ON.
- IPDM E/R transmits rear window defogger control signal to AV control unit via CAN communication.
- AV control unit transmit rear defogger indicator signal to multifunction switch (rear window defogger switch) via AV communication then rear window defogger indicator is illuminated.

#### Timer function


- BCM turns rear window defogger relay ON for approximately 15 minutes when rear window defogger switch is turned ON. It makes rear window defogger and door mirror defogger (with mirror defogger) operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. Then BCM turns rear window defogger relay OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

# REAR WINDOW DEFOGGER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000006345703



JMLIA0125ZZ

- |  |  |  |
|--|--|--|
| 1. Rear window defogger relay (built-in relay box)   | 2. BCM M118, M119, M122, M123          | 3. IPDM E/R E6                         |
| 4. Rear window defogger switch (built-in multifunction switch M72)   | 5. Rear window defogger connector D108 | 6. Rear window defogger connector D120 |
| 7. AV control unit <ul style="list-style-type: none"> <li>• With NAVI M87, M88</li> <li>• Without NAVI M83, M85</li> </ul> |  |  |
| A. Dash side lower (driver side)   | B. Dash side lower (passenger side)    | C. Engine room dash panel (RH)         |
| D. Behind back door finisher   | E. Behind cluster lid C                |  |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

K  
DEF

M

N

O

P

## Component Description

INFOID:000000006345704

Item	Function
BCM	<ul style="list-style-type: none"> <li>• Operates the rear window defogger with the operation of rear window defogger switch.</li> <li>• Performs the timer control of rear window defogger.</li> </ul>
Rear window defogger relay	<ul style="list-style-type: none"> <li>• Operates the rear window defogger and the door mirror defogger with the control signal from BCM.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>• Transmit rear window defogger control signal to AV control unit via CAN communication.</li> </ul>
Multifunction switch (Rear window defogger switch)	<ul style="list-style-type: none"> <li>• The rear window defogger switch is installed.</li> <li>• Turns the indicator lamp ON when detecting the operation of rear window defogger.</li> </ul>
AV control unit	<ul style="list-style-type: none"> <li>• Displays the rear window defogger ON to the display when detecting the operation of rear window defogger.</li> </ul>

## REAR WINDOW DEFOGGER SYSTEM

### < SYSTEM DESCRIPTION >

Rear window defogger	<ul style="list-style-type: none"><li>Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.</li></ul>
Door mirror defogger*	<ul style="list-style-type: none"><li>Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.</li></ul>

\*: With mirror defogger

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000006922866

##### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>• Read and save the vehicle specification.</li> <li>• Write the vehicle specification when replacing BCM.</li> </ul>

##### SYSTEM APPLICATION

BCM can perform the following functions for each system.

##### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

##### NOTE:

\*: This item is displayed, but is not used.

#### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK" to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Except emergency stop operation)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"*. ) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)*
	OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>

### NOTE:

\*: For models without steering lock unit, power supply position changes from "OFF" to "LOCK" when steering lock conditions are satisfied.

## REAR WINDOW DEFOGGER

### REAR WINDOW DEFOGGER : CONSULT-III Function (BCM - REAR DEFOGGER)

INFOID:0000000006345706

#### Data monitor

Monitor Item	Description
REAR DEF SW	This is displayed even when it is not equipped.
PUSH SW	Indicates [ON/OFF] condition of push switch.

## DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

### ACTIVE TEST

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger operates when "ON" on CONSULT-III screen is touched.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### Diagnosis Procedure

INFOID:000000006345707

#### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1		K
11	Battery power supply	10

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
	BCM		
Connector	Terminal		
M118	1	Ground	Battery voltage
M119	11		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

# REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER SWITCH

### Description

INFOID:0000000006345708

- The rear window defogger is operated by turning the rear window defogger switch ON.
- The indicator lamp in the rear window defogger illuminates when the rear window defogger is operating.

### Component Function Check

INFOID:0000000006345709

#### 1.CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

Check that the indicator lamp of rear window defogger illuminates when rear window defogger switch ON.

Is the inspection result normal?

- YES    >> Rear window defogger switch function is OK.  
NO    >> Refer to [DEF-11, "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006345710

#### 1.CHECK MULTIFUNCTION SWITCH (REAR WINDOW DEFOGGER SWITCH)

Does multifunction switch operate normally?

- Base audio without navigation system. Refer to [AV-21, "On Board Diagnosis Function"](#).
- Bose audio without navigation system. Refer to [AV-159, "On Board Diagnosis Function"](#).
- Bose audio with navigation system. Refer to [AV-358, "On Board Diagnosis Function"](#).

Is the inspection result normal?

- YES    >> INSPECTION END  
NO    >> Replace multifunction switch (rear window defogger switch). Refer to [AV-134, "Removal and Installation"](#) (Base audio without navigation system), [AV-325, "Removal and Installation"](#) (Bose audio without navigation system) or [AV-525, "Removal and Installation"](#) (Bose audio with navigation system).

A

B

C

D

E

F

G

H

J

K

DEF

M

N

O

P

# REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER RELAY

### Description

INFOID:0000000006345711

Power is supplied to the rear window defogger with BCM control.

### Component Function Check

INFOID:0000000006345712

#### 1.CHECK REAR WINDOW DEFOGGER RELAY POWER SUPPLY CIRCUIT

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

YES >> Rear window defogger relay power supply circuit is OK.

NO >> Refer to [DEF-12, "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006345713

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No.3, located in fuse block (J/B)].

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

#### 2.CHECK REAR WINDOW DEFOGGER CIRCUIT 1

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
M123	151	Ground	Rear window defogger switch: ON	0
			Rear window defogger switch: OFF	Battery voltage

Is the inspection result normal?

YES >> Rear window defogger power supply circuit is OK.

NO >> GO TO 3.

#### 3.CHECK REAR WINDOW DEFOGGER CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector and fuse block (J/B).
3. Check continuity between BCM harness connector and fuse block (J/B) harness connector.

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M123	151	M2	4B	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

#### 4.CHECK REAR WINDOW DEFOGGER RELAY

1. Disconnect rear window defogger relay,
2. Check rear window defogger relay.  
Refer to [DEF-13, "Component Inspection"](#)

Is the inspection result normal?

# REAR WINDOW DEFOGGER RELAY

## < DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 5.

NO >> Replace rear window defogger relay.

## 5.CHECK FUSE BLOCK (J/B)

1. Install the rear window defogger relay.
2. Turn ignition switch ON.
3. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

(+)		(-)	Voltage (V) (Approx.)
Fuse block (J/B)			
Connector	Terminal		
M2	4B	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace fuse block (J/B).

## 6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#)

>> INSPECTION END.

## Component Inspection

INFOID:0000000006345714

### 1.CHECK REAR WINDOW DEFOGGER RELAY


1. Turn ignition switch OFF.
2. Disconnect rear window defogger relay.
3. Check rear window defogger relay.

Rear window defogger relay	Condition		Continuity
Terminal	3	5	
		12 V direct current supply between terminals 1 and 2.	Existed
		No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace rear window defogger relay.



# REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER

### Description

INFOID:0000000006345715

Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.

### Component Function Check

INFOID:0000000006345716

#### 1.CHECK REAR WINDOW DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger is OK.  
NO >> Refer to [DEF-14. "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006880213

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check the following.
  - 20A fuse [No.14, located in fuse block (J/B)]
  - 20A fuse [No.15, located in fuse block (J/B)]

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear window defogger harness connector and ground.

(+) Rear window defogger		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D108	1	Ground	Rear window defogger switch: ON	Battery voltage
			Rear window defogger switch: OFF	0

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 4.

#### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Check continuity between rear window defogger harness connector and ground.

Rear window defogger		Ground	Continuity
Connector	Terminal		
D120	2		Existed

Is the inspection result normal?

- YES >> GO TO 7.  
NO >> Repair or replace harness between rear window defogger and ground.

#### 4.CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

# REAR WINDOW DEFOGGER

## < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector and rear window defogger connector.
3. Check continuity between fuse block (J/B) harness connector and rear window defogger harness connector.

Fuse block (J/B)		Rear window defogger		Continuity
Connector	Terminal	Connector	Terminal	
B6	10G	D108	1	Existed
	11G			

4. Check continuity between fuse block (J/B) harness connector and ground.

Fuse block (J/B)		Ground	Continuity
Connector	Terminal		
B6	10G		Not existed
	11G		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5.CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) (fuse block side) and ground.

(+)	(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)		Connector	Terminal	
B6	10G	Ground	Rear window defogger switch: ON	
			Battery voltage	
	11G		Rear window defogger switch: OFF	
			0	
			Rear window defogger switch: ON	
			Battery voltage	
			Rear window defogger switch: OFF	
			0	

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

## 6.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay. Refer to [DEF-13, "Component Inspection"](#)

Is the inspection result normal?

YES >> Replace fuse block (J/B)

NO >> Replace rear window defogger relay.

## 7.CHECK FILAMENT

Check the filament for damage or blown.

Refer to [DEF-71, "Inspection and Repair"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair filament.

## 8.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#)

>> INSPECTION END

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

## DOOR MIRROR DEFOGGER

### Description

INFOID:0000000006345719

Power is supplied to the door mirror defogger with BCM control.

### Component Function Check

INFOID:0000000006345720

#### 1.CHECK DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that both side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Door mirror defogger is OK.  
NO >> Refer to [DEF-16, "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006345721

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No.13, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

#### 2.CHECK FUSE BLOCK (J/B)

1. Disconnect fuse block (J/B) connector.
2. Turn ignition switch ON.
3. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)	Connector				
M3	9C	Ground	Rear window defogger switch: ON	Battery voltage	
			Rear window defogger switch: OFF	0	
	10C		Rear window defogger switch: ON	Battery voltage	
			Rear window defogger switch: OFF	0	

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace fuse block (J/B).

#### 3.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

# DRIVER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

## DRIVER SIDE DOOR MIRROR DEFOGGER

### Description

INFOID:0000000006345722

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

### Component Function Check

INFOID:0000000006345723

#### 1.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the driver side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Driver side door mirror defogger is OK.  
NO >> Refer to [DEF-17, "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006345724

#### 1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (driver side) harness connector and ground.

(+) Door mirror (driver side)		(-) Connector	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D3	7	Ground	Rear window defogger switch: ON	Battery voltage
			Rear window defogger switch: OFF	0

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between fuse block (J/B) harness connector and door mirror (driver side) harness connector.

Fuse block (J/B)		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M3	10C	D3	7	Existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness between fuse block (J/B) and door mirror (driver side).

#### 3.CHECK FUSE BLOCK (J/B) OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) harness connector and ground.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# DRIVER SIDE DOOR MIRROR DEFOGGER

## < DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (V) (Approx.)
Fuse block (J/B)	Terminal			
Connector	Terminal	Ground	Rear window defogger switch: ON	Battery voltage
M3	10C		Rear window defogger switch: OFF	0

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace fuse block (J/B).

## 4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror (driver side) harness connector and ground.

Door mirror (driver side)		Ground	Continuity
Connector	Terminal		
D3	19		Existed

Is the inspection result normal?

YES >> Replace door mirror glass (driver side). Refer to [MIR-117, "GLASS MIRROR : Removal and Installation".](#)

NO >> Repair or replace harness between door mirror (driver side) and ground.

## 5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#)

>> INSPECTION END

# PASSENGER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

## PASSENGER SIDE DOOR MIRROR DEFOGGER

### Description

INFOID:0000000006345725

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

### Component Function Check

INFOID:0000000006345726

#### 1.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the passenger side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Passenger side door mirror defogger is OK.  
NO >> Refer to [DEF-19, "Diagnosis Procedure"](#)

### Diagnosis Procedure

INFOID:0000000006345727

#### 1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (passenger side) harness connector and ground.

(+) Door mirror (Passenger side)		(-) Connector	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D33	7	Ground	Rear window defogger switch: ON	Battery voltage
			Rear window defogger switch: OFF	0

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between fuse block (J/B) harness connector and door mirror (passenger side) harness connector.

Fuse block (J/B)		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M3	9C	D33	7	Existed

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness between fuse block (J/B) and door mirror (passenger side).

#### 3.CHECK FUSE BLOCK (J/B) OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) harness connector and ground.

DEF

# PASSENGER SIDE DOOR MIRROR DEFOGGER

## < DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (V) (Approx.)
Fuse block (J/B)	Terminal			
Connector	Terminal	Ground	Rear window defogger switch: ON	Battery voltage
M3	9C		Rear window defogger switch: OFF	0

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace fuse block (J/B).

## 4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror (passenger side) harness connector and ground.

Door mirror (passenger side)		Ground	Continuity
Connector	Terminal		
D33	19		Existed

Is the inspection result normal?

YES >> Replace door mirror glass (passenger side). Refer to [MIR-117, "GLASS MIRROR : Removal and Installation".](#)

NO >> Repair or replace harness between door mirror (passenger side) and ground.

## 5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#)

>> INSPECTION END


# REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## REAR WINDOW DEFOGGER SYSTEM

### Wiring Diagram - DEFOGGER SYSTEM -

INFOID:0000000006345728



# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

DEFROGGER		Connector No.	DI	39 O	Connector No.	D31
Connector No.		Connector Name	WIRE TO WIRE	40 BR	Connector Name	WIRE TO WIRE
Connector Name		Connector Type	TH40FW-CS15	41 L	Connector Type	TH40FW-CS15
HS				42 GR		- [With automatic drive positioner]
				43 BR		- [Without automatic drive positioner]
				43 O		- [Without automatic drive positioner]
				44 W		- [With automatic drive positioner]
				44 GR		- [Without automatic drive positioner]
				45 Y		- [With automatic drive positioner]
				45 G		- [Without automatic drive positioner]
				46 G		- [With automatic drive positioner]
				46 V		- [Without automatic drive positioner]
				49 GR		- [Without automatic drive positioner]
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.
1	R	-	50	B	-	7 R
2	B	-	52	R	-	8 BR
3	V	-	53	SB	-	9 V
4	W	-	54	O	-	12 P
5	L	-	55	Y	-	13 LG
6	O	-				14 B
7	GR	-				15 W
8	W	-				16 BR
9	O	-				17 B
10	BR	-				18 R
11	P	-				19 Y
12	LG	-				20 S
13	B	-				20 R
14	Y	-				21 G
15	W	-				21 BR
16	R	-				22 V
17	W	-				23 P
18	G	-				24 W
19	Y	-				25 SB
20	W	-				26 R
21	O	-				29 SHIELD
22	P	-				30 W
23	BR	-				31 LG
24	V	-				32 BR
25	GR	-				33 O
26	Y	-				34 GR
27	Y	-				35 G
28	SHIELD	-				43 Y
29	LG	-				44 V
30	G	-				45 P
31	W	-				46 W
32	G	-				46 G
33	L	-				52 G
34	SB	-				53 GR
35	R	-				54 O
36	LG	-				55 L
37	R	-				P
38	P	-				

JCLWA4439GB

# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

DEFROGGER		
Connector No.	Connector Name	Connector Type
D33	DOOR MIRROR (PASSENGER SIDE)	TH24MW-NH
12 11 10 9 8 7 6 5 4 3 2 1 24 23 22 21 20 19 18 17 16 15 14 13		
		
Terminal No.	Color of Wire	Signal Name [Specification]
3	W	SIDE CAMERA RH COMM
4	LG	SIDE CAMERA RH IMAGE SIGNAL
5	B	SIDE CAMERA RH POWER SUPPLY
6	R	-
7	L	-
10	G	-
11	GR	-
12	O	-
16	BR	-
17	G	SIDE CAMERA RH IMAGE GND
18	Y	SIDE CAMERA RH GND
19	B	-
21	P	-
22	Y	-
23	W	-
24	V	-

REAR WINDOW DEFOGGER		
Connector No.	Connector Name	Connector Type
D108	REAR WINDOW DEFOGGER	M024NB-P-LC
43 SB 44 BR 45 G 46 R		
		
Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	G	-
3	B	-
4	Y	-
5	V	-
6	B	-

POWER DISTRIBUTION MODULE		
Connector No.	Connector Name	Connector Type
E6	POWER DISTRIBUTION MODULE	TH08FW-NH
39 P 40 L 41 BW 42 Y		
		
Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	G	-
3	B	-
4	Y	-
5	V	-
6	B	-

JCLWA4440GB

A

B

C

D

E

F

G

H

I

K

DEF

M

Z

O

P

# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

DEFROGGER			
Connector No.	E106	Signal Name [Specification]	
Connector Name	WIRE TO WIRE		
Connector Type	THBDFW-CS16-TM4		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	R	64	B
2	W	65	G
3	B	66	R
4	GR	67	SHEILD
5	GR	68	Y
8	Y	69	LG
9	BR	70	W
10	EG	71	R
11	SB	72	Y
12	BG	73	B
13	L	74	BR
14	R	74	L
15	P	75	G
16	V	75	W
17	SB	76	Y
18	V	76	-
20	BG	77	R
21	L	77	-
22	V	78	L
23	G	78	BR
24	P	79	Y
25	Y	79	L
26	V	80	-
27	W	81	R
28	G	82	-
31	EG	83	BR
32	W	84	G
33	B	85	L
34	R	86	P
35	G	87	Y
36	SHEILD	89	GR
37	V	90	SHEILD
38	BR	91	W
39	BG	92	Y
41	W	93	Y
42	G	94	LG
43	BR	95	BG
45	W	96	P
		97	R

FUSE BLOCK (J/B)			
Connector No.	M3	Signal Name [Specification]	
Connector Name	FUSE BLOCK (J/B)		
Connector Type	NS12FW-CS		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	C	5C4C	3C2C1C
2	BR	12C1C	10C1C
3	Y	13C1C	8C7C6C
4	P	-	-

FUSE BLOCK (J/B)			
Connector No.	M1	Signal Name [Specification]	
Connector Name	FUSE BLOCK (J/B)		
Connector Type	NS06FW-M2		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	A	3A	2A1A
2	TA	3A	7A6A5A4A
3	TA	-	-
4	TA	-	-
5	TA	-	-
6	TA	-	-

FUSE BLOCK (J/B)			
Connector No.	M2	Signal Name [Specification]	
Connector Name	FUSE BLOCK (J/B)		
Connector Type	NS10FW-CS		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	A	1A	GR
2	BR	2A	G
3	Y	3A	L
4	P	4A	P
5	V	5A	V
6	Y	6A	-
7	R	7A	R
8	W	8A	L

JCLWA4441GB

# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**



DEFROGGER		M6		M5		M24		DEF	
Connector No.	WIRE TO WIRE	39	BG	25	Y	51	SB	-	A
Connector Name		40	SB	26	V	52	SE	-	B
Connector Type	TH4DMW-CS15	41	L	27	G	53	V	-	C
		42	R	28	G	54	G	-	D
		43	BR	31	L	55	L	-	E
		44	Y	32	G	56	P	-	F
		45	G	33	B	57	W	-	G
		46	V	34	W	58	GR	-	H
		46	V	35	R	59	SHIELD	-	I
		49	P	36	SHIELD	90	W	-	J
		50	B	37	V	91	W	-	K
		52	R	38	BG	92	Y	-	L
		53	V	39	BR	93	BR	-	M
Terminal Color No. of Wire	Signal Name [Specification]	54	LG	41	W	94	P	-	N
1	R	55	SB	42	BG	95	GR	-	O
2	B			43	BG	96	W	-	P
3	BR			45	W	97	L	-	Q
4	P			49	L	98	SHIELD	-	R
5	L			50	P	99	V	-	S
6	R			51	BR	100	SB	-	T
7	R			52	L				U
8	W			53	P				V
9	G			54	Y				W
10	L			55	BR				X
11	G			57	G				Y
12	V			59	W				Z
13	B			60	L				AA
14	Y			61	G				AB
15	W			62	SB				AC
16	R			63	G				AD
17	B			64	B				AE
18	G			65	W				AF
19	Y			66	R				AG
20	L			67	SHIELD				AH
21	LG			68	Y				AI
22	L			69	GR				AJ
23	G			70	LG				AK
24	Y			71	LG				AL
25	GR			72	Y				AM
26	R			73	SB				AN
27	W			74	BR				AO
28	SHIELD			74	L				AP
29	Y			75	G				AQ
30	Y			76	W				AR
31	R			76	GR				AS
32	BR			77	R				AT
33	SB			77	P				AU
34	Y			78	L				AV
35	P			78	R				AW
36	LG			79	Y				AX
37	BR			79	W				AY
38	P			80	SB				AZ

JCLWA4442GB

DEF

# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

DEFROGGER					
Connector No.	M72	Connector Name	BCM (BODY CONTROL MODULE)		
Connector Name	MULTIFUNCTION SWITCH	Connector Type	NS16FW-CS		
Connector Type	TH16FW-NH				
					
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal Color of Wire		
1	B	GND	4	LG	INTERIOR ROOM AMP POWER SUPPLY
3	V	ACC	5	L	PASSENGER DOOR UNLOCK OUTPUT
4	R	ILL.	7	Y	STEP LAMP OUTPUT
5	Y	ILL. CONT	8	V	ALL DOOR FUEL LID LOCK OUTPUT
6	SB	AV COMM (H)	9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
8	LG	AV COMM (L)	10	BR	REAR DOOR UNLOCK OUTPUT
9	B	SW GND	11	BR	BAT (FUSE)
14	Y	DISK EJECT SIGNAL	13	B	SW
16	G	HAZARD ON	14	W	PUSH+BUTTON IGNITION SW (L) GND
Connector No.	M119	Connector Name	BCM (BODY CONTROL MODULE)		
Connector Name	MD3FB-LC	Connector Type	TH40FB-NH		
					
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F-L)	113	P	OPTICAL SENSOR
2	W	POWER WINDOW POWER SUPPLY(BAT)	116	SB	STOP AMP SW 1
3	Y	POWER WINDOW POWER SUPPLY(BAT)	119	SB	STOP AMP SW 2
72	R	ROOM ANT-	121	BR	DE/DOOR UNLOCK SENSOR
73	G	ROOM ANT+	123	W	KEY SLOT SW
74	SB	PASSENGER DOOR ANT-	124	LG	IGN / E/B
75	GR	PASSENGER DOOR ANT+	132	BR	PASSENGER DOOR SW
76	V	DRIVER DOOR ANT-	133	W	POWER WINDOW SW COMM
77	LG	DRIVER DOOR ANT+	134	GR	PUSH+BUTTON IGNITION SW(L) POWER
78	V	ROOM ANT-			LOCK IND
80	BR	ROOM ANT+			
<b>REAR WINDOW DEFROGGER RELAY CONT</b>					
81	W	NATS ANT AMP	137	BG	RECEIVER/SENSOR GND
82	R	IGN RELAY (F-S) CONT	138	Y	RECEIVER/SENSOR POWER SUPPLY
83	Y	KEYLESS ENTRY RECEIVER COMM	139	L	TIRE PRESSURE RECEIVER COMM
87	BR	COMBI SW INPUT 5	140	GR	SHIFT N/P
88	V	COMBI SW INPUT 3	141	G	SECURITY INDICATOR OUTPUT
90	BR	PUSH SW	142	BG	COMBI SW INPUT 5
90	P	CAN-L	143	P	COMBI SW OUTPUT 1
91	L	CAN-H	144	G	COMBI SW OUTPUT 2
92	LG	KEY SLOT ILL.	145	L	COMBI SW OUTPUT 3
93	V	ON IND.	146	SE	COMBI SW OUTPUT 4
94	Y	PUDDLE LAMP CONT	150	LG	DRIVER DOOR SW
95	BG	ACC RELAY CONT	151	G	REAR WINDOW DEFROGGER RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY			
97	L	S/L CONDITION 1			
98	P	S/L CONDITION 2			
99	R	SHIFT P			
100	G	PASSENGER DOOR REQUEST SW			
101	SB	DRIVER DOOR REQUEST SW			
102	BG	BLOWER FAN MOTOR RELAY CONT			
103	LG	BLOWER FAN MOTOR RELAY CONT			
106	W	S/L UNIT POWER SUPPLY			
107	LG	COMBI SW INPUT 1			
108	R	COMBI SW INPUT 4			
109	Y	COMBI SW INPUT 2			
110	G	HAZARD SW			
111	Y	S/L UNIT COMM			
19	V	ROOM LAMP TIMER CONTROL			

JCLWA4443GB

# REAR WINDOW DEFOGGER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

A

B

C

D

E

F

G

H

I

J

K

DEF

M

Z

O

P

DEFROGGER		Connector No.	M209	AV COMM (H)
Terminal Color No.	Signal Name [Specification]	Connector No.	M209	CAN-L
7 Y	-	Connector Name	AV CONTROL UNIT	P
8 LG	-	Connector Type	TH24FV-NH	L
9 Y	-			B
12 L	-			SHIELD
13 V	-			
14 B	-			
15 W	-			
16 BR	-			
17 B	-			
18 R	-			
19 B	-			
20 Y	- (With BOSE audio) - (Without BOSE audio)	Connector No.	M209	CAN-H
21 G	- (With BOSE audio) - (Without BOSE audio)	Connector Name	AV CONTROL UNIT	SW GND
22 SB	-	Connector Type	TH24FV-NH	SHIELD
23 GR	-			
24 G	-			
25 Y	-			
26 R	-			
29 SHIELD	-			
30 W	-			
31 LG	-			
32 G	-			
33 BR	-			
34 V	-			
35 G	-			
43 L	-			
44 Y	-			
45 R	-			
46 W	-			
52 R	-			
53 G	-			
54 W	-			
55 BG	-			

DEFROGGER		Connector No.	M209	AV COMM (H)											
Terminal Color No.	Signal Name [Specification]	Connector No.	M209	CAN-L											
76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91
92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107

JCLWA4444GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### BCM (BODY CONTROL MODULE)

#### Reference Value

INFOID:000000006937045

#### VALUES ON THE DIAGNOSIS TOOL

##### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Steering is unlocked	Off
S/L UNLK-IPDM <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Steering is locked	On
	Steering is unlocked	Off
S/L RELAY-REQ <b>NOTE:</b> For models without steering lock unit, this item is not monitored.	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK.	On
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT




PHYSICAL VALUES

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (W)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					Battery voltage
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	
13 (B)	Ground	Ground	—	Ignition switch ON	
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC







# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	A B C D E F G H I J K DEF M N O P
+	-	Signal name	Input/ Output				
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V	PKID0926E
					Turn signal switch RH	 6.5 V	
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V	PKID0926E
					Turn signal switch LH	 6.5 V	
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage	H
					ON	0 V	
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V	PKID0926E
					Turn signal switch RH	 6.5 V	
23 (G)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage	DEF
					Other than OPEN (Back door opener actuator is not activated)	0 V	
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V	PKID0926E
					Turn signal switch LH	 6.5 V	
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V	DEF
					ON (Operated)	Battery voltage	




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
34 (SB)	Ground	Luggage room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment			
				 (V) 15 10 5 0 JMKA0062GB			
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compartment			
				 (V) 15 10 5 0 JMKA0063GB			
38 (B)	Ground	Back door antenna (-)	Output When the back door opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area			
				 (V) 15 10 5 0 JMKA0062GB			
				When Intelligent Key is not in the antenna detection area			
				 (V) 15 10 5 0 JMKA0063GB			





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When Intelligent Key is in the antenna detection area		JMKA0062GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
60* <sup>1</sup> (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (W)	Ground	Back door opener re- quest switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
64 (V)	Ground	Intelligent Key warn- ing buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (BG)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 JPMIA0016GB 1.0 V
					Not in stop position	0 V







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
66 (R)	Ground	Back door switch	Input	Back door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
67 (GR)	Ground	Back door opener switch	Input	Back door opener switch
				Pressed   <small>JPMIA0011GB</small> 11.8 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
				ON (Door open) 0 V
				ON (Door open) 0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

J

K

**DEF**

M

N


O

P


# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
75 (GR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB





JMKIA0062GB



JMKIA0063GB

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	<p>When Intelligent Key is in the passenger compartment</p>  <p>JMKIA0062GB</p>
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	<p>When Intelligent Key is in the passenger compartment</p>  <p>JMKIA0062GB</p>
80 (GR)	Ground	NATS antenna amp.	Input/ Output	<p>Ignition switch is pressed while inserting the key into the key slot.</p> <p>Just after pressing ignition switch. Pointer of tester should move.</p>
81 (W)	Ground	NATS antenna amp.	Input/ Output	<p>Ignition switch is pressed while inserting the key into the key slot.</p> <p>Just after pressing ignition switch. Pointer of tester should move.</p>
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	<p>OFF or ACC</p> <p>ON</p>

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
**DEF**  
 M  
 N  
 O  
 P


# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	<p>During waiting</p>  <p>JMKIA0064GB</p>
				<p>When operating either button on the key</p>  <p>JMKIA0065GB</p>
87 (BR)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>JPMIA0041GB</p> <p>1.4 V</p>
				<p>Front fog lamp switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0037GB</p> <p>1.3 V</p>
				<p>Rear wiper switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0039GB</p> <p>1.3 V</p>
				<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>  <p>JPMIA0040GB</p> <p>1.3 V</p>




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K <b>DEF</b> M N O P	
	Signal name	Input/ Output				
88 (V)	Ground	Combination switch INPUT 3	Input	All switches OFF (Wiper intermittent dial 4)   <small>JPMIA0041GB</small> 1.4 V	A B C D E F G H I J K <b>DEF</b> M N O P	
				Lighting switch HI (Wiper intermittent dial 4)	E F	
					G H I	
				Lighting switch 2ND (Wiper intermittent dial 4)	J K	
					<b>DEF</b> M N O P	
89* <sup>2</sup> (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (push switch)	Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>	M N O P
					1.3 V	<b>DEF</b> M N O P
90 (P)	Ground	CAN-L	Input/ Output	—	—	P
91 (L)	Ground	CAN-H	Input/ Output	—	—	






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 JPMIA0015GB 6.5 V
					ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
97* <sup>2</sup> (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98* <sup>2</sup> (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
					ON (Pressed)	0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
					ON (Pressed)	0 V
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF
106*2 (W)	Ground	Steering lock unit power supply	Output	Ignition switch OFF or ACC ON
107 (LG)	Ground	Combination switch INPUT 1	Input	All switches OFF
				 1.4 V JPMIA0041GB
				Turn signal switch LH
				 1.3 V JPMIA0037GB
				Turn signal switch RH
				 1.3 V JPMIA0036GB
				Front wiper switch LO
				 1.3 V JPMIA0038GB
				Front washer switch ON
				 1.3 V JPMIA0039GB

A

B

C

D

E

F

G

H

I

J

K

DEF

M






N

O

P







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input	 All switches OFF (Wiper intermittent dial 4)   Lighting switch AUTO (Wiper intermittent dial 4)   Lighting switch 1ST (Wiper intermittent dial 4)   Rear wiper switch INT (Wiper intermittent dial 4)   Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>
				JPMIA0041GB 1.4 V
				JPMIA0038GB 1.3 V
				JPMIA0036GB 1.3 V
				JPMIA0040GB 1.3 V

# BCM (BODY CONTROL MODULE)



## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	Signal name	Input/ Output				
109 (Y)	Ground	Combination switch INPUT 2	Input  Combination switch (Wiper intermittent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V	A
				Lighting switch PASS	 JPMIA0037GB 1.3 V	B
				Lighting switch 2ND	 JPMIA0036GB 1.3 V	C
				Front wiper switch INT	 JPMIA0038GB 1.3 V	D
				Front wiper switch HI	 JPMIA0040GB 1.3 V	E
110 (G)	Ground	Hazard switch	Input  Hazard switch	ON	0 V	F
				OFF	 JPMIA0012GB 1.1 V	G

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
DEF  
M  
N  
O  
P




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
111*2 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage	
					LOCK or UNLOCK	 (V) 15 10 5 0 50 ms	
					For 15 seconds after UN-LOCK	Battery voltage	
					15 seconds or later after UNLOCK	0 V	
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 (V) 15 10 5 0 10 ms	
					UNLOCK status (Unlock switch sensor ON)	1.1 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K DEF M N O P
	+	-			
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch OFF (Door close)  ON (Door open)	 JPMIA0011GB 11.8 V
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON  Ignition switch OFF or ACC	 JPMIA0013GB 10.2 V
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination  ON (Tail lamps OFF)  ON (Tail lamps ON)	9.5 V  <b>NOTE:</b> The pulse width of this wave is varied by the illumination brightening/dimming level.  JPMIA0159GB
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp OFF ON	Battery voltage  0 V
137 (BG)	Ground	Receiver and sensor ground	Input	Ignition switch ON	0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch OFF ACC or ON	0 V  5.0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever
141 (G)	Ground	Security indicator	Output	Security indicator
142 (BG)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
144 (G)	Ground	Combination switch OUTPUT 2	Output	All switches OFF (Wiper intermittent dial 4)  Front washer switch ON (Wiper intermittent dial 4)  Rear wiper switch ON (Wiper intermittent dial 4)  Rear washer switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>
145 (L)	Ground	Combination switch OUTPUT 3	Output	All switches OFF  Front wiper switch INT  Front wiper switch LO  Lighting switch AUTO
146 (SB)	Ground	Combination switch OUTPUT 4	Output	All switches OFF  Front fog lamp switch ON  Lighting switch 2ND  Lighting switch PASS  Turn signal switch LH
150 (LG)	Ground	Driver door switch	Input	OFF (Door close)  ON (Door open)
151 (G)	Ground	Rear window defogger relay control	Output	Active  Not activated
				Battery voltage

**NOTE:**





- \*1: Without steering lock unit
- \*2: With steering lock unit

A  
B  
C  
D  
E

F  
G  
H  
I  
J  
K

DEF

M  
N  
O  
P




# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - BCM -

INFOID:0000000006937046




2010/09/21

JCMWA6166GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWA6167GB



A B C D E F G H I J K L M N O P Q R S T U V Z DEF

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


-  With sunroof
-  With automatic drive positioner
-  Without automatic drive positioner

A/T ASSEMBLY  
(F51)



140

BCM (BODY CONTROL MODULE)  
(M118) (M119) (M120), (M121) (M122) (M123)




\* : This connector is not shown in "Harness Layout".

JCMWA6168GB

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWA6169GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWA6170GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M33	COMBINATION SWITCH	TH16FW-NH	1	P	FR WASHER(-)	4	LG	INTERIOR ROOM LAMP POWER SUPPLY
			2	SB	OUTPUT 4	5	L	PASSENGER DOOR UNLOCK OUTPUT
			3	GR	FR WASHER(+)	7	Y	STEP LAMP OUTPUT
			4	G	IGN	8	V	ALL DOOR FUEL LID LOCK OUTPUT
			5	L	OUTPUT 3	9	W	DRIVER DOOR FUEL LID UNLOCK OUTPUT
			6	B	GRND	10	BR	REAR DOOR UNLOCK OUTPUT
			7	V	INPUT 3	11	R	BAT (FUSE)
			8	BG	OUTPUT 5	13	B	GRND
			9	Y	INPUT 2	14	W	PUSH-BUTTON IGNITION SW LL GND
			10	R	INPUT 4	15	Y	ACC IND
			11	LG	INPUT 1	17	V	TURN SIGNAL RH (FRONT)
			12	P	OUTPUT 1	18	BG	TURN SIGNAL LH (FRONT)
			13	BR	INPUT 5	19	V	ROOM LAMP-TIMER CONTROL
			14	G	OUTPUT 2			

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M119	BCM (BODY CONTROL MODULE)	NS16FW-CS	1	HS	

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M121	BCM (BODY CONTROL MODULE)	TH40FB-NH	80	GR	NATS ANT AMP.
			81	W	NATS ANT AMP.
			82	R	IGN RELAY (F/B) CONT
			83	Y	KEYLESS ENTRY RECEIVER COMM
			87	BR	COMBI SW INPUT 5
			88	V	COMBI SW INPUT 3
			89	BR	PUSH SW (With steering lock unit)
			90	P	CAN-L
			91	L	CAN-H
			92	LG	KEY SLOT ILL
			93	V	ON IND
			94	Y	PUDDLE LAMP CONT
			95	BG	AC RELAY CONT
			96	GR	A/T SHIFT SELECTOR POWER SUPPLY
			97	L	S/L CONDITION 1
			98	P	S/L CONDITION 2
			99	R	SHIFT P
			100	G	PASSENGER DOOR REQUEST SW
			101	SB	DRIVER DOOR REQUEST SW
			102	BG	BLOWER FAN MOTOR RELAY CONT
			103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
			106	W	S/L UNIT POWER SUPPLY
			107	LG	COMBI SW INPUT 1
			108	R	COMBI SW INPUT 4
			109	Y	COMBI SW INPUT 2
			110	G	HAZARD SW
			111	Y	S/L UNIT COMM

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M122	BCM (BODY CONTROL MODULE)	TH40FB-NH	1	HS	

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M120	BCM (BODY CONTROL MODULE)	NS12FW-CS	20	V	TURN SIGNAL RH (REAR)
			23	G	BACK DOOR OPEN OUTPUT
			25	G	TURN SIGNAL LH (REAR)
			26	G	REAR WIPER OUTPUT
			27	13	
			28	13	
			29	13	
			30	13	
			31	13	

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M123	BCM (BODY CONTROL MODULE)	MS3FB-LC	1	W	BAT (F/L)
			2	W	POWER WINDOW POWER SUPPLY(BAT)
			3	Y	POWER WINDOW POWER SUPPLY(RAP)

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M122	BCM (BODY CONTROL MODULE)	TH40FB-NH	72	R	ROOM ANT2-
			73	G	PASSENGER DOOR ANT-
			74	SB	PASSENGER DOOR ANT+
			75	GR	DRIVER DOOR ANT-
			76	V	DRIVER DOOR ANT+
			77	LG	ROOM ANT1-
			78	Y	ROOM ANT1+

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M122	BCM (BODY CONTROL MODULE)	TH40FB-NH	1	HS	

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M120	BCM (BODY CONTROL MODULE)	NS12FW-CS	20	V	TURN SIGNAL RH (REAR)
			23	G	BACK DOOR OPEN OUTPUT
			25	G	TURN SIGNAL LH (REAR)
			26	G	REAR WIPER OUTPUT
			27	13	
			28	13	
			29	13	
			30	13	
			31	13	


Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
M123	BCM (BODY CONTROL MODULE)	MS3FB-LC	1	W	BAT (F/L)
			2	W	POWER WINDOW POWER SUPPLY(BAT)
			3	Y	POWER WINDOW POWER SUPPLY(RAP)

JCMWA6171GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
DEF

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)		
Connector No.	M12/3	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	TH40FG-NH	
		
Terminal No.	Color of Wire	Signal Name [Specification]
1.13	P	OPTICAL SENSOR
1.16	SB	STOP LAMP SW 1
1.18	P	STOP LAMP SW 2
1.19	SB	DR DOOR UNLOCK SENSOR
1.21	BR	KEY SLOT SW
1.23	W	IGN F/B
1.24	LG	PASSENGER DOOR SW
1.32	BR	POWER WINDOW SW COMM
1.33	W	PUSH-BUTTON IGNITION SW/ILL POWER
1.34	GR	LOCK ND
1.37	BG	RECEIVER SENSOR GND
1.38	Y	RECEIVER SENSOR POWER SUPPLY
1.39	L	TIRE PRESSURE RECEIVER COMM
1.40	GR	SHIFT N/P
1.41	G	SECURITY INDICATOR OUTPUT
1.42	BG	COMBI SW OUTPUT 5
1.43	P	COMBI SW OUTPUT 1
1.44	G	COMBI SW OUTPUT 2
1.45	L	COMBI SW OUTPUT 3
1.46	SB	COMBI SW OUTPUT 4
1.50	LG	DRIVER DOOR SW
1.51	G	REAR WINDOW DEFROGGER RELAY CONT

JCMWA6172GB

INFOID:0000000006937047

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (battery voltage)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Power position: IGN</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>• Interlock/PNP switch signal (CAN): OFF</li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (battery voltage)</li> <li>- PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>• BCM steering lock control status</li> <li>• Steering lock condition No. 1 signal status</li> <li>• Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering lock unit status signal (CAN) is received normally</li> <li>• The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering condition No. 1 signal: LOCK (0 V)</li> <li>• Steering condition No. 2 signal: LOCK (Battery voltage)</li> </ul>

## REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

## DTC Inspection Priority Chart

INFOID:000000006937048

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC	
3	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI SCANNING</li> </ul>	A
4	<ul style="list-style-type: none"> <li>• B2013: ID DISCORD BCM-S/L</li> <li>• B2014: CHAIN OF S/L-BCM</li> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP SW</li> <li>• B2605: PNP SW</li> <li>• B2606: S/L RELAY</li> <li>• B2607: S/L RELAY</li> <li>• B2608: STARTER RELAY</li> <li>• B2609: S/L STATUS</li> <li>• B260A: IGNITION RELAY</li> <li>• B260B: STEERING LOCK UNIT</li> <li>• B260C: STEERING LOCK UNIT</li> <li>• B260D: STEERING LOCK UNIT</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2612: S/L STATUS</li> <li>• B2614: ACC RELAY CIRC</li> <li>• B2615: BLOWER RELAY CIRC</li> <li>• B2616: IGN RELAY CIRC</li> <li>• B2617: STARTER RELAY CIRC</li> <li>• B2618: BCM</li> <li>• B2619: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B26E9: S/L STATUS</li> <li>• B26EA: KEY REGISTRATION</li> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• U0415: VEHICLE SPEED SIG</li> </ul>	B C D E F G H I J K
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1734: CONTROL UNIT</li> </ul>	DEF M N O
6	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2622: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>	P

## DTC Index

INFOID:0000000006937049

### NOTE:

- The details of time display are as follows.
- CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	<a href="#">BCS-38</a>
U1010: CONTROL UNIT (CAN)	—	—	—	—	<a href="#">BCS-39</a>
U0415: VEHICLE SPEED SIG	—	—	—	—	<a href="#">BCS-40</a>
B2013: ID DISCORD BCM-S/L*	×	×	—	—	<a href="#">SEC-49</a>
B2014: CHAIN OF S/L-BCM*	×	×	—	—	<a href="#">SEC-50</a>
B2190: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-42</a>
B2191: DIFFERENCE OF KEY	×	—	—	—	<a href="#">SEC-45</a>
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-46</a>
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-47</a>
B2195: ANTI SCANNING	×	—	—	—	<a href="#">SEC-48</a>
B2553: IGNITION RELAY	—	×	—	—	<a href="#">PCS-50</a>
B2555: STOP LAMP	—	×	—	—	<a href="#">SEC-53</a>
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-55</a>
B2557: VEHICLE SPEED	×	×	×	—	<a href="#">SEC-57</a>
B2560: STARTER CONT RELAY	×	×	×	—	<a href="#">SEC-58</a>
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-41</a>
B2601: SHIFT POSITION	×	×	×	—	<a href="#">SEC-59</a>
B2602: SHIFT POSITION	×	×	×	—	<a href="#">SEC-62</a>
B2603: SHIFT POSI STATUS	×	×	×	—	<a href="#">SEC-64</a>
B2604: PNP SW	×	×	×	—	<a href="#">SEC-67</a>
B2605: PNP SW	×	×	×	—	<a href="#">SEC-69</a>
B2606: S/L RELAY*	×	×	×	—	<a href="#">SEC-71</a>
B2607: S/L RELAY*	×	×	×	—	<a href="#">SEC-72</a>
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-74</a>
B2609: S/L STATUS*	×	×	×	—	<a href="#">SEC-76</a>
B260A: IGNITION RELAY	×	×	×	—	<a href="#">PCS-52</a>
B260B: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-80</a>
B260C: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-81</a>
B260D: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-82</a>
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-83</a>
B2612: S/L STATUS*	×	×	×	—	<a href="#">SEC-87</a>
B2614: ACC RELAY CIRC	—	×	×	—	<a href="#">PCS-54</a>
B2615: BLOWER RELAY CIRC	—	×	×	—	<a href="#">PCS-57</a>
B2616: IGN RELAY CIRC	—	×	×	—	<a href="#">PCS-60</a>
B2617: STARTER RELAY CIRC	×	×	×	—	<a href="#">SEC-91</a>
B2618: BCM	×	×	×	—	<a href="#">PCS-63</a>

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2619: BCM*	×	×	×	—	<a href="#">SEC-93</a>
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-94</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-97</a>
B2621: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-59</a>
B2622: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-61</a>
B2623: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-63</a>
B26E1: ENG STATE NO RES	×	×	×	—	<a href="#">SEC-84</a>
B26E9: S/L STATUS*	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-85</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-86</a>
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-23</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	
C1709: [NO DATA] FR	—	—	—	×	<a href="#">WT-25</a>
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-28</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-30</a>
C1734: CONTROL UNIT	—	—	—	×	<a href="#">WT-32</a>

\*: For models without steering lock unit, this DTC is not applied.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# REAR WINDOW DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### REAR WINDOW DEFOGGER DOES NOT OPERATE

#### Diagnosis Procedure

INFOID:000000006345734

#### 1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [DEF-10, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.

Refer to [DEF-11, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-12, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-14, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

# REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

## Diagnosis Procedure

INFOID:0000000006345735

### 1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [DEF-10, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.

Refer to [DEF-11, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-12, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# **REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE.**

< SYMPTOM DIAGNOSIS >

**REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE.**

## **Diagnosis Procedure**

INFOID:000000006345736

### **1.CHECK REAR WINDOW DEFOGGER**

Check rear window defogger.

Refer to [DEF-14, "Component Function Check".](#)

Is the inspection result normal?

YES    >> GO TO 2.

NO      >> Repair or replace the malfunctioning parts.

### **2.CONFIRM THE OPERATION**

Confirm the operation again

Is the inspection result normal?

YES    >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident".](#)

NO      >> GO TO 1.

# DOOR MIRROR DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## DOOR MIRROR DEFOGGER DOES NOT OPERATE BOTH SIDES

### BOTH SIDES : Diagnosis Procedure

INFOID:000000006345737

#### 1. CHECK DOOR MIRROR DEFOGGER

Check door mirror defogger.

Refer to [DEF-16, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

### DRIVER SIDE

#### DRIVER SIDE : Diagnosis Procedure

INFOID:000000006345738

#### 1. CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

Check driver side door mirror defogger.

Refer to [DEF-17, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

### PASSENGER SIDE

#### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000006345739

#### 1. CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER.

Check passenger side door mirror defogger.

Refer to [DEF-19, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

# ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

< SYMPTOM DIAGNOSIS >

## ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

### Diagnosis Procedure

INFOID:000000006345740

#### 1. CHECK AV CONTROL UNIT FUNCTION

Check that the AV control unit is operating normally.

- Base audio without navigation system. Refer to [AV-68, "Work Flow"](#).
- Bose audio without navigation system. Refer to [AV-227, "Work Flow \(Multi AV\)"](#).
- Bose audio with navigation system. Refer to [AV-419, "Work Flow \(Multi AV\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

# REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

### Diagnosis Procedure

INFOID:000000006345741

#### 1.CHECK MULTIFUNCTION SWITCH (REAR WINDOW DEFOGGER SWITCH)

Check rear window defogger operate.

Is the inspection result normal?

YES    >> Replace multifunction switch (rear window defogger switch). Refer to [AV-134, "Removal and Installation"](#) (Base audio without navigation system), [AV-325, "Removal and Installation"](#) (Bose audio without navigation system) or [AV-525, "Removal and Installation"](#) (Bose audio with navigation system).

NO    >> Check rear window defogger system. Refer to [DEF-3, "Work Flow"](#)

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000006922923

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

# FILAMENT

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION FILAMENT

### Inspection and Repair

INFOID:000000006345743


#### INSPECTION

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.




SEL122R

- Attach probe circuit tester (in Volt range) to middle portion of each filament.



SEL263

- If a filament is burned out, circuit tester registers 0 or battery voltage.
- To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



SEL265

### REPAIR

#### REPAIR EQUIPMENT

- Conductive silver composition (Dupont No. 4817 or equivalent)


# FILAMENT

## < REMOVAL AND INSTALLATION >


- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

## REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.  
Shake silver composition container before use.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.  
Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.  
If a heat gun is not available, let the repaired area dry for 24 hours.

