

SECTION **MIR**
MIRRORS

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

CONTENTS

| | |
|--|------------|
| WITH ADP | |
| BASIC INSPECTION | 3 |
| DIAGNOSIS AND REPAIR WORKFLOW | 3 |
| Work Flow | 3 |
| SYSTEM DESCRIPTION | 4 |
| DOOR MIRROR SYSTEM | 4 |
| System Diagram | 4 |
| System Description | 4 |
| Component Parts Location | 6 |
| Component Description | 6 |
| INSIDE MIRROR SYSTEM | 8 |
| System Description | 8 |
| Component Description | 8 |
| DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT) | 9 |
| Diagnosis Description | 9 |
| CONSULT-III Function | 9 |
| DTC/CIRCUIT DIAGNOSIS | 12 |
| DOOR MIRROR REMOTE CONTROL SWITCH | 12 |
| MIRROR SWITCH | 12 |
| MIRROR SWITCH : Description | 12 |
| MIRROR SWITCH : Component Function Check... .. | 12 |
| MIRROR SWITCH : Diagnosis Procedure | 12 |
| MIRROR SWITCH : Component Inspection | 13 |
| CHANGEOVER SWITCH | 14 |
| CHANGEOVER SWITCH : Description | 14 |
| CHANGEOVER SWITCH : Component Function Check | 14 |
| CHANGEOVER SWITCH : Diagnosis Procedure... .. | 14 |
| CHANGEOVER SWITCH : Component Inspection | 15 |
| DOOR MIRROR SYSTEM | 17 |
| Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) - | 17 |
| AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM | 26 |
| Wiring Diagram - INSIDE MIRROR SYSTEM - | 26 |
| ECU DIAGNOSIS INFORMATION | 28 |
| DRIVER SEAT CONTROL UNIT | 28 |
| Reference Value | 28 |
| Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM - | 33 |
| Fail Safe | 47 |
| DTC Index | 48 |
| AUTOMATIC DRIVE POSITIONER CONTROL UNIT | 49 |
| Reference Value | 49 |
| Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM - | 53 |
| BCM (BODY CONTROL MODULE) | 68 |
| Reference Value | 68 |
| Wiring Diagram - BCM - | 92 |
| Fail-safe | 98 |
| DTC Inspection Priority Chart | 100 |
| DTC Index | 101 |
| SYMPTOM DIAGNOSIS | 104 |
| DOOR MIRROR DOES NOT OPERATE | 104 |
| Diagnosis Procedure | 104 |
| REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE | 105 |
| Diagnosis Procedure | 105 |
| SQUEAK AND RATTLE TROUBLE DIAGNOSES | 106 |
| Work Flow | 106 |

MIR

| | | | |
|--|------------|--|------------|
| Inspection Procedure | 108 | DOOR MIRROR SYSTEM | 121 |
| Diagnostic Worksheet | 110 | Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) - | 121 |
| PRECAUTION | 112 | AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM | 124 |
| PRECAUTIONS | 112 | Wiring Diagram - INSIDE MIRROR SYSTEM - ... | 124 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 112 | SYMPTOM DIAGNOSIS | 126 |
| PREPARATION | 113 | SQUEAK AND RATTLE TROUBLE DIAG- NOSES | 126 |
| PREPARATION | 113 | Work Flow | 126 |
| Commercial Service Tools | 113 | Inspection Procedure | 128 |
| REMOVAL AND INSTALLATION | 114 | Diagnostic Worksheet | 130 |
| INSIDE MIRROR | 114 | PRECAUTION | 132 |
| Exploded View | 114 | PRECAUTIONS | 132 |
| Removal and Installation | 114 | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 132 |
| OUTSIDE MIRROR | 116 | PREPARATION | 133 |
| Exploded View | 116 | PREPARATION | 133 |
| DOOR MIRROR ASSEMBLY | 116 | Commercial Service Tools | 133 |
| DOOR MIRROR ASSEMBLY : Removal and In- stallation | 116 | REMOVAL AND INSTALLATION | 134 |
| DOOR MIRROR ASSEMBLY : Disassembly and Assembly | 117 | INSIDE MIRROR | 134 |
| GLASS MIRROR | 117 | Exploded View | 134 |
| GLASS MIRROR : Removal and Installation | 117 | Removal and Installation | 134 |
| DOOR MIRROR COVER | 117 | OUTSIDE MIRROR | 136 |
| DOOR MIRROR COVER : Removal and Installa- tion | 117 | Exploded View | 136 |
| DOOR MIRROR REMOTE CONTROL SWITCH | 118 | DOOR MIRROR ASSEMBLY | 136 |
| Exploded View | 118 | DOOR MIRROR ASSEMBLY : Removal and In- stallation | 136 |
| Removal and Installation | 118 | DOOR MIRROR ASSEMBLY : Disassembly and Assembly | 137 |
| WITHOUT ADP | | GLASS MIRROR | 137 |
| SYSTEM DESCRIPTION | 119 | GLASS MIRROR : Disassembly and Assembly .. | 137 |
| DOOR MIRROR SYSTEM | 119 | DOOR MIRROR COVER | 137 |
| Component Description | 119 | DOOR MIRROR COVER : Disassembly and As- sembly | 137 |
| INSIDE MIRROR SYSTEM | 120 | DOOR MIRROR REMOTE CONTROL SWITCH | 138 |
| System Description | 120 | Exploded View | 138 |
| Component Description | 120 | Removal and Installation | 138 |
| DTC/CIRCUIT DIAGNOSIS | 121 | | |

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006346064

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2.CHECK DTC

Perform self-diagnosis for automatic drive positioner (ADP) with CONSULT-III.

Is any DTC detected?

YES >> Refer to [ADP-144. "DTC Index"](#)

NO >> GO TO 3.

3.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

4.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

5.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

6.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P


MIR

SYSTEM DESCRIPTION

DOOR MIRROR SYSTEM

System Diagram

INFOID:000000006346065



System Description

INFOID:000000006346066

MANUAL FUNCTION

Description

- Automatic drive positioner control unit controls door mirror.
- Automatic drive positioner control unit inputs changeover switch signal and perform the LH/RH control of door mirror motor supplying electric power when changeover switch is operated.
- Automatic drive positioner control unit inputs mirror switch signal and supplies electric power to door mirror.
- The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

- Ignition switch: ON or ACC
- Changeover switch: Select either left or right

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Description

- Select one of the door mirror faces by change over switch, and then set the selected mirror face downward/inward.
- When the ignition switch is ON position and A/T shift selector is in R position, the TCM sends the R signal to the driver seat control unit. The R signal is transmitted to the automatic drive positioner control unit from the driver seat control unit via UART communication. When the R signal is detected, the automatic device positioner control unit activated the mirror motor.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

DOOR MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

- Ignition switch: ON
- Changeover switch: Select either left or right
- A/T shift selector: R position

During the reverse interlock door mirror system, if all of the above conditions are not satisfied, mirror face returns to original angle.

Mirror Angle Memory Function

- During the reverse interlock door mirror operation, the mirror angle can be changed. After adjustment, the mirror face positions can be memorized (2 positions). For memory setting.
- Initial setting is downward 7°, inward 1° (both of left and right).
- When the driver's seat, outside mirror and steering column are not in the memorized position, the outside mirror will move with the initial tilt-down angle, if the reverse tilt-down position is stored. Linking Intelligent Key to a stored memory position.

Memory Procedure

1. Apply the parking brake.
2. Push the ignition switch to the ON position. (Do not start the engine.)
3. Push the memory switch 1 or 2 fully for at least 1 second to operate the automatic drive positioner.
4. Turn the door mirror control switch (changeover switch) to L (left).
5. Depress the brake pedal.
6. Move the A/T shift selector to R position (reverse).
7. Adjust the mirror to the desired viewing position for backing up by operating the door mirror control switch (mirror switch).
8. Push the SET switch and, within 5 seconds, push the memory switch 1 or 2 selected in step 3 fully for at least 1 second.
The indicator light for the pushed memory switch will come on and stay pushing the switch. After the indicator light goes off, the selected mirror position is stored in the selected memory (1 or 2).
9. Turn the door mirror control switch (changeover switch) to R (right).
Repeat the above procedure to adjust the right mirror position and store in the selected memory.

AUTOMATIC DRIVE POSITIONER SYSTEM LINKED OPERATION

Description

Door mirror control is included in automatic drive positioner system. Refer to automatic drive positioner system for more details.

Refer to [ADP-13. "AUTOMATIC DRIVE POSITIONER SYSTEM : System Description"](#).

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P


DOOR MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITH ADP]

Component Parts Location

INFOID:000000006346067



JMLIA0129ZZ

- | | | |
|---|--|--|
| 1. Door mirror remote control switch D17 | 2. Door mirror (driver side) D3 | 3. Door mirror (passenger side) D33 |
| 4. Automatic drive positioner control unit M51, M52 | 5. Driver seat control unit B451, B452 | 6. AT assembly connector (TCM) F51 |
| 7. BCM M118, M119, M122 | | |
| A. View with instrument driver lower panel removed | B. Back side of the seat cushion | C. AT assembly (TCM is built in AT assembly) |
| D. Dash side lower (passenger side) | | |

Component Description

INFOID:000000006346068

| Component | | Function |
|---|-------------------|---|
| Automatic drive positioner control unit | | Door mirror is supplied with power after receiving the input of the MIRROR SWITCH and CHANGEOVER SWITCH. |
| Door mirror remote control switch | Mirror switch | It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT. |
| | Changeover switch | It transmits the LH/RH control of door mirror that supplies power to AUTOMATIC DRIVE POSITIONER CONTROL UNIT. |
| Door mirror | | It makes mirror face operate from side to side and up and down via integrated motor. |
| BCM | | The ignition switch signal (ACC/ON) is transmitted to driver seat control unit via CAN communication. |

DOOR MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

| Component | Function |
|--------------------------|---|
| Driver seat control unit | The ignition switch signal (ACC/ON) is transmitted to automatic drive positioner control unit via UART communication. |
| TCM | The A/T shift position signal is transmitted to driver seat control unit via CAN communication. |

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

INSIDE MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

INSIDE MIRROR SYSTEM

System Description

INFOID:000000006346069

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:000000006346070

| Component | Function |
|----------------------------------|---|
| Auto anti-dazzling inside mirror | It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind. |

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

Diagnosis Description

INFOID:000000006346071

The auto drive positioner system can be checked and diagnosed for component operation with CONSULT-III.

DIAGNOSTIC MODE

| Diagnostic mode [AUTO DRIVE POS.] | Description |
|--------------------------------------|--|
| WORK SUPPORT | Changes the setting of each function. |
| SELF-DIAG RESULTS | Performs self-diagnosis for the auto drive positioner system and displays the results. |
| DATA MONITOR | Displays input signals transmitted from various switches and sensors to driver seat control unit in real time. |
| CAN DIAG SUPPORT MNTR | The result of transmit/receive diagnosis of CAN communication can be read. |
| ACTIVE TEST | Drive each output device. |
| ECU PART NUMBER | Displays part numbers of driver seat control unit parts. |

CONSULT-III Function

INFOID:000000006346072

SELF-DIAGNOSIS RESULTS

Refer to [ADP-144, "DTC Index"](#).

DATA MONITOR

| Monitor Item | Unit | Main Signals | Selection From Menu | Contents |
|---------------|----------|--------------|---------------------|--|
| SET SW | "ON/OFF" | × | × | ON/OFF status judged from the setting switch signal. |
| MEMORY SW 1 | "ON/OFF" | × | × | ON/OFF status judged from the seat memory switch 1 signal. |
| MEMORY SW 2 | "ON/OFF" | × | × | ON/OFF status judged from the seat memory switch 2 signal. |
| SLIDE SW-FR | "ON/OFF" | × | × | ON/OFF status judged from the sliding switch (forward) signal. |
| SLIDE SW-RR | "ON/OFF" | × | × | ON/OFF status judged from the sliding switch (backward) signal. |
| RECLN SW-FR | "ON/OFF" | × | × | ON/OFF status judged from the reclining switch (forward) signal. |
| RECLN SW-RR | "ON/OFF" | × | × | ON/OFF status judged from the reclining switch (backward) signal. |
| LIFT FR SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch front (up) signal. |
| LIFT FR SW-DN | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch front (down) signal. |
| LIFT RR SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch rear (up) signal. |
| LIFT RR SW-DN | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch rear (down) signal. |
| MIR CON SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the mirror switch (up) signal. |
| MIR CON SW-DN | "ON/OFF" | × | × | ON/OFF status judged from the mirror switch (down) signal. |
| MIR CON SW-RH | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (passenger side) signal. |
| MIR CON SW-LH | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (driver side) signal. |

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

| Monitor Item | Unit | Main Signals | Selection From Menu | Contents |
|----------------|----------|--------------|---------------------|---|
| MIR CHNG SW-R | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (switching to right) signal. |
| MIR CHNG SW-L | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (switching to left) signal. |
| TILT SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the tilt switch (up) signal. |
| TILT SW-DOWN | "ON/OFF" | × | × | ON/OFF status judged from the tilt switch (down) signal. |
| TELESCO SW-FR | "ON/OFF" | × | × | ON/OFF status judged from the telescoping switch (forward) signal. |
| TELESCO SW-RR | "ON/OFF" | × | × | ON/OFF status judged from the telescoping switch (backward) signal. |
| DETENT SW | "ON/OFF" | × | × | The selector lever position "OFF (P position) / ON (other than P position)" judged from the detention switch signal. |
| STARTER SW | "ON/OFF" | × | × | Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal. |
| SLIDE PULSE | — | — | × | Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases. |
| RECLN PULSE | — | — | × | Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases. |
| LIFT FR PULSE | — | — | × | Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases. |
| LIFT RR PULSE | — | — | × | Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases. |
| MIR/SEN RH U-D | "V" | — | × | Voltage input from door mirror sensor (passenger side) up/down is displayed. |
| MIR/SEN RH R-L | "V" | — | × | Voltage input from door mirror sensor (passenger side) left/right is displayed. |
| MIR/SEN LH U-D | "V" | — | × | Voltage input from door mirror sensor (driver side) up/down is displayed. |
| MIR/SEN LH R-L | "V" | — | × | Voltage input from door mirror sensor (driver side) left/right is displayed. |
| TILT SEN | "V" | — | × | Voltage input from tilt sensor is displayed. |
| TELESCO SEN | "V" | — | × | Voltage input from telescopic sensor is displayed. |

ACTIVE TEST

CAUTION:

When driving vehicle, do not perform active test.

| Test item | Description |
|-----------------|--|
| SEAT SLIDE | Activates/deactivates the sliding motor. |
| SEAT RECLINING | Activates/deactivates the reclining motor. |
| SEAT LIFTER FR | Activates/deactivates the lifting motor (front). |
| SEAT LIFTER RR | Activates/deactivates the lifting motor (rear). |
| TILT MOTOR | Activates/deactivates the tilt motor. |
| TELESCO MOTOR | Activates/deactivates the telescopic motor. |
| MIRROR MOTOR RH | Activates/deactivates the mirror motor (passenger side). |

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

| Test item | Description |
|------------------|---|
| MIRROR MOTOR LH | Activates/deactivates the mirror motor (driver side). |
| MEMORY SW INDCTR | Turns ON/OFF the memory indicator. |

WORK SUPPORT

| Work item | Content | Item |
|-------------------------|--|--------|
| SEAT SLIDE VOLUME SET | The amount of seat sliding for entry/exit assist can be selected from 3 items. | 40 mm |
| | | 80 mm |
| | | 150 mm |
| EXIT TILT SETTING | Entry/exit assist (steering column) can be selected: ON (operated) – OFF (not operated) | ON |
| | | OFF |
| EXIT SEAT SLIDE SETTING | Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated) | ON |
| | | OFF |

A
B
C
D
E
F
G
H
I
J
K

MIR

M
N
O
P

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR REMOTE CONTROL SWITCH MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:000000006346073

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

MIRROR SWITCH : Component Function Check

INFOID:000000006346074

1.CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in "DATA MONITOR" mode with CONSULT-III.

| Monitor item | Condition |
|------------------|--|
| MIR CON SW-UP/DN | When operating the mirror switch toward the up or down side. : ON |
| | Other than above. : OFF |
| MIR CON SW-RH/LH | When operating the mirror switch toward the right or left side. : ON |
| | Other than above. : OFF |

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [MIR-12. "MIRROR SWITCH : Diagnosis Procedure"](#).

MIRROR SWITCH : Diagnosis Procedure

INFOID:000000006346075

1.CHECK MIRROR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------------------------|----------|--------|--------------------------|
| Door mirror remote control switch | | | |
| Connector | Terminal | Ground | 5 |
| D17 | 4 | | |
| | 12 | | |
| | 13 | | |
| | 15 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK MIRROR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

| Automatic drive positioner control unit | | Door mirror remote control switch | | Continuity |
|---|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 3 | D17 | 15 | Existed |
| | 4 | | 13 | |
| | 19 | | 12 | |
| | 20 | | 4 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 3 | Ground | Not existed |
| | 4 | | |
| | 19 | | |
| | 20 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-217, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

| Door mirror remote control switch | | Ground | Continuity |
|-----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D17 | 7 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK MIRROR SWITCH

Check door mirror remote control switch (mirror switch).
Refer to [MIR-13, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace door mirror remote control switch (mirror switch). Refer to [MIR-118, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

MIRROR SWITCH : Component Inspection

INFOID:000000006346076

1.CHECK MIRROR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

| Door mirror remote control switch | | Condition | Continuity |
|-----------------------------------|----------|------------------|-------------|
| Connector | Terminal | | |
| D17 | 4 | RIGHT | Existed |
| | | Other than above | Not existed |
| | 13 | LEFT | Existed |
| | | Other than above | Not existed |
| | 15 | UP | Existed |
| | | Other than above | Not existed |
| | 12 | DOWN | Existed |
| | | Other than above | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-118, "Removal and Installation"](#).

CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:000000006346077

Changeover switch is integrated into door mirror remote control switch.

Changeover switch has three positions (L, N and R).

It changes door mirror motor operation by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:000000006346078

1. CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in "DATA MONITOR" mode with CONSULT-III.

| Monitor item | Condition |
|-----------------|---|
| MIR CHNG SW-R/L | When operating the changeover toward the right or left side. : ON |
| | Other than above. : OFF |

Is the inspection result normal?

YES >> Changeover switch function is OK.

NO >> Refer to [MIR-14, "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:000000006346079

1. CHECK CHANGEOVER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------------------------|----------|--------|--------------------------|
| Door mirror remote control switch | | | |
| Connector | Terminal | | |
| D17 | 10 | Ground | 5 |
| | 11 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK CHANGEOVER SWITCH CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

| Automatic drive positioner control unit | | Door mirror remote control switch | | Continuity |
|---|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 2 | D17 | 11 | Existed |
| | 18 | | 10 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 2 | | Not existed |
| | 18 | | |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-217, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

| Door mirror remote control switch | | Ground | Continuity |
|-----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D17 | 7 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK CHANGE OVER SWITCH

Check door mirror remote control switch (changeover switch).
Refer to [MIR-15, "CHANGE OVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace door mirror remote control switch (changeover switch). Refer to [MIR-118, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

CHANGE OVER SWITCH : Component Inspection

INFOID:000000006346080

1.CHECK CHANGE OVER SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

| Door mirror remote control switch | | Terminal | Condition | Continuity |
|-----------------------------------|----|----------|------------------|-------------|
| Connector | | | | |
| D17 | 10 | 7 | LEFT | Existed |
| | | | Other than above | Not existed |
| | 11 | | RIGHT | Existed |
| | | | Other than above | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-118. "Removal and Installation"](#).

DOOR MIRROR SYSTEM

[WITH ADP]


< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -

INFOID:000000006346081

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)



*: This connector is not shown in "Harness Layout".

2010/09/21

JCLWA4342GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]



*: This connector is not shown in "Harness Layout".

JCLWA4343GB


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FN-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | R | - |
| 5 | G | - |
| 6 | SB | - |
| 7 | V | - |
| 8 | L | - |
| 12 | SB | - |
| 13 | LG | - |
| 14 | GR | - |
| 15 | LG | - |
| 17 | W | - |
| 18 | SB | - |
| 19 | LG | - |
| 20 | BR | - |
| 21 | SHIELD | - |
| 22 | Y | - |
| 24 | P | - |
| 27 | B | - |
| 28 | R | - |
| 29 | W | - |
| 30 | SHIELD | - |
| 31 | SHIELD | - |
| 32 | W | - |
| 33 | SB | - |
| 34 | L | - |
| 35 | P | - |
| 36 | L | - |
| 37 | P | - |
| 38 | BR | - |
| 39 | Y | - |
| 44 | Y | - |
| 45 | GR | - |
| 46 | LG | - |
| 47 | SB | - |
| 48 | G | - |
| 50 | V | - |
| 60 | P | - |
| 61 | L | - |
| 62 | SHIELD | - |


| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FN-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 3 | L | - |
| 17 | Y | - |
| 19 | P | - |
| 21 | V | - |
| 32 | B | - |

| | | |
|----|----|---|
| 33 | R | - |
| 40 | BR | - |
| 48 | B | - |
| 53 | B | - |
| 60 | G | - |
| 66 | GR | - |
| 67 | Y | - |

| | |
|----------------|--------------------------|
| Connector No. | B451 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | TH32FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L/W | RX |
| 3 | R/Y | CAN-H |
| 9 | W/G | PULSE (RECLINING) |
| 10 | P/B | PULSE (RR LIFTING) |
| 11 | BR | SLIDING SW (BACKWARD) |
| 12 | SB | RECLINING SW (BACKWARD) |
| 13 | LG/R | FRONT LIFTING SW (DOWNWARD) |
| 14 | G/B | REAR LIFTING SW (DOWNWARD) |
| 16 | O | VCC |
| 17 | Y/R | TX |
| 19 | V | CAN-L |
| 21 | L/Y | P RANGE SW |
| 24 | R | PULSE (SLIDING) |
| 26 | Y/B | PULSE (RR LIFTING) |
| 27 | Y | SLIDING SW (FORWARD) |
| 28 | W/B | RECLINING SW (FORWARD) |
| 29 | P/L | FRONT LIFTING SW (UPWARD) |
| 31 | GR | SENSOR GND |
| 32 | B/W | GND (SIGNAL) |

| | |
|----------------|--------------------------|
| Connector No. | B452 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | NS16FN-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 33 | R | BAT (G/B) |
| 35 | W/R | SLIDING MOTOR (FORWARD) |
| 36 | G/Y | RECLINING MOTOR (FORWARD) |
| 37 | G/W | FRONT LIFTING MOTOR (DOWNWARD) |
| 38 | L/Y | REAR LIFTING MOTOR (UPWARD) |
| 39 | R/B | REAR LIFTING MOTOR (BACKWARD) |
| 40 | R/W | BAT (FUSE) |
| 42 | W/B | SLIDING MOTOR (BACKWARD) |
| 44 | P | RECLINING MOTOR (BACKWARD) |
| 45 | L/R | FRONT LIFTING MOTOR (UPWARD) |
| 48 | B | GND (POWER) |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|--------------|
| Connector No. | B480 |
| Connector Name | WIRE TO WIRE |
| Connector Type | HS16MW-CS |



| | | | | | |
|----|----|----|----|----|----|
| 19 | 3 | 1 | 17 | 40 | 69 |
| 20 | 66 | 32 | 48 | 21 | 33 |
| 67 | 60 | 67 | 60 | | |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L/W | - |
| 3 | R/Y | - |
| 17 | Y/R | - |
| 19 | V | - |
| 21 | L/Y | - |
| 32 | B/W | - |
| 33 | R | - |
| 40 | R/W | - |
| 48 | B | - |
| 58 | Y | - |
| 60 | Y/R | - |
| 66 | B | - |
| 67 | L | - |

| | |
|----------------|--------------|
| Connector No. | D1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40PW-CS15 |



| | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 |
| 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | V | - |
| 4 | W | - |
| 5 | L | - |
| 6 | O | - |
| 7 | GR | - |
| 8 | W | - |
| 9 | O | - |

| | | |
|----|--------|--|
| 10 | BR | - |
| 11 | P | - |
| 12 | LG | - |
| 13 | B | - |
| 14 | Y | - |
| 15 | W | - |
| 16 | R | - |
| 17 | G | - |
| 18 | G | - |
| 19 | Y | - |
| 20 | W | - |
| 21 | O | - |
| 22 | P | - |
| 23 | BR | - |
| 24 | V | - |
| 25 | GR | - |
| 26 | Y | - |
| 27 | B | - |
| 28 | SHIELD | - |
| 29 | LG | - |
| 30 | G | - |
| 31 | W | - |
| 32 | G | - |
| 33 | L | - |
| 34 | SB | - |
| 35 | R | - |
| 36 | LG | - |
| 37 | R | - |
| 38 | P | - |
| 39 | O | - |
| 40 | BR | - |
| 41 | L | - |
| 42 | GR | - [With automatic drive positioner] |
| 43 | BR | - [Without automatic drive positioner] |
| 44 | W | - [With automatic drive positioner] |
| 44 | GR | - [Without automatic drive positioner] |
| 45 | Y | - [With automatic drive positioner] |
| 45 | G | - [Without automatic drive positioner] |
| 46 | G | - [With automatic drive positioner] |
| 46 | V | - [Without automatic drive positioner] |
| 49 | GR | - |
| 50 | B | - |
| 52 | R | - |
| 53 | SB | - |
| 54 | O | - |
| 55 | Y | - |

| | |
|----------------|---------------------------|
| Connector No. | D3 |
| Connector Name | DOOR MIRROR (DRIVER SIDE) |
| Connector Type | TH24MW-NH |



| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | O | - |
| 3 | B | SIDE CAMERA LH COMM |
| 5 | Y | SIDE CAMERA LH IMAGE SIGNAL |
| 6 | R | SIDE CAMERA LH POWER SUPPLY |
| 7 | W | - |
| 10 | G | - |
| 11 | P | - |
| 12 | O | - |
| 14 | LG | - |
| 17 | G | SIDE CAMERA LH IMAGE GND |
| 18 | W | SIDE CAMERA LH GND |
| 19 | B | - |
| 21 | GR | - |
| 22 | BR | - |
| 23 | Y | - |
| 24 | V | - |

| | |
|----------------|-----------------------------------|
| Connector No. | D17 |
| Connector Name | DOOR MIRROR REMOTE CONTROL SWITCH |
| Connector Type | TK10FBR |



| | | | | | | |
|---|---|----|----|----|----|----|
| 8 | 9 | 10 | 11 | 12 | 13 | 15 |
|---|---|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 4 | BR | - |
| 7 | B | - |
| 8 | B | - |
| 9 | R | - |
| 10 | GR | - |
| 11 | LG | - |


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|--------------|
| Connector No. | D31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH4CFW-CS15 |




| | |
|----------------|------------------------------|
| Connector No. | D33 |
| Connector Name | DOOR MIRROR (PASSENGER SIDE) |
| Connector Type | TH2AMP-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 7 | R | - |
| 8 | BR | - |
| 9 | V | - |
| 12 | P | - |
| 13 | LG | - |
| 14 | B | - |
| 15 | W | - |
| 16 | BR | - |
| 17 | B | - |
| 18 | R | - |
| 19 | Y | - |
| 20 | B | - [With BOSE audio] - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] - [Without BOSE audio] |
| 22 | BR | - [Without BOSE audio] |
| 23 | V | - |
| 24 | P | - |
| 24 | W | - |
| 25 | SB | - |
| 26 | R | - |
| 28 | SHIELD | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | BR | - |
| 33 | O | - |
| 34 | GR | - |
| 35 | G | - |
| 43 | Y | - |
| 44 | V | - |
| 45 | P | - |
| 46 | W | - |
| 52 | G | - |
| 53 | GR | - |
| 54 | O | - |
| 55 | L | - |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | SIDE CAMERA RH COMM |
| 4 | LG | SIDE CAMERA RH IMAGE SIGNAL |
| 5 | B | SIDE CAMERA RH POWER SUPPLY |
| 6 | R | - |
| 7 | L | - |
| 10 | G | - |
| 11 | GR | - |
| 12 | O | - |
| 16 | BR | - |
| 17 | G | SIDE CAMERA RH IMAGE GND |
| 18 | Y | SIDE CAMERA RH GND |
| 19 | B | - |
| 21 | P | - |
| 22 | Y | - |
| 23 | W | - |
| 24 | V | - |

| | |
|----------------|-----------------|
| Connector No. | E106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH8CFW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | W | - |
| 3 | B | - |
| 4 | GR | - |
| 5 | GR | - |
| 8 | Y | - |

| | | |
|----|--------|---------------------------------|
| 9 | BR | - |
| 10 | RG | - |
| 11 | SB | - |
| 12 | EG | - [With ICC] - [Without ICC] |
| 14 | R | - [With ICC] - [Without ICC] |
| 15 | P | - [With ICC] - [Without ICC] |
| 17 | V | - [With ICC] - [Without ICC] |
| 18 | SB | - [With ICC] - [Without ICC] |
| 20 | BG | - [With ICC] - [Without ICC] |
| 21 | L | - [With ICC] - [Without ICC] |
| 22 | V | - [With ICC] - [Without ICC] |
| 23 | G | - [With ICC] - [Without ICC] |
| 24 | P | - |
| 25 | V | - |
| 26 | Y | - |
| 27 | W | - |
| 28 | G | - |
| 31 | EG | - |
| 32 | W | - |
| 33 | B | - |
| 34 | R | - |
| 35 | G | - |
| 38 | SHIELD | - |
| 37 | V | - |
| 38 | BR | - |
| 39 | BG | - |
| 41 | W | - |
| 42 | G | - |
| 43 | BR | - |
| 45 | W | - |
| 49 | L | - |
| 50 | P | - |
| 51 | L | - |
| 52 | L | - |
| 53 | P | - |
| 54 | BG | - |
| 56 | BR | - |
| 57 | BR | - |
| 59 | W | - |
| 60 | LG | - |
| 61 | G | - |
| 62 | SB | - |
| 63 | W | - |
| 64 | B | - |
| 65 | G | - |
| 66 | R | - |
| 67 | SHIELD | - |
| 68 | Y | - |
| 69 | LG | - |
| 70 | W | - |

| | | |
|-----|--------|---------------------------------|
| 71 | R | - |
| 72 | Y | - |
| 73 | B | - |
| 74 | BR | - [With ICC] - [Without ICC] |
| 74 | L | - [With ICC] - [Without ICC] |
| 75 | G | - [With ICC] - [Without ICC] |
| 76 | W | - [With ICC] - [Without ICC] |
| 77 | R | - [With ICC] - [Without ICC] |
| 77 | P | - [With ICC] - [Without ICC] |
| 78 | L | - [With ICC] - [Without ICC] |
| 78 | BR | - [With ICC] - [Without ICC] |
| 79 | Y | - [With ICC] - [Without ICC] |
| 79 | L | - [With ICC] - [Without ICC] |
| 80 | SB | - |
| 81 | R | - |
| 82 | SB | - |
| 83 | EG | - |
| 84 | G | - |
| 85 | L | - |
| 86 | P | - |
| 87 | V | - |
| 89 | GR | - |
| 90 | SHIELD | - |
| 91 | W | - |
| 92 | Y | - |
| 93 | V | - |
| 94 | LG | - |
| 95 | BG | - |
| 96 | P | - |
| 97 | R | - |
| 98 | SHIELD | - |
| 99 | L | - |
| 100 | P | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]


DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|--------------|
| Connector No. | F51 |
| Connector Name | A/T ASSEMBLY |
| Connector Type | RK10FG-DCY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | BR | - |
| 3 | L | - |
| 4 | V | - |
| 5 | B | - |
| 6 | Y | - |
| 7 | R | - |
| 8 | P | - |
| 9 | GR | - |
| 10 | B | - |

| | |
|----------------|-----------------------------------|
| Connector No. | F301 |
| Connector Name | TOM (TRANSMISSION CONTROL MODULE) |
| Connector Type | SP10FG |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | VIGN |
| 2 | - | BATT |
| 3 | - | CAN-H |
| 4 | - | K LINE |
| 5 | - | GND |
| 6 | - | VIGN |
| 7 | - | REV LAMP RLY |
| 8 | - | CAN-L |
| 9 | - | START RLY |
| 10 | - | GND |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS30FW-M2 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | - |
| 2A | G | - |
| 3A | L | - |
| 4A | P | - |
| 5A | V | - |
| 6A | Y | - |
| 7A | R | - |
| 8A | L | - |

| | |
|----------------|--------------|
| Connector No. | M5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-CS15 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | BR | - |
| 4 | P | - |
| 5 | L | - |
| 6 | R | - |
| 7 | R | - |
| 8 | W | - |
| 9 | G | - |
| 10 | L | - |
| 11 | G | - |
| 12 | V | - |
| 13 | B | - |
| 14 | Y | - |

| | | |
|----|--------|--|
| 15 | W | - |
| 16 | R | - |
| 17 | B | - |
| 18 | G | - |
| 19 | Y | - |
| 20 | L | - |
| 21 | LG | - |
| 22 | L | - |
| 23 | G | - |
| 24 | Y | - |
| 25 | GR | - |
| 26 | R | - |
| 27 | W | - |
| 28 | SHIELD | - |
| 29 | Y | - |
| 30 | Y | - |
| 31 | R | - |
| 32 | BR | - |
| 33 | SB | - |
| 34 | Y | - |
| 35 | P | - |
| 36 | LG | - |
| 37 | BR | - |
| 38 | P | - |
| 39 | BG | - |
| 40 | SB | - |
| 41 | L | - |
| 42 | R | - |
| 43 | BR | - |
| 44 | V | - |
| 45 | G | - |
| 46 | SB | - [With automatic drive positioner] |
| 48 | V | - [Without automatic drive positioner] |
| 49 | P | - |
| 50 | B | - |
| 52 | R | - |
| 53 | V | - |
| 54 | LG | - |
| 55 | SB | - |


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|-----------------|
| Connector No. | M8 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | |
| 2 | R | |
| 3 | B | |
| 4 | SHIELD | |
| 5 | G | |
| 8 | Y | |
| 9 | BR | |
| 10 | R | |
| 11 | BR | |
| 12 | BG | |
| 13 | L | |
| 14 | R | |
| 15 | P | |
| 16 | V | |
| 17 | SB | |
| 18 | V | |
| 20 | BG | |
| 21 | L | |
| 22 | W | |
| 23 | P | |
| 24 | BR | |
| 26 | Y | |
| 26 | V | |
| 27 | G | |
| 28 | G | |
| 31 | L | |
| 32 | G | |
| 33 | B | |
| 34 | W | |
| 35 | R | |
| 36 | SHIELD | |
| 37 | V | |
| 38 | BG | |
| 39 | BR | |
| 41 | W | |
| 42 | BG | |
| 43 | BG | |
| 45 | W | |

| | | | |
|----|--------|--|--|
| 49 | L | | |
| 50 | P | | |
| 51 | BR | | |
| 52 | L | | |
| 53 | P | | |
| 54 | Y | | |
| 56 | BR | | |
| 57 | G | | |
| 59 | W | | |
| 60 | L | | |
| 61 | G | | |
| 62 | SB | | |
| 63 | G | | |
| 64 | B | | |
| 65 | W | | |
| 66 | R | | |
| 67 | SHIELD | | |
| 68 | Y | | |
| 69 | GR | | |
| 70 | LG | | |
| 71 | LG | | |
| 72 | Y | | |
| 73 | SB | | |
| 74 | BR | | |
| 74 | L | | |
| 75 | G | | |
| 76 | W | | |
| 76 | GR | | |
| 77 | R | | |
| 77 | P | | |
| 78 | L | | |
| 78 | R | | |
| 79 | Y | | |
| 79 | W | | |
| 80 | SB | | |
| 81 | SB | | |
| 82 | SB | | |
| 83 | V | | |
| 84 | G | | |
| 85 | L | | |
| 86 | P | | |
| 87 | W | | |
| 89 | GR | | |
| 90 | SHIELD | | |
| 91 | W | | |
| 92 | Y | | |
| 93 | BR | | |
| 94 | P | | |
| 95 | GR | | |
| 96 | W | | |
| 97 | L | | |
| 98 | SHIELD | | |

| | | | |
|-----|----|--|--|
| 99 | V | | |
| 100 | SB | | |

| | |
|----------------|-----------------|
| Connector No. | M7 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 3 | SB | - [With automatic drive positioner] |
| 3 | W | - [Without automatic drive positioner] |
| 5 | G | |
| 6 | BG | |
| 7 | W | |
| 8 | B | |
| 12 | SB | |
| 13 | LG | |
| 14 | Y | |
| 15 | G | |
| 17 | W | |
| 18 | SB | |
| 19 | LG | |
| 20 | BR | |
| 21 | SHIELD | |
| 22 | Y | |
| 24 | V | |
| 27 | B | |
| 27 | W | |
| 28 | R | |
| 29 | R | |
| 30 | SHIELD | |
| 31 | L | |
| 32 | P | |
| 33 | SB | |
| 34 | L | |
| 35 | P | |
| 36 | L | |
| 37 | P | |
| 38 | BR | |
| 39 | Y | |
| 44 | L | |
| 45 | GR | |
| 46 | LG | |
| 47 | SB | |

| | | | |
|----|--------|--|--|
| 49 | V | | |
| 50 | R | | |
| 60 | P | | |
| 61 | L | | |
| 62 | SHIELD | | |
| 63 | R | | |
| 64 | G | | |
| 65 | SHIELD | | |
| 66 | SB | | |
| 67 | V | | |
| 68 | LG | | |
| 69 | SHIELD | | |
| 70 | W | | |
| 73 | G | | |
| 74 | R | | |
| 75 | W | | |
| 76 | W | | |
| 77 | B | | |
| 78 | P | | |
| 79 | GR | | |
| 83 | BG | | |
| 85 | LG | | |
| 86 | R | | |
| 87 | Y | | |
| 88 | W | | |
| 89 | BR | | |
| 90 | BG | | |
| 91 | G | | |
| 92 | V | | |
| 93 | BR | | |
| 94 | V | | |
| 95 | G | | |
| 96 | Y | | |
| 98 | W | | |
| 99 | R | | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]


DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|---------------------|
| Connector No. | M24 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B | - |
| 5 | B | - |
| 6 | L | - |
| 7 | V | - |
| 8 | G | - |
| 11 | SB | - |
| 14 | P | - |
| 16 | Y | - |

| | |
|----------------|---|
| Connector No. | M51 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | THB2FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | TILT SW (UPWARD) |
| 2 | LG | MIRROR SELECT SW (RH) |
| 3 | G | MIRROR SW (UPWARD) |
| 4 | V | MIRROR SW (LEFTWARD) |
| 5 | R | MIRROR SENSOR (RH VERTICAL) |
| 6 | GR | MIRROR SENSOR (LH VERTICAL) |
| 7 | BG | TILT SENSOR |
| 9 | L | ADDRESS1 |
| 10 | V | TX (UART) |
| 11 | GR | TELESCOPIC SW (FRONTWARD) |
| 12 | BG | IND1 |
| 13 | P | IND2 |
| 14 | W | MIRROR MOTOR (RH VERTICAL) |

| | | |
|----|----|-------------------------------|
| 15 | G | MIRROR MOTOR (RH HORIZONTAL) |
| 16 | Y | MIRROR MOTOR (LH COMMON) |
| 17 | W | TILT SW (DOWNWARD) |
| 18 | P | MIRROR SELECT SW (LH) |
| 19 | SB | MIRROR SW (DOWNWARD) |
| 20 | BR | MIRROR SW (RIGHTWARD) |
| 21 | L | MIRROR SENSOR (RH HORIZONTAL) |
| 22 | G | MIRROR SENSOR (LH HORIZONTAL) |
| 23 | P | TELESCOPIC SENSOR |
| 24 | R | SET SW |
| 25 | SB | ADDRESS |
| 26 | Y | RX (UART) |
| 27 | G | TELESCOPIC SW (BACKWARD) |
| 30 | R | MIRROR MOTOR (RH COMMON) |
| 31 | LG | MIRROR MOTOR (LH VERTICAL) |
| 32 | L | MIRROR MOTOR (LH HORIZONTAL) |

| | |
|----------------|---|
| Connector No. | M62 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | R | POWER SUPPLY (SENSOR) |
| 34 | R | BAT (FUSE) |
| 35 | L | TILT MOTOR (UPWARD) |
| 36 | GR | TELESCOPIC MOTOR (FORWARD) |
| 39 | SB | BAT (C/B) |
| 40 | B | GND (SIGNAL) |
| 41 | Y | GND (SUPPLY) |
| 42 | BG | TILT MOTOR (DOWNWARD) |
| 44 | G | TELESCOPIC MOTOR (BACKWARD) |
| 48 | B | GND (POWER) |

| | |
|----------------|-----------------|
| Connector No. | M62 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | MO2FW-P-LC |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | SB | - |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | MO2FW-LC |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (F/L) |
| 2 | W | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | Y | POWER WINDOW POWER SUPPLY (BAP) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 4 | LG | INTERIOR ROOM LAMP POWER SUPPLY |

| | | |
|----|----|-----------------------------------|
| 5 | L | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | Y | STEP LAMP OUTPUT |
| 8 | V | ALL DOOR FUEL ID LOCK OUTPUT |
| 9 | C | DRIVER DOOR FUEL ID UNLOCK OUTPUT |
| 10 | BR | REAR DOOR UNLOCK OUTPUT |
| 11 | R | BAT (FUSE) |
| 13 | B | GND |
| 14 | W | PUSH-BUTTON IGNITION SW ILL GND |
| 15 | Y | TURN SIGNAL RH (FRONT) |
| 17 | W | TURN SIGNAL LH (FRONT) |
| 18 | BG | ROOM LAMP TIMER CONTROL |
| 19 | V | |

DOOR MIRROR SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]


A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|--------------|
| Connector No. | M124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MP-CS15 |



| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7 | Y | - |
| 8 | LG | - |
| 9 | Y | - |
| 12 | L | - |
| 13 | V | - |
| 14 | B | - |
| 15 | W | - |
| 16 | BR | - |
| 17 | B | - |
| 18 | R | - |
| 19 | B | - |
| 20 | Y | - [With BOSE audio] |
| 20 | W | - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] |
| 21 | L | - [Without BOSE audio] |
| 22 | SB | - |
| 23 | GR | - |
| 24 | G | - |
| 25 | Y | - |
| 26 | R | - |
| 29 | SHIELD | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | G | - |
| 33 | BR | - |
| 34 | V | - |
| 35 | G | - |
| 43 | L | - |
| 44 | Y | - |
| 45 | R | - |
| 46 | W | - |
| 52 | R | - |
| 53 | G | - |
| 54 | W | - |
| 55 | BG | - |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 72 | R | ROOM ANT2- |
| 73 | G | ROOM ANT2+ |
| 74 | SB | PASSENGER DOOR ANT- |
| 75 | GR | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | LG | DRIVER DOOR ANT+ |
| 78 | Y | ROOM ANTI- |
| 79 | BR | ROOM ANTI+ |
| 80 | GR | NATS ANT AMP |
| 81 | W | NATS ANT AMP |
| 82 | R | IGN RELAY (F/B) CONT |
| 83 | Y | KEYLESS ENTRY RECEIVER COMM |
| 87 | BR | COMBI SW INPUT 5 |
| 88 | V | COMBI SW INPUT 3 |
| 89 | BR | PUSH SW |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | LG | KEY SLOT ILL |
| 93 | V | ON IND |
| 94 | Y | PUDDLE LAMP CONT |
| 95 | BG | ACC RELAY CONT |
| 96 | GR | A/T SHIFT SELECTOR POWER SUPPLY |
| 97 | L | S/L CONDITION 1 |
| 98 | P | S/L CONDITION 2 |
| 99 | R | SHIFT P |
| 100 | G | PASSENGER DOOR REQUEST SW |
| 101 | SB | DRIVER DOOR REQUEST SW |
| 102 | BG | BLOWER FAN MOTOR RELAY CONT |
| 103 | LG | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 106 | W | S/L UNIT POWER SUPPLY |
| 107 | LG | COMBI SW INPUT 1 |
| 108 | R | COMBI SW INPUT 4 |
| 109 | Y | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |
| 111 | Y | S/L UNIT COMM |

JCLWA4350GB

MIR

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

INSIDE MIRROR

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | - |
| 2A | G | - |
| 3A | L | - |
| 4A | P | - |
| 5A | V | - |
| 6A | Y | - |
| 7A | R | - |
| 8A | L | - |

| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3B | P | - |
| 4B | G | - |
| 5B | BG | - |
| 6B | Y | - |
| 7B | P | - |
| 8B | R | - |
| 9B | SB | - |

| | |
|----------------|--------------|
| Connector No. | M106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NH10MH-CS10 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | SHIELD | - |
| 3 | L | - |
| 4 | W | - |
| 5 | Y | - |
| 7 | BR | - |
| 8 | Y | - |
| 9 | B | - |
| 10 | R | - |
| 11 | V | - |
| 12 | R | - |
| 13 | LS | - |
| 14 | R | - [With NAVI] |
| 14 | Y | - [Without NAVI] |
| 15 | SHIELD | - |
| 16 | G | - [With NAVI] |
| 16 | BR | - [Without NAVI] |
| 18 | B | - |


| | |
|----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NH10PFT-CS10 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 1 | G | - |
| 2 | SHIELD | - |
| 3 | L | - |
| 4 | BR | - [With automatic drive positioner] |


| | | |
|----|--------|--|
| 4 | W | - [Without automatic drive positioner] |
| 5 | G | - |
| 7 | BR | - |
| 8 | Y | - |
| 9 | B | - |
| 10 | Y | - |
| 11 | V | - |
| 12 | BR | - |
| 13 | R | - |
| 14 | W | - |
| 15 | SHIELD | - |
| 16 | B | - |
| 18 | B | - |

| | |
|----------------|----------------------------------|
| Connector No. | R3 |
| Connector Name | AUTO ANTI-DAZZLING INSIDE MIRROR |
| Connector Type | TH10FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | BR | - |
| 8 | B | - |
| 10 | G | - |

| | |
|----------------|----------------------------------|
| Connector No. | R6 |
| Connector Name | AUTO ANTI-DAZZLING INSIDE MIRROR |
| Connector Type | JAA07FB |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | B | - |
| 7 | W | - |

JCLWA4353GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

ECU DIAGNOSIS INFORMATION

DRIVER SEAT CONTROL UNIT

Reference Value

INFOID:000000006935351

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

| Monitor Item | Condition | Value/Status | |
|---------------|-----------------------------|------------------|-----|
| SET SW | Set switch | Push | ON |
| | | Release | OFF |
| MEMORY SW1 | Memory switch 1 | Push | ON |
| | | Release | OFF |
| MEMORY SW2 | Memory switch 2 | Push | ON |
| | | Release | OFF |
| SLIDE SW-FR | Sliding switch (front) | Operate | ON |
| | | Release | OFF |
| SLIDE SW-RR | Sliding switch (rear) | Operate | ON |
| | | Release | OFF |
| RECLN SW-FR | Reclining switch (front) | Operate | ON |
| | | Release | OFF |
| RECLN SW-RR | Reclining switch (rear) | Operate | ON |
| | | Release | OFF |
| LIFT FR SW-UP | Lifting switch front (up) | Operate | ON |
| | | Release | OFF |
| LIFT FR SW-DN | Lifting switch front (down) | Operate | ON |
| | | Release | OFF |
| LIFT RR SW-UP | Lifting switch rear (up) | Operate | ON |
| | | Release | OFF |
| LIFT RR SW-DN | Lifting switch rear (down) | Operate | ON |
| | | Release | OFF |
| MIR CON SW-UP | Mirror switch | Up | ON |
| | | Other than above | OFF |
| MIR CON SW-DN | Mirror switch | Down | ON |
| | | Other than above | OFF |
| MIR CON SW-RH | Mirror switch | Right | ON |
| | | Other than above | OFF |
| MIR CON SW-LH | Mirror switch | Left | ON |
| | | Other than above | OFF |
| MIR CHNG SW-R | Changeover switch | Right | ON |
| | | Other than above | OFF |
| MIR CHNG SW-L | Changeover switch | Left | ON |
| | | Other than above | OFF |
| TILT SW-UP | Tilt switch | Up | ON |
| | | Other than above | OFF |
| TILT SW-DOWN | Tilt switch | Down | ON |
| | | Other than above | OFF |

DRIVER SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Monitor Item | Condition | | Value/Status |
|----------------|------------------------------|--|--------------------------------|
| TELESCO SW-FR | Telescopic switch | Forward | ON |
| | | Other than above | OFF |
| TELESCO SW-RR | Tilt switch | Backward | ON |
| | | Other than above | OFF |
| DETENT SW | AT selector lever | P position | OFF |
| | | Other than above | ON |
| STARTER SW | Ignition position | Cranking | ON |
| | | Other than above | OFF |
| SLIDE PULSE | Seat sliding | Forward | The numeral value decreases *1 |
| | | Backward | The numeral value increases *1 |
| | | Other than above | No change to numeral value *1 |
| RECLN PULSE | Seat reclining | Forward | The numeral value decreases *1 |
| | | Backward | The numeral value increases *1 |
| | | Other than above | No change to numeral value *1 |
| LIFT FR PULSE | Seat lifter (front) | Up | The numeral value decreases *1 |
| | | Down | The numeral value increases *1 |
| | | Other than above | No change to numeral value *1 |
| LIFT RR PULSE | Seat lifter (rear) | Up | The numeral value decreases *1 |
| | | Down | The numeral value increases *1 |
| | | Other than above | No change to numeral value *1 |
| MIR/SEN RH U-D | Door mirror (passenger side) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| MIR/SEN RH R-L | Door mirror (passenger side) | Change between 3.4 (close to left edge) 0.6 (close to right edge) | |
| MIR/SEN LH U-D | Door mirror (driver side) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| MIR/SEN LH R-L | Door mirror (driver side) | Change between 0.6 (close to left edge) 3.4 (close to right edge) | |
| TILT SEN | Tilt position | Change between 1.2 (close to top) 3.4 (close to bottom) | |
| TELESCO SEN | Telescopic position | Change between 3.4 (close to top) 0.8 (close to bottom) | |

*1: The value at the position attained when the battery is connected is regarded as 32768.

TERMINAL LAYOUT







PHYSICAL VALUES

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >




[WITH ADP]

| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx) | |
|--------------|--------|------------|------------------------------------|--------------|------------------------|--|---|
| + | - | | Signal name | Input/Output | | | |
| 1 | Ground | L/W | UART communication (RX) | Input | Ignition switch ON |  <p style="text-align: right; font-size: small;">JMJA0118ZZ</p> | |
| 3 | — | R/Y | CAN-H | — | — | — | |
| 9 | Ground | W/G | Reclining sensor signal | Input | Seat reclining | Operate |  <p style="text-align: right; font-size: small;">JMJA0119ZZ</p> |
| | | | | | | Stop | 0 or 5 |
| 10 | Ground | P/B | Lifting sensor (rear) signal | Input | Seat lifting (rear) | Operate |  <p style="text-align: right; font-size: small;">JMJA0119ZZ</p> |
| | | | | | | Stop | 0 or 5 |
| 11 | Ground | BR | Sliding switch backward signal | Input | Sliding switch | Operate (backward) | 0 |
| | | | | | | Release | Battery voltage |
| 12 | Ground | SB | Reclining switch backward signal | Input | Reclining switch | Operate (backward) | 0 |
| | | | | | | Release | Battery voltage |
| 13 | Ground | LG/R | Lifting switch (front) down signal | Input | Lifting switch (front) | Operate (down) | 0 |
| | | | | | | Release | Battery voltage |
| 14 | Ground | G/B | Lifting switch (rear) down signal | Input | Lifting switch (rear) | Operate (down) | 0 |
| | | | | | | Release | Battery voltage |
| 16 | Ground | O | Sensor power supply | Output | — | 5 | |
| 17 | Ground | Y/R | UART communication (TX) | Output | Ignition switch ON |  <p style="text-align: right; font-size: small;">JMJA0121ZZ</p> | |
| 19 | — | V | CAN-L | — | — | — | |

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx) | |
|--------------|--------|------------|---------------------------------------|--------------|-----------------------------|-------------------------|--|
| + | - | | Signal name | Input/Output | | | |
| 21 | Ground | L/Y | Detention switch | Input | A/T selector lever | P position | 0 |
| | | | | | | Except P position |  |
| 24 | Ground | R | Sliding sensor signal | Input | Seat sliding | Operate |  |
| | | | | | | Stop | 0 or 5 |
| 25 | Ground | Y/B | Lifting sensor (front) signal | Input | Seat lifting (front) | Operate |  |
| | | | | | | Stop | 0 or 5 |
| 26 | Ground | Y | Sliding switch forward signal | Input | Sliding switch | Operate (forward) | 0 |
| | | | | | | Release | Battery voltage |
| 27 | Ground | R/G | Reclining switch forward signal | Input | Reclining switch | Operate (forward) | 0 |
| | | | | | | Release | Battery voltage |
| 28 | Ground | W/B | Lifting switch (front) up signal | Input | Seat lifting switch (front) | Operate (up) | 0 |
| | | | | | | Release | Battery voltage |
| 29 | Ground | P/L | Lifting switch (rear) up signal | Input | Seat lifting switch (rear) | Operate (up) | 0 |
| | | | | | | Release | Battery voltage |
| 31 | Ground | GR | Sensor ground | — | — | 0 | |
| 32 | Ground | B/W | Ground (signal) | — | — | 0 | |
| 33 | Ground | R | Power source (C/B) | Input | — | Battery voltage | |
| 35 | Ground | W/R | Sliding motor forward output signal | Output | Seat sliding | Operate (forward) | Battery voltage |
| | | | | | | Release | 0 |
| 36 | Ground | G/Y | Reclining motor forward output signal | Output | Seat reclining | Operate (forward) | Battery voltage |
| | | | | | | Release | 0 |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx) | |
|--------------|--------|------------|---|------------------|----------------------|----------------------------|-----------------|
| + | - | | Signal name | Input/ Output | | | |
| 37 | Ground | G/W | Lifting motor (front) down output signal | Output | Seat lifting (front) | Operate (down) | Battery voltage |
| | | | | | | Stop | 0 |
| 38 | Ground | L/Y | Lifting motor (rear) up output signal | Output | Seat lifting (rear) | Operate (up) | Battery voltage |
| | | | | | | Stop | 0 |
| 39 | Ground | R/B | Lifting motor (rear) down output signal | Output | Seat lifting (rear) | Operate (down) | Battery voltage |
| | | | | | | Stop | 0 |
| 40 | Ground | R/W | Power source (Fuse) | Input | — | Battery voltage | |
| 42 | Ground | W/B | Sliding motor back- ward output signal | Output | Seat sliding | Operate (back- ward) | Battery voltage |
| | | | | | | Stop | 0 |
| 44 | Ground | P | Reclining motor back- ward output signal | Output | Seat reclining | Operate (back- ward) | Battery voltage |
| | | | | | | Stop | 0 |
| 45 | Ground | L/R | Lifting motor (front) up output signal | Output | Seat lifting (front) | Operate (up) | Battery voltage |
| | | | | | | Stop | 0 |
| 48 | Ground | B | Ground (power) | — | — | 0 | |


DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:000000006935352




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCJWA1317GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

*: This connector is not shown in "Harness Layout".



JCJWA1318GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|------------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FN-CS1.6-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | R | - |
| 5 | G | - |
| 6 | SB | - |
| 7 | Y | - |
| 8 | L | - |
| 12 | SB | - |
| 13 | LG | - |
| 14 | GR | - |
| 15 | LG | - |
| 17 | W | - |
| 18 | SB | - |
| 19 | LG | - |
| 20 | BR | - |
| 21 | SHIELD | - |
| 22 | Y | - |
| 24 | P | - |
| 27 | B | - |
| 28 | R | - |
| 29 | W | - |
| 30 | SHIELD | - |
| 31 | SHIELD | - |
| 32 | W | - |
| 33 | SB | - |
| 34 | L | - |
| 35 | P | - |
| 36 | L | - |
| 37 | P | - |
| 38 | BR | - |
| 39 | Y | - |
| 44 | Y | - |
| 45 | GR | - |
| 46 | LG | - |
| 47 | SB | - |
| 49 | G | - |
| 50 | V | - |
| 60 | P | - |
| 61 | L | - |
| 62 | SHIELD | - |

| | | |
|----|--------|---|
| 63 | R | - |
| 64 | G | - |
| 65 | SHIELD | - |
| 66 | W | - |
| 67 | V | - |
| 68 | SB | - |
| 69 | SHIELD | - |
| 70 | W | - |
| 73 | SB | - |
| 74 | L | - |
| 75 | W | - |
| 76 | BR | - |
| 77 | R | - |
| 78 | P | - |
| 79 | GR | - |
| 83 | BG | - |
| 85 | V | - |
| 86 | LG | - |
| 87 | Y | - |
| 88 | R | - |
| 89 | B | - |
| 90 | BG | - |
| 91 | G | - |
| 92 | BR | - |
| 93 | G | - |
| 94 | SB | - |
| 95 | G | - |
| 96 | Y | - |
| 98 | W | - |
| 99 | GR | - |

| | |
|----------------|--------------|
| Connector No. | B5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MP-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | SB | - |
| 3 | Y | - |
| 4 | R | - |
| 5 | W | - |
| 6 | G | - |

| | | |
|----|--------|---|
| 7 | LG | - |
| 8 | B | - |
| 9 | V | - |
| 10 | SB | - |
| 11 | GR | - |
| 12 | W | - |
| 13 | SHIELD | - |
| 14 | SB | - |
| 15 | GR | - |
| 16 | P | - |
| 21 | G | - |
| 22 | B | - |
| 23 | SHIELD | - |
| 24 | BG | - |
| 25 | BR | - |
| 26 | Y | - |
| 27 | W | - |
| 28 | R | - |
| 29 | L | - |
| 30 | SHIELD | - |
| 31 | Y | - |

| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 3 | L | - |
| 17 | Y | - |
| 19 | P | - |
| 21 | V | - |
| 32 | B | - |
| 33 | R | - |
| 40 | BR | - |
| 48 | B | - |
| 59 | B | - |
| 60 | G | - |
| 66 | GR | - |
| 67 | Y | - |

| | |
|----------------|---------------------------------|
| Connector No. | B16 |
| Connector Name | FRONT DOOR SWITCH (DRIVER SIDE) |
| Connector Type | AG3FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | V | - |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------------------------|
| Connector No. | D17 |
| Connector Name | DOOR MIRROR REMOTE CONTROL SWITCH |
| Connector Type | TK06BR |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 4 | BR | - |
| 7 | B | - |
| 8 | B | - |
| 9 | R | - |
| 10 | GR | - |
| 11 | LG | - |
| 12 | G | - |
| 13 | W | - |
| 15 | Y | - |



| | |
|----------------|--------------|
| Connector No. | D31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-CS15 |

| | | |
|----|--------|------------------------|
| 21 | G | - [With BOSE audio] |
| 21 | BR | - [Without BOSE audio] |
| 22 | V | - |
| 23 | P | - |
| 24 | W | - |
| 25 | SB | - |
| 26 | R | - |
| 29 | SHIELD | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | BR | - |
| 33 | O | - |
| 34 | GR | - |
| 35 | G | - |
| 43 | Y | - |
| 44 | V | - |
| 45 | P | - |
| 46 | W | - |
| 52 | G | - |
| 53 | GR | - |
| 54 | O | - |
| 55 | L | - |

| | |
|----------------|------------------------------|
| Connector No. | D33 |
| Connector Name | DOOR MIRROR (PASSENGER SIDE) |
| Connector Type | TH24MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | SIDE CAMERA RH COMM |
| 4 | LG | SIDE CAMERA RH IMAGE SIGNAL |
| 5 | B | SIDE CAMERA RH POWER SUPPLY |
| 6 | R | - |
| 7 | L | - |
| 10 | G | - |
| 11 | GR | - |
| 12 | O | - |
| 16 | BR | SIDE CAMERA RH IMAGE GND |
| 17 | G | SIDE CAMERA RH GND |
| 18 | Y | - |
| 19 | B | - |
| 21 | P | - |
| 22 | Y | - |

| | | |
|----|---|---|
| 23 | W | - |
| 24 | V | - |

JCJWA1322GB


DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | E106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FN-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | W | |
| 3 | B | |
| 4 | GR | |
| 5 | GR | |
| 6 | Y | |
| 8 | BR | |
| 9 | BR | |
| 10 | EG | |
| 11 | SB | |
| 12 | EG | |
| 13 | L | |
| 14 | R | |
| 15 | P | |
| 16 | V | |
| 17 | SB | |
| 18 | V | |
| 20 | EG | |
| 21 | L | |
| 22 | V | |
| 23 | G | |
| 24 | P | |
| 26 | Y | |
| 26 | V | |
| 27 | W | |
| 28 | G | |
| 31 | EG | |
| 32 | W | |
| 33 | B | |
| 34 | R | |
| 35 | G | |
| 36 | SHIELD | |
| 37 | V | |
| 38 | BR | |
| 39 | EG | |
| 41 | W | |
| 42 | G | |
| 43 | BR | |
| 45 | W | |

| | | |
|----|--------|-----------------|
| 49 | L | |
| 50 | P | |
| 51 | L | |
| 52 | L | |
| 53 | P | |
| 54 | EG | |
| 56 | BR | |
| 57 | BR | |
| 59 | W | |
| 60 | LG | |
| 61 | G | |
| 62 | SB | |
| 63 | W | |
| 64 | B | |
| 65 | G | |
| 66 | R | |
| 67 | SHIELD | |
| 68 | Y | |
| 69 | LG | |
| 70 | W | |
| 71 | R | |
| 72 | Y | |
| 73 | B | |
| 74 | BR | |
| 74 | L | - [With ICC] |
| 75 | G | - [Without ICC] |
| 75 | G | - [With ICC] |
| 75 | W | - [Without ICC] |
| 76 | W | - [With ICC] |
| 76 | Y | - [Without ICC] |
| 77 | R | - [With ICC] |
| 77 | P | - [Without ICC] |
| 78 | L | - [With ICC] |
| 78 | BR | - [Without ICC] |
| 79 | Y | - [With ICC] |
| 79 | L | - [Without ICC] |
| 80 | SB | |
| 81 | R | |
| 82 | SB | |
| 83 | EG | |
| 84 | G | |
| 85 | L | |
| 86 | P | |
| 87 | V | |
| 89 | GR | |
| 90 | SHIELD | |
| 91 | W | |
| 92 | Y | |
| 93 | V | |
| 94 | LG | |
| 95 | EG | |
| 96 | P | |
| 97 | R | |

| | | |
|-----|--------|--|
| 98 | SHIELD | |
| 99 | L | |
| 100 | P | |

| | |
|----------------|--------------|
| Connector No. | F51 |
| Connector Name | A/T ASSEMBLY |
| Connector Type | RK10FG-DGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | |
| 2 | BR | |
| 3 | L | |
| 4 | V | |
| 5 | B | |
| 6 | Y | |
| 7 | R | |
| 8 | P | |
| 9 | GR | |
| 10 | B | |


| | |
|----------------|-----------------------------------|
| Connector No. | F301 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Type | SPT0FG |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | VIGN |
| 2 | - | BATT |
| 3 | - | CAN-H |
| 4 | - | K LINE |
| 5 | - | GND |
| 6 | - | VIGN |
| 7 | - | REV LAMP RLY |

| | | |
|----|--|-----------|
| 8 | | CAN-L |
| 9 | | START RLY |
| 10 | | GND |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | |
| 2A | G | |
| 3A | L | |
| 4A | P | |
| 5A | V | |
| 6A | Y | |
| 7A | R | |
| 8A | L | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|--------------|
| Connector No. | M4 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH27V-NH |

| | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | SB | |
| 3 | Y | |
| 4 | R | |
| 5 | W | |
| 6 | C | |
| 7 | LG | |
| 8 | B | |
| 9 | V | |
| 10 | B | |
| 11 | W | |
| 12 | W | |
| 13 | SHIELD | |
| 14 | V | |
| 15 | V | |
| 16 | W | |
| 17 | G | |
| 21 | G | |
| 22 | B | |
| 23 | SHIELD | |
| 24 | R | |
| 25 | R | |
| 26 | Y | |
| 27 | G | |
| 28 | B | |
| 29 | W | |
| 30 | SHIELD | |
| 31 | Y | |

| | |
|----------------|--------------|
| Connector No. | M5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH4GMV-CS15 |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | B | |
| 3 | BR | |
| 4 | P | |
| 5 | L | |
| 6 | R | |
| 7 | R | |
| 8 | W | |
| 9 | G | |
| 10 | L | |
| 11 | G | |
| 12 | V | |
| 13 | B | |
| 14 | Y | |
| 15 | W | |
| 16 | R | |
| 17 | B | |
| 18 | G | |
| 19 | Y | |
| 20 | L | |
| 21 | LG | |
| 22 | L | |
| 23 | G | |
| 24 | Y | |
| 25 | GR | |
| 26 | R | |
| 27 | W | |
| 28 | SHIELD | |
| 29 | Y | |
| 30 | Y | |
| 31 | R | |
| 32 | BR | |
| 33 | SB | |
| 34 | Y | |
| 35 | P | |
| 36 | LG | |
| 37 | BR | |
| 38 | P | |

| | | |
|----|----|--|
| 39 | BG | - |
| 40 | SB | - |
| 41 | L | - |
| 42 | R | - |
| 43 | BR | - |
| 44 | V | - |
| 45 | G | - |
| 46 | SB | - [With automatic drive positioner] |
| 47 | V | - [Without automatic drive positioner] |
| 48 | P | - |
| 49 | B | - |
| 50 | B | - |
| 52 | R | - |
| 53 | V | - |
| 54 | LG | - |
| 55 | SB | - |


DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | R | - |
| 3 | B | - |
| 4 | SHIELD | - |
| 5 | G | - |
| 8 | Y | - |
| 9 | BR | - |
| 10 | R | - |
| 11 | BR | - |
| 12 | BG | - |
| 13 | L | - |
| 14 | R | - |
| 15 | P | - |
| 16 | V | - |
| 17 | SB | - |
| 18 | V | - |
| 20 | BG | - |
| 21 | L | - |
| 22 | W | - |
| 23 | P | - |
| 24 | BR | - |
| 26 | Y | - |
| 26 | V | - |
| 27 | G | - |
| 28 | G | - |
| 31 | L | - |
| 32 | G | - |
| 33 | B | - |
| 34 | W | - |
| 35 | R | - |
| 36 | SHIELD | - |
| 37 | V | - |
| 38 | BG | - |
| 39 | BR | - |
| 41 | W | - |
| 42 | BG | - |
| 43 | BG | - |
| 45 | W | - |

| | | |
|----|--------|---------------------------------|
| 49 | L | - |
| 50 | P | - |
| 51 | BR | - |
| 52 | L | - |
| 53 | P | - |
| 54 | Y | - |
| 56 | BR | - |
| 57 | G | - |
| 59 | W | - |
| 60 | L | - |
| 61 | G | - |
| 62 | SB | - |
| 63 | G | - |
| 64 | B | - |
| 65 | W | - |
| 66 | R | - |
| 67 | SHIELD | - |
| 68 | Y | - |
| 69 | GR | - |
| 70 | LG | - |
| 71 | LG | - |
| 72 | Y | - |
| 73 | SB | - |
| 74 | BR | - |
| 74 | L | - [With ICC] - [Without ICC] |
| 75 | G | - |
| 76 | W | - [With ICC] - [Without ICC] |
| 76 | GR | - [Without ICC] |
| 77 | R | - [With ICC] - [Without ICC] |
| 77 | P | - [Without ICC] |
| 78 | L | - [With ICC] - [Without ICC] |
| 78 | R | - [Without ICC] |
| 79 | Y | - [With ICC] - [Without ICC] |
| 79 | W | - [Without ICC] |
| 80 | SB | - |
| 81 | SB | - |
| 82 | SB | - |
| 83 | V | - |
| 84 | G | - |
| 85 | L | - |
| 86 | P | - |
| 87 | W | - |
| 89 | GR | - |
| 90 | SHIELD | - |
| 91 | W | - |
| 92 | Y | - |
| 93 | BR | - |
| 94 | P | - |
| 95 | GR | - |
| 96 | W | - |
| 97 | L | - |
| 98 | SHIELD | - |

| | | |
|-----|----|---|
| 99 | V | - |
| 100 | SB | - |

| | |
|----------------|-----------------|
| Connector No. | M7 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS18-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 3 | SB | - [With automatic drive positioner] - [Without automatic drive positioner] |
| 3 | W | - |
| 5 | G | - |
| 6 | BG | - |
| 7 | W | - |
| 8 | B | - |
| 12 | SB | - |
| 13 | LG | - |
| 14 | Y | - |
| 15 | G | - |
| 17 | W | - |
| 18 | SB | - |
| 19 | LG | - |
| 20 | BR | - |
| 21 | SHIELD | - |
| 22 | Y | - |
| 24 | V | - |
| 27 | B | - |
| 27 | W | - |
| 28 | R | - |
| 29 | R | - |
| 30 | SHIELD | - |
| 31 | L | - |
| 32 | P | - |
| 33 | SB | - |
| 34 | L | - |
| 35 | P | - |
| 36 | L | - |
| 37 | P | - |
| 38 | BR | - |
| 39 | Y | - |
| 44 | L | - |
| 45 | GR | - |
| 46 | LG | - |
| 47 | SB | - |

| | | |
|----|--------|---|
| 49 | V | - |
| 50 | R | - |
| 60 | P | - |
| 61 | L | - |
| 62 | SHIELD | - |
| 63 | R | - |
| 64 | G | - |
| 65 | SHIELD | - |
| 66 | SB | - |
| 67 | V | - |
| 68 | LG | - |
| 69 | SHIELD | - |
| 70 | W | - |
| 73 | G | - |
| 74 | R | - |
| 75 | W | - |
| 76 | W | - |
| 77 | B | - |
| 78 | P | - |
| 79 | GR | - |
| 83 | BG | - |
| 85 | LG | - |
| 86 | R | - |
| 87 | Y | - |
| 88 | W | - |
| 89 | BR | - |
| 90 | BG | - |
| 91 | G | - |
| 92 | V | - |
| 93 | BR | - |
| 94 | V | - |
| 95 | G | - |
| 96 | Y | - |
| 98 | W | - |
| 99 | R | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR


DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------|
| Connector No. | M22 |
| Connector Name | KEY SLOT |
| Connector Type | TH12FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | BAT |
| 2 | GR | CLOCK |
| 3 | W | DATA |
| 5 | Y | ILL BATT |
| 6 | LG | ILL |
| 7 | B | GND |
| 11 | BR | KEY SWITCH SIGNAL |

| | |
|----------------|---------------------|
| Connector No. | M24 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B | - |
| 5 | B | - |
| 6 | L | - |
| 7 | Y | - |
| 8 | G | - |
| 11 | SB | - |
| 14 | P | - |
| 16 | Y | - |

| | |
|----------------|--------------------------|
| Connector No. | M31 |
| Connector Name | TILT & TELESCOPIC SWITCH |
| Connector Type | TK08FY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | GR | - |
| 3 | G | - |
| 4 | Y | - |
| 5 | W | - |

| | |
|----------------|--------------------------|
| Connector No. | M48 |
| Connector Name | TILT & TELESCOPIC SENSOR |
| Connector Type | TK04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | P | - |
| 3 | BG | - |
| 4 | Y | - |

| | |
|----------------|-------------------------|
| Connector No. | M49 |
| Connector Name | TILT & TELESCOPIC MOTOR |
| Connector Type | NS04FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | GR | - |
| 3 | BG | - |
| 4 | L | - |

| | |
|----------------|---|
| Connector No. | M51 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | TH02FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------|
| 1 | Y | TILT SW (UPWARD) |
| 2 | LG | MIRROR SELECT SW (RH) |
| 3 | G | MIRROR SW (UPWARD) |
| 4 | V | MIRROR SW (LEFTWARD) |
| 5 | R | MIRROR SENSOR (RH VERTICAL) |
| 6 | GR | MIRROR SENSOR (LH VERTICAL) |
| 7 | BG | TILT SENSOR |
| 9 | L | TX (UART) |
| 10 | V | ADDRESS |
| 11 | GR | TELESCOPIC SW (FRONTWARD) |
| 12 | BG | IND1 |
| 13 | P | IND2 |
| 14 | W | MIRROR MOTOR (RH VERTICAL) |
| 15 | G | MIRROR MOTOR (RH HORIZONTAL) |
| 16 | Y | MIRROR MOTOR (LH COMMON) |
| 17 | W | TILT SW (DOWNWARD) |
| 18 | P | MIRROR SELECT SW (LH) |
| 19 | SB | MIRROR SW (DOWNWARD) |

| | | |
|----|----|-------------------------------|
| 20 | BR | MIRROR SW (RIGHTWARD) |
| 21 | L | MIRROR SENSOR (RH HORIZONTAL) |
| 22 | G | MIRROR SENSOR (LH HORIZONTAL) |
| 23 | P | TELESCOPIC SENSOR |
| 24 | R | SET SW |
| 25 | SB | ADDRESS |
| 26 | Y | RX (UART) |
| 27 | G | TELESCOPIC SW (BACKWARD) |
| 30 | R | MIRROR MOTOR (RH COMMON) |
| 31 | LG | MIRROR MOTOR (LH VERTICAL) |
| 32 | L | MIRROR MOTOR (LH HORIZONTAL) |

| | |
|----------------|---|
| Connector No. | M52 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | R | POWER SUPPLY (SENSOR) |
| 34 | R | BAT (FUSE) |
| 35 | L | TILT MOTOR (UPWARD) |
| 36 | GR | TELESCOPIC MOTOR (FORWARD) |
| 39 | SB | BAT (C/B) |
| 40 | B | GND(SIGNAL) |
| 41 | Y | GND(SENSOR) |
| 42 | BG | TILT MOTOR (DOWNWARD) |
| 44 | G | TELESCOPIC MOTOR (BACKWARD) |
| 48 | B | GND(POWER) |

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M62 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | M02PW-P-LC |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | SB | - |

| | |
|----------------|----------------------------|
| Connector No. | M67 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH02PW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 41 | V | ACC POWER SUPPLY |
| 42 | Y | FUEL LEVEL SENSOR SIGNAL |
| 43 | R | INTAKE SENSOR SIGNAL |
| 44 | LG | IN-VEHICLE SENSOR SIGNAL |
| 45 | P | AMBIENT SENSOR SIGNAL |
| 46 | EG | SUNLOAD SENSOR SIGNAL |
| 47 | G | EXHAUST GAS / OUTSIDE AIR DETECTING SENSOR SIGNAL |
| 53 | G | IGNITION POWER SUPPLY |
| 54 | Y | BATTERY POWER SUPPLY |
| 55 | B | GROUND |
| 56 | L | CAN-H |
| 57 | W | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 58 | BR | FUEL LEVEL SENSOR GROUND |
| 59 | GR | INTAKE SENSOR GROUND |
| 60 | L | IN-VEHICLE SENSOR GROUND |
| 61 | BR | AMBIENT SENSOR GROUND |
| 62 | SB | SUNLOAD SENSOR GROUND |
| 63 | R | - |
| 65 | EG | ECV SIGNAL |
| 68 | L | A/C LAM SIGNAL |

| | |
|----------------|------------------------------|
| Connector No. | M72 |
| Connector Name | EACH DOOR MOTOR POWER SUPPLY |
| Connector Type | CAN-L |



| | | | |
|--------------|----|--------|------------------------------|
| Terminal No. | 70 | R | EACH DOOR MOTOR POWER SUPPLY |
| 71 | B | GROUND | |
| 72 | P | CAN-L | |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | G | ACC |
| 3 | V | ACC |
| 4 | R | ILL. |
| 5 | Y | ILL CONT. |
| 6 | SB | AV COMM (H) |
| 8 | LG | AV COMM (L) |
| 9 | B | SW GND |
| 14 | Y | DISK EJECT SIGNAL |
| 16 | G | HAZARD ON |

| | |
|----------------|----------------------|
| Connector No. | M72 |
| Connector Name | MULTIFUNCTION SWITCH |
| Connector Type | TH16PW-NH |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03PB-LG |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (F/L) |
| 2 | W | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | Y | POWER WINDOW POWER SUPPLY (RAP) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M516FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 4 | LG | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | L | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | Y | STEER LAMP OUTPUT |
| 8 | V | ALL DOOR FUEL LID LOCK OUTPUT |
| 9 | G | DRIVER DOOR FUEL LID UNLOCK OUTPUT |
| 10 | BR | REAR DOOR UNLOCK OUTPUT |
| 11 | R | BAT (FUSE) |
| 13 | B | GND |
| 14 | W | PUSH-BUTTON IGNITION SW ILL GND |
| 15 | Y | ACC IND |
| 17 | W | TURN SIGNAL RH (FRONT) |
| 18 | BG | TURN SIGNAL LH (FRONT) |
| 19 | V | ROOM LAMP TIMER CONTROL |

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 72 | R | ROOM ANT2- |
| 73 | G | ROOM ANT2+ |
| 74 | SB | PASSENGER DOOR ANT- |
| 75 | GR | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | LG | DRIVER DOOR ANT+ |
| 78 | Y | ROOM ANT1- |
| 79 | BR | ROOM ANT1+ |
| 80 | GR | MATS ANT AMP. |

| | | |
|-----|----|-------------------------------------|
| 81 | W | MATS ANT AMP |
| 82 | R | IGN RELAY (E/B) CONT |
| 83 | Y | KEYLESS ENTRY RECEIVER COMM |
| 87 | BR | COMBI SW INPUT 3 |
| 88 | V | COMBI SW INPUT 3 |
| 89 | BR | PUSH SW |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | LG | KEY SLOT ILL |
| 93 | V | ON IND |
| 94 | Y | PUDDLE LAMP CONT |
| 95 | BG | ACC RELAY CONT |
| 96 | GR | A/T SHIFT SELECTOR POWER SUPPLY |
| 97 | L | S/L CONDITION 1 |
| 98 | P | S/L CONDITION 2 |
| 99 | R | SHIFT P |
| 100 | G | PASSENGER DOOR REQUEST SW |
| 101 | SR | DRIVER DOOR REQUEST SW |
| 102 | BG | BLOWER FAN MOTOR RELAY CONT |
| 103 | LG | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 106 | W | S/L UNIT POWER SUPPLY |
| 107 | LG | COMBI SW INPUT 1 |
| 108 | R | COMBI SW INPUT 4 |
| 109 | Y | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |
| 111 | Y | S/L UNIT COMM |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

JCJWA1327GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-------------------------|
| Connector No. | M123 |
| Connector Name | BCM BODY CONTROL MODULE |
| Connector Type | TH40FG-NH |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 113 | P | OPTICAL SENSOR |
| 116 | SB | STOP LAMP SW 1 |
| 118 | P | STOP LAMP SW 2 |
| 119 | SB | DR DOOR UNLOCK SENSOR |
| 121 | BR | KEY SLOT SW |
| 122 | W | IGN F/B |
| 124 | LG | PASSENGER DOOR SW |
| 132 | BR | POWER WINDOW SW COMM |
| 133 | W | PUSH-BUTTON IGNITION SW ALL POWER LOCK IND |
| 134 | GR | RECEIVER/SENSOR GND |
| 137 | EG | RECEIVER/SENSOR POWER SUPPLY |
| 138 | Y | TIRE PRESSURE RECEIVER COMM |
| 139 | L | SHIFT N/P |
| 140 | GR | SECURITY INDICATOR OUTPUT |
| 141 | G | COMBI SW OUTPUT 5 |
| 142 | EG | COMBI SW OUTPUT 1 |
| 143 | P | COMBI SW OUTPUT 2 |
| 144 | G | COMBI SW OUTPUT 3 |
| 145 | L | COMBI SW OUTPUT 4 |
| 146 | SB | DRIVER DOOR SW |
| 150 | LG | REAR WINDOW DEFOGGER RELAY CONT |
| 151 | G | |

| | |
|----------------|--------------|
| Connector No. | M124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-CS15 |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | |

| | | |
|----|--------|------------------------|
| 7 | Y | |
| 8 | LG | |
| 9 | Y | |
| 12 | L | |
| 13 | V | |
| 14 | B | |
| 15 | W | |
| 16 | BR | |
| 17 | B | |
| 18 | R | |
| 19 | B | |
| 20 | Y | - [With BOSE audio] |
| 20 | W | - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] |
| 21 | L | - [Without BOSE audio] |
| 22 | SB | |
| 23 | GR | |
| 24 | G | |
| 25 | Y | |
| 26 | R | |
| 28 | SHIELD | |
| 30 | W | |
| 31 | LG | |
| 32 | G | |
| 33 | BR | |
| 34 | V | |
| 35 | G | |
| 43 | L | |
| 44 | Y | |
| 45 | R | |
| 46 | W | |
| 52 | R | |
| 53 | G | |
| 54 | W | |
| 55 | EG | |

| | |
|----------------|--------------------|
| Connector No. | M137 |
| Connector Name | A/T SHIFT SELECTOR |
| Connector Type | TH1ZFV-NH |



| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
|---|---|---|---|---|---|---|---|---|----|----|

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | |

| | | |
|----|----|--|
| 2 | V | |
| 3 | L | |
| 4 | B | |
| 5 | G | |
| 7 | R | |
| 8 | SB | |
| 9 | B | |
| 10 | GR | |
| 11 | R | |

| | |
|----------------|-----------------|
| Connector No. | M202 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH24FW-NH |



| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 36 | BG | SIGNAL VCC |
| 37 | LG | SIGNAL GND |
| 38 | R | HP |
| 39 | BR | COMM (DISP->CONT) |
| 40 | B | RGB AREA (Y'S) SIGNAL |
| 41 | SHIELD | SHIELD |
| 42 | W | RGB SYNC |
| 43 | G | RGB (R/RED) SIGNAL |
| 44 | L | RGB (G/GREEN) SIGNAL |
| 45 | P | RGB (B/BLUE) SIGNAL |
| 46 | V | COMPOSITE IMAGE SIGNAL GND |
| 47 | SB | COMPOSITE IMAGE SIGNAL |
| 48 | Y | INVERTER VCC |
| 49 | BR | INVERTER GND |
| 50 | G | VFP |
| 51 | Y | COMM (CONT->DISP) |
| 52 | SHIELD | SHIELD |
| 57 | SHIELD | SHIELD |
| 58 | SHIELD | SHIELD |

| | |
|----------------|-----------------|
| Connector No. | M204 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH22FW-NH |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 76 | LG | AV COMM (L) |
| 77 | SB | AV COMM (H) |
| 78 | LG | AV COMM (L) |
| 79 | SB | AV COMM (H) |
| 80 | P | CAN-H |
| 81 | L | CAN-L |
| 82 | B | SW GND |
| 86 | SHIELD | SHIELD |
| 87 | L | TEL VOICE SIGNAL (+) |
| 88 | P | TEL VOICE SIGNAL (-) |
| 92 | R | VEHICLE SPEED SIGNAL (8-PULSE) |
| 93 | V | PARKING BRAKE SIGNAL |
| 94 | BG | REVERSE SIGNAL |
| 95 | G | IGNITION SIGNAL |
| 96 | Y | DISK-EJECT SIGNAL |

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

A
B
C
D
E
F
G
H
I
J
K

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M210 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH2FV-NH |



| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------------|
| 65 | V | PARKING BRAKE SIGNAL |
| 67 | G | COMPOSITE IMAGE SIGNAL |
| 68 | R | COMPOSITE IMAGE SIGNAL GND |
| 71 | SHIELD | COMPOSITE IMAGE SIGNAL SHIELD |
| 72 | R | MICROPHONE SHIELD |
| 73 | R | MICROPHONE VCC |
| 74 | P | COMM (CONT->DISP) |
| 75 | LG | CAN-L |
| 76 | LG | AV COMM (L) |
| 79 | R | AV COMM (L) |
| 80 | G | ILLUMINATION |
| 81 | EG | IGNITION SIGNAL |
| 82 | R | REVERSE SIGNAL |
| 83 | SHIELD | VEHICLE SPEED SIGNAL (θ-PULSE) SHIELD |
| 87 | G | MICROPHONE SIGNAL |
| 88 | SHIELD | SHIELD |
| 89 | G | COMM (DISP->CONT) |
| 90 | L | CAN-H |
| 91 | SB | AV COMM (H) |
| 92 | SB | AV COMM (H) |

MIR

M
N
O
P

Fail Safe

The fail-safe mode may be activated if the following symptoms are observed.

JCJWA1329GB

INFOID:0000000006935353

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Operating in fail-safe mode | Malfunction Item | Related DTC | Diagnosis |
|---|-----------------------|-------------|------------------------|
| Only manual functions operate normally. | CAN communication | U1000 | ADP-44 |
| | Tilt sensor | B2118 | ADP-49 |
| | Telescopic sensor | B2119 | ADP-52 |
| | Detent switch | B2126 | ADP-55 |
| Only manual functions, except door mirror, operate normally. | UART communication | B2128 | ADP-57 |
| Only manual functions, except seat sliding, operate normally. | Seat sliding output | B2112 | ADP-45 |
| Only manual functions, except seat reclining, operate normally. | Seat reclining output | B2113 | ADP-47 |

DTC Index

INFOID:000000006935354

| CONSULT-III display | Timing ^{*1} | | Item | Reference page |
|--------------------------|----------------------|-----------------------|-----------------------------|------------------------|
| | Current mal-function | Previous mal-function | | |
| CAN COMM CIRCUIT [U1000] | 0 | 1-39 | CAN communication | ADP-44 |
| SEAT SLIDE [B2112] | 0 | 1-39 | Seat slide motor output | ADP-45 |
| SEAT RECLINING [B2113] | 0 | 1-39 | Seat reclining motor output | ADP-47 |
| TILT SENSOR [B2118] | 0 | 1-39 | Tilt sensor input | ADP-49 |
| TELESCO SENSOR [B2119] | 0 | 1-39 | Telescopic sensor input | ADP-52 |
| DETENT SW [B2126] | 0 | 1-39 | Detention switch condition | ADP-55 |
| UART COMM [B2128] | 0 | 1-39 | UART communication | ADP-57 |

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value

INFOID:000000006935355

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx.) |
|--------------|--------|------------|--|------------------|----------------------------|--|
| + | - | | Signal name | Input/ Output | | |
| 1 | Ground | Y | Tilt switch up signal | Input | Tilt switch | Operate (up) 0 |
| | | | | | | Other than above 5 |
| 2 | Ground | LG | Changeover switch RH signal | Input | Changeover switch position | RH 0 |
| | | | | | | Neutral or LH 5 |
| 3 | Ground | G | Mirror switch up signal | Input | Mirror switch | Operated (up) 0 |
| | | | | | | Other than above 5 |
| 4 | Ground | V | Mirror switch left signal | Input | Mirror switch | Operated (left) 0 |
| | | | | | | Other than above 5 |
| 5 | Ground | R | Door mirror sensor (RH) up/down signal | Input | Door mirror RH position | Change between 3.4 (close to peak) 0.6 (close to valley) |
| 6 | Ground | GR | Door mirror sensor (LH) up/down signal | Input | Door mirror LH position | Change between 3.4 (close to peak) 0.6 (close to valley) |
| 7 | Ground | O | Tilt sensor signal | Input | Tilt position | Change between 1.2 (close to top) 3.4 (close to bottom) |
| 9 | Ground | L | Memory switch 1 signal | Input | Memory switch 1 | Push 0 |
| | | | | | | Other than above 5 |
| 10 | Ground | V | UART communication (TX) | Output | Ignition switch ON | |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx.) |
|--------------|--------|------------|--|------------------|----------------------------|---|
| + | - | | Signal name | Input/ Output | | |
| 11 | Ground | GR | Telescopic switch forward signal | Input | Telescopic switch | Operate (forward) 0 |
| | | | | | | Other than above 5 |
| 12 | Ground | O | Memory indicator 1 signal | Output | Memory indicator 1 | Illuminate 0 |
| | | | | | | Other than above Battery voltage |
| 13 | Ground | P | Memory indicator 2 signal | Output | Memory indicator 2 | Illuminate 0 |
| | | | | | | Other than above Battery voltage |
| 14 | Ground | W | Door mirror motor (RH) up output signal | Output | Door mirror RH | Operate (up) Battery voltage |
| | | | | | | Other than above 0 |
| 15 | Ground | G | Door mirror motor (RH) left output signal | Output | Door mirror RH | Operate (left) Battery voltage |
| | | | | | | Other than above 0 |
| 16 | Ground | Y | Door mirror motor (LH) down output signal | Output | Door mirror (LH) | Operate (down) Battery voltage |
| | | | | | | Other than above 0 |
| | | | Door mirror motor (LH) right output signal | | | Operate (right) Battery voltage |
| | | | | | | Other than above 0 |
| 17 | Ground | W | Tilt switch down signal | Input | Tilt switch | Operate (down) 0 |
| | | | | | | Other than above 5 |
| 18 | Ground | P | Changeover switch LH signal | Input | Changeover switch position | LH 0 |
| | | | | | | Neutral or RH 5 |
| 19 | Ground | SB | Mirror switch down signal | Input | Mirror switch | Operate (down) 0 |
| | | | | | | Other than above 5 |
| 20 | Ground | BR | Mirror switch right signal | Input | Mirror switch | Operate (right) 0 |
| | | | | | | Other than above 5 |
| 21 | Ground | L | Door mirror sensor (RH) left/right signal | Input | Door mirror RH position | Change between 3.4 (close to left edge) 0.6 (close to right edge) |
| 22 | Ground | G | Door mirror sensor (LH) left/right signal | Input | Door mirror LH position | Change between 0.6 (close to left edge) 3.4 (close to right edge) |
| 23 | Ground | P | Telescopic sensor signal | Input | Telescopic position | Change between 0.8 (close to top) 3.4 (close to bottom) |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. | | Wire color | Description | | Condition | | Voltage (V) (Approx.) |
|--------------|--------|------------|--|------------------|---------------------|---|--------------------------|
| + | - | | Signal name | Input/ Output | | | |
| 24 | Ground | R | Set switch signal | Input | Set switch | Push | 0 |
| | | | | | | Other than above | 5 |
| 25 | Ground | SB | Memory switch 2 signal | Input | Memory switch 2 | Push | 0 |
| | | | | | | Other than above | 5 |
| 26 | Ground | Y | UART communication (RX) | Input | Ignition switch ON |  | |
| 27 | Ground | G | Telescopic switch backward signal | Input | Telescopic switch | Operate (backward) | 0 |
| | | | | | | Other than above | 5 |
| 30 | Ground | R | Door mirror motor (RH) down output signal | Output | Door mirror (RH) | Operate (down) | Battery voltage |
| | | | | | | Other than above | 0 |
| | | | Door mirror motor (RH) right output signal | | | Operate (right) | Battery voltage |
| | | | | | | Other than above | 0 |
| 31 | Ground | LG | Door mirror motor (LH) up output signal | Output | Door mirror (LH) | Operate (up) | Battery voltage |
| | | | | | | Other than above | 0 |
| 32 | Ground | L | Door mirror motor (LH) left output signal | Output | Door mirror (LH) | Operate (left) | Battery voltage |
| | | | | | | Other than above | 0 |
| 33 | Ground | R | Sensor power supply | Input | — | 5 | |
| 34 | Ground | R | Power source (Fuse) | Input | — | Battery voltage | |
| 35 | Ground | L | Tilt motor up output signal | Output | Steering tilt | Operate (up) | Battery voltage |
| | | | | | | Other than above | 0 |
| 36 | Ground | GR | Telescopic motor forward output signal | Output | Steering telescopic | Operate (forward) | Battery voltage |
| | | | | | | Other than above | 0 |
| 39 | Ground | SB | Power source (C/B) | — | — | Battery voltage | |
| 40 | Ground | B | Ground | — | — | 0 | |
| 41 | Ground | Y | Sensor ground | — | — | 0 | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


| Terminal No. | | Wire color | Description | | Condition | Voltage (V) (Approx.) |
|--------------|--------|------------|---|------------------|---------------------|--------------------------|
| + | - | | Signal name | Input/ Output | | |
| 42 | Ground | O | Tilt motor down output signal | Output | Steering tilt | Battery voltage |
| | | | | | Operate (down) | 0 |
| 44 | Ground | G | Telescopic motor backward output signal | Output | Steering telescopic | Battery voltage |
| | | | | | Operate (backward) | 0 |
| 48 | Ground | B | Ground | — | — | 0 |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

◁ NV ▷ : With NAVI




JCJWA1316GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCJWA1317GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

*: This connector is not shown in "Harness Layout".



JCJWA1318GB


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FN-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | R | |
| 5 | G | |
| 6 | SB | |
| 7 | Y | |
| 8 | L | |
| 12 | SB | |
| 13 | LG | |
| 14 | GR | |
| 15 | LG | |
| 17 | W | |
| 18 | SB | |
| 19 | LG | |
| 20 | BR | |
| 21 | SHIELD | |
| 22 | Y | |
| 24 | P | |
| 27 | B | |
| 28 | R | |
| 29 | W | |
| 30 | SHIELD | |
| 31 | SHIELD | |
| 32 | W | |
| 33 | SB | |
| 34 | L | |
| 35 | P | |
| 36 | L | |
| 37 | P | |
| 38 | BR | |
| 39 | Y | |
| 44 | Y | |
| 45 | GR | |
| 46 | LG | |
| 47 | SB | |
| 49 | G | |
| 50 | V | |
| 60 | P | |
| 61 | L | |
| 62 | SHIELD | |

| | | |
|----|--------|--|
| 63 | R | |
| 64 | G | |
| 65 | SHIELD | |
| 66 | W | |
| 67 | V | |
| 68 | SB | |
| 69 | SHIELD | |
| 70 | W | |
| 73 | SB | |
| 74 | L | |
| 75 | W | |
| 76 | BR | |
| 77 | R | |
| 78 | P | |
| 79 | GR | |
| 83 | BG | |
| 85 | V | |
| 86 | LG | |
| 87 | Y | |
| 88 | R | |
| 89 | B | |
| 90 | BG | |
| 91 | G | |
| 92 | BR | |
| 93 | G | |
| 94 | SB | |
| 95 | G | |
| 96 | Y | |
| 98 | W | |
| 99 | GR | |

| | |
|----------------|--------------|
| Connector No. | B5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MP-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | SB | |
| 3 | Y | |
| 4 | R | |
| 5 | W | |
| 6 | G | |

| | | |
|----|--------|--|
| 7 | LG | |
| 8 | B | |
| 9 | V | |
| 10 | SB | |
| 11 | GR | |
| 12 | W | |
| 13 | SHIELD | |
| 14 | SB | |
| 15 | GR | |
| 16 | P | |
| 21 | G | |
| 22 | B | |
| 23 | SHIELD | |
| 24 | BG | |
| 25 | BR | |
| 26 | Y | |
| 27 | W | |
| 28 | R | |
| 29 | L | |
| 30 | SHIELD | |
| 31 | Y | |

| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 3 | L | |
| 17 | Y | |
| 19 | P | |
| 21 | V | |
| 32 | B | |
| 33 | R | |
| 40 | BR | |
| 48 | B | |
| 59 | B | |
| 60 | G | |
| 66 | GR | |
| 67 | Y | |

| | |
|----------------|---------------------------------|
| Connector No. | B16 |
| Connector Name | FRONT DOOR SWITCH (DRIVER SIDE) |
| Connector Type | AG3FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | V | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|----------------------------------|
| Connector No. | B46 |
| Connector Name | AROUND VIEW MONITOR CONTROL UNIT |
| Connector Type | TH407V-NH |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 1 | B | GND |
| 2 | Y | BATTERY |
| 3 | P | IGNITION SIGNAL |
| 4 | GR | ACC |
| 5 | BG | ILLUMINATION SIGNAL |
| 6 | SB | VEHICLE SPEED SIGNAL (θ-PULSE) |
| 7 | V | REVERSE SIGNAL |
| 8 | V | CONTROL SIGNAL |
| 13 | B | AV COMM (H) |
| 17 | SB | AV COMM (L) |
| 18 | LG | AV COMM (H) |
| 21 | SB | AV COMM (L) |
| 22 | LG | AV COMM (L) |
| 23 | LG | AUXILIARY INFRARED LED (+) |
| 24 | G | AUXILIARY INFRARED LED (-) |
| 27 | W | CAMERA IMAGE SIGNAL |
| 28 | SHIELD | CAMERA IMAGE SIGNAL GND |
| 29 | Y | SIDE CAMERA RH IMAGE SIGNAL |
| 30 | G | SIDE CAMERA RH IMAGE GND |
| 31 | SHIELD | SHIELD |
| 32 | B | SIDE CAMERA RH COMM |
| 33 | W | SIDE CAMERA RH COMM |
| 34 | R | SIDE CAMERA RH POWER SUPPLY |
| 35 | L | REAR CAMERA COMM |
| 36 | BR | REAR CAMERA POWER SUPPLY |
| 37 | SHIELD | SHIELD |
| 38 | R | REAR CAMERA GND |
| 39 | Y | REAR CAMERA IMAGE SIGNAL |
| 40 | W | REAR CAMERA IMAGE GND |

| | |
|----------------|--------------------------|
| Connector No. | B451 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | TH32FW |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L/W | RX |
| 3 | R/Y | CAN-H |
| 9 | W/G | PULSE (RECLINING) |
| 10 | P/B | PULSE (RR LIFTING) |
| 11 | BR | SLIDING SW (BACKWARD) |
| 12 | SB | RECLINING SW (BACKWARD) |
| 13 | L/G/R | FRONT LIFTING SW (DOWNWARD) |
| 14 | G/B | REAR LIFTING SW (DOWNWARD) |
| 16 | O | VCC |
| 17 | Y/R | TX |
| 19 | V | CAN-L |
| 21 | L/Y | P RANGE SW |
| 24 | R | PULSE (SLIDING) |
| 25 | Y/B | PULSE (FR LIFTING) |
| 26 | Y | SLIDING SW (FORWARD) |
| 27 | R/G | RECLINING SW (FORWARD) |
| 28 | W/B | FRONT LIFTING SW (UPWARD) |
| 29 | P/L | REAR LIFTING SW (UPWARD) |
| 31 | GR | SENSOR GND |
| 32 | B/W | GND (SIGNAL) |

| | |
|----------------|--------------------------|
| Connector No. | B452 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | NS15FW-CS |

| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | R | BAT (G.B.) |
| 35 | W/R | SLIDING MOTOR (FORWARD) |

| | | |
|----|-----|--------------------------------|
| 36 | G/Y | RECLINING MOTOR (FORWARD) |
| 37 | G/W | FRONT LIFTING MOTOR (DOWNWARD) |
| 38 | L/Y | REAR LIFTING MOTOR (UPWARD) |
| 39 | R/B | REAR LIFTING MOTOR (BACKWARD) |
| 40 | R/W | BAT (USE) |
| 42 | W/B | SLIDING MOTOR (BACKWARD) |
| 44 | P | RECLINING MOTOR (BACKWARD) |
| 45 | L/R | FRONT LIFTING MOTOR (UPWARD) |
| 48 | B | GND (POWER) |

| | |
|----------------|----------------|
| Connector No. | B453 |
| Connector Name | SLIDING SENSOR |
| Connector Type | 8098 0241 |

| | | |
|----|----|----|
| 24 | 31 | 16 |
|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 18 | O | - |
| 24 | R | - |
| 31 | GR | - |

| | |
|----------------|-----------------|
| Connector No. | B454 |
| Connector Name | RECLINING MOTOR |
| Connector Type | NS08FW-CS |

| | | | | | |
|----|----|----|----|----|---|
| 36 | 38 | 44 | 16 | 31 | 9 |
|----|----|----|----|----|---|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 9 | W/G | - |
| 16 | O | - |
| 31 | GR | - |
| 36 | G/Y | - |
| 44 | P | - |

| | |
|----------------|-----------------------|
| Connector No. | B455 |
| Connector Name | LIFTING MOTOR (FRONT) |
| Connector Type | NS06FW-CS |

| | | | | |
|----|----|----|----|----|
| 45 | 37 | 16 | 31 | 25 |
|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 16 | O | - |
| 25 | Y/B | - |
| 31 | GR | - |
| 37 | G/W | - |
| 45 | L/R | - |

| | |
|----------------|----------------------|
| Connector No. | B456 |
| Connector Name | LIFTING MOTOR (REAR) |
| Connector Type | NS06FEBR-CS |

| | | | | |
|----|----|----|----|----|
| 38 | 39 | 16 | 31 | 10 |
|----|----|----|----|----|



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | P/B | - |
| 16 | O | - |
| 31 | GR | - |
| 38 | L/R | - |
| 39 | R/B | - |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-------------------|
| Connector No. | B469 |
| Connector Name | POWER SEAT SWITCH |
| Connector Type | NS10PW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11 | BR | - |
| 12 | SB | - |
| 13 | LG/R | - |
| 14 | G/B | - |
| 26 | Y | - |
| 27 | R/G | - |
| 28 | W/B | - |
| 29 | P/L | - |
| 32 | B/W | - |

| | |
|----------------|--------------|
| Connector No. | B460 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS (BMW-CS) |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L/W | - |
| 3 | R/Y | - |
| 17 | Y/R | - |
| 19 | V | - |
| 21 | L/Y | - |
| 32 | B/W | - |
| 33 | R | - |
| 40 | R/W | - |
| 48 | B | - |
| 56 | Y | - |
| 60 | Y/R | - |
| 66 | B | - |
| 67 | L | - |

| | |
|----------------|---------------|
| Connector No. | B461 |
| Connector Name | SLIDING MOTOR |
| Connector Type | 6098-0238 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 35 | W/R | - |
| 42 | W/B | - |

| | |
|----------------|--------------|
| Connector No. | D1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40PW-CS15 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | V | - |
| 4 | W | - |
| 5 | L | - |
| 6 | O | - |
| 7 | GR | - |
| 8 | W | - |
| 9 | O | - |
| 10 | BR | - |
| 11 | P | - |
| 12 | LG | - |
| 13 | B | - |
| 14 | Y | - |
| 15 | W | - |
| 16 | R | - |
| 17 | W | - |
| 18 | G | - |
| 19 | Y | - |
| 20 | W | - |

| | | |
|----|--------|--|
| 21 | O | - |
| 22 | P | - |
| 23 | BR | - |
| 24 | V | - |
| 25 | GR | - |
| 26 | Y | - |
| 27 | B | - |
| 28 | SHIELD | - |
| 29 | LG | - |
| 30 | G | - |
| 31 | W | - |
| 32 | G | - |
| 33 | L | - |
| 34 | SB | - |
| 35 | R | - |
| 36 | LG | - |
| 37 | R | - |
| 38 | P | - |
| 39 | O | - |
| 40 | BR | - |
| 41 | L | - |
| 42 | GR | - |
| 43 | BR | - [With automatic drive positioner] |
| 43 | O | - [Without automatic drive positioner] |
| 44 | W | - [With automatic drive positioner] |
| 44 | GR | - [Without automatic drive positioner] |
| 45 | Y | - [With automatic drive positioner] |
| 45 | G | - [Without automatic drive positioner] |
| 46 | G | - [With automatic drive positioner] |
| 46 | V | - [Without automatic drive positioner] |
| 49 | GR | - |
| 50 | B | - |
| 52 | R | - |
| 53 | SB | - |
| 54 | O | - |
| 55 | Y | - |

| | |
|----------------|---------------------------|
| Connector No. | D3 |
| Connector Name | DOOR MIRROR (DRIVER SIDE) |
| Connector Type | TH24MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12 | O | - |
| 11 | P | - |
| 10 | BR | - |
| 9 | V | - |
| 8 | Y | - |
| 7 | B | - |
| 6 | W | - |
| 5 | R | - |
| 4 | O | - |
| 3 | L | - |
| 2 | P | - |

| | | |
|----|----|---|
| 2 | O | - |
| 3 | B | - |
| 5 | Y | - |
| 6 | R | - |
| 7 | W | - |
| 10 | G | - |
| 11 | P | - |
| 12 | O | - |
| 14 | LG | - |
| 17 | G | - |
| 18 | W | - |
| 19 | B | - |
| 21 | GR | - |
| 22 | BR | - |
| 23 | Y | - |
| 24 | V | - |

| | |
|----------------|--------------------|
| Connector No. | D5 |
| Connector Name | SEAT MEMORY SWITCH |
| Connector Type | JABFW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 2 | BR | - |
| 3 | GR | - |
| 4 | B | - |
| 5 | R | - |
| 6 | O | - |
| 7 | P | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------------------------|
| Connector No. | D17 |
| Connector Name | DOOR MIRROR REMOTE CONTROL SWITCH |
| Connector Type | TK06BR |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 4 | BR | - |
| 7 | B | - |
| 8 | B | - |
| 9 | R | - |
| 10 | GR | - |
| 11 | LG | - |
| 12 | G | - |
| 13 | W | - |
| 15 | Y | - |

| | |
|----------------|--------------|
| Connector No. | D31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-CS15 |



| | | |
|----|--------|------------------------|
| 21 | G | - [With BOSE audio] |
| 21 | BR | - [Without BOSE audio] |
| 22 | V | - |
| 23 | P | - |
| 24 | W | - |
| 25 | SB | - |
| 26 | R | - |
| 29 | SHIELD | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | BR | - |
| 33 | O | - |
| 34 | GR | - |
| 35 | G | - |
| 43 | Y | - |
| 44 | V | - |
| 45 | P | - |
| 46 | W | - |
| 52 | G | - |
| 53 | GR | - |
| 54 | O | - |
| 55 | L | - |

| | |
|----------------|------------------------------|
| Connector No. | D33 |
| Connector Name | DOOR MIRROR (PASSENGER SIDE) |
| Connector Type | TH24MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | SIDE CAMERA RH COMM |
| 4 | LG | SIDE CAMERA RH IMAGE SIGNAL |
| 5 | B | SIDE CAMERA RH POWER SUPPLY |
| 6 | R | - |
| 7 | L | - |
| 10 | G | - |
| 11 | GR | - |
| 12 | O | - |
| 16 | BR | SIDE CAMERA RH IMAGE GND |
| 17 | G | SIDE CAMERA RH GND |
| 18 | Y | - |
| 19 | B | - |
| 21 | P | - |
| 22 | Y | - |

| | | |
|----|---|---|
| 23 | W | - |
| 24 | V | - |

JCJWA1322GB


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | E106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80PW-CS16-TM4 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | W | |
| 3 | B | |
| 4 | GR | |
| 5 | GR | |
| 6 | Y | |
| 8 | BR | |
| 9 | BR | |
| 10 | EG | |
| 11 | SB | |
| 12 | EG | |
| 13 | L | |
| 14 | R | |
| 15 | P | |
| 16 | V | |
| 17 | SB | |
| 18 | V | |
| 20 | EG | |
| 21 | L | |
| 22 | V | |
| 23 | G | |
| 24 | P | |
| 26 | Y | |
| 26 | V | |
| 27 | W | |
| 28 | G | |
| 31 | EG | |
| 32 | W | |
| 33 | B | |
| 34 | R | |
| 35 | G | |
| 36 | SHIELD | |
| 37 | V | |
| 38 | BR | |
| 39 | EG | |
| 41 | W | |
| 42 | G | |
| 43 | BR | |
| 45 | W | |

| | | |
|----|--------|-----------------|
| 49 | L | |
| 50 | P | |
| 51 | L | |
| 52 | L | |
| 53 | P | |
| 54 | EG | |
| 56 | BR | |
| 57 | BR | |
| 59 | W | |
| 60 | LG | |
| 61 | G | |
| 62 | SB | |
| 63 | W | |
| 64 | B | |
| 65 | G | |
| 66 | R | |
| 67 | SHIELD | |
| 68 | Y | |
| 69 | LG | |
| 70 | W | |
| 71 | R | |
| 72 | Y | |
| 73 | B | |
| 74 | BR | |
| 74 | L | - [With ICC] |
| 75 | G | - [Without ICC] |
| 75 | G | - [With ICC] |
| 75 | W | - [Without ICC] |
| 76 | W | - [With ICC] |
| 76 | Y | - [Without ICC] |
| 77 | R | - [With ICC] |
| 77 | P | - [Without ICC] |
| 78 | L | - [With ICC] |
| 78 | BR | - [Without ICC] |
| 79 | Y | - [With ICC] |
| 79 | L | - [Without ICC] |
| 80 | SB | |
| 81 | R | |
| 82 | SB | |
| 83 | EG | |
| 84 | G | |
| 85 | L | |
| 86 | P | |
| 87 | V | |
| 89 | GR | |
| 90 | SHIELD | |
| 91 | W | |
| 92 | Y | |
| 93 | V | |
| 94 | LG | |
| 95 | EG | |
| 96 | P | |
| 97 | R | |

| | | |
|-----|--------|--|
| 98 | SHIELD | |
| 99 | L | |
| 100 | P | |

| | |
|----------------|--------------|
| Connector No. | F51 |
| Connector Name | A/T ASSEMBLY |
| Connector Type | RK10FG-DGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | |
| 2 | BR | |
| 3 | L | |
| 4 | V | |
| 5 | B | |
| 6 | Y | |
| 7 | R | |
| 8 | P | |
| 9 | GR | |
| 10 | B | |


| | |
|----------------|-----------------------------------|
| Connector No. | F301 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Type | SPT0FG |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | VIGN |
| 2 | - | BATT |
| 3 | - | CAN-H |
| 4 | - | K LINE |
| 5 | - | GND |
| 6 | - | VIGN |
| 7 | - | REV LAMP RLY |

| | | |
|----|---|-----------|
| 8 | - | CAN-L |
| 9 | - | START RLY |
| 10 | - | GND |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | |
| 2A | G | |
| 3A | L | |
| 4A | P | |
| 5A | V | |
| 6A | Y | |
| 7A | R | |
| 8A | L | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|--------------|
| Connector No. | M4 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH27V-NH |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | SB | |
| 3 | Y | |
| 4 | R | |
| 5 | W | |
| 6 | C | |
| 7 | LG | |
| 8 | B | |
| 9 | V | |
| 10 | B | |
| 11 | W | |
| 12 | W | |
| 13 | SHIELD | |
| 14 | V | |
| 15 | V | |
| 16 | W | |
| 17 | G | |
| 22 | B | |
| 23 | SHIELD | |
| 24 | R | |
| 25 | R | |
| 26 | Y | |
| 27 | G | |
| 28 | B | |
| 29 | W | |
| 30 | SHIELD | |
| 31 | Y | |

| | |
|----------------|--------------|
| Connector No. | M5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH4GMV-CS15 |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | B | |
| 3 | BR | |
| 4 | P | |
| 5 | L | |
| 6 | R | |
| 7 | R | |
| 8 | W | |
| 9 | G | |
| 10 | L | |
| 11 | G | |
| 12 | V | |
| 13 | B | |
| 14 | Y | |
| 15 | W | |
| 16 | R | |
| 17 | B | |
| 18 | G | |
| 19 | Y | |
| 20 | L | |
| 21 | LG | |
| 22 | L | |
| 23 | G | |
| 24 | Y | |
| 25 | GR | |
| 26 | R | |
| 27 | W | |
| 28 | SHIELD | |
| 29 | Y | |
| 30 | Y | |
| 31 | R | |
| 32 | BR | |
| 33 | SB | |
| 34 | Y | |
| 35 | P | |
| 36 | LG | |
| 37 | BR | |
| 38 | P | |

| | | |
|----|----|--|
| 39 | BG | - |
| 40 | SB | - |
| 41 | L | - |
| 42 | R | - |
| 43 | BR | - |
| 44 | V | - |
| 45 | G | - |
| 46 | SB | - [With automatic drive positioner] |
| 48 | V | - [Without automatic drive positioner] |
| 49 | P | - |
| 50 | B | - |
| 52 | R | - |
| 53 | V | - |
| 54 | LG | - |
| 55 | SB | - |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | |
| 2 | R | |
| 3 | B | |
| 4 | SHIELD | |
| 5 | G | |
| 6 | Y | |
| 8 | BR | |
| 9 | BR | |
| 10 | R | |
| 11 | BR | |
| 12 | BG | |
| 13 | L | |
| 14 | R | |
| 15 | P | |
| 16 | V | |
| 17 | SB | |
| 18 | V | |
| 20 | BG | |
| 21 | L | |
| 22 | W | |
| 23 | P | |
| 24 | BR | |
| 26 | Y | |
| 26 | V | |
| 27 | G | |
| 28 | G | |
| 31 | L | |
| 32 | G | |
| 33 | B | |
| 34 | W | |
| 35 | R | |
| 36 | SHIELD | |
| 37 | V | |
| 38 | BG | |
| 39 | BR | |
| 41 | W | |
| 42 | BG | |
| 43 | BG | |
| 45 | W | |

| | | |
|----|--------|--|
| 49 | L | |
| 50 | P | |
| 51 | BR | |
| 52 | L | |
| 53 | P | |
| 54 | Y | |
| 56 | BR | |
| 57 | G | |
| 59 | W | |
| 60 | L | |
| 61 | G | |
| 62 | SB | |
| 63 | G | |
| 64 | B | |
| 65 | W | |
| 66 | R | |
| 67 | SHIELD | |
| 68 | Y | |
| 69 | GR | |
| 70 | LG | |
| 71 | LG | |
| 72 | Y | |
| 73 | SB | |
| 74 | BR | |
| 74 | L | |
| 75 | G | |
| 76 | W | |
| 76 | GR | |
| 77 | R | |
| 77 | P | |
| 78 | L | |
| 78 | R | |
| 79 | Y | |
| 79 | W | |
| 80 | SB | |
| 81 | SB | |
| 82 | SB | |
| 83 | V | |
| 84 | G | |
| 85 | L | |
| 86 | P | |
| 87 | W | |
| 89 | GR | |
| 90 | SHIELD | |
| 91 | W | |
| 92 | Y | |
| 93 | BR | |
| 94 | P | |
| 95 | GR | |
| 96 | W | |
| 97 | L | |
| 98 | SHIELD | |

| | |
|----------------|----|
| Connector No. | V |
| Connector Name | SB |

| | |
|----------------|-----------------|
| Connector No. | M7 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS18-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 3 | SB | - [With automatic drive positioner] |
| 3 | W | - [Without automatic drive positioner] |
| 5 | G | |
| 6 | BG | |
| 7 | W | |
| 8 | B | |
| 12 | SB | |
| 13 | LG | |
| 14 | Y | |
| 15 | G | |
| 17 | W | |
| 18 | SB | |
| 19 | LG | |
| 20 | BR | |
| 21 | SHIELD | |
| 22 | Y | |
| 24 | V | |
| 27 | B | |
| 27 | W | |
| 28 | R | |
| 30 | SHIELD | |
| 31 | L | |
| 32 | P | |
| 33 | SB | |
| 34 | L | |
| 35 | P | |
| 36 | L | |
| 37 | P | |
| 38 | BR | |
| 39 | Y | |
| 44 | L | |
| 45 | GR | |
| 46 | LG | |
| 47 | SB | |

| | | |
|----|--------|--|
| 49 | V | |
| 50 | R | |
| 60 | P | |
| 61 | L | |
| 62 | SHIELD | |
| 63 | R | |
| 64 | G | |
| 65 | SHIELD | |
| 66 | SB | |
| 67 | V | |
| 68 | LG | |
| 69 | SHIELD | |
| 70 | W | |
| 73 | G | |
| 74 | R | |
| 75 | W | |
| 76 | W | |
| 77 | B | |
| 78 | P | |
| 79 | GR | |
| 83 | BG | |
| 85 | LG | |
| 86 | R | |
| 87 | Y | |
| 88 | W | |
| 89 | BR | |
| 90 | BG | |
| 91 | G | |
| 92 | V | |
| 93 | BR | |
| 94 | V | |
| 95 | G | |
| 96 | Y | |
| 98 | W | |
| 99 | R | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------|
| Connector No. | M22 |
| Connector Name | KEY SLOT |
| Connector Type | TH12FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | BAT |
| 2 | GR | CLOCK |
| 3 | W | DATA |
| 5 | Y | ILL BATT |
| 6 | LG | ILL |
| 7 | B | GND |
| 11 | BR | KEY SWITCH SIGNAL |

| | |
|----------------|---------------------|
| Connector No. | M24 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B | - |
| 5 | B | - |
| 6 | L | - |
| 7 | V | - |
| 8 | G | - |
| 11 | SB | - |
| 14 | P | - |
| 16 | Y | - |

| | |
|----------------|--------------------------|
| Connector No. | M31 |
| Connector Name | TILT & TELESCOPIC SWITCH |
| Connector Type | TK08FY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | GR | - |
| 3 | G | - |
| 4 | Y | - |
| 5 | W | - |

| | |
|----------------|--------------------------|
| Connector No. | M48 |
| Connector Name | TILT & TELESCOPIC SENSOR |
| Connector Type | TK04FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | P | - |
| 3 | BG | - |
| 4 | Y | - |

| | |
|----------------|-------------------------|
| Connector No. | M49 |
| Connector Name | TILT & TELESCOPIC MOTOR |
| Connector Type | NS04FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | GR | - |
| 3 | BG | - |
| 4 | L | - |

| | |
|----------------|---|
| Connector No. | M51 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | TH02FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------|
| 1 | Y | TILT SW (UPWARD) |
| 2 | LG | MIRROR SELECT SW (RH) |
| 3 | G | MIRROR SW (UPWARD) |
| 4 | V | MIRROR SW (LEFTWARD) |
| 5 | R | MIRROR SENSOR (RH VERTICAL) |
| 6 | GR | MIRROR SENSOR (LH VERTICAL) |
| 7 | BG | TILT SENSOR |
| 9 | L | TX (UART) |
| 10 | V | ADDRESS |
| 11 | GR | TELESCOPIC SW (FRONTWARD) |
| 12 | BG | IND1 |
| 13 | P | IND2 |
| 14 | W | MIRROR MOTOR (RH VERTICAL) |
| 15 | G | MIRROR MOTOR (RH HORIZONTAL) |
| 16 | Y | MIRROR MOTOR (LH COMMON) |
| 17 | W | TILT SW (DOWNWARD) |
| 18 | P | MIRROR SELECT SW (LH) |
| 19 | SB | MIRROR SW (DOWNWARD) |

| | | |
|----|----|-------------------------------|
| 20 | BR | MIRROR SW (RIGHTWARD) |
| 21 | L | MIRROR SENSOR (RH HORIZONTAL) |
| 22 | G | MIRROR SENSOR (LH HORIZONTAL) |
| 23 | P | TELESCOPIC SENSOR |
| 24 | R | SET SW |
| 25 | SB | ADDRESS |
| 26 | Y | RX (UART) |
| 27 | G | TELESCOPIC SW (BACKWARD) |
| 30 | R | MIRROR MOTOR (RH COMMON) |
| 31 | LG | MIRROR MOTOR (LH VERTICAL) |
| 32 | L | MIRROR MOTOR (LH HORIZONTAL) |

| | |
|----------------|---|
| Connector No. | M52 |
| Connector Name | AUTOMATIC DRIVE POSITIONER CONTROL UNIT |
| Connector Type | NS16FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | R | POWER SUPPLY (SENSOR) |
| 34 | R | BAT (FUSE) |
| 35 | L | TILT MOTOR (UPWARD) |
| 36 | GR | TELESCOPIC MOTOR (FORWARD) |
| 39 | SB | BAT (C/B) |
| 40 | B | GND(SIGNAL) |
| 41 | Y | GND(SENSOR) |
| 42 | BG | TILT MOTOR (DOWNWARD) |
| 44 | G | TELESCOPIC MOTOR (BACKWARD) |
| 48 | B | GND(POWER) |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M62 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | M02PW-P-LC |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | SB | - |


| | |
|----------------|----------------------------|
| Connector No. | M67 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH02PW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 41 | V | ACC POWER SUPPLY |
| 42 | Y | FUEL LEVEL SENSOR SIGNAL |
| 43 | R | INTAKE SENSOR SIGNAL |
| 44 | LG | IN-VEHICLE SENSOR SIGNAL |
| 45 | P | AMBIENT SENSOR SIGNAL |
| 46 | EG | SUNLOAD SENSOR SIGNAL |
| 47 | G | EXHAUST GAS / OUTSIDE TEMPERATURE SENSOR SIGNAL |
| 53 | G | IGNITION POWER SUPPLY |
| 54 | Y | BATTERY POWER SUPPLY |
| 55 | B | GROUND |
| 56 | L | CAN-H |
| 57 | W | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 58 | BR | FUEL LEVEL SENSOR GROUND |
| 59 | GR | INTAKE SENSOR GROUND |
| 60 | L | IN-VEHICLE SENSOR GROUND |
| 61 | BR | AMBIENT SENSOR GROUND |
| 62 | SB | SUNLOAD SENSOR GROUND |
| 63 | R | - |
| 65 | EG | ECV SIGNAL |
| 68 | L | A/C LAM SIGNAL |

| | | |
|----|---|------------------------------|
| 70 | R | EACH DOOR MOTOR POWER SUPPLY |
| 71 | B | GROUND |
| 72 | P | CAN-L |

| | |
|----------------|----------------------|
| Connector No. | M72 |
| Connector Name | MULTIFUNCTION SWITCH |
| Connector Type | TH16PW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | GROUND |
| 3 | V | ACC |
| 4 | R | ILL |
| 5 | Y | ILL CONT |
| 6 | SB | AV COMM (H) |
| 8 | LG | AV COMM (L) |
| 9 | B | SW GND |
| 14 | Y | DISK EJECT SIGNAL |
| 16 | G | HAZARD ON |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03PB-LG |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (F/L) |
| 2 | W | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | Y | POWER WINDOW POWER SUPPLY (RAP) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M016PW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 4 | LG | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | L | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | Y | STEER LAMP OUTPUT |
| 8 | V | ALL DOOR FUEL LID LOCK OUTPUT |
| 9 | G | DRIVER DOOR FUEL LID UNLOCK OUTPUT |
| 10 | BR | REAR DOOR UNLOCK OUTPUT |
| 11 | R | BAT (FUSE) |
| 13 | B | GROUND |
| 14 | W | PUSH-BUTTON IGNITION SW ILL GND |
| 15 | Y | ACC IND |
| 17 | W | TURN SIGNAL RH (FRONT) |
| 18 | BG | TURN SIGNAL LH (FRONT) |
| 19 | V | ROOM LAMP TIMER CONTROL |

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 72 | R | ROOM ANT2- |
| 73 | G | ROOM ANT2+ |
| 74 | SB | PASSENGER DOOR ANT- |
| 75 | GR | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | LG | DRIVER DOOR ANT+ |
| 78 | Y | ROOM ANT1- |
| 79 | BR | ROOM ANT1+ |
| 80 | GR | MATS ANT AMP. |

| | | |
|-----|----|-------------------------------------|
| 81 | W | MATS ANT AMP |
| 82 | R | IGN RELAY (E/B) CONT |
| 83 | V | KEYLESS ENTRY RECEIVER COMM |
| 87 | BR | COMBI SW INPUT 3 |
| 88 | V | COMBI SW INPUT 3 |
| 89 | BR | PUSH SW |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | LG | KEY SLOT ILL |
| 93 | V | ON IND |
| 94 | Y | PUDDLE LAMP CONT |
| 95 | BG | ACC RELAY CONT |
| 96 | GR | A/T SHIFT SELECTOR POWER SUPPLY |
| 97 | L | S/L CONDITION 1 |
| 98 | P | S/L CONDITION 2 |
| 99 | R | SHIFT P |
| 100 | G | PASSENGER DOOR REQUEST SW |
| 101 | SR | DRIVER DOOR REQUEST SW |
| 102 | BG | BLOWER FAN MOTOR RELAY CONT |
| 103 | LG | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 106 | W | S/L UNIT POWER SUPPLY |
| 107 | LG | COMBI SW INPUT 1 |
| 108 | R | COMBI SW INPUT 4 |
| 109 | Y | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |
| 111 | Y | S/L UNIT COMM |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-------------------------|
| Connector No. | M123 |
| Connector Name | BCM BODY CONTROL MODULE |
| Connector Type | TH4FG-NH |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 113 | P | OPTICAL SENSOR |
| 116 | SB | STOP LAMP SW 1 |
| 119 | SB | STOP LAMP SW 2 |
| 121 | BR | DR DOOR UNLOCK SENSOR |
| 122 | W | IGN F/B |
| 124 | LG | PASSENGER DOOR SW |
| 132 | BR | POWER WINDOW SW COMM |
| 133 | W | PUSH-BUTTON IGNITION SW ALL POWER LOCK IND |
| 134 | GR | RECEIVER/SENSOR GND |
| 137 | EG | RECEIVER/SENSOR POWER SUPPLY |
| 138 | Y | TIRE PRESSURE RECEIVER COMM |
| 139 | L | SHIFT N/P |
| 140 | GR | SECURITY INDICATOR OUTPUT |
| 141 | G | COMBI SW OUTPUT 5 |
| 142 | EG | COMBI SW OUTPUT 1 |
| 143 | P | COMBI SW OUTPUT 2 |
| 144 | G | COMBI SW OUTPUT 3 |
| 145 | L | COMBI SW OUTPUT 4 |
| 146 | SB | DRIVER DOOR SW |
| 150 | LG | REAR WINDOW DEFOGGER RELAY CONT |
| 151 | G | |

| | |
|----------------|--------------|
| Connector No. | M124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40WV-CS15 |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7 | Y | |
| 8 | LG | |
| 9 | Y | |
| 10 | B | |
| 11 | G | |
| 12 | L | |
| 13 | V | |
| 14 | W | |
| 15 | B | |
| 16 | BR | |
| 17 | B | |
| 18 | R | |
| 19 | B | |
| 20 | Y | - [With BOSE audio] |
| 20 | W | - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] |
| 21 | L | - [Without BOSE audio] |
| 22 | SB | |
| 23 | GR | |
| 24 | G | |
| 25 | Y | |
| 26 | R | |
| 28 | SHIELD | |
| 30 | W | |
| 31 | LG | |
| 32 | G | |
| 33 | BR | |
| 34 | V | |
| 35 | G | |
| 43 | L | |
| 44 | Y | |
| 45 | R | |
| 46 | W | |
| 52 | R | |
| 53 | G | |
| 54 | W | |
| 55 | EG | |

| | |
|----------------|--------------------|
| Connector No. | M137 |
| Connector Name | A/T SHIFT SELECTOR |
| Connector Type | TH1ZFW-NH |



| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
|---|---|---|---|---|---|---|---|---|----|----|

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | V | |
| 3 | L | |
| 4 | B | |
| 5 | G | |
| 7 | R | |
| 8 | SB | |
| 9 | B | |
| 10 | GR | |
| 11 | R | |

| | |
|----------------|-----------------|
| Connector No. | M202 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH24FW-NH |



| | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 36 | BG | SIGNAL VCC |
| 37 | LG | SIGNAL GND |
| 38 | R | HP |
| 39 | BR | COMM (DISP->CONT) |
| 40 | B | RGB AREA (Y'S) SIGNAL |
| 41 | SHIELD | |
| 42 | W | RGB SYNC |
| 43 | G | RGB (R/RED) SIGNAL |
| 44 | L | RGB (G/GREEN) SIGNAL |
| 45 | P | RGB (B/BLUE) SIGNAL |
| 46 | V | COMPOSITE IMAGE SIGNAL GND |
| 47 | SB | COMPOSITE IMAGE SIGNAL |
| 48 | Y | INVERTER VCC |
| 49 | BR | INVERTER GND |
| 50 | G | VFP |
| 51 | Y | COMM (CONT->DISP) |
| 57 | SHIELD | |
| 58 | SHIELD | |

| | |
|----------------|-----------------|
| Connector No. | M204 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH22FW-NH |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | 112 | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 76 | LG | AV COMM (L) |
| 77 | SB | AV COMM (H) |
| 78 | LG | AV COMM (L) |
| 79 | SB | AV COMM (H) |
| 80 | P | CAN-H |
| 81 | L | CAN-L |
| 82 | B | SW GND |
| 86 | SHIELD | SHIELD |
| 87 | L | TEL VOICE SIGNAL (+) |
| 88 | P | TEL VOICE SIGNAL (-) |
| 92 | R | VEHICLE SPEED SIGNAL (8-PULSE) |
| 93 | V | PARKING BRAKE SIGNAL |
| 94 | BG | REVERSE SIGNAL |
| 95 | G | IGNITION SIGNAL |
| 96 | Y | DISK-EJECT SIGNAL |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

AUTOMATIC DRIVE POSITIONER

| | |
|----------------|-----------------|
| Connector No. | M210 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH2FV-NH |



| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 65 | V | PARKING BRAKE SIGNAL |
| 67 | G | COMPOSITE IMAGE SIGNAL |
| 68 | R | COMPOSITE IMAGE SIGNAL GND |
| 71 | SHIELD | COMPOSITE IMAGE SIGNAL |
| 72 | R | MICROPHONE SHIELD |
| 72 | R | MICROPHONE VCC |
| 72 | R | COMM (CONT->DISP) |
| 74 | P | CAN-L |
| 75 | LG | AV COMM (L) |
| 76 | LG | AV COMM (L) |
| 79 | R | ILLUMINATION |
| 80 | G | IGNITION SIGNAL |
| 81 | BG | REVERSE SIGNAL |
| 82 | R | VEHICLE SPEED SIGNAL (P-PULSE) |
| 83 | SHIELD | SHIELD |
| 87 | G | MICROPHONE SIGNAL |
| 88 | SHIELD | SHIELD |
| 89 | G | COMM (DISP->CONT) |
| 90 | L | CAN-H |
| 91 | SB | AV COMM (H) |
| 92 | SB | AV COMM (H) |

MIR

JCJWA1329GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000006935358

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------------|
| FR WIPER HI | Other than front wiper switch HI | Off |
| | Front wiper switch HI | On |
| FR WIPER LOW | Other than front wiper switch LO | Off |
| | Front wiper switch LO | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER INT | Other than front wiper switch INT | Off |
| | Front wiper switch INT | On |
| FR WIPER STOP | Front wiper is not in STOP position | Off |
| | Front wiper is in STOP position | On |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | Wiper intermittent dial position |
| RR WIPER ON | Other than rear wiper switch ON | Off |
| | Rear wiper switch ON | On |
| RR WIPER INT | Other than rear wiper switch INT | Off |
| | Rear wiper switch INT | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER STOP | Rear wiper is in STOP position | Off |
| | Rear wiper is not in STOP position | On |
| TURN SIGNAL R | Other than turn signal switch RH | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Other than turn signal switch LH | Off |
| | Turn signal switch LH | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| HI BEAM SW | Other than lighting switch HI | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Monitor Item | Condition | Value/Status | |
|----------------|--|--------------|-----|
| DOOR SW-DR | Driver door closed | Off | A |
| | Driver door opened | On | |
| DOOR SW-AS | Passenger door closed | Off | B |
| | Passenger door opened | On | |
| DOOR SW-RR | Rear RH door closed | Off | C |
| | Rear RH door opened | On | |
| DOOR SW-RL | Rear LH door closed | Off | D |
| | Rear LH door opened | On | |
| DOOR SW-BK | Back door closed | Off | E |
| | Back door opened | On | |
| CDL LOCK SW | Other than power door lock switch LOCK | Off | E |
| | Power door lock switch LOCK | On | |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | Off | F |
| | Power door lock switch UNLOCK | On | |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off | G |
| | Driver door key cylinder LOCK position | On | |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off | H |
| | Driver door key cylinder UNLOCK position | On | |
| KEY CYL SW-TR | NOTE: The item is indicated, but not monitored. | Off | H |
| HAZARD SW | Hazard switch is OFF | Off | I |
| | Hazard switch is ON | On | |
| REAR DEF SW | NOTE: The item is indicated, but not monitored. | Off | J |
| TR CANCEL SW | NOTE: The item is indicated, but not monitored. | Off | K |
| TR/BD OPEN SW | Back door opener switch OFF | Off | K |
| | While the back door opener switch is turned ON | On | |
| TRNK/HAT MNTR | NOTE: The item is indicated, but not monitored. | Off | MIR |
| RKE-LOCK | LOCK button of the key is not pressed | Off | M |
| | LOCK button of the key is pressed | On | |
| RKE-UNLOCK | UNLOCK button of the key is not pressed | Off | N |
| | UNLOCK button of the key is pressed | On | |
| RKE-TR/BD | NOTE: The item is indicated, but not monitored. | Off | N |
| RKE-PANIC | PANIC button of the key is not pressed | Off | O |
| | PANIC button of the key is pressed | On | |
| RKE-P/W OPEN | UNLOCK button of the key is not pressed | Off | P |
| | UNLOCK button of the key is pressed and held | On | |
| RKE-MODE CHG | LOCK/UNLOCK button of the key is not pressed and held simultaneously | Off | P |
| | LOCK/UNLOCK button of the key is pressed and held simultaneously | On | |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V | |
| | Dark outside of the vehicle | Close to 0 V | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Monitor Item | Condition | Value/Status |
|---|--|--------------|
| REQ SW -DR | Driver door request switch is not pressed | Off |
| | Driver door request switch is pressed | On |
| REQ SW -AS | Passenger door request switch is not pressed | Off |
| | Passenger door request switch is pressed | On |
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off |
| REQ SW -RL | NOTE: The item is indicated, but not monitored. | Off |
| REQ SW -BD/TR | Back door request switch is not pressed | Off |
| | Back door request switch is pressed | On |
| PUSH SW | Push-button ignition switch (push switch) is not pressed | Off |
| | Push-button ignition switch (push switch) is pressed | On |
| IGN RLY2 -F/B | Ignition switch in OFF or ACC position | Off |
| | Ignition switch in ON position | On |
| ACC RLY -F/B | NOTE: The item is indicated, but not monitored. | Off |
| CLUCH SW | NOTE: The item is indicated, but not monitored. | Off |
| BRAKE SW 1 | The brake pedal is depressed when No. 7 fuse is blown | Off |
| | The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal | On |
| BRAKE SW 2 | The brake pedal is not depressed | Off |
| | The brake pedal is depressed | On |
| DETE/CANCL SW | Selector lever in P position | Off |
| | Selector lever in any position other than P | On |
| SFT PN/N SW | Selector lever in any position other than P and N | Off |
| | Selector lever in P or N position | On |
| S/L -LOCK NOTE: For models without steering lock unit, this item is not monitored. | Steering is unlocked | Off |
| | Steering is locked | On |
| S/L -UNLOCK NOTE: For models without steering lock unit, this item is not monitored. | Steering is locked | Off |
| | Steering is unlocked | On |
| S/L RELAY-F/B NOTE: For models without steering lock unit, this item is not monitored. | Ignition switch in OFF or ACC position | Off |
| | Ignition switch in ON position | On |
| UNLK SEN -DR | Driver door is unlocked | Off |
| | Driver door is locked | On |
| PUSH SW -IPDM | Push-button ignition switch (push-switch) is not pressed | Off |
| | Push-button ignition switch (push-switch) is pressed | On |
| IGN RLY1 -F/B | Ignition switch in OFF or ACC position | Off |
| | Ignition switch in ON position | On |
| DETE SW -IPDM | Selector lever in any position other than P | Off |
| | Selector lever in P position | On |
| SFT PN -IPDM | Selector lever in any position other than P and N | Off |
| | Selector lever in P or N position | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Monitor Item | Condition | Value/Status | |
|---|---|-----------------------------------|-----|
| SFT P -MET | Selector lever in any position other than P | Off | A |
| | Selector lever in P position | On | |
| SFT N -MET | Selector lever in any position other than N | Off | B |
| | Selector lever in N position | On | |
| ENGINE STATE | Engine stopped | Stop | C |
| | While the engine stalls | Stall | |
| | At engine cranking | Crank | |
| | Engine running | Run | D |
| S/L LOCK-IPDM NOTE: For models without steering lock unit, this item is not monitored. | Steering is unlocked | Off | E |
| | Steering is locked | On | |
| S/L UNLK-IPDM NOTE: For models without steering lock unit, this item is not monitored. | Steering is locked | Off | F |
| | Steering is unlocked | On | |
| S/L RELAY-REQ NOTE: For models without steering lock unit, this item is not monitored. | Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK. | Off | G |
| | Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK. | On | |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading | H |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading | I |
| DOOR STAT-DR | Driver door is locked | LOCK | J |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| | Driver door is unlocked | UNLOCK | |
| DOOR STAT-AS | Passenger door is locked | LOCK | K |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| | Passenger door is unlocked | UNLOCK | |
| ID OK FLAG | Steering is locked | Reset | MIR |
| | Steering is unlocked | Set | |
| PRMT ENG STRT | The engine start is prohibited | Reset | M |
| | The engine start is permitted | Set | |
| PRMT RKE STRT | NOTE: The item is indicated, but not monitored. | Reset | |
| KEY SW -SLOT | The key is not inserted into key slot | Off | N |
| | The key is inserted into key slot | On | |
| RKE OPE COUN1 | During the operation of the key | Operation frequency of the key | O |
| RKE OPE COUN2 | NOTE: The item is indicated, but not monitored. | — | |
| CONFIRM ID ALL | The key ID that the key slot receives does not accord with any key ID registered to BCM. | Yet | P |
| | The key ID that the key slot receives accords with any key ID registered to BCM. | Done | |
| CONFIRM ID4 | The key ID that the key slot receives does not accord with the fourth key ID registered to BCM. | Yet | |
| | The key ID that the key slot receives accords with the fourth key ID registered to BCM. | Done | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


| Monitor Item | Condition | Value/Status |
|--------------|---|-------------------------------|
| CONFIRM ID3 | The key ID that the key slot receives does not accord with the third key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with the third key ID registered to BCM. | Done |
| CONFIRM ID2 | The key ID that the key slot receives does not accord with the second key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with the second key ID registered to BCM. | Done |
| CONFIRM ID1 | The key ID that the key slot receives does not accord with the first key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with the first key ID registered to BCM. | Done |
| TP 4 | The ID of fourth key is not registered to BCM | Yet |
| | The ID of fourth key is registered to BCM | Done |
| TP 3 | The ID of third key is not registered to BCM | Yet |
| | The ID of third key is registered to BCM | Done |
| TP 2 | The ID of second key is not registered to BCM | Yet |
| | The ID of second key is registered to BCM | Done |
| TP 1 | The ID of first key is not registered to BCM | Yet |
| | The ID of first key is registered to BCM | Done |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front LH tire |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front RH tire |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear RH tire |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear LH tire |
| ID REGST FL1 | ID of front LH tire transmitter is registered | Done |
| | ID of front LH tire transmitter is not registered | Yet |
| ID REGST FR1 | ID of front RH tire transmitter is registered | Done |
| | ID of front RH tire transmitter is not registered | Yet |
| ID REGST RR1 | ID of rear RH tire transmitter is registered | Done |
| | ID of rear RH tire transmitter is not registered | Yet |
| ID REGST RL1 | ID of rear LH tire transmitter is registered | Done |
| | ID of rear LH tire transmitter is not registered | Yet |
| WARNING LAMP | Tire pressure indicator OFF | Off |
| | Tire pressure indicator ON | On |
| BUZZER | Tire pressure warning alarm is not sounding | Off |
| | Tire pressure warning alarm is sounding | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

TERMINAL LAYOUT



A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR


PHYSICAL VALUES

JPMIA0062ZZ

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 1 (W) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (W) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | | Battery voltage |
| 3 (Y) | Ground | P/W power supply (RAP) | Output | Ignition switch ON | | Battery voltage |
| 4 (LG) | Ground | Interior room lamp power supply | Output | Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply) | | 0 V |
| | | | | Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply) | | Battery voltage |
| 5 (L) | Ground | Passenger door UN- LOCK | Output | Passenger door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 7 (Y) | Ground | Step lamp | Output | Step lamp | ON | 0 V |
| | | | | | OFF | Battery voltage |
| 8 (V) | Ground | All doors, fuel lid LOCK | Output | All doors | LOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than LOCK (Actuator is not activated) | 0 V |
| 9 (G) | Ground | Driver door, fuel lid UNLOCK | Output | Driver door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 10 (BR) | Ground | Rear RH door and rear LH door UN- LOCK | Output | Rear RH door and rear LH door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 11 (R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0 V |
| 14 (W) | Ground | Push-button ignition switch illumination ground | Output | Tail lamp | OFF | 0 V |
| | | | | | ON | <p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p> |
| 15 (Y) | Ground | ACC indicator lamp | Output | Ignition switch | OFF or ON | Battery voltage |
| | | | | | ACC | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------|------------------|-----------------------|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 17 (W) | Ground | Turn signal RH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch RH |  <p style="text-align: right; font-size: small;">PKID0926E</p> |
| 18 (BG) | Ground | Turn signal LH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  <p style="text-align: right; font-size: small;">PKID0926E</p> |
| 19 (V) | Ground | Room lamp timer control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 20 (V) | Ground | Turn signal RH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch RH |  <p style="text-align: right; font-size: small;">PKID0926E</p> |
| 23 (G) | Ground | Back door open | Output | Back door | OPEN (Back door opener actuator is activated) | Battery voltage |
| | | | | | Other than OPEN (Back door opener actuator is not activated) | 0 V |
| 25 (G) | Ground | Turn signal LH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  <p style="text-align: right; font-size: small;">PKID0926E</p> |
| 26 (G) | Ground | Rear wiper | Output | Rear wiper | OFF (Stopped) | 0 V |
| | | | | | ON (Operated) | Battery voltage |







A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 34 (SB) | Ground | Luggage room antenna (-) | Output | Ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compartment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 35 (V) | Ground | Luggage room antenna (+) | Output | Ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compartment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 38 (B) | Ground | Back door antenna (-) | Output | When the back door opener request switch is operated with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|---|---|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 39 (W) | Ground | Back door antenna (+) | Output | When the back door opener request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> | |
| 47 (Y) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 V |
| 52 (SB) | Ground | Starter relay control | Output | Ignition switch ON | When selector lever is in P or N position | Battery voltage |
| | | | | | When selector lever is not in P or N position | 0 V |
| 60*1 (BR) | Ground | Push-button ignition switch (Push switch) | Input | Push-button ignition switch (push switch) | Pressed | 0 V |
| | | | | | Not pressed | Battery voltage |
| 61 (W) | Ground | Back door opener request switch | Input | Back door opener request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB</p> |
| | | | | | | 1.0 V |
| 64 (V) | Ground | Intelligent Key warning buzzer (Engine room) | Output | Intelligent Key warning buzzer (Engine room) | Sounding | 0 V |
| | | | | | Not sounding | Battery voltage |
| 65 (BG) | Ground | Rear wiper stop position | Input | Rear wiper | In stop position |  <p style="text-align: right; font-size: small;">JPMIA0016GB</p> |
| | | | | | | |
| | | | | | | 0 V |





A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------|------------------|-------------------------|--------------------|---|
| + | - | Signal name | Input/ Output | | | |
| 66 (R) | Ground | Back door switch | Input | Back door switch | OFF (Door close) |  <small>JPMIA0011GB</small> 11.8 V |
| | | | | | ON (Door open) | 0 V |
| 67 (GR) | Ground | Back door opener switch | Input | Back door opener switch | Pressed | 0 V |
| | | | | | Not pressed |  <small>JPMIA0011GB</small> 11.8 V |
| 68 (BR) | Ground | Rear RH door switch | Input | Rear RH door switch | OFF (Door close) |  <small>JPMIA0011GB</small> 11.8 V |
| | | | | | ON (Door open) | 0 V |
| 69 (R) | Ground | Rear LH door switch | Input | Rear LH door switch | OFF (Door close) |  <small>JPMIA0011GB</small> 11.8 V |
| | | | | | ON (Door open) | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| | | Signal name | Input/ Output | | |
| + | - | | | | |
| 72 (R) | Ground | Room antenna 2 (-) (Center console) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 73 (G) | Ground | Room antenna 2 (+) (Center console) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 74 (SB) | Ground | Passenger door an- tenna (-) | Output | When the pas- senger door re- quest switch is operated with ig- nition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detec- tion area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |







A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 75 (GR) | Ground | Passenger door antenna (+) | Output | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the passenger door request switch is operated with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 76 (V) | Ground | Driver door antenna (-) | Output | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the driver door request switch is operated with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 77 (LG) | Ground | Driver door antenna (+) | Output | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the driver door request switch is operated with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|--|---|---|
| + | - | Signal name | Input/ Output | | | |
| 78 (Y) | Ground | Room antenna 1 (-) (Instrument panel) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> | |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> | |
| 79 (BR) | Ground | Room antenna 1 (+) (Instrument panel) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> | |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> | |
| 80 (GR) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 81 (W) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 82 (R) | Ground | Ignition relay [Fuse block (J/B)] control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | ON | Battery voltage | |















A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | | | | | | | |
|--|--|---|------------------|---|---|---|---|---|--|---|--|--|--|
| + | - | Signal name | Input/ Output | | | | | | | | | | |
| 83 (Y) | Ground | Remote keyless entry receiver communication | Input/ Output | During waiting |  <small>JMKIA0064GB</small> | | | | | | | | |
| | | | | When operating either button on the key |  <small>JMKIA0065GB</small> | | | | | | | | |
| 87 (BR) | Ground | Combination switch INPUT 5 | Input | Combination switch | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">All switches OFF (Wiper intermittent dial 4)</td> <td style="text-align: center;">  <small>JPMIA0041GB</small> 1.4 V </td> </tr> <tr> <td style="text-align: center;">Front fog lamp switch ON (Wiper intermittent dial 4)</td> <td style="text-align: center;">  <small>JPMIA0037GB</small> 1.3 V </td> </tr> <tr> <td style="text-align: center;">Rear wiper switch ON (Wiper intermittent dial 4)</td> <td style="text-align: center;">  <small>JPMIA0039GB</small> 1.3 V </td> </tr> <tr> <td style="text-align: center;">Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 </td> <td style="text-align: center;">  <small>JPMIA0040GB</small> 1.3 V </td> </tr> </table> | All switches OFF (Wiper intermittent dial 4) |  <small>JPMIA0041GB</small> 1.4 V | Front fog lamp switch ON (Wiper intermittent dial 4) |  <small>JPMIA0037GB</small> 1.3 V | Rear wiper switch ON (Wiper intermittent dial 4) |  <small>JPMIA0039GB</small> 1.3 V | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 |  <small>JPMIA0040GB</small> 1.3 V |
| | | | | All switches OFF (Wiper intermittent dial 4) |  <small>JPMIA0041GB</small> 1.4 V | | | | | | | | |
| | | | | Front fog lamp switch ON (Wiper intermittent dial 4) |  <small>JPMIA0037GB</small> 1.3 V | | | | | | | | |
| | | | | Rear wiper switch ON (Wiper intermittent dial 4) |  <small>JPMIA0039GB</small> 1.3 V | | | | | | | | |
| Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 |  <small>JPMIA0040GB</small> 1.3 V | | | | | | | | | | | | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 88 (V) | Ground | Combination switch INPUT 3 | Input | | |
| | | | | | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Lighting switch HI (Wiper intermittent dial 4) </div>  <p style="text-align: right; margin-right: 50px;">1.3 V</p> |
| | | | | | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Lighting switch 2ND (Wiper intermittent dial 4) </div>  <p style="text-align: right; margin-right: 50px;">1.3 V</p> |
| | | | | | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Rear washer switch ON (Wiper intermittent dial 4) </div>  <p style="text-align: right; margin-right: 50px;">1.3 V</p> |
| | | | | | <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> Any of the conditions below with all switches OFF <ul style="list-style-type: none"> Wiper intermittent dial 1 Wiper intermittent dial 2 Wiper intermittent dial 3 </div>  <p style="text-align: right; margin-right: 50px;">1.3 V</p> |
| 89*2 (BR) | Ground | Push-button ignition switch (Push switch) | Input | Push-button igni- tion switch (push switch) | Pressed Not pressed |
| | | | | | 0 V |
| | | | | | Battery voltage |
| 90 (P) | Ground | CAN-L | Input/ Output | — | — |
| 91 (L) | Ground | CAN-H | Input/ Output | — | — |




A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|-------------------------------|---------------------------|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 92 (LG) | Ground | Key slot illumination | Output | Key slot illumination | OFF | Battery voltage |
| | | | | | Blinking |  <p style="text-align: center;">6.5 V</p> |
| 93 (V) | Ground | ON indicator lamp | Output | Ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 V |
| 94 (Y) | Ground | Puddle lamp control | Output | Puddle lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 95 (BG) | Ground | ACC relay control | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | Battery voltage |
| 96 (GR) | Ground | A/T shift selector (Detention switch) power supply | Output | — | Battery voltage | |
| 97*2 (L) | Ground | Steering lock condition No. 1 | Input | Steering lock | LOCK status | 0 V |
| | | | | | UNLOCK status | Battery voltage |
| 98*2 (P) | Ground | Steering lock condition No. 2 | Input | Steering lock | LOCK status | Battery voltage |
| | | | | | UNLOCK status | 0 V |
| 99 (R) | Ground | Selector lever P position switch | Input | Selector lever | P position | 0 V |
| | | | | | Any position other than P | Battery voltage |
| 100 (G) | Ground | Passenger door request switch | Input | Passenger door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: center;">1.0 V</p> |
| 101 (SB) | Ground | Driver door request switch | Input | Driver door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: center;">1.0 V</p> |
| 102 (BG) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | | |
|------------------------------|---|--|---|---|--------------------|-----------------------|---|-------|
| | | Signal name | Input/ Output | | | | | |
| + | - | | | | | | | |
| 103 (LG) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | Battery voltage | | | |
| 106*2 (W) | Ground | Steering lock unit power supply | Output | Ignition switch | OFF or ACC | Battery voltage | | |
| | | | | | ON | 0 V | | |
| | | | | Combination switch (Wiper intermittent dial 4) | Input | All switches OFF |  | 1.4 V |
| | | | | | | Turn signal switch LH |  | 1.3 V |
| | | | | | | Turn signal switch RH |  | 1.3 V |
| Front wiper switch LO |  | 1.3 V | | | | | | |
| | | Front washer switch ON |  | 1.3 V | | | | |






A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 108 (R) | Ground | Combination switch INPUT 4 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  <small>JPMIA0041GB</small> 1.4 V |
| | | | | | Lighting switch AUTO (Wiper intermittent dial 4) |  <small>JPMIA0038GB</small> 1.3 V |
| | | | | | Lighting switch 1ST (Wiper intermittent dial 4) |  <small>JPMIA0036GB</small> 1.3 V |
| | | | | | Rear wiper switch INT (Wiper intermittent dial 4) |  <small>JPMIA0040GB</small> 1.3 V |
| | | | | | Any of the conditions below with all switches OFF |  <small>JPMIA0039GB</small> 1.3 V |
| | | | | | <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|--|--|--|
| + | - | Signal name | Input/ Output | | | |
| 109 (Y) | Ground | Combination switch INPUT 2 | Input | Combination switch (Wiper intermittent dial 4) | All switches OFF |  1.4 V |
| | | | | | Lighting switch PASS |  1.3 V |
| | | | | | Lighting switch 2ND |  1.3 V |
| | | | | | Front wiper switch INT |  1.3 V |
| | | | | | Front wiper switch HI |  1.3 V |
| | | | | | ON | 0 V |
| 110 (G) | Ground | Hazard switch | Input | Hazard switch | OFF | |
| | | | | OFF |  1.1 V | |



A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|---|
| + | - | Signal name | Input/ Output | | | |
| 111*2 (Y) | Ground | Steering lock unit communication | Input/ Output | Steering lock | LOCK status | Battery voltage |
| | | | | | LOCK or UNLOCK |  <p style="text-align: right; font-size: small;">JMKIA0066GB</p> |
| | | | | | For 15 seconds after UN- LOCK | Battery voltage |
| | | | | | 15 seconds or later after UNLOCK | 0 V |
| 113 (P) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle | Close to 5 V |
| | | | | | When dark outside of the vehicle | Close to 0 V |
| 116 (SB) | Ground | Stop lamp switch 1 | Input | — | Battery voltage | |
| 118 (P) | Ground | Stop lamp switch 2 (Without ICC) | Input | Stop lamp switch | OFF (Brake pedal is not depressed) | 0 V |
| | | | | | ON (Brake pedal is de- pressed) | Battery voltage |
| | | Stop lamp switch 2 (With ICC) | | Stop lamp switch OFF (Brake pedal is not de- pressed) and ICC brake hold relay OFF | | 0 V |
| | | | | Stop lamp switch ON (Brake pedal is de- pressed) or ICC brake hold relay ON | | Battery voltage |
| 119 (SB) | Ground | Front door lock as- sembly driver side (Unlock sensor) | Input | Driver door | LOCK status (Unlock sensor switch OFF) |  <p style="text-align: right; font-size: small;">JPMIA0012GB</p> |
| | | | | | UNLOCK status (Unlock switch sensor ON) | 1.1 V |
| | | | | | UNLOCK status (Unlock switch sensor ON) | 0 V |
| 121 (BR) | Ground | Key slot switch | Input | When the key is inserted into key slot | Battery voltage | |
| | | | | When the key is not inserted into key slot | 0 V | |
| 123 (W) | Ground | IGN feedback | Input | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|--|---|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 124 (LG) | Ground | Passenger door switch | Input | Passenger door switch | OFF (Door close) |  <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p> |
| | | | | | ON (Door open) | 0 V |
| 132 (BR) | Ground | Power window switch communication | Input/ Output | Ignition switch ON |  <p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p> | |
| | | | | Ignition switch OFF or ACC | Battery voltage | |
| 133 (W) | Ground | Push-button ignition switch illumination | Output | Push-button igni- tion switch illumina- tion | ON (Tail lamps OFF) | 9.5 V |
| | | | | | ON (Tail lamps ON) | <p style="text-align: center;">NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMIA0159GB</p> |
| 134 (GR) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 137 (BG) | Ground | Receiver and sensor ground | Input | Ignition switch ON | 0 V | |
| 138 (Y) | Ground | Receiver and sensor power supply | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 5.0 V |






A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--------------------------------------|------------------|---|---|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 139 (L) | Ground | Tire pressure receiver communication | Input/ Output | Ignition switch ON | Standby state |  <small>OCC3881D</small> |
| | | | | When receiving the signal from the transmitter |  <small>OCC3880D</small> | |
| 140 (GR) | Ground | Selector lever P/N position | Input | Selector lever | P or N position | Battery voltage |
| | | | | Except P and N positions | 0 V | |
| 141 (G) | Ground | Security indicator | Output | Security indicator | ON | 0 V |
| | | | | Blinking |  <small>JPMIA0014GB</small> | 11.3 V |
| | | | | OFF | Battery voltage | |
| 142 (BG) | Ground | Combination switch OUTPUT 5 | Output | Combination switch (Wiper intermittent dial 4) | All switches OFF | 0 V |
| | | | | Lighting switch 1ST |  <small>JPMIA0031GB</small> | 10.7 V |
| | | | | Lighting switch HI | | |
| | | | | Lighting switch 2ND | | |
| Turn signal switch RH | 0 V | | | | | |
| 143 (P) | Ground | Combination switch OUTPUT 1 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) | 0 V |
| | | | | Front wiper switch HI (Wiper intermittent dial 4) |  <small>JPMIA0032GB</small> | 10.7 V |
| | | | | Rear wiper switch INT (Wiper intermittent dial 4) | | |
| | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 | | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|---|--|-----------------|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 144 (G) | Ground | Combination switch OUTPUT 2 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) | 0 V |
| | | | | | Front washer switch ON (Wiper intermittent dial 4) | |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) | |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) | |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | |
| 145 (L) | Ground | Combination switch OUTPUT 3 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V |
| | | | | | Front wiper switch INT | |
| | | | | | Front wiper switch LO | |
| | | | | | Lighting switch AUTO | |
| 146 (SB) | Ground | Combination switch OUTPUT 4 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V |
| | | | | | Front fog lamp switch ON | |
| | | | | | Lighting switch 2ND | |
| | | | | | Lighting switch PASS | |
| | | | | | Turn signal switch LH | |
| 150 (LG) | Ground | Driver door switch | Input | Driver door switch | OFF (Door close) | |
| | | | | | ON (Door open) | 0 V |
| 151 (G) | Ground | Rear window defog- ger relay control | Output | Rear window de- fogger | Active | 0 V |
| | | | | | Not activated | Battery voltage |

NOTE:

- *1: Without steering lock unit
- *2: With steering lock unit


A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCMWA6167GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

- ◊ RF : With sunroof
- ◊ FM : With automatic drive positioner
- ◊ OP : Without automatic drive positioner




JCMWA6168GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JCMWA6170GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)

| | |
|----------------|--------------------|
| Connector No. | M133 |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TH16FN-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | FR WASHER(-) |
| 2 | SB | OUTPUT 4 |
| 3 | GR | FR WASHER(+) |
| 4 | G | IGN |
| 5 | L | OUTPUT 3 |
| 6 | B | GND |
| 7 | V | INPUT 3 |
| 8 | BG | OUTPUT 5 |
| 9 | Y | INPUT 2 |
| 10 | R | INPUT 4 |
| 11 | LG | INPUT 1 |
| 12 | P | OUTPUT 1 |
| 13 | BR | INPUT 5 |
| 14 | G | OUTPUT 2 |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M09FB-LC |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 1 | W | BAT (F/L) |
| 2 | W | POWER WINDOW POWER SUPPLY(BAT) |
| 3 | Y | POWER WINDOW POWER SUPPLY(RAP) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS12FF-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 4 | LG | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | L | PASSENGER DOOR UNLOCK OUTPUT |
| 6 | Y | STEP LAMP OUTPUT |
| 7 | G | ALL DOOR FUEL LID LOCK OUTPUT |
| 8 | V | DRIVER DOOR FUEL LID UNLOCK OUTPUT |
| 9 | G | REAR DOOR UNLOCK OUTPUT |
| 10 | BR | BAT (FUSE) |
| 11 | R | GND |
| 12 | B | PUSH-BUTTON IGNITION SW ILL GND |
| 13 | W | ACC IND |
| 14 | W | TURN SIGNAL RH (FRONT) |
| 15 | Y | TURN SIGNAL LH (FRONT) |
| 16 | W | ROOM LAMP TIMER CONTROL |
| 17 | W | ACC IND |
| 18 | BG | TURN SIGNAL LH (FRONT) |
| 19 | V | ROOM LAMP TIMER CONTROL |

| | |
|----------------|---------------------------|
| Connector No. | M120 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS12FW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | V | TURN SIGNAL RH (REAR) |
| 21 | G | BACK DOOR OPEN OUTPUT |
| 22 | G | TURN SIGNAL LH (REAR) |
| 23 | G | REAR WIPER OUTPUT |
| 24 | G | REAR WIPER OUTPUT |
| 25 | G | REAR WIPER OUTPUT |
| 26 | G | REAR WIPER OUTPUT |

| | |
|----------------|---------------------------|
| Connector No. | M121 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FGY-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------------|
| 34 | SB | LUGGAGE ROOM ANT- |
| 35 | V | LUGGAGE ROOM ANT+ |
| 36 | B | BACK DOOR ANT- |
| 37 | W | BACK DOOR ANT+ |
| 38 | B | IGN RELAY (BDM E/R) CONT |
| 39 | W | STARTER RELAY CONT |
| 40 | SB | PUSH SW (Without steering lock unit) |
| 41 | BR | BACK DOOR OPENER REQUEST SW |
| 42 | W | I-KEY WARN BUZZER (ENG ROOM) |
| 43 | V | REAR WIPER STOP POSITION |
| 44 | BG | BACK DOOR SW |
| 45 | R | BACK DOOR OPENER SW |
| 46 | GR | REAR RH DOOR SW |
| 47 | BR | REAR LH DOOR SW |

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 72 | R | ROOM ANT- |
| 73 | G | ROOM ANT2- |
| 74 | SB | PASSENGER DOOR ANT- |
| 75 | GR | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | LG | DRIVER DOOR ANT+ |
| 78 | Y | ROOM ANT1- |
| 79 | BR | ROOM ANT1+ |

| | | |
|-----|----|-------------------------------------|
| 80 | GR | MATS ANT AMP |
| 81 | W | MATS ANT AMP |
| 82 | R | IGN RELAY (E/B) CONT |
| 83 | Y | KEYLESS ENTRY RECEIVER COMMI |
| 87 | BR | COMBI SW INPUT 5 |
| 88 | V | COMBI SW INPUT 3 |
| 89 | BR | PUSH SW (With steering lock unit) |
| 90 | P | GAN-L |
| 91 | L | GAN-H |
| 92 | LG | KEY SLOT ILL |
| 93 | V | ON IND |
| 94 | Y | PUDDLE LAMP CONT |
| 95 | BG | ACC RELAY CONT |
| 96 | GR | A/T SHIFT SELECTOR POWER SUPPLY |
| 97 | L | S/L CONDITION 1 |
| 98 | P | S/L CONDITION 2 |
| 99 | R | SHIFT P |
| 100 | G | PASSENGER DOOR REQUEST SW |
| 101 | SB | DRIVER DOOR REQUEST SW |
| 102 | BG | BLOWER FAN MOTOR RELAY CONT |
| 103 | LG | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 106 | W | S/L UNIT POWER SUPPLY |
| 107 | LG | COMBI SW INPUT 1 |
| 108 | R | COMBI SW INPUT 4 |
| 109 | Y | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |
| 111 | Y | S/L UNIT COMM |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------------|
| 113 | P | OPTICAL SENSOR |
| 116 | SB | STOP LAMP SW 1 |
| 118 | P | STOP LAMP SW 2 |
| 119 | SB | DR DOOR UNLOCK SENSOR |
| 121 | BR | KEY SLOT SW |
| 122 | W | IGN F/B |
| 124 | LG | PASSENGER DOOR SW |
| 132 | BR | POWER WINDOW SW COMM |
| 133 | W | PUSH-BUTTON IGNITION SW ILL POWER |
| 134 | GR | LOCK IND |
| 137 | BG | RECEIVER/SENSOR GND |
| 138 | Y | RECEIVER/SENSOR POWER SUPPLY |
| 139 | L | TIRE PRESSURE RECEIVER COMM |
| 140 | GR | SHIFT N/P |
| 141 | G | SECURITY INDICATOR OUTPUT |
| 142 | BG | COMBI SW OUTPUT 5 |
| 143 | P | COMBI SW OUTPUT 1 |
| 144 | G | COMBI SW OUTPUT 2 |
| 145 | L | COMBI SW OUTPUT 3 |
| 146 | SB | COMBI SW OUTPUT 4 |
| 150 | LG | DRIVER DOOR SW |
| 151 | G | REAR WINDOW DEFOGGER RELAY CONT |

BCM (BODY CONTROL MODULE)

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FG-1N1 |



JCMWA6172GB

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

INFOID:000000006935360

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Display contents of CONSULT | Fail-safe | Cancellation | |
|-----------------------------|-------------------------|--|---|
| B2013: ID DISCORD BCM-S/L | Inhibit engine cranking | Erase DTC | A |
| B2014: CHAIN OF S/L-BCM | Inhibit engine cranking | Erase DTC | B |
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC | B |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC | |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC | C |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC | |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF | |
| B2557: VEHICLE SPEED | Inhibit steering lock | When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms | D |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal | E |
| B2601: SHIFT POSITION | Inhibit steering lock | 500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN) | F |
| B2602: SHIFT POSITION | Inhibit steering lock | 5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more | G |
| B2603: SHIFT POSI STATUS | Inhibit steering lock | 500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V) | H |
| B2604: PNP SW | Inhibit steering lock | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF | I |
| B2605: PNP SW | Inhibit steering lock | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position <ul style="list-style-type: none"> - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON | J |
| B2606: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal) | K |

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|---|
| B2607: S/L RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal) |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B2609: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B2612: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R) |
| B2617: STARTER RELAY CIRC | Inhibit engine cranking | 1 second after the starter motor relay control inside BCM becomes normal |
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B2619: BCM | Inhibit engine cranking | 1 second after the steering lock unit power supply output control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |
| B26E9: S/L STATUS | <ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock | When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage) |

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000006935361

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|--|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| Priority | DTC | | |
|----------|---|--|-----|
| 3 | <ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING | A | |
| | | B | |
| | 4 | <ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG | C |
| | | | D |
| | | | E |
| | | F | |
| | | G | |
| | | H | |
| | | I | |
| | | J | |
| | | K | |
| 5 | | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT | MIR |
| | | M | |
| | | N | |
| | | O | |
| | 6 | <ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA | P |

DTC Index

INFOID:000000006935362

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|--|-----------|--|---------------------------------|---------------------------------------|------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | — | — | BCS-38 |
| U1010: CONTROL UNIT (CAN) | — | — | — | — | BCS-39 |
| U0415: VEHICLE SPEED SIG | — | — | — | — | BCS-40 |
| B2013: ID DISCORD BCM-S/L* | × | × | — | — | SEC-49 |
| B2014: CHAIN OF S/L-BCM* | × | × | — | — | SEC-50 |
| B2190: NATS ANTENNA AMP | × | — | — | — | SEC-42 |
| B2191: DIFFERENCE OF KEY | × | — | — | — | SEC-45 |
| B2192: ID DISCORD BCM-ECM | × | — | — | — | SEC-46 |
| B2193: CHAIN OF BCM-ECM | × | — | — | — | SEC-47 |
| B2195: ANTI SCANNING | × | — | — | — | SEC-48 |
| B2553: IGNITION RELAY | — | × | — | — | PCS-50 |
| B2555: STOP LAMP | — | × | — | — | SEC-53 |
| B2556: PUSH-BTN IGN SW | — | × | × | — | SEC-55 |
| B2557: VEHICLE SPEED | × | × | × | — | SEC-57 |
| B2560: STARTER CONT RELAY | × | × | × | — | SEC-58 |
| B2562: LOW VOLTAGE | — | × | — | — | BCS-41 |
| B2601: SHIFT POSITION | × | × | × | — | SEC-59 |
| B2602: SHIFT POSITION | × | × | × | — | SEC-62 |
| B2603: SHIFT POSI STATUS | × | × | × | — | SEC-64 |
| B2604: PNP SW | × | × | × | — | SEC-67 |
| B2605: PNP SW | × | × | × | — | SEC-69 |
| B2606: S/L RELAY* | × | × | × | — | SEC-71 |
| B2607: S/L RELAY* | × | × | × | — | SEC-72 |
| B2608: STARTER RELAY | × | × | × | — | SEC-74 |
| B2609: S/L STATUS* | × | × | × | — | SEC-76 |
| B260A: IGNITION RELAY | × | × | × | — | PCS-52 |
| B260B: STEERING LOCK UNIT* | — | × | × | — | SEC-80 |
| B260C: STEERING LOCK UNIT* | — | × | × | — | SEC-81 |
| B260D: STEERING LOCK UNIT* | — | × | × | — | SEC-82 |
| B260F: ENG STATE SIG LOST | × | × | × | — | SEC-83 |
| B2612: S/L STATUS* | × | × | × | — | SEC-87 |
| B2614: ACC RELAY CIRC | — | × | × | — | PCS-54 |
| B2615: BLOWER RELAY CIRC | — | × | × | — | PCS-57 |
| B2616: IGN RELAY CIRC | — | × | × | — | PCS-60 |
| B2617: STARTER RELAY CIRC | × | × | × | — | SEC-91 |
| B2618: BCM | × | × | × | — | PCS-63 |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference page |
|---------------------------|-----------|--|---------------------------------|---------------------------------------|------------------------|
| B2619: BCM* | × | × | × | — | SEC-93 |
| B261A: PUSH-BTN IGN SW | — | × | × | — | SEC-94 |
| B261E: VEHICLE TYPE | × | × | × (Turn ON for 15 seconds) | — | SEC-97 |
| B2621: INSIDE ANTENNA | — | × | — | — | DLK-59 |
| B2622: INSIDE ANTENNA | — | × | — | — | DLK-61 |
| B2623: INSIDE ANTENNA | — | × | — | — | DLK-63 |
| B26E1: ENG STATE NO RES | × | × | × | — | SEC-84 |
| B26E9: S/L STATUS* | × | × | × (Turn ON for 15 seconds) | — | SEC-85 |
| B26EA: KEY REGISTRATION | — | × | × (Turn ON for 15 seconds) | — | SEC-86 |
| C1704: LOW PRESSURE FL | — | — | — | × | WT-23 |
| C1705: LOW PRESSURE FR | — | — | — | × | |
| C1706: LOW PRESSURE RR | — | — | — | × | |
| C1707: LOW PRESSURE RL | — | — | — | × | |
| C1708: [NO DATA] FL | — | — | — | × | WT-25 |
| C1709: [NO DATA] FR | — | — | — | × | |
| C1710: [NO DATA] RR | — | — | — | × | |
| C1711: [NO DATA] RL | — | — | — | × | |
| C1716: [PRESSDATA ERR] FL | — | — | — | × | WT-28 |
| C1717: [PRESSDATA ERR] FR | — | — | — | × | |
| C1718: [PRESSDATA ERR] RR | — | — | — | × | |
| C1719: [PRESSDATA ERR] RL | — | — | — | × | |
| C1729: VHCL SPEED SIG ERR | — | — | — | × | WT-30 |
| C1734: CONTROL UNIT | — | — | — | × | WT-32 |

*: For models without steering lock unit, this DTC is not applied.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

DOOR MIRROR DOES NOT OPERATE

[WITH ADP]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000006346094

1. CHECK AUTOMATIC DRIVE POSITIONER SYSTEM

Check door mirror operate with automatic drive positioner system.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check automatic drive positioner system operation. Refer to [ADP-12. "AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram"](#)

2. CHECK DOOR MIRROR REMOTE CONTROL SWITCH (MIRROR SWITCH)

Check mirror switch.

Refer to [MIR-12. "MIRROR SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK DOOR MIRROR REMOTE CONTROL SWITCH (CHANGEOVER SWITCH)

Check changeover switch.

Refer to [MIR-14. "CHANGEOVER SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#)

NO >> GO TO 1.

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH ADP]

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000006346095

1. CHECK DOOR MIRROR (MANUAL FUNCTION)

Check door mirror function with door mirror remote control switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DTC

Check DTC for TCM.

Refer to [TM-156, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:00000006346096



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-110, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [MIR-108, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000006346097

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

Diagnostic Worksheet

INFOID:00000006346098







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about ____ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

| | YES | NO | Initials of person performing |
|--|--------------------------|--------------------------|-------------------------------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006346099

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >


[WITH ADP]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000006346100

| Tool name | Description |
|--|---|
| Remover tool  PIIB7923J | Remove the clip and pawl and metal clip |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

INSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITH ADP]


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View


INFOID:000000006346101

Base



1. Inside mirror
 2. Mirror base
- Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
 2. Mirror base
 3. Inside mirror cover
 4. Harness connector
 5. TORX bolt
- Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000006346102

REMOVAL

Base model

INSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITH ADP]

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

OUTSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITH ADP]

OUTSIDE MIRROR

Exploded View

INFOID:00000006346103



- | | | |
|--|---|------------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Door mirror corner cover | 9. BSW indicator |

- : Clip
△ : Pawl

DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:00000006880859

REMOVAL

1. Remove front door finisher.
 - Driver side: Refer to [INT-12, "DRIVER SIDE : Removal and Installation"](#).
 - Passenger side: Refer to [INT-15, "PASSENGER SIDE : Removal and Installation"](#).
2. Disconnect BSW indicator harness connector. (if equipped)
3. Remove door corner cover fixing clips and remove door corner cover.
4. Disconnect door mirror harness connector.
5. Remove mounting nuts, and then remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-425, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

OUTSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITH ADP]

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:000000006346105

DISASSEMBLY

1. Remove door mirror cover. Refer to [MIR-117, "DOOR MIRROR COVER : Removal and Installation"](#).
2. Remove side camera after removing door mirror assembly.(BOSE audio with navigation model)
 - Side camera LH: Refer to [AV-533, "Removal and Installation"](#).
 - Side camera RH: Refer to [AV-534, "Removal and Installation"](#).
3. Remove base cover and puddle lamp.

ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Removal and Installation


INFOID:000000006346107

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.

NOTE:

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Removal and Installation

INFOID:000000006346109

CAUTION:

Do not damage the mirror bodies.

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-117, "GLASS MIRROR : Removal and Installation"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITH ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:000000006346110


Refer to [INT-12, "DRIVER SIDE : Exploded View"](#)


Removal and Installation

INFOID:000000006346111

REMOVAL

1. Remove the power window main switch finisher. Refer to [INT-12, "DRIVER SIDE : Removal and Installation"](#).
2. Remove door mirror remote control switch (1) from power window main switch finisher (2) using flat-bladed screwdriver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.

DOOR MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT ADP]

SYSTEM DESCRIPTION

DOOR MIRROR SYSTEM

Component Description

INFOID:000000006346112

| Component | Function |
|-----------------------------------|--|
| Door mirror remote control switch | It supplies power to mirror motor through mirror switch and changeover switch. |
| Door mirror | It makes mirror face operate from side to side and up and down with the mirror control switch operation. |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

INSIDE MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT ADP]

INSIDE MIRROR SYSTEM

System Description

INFOID:000000006346113

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:000000006346114

| Component | Function |
|----------------------------------|---|
| Auto anti-dazzling inside mirror | It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind. |

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -

INFOID:000000006346115

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)



2008/08/28

JCLWA2505GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR


DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|--------------|
| Connector No. | D1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-CS15 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | V | - |
| 4 | W | - |
| 5 | L | - |
| 6 | O | - |
| 7 | GR | - |
| 8 | W | - |
| 9 | O | - |
| 10 | BR | - |
| 11 | P | - |
| 12 | LG | - |
| 13 | B | - |
| 14 | Y | - |
| 15 | W | - |
| 16 | R | - |
| 17 | W | - |
| 18 | G | - |
| 19 | Y | - |
| 20 | W | - |
| 21 | O | - |
| 22 | P | - |
| 23 | ER | - |
| 24 | V | - |
| 25 | GR | - |
| 26 | Y | - |
| 27 | B | - |
| 28 | SHIELD | - |
| 29 | LG | - |
| 30 | G | - |
| 31 | W | - |
| 32 | G | - |
| 33 | L | - |
| 34 | SB | - |
| 35 | R | - |
| 36 | LG | - |
| 37 | R | - |
| 38 | P | - |


| | | |
|----|----|--|
| 39 | O | - |
| 40 | BR | - |
| 41 | L | - |
| 42 | GR | - |
| 43 | BR | - [With automatic drive positioner] |
| 43 | O | - [Without automatic drive positioner] |
| 44 | W | - [With automatic drive positioner] |
| 44 | GR | - [Without automatic drive positioner] |
| 45 | Y | - [With automatic drive positioner] |
| 45 | G | - [Without automatic drive positioner] |
| 46 | G | - [With automatic drive positioner] |
| 46 | V | - [Without automatic drive positioner] |
| 49 | GR | - |
| 50 | B | - |
| 52 | R | - |
| 53 | SB | - |
| 54 | O | - |
| 55 | Y | - |

| | |
|----------------|---------------------------|
| Connector No. | D3 |
| Connector Name | DOOR MIRROR (DRIVER SIDE) |
| Connector Type | TH2MMW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | O | - |
| 3 | B | SIDE CAMERA LH COMM |
| 3 | Y | SIDE CAMERA LH IMAGE SIGNAL |
| 6 | R | SIDE CAMERA LH POWER SUPPLY |
| 7 | W | - |
| 10 | G | - |
| 11 | P | - |
| 12 | O | - |
| 14 | LG | - |
| 17 | G | SIDE CAMERA LH IMAGE GND |
| 18 | W | SIDE CAMERA LH GND |
| 19 | B | - |
| 21 | GR | - |
| 22 | BR | - |
| 23 | Y | - |
| 24 | V | - |

| | |
|----------------|-----------------------------------|
| Connector No. | D7 |
| Connector Name | DOOR MIRROR REMOTE CONTROL SWITCH |
| Connector Type | TK6FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 7 | V | - |
| 8 | B | - |
| 9 | R | - |
| 10 | G | - |
| 12 | G | - |
| 13 | GR | - |
| 14 | P | - |
| 15 | O | - |
| 18 | O | - |

| | |
|----------------|--------------|
| Connector No. | D31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-CS15 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7 | R | - |
| 8 | BR | - |
| 9 | V | - |
| 12 | P | - |
| 13 | LG | - |
| 14 | B | - |
| 15 | W | - |
| 16 | BR | - |
| 17 | B | - |
| 18 | R | - |
| 19 | Y | - |
| 20 | B | - [With BOSE audio] |

| | | |
|----|--------|------------------------|
| 20 | R | - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] |
| 21 | BR | - [Without BOSE audio] |
| 22 | V | - |
| 23 | P | - |
| 24 | W | - |
| 25 | SB | - |
| 26 | R | - |
| 29 | SHIELD | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | BR | - |
| 33 | O | - |
| 34 | GR | - |
| 35 | G | - |
| 44 | Y | - |
| 44 | V | - |
| 45 | P | - |
| 46 | W | - |
| 52 | G | - |
| 53 | GR | - |
| 54 | O | - |
| 55 | L | - |

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)

| | |
|----------------|------------------------------|
| Connector No. | D33 |
| Connector Name | DOOR MIRROR (PASSENGER SIDE) |
| Connector Type | TH4MW-NH |

| | |
|----------------|--------------|
| Connector No. | M5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-C515 |

| | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 |
| 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | SIDE CAMERA RH COMM |
| 4 | LG | SIDE CAMERA RH IMAGE SIGNAL |
| 5 | B | SIDE CAMERA RH IMAGE SIGNAL |
| 6 | R | SIDE CAMERA RH POWER SUPPLY |
| 7 | L | - |
| 10 | G | - |
| 11 | GR | - |
| 12 | O | - |
| 16 | BR | - |
| 17 | G | SIDE CAMERA RH IMAGE GND |
| 18 | Y | SIDE CAMERA RH GND |
| 19 | B | - |
| 21 | P | - |
| 22 | Y | - |
| 23 | W | - |
| 24 | V | - |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FY-MZ |

| | | |
|----|----|----|
| 3A | 2A | 1A |
| 8A | 7A | 6A |
| 5A | 4A | 4A |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | - |
| 2A | G | - |
| 3A | L | - |
| 4A | P | - |
| 5A | V | - |
| 6A | Y | - |

| | |
|----|---|
| 7A | R |
| 8A | L |

| | |
|----------------|--------------|
| Connector No. | M5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-C515 |

| | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 |
| 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | BR | - |
| 4 | P | - |
| 5 | L | - |
| 6 | R | - |
| 7 | R | - |
| 8 | W | - |
| 9 | G | - |
| 10 | L | - |
| 11 | G | - |
| 12 | V | - |
| 13 | B | - |
| 14 | Y | - |
| 15 | W | - |
| 16 | R | - |
| 17 | B | - |
| 18 | G | - |
| 19 | Y | - |
| 20 | L | - |
| 21 | LG | - |
| 22 | L | - |
| 23 | G | - |
| 24 | Y | - |
| 25 | GR | - |
| 26 | R | - |
| 27 | W | - |
| 28 | SHIELD | - |
| 29 | Y | - |
| 30 | Y | - [With BOSE audio] |
| 31 | R | - [Without BOSE audio] |
| 32 | BR | - [With BOSE audio] |
| 33 | SP | - [Without BOSE audio] |
| 34 | Y | - |

| | | |
|----|----|--|
| 35 | P | - |
| 36 | LG | - |
| 37 | BR | - |
| 38 | P | - |
| 39 | BG | - |
| 40 | SB | - |
| 41 | L | - |
| 42 | R | - |
| 43 | BR | - |
| 44 | V | - |
| 45 | G | - |
| 46 | SB | - [With automatic drive positioner] |
| 46 | V | - [Without automatic drive positioner] |
| 49 | P | - |
| 50 | B | - |
| 52 | R | - |
| 53 | V | - |
| 54 | LG | - |
| 55 | SB | - |

| | |
|----------------|--------------|
| Connector No. | M124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-C515 |

| | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 |
| 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7 | Y | - |
| 8 | LG | - |
| 9 | Y | - |
| 12 | L | - |
| 13 | V | - |
| 14 | B | - |
| 15 | W | - |
| 16 | BR | - |
| 17 | B | - |
| 18 | R | - |
| 19 | B | - |
| 20 | Y | - [With BOSE audio] |
| 20 | W | - [Without BOSE audio] |
| 21 | G | - [With BOSE audio] |
| 21 | L | - [Without BOSE audio] |
| 22 | SB | - [With BOSE audio] |
| 23 | GR | - |

| | | |
|----|--------|---|
| 24 | G | - |
| 25 | Y | - |
| 26 | R | - |
| 28 | SHIELD | - |
| 29 | W | - |
| 30 | W | - |
| 31 | LG | - |
| 32 | G | - |
| 33 | BR | - |
| 34 | V | - |
| 35 | G | - |
| 43 | L | - |
| 44 | Y | - |
| 45 | R | - |
| 46 | W | - |
| 52 | R | - |
| 53 | G | - |
| 54 | W | - |
| 55 | BG | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

Wiring Diagram - INSIDE MIRROR SYSTEM -

INFOID:000000006902253

◊PM◊: With automatic drive positioner
◊OP◊: Without automatic drive positioner

INSIDE MIRROR



2009/07/16

JCLWA3671GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

INSIDE MIRROR

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | GR | - |
| 2A | G | - |
| 3A | L | - |
| 4A | P | - |
| 5A | V | - |
| 6A | Y | - |
| 7A | R | - |
| 8A | L | - |

| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3B | P | - |
| 4B | G | - |
| 5B | BG | - |
| 6B | Y | - |
| 7B | P | - |
| 8B | R | - |
| 9B | SB | - |

| | |
|----------------|--------------|
| Connector No. | M106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NH10MH-CS10 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | SHIELD | - |
| 3 | L | - |
| 4 | W | - |
| 5 | Y | - |
| 7 | BR | - |
| 8 | Y | - |
| 9 | B | - |
| 10 | R | - |
| 11 | V | - |
| 12 | R | - |
| 13 | LS | - |
| 14 | R | - [With NAVI] |
| 14 | Y | - [Without NAVI] |
| 15 | SHIELD | - |
| 16 | G | - [With NAVI] |
| 16 | BR | - [Without NAVI] |
| 18 | B | - |


| | |
|----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NH10PFC-CS10 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 1 | G | - |
| 2 | SHIELD | - |
| 3 | L | - |
| 4 | BR | - [With automatic drive positioner] |


| | | |
|----|--------|--|
| 4 | W | - [Without automatic drive positioner] |
| 5 | G | - |
| 7 | BR | - |
| 8 | Y | - |
| 9 | B | - |
| 10 | Y | - |
| 11 | V | - |
| 12 | BR | - |
| 13 | R | - |
| 14 | W | - |
| 15 | SHIELD | - |
| 16 | B | - |
| 18 | B | - |

| | |
|----------------|----------------------------------|
| Connector No. | R3 |
| Connector Name | AUTO ANTI-DAZZLING INSIDE MIRROR |
| Connector Type | TH10FB-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | BR | - |
| 8 | B | - |
| 10 | G | - |

| | |
|----------------|----------------------------------|
| Connector No. | R6 |
| Connector Name | AUTO ANTI-DAZZLING INSIDE MIRROR |
| Connector Type | JAA07FB |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | B | - |
| 7 | W | - |

JCLWA4353GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MIR

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000006346117



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-130. "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [MIR-128. "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000006346118

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

3. The trunk lid torsion bars knocking together

4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise

2. Sunvisor shaft shaking in the holder

3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder

2. A squeak between the seat pad cushion and frame

3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall

2. Components that pass through the engine wall

3. Engine wall mounts and connectors

4. Loose radiator mounting pins

5. Hood bumpers out of adjustment

6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

Diagnostic Worksheet

INFOID:000000006346119







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about ____ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

| | YES | NO | Initials of person performing |
|--|--------------------------|--------------------------|-------------------------------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006346120

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >


[WITHOUT ADP]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000006346121

| Tool name | Description |
|--|---|
| Remover tool  PIIB7923J | Remove the clip and pawl and metal clip |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

INSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View

INFOID:000000006346122


Base



1. Inside mirror
2. Mirror base

Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
2. Mirror base
3. Inside mirror cover
4. Harness connector
5. TORX bolt

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000006346123

REMOVAL

Base model

Revision: 2011 October

MIR-134

2011 EX

INSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

MIR

OUTSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

OUTSIDE MIRROR

Exploded View

INFOID:00000006880858



- | | | |
|--|---|------------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Door mirror corner cover | 9. BSW indicator |

- : Clip
△ : Pawl

DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:00000006880860

REMOVAL

1. Remove front door finisher.
 - Driver side: Refer to [INT-12, "DRIVER SIDE : Removal and Installation"](#).
 - Passenger side: Refer to [INT-15, "PASSENGER SIDE : Removal and Installation"](#).
2. Disconnect BSW indicator harness connector. (if equipped)
3. Remove door corner cover fixing clips and remove door corner cover.
4. Disconnect door mirror harness connector.
5. Remove door mirror mounting nuts, and remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-425, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

OUTSIDE MIRROR

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:000000006346126

DISASSEMBLY

1. Remove door mirror cover. Refer to [MIR-137, "DOOR MIRROR COVER : Disassembly and Assembly"](#).
2. Remove side camera after removing door mirror assembly (BOSE audio with navigation model).
 - Side camera LH: Refer to [AV-533, "Removal and Installation"](#).
 - Side camera RH: Refer to [AV-534, "Removal and Installation"](#).
3. Remove base cover and puddle lamp.

ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Disassembly and Assembly


INFOID:000000006346128

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.

NOTE:

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Disassembly and Assembly

INFOID:000000006346130

CAUTION:

Do not damage the mirror bodies.

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-137, "GLASS MIRROR : Disassembly and Assembly"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:000000006346131


Refer to [INT-18, "Exploded View"](#)


Removal and Installation

INFOID:000000006346132

REMOVAL

1. Remove the power window main switch finisher. Refer to [INT-12, "DRIVER SIDE : Exploded View"](#).
2. Remove door mirror remote control switch (1) from power window main switch finisher (2) using flat-bladed screwdriver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.