

SECTION MIR

MIRRORS

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

WITH ADP

BASIC INSPECTION	3
DIAGNOSIS AND REPAIR WORKFLOW	3
Work Flow	3
SYSTEM DESCRIPTION	4
DOOR MIRROR SYSTEM	4
System Diagram	4
System Description	4
Component Parts Location	6
Component Description	6
INSIDE MIRROR SYSTEM	8
System Description	8
Component Description	8
DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)	9
Diagnosis Description	9
CONSULT Function	9
DTC/CIRCUIT DIAGNOSIS	12
DOOR MIRROR REMOTE CONTROL SWITCH	12
MIRROR SWITCH	12
MIRROR SWITCH : Description	12
MIRROR SWITCH : Component Function Check	12
MIRROR SWITCH : Diagnosis Procedure	12
MIRROR SWITCH : Component Inspection	13
CHANGEOVER SWITCH	14
CHANGEOVER SWITCH : Description	14
CHANGEOVER SWITCH : Component Function Check	14
CHANGEOVER SWITCH : Diagnosis Procedure	14
CHANGEOVER SWITCH : Component Inspection	15

DOOR MIRROR SYSTEM	17
Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -	17
AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM	25
Wiring Diagram - INSIDE MIRROR SYSTEM -	25
ECU DIAGNOSIS INFORMATION	27
DRIVER SEAT CONTROL UNIT	27
Reference Value	27
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	32
Fail Safe	45
DTC Index	46
AUTOMATIC DRIVE POSITIONER CONTROL UNIT	47
Reference Value	47
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	51
BCM (BODY CONTROL MODULE)	65
Reference Value	65
Wiring Diagram - BCM -	89
Fail-safe	103
DTC Inspection Priority Chart	104
DTC Index	105
SYMPTOM DIAGNOSIS	108
DOOR MIRROR DOES NOT OPERATE	108
Diagnosis Procedure	108
REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE	109
Diagnosis Procedure	109
SQUEAK AND RATTLE TROUBLE DIAGNOSES	110
Work Flow	110

MIR

Inspection Procedure	112	DOOR MIRROR SYSTEM	125
Diagnostic Worksheet	114	Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -	125
PRECAUTION	116		
PRECAUTIONS	116		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	116		
PREPARATION	117		
PREPARATION	117		
Commercial Service Tools	117		
REMOVAL AND INSTALLATION	118		
INSIDE MIRROR	118		
Exploded View	118		
Removal and Installation	118		
OUTSIDE MIRROR	120		
Exploded View	120		
DOOR MIRROR ASSEMBLY	120		
DOOR MIRROR ASSEMBLY : Removal and In- stallation	120		
DOOR MIRROR ASSEMBLY : Disassembly and Assembly	121		
GLASS MIRROR	121		
GLASS MIRROR : Removal and Installation	121		
DOOR MIRROR COVER	121		
DOOR MIRROR COVER : Removal and Installa- tion	121		
DOOR MIRROR REMOTE CONTROL			
SWITCH	122		
Exploded View	122		
Removal and Installation	122		
WITHOUT ADP			
SYSTEM DESCRIPTION	123		
DOOR MIRROR SYSTEM	123		
Component Description	123		
INSIDE MIRROR SYSTEM	124		
System Description	124		
Component Description	124		
DTC/CIRCUIT DIAGNOSIS	125		
DOOR MIRROR SYSTEM	125		
Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -	125		
AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM	128		
Wiring Diagram - INSIDE MIRROR SYSTEM - ...	128		
SYMPTOM DIAGNOSIS	130		
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	130		
Work Flow	130		
Inspection Procedure	132		
Diagnostic Worksheet	134		
PRECAUTION	136		
PRECAUTIONS	136		
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	136		
PREPARATION	137		
PREPARATION	137		
Commercial Service Tools	137		
REMOVAL AND INSTALLATION	138		
INSIDE MIRROR	138		
Exploded View	138		
Removal and Installation	138		
OUTSIDE MIRROR	140		
Exploded View	140		
DOOR MIRROR ASSEMBLY	140		
DOOR MIRROR ASSEMBLY : Removal and In- stallation	140		
DOOR MIRROR ASSEMBLY : Disassembly and Assembly	141		
GLASS MIRROR	141		
GLASS MIRROR : Disassembly and Assembly ..	141		
DOOR MIRROR COVER	141		
DOOR MIRROR COVER : Disassembly and As- sembly	141		
DOOR MIRROR REMOTE CONTROL			
SWITCH	142		
Exploded View	142		
Removal and Installation	142		

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000007459401

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2. CHECK DTC

Perform self-diagnosis for automatic drive positioner (ADP) with CONSULT.

Is any DTC detected?

YES >> Refer to [ADP-143, "DTC Index"](#)

NO >> GO TO 3.

3. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

4. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

5. IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

6. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

DOOR MIRROR SYSTEM

System Diagram

INFOID:000000007459402



System Description

INFOID:000000007459403

MANUAL FUNCTION

Description

- Automatic drive positioner control unit controls door mirror.
- Automatic drive positioner control unit inputs changeover switch signal and perform the LH/RH control of door mirror motor supplying electric power when changeover switch is operated.
- Automatic drive positioner control unit inputs mirror switch signal and supplies electric power to door mirror.
- The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

- Ignition switch: ON or ACC
- Changeover switch: Select either left or right

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Description

- Select one of the door mirror faces by change over switch, and then set the selected mirror face downward/inward.
- When the ignition switch is ON position and A/T shift selector is in R position, the TCM sends the R signal to the driver seat control unit. The R signal is transmitted to the automatic drive positioner control unit from the driver seat control unit via UART communication. When the R signal is detected, the automatic device positioner control unit activated the mirror motor.

Operation Conditions

If the following conditions are not satisfied, operation is not performed.

DOOR MIRROR SYSTEM

[WITH ADP]

< SYSTEM DESCRIPTION >

- Ignition switch: ON
- Changeover switch: Select either left or right
- A/T shift selector: R position

During the reverse interlock door mirror system, if all of the above conditions are not satisfied, mirror face returns to original angle.

Mirror Angle Memory Function

- During the reverse interlock door mirror operation, the mirror angle can be changed. After adjustment, the mirror face positions can be memorized (2 positions). For memory setting.
- Initial setting is downward 7°, inward 1° (both of left and right).
- When the driver's seat, outside mirror and steering column are not in the memorized position, the outside mirror will move with the initial tilt-down angle, if the reverse tilt-down position is stored. Linking Intelligent Key to a stored memory position.

Memory Procedure

1. Apply the parking brake.
2. Push the ignition switch to the ON position. (Do not start the engine.)
3. Push the memory switch 1 or 2 fully for at least 1 second to operate the automatic drive positioner.
4. Turn the door mirror control switch (changeover switch) to L (left).
5. Depress the brake pedal.
6. Move the A/T shift selector to R position (reverse).
7. Adjust the mirror to the desired viewing position for backing up by operating the door mirror control switch (mirror switch).
8. Push the SET switch and, within 5 seconds, push the memory switch 1 or 2 selected in step 3 fully for at least 1 second.
The indicator light for the pushed memory switch will come on and stay pushing the switch. After the indicator light goes off, the selected mirror position is stored in the selected memory (1 or 2).
9. Turn the door mirror control switch (changeover switch) to R (right).
Repeat the above procedure to adjust the right mirror position and store in the selected memory.

AUTOMATIC DRIVE POSITIONER SYSTEM LINKED OPERATION

Description

Door mirror control is included in automatic drive positioner system. Refer to automatic drive positioner system for more details.

Refer to [ADP-13. "AUTOMATIC DRIVE POSITIONER SYSTEM : System Description"](#).

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P


DOOR MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITH ADP]

Component Parts Location

INFOID:0000000007459404



JMLIA0129ZZ

- | | | |
|--|--|---|
| 1. Door mirror remote control switch
D17 | 2. Door mirror (driver side) D3 | 3. Door mirror (passenger side) D33 |
| 4. Automatic drive positioner control
unit M51, M52 | 5. Driver seat control unit B451, B452 | 6. AT assembly connector (TCM) F51 |
| 7. BCM M118, M119, M122 | | |
| A. View with instrument driver lower
panel removed | B. Back side of the seat cushion | C. AT assembly (TCM is built in AT as-
sembly) |
| D. Dash side lower (passenger side) | | |

Component Description

INFOID:0000000007459405

Component	Function	
Automatic drive positioner control unit	Door mirror is supplied with power after receiving the input of the MIRROR SWITCH and CHANGEOVER SWITCH.	
Door mirror remote control switch	Mirror switch	It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.
	Changeover switch	It transmits the LH/RH control of door mirror that supplies power to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.
Door mirror	It makes mirror face operate from side to side and up and down via integrated motor.	
BCM	The ignition switch signal (ACC/ON) is transmitted to driver seat control unit via CAN communication.	

DOOR MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITH ADP]

Component	Function
Driver seat control unit	The ignition switch signal (ACC/ON) is transmitted to automatic drive positioner control unit via UART communication.
TCM	The A/T shift position signal is transmitted to driver seat control unit via CAN communication.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

INSIDE MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITH ADP]

INSIDE MIRROR SYSTEM

System Description

INFOID:0000000007459406

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:0000000007459407

Component	Function
Auto anti-dazzling inside mirror	It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind.

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

Diagnosis Description

INFOID:0000000007773687

The auto drive positioner system can be checked and diagnosed for component operation with CONSULT.

DIAGNOSTIC MODE

Diagnostic mode [AUTO DRIVE POS.]	Description
WORK SUPPORT	Changes the setting of each function.
SELF-DIAG RESULTS	Performs self-diagnosis for the auto drive positioner system and displays the results.
DATA MONITOR	Displays input signals transmitted from various switches and sensors to driver seat control unit in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Drive each output device.
ECU PART NUMBER	Displays part numbers of driver seat control unit parts.

CONSULT Function

INFOID:0000000007773688

SELF-DIAGNOSIS RESULTS

Refer to [MIR-46, "DTC Index".](#)

DATA MONITOR

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
SET SW	"ON/OFF"	×	×	ON/OFF status judged from the setting switch signal.
MEMORY SW 1	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 1 signal.
MEMORY SW 2	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 2 signal.
SLIDE SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (forward) signal.
SLIDE SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (backward) signal.
RECLN SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (forward) signal.
RECLN SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (backward) signal.
LIFT FR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (up) signal.
LIFT FR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (down) signal.
LIFT RR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (up) signal.
LIFT RR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (down) signal.
MIR CON SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (up) signal.
MIR CON SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (down) signal.
MIR CON SW-RH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (passenger side) signal.
MIR CON SW-LH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (driver side) signal.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
MIR CHNG SW-R	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to right) signal.
MIR CHNG SW-L	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to left) signal.
TILT SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (up) signal.
TILT SW-DOWN	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (down) signal.
TELESCO SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (forward) signal.
TELESCO SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (backward) signal.
DETENT SW	"ON/OFF"	×	×	The selector lever position "OFF (P position) / ON (other than P position)" judged from the detention switch signal.
STARTER SW	"ON/OFF"	×	×	Ignition key switch ON (START, ON) / OFF (ACC, OFF) status judged from the ignition switch signal.
SLIDE PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
RECLN PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
LIFT FR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
LIFT RR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
MIR/SEN RH U-D	"V"	—	×	Voltage input from door mirror sensor (passenger side) up/down is displayed.
MIR/SEN RH R-L	"V"	—	×	Voltage input from door mirror sensor (passenger side) left/right is displayed.
MIR/SEN LH U-D	"V"	—	×	Voltage input from door mirror sensor (driver side) up/down is displayed.
MIR/SEN LH R-L	"V"	—	×	Voltage input from door mirror sensor (driver side) left/right is displayed.
TILT SEN	"V"	—	×	Voltage input from tilt sensor is displayed.
TELESCO SEN	"V"	—	×	Voltage input from telescopic sensor is displayed.

ACTIVE TEST

CAUTION:

When driving vehicle, do not perform active test.

Test item	Description
SEAT SLIDE	Activates/deactivates the sliding motor.
SEAT RECLINING	Activates/deactivates the reclining motor.
SEAT LIFTER FR	Activates/deactivates the lifting motor (front).
SEAT LIFTER RR	Activates/deactivates the lifting motor (rear).
TILT MOTOR	Activates/deactivates the tilt motor.
TELESCO MOTOR	Activates/deactivates the telescopic motor.
MIRROR MOTOR RH	Activates/deactivates the mirror motor (passenger side).

DIAGNOSIS SYSTEM (DRIVER SEAT CONTROL UNIT)

< SYSTEM DESCRIPTION >

[WITH ADP]

Test item	Description
MIRROR MOTOR LH	Activates/deactivates the mirror motor (driver side).
MEMORY SW INDCTR	Turns ON/OFF the memory indicator.

WORK SUPPORT

Work item	Content	Item
SEAT SLIDE VOLUME SET	The amount of seat sliding for entry/exit assist can be selected from 3 items.	40 mm
		80 mm
		150 mm
EXIT TILT SETTING	Entry/exit assist (steering column) can be selected: ON (operated) – OFF (not operated)	ON
		OFF
EXIT SEAT SLIDE SETTING	Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated)	ON
		OFF

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR REMOTE CONTROL SWITCH MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:0000000007459410

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

MIRROR SWITCH : Component Function Check

INFOID:0000000007459411

1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in "DATA MONITOR" mode with CONSULT.

Monitor item	Condition
MIR CON SW-UP/DN	When operating the mirror switch toward the up or down side. : ON
	Other than above. : OFF
MIR CON SW-RH/LH	When operating the mirror switch toward the right or left side. : ON
	Other than above. : OFF

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [MIR-12, "MIRROR SWITCH : Diagnosis Procedure".](#)

MIRROR SWITCH : Diagnosis Procedure

INFOID:0000000007459412

1. CHECK MIRROR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

(+)			
Connector	Terminal	Voltage (V) (Approx.)	
D17	4	Ground	5
	12		
	13		
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK MIRROR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	3	D17	15	Existed
	4		13	
	19		12	
	20		4	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	3		Not existed
	4		
	19		
	20		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-222, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK MIRROR SWITCH

Check door mirror remote control switch (mirror switch).

Refer to [MIR-13, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace door mirror remote control switch (mirror switch). Refer to [MIR-122, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

MIRROR SWITCH : Component Inspection

INFOID:000000007459413

1.CHECK MIRROR SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Door mirror remote control switch		Condition		Continuity
Connector	Terminal			
D17	4	7	Mirror switch	RIGHT
	13			Other than above
	15			LEFT
	12			Other than above
				UP
				Other than above
				DOWN
				Other than above

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-122, "Removal and Installation"](#).

CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:0000000007459414

Changover switch is integrated into door mirror remote control switch.

Changover switch has three positions (L, N and R).

It changes door mirror motor operation by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:0000000007459415

1.CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in "DATA MONITOR" mode with CONSULT.

Monitor item	Condition
MIR CHNG SW-R/L	When operating the changeover toward the right or left side. : ON
	Other than above. : OFF

Is the inspection result normal?

YES >> Changover switch function is OK.

NO >> Refer to [MIR-14, "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:0000000007459416

1.CHECK CHANGEOVER SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect door mirror remote control switch connector.
- Turn ignition switch ON.
- Check voltage between door mirror remote control switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror remote control switch			
Connector	Terminal		
D17	10	Ground	5
	11		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK CHANGEOVER SWITCH CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	2	D17	11	Existed
	18		10	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	2		Not existed
	18		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-222, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK CHANGEOVER SWITCH

Check door mirror remote control switch (changeover switch).

Refer to [MIR-15, "CHANGEOVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace door mirror remote control switch (changeover switch). Refer to [MIR-122, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

CHANGEOVER SWITCH : Component Inspection

INFOID:000000007459417

1.CHECK CHANGEOVER SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

A

B

C

D

E

F

G

H

J

K

MIR

M

N

O

P

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

Door mirror remote control switch			Condition		Continuity	
Connector	Terminal		Changeover switch	LEFT	Existed	
D17	10	7		Other than above	Not existed	
	11			RIGHT	Existed	
Is the inspection result normal?				Other than above	Not existed	

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-122, "Removal and Installation"](#).

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


[WITH ADP]

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -

INFOID:0000000007459418


DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)



DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]



* : This connector is not shown in "Harness Layout".

JCLWA4343GB

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	B1	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE		60	P		14	G/B	REAR LIFTING SW (DOWNWARD)
Connector Type	THB801W CS16-TMA4		61	L		16	O	VCC
			62	SHIELD		17	V/R	TX
			63	R		19	V	CAN-L
			64	G		21	L/W	P RANGE/SW
			65	SHIELD		24	R	PULSE(SIDING)
			66	W		25	Y/B	PULSE(F LIFTING)
			67	V		26	Y	SLIDING SW (FORWARD)
			68	SB		27	R/G	RECLINING SW (FORWARD)
			69	SHIELD		28	W/B	FRONT LIFTING SW (UPWARD)
			70	W		29	P/L	REAR LIFTING SW (UPWARD)
			73	SB		31	GR	SENSOR GND
			74	L		32	B/W	GND (SIGNAL)
			75	W				
			76	BR				
			77	R				
			78	P				
			79	GR				
			83	IG				
			85	V				
			86	LG				
			87	Y				
			88	R				
			89	B				
			90	IG				
			91	IG				
			92	BR				
			93	G				
			94	SB				
			95	Y				
			96	W				
			99	GR				

JRLWE4784GB

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	Signal Name [Specification]	Terminal Color Of No.	Wire	Signal Name [Specification]	Terminal Color Of No.	Wire	Signal Name [Specification]
1	LN	1	BR	-	2	O	-
3	RY	2	P	-	4	BR	-
19	V	3	BR	-	20	W	-
21	UT	4	Y	-	21	O	-
32	B/W	5	GR	-	22	P	-
33	R	6	Y	-	23	GR	-
40	R/W	7	GR	-	24	GR	-
48	B	8	Y	-	25	GR	-
60	Y/R	9	GR	-	26	Y	-
66	B	10	GR	-	27	Y	-
67	L	11	GR	-	28	Y	-
37	R	12	GR	-	29	LG	-
38	P	13	GR	-	30	LG	-
39	O	14	GR	-	31	W	-
40	BR	15	GR	-	32	G	-
41	L	16	GR	-	33	L	-
42	GR	17	GR	-	34	Sb	-
43	BR	18	GR	-	35	R	-
43	O	19	GR	-	36	R	-
44	GR	20	GR	-	37	LG	-
44	W	21	GR	-	38	Y	-
45	G	22	GR	-	39	P	-
45	Y	23	GR	-	40	V	-
46	G	24	GR	-	41	GR	-
46	V	25	GR	-	42	GR	-
49	GR	26	GR	-	43	GR	-
50	B	27	GR	-	44	GR	-
52	R	28	GR	-	53	Sb	-
53	Sb	29	GR	-	54	O	-
54	O	30	GR	-	55	Y	-
55	Y	31	GR	-	56	GR	-
8	W	32	GR	-	57	Y	-
9	R	33	GR	-	58	B	-
		34	GR	-	59	B	-
		35	GR	-	60	B	-
		36	GR	-	61	B	-
		37	GR	-	62	B	-
		38	GR	-	63	B	-
		39	GR	-	64	B	-

JRLWE4785GB

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Terminal No.	Wire Color	Signal Name [Specification]	Terminal No.	Wire Color	Signal Name [Specification]
1	R	-	63	T	-
2	W	-	64	B	-
3	G	-	65	G	-
4	GR	-	66	R	-
5	GR	-	67	SHIELD	-
8	Y	-	68	Y	-
9	BR	-	70	W	-
10	BG	-	71	R	-
11	SB	-	72	B	-
12	BG	-	73	B	-
13	L	-	74	L	-
14	R	-	75	G	-
15	P	-	76	W	-
16	V	-	77	Y	-
17	SB	-	78	P	-
18	V	-	79	R	-
20	BG	-	80	R	-
21	L	-	81	R	-
22	G	-	82	SB	-
23	Y	-	83	BS	-
24	V	-	84	G	-
28	G	-	85	L	-
31	BG	-	86	P	-
32	W	-	87	V	-
33	B	-	88	GR	-
34	R	-	89	SHIELD	-
35	G	-	90	W	-
36	SHIELD	-	91	Y	-
37	V	-	92	-	-
38	BR	-	93	V	-
39	BS	-	94	LG	-
41	W	-	95	BG	-
42	G	-	96	P	-

JRLWE4786GB

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector Type	NS06FW-M2	16	R
----------------	-----------	----	---

No.	Terminal	Color Of Wire	Signal Name [Specification]
1	W	-	65 W
2	R	-	66 R
3	B	-	67 SHIELD
4	SHIELD	-	68 Y
5	G	-	69 GR
8	Y	-	70 LG
9	BR	-	71 LG
10	R	-	72 Y
11	BR	-	73 SB
12	BG	-	74 BR
13	L	-	74 L
14	R	-	75 G
15	P	-	76 GR
16	V	-	76 W
17	SB	-	77 P
18	V	-	77 R
20	BG	-	78 L
21	L	-	78 R
22	W	-	79 W
23	P	-	79 Y
24	BR	-	80 SB
25	Y	-	81 SB
26	V	-	82 SB
27	G	-	83 V
28	G	-	84 G
31	L	-	85 L
32	G	-	86 P
33	B	-	87 W
34	W	-	88 GR
35	R	-	89 SHIELD
36	SHIELD	-	91 W
37	V	-	92 Y
38	BG	-	93 BR
39	BR	-	94 P
41	W	-	95 GR
42	IC	-	96 W

2A 19 Y

22 L

Terminal	Color Of	Signal Name [Specification]
		25 GR

Connector Name		Signal Name [Specification]		Terminal No.		Color Of Wire	
M5	WIRE TO WIRE	1	R	1	R	Red	-
		2	R	2	R	Red	-
		3	R	3	R	Red	-
		4	R	4	R	Red	-
		5	R	5	R	Red	-
		6	R	6	R	Red	-
		7	R	7	R	Red	-
		8	R	8	R	Red	-
		9	R	9	R	Red	-
		10	R	10	R	Red	-
		11	R	11	R	Red	-
		12	R	12	R	Red	-
		13	R	13	R	Red	-
		14	R	14	R	Red	-
		15	R	15	R	Red	-
		16	R	16	R	Red	-
		17	R	17	R	Red	-
		18	R	18	R	Red	-
		19	R	19	R	Red	-
		20	R	20	R	Red	-
		21	R	21	R	Red	-
		22	R	22	R	Red	-
		23	R	23	R	Red	-
		24	R	24	R	Red	-
		25	R	25	R	Red	-
		26	R	26	R	Red	-
		27	R	27	R	Red	-
		28	R	28	R	Red	-
		29	R	29	R	Red	-
		30	R	30	R	Red	-
		31	R	31	R	Red	-
		32	R	32	R	Red	-
		33	R	33	R	Red	-
		34	R	34	R	Red	-
		35	R	35	R	Red	-
		36	R	36	R	Red	-
		37	R	37	R	Red	-
		38	R	38	R	Red	-
		39	R	39	R	Red	-
		40	R	40	R	Red	-
		41	R	41	R	Red	-
		42	R	42	R	Red	-
		43	R	43	R	Red	-
		44	R	44	R	Red	-
		45	R	45	R	Red	-
		46	R	46	R	Red	-
		47	R	47	R	Red	-
		48	R	48	R	Red	-
		49	R	49	R	Red	-
		50	R	50	R	Red	-
		51	R	51	R	Red	-
		52	R	52	R	Red	-
		53	R	53	R	Red	-
		54	R	54	R	Red	-
		55	R	55	R	Red	-
		56	R	56	R	Red	-
		57	R	57	R	Red	-
		58	R	58	R	Red	-
		59	R	59	R	Red	-
		60	R	60	R	Red	-
		61	R	61	R	Red	-
		62	R	62	R	Red	-
		63	R	63	R	Red	-
		64	R	64	R	Red	-
		65	R	65	R	Red	-
		66	R	66	R	Red	-
		67	R	67	R	Red	-
		68	R	68	R	Red	-
		69	R	69	R	Red	-
		70	R	70	R	Red	-
		71	R	71	R	Red	-
		72	R	72	R	Red	-
		73	R	73	R	Red	-
		74	R	74	R	Red	-
		75	R	75	R	Red	-
		76	R	76	R	Red	-
		77	R	77	R	Red	-
		78	R	78	R	Red	-
		79	R	79	R	Red	-
		80	R	80	R	Red	-
		81	R	81	R	Red	-
		82	R	82	R	Red	-
		83	R	83	R	Red	-
		84	R	84	R	Red	-
		85	R	85	R	Red	-
		86	R	86	R	Red	-
		87	R	87	R	Red	-
		88	R	88	R	Red	-
		89	R	89	R	Red	-
		90	R	90	R	Red	-
		91	R	91	R	Red	-
		92	R	92	R	Red	-
		93	R	93	R	Red	-
		94	R	94	R	Red	-
		95	R	95	R	Red	-
		96	R	96	R	Red	-
		97	R	97	R	Red	-
		98	R	98	R	Red	-
		99	R	99	R	Red	-
		100	R	100	R	Red	-
		101	R	101	R	Red	-
		102	R	102	R	Red	-
		103	R	103	R	Red	-
		104	R	104	R	Red	-
		105	R	105	R	Red	-
		106	R	106	R	Red	-
		107	R	107	R	Red	-
		108	R	108	R	Red	-
		109	R	109	R	Red	-
		110	R	110	R	Red	-
		111	R	111	R	Red	-
		112	R	112	R	Red	-
		113	R	113	R	Red	-
		114	R	114	R	Red	-
		115	R	115	R	Red	-
		116	R	116	R	Red	-
		117	R	117	R	Red	-
		118	R	118	R	Red	-
		119	R	119	R	Red	-
		120	R	120	R	Red	-
		121	R	121	R	Red	-
		122	R	122	R	Red	-
		123	R	123	R	Red	-
		124	R	124	R	Red	-
		125	R	125	R	Red	-
		126	R	126	R	Red	-
		127	R	127	R	Red	-
		128	R	128	R	Red	-
		129	R	129	R	Red	-
		130	R	130	R	Red	-
		131	R	131	R	Red	-
		132	R	132	R	Red	-
		133	R	133	R	Red	-
		134	R	134	R	Red	-
		135	R	135	R	Red	-
		136	R	136	R	Red	-
		137	R	137	R	Red	-
		138	R	138	R	Red	-
		139	R	139	R	Red	-
		140	R	140	R	Red	-
		141	R	141	R	Red	-
		142	R	142	R	Red	-
		143	R	143	R	Red	-
		144	R	144	R	Red	-
		145	R	145	R	Red	-
		146	R	146	R	Red	-
		147	R	147	R	Red	-
		148	R	148	R	Red	-
		149	R	149	R	Red	-
		150	R	150	R	Red	-
		151	R	151	R	Red	-
		152	R	152	R	Red	-
		153	R	153	R	Red	-
		154	R	154	R	Red	-
		155	R	155	R	Red	-
		156	R	156	R	Red	-
		157	R	157	R	Red	-
		158	R	158	R	Red	-
		159	R	159	R	Red	-
		160	R	160	R	Red	-
		161	R	161	R	Red	-
		162	R	162	R	Red	-
		163	R	163	R	Red	-
		164	R	164	R	Red	-
		165	R	165	R	Red	-
		166	R	166	R	Red	-
		167	R	167	R	Red	-
		168	R	168	R	Red	-
		169	R	169	R	Red	-
		170	R	170	R	Red	-
		171	R	171	R	Red	-
		172	R	172	R	Red	-
		173	R	173	R	Red	-
		174	R	174	R	Red	-
		175	R	175	R	Red	-
		176	R	176	R	Red	-
		177	R	177	R	Red	-
		178	R	178	R	Red	-
		179	R	179	R	Red	-
		180	R	180	R	Red	-
		181	R	181	R	Red	-
		182	R	182	R	Red	-
		183	R	183	R	Red	-
		184	R	184	R	Red	-
		185	R	185	R	Red	-
		186	R	186	R	Red	-
		187	R	187	R	Red	-
		188	R	188	R	Red	-
		189	R	189	R	Red	-
		190	R	190	R	Red	-
		191	R	191	R	Red	-
		192	R	192	R	Red	-
		193	R	193	R	Red	-
		194	R	194	R	Red	-
		195	R	195	R	Red	-
		196	R	196	R	Red	-
		197	R	197	R	Red	-
		198	R	198	R	Red	-
		199	R	199	R	Red	-
		200	R	200	R	Red	-
		201	R	201	R	Red	-
		202	R	202	R	Red	-
		203	R	203	R	Red	-
		204	R	204	R	Red	-
		205	R	205	R	Red	-
		206	R	206	R	Red	-
		207	R	207	R	Red	-
		208	R	208	R	Red	-
		209	R	209	R	Red	-
		210	R	210	R	Red	-
		211	R	211	R	Red	-
		212	R	212	R	Red	-
		213	R	213	R	Red	-
		214	R	214	R	Red	-
		215	R	215	R	Red	-
		216	R	216	R	Red	-
		217	R	217	R	Red	-
		218	R	218	R	Red	-
		219	R	219	R	Red	-
		220	R	220	R	Red	-
		221	R	221	R	Red	-
		222	R	222	R	Red	-
		223	R	223	R	Red	-
		224	R	224	R	Red	-
		225	R	225	R	Red	-
		226	R	226	R	Red	-
		227	R	227	R	Red	-
		228	R	228	R	Red	-
		229	R	229	R	Red	-
		230	R	230	R	Red	-
		231	R	231	R	Red	-
		232	R	232	R	Red	-
		233	R	233	R	Red	-
		234	R	234	R	Red	-
		235	R	235	R	Red	-
		236	R	236	R	Red	-
		237	R	237	R	Red	-
		238	R	238	R	Red	-
		239	R	239	R	Red	-
		240	R	240	R	Red	-
		241	R	241	R	Red	-
		242	R	242	R	Red	-
		243	R	243	R	Red	-
		244	R	244	R	Red	-
		245	R	245	R	Red	-
		246	R	246	R	Red	-
		247	R	247	R	Red	-
		248	R	248	R	Red	-
		249	R	249	R	Red	-
		250</td					

1A GR - -
2A G - -
27 W SHIELD

4A	P	-	-	30	Y
5A	V	-	-	31	R

Connector No.	M5	Wire	Wire To Wire	
60A	Y	-	-	
7A	R	-	-	
8A	L	-	-	
32	BR	-	-	16 V -
33	SB	-	-	17 S -
34	Y	-	-	18 V -
35	P	-	-	20 BG -
36	LG	-	-	21 L -
37	BR	-	-	22 W -
38	P	-	-	23 P -
39	BG	-	-	24 BR -
40	SB	-	-	25 Y -
41	L	-	-	26 V -
42	R	-	-	27 G -
43	BR	-	-	28 G -
44	V	-	-	31 L -
45	G	-	-	32 G -
46	SB	-	-	33 B -
46	V	-	-	34 W -
49	P	-	-	35 R -
50	B	-	-	36 SHIELD -
52	R	-	-	37 V -
53	V	-	-	38 BG -
54	LG	-	-	39 BR -
55	SB	-	-	41 W -
				42 BG -
				43 P -
				44 -
				45 -
				46 -
				47 -
				48 -
				49 -
				50 -
				51 -
				52 -
				53 -
				54 -
				55 -

7A	R	-	-	33	SB
8A	L	-	-	34	Y

Connector No. MIS 36 37 38 LG BB

JRLWF4787GE

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.		M24											
Connector Name		DATA LINK CONNECTOR											
Connector Type:		BD16IW											
98	SHEILD	-	-	45	GR	-	-	13	P	-	-	14	W
99	V	-	-	46	LG	-	-	15	G	MIRROR MOTOR (RH VERTICAL)	-	16	Y
100	SB	-	-	47	SB	-	-	17	W	MIRROR MOTOR (RH HORIZONTAL)	-	18	P
49	V	-	-	49	Y	-	-	19	SB	TILT SW (DOWNWARD)	-	20	BR
50	R	-	-	50	R	-	-	21	L	MIRROR SELECT SW (LH)	-	22	G
69	P	-	-	61	L	-	-	23	P	MIRROR SW (DOWNWARD)	-	24	R
62	L	-	-	63	R	-	-	25	SB	MIRROR SW (HIGHWARD)	-	26	Y
64	G	-	-	64	G	-	-	27	G	MIRROR SENSOR (RH HORIZONTAL)	-	28	RX (UART)
65	SHEILD	-	-	65	SB	-	-	29	R	TELESCOPIC SENSOR (RH)	-	30	R
66	-	-	-	66	LG	-	-	31	LG	TELESCOPIC SW (BACKWARD)	-	32	L
67	V	-	-	67	Y	-	-	33	LG	MIRROR MOTOR (RH COMMON)	-	34	LG (UART)
68	LG	-	-	68	LG	-	-	35	LG	MIRROR MOTOR (RH VERTICAL)	-	36	LG (POSITIONER UNIT)
69	SHEILD	-	-	69	SHEILD	-	-	37	LG	MIRROR MOTOR (LH HORIZONTAL)	-	38	LG (POSITIONER UNIT)
70	W	-	-	70	W	-	-	39	LG	MIRROR MOTOR (LH VERTICAL)	-	40	LG (POSITIONER UNIT)
73	G	-	-	73	G	-	-	41	LG	MIRROR MOTOR (LH HIGHWARD)	-	42	LG (POSITIONER UNIT)
74	R	-	-	74	R	-	-	43	LG	MIRROR MOTOR (LH DOWNWARD)	-	44	LG (POSITIONER UNIT)
75	W	-	-	75	W	-	-	45	LG	MIRROR MOTOR (LH LEFTWARD)	-	46	LG (POSITIONER UNIT)
76	W	-	-	76	W	-	-	47	LG	MIRROR MOTOR (LH RIGHTWARD)	-	48	LG (POSITIONER UNIT)
77	B	-	-	77	B	-	-	49	LG	MIRROR MOTOR (LH UPWARD)	-	50	LG (POSITIONER UNIT)
78	P	-	-	78	P	-	-	51	LG	MIRROR MOTOR (LH BACKWARD)	-	52	LG (POSITIONER UNIT)
79	GR	-	-	79	GR	-	-	53	LG	MIRROR MOTOR (LH FRONTWARD)	-	54	LG (POSITIONER UNIT)
83	BS	-	-	83	BS	-	-	55	LG	MIRROR MOTOR (LH SIDEWARD)	-	56	LG (POSITIONER UNIT)
85	LG	-	-	85	LG	-	-	57	LG	MIRROR MOTOR (LH SIDEFRONTWARD)	-	58	LG (POSITIONER UNIT)
86	R	-	-	86	R	-	-	59	LG	MIRROR MOTOR (LH SIDEHIGHWARD)	-	60	LG (POSITIONER UNIT)
87	Y	-	-	87	Y	-	-	61	LG	MIRROR MOTOR (LH SIDELOWWARD)	-	62	LG (POSITIONER UNIT)
88	W	-	-	88	W	-	-	63	LG	MIRROR MOTOR (LH SIDEUPWARD)	-	64	LG (POSITIONER UNIT)
89	BR	-	-	89	BR	-	-	65	LG	MIRROR MOTOR (LH SIDEBACKWARD)	-	66	LG (POSITIONER UNIT)
90	BG	-	-	90	BG	-	-	67	LG	MIRROR MOTOR (LH SIDEFRONTBACKWARD)	-	68	LG (POSITIONER UNIT)
91	G	-	-	91	G	-	-	69	LG	MIRROR MOTOR (LH SIDEFRONTHIGHWARD)	-	70	LG (POSITIONER UNIT)
92	V	-	-	92	V	-	-	71	LG	MIRROR MOTOR (LH SIDEFRONTLOWWARD)	-	72	LG (POSITIONER UNIT)
93	BR	-	-	93	BR	-	-	73	LG	MIRROR MOTOR (LH SIDEFRONTUPWARD)	-	74	LG (POSITIONER UNIT)
94	Y	-	-	94	Y	-	-	75	LG	MIRROR MOTOR (LH SIDEFRONTDOWNWARD)	-	76	LG (POSITIONER UNIT)
95	G	-	-	95	G	-	-	77	LG	MIRROR MOTOR (LH SIDEFRONTLEFTWARD)	-	78	LG (POSITIONER UNIT)
96	Y	-	-	96	Y	-	-	79	LG	MIRROR MOTOR (LH SIDEFRONTRIGHTWARD)	-	80	LG (POSITIONER UNIT)
99	R	-	-	99	R	-	-	81	LG	MIRROR MOTOR (LH SIDEFRONTUPHIGHWARD)	-	82	LG (POSITIONER UNIT)
20	BR	-	-	20	BR	-	-	83	LG	MIRROR MOTOR (LH SIDEFRONTUPLOWWARD)	-	84	LG (POSITIONER UNIT)
21	SHEILD	-	-	21	SHEILD	-	-	85	LG	MIRROR MOTOR (LH SIDEFRONTBACKHIGHWARD)	-	86	LG (POSITIONER UNIT)
22	Y	-	-	22	Y	-	-	87	LG	MIRROR MOTOR (LH SIDEFRONTBACKLOWWARD)	-	88	LG (POSITIONER UNIT)
24	V	-	-	24	V	-	-	89	LG	MIRROR MOTOR (LH SIDEFRONTBACKUPWARD)	-	90	LG (POSITIONER UNIT)
27	S	-	-	27	S	-	-	91	LG	MIRROR MOTOR (LH SIDEFRONTBACKDOWNWARD)	-	92	LG (POSITIONER UNIT)
28	W	-	-	28	W	-	-	93	LG	MIRROR MOTOR (LH SIDEFRONTFRONTHIGHWARD)	-	94	LG (POSITIONER UNIT)
29	R	-	-	29	R	-	-	95	LG	MIRROR MOTOR (LH SIDEFRONTFRONTLOWWARD)	-	96	LG (POSITIONER UNIT)
31	L	-	-	31	L	-	-	97	LG	MIRROR MOTOR (LH SIDEFRONTFRONTUPWARD)	-	98	LG (POSITIONER UNIT)
32	P	-	-	32	P	-	-	99	LG	MIRROR MOTOR (LH SIDEFRONTFRONTDOWNWARD)	-	100	LG (POSITIONER UNIT)
33	SB	-	-	33	SB	-	-	101	LG	MIRROR MOTOR (LH SIDEFRONTFRONTUPHIGHWARD)	-	102	LG (POSITIONER UNIT)
34	L	-	-	34	L	-	-	103	LG	MIRROR MOTOR (LH SIDEFRONTFRONTUPLOWWARD)	-	104	LG (POSITIONER UNIT)
35	P	-	-	35	P	-	-	105	LG	MIRROR MOTOR (LH SIDEFRONTFRONTBACKHIGHWARD)	-	106	LG (POSITIONER UNIT)
36	L	-	-	36	L	-	-	107	LG	MIRROR MOTOR (LH SIDEFRONTFRONTBACKLOWWARD)	-	108	LG (POSITIONER UNIT)
37	P	-	-	37	P	-	-	109	LG	MIRROR MOTOR (LH SIDEFRONTFRONTBACKUPWARD)	-	110	LG (POSITIONER UNIT)
38	BR	-	-	38	BR	-	-	111	LG	MIRROR MOTOR (LH SIDEFRONTFRONTBACKDOWNWARD)	-	112	LG (POSITIONER UNIT)
39	Y	-	-	39	Y	-	-	113	LG	MIRROR MOTOR (LH SIDEFRONTFRONTFRONTHIGHWARD)	-	114	LG (POSITIONER UNIT)
44	L	-	-	44	L	-	-	115	LG	MIRROR MOTOR (LH SIDEFRONTFRONTFRONTLOWWARD)	-	116	LG (POSITIONER UNIT)

DOOR MIRROR SYSTEM

[WITH ADP]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	M021WP-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	S8	
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEER AMB CONT
8	V	ALL DOOR FUEL ID LOCK OUTPUT
9	G	DRIVER DOOR FUEL ID LOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
14	W	PUSH-BUTTON IGNITION SW/HLD
15	Y	ACC(IND)
17	W	TURN SIGNAL RH(FRONT)
18	BG	TURN SIGNAL LH(FRONT)
19	V	INT ROOM LAMP CONT

1	W	
2	W	POWER WINDOW POWER SUPPLY(BAT)
3	Y	POWER WINDOW POWER SUPPLY(BAT)

79	BR	ROOM ANT1+
80	GR	NATS ANT AMP.
81	W	
82	R	IGN RELAY/F/CONT
83	BR	KEYLESS ENTRY RECEIVER/COMM
87	Y	COMBI SW INPUTS
89	Y	COMBI SW INPUT3
90	P	
91	L	CAN-H
92	LG	KEY SLOT/ILL CONT
93	V	ON IND
94	Y	PUDDLE LAMP CONT
95	BG	ACC RELAY/CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	G	DRIVER DOOR REQUEST SW
102	BG	BLOWOFF FAN/MOTOR/RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER/POWER SUPPLY
107	LG	COMBI SW INPUT1
108	R	COMBI SW INPUT4
109	Y	COMBI SW INPUT2
110	G	HAZARD SW
	BG	

93	W	
94	Y	
95	BG	
96	GR	
99	R	
100	G	
101	G	
102	BG	
103	LG	
107	LG	
108	R	
109	Y	
110	G	

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

JRLWE4789GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

Wiring Diagram - INSIDE MIRROR SYSTEM -

INFOID:0000000007459419

PM : With automatic drive positioner
OP : Without automatic drive positioner

INSIDE MIRROR



2009/07/16

JCLWA3671GB


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH ADP]

INSIDE MIRROR


Connector No.	M1
Connector Name	FUSE BLOCK (f/8)
Connector Type	NS36FW-M2



Terminal Color Of No.	Wire To Wire	Signal Name [Specification]
1	G	-
2	SHIELD	-
3	L	-
4	BR	-[With automatic drive positioner] -[Without automatic drive positioner]
5	W	-
6	G	-
7	BR	-
8	V	-
9	B	-
10	Y	-
11	V	-
12	BR	-
13	R	-
14	W	-
15	SHIELD	-
16	B	-
17	Y	-
18	BR	-
19	W	-
20	G	-




Connector No.	M2
Connector Name	FUSE BLOCK (f/8)
Connector Type	NS30FW-CS



Terminal Color Of No.	Wire To Wire	Signal Name [Specification]
1	G	-
2	SHIELD	-
3	L	-
4	W	-
5	Y	-
6	BR	-
7	BR	-
8	Y	-
9	B	-
10	R	-
11	V	-
12	LG	-
13	R	-[With NAVI] -[Without NAVI]
14	V	-
15	SHIELD	-
16	BR	-[Without NAVI] -[With NAVI]
17	B	-
18	V	-



Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



JRLWE4872GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

ECU DIAGNOSIS INFORMATION DRIVER SEAT CONTROL UNIT

Reference Value

INFOID:000000007773689

VALUES ON THE DIAGNOSIS TOOL

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
SET SW	Set switch	Push
		Release
MEMORY SW1	Memory switch 1	Push
		Release
MEMORY SW2	Memory switch 2	Push
		Release
SLIDE SW-FR	Sliding switch (front)	Operate
		Release
SLIDE SW-RR	Sliding switch (rear)	Operate
		Release
RECLN SW-FR	Reclining switch (front)	Operate
		Release
RECLN SW-RR	Reclining switch (rear)	Operate
		Release
LIFT FR SW-UP	Lifting switch front (up)	Operate
		Release
LIFT FR SW-DN	Lifting switch front (down)	Operate
		Release
LIFT RR SW-UP	Lifting switch rear (up)	Operate
		Release
LIFT RR SW-DN	Lifting switch rear (down)	Operate
		Release
MIR CON SW-UP	Mirror switch	Up
		Other than above
MIR CON SW-DN	Mirror switch	Down
		Other than above
MIR CON SW-RH	Mirror switch	Right
		Other than above
MIR CON SW-LH	Mirror switch	Left
		Other than above
MIR CHNG SW-R	Changeover switch	Right
		Other than above
MIR CHNG SW-L	Changeover switch	Left
		Other than above
TILT SW-UP	Tilt switch	Up
		Other than above
TILT SW-DOWN	Tilt switch	Down
		Other than above

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DRIVER SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition		Value/Status
TELESCO SW-FR	Telescopic switch	Forward	ON
		Other than above	OFF
TELESCO SW-RR	Tilt switch	Backward	ON
		Other than above	OFF
DETENT SW	AT selector lever	P position	OFF
		Other than above	ON
STARTER SW	Ignition position	Cranking	ON
		Other than above	OFF
SLIDE PULSE	Seat sliding	Forward	The numeral value decreases * ¹
		Backward	The numeral value increases * ¹
		Other than above	No change to numeral value * ¹
RECLN PULSE	Seat reclining	Forward	The numeral value decreases * ¹
		Backward	The numeral value increases * ¹
		Other than above	No change to numeral value * ¹
LIFT FR PULSE	Seat lifter (front)	Up	The numeral value decreases * ¹
		Down	The numeral value increases * ¹
		Other than above	No change to numeral value * ¹
LIFT RR PULSE	Seat lifter (rear)	Up	The numeral value decreases * ¹
		Down	The numeral value increases * ¹
		Other than above	No change to numeral value * ¹
MIR/SEN RH U-D	Door mirror (passenger side)	Change between 3.4 (close to peak) 0.6 (close to valley)	
MIR/SEN RH R-L	Door mirror (passenger side)	Change between 3.4 (close to left edge) 0.6 (close to right edge)	
MIR/SEN LH U-D	Door mirror (driver side)	Change between 3.4 (close to peak) 0.6 (close to valley)	
MIR/SEN LH R-L	Door mirror (driver side)	Change between 0.6 (close to left edge) 3.4 (close to right edge)	
TILT SEN	Tilt position	Change between 1.2 (close to top) 3.4 (close to bottom)	
TELESCO SEN	Telescopic position	Change between 3.4 (close to top) 0.8 (close to bottom)	

*¹: The value at the position attained when the battery is connected is regarded as 32768.

TERMINAL LAYOUT






PHYSICAL VALUES

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx)
+	-		Signal name	Input/Output		
1	Ground	L/W	UART communication (RX)	Input	Ignition switch ON	 2mSec/div
3	—	R/Y	CAN-H	—	—	—
9	Ground	W/G	Reclining sensor signal	Input	Seat reclining	Operate
						 10mSec/div
10	Ground	P/B	Lifting sensor (rear) signal	Input	Seat lifting (rear)	Operate
						 10mSec/div
11	Ground	BR	Sliding switch backward signal	Input	Sliding switch	Operate (backward)
						0
12	Ground	SB	Reclining switch backward signal	Input	Reclining switch	Operate (backward)
						0
13	Ground	LG/R	Lifting switch (front) down signal	Input	Lifting switch (front)	Operate (down)
						0
14	Ground	G/B	Lifting switch (rear) down signal	Input	Lifting switch (rear)	Operate (down)
						0
16	Ground	O	Sensor power supply	Output	—	5
17	Ground	Y/R	UART communication (TX)	Output	Ignition switch ON	 10mSec/div
19	—	V	CAN-L	—	—	—

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N



O

P

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx)					
+	-		Signal name	Input/ Output							
21	Ground	L/Y	Detention switch	Input	A/T selector lever	P position					
						0					
24	Ground	R	Sliding sensor signal	Input	Seat sliding	Except P position					
						 20mSec/div 5V/div					
25	Ground	Y/B	Lifting sensor (front) signal	Input	Seat lifting (front)	Operate					
						 10mSec/div 2V/div					
26	Ground	Y	Sliding switch forward signal	Input	Sliding switch	Stop					
						0 or 5					
27	Ground	R/G	Reclining switch forward signal	Input	Reclining switch	Operate (forward)					
						Battery voltage					
28	Ground	W/B	Lifting switch (front) up signal	Input	Seat lifting switch (front)	Release					
						0 or 5					
29	Ground	P/L	Lifting switch (rear) up signal	Input	Seat lifting switch (rear)	Operate (up)					
						Battery voltage					
31	Ground	GR	Sensor ground	—	—	0					
32	Ground	B/W	Ground (signal)	—	—	0					
33	Ground	R	Power source (C/B)	Input	—	Battery voltage					
35	Ground	W/R	Sliding motor forward output signal	Output	Seat sliding	Operate (forward)					
						Battery voltage					
36	Ground	G/Y	Reclining motor forward output signal	Output	Seat reclining	Release					
						0					
Operate (forward)						Battery voltage					
						0					
Operate (forward)						Battery voltage					
						0					

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx)
+	-		Signal name	Input/ Output			
37	Ground	G/W	Lifting motor (front) down output signal	Output	Seat lifting (front)	Operate (down)	Battery voltage
						Stop	0
38	Ground	L/Y	Lifting motor (rear) up output signal	Output	Seat lifting (rear)	Operate (up)	Battery voltage
						Stop	0
39	Ground	R/B	Lifting motor (rear) down output signal	Output	Seat lifting (rear)	Operate (down)	Battery voltage
						Stop	0
40	Ground	R/W	Power source (Fuse)	Input	—		Battery voltage
42	Ground	W/B	Sliding motor backward output signal	Output	Seat sliding	Operate (back-ward)	Battery voltage
						Stop	0
44	Ground	P	Reclining motor backward output signal	Output	Seat reclining	Operate (back-ward)	Battery voltage
						Stop	0
45	Ground	L/R	Lifting motor (front) up output signal	Output	Seat lifting (front)	Operate (up)	Battery voltage
						Stop	0
48	Ground	B	Ground (power)	—	—		0

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

DRIVER SEAT CONTROL UNIT


[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:000000007773690

AUTOMATIC DRIVE POSITIONER




DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

NV : With NAVI




JCJWA1316GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JCJWA1317GB

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

* : This connector is not shown in "Harness Layout".



JCJWA1318GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
MIR

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B1	Signal Name [Specification]
Connector Name	WIRE TO WIRE	
Connector Type	THB80WW CS16-TMA4	
		
60	P	-
61	L	-
62	SHIELD	-
63	R	-
64	G	-
65	SHIELD	-
66	W	-
67	V	-
68	SB	-
69	SHIELD	-
70	W	-
73	SB	-
74	L	-
75	W	-
76	BR	-
77	R	-
78	O	-
79	GR	-
83	BS	-
85	V	-
86	LG	-
87	Y	-
88	R	-
89	B	-
90	BG	-
91	G	-
92	BR	-
93	G	-
94	SB	-
95	G	-
96	Y	-
98	W	-
99	GR	-

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1	LG	1	LG
2	SB	2	Y
3	-	3	LG
4	R	4	-
5	W	5	W
6	G	6	-
7	LG	7	LG
8	B	8	B
14	BR	14	BR
15	B	15	BR
17	W	16	GR
18	S8	16	GR
19	LG	21	G
20	BR	22	B
21	SHIELD	23	SHIELD
22	I	24	BS
23	P	25	Y
24	P	27	W
27	B	28	R
28	R	29	L
29	W	30	SHIELD
30	SHIELD	31	W
31	SHIELD	32	W
32	W	33	S8
33	S8	34	L
34	L	35	P
35	P	36	L
36	L	37	P
37	P	38	BR
38	BR	39	Y
39	Y	44	Y
44	Y	45	GR
45	GR	46	LG
46	LG	47	S8
47	S8	49	G
49	G	50	V

Terminal Color Of Wire No.	Signal Name [Specification]
2	-

JRJWC9329GB

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B46	Connector No.	B451
Connector Name	ROUND VIEW MONITOR CONTROL UNIT	Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH40W NNH	Connector Type	TH32NW



Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 B	GND	1 L/W	RX
2 Y	BATTERY	3 R/Y	CANH
3 P	IGNITION SIGNAL	9 W/G	PULSE (RECLINING)
4 GR	ACC	10 P/B	PULSE (R/LIFTING)
5 EG	ILLUMINATION SIGNAL	11 BR	SLIDING SW (BACKWARD)
6 SB	VEHICLE SPEED SIGNAL (8-PULSE)	12 SB	RECLINING SW (BACKWARD)
7 V	REVERSE SIGNAL	13 LG/R	FRONT LIFTING SW (DOWNWARD)
9 V	CONTROL SIGNAL	14 G/B	REAR LIFTING SW (DOWNWARD)
13 B	CONTROL SIGNAL	16 O	VCC
17 SB	AV COMM(H)	17 Y/R	TX
18 L/G	AV COMM(L)	19 V	CANL
21 SB	AV COMM(H)	21 LY	P RANGE SW
22 L/G	AV COMM(L)	24 R	PULSE (SLIDING)
23 L/G	AUXILIARY INFRARED LED (L)	25 V/B	PULSE (FLIFTING)
24 G	AUXILIARY INFRARED LED (C)	26 Y	SLIDING SW (FORWARD)
27 W	CAMERA IMAGE SIGNAL	27 R/G	RECLINING SW (FORWARD)
28 SHIELD	CAMERA IMAGE SIGNAL GRID	28 W/B	FRONT LIFTING SW (UPWARD)
29 Y	SIDE CAMERA RH IMAGE SIGNAL	29 P/L	REAR LIFTING SW (UPWARD)
30 G	SIDE CAMERA RH IMAGE GRID	31 GR	SENSOR GND
31 SHIELD	SIDE CAMERA RH GRID	32 BW	GRID (SIGNAL)
32 B	SIDE CAMERA RH COMM		
33 W	SIDE CAMERA RH POWER SUPPLY		
34 R	SIDE CAMERA RH POWER SUPPLY		
35 L	REAR CAMERA COMM		
36 BR	REAR CAMERA POWER SUPPLY		
37 SHIELD	SHIELD		
38 R	REAR CAMERA GND		
39 Y	REAR CAMERA IMAGE SIGNAL		
40 W	REAR CAMERA IMAGE END		

Connector No.	B46	Connector No.	B452
Connector Name	ROUND VIEW MONITOR CONTROL UNIT	Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH40W NNH	Connector Type	NS16FW-CS



Connector No.	B451	Connector No.	B452
Connector Name	DRIVER SEAT CONTROL UNIT	Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32NW	Connector Type	NS16FW-CS



Connector No.	B454	Connector No.	B454
Connector Name	RECLINING MOTOR	Connector Name	RECLINING MOTOR
Connector Type	NS16FW-CS	Connector Type	NS16FW-CS



Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 L/W	RX	33 R	BAT (CB)
3 R/Y	CANH	35 W/R	SLIDING MOTOR (FORWARD)
9 W/G	PULSE (RECLINING)	36 G/Y	RECLINING MOTOR (FORWARD)
10 P/B	PULSE (R/LIFTING)	37 G/W	FRONT LIFTING MOTOR (DOWNWARD)
11 BR	SLIDING SW (BACKWARD)	38 LY	REAR LIFTING MOTOR (UPWARD)
12 SB	RECLINING SW (BACKWARD)	39 R/B	REAR LIFTING MOTOR (BACKWARD)
13 LG/R	FRONT LIFTING SW (DOWNWARD)	40 R/W	SLIDING MOTOR (BACKWARD)
14 G/B	REAR LIFTING SW (DOWNWARD)	42 W/B	SLIDING MOTOR (FORWARD)
16 O	VCC	44 P	P RECLINING MOTOR (BACKWARD)
17 Y/R	TX	45 L/R	L/R FRONT LIFTING MOTOR (UPWARD)
19 V	CANL	48 B	GND (POWER)

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
33 R	BAT (CB)	35 G/Y	SLIDING MOTOR (FORWARD)
36 G/Y	RECLINING MOTOR (FORWARD)	37 G/W	FRONT LIFTING MOTOR (DOWNWARD)
38 LY	REAR LIFTING MOTOR (UPWARD)	39 R/B	REAR LIFTING MOTOR (BACKWARD)
40 R/W	SLIDING MOTOR (BACKWARD)	42 W/B	SLIDING MOTOR (FORWARD)
44 P	P RECLINING MOTOR (BACKWARD)	45 L/R	L/R FRONT LIFTING MOTOR (UPWARD)
48 B	GND (POWER)		

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
33 R	BAT (CB)	35 G/Y	FRONT LIFTING MOTOR (DOWNWARD)
36 G/Y	RECLINING MOTOR (FORWARD)	37 G/W	REAR LIFTING MOTOR (UPWARD)
38 LY	REAR LIFTING SW (DOWNWARD)	39 R/B	SLIDING MOTOR (BACKWARD)
40 R/W	SLIDING MOTOR (FORWARD)	42 W/B	SLIDING MOTOR (FORWARD)
44 P	P RECLINING MOTOR (BACKWARD)	45 L/R	L/R FRONT LIFTING MOTOR (UPWARD)
48 B	GND (POWER)		

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
33 R	BAT (CB)	35 G/Y	FRONT LIFTING MOTOR (DOWNWARD)
36 G/Y	RECLINING MOTOR (FORWARD)	37 G/W	REAR LIFTING MOTOR (UPWARD)
38 LY	REAR LIFTING SW (DOWNWARD)	39 R/B	SLIDING MOTOR (BACKWARD)
40 R/W	SLIDING MOTOR (FORWARD)	42 W/B	SLIDING MOTOR (FORWARD)
44 P	P RECLINING MOTOR (BACKWARD)	45 L/R	L/R FRONT LIFTING MOTOR (UPWARD)
48 B	GND (POWER)		

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
33 R	BAT (CB)	35 G/Y	FRONT LIFTING MOTOR (DOWNWARD)
36 G/Y	RECLINING MOTOR (FORWARD)	37 G/W	REAR LIFTING MOTOR (UPWARD)
38 LY	REAR LIFTING SW (DOWNWARD)	39 R/B	SLIDING MOTOR (BACKWARD)
40 R/W	SLIDING MOTOR (FORWARD)	42 W/B	SLIDING MOTOR (FORWARD)
44 P	P RECLINING MOTOR (BACKWARD)	45 L/R	L/R FRONT LIFTING MOTOR (UPWARD)
48 B	GND (POWER)		

JRJWC9330GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
MIR

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B456	Connector No.	B460
Connector Name	LIFTING MOTOR (REAR)	Connector Name	WIRE TO WIRE
Connector Type	NS506BRCS	Connector Type	NS16AW-CS

H.S.

H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
21	GP	-
35	U/I	-
39	R/B	-

H.S.

H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/W	-	1	R	-
3	BY	-	2	B	-
17	Y/R	-	4	W	-
19	V	-	5	L	-
21	LY	-	6	O	-
32	B/W	-	7	GR	-
33	R	-	8	W	-
40	R/W	-	9	O	-
48	B	-	10	BR	-
60	Y/R	-	11	P	-
66	B	-	12	LG	-
67	L	-	13	Y	-
			14	Y	-
			15	W	-
			16	R	-
			17	W	-
			18	G	-
			19	Y	-
			20	W	-
			21	O	-
			22	P	-
			23	BR	-
			24	Y	-
			25	GR	-
			26	Y	-
			27	B	-
			28	SHELD	-
			29	LG	-
			30	G	-
			31	W	-
			32	G	-
			33	L	-
			34	S	-
			35	R	-
			36	LG	-

H.S.

H.S.

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Connector No.	D31	Connector No.	D33
23	Y	Connector Name	-	Connector Name	DOOR MIRROR (PASSENGER SIDE)
24	V	Connector Type	TH40WW-CS15	Connector Type	TH40WW-NH
Connector No.	DS	Connector Name	SEAT MEMORY SWITCH	Terminal No.	Color Of Wire
Connector Type	AUBFW			1	W
				2	GR
				3	Y
				4	BR
				5	BG
				6	S.B
				7	LG
				8	RG
				9	SG
				10	GD
				11	RD
				12	RD
				13	LG
				14	R
				15	P
				16	V
				17	SB
				18	V
				19	-
				20	BG
				21	L
				22	V
				23	G
				24	P
				25	Y
				26	W
				27	W
				28	G
				29	BG
				30	BR
				31	BR
				32	W
				33	B
				34	R
				35	G
				36	SHIELD
				37	V
				38	BR
				39	BG
				40	W
				41	W
				42	G
				43	BR
				44	W
				45	L
				46	P
				47	LG
				48	W
				49	W
				50	P
				51	LG
				52	BR
				53	W
				54	LG
				55	W
				56	BR
				57	W
				58	LG
				59	W
				60	LG
				61	G
				62	SB
				63	W
				64	B
				65	G
				66	R
				67	SHIELD
				68	Y
				69	LG
				70	-
				71	-
				72	-
				73	-
				74	-
				75	-
				76	-
				77	-
				78	-
				79	-
				80	-
				81	-
				82	-
				83	-
				84	-
				85	-
				86	-
				87	-
				88	-
				89	-
				90	-
				91	-
				92	-
				93	-
				94	-
				95	-
				96	-
				97	-
				98	-
				99	-
				100	-
				101	-
				102	-
				103	-
				104	-
				105	-
				106	-
				107	-
				108	-
				109	-
				110	-
				111	-
				112	-
				113	-
				114	-
				115	-
				116	-
				117	-
				118	-
				119	-
				120	-
				121	-
				122	-
				123	-
				124	-
				125	-
				126	-
				127	-
				128	-
				129	-
				130	-
				131	-
				132	-
				133	-
				134	-
				135	-
				136	-
				137	-
				138	-
				139	-
				140	-
				141	-
				142	-
				143	-
				144	-
				145	-
				146	-
				147	-
				148	-
				149	-
				150	-
				151	-
				152	-
				153	-
				154	-
				155	-
				156	-
				157	-
				158	-
				159	-
				160	-
				161	-
				162	-
				163	-
				164	-
				165	-
				166	-
				167	-
				168	-
				169	-
				170	-
				171	-
				172	-
				173	-
				174	-
				175	-
				176	-
				177	-
				178	-
				179	-
				180	-
				181	-
				182	-
				183	-
				184	-
				185	-
				186	-
				187	-
				188	-
				189	-
				190	-
				191	-
				192	-
				193	-
				194	-
				195	-
				196	-
				197	-
				198	-
				199	-
				200	-
				201	-
				202	-
				203	-
				204	-
				205	-
				206	-
				207	-
				208	-
				209	-
				210	-
				211	-
				212	-
				213	-
				214	-
				215	-
				216	-
				217	-
				218	-
				219	-
				220	-
				221	-
				222	-
				223	-
				224	-
				225	-
				226	-
				227	-
				228	-
				229	-
				230	-
				231	-
				232	-
				233	-
				234	-
				235	-
				236	-
				237	-
				238	-
				239	-
				240	-
				241	-
				242	-
				243	-
				244	-
				245	-
				246	-
				247	-
				248	-
				249	-
				250	-
				251	-
				252	-
				253	-
				254	-
				255	-
				256	-
				257	-
				258	-
				259	-
				260	-
				261	-
				262	-
				263	-
				264	-
				265	-
				266	-
				267	-
				268	-
				269	-
				270	-
				271	-
				272	-
				273	-
				274	-
				275	-
				276	-
				277	-
				278	-
				279	-
				280	-
				281	-
				282	-
				283	-
				284	-
				285	-
				286	-
				287	-
				288	-
				289	-
				290	-
				291	-
				292	-
				293	-
				294	-
				295	-
				296	-
				297	-
				298	-
				299	-
				300	-
				301	-
				302	-
				303	-
				304	-
				305	-
				306	-
				307	-
				308	-
				309	-
				310	-
				311	-
				312	-
				313	-
				314	-
				315	-
				316	-
				317	-
				318	-
				319	-
				320	-
				321	-
				322	-
				323	-
				324	-
				325	-
				326	-
				327	-
				328	-

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	BR	-
4	P	-
5	L	-
6	R	-
7	R	-
8	W	-
9	W	-
10	L	-
11	G	-
12	V	-
13	B	-
14	Y	-
15	W	-
16	R	-
17	B	-
18	G	-
19	Y	-
20	L	-
21	LG	-
22	L	-
23	G	-
24	G	-

卷之三

Connector No.	Connector Name	Connector Type	Terminal No.	Color Of Wire	Signal Name [Specification]
M1	FUSE BLOCK (J/FB)		1A	G	-
			2A	G	-
			3A	L	-
			4A	P	-
			5A	V	-
			6A	Y	-
			7A	R	-
			8A	L	-

100

Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]
F51	1	Y	-
Connector Name A/T ASSEMBLY	2	BR	-
	3	L	-
Connector Type RWD10G-DGY	4	V	-
	5	B	-
	6	Y	-
	7	R	-
	8	P	-
	9	GR	-
	10	BL	-

Connector No.	F301	Terminal No.	Color Of Wire	Signal Name [Specification]
Connector Name	TCM (TRANSMISSION CONTROL MODULE)	1	-	VIGN
Connected Type	SMD10G	2	-	BATT
		3	-	CAN-H
		4	-	KLINE
		5	-	GROUND
		6	-	VIGN
		7	-	REV/AMBIENT
		8	-	CAN-L
		9	-	START/BLD
		10	-	MONITOR

GROUND

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Wire To Wire
25 GR	-	71 LG	-
26 R	-	72 Y	-
27 W	-	73 SB	-
28 SHIELD	-	74 BR	-
29 Y	-	75 L	-
30 Y	-	76 G	-
31 R	-	77 GR	-
32 BR	-	78 P	-
33 SB	-	79 -	-
34 Y	-	80 -	-
35 P	-	81 SB	-
36 LG	-	82 SB	-
37 BR	-	83 V	-
38 P	-	84 G	-
39 EG	-	85 L	-
40 SB	-	86 P	-
41 L	-	87 W	-
42 R	-	88 GR	-
43 ER	-	89 SHIELD	-
44 V	-	90 W	-
45 G	-	91 W	-
46 SB	-	92 Y	-
47 V	-	93 BR	-
48 P	-	94 P	-
49 R	-	95 GR	-
50 B	-	96 W	-
52 R	-	97 L	-
53 V	-	98 SHIELD	-
54 LG	-	99 V	-
55 SB	-	100 SB	-

JRJWC9334GB

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Connector No.	M62	BG	ECU SIGNAL
No.	Wire	Connector Name	CIRCUIT BREAKER	L	A/C CAN SIGNAL
18	P	Connector Name	MIRROR SELECT SW (LH)		
19	S8	Connector Type	MIRROR SW (DOWNWARD)		
20	BR		MIRROR SW (RIGHTWARD)		
21	L		MIRROR SENSOR(LH HORIZONTAL)	R	EACH DOOR MOTOR POWER SUPPLY
22	G		MIRROR SENSOR(LH HORIZONTAL)	B	GROUND
23	P		TELESCOPIC SENSOR	P	CAN-L
24	R		SET SW		
25	S8		AUDIOES2		
26	Y		RX(UART)		
27	G		TELESCOPIC SW(BACKWARD)		
30	R		MIRROR MOTOR(RH COMMON)		
31	LG		MIRROR MOTOR(LH VERTICAL)		
32	L		MIRROR MOTOR(LH HORIZONTAL)		
AUTOMATIC DRIVE POSITIONER CONTROL UNIT		Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Terminal No.	Wire	Connector No.	M67	Connector Name	UNIFIED METER AND A/C AMP.
1	W	Connector Type	TH321W-NH	1	GROUND
2	SB			3	B
				4	V
				5	ACC
				6	R
				7	ILL
				8	Y
				9	IL CONT
				10	SB
				11	AV COMM(H)
				12	AV COMM(L)
				13	SW END
				14	DSE ELECT SIGNAL
				15	HAZARD ON
				16	G
POWER SUPPLY (SENSOR)		Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Terminal No.	Wire	Connector No.	M62	Connector Name	UNIFIED METER AND A/C AMP.
33	R	Connector Type	NS16FW-CS	1	GROUND
34	R			2	ACC POWER SUPPLY
35	L			3	FUEL LEVEL SWITCH SIGNAL
36	GR			4	INTAKE SENSOR SIGNAL
39	S8			5	INVEHICLE SENSOR SIGNAL
40	B			6	AMBIENT SENSOR SIGNAL
41	Y			7	SUNLOAD SENSOR SIGNAL
42	EG			8	TELESCOPIC MOTOR(BACKWARD)
44	G			9	TELESCOPIC MOTOR(FORWARD)
45	G			10	TILT MOTOR(DOWNWARD)
46	EG			11	TILT MOTOR(UPWARD)
48	B			12	IGNITION POWER
53	G			13	IGNITION POWER SUPPLY
54	Y			14	BATTERY POWER SUPPLY
55	B			15	GROUND
56	L			16	IGNITION GND
57	W			17	BRAKE FLUID LEVEL SWITCH SIGNAL
58	BR			18	FUEL LEVEL SENSOR GROUND
59	GR			19	INTAKE SENSOR GROUND
60	L			20	INVEHICLE SENSOR GROUND
61	BR			21	AMBIENT SENSOR GROUND
62	SB			22	SUNLOAD SENSOR GROUND
63	R			23	TELESCOPIC MOTOR GROUND

JRJWC9336GB

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER


Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
79	BR	ROOM ANTI+	138	Y	RECEIVER SENSOR POWER SUPPLY
80	GR	ANTI AMP	139	L	TIRE PRESSURE RECEIVER COMM
81	W	ANTI AMP	140	GR	SHIFT/NP
82	R	IGN RELAY/EBL/CONT	141	G	SECURITY IND/LAMP/CONT
83	Y	KEYLESS ENTRY RECEIVER COMM	142	BG	COMBISW OUTPUT 5
87	BR	COMBI SW INPUTS	143	P	COMBISW OUTPUT 1
88	Y	COMBI SW INPUT 3	144	G	COMBISW OUTPUT 2
90	P	CARH	145	L	COMBISW OUTPUT 3
91	L	CARH+1	146	W	COMBISW OUTPUT 4
92	LG	KEY SLOT/CONT	148	SB	DRIVEDOOR SW
93	V	ON IND	150	LG	REAR WINDOW DEFROGER RELAY CONT
94	Y	PUDDLE LAMP CONT	151	G	REAR WINDOW DEFROGER RELAY SW
95	GR	ACC/DELAY CONT	152	R	-
99	R	SHIFT P	153	G	-
100	G	PASSENGER DOOR REQUEST SW	154	W	-
101	GR	DRIVER DOOR REQUEST SW	155	BG	-
102	BG	BLOWVENT/VENT/ON/RELAY	156	Y	-
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	157	Y	-
107	LG	COMBI SW INPUT 1	158	R	-
108	R	COMBI SW INPUT 4	159	Y	COMBI SW INPUT 2
110	G	HAZARD SW	160	G	-

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
32	G	-	33	BR	-
34	V	-	35	G	-
43	L	-	44	Y	-
45	W	-	46	Y	-
47	LG	-	48	BR	-
49	W	-	50	G	-
51	Y	-	52	Y	COMM(DIP-CONT)
53	LG	-	54	W	RGB AREA(TS) SIGNAL
55	BG	-	56	P	RGB SYNC
			57	SHIELD	RGB(R/RED) SIGNAL
			58	SHIELD	RGB(G/GREEN) SIGNAL
			59	SHIELD	RGB(B/BLUE) SIGNAL
			60	SHIELD	RGB IMAGE SIGNAL GND
			61	SHIELD	COMPOSITE IMAGE SIGNAL GND
			62	SHIELD	INVERTER(CC)
			63	SHIELD	INVERTER(BD)
			64	SHIELD	WP
			65	SHIELD	COMM(CONT-DISF)
			66	SHIELD	SHIELD



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-	2	V	-
3	L	-	4	B	-
5	G	-	6	SB	-
7	R	-	8	SB	-
9	B	-	10	GR	-
11	R	-			

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
12	L	-	13	V	-
14	B	-	15	W	-
16	BR	-	17	B	-
17	B	-	18	R	-
19	B	-	20	W	(Without BOSE audio)
21	Y	-	22	G	- (With BOSE audio)
23	SB	DR DOOR UNLOCK SENSOR	24	SB	- (Without BOSE audio)
25	GR	KEY SLOT SW	26	Y	- (With BOSE audio)
27	IGN/F/B	-	28	BR	-
29	SHIELD	-	30	W	-
31	LG	RECEIVERSENSOR GND			



JRJWC9337GB

DRIVER SEAT CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

J

K

MIR


M

N

O

P

AUTOMATIC DRIVE POSITIONER	
Terminal No.	Color Of Wire
76	LG
77	SB
78	LG
79	SG
80	P
81	L
82	B
85	SHIELD
87	L
88	P
92	R
93	V
94	EG
95	G
96	T
	SHIELD
	TEL VOICE SIGNAL (+)
	TEL VOICE SIGNAL (-)
	VEHICLE SPEED SIGNAL (8-PULSE)
	PARKING BRAKE SIGNAL
	REVERSE SIGNAL
	IGNITION SIGNAL
	DISK EFFECT SIGNAL



AUTOMATIC DRIVE POSITIONER	
Terminal No.	Color Of Wire
65	V
67	G
68	R
71	SHIELD
72	R
73	R
74	P
75	LG
76	LG
79	R
80	G
81	EG
82	B
83	SHIELD
87	G
88	SHIELD
89	G
	CAN/H
	AV COMM(H)
	AV COMM(H)
	AV COMM(L)
	AV COMM(L)
	AV COMM(L)
	CAN/L
	SW/GND
	SHIELD
	TELEPHONE SIGNAL (+)
	TELEPHONE SIGNAL (-)
	VEHICLE SPEED SIGNAL (8-PULSE)
	PARKING BRAKE SIGNAL
	REVERSE SIGNAL
	IGNITION SIGNAL
	DISK EFFECT SIGNAL
	COM(M(CONT->DISP))
	CAN/L
	AV COMM(L)
	AV COMM(L)
	ILLUMINATION
	IGNITION SIGNAL
	REVERSE SIGNAL
	VEHICLE SPEED SIGNAL (8-PULSE)
	SHIELD
	MICROPHONE SIGNAL
	SHIELD
	COMM(DISP-CONT)

JRJWC9338GB

INFOID:0000000007773691

Fail Safe

The fail-safe mode may be activated if the following symptoms are observed.

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Operating in fail-safe mode	Malfunction Item	Related DTC	Diagnosis
Only manual functions operate normally.	CAN communication	U1000	ADP-44
	Tilt sensor	B2118	ADP-49
	Telescopic sensor	B2119	ADP-52
	Detention switch	B2126	ADP-55
Only manual functions, except door mirror, operate normally.	UART communication	B2128	ADP-57
Only manual functions, except seat sliding, operate normally.	Seat sliding output	B2112	ADP-45
Only manual functions, except seat reclining, operate normally.	Seat reclining output	B2113	ADP-47

DTC Index

INFOID:000000007773692

CONSULT display	Timing ^{*1}		Item	Reference page
	Current mal-function	Previous mal-function		
CAN COMM CIRCUIT [U1000]	0	1-39	CAN communication	ADP-44
SEAT SLIDE [B2112]	0	1-39	Seat slide motor output	ADP-45
SEAT RECLINING [B2113]	0	1-39	Seat reclining motor output	ADP-47
TILT SENSOR [B2118]	0	1-39	Tilt sensor input	ADP-49
TELESCO SENSOR [B2119]	0	1-39	Telescopic sensor input	ADP-52
DETENT SW [B2126]	0	1-39	Detention switch condition	ADP-55
UART COMM [B2128]	0	1-39	UART communication	ADP-57

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value

INFOID:0000000007773698


TERMINAL LAYOUT



JMJA0199ZZ

PHYSICAL VALUES

Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)
		Signal name	Input/Out-put		
1	Ground	Y	Tilt switch up signal	Input	Operate (up)
2	Ground	LG	Changeover switch RH signal	Input	Other than above
3	Ground	G	Mirror switch up signal	Input	RH
4	Ground	V	Mirror switch left signal	Input	Neutral or LH
5	Ground	R	Door mirror sensor (RH) up/down signal	Input	Operated (up)
6	Ground	GR	Door mirror sensor (LH) up/down signal	Input	Other than above
7	Ground	O	Tilt sensor signal	Input	Operated (left)
9	Ground	L	Memory switch 1 signal	Input	Other than above
10	Ground	V	UART communication (TX)	Output	Push



JMJA0118ZZ

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)
		+	-		
Signal name	Input/ Out- put				
11 Ground	GR	Telescopic switch forward signal	Input	Telescopic switch	Operate (forward)
					Other than above
12 Ground	O	Memory indictor 1 signal	Out- put	Memory indictor 1	Illuminate
					Other than above
13 Ground	P	Memory indictor 2 signal	Out- put	Memory indictor 2	Illuminate
					Other than above
14 Ground	W	Door mirror motor (RH) up output signal	Out- put	Door mirror RH	Operate (up)
					Other than above
15 Ground	G	Door mirror motor (RH) left output signal	Out- put	Door mirror RH	Operate (left)
					Other than above
16 Ground	Y	Door mirror motor (LH) down output signal	Out- put	Door mirror (LH)	Operate (down)
					Other than above
		Door mirror motor (LH) right output signal			Operate (right)
					Other than above
17 Ground	W	Tilt switch down signal	Input	Tilt switch	Operate (down)
					Other than above
18 Ground	P	Changeover switch LH signal	Input	Changeover switch position	LH
					Neutral or RH
19 Ground	SB	Mirror switch down signal	Input	Mirror switch	Operate (down)
					Other than above
20 Ground	BR	Mirror switch right signal	Input	Mirror switch	Operate (right)
					Other than above
21 Ground	L	Door mirror sensor (RH) left/right signal	Input	Door mirror RH position	
22 Ground	G	Door mirror sensor (LH) left/right signal	Input	Door mirror LH position	
23 Ground	P	Telescopic sensor signal	Input	Telescopic position	

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx.)		
+	-		Signal name	Input/Out-put					
24	Ground	R	Set switch signal	Input	Set switch	Push	0		
						Other than above	5		
25	Ground	SB	Memory switch 2 signal	Input	Memory switch 2	Push	0		
						Other than above	5		
26	Ground	Y	UART communication (RX)	Input	Ignition switch ON				
27	Ground	G	Telescopic switch backward signal	Input	Telescopic switch	Operate (back-ward)	0		
						Other than above	5		
30	Ground	R	Door mirror motor (RH) down output signal	Out-put	Door mirror (RH)	Operate (down)	Battery voltage		
			Door mirror motor (RH) right output signal			Other than above	0		
						Operate (right)	Battery voltage		
						Other than above	0		
31	Ground	LG	Door mirror motor (LH) up output signal	Out-put	Door mirror (LH)	Operate (up)	Battery voltage		
						Other than above	0		
32	Ground	L	Door mirror motor (LH) left output signal	Out-put	Door mirror (LH)	Operate (left)	Battery voltage		
						Other than above	0		
33	Ground	R	Sensor power supply	Input	—		5		
34	Ground	R	Power source (Fuse)	Input	—		Battery voltage		
35	Ground	L	Tilt motor up output signal	Out-put	Steering tilt	Operate (up)	Battery voltage		
						Other than above	0		
36	Ground	GR	Telescopic motor forward output signal	Out-put	Steering telescopic	Operate (forward)	Battery voltage		
						Other than above	0		
39	Ground	SB	Power source (C/B)	—	—		Battery voltage		
40	Ground	B	Ground	—	—		0		
41	Ground	Y	Sensor ground	—	—		0		

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)		
		Signal name	Input/ Out- put				
42	Ground	O	Tilt motor down output signal	Out- put	Operate (down)	Battery voltage	
					Other than above	0	
44	Ground	G	Telescopic motor backward output signal	Out- put	Steering tele- scopic	Operate (back- ward)	Battery voltage
						Other than above	0
48	Ground	B	Ground	—	—	—	0


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:0000000007773699



JCJWA1315GE

Revision: 2014 October

MIR-51


2012 EX

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

⟨NV⟩ : With NAVI




JCJWA1316GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JCJWA1317GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
MIR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



* : This connector is not shown in "Harness Layout".

JCJWA1318GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]


< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B1	
Connector Name	WIRE TO WIRE	
Connector Type	THB80WW-CS16-TM4	



Terminal Color Of Wire No.	Signal Name [Specification]
3 R	-
5 G	-
6 GR	-
7 V	-
8 L	-
12 SB	-
13 LG	-
14 GR	-
15 LG	-
17 W	-
18 SB	-
19 LG	-
20 BR	-
21 SHIELD	-
22 Y	-
24 P	-
27 B	-
28 R	-
29 W	-
30 SHIELD	-
31 SHIELD	-
32 W	-
33 SB	-
34 L	-
35 P	-
36 L	-
37 P	-
38 BR	-
39 Y	-
44 Y	-
45 GR	-
46 LG	-
47 SB	-
49 G	-
50 V	-



Connector No.	B5	
Connector Name	WIRE TO WIRE	
Connector Type	TH32WW-Nn1	



Terminal Color Of Wire No.	Signal Name [Specification]	Signal Name [Specification]
1 LG	-	-
2 SB	-	-
3 Y	-	-
4 R	-	-
5 W	-	-
6 G	-	-
7 LG	-	-
8 B	-	-
9 GR	-	-
10 SB	-	-
11 GR	-	-
12 SB	-	-
13 GR	-	-
14 SB	-	-
15 GR	-	-
16 P	-	-
17 GR	-	-
18 Y	-	-
19 L	-	-
20 BR	-	-
21 SHIELD	-	-
22 Y	-	-
23 GR	-	-
24 P	-	-
25 BR	-	-
26 Y	-	-
27 W	-	-
28 R	-	-
29 L	-	-
30 SHIELD	-	-
31 Y	-	-



Connector No.	B11	
Connector Name	WIRE TO WIRE	
Connector Type	NS16FW-CS	



Terminal Color Of Wire No.	Signal Name [Specification]	Signal Name [Specification]
1 G	-	-
2 V	-	-
3 GR	-	-
4 SB	-	-
5 BR	-	-
6 Y	-	-
7 P	-	-
8 L	-	-
9 W	-	-
10 GR	-	-
11 SB	-	-
12 BR	-	-
13 Y	-	-
14 P	-	-
15 L	-	-
16 W	-	-
17 GR	-	-
18 SB	-	-
19 BR	-	-
20 Y	-	-
21 P	-	-
22 L	-	-
23 W	-	-
24 GR	-	-
25 SB	-	-
26 BR	-	-
27 Y	-	-
28 P	-	-
29 L	-	-
30 SB	-	-
31 BR	-	-
32 Y	-	-
33 P	-	-
34 L	-	-
35 W	-	-
36 GR	-	-
37 SB	-	-
38 BR	-	-
39 Y	-	-
44 Y	-	-
45 GR	-	-
46 LG	-	-
47 SB	-	-
49 G	-	-
50 V	-	-



Terminal Color Of Wire No.	Signal Name [Specification]	Signal Name [Specification]
1 G	-	-
2 V	-	-
3 GR	-	-
4 SB	-	-
5 BR	-	-
6 Y	-	-
7 P	-	-
8 L	-	-
9 W	-	-
10 GR	-	-
11 SB	-	-
12 BR	-	-
13 Y	-	-
14 P	-	-
15 L	-	-
16 W	-	-
17 GR	-	-
18 SB	-	-
19 BR	-	-
20 Y	-	-
21 P	-	-
22 L	-	-
23 W	-	-
24 GR	-	-
25 SB	-	-
26 BR	-	-
27 Y	-	-
28 R	-	-
29 L	-	-
30 SB	-	-
31 BR	-	-
32 Y	-	-
33 P	-	-
34 L	-	-
35 W	-	-
36 GR	-	-
37 SB	-	-
38 BR	-	-
39 Y	-	-
44 Y	-	-
45 GR	-	-
46 LG	-	-
47 SB	-	-
49 G	-	-
50 V	-	-



Terminal Color Of Wire No.	Signal Name [Specification]	Signal Name [Specification]
1 G	-	-
2 V	-	-
3 GR	-	-
4 SB	-	-
5 BR	-	-
6 Y	-	-
7 P	-	-
8 L	-	-
9 W	-	-
10 GR	-	-
11 SB	-	-
12 BR	-	-
13 Y	-	-
14 P	-	-
15 L	-	-
16 W	-	-
17 GR	-	-
18 SB	-	-
19 BR	-	-
20 Y	-	-
21 P	-	-
22 L	-	-
23 W	-	-
24 GR	-	-
25 SB	-	-
26 BR	-	-
27 Y	-	-
28 R	-	-
29 L	-	-
30 SB	-	-
31 BR	-	-
32 Y	-	-
33 P	-	-
34 L	-	-
35 W	-	-
36 GR	-	-
37 SB	-	-
38 BR	-	-
39 Y	-	-
44 Y	-	-
45 GR	-	-
46 LG	-	-
47 SB	-	-
49 G	-	-
50 V	-	-



A B C D E F G H I K M N Z O P


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B46	Signal Name [Specification]
Connector Name	REARVIEW MONITOR CONTROL UNIT	GND
Connector Type	TH409W NH	AV(COMM)(L)



Terminal Color Of
No. Wire Signal Name [Specification]

1	B	GND
2	Y	BATTERY
3	P	IGNITION SIGNAL
4	GR	ACC
5	BS	ILLUMINATION SIGNAL
6	S8	VEHICLE SPEED SIGNAL(8-PULSE)
7	V	REVERSE SIGNAL
9	V	CONTROL SIGNAL
13	B	CONTROL SIGNAL
17	S8	AV(COMM)(H)
18	LG	AV(COMM)(L)
21	S8	AV(COMM)(L)
22	LG	AV(COMM)(L)
23	LG	AUXILIARY INFRARED(4)
24	G	AUXILIARY INFRARED(4)
27	W	CAMERA IMAGE SIGNAL
28	SHIELD	CAMERA IMAGE SIGNAL GND
29	Y	SIDE CAMERA RH IMAGE SIGNAL
30	G	SIDE CAMERA RH IMAGE GRID
31	SHIELD	SHIELD
32	B	SIDE CAMERA RH GND
33	W	SIDE CAMERA RH COMM
34	R	SIDE CAMERA RH POWER SUPPLY
35	L	Rear Camera COMM
36	BR	Rear Camera Power Supply
37	SHIELD	SHIELD
38	R	Rear Camera GND
39	Y	Rear Camera IMAGE SIGNAL
40	W	Rear Camera IMAGE END

Terminal Color Of
No. Wire Signal Name [Specification]

1	L/W	BAT(CB)
3	R/Y	CANH
9	P/G	PULSE RECLINING
10	P/B	PULSE (IN LIFTING)
11	BR	SLIDING SW(BACKWARD)
12	S8	RECLINING SW(BACKWARD)
13	LG/R	FRONT LIFTING SW(DOWNWARD)
14	G/B	REAR LIFTING SW(DOWNWARD)
16	O	TX
17	Y/R	CANL
19	V	P RANGE SW
21	L/Y	PULSE(SLIDING)
24	R	PULSE (LIFTING)
25	Y/B	SLIDING SW(FORWARD)
26	Y	RECLINING SW(FORWARD)
27	R/G	FRONT LIFTING SW(UPWARD)
28	W/B	REAR LIFTING SW(UPWARD)
29	P/L	SENSOR GND
31	GR	SENSOR GND
32	B/W	GND(SIGNAL)

Terminal Color Of
No. Wire Signal Name [Specification]

33	R	H.S.
----	---	------

Terminal Color Of
No. Wire Signal Name [Specification]

35	W/G	BAT(CB)
36	G/Y	RECLINING MOTOR(FORWARD)
37	G/W	FRONT LIFTING MOTOR(DOWNWARD)
38	U/Y	REAR LIFTING MOTOR(UPWARD)
39	R/B	REAR LIFTING MOTOR(BACKWARD)
40	R/W	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

42	W/B	BAT(FORWARD)
44	P	RECLINING MOTOR(BACKWARD)
45	L/R	FRONT LIFTING MOTOR(UPWARD)
48	B	GND(POWER)

Terminal Color Of
No. Wire Signal Name [Specification]

45	W/G	BAT(CB)
46	Y/B	RECLINING MOTOR(FORWARD)
47	G/Y	FRONT LIFTING MOTOR(UPWARD)
48	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

49	W/G	BAT(CB)
50	G/Y	RECLINING MOTOR(FORWARD)
51	G/W	FRONT LIFTING MOTOR(DOWNWARD)
52	U/Y	REAR LIFTING MOTOR(UPWARD)
53	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

54	R/W	BAT(CB)
55	Y/B	RECLINING MOTOR(FORWARD)
56	G/Y	FRONT LIFTING MOTOR(UPWARD)
57	R/B	REAR LIFTING MOTOR(BACKWARD)
58	L/R	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

59	W/G	BAT(CB)
60	G/Y	RECLINING MOTOR(FORWARD)
61	G/W	FRONT LIFTING MOTOR(DOWNWARD)
62	U/Y	REAR LIFTING MOTOR(UPWARD)
63	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

64	W/G	BAT(CB)
65	G/Y	RECLINING MOTOR(FORWARD)
66	G/W	FRONT LIFTING MOTOR(UPWARD)
67	U/Y	REAR LIFTING MOTOR(BACKWARD)
68	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

69	W/G	BAT(CB)
70	G/Y	RECLINING MOTOR(FORWARD)
71	G/W	FRONT LIFTING MOTOR(DOWNWARD)
72	U/Y	REAR LIFTING MOTOR(UPWARD)
73	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

74	W/G	BAT(CB)
75	G/Y	RECLINING MOTOR(FORWARD)
76	G/W	FRONT LIFTING MOTOR(UPWARD)
77	U/Y	REAR LIFTING MOTOR(BACKWARD)
78	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

79	W/G	BAT(CB)
80	G/Y	RECLINING MOTOR(FORWARD)
81	G/W	FRONT LIFTING MOTOR(DOWNWARD)
82	U/Y	REAR LIFTING MOTOR(UPWARD)
83	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

84	W/G	BAT(CB)
85	G/Y	RECLINING MOTOR(FORWARD)
86	G/W	FRONT LIFTING MOTOR(UPWARD)
87	U/Y	REAR LIFTING MOTOR(BACKWARD)
88	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

89	W/G	BAT(CB)
90	G/Y	RECLINING MOTOR(FORWARD)
91	G/W	FRONT LIFTING MOTOR(DOWNWARD)
92	U/Y	REAR LIFTING MOTOR(UPWARD)
93	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

94	W/G	BAT(CB)
95	G/Y	RECLINING MOTOR(FORWARD)
96	G/W	FRONT LIFTING MOTOR(UPWARD)
97	U/Y	REAR LIFTING MOTOR(BACKWARD)
98	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

99	W/G	BAT(CB)
100	G/Y	RECLINING MOTOR(FORWARD)
101	G/W	FRONT LIFTING MOTOR(DOWNWARD)
102	U/Y	REAR LIFTING MOTOR(UPWARD)
103	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

104	W/G	BAT(CB)
105	G/Y	RECLINING MOTOR(FORWARD)
106	G/W	FRONT LIFTING MOTOR(UPWARD)
107	U/Y	REAR LIFTING MOTOR(BACKWARD)
108	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

109	W/G	BAT(CB)
110	G/Y	RECLINING MOTOR(FORWARD)
111	G/W	FRONT LIFTING MOTOR(DOWNWARD)
112	U/Y	REAR LIFTING MOTOR(UPWARD)
113	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

114	W/G	BAT(CB)
115	G/Y	RECLINING MOTOR(FORWARD)
116	G/W	FRONT LIFTING MOTOR(UPWARD)
117	U/Y	REAR LIFTING MOTOR(BACKWARD)
118	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

119	W/G	BAT(CB)
120	G/Y	RECLINING MOTOR(FORWARD)
121	G/W	FRONT LIFTING MOTOR(DOWNWARD)
122	U/Y	REAR LIFTING MOTOR(UPWARD)
123	R/B	REAR LIFTING MOTOR(BACKWARD)

Terminal Color Of
No. Wire Signal Name [Specification]

124	W/G	BAT(CB)
125	G/Y	RECLINING MOTOR(FORWARD)
126	G/W	FRONT LIFTING MOTOR(UPWARD)
127	U/Y	REAR LIFTING MOTOR(BACKWARD)
128	R/B	BAT(FUSE)

Terminal Color Of
No. Wire Signal Name [Specification]

129	W/G	BAT(CB)
130	G/Y	RECLINING MOTOR(FORWARD)
131	G/W	FRONT LIFTING MOTOR(DOWNWARD)
132	U/Y	REAR LIFTING MOTOR(UPWARD)
133	R/B	REAR LIFTING MOTOR

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B456
Connector Name	LIFTING MOTOR(REAR)
Connector Type	NS60BRC5S



Terminal Color Of Wire No.	Signal Name [Specification]
10 P/B	-
15 O	-
31 GR	-
38 UT	-
39 R/B	-
40 R/W	-
48 B	-
50 Y/R	-
66 B	-
67 L	-

Connector No.	B459
Connector Name	POWER SEAT SW/TCH
Connector Type	NS101WCS



Terminal Color Of Wire No.	Signal Name [Specification]
11 BR	-
12 G/R	-
13 LG/R	-
26 Y	-
27 RG	-
28 W/R	-
29 F/L	-
32 BNW	-
35 W/B	-
42 W/B	-
43 W/B	-
44 W/B	-
45 W/B	-
46 W/B	-
47 W/B	-
48 W/B	-
49 W/B	-
50 W/B	-
51 W/B	-
52 W/B	-
53 SB	-
54 O	-
55 Y	-
56 W	-
57 G	-
58 R	-
59 B	-
60 W	-
61 G	-
62 R	-
63 B	-
64 W	-
65 G	-
66 R	-
67 B	-
68 W	-
69 G	-
70 R	-
71 B	-
72 W	-
73 G	-
74 R	-
75 B	-
76 W	-
77 B	-
78 G	-
79 R	-
80 W	-
81 G	-
82 R	-
83 B	-
84 W	-
85 G	-
86 R	-
87 B	-
88 W	-
89 G	-
90 R	-
91 B	-
92 W	-
93 G	-
94 R	-
95 B	-
96 W	-
97 G	-
98 R	-
99 B	-
100 W	-
101 G	-
102 R	-
103 B	-
104 W	-
105 G	-
106 R	-
107 B	-
108 W	-
109 G	-
110 R	-
111 B	-
112 W	-
113 G	-
114 R	-
115 B	-
116 W	-
117 G	-
118 R	-
119 B	-
120 W	-
121 G	-
122 R	-
123 B	-
124 W	-
125 G	-
126 R	-
127 B	-
128 W	-
129 G	-
130 R	-
131 B	-
132 W	-
133 G	-
134 R	-
135 B	-
136 W	-
137 G	-
138 R	-
139 B	-
140 W	-
141 G	-
142 R	-
143 B	-
144 W	-
145 G	-
146 R	-
147 B	-
148 W	-
149 G	-
150 R	-
151 B	-
152 W	-
153 G	-
154 R	-
155 B	-
156 W	-
157 G	-
158 R	-
159 B	-
160 W	-
161 G	-
162 R	-
163 B	-
164 W	-
165 G	-
166 R	-
167 B	-
168 W	-
169 G	-
170 R	-
171 B	-
172 W	-
173 G	-
174 R	-
175 B	-
176 W	-
177 G	-
178 R	-
179 B	-
180 W	-
181 G	-
182 R	-
183 B	-
184 W	-
185 G	-
186 R	-
187 B	-
188 W	-
189 G	-
190 R	-
191 B	-
192 W	-
193 G	-
194 R	-
195 B	-
196 W	-
197 G	-
198 R	-
199 B	-
200 W	-
201 G	-
202 R	-
203 B	-
204 W	-
205 G	-
206 R	-
207 B	-
208 W	-
209 G	-
210 R	-
211 B	-
212 W	-
213 G	-
214 R	-
215 B	-
216 W	-
217 G	-
218 R	-
219 B	-
220 W	-
221 G	-
222 R	-
223 B	-
224 W	-
225 G	-
226 R	-
227 B	-
228 W	-
229 G	-
230 R	-
231 B	-
232 W	-
233 G	-
234 R	-
235 B	-
236 W	-
237 G	-
238 R	-
239 B	-
240 W	-
241 G	-
242 R	-
243 B	-
244 W	-
245 G	-
246 R	-
247 B	-
248 W	-
249 G	-
250 R	-
251 B	-
252 W	-
253 G	-
254 R	-
255 B	-
256 W	-
257 G	-
258 R	-
259 B	-
260 W	-
261 G	-
262 R	-
263 B	-
264 W	-
265 G	-
266 R	-
267 B	-
268 W	-
269 G	-
270 R	-
271 B	-
272 W	-
273 G	-
274 R	-
275 B	-
276 W	-
277 G	-
278 R	-
279 B	-
280 W	-
281 G	-
282 R	-
283 B	-
284 W	-
285 G	-
286 R	-
287 B	-
288 W	-
289 G	-
290 R	-
291 B	-
292 W	-
293 G	-
294 R	-
295 B	-
296 W	-
297 G	-
298 R	-
299 B	-
300 W	-
301 G	-
302 R	-
303 B	-
304 W	-
305 G	-
306 R	-
307 B	-
308 W	-
309 G	-
310 R	-
311 B	-
312 W	-
313 G	-
314 R	-
315 B	-
316 W	-
317 G	-
318 R	-
319 B	-
320 W	-
321 G	-
322 R	-
323 B	-
324 W	-
325 G	-
326 R	-
327 B	-
328 W	-
329 G	-
330 R	-
331 B	-
332 W	-
333 G	-
334 R	-
335 B	-
336 W	-
337 G	-
338 R	-
339 B	-
340 W	-
341 G	-
342 R	-
343 B	-
344 W	-
345 G	-
346 R	-
347 B	-
348 W	-
349 G	-
350 R	-
351 B	-
352 W	-
353 G	-
354 R	-
355 B	-
356 W	-
357 G	-
358 R	-
359 B	-
360 W	-
361 G	-
362 R	-
363 B	-
364 W	-
365 G	-
366 R	-
367 B	-
368 W	-
369 G	-
370 R	-
371 B	-
372 W	-
373 G	-
374 R	-
375 B	-
376 W	-
377 G	-
378 R	-
379 B	-
380 W	-
381 G	-
382 R	-
383 B	-
384 W	-
385 G	-
386 R	-
387 B	-
388 W	-
389 G	-
390 R	-
391 B	-
392 W	-
393 G	-
394 R	-
395 B	-
396 W	-
397 G	-
398 R	-
399 B	-
400 W	-
401 G	-
402 R	-
403 B	-
404 W	-
405 G	-
406 R	-
407 B	-
408 W	-
409 G	-
410 R	-
411 B	-
412 W	-
413 G	-
414 R	-
415 B	-
416 W	-
417 G	-
418 R	-
419 B	-
420 W	-
421 G	-
422 R	-
423 B	-
424 W	-
425 G	-
426 R	-
427 B	-
428 W	-
429 G	-
430 R	-
431 B	-
432 W	-
433 G	-
434 R	-
435 B	-
436 W	-
437 G	-
438 R	-
439 B	-
440 W	-
441 G	-
442 R	-
443 B	-
444 W	-
445 G	-
446 R	-
447 B	-
448 W	-
449 G	-
450 R	-
451 B	-
452 W	-
453 G	-
454 R	-
455 B	-
456 W	-
457 G	-
458 R	-
459 B	-
460 W	-
461 G	-
462 R	-
463 B	-
464 W	-
465 G	-
466 R	-
467 B	-
468 W	-
469 G	-
470 R	-
471 B	-
472 W	-
473 G	-
474 R	-
475 B	-
476 W	-
477 G	-
478 R	-
479 B	-
480 W	-
481 G	-
482 R	-
483 B	-
484 W	-
485 G	-
486 R	-
487 B	-
488 W	-
489 G	-
490 R	-
491 B	-
492 W	-
493 G	-
494 R	-
495 B	-
496 W	-
497 G	-
498 R	-
499 B	-
500 W	-
501 G	-
502 R	-
503 B	-
504 W	-
505 G	-
506 R	-
507 B	-
508 W	-
509 G	-
510 R	-
511 B	-
512 W	-
513 G	-
514 R	-
515 B	-
516 W	-
517 G	-
518 R	-
519 B	-
520 W	-
521 G	-
522 R	-
523 B	-
524 W	-
525 G	-
526 R	-
527 B	-
528 W	-
529 G	-
530 R	-
531 B	-
532 W	-
533 G	-
534 R	-
535 B	-
536 W	-
537 G	-
538 R	-
539 B	-
540 W	-
541 G	-
542 R	-
543 B	-
544 W	-
545 G	-
546 R	-
547 B	-
548 W	-
549 G	-
550 R	-
551 B	-
552 W	-
553 G	-
554 R	-
555 B	-
556 W	-
557 G	-
558 R	-
559 B	-
560 W	-
561 G	-
562 R	-
563 B	-
564 W	-
565 G	-
566 R	-
567 B	-
568 W	-
569 G	-
570 R	-
571 B	-
572 W	-
573 G	-
574 R	-
575 B	-
576 W	-
577 G	-
578 R	-
579 B	-
580 W	-
581 G	-
582 R	-
583 B	-

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Connector No.	D31	Connector No.	D33	Connector Name	DOOR MIRROR (PASSENGER SIDE)
23	Y		-	5	GR		-
24	V		-	8	Y	BR	-
		Connector Name	WIRE TO WIRE	9	BR		-
		Connector Type	TH40FW-CS15	10	BG		-
Connector No.	D5	Connector Name	SEAT MEMORY SWITCH	11	SB		-
Connector Type	ADSFN			12	BG		-
				13	L		-
				14	R		-
				15	P		-
				16	V		-
				17	SB		-
				18	V		-
				19	V		-
				20	BG		-
				21	L		-
				22	V		-
				23	G		-
				24	P		-
				25	Y		-
				26	V		-
				27	W		-
				28	G		-
				29	BG		-
				30	O		-
				31	BR		-
				32	W		-
				33	B		-
				34	R		-
				35	G		-
				36	SHIELD		-
				37	V		-
				38	BR		-
				39	BG		-
				40	W		-
				41	W		-
				42	G		-
				43	BR		-
				44	W		-
				45	L		-
				46	P		-
				47	P		-
				48	L		-
				49	W		-
				50	W		-
				51	L		-
				52	BR		-
				53	BR		-
				54	BR		-
				55	BR		-
				56	BR		-
				57	BR		-
				58	W		-
				59	W		-
				60	LG		-
				61	G		-
				62	SB		-
				63	W		-
				64	B		-
				65	G		-
				66	R		-
				67	SHIELD		-
				68	V		-
				69	LG		-

JRJWC9332GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Terminal No.	Wire No.	Color Of Wire	Signal Name [Specification]
1	R	-	
2	B	-	
3	BR	-	
4	P	-	
5	L	-	
6	R	-	
7	R	-	
8	W	-	
9	G	-	
10	L	-	
11	G	-	
12	V	-	
13	B	-	
14	Y	-	
15	W	-	
16	R	-	
17	B	-	
18	G	-	
19	Y	-	
20	L	-	
21	LG	-	
22	L	-	
23	G	-	

24



卷之三

21 6

GRUND

10

10



AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Connector No.	Wire To Wire	Signal Name [Specification]	Terminal Color Of Wire No.	Color Of Wire
25 GR	-	-	71 LG	-
26 R	-	-	72 Y	-
27 W	-	-	73 SB	-
28 SHIELD	-	-	74 BR	-
29 Y	-	-	74 (With ICC)	-
30 Y	-	-	74 (Without ICC)	-
31 R	-	-	75 G	-
32 ER	-	-	76 GR	-
33 SB	-	-	76 (With ICC)	-
34 Y	-	-	76 (Without ICC)	-
35 P	-	-	77 W	-
36 LG	-	-	77 (With ICC)	-
37 ER	-	-	78 L	-
38 P	-	-	78 (Without ICC)	-
39 EG	-	-	79 W	-
40 SB	-	-	79 (With ICC)	-
41 L	-	-	80 SB	-
42 R	-	-	81 SB	-
43 ER	-	-	82 SB	-
44 V	-	-	83 V	-
45 G	-	-	84 G	-
46 SB	-	-	85 L	-
47 V	-	-	86 P	-
48 - [With automatic drive positioner]	-	-	87 W	-
49 - [Without automatic drive positioner]	-	-	89 GR	-
50 P	-	-	90 SHIELD	-
52 R	-	-	91 W	-
53 V	-	-	92 Y	-
54 LG	-	-	93 BR	-
55 SB	-	-	94 P	-
			95 GR	-
			96 W	-
			97 L	-
			98 SHIELD	-
			99 V	-
			100 SB	-

H.S

THB0WW-C516-TM4

AUTOMATIC DRIVE POSITIONER

Connector No.	Wire To Wire	Signal Name [Specification]	Terminal Color Of Wire No.	Color Of Wire
43 BG	-	-	27 B	-
45 W	-	-	28 W	-
49 L	-	-	29 R	-
50 P	-	-	30 SHIELD	-
51 BR	-	-	31 L	-
54 Y	-	-	32 P	-
57 G	-	-	33 SB	-
59 W	-	-	34 L	-
60 L	-	-	35 P	-
61 G	-	-	36 L	-
62 SB	-	-	37 P	-
63 G	-	-	38 BR	-
64 B	-	-	39 Y	-
65 W	-	-	44 L	-
66 R	-	-	45 GR	-
67 SHIELD	-	-	46 LG	-
68 Y	-	-	47 SB	-
69 GR	-	-	48 V	-
70 LG	-	-	50 R	-

H.S

THB0WW-C516-TM4

JRJWC9334GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
60	P	-	61	L	-	62	SHIELD	-
62	R	-	63	GR	BAT	64	W	CLOCK
63	G	-	65	Y	DATA	65	LG	ILLUM
65	BR	-	66	V	ILL	67	B	GND
66	LG	-	68	LG	KEY SWITCH-SIGNAL	69	SHIELD	-
70	W	-	71	G	-	72	W	-
73	G	-	74	R	-	75	W	DATA LINK/CONNECTOR
76	W	-	77	B	-	78	P	BD16IW
79	GR	-	81	EG	-	85	LG	-
86	R	-	87	Y	-	88	W	-
89	BR	-	90	EG	-	91	G	-
91	G	-	92	Y	-	93	IR	-
94	V	-	95	V	-	96	Y	-
98	W	-	99	R	-			
14	P	-	15	Y	-	16	Y	-

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS344W-CS



Connector No.	M31
Connector Name	TILT & TELESCOPIC SW/TILT
Connector Type	XG6F-GY

H.S.

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	XG6FW

H.S.

Connector No.	M51
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH122FW-NH

H.S.

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]
	2	GR	-	2	GR	-
	3	G	-	3	BS	-
	4	Y	-	4	L	-
	5	W	-			

Terminal No.	1	B	Signal Name [Specification]	1	B	Signal Name [Specification]

<tbl_r cells="7

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
18	P	MIRROR SELECT SW (LH)	65	BG	ECU SIGNAL
19	S8	MIRROR SW (DOWNWARD)	69	L	A/C CAN SIGNAL
20	BR	MIRROR SW (RIGHTWARD)	70	R	EACH DOOR POWER SUPPLY
21	L	MIRROR SENSOR (RH/HORIZONTAL)	71	B	GND
22	G	MIRROR SENSOR (LH/HORIZONTAL)	72	P	CAN-L
23	P	TELESCOPIC SENSOR			
24	R	SET SW			
25	S8	ADDRESS2			
26	Y	TELESCOPIC SW (BACKWARD)			
27	G	MIRROR MOTOR (RH COMMON)			
30	R	MIRROR MOTOR (LH/HORIZONTAL)			
31	LG	MIRROR MOTOR (LH/VERTICAL)			
32	L	MIRROR MOTOR (RH/HORIZONTAL)			
33	R	POWER SUPPLY (SENSE)			
34	R	POWER SUPPLY (SENSE)			
35	L	TILT MOTOR (UPWARD)			
36	GR	TELESCOPIC MOTOR (FORWARD)			
39	S8	BAT (C/B)			
40		ON/DISIGNAL			
41	Y	ON/DISENSOR			
42	EG	TILT MOTOR (DOWNWARD)			
44	G	TELESCOPIC MOTOR (BACKWARD)			
45	B	CAN (POWER)			
47	G	BATTERY (DC12V) CONNECTING SW (SENSE)			
53	G	IGNITION POWER SUPPLY			
54	Y	BATTERY POWER SUPPLY			
55	B	GROUND			
56	L	CAN-H			
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL			
58	BR	FUEL LEVEL SENSOR GROUND			
59	GR	INTAKE SENSOR GROUND			
60	L	INVEHICLE SENSOR GROUND			
61	BR	ALARM SENSOR GROUND			
62	SB	SUNLOAD SENSOR GROUND			
63	R	-			

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
79	BR	FROM ANT1+	138	Y	RECEIVER SENSOR POWER SUPPLY
80	GR	ANT1 ANT. AMP.	139	L	TIRE PRESSURE RECEIVER COMM
81	W	ANT2 ANT. AMP.	140	GR	SHUT/NP
82	R	IGNITION RELAY/ECIG. CONT.	141	G	SECURITY IND/LAMP/CONT.
83	Y	KEYLESS ENTRY RECEIVER COMM	142	BR	COMBI SW OUTPUT 5
87	BR	COMBI SW INPUT 5	143	L	COMBI SW OUTPUT 3
88	V	COMBI SW INPUT 3	144	G	COMBI SW OUTPUT 2
90	P	CAN-H	145	L	COMBI SW OUTPUT 4
91	L	CAN-L	146	SB	COMBI SW OUTPUT 1
92	LG	KEY SLOT/STL. CONT.	150	LG	DRIVED DOOR SW
93	V	ON IND.	151	G	REAR WINDOW DEFROSTER RELAY CONT
94	Y	PUDDLE LAMP CONT.	152	R	-
95	EG	ACC RELAY CONT.	153	G	-
96	GR	A/SHIFT SELECTOR POWER SUPPLY	154	W	-
99	R	SHIFT P.	155	BG	-
100	G	PASSENGER DOOR REQUEST SW			
101	SB	DRIVER DOOR REQUEST SW			
102	BR	BLOWER/MOTOR RELAY CONT.			
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY			
107	LG	COMBI SW INPUT 1	1	2	3
108	R	COMBI SW INPUT 4	4	5	6
109	Y	COMBI SW INPUT 2	7	8	9
110	G	HAZARD SW	10	11	12
			11		13
			12		14
			13		15
			14		16
			15		17
			16		18
			17		19
			18		20
			19		21
			20		22
			21		23
			22		24
			23		25
			24		26
			25		27
			26		28
			27		29
			28		30
			29		31

JRJWC9337GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name (Specification)
76	LG	AV COMM(L)
77	Sb	AV COMM(H)
78	LG	AV COMM(L)
79	Sb	AV COMM(H)
80	P	CAN-L
81	L	CAN-H
82	B	SW GND
85	SHIELD	SHIELD
87	L	TEL VOICE SIGNAL (+)
88	P	TEL VOICE SIGNAL (-)
92	R	VEHICLE SPEED SIGNAL (8-PULSE)
93	V	PARKING BRAKE SIGNAL
94	EG	REVERSE SIGNAL
95	G	IGNITION SIGNAL
96	V	DISK EFFECT SIGNAL

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH32W-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
65	V	PARKING BRAKE SIGNAL
67	G	COMPOSITE IMAGE SIGNAL(OND)
68	R	COMPOSITE IMAGE SIGNAL(OFF)
71	SHIELD	MICROPHONE SHIELD
72	R	MICROPHONE/ECC
73	R	COMIN (CONT. 901P)
74	P	CAN-L
75	LG	AV COMM(L)
76	LG	AV COMM(H)
79	R	ILLUMINATION
80	G	IGNITION SIGNAL
81	EG	REVERSE SIGNAL
82	R	VEHICLE SPEED SIGNAL (8-PULSE)
83	SHIELD	SHIELD
87	G	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	G	COMM(DISP-CONT)

JRJWC9338GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000007773700

VALUES ON THE DIAGNOSIS TOOL

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MIR

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
REVERSE SW	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	NOTE: The item is indicated, but not monitored.	Off
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speed-ometer reading
VEH SPEED 2	While driving	Equivalent to speed-ometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Shift position is in the P position)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


Monitor Item	Condition	Value/Status
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

TERMINAL LAYOUT



JPMIA0062ZZ

PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (W)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC

A

B

C

D

E

F

G

H

I

J

K


MIR

M

N

O

P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON
23 (G)	Ground	Back door open	Output	Back door
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON
26 (G)	Ground	Rear wiper	Output	Rear wiper

BCM (BODY CONTROL MODULE)

[WITH ADP]





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
34 (SB)	Ground	Luggage room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment
				 JMKA0062GB
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compartment
				 JMKA0063GB
38 (B)	Ground	Back door antenna (-)	Output When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 JMKA0062GB
				When Intelligent Key is not in the antenna detection area
				 JMKA0063GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	 When Intelligent Key is in the antenna detection area <small>JMKIA0062GB</small>
					 When Intelligent Key is not in the antenna detection area <small>JMKIA0063GB</small>
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC
					0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position
					0 V
60 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed
					0 V
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)
					 1.0 V <small>JPMIA0016GB</small>
64 (V)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding
					0 V
65 (BG)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position
					 1.0 V <small>JPMIA0016GB</small>
					Not in stop position
					0 V

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
66 (R)	Ground	Back door switch	Input	OFF (Door close) ON (Door open)
				11.8 V 0 V
67 (GR)	Ground	Back door opener switch	Input	Pressed Not pressed
				0 V 11.8 V
68 (BR)	Ground	Rear RH door switch	Input	OFF (Door close) ON (Door open)
				11.8 V 0 V
69 (R)	Ground	Rear LH door switch	Input	OFF (Door close) ON (Door open)
				11.8 V 0 V




JPMIA0011GB



JPMIA0011GB



JPMIA0011GB



JPMIA0011GB

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 JMKA0062GB
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 JMKA0063GB
74 (SB)	Ground	Passenger door an- tenna (-)	Output When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area
				 JMKA0062GB
				When Intelligent Key is not in the antenna detection area
				 JMKA0063GB

BCM (BODY CONTROL MODULE)

[WITH ADP]





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
75 (GR)	Ground	Passenger door antenna (+)	Output	When the passenger door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
76 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 JMKA0062GB
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 JMKA0063GB
80 (GR)	Ground	NATS antenna amp.	Input/ Output	When Intelligent Key is in the passenger compart- ment
				 JMKA0062GB
81 (W)	Ground	NATS antenna amp.	Input/ Output	When Intelligent Key is not in the passenger compart- ment
				 JMKA0063GB
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch
				OFF or ACC
				ON
				0 V
				Battery voltage

BCM (BODY CONTROL MODULE)

[WITH ADP]






< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	<p>During waiting</p>  <p>JMKIA0064GB</p>
				<p>When operating either button on the key</p>  <p>JMKIA0065GB</p>
87 (BR)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>1.4 V</p> <p>JPMIA0041GB</p>
				<p>Front fog lamp switch ON (Wiper intermittent dial 4)</p>  <p>1.3 V</p> <p>JPMIA0037GB</p>
				<p>Rear wiper switch ON (Wiper intermittent dial 4)</p>  <p>1.3 V</p> <p>JPMIA0039GB</p>
				<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7  <p>1.3 V</p> <p>JPMIA0040GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
88 (V)	Ground	Combination switch INPUT 3	Input	 All switches OFF (Wiper intermittent dial 4)  Lighting switch HI (Wiper intermittent dial 4)  Lighting switch 2ND (Wiper intermittent dial 4)  Rear washer switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3
				JPMIA0041GB 1.4 V
				JPMIA0036GB 1.3 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
90 (P)	Ground	CAN-L	Input/ Output	—
91 (L)	Ground	CAN-H	Input/ Output	—

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 JPMIA0015GB 6.5 V
					ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
					ON (Pressed)	0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
					ON (Pressed)	0 V
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF  1.4 V
				Turn signal switch LH  1.3 V
				Turn signal switch RH  1.3 V
				Front wiper switch LO  1.3 V
				Front washer switch ON  1.3 V

BCM (BODY CONTROL MODULE)

[WITH ADP]








< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
108 (R)	Ground	Combination switch INPUT 4	Input	All switches OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4 V
				Lighting switch AUTO (Wiper intermittent dial 4)	 <small>JPMIA0038GB</small> 1.3 V
				Lighting switch 1ST (Wiper intermittent dial 4)	 <small>JPMIA0036GB</small> 1.3 V
				Rear wiper switch INT (Wiper intermittent dial 4)	 <small>JPMIA0040GB</small> 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	 <small>JPMIA0039GB</small> 1.3 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (Y)	Ground	Combination switch INPUT 2	Combination switch (Wiper intermittent dial 4)	All switches OFF  1.4 V
				Lighting switch PASS  1.3 V
				Lighting switch 2ND  1.3 V
				Front wiper switch INT  1.3 V
				Front wiper switch HI  1.3 V
110 (G)	Ground	Hazard switch	Hazard switch	ON  0 V
				OFF  1.1 V

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 <small>JPMIA0012GB</small> 1.1 V	
					UNLOCK status (Unlock switch sensor ON)	0 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 <small>JPMIA0011GB</small> 11.8 V	
					ON (Door open)	0 V	
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 <small>JPMIA0013GB</small> 10.2 V	
				Ignition switch OFF or ACC		Battery voltage	

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N




O

P

BCM (BODY CONTROL MODULE)

[WITH ADP]









< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.  <small>JPMIA0159GB</small>
					OFF	0 V
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (BG)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 <small>OCC3881D</small>
					When receiving the signal from the transmitter	 <small>OCC3880D</small>
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 <small>JPMIA0014GB</small>
					OFF	Battery voltage 11.3 V

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
142 (BG)	Ground	Combination switch OUTPUT 5	Combination switch (Wiper intermittent dial 4)	All switches OFF 0 V
				Lighting switch 1ST 10.7 V
				Lighting switch HI  JPMIA0031GB
				Lighting switch 2ND 10.7 V
				Turn signal switch RH  JPMIA0031GB
143 (P)	Ground	Combination switch OUTPUT 1	Combination switch	All switches OFF (Wiper intermittent dial 4) 0 V
				Front wiper switch HI (Wiper intermittent dial 4)  JPMIA0032GB
				Rear wiper switch INT (Wiper intermittent dial 4)  JPMIA0032GB
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 10.7 V
				All switches OFF (Wiper intermittent dial 4) 0 V
144 (G)	Ground	Combination switch OUTPUT 2	Combination switch	Front washer switch ON (Wiper intermittent dial 4)  JPMIA0033GB
				Rear wiper switch ON (Wiper intermittent dial 4)  JPMIA0033GB
				Rear washer switch ON (Wiper intermittent dial 4)  JPMIA0033GB
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 10.7 V
				All switches OFF 0 V
145 (L)	Ground	Combination switch OUTPUT 3	Combination switch (Wiper intermittent dial 4)	Front wiper switch INT  JPMIA0034GB
				Front wiper switch LO  JPMIA0034GB
				Lighting switch AUTO  JPMIA0034GB
				0 V

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O


P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
146 (SB)	Ground	Combination switch OUTPUT 4	Combination switch (Wiper intermittent dial 4)	All switches OFF
				Front fog lamp switch ON
				Lighting switch 2ND
				Lighting switch PASS
				Turn signal switch LH
150 (LG)	Ground	Driver door switch	Driver door switch	OFF (Door close)
				ON (Door open)
151 (G)	Ground	Rear window defogger relay control	Rear window de-fogger	Active
				Not activated



JPMIA0035GB

10.7 V



JPMIA0011GB

11.8 V


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

INFOID:000000007773701

Wiring Diagram - BCM -




2011/06/24

JRMWC4032GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JRMWC4033GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]


- ⟨RF⟩ : With sunroof
- ⟨PM⟩ : With automatic drive positioner
- ⟨OP⟩ : Without automatic drive positioner



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]




JRMWC4035GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]



JRMWC4036GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


[WITH ADP]

BCM (BODY CONTROL MODULE)

Connector No.	R216
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW
Color Of Terminal No.	Signal Name [Specification]
1 B	-
2 L	-



Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-



Terminal No.	Color Of Wire	Signal Name [Specification]
2	16	-



卷之三



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR.	-
2	L	-

100

Connector No.	B242
Connector Name	FUEL LID LOCK ACTUATOR
Connector Type	M04-FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	V	-



Terminal No.	Color Of Wire	Signal Name [Specification]
33	BR	IGNITION
40	SB	BA OFF SV
42	G	IGNITION
46	B	GROUND
47	V	BRACEFLD BIVUNIC CUCANAI

Revision: 2014 October


BCM (BODY CONTROL MODULE)

[WITH ADP]


< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)


Connector No.	B250	Connector No.	D3
Connector Name	REAR TURN SIGNAL LAMP LH	Connector Name	DOOR MIRROR (DRIVER-SIDE)
Connector Type	HS21G-W	Connector Type	TH24WW-NH




Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	G	-	1	L/W	RX
2	B	-	2	R/Y	CANH
3	B	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (DOWNWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (DOWNWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	W	-
19	V	-	19	B	-
20	V	-	20	GR	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)




Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (DOWNWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (DOWNWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	W	-
19	V	-	19	B	-
20	V	-	20	GR	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)




Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (UPWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (UPWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	B	-
19	V	-	19	GR	-
20	V	-	20	Y	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)




Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (UPWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (UPWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	B	-
19	V	-	19	GR	-
20	V	-	20	Y	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)




Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (UPWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (UPWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	B	-
19	V	-	19	GR	-
20	V	-	20	Y	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)



Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (UPWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (UPWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	B	-
19	V	-	19	GR	-
20	V	-	20	Y	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)



Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]
1	R	-	1	O	RX
2	B	-	2	R/Y	CANH
3	G/Y	-	3	W/G	PULSE (RECLINING)
4	P	-	4	W/G	PULSE (LIFTING)
5	W	-	5	Y	SIDE CAMERA LH IMAGE SIGNAL
6	V	-	6	R	SIDE CAMERA LH POWER SUPPLY
7	L/Y	-	7	W	-
8	L	-	8	SB	SLIDING SW (BACKWARD)
9	L/R	-	9	SB	RECLINING SW (BACKWARD)
10	G/W	-	10	G	FRONT LIFTING SW (UPWARD)
11	G/W	-	11	G/R	REAR LIFTING SW (UPWARD)
12	G/W	-	12	O	-
13	G/W	-	13	VCC	-
14	G/W	-	14	LG	SIDE CAMERA LH IMAGE GRID
15	G/W	-	15	TX	-
16	O	-	16	Y/R	CANL
17	Y/R	-	17	W	SIDE CAMERA LH GND
18	Y	-	18	B	-
19	V	-	19	GR	-
20	V	-	20	Y	-
21	L/Y	-	21	R	PULSE (SLIDING)
22	Y/B	-	22	Y	PULSE (LIFTING)
23	Y/B	-	23	BR	SLIDING SW (FORWARD)
24	V	-	24	V	RECLINING SW (FORWARD)



Terminal	Color Of Wire	Signal Name [Specification]	Terminal	Color Of Wire	Signal Name [Specification]

<tbl_r cells="6" ix="1" max

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)







Connector No.	D9	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	POWER WINDOW MAIN SWITCH	No. 1	Y	No. 1	LG
Connector Type	NS31W.CS	No. 2	B	No. 2	P
			-		-
Connector No.	D13	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE REQUEST SWITCH	No. 1	Y	No. 1	LG
Connector Type	RK02TL	No. 2	B	No. 2	Sb
			-		-
Connector No.	D14	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)	No. 2	L	No. 2	L
Connector Type	RK02MGY	No. 4	B	No. 4	B
		No. 5	Y	No. 5	Y
		No. 6	V	No. 6	V
Connector No.	D15	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)	No. 1	Y	No. 1	LG
Connector Type	EDHFGY-HS	No. 2	B	No. 2	Sb
			-		-
Connector No.	D16	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)	No. 1	Y	No. 1	LG
Connector Type	RK02FL	No. 2	B	No. 2	Sb
			-		-
Connector No.	D17	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)	No. 1	Y	No. 1	LG
Connector Type	RK02MGY	No. 2	B	No. 2	Sb
			-		-
Connector No.	D18	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)	No. 1	Y	No. 1	LG
Connector Type	NS16W.CS	No. 2	B	No. 2	Sb
			-		-
Connector No.	D19	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)	No. 1	Y	No. 1	LG
Connector Type	NS16W.CS	No. 2	B	No. 2	Sb
			-		-
Connector No.	D21	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	STEP LAMP (DRIVER SIDE)	No. 1	O	No. 1	LG
Connector Type	TB02IW	No. 2	Sb	No. 2	Sb
			-		-
Connector No.	D22	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	STEP LAMP (PASSENGER SIDE)	No. 1	R	No. 1	LG
Connector Type	TB02IW	No. 2	Sb	No. 2	Sb
			-		-

JRMWG8100GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >



A
B
C
D
M
G
F
I
H
K
L
J
MIR
M
Z
O
P

JRMWG8101GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)		
28 G UZ	Connector No. E110	Connector No. M1
29 LG DS RR	Connector Name STOP LAMP SWITCH	Connector Name FUSE BLOCK (U/B)
30 SB BL5	Connector Type NS56FW-M2	Connector Type NS56FW-M2
31 R VD OFF SW		
35 L CAN-H		
45 B CAN-L		
Connector No. E50		
Connector Name ICC BRAKE HOLD RELAY		
Connector Type NS04FW-R-US		
Terminal Color Of Wire Signal Name [Specification]		
1 B	Terminal No.	Color Of Wire
2 B/Y		
3 B/W		
4 V		
5 G		
6 P		
8 BG		
Connector No. E103		
Connector Name FUSE BLOCK (U/B)		
Connector Type NS56FW-CS		
Terminal Color Of Wire Signal Name [Specification]		
1 V	Terminal No.	Color Of Wire
2 B		
3 P		
4 SB		
6 P		
7 R		
Connector No. E57		
Connector Name INTELLIGENT EXHAUSTS SYSTEM (ECU)		
Connector Type RK03FBR		
Terminal Color Of Wire Signal Name [Specification]		
1P Y	Terminal No.	Color Of Wire
2F W		
4F G		
6F BR		
8F L		
9F R		
Connector No. E110		
Connector Name STOP LAMP SWITCH		
Connector Type NS04FW-LC		
Terminal Color Of Wire Signal Name [Specification]		
1A L	Terminal No.	Color Of Wire
2A G		
3A Y		
4A P		
5A V		
6A Y		
7A R		
8A SB		
Connector No. F51		
Connector Name A/T ASSEMBLY		
Connector Type RK10F-G/VY		
Terminal Color Of Wire Signal Name [Specification]		
1B Y	Terminal No.	Color Of Wire
2B BR		
3V V		
4B W		
6Y R		
7R P		
8P GR		
10B B		
9B SB		
Connector No. M2		
Connector Name FUSE BLOCK (U/B)		
Connector Type NS56FW-CS		
Terminal Color Of Wire Signal Name [Specification]		
1P Y	Terminal No.	Color Of Wire
2B BR		
3V V		
4B W		
6B GR		
7B P		
8B R		
9B SB		

JRMWG8103GB

O

M

Z

K

P

MIR

N

M

Z

O

P

A

B

C

D

M

G

H

I

K

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)

Connector No.			M22	Connector No.	M27	Connector No.	M50
Connector No.	M3	Connector Name	FUSE BLOCK (J/B)	Connector No.	M27	Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	NS121W CS	Connector Type	TH121W NH	Connector Type	AQFW	Connector Type	KOFBR
Terminal No.	Color Of Wire	Signal Name [Specification]		Terminal No.	Color Of Wire	Signal Name [Specification]	
10C	L	-	1	R	R	-	
11C	B	-	2	GR	BR	-	
12C	EG	-	3	W	BR	-	
6C	R	-	5	Y	W	-	
7C	B	-	6	LG	BR	-	
9C	EG	-	7	B	GR	-	
		KEY SWITCH SIGNAL	11	BR	P	-	
Connector No.	M9	Connector Name	DIO/DIE	Connector No.	M24	Connector Name	DATA LINK CONNECTOR
Connector Type	24335_C9900	Connector Type	SD516W	Connector No.		Connector Name	FR WASHER(-)
				Terminal No.	Color Of Wire	Signal Name [Specification]	
				1	P	FR WASHER(-)	
				2	SB	OUTPUT 4 FR WASHER(-)	
				3	GR	-	
				4	G	IGN	
				5	L	OUTPUT 3 GROUND	
				6	B	INPUT 5 GROUND	
				7	V	INPUT 3 GROUND	
				8	BG	OUTPUT 5 INPUT 2	
				9	Y	INPUT 2 INPUT 4	
				10	R	INPUT 1 OUTPUT 1	
				11	LG	ALTERNATOR SIGNAL AIR BAG SIGNAL	
				12	P	INPUT 5 SECURITY SIGNAL	
				13	BR	OUTPUT 2 GROUND	
				14	G	OUTPUT 2 GROUND	
				15	G	GROUND	
				16	B	METER CONTROL SWITCH GROUND	
				19	B	ILL GND	
				20	R	ILL	
				21	RG	IGNITION SIGNAL	

JRMWG8104GB

BCM (BODY CONTROL MODULE)

[WITH ADP]

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)			
22	B	GROUND	
24	BR	COMMUNICATION SIGNAL (LCD->AMP)	69 L A/C LAN SIGNAL
25	Y	VEHICLE SPEED SIGNAL (AMP->CD)	70 R EACH DOOR MOTOR POWER SUPPLY
26	R	PARKING BRAKE SWITCH SIGNAL	71 B GROUND
27	V	SEAT BELT BUCKLE SWITCH SIGNAL	72 P CAN-L
28	W	WASHER LEVEL SWITCH SIGNAL	Connector No. M113 Connector Name FOOT LAMP (PASSENGER SIDE) Connector Type ADNEW
29	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)	
30	G	SEATBELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	
31	L	WASHER LEVEL SWITCH SIGNAL	
33	B	ILLUMINATION CONTROL SIGNAL	
36	IG	SELECT SWITCH SIGNAL	
37	SB	ENTER SWITCH SIGNAL	
38	L	TRIM A/B/RESET SWITCH SIGNAL	
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (+)	
40	EG	ILLUMINATION CONTROL SWITCH SIGNAL (-)	
Connector No. M467		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name UNIFIED METER AND A/C AMP		1 BG GROUND	
Connector Type TH32FW-NH		3 V ACC	
		4 Y ILL CONT	
		5 SB AV COMM(H)	
		6 LG AV COMM(L)	
		7 SG SWING	
		8 B DISK REC SIGNAL	
		9 Y HAZARD ON	
		14 Y	
		16 G	
Connector No. M54		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name FUEL LEVEL SENSOR		1 BG GROUND	
Connector Type TK03FW		2 Y SIGNAL OUTPUT	
		3 LG BATTERY	
Connector No. M594		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name OPTICAL SENSOR		1 W BAT(F/L)	
Connector Type MO3FBL-C		2 W POWER WINDOW POWER SUPPLY(BAT)	
		3 Y POWER WINDOW POWER SUPPLY(AP)	
Connector No. M604		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name REMOTE KEYLESS ENTRY RECEIVER		1 BG GROUND	
Connector Type JABD4FB		2 Y SIGNAL	
		3 LG BATTERY	
Connector No. M101		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
Connector No. M113		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name FOOT LAMP (PASSENGER SIDE)		1 R GROUND	
Connector Type ADNEW		2 BR SIGNAL	
Connector No. M118		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name BCM (BODY CONTROL MODULE)		1 BG GROUND	
Connector Type MO3FBL-C		2 Y SIGNAL	
		3 LG BATTERY	
Connector No. M104		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name REMOTE KEYLESS ENTRY RECEIVER		1 BG GROUND	
Connector Type JABD4FB		2 Y SIGNAL	
		3 LG BATTERY	
Connector No. M105		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M106		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M107		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M108		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M109		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M110		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M111		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M112		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M113		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M114		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M115		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M116		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M117		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M118		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M119		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M120		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M121		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M122		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M123		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M124		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M125		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M126		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M127		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M128		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M129		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M130		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M131		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M132		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M133		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M134		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M135		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M136		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M137		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M138		Terminal Color Of Wire No. Signal Name [Specification]	
Connector Name THE PRESSURE RECEIVER		1 R GROUND	
Connector Type TK04FW		2 BR SIGNAL	
		3 LG BATTERY	
Connector No. M139		Terminal Color Of Wire No. Signal Name [Specification]	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

BCM (BODY CONTROL MODULE)


Connector No.	M119	BCM(BODY CONTROL MODULE)	Connector No.	M221	RECEIVER/SENSOR/GND
Connector Name	BCM(BODY CONTROL MODULE)	Connector Name	BCM(BODY CONTROL MODULE)	Terminal No.	137
Connector Type	NS1616W CS	Connector Type	TH40FGY-NH	Color Of Wire	BG
				Signal Name [Specification]	ROOM ANTI- ROOM ANT1+
				No.	78
				Wire	Y
				Color Of Wire	BR
				Signal Name [Specification]	NATS ANTAMP.
				No.	80
				Wire	GR
				Color Of Wire	W
				Signal Name [Specification]	IGN RELAY/ECU/CONT.
				No.	81
				Wire	R
				Color Of Wire	IG
				Signal Name [Specification]	KEYLESS ENTRY RECEIVER/COMM
				No.	82
				Wire	Y
				Color Of Wire	BR
				Signal Name [Specification]	COMBI SW INPUT1
				No.	83
				Wire	V
				Color Of Wire	COMBI SW INPUT2
				Signal Name [Specification]	COMBI SW INPUT3
				No.	83
				Wire	V
				Color Of Wire	COMBI SW INPUT4
				Signal Name [Specification]	CAN-H
				No.	90
				Wire	P
				Color Of Wire	COMBI SW OUTPUT1
				Signal Name [Specification]	CAN-L
				No.	145
				Wire	L
				Color Of Wire	COMBI SW OUTPUT2
				Signal Name [Specification]	DRIVEN DOOR SW
				No.	150
				Wire	LG
				Color Of Wire	REAR WINDOW DEFOGGER RELAY/CONT
				Signal Name [Specification]	ON/IND
				No.	151
				Wire	G
				Color Of Wire	REAR WINDOW DEFOGGER RELAY/CONT
				Signal Name [Specification]	PUDDLE LAMP/CONT
				No.	92
				Wire	LG
				Color Of Wire	ACC/DELAY/CONT
				Signal Name [Specification]	SHIFT P
				No.	95
				Wire	BR
				Color Of Wire	A/T SHIFT SELECTOR/POWER SUPPLY
				Signal Name [Specification]	INSIDE KEY/ANTENNA/INSTRUMENT CENTER
				No.	96
				Wire	GR
				Color Of Wire	IGN/KEY/ECU/GY
				Signal Name [Specification]	DRIVER DOOR REQUEST SW
				No.	101
				Wire	SB
				Color Of Wire	BLOWER FAN/MOTOR/RELAY/CONT
				Signal Name [Specification]	KEYLESS ENTRY RECEIVER/POWER SUPPLY
				No.	102
				Wire	IG
				Color Of Wire	KEYLESS ENTRY RECEIVER/POWER SUPPLY
				Signal Name [Specification]	COMBI SW INPUT1
				No.	103
				Wire	LG
				Color Of Wire	COMBI SW INPUT2
				Signal Name [Specification]	HAZARD SW
				No.	108
				Wire	R
				Color Of Wire	BACK DOOR OPENER REQUEST SW
				Signal Name [Specification]	I-KEY/WARN BUZZER (ENG ROOM)
				No.	109
				Wire	Y
				Color Of Wire	REAR WIPER/STO/POSITION
				Signal Name [Specification]	HAZARD SW
				No.	110
				Wire	G
				Color Of Wire	BACK DOOR SW
				Signal Name [Specification]	TURN SIGNAL RH (FRONT)
				No.	65
				Wire	R
				Color Of Wire	BACK DOOR OPENER SW
				Signal Name [Specification]	REAR H/DOOR SW
				No.	66
				Wire	BR
				Color Of Wire	REAR H/DOOR SW
				Signal Name [Specification]	REAR H/DOOR SW
				No.	67
				Wire	GR
				Color Of Wire	INT ROOM/LAMP/CONT
				Signal Name [Specification]	INT ROOM/LAMP/CONT
				No.	68
				Wire	BR
				Color Of Wire	INT ROOM/LAMP/CONT
				Signal Name [Specification]	INT ROOM/LAMP/CONT
				No.	69
				Wire	R
				Color Of Wire	INT ROOM/LAMP/CONT
Connector No.	M120	BCM(BODY CONTROL MODULE E)	Connector No.	M122	Signal Name Specification
Connector Name	BCM(BODY CONTROL MODULE E)	Connector Name	SCM(BODY CONTROL MODULE)	Terminal No.	1
Connector Type	NS12FW-CS	Connector Type	TH40FB-NH	Color Of Wire	BR
				Signal Name Specification	-
				No.	2
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	113
				Wire	OPICAL SENSOR
				Color Of Wire	-
				Signal Name Specification	STOP LAMP SW1
				No.	116
				Wire	SB
				Color Of Wire	STOP LAMP SW2
				Signal Name Specification	DR/DOOR UNLOCK SENSOR
				No.	118
				Wire	P
				Color Of Wire	IGN/FB
				Signal Name Specification	PASSENGER DOOR SW
				No.	123
				Wire	W
				Color Of Wire	PASSENGER DOOR SW COMM
				Signal Name Specification	UNIVERSAL DOOR SW COMM
				No.	124
				Wire	Y
				Color Of Wire	PUSH-BUTTON IGNITION SW/ILLUMINATOR
				Signal Name Specification	LOCK IND.
				No.	133
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	134
				Wire	B
				Color Of Wire	-
				Signal Name Specification	-
				No.	135
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	136
				Wire	BR
				Color Of Wire	-
				Signal Name Specification	-
				No.	137
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	138
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	139
				Wire	P
				Color Of Wire	-
				Signal Name Specification	-
				No.	140
				Wire	GR
				Color Of Wire	-
				Signal Name Specification	-
				No.	141
				Wire	IG
				Color Of Wire	-
				Signal Name Specification	-
				No.	142
				Wire	BR
				Color Of Wire	-
				Signal Name Specification	-
				No.	143
				Wire	P
				Color Of Wire	-
				Signal Name Specification	-
				No.	144
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	145
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	146
				Wire	BR
				Color Of Wire	-
				Signal Name Specification	-
				No.	147
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	148
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	149
				Wire	Y
				Color Of Wire	-
				Signal Name Specification	-
				No.	150
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	151
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	152
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	153
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	154
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	155
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	156
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	157
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	158
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	159
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	160
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	161
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	162
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	163
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	164
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	165
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	166
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	167
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	168
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	169
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	170
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	171
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	172
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	173
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	174
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	175
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	176
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	177
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	178
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	179
				Wire	LG
				Color Of Wire	-
				Signal Name Specification	-
				No.	180
				Wire	LG

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)		
Connector No.	R12	-
Connector Name	VANITY MIRROR LAMP LH	-
Connector Type	MCA02FW	-
		
INSIDE KEY ANTENNA (CONSOLE)		
Connector No.	M146	-
Connector Name	INSIDE KEY ANTENNA (CONSOLE)	-
Connector Type	IK02HGY	-
		
R13		
Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	R	-
		
SUNROOF MOTOR ASSEMBLY		
Connector No.	R4	-
Connector Name	SUNROOF MOTOR ASSEMBLY	-
Connector Type	Y101GY	-
		
SW-BIT1		
Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	SW-BIT1
5	P	SW-BIT1
7	BR	+B
8	L	SPEED SENSOR (DP)
9	Y	TIMER (HTRU)
10	G	GROUND

JRMWG8107GB

INFOID:0000000007773702

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

MIR

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent • Starter control relay signal • Starter relay status signal
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000007773703

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

Priority	DTC	
4	<ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG 	A B C D E F G
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT 	H I J
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	K

DTC Index

INFOID:000000007773704

MIR

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18. "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	BCS-37
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-38
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-39

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-40
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-43
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-44
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-45
B2195: ANTI SCANNING	×	—	—	—	SEC-46
B2553: IGNITION RELAY	—	×	—	—	PCS-48
B2555: STOP LAMP	—	×	—	—	SEC-47
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-49
B2557: VEHICLE SPEED	×	×	×	—	SEC-51
B2560: STARTER CONT RELAY	×	×	×	—	SEC-52
B2562: LOW VOLTAGE	—	×	—	—	BCS-40
B2601: SHIFT POSITION	×	×	×	—	SEC-53
B2602: SHIFT POSITION	×	×	×	—	SEC-56
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-59
B2604: PNP SW	×	×	×	—	SEC-62
B2605: PNP SW	×	×	×	—	SEC-64
B2608: STARTER RELAY	×	×	×	—	SEC-66
B260A: IGNITION RELAY	×	×	×	—	PCS-50
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-68
B2614: ACC RELAY CIRC	—	×	×	—	PCS-52
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-55
B2616: IGN RELAY CIRC	—	×	×	—	PCS-58
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-71
B2618: BCM	×	×	×	—	PCS-61
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-73
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	SEC-76
B2621: INSIDE ANTENNA	—	×	—	—	DLK-60
B2622: INSIDE ANTENNA	—	×	—	—	DLK-62
B2623: INSIDE ANTENNA	—	×	—	—	DLK-64
B26E1: ENG STATE NO RES	×	×	×	—	SEC-69
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-70
C1704: LOW PRESSURE FL	—	—	—	×	WT-23
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	WT-25
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH ADP]

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-28
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-30
C1734: CONTROL UNIT	—	—	—	×	WT-32

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

SYMPTOM DIAGNOSIS

DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000007459431

1.CHECK AUTOMATIC DRIVE POSITIONER SYSTEM

Check door mirror operate with automatic drive positioner system.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check automatic drive positioner system operation. Refer to [ADP-12, "AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram"](#)

2.CHECK DOOR MIRROR REMOTE CONTROL SWITCH (MIRROR SWITCH)

Check mirror switch.

Refer to [MIR-12, "MIRROR SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH (CHANGEOVER SWITCH)

Check changeover switch.

Refer to [MIR-14, "CHANGEOVER SWITCH : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#)

NO >> GO TO 1.

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH ADP]

REVERSE INTERLOCK DOOR MIRROR DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000007459432

1.CHECK DOOR MIRROR (MANUAL FUNCTION)

Check door mirror function with door mirror remote control switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DTC

Check DTC for TCM.

Refer to [TM-154, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 1.

MIR

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:0000000007459433



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-114, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to [MIR-112, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000007459434

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH ADP]

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

A

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

B

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

C

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

D

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

E

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

F

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

G

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

H

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

I

J

K

MIR

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

Diagnostic Worksheet

INFOID:0000000007459435







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only about _____ mph | <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns: left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> buzz (like a bumble bee) |

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

- | | | | |
|--|--------------------------|--------------------------|-------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

MIR

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

M

N

O

This form must be attached to Work Order

PIIB8742E

P

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000007459436

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

[WITH ADP]


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007459437

Tool name	Description
Remover tool	 PIIB7923J Remove the clip and pawl and metal clip

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View

INFOID:0000000007459438


Base



1. Inside mirror
2. Mirror base

Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
2. Mirror base
3. Inside mirror cover
4. Harness connector
5. TORX bolt

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000007459439

REMOVAL

Base model

INSIDE MIRROR


[WITH ADP]

< REMOVAL AND INSTALLATION >

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

A
B
C
D

E

F

G

H

I

J

K

MIR

M

N

O

P

OUTSIDE MIRROR


[WITH ADP]

< REMOVAL AND INSTALLATION >

OUTSIDE MIRROR

Exploded View

INFOID:0000000007459440



- | | | |
|--|---|------------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Door mirror corner cover | 9. BSW indicator |

○ : Clip

△ : Pawl

DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:0000000007459441

REMOVAL

1. Remove front door finisher.
 - Driver side: Refer to [INT-11, "DRIVER SIDE : Removal and Installation".](#)
 - Passenger side: Refer to [INT-14, "PASSENGER SIDE : Removal and Installation".](#)
2. Disconnect BSW indicator harness connector. (if equipped)
3. Remove door corner cover fixing clips and remove door corner cover.
4. Disconnect door mirror harness connector.
5. Remove mounting nuts, and then remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-428, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure".](#)

OUTSIDE MIRROR

[WITH ADP]

< REMOVAL AND INSTALLATION >

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:0000000007459442

DISASSEMBLY

1. Remove door mirror cover. Refer to [MIR-121. "DOOR MIRROR COVER : Removal and Installation"](#).
2. Remove side camera after removing door mirror assembly.(BOSE audio with navigation model)
 - Side camera LH: Refer to [AV-538. "Removal and Installation"](#).
 - Side camera RH: Refer to [AV-539. "Removal and Installation"](#).
3. Remove base cover and puddle lamp.

ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Removal and Installation


INFOID:0000000007459443

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.

NOTE:

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Removal and Installation

INFOID:0000000007459444

CAUTION:

Do not damage the mirror bodies.

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-121. "GLASS MIRROR : Removal and Installation"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITH ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:0000000007459445

Refer to [INT-11, "DRIVER SIDE : Exploded View".](#)


Removal and Installation

INFOID:0000000007459446

REMOVAL

1. Remove the power window main switch finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation".](#)
2. Remove door mirror remote control switch (1) from power window main switch finisher (2) using remover tool (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

DOOR MIRROR SYSTEM

Component Description

INFOID:000000007459447

Component	Function
Door mirror remote control switch	It supplies power to mirror motor through mirror switch and changeover switch.
Door mirror	It makes mirror face operate from side to side and up and down with the mirror control switch operation.

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N

O

P

INSIDE MIRROR SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT ADP]

INSIDE MIRROR SYSTEM

System Description

INFOID:0000000007459448

The sensor built in inside mirror detects the brightness of headlight of the vehicle behind and automatically changes the light transmission to decrease the brightness.

Component Description

INFOID:0000000007459449

Component	Function
Auto anti-dazzling inside mirror	It automatically changes the light transmittance according to the brightness of the light from the headlight of the vehicle behind.

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


DTC/CIRCUIT DIAGNOSIS

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER) -

INFOID:000000007459450

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)



2008/08/28

JCLWA2505GB

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No.	D1	Terminal No.	Wire To Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Wire To Wire	Signal Name [Specification]
Connector Name		36	LG	-	21	GR	-	12	P	-
Connector Type	WIRE TO WIRE	37	R	-	22	BR	-	13	LG	-
	TH40FW-CS15	38	P	-	23	Y	-	14	B	-
		39	O	-	24	V	-	15	W	-
		40	BR	-				16	BR	-
		41	L	-				17	B	-
		42	GR	-				18	R	-
		43	BR	- [With automatic drive positioner] - [Without automatic drive positioner]				19	Y	- [With BOSE audio] - [Without BOSE audio]
		43	O	- [Without automatic drive positioner] - [With automatic drive positioner]				20	B	- [Without BOSE audio] - [Without BOSE audio]
		44	GR	- [Without automatic drive positioner] - [With automatic drive positioner]				21	BR	- [Without BOSE audio] - [With BOSE audio]
		44	W	- [Without automatic drive positioner] - [With automatic drive positioner]				21	G	- [Without BOSE audio] - [With BOSE audio]
		45	G	- [Without automatic drive positioner] - [With automatic drive positioner]				22	V	-
		45	Y	- [Without automatic drive positioner] - [With automatic drive positioner]				23	P	-
		46	G	- [Without automatic drive positioner] - [With automatic drive positioner]				24	W	-
		46	V	- [Without automatic drive positioner] - [With automatic drive positioner]				25	SB	-
		49	GR	-				26	R	-
		50	B	-				29	SHIELD	-
		52	R	-				30	W	-
		53	SB	-				31	LG	-
		54	O	-				32	BR	-
		55	Y	-				33	O	-
Connector No.	03							34	GR	-
Connector Name	DOOR MIRROR (DRIVERS SIDE)							35	G	-
Connector Type	TH24NW-NH							35	Y	-
								43	V	-
								44	V	-
								45	P	-
								46	W	-
								52	G	-
								53	GR	-
								54	O	-
								55	I	-

JRLWE4790GB

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

DOOR MIRROR (WITHOUT AUTOMATIC DRIVE POSITIONER)



Connector No. M1



Transcription | *Cantus* = 24



Terminal No.	Color Of Wires	Signal Name [Specification]
--------------	----------------	-----------------------------

JRI-WF4791GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]


AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

Wiring Diagram - INSIDE MIRROR SYSTEM -

INFOID:0000000007459451

PM : With automatic drive positioner
OP : Without automatic drive positioner

INSIDE MIRROR



2009/07/16

JCLWA3671GB

AUTO ANTI-DAZZLING INSIDE MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT ADP]

INSIDE MIRROR

Connector No.	M106	Terminal Color Of Wire No.	Color Of Wire	Signal Name [Specification]
Connector Name	FUSE BLOCK (J/8)	1	G	
Connector Type	NS106W-M2	2	SHIELD	-
		3	L	-
		4	BR	[With automatic drive positioner] [Without automatic drive positioner]
		5	W	-
		6	G	-
		7	BR	-
		8	Y	-
		9	B	-
		10	Y	-
		11	V	-
		12	BR	-
		13	R	-
		14	W	-
		15	SHIELD	-
		16	B	-
		17	W	-
		18	B	-

Terminal Color Of Wire No.	Signal Name [Specification]	Connector No.	Color Of Wire	Signal Name [Specification]
1A	GR	1	G	
2A	G	2	SHIELD	-
3A	L	3	L	-
4A	P	4	W	-
5A	V	5	Y	-
6A	Y	7	BR	-
7A	R	8	Y	-
8A	L	9	B	-
		10	R	-
		11	V	-
		12	BR	-
		13	G	-
		14	R	[With NAVI] [Without NAVI]
		14	Y	-
		15	SHIELD	-
		16	BR	[Without NAVI] [With NAVI]
		18	B	-

Terminal Color Of Wire No.	Signal Name [Specification]	Connector No.	Color Of Wire	Signal Name [Specification]
3B	P	1	BR	IGN
4B	G	2	GND	-
5B	EG	3	BAT	-
6B	Y	4		-
7B	P	5		-
8B	R	6		-
9B	SB	7		-

JRLWE4872GB

O

Z

M

K

-

G

T

-

D

C

B

A

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >


[WITHOUT ADP]

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000007459452



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [MIR-134, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [MIR-132, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

MIR

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:0000000007459453

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

A

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

B

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

C

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

D

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

E

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

F

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

G

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

H

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

I

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

J

K

L

M

N

O

P

MIR

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

Diagnostic Worksheet

INFOID:0000000007459454







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITHOUT ADP]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only about _____ mph | <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns: left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> knock (like a knock at the door) |
| <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> buzz (like a bumble bee) |

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

- | | | | |
|--|--------------------------|--------------------------|-------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

MIR

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

M

N

O

This form must be attached to Work Order

PIIB8742E

P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000007459455

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >

[WITHOUT ADP]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007459456

A

B

C

D

E

F

G

H

I

J

K

MIR

M

N


O

P

Tool name

Description

Remover tool



PIIB7923J

Remove the clip and pawl and metal clip


REMOVAL AND INSTALLATION

INSIDE MIRROR

Exploded View

INFOID:0000000007459457


Base



1. Inside mirror
2. Mirror base

Refer to [GI-4, "Components"](#) for symbols in the figure.

Option



1. Inside mirror
2. Mirror base
3. Inside mirror cover
4. Harness connector
5. TORX bolt

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000007459458

REMOVAL

Base model

INSIDE MIRROR


[WITHOUT ADP]

< REMOVAL AND INSTALLATION >

1. Insert minus driver (A) under the inside mirror (1).
2. Slide the inside mirror to the upper side while pushing the pawl downward.

CAUTION:

Never use excessive force to remove the inside mirror because it is inserted tightly into the mirror base.



Option model

1. Remove the inside mirror cover.
2. Remove TORX bolt.
3. Disconnect harness connector.
4. Slide the inside mirror upward to remove.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When inserting the inside mirror into the mirror base, be sure to push the pawl until it get connected to the mirror base.

A
B
C
D

E

F

G

H

I

J

K

MIR

M

N

O

P

OUTSIDE MIRROR


< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

OUTSIDE MIRROR

Exploded View

INFOID:0000000007459459



JMLIA1771ZZ

- | | | |
|--|---|------------------|
| 1. Door mirror cover | 2. Mirror assembly | 3. Glass mirror |
| 4. Side camera assembly (with side camera model) | 5. Side camera finisher assembly (with side camera model) | 6. Base cover |
| 7. Puddle lamp | 8. Door mirror corner cover | 9. BSW indicator |

○ : Clip

△ : Pawl

DOOR MIRROR ASSEMBLY

DOOR MIRROR ASSEMBLY : Removal and Installation

INFOID:0000000007459460

REMOVAL

1. Remove front door finisher.
 - Driver side: Refer to [INT-11, "DRIVER SIDE : Removal and Installation"](#).
 - Passenger side: Refer to [INT-14, "PASSENGER SIDE : Removal and Installation"](#).
2. Disconnect BSW indicator harness connector. (if equipped)
3. Remove door corner cover fixing clips and remove door corner cover.
4. Disconnect door mirror harness connector.
5. Remove door mirror mounting nuts, and remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Perform camera image calibration. Refer to [AV-428, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

OUTSIDE MIRROR

[WITHOUT ADP]

< REMOVAL AND INSTALLATION >

DOOR MIRROR ASSEMBLY : Disassembly and Assembly

INFOID:0000000007459461

DISASSEMBLY

1. Remove door mirror cover. Refer to [MIR-141. "DOOR MIRROR COVER : Disassembly and Assembly"](#).
2. Remove side camera after removing door mirror assembly (BOSE audio with navigation model).
 - Side camera LH: Refer to [AV-538. "Removal and Installation"](#).
 - Side camera RH: Refer to [AV-539. "Removal and Installation"](#).
3. Remove base cover and puddle lamp.

ASSEMBLY

Assemble in the reverse order of disassemble.

GLASS MIRROR

GLASS MIRROR : Disassembly and Assembly


INFOID:0000000007459462

DISASSEMBLY

1. Place the glass mirror upward.
2. Put a strip of protective tape (B) on housing assembly.
3. As shown in the figure, insert a flat-bladed screwdriver (A) into the recess between glass mirror (1) and actuator (2). Push up both pawls (3) simultaneously to remove glass mirror lower half side.

NOTE:

Insert screwdriver into recesses, and push up while rotating (twisting) to make work easier.



4. Remove two terminals of mirror heater attachment.
5. Lightly lift up lower side of glass mirror, and detach both pawls of upper side as if pulling it out. Disassemble glass mirror from actuator.

NOTE:

Be certain not to allow grease on sealing agent in center of mirror or back side of glass mirror.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR COVER

DOOR MIRROR COVER : Disassembly and Assembly

INFOID:0000000007459463

CAUTION:

Do not damage the mirror bodies.

DISASSEMBLY

1. Remove the glass mirror. Refer to [MIR-141. "GLASS MIRROR : Disassembly and Assembly"](#).
2. Remove the pawls, and disassemble the door mirror cover from the mirror assembly.

ASSEMBLY

Assemble in the reverse order of disassemble.

CAUTION:

After installation, visually check that pawls are securely engaged.

DOOR MIRROR REMOTE CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[WITHOUT ADP]

DOOR MIRROR REMOTE CONTROL SWITCH

Exploded View

INFOID:0000000007459464

Refer to [INT-11, "DRIVER SIDE : Exploded View".](#)


Removal and Installation

INFOID:0000000007459465

REMOVAL

1. Remove the power window main switch finisher. Refer to [INT-11, "DRIVER SIDE : Removal and Installation".](#)
2. Remove door mirror remote control switch (1) from power window main switch finisher (2) using remover tool (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.