

MWI

SECTION METER, WARNING LAMP & INDICATOR

CONTENTS

BASIC INSPECTION	4	ODO/TRIP METER	20
DIAGNOSIS AND REPAIR WORKFLOW	4	ODO/TRIP METER : System Diagram	20
Work flow	4	ODO/TRIP METER : System Description	20
SYSTEM DESCRIPTION	6	ODO/TRIP METER : Component Parts Location....	21
METER SYSTEM	6	ODO/TRIP METER : Component Description	22
METER SYSTEM	6	SHIFT POSITION INDICATOR	22
METER SYSTEM : System Diagram	6	SHIFT POSITION INDICATOR : System Diagram...	22
METER SYSTEM : System Description	6	SHIFT POSITION INDICATOR : System Descrip-	
METER SYSTEM : Component Parts Location	10	tion	22
METER SYSTEM : Component Description	11	SHIFT POSITION INDICATOR : Component	
SPEEDOMETER	11	Parts Location	24
SPEEDOMETER : System Diagram	12	SHIFT POSITION INDICATOR : Component De-	
SPEEDOMETER : System Description	12	scription	25
SPEEDOMETER : Component Parts Location	13	WARNING LAMPS/INDICATOR LAMPS	25
SPEEDOMETER : Component Description	14	WARNING LAMPS/INDICATOR LAMPS : System	
TACHOMETER	14	Diagram	25
TACHOMETER : System Diagram	14	WARNING LAMPS/INDICATOR LAMPS : System	
TACHOMETER : System Description	14	Description	25
TACHOMETER : Component Parts Location	15	WARNING LAMPS/INDICATOR LAMPS : Com-	
TACHOMETER : Component Description	16	ponent Parts Location	26
ENGINE COOLANT TEMPERATURE GAUGE	16	WARNING LAMPS/INDICATOR LAMPS : Com-	
ENGINE COOLANT TEMPERATURE GAUGE :		ponent Description	27
System Diagram	16	METER ILLUMINATION CONTROL	27
ENGINE COOLANT TEMPERATURE GAUGE :		METER ILLUMINATION CONTROL : System Di-	
System Description	16	agram	27
ENGINE COOLANT TEMPERATURE GAUGE :		METER ILLUMINATION CONTROL : System De-	
Component Parts Location	17	scription	27
ENGINE COOLANT TEMPERATURE GAUGE :		METER ILLUMINATION CONTROL : Component	
Component Description	18	Parts Location	29
FUEL GAUGE	18	METER ILLUMINATION CONTROL : Component	
FUEL GAUGE : System Diagram	18	Description	30
FUEL GAUGE : System Description	18	INFORMATION DISPLAY	30
FUEL GAUGE : Component Parts Location	19	INFORMATION DISPLAY : System Diagram	30
FUEL GAUGE : Component Description	20	INFORMATION DISPLAY : System Description ...	30
		INFORMATION DISPLAY : Component Parts Lo-	
		cation	34
		INFORMATION DISPLAY : Component descrip-	
		tion	35

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P
MWI

COMPASS	36
Description	36
Component Parts Location	38
Special Repair Requirement	38
CLOCK	39
Component Parts Location	39
DIAGNOSIS SYSTEM (METER)	40
Diagnosis Description	40
DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)	42
CONSULT Function (METER/M&A)	42
DTC/CIRCUIT DIAGNOSIS	46
U1000 CAN COMM CIRCUIT	46
Description	46
DTC Logic	46
Diagnosis Procedure	46
U1010 CONTROL UNIT (CAN)	47
Description	47
DTC Logic	47
Diagnosis Procedure	47
B2201 COMMUNICATION ERROR 1	48
Description	48
DTC Logic	48
Diagnosis Procedure	48
B2202 COMMUNICATION ERROR 2	50
Description	50
DTC Logic	50
Diagnosis Procedure	50
B2205 VEHICLE SPEED	52
Description	52
DTC Logic	52
Diagnosis Procedure	52
B2267 ENGINE SPEED	53
Description	53
DTC Logic	53
Diagnosis Procedure	53
B2268 WATER TEMP	54
Description	54
DTC Logic	54
Diagnosis Procedure	54
POWER SUPPLY AND GROUND CIRCUIT	55
COMBINATION METER	55
COMBINATION METER : Diagnosis Procedure ...	55
UNIFIED METER AND A/C AMP.	55
UNIFIED METER AND A/C AMP. : Diagnosis Pro- cedure	55
IPDM E/R (INTELLIGENT POWER DISTRIBU- TION MODULE ENGINE ROOM)	56
IPDM E/R (INTELLIGENT POWER DISTRIBU- TION MODULE ENGINE ROOM) : Diagnosis Pro- cedure	56
FUEL LEVEL SENSOR SIGNAL CIRCUIT	58
Description	58
Component Function Check	58
Diagnosis Procedure	59
Component Inspection	60
METER CONTROL SWITCH SIGNAL CIR- CUIT	62
Description	62
Diagnosis Procedure	62
Component Inspection	63
TRIP A/B RESET SWITCH SIGNAL CIRCUIT..	64
Description	64
Diagnosis Procedure	64
Component Inspection	64
OIL PRESSURE SWITCH SIGNAL CIRCUIT ...	66
Description	66
Component Function Check	66
Diagnosis Procedure	66
Component Inspection	66
PARKING BRAKE SWITCH SIGNAL CIR- CUIT	67
Description	67
Diagnosis Procedure	67
Component Inspection	67
WASHER LEVEL SWITCH SIGNAL CIRCUIT... 	69
Description	69
Diagnosis Procedure	69
Component Inspection	69
COMPASS	70
Wiring Diagram - COMPASS -	70
CLOCK	72
Wiring Diagram - CLOCK -	72
ECU DIAGNOSIS INFORMATION	74
COMBINATION METER	74
Reference Value	74
Wiring Diagram - METER -	77
Fail-Safe	87
DTC Index	88
UNIFIED METER AND A/C AMP.	89
Reference Value	89
Wiring Diagram - METER -	96
Fail-Safe	106
DTC Index	107

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	109	
Reference Value	109	A
Wiring Diagram - IPDM E/R -	116	B
Fail-safe	119	C
DTC Index	121	D
SYMPTOM DIAGNOSIS	122	E
THE FUEL GAUGE POINTER DOES NOT MOVE	122	F
Description	122	G
Diagnosis Procedure	122	H
THE METER CONTROL SWITCH IS INOPERATIVE	123	I
Description	123	J
Diagnosis Procedure	123	K
THE TRIP A/B RESET SWITCH IS INOPERATIVE	124	L
Description	124	M
Diagnosis Procedure	124	MWI
THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON	125	O
Description	125	P
Diagnosis Procedure	125	
THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF	126	
Description	126	
Diagnosis Procedure	126	
THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY	127	
Description	127	
Diagnosis Procedure	127	
THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY	128	
Description	128	
Diagnosis Procedure	128	
THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY	129	
Description	129	
Diagnosis Procedure	129	
THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT	130	
Description	130	
Diagnosis Procedure	130	
NORMAL OPERATING CONDITION	131	
COMPASS	131	
COMPASS : Description	131	
INFORMATION DISPLAY	131	
INFORMATION DISPLAY : Description	131	
PRECAUTION	132	
PRECAUTIONS	132	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	132	
PREPARATION	133	
PREPARATION	133	
Commercial Service Tools	133	
REMOVAL AND INSTALLATION	134	
COMBINATION METER	134	
Exploded View	134	
Removal and Installation	134	
Disassembly and Assembly	134	
UNIFIED METER AND A/C AMP.	135	
Exploded View	135	
Removal and Installation	135	
METER CONTROL SWITCH	136	
Exploded View	136	
Removal and Installation	136	
TRIP A/B RESET SWITCH	137	
Exploded View	137	
Removal and Installation	137	
COMPASS	138	
Exploded View	138	
Removal and Installation	138	
CLOCK	139	
Exploded View	139	
Removal and Installation	139	

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work flow

INFOID:000000007455609

OVERALL SEQUENCE



JSNIA4484GB

- Reference 1...[MWI-40, "Diagnosis Description"](#).
- Reference 2...[MWI-107, "DTC Index"](#).
- Reference 3...[MWI-55, "COMBINATION METER : Diagnosis Procedure"](#).

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2.CHECK SYMPTOM

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

3.CHECK ON BOARD DIAGNOSIS OPERATION

Check that the on board diagnosis function operates. Refer to [MWI-40, "Diagnosis Description"](#).

Does the on board diagnosis function operate normally?

- YES >> GO TO 4.
NO >> GO TO 6.

4.CHECK CONSULT SELF-DIAGNOSIS RESULTS

1. Connect CONSULT and perform self-diagnosis. Refer to [MWI-107, "DTC Index"](#).
2. When DTC is detected, follow the instructions below:
 - Record DTC and Freeze Frame Data.

Are self-diagnosis results normal?

- YES >> GO TO 5.
NO >> GO TO 8.

5.NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 8.

6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

Inspect combination meter power supply and ground circuits. Refer to [MWI-55, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 8.

7.REPLACE COMBINATION METER

Replace combination meter.

>> GO TO 9.

8.REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 9.

9.FINAL CHECK

Check that the combination meter operates normally.

Do they operate normally?

- YES >> INSPECTION END
NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

METER SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

METER SYSTEM

METER SYSTEM

METER SYSTEM : System Diagram

INFOID:0000000007455610



JSNIA2512GB

METER SYSTEM : System Description

INFOID:0000000007455611

COMBINATION METER

- The combination meter retrieves the information required for controlling the operations of the meters, indicator lamps/warning lamps and information display from the communication signals from the unified meter and A/C amp. and the signals from various switches and sensors.
- The combination meter incorporates a trip computer that displays warnings and messages on the information display according to the information received from various units.
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5, "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter integrates the meter circuit check function and the segment check function that checks the information display operation.

UNIFIED METER AND A/C AMP.

- Receives information required by the combination meter from various units via CAN communication line and transmits it to the combination meter with communication line.
- The unified meter and A/C amp. incorporates a power saving control function that reduces the power consumption according to the vehicle status. Refer to [BCS-15, "System Description"](#) for details.
- The unified meter and A/C amp. incorporates a diagnosis function that allows the technician to perform diagnoses with CONSULT.

METER SYSTEM

< SYSTEM DESCRIPTION >

Between unified meter and A/C amp. and combination meter.

Unit	Communication line	Input from combination meter	Output to combination meter
Unified meter and A/C amp.	Communication line (METER <> AMP.)	<ul style="list-style-type: none"> • Parking brake switch signal • Washer level switch signal • Meter day/night condition signal • Illumination control switch signal • Refuel status signal • Low fuel warning lamp signal • Odo data signal 	<ul style="list-style-type: none"> • Vehicle speed signal • Turn indicator signal • High beam request signal • Position light request signal • Engine speed signal • Fuel level sensor signal • Engine coolant temperature signal • A/T CHECK indicator signal • Oil pressure switch signal • Door switch signal • Buzzer output signal • AFS OFF indicator lamp signal • TPMS malfunction warning lamp signal • AWD warning lamp signal • VDC OFF indicator lamp signal • VDC warning lamp signal • ABS warning lamp signal • Brake warning lamp signal • Malfunctioning indicator lamp signal • Master warning signal • ICC warning lamp signal • Lane departure warning lamp signal • LDP ON indicator lamp signal • IBA OFF indicator lamp • BSW warning lamp signal • Front fog lights request signal
	Communication line (LCD <> AMP.)	<ul style="list-style-type: none"> • Average fuel consumption reset signal • Travel time reset signal • Possible driving distance reset signal • Average vehicle speed reset signal • Select switch signal • Enter switch signal • Trip A/B reset switch signal • Ambient air temperature display signal 	<ul style="list-style-type: none"> • Shift position signal • Manual mode indicator signal • Manual mode shift refusal signal • Meter display signal • Door switch signal • Fuel level sensor signal • Parking brake switch signal • Washer level switch signal • Charge warning signal • Instantaneous fuel consumption display signal • Ambient air temperature display signal • Average fuel consumption display signal • Average vehicle speed display signal • Possible driving distance display signal • Engine speed signal • Vehicle speed signal • Low tire pressure warning lamp signal • Fuel filler cap warning display signal

IPDM E/R

- IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
- IPDM E/R is equipped with the diagnosis function. It can perform the operation check of oil pressure warning lamp with the auto active test and the diagnosis with CONSULT.

METER CONTROL FUNCTION LIST

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

METER SYSTEM

< SYSTEM DESCRIPTION >


X: Applicable

System		Description	Signal source	Via unified meter and A/C amp.
Meter/gauge	Speedometer	Receives vehicle speed signal and indicates vehicle speed.	ABS actuator and electric unit (control unit)	X
	Tachometer	Receives engine speed signal and indicates engine speed.	ECM	X
	Fuel gauge	Receives fuel level sensor signal and indicates fuel level.	Fuel level sensor unit	X
	Engine coolant temperature gauge	Receives engine coolant temperature signal and indicates coolant temperature.	ECM	X
Warning lamp/indicator lamp	Oil pressure warning lamp	Receives oil pressure warning lamp signal and illuminates warning lamp.	IPDM E/R	X
	Master warning	Illuminates according to warning output on information display.	—	X
Information display	Door open warning	Receives door switch signals and displays warning.	BCM	X
	Parking brake release warning	Receives parking brake switch signal and vehicle speed signal and displays warnings.	Parking brake switch ABS actuator and electric unit (control unit)	X
	Low fuel warning	Receives fuel gauge signal and displays warning if fuel level decreases to 14 ℥ (3-3/4 US gal, 3-1/8 Imp gal) or less.	Fuel level sensor unit	X
	Low washer fluid warning	Receives washer level switch signal and displays warning.	Washer level switch	
	Low outside temperature warning	Monitors ambient sensor signal and displays warning if ambient temperature decreases to 3°C (37°F) or less. (If enabled)	Ambient sensor	X
	Low tire pressure warning	Receives low tire pressure warning lamp signal and displays warning.	BCM	X
	Fuel filler cap warning	Receives fuel filler cap warning display signals and displays warning.	ECM	X
	Instantaneous fuel consumption	Calculates instantaneous fuel consumption based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM ABS actuator and electric unit (control unit)	X
	Average fuel consumption	Calculates average fuel consumption in a reset-to-reset interval based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM ABS actuator and electric unit (control unit)	X
	Average vehicle speed	Calculates average vehicle speed in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X
	Travel time	Displays accumulated key switch ON time from reset to reset.	—	X
	Travel distance	Calculates accumulated travel distance in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X
	Possible driving distance	Calculates possible driving distance based on received fuel consumption monitor signal, vehicle speed signals and fuel level sensor signal and displays it.	ECM ABS actuator and electric unit (control unit) Fuel level sensor unit	X
	Ambient air temperature	Corrects ambient air temperature value based on received ambient sensor signals and displays it.	Ambient sensor	X

METER SYSTEM

< SYSTEM DESCRIPTION >

ARRANGEMENT OF COMBINATION METER



JSNIA3714ZZ

A. U.S.A.

B. Canada

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI


O
P

METER SYSTEM

< SYSTEM DESCRIPTION >

METER SYSTEM : Component Parts Location

INFOID:000000007455612



JPNIA0868ZZ

- | | | |
|--|------------------------|-------------------|
| 1. Fuel level sensor unit and fuel pump
(main) | 2. BCM | 3. IPDM E/R |
| 4. ECM
Refer to EC-38, "Component Parts Location" . | 5. Oil pressure switch | 6. Ambient sensor |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

METER SYSTEM : Component Description

INFOID:000000007455613

Unit	Description
Combination meter	<p>Controls the following with the signals from the unified meter and A/C amp, switches and sensors.</p> <ul style="list-style-type: none"> • Speedometer • Tachometer • Engine coolant temperature gauge • Fuel gauge • Warning lamps • Indicator lamps • Information display • Warning chime
Unified meter and A/C amp.	<ul style="list-style-type: none"> • The combination meter receives the necessary information from various units via CAN communication line and transmits them to the unified meter and A/C amp. with the communication line that connects both of them. • Transmits the fuel gauge signal from the fuel gauge unit with the communication line that connects the unified meter and A/C amp. and the combination meter. • Reads the signals from the A/T shift selector transmits them to TCM with CAN communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with CAN communication line.
Fuel level sensor unit	Refer to MWI-58, "Description" .
Oil pressure switch	Refer to MWI-66, "Description" .
ECM	<p>Transmits the following signals to the unified meter and A/C amp. with CAN communication line.</p> <ul style="list-style-type: none"> • Engine speed signal • Engine coolant temperature signal • Fuel consumption monitor signal • Fuel filler cap warning display signal
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
BCM	<ul style="list-style-type: none"> • Transmits signals provided by various units to the unified meter and A/C amp. with CAN communication line. • Transmits the security signal and low tire pressure warning lamp signal to the combination meter.
A/T shift selector	<p>Transmits the following signals to the unified meter and A/C amp.</p> <ul style="list-style-type: none"> • Manual mode signal • Non-manual mode signal • Manual mode shift up signal • Manual mode shift down signal
TCM	Transmits shift position signal, manual mode indicator signal and manual mode shift refusal signal to the unified meter and A/C amp.
Meter control switch	Refer to MWI-62, "Description" .
Trip A/B reset switch	Refer to MWI-64, "Description" .
Washer level switch	Transmits the washer level signal to the combination meter.
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Refer to MWI-67, "Description" .


SPEEDOMETER

METER SYSTEM

< SYSTEM DESCRIPTION >

SPEEDOMETER : System Diagram

INFOID:000000007455614



SPEEDOMETER : System Description

INFOID:000000007455615


- The ABS actuator and electric unit (control unit) converts the pulse signal provided by the wheel sensor to a vehicle speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line and transmits it to the combination meter by means of communication line.
- The combination meter indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.

METER SYSTEM

< SYSTEM DESCRIPTION >

SPEEDOMETER : Component Parts Location

INFOID:000000007583212



1. Fuel level sensor unit and fuel pump (main)
4. ECM
Refer to [EC-38, "Component Parts Location"](#).

2. BCM
5. Oil pressure switch

3. IPDM E/R
6. Ambient sensor

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O

P

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

SPEEDOMETER : Component Description


INFOID:000000007455617

Unit	Description
Combination meter	Indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line to the combination meter by means of communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

TACHOMETER

TACHOMETER : System Diagram

INFOID:000000007455618



JSNIA0160GB

TACHOMETER : System Description

INFOID:000000007455619


- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the engine speed signal from ECM with CAN communication line and transmits it to the combination meter by means of communication line.
- Combination meter converts engine speed signal to the angle signal, and commands to tachometer.

METER SYSTEM

< SYSTEM DESCRIPTION >

TACHOMETER : Component Parts Location

INFOID:000000007583213



1. Fuel level sensor unit and fuel pump (main)
2. BCM
3. IPDM E/R
4. ECM
Refer to [EC-38, "Component Parts Location"](#).
5. Oil pressure switch
6. Ambient sensor

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

TACHOMETER : Component Description


INFOID:0000000007455621

Unit	Description
Combination meter	Indicates the engine speed according to the engine speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine speed signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine speed signal to the unified meter and A/C amp. with CAN communication line.

ENGINE COOLANT TEMPERATURE GAUGE

ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:0000000007455622



ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:0000000007455623

- ECM converses a signal from engine coolant temperature sensor to engine coolant temperature signal, and transmits to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine coolant temperature signal to combination meter with communication line.
- Combination meter converses engine coolant temperature signal to the angle signal, and commands to engine coolant temperature gauge.

METER SYSTEM

< SYSTEM DESCRIPTION >

ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location

INFOID:000000007583214

A

B

C

D

E

F

G

H

I

J

K


L

M

MWI

O

P



1. Fuel level sensor unit and fuel pump (main)
4. ECM
Refer to [EC-38, "Component Parts Location"](#).

2. BCM
5. Oil pressure switch

3. IPDM E/R
6. Ambient sensor

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

ENGINE COOLANT TEMPERATURE GAUGE : Component Description


INFOID:0000000007455625

Unit	Description
Combination meter	Indicates the water temperature gauge according to the engine coolant temperature signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine coolant temperature signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine coolant temperature signal to the unified meter and A/C amp. with CAN communication line.

FUEL GAUGE

FUEL GAUGE : System Diagram

INFOID:0000000007455626



JSNIA0534GB

FUEL GAUGE : System Description

INFOID:0000000007455627

CONTROL OUTLINE

- The unified meter and A/C amp. reads the fuel level sensor signal from the fuel gauge unit and transmits it to the combination meter with the communication line.
- The combination meter indicates the fuel level on the fuel gauge according to the received fuel level sensor signal.

REFUEL CONTROL

The combination meter accelerates the fuel gauge segment if the all conditions listed below are met, or the ignition switch is ON from OFF.


- Ignition switch is ON position
- The vehicle is not moving
- The fuel level change by 15 ℥ (4 US gal, 3-3/10 Imp gal) or more

METER SYSTEM

< SYSTEM DESCRIPTION >

FUEL GAUGE : Component Parts Location

INFOID:000000007583215



1. Fuel level sensor unit and fuel pump (main)
2. BCM
3. IPDM E/R
4. ECM
Refer to [EC-38, "Component Parts Location"](#).
5. Oil pressure switch
6. Ambient sensor

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

FUEL GAUGE : Component Description


INFOID:000000007455629

Unit	Description
Combination meter	Indicates the fuel gauge according to the fuel level sensor signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the fuel level sensor signal from the fuel level sensor unit to the combination meter by means of communication line.
Fuel level sensor unit	Refer to MWI-58, "Description" .

ODO/TRIP METER

ODO/TRIP METER : System Diagram

INFOID:000000007455630



ODO/TRIP METER : System Description

INFOID:000000007455631


- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

METER SYSTEM

< SYSTEM DESCRIPTION >

ODO/TRIP METER : Component Parts Location

INFOID:000000007583216



1. Fuel level sensor unit and fuel pump (main)
2. BCM
3. IPDM E/R
4. ECM
Refer to [EC-38, "Component Parts Location"](#).
5. Oil pressure switch
6. Ambient sensor

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

ODO/TRIP METER : Component Description


INFOID:0000000007455633

Unit	Description
Combination meter	The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.
Unified meter and A/C amp.	The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

SHIFT POSITION INDICATOR

SHIFT POSITION INDICATOR : System Diagram

INFOID:0000000007455634



JSNIA2328GB

SHIFT POSITION INDICATOR : System Description

INFOID:0000000007455635

Shift position is displayed in the information display LCD in the combination meter.

MANUAL MODE

- Unified meter and A/C amp. inputs manual mode signal and shift-up/down signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM processes manual mode signal and shift-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line.
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal.
- TCM transmits a manual mode shift refusal signal to the unified meter and A/C amp. via CAN communication line when gear shifting cannot be performed in manual mode.
- The unified meter and A/C amp. transmits a manual mode shift refusal signal to the combination meter via communication line.
- The combination meter blinks the shift position indicator and sounds a buzzer when receiving a manual mode shift refusal signal.

METER SYSTEM

< SYSTEM DESCRIPTION >

NON-MANUAL MODE

- Unified meter and A/C amp. inputs non-manual mode signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM transmits shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits shift position signal to combination meter with the communication line.
- Combination meter indicates A/T shift position when receiving shift position signal.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O


P

METER SYSTEM

< SYSTEM DESCRIPTION >

SHIFT POSITION INDICATOR : Component Parts Location

INFOID:0000000007583217



- | | | |
|--|------------------------|-------------------|
| 1. Fuel level sensor unit and fuel pump
(main) | 2. BCM | 3. IPDM E/R |
| 4. ECM
Refer to EC-38, "Component Parts Location" . | 5. Oil pressure switch | 6. Ambient sensor |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

SHIFT POSITION INDICATOR : Component Description


INFOID:0000000007455637

Unit	Description
Combination meter	Displays the shift position on the information display with shift position signal and manual mode indicator signal received from unified meter and A/C amp.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Transmits the signals from the A/T shift selector to TCM with CAN communication line. Transmits shift position signal and manual mode indicator signal received from TCM with CAN communication line to the combination meter by means of communication line.
A/T shift selector	<p>Transmits the following signals to the unified meter and A/C amp.</p> <ul style="list-style-type: none"> Manual mode signal Non-manual mode signal Manual mode shift up signal Manual mode shift down signal
TCM	Transmits shift position signal, manual mode indicator signal and manual mode shift refusal signal to the unified meter and A/C amp.

WARNING LAMPS/INDICATOR LAMPS

WARNING LAMPS/INDICATOR LAMPS : System Diagram

INFOID:0000000007455638



JPNIA0969GB

WARNING LAMPS/INDICATOR LAMPS : System Description

INFOID:0000000007455639

OIL PRESSURE WARNING LAMP

- IPDM E/R inputs oil pressure switch signal from oil pressure switch, and transmits the signal to unified meter and A/C amp. through BCM with CAN communication line.
- Unified meter and A/C amp. transmits oil pressure switch signal to combination meter with communication line.
- Let the combination meter turn oil pressure warning lamp ON with received oil pressure switch signal.


MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

WARNING LAMPS/INDICATOR LAMPS : Component Parts Location

INFOID:0000000007583218



JPNIA0868ZZ

1. Fuel level sensor unit and fuel pump (main)
2. BCM
3. IPDM E/R
4. ECM
Refer to [EC-38, "Component Parts Location"](#).
5. Oil pressure switch
6. Ambient sensor

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

WARNING LAMPS/INDICATOR LAMPS : Component Description


INFOID:0000000007455641

Unit	Description
Combination meter	Turns the oil pressure warning lamp ON/OFF according to the oil pressure switch signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the oil pressure switch signal received from the IPDM E/R with BCM to the combination meter by means of communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals from the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
Oil pressure switch	Refer to MWI-66, "Description" .
BCM	Transmits the oil pressure switch signal received from IPDM E/R via CAN communication to the unified meter and A/C amp. via CAN communication line.

METER ILLUMINATION CONTROL

METER ILLUMINATION CONTROL : System Diagram

INFOID:0000000007455642



JSNIA0024GB

METER ILLUMINATION CONTROL : System Description

INFOID:0000000007455643

SYSTEM DESCRIPTION

The combination meter controls the meter illumination by the illumination control switch signal from the meter control switch and the position light request signal transmitted by BCM with unified meter and A/C amp.


Daytime Mode

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

Meter illumination is adjusted to 5 steps by illumination control switch (1) in daytime mode.



Nighttime Mode


- Combination meter is transferred to nighttime mode with position light request signal from BCM with CAN communication line.
- Meter illumination is adjusted to 22 steps by illumination control switch in nighttime.

METER SYSTEM

< SYSTEM DESCRIPTION >

METER ILLUMINATION CONTROL : Component Parts Location

INFOID:000000007583219



1. Fuel level sensor unit and fuel pump (main)
2. BCM
3. IPDM E/R
4. ECM
Refer to [EC-38, "Component Parts Location"](#).
5. Oil pressure switch
6. Ambient sensor

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

METER ILLUMINATION CONTROL : Component Description


INFOID:0000000007455645

Unit	Description
Combination meter	Controls the meter illumination with the illumination control switch signal from the meter control switch and the position light request signal from unified meter and A/C amp.
Unified meter and A/C amp.	Transmits the position light request signal received from BCM via CAN communication to the combination meter by means of communication.
Meter control switch	Transmits the following signals to the combination meter. • Illumination control switch signal (+) • Illumination control switch signal (-)

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:0000000007455646



JPNIA1096GB

INFORMATION DISPLAY : System Description

INFOID:0000000007455647

DESCRIPTION

- The combination meter retrieves the information required for controlling the operations of the information display from the communication signals from the unified meter and A/C amp., etc.
- The combination meter incorporates a trip computer that displays the warning / information according to the information received from various units.

PARKING BRAKE RELEASE WARNING

The combination meter indicates parking brake release warning judged with the vehicle speed signal received from the unified meter and A/C amp. by means of communication line and the parking brake switch signal from the parking brake switch.

Warning Operation Condition

Parking brake release warning is judged if all of the following conditions are fulfilled

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

LOW FUEL WARNING

METER SYSTEM

< SYSTEM DESCRIPTION >

The combination meter indicates low fuel warning judged with the fuel level sensor signal received from the unified meter and A/C amp.

Warning Operation Condition


- Fuel level: Approx. 14 ℥ (3-3/4 US gal, 3-1/8 Imp gal) or less

LOW WASHER FLUID WARNING

The combination meter indicates low washer fluid warning judged with the signal from the washer level switch.

Warning Operation Condition

- Indicates the warning when it is in washer level switch ON condition for 180 seconds or more. Release the warning when it is in washer level switch OFF condition for 30 seconds or more.



LOW TIRE PRESSURE WARNING

- The unified meter and A/C amp. receives remaining low tire pressure warning lamp signal from the BCM with CAN communication line.
- The unified meter and A/C amp. transmits remaining low tire pressure warning lamp signal to the combination meter with communication line.
- The combination meter indicates low tire pressure warning when receiving remaining low tire pressure warning lamp signal.
- The combination meter indicates low tire pressure warning judged with the low tire pressure warning lamp signal received from the unified meter and A/C amp.

For details, refer to [WT-7. "TIRE PRESSURE MONITORING SYSTEM : System Description"](#).

FUEL FILLER CAP WARNING

- The unified meter and A/C amp. receives remaining fuel filler cap warning display signal from the ECM with CAN communication line.
- The unified meter and A/C amp. transmits remaining fuel filler cap warning display signal to the combination meter with communication line.
- The combination meter indicates fuel filler cap warning when receiving remaining fuel filler cap warning display signal.
- The combination meter indicates fuel filler cap warning judged with the fuel filler cap warning display signal received from the unified meter and A/C amp.

For details, refer to [EC-109. "System Description"](#).

DOOR OPEN WARNING

The combination meter indicates door open warning judged with each door switch signal received from the unified meter and A/C amp. by means of communication line.

INSTANTANEOUS FUEL CONSUMPTION

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the instantaneous fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.

AVERAGE FUEL CONSUMPTION

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the average fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.
- The average fuel consumption displayed on the information display is uploaded at approximately 30-second intervals.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

METER SYSTEM

< SYSTEM DESCRIPTION >

NOTE:

When turning ON the ignition switch after triggering a reset or removing/installing the battery, “——” is indicated until 30 seconds/500 m (0.31 miles) of driving.

AVERAGE VEHICLE SPEED

- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line.
- Measures the time during the ignition switch ON with the unified meter and A/C amp.
- The unified meter and A/C amp. calculates the average vehicle speed according to the above signals. These signals are transmitted to the combination meter with the communication line.
- The average vehicle speed displayed on the information display is uploaded at approximately 30-second intervals.

NOTE:

When turning ON the ignition switch after triggering a reset or removing/installing the battery, “——” is indicated until 30 seconds/500 m (0.31 miles) of driving.

TRAVEL TIME

Measures the time during the ignition switch ON with the unified meter and A/C amp, and transmits it to the combination meter by means of communication line.

TRAVEL DISTANCE

- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

POSSIBLE DRIVING DISTANCE

The unified meter and A/C amp. calculates possible driving distance according to the vehicle speed signal and fuel consumption monitor signal transmitted via CAN communication and the fuel level sensor signal transmitted from the fuel level sensor. These signals are transmitted to the combination meter with the communication line.

NOTE:

- When turning ON the ignition switch after removing/installing the battery, “——” is indicated until 30 seconds.
- “——” is displayed for 30 seconds after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).
- The indicated values may not match each other when filling the fuel with the ignition switch ON. Refer to [MWI-131, "INFORMATION DISPLAY : Description"](#).

AMBIENT AIR TEMPERATURE

- The unified meter and A/C amp. receives the ambient sensor signal from the ambient sensor.
- The unified meter and A/C amp. calculates the ambient temperature according to the ambient sensor signal, and transmits it to the combination meter.
- The indicated temperature does not increase if the vehicle speed is less than 20 km/h (12 MPH).

NOTE:

- The ambient sensor input value that is displayed on “Data Monitor” of CONSULT is the value before the correction. It may not match the indicated temperature on the information display.
- Ambient temperature may be indicated higher than an actual temperature, depending on heat in the engine, a road surface temperature, and so on.

SETTING

Setting item list

Items		Setting range	Setting unit	Description
ALERT	TIME TO REST	No setting - 6 hours	30 minutes, [60 minutes]*	Time to rest is displayed on the information display if the vehicle reached the set travel distance.
	ICY	ON/OFF	—	Low outside temp is displayed on the information display if the ambient temperature is 3°C (37°F) or less.

METER SYSTEM

< SYSTEM DESCRIPTION >

Items	Setting range	Setting unit	Description
MAINTENANCE	ENGINE OIL	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*
	OIL FILTER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*
	TIRE	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*
	OTHER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*
DISPLAY	LANGUAGE	ENGLISH/FRANCAIS	—
	UNIT	US/METRIC	—

*: Press and hold the switch (1 second or more).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O


P

METER SYSTEM

< SYSTEM DESCRIPTION >

INFORMATION DISPLAY : Component Parts Location

INFOID:000000007583220



JPNIA0868ZZ

- | | | |
|--|------------------------|-------------------|
| 1. Fuel level sensor unit and fuel pump
(main) | 2. BCM | 3. IPDM E/R |
| 4. ECM
Refer to EC-38, "Component Parts Location" . | 5. Oil pressure switch | 6. Ambient sensor |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|--|----------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Unified meter and A/C amp. | 9. Combination meter |
| 10. Fuel level sensor unit (sub) | | |
| A. Rear seat (inside right) | B. Dash side finisher (passenger side) | C. Hoodledge cover (RH) |
| D. 2WD [oil pan (upper) RH side] | E. AWD (oil filter bracket part) | F. Condenser (front) |
| G. Hoodledge cover (LH) | H. Behind cluster lid C | I. Rear seat (inside left) |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

INFORMATION DISPLAY : Component Description

INFOID:000000007455649

Unit	Description
Combination meter	Controls the information display with the signals received from the unified meter and A/C amp. by means of communication and the signals from various switches and sensors.
Unified meter and A/C amp.	Transmits signals received from various units to the combination meter by means of communication.
Fuel level sensor unit	Refer to MWI-58, "Description" .
ECM	Transmits the following signals to the unified meter and A/C amp. via CAN communication. <ul style="list-style-type: none">• Engine speed signal• Fuel consumption monitor signal• Fuel filler cap warning display signal
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. via CAN communication.
BCM	Transmits signals provided by various units to the unified meter and A/C amp. via CAN communication.
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none">• Enter switch signal• Select switch signal
Washer level switch	Transmits the washer level signal to the combination meter.
Parking brake switch	Refer to MWI-67, "Description" .
Door switch	Transmits the door switch signals to BCM.
Ambient sensor	Detects the ambient air temperature and transmits the ambient sensor signal to the unified meter and A/C amp.

COMPASS

< SYSTEM DESCRIPTION >


COMPASS

Description

INFOID:0000000007455650

DESCRIPTION

- This electronic compass is able to display 8 primary directions: N, NE, E, SE, S, SW, W, NW.
- The compass switch (1) is used to operate the compass.



Switch Operation

Press	Compass is turned ON/OFF
Press and hold (for 3- 9 sec.)	Compass display (2) turns to zone variation change mode
Press and hold (for more than 9 sec.)	Compass display turns to calibration mode


- All standard compasses determine direction relative to magnetic north; however, this electronic compass is designed to display direction relative to true north.
- The difference between magnetic north and true north varies from place to place across the surface of the earth.
- This electronic compass must be “told” approximately where it is on the earth’s surface so that the magnetic north reading can be properly converted into a true north display.
- To tell the electronic compass where it’s at, the earth is separated into numbered “Zone Variances”. The zone variance number in which the compass is to function must be entered into this electronic compass.
- Each zone is magnetically about 4.2° wide. Typically, anything under 22.5° total zone change is not noticed on the electronic compass display. However, over 22.5° , a reading may be off by one or more primary directions.
- On long trips, a vehicle may leave its original zone and enter one or more new zones. Generally, you do not need to reset the compass zone if you travel between 3 or 4 zones, such as business travel or vacation. The typical driver will not notice any difference on the display within 3 or 4 zones. However, if the vehicle is “permanently” moved to a new location, it is recommended that the compass zone be reset.

ZONE VARIATION SETTING PROCEDURE

COMPASS

< SYSTEM DESCRIPTION >

1. Press and hold the compass switch for 3 – 9 seconds.
2. The current zone setting appears on the compass display.
3. Find the current geographical location number in the zone variation chart.
4. Select the new zone number. (Press the compass switch until the new zone number appears on the compass display.)
5. After select the new zone number, the compass display will automatically shows a direction within a few seconds.
6. Perform the following calibration procedure for more accurate indications.



CALIBRATION PROCEDURE

NOTE:

The compass calibrates itself under normal driving conditions. However, occasional circumstances may cause the compass to operate inaccurately. Example: Driving from rural (wide open) areas to crowded city areas, or if an aftermarket (i.e., non original equipment) antenna with a magnetic base is attached to the vehicle. Calibrate the mirror compass if the display shows only one direction or a limited number of directions.

NOTE:

- If "magnetic hats" are used in the dealership for vehicle identification, remove the hat from the vehicle before performing the following steps. Do not put the hat back on the vehicle after the procedure is completed.
- Drive the vehicle to an open level area; away from large metallic objects, structures, and overhead power lines.
- Turn off "non-essential" electrical accessories (rear window defrost, heater/air conditioning, wipers) and close the doors.

1. Verify the correct compass zone setting for the geographical location.
2. Press and hold the compass switch for more than 9 seconds.
3. "C" is displayed on the compass display, when calibration starts.
4. Drive slowly [less than 8 km/h (5 MPH)] in a circle until the "C / CAL" is replaced with primary headings (N, NE, E, SE, S, SW, W, or NW).

NOTE:

This will require driving at least 2 complete 360 degree circles; 3 complete circles may be required.

5. The compass calibration procedure is now complete. The compass should operate normally.

NOTE:


If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, repeat the calibration procedure.

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

- 1 : Compass switch
2 : Compass display



Special Repair Requirement

INFOID:000000007455652

1 .PERFORM ZONE VARIATION SETTING

Perform the zone variation setting. Refer to [MWI-36, "Description"](#).

>> GO TO 2.

2 .PERFORM CALIBRATION

Perform the calibration. Refer to [MWI-36, "Description"](#).

>> Setting completion

CLOCK


< SYSTEM DESCRIPTION >

CLOCK

Component Parts Location

INFOID:000000007455653

1 : Clock



A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (METER)

Diagnosis Description

INFOID:0000000007455654

SELF-DIAGNOSIS MODE

- Information display LCD segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.

OPERATION PROCEDURE

1. Turn ignition switch ON, and switch the trip meter to "trip A" or "trip B".

NOTE:


If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0".
(The same way for "trip B".)

2. Turn ignition switch OFF.

3. While pressing the trip A/B reset switch (1), turn ignition switch ON again.


4. Make sure that the trip meter displays "0000.0".

5. Press the trip A/B reset switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)



6. The unified meter control unit is turned to self-diagnosis mode.

- Displays "888888" (1) and "8888.8" (2) in the information display LCD (3) for approximately 5 seconds and then blinks the segment dots of the information display LCD alternately.



- Water temperature gauge and fuel gauge return to zero, and at the same time.


NOTE:

- Check combination meter power supply and ground circuit when self-diagnosis mode of combination meter does not start. Replace combination meter if normal.
- If any of the segments is not displayed, replace combination meter.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

7. Each meter activates during pressing trip A/B reset switch.



NOTE:

- If any of the meter and gages is not activated, replace combination meter.
- The figure is reference.

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

CONSULT Function (METER/M&A)

INFOID:0000000007455655

CONSULT APPLICATION ITEMS

CONSULT can perform the following diagnosis modes with CAN communication with the unified meter and A/C amp.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	Unified meter and A/C amp. checks the conditions and displays memorized error.
	Data Monitor	Displays unified meter and A/C amp. input/output data in real time.
	Ecu Identification	The unified meter and A/C amp. part number is displayed.

SELF DIAG RESULT

Refer to [MWI-107, "DTC Index".](#)

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h] or [mph]	X	<p>Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line.</p> <p>NOTE: 655.35 is displayed when the malfunction signal is received.</p>
SPEED OUTPUT [km/h] or [mph]	X	<p>Vehicle speed signal value transmitted to other units with CAN communication line.</p> <p>NOTE: 655.35 is displayed when the malfunction signal is received.</p>
ODO OUTPUT [km/h] or [mph]		Odometer signal value transmitted to other units with CAN communication line.
TACHO METER [rpm]	X	<p>Value of the engine speed signal received from ECM with CAN communication line.</p> <p>NOTE: 8191.875 is displayed when the malfunction signal is received.</p>
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°C] or [°F]	X	<p>Value of engine coolant temperature signal received from ECM with CAN communication line.</p> <p>NOTE: 215 is displayed when the malfunction signal is input.</p>
FUEL CAP W/L [On/Off]		Status of fuel filler cap warning display detected from fuel filler cap warning display signal received from ECM via CAN communication.
ABS W/L [On/Off]		Status of ABS warning lamp judged from ABS warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
VDC/TCS IND [On/Off]		Status of VDC OFF indicator lamp judged from VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
SLIP IND [On/Off]		Status of VDC warning lamp judged from VDC warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
BRAKE W/L [On/Off]		<p>Status of brake warning lamp judged from brake warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.</p> <p>NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.</p>
DOOR W/L [On/Off]		Status of door warning judged from door switch signal received from BCM with CAN communication line.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
HI-BEAM IND [On/Off]		Status of high beam indicator lamp judged from high beam request signal received from BCM with CAN communication line.
TURN IND [On/Off]		Status of turn indicator lamp judged from turn indicator signal received from BCM with CAN communication line.
FR FOG IND [Off]		Status of front fog light indicator lamp detected from front fog light request signal is received from BCM via CAN communication.
RR FOG IND [Off]		This item is displayed, but cannot be monitored.
LIGHT IND [On/Off]		Status of tail lamp indicator lamp judged from position light request signal received from BCM with CAN communication line.
OIL W/L [On/Off]		Status of oil pressure warning lamp judged from oil pressure switch signal received from IPDM E/R with CAN communication line.
MIL [On/Off]		Status of malfunction indicator lamp judged from malfunctioning indicator lamp signal received from ECM with CAN communication line.
GLOW IND [Off]		This item is displayed, but cannot be monitored.
C-ENG2 W/L [Off]		This item is displayed, but cannot be monitored.
CRUISE IND [On/Off]		Status of CRUISE indicator judged from ASCD status signal received from ECM with CAN communication line.
SET IND [On/Off]		<ul style="list-style-type: none"> • Status of SET indicator judged from ASCD status signal received from ECM with CAN communication line. • Status of SET indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
CRUISE W/L [On/Off]		Status of CRUISE warning lamp judged from ICC warning lamp signal received from ICC sensor integrated unit with CAN communication line.
BA W/L [Off]		Status of IBA OFF indicator lamp judged from IBA OFF indicator lamp signal received ICC sensor integrated unit with CAN communication line.
ATC/T-AMT W/L [On/Off]		Status of A/T check warning lamp judged from A/T check indicator signal received from TCM with CAN communication line.
4WD W/L [On/Off]		Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line.
4WD LOCK IND [Off]		This item is displayed, but cannot be monitored.
FUEL W/L [On/Off]		Low-fuel warning status judged by the identified fuel level.
WASHER W/L [On/Off]		Status of washer warning judged from washer level switch input to combination meter.
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp judged from TPMS malfunction warning lamp signal received from BCM with CAN communication line.
KEY G/Y W/L [On/Off]		Status of key warning lamp (G/Y) judged from key warning signal received from BCM with CAN communication line.
AFS OFF IND [On/Off]		Status of AFS OFF indicator lamp judged from AFS OFF indicator lamp signal received from AFS control unit with CAN communication line.
4WAS/RAS W/L [Off]		This item is displayed, but cannot be monitored.
DDS W/L [Off]		This item is displayed, but cannot be monitored.
LANE W/L [On/Off]		Status of lane departure warning lamp judged from lane departure warning lamp signal received from lane camera unit with CAN communication line.
LDP IND [On/Off]		Status of LDP ON indicator lamp judged from LDP ON indicator lamp signal received from lane camera unit with CAN communication line.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
DCA IND [On/Off]		Status of DCA switch indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
BSW W/L [On/Off]		Status of BSW warning lamp judged from BSW warning lamp signal received from BSW control module with CAN communication line.
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY, OUTKY, LK WN]		Displays status of Intelligent Key system warning judged from meter display signal received from BCM with CAN communication line.
ACC TARGET [On/Off]		Status of vehicle ahead detection indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC DISTANCE [Off, SHORT, MID, LONG]		Status of set distance indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC OWN VHL [On/Off]		Status of own vehicle indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC SET SPEED		Status of set vehicle speed indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC UNIT [On/Off]		Status of display unit judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
SHIFT IND [P, R, N, D, L, M1, M2, M3, M4, M5, M6, M7]		Status of shift position indicator judged from shift position signal and manual mode indicator signal received from TCM with CAN communication line.
O/D OFF SW [Off]		This item is displayed, but cannot be monitored.
AT S MODE SW [On/Off]		Status of snow mode switch.
AT P MODE SW [Off]		This item is displayed, but cannot be monitored.
M RANGE SW [On/Off]		Status of manual mode switch.
NM RANGE SW [On/Off]		Status of non-manual mode switch.
AT SFT UP SW [On/Off]		Status of manual mode shift up switch.
AT SFT DWN SW [On/Off]		Status of manual mode shift down switch.
ST SFT UP SW [Off]		This item is displayed, but cannot be monitored.
ST SFT DWN SW [Off]		This item is displayed, but cannot be monitored.
COMP F/B SIG [On/Off]		A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.
4WD LOCK SW [Off]		This item is displayed, but cannot be monitored.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch (driver side).
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
DISTANCE [km]		Value of possible driving distance calculated by unified meter and A/C amp.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
OUTSIDE TEMP [°C] or [°F]		<p>Ambient air temperature value converted from ambient sensor signal received from ambient sensor.</p> <p>NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)</p>
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit with CAN communication line.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is judged with the buzzer output signal received from each unit with CAN communication line and the warning output condition of the combination meter.

NOTE:

Some items are not available according to vehicle specification.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007455656

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-15, "How to Use CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000007455657

DTCT DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000007455658

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-42, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:0000000007455659

Initial diagnosis of unified meter and A/C amp.

DTC Logic

INFOID:0000000007455660

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	If any malfunction is detected during initial diagnosis of unified meter and A/C amp. CAN controller	Unified meter and A/C amp.

Diagnosis Procedure

INFOID:0000000007455661

1.REPLACE UNIFIED METER AND A/C AMP.

When DTC "U1010" is detected, replace unified meter and A/C amp.

>> INSPECTION END

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

B2201 COMMUNICATION ERROR 1

< DTC/CIRCUIT DIAGNOSIS >

B2201 COMMUNICATION ERROR 1

Description

INFOID:0000000007455662

The communication line (LCD <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

DTC Logic

INFOID:0000000007455663

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2201	COMM ERROR 1	If a communication error is present in the communication line (LCD <-> AMP.) for 2 seconds or more	Communication line (LCD <-> AMP.) circuit

Diagnosis Procedure

INFOID:0000000007455664

1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector and unified meter and A/C amp. harness connector.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
M53	24	M66	14	Existed
	25		34	

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	24		
	25		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector and ground.

B2201 COMMUNICATION ERROR 1

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Voltage (Approx.)
(+)	(-)	
Unified meter and A/C amp.	Ground	
Connector	Terminal	
M66	14	12 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Combination meter	Ground	
Connector	Terminal	
M53	25	5 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter.

A

B

C

D

E

F

G

H

J

K

L

M

MWI

O

P

B2202 COMMUNICATION ERROR 2

< DTC/CIRCUIT DIAGNOSIS >

B2202 COMMUNICATION ERROR 2

Description

INFOID:0000000007455665

The communication line (METER <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the combination meter.

DTC Logic

INFOID:0000000007455666

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2202	COMM ERROR 2	If a communication error is present in the communication line (METER <-> AMP.) for 2 seconds or more	Communication line (METER <-> AMP.) circuit

Diagnosis Procedure

INFOID:0000000007455667

1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector and unified meter and A/C amp. harness connector.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
M53	2	M66	27	Existed
	3		7	

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		Not existed
M53	2		
	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector and ground.

B2202 COMMUNICATION ERROR 2

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Voltage (Approx.)	
(+)	(-)		
Unified meter and A/C amp.			
Connector	Terminal		
M66	27	Ground	5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector and ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
Combination meter			
Connector	Terminal		
M53	3	Ground	5 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter.

A

B

C

D

E

F

G

H

J

K

L

M

MWI

O

P

B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2205 VEHICLE SPEED

Description

INFOID:0000000007455668

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication to unified meter and A/C amp.

DTC Logic

INFOID:0000000007455669

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2205	VEHICLE SPEED	If the abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more	<ul style="list-style-type: none">• Wheel sensor• ABS actuator and electric unit (control unit)

Diagnosis Procedure

INFOID:0000000007455670

1. PERFORM SELF-DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnostic Result" of ABS actuator and electric unit (control unit), and repair or replace malfunctioning parts.

>> Refer to [BRC-31, "CONSULT Function"](#).

B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2267 ENGINE SPEED

Description

INFOID:0000000007455671

The engine speed signal is transmitted from ECM to the unified meter and A/C amp. with CAN communication.

DTC Logic

INFOID:0000000007455672

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2267	ENGINE SPEED	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more	<ul style="list-style-type: none">• Crankshaft position sensor (POS)• ECM

Diagnosis Procedure

INFOID:0000000007455673

1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnostic Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-136, "CONSULT Function"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

B2268 WATER TEMP

Description

INFOID:0000000007455674

The engine coolant temperature signal is transmitted from ECM to the unified meter and A/C amp. via CAN communication.

DTC Logic

INFOID:0000000007455675

DTCT DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2268	WATER TEMP	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	<ul style="list-style-type: none">• Engine coolant temperature sensor• ECM

Diagnosis Procedure

INFOID:0000000007455676

1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-136, "CONSULT Function"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000007455677

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

Terminals			Ignition switch position	Value (Approx.)
(+)		(-)		
Combination meter	Terminal	Signal name		
M53	1	Battery power supply	Ground	OFF
	21	Ignition signal		ON

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

Combination meter		Continuity
Connector	Terminal	
M53	5	Ground
	15	
	22	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

UNIFIED METER AND A/C AMP.

UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000007455678

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ACC or ON	19
Ignition switch ON or START	3

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector and ground.

Terminals			Ignition switch position	Value (Approx.)
(+) Unified meter and A/C amp.		(-) Terminal		
M67	54	Battery power supply	Ground	OFF
	41	ACC power supply		ACC
	53	Ignition signal		ON

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter and A/C amp.		Ground	Continuity
Connector	Terminal		
M67	55		
	71		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000007671079

1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

Signal name	Fuses and fusible link No.
Battery power supply	C
	50
	51

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Voltage (Approx.)	
(+)			
IPDM E/R			
Connector	Terminal		
E4	1	Ground	
		Battery voltage	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

IPDM E/R		Continuity
Connector	Terminal	Ground
E5	12	
E6	41	

Does continuity exist?

YES >> INSPECTION END

NO >> Repair the harness or connector.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Description

INFOID:0000000007455680

The fuel level sensor unit and fuel pump (main) and the fuel level sensor unit (sub) detect the fuel level in the fuel tank and transmit the fuel gauge signal to the unified meter and A/C amp.

Component Function Check

INFOID:0000000007455681

1. PERFORM SELF-DIAGNOSIS OF UNIFIED METER AND A/C AMP.

Perform "Self Diagnosis" of unified meter and A/C amp. with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [MWI-107, "DTC Index"](#).

NO >> GO TO 2.

2. PERFORM COMPONENT FUNCTION CHECK (1)

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump (main) connector and fuel level sensor unit (sub) connector.
3. Connect variable resistor between harness connector terminals located on the vehicle side of the fuel level sensor unit and fuel pump (main) and fuel level sensor unit (sub).

Fuel level sensor unit and fuel pump (main)		Fuel level sensor unit (sub)	
Connector	Terminals	Connector	Terminals
B22	5	B21	1

4. Set variable resistor according to the resistance value shown in the following table and turn ignition switch ON.

Resistance (Ω) [*] (Approx.)	Fuel gauge indication position (Approx.)
Less than 6.0	Full
25.5	3/4
45.5	2/4
66.0	1/4
More than 80.0	Empty

*: Reference resistance values used when the combination meter judges the indication position of the fuel gauge.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM COMPONENT FUNCTION CHECK (2)

Check the fuel level sensor unit and fuel pump (main) and/or fuel level sensor unit (sub). Refer to [MWI-60, "Component Inspection"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit and fuel pump (main) and/or fuel level sensor unit (sub). Refer to [FL-6, "Removal and Installation"](#).

4. CHECK DATA MONITOR OF UNIFIED METER AND A/C AMP.

Select "FUEL METER" that is the data monitor item of "METER/M&A". Apply resistance according to the table below and check the monitor value.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Resistance (Ω) (Approx.)	Reference value of data monitor [L]
Less than 6.0	Approx. 72
25.5	Approx. 60
45.5	Approx. 42
66.0	Approx. 23
More than 80.0	Approx. 11

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-134, "Removal and Installation"](#).
NO >> Refer to [MWI-59, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007455682

1.CHECK FUEL LEVEL SENSOR (SUB) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector and fuel level sensor unit (sub) connector.
3. Check continuity between unified meter and A/C amp. harness connector and fuel level sensor unit (sub) harness connector.

Unified meter A/C amp.		Fuel level sensor unit (sub)		Continuity
Connector	Terminal	Connector	terminal	
M67	42	B21	1	Existed

4. Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter A/C amp.		Ground	Continuity
Connector	Terminal		Not existed
M67	42		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2.CHECK FUEL LEVEL SENSOR (MAIN-SUB) CIRCUIT

1. Disconnect fuel level sensor unit and fuel pump (main) connector.
2. Check continuity between fuel level sensor unit (sub) harness connector and fuel level sensor unit and fuel pump (main) harness connector.

Fuel level sensor unit (sub)		Fuel level sensor unit and fuel pump (main)		Continuity
Connector	Terminal	Connector	terminal	
B21	2	B22	2	Existed

3. Check continuity between fuel level sensor unit (sub) harness connector and ground.

Fuel level sensor unit (sub)		Ground	Continuity
Connector	Terminal		Not existed
B21	2		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK FUEL LEVEL SENSOR (MAIN) CIRCUIT

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between fuel level sensor unit and fuel pump (main) harness connector and unified meter and A/C amp. harness connector.

Fuel level sensor unit and fuel pump (main)		Unified meter A/C amp.		Continuity
Connector	Terminal	Connector	terminal	
B22	5	M67	58	Existed

Is the inspection result normal?

- YES >> Replace unified meter and A/C amp. Refer to [MWI-135, "Removal and Installation"](#).
 NO >> Repair harness or connector.

Component Inspection


INFOID:0000000007455683

1.CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)

1. Remove the fuel level sensor unit and fuel pump (main). Refer to [FL-6, "Removal and Installation"](#).
2. Check the resistance between fuel level sensor unit and fuel pump (main).

Fuel level sensor unit and fuel pump (main)		Condition*	Resistance (Approx.)
Terminal			
2	5	Full (A)	2.5 Ω
		Empty (B)	81.5 Ω

*: When float rod is contact with stopper.



JPNIA0841ZZ

Standard float position

Float position [mm (in)]*	
Full (A)	Approx. 192 (7.56)
Empty (B)	Approx. 32 (1.26)

*: When float rod is contact with stopper.

Is the inspection result normal?


- YES >> GO TO 2.
 NO >> Replace fuel level sensor unit and fuel pump (main). Refer to [FL-6, "Removal and Installation"](#).

2.CHECK FUEL LEVEL SENSOR UNIT (SUB)

1. Remove the fuel level sensor unit (sub). Refer to [FL-6, "Removal and Installation"](#).
2. Inspect the resistance of fuel level sensor unit (sub).

Fuel level sensor unit (sub)		Condition*	Resistance (Approx.)
Terminal			
1	2	Full (A)	2.5 Ω
		Empty (B)	42.5 Ω

*: When float rod is contact with stopper.



JPNIA0842ZZ

Standard float position

Float position [mm (in)]*	
Full (A)	Approx. 35 (1.38)
Empty (B)	Approx. 203 (7.99)

*: When float rod is contact with stopper.

Is the inspection result normal?

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub). Refer to [FL-6, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

METER CONTROL SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000007455684

Transmits the following signals to the combination meter.

- + (Illumination control) switch signal (+)
- - (Illumination control) switch signal (-)
- (select) switch signal
- (enter) switch signal

Diagnosis Procedure

INFOID:0000000007455685

1. CHECK METER CONTROL SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Measure voltage between the following terminals of the combination meter.

Combination meter			Condition	Voltage (Approx.)
Connector	Terminal			
	(+)	(-)		
M53	36	16	When (select) switch is pressed	0 V
			Other than the above	5 V
	37	16	When (enter) switch is pressed	0 V
			Other than the above	5 V
	39	16	When - (illumination control) switch is pressed	0 V
			Other than the above	5 V
	40	16	When + (illumination control) switch is pressed	0 V
			Other than the above	5 V

Is the inspection result normal?

YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector and meter control switch harness connector.

Combination meter		Meter control switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	16	M54	2	Existed
	36		6	
	37		7	
	39		3	
	40		1	

4. Check continuity between combination meter harness connector and ground.

METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Ground	Continuity
Connector	Terminal		
M53	16		
	36		
	37		Not existed
	39		
	40		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:000000007455686

1.CHECK METER CONTROL SWITCH UNIT

1. Turn ignition switch OFF.
2. Disconnect the meter control switch connector.
3. Check continuity between the following terminals of the meter control switch.

Combination meter		Operation and status		Continuity
Connector	Terminal			
M54	6	2	Press ● (select) switch	Existed
			Other than the above	Not existed
	7	2	Press □ (enter) switch	Existed
			Other than the above	Not existed
	3	2	Press ⚡- (illumination control) switch	Existed
			Other than the above	Not existed
	1	2	Press ⚡+ (illumination control) switch	Existed
			Other than the above	Not existed

Is inspection result normal?

YES >> INSPECTION END

NO >> Replace meter control switch.

A

B

C

D

E

F

G

H

I

J

K

L

MWI

O

P

TRIP A/B RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TRIP A/B RESET SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000007455687

Transmits the trip A/B reset switch signals to the combination meter.

Diagnosis Procedure

INFOID:0000000007455688

1.CHECK TRIP A/B RESET SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Measure voltage between the combination meter harness connector terminals.

Combination meter		Condition		Voltage (Approx.)
Connector	Terminal	(+)	(-)	
M53	38	16	When trip A/B reset switch is pressed	0 V
			Other than the above	5 V

Is the inspection result normal?

YES >> INSPECTION END
NO >> GO TO 2.

2.CHECK TRIP A/B RESET SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector and trip A/B reset switch harness connector.

Combination meter		Trip A/B reset switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	38	M56	1	Existed
	16		2	

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	38		Not existed
	16		

Is the inspection result normal?

YES >> INSPECTION END
NO >> Repair harness or connector.

Component Inspection

INFOID:0000000007455689

1.CHECK TRIP A/B RESET SWITCH UNIT

1. Turn ignition switch OFF.
2. Disconnect the trip A/B reset switch connector.
3. Check continuity between the trip A/B reset switch connector terminals.

TRIP A/B RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Trip A/B reset switch	Operation and status		Continuity
Terminal	1	2	
		Press trip A/B reset switch	Existed
		Other than the above	Not existed

Is inspection result normal?

YES >> INSPECTION END

NO >> Replace trip A/B reset switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

OIL PRESSURE SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000007455690

Detects the engine oil pressure and transmits the oil pressure switch signal to IPDM E/R.

Component Function Check

INFOID:0000000007455691

1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

"OIL W/L"

Ignition switch ON	: On
Engine running	: Off

>> INSPECTION END

Diagnosis Procedure

INFOID:0000000007455692

1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector and oil pressure switch harness connector.

IPDM E/R		Oil pressure switch		Continuity
Connector	Terminal	Connector	Terminal	
E7	75	F37	1	Existed

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E7	75		Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.


Component Inspection

INFOID:0000000007455693

1. CHECK OIL PRESSURE SWITCH UNIT

Check continuity between oil pressure switch and ground.

Condition	Continuity
Engine stopped	Existed
Engine running	Not existed



Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace oil pressure switch.

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000007455694


Transmits the parking brake switch signal to the combination meter.

Diagnosis Procedure

INFOID:0000000007455695

1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the voltage and waveform between combination meter harness connector and ground.

Terminals		Condition	Voltage and waveform		
(+) (-)					
Combination meter	Connector Terminal				
M53	27	Ground	Parking brake applied		
			Approx. 0 V		
M53	27	Ground	Parking brake released		
			 JSNIA0007GB		

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector and parking brake switch harness connector.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	27	E107	1	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	27		Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.

Component Inspection

INFOID:0000000007455696

1. CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-90, "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace parking brake switch.

WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WASHER LEVEL SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000007455697

Transmits the washer level switch signal to the combination meter.

Diagnosis Procedure

INFOID:0000000007455698

1.CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and washer level switch connector.
3. Check continuity between combination meter harness connector and washer level switch harness connector.

Combination meter		Washer level switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	31	E32	1	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	31		Not existed

5. Check continuity between washer level switch harness connector and ground.

Washer level switch		Ground	Continuity
Connector	Terminal		
E32	2		Existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.

Component Inspection

INFOID:0000000007455699

1.CHECK WASHER LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect washer level switch connector.
3. Check washer level switch.

Terminal		Condition	Continuity
1	2	Washer fluid level is low (washer level switch ON)	Existed
		Washer fluid level is normal (washer level switch OFF)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace washer level switch. Refer to [WW-113, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P


COMPASS

< DTC/CIRCUIT DIAGNOSIS >

COMPASS

Wiring Diagram - COMPASS -

INFOID:0000000007455700



COMPASS

2009/07/16

JCNWA2732GB

COMPASS

< DTC/CIRCUIT DIAGNOSIS >

COMPASS			
Connector No.	M1	Connector No.	R6
Connector Name	FUSE BLOCK (J/8)	Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Type	NS36FW-M2	Connector Type	NA07FB
			
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1A GR	-	1 G	G
2A G	-	2 SHIELD	-
3A L	-	3 L	-
4A P	-	4 BR	- [With automatic drive positioner] - [Without automatic drive positioner]
5A V	-	5 W	-
6A Y	-	6 G	-
7A R	-	7 BR	-
8A L	-	8 Y	-
9A R	-	9 B	-
10A Y	-	10 Y	-
11A V	-	11 V	-
12A BR	-	12 BR	-
13A R	-	13 R	-
14A W	-	14 W	-
15A BR	-	15 E5	-
16A B	-	16 B	-
17A B	-	18 B	-
18A G	-	19	
19A B	-	20	
20A G	-		
Connector No.	R3	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR	6	B
Connector Type	TH10FB-NH	7	W
			
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1A LG	-	6 BR	IGN
2A R	- [With NAVI]	8 G	GND
3A Y	- [Without NAVI]	10 G	BAT
4A BR	- [Without NAVI]		
5A G	- [With NAVI]		
6A B	- [Without NAVI]		
7A G	-		
8A B	-		
9A B	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B	-		
20A B	-		
Connector No.	R1	Terminal Color Of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	6	BR
Connector Type	NA10FW-C510	8	G
			
Terminal Color Of Wire No.	Signal Name [Specification]	10	G
3B P	-		
4B G	-		
5B EG	-		
6B Y	-		
7B P	-		
8B R	-		
9B SB	-		
10A B	-		
11A B	-		
12A B	-		
13A B	-		
14A B	-		
15A B	-		
16A B	-		
17A B	-		
18A B	-		
19A B</			


CLOCK

< DTC/CIRCUIT DIAGNOSIS >

CLOCK

Wiring Diagram - CLOCK -

INFOID:0000000007455701




CLOCK

2008/08/28


JCNWA1799GB

CLOCK

< DTC/CIRCUIT DIAGNOSIS >



Terminal No.	Color Of Wire	Signal Name [Specification]
3B	P	-
4B	G	-
5B	BS	-
6B	Y	-
7B	P	-
8B	R	-
9B	Sb	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	ILLUMINATION (-)
2	R	ILLUMINATION (+)
3	B	GROUND
4	Y	BAT

JRNWE1254GB

O

P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION COMBINATION METER


Reference Value

INFOID:000000007455702

VALUES ON THE DIAGNOSIS TOOL



Refer to [MWI-89, "Reference Value".](#)

TERMINAL LAYOUT







JPNIA1324ZZ

PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	—
2 (LG)	Ground	Communication signal (METER→AMP.)	Output	Ignition switch ON	—  JSNIA0027GB
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—  JSNIA0027GB
5 (B)	Ground	Ground	—	Ignition switch ON	0 V
6 (P)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON
					Battery voltage
7 (BR)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON
					0 V
10 (G)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON
					12 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
16 (B)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
21 (BG)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (BR)	Ground	Communication signal (LCD→AMP.)	Output	Ignition switch ON	—	 JSNIA0028GB
25 (Y)	Ground	Communication signal (AMP.→LCD)	Input	Ignition switch ON	—	 JSNIA0027GB
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies depending on the specification (destination unit).  JSNIA0012GB
27 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake is applied	0 V
					Parking brake is released	 JSNIA0007GB
28 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	5 V
					The brake fluid level is lower than the low level	0 V

A

B

C

D

E

F

G

H

I

J

K

L

M


MWI

O

P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
29 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
30 (G)	Ground	Seat belt buckle switch signal (passenger side)	Input	Ignition switch ON	• When getting in the passenger seat • When passenger seat belt is fastened	12 V
					• When getting in the passenger seat • When passenger seat belt is unfastened	0 V
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
33 (B)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.	NOTE: When brightness level is midway  <small>JSNIA0010GB</small>
36 (LG)	16 (B)	Select switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
37 (SB)	16 (B)	Enter switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
38 (L)	16 (B)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
39 (P)	16 (B)	Illumination control switch signal (-)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V
40 (BG)	16 (B)	Illumination control switch signal (+)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:0000000007455703



2010/09/21


JCNWA3389GE

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

- : With NAVI
- : Without NAVI
- : With ICC


* : This connector is not shown in "Harness Layout".



JCNWA3390GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWA3391GB

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER						
Connector No.	B1	Connector Name	WIRE TO WIRE	Terminal Color Of Wire	Signal Name [Specification]	Connector No.
Connector Type	THB9W-CS16/TM4			3	R	
				4	G	
				5	Y	
				6	W	
				7	B	
				8	S	
				9	GR	
				10	BL	
				11	RD	
				12	BR	
				13	LG	
				14	GR	
				15	IG	
				17	W	
				18	S	
				19	LG	
				20	BR	
				21	SHEILD	
				22	Y	
				24	P	
				27	B	
				28	R	
				29	W	
				30	SHEILD	
				31	W	
				33	S	
				34	L	
				35	P	
				36	W	
				37	P	
				38	BP	
				39	Y	
				41	Y	
				43	GR	
				45	GR	
				46	LG	
				47	SB	
				49	G	
				50	Y	
				34	W	

Connector No.	B13	Connector Name	SEA BELT BUCKLE SWITCH (DRIVER SIDE)	Terminal Color Of Wire	No.	Signal Name [Specification]
Connector Type	THB4P-W-NH			1	P	-
				2	W	-
				3	B	-
				4	R	-
				5	B	-

Connector No.	E12	Connector Name	WIRE TO WIRE	Terminal Color Of Wire	No.	Signal Name [Specification]
Connector Type	THB4P-G-RS			1	P	-
				2	W	-
				3	B	-
				4	R	-
				5	B	-

Connector No.	E13	Connector Name	WIRE TO WIRE	Terminal Color Of Wire	No.	Signal Name [Specification]
Connector Type	THA36WB-HS10-SZ2			1	P	-
				2	W	-
				3	B	-
				4	R	-
				5	B	-

Connector No.	B21	Connector Name	GUI LIGHT SENSOR(BIN1)(SUB)	Terminal Color Of Wire	No.	Signal Name [Specification]
Connector Type	ED2-FG7-R5			1	Y	-
				2	W	-

Connector No.	E19	Connector Name	WIRE TO WIRE	Terminal Color Of Wire	No.	Signal Name [Specification]
Connector Type	THB4P-G-RS			1	P	-
				2	W	-

JRNWE1245GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER									
Connector No.	35	SB	-	6	BG	DP RL	Terminal [Color Of Wire]	Signal Name [Specification]	
Connector Name	40	BG	-	56	LG	DP RR	No.	Wire	
Connector Type	41	G	-	57	G	DP FR	1	R	IGNITION
Connector No.	42	Y	-	58	V	DS FR	2	L	ITS COMM-H
Connector Name	43	BR	-	69	BR	DS RL	3	L	CAN-H
Connector Type	44	BG	-	70	BG	CAN-L	4	B	GND
Connector No.	75	P	-	74	-	BUS-I	5	P	ITS COMM-L
Connector Name	75	S8	-	75	-	BUS-II	6	P	CAN-L
Connector Type	76	Y	-	76	-				
Connector No.	77	R	-	77	-				
Connector Name	80	W	-	78	-				
Connector Type	THOBFW-NH			79	-				
Connector No.	35	SB	-	80	-				
Connector Name	40	BG	-	81	-				
Connector Type	41	G	-	82	-				
Connector No.	42	Y	-	83	-				
Connector Name	43	BR	-	84	-				
Connector Type	44	BG	-	85	-				
Connector No.	75	P	-	86	-				
Connector Name	75	S8	-	87	-				
Connector Type	76	Y	-	88	-				
Connector No.	77	R	-	89	-				
Connector Name	80	W	-	90	-				
Connector Type	THOBFW-NH			91	-				
Connector No.	35	SB	-	92	-				
Connector Name	40	BG	-	93	-				
Connector Type	41	G	-	94	-				
Connector No.	42	Y	-	95	-				
Connector Name	43	BR	-	96	-				
Connector Type	44	BG	-	97	-				
Connector No.	75	P	-	98	-				
Connector Name	75	S8	-	99	-				
Connector Type	76	Y	-	100	-				
Connector No.	77	R	-	101	-				
Connector Name	80	W	-	102	-				
Connector Type	THOBFW-C516-TM4			103	-				
Connector No.	35	SB	-	104	-				
Connector Name	40	BG	-	105	-				
Connector Type	41	G	-	106	-				
Connector No.	42	Y	-	107	-				
Connector Name	43	BR	-	108	-				
Connector Type	44	BG	-	109	-				
Connector No.	75	P	-	110	-				
Connector Name	75	S8	-	111	-				
Connector Type	76	Y	-	112	-				
Connector No.	77	R	-	113	-				
Connector Name	80	W	-	114	-				
Connector Type	THOBFW-C516-TM4			115	-				
Connector No.	35	SB	-	116	-				
Connector Name	40	BG	-	117	-				
Connector Type	41	G	-	118	-				
Connector No.	42	Y	-	119	-				
Connector Name	43	BR	-	120	-				
Connector Type	44	BG	-	121	-				
Connector No.	75	P	-	122	-				
Connector Name	75	S8	-	123	-				
Connector Type	76	Y	-	124	-				
Connector No.	77	R	-	125	-				
Connector Name	80	W	-	126	-				
Connector Type	THOBFW-C516-TM4			127	-				
Connector No.	35	SB	-	128	-				
Connector Name	40	BG	-	129	-				
Connector Type	41	G	-	130	-				
Connector No.	42	Y	-	131	-				
Connector Name	43	BR	-	132	-				
Connector Type	44	BG	-	133	-				
Connector No.	75	P	-	134	-				
Connector Name	75	S8	-	135	-				
Connector Type	76	Y	-	136	-				
Connector No.	77	R	-	137	-				
Connector Name	80	W	-	138	-				
Connector Type	THOBFW-C516-TM4			139	-				
Connector No.	35	SB	-	140	-				
Connector Name	40	BG	-	141	-				
Connector Type	41	G	-	142	-				
Connector No.	42	Y	-	143	-				
Connector Name	43	BR	-	144	-				
Connector Type	44	BG	-	145	-				
Connector No.	75	P	-	146	-				
Connector Name	75	S8	-	147	-				
Connector Type	76	Y	-	148	-				
Connector No.	77	R	-	149	-				
Connector Name	80	W	-	150	-				
Connector Type	THOBFW-C516-TM4			151	-				
Connector No.	35	SB	-	152	-				
Connector Name	40	BG	-	153	-				
Connector Type	41	G	-	154	-				
Connector No.	42	Y	-	155	-				
Connector Name	43	BR	-	156	-				
Connector Type	44	BG	-	157	-				
Connector No.	75	P	-	158	-				
Connector Name	75	S8	-	159	-				
Connector Type	76	Y	-	160	-				
Connector No.	77	R	-	161	-				
Connector Name	80	W	-	162	-				
Connector Type	THOBFW-C516-TM4			163	-				
Connector No.	35	SB	-	164	-				
Connector Name	40	BG	-	165	-				
Connector Type	41	G	-	166	-				
Connector No.	42	Y	-	167	-				
Connector Name	43	BR	-	168	-				
Connector Type	44	BG	-	169	-				
Connector No.	75	P	-	170	-				
Connector Name	75	S8	-	171	-				
Connector Type	76	Y	-	172	-				
Connector No.	77	R	-	173	-				
Connector Name	80	W	-	174	-				
Connector Type	THOBFW-C516-TM4			175	-				
Connector No.	35	SB	-	176	-				
Connector Name	40	BG	-	177	-				
Connector Type	41	G	-	178	-				
Connector No.	42	Y	-	179	-				
Connector Name	43	BR	-	180	-				
Connector Type	44	BG	-	181	-				
Connector No.	75	P	-	182	-				
Connector Name	75	S8	-	183	-				
Connector Type	76	Y	-	184	-				
Connector No.	77	R	-	185	-				
Connector Name	80	W	-	186	-				
Connector Type	THOBFW-C516-TM4			187	-				
Connector No.	35	SB	-	188	-				
Connector Name	40	BG	-	189	-				
Connector Type	41	G	-	190	-				
Connector No.	42	Y	-	191	-				
Connector Name	43	BR	-	192	-				
Connector Type	44	BG	-	193	-				
Connector No.	75	P	-	194	-				
Connector Name	75	S8	-	195	-				
Connector Type	76	Y	-	196	-				
Connector No.	77	R	-	197	-				
Connector Name	80	W	-	198	-				
Connector Type	THOBFW-C516-TM4			199	-				
Connector No.	35	SB	-	200	-				
Connector Name	40	BG	-	201	-				
Connector Type	41	G	-	202	-				
Connector No.	42	Y	-	203	-				
Connector Name	43	BR	-	204	-				
Connector Type	44	BG	-	205	-				
Connector No.	75	P	-	206	-				
Connector Name	75	S8	-	207	-				
Connector Type	76	Y	-	208	-				
Connector No.	77	R	-	209	-				
Connector Name	80	W	-	210	-				
Connector Type	THOBFW-C516-TM4			211	-				
Connector No.	35	SB	-	212	-				
Connector Name	40	BG	-	213	-				
Connector Type	41	G	-	214	-				
Connector No.	42	Y	-	215	-				
Connector Name	43	BR	-	216	-				
Connector Type	44	BG	-	217	-				
Connector No.	75	P	-	218	-				
Connector Name	75	S8	-	219	-				
Connector Type	76	Y	-	220	-				
Connector No.	77	R	-	221	-				
Connector Name	80	W	-	222	-				
Connector Type	THOBFW-C516-TM4			223	-				
Connector No.	35	SB	-	224	-				
Connector Name	40	BG	-	225	-				
Connector Type	41	G	-	226	-				
Connector No.	42	Y	-	227	-				
Connector Name	43	BR	-	228	-				
Connector Type	44	BG	-	229	-				
Connector No.	75	P	-	230	-				
Connector Name	75	S8	-	231	-				
Connector Type	76	Y	-	232	-				
Connector No.	77	R	-	233	-				
Connector Name	80	W	-	234	-				
Connector Type	THOBFW-C516-TM4			235	-				
Connector No.	35	SB	-	236	-				
Connector Name	40	BG	-	237	-				
Connector Type	41	G	-	238	-				
Connector No.	42	Y	-	239	-				
Connector Name	43	BR	-	240	-				
Connector Type	44	BG	-	241	-				
Connector No.	75	P	-	242	-				
Connector Name	75	S8	-	243	-				
Connector Type	76	Y	-	244	-				
Connector No.	77	R	-	245	-				
Connector Name	80	W	-	246	-				
Connector Type	THOBFW-C516-TM4			247	-				
Connector No.	35	SB	-	248	-				
Connector Name	40	BG	-	249	-				
Connector Type	41	G	-	250	-				
Connector No.	42	Y	-	251	-				
Connector Name	43	BR	-	252	-				
Connector Type	44	BG	-	253	-				
Connector No.	75	P	-	254	-				
Connector Name	75	S8	-	255	-				
Connector Type	76	Y	-	256	-				
Connector No.	77	R	-	257	-				
Connector Name	80	W	-	258	-				
Connector Type	THOBFW-C516-TM4			259	-				
Connector No.	35	SB	-	260	-				
Connector Name	40	BG	-	261	-				
Connector Type	41	G	-	262	-				
Connector No.	42	Y	-	263	-				
Connector Name	43	BR	-	264	-				
Connector Type	44	BG	-	265	-				
Connector No.	75	P	-	266	-				
Connector Name	75	S8	-	267	-				
Connector Type	76	Y	-	268	-				
Connector No.	77	R	-	269	-				
Connector Name	80	W	-	270	-				
Connector Type	THOBFW-C516-TM4			271	-				
Connector No.	35	SB	-	272	-				
Connector Name	40	BG	-	273	-				
Connector Type	41	G	-	274	-				

JRNWE1246GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER				Terminal Color Of Wire		Signal Name [Specification]	
Connector No.	Terminal No.	Color Of Wire	Signal Name	Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]
11	S8	-	-	74	BR	-	[With I(C)]
12	B6	-	-	74	L	-	[Without I(C)]
13	L	-	-	75	G	-	[With I(C)]
14	R	-	-	75	W	-	[Without I(C)]
15	P	-	-	76	W	-	[With I(C)]
16	V	-	-	76	Y	-	[Without I(C)]
27	S8	-	-	77	P	-	[Without I(C)]
18	V	-	-	77	R	-	[With I(C)]
20	B6	-	-	78	BR	-	[Without I(C)]
21	L	-	-	78	L	-	[With I(C)]
22	V	-	-	79	L	-	[Without I(C)]
23	G	-	-	79	Y	-	[With I(C)]
24	P	-	-	80	S8	-	-
25	Y	-	-	81	R	-	-
26	V	-	-	82	S8	-	-
27	W	-	-	83	B6	-	-
28	G	-	-	84	G	-	-
31	B6	-	-	85	L	-	-
32	W	-	-	86	P	-	-
33	B	-	-	87	V	-	-
34	R	-	-	89	GR	-	-
35	G	-	-	90	SHEILD	-	-
36	SHEILD	-	-	91	W	-	-
37	V	-	-	92	Y	-	-
38	BR	-	-	93	V	-	-
39	LG	-	-	94	LG	-	-
41	W	-	-	95	BG	-	-
42	G	-	-	96	P	-	-
43	BR	-	-	97	R	-	-
45	W	-	-	98	SHEILD	-	-
49	L	-	-	99	L	-	-
50	P	-	-	100	P	-	-
51	L	-	-				
54	B6	-	-				
57	BR	-	-				
59	W	-	-				
60	G	-	-				
63	G	-	-				
62	S8	-	-				
63	W	-	-				
64	B	-	-				
65	G	-	-				
66	R	-	-				
67	SHEILD	-	-				
68	Y	-	-				
69	LG	-	-				
70	W	-	-				
71	R	-	-				
72	Y	-	-				
73	B	-	-				

Connector No.	Terminal No.	Color Of Wire	Signal Name	Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]
E36	-	-	-	ALTERNATOR	-	-	-
HS3/B	-	-	-	HS3/B	-	-	-

Connector No.	Terminal No.	Color Of Wire	Signal Name	Connector No.	Terminal No.	Color Of Wire	Signal Name
F1	-	-	-	WIRE TO WIRE	-	-	-
HS4/S	-	-	-	5A35FB-HS4/S/2	-	-	-

Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]	Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]
E37	-	-	-	OIL PRESSURE SWITCH	-	-	-
ED1FG-HS-AR	-	-	-	ED1FG-HS-AR	-	-	-

Connector No.	Terminal No.	Color Of Wire	Signal Name	Connector No.	Terminal No.	Color Of Wire	Signal Name [Specification]
E107	-	-	-	PARKING BRAKE SWITCH	-	-	-
TB1FW	-	-	-	TB1FW	-	-	-

JRNWE1247GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER Connector No. F51 Connector Name A/F ASSEMBLY Connector Type RK101G-D0Y	Signal Name [Specification]																																																				
	1 R	-																																																			
	33 B	-																																																			
	34 B	-																																																			
Connector No. F301 Connector Name FUSE/TRANSMISSION CONTROL MODULE Connector Type SP101G																																																					
 																																																					
<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>-</td><td>VIGN</td></tr> <tr><td>2</td><td>-</td><td>BATT</td></tr> <tr><td>3</td><td>-</td><td>CANH</td></tr> <tr><td>4</td><td>-</td><td>KLINE</td></tr> <tr><td>5</td><td>-</td><td>GROUND</td></tr> <tr><td>6</td><td>-</td><td>REV LAMP RLY</td></tr> <tr><td>7</td><td>-</td><td>CAN-L</td></tr> <tr><td>8</td><td>-</td><td>START RLY</td></tr> <tr><td>9</td><td>-</td><td>GROUND</td></tr> <tr><td>10</td><td>-</td><td>WIRE TO WIRE</td></tr> </tbody> </table>			Terminal No.	Color Of Wire	Signal Name [Specification]	1	-	VIGN	2	-	BATT	3	-	CANH	4	-	KLINE	5	-	GROUND	6	-	REV LAMP RLY	7	-	CAN-L	8	-	START RLY	9	-	GROUND	10	-	WIRE TO WIRE																		
Terminal No.	Color Of Wire	Signal Name [Specification]																																																			
1	-	VIGN																																																			
2	-	BATT																																																			
3	-	CANH																																																			
4	-	KLINE																																																			
5	-	GROUND																																																			
6	-	REV LAMP RLY																																																			
7	-	CAN-L																																																			
8	-	START RLY																																																			
9	-	GROUND																																																			
10	-	WIRE TO WIRE																																																			
<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>BR</td><td>AWD CONTROL UNIT</td></tr> <tr><td>2</td><td>L</td><td>TH16FW-NH</td></tr> <tr><td>3</td><td>V</td><td>-</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> <tr><td>5</td><td>Y</td><td>-</td></tr> <tr><td>6</td><td>R</td><td>-</td></tr> <tr><td>7</td><td>P</td><td>-</td></tr> <tr><td>8</td><td>GR</td><td>-</td></tr> <tr><td>9</td><td>B</td><td>-</td></tr> <tr><td>10</td><td>4</td><td>AWD SOL BAT</td></tr> <tr><td>11</td><td>3</td><td>GROUND</td></tr> <tr><td>12</td><td>2</td><td>GROUND</td></tr> <tr><td>13</td><td>1</td><td>IGN</td></tr> <tr><td>14</td><td>16</td><td>CANH</td></tr> <tr><td>15</td><td>Y</td><td>BATTERY</td></tr> <tr><td>16</td><td>P</td><td>CANL</td></tr> </tbody> </table>			Terminal No.	Color Of Wire	Signal Name [Specification]	1	BR	AWD CONTROL UNIT	2	L	TH16FW-NH	3	V	-	4	B	-	5	Y	-	6	R	-	7	P	-	8	GR	-	9	B	-	10	4	AWD SOL BAT	11	3	GROUND	12	2	GROUND	13	1	IGN	14	16	CANH	15	Y	BATTERY	16	P	CANL
Terminal No.	Color Of Wire	Signal Name [Specification]																																																			
1	BR	AWD CONTROL UNIT																																																			
2	L	TH16FW-NH																																																			
3	V	-																																																			
4	B	-																																																			
5	Y	-																																																			
6	R	-																																																			
7	P	-																																																			
8	GR	-																																																			
9	B	-																																																			
10	4	AWD SOL BAT																																																			
11	3	GROUND																																																			
12	2	GROUND																																																			
13	1	IGN																																																			
14	16	CANH																																																			
15	Y	BATTERY																																																			
16	P	CANL																																																			
<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>BR</td><td>AWD SOL (+)</td></tr> <tr><td>2</td><td>Y</td><td>AWD SOL (-)</td></tr> <tr><td>3</td><td>W</td><td>OIL TEMP.</td></tr> <tr><td>7</td><td>G</td><td>IGN</td></tr> <tr><td>8</td><td>L</td><td>AWD SOL BAT</td></tr> <tr><td>9</td><td>BG</td><td>GROUND</td></tr> <tr><td>10</td><td>B</td><td>GROUND</td></tr> <tr><td>11</td><td>LG</td><td>IGN</td></tr> <tr><td>13</td><td>LG</td><td>OIL TEMP*</td></tr> <tr><td>15</td><td>Y</td><td>BATTERY</td></tr> <tr><td>16</td><td>P</td><td>CANL</td></tr> </tbody> </table>			Terminal No.	Color Of Wire	Signal Name [Specification]	1	BR	AWD SOL (+)	2	Y	AWD SOL (-)	3	W	OIL TEMP.	7	G	IGN	8	L	AWD SOL BAT	9	BG	GROUND	10	B	GROUND	11	LG	IGN	13	LG	OIL TEMP*	15	Y	BATTERY	16	P	CANL															
Terminal No.	Color Of Wire	Signal Name [Specification]																																																			
1	BR	AWD SOL (+)																																																			
2	Y	AWD SOL (-)																																																			
3	W	OIL TEMP.																																																			
7	G	IGN																																																			
8	L	AWD SOL BAT																																																			
9	BG	GROUND																																																			
10	B	GROUND																																																			
11	LG	IGN																																																			
13	LG	OIL TEMP*																																																			
15	Y	BATTERY																																																			
16	P	CANL																																																			
<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>2 G</td><td>-</td><td>SHIELD</td></tr> <tr><td>3 W</td><td>-</td><td>-</td></tr> <tr><td>4 R</td><td>-</td><td>-</td></tr> <tr><td>5 B</td><td>-</td><td>-</td></tr> <tr><td>9 Y</td><td>-</td><td>-</td></tr> <tr><td>10 GR</td><td>-</td><td>-</td></tr> <tr><td>19 EG</td><td>-</td><td>-</td></tr> <tr><td>20 Y</td><td>-</td><td>-</td></tr> <tr><td>28 B</td><td>-</td><td>-</td></tr> <tr><td>29 LG</td><td>-</td><td>-</td></tr> </tbody> </table>			Terminal No.	Color Of Wire	Signal Name [Specification]	2 G	-	SHIELD	3 W	-	-	4 R	-	-	5 B	-	-	9 Y	-	-	10 GR	-	-	19 EG	-	-	20 Y	-	-	28 B	-	-	29 LG	-	-																		
Terminal No.	Color Of Wire	Signal Name [Specification]																																																			
2 G	-	SHIELD																																																			
3 W	-	-																																																			
4 R	-	-																																																			
5 B	-	-																																																			
9 Y	-	-																																																			
10 GR	-	-																																																			
19 EG	-	-																																																			
20 Y	-	-																																																			
28 B	-	-																																																			
29 LG	-	-																																																			

JRNWE1248GB

A B C D E F G H I J K L M N P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

JRNWE1249GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER Connector No. M53 Connector Name COMBINATION METER Connector Type TH40RW-NH			<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>GR</td><td>BATTERY POWER SUPPLY</td></tr> <tr><td>2</td><td>LG</td><td>COMMUNICATION SIGNAL (METER->AMP)</td></tr> <tr><td>3</td><td>GR</td><td>COMMUNICATION SIGNAL (AMP->METER)</td></tr> <tr><td>5</td><td>B</td><td>GROUND</td></tr> <tr><td>6</td><td>P</td><td>ALTERNATOR SIGNAL</td></tr> <tr><td>7</td><td>BR</td><td>AIR BAG SIGNAL</td></tr> <tr><td>10</td><td>G</td><td>SECURITY SIGNAL</td></tr> <tr><td>15</td><td>B</td><td>METER CONTROL SWITCH GROUND</td></tr> <tr><td>19</td><td>B</td><td>ILLUMIN.</td></tr> <tr><td>21</td><td>EG</td><td>IGNITION SIGNAL</td></tr> <tr><td>22</td><td>B</td><td>GROUND</td></tr> <tr><td>24</td><td>BR</td><td>COMMUNICATION SIGNAL (ICD->AMP)</td></tr> <tr><td>25</td><td>Y</td><td>COMMUNICATION SIGNAL (AMP->ICD)</td></tr> <tr><td>26</td><td>R</td><td>VEHICLE SPEED SIGNAL (8 PULSE)</td></tr> <tr><td>27</td><td>V</td><td>PARKING BRAKE SWITCH SIGNAL</td></tr> <tr><td>28</td><td>W</td><td>Brake Fluid Level Switch Signal (Driver Side)</td></tr> <tr><td>29</td><td>S8</td><td>SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)</td></tr> <tr><td>30</td><td>G</td><td>SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)</td></tr> <tr><td>31</td><td>L</td><td>WASHER LEVEL SWITCH SIGNAL</td></tr> <tr><td>33</td><td>B</td><td>ILLUMINATION CONTROL SIGNAL</td></tr> <tr><td>35</td><td>LG</td><td>SELECTOR SWITCH SIGNAL</td></tr> <tr><td>37</td><td>S8</td><td>ENTER SWITCH SIGNAL</td></tr> <tr><td>38</td><td>L</td><td>TRIP A/B RESET SWITCH SIGNAL</td></tr> <tr><td>39</td><td>P</td><td>ILLUMINATION CONTROL SWITCH SIGNAL (-)</td></tr> <tr><td>40</td><td>EG</td><td>ILLUMINATION CONTROL SWITCH SIGNAL (+)</td></tr> </tbody> </table>		Terminal No.	Color Of Wire	Signal Name [Specification]	1	GR	BATTERY POWER SUPPLY	2	LG	COMMUNICATION SIGNAL (METER->AMP)	3	GR	COMMUNICATION SIGNAL (AMP->METER)	5	B	GROUND	6	P	ALTERNATOR SIGNAL	7	BR	AIR BAG SIGNAL	10	G	SECURITY SIGNAL	15	B	METER CONTROL SWITCH GROUND	19	B	ILLUMIN.	21	EG	IGNITION SIGNAL	22	B	GROUND	24	BR	COMMUNICATION SIGNAL (ICD->AMP)	25	Y	COMMUNICATION SIGNAL (AMP->ICD)	26	R	VEHICLE SPEED SIGNAL (8 PULSE)	27	V	PARKING BRAKE SWITCH SIGNAL	28	W	Brake Fluid Level Switch Signal (Driver Side)	29	S8	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)	30	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	31	L	WASHER LEVEL SWITCH SIGNAL	33	B	ILLUMINATION CONTROL SIGNAL	35	LG	SELECTOR SWITCH SIGNAL	37	S8	ENTER SWITCH SIGNAL	38	L	TRIP A/B RESET SWITCH SIGNAL	39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)	40	EG	ILLUMINATION CONTROL SWITCH SIGNAL (+)
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																
1	GR	BATTERY POWER SUPPLY																																																																																
2	LG	COMMUNICATION SIGNAL (METER->AMP)																																																																																
3	GR	COMMUNICATION SIGNAL (AMP->METER)																																																																																
5	B	GROUND																																																																																
6	P	ALTERNATOR SIGNAL																																																																																
7	BR	AIR BAG SIGNAL																																																																																
10	G	SECURITY SIGNAL																																																																																
15	B	METER CONTROL SWITCH GROUND																																																																																
19	B	ILLUMIN.																																																																																
21	EG	IGNITION SIGNAL																																																																																
22	B	GROUND																																																																																
24	BR	COMMUNICATION SIGNAL (ICD->AMP)																																																																																
25	Y	COMMUNICATION SIGNAL (AMP->ICD)																																																																																
26	R	VEHICLE SPEED SIGNAL (8 PULSE)																																																																																
27	V	PARKING BRAKE SWITCH SIGNAL																																																																																
28	W	Brake Fluid Level Switch Signal (Driver Side)																																																																																
29	S8	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)																																																																																
30	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)																																																																																
31	L	WASHER LEVEL SWITCH SIGNAL																																																																																
33	B	ILLUMINATION CONTROL SIGNAL																																																																																
35	LG	SELECTOR SWITCH SIGNAL																																																																																
37	S8	ENTER SWITCH SIGNAL																																																																																
38	L	TRIP A/B RESET SWITCH SIGNAL																																																																																
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)																																																																																
40	EG	ILLUMINATION CONTROL SWITCH SIGNAL (+)																																																																																
		<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>GR</td><td>BATTERY POWER SUPPLY</td></tr> <tr><td>2</td><td>LG</td><td>COMMUNICATION SIGNAL (METER->A/C AMP)</td></tr> <tr><td>3</td><td>GR</td><td>UNIFIED METER AND A/C AMP.</td></tr> <tr><td>4</td><td>Y</td><td>IGNITION POWER SUPPLY</td></tr> <tr><td>5</td><td>B</td><td>BATTERY POWER SUPPLY</td></tr> <tr><td>6</td><td>LG</td><td>GROUND</td></tr> <tr><td>7</td><td>Y</td><td>FUEL LEVEL SENSOR SIGNAL</td></tr> <tr><td>8</td><td>LG</td><td>INTAKE AIR TEMP SIGNAL</td></tr> <tr><td>9</td><td>Y</td><td>AMBIENT SENSOR SIGNAL</td></tr> <tr><td>10</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>11</td><td>Y</td><td>FUEL TANK TEMP SIGNAL</td></tr> <tr><td>12</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>13</td><td>Y</td><td>AMBIENT SENSOR SIGNAL</td></tr> <tr><td>14</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>15</td><td>Y</td><td>FUEL TANK TEMP SIGNAL</td></tr> <tr><td>16</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> </tbody> </table>		Terminal No.	Color Of Wire	Signal Name [Specification]	1	GR	BATTERY POWER SUPPLY	2	LG	COMMUNICATION SIGNAL (METER->A/C AMP)	3	GR	UNIFIED METER AND A/C AMP.	4	Y	IGNITION POWER SUPPLY	5	B	BATTERY POWER SUPPLY	6	LG	GROUND	7	Y	FUEL LEVEL SENSOR SIGNAL	8	LG	INTAKE AIR TEMP SIGNAL	9	Y	AMBIENT SENSOR SIGNAL	10	LG	AMBIENT SENSOR GROUND	11	Y	FUEL TANK TEMP SIGNAL	12	LG	AMBIENT SENSOR GROUND	13	Y	AMBIENT SENSOR SIGNAL	14	LG	AMBIENT SENSOR GROUND	15	Y	FUEL TANK TEMP SIGNAL	16	LG	AMBIENT SENSOR GROUND																												
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																
1	GR	BATTERY POWER SUPPLY																																																																																
2	LG	COMMUNICATION SIGNAL (METER->A/C AMP)																																																																																
3	GR	UNIFIED METER AND A/C AMP.																																																																																
4	Y	IGNITION POWER SUPPLY																																																																																
5	B	BATTERY POWER SUPPLY																																																																																
6	LG	GROUND																																																																																
7	Y	FUEL LEVEL SENSOR SIGNAL																																																																																
8	LG	INTAKE AIR TEMP SIGNAL																																																																																
9	Y	AMBIENT SENSOR SIGNAL																																																																																
10	LG	AMBIENT SENSOR GROUND																																																																																
11	Y	FUEL TANK TEMP SIGNAL																																																																																
12	LG	AMBIENT SENSOR GROUND																																																																																
13	Y	AMBIENT SENSOR SIGNAL																																																																																
14	LG	AMBIENT SENSOR GROUND																																																																																
15	Y	FUEL TANK TEMP SIGNAL																																																																																
16	LG	AMBIENT SENSOR GROUND																																																																																
		<table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color Of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr><td>1</td><td>GR</td><td>BATTERY POWER SUPPLY</td></tr> <tr><td>2</td><td>LG</td><td>COMMUNICATION SIGNAL (METER->A/C AMP)</td></tr> <tr><td>3</td><td>GR</td><td>UNIFIED METER AND A/C AMP.</td></tr> <tr><td>4</td><td>Y</td><td>IGNITION POWER SUPPLY</td></tr> <tr><td>5</td><td>B</td><td>BATTERY POWER SUPPLY</td></tr> <tr><td>6</td><td>LG</td><td>GROUND</td></tr> <tr><td>7</td><td>Y</td><td>FUEL LEVEL SENSOR SIGNAL</td></tr> <tr><td>8</td><td>LG</td><td>INTAKE AIR TEMP SIGNAL</td></tr> <tr><td>9</td><td>Y</td><td>AMBIENT SENSOR SIGNAL</td></tr> <tr><td>10</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>11</td><td>Y</td><td>FUEL TANK TEMP SIGNAL</td></tr> <tr><td>12</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>13</td><td>Y</td><td>AMBIENT SENSOR SIGNAL</td></tr> <tr><td>14</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> <tr><td>15</td><td>Y</td><td>FUEL TANK TEMP SIGNAL</td></tr> <tr><td>16</td><td>LG</td><td>AMBIENT SENSOR GROUND</td></tr> </tbody> </table>		Terminal No.	Color Of Wire	Signal Name [Specification]	1	GR	BATTERY POWER SUPPLY	2	LG	COMMUNICATION SIGNAL (METER->A/C AMP)	3	GR	UNIFIED METER AND A/C AMP.	4	Y	IGNITION POWER SUPPLY	5	B	BATTERY POWER SUPPLY	6	LG	GROUND	7	Y	FUEL LEVEL SENSOR SIGNAL	8	LG	INTAKE AIR TEMP SIGNAL	9	Y	AMBIENT SENSOR SIGNAL	10	LG	AMBIENT SENSOR GROUND	11	Y	FUEL TANK TEMP SIGNAL	12	LG	AMBIENT SENSOR GROUND	13	Y	AMBIENT SENSOR SIGNAL	14	LG	AMBIENT SENSOR GROUND	15	Y	FUEL TANK TEMP SIGNAL	16	LG	AMBIENT SENSOR GROUND																												
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																
1	GR	BATTERY POWER SUPPLY																																																																																
2	LG	COMMUNICATION SIGNAL (METER->A/C AMP)																																																																																
3	GR	UNIFIED METER AND A/C AMP.																																																																																
4	Y	IGNITION POWER SUPPLY																																																																																
5	B	BATTERY POWER SUPPLY																																																																																
6	LG	GROUND																																																																																
7	Y	FUEL LEVEL SENSOR SIGNAL																																																																																
8	LG	INTAKE AIR TEMP SIGNAL																																																																																
9	Y	AMBIENT SENSOR SIGNAL																																																																																
10	LG	AMBIENT SENSOR GROUND																																																																																
11	Y	FUEL TANK TEMP SIGNAL																																																																																
12	LG	AMBIENT SENSOR GROUND																																																																																
13	Y	AMBIENT SENSOR SIGNAL																																																																																
14	LG	AMBIENT SENSOR GROUND																																																																																
15	Y	FUEL TANK TEMP SIGNAL																																																																																
16	LG	AMBIENT SENSOR GROUND																																																																																

JRNWE1250GB


COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

JRNWE1251GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JRNWE1252GB

INFOID:0000000007455704

Fail-Safe

FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Function	Specifications
Speedometer	Reset to zero by suspending communication.
Tachometer	
Fuel gauge	
Water temperature gauge	
Illumination control	When suspending communication, change to nighttime mode.
Information display	The display turns off by suspending communication.
Buzzer	The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	The lamp turns on by suspending communication.
ABS warning lamp	
VDC warning lamp	
Brake warning lamp	
CRUISE warning lamp	
IBA OFF indicator lamp	
Malfunction indicator lamp	
High beam indicator	
Turn signal indicator lamp	
Tail lamp indicator lamp	
Oil pressure warning lamp	The lamp turns off by suspending communication.
A/T CHECK warning lamp	
AWD warning lamp	
Low tire pressure warning lamp	
Key warning lamp	
VDC OFF indicator lamp	
BSW warning lamp	
AFS OFF indicator lamp	
Lane departure warning lamp	
LDP ON indicator lamp	
Master warning lamp	

DTC Index

INFOID:000000007455705

Refer to [MWI-107, "DTC Index".](#)

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

UNIFIED METER AND A/C AMP.

Reference Value

INFOID:0000000007455706

VALUES ON THE DIAGNOSIS TOOL

CONSULT MONITOR ITEM

Monitor Item	Condition		Value/Status
SPEED METER [km/h] or [mph]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h] or [mph]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h] or [mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C] or [°F]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
FUEL CAP W/L	Ignition switch ON	Fuel filler cap warning display ON Fuel filler cap warning display OFF	On Off
ABS W/L	Ignition switch ON	ABS warning lamp ON ABS warning lamp OFF	On Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON VDC OFF indicator lamp OFF	On Off
SLIP IND	Ignition switch ON	VDC warning lamp ON VDC warning lamp OFF	On Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON Brake warning lamp OFF	On Off
DOOR W/L	Ignition switch ON	Door warning displayed Door warning not displayed	On Off
HI-BEAM IND	Ignition switch ON	Hi-beam indicator lamp ON Hi-beam indicator lamp OFF	On Off
TURN IND	Ignition switch ON	Turn indicator lamp ON Turn indicator lamp OFF	On Off
FR FOG IND	Ignition switch ON	Front fog light indicator lamp ON Front fog light indicator lamp OFF	On Off
RR FOG IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
LIGHT IND	Ignition switch ON	Tail lamp indicator lamp ON Tail lamp indicator lamp OFF	On Off

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off
MIL	Ignition switch ON	Malfunction warning lamp ON	On
		Malfunction warning lamp OFF	Off
GLOW IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
C-ENG2 W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
CRUISE IND	Ignition switch ON	CRUISE indicator displayed	On
		CRUISE indicator not displayed	Off
SET IND	Ignition switch ON	SET indicator lamp ON	On
		SET indicator lamp OFF	Off
CRUISE W/L	Ignition switch ON	CRUISE warning lamp ON	On
		CRUISE warning lamp OFF	Off
BA W/L	Ignition switch ON	IBA OFF indicator lamp ON	On
		IBA OFF indicator lamp OFF	Off
ATC/T-AMT W/L	Ignition switch ON	A/T check warning lamp ON	On
		A/T check warning lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
4WD LOCK IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
FUEL W/L	Ignition switch ON	Low-fuel warning lamp displayed	On
		Low-fuel warning lamp not displayed	Off
WASHER W/L	Ignition switch ON	Washer warning displayed	On
		Washer warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure warning lamp ON	On
		Low tire pressure warning lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	Key warning lamp ON	On
		Key warning lamp OFF	Off
AFS OFF IND	Ignition switch ON	AFS OFF indicator lamp ON	On
		AFS OFF indicator lamp OFF	Off
4WAS/RAS W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
DDS W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
LANE W/L	Ignition switch ON	Lane departure warning lamp ON	On
		Lane departure warning lamp OFF	Off
LDP IND	Ignition switch ON	LDP ON indicator lamp ON	On
		LDP ON indicator lamp OFF	Off
DCA IND	Ignition switch ON	DCA switch indicator displayed	On
		DCA switch indicator not displayed	Off

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
BSW W/L	Ignition switch ON	BSW warning lamp ON	On
		BSW warning lamp OFF	Off
LCD	Ignition switch ON	Engine start information display	B&P I
	Ignition switch ACC	Engine start information display	B&P N
	Ignition switch LOCK	Key ID warning display	ID NG
	Ignition switch LOCK	Steering lock information display	ROTAT
	Ignition switch LOCK	P position warning display	SFT P
	Ignition switch LOCK	Intelligent Key insert information display	INSRT
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT
	Ignition switch ON	Take away warning display	NO KY
	Ignition switch LOCK	Key warning display	OUTKY
	Ignition switch ON	ACC warning display	LK WN
ACC TARGET	Ignition switch ON	Vehicle ahead detection indicator displayed	On
		Vehicle ahead detection indicator not displayed	Off
ACC DISTANCE	Ignition switch ON	When following distance set to "LONG"	LONG
		When following distance set to "MIDDLE"	MID
		When following distance set to "SHORT"	SHORT
		Set distance indicator not displayed	Off
ACC OWN VHL	Ignition switch ON	Own vehicle indicator displayed	On
		Own vehicle indicator not displayed	Off
ACC SET SPEED	Ignition switch ON	Set vehicle speed indicator not displayed	Off
		Set vehicle speed indicator displayed	Indicates the set vehicle speed
ACC UNIT	Ignition switch ON	Set vehicle speed indicator unit display ON	On
		Set vehicle speed indicator unit display OFF	Off
SHIFT IND	Ignition switch ON	Shift position indicator P display	P
		Shift position indicator R display	R
		Shift position indicator N display	N
		Shift position indicator D display	D
		Shift position indicator DS display	L
		Shift position indicator M1 display	M1
		Shift position indicator M2 display	M2
		Shift position indicator M3 display	M3
		Shift position indicator M4 display	M4
		Shift position indicator M5 display	M5
		Shift position indicator M6 display	M6
		Shift position indicator M7 display	M7

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
O/D OFF SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
AT S MODE SW	Ignition switch ON	Snow mode switch ON	On
		Snow mode switch OFF	Off
AT P MODE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
M RANGE SW	Ignition switch ON	Selector lever manual mode position	On
		Other than the above	Off
NM RANGE SW	Ignition switch ON	Selector lever manual mode position	Off
		Other than the above	On
AT SFT UP SW	Ignition switch ON	Selector lever + position	On
		Other than the above	Off
AT SFT DWN SW	Ignition switch ON	Selector lever – position	On
		Other than the above	Off
ST SFT UP SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ST SFT DWN SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
COMP F/B SIG	Ignition switch ON	A/C compressor activation condition	On
		A/C compressor deactivation condition	Off
4WD LOCK SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Driver seat belt not fastened	On
		Driver seat belt fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low-fuel warning signal output	On
		Low-fuel warning signal not output	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off


NOTE:

Some items are not available according to vehicle specification.

TERMINAL LAYOUT




UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



JSNIA0097ZZ

PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
5 (L)	Ground	Manual mode shift up signal	Input	Ignition switch ON	Selector lever UP operation	0 V
					Other than the above	12 V
7 (GR)	Ground	Communication signal (AMP. → METER)	Output	Ignition switch ON	—	 SKIA3362E
8 (L)	Ground	Vehicle speed signal (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies depending on the specification (destination unit).  JSNIA0015GB
9 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When seat belt is fastened	12 V
					When seat belt is not fastened	0 V
10 (W)	Ground	Manual mode signal	Input	Ignition switch ON	Selector lever DS position	0 V
					Other than the above	12 V
11 (G)	Ground	Non-manual mode signal	Input	Ignition switch ON	Selector lever DS position	12 V
					Other than the above	0 V
14 (BR)	Ground	Communication signal (LCD → AMP.)	Input	Ignition switch ON	—	 JSNIA0028GB

A

B

6

D

E

F

G

上

1

J

K

L

M






MWI

Q

P


UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
25 (V)	Ground	Manual mode shift down signal	Input	Ignition switch ON	Selector lever down operation	0 V
					Other than the above	12 V
27 (LG)	Ground	Communication signal (METER → AMP.)	Input	Ignition switch ON	—	 SKIA3361E
28 (R)	Ground	Vehicle speed signal (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	 JSNIA0012GB
30 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake is applied	0 V
					Parking brake is released	 JSNIA0007GB
34 (Y)	Ground	Communication signal (AMP. → LCD)	Output	Ignition switch ON	—	 JSNIA0027GB
41 (V)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
42 (Y)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	 JSNIA0013GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
45 (P)	Ground	Ambient sensor signal	Input	—	—	 JSNIA0014GB
53 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
54 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
55 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
56 (L)	Ground	CAN-H	—	—	—	—
57 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	5 V
				Ignition switch ON	The brake fluid level is lower than the low level	0 V
58 (BR)	Ground	Fuel level sensor ground	—	Ignition switch ON	—	0 V
61 (BR)	Ground	Ambient sensor signal ground	—	Ignition switch ON	—	0 V
71 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
72 (P)	Ground	CAN-L	—	—	—	—

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O


P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:0000000007583081



2010/09/21


JCNWA3389GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

-  : With NAVI
-  : Without NAVI
-  : With I_C

* : This connector is not shown in "Harness Layout".




JCNWA3390GB

MWI

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



JCNWA3391GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

METER						
Connector No.	B1	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire
Connector Type	TH98W-CS16-TM4	60	P	-	19	W
Connector Name	WIRE TO WIRE	61	L	-	20	GR
Connector No.	TH98W-CS16-TM4	62	SHIELD	-	21	Y
Connector Name	SHIELD	63	R	-	22	G
Connector No.	TH98W-CS16-TM4	64	G	-	23	W
Connector Name	SHIELD	65	SB	-	25	SB
Connector No.	TH98W-CS16-TM4	66	W	-	26	R
Connector Name	SHIELD	67	V	-	27	P
Connector No.	TH98W-CS16-TM4	68	SB	-	28	GR
Connector Name	SHIELD	69	R	-	29	G
Connector No.	TH98W-CS16-TM4	70	W	-	30	Y
Connector Name	SHIELD	71	SB	-	31	LG
Connector No.	TH98W-CS16-TM4	72	LG	-	32	R
Connector Name	SHIELD	73	SB	-	33	W
Connector No.	TH98W-CS16-TM4	74	L	-	34	W
Connector Name	SHIELD	75	W	-	35	W
Connector No.	TH98W-CS16-TM4	76	BR	-	36	W
Connector Name	SHIELD	77	R	-	37	W
Connector No.	TH98W-CS16-TM4	78	P	-	38	W
Connector Name	SHIELD	79	GR	-	39	Y
Connector No.	TH98W-CS16-TM4	80	L	-	40	LG
Connector Name	SHIELD	81	SB	-	41	LG
Connector No.	TH98W-CS16-TM4	82	G	-	42	LG
Connector Name	SHIELD	83	BG	-	43	LG
Connector No.	TH98W-CS16-TM4	84	V	-	44	LG
Connector Name	SHIELD	85	Y	-	45	LG
Connector No.	TH98W-CS16-TM4	86	LG	-	46	LG
Connector Name	SHIELD	87	Y	-	47	LG
Connector No.	TH98W-CS16-TM4	88	R	-	48	LG
Connector Name	SHIELD	89	B	-	49	LG
Connector No.	TH98W-CS16-TM4	90	BG	-	50	LG
Connector Name	SHIELD	91	G	-	51	LG
Connector No.	TH98W-CS16-TM4	92	BR	-	52	LG
Connector Name	SHIELD	93	G	-	53	LG
Connector No.	TH98W-CS16-TM4	94	SB	-	54	LG
Connector Name	SHIELD	95	G	-	55	LG
Connector No.	TH98W-CS16-TM4	96	Y	-	56	LG
Connector Name	SHIELD	97	W	-	57	LG
Connector No.	TH98W-CS16-TM4	98	W	-	58	LG
Connector Name	SHIELD	99	GR	-	59	LG
Connector No.	TH98W-CS16-TM4	31	SHIELD	-	60	LG
Connector Name	SHIELD	32	W	-	61	LG
Connector No.	TH98W-CS16-TM4	33	SB	-	62	LG
Connector Name	SHIELD	34	L	-	63	LG
Connector No.	TH98W-CS16-TM4	35	P	-	64	LG
Connector Name	SHIELD	36	L	-	65	LG
Connector No.	TH98W-CS16-TM4	37	P	-	66	LG
Connector Name	SHIELD	38	BR	-	67	LG
Connector No.	TH98W-CS16-TM4	39	Y	-	68	LG
Connector Name	SHIELD	40	Y	-	69	LG
Connector No.	TH98W-CS16-TM4	41	GR	-	70	LG
Connector Name	SHIELD	42	LG	-	71	LG
Connector No.	TH98W-CS16-TM4	43	LG	-	72	LG
Connector Name	SHIELD	44	LG	-	73	LG
Connector No.	TH98W-CS16-TM4	45	LG	-	74	LG
Connector Name	SHIELD	46	LG	-	75	LG
Connector No.	TH98W-CS16-TM4	47	SB	-	76	LG
Connector Name	SHIELD	48	P	-	77	LG
Connector No.	TH98W-CS16-TM4	49	G	-	78	LG
Connector Name	SHIELD	50	V	-	79	LG
Connector No.	TH98W-CS16-TM4	51	W	-	80	LG
Connector Name	SHIELD	52	W	-	81	LG
Connector No.	TH98W-CS16-TM4	53	W	-	82	LG
Connector Name	SHIELD	54	W	-	83	LG
Connector No.	TH98W-CS16-TM4	55	W	-	84	LG
Connector Name	SHIELD	56	W	-	85	LG
Connector No.	TH98W-CS16-TM4	57	W	-	86	LG
Connector Name	SHIELD	58	W	-	87	LG
Connector No.	TH98W-CS16-TM4	59	W	-	88	LG
Connector Name	SHIELD	60	W	-	89	LG
Connector No.	TH98W-CS16-TM4	61	W	-	90	LG
Connector Name	SHIELD	62	W	-	91	LG
Connector No.	TH98W-CS16-TM4	63	W	-	92	LG
Connector Name	SHIELD	64	W	-	93	LG
Connector No.	TH98W-CS16-TM4	65	W	-	94	LG
Connector Name	SHIELD	66	W	-	95	LG
Connector No.	TH98W-CS16-TM4	67	W	-	96	LG
Connector Name	SHIELD	68	W	-	97	LG
Connector No.	TH98W-CS16-TM4	69	W	-	98	LG
Connector Name	SHIELD	70	W	-	99	LG
Connector No.	TH98W-CS16-TM4	71	W	-	100	LG
Connector Name	SHIELD	72	W	-	101	LG
Connector No.	TH98W-CS16-TM4	73	W	-	102	LG
Connector Name	SHIELD	74	W	-	103	LG
Connector No.	TH98W-CS16-TM4	75	W	-	104	LG
Connector Name	SHIELD	76	W	-	105	LG
Connector No.	TH98W-CS16-TM4	77	W	-	106	LG
Connector Name	SHIELD	78	W	-	107	LG
Connector No.	TH98W-CS16-TM4	79	W	-	108	LG
Connector Name	SHIELD	80	W	-	109	LG
Connector No.	TH98W-CS16-TM4	81	W	-	110	LG
Connector Name	SHIELD	82	W	-	111	LG
Connector No.	TH98W-CS16-TM4	83	W	-	112	LG
Connector Name	SHIELD	84	W	-	113	LG
Connector No.	TH98W-CS16-TM4	85	W	-	114	LG
Connector Name	SHIELD	86	W	-	115	LG
Connector No.	TH98W-CS16-TM4	87	W	-	116	LG
Connector Name	SHIELD	88	W	-	117	LG
Connector No.	TH98W-CS16-TM4	89	W	-	118	LG
Connector Name	SHIELD	90	W	-	119	LG
Connector No.	TH98W-CS16-TM4	91	W	-	120	LG
Connector Name	SHIELD	92	W	-	121	LG
Connector No.	TH98W-CS16-TM4	93	W	-	122	LG
Connector Name	SHIELD	94	W	-	123	LG
Connector No.	TH98W-CS16-TM4	95	W	-	124	LG
Connector Name	SHIELD	96	W	-	125	LG
Connector No.	TH98W-CS16-TM4	97	W	-	126	LG
Connector Name	SHIELD	98	W	-	127	LG
Connector No.	TH98W-CS16-TM4	99	W	-	128	LG
Connector Name	SHIELD	100	W	-	129	LG
Connector No.	TH98W-CS16-TM4	101	W	-	130	LG
Connector Name	SHIELD	102	W	-	131	LG
Connector No.	TH98W-CS16-TM4	103	W	-	132	LG
Connector Name	SHIELD	104	W	-	133	LG
Connector No.	TH98W-CS16-TM4	105	W	-	134	LG
Connector Name	SHIELD	106	W	-	135	LG
Connector No.	TH98W-CS16-TM4	107	W	-	136	LG
Connector Name	SHIELD	108	W	-	137	LG
Connector No.	TH98W-CS16-TM4	109	W	-	138	LG
Connector Name	SHIELD	110	W	-	139	LG
Connector No.	TH98W-CS16-TM4	111	W	-	140	LG
Connector Name	SHIELD	112	W	-	141	LG
Connector No.	TH98W-CS16-TM4	113	W	-	142	LG
Connector Name	SHIELD	114	W	-	143	LG
Connector No.	TH98W-CS16-TM4	115	W	-	144	LG
Connector Name	SHIELD	116	W	-	145	LG
Connector No.	TH98W-CS16-TM4	117	W	-	146	LG
Connector Name	SHIELD	118	W	-	147	LG
Connector No.	TH98W-CS16-TM4	119	W	-	148	LG
Connector Name	SHIELD	120	W	-	149	LG
Connector No.	TH98W-CS16-TM4	121	W	-	150	LG
Connector Name	SHIELD	122	W	-	151	LG
Connector No.	TH98W-CS16-TM4	123	W	-	152	LG
Connector Name	SHIELD	124	W	-	153	LG
Connector No.	TH98W-CS16-TM4	125	W	-	154	LG
Connector Name	SHIELD	126	W	-	155	LG
Connector No.	TH98W-CS16-TM4	127	W	-	156	LG
Connector Name	SHIELD	128	W	-	157	LG
Connector No.	TH98W-CS16-TM4	129	W	-	158	LG
Connector Name	SHIELD	130	W	-	159	LG
Connector No.	TH98W-CS16-TM4	131	W	-	160	LG
Connector Name	SHIELD	132	W	-	161	LG
Connector No.	TH98W-CS16-TM4	133	W	-	162	LG
Connector Name	SHIELD	134	W	-	163	LG
Connector No.	TH98W-CS16-TM4	135	W	-	164	LG
Connector Name	SHIELD	136	W	-	165	LG
Connector No.	TH98W-CS16-TM4	137	W	-	166	LG
Connector Name	SHIELD	138	W	-	167	LG
Connector No.	TH98W-CS16-TM4	139	W	-	168	LG
Connector Name	SHIELD	140	W	-	169	LG
Connector No.	TH98W-CS16-TM4	141	W	-	170	LG
Connector Name	SHIELD	142	W	-	171	LG
Connector No.	TH98W-CS16-TM4	143	W	-	172	LG
Connector Name	SHIELD	144	W	-	173	LG
Connector No.	TH98W-CS16-TM4	145	W	-	174	LG
Connector Name	SHIELD	146	W	-	175	LG
Connector No.	TH98W-CS16-TM4	147	W	-	176	LG
Connector Name	SHIELD	148	W	-	177	LG
Connector No.	TH98W-CS16-TM4	149	W	-	178	LG
Connector Name	SHIELD	150	W	-	179	LG
Connector No.	TH98W-CS16-TM4	151	W	-	180	LG
Connector Name	SHIELD	152	W	-	181	LG
Connector No.	TH98W-CS16-TM4	153	W	-	182	LG
Connector Name	SHIELD	154	W	-	183	LG
Connector No.	TH98W-CS16-TM4	155	W	-	184	LG
Connector Name	SHIELD	156	W	-	185	LG
Connector No.	TH98W-CS16-TM4	157	W	-	186	LG
Connector Name	SHIELD	158	W	-	187	LG
Connector No.	TH98W-CS16-TM4	159	W	-	188	LG
Connector Name	SHIELD	160	W	-	189	LG
Connector No.	TH98W-CS16-TM4	161	W	-	190	LG
Connector Name	SHIELD	162	W	-	191	LG
Connector No.	TH98W-CS16-TM4	163	W	-	192	LG
Connector Name	SHIELD	164	W	-	193	LG
Connector No.	TH98W-CS16-TM4	165	W	-	194	LG
Connector Name	SHIELD	166	W	-	195	LG
Connector No.	TH98W-CS16-TM4	167	W	-	196	LG
Connector Name	SHIELD	168	W	-	197	LG
Connector No.	TH98W-CS16-TM4	169	W	-	198	LG
Connector Name	SHIELD	170	W	-	199	LG
Connector No.	TH98W-CS16-TM4	171	W	-	200	LG
Connector Name	SHIELD	172	W	-	201	LG
Connector No.	TH98W-CS16-TM4	173	W	-	202	LG
Connector Name	SHIELD	174	W	-	203	LG
Connector No.	TH98W-CS16-TM4	175	W	-	204	LG
Connector Name	SHIELD	176	W	-	205	LG
Connector No.	TH98W-CS16-TM4	177	W	-	206	LG
Connector Name	SHIELD	178	W	-	207	LG
Connector No.	TH98W-CS16-TM4	179	W	-	208	LG
Connector Name	SHIELD	180	W	-	209	LG
Connector No.	TH98W-CS16-TM4	181	W	-	210	LG
Connector Name	SHIELD	182	W	-	211	LG
Connector No.	TH98W-CS16-TM4	183	W	-	212	LG
Connector Name	SHIELD	184	W	-	213	LG
Connector No.	TH98W-CS16-TM4	185	W	-	214	LG
Connector Name	SHIELD	186	W	-	215	LG
Connector No.	TH98W-CS16-TM4	187	W	-	216	LG
Connector Name	SHIELD	188	W	-	217	LG
Connector No.	TH98W-CS16-TM4	189	W	-	218	LG
Connector Name	SHIELD	190	W	-	219	LG
Connector No.	TH98W-CS16-TM4	191	W	-	220	LG
Connector Name	SHIELD	192	W	-	221	LG
Connector No.	TH98W-CS16-TM4	193	W	-	222	LG
Connector Name	SHIELD	194	W	-	223	LG
Connector No.	TH98W-CS16-TM4	195	W	-	224	LG
Connector Name	SHIELD	196	W	-	225	LG
Connector No.	TH98W-CS16-TM4	197	W	-	226	LG
Connector Name	SHIELD	198	W	-	227	LG
Connector No.	TH98W-CS16-TM4	199	W	-	228	LG
Connector Name	SHIELD	200	W	-	229	LG
Connector No.	TH98W-CS16-TM4	201	W	-	230	LG
Connector Name	SHIELD	202	W	-	231	LG
Connector No.	TH98W-CS16-TM4	203	W	-	232	LG
Connector Name	SHIELD	204	W	-	233	LG
Connector No.	TH98W-CS16-TM4	205	W	-	234	LG
Connector Name	SHIELD	206	W	-	235	LG
Connector No.	TH98W-CS16-TM4	207	W	-	236	LG
Connector Name	SHIELD	208	W	-	237	LG
Connector No.	TH98W-CS16-TM4	209	W	-	238	LG
Connector Name	SHIELD	210	W	-	239	LG
Connector No.	TH98W-CS16-TM4	211	W	-	240	LG
Connector Name	SHIELD	212				

JRNWE1245GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

JRNWE1246GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

METER		Terminal No.		Color Of Wire		Signal Name [Specification]	
11	S8	-	-	-	-	- [With ICC]	- [Without ICC]
12	E6	-	-	L	BG	- [With ICC]	- [Without ICC]
13	L	-	-	G	-	- [With ICC]	- [Without ICC]
14	R	-	-	W	-	- [With ICC]	- [Without ICC]
15	P	-	-	W	-	- [With ICC]	- [Without ICC]
16	V	-	-	Y	-	- [With ICC]	- [Without ICC]
17	S8	-	-	P	-	- [With ICC]	- [Without ICC]
18	V	-	-	R	-	- [With ICC]	- [Without ICC]
20	E6	-	-	BR	BR	- [With ICC]	- [Without ICC]
21	L	-	-	L	-	- [With ICC]	- [Without ICC]
22	V	-	-	Y	-	- [With ICC]	- [Without ICC]
23	G	-	-	P	-	- [With ICC]	- [Without ICC]
24	P	-	-	S8	-	- [With ICC]	- [Without ICC]
25	Y	-	-	R	-	- [With ICC]	- [Without ICC]
26	V	-	-	S8	-	- [With ICC]	- [Without ICC]
27	W	-	-	BR	-	- [With ICC]	- [Without ICC]
28	G	-	-	G	-	- [With ICC]	- [Without ICC]
31	E6	-	-	S8	L	- [With ICC]	- [Without ICC]
32	W	-	-	P	-	- [With ICC]	- [Without ICC]
33	B	-	-	V	-	- [With ICC]	- [Without ICC]
34	R	-	-	GR	-	- [With ICC]	- [Without ICC]
35	G	-	-	SHEILD	-	- [With ICC]	- [Without ICC]
36	SHEILD	-	-	90	GR	- [With ICC]	- [Without ICC]
37	V	-	-	91	W	- [With ICC]	- [Without ICC]
38	BR	-	-	92	Y	- [With ICC]	- [Without ICC]
39	E6	-	-	93	V	- [With ICC]	- [Without ICC]
41	N	-	-	94	LG	- [With ICC]	- [Without ICC]
42	G	-	-	95	BG	- [With ICC]	- [Without ICC]
43	BR	-	-	96	P	- [With ICC]	- [Without ICC]
45	W	-	-	97	R	- [With ICC]	- [Without ICC]
49	L	-	-	98	SHEILD	- [With ICC]	- [Without ICC]
50	P	-	-	99	L	- [With ICC]	- [Without ICC]
51	E6	-	-	100	P	- [With ICC]	- [Without ICC]
54	E6	-	-	-	-	-	-
57	BR	-	-	-	-	-	-
59	W	-	-	-	-	-	-
60	LG	-	-	-	-	-	-
61	G	-	-	-	-	-	-
62	S8	-	-	-	-	-	-
63	W	-	-	-	-	-	-
64	B	-	-	-	-	-	-
65	G	-	-	-	-	-	-
66	R	-	-	-	-	-	-
67	SHEILD	-	-	-	-	-	-
68	Y	-	-	-	-	-	-
69	LG	-	-	-	-	-	-
70	W	-	-	-	-	-	-
71	R	-	-	-	-	-	-
72	Y	-	-	-	-	-	-
73	B	-	-	-	-	-	-

H.S.		Connector No.		Color Of Wire		Signal Name [Specification]	
H.S.	43	F36	ALTERNATOR	-	-	-	-
H.S.	43	HS3/B	CONNECTOR TYPE	-	-	-	-
H.S.	43	F1	WIRE TO WIRE	-	-	-	-

H.S.		Connector No.		Color Of Wire		Signal Name [Specification]	
H.S.	1	F1	WIRE TO WIRE	-	-	-	-
H.S.	1	SA43/B-HS10-S1Z2	CONNECTOR TYPE	-	-	-	-
H.S.	1	HS1	CONNECTOR NO.	-	-	-	-
H.S.	1	HS1	CONNECTOR NAME	-	-	-	-
H.S.	1	HS1	CONNECTOR TYPE	ED1FG4S-AR	-	-	-

H.S.		Connector No.		Color Of Wire		Signal Name [Specification]	
H.S.	1	F37	CONNECTOR NO.	-	-	-	-
H.S.	1	HS1	CONNECTOR NAME	OIL PRESSURE SWITCH	-	-	-
H.S.	1	HS1	CONNECTOR TYPE	ED1FG4S-AR	-	-	-
H.S.	1	HS1	CONNECTOR NO.	-	-	-	-
H.S.	1	HS1	CONNECTOR NAME	-	-	-	-
H.S.	1	HS1	CONNECTOR TYPE	ED1FG4S-AR	-	-	-

H.S.		Connector No.		Color Of Wire		Signal Name [Specification]	
H.S.	1	E107	PARKING BRAKE SWITCH	-	-	-	-
H.S.	1	HS1	CONNECTOR TYPE	TB1JFW	-	-	-
H.S.	1	HS1	CONNECTOR NO.	-	-	-	-
H.S.	1	HS1	CONNECTOR NAME	-	-	-	-
H.S.	1	HS1	CONNECTOR TYPE	ED1FG4S-AR	-	-	-

JRNWE1247GB

A B C D M T G I K L P O MWI


UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

JRNWE1248GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



JRNWE1249GB

UNIFIED METER AND A/C AMP.


< ECU DIAGNOSIS INFORMATION >

METER		Connector No.	M53	Connector No.	M54	Connector Name	METER CONTROL SWITCH	Connector No.	M66	Connector Name	UNIFIED METER AND A/C AMP.	Connector Type	TH40PW-NH	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
Connector Name		COMBINATION METER		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		IGNITION POWER SUPPLY		IGNITION POWER SUPPLY		BG	SUNLOAD SENSOR SIGNAL	G	EXHAUST GAS/OUTSIDE AIR DETECTION SENSOR SIGNAL
Connector Type		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		BATTERY POWER SUPPLY		BATTERY POWER SUPPLY		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		GROUND		GROUND		B	-	L	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		CAN-H		CAN-H		W	BRAKE FLUID LEVEL SWITCH SIGNAL	W	FUEL LEVEL SENSOR SIGNAL
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		INTAKE SENSOR GROUND		INTAKE SENSOR GROUND		GR	-	GR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		IN-VEHICLE SENSOR GROUND		IN-VEHICLE SENSOR GROUND		L	-	L	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		AMBIENT SENSOR GROUND		AMBIENT SENSOR GROUND		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		SUNLOAD SENSOR GROUND		SUNLOAD SENSOR GROUND		SB	-	SB	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ECU SIGNAL		ECU SIGNAL		R	-	R	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		AC/LAN SIGNAL		AC/LAN SIGNAL		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		EACH DOOR MOTOR POWER SUPPLY		EACH DOOR MOTOR POWER SUPPLY		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		GROUND		GROUND		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		CAN-H		CAN-H		P	-	P	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		CAN-L		CAN-L		P	-	P	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ECM		ECM		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		RHD4RGZ-BLHZ		RHD4RGZ-BLHZ		BR	-	BR	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		A/S KNOW SWITCH SIGNAL		A/S KNOW SWITCH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		MANUAL MODE SHIFT DOWN SIGNAL		MANUAL MODE SHIFT DOWN SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		LGH		LGH		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		COMMUNICATION SIGNAL (VTR>>AMP)		COMMUNICATION SIGNAL (VTR>>AMP)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		COMMUNICATION SIGNAL (AMP>>CD)		COMMUNICATION SIGNAL (AMP>>CD)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		BLOWER/MOTOR CONTROL SIGNAL		BLOWER/MOTOR CONTROL SIGNAL		P	-	P	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ION ON/OFF SIGNAL		ION ON/OFF SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		MANUAL MODE SHIFT DOWN SIGNAL		MANUAL MODE SHIFT DOWN SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		LGH		LGH		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		COMMUNICATION SIGNAL (VTR>>AMP)		COMMUNICATION SIGNAL (VTR>>AMP)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		VEHICLE SPEED SIGNAL (8 PULSE)		VEHICLE SPEED SIGNAL (8 PULSE)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		PARKING BRAKE SWITCH SIGNAL		PARKING BRAKE SWITCH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)		SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)		SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		WASHER LEVEL SWITCH SIGNAL		WASHER LEVEL SWITCH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ILLUMINATION CONTROL SIGNAL		ILLUMINATION CONTROL SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		SELECT SWITH SIGNAL		SELECT SWITH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ENTER SWITH SIGNAL		ENTER SWITH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		TRIP A/B RESET SWITH SIGNAL		TRIP A/B RESET SWITH SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ILLUMINATION CONTROL SIGNAL (-)		ILLUMINATION CONTROL SIGNAL (-)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		ILLUMINATION CONTROL SIGNAL (+)		ILLUMINATION CONTROL SIGNAL (+)		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		FUEL TANK TEMP. SEN.		FUEL TANK TEMP. SEN.		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		FUEL PRESSURE SEN.		FUEL PRESSURE SEN.		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		IN-VEHICLE SENSOR SIGNAL		IN-VEHICLE SENSOR SIGNAL		Y	-	Y	-
Ambient Sensor		TH40PW-NH		UNIFIED METER AND A/C AMP.		CONNECTOR TYPE		TH40PW-NH		AMBIENT SENSOR SIGNAL		AMBIENT SENSOR SIGNAL		Y	-	Y	-

JRNWE1250GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



JRNWE1251GB

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

METER		Connector No.	M204	73	R	COMM (CONT->DISP)
Connector No.	AV CONTROL UNIT	Connector Name	CAN-H	74	P	CAN-L
21	L	SEAT BELT	DRX(+)	75	LG	AV COMM(L)
24	G	CANL	DRX(-)	76	LG	AV COMM(L)
45	Y	AS3 (+)		79	R	ILLUMINATION
46	P	AS3 (-)		80	G	IGNITION SIGNAL
47	Y	AS2 (+)		81	BG	REVERSE SIGNAL
48	Y	AS2 (-)		82	R	VEHICLE SPEED SIGNAL (8-PULSE)
49	L	ODS INPUT		83	SHIELD	
				87	G	MICROPHONE SIGNAL
				88	SHIELD	SHIELD
				89	G	COMM (DSP->CONT)
				90	L	CAN-H
				91	SB	AV COMM(H)
				92	SB	AV COMM(H)

H.S.		Terminal Color Of	Signal Name [Specification]	No.	Wire	
36	37	LG	AV COMM(L)	75	SB	
38	39	LG	AV COMM(L)	77	SB	
40	41	LG	AV COMM(L)	78	LG	
42	43	LG	AV COMM(L)	80	P	
44	45	LG	AV COMM(L)	81	L	CAN-H
46	47	LG	AV COMM(L)	82	B	SW END
				85	SHIELD	
				87	L	TEL VOICE SIGNAL (+)
				88	P	TEL VOICE SIGNAL (-)
				92	R	VEHICLE SPEED SIGNAL (8-PULSE)
				93	V	PARKING BRAKE SIGNAL
				94	EG	REVERSE SIGNAL
				95	G	IGNITION SIGNAL
				96	Y	DISP EFFECT SIGNAL

H.S.		Terminal Color Of	Signal Name [Specification]	No.	Wire	
36	EG	SHIELD	RGB (RED) SIGNAL	43	G	RGB (RED) SIGNAL
37	IG	SHIELD	RGB (GREEN) SIGNAL	44	L	RGB (GREEN) SIGNAL
38	R	SHIELD	RGB (BLUE) SIGNAL	45	P	RGB (BLUE) SIGNAL
39	IR	SHIELD	COMPOSITE IMAGE SIGNAL GND	46	V	COMPOSITE IMAGE SIGNAL GND
40	B	SHIELD	COM (DIP-CON)	47	SB	COMPOSITE IMAGE SIGNAL
41	SHIELD	SHIELD	RGB/ARRA (TS) SIGNAL	48	Y	INVERTER VCC
42	W	SHIELD	RGB-SYNC	49	BR	INVERTER GND
				50	G	Y
				51	Y	COMM (CONT->DISP)
				52	SHIELD	SHIELD
				57	SHIELD	SHIELD
				58	SHIELD	SHIELD

H.S.		Terminal Color Of	Signal Name [Specification]	No.	Wire	
65	V	SHIELD	PARKING BRAKE SIGNAL	67	BB	COMPOSITE IMAGE SIGNAL GND
67	G	SHIELD	COMPOSITE IMAGE SIGNAL GND	68	R	COMPOSITE IMAGE SIGNAL
68	R	SHIELD	MICROPHONE SHIELD	71	SHIELD	MICROPHONE VCC
72	R	SHIELD				

JRNWE1252GB

INFOID:0000000007585288

Fail-Safe

FAIL-SAFE

The unified meter and A/C amp. activates the fail-safe control if CAN communication with each unit is malfunctioning.

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

	Function	Specifications
Speedometer	Reset to zero by suspending communication.	
Tachometer		
Fuel gauge		
Water temperature gauge		
Illumination control		When suspending communication, change to nighttime mode.
Information display		The display turns off by suspending communication.
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	
	VDC warning lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	IBA OFF indicator lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	Master warning lamp	
	AFS OFF indicator lamp	
	High beam indicator	
	Turn signal indicator lamp	
	Tail lamp indicator lamp	
	Oil pressure warning lamp	
	VDC OFF indicator lamp	
	BSW warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
	Key warning lamp	
	Lane departure warning lamp	
	LDP ON indicator lamp	

DTC Index

INFOID:000000007455709

Display contents of CONSULT	Time	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	CRNT, 1 - 39	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-46
CONTROL UNIT (CAN) [U1010]	CRNT, 1 - 39	When detecting error during the initial diagnosis of CAN controller of unified meter and A/C amp.	MWI-47
COMM ERROR 1 [B2201]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-48
COMM ERROR 2 [B2202]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-50
VEHICLE SPEED [B2205]	CRNT, 1 - 39	The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-52

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Time	Diagnostic item is detected when ...	Refer to
ENGINE SPEED [B2267]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-53
WATER TEMP [B2268]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-54

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:0000000007671080

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		• Front fog lamp switch ON • Daytime running light activated (Only for Canada)	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
<ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ST/INHI RLY	Ignition switch ON	Off
	At engine cranking	INHI ON → ST ON
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> • Press the selector button with selector lever in P position • Selector lever in any position other than P
	Release the selector button with selector lever in P position	On
S/L RLY -REQ	NOTE: The item is indicated, but not monitored.	Off
S/L STATE	NOTE: The item is indicated, but not monitored.	UNLOCK
DTRL REQ	NOTE: The item is indicated, but not monitored.	Off
OIL P SW	Ignition switch OFF, ACC or engine running	Open
	Ignition switch ON	Close
HOOD SW	Close the hood	Off
	Open the hood	On
HL WASHER REQ	NOTE: The item is indicated, but not monitored.	Off
THFT HRN REQ	Not operation	Off
	<ul style="list-style-type: none"> • Panic alarm is activated • Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM 	On
HORN CHIRP	Not operating	Off
	Door locking with Intelligent Key (horn chirp mode)	On
CRNRNG LMP REQ	NOTE: The item is indicated, but not monitored.	Off

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
4 (V)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch ON	Front wiper switch HI	Battery voltage
7 (R)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
				Lighting switch ON	Lighting switch 1ST	Battery voltage
12 (B/W)	Ground	Ground	—	Ignition switch ON		0 V
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running 		Battery voltage
16 (LG)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
				Any position other than front wiper stop position		Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

<ECU DIAGNOSIS INFORMATION>

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
19 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
26* (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
27 (BG)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC	
				0 V	
28 (L)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	
				Battery voltage	
30 (GR)	Ground	Starter relay control	Input	Ignition switch ON	
				Selector lever in any position other than P or N	
				0 V	
				Selector lever P or N	
				Battery voltage	
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
39 (P)	—	CAN-L	Input/ Output	—	—
40 (L)	—	CAN-H	Input/ Output	—	—
41 (B/W)	Ground	Ground	—	Ignition switch ON	0 V
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON	0.7 V
43 (SB)	Ground	A/T shift selector (Detention switch)	Input	Ignition switch ON	• Press the selector button (Selector lever P) • Selector lever in any position other than P
				Release the selector button (selector lever P)	Battery voltage
				0 V	
44 (BR)	Ground	Horn relay control	Input	The horn is deactivated	Battery voltage
				The horn is activated	0 V
45 (G)	Ground	Anti theft horn relay control	Input	The horn is deactivated	Battery voltage
				The horn is activated	0 V
46 (R)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any position other than P or N
				Selector lever P or N	Battery voltage
48 (L)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF
				A/C switch ON (A/C compressor is operating)	Battery voltage
49 (BG)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L M MWI O P
	+	-			
51 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage
54 (P)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage
55 (SB)	Ground	ECM power supply	Output	Ignition switch OFF	Battery voltage
56 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
57 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
58 (V)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
69 (BR)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	0 – 1.5 V
70 (BG)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF	0 – 1.0 V ↓ Battery voltage ↓ 0 V
				Ignition switch ON	0 – 1.0 V
74 (P)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
75 (SB)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped
					0 V
					Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

<ECU DIAGNOSIS INFORMATION>

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
76 (Y)	Ground	Power generation com-mand signal	Output	Ignition switch ON
				 JPMIA0001GB 6.3 V
				 JPMIA0002GB 3.8 V
77 (R)	Ground	Fuel pump relay control	Output	40% is set on "ACTIVE TEST", "AL-TERNATOR DUTY" of "ENGINE"
				 JPMIA0003GB 1.4 V
				80% is set on "ACTIVE TEST", "AL-TERNATOR DUTY" of "ENGINE"
80 (W)	Ground	Starter motor	Output	<ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running
				Approximately 1 second or more after turning the ignition switch ON
83 (BG)	Ground	Headlamp LO (RH)	Output	Lighting switch OFF
				Lighting switch 2ND
84 (V)	Ground	Headlamp LO (LH)	Output	Lighting switch OFF
				Lighting switch 2ND
86 (W)	Ground	Front fog lamp (RH)	Output	Front fog lamp switch OFF
				<ul style="list-style-type: none"> Front fog lamp switch ON Daytime running light activated (Only for Can-ada)
87 (L)	Ground	Front fog lamp (LH)	Output	Front fog lamp switch OFF
				<ul style="list-style-type: none"> Front fog lamp switch ON Daytime running light activated (Only for Can-ada)
88 (GR)	Ground	Washer pump power sup- ply	Output	Ignition switch ON
				Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
89 (BR)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	
				Lighting switch OFF <ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 	0 V Battery voltage
90 (P)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	
				Lighting switch OFF <ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 	0 V Battery voltage
91 (P)	Ground	Parking lamp (RH)	Output	Ignition switch ON	
				Lighting switch OFF Lighting switch 1ST	0 V Battery voltage
92 (BG)	Ground	Parking lamp (LH)	Output	Ignition switch ON	
				Lighting switch OFF Lighting switch 1ST	0 V Battery voltage
97 (V)	Ground	Cooling fan control	Output	Engine idling	0 – 5 V
104 (LG)	Ground	Hood switch	Input	Close the hood	Battery voltage
				Open the hood	0 V

*: Only for the models with ICC system

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - IPDM E/R -

INFOID:000000007671081

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)




2011/06/24

JRMWC4037GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< ECU DIAGNOSIS INFORMATION >



JRMWC4038GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



JRMWC4039GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Connector No.	Connector No.	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
E4	E6	W	-	P	-	L	-	BW	-
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)								
Connector Type	TH081WNH								
Connector No.	E5	1	[1] [2] [3] [4] [5] [6] [7] [8]	2	[1] [2] [3] [4] [5] [6] [7] [8]	3	[1] [2] [3] [4] [5] [6] [7] [8]	4	[1] [2] [3] [4] [5] [6] [7] [8]
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)								
Connector Type	TH20PW-CS12-M4-14V								
Connector No.	E7	1	[1] [2] [3] [4] [5] [6] [7] [8]	2	[1] [2] [3] [4] [5] [6] [7] [8]	3	[1] [2] [3] [4] [5] [6] [7] [8]	4	[1] [2] [3] [4] [5] [6] [7] [8]
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)								
Connector Type	TH20PW-CS12-M4								
Terminal Color Of Wire	4	V	-	5	L	-	6	BR	-
No.	7	R	-	8	BW	-	9	G	-
Terminal Color Of Wire	12	W	-	13	Y	-	14	LG	-
No.	15	G	-	16	W	-	17	W	-
Terminal Color Of Wire	25	G	-	26	R	-	27	BG	-
No.	28	R	-	29	L	-	30	GR	-
Terminal Color Of Wire	36	G	-	37	G	-	38	V	-
No.	39	W	-	40	L	-	41	BW	-
Terminal Color Of Wire	43	S	-	44	BR	-	45	G	-
No.	46	R	-	47	Y	-	48	LG	-
Terminal Color Of Wire	49	LG	-	50	W	-	51	Y	-
No.	52	W	-	53	W	-	54	P	-
Terminal Color Of Wire	55	SB	-	56	LG	-	57	G	-
No.	58	V	-	59	BR	-	60	V	-
Terminal Color Of Wire	61	BR	-	62	LG	-	63	LG	-
No.	64	P	-	65	LG	-	66	LG	-
Terminal Color Of Wire	67	LG	-	68	LG	-	69	LG	-
No.	70	P	-	71	P	-	72	P	-
Terminal Color Of Wire	73	P	-	74	P	-	75	SB	-
No.	76	Y	-	77	R	-	78	W	-
Terminal Color Of Wire	79	W	-	80	W	-	81	W	-

JRMWG8116GB

INFOID:0000000007671082

Fail-safe

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

A

B

C

D

E

F

G

H

I

J

K

L

M

O

P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

<ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp low relay when the ignition switch is turned ON Turns OFF the headlamp low relay when the ignition switch is turned OFF Headlamp high relay OFF
<ul style="list-style-type: none"> Parking lamps License plate lamps Side maker lamps Illuminations Tail lamps 	<ul style="list-style-type: none"> Turns ON the tail lamp relay when the ignition switch is turned ON Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Front fog lamps	Front fog lamp relay OFF
Horn	Horn relay OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> Detects DTC "B2098: IGN RELAY ON" Turns ON the tail lamp relay for 10 minutes
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000007671083

NOTE:

- The details of time display are as follows.
- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
- The number is 0 when is detected now.
- The number increases like 1 → 2 … 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
- The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

x: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	PCS-14
B2098: IGN RELAY ON	×	PCS-15
B2099: IGN RELAY OFF	—	PCS-16
B210B: START CONT RLY ON	—	SEC-77
B210C: START CONT RLY OFF	—	SEC-78
B210D: STARTER RELAY ON	—	SEC-79
B210E: STARTER RELAY OFF	—	SEC-80
B210F: INTRLCK/PNP SW ON	—	SEC-82
B2110: INTRLCK/PNP SW OFF	—	SEC-84

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE FUEL GAUGE POINTER DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE FUEL GAUGE POINTER DOES NOT MOVE

Description

INFOID:000000007455714

Fuel gauge needle will not move from a certain position.

Diagnosis Procedure

INFOID:000000007455715

1.CONDUCTING THE COMBINATION METER SELF-DIAGNOSIS MODE

Perform the self-diagnosis mode of combination meter, and then check that the fuel gauge operates normally. Refer to [MWI-40, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-134, "Removal and Installation"](#).

2.CHECK FLOAT INTERFERENCE

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning part.

3.CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-58, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

THE METER CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

THE METER CONTROL SWITCH IS INOPERATIVE

Description

INFOID:0000000007455716

If any of the following malfunctions is found for the meter control switch operation.

- All switches are inoperative.
- The specified switch cannot be operated.

Diagnosis Procedure

INFOID:0000000007455717

1.CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

Check the meter control switch signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK METER CONTROL SWITCH UNIT

Perform a unit check for the meter control switch. Refer to [MWI-63, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace meter control switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE TRIP A/B RESET SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

THE TRIP A/B RESET SWITCH IS INOPERATIVE

Description

INFOID:0000000007455718

The trip A/B reset switch is inoperative.

Diagnosis Procedure

INFOID:0000000007455719

1.CHECK TRIP A/B RESET SWITCH SIGNAL CIRCUIT

Check the trip A/B reset switch signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK TRIP A/B RESET SWITCH UNIT

Perform a unit check for the trip A/B reset switch. Refer to [MWI-63, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace trip A/B reset switch.

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:0000000007455720

The oil pressure warning lamp stays off when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:0000000007455721

1.CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-9, "Diagnosis Description"](#).

Does oil pressure warning lamp blink?

YES >> GO TO 2.

NO >> Replace combination meter.

2.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-66, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Replace oil pressure switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:0000000007455722

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure).

Diagnosis Procedure

INFOID:0000000007455723

1. CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-9, "Diagnosis Description"](#).

Does oil pressure warning lamp blink?

YES >> GO TO 2.

NO >> Replace combination meter.

2. CHECK IPDM E/R OUTPUT VOLTAGE

1. Disconnect the oil pressure switch connector.
2. Turn ignition switch ON.
3. Check voltage between the oil pressure switch harness connector and ground.

Terminals		Voltage	
Oil pressure switch			
Connector	Terminal		
F37	1	Ground	
		Approx. 12 V	

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Replace oil pressure switch.

4. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-66, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair harness or connector.

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000007455724

- The parking brake warning is displayed during vehicle travel even though the parking brake is released.
- The parking brake warning is not displayed even though driving the vehicle with the parking brake applied.

Diagnosis Procedure

INFOID:000000007455725

1.CHECK PARKING BRAKE WARNING LAMP OPERATION

1. Start engine.
2. Check the operation of the parking brake warning lamp when operating the parking brake.

Condition	Warning lamp status
Parking brake is applied	ON
Parking brake is released	OFF

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> GO TO 2.

2.CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Check the parking brake switch signal circuit. Refer to [MWI-67, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NG >> Repair harness or connector.

3.CHECK PARKING BRAKE SWITCH UNIT

Perform a unit check for the parking brake switch. Refer to [BRC-90, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace parking brake switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000007455726

- The warning is still displayed even after washer fluid is added.
- The warning is not displayed even though the washer tank is empty.

Diagnosis Procedure

INFOID:000000007455727

1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

Check the washer level switch signal circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK WASHER LEVEL SWITCH UNIT

Perform a unit check for the washer level switch. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace washer level switch. Refer to [WW-113, "Removal and Installation"](#).

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000007455728

- The door ajar warning is displayed even though all of the doors are closed.
- The door ajar warning is not displayed even though a door is ajar.

Diagnosis Procedure

INFOID:000000007455729

1. CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT and check the BCM input signals. Refer to [DLK-67, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "DOOR W/L" monitor value.

"DOOR W/L"	
Door open	: On
Door closed	: Off

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace BCM. Refer to [BCS-92, "Removal and Installation"](#).

3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Check the door switch signal circuit. Refer to [DLK-67, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair harness or connector.

4. CHECK DOOR SWITCH UNIT

Perform a unit check for the door switch. Refer to [DLK-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace applicable door switch. Refer to [DLK-274, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

Description

INFOID:000000007455730

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

Diagnosis Procedure

INFOID:000000007455731

NOTE:

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-131, "INFORMATION DISPLAY : Description"](#).

1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Check the ambient sensor signal circuit. Refer to [HAC-67, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK AMBIENT SENSOR UNIT

Perform a unit check for the ambient sensor. Refer to [HAC-68, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace unified meter and A/C amp.

NO >> Replace ambient sensor. Refer to [HAC-124, "Removal and Installation"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION COMPASS

COMPASS : Description

INFOID:000000007455732

COMPASS

- The electronic compass is highly protected from changes in most magnetic fields. However, some large changes in magnetic fields can affect it. Some examples are (but not limited to): high tension power lines, large steel buildings, subways, steel bridges, automatic car washes, large piles of scrap metal, etc. While this does not happen very often, it is possible.
- During normal operation, the Compass Mirror will continuously update the compass calibration to adjust for gradual changes in the vehicle's magnetic "remnant" field. If the vehicle is subjected to high magnetic influences, the compass may appear to indicate false headings, become locked, or appear that it is unable to be calibrated. If this occurs, perform the calibration procedure.
- If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, verify the correct zone variance.

Symptom Chart

Symptom	Cause	Solution / Reference
The compass display reads "C".		
Compass shows the wrong direction.		
Compass does not change direction appears "Locked".	<ul style="list-style-type: none">Compass is not calibrated.Incorrect zone variance setting.Large change in magnetic field (Steel bridges, subways, concentrations of metal, carwashes, etc.)Compass was calibrated incorrectly or in the presence of a strong magnetic field.	Perform calibration. Refer to MWI-36, "Description" .
Compass does not show all the directions, one or more is missing.		
The compass was calibrated but it "loses" calibration.		
On long trips the compass shows the wrong direction.		Perform zone variation setting if correct reading is desired in that location. Refer to MWI-36, "Description" .

INFORMATION DISPLAY

INFORMATION DISPLAY : Description

INFOID:000000007455733

AMBIENT AIR TEMPERATURE

The displayed ambient air temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the unified meter and A/C amp. Refer to [MWI-30, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

POSSIBLE DRIVING DISTANCE

The calculated possible driving distance may differ from the actual distance to empty if the refueling amount is approximately 15 ℥ (4 US gal, 3-3/10 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000007455734

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007455735

A

B

C

D

E

F

G

H

I

J

K


L

M

MWI

O

P

Tool name	Description
Power tool	 Loosening screws PBIC0191E

COMBINATION METER

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

COMBINATION METER


Exploded View

INFOID:000000007455736

REMOVAL

Refer to [IP-12, "Exploded View"](#).

DISASSEMBLY



1. Front cover

2. Upper housing


3. Unified meter control unit

Removal and Installation

INFOID:000000007455737

Removal

1. Remove the cluster lid A. Refer to [IP-13, "Removal and Installation"](#).
2. Remove screws (A) and connector, and then remove combination meter (1).



Installation

Install in the reverse order of removal.

Disassembly and Assembly

INFOID:000000007455738

DISASSEMBLY

1. Disengage the tabs to separate the upper housing with the front cover from unified meter control unit.
2. Disengage the tabs to separate the front cover from upper housing.

ASSEMBLY

Assemble in the reverse order of disassembly.


UNIFIED METER AND A/C AMP.

< REMOVAL AND INSTALLATION >

UNIFIED METER AND A/C AMP.

Exploded View

INFOID:0000000007455739




1. Unified meter and A/C amp.
2. Bracket (LH)
3. AV control unit
4. Bracket (RH)

Removal and Installation

INFOID:0000000007455740

REMOVAL

1. Remove AV control unit. Refer to [AV-128, "Exploded View"](#) (BASE AUDIO WITHOUT NAVIGATION), [AV-316, "Exploded View"](#) (BOSE AUDIO WITHOUT NAVIGATION) or [AV-519, "Exploded View"](#) (BOSE AUDIO WITH NAVIGATION).
2. Remove mounting screws (A), and then remove unified meter and A/C amp. (1).



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

Since unified meter and A/C amp. connector and AV control unit connector have the same form, be careful not to insert them wrongly.

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
P

METER CONTROL SWITCH

< REMOVAL AND INSTALLATION >

METER CONTROL SWITCH


Exploded View

INFOID:0000000007455741

REMOVAL

[IP-12, "Exploded View"](#)

DISASSEMBLY



1. Meter control switch

2. Cluster lid A

Removal and Installation

INFOID:0000000007455742

REMOVAL

1. Remove cluster lid A. Refer to [IP-13, "Removal and Installation"](#).
2. Remove screws and remove meter control switch.

INSTALLATION

Install in the reverse order of removal.


TRIP A/B RESET SWITCH

< REMOVAL AND INSTALLATION >

TRIP A/B RESET SWITCH

Exploded View

INFOID:0000000007455743



JPNIA0871ZZ

1. Trip A/B reset switch

Removal and Installation

INFOID:0000000007455744

REMOVAL

1. Remove combination meter. Refer to MWI-134, "Removal and Installation".
2. Press pawls and remove trip A/B reset switch.

INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

COMPASS

< REMOVAL AND INSTALLATION >

COMPASS

Exploded View

INFOID:0000000007455745

Refer to [MIR-118. "Exploded View"](#) (with ADP) or [MIR-138. "Exploded View"](#) (without ADP).

Removal and Installation

INFOID:0000000007455746

Refer to [MIR-118. "Removal and Installation"](#) (with ADP) or [MIR-138. "Removal and Installation"](#) (without ADP).

CLOCK

< REMOVAL AND INSTALLATION >

CLOCK


Exploded View

INFOID:0000000007455747

REMOVAL

Refer to [IP-12, "Exploded View"](#).

DISASSEMBLY



1. Clock

2. Cluster lid C


3. Preset switch

Removal and Installation

INFOID:0000000007455748

REMOVAL

1. Remove cluster lid C assembly. Refer to [IP-13, "Removal and Installation"](#).
2. Remove screws (A), (B), (C) and remove clock (1) in conjunction with preset switch (2) from cluster lid C.
3. Disengage the tabs to separate clock.



MWI

INSTALLATION

Install in the reverse order of removal.

NOTE:

Never confuse screws when installing.

O

P