

# SECTION **WW**

## **WIPER & WASHER**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<b>BASIC INSPECTION .....</b>	3	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....	23
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	3	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	23
Work Flow .....	3		
<b>SYSTEM DESCRIPTION .....</b>	6		
<b>FRONT WIPER AND WASHER SYSTEM .....</b>	6	<b>FRONT WIPER MOTOR LO CIRCUIT .....</b>	25
System Diagram .....	6	Component Function Check .....	25
System Description .....	6	Diagnosis Procedure .....	25
Component Parts Location .....	9	<b>FRONT WIPER MOTOR HI CIRCUIT .....</b>	27
Component Description .....	9	Component Function Check .....	27
<b>REAR WIPER AND WASHER SYSTEM .....</b>	11	Diagnosis Procedure .....	27
System Diagram .....	11	<b>FRONT WIPER STOP POSITION SIGNAL CIRCUIT .....</b>	29
System Description .....	11	Component Function Check .....	29
Component Parts Location .....	13	Diagnosis Procedure .....	29
Component Description .....	13	<b>FRONT WIPER MOTOR GROUND CIRCUIT .....</b>	31
<b>DIAGNOSIS SYSTEM (BCM) .....</b>	14	Diagnosis Procedure .....	31
<b>COMMON ITEM .....</b>	14	<b>WASHER SWITCH .....</b>	32
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	14	Description .....	32
<b>WIPER .....</b>	15	Component Inspection .....	32
WIPER : CONSULT Function (BCM - WIPER) .....	15	<b>REAR WIPER MOTOR CIRCUIT .....</b>	33
<b>DIAGNOSIS SYSTEM (IPDM E/R) .....</b>	17	Component Function Check .....	33
Diagnosis Description .....	17	Diagnosis Procedure .....	33
CONSULT Function (IPDM E/R) .....	19	<b>REAR WIPER STOP POSITION SIGNAL CIRCUIT .....</b>	35
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	22	Component Function Check .....	35
<b>WIPER AND WASHER FUSE .....</b>	22	Diagnosis Procedure .....	35
Description .....	22	<b>FRONT WIPER AND WASHER SYSTEM .....</b>	37
Diagnosis Procedure .....	22	Wiring Diagram - FRONT WIPER AND WASHER SYSTEM - .....	37
<b>POWER SUPPLY AND GROUND CIRCUIT .....</b>	23	<b>REAR WIPER AND WASHER SYSTEM .....</b>	42
<b>BCM (BODY CONTROL MODULE) .....</b>	23	Wiring Diagram - REAR WIPER AND WASHER SYSTEM - .....	42
BCM (BODY CONTROL MODULE) : Diagnosis Procedure .....	23		

WW

<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>48</b>	Removal and Installation .....	<b>112</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>48</b>	<b>FRONT WASHER PUMP .....</b>	<b>113</b>
Reference Value .....	48	Exploded View .....	113
Wiring Diagram - BCM - .....	72	Removal and Installation .....	113
Fail-safe .....	86	<b>WASHER LEVEL SWITCH .....</b>	<b>114</b>
DTC Inspection Priority Chart .....	87	Removal and Installation .....	114
DTC Index .....	88	<b>FRONT WASHER NOZZLE AND TUBE .....</b>	<b>115</b>
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	<b>91</b>	Hydraulic Layout .....	115
Reference Value .....	91	Removal and Installation .....	115
Wiring Diagram - IPDM E/R - .....	98	Inspection and Adjustment .....	115
Fail-safe .....	101	<b>FRONT WIPER ARM .....</b>	<b>117</b>
DTC Index .....	103	Exploded View .....	117
<b>SYMPTOM DIAGNOSIS .....</b>	<b>104</b>	Removal and Installation .....	117
<b>WIPER AND WASHER SYSTEM SYMPTOMS .....</b>	<b>104</b>	Adjustment .....	117
Symptom Table .....	104	<b>WIPER BLADE .....</b>	<b>119</b>
<b>NORMAL OPERATING CONDITION .....</b>	<b>107</b>	Exploded View .....	119
Description .....	107	Removal and Installation .....	119
<b>FRONT WIPER DOES NOT OPERATE .....</b>	<b>108</b>	Replacement .....	119
Description .....	108	<b>FRONT WIPER DRIVE ASSEMBLY .....</b>	<b>121</b>
Diagnosis Procedure .....	108	Exploded View .....	121
<b>PRECAUTION .....</b>	<b>110</b>	Removal and Installation .....	121
<b>PRECAUTIONS .....</b>	<b>110</b>	Disassembly and Assembly .....	122
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	110	<b>WIPER AND WASHER SWITCH .....</b>	<b>123</b>
Precaution for Procedure without Cowl Top Cover..	110	Exploded View .....	123
<b>PREPARATION .....</b>	<b>111</b>	<b>REAR WIPER ARM .....</b>	<b>124</b>
<b>PREPARATION .....</b>	<b>111</b>	Exploded View .....	124
Commercial Service Tool .....	111	Removal and Installation .....	124
<b>REMOVAL AND INSTALLATION .....</b>	<b>112</b>	Adjustment .....	124
<b>WASHER TANK .....</b>	<b>112</b>	<b>REAR WIPER MOTOR .....</b>	<b>126</b>
Exploded View .....	112	Exploded View .....	126
		Removal and Installation .....	126
		<b>REAR WASHER NOZZLE AND TUBE .....</b>	<b>127</b>
		Hydraulic Layout .....	127
		Removal and Installation .....	127
		Inspection and Adjustment .....	128

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000008286183

#### OVERALL SEQUENCE



JMKIA8652GB

#### DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-89. "DTC Inspection Priority Chart"](#) (BCM) or [PCS-32. "DTC Index"](#) (IPDM E/R), and determine trouble diagnosis order.

**NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-42. "Intermittent Incident"](#).

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

### Is malfunctioning part detected?

YES    >> GO TO 8.

NO      >> Check according to [GI-42, "Intermittent Incident"](#).

A

## 8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

B

C

D

>> GO TO 9.

E

## 9.FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

F

### Is DTC detected and does symptom remain?

G

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

H

NO      >> Before returning the vehicle to the customer, always erase DTC.

I

J

K

WW

M

N

O

P

# FRONT WIPER AND WASHER SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### FRONT WIPER AND WASHER SYSTEM

#### System Diagram

INFOID:0000000008286184



#### System Description

INFOID:0000000008286185

#### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Front wiper control function

Control by IPDM E/R

- Front wiper control function
- Relay control function

Combination meter indicates low washer fluid warning judged with the signal from the washer level switch.

For details of low washer fluid warning, refer to [MWI-30, "INFORMATION DISPLAY : System Description"](#).

#### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

#### FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

#### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition

- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

# FRONT WIPER AND WASHER SYSTEM


## < SYSTEM DESCRIPTION >

### FRONT WIPER INT OPERATION

- BCM transmits the front wiper request signal (INT) to IPDM E/R with CAN communication depending on the front wiper INT operating condition and intermittent operation delay interval according to the wiper intermittent dial position.

Front wiper INT operating condition

- Ignition switch ON
- Front wiper switch INT
- IPDM E/R turns ON the integrated front wiper relay so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper stop position signal received from IPDM E/R with CAN communication.
- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval.



#### NOTE:

Factory setting of the front wiper intermittent operation is the operation without vehicle speed. Front wiper intermittent operation can be set to the operation with vehicle speed by CONSULT. Refer to [WW-15, "WIPER : CONSULT Function \(BCM - WIPER\)".](#)

Front wiper intermittent operation with vehicle speed

- BCM calculates the intermittent operation delay interval from the following
- Vehicle speed signal (received from the unified meter and A/C amp. with CAN communication)
- Wiper intermittent dial position

Wiper intermittent dial position	Intermittent operation interval	Intermittent operation delay Interval (s)			
		Vehicle speed			
		Vehicle stopped or less than 5 km/h (3.1 MPH)	5 km/h (3.1 MPH) or more or less than 35km/h (21.7 MPH)	35 km/h (21.7 MPH) or more or less than 65km/h (40.4 MPH)*	65 km/h (40.4 MPH) or more
1	Short ↑	0.8	0.6	0.4	0.24
2		4	3	2	1.2
3		10	7.5	5	3
4		16	12	8	4.8
5		24	18	12	7.2
6		32	24	16	9.6
7		42	31.5	21	12.6

\*: When without vehicle speed setting


### FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch OFF.

## FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch when the front washer switch ON.

## FRONT WIPER DROP WIPE OPERATION

- BCM controls the front wiper to operate once according to the conditions of front wiper drop wipe operation.

Front wiper drop wipe operating condition

- Ignition switch ON
- Front wiper switch OFF
- Front washer switch OFF
- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication so that the front wiper operate once three seconds after front wiper operation linked with washer.
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

## FRONT WIPER FAIL-SAFE OPERATION


When the front wiper auto stop circuit is malfunctioning, IPDM E/R performs the fail-safe function. Refer to [PCS-30, "Fail-safe"](#).

# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:0000000008286186



JPLIA0983ZZ

- |                                       |                                |                               |
|---------------------------------------|--------------------------------|-------------------------------|
| 1. Combination switch                 | 2. BCM                         | 3. IPDM E/R                   |
| 4. Washer pump                        | 5. Front wiper motor           | 6. Unified meter and A/C amp. |
| A. Dash side lower (Passenger side)   | B. Engine room dash panel (RH) | C. Radiator core support (RH) |
| D. Cowl top, left side of engine room | E. Behind cluster lid C        |                               |

## Component Description

INFOID:0000000008286187

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges the each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> </ul>

## FRONT WIPER AND WASHER SYSTEM

### < SYSTEM DESCRIPTION >

Part	Description
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-10, "System Description"</a> .
Unified meter and A/C amp.	Transmits the vehicle speed signal to BCM with CAN communication.


# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## REAR WIPER AND WASHER SYSTEM

### System Diagram

INFOID:0000000008286188



### System Description

INFOID:0000000008286189

#### OUTLINE

The rear wiper is controlled by each function of BCM.

Control by BCM

- Combination switch reading function
- Rear wiper control function

#### REAR WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM controls the rear wiper to start or stop.

#### REAR WIPER ON OPERATION

- BCM supplies power to the rear wiper motor according to the rear wiper ON operating condition.

Rear wiper ON operating condition


- Ignition switch ON
- Rear wiper switch ON

#### REAR WIPER INT OPERATION

- BCM supplies power to the rear wiper motor according to the INT operating condition.

Rear wiper INT operating condition

- Ignition switch ON
- Rear wiper switch INT
- BCM controls the rear wiper to operate once.
- BCM detects the rear wiper motor stopping position.
- BCM supplies power to the rear wiper motor after an intermittent from the stop of the rear wiper motor.



#### REAR WIPER AUTO STOP OPERATION

- BCM stops supplying power to the rear wiper motor when the rear wiper switch is turned OFF.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N


O

P

## REAR WIPER AND WASHER SYSTEM

### < SYSTEM DESCRIPTION >

- BCM reads an stop position signal from the rear wiper motor to detect a rear wiper motor position.
- When the rear wiper motor is at other than the stopping position, BCM continues to supply power to the rear wiper motor until it returns to the stopping position.



#### NOTE:

BCM stops supplying power to the rear wiper motor when the ignition switch is turned OFF.

### REAR WIPER OPERATION LINKED WITH WASHER

- BCM supplies power to the rear wiper motor according to the washer linked operating condition of rear wiper. When the rear washer switch is turned OFF, BCM controls rear wiper to operate approximately 3 times.

Washer linked operating condition of rear wiper

- Ignition switch ON
- Rear washer switch ON (0.4 second or more)
- The washer pump is grounded through the combination switch with the rear washer switch ON.

### REAR WIPER DROP WIPE OPERATION

- BCM controls the rear wiper to operate once according to the rear wiper drop wipe operating condition.

Rear wiper drop wipe operating condition

- Ignition switch ON
- Rear wiper switch OFF
- Rear washer switch OFF
- BCM controls the rear wiper so that it operates once approximately three seconds later after the washer interlocking operation of the rear wiper.

### REAR WIPER FAIL-SAFE OPERATION


BCM performs the fail-safe function when the rear wiper auto stop circuit is malfunctioning. Refer to [BCS-88, "Fail-safe".](#)

# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000008286190



- |                                     |                               |   |
|-------------------------------------|-------------------------------|---|
| 1. Combination switch               | 2. BCM                        | 3. Washer pump                          |
| 4. Rear wiper motor                 |                               |   |
| A. Dash side lower (Passenger side) | B. Radiator core support (RH) | C. Back door trim finisher lower inside |

## Component Description

INFOID:000000008286191

WW

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"><li>Judges each switch status by the combination switch reading function.</li><li>Supplies power to the rear wiper motor.</li><li>Performs the auto stop control of the rear wiper.</li></ul>
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-10, "System Diagram"</a> .

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000008772592

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"><li>• Read and save the vehicle specification.</li><li>• Write the vehicle specification when replacing BCM.</li></ul>

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	AIR PRESSURE MONITOR	x	x	x

#### NOTE:

\*: This item is displayed, but is not used.

#### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"**)
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC	While turning power supply position from "LOCK"** to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Except emergency stop operation)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"**
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"**.) to low power consumption mode
	LOCK	Power supply position is "LOCK"**
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>

### NOTE:

\*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## WIPER

### WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000008286193

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Service item	Setting item	Description
WIPER SPEED SETTING	On	With vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper intermittent dial position)
	Off*	Without vehicle speed (Front wiper intermittent time linked with the wiper intermittent dial position)

\*:Factory setting

## DATA MONITOR

### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	Description
PUSH SW [Off/On]	The switch status input from push-button ignition switch.
VEHICLE SPEED 1 [km/h]	The value of the vehicle speed signal received from unified meter and A/C amp. with CAN communication.
FR WIPER HI [Off/On]	Each switch status that BCM judges from the combination switch reading function.
FR WIPER LOW [Off/On]	
FR WASHER SW [Off/On]	
FR WIPER INT [Off/On]	
FR WIPER STOP [Off/On]	Front wiper motor (stop position) status received from IPDM E/R with CAN communication.
INT VOLUME [1 – 7]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER ON [Off/On]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER INT [Off/On]	
RR WASHER SW [Off/On]	
RR WIPER STOP [Off/On]	

## ACTIVE TEST

Test item	Operation	Description
FR WIPER	Hi	Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation.
	Lo	Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation.
	INT	Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation.
	Off	Stops transmitting the front wiper request signal to stop the front wiper operation.
RR WIPER	On	Outputs the voltage to operate the rear wiper motor.
	Off	Stops the voltage to stop.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:0000000008799902

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side maker lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

**NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

**CAUTION:**

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-63, "Component Function Check".](#)
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.


Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"><li>• Parking lamps</li><li>• License plate lamps</li><li>• Side maker lamps</li><li>• Tail lamps</li><li>• Front fog lamps</li></ul>	10 seconds
4	Headlamps	<ul style="list-style-type: none"><li>• LO 10 seconds</li><li>• HI ON ↔ OFF 5 times</li></ul>
5	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
6*	Cooling fan	MID for 5 seconds → HI for 5 seconds

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Parking lamps • License plate lamps • Side maker lamps • Tail lamps • Front fog lamps • Headlamp (HI, LO) • Front wiper (HI, LO)	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES • Unified meter and A/C amp. signal input circuit • CAN communication signal between unified meter and A/C amp. and ECM • CAN communication signal between ECM and IPDM E/R
		NO • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES • Harness or connector between IPDM E/R and oil pressure switch • Oil pressure switch • IPDM E/R
		NO • CAN communication signal between IPDM E/R and BCM • CAN communication signal between BCM and unified meter and A/C amp. • Combination meter

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul> <ul style="list-style-type: none"> <li>• Cooling fan</li> <li>• Harness or connector between cooling fan and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connector between IPDM E/R and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT Function (IPDM E/R)

INFOID:000000008799903

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-32, "DTC Index"](#).

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay request received from BCM via CAN communication. <b>NOTE:</b> For models without steering lock unit, this item is not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R. <b>NOTE:</b> For models without steering lock unit, this item is not monitored.
DTRL REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

### Test item

Test item	Operation	Description
CORNERRING LAMP	Off	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay 1 and horn relay 2 for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Test item	Operation	Description
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## WIPER AND WASHER FUSE

< DTC/CIRCUIT DIAGNOSIS >

# DTC/CIRCUIT DIAGNOSIS

## WIPER AND WASHER FUSE

### Description

INFOID:0000000008286196

Fuse list

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	#60	30 A
Washer pump	IPDM E/R	#47	10 A

### Diagnosis Procedure

INFOID:0000000008286197

#### 1.CHECK FUSES

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	#60	30 A
Washer pump	IPDM E/R	#47	10 A

#### Is the fuse fusing?

- YES    >> Replace the fuse with a new one after repairing the applicable circuit.  
NO     >> The fuse is normal.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:0000000008286198

#### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	K
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		
Connector	Terminal	
M118	1	Ground
M119	11	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M119	13	Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:0000000008286199

#### 1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Signal name	Fuses and fusible link No.
	C
Battery power supply	50
	51

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		
Connector	Terminal	Ground
E4	1	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

## 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Continuity
Connector	Terminal	
E5	12	
E6	41	Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

# FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR LO CIRCUIT

### Component Function Check

INFOID:0000000008286200

#### 1.CHECK FRONT WIPER LO OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).

2. Check that the front wiper operates at the LO operation.

##### CONSULT ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.  
2. With operating the test item, check front wiper operation.

**Lo : Front wiper (LO) operation**

**Off : Stop the front wiper.**

Is front wiper (LO) operation normally?

YES >> Front wiper motor LO circuit is normal.

NO >> Refer to [WW-25, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000008286201

#### 1.CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

1. Turn the ignition switch OFF, and wait for 20 seconds or more.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON, and wait for 10 seconds.
4. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Ap-prox.)
(+)		
IPDM E/R		Ground
Connector	Terminal	
E5	4	Battery voltage (10 seconds*)

\*: According to front wiper protection function, IPDM E/R supplies voltage for 10 seconds (battery voltage) and then stops for 20 seconds (0 V). This operation repeats 5 times, and then IPDM E/R stops voltage supply. To perform the check again, turn ignition switch OFF, wait for 20 seconds or more, and then perform the check.

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R.

#### 2.CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	4	E42	1	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harness or connector.

#### 3.CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

## FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

---

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	4		Not existed

Does continuity exist?

YES >> Repair the harness or connector.

NO >> Replace front wiper motor.

# FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR HI CIRCUIT

### Component Function Check

INFOID:0000000008286202

#### 1.CHECK FRONT WIPER HI OPERATION

IPDM E/R AUTO ACTIVE TEST

- Start IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).

- Check that the front wiper operates at the HI operation.

CONSULT ACTIVE TEST

- Select “FRONT WIPER” of IPDM E/R active test item.
- With operating the test item, check front wiper operation.

**Hi : Front wiper (HI) operation**

**Off : Stop the front wiper.**

Is front wiper (HI) operation normally?

YES >> Front wiper motor HI circuit is normal.

NO >> Refer to [WW-27, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000008286203

#### 1.CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

- Turn the ignition switch OFF, and wait for 20 seconds or more.
- Disconnect front wiper motor connector.
- Turn the ignition switch ON.
- Select “FRONT WIPER” of IPDM E/R active test item.
- With operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Appr.)
(+)	(-)		
IPDM E/R		FRONT WIPER	
Connector	Terminal		
E5	5	Hi	Battery voltage (10 seconds*)

\*: According to front wiper protection function, IPDM E/R supplies voltage for 10 seconds (battery voltage) and then stops for 20 seconds (0 V). This operation repeats 5 times, and then IPDM E/R stops voltage supply. To perform the check again, turn ignition switch OFF, wait for 20 seconds or more, and then perform the check.

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R.

#### 2.CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	5	E42	4	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harness or connector.

#### 3.CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

## FRONT WIPER MOTOR HI CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	5		Not existed

#### Does continuity exist?

YES    >> Repair the harness or connector.

NO    >> Replace front wiper motor.

# FRONT WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER STOP POSITION SIGNAL CIRCUIT

### Component Function Check

INFOID:000000008286204

#### 1. CHECK FRONT WIPER STOP POSITION SIGNAL

##### CONSULT DATA MONITOR

1. Select "WIP AUTO STOP" of IPDM E/R data monitor item.
2. Operate the front wiper.
3. With the front wiper operation, check the monitor status.

Monitor item	Condition		Monitor status
WIP AUTO STOP	Front wiper motor	Stop position	STOP P
		Except stop position	ACT P

Is the status of item normal?

- YES >> Front wiper stop position signal circuit is normal.  
NO >> Refer to [WW-29, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000008286205

#### 1. CHECK FRONT WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R	Ground	
Connector	Terminal	Battery voltage
E5	16	

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Continuity
Connector	Terminal	
E5	16	
		Not existed

Does continuity exist?

- YES >> Repair the harnesses or connectors.  
NO >> Replace IPDM E/R.

#### 3. CHECK FRONT WIPER MOTOR (AUTO STOP) CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

## FRONT WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

---

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	16	E42	5	Existed

Does continuity exist?

YES    >> Replace front wiper motor.

NO    >> Repair the harnesses or connectors.

# FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR GROUND CIRCUIT

### Diagnosis Procedure

INFOID:0000000008286206

#### 1.CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E42	2		Existed

Does continuity exist?

- YES    >> Front wiper motor ground circuit is normal.  
NO    >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# WASHER SWITCH


< DTC/CIRCUIT DIAGNOSIS >

## WASHER SWITCH

### Description

INFOID:0000000008286207

- Washer switch is integrated with combination switch.
- Combination switch operates front washer or rear washer by changing voltage polarity to be supplied to washer pump.



### Component Inspection

INFOID:0000000008286208

#### 1.CHECK WIPER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch connector.
3. Check continuity between the combination switch terminals.

- A : Terminal 4  
B : Terminal 6  
C : Terminal 3  
D : Terminal 1

	OFF	FR	RR
A		O	O
B			O
C	O		O
D	O	O	O

JPLIA0164GB

Combination switch		Condition	Continuity
Terminal			
1	6	Front washer switch ON	Existed
3	4		
1	4	Rear washer switch ON	
3	6		

#### Does continuity exist?

- YES >> Wiper and washer switch is normal.  
NO >> Replace combination switch (Wiper and washer switch).

## REAR WIPER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER MOTOR CIRCUIT

### Component Function Check

INFOID:0000000008286209

#### 1.CHECK REAR WIPER ON OPERATION

##### CONSULT ACTIVE TEST

1. Select "RR WIPER" of BCM active test item.
2. With operating the test item, check rear wiper operation.

**On : Rear wiper ON operation**

**Off : Stop the rear wiper.**

Is rear wiper operation normally?

YES >> Rear wiper motor circuit is normal.

NO >> Refer to [WW-33, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000008286210

#### 1.CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

##### CONSULT ACTIVE TEST

1. Turn rear wiper switch OFF, and wait for 1 minute or more.
2. Turn the ignition switch OFF.
3. Disconnect rear wiper motor connector.
4. Turn the ignition switch ON.
5. Select "RR WIPER" of BCM active test item.
6. With operating the test item, check voltage between BCM harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		Ground	REAR WIPER
Connector	Terminal		
M120	26	On	Battery voltage (5 seconds*)

\*: When "REAR WIPER" is "On" for 5 seconds or more during active test of CONSULT, BCM stops the power supply according to rear wiper motor protection function. To perform the check again, turn "REAR WIPER" to "Off", wait for 1 minute or more, and then perform the check.

Is the measurement value normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK REAR WIPER MOTOR SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Not existed
M120	26		

Does continuity exist?

YES >> Repair the harness or connector.

NO >> Replace BCM. Refer to [BCS-96, "Exploded View"](#).

#### 3.CHECK REAR WIPER MOTOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## REAR WIPER MOTOR CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and rear wiper motor harness connector.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M120	26	D115	2	Existed

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harness or connector.

## 4.CHECK REAR WIPER MOTOR GROUND OPEN CIRCUIT

Check continuity between rear wiper motor harness connector and ground.

Rear wiper motor		Ground	Continuity
Connector	Terminal		
D115	4		Existed

Does continuity exist?

YES >> Replace rear wiper motor.

NO >> Repair the harness or connector.

# REAR WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER STOP POSITION SIGNAL CIRCUIT

### Component Function Check

INFOID:0000000008286211

#### 1. CHECK REAR WIPER (AUTO STOP) OPERATION

##### (B) CONSULT DATA MONITOR

1. Select "WIPER" of BCM data monitor item.
2. Operate the rear wiper.
3. Check that "RR WIPER STOP" changes to "ON" and "OFF" linked with the wiper operation.

Monitor item	Condition		Monitor status
RR WIPER STOP	Rear wiper motor	Stop position	Off
		Except stop position	On

Is the status of item normal?


- YES >> Rear wiper stop position signal circuit is normal.  
NO >> Refer to [WW-35, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000008286212

#### 1. CHECK REAR WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between BCM harness connector and ground.



Is the measurement value normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK REAR WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M121	65	Not existed

Does continuity exist?

- YES >> Repair the harness or connector.  
NO >> Replace BCM. Refer to [BCS-96, "Exploded View"](#).

## REAR WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### 3.CHECK REAR WIPER MOTOR (AUTO STOP) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M121	65	D115	3	Existed

Does continuity exist?

- YES    >> Replace rear wiper motor.  
NO     >> Repair the harness or connector.

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AND WASHER SYSTEM


### Wiring Diagram - FRONT WIPER AND WASHER SYSTEM -

INFOID:0000000008286213

For connector terminal arrangements, harness layouts, and alphabets in a (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

: Refer to "Connector Information" in "HOW TO READ WIRING DIAGRAMS" in "GENERAL INFORMATION".

### FRONT WIPER AND WASHER SYSTEM



2013/11/22

JRLWD2204GB

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AND WASHER SYSTEM

Terminal No.	Wire	Signal Name [Specification]	Terminal No.	Wire	Signal Name [Specification]
46	R	-	18	V	-
47	BR	-	20	BG	-
48	-	-	21	L	-
49	-	-	22	V	-
50	BR	-	23	G	-
51	-	-	24	P	-
52	-	-	25	Y	-
53	-	-	26	V	-
54	-	-	27	W	-
55	-	-	28	G	-
56	-	-	31	BG	-
57	-	-	32	W	-
58	-	-	33	B	-
59	-	-	34	R	-
60	-	-	35	G	-
61	-	-	36	SHIELD	-
62	-	-	37	V	-
63	-	-	38	BR	-
64	-	-	39	BG	-
65	-	-	41	W	-
66	-	-	42	G	-
67	-	-	43	BR	-
68	GR	-	45	W	-
69	BR	-	49	L	-
70	P	-	50	P	-
71	-	-	51	L	-
72	-	-	54	BG	-
73	-	-	57	BR	-
74	-	-	59	W	-
75	-	-	60	LG	-
76	-	-	61	G	-
77	-	-	62	SB	-
78	-	-	63	W	-
79	-	-	64	B	-
80	-	-	65	G	-
81	-	-	66	R	-
82	-	-	67	SHIELD	-
83	-	-	68	Y	-
84	-	-	69	LG	-
85	-	-	70	W	-
86	-	-	71	R	-
87	W	-	72	Y	-
88	W	-	73	B	-
89	GR	-	74	BR	- [With ICG]
90	BR	-	74	L	- [Without ICG]
91	P	-	75	G	- [With ICG]
92	BR	-	75	W	- [Without ICG]
93	Y	-	76	W	- [With ICG]
94	SB	-	76	Y	- [Without ICG]
95	-	-	77	-	-

JRLWD2386GB

# FRONT WIPER AND WASHER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

A

<b>FRONT WIPER AND WASHER SYSTEM</b>	8A	L	-	
77 P	- (Without ICC)	-		
77 R	- (With ICC)	-		
78 BR	- (Without ICC)	-		
78 L	- (With ICC)	-		
79 L	- (Without ICC)	-		
79 Y	- (With ICC)	-		
80 SB	-	-		
81 R	-	-		
82 SB	-	-		
83 BG	-	-		
84 G	-	-		
85 L	-	-		
86 P	-	-		
87 V	-	-		
89 GR	-	-		
90 SHIELD	-	-		
91 W	-	-		
92 Y	-	-		
93 V	-	-		
94 LG	-	-		
95 BG	-	-		
96 P	-	-		
97 R	-	-		
98 SHIELD	-	-		
99 L	-	-		
100 P	-	-		
39 BR	-	-		
41 W	-	-		
42 BG	-	-		
43 EG	-	-		
45 W	-	-		
49 L	-	-		
50 P	-	-		
51 BR	-	-		
54 Y	-	-		
57 G	-	-		
59 W	-	-		
60 L	-	-		
61 G	-	-		
62 SB	-	-		
63 G	-	-		
64 B	-	-		
66 R	-	-		
67 SHIELD	-	-		
68 Y	-	-		
69 GR	-	-		
70 LG	-	-		
71 LG	-	-		
72 Y	-	-		
73 SB	-	-		
74 BR	(With ICC)	-		
74 L	-	-		
74 R	(Without ICC)	-		
75 G	-	-		
76 GR	-	-		
76 W	-	-		
77 P	-	-		
77 Y	-	-		
78 L	(With ICC)	-		
78 R	(Without ICC)	-		
79 W	-	-		
79 Y	-	-		
80 SB	-	-		
81 SB	-	-		
82 SB	-	-		
83 V	-	-		
84 G	-	-		
85 L	-	-		
86 P	-	-		
87 W	-	-		
88 GR	-	-		
89 SHIELD	-	-		
90 W	-	-		
91 W	-	-		
92 Y	-	-		
93 BR	-	-		
94 P	-	-		
38 BG	-	-		

WW

M

Z

O

P

A

A

B

D

T

G

WW

JRLWD2387GB

# FRONT WIPER AND WASHER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

## FRONT WIPER AND WASHER SYSTEM

Terminal Color Of No.	Wire Signal Name [Specification]	Color Of Wire	Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Color Of Wire	Signal Name [Specification]
4	G IGN	IGN	OUTPUT 3 GROUND	5	L GND	SB	PASSENGER DOOR ANTI-
6	B	GROUND	INPUT 3	7	V	GR	PASSENGER DOOR ANTI+
8	BG	INPUT 5	OUTPUT 5	9	Y	V	DRIVER DOOR ANTI-
10	R	INPUT 4	INPUT 4	11	LG	Y	DRIVER DOOR ANTI+
12	P	OUTPUT 1	OUTPUT 1	13	BR	NEUT 5	ROOM ANTI-
14	G	OUTPUT 2	OUTPUT 2				ROOM ANTI+
							NR'S ANTI AMP
							NR'S ANTI AMP
							IGN RELAY (FB) / CONF
							KEYLESS ENTRY RECEIVER COMM
							COMBI SW INPUT 5
							COMBI SW INPUT 3
							CANL
							CANH
							KEY SLOTTED CONN
							ONIND
							PUDLE LAMP CONN
							ACC RELAY CONN
							ACC SHIFT SELECTOR POWER SUPPLY
							SHIFT P
							PASSENGER DOOR REQUEST SW
							DRIVER DOOR REQUEST SW
							BLOWER FAN MOTOR RELAY CONN
							KEYLESS ENTRY RECEIVER POWER SUPPLY
							COMBI SW INPUT 4
							COMBI SW INPUT 2
							HAZARD SW

JRLWD2388GB

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## FRONT WIPER AND WASHER SYSTEM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH0FG-NH



Terminal Color Of No.	Wire	Signal Name (Specification)
113	P	OPTICAL SENSOR
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR. DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN. HB
124	LG	PASSENGER DOOR SW
132	BR	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW/L POWER
134	GR	LOCK IND.
137	BG	RECEIVERSENSOR GND
138	Y	RECEIVERSENSOR POWER SUPPLY
139	L	TIRE PRESSURE RECEIVER COMM
140	GR	SHIFT INP
141	G	SECURITY/IND LAMP CONT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	LG	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

JRLWD2389GB

# REAR WIPER AND WASHER SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM

### Wiring Diagram - REAR WIPER AND WASHER SYSTEM -

INFOID:0000000008286214

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).





# REAR WIPER AND WASHER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

## REAR WIPER AND WASHER SYSTEM

Connector No.			Connector No.		
Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
6 O	-	22 V	-	22 V	-
13 R	-	23 G	-	24 P	-
14 L	- [With around view monitor]	25 Y	-	26 V	-
14 SHIELD	- [Without around view monitor]	27 W	-	28 G	-
15 Y	-	28 G	-	31 BG	-
15 SHIELD	-	32 W	-	33 B	-
16 G	- [With around view monitor]	34 R	-	35 G	-
16 L	- [Without around view monitor]	36 SHIELD	-	37 V	-
17 G	- [Without around view monitor]	38 BR	-	39 BG	-
17 W	- [With around view monitor]	41 W	-	42 G	-
18 SHIELD	-	43 BR	-	45 W	-
19 LG	-	46 W	-	49 L	-
20 O	-	50 P	-	51 L	-
21 V	-	52 T80FW-CS16-TMA	-	54 BG	-
22 P	-	55 T80FW-CS16-TMA	-	57 BR	-
23 BR	-	58 T80FW-CS16-TMA	-	59 W	-
24 R	-	60 LG	-	61 G	-
				62 SB	-
				63 W	-
				64 B	-
				65 G	-
				66 R	-
				67 SHIELD	-
				68 Y	-
				69 LG	-
				70 W	-
				71 R	-
				72 Y	-
				73 B	-
				74 BR	- [Without ICCI]
				74 L	- [With ICCI]
				75 G	- [Without ICCI]
				75 W	- [With ICCI]
				76 W	- [Without ICCI]
				76 Y	- [With ICCI]
				77 P	- [Without ICCI]
				77 R	- [With ICCI]
				78 BR	- [Without ICCI]
				78 L	- [With ICCI]

JRLWD2391GB

# REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A      B      C      D      E      F      G      H      I      J      K      L      M      N

## REAR WIPER AND WASHER SYSTEM

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
79	L - (Without CC)	43	BG
79	Y - (With CC)	45	W
80	SB	49	L
81	R	50	P
82	SB	51	BR
83	BG	54	Y
84	G	57	G
85	L	59	W
86	P	60	L
87	V	61	G
89	GR	62	SB
90	SHIELD	63	G
91	W	64	B
92	Y	65	W
93	V	66	R
94	LG	67	SHIELD
95	BG	68	Y
96	P	69	GR
97	R	70	LG
98	SHIELD	71	LG
99	L	72	Y
100	P	73	SB
		74	BR
		74	L
		74	BR
		75	G
		76	CR
		76	W
		77	P
		77	R
		78	L
		78	R
		79	W
		79	Y
		80	SB
		81	SB
		82	SB
		83	V
		84	G
		85	L
		86	P
		87	W
		89	GR
		90	SHIELD
		91	W
		92	Y
		93	BR
		94	P
		95	GR
		96	W
		97	L
		42	BG

JRLWD2392GB

# REAR WIPER AND WASHER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

## REAR WIPER AND WASHER SYSTEM

		Signal Name [Specification]									
45	GR	12	P	OUTPUT 1							
46	LG	13	BR		INPUT 5						
47	SB	14	G		OUTPUT 2						
49	V										
50	R										
60	P										
61	L										
62	SHEILD										
63	R										
64	G										
65	SHEILD										
66	SB										
67	V										
68	LG										
69	SHEILD										
70	W										
73	G										
74	R										
75	W										
76	W										
77	B										
78	P										
79	GIR										
83	BG										
85	LG										
86	R										
87	Y										
88	W										
89	BR										
90	BG										
91	G										
92	V										
93	BR										
94	V										
95	G										
96	Y										
99	R										
		Signal Name [Specification]									
1	P	1	2	3	4	5	6				
		7	8	9	[0:1]	12	13	14			
		Signal Name [Specification]									
1	P	FR WASHER(-)	SB	OUTPUT 4							
			GR	FR WASHER(+)							
3	IGN		G	IGN							
4	G		L	OUTPUT 3							
5	L			GROUND							
6	B			INPUT 3							
7	V			INPUT 3							
8	BG			OUTPUT 5							
9	Y			INPUT 2							
10	R			INPUT 4							
11	LG			INPUT 1							


JRLWD2393GB

# REAR WIPER AND WASHER SYSTEM

**< DTC/CIRCUIT DIAGNOSIS >**

## REAR WIPER AND WASHER SYSTEM

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS127W-CS



Terminal Color Of No.	Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	G	BACK DOOR OPEN OUTPUT
25	G	TURN SIGNAL LH (REAR)
26	G	REAR WIPER OUTPUT



Terminal Color Of No.	Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANTI-
35	V	LUGGAGE ROOM ANTI+
38	B	BACK DOOR ANTI-
39	W	BACK DOOR ANTI
47	Y	IGN RELAY (UPFM ERI) CONT
52	SB	STARTER RELAY CONT
60	BR	PUSH SW
61	W	BACK DOOR OPENER REQUEST SW
64	V	I-KEY WARN BUZZER (ENG ROOM)
65	BG	REAR WIPER STOP POSITION
66	R	BACK DOOR SW
68	GR	BACK DOOR OPENER SW
69	R	REAR RH DOOR SW

JRLWD2394GB

A

B

C

D

E

F

G

H

K

WW

M

Z

O

P

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

# ECU DIAGNOSIS INFORMATION

## BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:000000008772593

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

#### CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REVERSE SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
ACC RLY -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L -UNLOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L RELAY-F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L RELAY-REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Shift position is in the P position)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT




PHYSICAL VALUES

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
WW  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (W)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN-LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					0 V
10 (BR)	Ground	Rear RH door and rear LH door UN-LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	
13 (B)	Ground	Ground	—	Ignition switch ON	
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC







**NOTE:**  
When the illumination brightening/dimming level is in the neutral position

JSNIA0010GB





# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch RH   PKID0926E 6.5 V
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch LH   PKID0926E 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF
					ON  Battery voltage
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch RH   PKID0926E 6.5 V
23 (G)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)
					Other than OPEN (Back door opener actuator is not activated)  0 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch LH   PKID0926E 6.5 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)
					ON (Operated)  0 V Battery voltage





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
34 (SB)	Ground	Luggage room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment			
				 (V) 15 10 5 0 JMKA0062GB			
35 (V)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compartment			
				 (V) 15 10 5 0 JMKA0063GB			
38 (B)	Ground	Back door antenna (-)	Output When the back door opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area			
				 (V) 15 10 5 0 JMKA0062GB			
				When Intelligent Key is not in the antenna detection area			
				 (V) 15 10 5 0 JMKA0063GB			

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	(V)  JMKA0062GB
					When Intelligent Key is not in the antenna detection area	(V)  JMKA0063GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
60 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	(V)  JPMIA0016GB 1.0 V
64 (V)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (BG)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	(V)  JPMIA0016GB 1.0 V
					Not in stop position	0 V

A

B

C

D

E

F

G

H

I

J

K

WW

M





N

O

P







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
66 (R)	Ground	Back door switch	Input	Back door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
67 (GR)	Ground	Back door opener switch	Input	Back door opener switch
				Pressed   <small>JPMIA0011GB</small> 11.8 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch
				OFF (Door close)   <small>JPMIA0011GB</small> 11.8 V
				ON (Door open) 0 V
				ON (Door open) 0 V

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
75 (GR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the passenger door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

J

K

WW

M

N


O

P


# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+      -	Signal name		
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF
				When Intelligent Key is not in the antenna detection area
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When Intelligent Key is not in the passenger compartment
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When Intelligent Key is not in the passenger compartment




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB





JMKIA0062GB



JMKIA0063GB




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K WW M N O P	
	+	-	Signal name	Input/ Output		
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.	B
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.	C
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC ON 0 V Battery voltage	D
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting	(V) 15 10 5 0  JMKA0064GB	E
				When operating either button on the key	(V) 15 10 5 0  JMKA0065GB	F G H I J K WW M N O P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
87 (BR)	Ground	Combination switch INPUT 5	Input	 All switches OFF (Wiper intermittent dial 4)   Front fog lamp switch ON (Wiper intermittent dial 4)   Rear wiper switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>
				JPMIA0041GB 1.4 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
				JPMIA0040GB 1.3 V

# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Lighting switch HI (Wiper intermittent dial 4)	 JPMIA0036GB 1.3 V
				Lighting switch 2ND (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear washer switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>	 JPMIA0040GB 1.3 V
90 (P)	Ground	CAN-L	Input/ Output	—	—
91 (L)	Ground	CAN-H	Input/ Output	—	—

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 WW  
 M  
 N  
 O  
 P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 (V) 15 10 5 0 1 s
					ON	6.5 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
					ON (Pressed)	1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms
					ON (Pressed)	1.0 V
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermittent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
				Turn signal switch LH	 JPMIA0037GB 1.3 V
				Turn signal switch RH	 JPMIA0036GB 1.3 V
				Front wiper switch LO	 JPMIA0038GB 1.3 V
				Front washer switch ON	 JPMIA0039GB 1.3 V






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input	 All switches OFF (Wiper intermittent dial 4)   Lighting switch AUTO (Wiper intermittent dial 4)   Lighting switch 1ST (Wiper intermittent dial 4)   Rear wiper switch INT (Wiper intermittent dial 4)   Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>
				JPMIA0041GB 1.4 V
				JPMIA0038GB 1.3 V
				JPMIA0036GB 1.3 V
				JPMIA0040GB 1.3 V




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
					Lighting switch PASS	 JPMIA0037GB 1.3 V
					Lighting switch 2ND	 JPMIA0036GB 1.3 V
					Front wiper switch INT	 JPMIA0038GB 1.3 V
					Front wiper switch HI	 JPMIA0040GB 1.3 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	ON	0 V
					OFF	 JPMIA0012GB 1.1 V




# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 JPMIA0012GB 1.1 V	
					UNLOCK status (Unlock switch sensor ON)	0 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 JPMIA0011GB 11.8 V	
					ON (Door open)	0 V	
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 JPMIA0013GB 10.2 V	
				Ignition switch OFF or ACC		Battery voltage	

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	<p><b>NOTE:</b> The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  <p>JPMIA0159GB</p>
					OFF	0 V
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (BG)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 <p>OCC3881D</p>
					When receiving the signal from the transmitter	 <p>OCC3880D</p>
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 <p>JPMIA0014GB</p> <p>11.3 V</p>
					OFF	Battery voltage

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
142 (BG)	Ground	Combination switch OUTPUT 5	Combination switch (Wiper intermittent dial 4)	All switches OFF
				Lighting switch 1ST
				Lighting switch HI
				Lighting switch 2ND
				Turn signal switch RH
143 (P)	Ground	Combination switch OUTPUT 1	Combination switch	All switches OFF (Wiper intermittent dial 4)
				Front wiper switch HI (Wiper intermittent dial 4)
				Rear wiper switch INT (Wiper intermittent dial 4)
				Any of the conditions below with all switches OFF
				<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>
144 (G)	Ground	Combination switch OUTPUT 2	Combination switch	All switches OFF (Wiper intermittent dial 4)
				Front washer switch ON (Wiper intermittent dial 4)
				Rear wiper switch ON (Wiper intermittent dial 4)
				Rear washer switch ON (Wiper intermittent dial 4)
				Any of the conditions below with all switches OFF
				<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>
145 (L)	Ground	Combination switch OUTPUT 3	Combination switch (Wiper intermittent dial 4)	All switches OFF
				Front wiper switch INT
				Front wiper switch LO
				Lighting switch AUTO




JPMIA0031GB

10.7 V




JPMIA0032GB

10.7 V



JPMIA0033GB

10.7 V





JPMIA0034GB

10.7 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L M N O P WW	
	+	-	Signal name	Input/ Output		
146 (SB)	Ground	Combination switch OUTPUT 4	Combination switch (Wiper intermittent dial 4)	Output	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	 JPMIA0035GB 10.7 V
150 (LG)	Ground	Driver door switch	Driver door switch	Input	OFF (Door close)	 JPMIA0011GB 11.8 V
					ON (Door open)	0 V
151 (G)	Ground	Rear window defogger relay control	Rear window defogger	Output	Active	0 V
					Not activated	Battery voltage


# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

**Wiring Diagram - BCM -**

INFOID:0000000008772594

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




2013/11/22

JRMWE9529GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE9530GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
WW

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

-  : With sunroof
-  : With automatic drive positioner
-  : Without automatic drive positioner




\* : This connector is not shown in "Harness Layout".

JRMWE9531GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWE9532GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
WW  
Z

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





JRMWE9533GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th><th colspan="2">B16</th><th colspan="2">Terminal Color Of Wire</th><th colspan="2">Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>Connector Name</td><td colspan="2">FRONT DOOR SWITCH (DRIVER SIDE)</td><td>1</td><td>B</td><td>-</td><td>-</td></tr> <tr> <td>Connector Type</td><td colspan="2">A03FW</td><td>2</td><td>L</td><td>-</td><td>-</td></tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B16		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)		1	B	-	-	Connector Type	A03FW		2	L	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th><th colspan="2">B228</th><th colspan="2">Terminal Color Of Wire</th><th colspan="2">Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>Connector Name</td><td colspan="2">INSIDE KEY ANTENNA (LUGGAGE ROOM)</td><td>1</td><td>V</td><td>-</td><td>-</td></tr> <tr> <td>Connector Type</td><td colspan="2">TR02FGY</td><td>2</td><td>SB</td><td>-</td><td>-</td></tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B228		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)		1	V	-	-	Connector Type	TR02FGY		2	SB	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th><th colspan="2">B242</th><th colspan="2">Terminal Color Of Wire</th><th colspan="2">Signal Name [Specification]</th></tr> </thead> <tbody> <tr> <td>Connector Name</td><td colspan="2">FUEL LID LOCK ACTUATOR</td><td>1</td><td>R</td><td>-</td><td>-</td></tr> <tr> <td>Connector Type</td><td colspan="2">M04FH/C</td><td>2</td><td>V</td><td>-</td><td>-</td></tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B242		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	FUEL LID LOCK ACTUATOR		1	R	-	-	Connector Type	M04FH/C		2	V	-	-
Connector No.	B16		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)		1	B	-	-																																																											
Connector Type	A03FW		2	L	-	-																																																											
Connector No.	B228		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)		1	V	-	-																																																											
Connector Type	TR02FGY		2	SB	-	-																																																											
Connector No.	B242		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	FUEL LID LOCK ACTUATOR		1	R	-	-																																																											
Connector Type	M04FH/C		2	V	-	-																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B17</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">FRONT DOOR SWITCH (PASSENGER SIDE)</td> <td>1</td> <td>V</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">A03FW</td> <td>2</td> <td>SB</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B17		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)		1	V	-	-	Connector Type	A03FW		2	SB	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B229</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">LUGGAGE ROOM LAMP (LUGGAGE SIDE)</td> <td>1</td> <td>V</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">TR03FW</td> <td>2</td> <td>SB</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B229		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	LUGGAGE ROOM LAMP (LUGGAGE SIDE)		1	V	-	-	Connector Type	TR03FW		2	SB	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B249</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">BRAKE BOOSTER CONTROL UNIT</td> <td>1</td> <td>R</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">TR24FGY</td> <td>2</td> <td>V</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B249		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	BRAKE BOOSTER CONTROL UNIT		1	R	-	-	Connector Type	TR24FGY		2	V	-	-
Connector No.	B17		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)		1	V	-	-																																																											
Connector Type	A03FW		2	SB	-	-																																																											
Connector No.	B229		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	LUGGAGE ROOM LAMP (LUGGAGE SIDE)		1	V	-	-																																																											
Connector Type	TR03FW		2	SB	-	-																																																											
Connector No.	B249		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	BRAKE BOOSTER CONTROL UNIT		1	R	-	-																																																											
Connector Type	TR24FGY		2	V	-	-																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B23</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">REAR DOOR SWITCH LH</td> <td>1</td> <td>L</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">A03FW</td> <td>2</td> <td>V</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B23		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	REAR DOOR SWITCH LH		1	L	-	-	Connector Type	A03FW		2	V	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B223</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">REAR DOOR SWITCH RH</td> <td>1</td> <td>V</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">A03FW</td> <td>2</td> <td>SB</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B223		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	REAR DOOR SWITCH RH		1	V	-	-	Connector Type	A03FW		2	SB	-	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Connector No.</th> <th colspan="2">B247</th> <th colspan="2">Terminal Color Of Wire</th> <th colspan="2">Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td colspan="2">DIODE</td> <td>1</td> <td>GR</td> <td>-</td> <td>-</td> </tr> <tr> <td>Connector Type</td> <td colspan="2">24335_C3900</td> <td>2</td> <td>BR</td> <td>-</td> <td>-</td> </tr> </tbody> </table>  <p><b>H.S.</b></p>	Connector No.	B247		Terminal Color Of Wire		Signal Name [Specification]		Connector Name	DIODE		1	GR	-	-	Connector Type	24335_C3900		2	BR	-	-
Connector No.	B23		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	REAR DOOR SWITCH LH		1	L	-	-																																																											
Connector Type	A03FW		2	V	-	-																																																											
Connector No.	B223		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	REAR DOOR SWITCH RH		1	V	-	-																																																											
Connector Type	A03FW		2	SB	-	-																																																											
Connector No.	B247		Terminal Color Of Wire		Signal Name [Specification]																																																												
Connector Name	DIODE		1	GR	-	-																																																											
Connector Type	24335_C3900		2	BR	-	-																																																											

JRMWE9716GB

P

M

Z

O

K

WW

A

B

C

D

E

G

I

J

K

L


N

EX

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B414</td></tr> <tr><td>Connector Name</td><td>POWER SEAT SWITCH</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B414	Connector Name	POWER SEAT SWITCH	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B451</td></tr> <tr><td>Connector Name</td><td>DRIVER SEAT CONTROL UNIT</td></tr> <tr><td>Connector Type</td><td>TH20FW</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B451	Connector Name	DRIVER SEAT CONTROL UNIT	Connector Type	TH20FW	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 R</td><td>LY</td></tr> <tr><td>2 B</td><td>-</td></tr> <tr><td>3 G/Y</td><td>R/Y</td></tr> <tr><td>4 P</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>6 V</td><td>-</td></tr> <tr><td>7 LY</td><td>-</td></tr> <tr><td>8 L</td><td>-</td></tr> <tr><td>9 U/R</td><td>-</td></tr> <tr><td>10 G/W</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 R	LY	2 B	-	3 G/Y	R/Y	4 P	-	5 W	-	6 V	-	7 LY	-	8 L	-	9 U/R	-	10 G/W	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 L/W</td><td>EX</td></tr> <tr><td>2 R/Y</td><td>CANH</td></tr> <tr><td>3 W/G</td><td>PULSE (RECLINING)</td></tr> <tr><td>4 P/B</td><td>PULSE (FR LIFTING)</td></tr> <tr><td>5 BR</td><td>SLIDING SW (BACKWARD)</td></tr> <tr><td>6 SB</td><td>RECLINING SW (BACKWARD)</td></tr> <tr><td>7 LG/R</td><td>FRONT LIFTING SW (DOWNWARD)</td></tr> <tr><td>8 GR/B</td><td>REAR LIFTING SW (DOWNWARD)</td></tr> <tr><td>9 O</td><td>VCC</td></tr> <tr><td>10 Y/R</td><td>TX</td></tr> <tr><td>11 V</td><td>CANL</td></tr> <tr><td>12 LY</td><td>P RANGE SW</td></tr> <tr><td>13 LY</td><td>PULSE (SLIDING)</td></tr> <tr><td>14 GR</td><td>PULSE (FR LIFTING)</td></tr> <tr><td>15 Y</td><td>SLIDING SW (FORWARD)</td></tr> <tr><td>16 G</td><td>RECLINING SW (UPWARD)</td></tr> <tr><td>17 TX</td><td>FRONT LIFTING SW (UPWARD)</td></tr> <tr><td>18 W</td><td>REAR LIFTING SW (UPWARD)</td></tr> <tr><td>19 B</td><td>SENSOR GND</td></tr> <tr><td>20 GR</td><td>GND (SIGNAL)</td></tr> <tr><td>21 GR</td><td>PULSE (SLIDING)</td></tr> <tr><td>22 BR</td><td>PULSE (FR LIFTING)</td></tr> <tr><td>23 Y</td><td>SLIDING SW (FORWARD)</td></tr> <tr><td>24 V</td><td>RECLINING SW (UPWARD)</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 L/W	EX	2 R/Y	CANH	3 W/G	PULSE (RECLINING)	4 P/B	PULSE (FR LIFTING)	5 BR	SLIDING SW (BACKWARD)	6 SB	RECLINING SW (BACKWARD)	7 LG/R	FRONT LIFTING SW (DOWNWARD)	8 GR/B	REAR LIFTING SW (DOWNWARD)	9 O	VCC	10 Y/R	TX	11 V	CANL	12 LY	P RANGE SW	13 LY	PULSE (SLIDING)	14 GR	PULSE (FR LIFTING)	15 Y	SLIDING SW (FORWARD)	16 G	RECLINING SW (UPWARD)	17 TX	FRONT LIFTING SW (UPWARD)	18 W	REAR LIFTING SW (UPWARD)	19 B	SENSOR GND	20 GR	GND (SIGNAL)	21 GR	PULSE (SLIDING)	22 BR	PULSE (FR LIFTING)	23 Y	SLIDING SW (FORWARD)	24 V	RECLINING SW (UPWARD)
Connector No.	B414																																																																																						
Connector Name	POWER SEAT SWITCH																																																																																						
Connector Type	NS10FW-CS																																																																																						
Connector No.	B451																																																																																						
Connector Name	DRIVER SEAT CONTROL UNIT																																																																																						
Connector Type	TH20FW																																																																																						
Terminal Color Of Wire	Signal Name [Specification]																																																																																						
1 R	LY																																																																																						
2 B	-																																																																																						
3 G/Y	R/Y																																																																																						
4 P	-																																																																																						
5 W	-																																																																																						
6 V	-																																																																																						
7 LY	-																																																																																						
8 L	-																																																																																						
9 U/R	-																																																																																						
10 G/W	-																																																																																						
Terminal Color Of Wire	Signal Name [Specification]																																																																																						
1 L/W	EX																																																																																						
2 R/Y	CANH																																																																																						
3 W/G	PULSE (RECLINING)																																																																																						
4 P/B	PULSE (FR LIFTING)																																																																																						
5 BR	SLIDING SW (BACKWARD)																																																																																						
6 SB	RECLINING SW (BACKWARD)																																																																																						
7 LG/R	FRONT LIFTING SW (DOWNWARD)																																																																																						
8 GR/B	REAR LIFTING SW (DOWNWARD)																																																																																						
9 O	VCC																																																																																						
10 Y/R	TX																																																																																						
11 V	CANL																																																																																						
12 LY	P RANGE SW																																																																																						
13 LY	PULSE (SLIDING)																																																																																						
14 GR	PULSE (FR LIFTING)																																																																																						
15 Y	SLIDING SW (FORWARD)																																																																																						
16 G	RECLINING SW (UPWARD)																																																																																						
17 TX	FRONT LIFTING SW (UPWARD)																																																																																						
18 W	REAR LIFTING SW (UPWARD)																																																																																						
19 B	SENSOR GND																																																																																						
20 GR	GND (SIGNAL)																																																																																						
21 GR	PULSE (SLIDING)																																																																																						
22 BR	PULSE (FR LIFTING)																																																																																						
23 Y	SLIDING SW (FORWARD)																																																																																						
24 V	RECLINING SW (UPWARD)																																																																																						

JRMWE9717GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**


BCM (BODY CONTROL MODULE)	
5 O	-
6 Y	-
7 BR	-
8 L	-
9 O	-
10 Y	-
11 G	-
13 P	-
14 V	-
15 B	-

Connector No.	D13	Connector No.	D15	Connector No.	D42
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWCH)	Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVERSIDE)	Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	RK02FL	Connector Type	E06GY-RS	Connector Type	TB02FW



Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-



Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 LG	-	1 R	-
2 P	-	2 SB	-
3 L	-	4 B	-
4 B	-	5 Y	-
6 V	-	6 V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
WW  
M  
Z  
P

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>D44</td></tr> <tr><td>Connector Name</td><td>FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA</td></tr> <tr><td>Connector Type</td><td>EK02NGY</td></tr> </table>  	Connector No.	D44	Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA	Connector Type	EK02NGY	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D54</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH LH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table>	Connector No.	D54	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Type	NS08FW-CS								
Connector No.	D44																																			
Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA																																			
Connector Type	EK02NGY																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D54																																			
Connector Name	REAR POWER WINDOW SWITCH LH																																			
Connector Type	NS08FW-CS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D74</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table>	Connector No.	D74	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FW-CS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D74																																			
Connector Name	REAR POWER WINDOW SWITCH RH																																			
Connector Type	NS08FW-CS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D74</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table>	Connector No.	D74	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FW-CS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D74																																			
Connector Name	REAR POWER WINDOW SWITCH RH																																			
Connector Type	NS08FW-CS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D75</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>	Connector No.	D75	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	E06FCY-RS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D75																																			
Connector Name	REAR DOOR LOCK ASSEMBLY RH																																			
Connector Type	E06FCY-RS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D75</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>	Connector No.	D75	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	E06FCY-RS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D75																																			
Connector Name	REAR DOOR LOCK ASSEMBLY RH																																			
Connector Type	E06FCY-RS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D76</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>	Connector No.	D76	Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE	Connector Type	E06FCY-RS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D76																																			
Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE																																			
Connector Type	E06FCY-RS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D76</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>	Connector No.	D76	Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE	Connector Type	E06FCY-RS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D76																																			
Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE																																			
Connector Type	E06FCY-RS																																			
<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Terminal Color Of Wire No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1 P</td><td>Y</td></tr> <tr><td>2 V</td><td>-</td></tr> <tr><td>3 G</td><td>-</td></tr> <tr><td>4 L</td><td>-</td></tr> <tr><td>5 W</td><td>-</td></tr> <tr><td>7 B</td><td>-</td></tr> </table>	Terminal Color Of Wire No.	Signal Name [Specification]	1 P	Y	2 V	-	3 G	-	4 L	-	5 W	-	7 B	-	<table border="1"> <tr><td>Connector No.</td><td>D77</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FCY-RS</td></tr> </table>	Connector No.	D77	Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE	Connector Type	E06FCY-RS
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Terminal Color Of Wire No.	Signal Name [Specification]																																			
1 P	Y																																			
2 V	-																																			
3 G	-																																			
4 L	-																																			
5 W	-																																			
7 B	-																																			
Connector No.	D77																																			
Connector Name	FRONT DOOR LOCK ASSEMBLY PASSENGER SIDE																																			
Connector Type	E06FCY-RS																																			

JRMWE9719GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>D114</td><td>Connector No.</td><td>D116</td></tr> <tr><td>Connector Name</td><td>BACK DOOR OPENER SWITCH</td><td>Connector Name</td><td>FRONT INTERMITTENT POWER DISTRIBUTION NODULE ENGINE ROOM</td></tr> <tr><td>Connector Type</td><td>TKOZM1ER-P</td><td>Connector Type</td><td>TH20FW-CS12-M4-IV</td></tr> </table>   	Connector No.	D114	Connector No.	D116	Connector Name	BACK DOOR OPENER SWITCH	Connector Name	FRONT INTERMITTENT POWER DISTRIBUTION NODULE ENGINE ROOM	Connector Type	TKOZM1ER-P	Connector Type	TH20FW-CS12-M4-IV	<table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td><td>V</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table> <table border="1"> <tr><td>Terminal Color Of No.</td><td>Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>BR</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of No.	Wire	Signal Name [Specification]	1	GR	V	2	B	-	Terminal Color Of No.	Wire	Signal Name [Specification]	1	Y	-	2	B	-	Terminal Color Of No.	Wire	Signal Name [Specification]	1	Y	-	2	R	-	Terminal Color Of No.	Wire	Signal Name [Specification]	1	BR	-	2	R	-	Terminal Color Of No.	Wire	Signal Name [Specification]	1	BR	-	2	R	-	Terminal Color Of No.	Wire	Signal Name [Specification]	1	BR	-	2	R	-	<table border="1"> <tr><td>Connector No.</td><td>E5</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP RH ENGINE ROOM</td></tr> <tr><td>Connector Type</td><td>TS05FB-FR</td></tr> </table>   	Connector No.	E5	Connector Name	FRONT COMBINATION LAMP RH ENGINE ROOM	Connector Type	TS05FB-FR
Connector No.	D114	Connector No.	D116																																																																							
Connector Name	BACK DOOR OPENER SWITCH	Connector Name	FRONT INTERMITTENT POWER DISTRIBUTION NODULE ENGINE ROOM																																																																							
Connector Type	TKOZM1ER-P	Connector Type	TH20FW-CS12-M4-IV																																																																							
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	GR	V																																																																								
2	B	-																																																																								
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	Y	-																																																																								
2	B	-																																																																								
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	Y	-																																																																								
2	R	-																																																																								
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	BR	-																																																																								
2	R	-																																																																								
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	BR	-																																																																								
2	R	-																																																																								
Terminal Color Of No.	Wire	Signal Name [Specification]																																																																								
1	BR	-																																																																								
2	R	-																																																																								
Connector No.	E5																																																																									
Connector Name	FRONT COMBINATION LAMP RH ENGINE ROOM																																																																									
Connector Type	TS05FB-FR																																																																									

JRMWE9720GB

A B C D E F G H I J K L M P Q R S T V W Z O

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

**BCM (BODY CONTROL MODULE)**

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
25 Y	BUS-L	1	L	1	POWER SUPPLY
26 LG	DP FL	2	W	2	POWER SUPPLY/MEMORY BACK-UP
27 GR	DS RL	3	Y	3	CANH
28 G	UZ	4	SB	4	K LINE
29 LG	DS RR			5	GROUND
30 SB	BLS			6	POWER SUPPLY
31 R	VDC OFF SW			7	BACK-UP LAMP RELAY
35 L	CANH			8	CANL
45 B	BLSH			9	STARTER RELAY
				10	GROUND

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
2 B	-	1	L	1	POWER SUPPLY
3 BY	-	2	W	2	-
4 BW	-	3	Y	3	-
5 V	-	4	SB	4	-
6 G	-			5	-
7 P	-			6	-
8 BG	-			7	-
				8	-

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 V	-	1	L	1	POWER SUPPLY
2 B	-	2	W	2	POWER SUPPLY/MEMORY BACK-UP
3 P	-	3	O	3	CANH
4 SB	-	4	V	4	K LINE
6 P	-	5	B	5	GROUND
7 R	-	6	Y	6	POWER SUPPLY
		7	R	7	BACK-UP LAMP RELAY
		8	LG	8	CANL
		9	GR	9	STARTER RELAY
		10	B	10	GROUND

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 Y	-	1	L	1	POWER SUPPLY
2 BR	-	2	G	2	POWER SUPPLY/MEMORY BACK-UP
4F G	-	3	GR	3	CANH
6F L	-	4	GR	4	K LINE
9F R	-	5	GR	5	GROUND
		6	GR	6	POWER SUPPLY
		7	GR	7	BACK-UP LAMP RELAY
		8	GR	8	CANL
		9	GR	9	STARTER RELAY
		10	GR	10	GROUND




Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 Y	-	1	P	1	- [For push button]
3 V	-	2	V	2	- [For key slot]
		3	V	3	-

JRMWE9721GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M9</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (JB)</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table> 	Connector No.	M9	Connector Name	FUSE BLOCK (JB)	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M2</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (JB)</td></tr> <tr><td>Connector Type</td><td>24355.C9900</td></tr> </table> 	Connector No.	M2	Connector Name	FUSE BLOCK (JB)	Connector Type	24355.C9900	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M9</td></tr> <tr><td>Connector Name</td><td>DIODE</td></tr> <tr><td>Connector Type</td><td>24355.C9900</td></tr> </table> 	Connector No.	M9	Connector Name	DIODE	Connector Type	24355.C9900																																														
Connector No.	M9																																																																	
Connector Name	FUSE BLOCK (JB)																																																																	
Connector Type	NS10FW-CS																																																																	
Connector No.	M2																																																																	
Connector Name	FUSE BLOCK (JB)																																																																	
Connector Type	24355.C9900																																																																	
Connector No.	M9																																																																	
Connector Name	DIODE																																																																	
Connector Type	24355.C9900																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>3B</td><td>P</td></tr> <tr><td>4B</td><td>G</td></tr> <tr><td>5B</td><td>BG</td></tr> <tr><td>6B</td><td>Y</td></tr> <tr><td>7B</td><td>P</td></tr> <tr><td>8B</td><td>R</td></tr> <tr><td>9B</td><td>SIB</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	3B	P	4B	G	5B	BG	6B	Y	7B	P	8B	R	9B	SIB	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td></tr> <tr><td>2</td><td>W</td></tr> <tr><td>3</td><td>-</td></tr> <tr><td>4</td><td>-</td></tr> <tr><td>5</td><td>-</td></tr> <tr><td>6</td><td>L</td></tr> <tr><td>7</td><td>V</td></tr> <tr><td>8</td><td>G</td></tr> <tr><td>11</td><td>SB</td></tr> <tr><td>14</td><td>P</td></tr> <tr><td>16</td><td>Y</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	R	2	W	3	-	4	-	5	-	6	L	7	V	8	G	11	SB	14	P	16	Y	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td></tr> <tr><td>2</td><td>W</td></tr> <tr><td>3</td><td>-</td></tr> <tr><td>4</td><td>-</td></tr> <tr><td>5</td><td>-</td></tr> <tr><td>6</td><td>L</td></tr> <tr><td>7</td><td>V</td></tr> <tr><td>8</td><td>G</td></tr> <tr><td>11</td><td>SB</td></tr> <tr><td>14</td><td>P</td></tr> <tr><td>16</td><td>Y</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	R	2	W	3	-	4	-	5	-	6	L	7	V	8	G	11	SB	14	P	16	Y
Terminal Color Of No.	Signal Name [Specification]																																																																	
3B	P																																																																	
4B	G																																																																	
5B	BG																																																																	
6B	Y																																																																	
7B	P																																																																	
8B	R																																																																	
9B	SIB																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	R																																																																	
2	W																																																																	
3	-																																																																	
4	-																																																																	
5	-																																																																	
6	L																																																																	
7	V																																																																	
8	G																																																																	
11	SB																																																																	
14	P																																																																	
16	Y																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	R																																																																	
2	W																																																																	
3	-																																																																	
4	-																																																																	
5	-																																																																	
6	L																																																																	
7	V																																																																	
8	G																																																																	
11	SB																																																																	
14	P																																																																	
16	Y																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M22</td></tr> <tr><td>Connector Name</td><td>KEY SLOT</td></tr> <tr><td>Connector Type</td><td>1H12FW-NH</td></tr> </table>	Connector No.	M22	Connector Name	KEY SLOT	Connector Type	1H12FW-NH	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td></tr> <tr><td>2</td><td>W</td></tr> <tr><td>3</td><td>-</td></tr> <tr><td>4</td><td>-</td></tr> <tr><td>5</td><td>-</td></tr> <tr><td>6</td><td>L</td></tr> <tr><td>7</td><td>V</td></tr> <tr><td>8</td><td>G</td></tr> <tr><td>11</td><td>SB</td></tr> <tr><td>14</td><td>P</td></tr> <tr><td>16</td><td>Y</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	R	2	W	3	-	4	-	5	-	6	L	7	V	8	G	11	SB	14	P	16	Y	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M27</td></tr> <tr><td>Connector Name</td><td>FOOT LAMP (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>A02FW</td></tr> </table>	Connector No.	M27	Connector Name	FOOT LAMP (DRIVER SIDE)	Connector Type	A02FW																												
Connector No.	M22																																																																	
Connector Name	KEY SLOT																																																																	
Connector Type	1H12FW-NH																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	R																																																																	
2	W																																																																	
3	-																																																																	
4	-																																																																	
5	-																																																																	
6	L																																																																	
7	V																																																																	
8	G																																																																	
11	SB																																																																	
14	P																																																																	
16	Y																																																																	
Connector No.	M27																																																																	
Connector Name	FOOT LAMP (DRIVER SIDE)																																																																	
Connector Type	A02FW																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M3</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (JB)</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table>	Connector No.	M3	Connector Name	FUSE BLOCK (JB)	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>12</td><td>10</td></tr> <tr><td>13</td><td>11</td></tr> <tr><td>14</td><td>9C</td></tr> <tr><td>15</td><td>TC</td></tr> <tr><td>16</td><td>AC</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	12	10	13	11	14	9C	15	TC	16	AC	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M21</td></tr> <tr><td>Connector Name</td><td>DATA</td></tr> <tr><td>Connector Type</td><td>TRKFBR</td></tr> </table>	Connector No.	M21	Connector Name	DATA	Connector Type	TRKFBR																																								
Connector No.	M3																																																																	
Connector Name	FUSE BLOCK (JB)																																																																	
Connector Type	NS10FW-CS																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
12	10																																																																	
13	11																																																																	
14	9C																																																																	
15	TC																																																																	
16	AC																																																																	
Connector No.	M21																																																																	
Connector Name	DATA																																																																	
Connector Type	TRKFBR																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td></tr> <tr><td>2</td><td>GR</td></tr> <tr><td>3</td><td>W</td></tr> <tr><td>5</td><td>Y</td></tr> <tr><td>6</td><td>LG</td></tr> <tr><td>7</td><td>B</td></tr> <tr><td>11</td><td>BR</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	R	2	GR	3	W	5	Y	6	LG	7	B	11	BR	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td></tr> <tr><td>2</td><td>BR</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	R	2	BR	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M50</td></tr> <tr><td>Connector Name</td><td>PUSH-BUTTON IGNITION SWITCH</td></tr> <tr><td>Connector Type</td><td>TRKFBR</td></tr> </table>	Connector No.	M50	Connector Name	PUSH-BUTTON IGNITION SWITCH	Connector Type	TRKFBR																																				
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	R																																																																	
2	GR																																																																	
3	W																																																																	
5	Y																																																																	
6	LG																																																																	
7	B																																																																	
11	BR																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	R																																																																	
2	BR																																																																	
Connector No.	M50																																																																	
Connector Name	PUSH-BUTTON IGNITION SWITCH																																																																	
Connector Type	TRKFBR																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>10C</td><td>L</td></tr> <tr><td>11C</td><td>R</td></tr> <tr><td>12C</td><td>BG</td></tr> <tr><td>6C</td><td>R</td></tr> <tr><td>7C</td><td>B</td></tr> <tr><td>9C</td><td>BG</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	10C	L	11C	R	12C	BG	6C	R	7C	B	9C	BG	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>B</td></tr> <tr><td>2</td><td>W</td></tr> <tr><td>3</td><td>W</td></tr> <tr><td>4</td><td>BR</td></tr> <tr><td>5</td><td>GR</td></tr> <tr><td>6</td><td>Y</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	B	2	W	3	W	4	BR	5	GR	6	Y	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of No.</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>-</td></tr> <tr><td>2</td><td>-</td></tr> <tr><td>3</td><td>-</td></tr> <tr><td>4</td><td>-</td></tr> <tr><td>5</td><td>-</td></tr> <tr><td>6</td><td>-</td></tr> </table>	Terminal Color Of No.	Signal Name [Specification]	1	-	2	-	3	-	4	-	5	-	6	-																						
Terminal Color Of No.	Signal Name [Specification]																																																																	
10C	L																																																																	
11C	R																																																																	
12C	BG																																																																	
6C	R																																																																	
7C	B																																																																	
9C	BG																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	B																																																																	
2	W																																																																	
3	W																																																																	
4	BR																																																																	
5	GR																																																																	
6	Y																																																																	
Terminal Color Of No.	Signal Name [Specification]																																																																	
1	-																																																																	
2	-																																																																	
3	-																																																																	
4	-																																																																	
5	-																																																																	
6	-																																																																	

JRMWE9722GB

A B C D E F G H I J K L M N O P Q R S T W Z

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

**BCM (BODY CONTROL MODULE)**

Connector No.	M67	Connector No.	M72
Connector Name	UNIFIED METER AND A/C AMP.	Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH32FW-NH	Connector Type	TH16FW-NH
Connector No.	M53	Terminal Color Of Wire	Signal Name [Specification]
Connector Name	COMBINATION METER	No.	No.
Connector Type	TH40FW-NH	Wire	Signal Name [Specification]
1	GR	1	V
2	LG	2	Y
3	GR	3	R
4	B	4	P
5	B	5	G
6	P	6	SB
7	BR	7	BR
10	G	8	LG
15	B	9	B
16	B	14	Y
19	B	15	Y
20	R	16	G
21	BG	17	W
22	B	18	W
24	BR	19	W
25	Y	20	W
26	R	21	W
27	V	22	W
28	W	23	W
29	SB	24	W
30	G	25	W
31	L	26	W
33	B	27	W
36	LG	28	W
37	SB	29	W
38	L	30	W
39	P	31	W
40	BG	32	W

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1	ACC POWER SUPPLY	1	GROUND
2	FUEL LEVEL SENSOR SIGNAL	2	ACC
3	IN-VEHICLE SENSOR SIGNAL	3	R
4	IN-VEHICLE SENSOR SIGNAL	4	P
5	AMBIENT SENSOR SIGNAL	5	Y
6	SUN LOAD SENSOR SIGNAL	6	SB
8	AV COMM (L)	8	LG
9	SM GND	9	B
14	DISK EJECT SIGNAL	14	Y
16	HAZARD ON	16	G

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1	GROUND	1	GROUND
2	ILL. CONT.	2	ILL. CONT.
3	IGNITION SIGNAL	3	IGNITION SIGNAL
4	GROUND	4	GROUND

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1	OPTICAL SENSOR	1	OPTICAL SENSOR
2	GROUND	2	GROUND
3	GROUND	3	GROUND
4	GROUND	4	GROUND

Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1	POWER	1	POWER
2	OUTPUT	2	OUTPUT
3	GROUND	3	GROUND

JRMWE9723GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No. M119

Connector Name FOOT LAMP (PASSENGER SIDE)

Connector Type A02FW





Connector No. M121

Connector Name BCM (BODY CONTROL MODULE)

Connector Type NS16FW-CS





NATS ANT AMP.	80	GR
NATS ANT AMP.	81	W
IGN/RELAY (EBI) COMM	82	R
KEYLESS ENTRY RECEIVER COMM	83	Y
COMBI SW INPUT 15	87	BR
COMBI SW INPUT 3	88	V
PUDLE LAMP COMM	90	P
ACC RELAY CONT	91	L
CANHL	92	LG
KEY SLOT TLL CONT	93	V
ON/IND	94	Y
A/T SHIFT SELECTOR POWER SUPPLY	95	BG
SHIFT P	96	GR
PASSENGER DOOR REQUEST SW	99	R
DRIVER DOOR REQUEST SW	100	G
BLOWER FAN MOTOR RELAY CONT	101	SB
KEYLESS ENTRY RECEIVER POWER SUPPLY	102	BG
COMBI SW INPUT 1	103	LG
STARTER RELAY CONT	107	LG
REAR DOOR UNLOCK OUTPUT	108	R
BUSH SW	109	Y
BACK DOOR OPENER REQUEST SW	110	G

Connector No. M118

Connector Name BCM (BODY CONTROL MODULE)

Connector Type NS05FW-LC





Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1 R	INTERIOR ROOM LAMP POWER SUPPLY	34 LG	INTERIOR ROOM ANT.
2 BR	-	35 L	PASSENGER DOOR ANTI-
		38 V	LUGGAGE ROOM ANTI-
		39 B	BACK DOOR ANTI-
		47 Y	IGN/RELAY (IPDM ERI) CONT
		52 SB	REAR DOOR UNLOCK OUTPUT
		60 BR	BUSH SW
		61 W	BACK DOOR OPENER REQUEST SW
		64 V	I-KEY WARM BUZZER (ENG ROOM)
		65 BG	REAR WIPER STOP POSITION
		66 R	BACK DOOR SW
		67 CR	BACK DOOR OPENER SW
		68 BR	REAR RHT DOOR SW
		69 R	REAR LHD DOOR SW

Connector No. M120

Connector Name BCM (BODY CONTROL MODULE)

Connector Type NS12FW-CS





Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1 W	BAT (FIL)	23 P	OFF/ON SENSOR
2 W	POWER WINDOW POWER SUPPLY(BAT)	24 SB	STOP LAMP SW 1
3 Y	POWER WINDOW POWER SUPPLY(RAP)	25 W	STOP LAMP SW 2

Terminal Color Of Wire

Signal Name [Specification]

Connector No. M122

Connector Name BCM (BODY CONTROL MODULE)

Connector Type TH0FB-VH





Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
20 V	TURN SIGNAL RH (REAR)	74 SB	PASSENGER DOOR ANTI-
23 G	BACH DOOR OPEN OUTPUT	75 GR	PASSENGER DOOR ANTI-
25 G	TURN SIGNAL LH (REAR)	76 V	DRIVER DOOR ANTI-
26 G	REAR WIPER OUTPUT	77 LG	DRIVER DOOR ANTI+
		78 Y	ROOM ANTI-
		79 BR	ROOM ANTI+

Terminal Color Of Wire

Signal Name [Specification]

Connector No. M123

Connector Name BCM (BODY CONTROL MODULE)

Connector Type 114GF-G-NH





Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
13 P	OFF/ON SENSOR	14 SB	DR DOOR UNLOCK SENSOR
16 SB	STOP LAMP SW 1	17 W	IGN/IB
18 P	STOP LAMP SW 2	19 BR	PASSENGER DOOR SW
20 W	POWER WINDOW SW COMM	21 LG	POWER WINDOW SW COMM
22 BR	PUSH+BUTTON (INTN) SW LL POWER	23 W	PUSH+BUTTON (INTN) SW LL POWER
24 BR	LOCK IND.	25 BR	LOCK IND.
26 BR	REVERSE SENSOR SW COMM	27 Y	REVERSE SENSOR SW COMM
28 Y	RECEIVER SENSOR POWER SUPPLY	29 Y	RECEIVER SENSOR POWER SUPPLY



JRMWE9724GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>M137</td><td>Connector No.</td><td>R12</td></tr> <tr><td>Connector Name</td><td>A/T SHIFT SELECTOR</td><td>Connector Name</td><td>VANITY MIRROR LAMP LH</td></tr> <tr><td>Connector Type</td><td>TH20W-NH</td><td>Connector Type</td><td>MC40F/N</td></tr> </table>  <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>W</td></tr> <tr><td>2</td><td>V</td></tr> <tr><td>3</td><td>L</td></tr> <tr><td>4</td><td>B</td></tr> <tr><td>5</td><td>G</td></tr> <tr><td>7</td><td>R</td></tr> <tr><td>8</td><td>S8</td></tr> <tr><td>9</td><td>B</td></tr> <tr><td>10</td><td>G/R</td></tr> <tr><td>11</td><td>R</td></tr> </table>	Connector No.	M137	Connector No.	R12	Connector Name	A/T SHIFT SELECTOR	Connector Name	VANITY MIRROR LAMP LH	Connector Type	TH20W-NH	Connector Type	MC40F/N	Terminal Color Of Wire	Signal Name [Specification]	No. 1	W	2	V	3	L	4	B	5	G	7	R	8	S8	9	B	10	G/R	11	R	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>-</td></tr> <tr><td>2</td><td>-</td></tr> </table> 	Terminal Color Of Wire	Signal Name [Specification]	No. 1	-	2	-
Connector No.	M137	Connector No.	R12																																						
Connector Name	A/T SHIFT SELECTOR	Connector Name	VANITY MIRROR LAMP LH																																						
Connector Type	TH20W-NH	Connector Type	MC40F/N																																						
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	W																																								
2	V																																								
3	L																																								
4	B																																								
5	G																																								
7	R																																								
8	S8																																								
9	B																																								
10	G/R																																								
11	R																																								
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	-																																								
2	-																																								
<table border="1"> <tr><td>Connector No.</td><td>M129</td><td>Connector No.</td><td>R13</td></tr> <tr><td>Connector Name</td><td>OPTION CONNECTOR (1)</td><td>Connector Name</td><td>VANITY MIRROR LAMP RH</td></tr> <tr><td>Connector Type</td><td>TH08MW-NH</td><td>Connector Type</td><td>MC40F/N</td></tr> </table>  <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>W</td></tr> <tr><td>2</td><td>V</td></tr> <tr><td>3</td><td>L</td></tr> <tr><td>4</td><td>B</td></tr> <tr><td>5</td><td>G</td></tr> <tr><td>7</td><td>R</td></tr> <tr><td>8</td><td>S8</td></tr> <tr><td>9</td><td>B</td></tr> <tr><td>10</td><td>G/R</td></tr> <tr><td>11</td><td>R</td></tr> </table>	Connector No.	M129	Connector No.	R13	Connector Name	OPTION CONNECTOR (1)	Connector Name	VANITY MIRROR LAMP RH	Connector Type	TH08MW-NH	Connector Type	MC40F/N	Terminal Color Of Wire	Signal Name [Specification]	No. 1	W	2	V	3	L	4	B	5	G	7	R	8	S8	9	B	10	G/R	11	R	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>-</td></tr> <tr><td>2</td><td>-</td></tr> </table> 	Terminal Color Of Wire	Signal Name [Specification]	No. 1	-	2	-
Connector No.	M129	Connector No.	R13																																						
Connector Name	OPTION CONNECTOR (1)	Connector Name	VANITY MIRROR LAMP RH																																						
Connector Type	TH08MW-NH	Connector Type	MC40F/N																																						
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	W																																								
2	V																																								
3	L																																								
4	B																																								
5	G																																								
7	R																																								
8	S8																																								
9	B																																								
10	G/R																																								
11	R																																								
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	-																																								
2	-																																								
<table border="1"> <tr><td>Connector No.</td><td>M131</td><td>Connector No.</td><td>R4</td></tr> <tr><td>Connector Name</td><td>INSIDE KEY/ANTENNA/INSTRUMENT CENTER</td><td>Connector Name</td><td>SUNROOF MOTOR ASSEMBLY</td></tr> <tr><td>Connector Type</td><td>HR20FGY</td><td>Connector Type</td><td>YEAT10FGY</td></tr> </table>  <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 3</td><td>G</td></tr> <tr><td>6</td><td>R</td></tr> </table>	Connector No.	M131	Connector No.	R4	Connector Name	INSIDE KEY/ANTENNA/INSTRUMENT CENTER	Connector Name	SUNROOF MOTOR ASSEMBLY	Connector Type	HR20FGY	Connector Type	YEAT10FGY	Terminal Color Of Wire	Signal Name [Specification]	No. 3	G	6	R	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>-</td></tr> <tr><td>2</td><td>-</td></tr> </table> 	Terminal Color Of Wire	Signal Name [Specification]	No. 1	-	2	-																
Connector No.	M131	Connector No.	R4																																						
Connector Name	INSIDE KEY/ANTENNA/INSTRUMENT CENTER	Connector Name	SUNROOF MOTOR ASSEMBLY																																						
Connector Type	HR20FGY	Connector Type	YEAT10FGY																																						
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 3	G																																								
6	R																																								
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	-																																								
2	-																																								
<table border="1"> <tr><td>Connector No.</td><td>M131</td><td>Connector No.</td><td>SW-BT1</td></tr> <tr><td>Connector Name</td><td>INSIDE KEY/ANTENNA/INSTRUMENT CENTER</td><td>Connector Name</td><td>SW-BT-</td></tr> <tr><td>Connector Type</td><td>HR20FGY</td><td>Connector Type</td><td>HR</td></tr> </table>  <table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>BR</td></tr> <tr><td>2</td><td>Y</td></tr> </table>	Connector No.	M131	Connector No.	SW-BT1	Connector Name	INSIDE KEY/ANTENNA/INSTRUMENT CENTER	Connector Name	SW-BT-	Connector Type	HR20FGY	Connector Type	HR	Terminal Color Of Wire	Signal Name [Specification]	No. 1	BR	2	Y	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>No. 1</td><td>P</td></tr> <tr><td>5</td><td>L</td></tr> <tr><td>8</td><td>Y</td></tr> <tr><td>9</td><td>G</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	No. 1	P	5	L	8	Y	9	G												
Connector No.	M131	Connector No.	SW-BT1																																						
Connector Name	INSIDE KEY/ANTENNA/INSTRUMENT CENTER	Connector Name	SW-BT-																																						
Connector Type	HR20FGY	Connector Type	HR																																						
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	BR																																								
2	Y																																								
Terminal Color Of Wire	Signal Name [Specification]																																								
No. 1	P																																								
5	L																																								
8	Y																																								
9	G																																								

JRMWE9725GB

INFOID:0000000008772595

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

## REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

## DTC Inspection Priority Chart

INFOID:000000008772596

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
3	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI SCANNING</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC
4	<ul style="list-style-type: none"> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP SW</li> <li>• B2605: PNP SW</li> <li>• B2608: STARTER RELAY</li> <li>• B260A: IGNITION RELAY</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2614: ACC RELAY CIRC</li> <li>• B2615: BLOWER RELAY CIRC</li> <li>• B2616: IGN RELAY CIRC</li> <li>• B2617: STARTER RELAY CIRC</li> <li>• B2618: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B26EA: KEY REGISTRATION</li> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• U0415: VEHICLE SPEED SIG</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1734: CONTROL UNIT</li> </ul>
6	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>

## DTC Index

INFOID:0000000008772597

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	<a href="#">BCS-41</a>
U1010: CONTROL UNIT (CAN)	—	—	—	—	<a href="#">BCS-42</a>
U0415: VEHICLE SPEED SIG	—	—	—	—	<a href="#">BCS-43</a>
B2190: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-40</a>

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2191: DIFFERENCE OF KEY	×	—	—	—	<a href="#">SEC-43</a>
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-44</a>
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-45</a>
B2195: ANTI SCANNING	×	—	—	—	<a href="#">SEC-46</a>
B2553: IGNITION RELAY	—	×	—	—	<a href="#">PCS-50</a>
B2555: STOP LAMP	—	×	—	—	<a href="#">SEC-47</a>
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-49</a>
B2557: VEHICLE SPEED	×	×	×	—	<a href="#">SEC-51</a>
B2560: STARTER CONT RELAY	×	×	×	—	<a href="#">SEC-52</a>
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-44</a>
B2601: SHIFT POSITION	×	×	×	—	<a href="#">SEC-53</a>
B2602: SHIFT POSITION	×	×	×	—	<a href="#">SEC-56</a>
B2603: SHIFT POSI STATUS	×	×	×	—	<a href="#">SEC-59</a>
B2604: PNP SW	×	×	×	—	<a href="#">SEC-62</a>
B2605: PNP SW	×	×	×	—	<a href="#">SEC-64</a>
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-66</a>
B260A: IGNITION RELAY	×	×	×	—	<a href="#">PCS-52</a>
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-68</a>
B2614: ACC RELAY CIRC	—	×	×	—	<a href="#">PCS-54</a>
B2615: BLOWER RELAY CIRC	—	×	×	—	<a href="#">PCS-57</a>
B2616: IGN RELAY CIRC	—	×	×	—	<a href="#">PCS-60</a>
B2617: STARTER RELAY CIRC	×	×	×	—	<a href="#">SEC-71</a>
B2618: BCM	×	×	×	—	<a href="#">PCS-63</a>
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-73</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-76</a>
B2621: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-58</a>
B2623: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-60</a>
B26E1: ENG STATE NO RES	×	×	×	—	<a href="#">SEC-69</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-70</a>
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-23</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	<a href="#">WT-25</a>
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	

A

B

C

D

E

F

G

H

I

J

WW

M

N

O

P

## BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-28</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-30</a>
C1734: CONTROL UNIT	—	—	—	×	<a href="#">WT-32</a>

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### Reference Value

INFOID:000000008799904

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		• Front fog lamp switch ON • Daytime running light activated (Only for Canada)	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

WW

M

N

O

P


**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
**<ECU DIAGNOSIS INFORMATION >**

Monitor Item	Condition		Value/Status
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On
ST/INHI RLY	Ignition switch ON		Off
	At engine cranking		INHI ON → ST ON
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> <li>• Press the selector button with selector lever in P position</li> <li>• Selector lever in any position other than P</li> </ul>	Off
	Release the selector button with selector lever in P position		On
S/L RLY -REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off
S/L STATE	<b>NOTE:</b> The item is indicated, but not monitored.		UNLOCK
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off
OIL P SW	Ignition switch OFF, ACC or engine running		Open
	Ignition switch ON		Close
HOOD SW	Close the hood		Off
	Open the hood		On
HL WASHER REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off
THFT HRN REQ	Not operation		Off
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>		On
HORN CHIRP	Not operating		Off
	Door locking with Intelligent Key (horn chirp mode)		On
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
4 (V)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
				Front wiper switch ON	Front wiper switch HI	Battery voltage
7 (R)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
				Lighting switch ON	Lighting switch 1ST	Battery voltage
12 (B/W)	Ground	Ground	—	Ignition switch ON		0 V
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> <li>• Approximately 1 second after turning the ignition switch ON</li> <li>• Engine running</li> </ul>		Battery voltage
16 (LG)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
				Any position other than front wiper stop position		Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## <ECU DIAGNOSIS INFORMATION>

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
19 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
26* (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF	
				Battery voltage	
27 (BG)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC	
				0 V	
28 (L)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	
				Battery voltage	
30 (GR)	Ground	Starter relay control	Input	Ignition switch ON	
				Selector lever in any position other than P or N	
				0 V	
				Selector lever P or N	
				Battery voltage	
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
39 (P)	—	CAN-L	Input/ Output	—	—
40 (L)	—	CAN-H	Input/ Output	—	—
41 (B/W)	Ground	Ground	—	Ignition switch ON	0 V
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON	0.7 V
43 (SB)	Ground	A/T shift selector (Detention switch)	Input	Ignition switch ON	• Press the selector button (Selector lever P) • Selector lever in any position other than P
					Release the selector button (selector lever P)
					0 V
44 (BR)	Ground	Horn relay control	Input	The horn is deactivated	Battery voltage
				The horn is activated	0 V
45 (G)	Ground	Anti theft horn relay control	Input	The horn is deactivated	Battery voltage
				The horn is activated	0 V
46 (R)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any position other than P or N
					0 V
					Selector lever P or N
					Battery voltage
48 (L)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF
					A/C switch ON (A/C compressor is operating)
					Battery voltage
49 (BG)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage




# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)				
	Signal name	Input/ Output						
51 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF				
				Battery voltage				
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)				
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>				
54 (P)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)				
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>				
55 (SB)	Ground	ECM power supply	Output	Ignition switch OFF				
56 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF				
				Battery voltage				
57 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF				
				Battery voltage				
58 (V)	Ground	Ignition relay power supply	Output	Ignition switch OFF				
				Battery voltage				
69 (BR)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)				
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>				
70 (BG)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF				
				$\begin{matrix} 0 - 1.0 \text{ V} \\ \downarrow \\ \text{Battery voltage} \\ \downarrow \\ 0 \text{ V} \end{matrix}$				
74 (P)	Ground	Ignition relay power supply	Output	Ignition switch OFF				
				Battery voltage				
75 (SB)	Ground	Oil pressure switch	Input	<table border="1"> <tr> <td>Ignition switch ON</td> <td>Engine stopped</td> </tr> <tr> <td></td> <td>Engine running</td> </tr> </table>	Ignition switch ON	Engine stopped		Engine running
Ignition switch ON	Engine stopped							
	Engine running							
0 V								
				Battery voltage				

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## <ECU DIAGNOSIS INFORMATION>

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
76 (Y)	Ground	Power generation com-mand signal	Output	Ignition switch ON
				 JPMIA0001GB 6.3 V
				 JPMIA0002GB 3.8 V
77 (R)	Ground	Fuel pump relay control	Output	40% is set on "ACTIVE TEST", "AL-TERNATOR DUTY" of "ENGINE"
				 JPMIA0003GB 1.4 V
				80% is set on "ACTIVE TEST", "AL-TERNATOR DUTY" of "ENGINE"
80 (W)	Ground	Starter motor	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>
				Approximately 1 second or more after turning the ignition switch ON
83 (BG)	Ground	Headlamp LO (RH)	Output	Lighting switch OFF
				Lighting switch 2ND
84 (V)	Ground	Headlamp LO (LH)	Output	Lighting switch OFF
				Lighting switch 2ND
86 (W)	Ground	Front fog lamp (RH)	Output	Front fog lamp switch OFF
				<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Can-ada)</li> </ul>
87 (L)	Ground	Front fog lamp (LH)	Output	Front fog lamp switch OFF
				<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Can-ada)</li> </ul>
88 (GR)	Ground	Washer pump power sup- ply	Output	Ignition switch ON
				Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
89 (BR)	Ground	Headlamp HI (RH)	Output Ignition switch ON	Lighting switch OFF
				• Lighting switch HI • Lighting switch PASS
90 (P)	Ground	Headlamp HI (LH)	Output Ignition switch ON	Lighting switch OFF
				• Lighting switch HI • Lighting switch PASS
91 (P)	Ground	Parking lamp (RH)	Output Ignition switch ON	Lighting switch OFF
				Lighting switch 1ST
92 (BG)	Ground	Parking lamp (LH)	Output Ignition switch ON	Lighting switch OFF
				Lighting switch 1ST
97 (V)	Ground	Cooling fan control	Output	Engine idling
104 (LG)	Ground	Hood switch	Input	Close the hood
				Open the hood

\*: Only for the models with ICC system

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R -

INFOID:0000000008799905

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)




2012/06/11

JRMWD2716GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >




JRMWD2717GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
WW  
M  
N  
O  
P

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**  
< ECU DIAGNOSIS INFORMATION >

---



JRMWD2718GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

A  
B  
C  
D  
M  
T  
G  
I  
—  
K  
WW  
M  
Z  
O  
P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)		
Connector No.	Connector Name	Connector Type
E4	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	L02FB-MC
E6	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	TH0FW-NH
E8	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	NS06FWCS
E9	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	TH16FW-NH
E5	TO ECU INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	TH0FW-CS12-M4-TV
E7	TO ECU INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	TH0FW-CS12-M4
E10	TO ECU INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	TH0FW-CS12-M4

## Fail-safe

JRMWE9734GB

INFOID:0000000008799906

## CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## <ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>License plate lamps</li> <li>Side maker lamps</li> <li>Illuminations</li> <li>Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn relay OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>Detects DTC "B2098: IGN RELAY ON"</li> <li>Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### DTC Index

INFOID:000000008799907

### NOTE:

- The details of time display are as follows.
- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
- The number is 0 when is detected now.
- The number increases like 1 → 2 … 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
- The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

x: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-14</a>
B2098: IGN RELAY ON CIRC	×	<a href="#">PCS-15</a>
B2099: IGN RELAY OFF CIRC	—	<a href="#">PCS-17</a>
B210B: STR CONT RLY ON CIRC	—	<a href="#">SEC-77</a>
B210C: STR CONT RLY OFF CIRC	—	<a href="#">SEC-78</a>
B210D: STARTER RLY ON CIRC	—	<a href="#">SEC-80</a>
B210E: STARTER RLY OFF CIRC	—	<a href="#">SEC-82</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-84</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-86</a>

WW

M

N

O

P

# WIPER AND WASHER SYSTEM SYMPTOMS

<SYMPTOM DIAGNOSIS>

## SYMPTOM DIAGNOSIS

### WIPER AND WASHER SYSTEM SYMPTOMS

#### Symptom Table

INFOID:0000000008286224

##### CAUTION:

Perform the self-diagnosis with CONSULT before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

Symptom	Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	• Combination switch • Harness between combination switch and BCM • BCM
		• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper request signal • BCM • IPDM E/R
	LO and INT	• Combination switch • Harness between combination switch and BCM • BCM
		• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper request signal • BCM • IPDM E/R
	INT only	• Combination switch • Harness between combination switch and BCM • BCM
		Front wiper request signal • BCM • IPDM E/R
	HI, LO and INT	SYMPOTM DIAGNOSIS “FRONT WIPER DOES NOT OPERATE” Refer to <a href="#">WW-108, "Diagnosis Procedure"</a> .

# WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Probable malfunction location	Inspection item	
Front wiper does not stop.	HI only	• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R  IPDM E/R	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .  IPDM E/R DATA MONITOR "FR WIP REQ"  —
		• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		IPDM E/R	IPDM E/R DATA MONITOR "FR WIP REQ"  —
	LO only	• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		IPDM E/R	IPDM E/R DATA MONITOR "FR WIP REQ"  —
		• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		• Combination switch • Harness between combination switch and BCM • BCM	IPDM E/R DATA MONITOR "FR WIP REQ"  —
		BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		Check the vehicle speed detection wiper setting. Refer to <a href="#">WW-15, "WIPER : CONSULT Function (BCM - WIPER)"</a> . <b>NOTE:</b> Factory setting of the front wiper intermitted operation is the operation without vehicle speed.	—
Front wiper does not operate normally.	Intermittent adjustment cannot be performed.	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		BCM	—
	Wiper is not linked to the washer operation.	Check the vehicle speed detection wiper setting. Refer to <a href="#">WW-15, "WIPER : CONSULT Function (BCM - WIPER)"</a> . <b>NOTE:</b> Factory setting of the front wiper intermitted operation is the operation without vehicle speed.	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
	Does not return to stop position [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)]	• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor	Front wiper stop position signal circuit Refer to <a href="#">WW-29, "Component Function Check"</a> .
Rear wiper does not operate.	ON only	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
	INT only	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
	ON and INT	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		• BCM • Harness between rear wiper motor and BCM • Harness between rear wiper motor and ground • Rear wiper motor	Rear wiper motor circuit Refer to <a href="#">WW-33, "Component Function Check"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

## WIPER AND WASHER SYSTEM SYMPTOMS

<SYMPTOM DIAGNOSIS>

Symptom		Probable malfunction location	Inspection item
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
	INT only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between rear wiper motor and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-93, "Symptom Table"</a> .
		BCM	—
	Rear wiper does not return to the stop position [Stops after a five-second operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>• BCM</li> <li>• Harness between rear wiper motor and BCM</li> <li>• Rear wiper motor</li> </ul>	Rear wiper stop position signal circuit Refer to <a href="#">WW-35, "Component Function Check"</a> .

## **NORMAL OPERATING CONDITION**

< SYMPTOM DIAGNOSIS >

### **NORMAL OPERATING CONDITION**

#### **Description**

INFOID:0000000008286225

#### **FRONT WIPER MOTOR PROTECTION FUNCTION**

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

#### **REAR WIPER MOTOR PROTECTION FUNCTION**

- BCM may stop rear wiper to protect the rear wiper motor when the rear wiper is stopped for 5 seconds or more due to a snowfall.
- Rear wiper operates normally one minute after the obstacles are removed with rear wiper OFF.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT WIPER DOES NOT OPERATE

### Description

INFOID:0000000008286226

The front wiper does not operate under any operating conditions.

### Diagnosis Procedure

INFOID:0000000008286227

#### 1. CHECK WIPER RELAY OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/HI operation.

##### CONSULT ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check that front wiper LO/HI operation and OFF.

Lo : Front wiper LO operation

Hi : Front wiper HI operation

Off : Stop the front wiper.

##### Does the front wiper operate?

YES >> GO TO 4.

NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the front wiper motor 30A (#60) fuse is not fusing.

##### Is the fuse fusing?

YES >> Replace the fuse after repairing the applicable circuit.

NO >> GO TO 3.

#### 3. CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

1. Disconnect front wiper motor connector.
2. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E42	2		Existed

##### Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

#### 4. CHECK FRONT WIPER REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R data monitor item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the monitor status.

Monitor item	Condition		Monitor status
FR WIPER REQ	Front wiper switch HI	ON	Hi
		OFF	Stop
	Front wiper switch LO	ON	Low
		OFF	Stop

##### Is the status of item normal?

YES >> Replace IPDM E/R.

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> GO TO 5.

## 5. CHECK COMBINATION SWITCH

Perform the inspection of the combination switch. Refer to [BCS-93, "Symptom Table"](#).

Is combination switch normal?

YES >> Replace BCM. Refer to [BCS-96, "Exploded View"](#).

NO >> Repair or replace the applicable parts.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000008286228

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution for Procedure without Cowl Top Cover

INFOID:0000000008286229

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



PIIB3706J

## PREPARATION


< PREPARATION >

# PREPARATION

## PREPARATION

### Commercial Service Tool

INFOID:0000000008286230

Tool name	Description
Washer nozzle adjuster	 JSLIA0149ZZ Adjusting washer nozzle. (Available in SEC. 289 of PARTS CATALOG: Part No. 28949 1EA0A) <b>NOTE:</b> Washer nozzle adjuster is included with shipment of nozzle.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# WASHER TANK


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### WASHER TANK

#### Exploded View

INFOID:000000008286231



1. Washer tank inlet

2. Washer tank

#### Removal and Installation


INFOID:000000008286232

##### REMOVAL

1. Remove the clip (A).

◀ : Vehicle front

2. Pull out the washer tank inlet (1) from the washer tank.
3. Remove the fender protector RH (front). Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
4. Remove the engine lower cover. Refer to [EXT-31, "Exploded View"](#).
5. Disconnect washer pump connector.
6. Disconnect the washer level switch connector.
7. Remove front washer tube and rear washer tube.
8. Remove washer tank mounting bolts.
9. Remove washer tank from the vehicle.



##### INSTALLATION

Note the following, and install in the reverse order of removal.

##### CAUTION:

Add water up to the top of the washer tank inlet after installing. Check that there is no leakage.


# FRONT WASHER PUMP

< REMOVAL AND INSTALLATION >

## FRONT WASHER PUMP

### Exploded View

INFOID:0000000008286233



- 1. Washer pump connector
- 2. Rear washer tube
- 3. Washer pump
- 4. Front washer tube
- 5. Packing
- 6. Washer tank

↳ : Vehicle front

### Removal and Installation

INFOID:0000000008286234

#### REMOVAL

1. Remove the fender protector RH (front). Refer to [EXT-25, "FENDER PROTECTOR : Removal and Installation".](#)
2. Disconnect the washer pump connector.
3. Remove front washer tube and rear washer tube.
4. Remove washer pump from the washer tank.
5. Remove the packing from the washer tank.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

##### **CAUTION:**

**Never twist the packing when installing the washer pump.**

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## **WASHER LEVEL SWITCH**

< REMOVAL AND INSTALLATION >

### **WASHER LEVEL SWITCH**

#### **Removal and Installation**

INFOID:0000000008286235

The washer level switch must be replaced together with the washer tank as an assembly. Refer to [WW-112, "Removal and Installation"](#).


# FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

## FRONT WASHER NOZZLE AND TUBE

### Hydraulic Layout

INFOID:0000000008286236



1. Front washer tube

2. Front washer nozzle

3. Front washer tube

4. Washer tank

△ : Clip

[ ] : Clip

### Removal and Installation


INFOID:0000000008286237

#### REMOVAL

1. Fully open hood assembly.
2. Remove the front washer nozzle in numerical order as shown in the figure.

↖ : Vehicle front

3. Disconnect the front washer tube from the front washer nozzle.



#### INSTALLATION

1. Connect the front washer tube into the front washer nozzle.
2. Install the front washer nozzle to the hood.
3. Adjust the front washer nozzle spray position. Refer to [WW-115, "Inspection and Adjustment"](#).

#### CAUTION:

The spray positions differ. Check that left and right nozzles are installed correctly.

### Inspection and Adjustment

INFOID:0000000008286238


#### INSPECTION

##### Washer Nozzle Inspection

# FRONT WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >


Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



## ADJUSTMENT

### Washer Nozzle Spray Position Adjustment

Adjust spray positions to match the positions shown in the figure.



1. Black printed frame line

: Spray area

Unit: mm (in)

	Passenger side				Driver side			
	A	B	C	D	E	F	G	H
X	569 (22.40)	45 (1.77)	216 (8.50)	392 (15.43)	39 (1.54)	469 (18.46)	379 (14.92)	203 (7.99)
Y	523 (20.59)	623 (24.53)	108 (4.25)	81 (3.19)	723 (28.46)	379 (14.92)	73 (2.87)	123 (4.84)

### CAUTION:


- Use washer nozzle adjuster\* (A) for nozzle adjustment.

- Never use needle or small pin.

\*: Washer nozzle adjuster is included with shipment of nozzle.

### NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.




# FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

## FRONT WIPER ARM

### Exploded View

INFOID:0000000008286239



1. Front wiper blade (RH)
2. Front wiper arm (RH)
3. Front wiper blade (LH)
4. Front wiper arm (LH)
5. Front wiper arm cap

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation


INFOID:0000000008286240

#### REMOVAL

1. Operate the front wiper to move it to the auto stop position.
2. Open the hood.
3. Remove front wiper arm caps.
4. Remove the front wiper arm mounting nuts.
5. Raise front wiper arm, and remove front wiper arm from the vehicle.

#### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nuts from being loosened.
2. Operate the front wiper motor to move the front wiper to the auto stop position.
3. Adjust the front wiper blade position. Refer to [WW-117, "Adjustment"](#).
4. Install the front wiper arm by tightening the mounting nuts.
5. Inject the washer fluid.
6. Operate the front wiper to move it to the auto stop position.
7. Check that the front wiper blades stop at the specified position.
8. Install front wiper arm caps.



### Adjustment

INFOID:0000000008286241

#### WIPER BLADE POSITION ADJUSTMENT

Clearance between the end of cowl top cover and the top of wiper blade

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O


P

## FRONT WIPER ARM

### < REMOVAL AND INSTALLATION >

Standard clearance

R :  $48.0 \pm 7.5 \text{ mm}$  ( $1.890 \pm 0.295 \text{ in}$ )  
L :  $76.5 \pm 7.5 \text{ mm}$  ( $3.012 \pm 0.295 \text{ in}$ )



JPLIA0082ZZ


# WIPER BLADE

< REMOVAL AND INSTALLATION >

## WIPER BLADE

### Exploded View

INFOID:0000000008286242



1. Wiper refill
  2. Wiper blade
  3. Wiper arm
- A : Wiper blade end  
B : Wiper blade tip

### Removal and Installation


INFOID:0000000008286243

#### REMOVAL

1. Push up the lever (A) of wiper blade (1), while sliding wiper blade toward the direction of the arrow, to remove it from wiper arm (2).

**CAUTION:**

Be careful not to drop the wiper blade onto the windshield glass to prevent damage to the windshield glass.




#### INSTALLATION

1. Install wiper blade into wiper arm.
2. Install wiper arm.

#### Replacement

INFOID:0000000008286244

1. Hold the rip of old wiper refill (1) at the rear end of the wiper blade with long-nose pliers, and pull out the wiper refill to the direction (A).




# WIPER BLADE

## < REMOVAL AND INSTALLATION >

2. Insert the tip of new wiper refill (1) into the rear end of wiper blade (2). Slide the new wiper refill to the direction shown by the arrow while pressing the new wiper refill onto the wiper blade rear end.

**NOTE:**

- Insert the wiper refill to be held securely by tab of wiper blade as shown in section.
  - After the wiper refill is fully inserted, remove the holder\* (3).
- \*: Attached to service parts.




3. Insert the new wiper refill toward the direction shown by the mark "←" until the stopper at the rear end of wiper refill fits in the "SET" mark tab on wiper blade.
4. Untwist the twisted wiper refill at the rear end of wiper blade, if any.
5. Check the following items after replacing wiper refill.
  - Wiper refill is not twisted at all.
  - Wiper refill thoroughly fits in the tab on wiper blade.
  - Wiper refill is inserted from the proper direction.


**NOTE:**

When the vertebra is detached.

- Insert the vertebra (1) into the wiper blade to the same bending direction.
- If a vertebra has a notch, fit it to a protrusion inside the wiper refill.



JMLIA1129ZZ



# FRONT WIPER DRIVE ASSEMBLY


< REMOVAL AND INSTALLATION >

## FRONT WIPER DRIVE ASSEMBLY

### Exploded View


INFOID:0000000008286245

### REMOVAL



1. Front wiper drive assembly

### DISASSEMBLY



1. Front wiper linkage 1
2. Shaft seal
3. Front wiper motor
4. Front wiper frame
5. Front wiper linkage 2

: Multi-purpose grease or an equivalent.

### Removal and Installation

INFOID:0000000008286246

### REMOVAL

1. Remove front wiper arm. Refer to [WW-117, "Removal and Installation"](#).
2. Remove cowl top cover. Refer to [EXT-23, "Removal and Installation"](#).
3. Remove bolts from the front wiper drive assembly.

# FRONT WIPER DRIVE ASSEMBLY

## < REMOVAL AND INSTALLATION >

4. Disconnect the front wiper motor connector.
5. Remove front wiper drive assembly from the vehicle.

## INSTALLATION

1. Install the front wiper drive assembly to the vehicle.
2. Connect the front wiper motor connector.
3. Operate the front wiper to move it to the auto stop position.
4. Install the cowl top cover. Refer to [EXT-23, "Removal and Installation"](#).
5. Install front wiper arms. Refer to [WW-117, "Removal and Installation"](#).

## Disassembly and Assembly

INFOID:000000008286247

### DISASSEMBLY

1. Remove the front wiper linkage 1 and 2 from the front wiper drive assembly.  
**CAUTION:**  
**Never bend the linkage or damage the plastic part of the ball joint when removing the wiper linkage.**
2. Remove the front wiper motor mounting screws, and then remove the front wiper motor from the front wiper frame.

### ASSEMBLY

1. Connect the front wiper motor connector.
2. Operate the front wiper to move it to the auto stop position.
3. Disconnect the front wiper motor connector.
4. Install front wiper motor to front wiper frame.
5. Install the front wiper linkage 2 to the front wiper motor and the front wiper frame.
6. Install the front wiper linkage 1 to the front wiper frame.  
**CAUTION:**
  - Never drop front wiper motor or cause it to come into contact with other parts.
  - Be careful for the grease condition at the front wiper motor and front wiper linkage joint (retainer). Apply Multi-purpose grease or an equivalent if necessary.

# **WIPER AND WASHER SWITCH**

< REMOVAL AND INSTALLATION >

## **WIPER AND WASHER SWITCH**

### **Exploded View**

INFOID:0000000008286248

Refer to [BCS-97, "Exploded View".](#)

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# REAR WIPER ARM

< REMOVAL AND INSTALLATION >

## REAR WIPER ARM

### Exploded View

INFOID:0000000008286249



- 1. Rear wiper blade
- 2. Rear wiper motor
- 3. Pivot seal
- 4. Rear wiper arm
- 5. Rear wiper arm cover

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation


INFOID:0000000008286250

#### REMOVAL

1. Operate the rear wiper to the auto stop position.
2. Remove the rear wiper arm cover.
3. Remove the rear wiper arm mounting nut.
4. Raise rear wiper arm, and remove wiper arm from the vehicle.

#### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nut from being loosened.
2. Operate the rear wiper motor to the auto stop position.
3. Adjust the rear wiper blade position. Refer to [WW-124, "Adjustment"](#).
4. Install the rear wiper arm by tightening the mounting nut.
5. Inject the washer fluid.
6. Operate the rear wiper to the auto stop position.
7. Check that the rear wiper blades stop at the specified position.
8. Install the rear wiper arm cover.



SKIA0082J

### Adjustment

INFOID:0000000008286251

#### REAR WIPER BLADE POSITION ADJUSTMENT


Clearance between the end of back door glass and the top of wiper blade center.

## REAR WIPER ARM

### < REMOVAL AND INSTALLATION >

Standard clearance

L :  $35.0 \pm 7.5 \text{ mm} (1.378 \pm 0.295 \text{ in})$



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

WW

M  
N  
O  
P


# REAR WIPER MOTOR

< REMOVAL AND INSTALLATION >

## REAR WIPER MOTOR

### Exploded View

INFOID:0000000008286252



JPLIA1398GB

1. Rear wiper blade
2. Rear wiper motor
3. Pivot seal
4. Rear wiper arm
5. Rear wiper arm cover

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:0000000008286253

#### REMOVAL

1. Remove rear wiper arm cover and rear wiper arm. Refer to [WW-124, "Removal and Installation"](#).
2. Remove back door finisher inner. Refer to [INT-40, "Exploded View"](#).
3. Disconnect the rear wiper motor connector.
4. Remove rear wiper motor mounting bolts.
5. Remove rear wiper motor from the vehicle.
6. Remove pivot seal.

#### INSTALLATION

1. Install the pivot seal.
2. Install the rear wiper motor to the vehicle.
3. Connect the rear wiper motor connector.
4. Operate the rear wiper to the auto stop position.
5. Install the back door finisher inner. Refer to [INT-40, "Exploded View"](#).
6. Install rear wiper arm cover and rear wiper arm. Refer to [WW-124, "Removal and Installation"](#).


# REAR WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

## REAR WASHER NOZZLE AND TUBE

### Hydraulic Layout

INFOID:0000000008286254



1. Rear washer nozzle

2. Rear washer tube

3. Washer tank

△ : Clip

○ : Grommet

### Removal and Installation

INFOID:0000000008286255

#### REMOVAL


1. Remove the high-mounted stop lamp. Refer to [EXL-224, "Exploded View"](#).
2. Remove the rear washer tube from the rear washer nozzle.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# REAR WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >

- Remove the rear washer nozzle (1) from the high-mounted stop lamp (2).



JPLIA0979ZZ

## INSTALLATION

Install in the reverse order of removal.


## Inspection and Adjustment

INFOID:000000008286256

## INSPECTION

### Washer Nozzle Inspection

Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



JPLIA0980ZZ

## ADJUSTMENT


### Washer Nozzle Spray Position adjustment

Adjust spray positions to match the positions shown in the figure.

1 : Black printed frame line

Unit: mm (in)

Spray position	H : Height	L : Length	φ : Spray position area
A	32.0 (1.26)	120.5 (4.74)	30 (1.18)
B	49.6 (1.95)	189.7 (7.47)	30 (1.18)




JPLIA0981ZZ

Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

### NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.



JPLIA0982ZZ