

SECTION **LAN**  
LAN SYSTEM

A  
B  
C

CONTENTS

D  
E

**CAN**

<b>PRECAUTIONS</b> .....	<b>4</b>	IPDM E/R Circuit Check .....	45
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	CAN Communication Circuit Check .....	46
Precautions When Using CONSULT-II .....	4	IPDM E/R Ignition Relay Circuit Check .....	50
CHECK POINTS FOR USING CONSULT-II .....	4	Component Inspection .....	50
Precautions For Trouble Diagnosis .....	4	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	50
CAN SYSTEM .....	4	<b>CAN SYSTEM (TYPE 2)</b> .....	<b>51</b>
Precautions For Harness Repair .....	5	System Description .....	51
CAN SYSTEM .....	5	Component Parts and Harness Connector Location..	51
<b>CAN COMMUNICATION</b> .....	<b>6</b>	Wiring Diagram - CAN - .....	52
System Description .....	6	Work Flow .....	54
CAN Communication Unit .....	6	CHECK SHEET .....	56
TYPE 1/TYPE2 .....	6	CHECK SHEET RESULTS (EXAMPLE) .....	58
TYPE 3 .....	9	Circuit Check Between TCM and Data Link Connector .....	73
TYPE 4/TYPE5 .....	13	Circuit Check Between Data Link Connector and Unified Meter and A/C Amp. ....	73
TYPE 6 .....	16	Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)..	74
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>20</b>	Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit ....	75
System Description .....	20	ECM Circuit Check .....	75
Component Parts and Harness Connector Location..	20	TCM Circuit Check .....	76
Wiring Diagram - CAN - .....	21	Display Unit Circuit Check .....	76
Work Flow .....	23	Data Link Connector Circuit Check .....	77
CHECK SHEET .....	25	BCM Circuit Check .....	77
CHECK SHEET RESULTS (EXAMPLE) .....	27	Steering Angle Sensor Circuit Check .....	78
Circuit Check Between TCM and Data Link Connector .....	40	Unified Meter and A/C Amp. Circuit Check .....	78
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp. ....	40	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	79
Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)..	41	Driver Seat Control Unit Circuit Check .....	79
ECM Circuit Check .....	41	IPDM E/R Circuit Check .....	80
TCM Circuit Check .....	42	CAN Communication Circuit Check .....	81
Display Unit Circuit Check .....	42	IPDM E/R Ignition Relay Circuit Check .....	85
Data Link Connector Circuit Check .....	43	Component Inspection .....	85
BCM Circuit Check .....	43	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	85
Steering Angle Sensor Circuit Check .....	44	<b>CAN SYSTEM (TYPE 3)</b> .....	<b>86</b>
Unified Meter and A/C Amp. Circuit Check .....	44	System Description .....	86
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	45	Component Parts and Harness Connector Location..	86

F  
G  
H  
I  
J  
L  
M

**LAN**

Schematic .....	87	CAN Communication Circuit Check .....	162
Wiring Diagram - CAN - .....	88	IPDM E/R Ignition Relay Circuit Check .....	165
Work Flow .....	91	Component Inspection .....	165
CHECK SHEET .....	93	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
CHECK SHEET RESULTS (EXAMPLE) .....	96	TION .....	165
Circuit Check Between TCM and Data Link Con-		<b>CAN SYSTEM (TYPE 5) .....</b>	<b>166</b>
connector .....	115	System Description .....	166
Circuit Check Between Data Link Connector and		Component Parts and Harness Connector Location	166
Unified Meter and A/C Amp. ....	116	Schematic .....	167
Circuit Check Between Unified Meter and A/C Amp.		Wiring Diagram - CAN - .....	168
and ABS Actuator and Electric Unit (Control Unit)	116	Work Flow .....	171
Circuit Check Between ABS Actuator and Electric		CHECK SHEET .....	173
Unit (Control Unit) and Driver Seat Control Unit ..	117	CHECK SHEET RESULTS (EXAMPLE) .....	175
ECM Circuit Check .....	118	Circuit Check Between TCM and Data Link Con-	
TCM Circuit Check .....	118	connector .....	191
Display Control Unit Circuit Check .....	119	Circuit Check Between Data Link Connector and	
Low Tire Pressure Warning Control Unit Circuit		Unified Meter and A/C Amp. ....	191
Check .....	119	Circuit Check Between Unified Meter and A/C Amp.	
ICC Unit Circuit Check .....	120	and ABS Actuator and Electric Unit (Control Unit).	192
Intelligent Key Unit Circuit Check .....	120	Circuit Check Between ABS Actuator and Electric	
Data Link Connector Circuit Check .....	121	Unit (Control Unit) and Driver Seat Control Unit ..	193
BCM Circuit Check .....	121	ECM Circuit Check .....	193
Steering Angle Sensor Circuit Check .....	122	TCM Circuit Check .....	194
Unified Meter and A/C Amp. Circuit Check .....	122	Display Unit Circuit Check .....	194
ICC Sensor Circuit Check .....	123	AWD Control Unit Circuit Check .....	195
ABS Actuator and Electric Unit (Control Unit) Circuit		Data Link Connector Circuit Check .....	195
Check .....	123	BCM Circuit Check .....	196
Driver Seat Control Unit Circuit Check .....	124	Steering Angle Sensor Circuit Check .....	196
IPDM E/R Circuit Check .....	125	Unified Meter and A/C Amp. Circuit Check .....	197
CAN Communication Circuit Check .....	126	ABS Actuator and Electric Unit (Control Unit) Circuit	
IPDM E/R Ignition Relay Circuit Check .....	131	Check .....	197
Component Inspection .....	131	Driver Seat Control Unit Circuit Check .....	198
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-		IPDM E/R Circuit Check .....	199
TION .....	131	CAN Communication Circuit Check .....	199
<b>CAN SYSTEM (TYPE 4) .....</b>	<b>132</b>	IPDM E/R Ignition Relay Circuit Check .....	204
System Description .....	132	Component Inspection .....	204
Component Parts and Harness Connector Location	132	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
Schematic .....	133	TION .....	204
Wiring Diagram - CAN - .....	134	<b>CAN SYSTEM (TYPE 6) .....</b>	<b>205</b>
Work Flow .....	137	System Description .....	205
CHECK SHEET .....	139	Component Parts and Harness Connector Location	205
CHECK SHEET RESULTS (EXAMPLE) .....	141	Schematic .....	206
Circuit Check Between TCM and Data Link Con-		Wiring Diagram - CAN - .....	207
connector .....	155	Work Flow .....	210
Circuit Check Between Data Link Connector and		CHECK SHEET .....	212
Unified Meter and A/C Amp. ....	155	CHECK SHEET RESULTS (EXAMPLE) .....	215
Circuit Check Between Unified Meter and A/C Amp.		Circuit Check Between TCM and Data Link Con-	
and ABS Actuator and Electric Unit (Control Unit)	156	connector .....	236
ECM Circuit Check .....	156	Circuit Check Between Data Link Connector and	
TCM Circuit Check .....	157	Unified Meter and A/C Amp. ....	237
Display Unit Circuit Check .....	157	Circuit Check Between Unified Meter and A/C Amp.	
AWD Control Unit Circuit Check .....	158	and ABS Actuator and Electric Unit (Control Unit).	237
Data Link Connector Circuit Check .....	158	Circuit Check Between ABS Actuator and Electric	
BCM Circuit Check .....	159	Unit (Control Unit) and Driver Seat Control Unit ..	238
Steering Angle Sensor Circuit Check .....	159	ECM Circuit Check .....	239
Unified Meter and A/C Amp. Circuit Check .....	160	TCM Circuit Check .....	239
ABS Actuator and Electric Unit (Control Unit) Circuit		Display Control Unit Circuit Check .....	240
Check .....	160	Low Tire Pressure Warning Control Unit Circuit	
IPDM E/R Circuit Check .....	161	Check .....	240

AWD Control Unit Circuit Check .....	241	Check .....	245
ICC Unit Circuit Check .....	241	Driver Seat Control Unit Circuit Check .....	245
Intelligent Key Unit Circuit Check .....	242	IPDM E/R Circuit Check .....	246
Data Link Connector Circuit Check .....	242	CAN Communication Circuit Check .....	247
BCM Circuit Check .....	243	IPDM E/R Ignition Relay Circuit Check .....	252
Steering Angle Sensor Circuit Check .....	243	Component Inspection .....	252
Unified Meter and A/C Amp. Circuit Check .....	244	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
ICC Sensor Circuit Check .....	244	TION .....	252
ABS Actuator and Electric Unit (Control Unit) Circuit			

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS007WY

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions When Using CONSULT-II

AKS0058H

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

#### CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6, "CAN Communication Unit"](#) .

### Precautions For Trouble Diagnosis CAN SYSTEM

AKS0058I

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


# PRECAUTIONS

[CAN]


## Precautions For Harness Repair CAN SYSTEM

AKS0058J

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

## CAN COMMUNICATION

PFP:23710

### System Description

AKS007GA

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit

AKS007Z4

Go to CAN system, when selecting your car model from the following table.


Body type	Wagon					
Axle	2WD			AWD		
Engine	VQ35DE			VQ35DE/VK45DE		
Transmission	A/T					
Brake control	VDC					
Navigation system			×			×
Low tire pressure warning system			×			×
ICC system			×			×
Intelligent Key system			×			×
Automatic drive positioner		×	×		×	×
CAN system type	1	2	3	4	5	6
CAN system trouble diagnosis	<a href="#">LAN-20</a>	<a href="#">LAN-51</a>	<a href="#">LAN-86</a>	<a href="#">LAN-132</a>	<a href="#">LAN-166</a>	<a href="#">LAN-205</a>

×: Applicable

### TYPE 1/TYPE2

#### System Diagram


- Type1



# CAN COMMUNICATION

[CAN]

● Type2



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Engine speed signal	T	R	R			R	R		
Engine status signal	T			R					
Engine coolant temperature signal	T	R				R			
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R					R		
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
Key switch signal				T				R	
Ignition switch signal				T				R	R
P range signal		T					R	R	
Stop lamp switch signal		R				T			
ABS operation signal	R						T		
TCS operation signal	R						T		
VDC operation signal	R						T		
Fuel consumption monitor signal	T		R			R			
Input shaft revolution signal	R	T							
Output shaft revolution signal	R	T							
A/C switch signal	R			T					
A/C compressor request signal	T								R
A/C relay status signal	R								T
A/C compressor feedback signal	T					R			
Blower fan motor switch signal	R			T					

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/C control signal			T			R			
			R			T			
Cooling fan speed request signal	T								R
Cooling fan speed signal	R								T
Position light request signal			R	T		R			R
Low beam request signal				T					R
Low beam status signal	R								T
High beam request signal				T		R			R
High beam status signal	R								T
Front fog light request signal				T					R
Day time running light request signal				T		R			
Turn LED burnout status signal				R		T			
Vehicle speed signal						R	T		
	R	R	R	R		T		R	
Sleep wake up signal				T		R		R	R
Door switch signal			R	T		R		R	R
Turn indicator signal				T		R			
Key fob ID signal				T				R	
Key fob door unlock signal				T				R	
Oil pressure switch signal				R					T
				T		R			
Buzzer output signal				T		R			
Fuel level sensor signal	R					T			
Fuel level low warning signal			R			T			
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
Front wiper request signal				T					R
Front wiper stop position signal				R					T
Rear window defogger switch signal				T					R
Rear window defogger control signal	R		R	R					T
Hood switch signal				R					T
Theft warning horn request signal				T					R
Horn chirp signal				T					R
Steering angle sensor signal					T		R		
ABS warning lamp signal						R	T		
VDC OFF indicator lamp signal						R	T		
SLIP indicator lamp signal						R	T		
Brake warning lamp signal						R	T		
System setting signal			T	R				R	
A/T CHECK indicator lamp signal		T				R			



# CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T position indicator lamp signal		T				R			
A/T shift schedule change demand signal		R					T		
Manual mode signal		R				T			
Not manual mode signal		R				T			
Manual mode shift up signal		R				T			
Manual mode shift down signal		R				T			
Manual mode indicator signal		T				R			
Distance to empty signal			R			T			
Hand brake switch				R		T			

## TYPE 3

### System Diagram

- Type3



### Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Engine speed signal	T	R	R		R				R		R		
Engine status signal	T						R						
Engine coolant temperature signal	T	R			R				R				
A/T self-diagnosis signal	R	T											

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Accelerator pedal position signal	T	R			R						R		
Closed throttle position signal	T	R			R								
Wide open throttle position signal	T	R											
Battery voltage signal	T	R											
Key switch signal							T					R	
Ignition switch signal							T					R	R
P range signal		T			R						R	R	
Stop lamp switch signal		R							T				
ABS operation signal	R				R						T		
TCS operation signal	R				R						T		
VDC operation signal	R				R						T		
Fuel consumption monitor signal	T		R						R				
Input shaft revolution signal	R	T			R								
Output shaft revolution signal	R	T			R								
A/C switch signal	R						T						
A/C compressor request signal	T												R
A/C relay status signal	R												T
A/C compressor feedback signal	T								R				
Blower fan motor switch signal	R						T						
A/C control signal			T						R				
			R						T				
Cooling fan speed signal	R												T
Position light request signal	R						T		R				R
Low beam request signal							T						R
Low beam status signal	R												T
High beam request signal							T		R				R
High beam status signal	R												T
Front fog light request signal							T						R
Day time running light request signal							T		R				

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Turn LED burnout status signal							R		T				
Vehicle speed signal					R				R		T		
	R	R	R	R		R	R		T	R		R	
Sleep wake up signal							T		R			R	R
						T	R						
Door switch signal			R			R	T		R			R	R
Turn indicator signal							T		R				
Key fob ID signal							T					R	
Key fob door unlock signal							T					R	
Oil pressure switch signal							R						T
							T		R				
Buzzer output signal							T		R				
						T			R				
Fuel level sensor signal	R							T					
Fuel level low warning signal			R						T				
ICC operation signal	R				T								
Front wiper request signal					R		T						R
Front wiper stop position signal							R						T
Rear window defogger switch signal							T						R
Rear window defogger control signal	R		R				R						T
Hood switch signal							R						T
Theft warning horn request signal							T						R
Horn chirp signal							T						R
Steering angle sensor signal								T			R		
Tire pressure signal				T					R				
Tire pressure data signal			R	T									
ABS warning lamp signal					R				R		T		
VDC OFF indicator lamp signal					R				R		T		
SLIP indicator lamp signal									R		T		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN


# CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Brake warning lamp signal									R		T		
System setting signal			T			R						R	
Distance to empty signal			R						T				
Hand brake switch signal							R		T				
Door lock/unlock request signal						T	R						
Door lock/unlock status signal						R	T						
Starter permission signal						T	R						
Back door open request signal						T	R						
Power window open request signal						T	R						
Alarm request signal						T	R						
Key warning signal						T			R				
ICC sensor signal					R					T			
ICC warning lamp signal					T				R				
ICC system display signal					T				R				
Current gear position signal		T			R						R		
Steering switch signal	T				R								
ASCD operation signal	T	R											
ASCD OD cancel request	T	R											
ICC OD cancel request	R	R			T								
A/T CHECK indicator lamp signal		T							R				
A/T position indicator lamp signal		T							R				
A/T shift schedule change demand signal		R									T		
Manual mode signal		R							T				
Not manual mode signal		R							T				
Manual mode shift up signal		R							T				
Manual mode shift down signal		R							T				
Manual mode indicator signal		T			R				R				
Ignition knob switch signal						T	R						

## TYPE 4/TYPE5 System Diagram

- Type4



- Type5



### Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Dis- play unit	AWD con- trol unit	BCM	Steer- ing angle sensor	Uni- fied meter and A/ C amp.	ABS actua- tor and elec- tric unit (con- trol unit)	Driver seat con- trol unit	IPDM E/R
A/T self-diagnosis signal	R	T								
ABS operation signal	R			R				T		
TCS operation signal	R							T		
VDC operation signal	R			R				T		
Stop lamp switch signal		R		R			T			
Battery voltage signal	T	R								

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	AWD control unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Key switch signal					T				R	
Ignition switch signal					T				R	R
P range signal		T						R	R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Engine speed signal	T	R	R	R			R	R		
Engine status signal	T				R					
Engine coolant temperature signal	T	R					R			
Accelerator pedal position signal	T	R		R				R		
Fuel consumption monitor signal	T		R				R			
Input shaft revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R				T					
A/C compressor request signal	T									R
A/C relay status signal	R									T
A/C compressor feedback signal	T						R			
Blower fan motor switch signal	R				T					
A/C control signal			T				R			
			R				T			
Cooling fan speed signal	R									T
Position light request signal			R		T		R			R
Low beam request signal					T					R
Low beam status signal	R									T
High beam request signal					T		R			R
High beam status signal	R									T
Front fog light request signal					T					R
Day time running light request signal					T		R			
Turn LED burnout status signal					R		T			
Vehicle speed signal							R	T		
	R	R	R		R		T		R	
Sleep wake up signal					T		R		R	R
Door switch signal			R		T		R		R	R
Turn indicator signal					T		R			
Key fob ID signal					T				R	
Key fob door unlock signal					T				R	
Oil pressure switch signal					R					T
					T		R			
Buzzer output signal					T		R			

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	AWD control unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Fuel level sensor signal	R						T			
Fuel level low warning signal			R				T			
Front wiper request signal					T					R
Front wiper stop position signal					R					T
Rear window defogger switch signal					T					R
Rear window defogger control signal	R		R		R					T
Hood switch signal					R					T
Theft warning horn request signal					T					R
Horn chirp signal					T					R
Steering angle sensor signal						T		R		
ABS warning lamp signal							R	T		
VDC OFF indicator lamp signal							R	T		
SLIP indicator lamp signal							R	T		
Brake warning lamp signal							R	T		
System setting signal			T		R				R	
AWD warning lamp signal				T			R			
AWD lock indicator lamp signal				T			R			
Distance to empty signal			R				T			
Hand brake switch signal				R	R		T			
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T					R			
A/T position indicator lamp signal		T					R			
A/T shift schedule change demand signal		R						T		
Manual mode signal		R					T			
Not manual mode signal		R					T			
Manual mode shift up signal		R					T			
Manual mode shift down signal		R					T			
Manual mode indicator signal		T					R			


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## TYPE 6

### System Diagram

- Type6





# CAN COMMUNICATION

[CAN]

## Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPD M E/R
A/T self-diagnosis signal	R	T												
ABS operation signal	R				R	R						T		
TCS operation signal	R					R						T		
VDC operation signal	R				R	R					R	T		
Stop lamp switch signal		R			R					T				
Battery voltage signal	T	R												
Key switch signal								T					R	
Ignition switch signal								T					R	R
P range signal		T				R						R	R	
Closed throttle position signal	T	R				R								
Wide open throttle position signal	T	R												
Engine speed signal	T	R	R		R	R				R		R		
Engine status signal	T							R						
Engine coolant temperature signal	T	R				R				R				
Accelerator pedal position signal	T	R			R	R						R		
Fuel consumption monitor signal	T		R							R				
A/T self-diagnosis signal	R	T												
Input shaft revolution signal	R	T				R								
Output shaft revolution signal	R	T				R								
A/C switch signal	R							T						
A/C compressor request signal	T													R
A/C relay status signal	R													T
A/C compressor feedback signal	T									R				
Blower fan motor switch signal	R							T						
A/C control signal			T							R				
			R							T				
Cooling fan speed signal	R													T
Position light request signal			R					T		R				R
Low beam request signal								T						R
Low beam status signal	R													T
High beam request signal								T		R				R

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPD M E/R
High beam status signal	R													T
Front fog light request signal								T						R
Day time running light request signal								T		R				
Turn LED burnout status signal								R		T				
Vehicle speed signal						R				R		T		
	R	R	R	R			R	R		T	R		R	
Sleep wake up signal								T		R			R	R
							T	R						
Door switch signal			R				R	T		R			R	R
Key fob ID signal								T					R	
Key fob door unlock signal								T					R	
Oil pressure switch signal								R						T
								T		R				
Buzzer output signal							T			R				
						T				R				
Fuel level sensor signal	R									T				
Fuel level low warning signal			R							T				
ICC operation signal	R					T								
Front wiper request signal						R		T						R
Front wiper stop position signal								R						T
Rear window defogger switch signal								T						R
Rear window defogger control signal	R		R					R						T
Hood switch signal								R						T
Theft warning horn request signal								T						R
Horn chirp signal								T						R
Steering angle sensor signal									T			R		
Tire pressure signal				T						R				
Tire pressure data signal			R	T										
ABS warning lamp signal						R				R		T		
VDC OFF indicator lamp signal						R				R		T		
SLIP indicator lamp signal										R		T		

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPD M E/R
Brake warning lamp signal										R		T		
System setting signal			T				R						R	
AWD warning lamp signal					T					R				
AWD lock indicator lamp signal					T					R				
Distance to empty signal			R							T				
Hand brake switch signal					R			R		T				
Door lock/unlock request signal							T	R						
Door lock/unlock status signal							R	T						
Starter permission signal							T	R						
Back door open request signal							T	R						
Power window open request signal							T	R						
Alarm request signal							T	R						
Key warning signal							T			R				
ICC sensor signal						R					T			
ICC warning lamp signal						T				R				
ICC system display signal						T				R				
Current gear position signal		T				R						R		
Steering switch signal	T					R								
ASCD operation signal	T	R												
ASCD OD cancel request	T	R												
ICC OD cancel request	R	R				T								
A/T CHECK indicator lamp signal		T								R				
A/T position indicator lamp signal		T								R				
A/T shift schedule change demand signal		R										T		
Manual mode signal		R								T				
Not manual mode signal		R								T				
Manual mode shift up signal		R								T				
Manual mode shift down signal		R								T				
Manual mode indicator signal		T								R				
Ignition knob switch signal							T	R						

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## CAN SYSTEM (TYPE 1)

PFP:23710


### System Description

AKS007Q0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007Q1



# CAN SYSTEM (TYPE 1)






[CAN]

## Wiring Diagram - CAN -

AKS007Q3

### LAN-CAN-01

DATA LINE



REFER TO THE FOLLOWING.

(F102) - SUPER MULTIPLE JUNCTION (SMJ)

(M3), (M90) - ELECTRICAL UNITS

TKWM0657E





**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-97, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-27, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .



# CAN SYSTEM (TYPE 1)

**[CAN]**

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR check sheet

# CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER A/C AMP  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER A/C AMP  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA7927E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

**Case 1**

Check harness between TCM and data link connector. Refer to [LAN-40, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7928E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-40, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA7929E



SKIA6559E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-41, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA7930E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-41, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7931E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-42, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	—	UNKW	—	UNKW	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—

PKIA7932E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 6

Check display unit circuit. Refer to [LAN-42, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CA $\checkmark$ 1	CA $\checkmark$ 3	—	—	CA $\checkmark$ 2	—	CA $\checkmark$ 5	—	CA $\checkmark$ 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNK $\checkmark$	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7933E





# CAN SYSTEM (TYPE 1)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-43, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7934E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-43, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2 ✓	—	CAN 5	—	CAN 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—	

PKIA7935E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 9

Check steering angle sensor circuit. Refer to [LAN-44, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7936E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 10

Check unified meter and A/C amp. circuit. Refer to LAN-44, "Unified Meter and A/C Amp. Circuit Check" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7937E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-45, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	✓	✓	✓	—	—	✓	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7938E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 12

Check IPDM E/R circuit. Refer to [LAN-45, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7 ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN ✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7939E



# CAN SYSTEM (TYPE 1)

[CAN]

## Case 13

Check CAN communication circuit. Refer to [LAN-46, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7940E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-50, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7942E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-50, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA7941E

## Circuit Check Between TCM and Data Link Connector

AKS00705

### 1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).


**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-23, "Work Flow"](#) .

NG >> Repair harness.



## Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00706

### 1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).


**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-23, "Work Flow"](#) .

NG >> Repair harness.





## Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

- 1 (L) - 15G (L) : Continuity should exist.**
- 11 (R) - 14G (R) : Continuity should exist.**

**OK or NG**

- OK >> GO TO 3.
- NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

- 15G (L) - 11 (L) : Continuity should exist.**
- 14G (R) - 15 (R) : Continuity should exist.**

**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-23, "Work Flow"](#).
- NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



AKS00709

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.
- NG >> Repair harness between A/T assembly and display unit.



SKIA6866E

AKS0070A

## Display Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

**14 (L) - 16 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit and harness connector M82.



AKS007QB

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-23, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and BCM.



AKS007QC

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



AKS007QD

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



AKS007QE

## Unified Meter and A/C Amp. Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS007QF

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



## IPDM E/R Circuit Check

AKS007QG

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R)**

**: Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, sensor side, meter side, control unit side and harness side).

- ECM
- A/T assembly
- Display unit
- BCM
- Steering angle sensor
- Unified meter and A/C amp.
- ABS actuator and electric unit (control unit)
- IPDM E/R
- Between ECM and IPDM E/R
- Between ECM and A/T assembly

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

AKS007QH

## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


**6 (L) - 14 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



## 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M


## 4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness between A/T assembly and harness connector F102.



## 5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.

**3 (L) - Ground : Continuity should not exist.**

**8 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 6.  
 NG >> Repair harness between A/T assembly and harness connector F102.




## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 7.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
  - Harness between ABS actuator and electric unit (control unit) and harness connector E205.






**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

- 11 (L) - Ground : Continuity should not exist.**
- 15 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 8.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between ABS actuator and electric unit (control unit) and harness connector E211.
  - Harness between ABS actuator and electric unit (control unit) and harness connector E205.




**8. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between harness connector B5 terminals 3 (L) and 10 (R).

- 3 (L) - 10 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 9.
- NG >> Repair harness between harness connector B5 and harness connector B5.




**9. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

- 3 (L) - Ground : Continuity should not exist.**
- 10 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 10.
- NG >> Repair harness between harness connector B5 and harness connector B5.




**10. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

- 48 (L) - 49 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 11.
- NG >> Repair harness between IPDM E/R and harness connector E205.




## 11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 12.
- NG >> Repair harness between IPDM E/R and harness connector E205.



## 12. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-50, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-23, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

### IPDM E/R Ignition Relay Circuit Check

AKS007QI

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

### Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007QJ

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



## CAN SYSTEM (TYPE 2)

PFP:23710


### System Description

AKS007R4

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007R5



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Wiring Diagram - CAN -


AKS007R7

### LAN-CAN-03


DATA LINE




NEXT PAGE




M5  
W



M14  
W



M62  
W



F44  
DGY





REFER TO THE FOLLOWING.

(F102) - SUPER MULTIPLE JUNCTION (SMJ)


(M3), (M90) - ELECTRICAL UNITS

TKWM0659E


## LAN-CAN-04



W



W



W

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


# CAN SYSTEM (TYPE 2)

[CAN]


AKS00C4B

## Work Flow


- When there are no indications of "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-56, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-56, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-97, "CAN Communication Line Inspection"](#) .
- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-56, "CHECK SHEET"](#) .
- Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-56, "CHECK SHEET"](#) .

## CAN SYSTEM (TYPE 2)

[CAN]

---

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-97, "CAN Communication Line Inspection"](#).

9. According to the check sheet results (example), start inspection. Refer to [LAN-58, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR check sheet



# CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER A/C AMP SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of METER A/C AMP CAN DIAG SUPPORT MNTR
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

PKIA7944E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-73, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7945E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-73, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7946E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-74, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7947E





# CAN SYSTEM (TYPE 2)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-75, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7949E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 6

Check TCM circuit. Refer to [LAN-76, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7950E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 7

Check display unit circuit. Refer to [LAN-76, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CA <del>N</del> 1	CA <del>N</del> 3	—	—	CA <del>N</del> 2	—	CA <del>N</del> 5	—	CA <del>N</del> 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UN <del>KN</del> W	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7951E





# CAN SYSTEM (TYPE 2)


[CAN]

## Case 8

Check data link connector circuit. Refer to [LAN-77, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7952E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 9

Check BCM circuit. Refer to [LAN-77, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2 ✓	—	CAN 5	—	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN ✓	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—

PKIA7953E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 10

Check steering angle sensor circuit. Refer to [LAN-78, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7954E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 11

Check unified meter and A/C amp. circuit. Refer to [LAN-78, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7955E



# CAN SYSTEM (TYPE 2)

[CAN]


## Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-79, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7956E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 13

Check driver seat control unit circuit. Refer to [LAN-79, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7957E





# CAN SYSTEM (TYPE 2)

[CAN]

## Case 15

Check CAN communication circuit. Refer to [LAN-81, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7959E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-85, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—

PKIA7961E



## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-85, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7960E

## Circuit Check Between TCM and Data Link Connector

AKS007R9

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-54, "Work Flow"](#) .
- NG >> Repair harness.



## Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS007RA

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-54, "Work Flow"](#) .
- NG >> Repair harness.



## Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS007RB

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

- 1 (L) - 15G (L) : Continuity should exist.**  
**11 (R) - 14G (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

- 15G (L) - 11 (L) : Continuity should exist.**  
**14G (R) - 15 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-54, "Work Flow"](#) .  
 NG >> Repair harness.



## Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS007RQ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E205
  - Harness connector B5

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

**11 (L) - 3 (L) : Continuity should exist.**

**15 (R) - 10 (R) : Continuity should exist.**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

**3 (L) - 14 (L) : Continuity should exist.**

**10 (R) - 15 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-54, "Work Flow"](#).  
NG >> Repair harness.



## ECM Circuit Check

AKS007RC

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and harness connector M82.



SKIA6865E

AKS007RD

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and display unit.



SKIA6866E

AKS007RE

## Display Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

**14 (L) - 16 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit and harness connector M82.



AKS007RF

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-54, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and BCM.



AKS007RG

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



## Unified Meter and A/C Amp. Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS007RJ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



## Driver Seat Control Unit Circuit Check

AKS007RK

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector B151
  - Harness connector B8

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B5.



AKS007RL

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector B8.





## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, sensor side, meter side, control unit side and harness side).
  - ECM
  - A/T assembly
  - Display unit
  - BCM
  - Steering angle sensor
  - Unified meter and A/C amp.
  - ABS actuator and electric unit (control unit)
  - Driver seat control unit
  - IPDM E/R
  - Between ECM and IPDM E/R
  - Between ECM and A/T assembly

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and ECM.
  - Harness between data link connector and harness connector M82.
  - Harness between data link connector and display unit.
  - Harness between data link connector and BCM.
  - Harness between data link connector and steering angle sensor.
  - Harness between data link connector and unified meter and A/C amp.
  - Harness between data link connector and harness connector M41.



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.


- 6 (L) - Ground : Continuity should not exist.**
- 14 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

- 3 (L) - 8 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



### 5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.

- 3 (L) - Ground : Continuity should not exist.**
- 8 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


**11 (L) - 15 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

**11 (L) - Ground : Continuity should not exist.**


**15 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.



## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


**3 (L) - 10 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M

## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.


- 3 (L) - Ground : Continuity should not exist.**  
**10 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.



## 10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

- 14 (OR) - 15 (SB) : Continuity should not exist.**

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector B151.



## 11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.

- 14 (OR) - Ground : Continuity should not exist.**  
**15 (SB) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector B151.



## 12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

- 48 (L) - 49 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 13.

NG >> Repair harness between IPDM E/R and harness connector E205.




### 13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.
- NG >> Repair harness between IPDM E/R and harness connector E205.



### 14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-85, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-54, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

#### IPDM E/R Ignition Relay Circuit Check

AKS007RN

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

#### Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007RO

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## CAN SYSTEM (TYPE 3)

PFP:23710


### System Description

AKS007RR

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007RS




# CAN SYSTEM (TYPE 3)

[CAN]

## Schematic

AKS007RT



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

TKWM0661E

# CAN SYSTEM (TYPE 3)






[CAN]

## Wiring Diagram - CAN -

AKS007RU

### LAN-CAN-05

▬ : DATA LINE



REFER TO THE FOLLOWING.

F102 - SUPER MULTIPLE JUNCTION (SMJ)





M90 - ELECTRICAL UNITS

TKWM0747E



LAN-CAN-06

DATA LINE










REFER TO THE FOLLOWING.  
 (M3) -ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN-CAN-07

— — — — — : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E21) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


# CAN SYSTEM (TYPE 3)

[CAN]


AKS00C4C

## Work Flow


- When there are no indications of "AIR PRESSURE MONITOR", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-93, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWKN" in the check sheet table. Refer to [LAN-93, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-184, "CAN Communication Line Check"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## CAN SYSTEM (TYPE 3)

[CAN]

7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-93, "CHECK SHEET"](#) .
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-93, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-184, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-96, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 3)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AIR PRESSURE  
MONITOR  
SELF-DIAG RESULTS

Attach copy of  
ICC  
SELF-DIAG RESULTS

Attach copy of  
INTELLIGENT KEY  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER A/C AMP  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

PKIA7963E

# CAN SYSTEM (TYPE 3)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AIR PRESSURE  
MONITOR  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ICC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
INTELLIGENT KEY  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER A/C AMP  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA7964E

# CAN SYSTEM (TYPE 3)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-115, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA9132E





# CAN SYSTEM (TYPE 3)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-116, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7965E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-116, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7966E



SKIA6586E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to LAN-117, "Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7967E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-118, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW <del>N</del>	—	—	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—
ICC	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
INTELLIGENT KEY	No indication	—	UNKW <del>N</del>	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—

PKIA7968E



SKIA6588E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 6

Check TCM circuit. Refer to [LAN-118, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7969E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 7

Check display control unit circuit. Refer to [LAN-119, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	—	CAN CRC 8 ✓	—	—	CAN CRC 2 ✓	—	CAN CRC 5 ✓	—	—	CAN CRC 7 ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7970E



SKIA6590E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 8

Check low tire pressure warning control unit circuit. Refer to [LAN-119, "Low Tire Pressure Warning Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7971E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 9

Check ICC unit circuit. Refer to [LAN-120, "ICC Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7972E



SKIA6592E



# CAN SYSTEM (TYPE 3)

[CAN]


## Case 10

Check Intelligent Key unit circuit. Refer to [LAN-120, "Intelligent Key Unit Circuit Check"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN ✓	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7973E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 11

Check data link connector circuit. Refer to [LAN-121, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	CAN CIRC 7	
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	

PKIA7974E



SKIA6594E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 12

Check BCM circuit. Refer to [LAN-121, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7975E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 13

Check steering angle sensor circuit. Refer to [LAN-122, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7976E



SKIA6596E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 14

Check unified meter and A/C amp. circuit. Refer to [LAN-122, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7977E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 15

Check ICC sensor circuit. Refer to [LAN-123, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7978E



SKIA6598E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 16

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-123, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7979E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 17

Check driver seat control unit circuit. Refer to [LAN-124, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7980E



SKIA6600E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 18

Check IPDM E/R circuit. Refer to [LAN-125, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7981E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 3)

[CAN]

## Case 19

Check CAN communication circuit. Refer to [LAN-126, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW <del>N</del>	—	—	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—
ICC	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
INTELLIGENT KEY	No indication	—	UNKW <del>N</del>	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—

PKIA7982E

## Case 20

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-131, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW <del>N</del>	—	—	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—
ICC	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
INTELLIGENT KEY	No indication	—	UNKW <del>N</del>	—	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—

PKIA7984E

## Case 21

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-131, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	✓	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7983E

## Circuit Check Between TCM and Data Link Connector

AKS007RW

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-91, "Work Flow"](#).
- NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS007RX

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-91, "Work Flow"](#).
- NG >> Repair harness.



## Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS007RY

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

**1 (L) - 15G (L) : Continuity should exist.**

**11 (R) - 14G (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

**15G (L) - 11 (L) : Continuity should exist.**  
**14G (R) - 15 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-91, "Work Flow"](#) .  
 NG >> Repair harness.



**Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit**

AKS007RZ

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E205
  - Harness connector B5

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

**11 (L) - 3 (L) : Continuity should exist.**  
**15 (R) - 10 (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).


**3 (L) - 14 (L) : Continuity should exist.**

**10 (R) - 15 (R) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-91, "Work Flow"](#) .

NG >> Repair harness.



AKS007S0

### ECM Circuit Check

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between ECM and harness connector M82.



AKS007S1

### TCM Circuit Check

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and display control unit.



## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M76 terminals 25 (L) and 26 (R).

**25 (L) - 26 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and harness connector M82.



## Low Tire Pressure Warning Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M74 terminals 9 (L) and 21 (R).

**9 (L) - 21 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace low tire pressure warning control unit.  
 NG >> Repair harness between low tire pressure warning control unit and harness connector M82.



## ICC Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector M88 terminals 14 (L) and 5 (R).

**14 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ICC unit.  
 NG >> Repair harness between ICC unit and harness connector M82.



## Intelligent Key Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M34 terminals 2 (L) and 3 (R).

**2 (L) - 3 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace Intelligent Key unit.  
 NG >> Repair harness between Intelligent Key unit and data link connector.



## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-91, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and BCM.



## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



AKS007S8

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



AKS007S9

## Unified Meter and A/C Amp. Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ICC Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E39 terminals 3 (L) and 6 (R).

**3 (L) - 6 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ICC sensor.  
 NG >> Repair harness between ICC sensor and ABS actuator and electric unit (control unit).



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and ICC sensor.



## Driver Seat Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector B151
  - Harness connector B8

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B5.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R)****: Approx. 108 - 132Ω**OK or NG

OK &gt;&gt; Replace IPDM E/R.

NG &gt;&gt; Repair harness between IPDM E/R and harness connector B8.



A

B

C

D

E

F

G

H

I

J

LAN

L

M

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, unit side, sensor side, meter side and harness side).
  - ECM
  - A/T assembly
  - Display control unit
  - Low tire pressure warning control unit
  - ICC unit
  - Intelligent Key unit
  - BCM
  - Steering angle sensor
  - Unified meter and A/C amp.
  - ICC sensor
  - ABS actuator and electric unit (control unit)
  - Driver seat control unit
  - IPDM E/R
  - Between ECM and IPDM E/R
  - Between ECM and A/T assembly

#### OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display control unit connector
  - Low tire pressure warning control unit connector
  - ICC unit connector
  - Intelligent Key unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


**6 (L) - 14 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display control unit.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and ICC unit.
- Harness between data link connector and Intelligent Key unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display control unit.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and ICC unit.
- Harness between data link connector and Intelligent Key unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


**3 (L) - Ground : Continuity should not exist.**

**8 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.





## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector, ICC sensor connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


**11 (L) - 15 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.
- Harness between ABS actuator and electric unit (control unit) and ICC sensor.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

**11 (L) - Ground : Continuity should not exist.**


**15 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.
- Harness between ABS actuator and electric unit (control unit) and ICC sensor.



## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


**3 (L) - 10 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.



## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

**3 (L) - Ground : Continuity should not exist.**


**10 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.



## 10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Continuity should not exist.**

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector B151.



## 11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.


**14 (OR) - Ground : Continuity should not exist.**

**15 (SB) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector B151.



## 12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 13.

NG >> Repair harness between IPDM E/R and harness connector E205.




### 13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.
- NG >> Repair harness between IPDM E/R and harness connector E205.



### 14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-131, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-91, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

#### IPDM E/R Ignition Relay Circuit Check

AKS007SF

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

#### Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007SG

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 4)


### System Description

AKS007SH

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007SI




# CAN SYSTEM (TYPE 4)

[CAN]

## Schematic

AKS007SJ



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

TKWM0750E

# CAN SYSTEM (TYPE 4)





[CAN]

## Wiring Diagram - CAN -

AKS007SK

### LAN-CAN-08

▬ : DATA LINE



REFER TO THE FOLLOWING.



F102 - SUPER MULTIPLE JUNCTION (SMJ)

M90 - ELECTRICAL UNITS


TKWM0751E

## LAN-CAN-09

▬ : DATA LINE



(M5)  
W







(M14)  
W

REFER TO THE FOLLOWING.  
(M3) -ELECTRICAL UNITS

TKWM0752E

## LAN-CAN-10

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS



# CAN SYSTEM (TYPE 4)

[CAN]

AKS00C4D

## Work Flow

- When there are no indications of "BCM", "METER A/C AMP" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)	NISSAN				<b>SELECT SYSTEM</b>			
	CONSULT-II				ENGINE			
	ENGINE				A/T			
	START (NISSAN BASED VHCL)				ABS			
	START (RENAULT BASED VHCL)				AIR BAG			
	SUB MODE				BCM			
					METER A/C AMP			
			LIGHT COPY		BACK		LIGHT COPY	

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.

(Example)	<b>SELECT DIAG MODE</b>		<b>SELF-DIAG RESULTS</b>			
	WORK SUPPORT		DTC RESULTS		TIME	
	<b>SELF-DIAG RESULTS</b>		CAN COMM CIRCUIT [U1000]		0	
	DATA MONITOR					
	DATA MONITOR (SPEC)					
	CAN DIAG SUPPORT MNTR					
	ACTIVE TEST					
					F.F.DATA	
			ERASE		PRINT	
			MODE BACK		LIGHT COPY	

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.

(Example)	<b>SELECT DIAG MODE</b>		<b>CAN DIAG SUPPORT MNTR</b>			
	WORK SUPPORT		<b>ENGINE</b>			
	<b>SELF-DIAG RESULTS</b>		INITIAL DIAG		OK	
	DATA MONITOR		TRANSMIT DIAG		OK	
	DATA MONITOR (SPEC)		TCM		OK	
	CAN DIAG SUPPORT MNTR		VDC/TCS/ABS		OK	
	ACTIVE TEST		METER/M&A		OK	
			ICC		UNKW/N	
			BCM/SEC		OK	
			IPDM E/R		OK	

		AWD/4WD/e4WD		UNKW/N	
		PRINT		Scroll Down	
		MODE BACK		LIGHT COPY	

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-139, "CHECK SHEET"](#).

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKW/N" in the check sheet table. Refer to [LAN-139, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-97, "CAN Communication Line Inspection"](#).

- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-139, "CHECK SHEET"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

- 
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-139, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-97, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-141, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 4)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	-	CAN 2	-	CAN 5	-	CAN 7
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN	UNKWN	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR check sheet

# CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER A/C AMP  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER A/C AMP  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA7986E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-155, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7987E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-155, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7988E



SKIA6603E

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to [LAN-156, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit \(Control Unit\)"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA7989E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-156, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N
METER A/C AMP	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—	—

PKIA7990E





# CAN SYSTEM (TYPE 4)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-157, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7991E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 6

Check display unit circuit. Refer to [LAN-157, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CA <del>✓</del> 1	CA <del>✓</del> 3	—	—	—	CA <del>✓</del> 2	—	CA <del>✓</del> 5	—	CA <del>✓</del> 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7992E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 7

Check AWD control unit circuit. Refer to [LAN-158, "AWD Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN ✓	UNKWN ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7993E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 8

Check data link connector circuit. Refer to [LAN-158, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7994E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 9

Check BCM circuit. Refer to [LAN-159, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7995E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 10

Check steering angle sensor circuit. Refer to [LAN-159, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7996E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 11

Check unified meter and A/C amp. circuit. Refer to [LAN-160, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7997E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-160, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7998E





# CAN SYSTEM (TYPE 4)


[CAN]

## Case 13

Check IPDM E/R circuit. Refer to [LAN-161, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7 ✓	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN ✓	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7999E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 14

Check CAN communication circuit. Refer to [LAN-162, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	
METER A/C AMP	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	—	—	—	

PKIA8000E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-165, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	
METER A/C AMP	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	—	—	—	

PKIA8000E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-165, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

PKIA8001E

## Circuit Check Between TCM and Data Link Connector

AKS007SM

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-137, "Work Flow"](#).
- NG >> Repair harness.



## Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS007SN

### 1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-137, "Work Flow"](#).
- NG >> Repair harness.



## Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS007SO

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

#### OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).


**1 (L) - 15G (L) : Continuity should exist.**

**11 (R) - 14G (R) : Continuity should exist.**

#### OK or NG

OK &gt;&gt; GO TO 3.

NG &gt;&gt; Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).


**15G (L) - 11 (L) : Continuity should exist.**

**14G (R) - 15 (R) : Continuity should exist.**

#### OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-137, "Work Flow"](#).

NG &gt;&gt; Repair harness.



## ECM Circuit Check

AKS007SP

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R)**

**: Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and harness connector M82.



SKIA6865E

AKS007SQ

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and display unit.



SKIA6866E

AKS007SR

## Display Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

**14 (L) - 16 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit and harness connector M82.



## AWD Control Unit Circuit Check

AKS007UD

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

**8 (L) - 16 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace AWD control unit.  
 NG >> Repair harness between AWD control unit and harness connector M82.



## Data Link Connector Circuit Check

AKS007SS

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-137, "Work Flow"](#).  
 NG >> Repair harness between data link connector and BCM.



AKS007ST

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).  
 NG >> Repair harness between BCM and data link connector.



AKS007SU

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



## Unified Meter and A/C Amp. Circuit Check

AKS007SV

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS007SW

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.



## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



AKS007SX

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R)**

**: Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LAN

L

M

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, control unit side, sensor side, meter side and harness side).
  - ECM
  - A/T assembly
  - Display unit
  - AWD control unit
  - BCM
  - Steering angle sensor
  - Unified meter and A/C amp.
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R
  - Between ECM and A/T assembly

#### OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display unit connector
  - AWD control unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


**6 (L) - 14 (R) : Continuity should not exist.**

#### OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (R) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Continuity should not exist.**

#### OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


**3 (L) - Ground : Continuity should not exist.**

**8 (R) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


**11 (L) - 15 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

**11 (L) - Ground : Continuity should not exist.**


**15 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.



## 8. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B5 terminals 3 (L) and 10 (R).

**3 (L) - 10 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 9.

NG >> Repair harness between harness connector B5 and harness connector B5.



## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.


**3 (L) - Ground : Continuity should not exist.**

**10 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 10.

NG >> Repair harness between harness connector B5 and harness connector B5.




## 10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 11.  
 NG >> Repair harness between IPDM E/R and harness connector E205.



## 11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

**48 (L) - Ground : Continuity should not exist.**

**49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 12.  
 NG >> Repair harness between IPDM E/R and harness connector E205.



## 12. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-165, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-137, "Work Flow"](#).  
 NG >> Replace ECM and/or IPDM E/R.

### IPDM E/R Ignition Relay Circuit Check

AKS007SZ

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

### Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007T0

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



LKIA0037E

## CAN SYSTEM (TYPE 5)


### System Description

AKS007T1

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007T2




# CAN SYSTEM (TYPE 5)

[CAN]

## Schematic

AKS007T3



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

TKWM0754E

# CAN SYSTEM (TYPE 5)





[CAN]

## Wiring Diagram - CAN -

AKS007T4

### LAN-CAN-11

▬ : DATA LINE



REFER TO THE FOLLOWING.

F102 - SUPER MULTIPLE JUNCTION (SMJ)




M90 - ELECTRICAL UNITS

TKWM0755E



## LAN-CAN-12

▬ : DATA LINE








REFER TO THE FOLLOWING.  
M3 - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN-CAN-13

— — — — — : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS

# CAN SYSTEM (TYPE 5)

[CAN]

AKS00C4E

## Work Flow

- When there are no indications of "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN	
CONSULT-II	
ENGINE	
START (NISSAN BASED VHCL)	
START (RENAULT BASED VHCL)	
SUB MODE	
	LIGHT COPY

SELECT SYSTEM			
ENGINE			
A/T			
ABS			
AIR BAG			
BCM			
METER A/C AMP			
BACK		LIGHT	COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
	BACK LIGHT COPY

SELF-DIAG RESULTS	
DTC RESULTS	
TIME	
CAN COMM CIRCUIT [U1000]	0
F.F.DATA	
ERASE PRINT	
MODE	BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
ENGINE	
PRNT	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	OK
IPDM E/R	OK
AWD/4WD/e4WD	UNKWN
PRINT	
MODE	BACK LIGHT COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-173, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-173, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-97, "CAN Communication Line Inspection"](#).
- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-173, "CHECK SHEET"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 5)

[CAN]

- 
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-173, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-97, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-175, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR check sheet

PKIA8003E

# CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER A/C AMP  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER A/C AMP  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8004E

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-191, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8005E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-191, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8006E





# CAN SYSTEM (TYPE 5)

[CAN]


## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to [LAN-192, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit \(Control Unit\)"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8007E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to [LAN-193, "Circuit Check Between ABS Actuator and Electric Unit \(Control Unit\) and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA8008E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-193, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	—	UNKWN	UNKWN
Display unit	—	CAN COMM	CAN 1	CAN 3 ✓	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	—

PKIA8009E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 6

Check TCM circuit. Refer to [LAN-194, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8010E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 7

Check display unit circuit. Refer to [LAN-194, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1 ✓	CAN 3 ✓	—	—	—	CAN 2 ✓	—	CAN 5 ✓	—	CAN 7 ✓	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA8011E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 8

Check AWD control unit circuit. Refer to [LAN-195, "AWD Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8012E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 9

Check data link connector circuit. Refer to [LAN-195, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA8013E



LAN

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 10

Check BCM circuit. Refer to [LAN-196, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8014E





# CAN SYSTEM (TYPE 5)


[CAN]

## Case 11

Check steering angle sensor circuit. Refer to [LAN-196, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8015E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 12

Check unified meter and A/C amp. circuit. Refer to [LAN-197, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8016E



# CAN SYSTEM (TYPE 5)

[CAN]


## Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-197, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8017E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 14

Check driver seat control unit circuit. Refer to [LAN-198, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8018E



# CAN SYSTEM (TYPE 5)

[CAN]


## Case 15

Check IPDM E/R circuit. Refer to [LAN-199, "IPDM E/R Circuit Check"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8019E



LAN

# CAN SYSTEM (TYPE 5)

[CAN]

## Case 16

Check CAN communication circuit. Refer to [LAN-199, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—	

PKIA8020E

## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-204, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	
METER A/C AMP	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—	

PKIA8022E

**Case 18**

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-204, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8021E

**Circuit Check Between TCM and Data Link Connector**

AKS00776

**1. CHECK HARNESS FOR OPEN CIRCUIT**


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-171, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.**

AKS00777

**1. CHECK HARNESS FOR OPEN CIRCUIT**


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-171, "Work Flow"](#).
- NG >> Repair harness.



## Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS00778

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

**1 (L) - 15G (L) : Continuity should exist.**

**11 (R) - 14G (R) : Continuity should exist.**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

**15G (L) - 11 (L) : Continuity should exist.**

**14G (R) - 15 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-171, "Work Flow"](#) .  
NG >> Repair harness.





**Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit**

AKS0079

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E205
  - Harness connector B5

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

**11 (L) - 3 (L) : Continuity should exist.**  
**15 (R) - 10 (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

**3 (L) - 14 (L) : Continuity should exist.**  
**10 (R) - 15 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-171, "Work Flow"](#).  
 NG >> Repair harness.



**ECM Circuit Check**

AKS0079

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R)**

**: Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and harness connector M82.



SKIA6865E

AKS0077B

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and display unit.



SKIA6866E

AKS0077C

## Display Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

**14 (L) - 16 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit and harness connector M82.



AKS007UE

## AWD Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

**8 (L) - 16 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace AWD control unit.  
 NG >> Repair harness between AWD control unit and harness connector M82.



AKS007TD

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-171, "Work Flow"](#).  
 NG >> Repair harness between data link connector and BCM.



SKIA6868E

AKS007TE

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).  
 NG >> Repair harness between BCM and data link connector.



SKIA6869E

AKS007TF

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



## Unified Meter and A/C Amp. Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



## Driver Seat Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector B151
  - Harness connector B8

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B5.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector B8.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, control unit side, sensor side, meter side and harness side).
  - ECM
  - A/T assembly
  - Display unit
  - AWD control unit
  - BCM
  - Steering angle sensor
  - Unified meter and A/C amp.
  - ABS actuator and electric unit (control unit)
  - Driver seat control unit
  - IPDM E/R
  - Between ECM and IPDM E/R
  - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display unit connector
  - AWD control unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
- Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


**6 (L) - 14 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



## 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.






#### 4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness between A/T assembly and harness connector F102.



#### 5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.

**3 (L) - Ground : Continuity should not exist.**

**8 (R) - Ground : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 6.  
 NG >> Repair harness between A/T assembly and harness connector F102.




#### 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R) : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 7.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
  - Harness between ABS actuator and electric unit (control unit) and harness connector E205.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

**11 (L) - Ground : Continuity should not exist.**


**15 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.



## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


**3 (L) - 10 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.



## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

**3 (L) - Ground : Continuity should not exist.**


**10 (R) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.




## 10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Continuity should not exist.**

OK or NG

- OK >> GO TO 11.  
 NG >> Repair harness between driver seat control unit and harness connector B151.



## 11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.

**14 (OR) - Ground : Continuity should not exist.**

**15 (SB) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 12.  
 NG >> Repair harness between driver seat control unit and harness connector B151.




## 12. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 13.  
 NG >> Repair harness between IPDM E/R and harness connector E205.



## 13. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

**48 (L) - Ground : Continuity should not exist.**

**49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.  
 NG >> Repair harness between IPDM E/R and harness connector E205.



## 14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-204, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-171, "Work Flow"](#) .

NG >> Replace ECM and/or IPDM E/R.

### IPDM E/R Ignition Relay Circuit Check

AKS007TL

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .


### Component Inspection

AKS007TM

#### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



## CAN SYSTEM (TYPE 6)

PFP:23710


### System Description

AKS007TN

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

AKS007TO



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

# CAN SYSTEM (TYPE 6)

[CAN]

## Schematic

AKS007TP



TKWM0758E

# CAN SYSTEM (TYPE 6)


[CAN]

## Wiring Diagram - CAN -






AKS0077Q

### LAN-CAN-14

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.



(F102) - SUPER MULTIPLE JUNCTION (SMJ)

(M90) - ELECTRICAL UNITS


TKWM0759E

## LAN-CAN-15


▬ : DATA LINE



(M5)  
W



(M14)  
W



(M34)  
W










REFER TO THE FOLLOWING.  
(M3) -ELECTRICAL UNITS

TKWM0760E



## LAN-CAN-16

— : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


# CAN SYSTEM (TYPE 6)

[CAN]


AKS00C4F

## Work Flow


- When there are no indications of "AIR PRESSURE MONITOR", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ALL MODE AWD/4WD", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ALL MODE AWD/4WD", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-212, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "V" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-212, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-184, "CAN Communication Line Check"](#).

# CAN SYSTEM (TYPE 6)

[CAN]

7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-212, "CHECK SHEET"](#) .
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-212, "CHECK SHEET"](#) .  
**NOTE:**  
If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-184, "CAN Communication Line Check"](#) .
9. According to the check sheet results (example), start inspection. Refer to [LAN-215, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	UNKWN	UNKWN
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 6)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AIR PRESSURE  
MONITOR  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ICC  
SELF-DIAG RESULTS

Attach copy of  
INTELLIGENT KEY  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
METER A/C AMP  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

PKIA8024E

# CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AIR PRESSURE  
MONITOR  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ICC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
INTELLIGENT KEY  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
METER A/C AMP  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8025E

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-236, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8026E



SKIA6630E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-237, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8027E



SKIA6631E



# CAN SYSTEM (TYPE 6)

[CAN]


## Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-237, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	—
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8028E



SKIA6632E

LAN

L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to [LAN-238, "Circuit Check Between ABS Actuator and Electric Unit \(Control Unit\) and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7 ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8029E



SKIA6633E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-239, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	—	—	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8030E



SKIA6634E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 6

Check TCM circuit. Refer to [LAN-239, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8031E



SKIA6635E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 7

Check display control unit circuit. Refer to [LAN-240, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN/CRC 1 ✓	CAN/CRC 3 ✓	—	—	CAN/CRC 6 ✓	—	—	—	CAN/CRC 2 ✓	—	CAN/CRC 5 ✓	—	—	CAN/CRC 7 ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8032E



SKIA6636E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 8

Check low tire pressure warning control unit circuit. Refer to [LAN-240, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8033E



SKIA6637E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 9

Check AWD control unit circuit. Refer to [LAN-241, "AWD Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	—	—	UNKWN ✓	—	UNKWN ✓	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8034E



SKIA6638E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 10

Check ICC unit circuit. Refer to [LAN-241, "ICC Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8035E



SKIA6639E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 11

Check Intelligent Key unit circuit. Refer to [LAN-242, "Intelligent Key Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN ✓	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8036E



SKIA6640E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 12

Check data link connector circuit. Refer to [LAN-242, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8037E



SKIA6641E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 13

Check BCM circuit. Refer to [LAN-243, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8038E



SKIA6642E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 14

Check steering angle sensor circuit. Refer to [LAN-243, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8039E



SKIA6643E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 15

Check unified meter and A/C amp. circuit. Refer to [LAN-244, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	✓	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	✓	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	✓	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	✓	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	✓	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	✓	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8040E



SKIA6644E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 16

Check ICC sensor circuit. Refer to [LAN-244, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8041E



SKIA6645E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 17

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-245, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8042E



SKIA6646E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 18

Check driver seat control unit circuit. Refer to [LAN-245, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8043E



SKIA6647E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 19

Check IPDM E/R circuit. Refer to [LAN-246, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN	✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8044E



SKIA6648E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 6)

[CAN]

## Case 20

Check CAN communication circuit. Refer to [LAN-247, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	
Display control unit	—	CAN COMM	CAN CIRC 1 <sup>✓</sup>	CAN CIRC 3 <sup>✓</sup>	—	—	CAN CIRC 6 <sup>✓</sup>	—	—	—	CAN CIRC 2 <sup>✓</sup>	—	CAN CIRC 5 <sup>✓</sup>	—	—	CAN CIRC 7 <sup>✓</sup>
AIR PRESSURE MONITOR	No indication <sup>✓</sup>	NG	UNKW <sup>✓</sup> N	—	—	—	—	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	—
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—
ICC	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—
INTELLIGENT KEY	No indication <sup>✓</sup>	—	UNKW <sup>✓</sup> N	—	—	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	—	—	—
BCM	No indication <sup>✓</sup>	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N
METER A/C AMP	No indication <sup>✓</sup>	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—	—
AUTO DRIVE POS.	No indication <sup>✓</sup>	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—
IPDM E/R	No indication <sup>✓</sup>	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	—	—	UNKW <sup>✓</sup> N	—	—	—	—	—

PKIA8045E

# CAN SYSTEM (TYPE 6)

[CAN]

## Case 21

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS
ENGINE	—	NG	UNKWN	—	✓	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	✓	—
ICC	—	NG	UNKWN	UNKWN	✓	—	—	—	—	—	UNKWN	—	—	UNKWN	✓	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8047E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## Case 22

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-252, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 8	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8046E

## Circuit Check Between TCM and Data Link Connector

AKS007TS

### 1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).


**14H (L) - 6 (L) : Continuity should exist.**

**15H (R) - 14 (R) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-210, "Work Flow"](#) .

NG >> Repair harness.



**Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.**

AKS007TT

**1. CHECK HARNESS FOR OPEN CIRCUIT**


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M55 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

**6 (L) - 1 (L) : Continuity should exist.**

**14 (R) - 11 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-210, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)**

AKS007TU

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M41
  - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

**1 (L) - 15G (L) : Continuity should exist.**

**11 (R) - 14G (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

**15G (L) - 11 (L) : Continuity should exist.**

**14G (R) - 15 (R) : Continuity should exist.**



OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-210, "Work Flow"](#) .
- NG >> Repair harness.

## Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS007TV

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E205
  - Harness connector B5

OK or NG


- OK >> GO TO 2.
- NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

**11 (L) - 3 (L) : Continuity should exist.**

**15 (R) - 10 (R) : Continuity should exist.**



OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

**3 (L) - 14 (L) : Continuity should exist.**

**10 (R) - 15 (R) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-210, "Work Flow"](#).
- NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

**94 (L) - 86 (R) : Approx. 108 - 132Ω**

#### OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - A/T assembly connector
  - Harness connector F102
  - Harness connector M82

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and display control unit.



## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M76 terminals 25 (L) and 26 (R).

**25 (L) - 26 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and harness connector M82.



## Low Tire Pressure Warning Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M74 terminals 9 (L) and 21 (R).

**9 (L) - 21 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace low tire pressure warning control unit.  
 NG >> Repair harness between low tire pressure warning control unit and harness connector M82.



## AWD Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

**8 (L) - 16 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace AWD control unit.  
 NG >> Repair harness between AWD control unit and harness connector M82.



## ICC Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector M88 terminals 14 (L) and 5 (R).

**14 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ICC unit.  
 NG >> Repair harness between ICC unit and harness connector M82.



SKIA6886E

## Intelligent Key Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M34 terminals 2 (L) and 3 (R).

**2 (L) - 3 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace Intelligent Key unit.  
 NG >> Repair harness between Intelligent Key unit and data link connector.



SKIA6887E

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

**6 (L) - 14 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-210, "Work Flow"](#).  
 NG >> Repair harness between data link connector and BCM.



AKS007U3

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

**39 (L) - 40 (R) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-28, "Removal and Installation of BCM"](#).  
 NG >> Repair harness between BCM and data link connector.



AKS007U4

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

**4 (L) - 5 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



## Unified Meter and A/C Amp. Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

**1 (L) - 11 (R) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace unified meter and A/C amp.  
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



## ICC Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E39 terminals 3 (L) and 6 (R).

**3 (L) - 6 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ICC sensor.  
 NG >> Repair harness between ICC sensor and ABS actuator and electric unit (control unit).



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS007U7

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

**11 (L) - 15 (R)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and ICC sensor.



## Driver Seat Control Unit Circuit Check

AKS007U8

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector B151
  - Harness connector B8

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

**14 (OR) - 15 (SB) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B5.



AKS007U9

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E205
  - Harness connector B5

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

**48 (L) - 49 (R) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector B8.



**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, unit side, sensor side, meter side and harness side).
  - ECM
  - A/T assembly
  - Display control unit
  - AWD control unit
  - Low tire pressure warning control unit
  - ICC unit
  - Intelligent Key unit
  - BCM
  - Steering angle sensor
  - Unified meter and A/C amp.
  - ICC sensor
  - ABS actuator and electric unit (control unit)
  - Driver seat control unit
  - IPDM E/R
  - Between ECM and IPDM E/R
  - Between ECM and A/T assembly

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector M82
  - Display control unit connector
  - Low tire pressure warning control unit connector
  - AWD control unit connector
  - ICC unit connector
  - Intelligent Key unit connector
  - BCM connector
  - Steering angle sensor connector
  - Unified meter and A/C amp. connector
  - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


**6 (L) - 14 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display control unit.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and ICC unit.
- Harness between data link connector and Intelligent Key unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.





### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (R) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM.
- Harness between data link connector and harness connector M82.
- Harness between data link connector and display control unit.
- Harness between data link connector and low tire pressure warning control unit.
- Harness between data link connector and AWD control unit.
- Harness between data link connector and ICC unit.
- Harness between data link connector and Intelligent Key unit.
- Harness between data link connector and BCM.
- Harness between data link connector and steering angle sensor.
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

**3 (L) - 8 (R) : Continuity should not exist.**

#### OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


**3 (L) - Ground : Continuity should not exist.**

**8 (R) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector, ICC sensor connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


**11 (L) - 15 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.
- Harness between ABS actuator and electric unit (control unit) and ICC sensor.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

**11 (L) - Ground : Continuity should not exist.**


**15 (R) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211.
- Harness between ABS actuator and electric unit (control unit) and harness connector E205.
- Harness between ABS actuator and electric unit (control unit) and ICC sensor.



## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


**3 (L) - 10 (R) : Continuity should not exist.**

### OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5.
- Harness between harness connector B5 and harness connector B8.




## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

- 3 (L) - Ground : Continuity should not exist.**
- 10 (R) - Ground : Continuity should not exist.**

### OK or NG

- OK >> GO TO 10.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between harness connector B5 and harness connector B5.
  - Harness between harness connector B5 and harness connector B8.




## 10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

- 14 (OR) - 15 (SB) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 11.
- NG >> Repair harness between driver seat control unit and harness connector B151.




## 11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.

- 14 (OR) - Ground : Continuity should not exist.**
- 15 (SB) - Ground : Continuity should not exist.**

### OK or NG

- OK >> GO TO 12.
- NG >> Repair harness between driver seat control unit and harness connector B151.




## 12. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

- 48 (L) - 49 (R) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 13.
- NG >> Repair harness between IPDM E/R and harness connector E205.




### 13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.
- NG >> Repair harness between IPDM E/R and harness connector E205.



### 14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-252, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-210, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

#### IPDM E/R Ignition Relay Circuit Check

AKS007UB

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-43, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

#### Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007UC

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

