

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D

E

CAN

PRECAUTIONS	4	IPDM E/R Circuit Check	46
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	CAN Communication Circuit Check	47
Precautions When Using CONSULT-II	4	IPDM E/R Ignition Relay Circuit Check	51
CHECK POINTS FOR USING CONSULT-II	4	Component Inspection	51
Precautions For Trouble Diagnosis	4	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	51
CAN SYSTEM	4	CAN SYSTEM (TYPE 2)	52
Precautions For Harness Repair	5	System Description	52
CAN SYSTEM	5	Component Parts and Harness Connector Location..	52
CAN COMMUNICATION	6	Wiring Diagram - CAN -	53
System Description	6	Work Flow	55
CAN Communication Unit	6	CHECK SHEET	57
TYPE 1/TYPE2	6	CHECK SHEET RESULTS (EXAMPLE)	59
TYPE 3	9	Circuit Check Between TCM and Data Link Connector	74
TYPE 4/TYPE5	13	Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	74
TYPE 6	16	Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)..	75
CAN SYSTEM (TYPE 1)	21	Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit	76
System Description	21	ECM Circuit Check	76
Component Parts and Harness Connector Location.	21	TCM Circuit Check	77
Wiring Diagram - CAN -	22	Display Unit Circuit Check	77
Work Flow	24	Data Link Connector Circuit Check	78
CHECK SHEET	26	BCM Circuit Check	78
CHECK SHEET RESULTS (EXAMPLE)	28	Steering Angle Sensor Circuit Check	79
Circuit Check Between TCM and Data Link Connector	41	Unified Meter and A/C Amp. Circuit Check	79
Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.	41	ABS Actuator and Electric Unit (Control Unit) Circuit Check	80
Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)..	42	Driver Seat Control Unit Circuit Check	80
ECM Circuit Check	42	IPDM E/R Circuit Check	81
TCM Circuit Check	43	CAN Communication Circuit Check	82
Display Unit Circuit Check	43	IPDM E/R Ignition Relay Circuit Check	86
Data Link Connector Circuit Check	44	Component Inspection	86
BCM Circuit Check	44	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	86
Steering Angle Sensor Circuit Check	45	CAN SYSTEM (TYPE 3)	87
Unified Meter and A/C Amp. Circuit Check	45	System Description	87
ABS Actuator and Electric Unit (Control Unit) Circuit Check	46	Component Parts and Harness Connector Location..	87

F

G

H

I

J

LAN

L

M

Schematic	88	CAN Communication Circuit Check	163
Wiring Diagram - CAN -	89	IPDM E/R Ignition Relay Circuit Check	166
Work Flow	92	Component Inspection	166
CHECK SHEET	94	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
CHECK SHEET RESULTS (EXAMPLE)	97	TION	166
Circuit Check Between TCM and Data Link Con-		CAN SYSTEM (TYPE 5)	167
connector	116	System Description	167
Circuit Check Between Data Link Connector and		Component Parts and Harness Connector Location	167
Unified Meter and A/C Amp.	117	Schematic	168
Circuit Check Between Unified Meter and A/C Amp.		Wiring Diagram - CAN -	169
and ABS Actuator and Electric Unit (Control Unit)	117	Work Flow	172
Circuit Check Between ABS Actuator and Electric		CHECK SHEET	174
Unit (Control Unit) and Driver Seat Control Unit ..	118	CHECK SHEET RESULTS (EXAMPLE)	176
ECM Circuit Check	119	Circuit Check Between TCM and Data Link Con-	
TCM Circuit Check	119	connector	192
Display Control Unit Circuit Check	120	Circuit Check Between Data Link Connector and	
Low Tire Pressure Warning Control Unit Circuit		Unified Meter and A/C Amp.	192
Check	120	Circuit Check Between Unified Meter and A/C Amp.	
ICC Unit Circuit Check	121	and ABS Actuator and Electric Unit (Control Unit).	193
Intelligent Key Unit Circuit Check	121	Circuit Check Between ABS Actuator and Electric	
Data Link Connector Circuit Check	122	Unit (Control Unit) and Driver Seat Control Unit ..	194
BCM Circuit Check	122	ECM Circuit Check	194
Steering Angle Sensor Circuit Check	123	TCM Circuit Check	195
Unified Meter and A/C Amp. Circuit Check	123	Display Unit Circuit Check	195
ICC Sensor Circuit Check	124	AWD Control Unit Circuit Check	196
ABS Actuator and Electric Unit (Control Unit) Circuit		Data Link Connector Circuit Check	196
Check	124	BCM Circuit Check	197
Driver Seat Control Unit Circuit Check	125	Steering Angle Sensor Circuit Check	197
IPDM E/R Circuit Check	126	Unified Meter and A/C Amp. Circuit Check	198
CAN Communication Circuit Check	127	ABS Actuator and Electric Unit (Control Unit) Circuit	
IPDM E/R Ignition Relay Circuit Check	132	Check	198
Component Inspection	132	Driver Seat Control Unit Circuit Check	199
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-		IPDM E/R Circuit Check	200
TION	132	CAN Communication Circuit Check	200
CAN SYSTEM (TYPE 4)	133	IPDM E/R Ignition Relay Circuit Check	205
System Description	133	Component Inspection	205
Component Parts and Harness Connector Location	133	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
Schematic	134	TION	205
Wiring Diagram - CAN -	135	CAN SYSTEM (TYPE 6)	206
Work Flow	138	System Description	206
CHECK SHEET	140	Component Parts and Harness Connector Location	206
CHECK SHEET RESULTS (EXAMPLE)	142	Schematic	207
Circuit Check Between TCM and Data Link Con-		Wiring Diagram - CAN -	208
connector	156	Work Flow	211
Circuit Check Between Data Link Connector and		CHECK SHEET	213
Unified Meter and A/C Amp.	156	CHECK SHEET RESULTS (EXAMPLE)	216
Circuit Check Between Unified Meter and A/C Amp.		Circuit Check Between TCM and Data Link Con-	
and ABS Actuator and Electric Unit (Control Unit)	157	connector	237
ECM Circuit Check	157	Circuit Check Between Data Link Connector and	
TCM Circuit Check	158	Unified Meter and A/C Amp.	238
Display Unit Circuit Check	158	Circuit Check Between Unified Meter and A/C Amp.	
AWD Control Unit Circuit Check	159	and ABS Actuator and Electric Unit (Control Unit).	238
Data Link Connector Circuit Check	159	Circuit Check Between ABS Actuator and Electric	
BCM Circuit Check	160	Unit (Control Unit) and Driver Seat Control Unit ..	239
Steering Angle Sensor Circuit Check	160	ECM Circuit Check	240
Unified Meter and A/C Amp. Circuit Check	161	TCM Circuit Check	240
ABS Actuator and Electric Unit (Control Unit) Circuit		Display Control Unit Circuit Check	241
Check	161	Low Tire Pressure Warning Control Unit Circuit	
IPDM E/R Circuit Check	162	Check	241

AWD Control Unit Circuit Check	242	Check	246
ICC Unit Circuit Check	242	Driver Seat Control Unit Circuit Check	246
Intelligent Key Unit Circuit Check	243	IPDM E/R Circuit Check	247
Data Link Connector Circuit Check	243	CAN Communication Circuit Check	248
BCM Circuit Check	244	IPDM E/R Ignition Relay Circuit Check	253
Steering Angle Sensor Circuit Check	244	Component Inspection	253
Unified Meter and A/C Amp. Circuit Check	245	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
ICC Sensor Circuit Check	245	TION	253
ABS Actuator and Electric Unit (Control Unit) Circuit			

A
B
C

D

E

F

G

H

I

J

LAN

L

M

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS007WY

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

AKS0058H

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6, "CAN Communication Unit"](#) .

**Precautions For Trouble Diagnosis
CAN SYSTEM**

AKS0058I

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


PRECAUTIONS

[CAN]


Precautions For Harness Repair CAN SYSTEM

AKS0058J

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

PFP:23710

System Description

AKS00BZ5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS00BZ6

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon					
Axle	2WD			AWD		
Engine	VQ35DE			VQ35DE/VK45DE		
Transmission	A/T					
Brake control	VDC					
Navigation system			×			×
Low tire pressure warning system			×			×
ICC system			×			×
Intelligent Key system			×			×
Automatic drive positioner		×	×		×	×
CAN system type	1	2	3	4	5	6
CAN system trouble diagnosis	LAN-21	LAN-52	LAN-87	LAN-133	LAN-167	LAN-206

×: Applicable

TYPE 1/TYPE2

System diagram


- Type1



CAN COMMUNICATION

[CAN]

● Type2



A
B
C
D
E
F
G
H
I
J
K
L
M

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Engine speed signal	T	R	R			R	R		
Engine status signal	T			R					
Engine coolant temperature signal	T					R			
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R					R		
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
Key switch signal				T				R	
Ignition switch signal				T				R	R
P range signal		T					R	R	
Stop lamp switch signal		R				T			
Fuel consumption monitor signal	T					R			
			R			T			
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T							
A/C switch signal	R			T					
A/C compressor request signal	T								R
A/C compressor feedback signal	T					R			
Blower fan motor switch signal	R			T					
A/C switch/indicator signal			T			R			
			R			T			
Cooling fan speed request signal	T								R

LAN

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Position light request signal			R	T		R			R
Low beam request signal				T					R
Low beam status signal	R								T
High beam request signal				T		R			R
High beam status signal	R								T
Front fog light request signal				T					R
Day time running light request signal				T		R			
Turn LED burnout status signal				R		T			
Vehicle speed signal						R	T		
	R	R	R	R		T		R	
Sleep wake up signal				T		R			R
Door switch signal			R	T		R		R	R
Turn indicator signal				T		R			
Key fob ID signal				T				R	
Key fob door unlock signal				T				R	
Oil pressure switch signal				R					T
				T		R			
Buzzer output signal				T		R			
Fuel level sensor signal	R					T			
Fuel level low warning signal			R			T			
ASCD SET lamp signal	T					R			
ASCD CRUISE lamp signal	T					R			
Malfunction indicator lamp signal	T					R			
ASCD operation signal	T	R							
ASCD OD cancel request signal	T	R							
Front wiper request signal				T					R
Front wiper stop position signal				R					T
Rear window defogger switch signal				T					R
Rear window defogger control signal	R		R	R					T
Hood switch signal				R					T
Theft warning horn request signal				T					R
Horn chirp signal				T					R
Steering angle sensor signal					T		R		
ABS warning lamp signal						R	T		
VDC OFF indicator lamp signal						R	T		
SLIP indicator lamp signal						R	T		
Brake warning lamp signal						R	T		
System setting signal			T	R				R	
			R	T				T	
A/T CHECK indicator lamp signal		T				R			

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Display unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T position indicator lamp signal		T				R			
A/T shift schedule change demand signal		R					T		
Manual mode signal		R				T			
Not manual mode signal		R				T			
Manual mode shift up signal		R				T			
Manual mode shift down signal		R				T			
Manual mode indicator signal		T				R			
Distance to empty signal			R			T			
Parking brake switch signal				R		T			
Snow mode switch signal	R					T			

TYPE 3

System diagram

- Type3



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Engine speed signal	T	R	R		R				R		R		
Engine status signal	T						R						
Engine coolant temperature signal	T				R				R				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T self-diagnosis signal	R	T											
Accelerator pedal position signal	T	R			R						R		
Closed throttle position signal	T	R			R								
Wide open throttle position signal	T	R											
Battery voltage signal	T	R											
Key switch signal							T					R	
Ignition switch signal							T					R	R
P range signal		T			R						R	R	
Stop lamp switch signal		R							T				
ABS operation signal					R						T		
TCS operation signal					R						T		
VDC operation signal					R						T		
Fuel consumption monitor signal	T								R				
			R						T				
Turbine revolution signal	R	T			R								
Output shaft revolution signal	R	T			R								
A/C switch signal	R						T						
A/C compressor request signal	T												R
A/C compressor feedback signal	T								R				
Blower fan motor switch signal	R						T						
A/C switch/indicator signal			T						R				
			R						T				
Cooling fan speed request signal	T												R
Position light request signal							T		R				R
Low beam request signal							T						R
Low beam status signal	R												T
High beam request signal							T		R				R
High beam status signal	R												T
Front fog light request signal							T						R
Day time running light request signal							T		R				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Turn LED burnout status signal							R		T				
Vehicle speed signal					R				R		T		
	R	R	R	R		R	R		T	R		R	
Sleep wake up signal							T		R				R
						T	R						
Door switch signal			R			R	T		R			R	R
Turn indicator signal							T		R				
Key fob ID signal							T					R	
Key fob door unlock signal							T					R	
Oil pressure switch signal							R						T
							T		R				
Buzzer output signal							T		R				
					T				R				
Fuel level sensor signal	R								T				
Fuel level low warning signal			R						T				
ASCD SET lamp signal	T								R				
ASCD CRUISE lamp signal	T								R				
Malfunctioning indicator lamp signal	T								R				
ICC operation signal	R				T								
Front wiper request signal					R		T						R
Front wiper stop position signal							R						T
Rear window defogger switch signal							T						R
Rear window defogger control signal	R		R				R						T
Hood switch signal							R						T
Theft warning horn request signal							T						R
Horn chirp signal							T						R
Steering angle sensor signal								T			R		
Tire pressure signal				T					R				
Tire pressure data signal			R	T									
ABS warning lamp signal					R				R		T		

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
VDC OFF indicator lamp signal					R				R		T		
SLIP indicator lamp signal									R		T		
Brake warning lamp signal									R		T		
System setting signal			T			R						R	
			R			T						T	
Distance to empty signal			R						T				
Parking brake switch signal							R		T				
Door lock/unlock request signal						T	R						
Door lock/unlock status signal						R	T						
Starter permission signal						T	R						
Back door open request signal						T	R						
Power window open request signal						T	R						
Alarm request signal						T	R						
Key warning signal						T			R				
ICC sensor signal					R					T			
ICC warning lamp signal					T				R				
ICC system display signal					T				R				
Current gear position signal		T			R						R		
Steering switch signal	T				R								
ASCD operation signal	T	R											
ASCD OD cancel request signal	T	R											
ICC OD cancel request signal	R	R			T								
A/T CHECK indicator lamp signal		T							R				
A/T position indicator lamp signal		T							R				
A/T shift schedule change demand signal		R									T		
Manual mode signal		R							T				
Not manual mode signal		R							T				


CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Manual mode shift up signal		R							T				
Manual mode shift down signal		R							T				
Manual mode indicator signal		T			R				R				
Ignition knob switch signal						T	R						
Snow mode switch signal	R								T				

TYPE 4/TYP5 System diagram

- Type4



- Type5



CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display unit	AWD control unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T self-diagnosis signal	R	T								
Stop lamp switch signal		R		R			T			
Battery voltage signal	T	R								
Key switch signal					T				R	
Ignition switch signal					T				R	R
P range signal		T						R	R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Engine speed signal	T	R	R	R			R	R		
Engine status signal	T				R					
Engine coolant temperature signal	T						R			
Accelerator pedal position signal	T	R		R				R		
Fuel consumption monitor signal	T						R			
			R				T			
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R				T					
A/C compressor request signal	T									R
A/C compressor feedback signal	T						R			
Blower fan motor switch signal	R				T					
A/C switch/indicator signal			T				R			
			R				T			
Cooling fan speed request signal	T									R
Position light request signal			R		T		R			R
Low beam request signal					T					R
Low beam status signal	R									T
High beam request signal					T		R			R
High beam status signal	R									T
Front fog light request signal					T					R
Day time running light request signal					T		R			
Turn LED burnout status signal					R		T			
Vehicle speed signal				R			R	T		
	R	R	R		R		T		R	
Sleep wake up signal					T		R			R
Door switch signal			R		T		R		R	R
Turn indicator signal					T		R			
Key fob ID signal					T				R	

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	AWD control unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Key fob door unlock signal					T				R	
Oil pressure switch signal					R					T
					T		R			
Buzzer output signal					T		R			
Fuel level sensor signal	R						T			
Fuel level low warning signal			R				T			
ASCD SET lamp signal	T						R			
ASCD CRUISE lamp signal	T						R			
Malfunction indicator lamp signal	T						R			
Front wiper request signal					T					R
Front wiper stop position signal					R					T
Rear window defogger switch signal					T					R
Rear window defogger control signal	R		R		R					T
Hood switch signal					R					T
Theft warning horn request signal					T					R
Horn chirp signal					T					R
Steering angle sensor signal						T		R		
ABS warning lamp signal							R	T		
VDC OFF indicator lamp signal							R	T		
SLIP indicator lamp signal							R	T		
Brake warning lamp signal							R	T		
System setting signal			T		R				R	
			R		T				T	
AWD warning lamp signal				T			R			
Distance to empty signal			R				T			
Parking brake switch signal				R	R		T			
ASCD operation signal	T	R								
ASCD OD cancel request signal	T	R								
A/T CHECK indicator lamp signal		T					R			
A/T position indicator lamp signal		T					R			
A/T shift schedule change demand signal		R						T		
Manual mode signal		R					T			
Not manual mode signal		R					T			
Manual mode shift up signal		R					T			
Manual mode shift down signal		R					T			
Manual mode indicator signal		T					R			
Snow mode switch signal	R						T			
Current gear position signal*	R	T								

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Display unit	AWD control unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Next gear position signal*	R	T								
Shift change signal*	R	T								
Shift pattern signal*	R	T								

*: VK45DE engine model only

TYPE 6

System diagram

- Type6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T self-diagnosis signal	R	T												
ABS operation signal						R						T		
TCS operation signal						R						T		
VDC operation signal						R					R	T		
Stop lamp switch signal		R			R					T				
Battery voltage signal	T	R												
Key switch signal								T					R	

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Ignition switch signal								T					R	R
P range signal		T				R						R	R	
Closed throttle position signal	T	R				R								
Wide open throttle position signal	T	R												
Engine speed signal	T	R	R		R	R				R		R		
Engine status signal	T							R						
Engine coolant temperature signal	T					R				R				
Accelerator pedal position signal	T	R			R	R						R		
Fuel consumption monitor signal	T									R				
			R							T				
A/T self-diagnosis signal	R	T												
Turbine revolution signal	R	T				R								
Output shaft revolution signal	R	T				R								
A/C switch signal	R							T						
A/C compressor request signal	T													R
A/C compressor feedback signal	T									R				
Blower fan motor switch signal	R							T						
A/C switch/indicator signal			T							R				
			R							T				
Cooling fan speed request signal	T													R
Position light request signal			R					T		R				R
Low beam request signal								T						R
Low beam status signal	R													T
High beam request signal								T		R				R
High beam status signal	R													T
Front fog light request signal								T						R

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
Day time running light request signal								T		R				
Turn LED burnout status signal								R		T				
Vehicle speed signal					R	R				R		T		
	R	R	R	R			R	R		T	R		R	
Sleep wake up signal								T		R				R
							T	R						
Door switch signal			R				R	T		R			R	R
Key fob ID signal								T					R	
Key fob door unlock signal								T					R	
Oil pressure switch signal								R						T
								T		R				
Buzzer output signal								T		R				
						T				R				
Fuel level sensor signal	R									T				
Fuel level low warning signal			R							T				
ASCD SET lamp signal	T									R				
ASCD CRUISE lamp signal	T									R				
Malfunction indicator lamp signal	T									R				
ICC operation signal	R					T								
Front wiper request signal						R		T						R
Front wiper stop position signal								R						T
Rear window defogger switch signal								T						R
Rear window defogger control signal	R		R					R						T
Hood switch signal								R						T
Theft warning horn request signal								T						R
Horn chirp signal								T						R
Steering angle sensor signal									T			R		
Tire pressure signal				T						R				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R		
Tire pressure data signal			R	T												A
ABS warning lamp signal						R				R		T				B
VDC OFF indicator lamp signal						R				R		T				C
SLIP indicator lamp signal										R		T				D
Brake warning lamp signal										R		T				E
System setting signal			T				R						R			F
			R				T						T			G
AWD warning lamp signal					T					R						H
Distance to empty signal			R							T						I
Parking brake switch signal					R			R		T						J
Door lock/unlock request signal							T	R								K
Door lock/unlock status signal							R	T								L
Starter permission signal							T	R								M
Back door open request signal							T	R								N
Power window open request signal							T	R								O
Alarm request signal							T	R								P
Key warning signal							T			R						Q
ICC sensor signal						R					T					R
ICC warning lamp signal						T				R						S
ICC system display signal						T				R						T
Current gear position signal		T				R						R				U
Steering switch signal	T					R										V
ASCD operation signal	T	R														W
ASCD OD cancel request signal	T	R														X
ICC OD cancel request signal	R	R				T										Y

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Low tire pressure warning control unit	AWD control unit	ICC unit	Intelligent Key unit	BCM	Steering angle sensor	Unified meter and A/C amp.	ICC sensor	ABS actuator and electric unit (control unit)	Driver seat control unit	IPDM E/R
A/T CHECK indicator lamp signal		T								R				
A/T position indicator lamp signal		T								R				
A/T shift schedule change demand signal		R										T		
Manual mode signal		R								T				
Not manual mode signal		R								T				
Manual mode shift up signal		R								T				
Manual mode shift down signal		R								T				
Manual mode indicator signal		T								R				
Ignition knob switch signal							T	R						
Snow mode switch signal	R									T				
Current gear position signal*	R	T												
Next gear position signal*	R	T												
Shift change signal*	R	T												
Shift pattern signal*	R	T												

*: VK45DE engine model only

CAN SYSTEM (TYPE 1)

PF2:23710


System Description

AKS00B27

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00B28



A
B
C
D
E
F
G
H
I
J
L
M

LAN







CAN SYSTEM (TYPE 1)

[CAN]

AKS00BZ9

Wiring Diagram - CAN -

LAN-CAN-01



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (M90) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.





TKWM1292E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02

▬ : DATA LINE



REFER TO THE FOLLOWING.


(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


TKWH0247E

Work Flow


- When there are no indications of "BCM", "METER A/C AMP" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-26, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWKN" in the check sheet table. Refer to [LAN-26, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-85, "CAN Communication Line Inspection"](#) .
- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-26, "CHECK SHEET"](#) .
- Mark the "NG" or "UNKWKN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-26, "CHECK SHEET"](#) .

CAN SYSTEM (TYPE 1)

[CAN]

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-85, "CAN Communication Line Inspection"](#).

9. According to the check sheet results (example), start inspection. Refer to [LAN-28, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display unit
CAN DIAG MONITOR check sheet

PKIA7926E

CAN SYSTEM (TYPE 1)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA7927E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-41, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7928E



CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-41, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7929E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-42, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7930E



SKIA6560E

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-42. "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	UNKW [✓] N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N
METER A/C AMP	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—

PKIA7931E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check TCM circuit. Refer to [LAN-43, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UN KN W N	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UN KN W N	UN KN W N	—	—	—	—	UN KN W N	UN KN W N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UN KN W N	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UN KN W N	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7932E



CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check display unit circuit. Refer to [LAN-43. "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CA N 1	CA N 3	—	—	CA N 2	—	CA N 5	—	CA N 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UN K WN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7933E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-44, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7934E



CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-44, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2 ✓	—	CAN 5	—	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—

PKIA7935E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check steering angle sensor circuit. Refer to [LAN-45, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7936E



SKIA6566E

CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check unified meter and A/C amp. circuit. Refer to [LAN-45, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7937E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-46, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 2	-	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-

PKIA7938E



CAN SYSTEM (TYPE 1)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-46. "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN ✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7939E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)

[CAN]

Case 13

Check CAN communication circuit. Refer to [LAN-47, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	UNKW [✓] N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication [✓]	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N
METER A/C AMP	No indication [✓]	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication [✓]	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—

PKIA7940E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-51, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	UNKW [✓] N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N
METER A/C AMP	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—

PKIA7942E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-51, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7941E

Circuit Check Between TCM and Data Link Connector

AKS00BZB

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.

15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-24, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00BZC

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.

14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-24, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS00BZD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

- 1 (L) - 15G (L) : Continuity should exist.**
11 (R) - 14G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

- 15G (L) - 11 (L) : Continuity should exist.**
14G (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-24, "Work Flow"](#) .
 NG >> Repair harness.



ECM Circuit Check

AKS00BZE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R)

: Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



AKS00BZF

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
- NG >> Repair harness between A/T assembly and display unit.



AKS00BZG

Display Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

14 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit and harness connector M82.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-24, "Work Flow"](#) .
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS00BZL

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



IPDM E/R Circuit Check

AKS00BZM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R)

: Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



AKS00BZV

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, sensor side, meter side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Display unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
- Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


6 (L) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



8. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B5 terminals 3 (L) and 10 (R).

3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Repair harness between harness connector B5 and harness connector B5.



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.


3 (L) - Ground : Continuity should not exist.

10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Repair harness between harness connector B5 and harness connector B5.



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between IPDM E/R and harness connector E205.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.


48 (L) - Ground : Continuity should not exist.

49 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between IPDM E/R and harness connector E205.



12. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-51, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-24, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00BZO

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).


Component Inspection

AKS00BZP

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


System Description

AKS00BZO

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00BZR




CAN SYSTEM (TYPE 2)

[CAN]






Wiring Diagram - CAN -

AKS00BZS

LAN-CAN-03



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.







- F102 -SUPER MULTIPLE JUNCTION (SMJ)
- M3, M90 -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM1293E

LAN-CAN-04

— — — — — : DATA LINE



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


CAN SYSTEM (TYPE 2)

[CAN]


AKS00BZT

Work Flow


- When there are no indications of "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-57, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-85, "CAN Communication Line Inspection"](#) .
- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .
- Mark the "NG" or "UNKWVN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-85, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-59, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display unit
CAN DIAG MONITOR check sheet

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA7944E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-74, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7945E



CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-74, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7946E



CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to [LAN-75, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7947E



CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to [LAN-76, "Circuit Check Between ABS Actuator and Electric Unit \(Control Unit\) and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	✓	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA7948E



SKIA6573E

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-76. "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7949E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check TCM circuit. Refer to [LAN-77, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7950E



CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check display unit circuit. Refer to [LAN-77, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1 ✓	CAN 3 ✓	—	—	CAN 2 ✓	—	CAN 5 ✓	—	CAN 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7951E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check data link connector circuit. Refer to [LAN-78, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7952E



CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-78. "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7953E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-79, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7954E



CAN SYSTEM (TYPE 2)


[CAN]

Case 11

Check unified meter and A/C amp. circuit. Refer to [LAN-79, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7955E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-80, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7956E



CAN SYSTEM (TYPE 2)


[CAN]

Case 13

Check driver seat control unit circuit. Refer to [LAN-80, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA7957E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-81, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA7958E



CAN SYSTEM (TYPE 2)

[CAN]

Case 15

Check CAN communication circuit. Refer to [LAN-82, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7959E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-86, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7961E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-86, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	BCM/SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	CAN 2	—	CAN 5	—	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA7960E

Circuit Check Between TCM and Data Link Connector

AKS00BZU


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.
15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00BZU


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.
14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

1 (L) - 15G (L) : Continuity should exist.
11 (R) - 14G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

15G (L) - 11 (L) : Continuity should exist.
14G (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS00BZX

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

11 (L) - 3 (L) : Continuity should exist.

15 (R) - 10 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

3 (L) - 14 (L) : Continuity should exist.

10 (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#).
NG >> Repair harness.



ECM Circuit Check

AKS00BZY

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R)

: Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and harness connector M82.



AKS00BZZ

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and display unit.



AKS00C00

Display Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

14 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit and harness connector M82.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-55, "Work Flow"](#) .
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



AKS00C03

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



AKS00C04

Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS00C05

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



Driver Seat Control Unit Circuit Check

AKS00C06

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector B151
 - Harness connector B8

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B5.



AKS00C07

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector B8.



LAN

L

M

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, sensor side, meter side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Display unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ABS actuator and electric unit (control unit)
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


6 (L) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

3 (L) - Ground : Continuity should not exist.


10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector B151.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.


14 (OR) - Ground : Continuity should not exist.

15 (SB) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector B151.



12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between IPDM E/R and harness connector E205.




13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.
- NG >> Repair harness between IPDM E/R and harness connector E205.



14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-86, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#) .
- NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00C09

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00C0A

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	




CAN SYSTEM (TYPE 3)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

AKS00C0D



TKWM1294E


CAN SYSTEM (TYPE 3)

[CAN]






AKS00C0E

Wiring Diagram - CAN -

LAN-CAN-05



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)





(M90) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM1295E

LAN-CAN-06

▬ : DATA LINE




REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS






TKWM0748E

LAN-CAN-07

— — — — — : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG. SECTION.


REFER TO THE FOLLOWING.

(E21) -SUPER MULTIPLE JUNCTION (SMJ)


(E56) -ELECTRICAL UNITS

Work Flow


- When there are no indications of "AIR PRESSURE MONITOR", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-94, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "V" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-94, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
 - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.
- Check CAN communication line of the navigation system. Refer to [AV-158, "CAN Communication Line Check"](#) .

CAN SYSTEM (TYPE 3)

[CAN]

7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-94, "CHECK SHEET"](#) .
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-94, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-158, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-97, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	—	UNKW	—	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	—	—	—	UNKW	—	UNKW	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW	—	—	—	—	—	—	—	—	UNKW	—	—	—
ICC	—	NG	UNKW	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	UNKW	—
INTELLIGENT KEY	No indication	—	UNKW	—	—	—	—	—	—	UNKW	—	—	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	—	—	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	—	—	UNKW	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIA7962E

CAN SYSTEM (TYPE 3)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AIR PRESSURE
MONITOR
SELF-DIAG RESULTS

Attach copy of
ICC
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

PKIA7963E

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AIR PRESSURE
MONITOR
CAN DIAG SUPPORT
MNTR

Attach copy of
ICC
CAN DIAG SUPPORT
MNTR

Attach copy of
INTELLIGENT KEY
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA7964E

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-116, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA9132E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-117, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR																
		Initial diagnosis	Transmit diagnosis	Receive diagnosis														
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	—	CAN CIRC 7	—	—
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—	—	—	—

PKIA7965E



SKIA6585E

CAN SYSTEM (TYPE 3)

[CAN]


Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-117, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

A
B
C
D
E
F
G
H
I
J
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7966E



SKIA6586E

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to [LAN-118, "Circuit Check Between ABS Actuator and Electric Unit \(Control Unit\) and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7967E



SKIA6587E

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-119, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	—	—	—	UNKW	—	UNKW	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW	—	—	—	—	—	—	—	—	UNKW	—	—	—
ICC	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	UNKW	UNKW	—
INTELLIGENT KEY	No indication	—	UNKW	—	—	—	—	—	—	UNKW	—	—	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	—	—	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	—	UNKW	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	—	—	UNKW	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	—	—	—

PKIA7968E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check TCM circuit. Refer to [LAN-119, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWVN	—	UNKWVN	—	—	UNKWVN	—	UNKWVN	—	UNKWVN	—	UNKWVN	UNKWVN
A/T	—	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—	—	UNKWVN	—	UNKWVN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWVN	—	—	—	—	—	—	—	—	UNKWVN	—	—	—
ICC	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	UNKWVN	—	—	UNKWVN	UNKWVN	—
INTELLIGENT KEY	No indication	—	UNKWVN	—	—	—	—	—	—	UNKWVN	—	—	—	—	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	—	—	UNKWVN
METER A/C AMP	No indication	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	—	—	—	UNKWVN	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWVN	—	UNKWVN	—	—	—	—	UNKWVN	—	UNKWVN	—	—	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	—	—	—

PKIA7969E



SKIA6589E

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check display control unit circuit. Refer to [LAN-120, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN DTC 1 ✓	CAN DTC 3 ✓	—	—	CAN DTC 6 ✓	—	—	CAN DTC 2 ✓	—	CAN DTC 5 ✓	—	—	CAN DTC 7 ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7970E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check low tire pressure warning control unit circuit. Refer to [LAN-120, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	

PKIA7971E



SKIA6591E

CAN SYSTEM (TYPE 3)

[CAN]


Case 9

Check ICC unit circuit. Refer to [LAN-121, "ICC Unit Circuit Check"](#).

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7972E



SKIA6592E

CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check Intelligent Key unit circuit. Refer to [LAN-121, "Intelligent Key Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	CAN CIRC 7	
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN ✓	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	

PKIA7973E



SKIA6593E

CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check data link connector circuit. Refer to [LAN-122, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7974E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 12

Check BCM circuit. Refer to [LAN-122, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7975E



SKIA6595E

CAN SYSTEM (TYPE 3)


[CAN]

Case 13

Check steering angle sensor circuit. Refer to [LAN-123, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7976E



CAN SYSTEM (TYPE 3)


[CAN]

Case 14

Check unified meter and A/C amp. circuit. Refer to [LAN-123, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7977E



SKIA6597E

CAN SYSTEM (TYPE 3)


[CAN]

Case 15

Check ICC sensor circuit. Refer to [LAN-124, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7978E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 16

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-124, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7979E



SKIA6599E

CAN SYSTEM (TYPE 3)


[CAN]

Case 17

Check driver seat control unit circuit. Refer to [LAN-125, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7980E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 18

Check IPDM E/R circuit. Refer to [LAN-126, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7981E



SKIA6601E

CAN SYSTEM (TYPE 3)

[CAN]

Case 19

Check CAN communication circuit. Refer to [LAN-127, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	—	UNKW ^N	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—	—	—	UNKW ^N	—	UNKW ^N	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW ^N	—	—	—	—	—	—	—	—	UNKW ^N	—	—	—
ICC	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	—	UNKW ^N	—	—	UNKW ^N	UNKW ^N	—
INTELLIGENT KEY	No indication	—	UNKW ^N	—	—	—	—	—	—	UNKW ^N	—	—	—	—	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	—	—	—	UNKW ^N	—	—	UNKW ^N	—	—	UNKW ^N
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	—	—	UNKW ^N	—	UNKW ^N	—	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	—	—	—	—	—

PKIA7982E

Case 20

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-132, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	—	UNKW ^N	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—	—	—	UNKW ^N	—	UNKW ^N	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW ^N	—	—	—	—	—	—	—	—	UNKW ^N	—	—	—
ICC	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	—	UNKW ^N	—	—	UNKW ^N	UNKW ^N	—
INTELLIGENT KEY	No indication	—	UNKW ^N	—	—	—	—	—	—	UNKW ^N	—	—	—	—	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	—	—	—	UNKW ^N	—	—	UNKW ^N	—	—	UNKW ^N
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	—	—	UNKW ^N	—	UNKW ^N	—	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	—	—	—	—	—

PKIA7984E

Case 21

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-132, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DISPLAY	TIRE-P	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA7983E

Circuit Check Between TCM and Data Link Connector

AKS00C0G

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.

15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-92, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00C0H

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.

14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-92, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS00C0I

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

1 (L) - 15G (L) : Continuity should exist.

11 (R) - 14G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

15G (L) - 11 (L) : Continuity should exist.
14G (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-92, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS00C0J

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

11 (L) - 3 (L) : Continuity should exist.
15 (R) - 10 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

3 (L) - 14 (L) : Continuity should exist.
10 (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-92, "Work Flow"](#) .
 NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and harness connector M82.



TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and display control unit.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M76 terminals 25 (L) and 26 (R).

25 (L) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and harness connector M82.



Low Tire Pressure Warning Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M74 terminals 9 (L) and 21 (R).

9 (L) - 21 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace low tire pressure warning control unit.
 NG >> Repair harness between low tire pressure warning control unit and harness connector M82.



AKS00C00

ICC Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector M88 terminals 14 (L) and 5 (R).

14 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC unit.
 NG >> Repair harness between ICC unit and harness connector M82.



AKS00C0P

Intelligent Key Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M34 terminals 2 (L) and 3 (R).

2 (L) - 3 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace Intelligent Key unit.
 NG >> Repair harness between Intelligent Key unit and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-92, "Work Flow"](#).
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



AKS00C05

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



AKS00C07

Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



AKS00COU

ICC Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E39 terminals 3 (L) and 6 (R).

3 (L) - 6 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC sensor.
 NG >> Repair harness between ICC sensor and ABS actuator and electric unit (control unit).



AKS00COV

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and ICC sensor.



AKS00COW

Driver Seat Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector B151
 - Harness connector B8

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B5.



LAN

IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R)**: Approx. 108 - 132Ω****OK or NG**

OK >> Replace IPDM E/R.

NG >> Repair harness between IPDM E/R and harness connector B8.



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, unit side, sensor side, meter side and harness side).
 - ECM
 - A/T assembly
 - Display control unit
 - Low tire pressure warning control unit
 - ICC unit
 - Intelligent Key unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ICC sensor
 - ABS actuator and electric unit (control unit)
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display control unit connector
 - Low tire pressure warning control unit connector
 - ICC unit connector
 - Intelligent Key unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


6 (L) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display control unit
- Harness between data link connector and low tire pressure warning control unit
- Harness between data link connector and ICC unit
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display control unit
- Harness between data link connector and low tire pressure warning control unit
- Harness between data link connector and ICC unit
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector, ICC sensor connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205
- Harness between ABS actuator and electric unit (control unit) and ICC sensor



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205
- Harness between ABS actuator and electric unit (control unit) and ICC sensor



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

3 (L) - Ground : Continuity should not exist.


10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector B151.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.


14 (OR) - Ground : Continuity should not exist.

15 (SB) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector B151.



12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between IPDM E/R and harness connector E205.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.


48 (L) - Ground : Continuity should not exist.

49 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between IPDM E/R and harness connector E205.



14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-132, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-92, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00C0Z

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00C10

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 4)

PFP:23710


System Description

AKS00C11

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00C12



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

AKS00C13



TKWM1296E

CAN SYSTEM (TYPE 4)






[CAN]

Wiring Diagram - CAN -

AKS00C14

LAN-CAN-08

▬ : DATA LINE



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)



M90 -ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J
L
M


LAN

LAN-CAN-09

▬ : DATA LINE



(M5)
W



(M14)
W

REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS





TKWM0752E

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-10

▬ : DATA LINE



REFER TO THE FOLLOWING.


(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


TKWH0250E

Work Flow


- When there are no indications of "BCM", "METER A/C AMP" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-140, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWKN" in the check sheet table. Refer to [LAN-140, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-85, "CAN Communication Line Inspection"](#) .

- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-140, "CHECK SHEET"](#)

CAN SYSTEM (TYPE 4)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-140, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-85, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-142, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display unit
CAN DIAG MONITOR check sheet

PKIA7985E

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of METER A/C AMP SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of METER A/C AMP CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIA7986E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-156, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7987E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-156, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7988E



CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-157, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

PKIA7989E



SKIA6604E

CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-157, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7990E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-158, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TC/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UN ✓ WN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UN ✓ WN	UN ✓ WN	—	—	—	—	—	UN ✓ WN	UN ✓ WN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UN ✓ WN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UN ✓ WN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7991E



CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check display unit circuit. Refer to [LAN-158, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CA N 1 ✓	CA N 3 ✓	—	—	—	CA N 2 ✓	—	CA N 5 ✓	—	CA N 7 ✓	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7992E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check AWD control unit circuit. Refer to [LAN-159, "AWD Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7993E



CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check data link connector circuit. Refer to [LAN-159, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7994E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-160, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7995E



CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-160, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7996E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check unified meter and A/C amp. circuit. Refer to [LAN-161, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7997E



CAN SYSTEM (TYPE 4)

[CAN]


Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-161, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA7998E



CAN SYSTEM (TYPE 4)


[CAN]

Case 13

Check IPDM E/R circuit. Refer to [LAN-162, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA7999E



CAN SYSTEM (TYPE 4)

[CAN]

Case 14

Check CAN communication circuit. Refer to [LAN-163, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	✓ UNKWN	—	✓ UNKWN	—	—	—	✓ UNKWN	—	✓ UNKWN	✓ UNKWN	✓ UNKWN
A/T	—	NG	✓ UNKWN	✓ UNKWN	—	—	—	—	—	—	✓ UNKWN	✓ UNKWN	—
Display unit	—	CAN COMM	✓ CAN 1	✓ CAN 3	—	—	—	—	✓ CAN 2	—	✓ CAN 5	—	✓ CAN 7
ALL MODE AWD/4WD	—	NG	✓ UNKWN	✓ UNKWN	—	—	—	—	—	—	✓ UNKWN	✓ UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	✓ UNKWN	✓ UNKWN	✓ UNKWN	—	—	✓ UNKWN	—	✓ UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8000E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓ UNKWN	—	—	—	—	—	—	✓ UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓ UNKWN	UNKWN	—	—	✓ UNKWN	—	✓ UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8001E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8002E

Circuit Check Between TCM and Data Link Connector

AKS00C16

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.

15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-138, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00C17

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.

14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-138, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS00C18

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

1 (L) - 15G (L) : Continuity should exist.
11 (R) - 14G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

15G (L) - 11 (L) : Continuity should exist.
14G (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-138, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check

AKS00C19

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



AKS00C1A

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
- NG >> Repair harness between A/T assembly and display unit.



AKS00C1B

Display Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

14 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit and harness connector M82.



AWD Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

8 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace AWD control unit.
 NG >> Repair harness between AWD control unit and harness connector M82.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-138, "Work Flow"](#) .
 NG >> Repair harness between data link connector and BCM.



SKIA6868E

AKS00C1E

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



SKIA6869E

AKS00C1F

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



AKS00C11

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, sensor side, meter side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Display unit
 - AWD control unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display unit connector
 - AWD control unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and ECM
 - Harness between data link connector and harness connector M82
 - Harness between data link connector and display unit
 - Harness between data link connector and AWD control unit
 - Harness between data link connector and BCM
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and unified meter and A/C amp.
 - Harness between data link connector and harness connector M41



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and AWD control unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



8. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B5 terminals 3 (L) and 10 (R).

3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Repair harness between harness connector B5 and harness connector B5.



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.


3 (L) - Ground : Continuity should not exist.

10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Repair harness between harness connector B5 and harness connector B5.




10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 11.
 NG >> Repair harness between IPDM E/R and harness connector E205.



11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) - Ground : Continuity should not exist.

49 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 12.
 NG >> Repair harness between IPDM E/R and harness connector E205.



12. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-166, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-138, "Work Flow"](#) .
 NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00C1K

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START""](#) .

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00C1L

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 5)


System Description

AKS00C1M

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00C1N



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

AKS00C10



TKWM1298E

CAN SYSTEM (TYPE 5)






[CAN]

Wiring Diagram - CAN -

AKS00C1P

LAN-CAN-11

▬ : DATA LINE



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)



M90 -ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J
L
M


LAN

LAN-CAN-12

▬ : DATA LINE



(M5)
W




(M14)
W






REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS

TKWM0756E

LAN-CAN-13



A
B
C
D
E
F
G
H
I
J
LAN
L
M



*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

E211 -SUPER MULTIPLE JUNCTION (SMJ)

E56 -ELECTRICAL UNITS

Work Flow

- When there are no indications of "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

	NISSAN CONSULT- II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY	→	SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP BACK LIGHT COPY
--	------------------------------------------------------------------------------------------------------------------------------	---	---------------------------------------------------------------------------------------------

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	→	SELF-DIAG RESULTS DTC RESULTS TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">CAN COMM CIRCUIT [U1000]</td> <td style="width: 30%;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td colspan="2" style="text-align: center;">F.F.DATA</td> </tr> <tr> <td>ERASE</td> <td>PRINT</td> </tr> <tr> <td>MODE BACK</td> <td>LIGHT COPY</td> </tr> </table>	CAN COMM CIRCUIT [U1000]	0					F.F.DATA		ERASE	PRINT	MODE BACK	LIGHT COPY
CAN COMM CIRCUIT [U1000]	0														
F.F.DATA															
ERASE	PRINT														
MODE BACK	LIGHT COPY														

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ALL MODE AWD/4WD", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.

(Example)

	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	→	CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">PRSN</td> <td style="width: 40%;"> </td> </tr> <tr> <td>INITIAL DIAG</td> <td>OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td>OK</td> </tr> <tr> <td>TCM</td> <td>OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td>OK</td> </tr> <tr> <td>METER/M&A</td> <td>OK</td> </tr> <tr> <td>ICC</td> <td>UNKWN</td> </tr> <tr> <td>BCM/SEC</td> <td>OK</td> </tr> <tr> <td>IPDM E/R</td> <td>OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td>UNKWN</td> </tr> <tr> <td>PRINT</td> <td>Scroll Down</td> </tr> <tr> <td>MODE BACK</td> <td>LIGHT COPY</td> </tr> </table>	PRSN		INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE BACK	LIGHT COPY
PRSN																											
INITIAL DIAG	OK																										
TRANSMIT DIAG	OK																										
TCM	OK																										
VDC/TCS/ABS	OK																										
METER/M&A	OK																										
ICC	UNKWN																										
BCM/SEC	OK																										
IPDM E/R	OK																										
AWD/4WD/e4WD	UNKWN																										
PRINT	Scroll Down																										
MODE BACK	LIGHT COPY																										

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-174, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-174, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the integrated display system. Refer to [AV-85, "CAN Communication Line Inspection"](#) .

- Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-174, "CHECK SHEET"](#) .

CAN SYSTEM (TYPE 5)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG MONITOR check sheet. Refer to [LAN-174, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit. Refer to [AV-85, "CAN Communication Line Inspection"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-176, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display unit
CAN DIAG MONITOR check sheet

PKIA8003E

CAN SYSTEM (TYPE 5)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8004E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-192, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	✓	—	✓	✓	✓	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	✓	✓	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	✓	2	✓	5	✓	7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	✓	✓	—	
BCM	No indication	NG	UNKWN	✓	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	✓	✓	✓	✓	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	✓	✓	—	✓	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	

PKIA8005E



CAN SYSTEM (TYPE 5)

[CAN]


Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-192. "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8006E



CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-193, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8007E



SKIA6617E

CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to LAN-194, "Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA8008E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-194, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	UNKW ^N	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	UNKW ^N	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	—	—	—	—	UNKW ^N	—	UNKW ^N
METER A/C AMP	No indication	—	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	—	UNKW ^N	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—	—	—	—

PKIA8009E



CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check TCM circuit. Refer to [LAN-195, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8010E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check display unit circuit. Refer to [LAN-195, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8011E



CAN SYSTEM (TYPE 5)


[CAN]

Case 8

Check AWD control unit circuit. Refer to [LAN-196, "AWD Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN ✓	UNKWN ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	—	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIA8012E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-196, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8013E



CAN SYSTEM (TYPE 5)


[CAN]

Case 10

Check BCM circuit. Refer to [LAN-197, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8014E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-197, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8015E



CAN SYSTEM (TYPE 5)


[CAN]

Case 12

Check unified meter and A/C amp. circuit. Refer to [LAN-198, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8016E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-198, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8017E




Case 14

Check driver seat control unit circuit. Refer to [LAN-199, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8018E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)


[CAN]

Case 15

Check IPDM E/R circuit. Refer to [LAN-200, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIA8019E



CAN SYSTEM (TYPE 5)

[CAN]

Case 16

Check CAN communication circuit. Refer to [LAN-200, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

PKIA8020E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-205, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

PKIA8022E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-205, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DISPLAY	AWD /4WD	BCM /SEC	STRG	METER /M&A	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	—	UNKW	UNKW	UNKW
A/T	—	NG	UNKW	✓	—	—	—	—	—	UNKW	UNKW	—
Display unit	—	CAN COMM	CAN 1	CAN 3	—	—	—	CAN 2	—	CAN 5	—	CAN 7
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	—	UNKW	—	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—
ABS	—	NG	UNKW	✓	UNKW	—	UNKW	—	UNKW	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	UNKW	—	UNKW	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—

PKIA8021E

Circuit Check Between TCM and Data Link Connector

AKS00C1R

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.

15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-172, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00C1S

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.

14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-172, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)

AKS00C1T

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

- 1 (L) - 15G (L) : Continuity should exist.**
- 11 (R) - 14G (R) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

- 15G (L) - 11 (L) : Continuity should exist.**
- 14G (R) - 15 (R) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-172, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS00C1U

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

11 (L) - 3 (L) : Continuity should exist.
15 (R) - 10 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

3 (L) - 14 (L) : Continuity should exist.
10 (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-172, "Work Flow"](#).
NG >> Repair harness.



ECM Circuit Check

AKS00C1V

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



AKS00C1W

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
- NG >> Repair harness between A/T assembly and display unit.



AKS00C1X

Display Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display unit connector.
2. Check resistance between display unit harness connector M62 terminals 14 (L) and 16 (R).

14 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit and harness connector M82.



SKIA6867E

AWD Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

8 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace AWD control unit.
 NG >> Repair harness between AWD control unit and harness connector M82.



SKIA6889E

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

AKS00C1Z


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-172, "Work Flow"](#) .
 NG >> Repair harness between data link connector and BCM.



SKIA6868E

AKS00C20

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



SKIA6869E

AKS00C21

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Unified Meter and A/C Amp. Circuit Check

AKS00C22

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS00C23

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E205.



AKS00C24

Driver Seat Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector B151
 - Harness connector B8

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B5.



LAN

IPDM E/R Circuit Check

AKS00C25

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector B8.

**CAN Communication Circuit Check**

AKS00C26

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, unit side, control unit side, sensor side, meter side and harness side).
 - ECM
 - A/T assembly
 - Display unit
 - AWD control unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ABS actuator and electric unit (control unit)
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display unit connector
 - AWD control unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


6 (L) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and AWD control unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display unit
- Harness between data link connector and AWD control unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

3 (L) - Ground : Continuity should not exist.


10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



A
B
C
D
E
F
G
H
I
J

LAN

L
M


10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Continuity should not exist.

OK or NG

- OK >> GO TO 11.
 NG >> Repair harness between driver seat control unit and harness connector B151.



11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.

14 (OR) - Ground : Continuity should not exist.

15 (SB) - Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 12.
 NG >> Repair harness between driver seat control unit and harness connector B151.




12. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 13.
 NG >> Repair harness between IPDM E/R and harness connector E205.



13. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) - Ground : Continuity should not exist.

49 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 14.
 NG >> Repair harness between IPDM E/R and harness connector E205.



14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-205, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-172, "Work Flow"](#) .
- NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00C27

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .


Component Inspection

AKS00C28

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 6)


System Description

AKS00C29

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00C2A




CAN SYSTEM (TYPE 6)

[CAN]

Schematic

AKS00C2B



A
B
C
D
E
F
G
H
I
J
LAN
L
M

TKWM1300E


CAN SYSTEM (TYPE 6)

[CAN]


AKS00C2C

Wiring Diagram - CAN -


LAN-CAN-14




NEXT PAGE




(M74)
W




(M76)
W




(M88)
W



(M92)
W



(F44)
DGY



(F502)
GY

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.





(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90) -ELECTRICAL UNITS

TKWM1301E

LAN-CAN-15

▬ : DATA LINE










REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS

TKWM0760E

LAN-CAN-16

— : DATA LINE



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(E56) -ELECTRICAL UNITS


CAN SYSTEM (TYPE 6)

[CAN]


AKS00C2D

Work Flow


- When there are no indications of "AIR PRESSURE MONITOR", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ALL MODE AWD/4WD", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AIR PRESSURE MONITOR", "ALL MODE AWD/4WD", "ICC", "INTELLIGENT KEY", "BCM", "METER A/C AMP", "ABS", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-213, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWKN" in the check sheet table. Refer to [LAN-213, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of "CAN DIAG SUPPORT MNTR" items which are not indicated in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-158, "CAN Communication Line Check"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]

7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-213, "CHECK SHEET"](#) .
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-213, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-158, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-216, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 6)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AIR PRESSURE
MONITOR
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ICC
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

PKIA8024E

CAN SYSTEM (TYPE 6)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AIR PRESSURE
MONITOR
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ICC
CAN DIAG SUPPORT
MNTR

Attach copy of
INTELLIGENT KEY
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8025E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-237, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8026E



SKIA6630E

CAN SYSTEM (TYPE 6)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-238, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8027E



SKIA6631E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 3

Check harness between unified meter and A/C amp. and ABS actuator and electric unit (control unit). Refer to LAN-238, "Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R		
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	—
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8028E



SKIA6632E

CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check harness between ABS actuator and electric unit (control unit) and driver seat control unit. Refer to [LAN-239, "Circuit Check Between ABS Actuator and Electric Unit \(Control Unit\) and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN	✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8029E



SKIA6633E

CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-240, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW [✓] N	—	—	—	—	—	—	—	—	—	UNKW [✓] N	—	—	—
ALL MODE AWD/4WD	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—
ICC	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—
INTELLIGENT KEY	No indication	—	UNKW [✓] N	—	—	—	—	—	—	—	UNKW [✓] N	—	—	—	—	—
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	UNKW [✓] N	—	—	UNKW [✓] N	—	—	UNKW [✓] N
METER A/C AMP	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	—	UNKW [✓] N	—	—	—	—	—

PKIA8030E



SKIA6634E

CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check TCM circuit. Refer to [LAN-240, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS
ENGINE	—	NG	UNKWVN	—	UNKWVN	—	—	—	UNKWVN	—	UNKWVN	—	UNKWVN	—	UNKWVN	UNKWVN
A/T	—	NG	UNKWVN	UNKWVN	—	—	—	—	UNKWVN	—	—	—	UNKWVN	—	UNKWVN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWVN	—	—	—	—	—	—	—	—	—	UNKWVN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	—	—	—	—	—	—	—	—	UNKWVN	—	UNKWVN	—
ICC	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	UNKWVN	UNKWVN	—
INTELLIGENT KEY	No indication	—	UNKWVN	—	—	—	—	—	—	—	UNKWVN	—	—	—	—	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	UNKWVN	—	—	UNKWVN
METER A/C AMP	No indication	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	—	—	—	UNKWVN	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	—	UNKWVN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWVN	—	UNKWVN	—	—	—	—	—	UNKWVN	—	UNKWVN	—	—	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	—	—	—	—	—	UNKWVN	—	—	—	—	—

PKIA8031E



SKIA6635E

CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check display control unit circuit. Refer to [LAN-241, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	—	CAN CRC 6 ✓	—	—	—	CAN CRC 2 ✓	—	CAN CRC 5 ✓	—	—	CAN CRC 7 ✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8032E



SKIA6636E

CAN SYSTEM (TYPE 6)


[CAN]

Case 8

Check low tire pressure warning control unit circuit. Refer to [LAN-241, "Low Tire Pressure Warning Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8033E



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 9

Check AWD control unit circuit. Refer to [LAN-242. "AWD Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	—	—	—	UNKW	—	UNKW	—	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	—	UNKW	—	UNKW	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKW	—	—	—	—	—	—	—	—	—	UNKW	—	—	—
ALL MODE AWD/4WD	—	NG	UNKW ✓	UNKW ✓	—	—	—	—	—	—	—	—	UNKW ✓	—	UNKW ✓	—
ICC	—	NG	UNKW	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	UNKW	UNKW	—
INTELLIGENT KEY	No indication	—	UNKW	—	—	—	—	—	—	—	UNKW	—	—	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	—	UNKW	—	—	UNKW	—	—	UNKW
METER A/C AMP	No indication	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW ✓	UNKW	UNKW	UNKW	—	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW ✓	—	—	—	UNKW	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	—	—	—	UNKW	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	—	—	—	UNKW	—	—	—	—	—

PKIA8034E



SKIA6638E

CAN SYSTEM (TYPE 6)


[CAN]

Case 10

Check ICC unit circuit. Refer to [LAN-242, "ICC Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	—
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN	—
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8035E



SKIA6639E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 11

Check Intelligent Key unit circuit. Refer to [LAN-243, "Intelligent Key Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8036E



SKIA6640E

CAN SYSTEM (TYPE 6)

[CAN]


Case 12

Check data link connector circuit. Refer to [LAN-243, "Data Link Connector Circuit Check"](#).

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication ✓	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8037E



SKIA6641E

CAN SYSTEM (TYPE 6)


[CAN]

Case 13

Check BCM circuit. Refer to [LAN-244, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8038E



SKIA6642E

CAN SYSTEM (TYPE 6)


[CAN]

Case 14

Check steering angle sensor circuit. Refer to [LAN-244, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8039E



SKIA6643E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 15

Check unified meter and A/C amp. circuit. Refer to [LAN-245, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8040E



SKIA6644E

CAN SYSTEM (TYPE 6)


[CAN]

Case 16

Check ICC sensor circuit. Refer to [LAN-245, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	✓	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8041E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 17

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-246. "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8042E



CAN SYSTEM (TYPE 6)


[CAN]

Case 18

Check driver seat control unit circuit. Refer to [LAN-246, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8043E



SKIA6647E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


[CAN]

Case 19

Check IPDM E/R circuit. Refer to [LAN-247, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7	✓
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN	✓
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8044E



SKIA6648E

CAN SYSTEM (TYPE 6)

[CAN]

Case 20

Check CAN communication circuit. Refer to [LAN-248. "CAN Communication Circuit Check"](#) .

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR		VDC/TCS /ABS
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—
Display control unit	—	CAN COMM	CAN [✓] CRC1	CAN [✓] CRC3	—	—	CAN [✓] CRC6	—	—	—	CAN [✓] CRC2	—	CAN [✓] CRC5	—	—	CAN [✓] CRC7
AIR PRESSURE MONITOR	No indication [✓]	NG	UNKW [✓] N	—	—	—	—	—	—	—	—	—	UNKW [✓] N	—	—	—
ALL MODE AWD/4WD	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—
ICC	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—
INTELLIGENT KEY	No indication [✓]	—	UNKW [✓] N	—	—	—	—	—	—	—	UNKW [✓] N	—	—	—	—	—
BCM	No indication [✓]	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	UNKW [✓] N	—	—	UNKW [✓] N	—	—	UNKW [✓] N
METER A/C AMP	No indication [✓]	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—	—	—	—
AUTO DRIVE POS.	No indication [✓]	NG	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication [✓]	—	UNKW [✓] N	UNKW [✓] N	—	—	—	—	—	—	UNKW [✓] N	—	—	—	—	—

PKIA8045E

CAN SYSTEM (TYPE 6)

[CAN]

Case 21

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-253, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												IPDM E/R
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	✓	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	✓	—
ICC	—	NG	UNKWN	UNKWN	✓	—	—	—	—	—	UNKWN	—	—	UNKWN	✓	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8047E

Case 22

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-253, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis												
				ECM	TCM	DISPLAY	TIRE-P	AWD /4WD	ICC /e4WD	I-KEY	BCM /SEC	STRG	METER /M&A	ICC SENSOR	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	—	—	—	UNKWN	—	—	—	UNKWN	—	UNKWN	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 6	—	—	—	CAN CIRC 2	—	CAN CIRC 5	—	—	CAN CIRC 7
AIR PRESSURE MONITOR	No indication	NG	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	—
INTELLIGENT KEY	No indication	—	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	UNKWN	—	—	UNKWN
METER A/C AMP	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	✓	—	—	—	✓	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8046E

Circuit Check Between TCM and Data Link Connector

AKS00C2E

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and harness connector M82.
4. Check continuity between harness connector M82 terminals 14H (L), 15H (R) and data link connector M5 terminals 6 (L), 14 (R).

14H (L) - 6 (L) : Continuity should exist.

15H (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#) .
- NG >> Repair harness.



SKIA6861E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00C2F

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M5 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R).

6 (L) - 1 (L) : Continuity should exist.

14 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between Unified Meter and A/C Amp. and ABS Actuator and Electric Unit (Control Unit)**

AKS00C2G

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M41
 - Harness connector E211

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect unified meter and A/C amp. connector and harness connector M41.
2. Check continuity between unified meter and A/C amp. harness connector M55 terminals 1 (L), 11 (R) and harness connector M41 terminals 15G (L), 14G (R).

1 (L) - 15G (L) : Continuity should exist.

11 (R) - 14G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E211 terminals 15G (L), 14G (R) and ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R).

15G (L) - 11 (L) : Continuity should exist.

14G (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between ABS Actuator and Electric Unit (Control Unit) and Driver Seat Control Unit

AKS00C2H

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and harness connector E205 terminals 3 (L), 10 (R).

11 (L) - 3 (L) : Continuity should exist.

15 (R) - 10 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L), 10 (R) and harness connector B8 terminals 14 (L), 15 (R).

3 (L) - 14 (L) : Continuity should exist.

10 (R) - 15 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).
- NG >> Repair harness.



AKS00C2I

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M90 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and harness connector M82.



AKS00C2J

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - A/T assembly connector
 - Harness connector F102
 - Harness connector M82

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and display control unit.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M76 terminals 25 (L) and 26 (R).

25 (L) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and harness connector M82.



Low Tire Pressure Warning Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of low tire pressure warning control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Check resistance between low tire pressure warning control unit harness connector M74 terminals 9 (L) and 21 (R).

9 (L) - 21 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace low tire pressure warning control unit.
 NG >> Repair harness between low tire pressure warning control unit and harness connector M82.



AKS00C2M

AWD Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M92 terminals 8 (L) and 16 (R).

8 (L) - 16 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace AWD control unit.
 NG >> Repair harness between AWD control unit and harness connector M82.



AKS00C2N

ICC Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector M88 terminals 14 (L) and 5 (R).

14 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC unit.
 NG >> Repair harness between ICC unit and harness connector M82.



AKS00C20

Intelligent Key Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M34 terminals 2 (L) and 3 (R).

2 (L) - 3 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace Intelligent Key unit.
 NG >> Repair harness between Intelligent Key unit and data link connector.



AKS00C2P

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M5 terminals 6 (L) and 14 (R).

6 (L) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-211, "Work Flow"](#) .
 NG >> Repair harness between data link connector and BCM.



SKIA6868E

AKS00C2Q

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 39 (L) and 40 (R).

39 (L) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-15, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



SKIA6869E

AKS00C2R

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M14 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M55 terminals 1 (L) and 11 (R).

1 (L) - 11 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and harness connector M41.



ICC Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E39 terminals 3 (L) and 6 (R).

3 (L) - 6 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC sensor.
 NG >> Repair harness between ICC sensor and ABS actuator and electric unit (control unit).



ABS Actuator and Electric Unit (Control Unit) Circuit Check

AKS00C2U

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).

11 (L) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and ICC sensor.



Driver Seat Control Unit Circuit Check

AKS00C2V

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector B151
 - Harness connector B8

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B5.



AKS00C2W

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector E205
 - Harness connector B5

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector B8.



LAN

L

M

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, unit side, sensor side, meter side and harness side).
 - ECM
 - A/T assembly
 - Display control unit
 - AWD control unit
 - Low tire pressure warning control unit
 - ICC unit
 - Intelligent Key unit
 - BCM
 - Steering angle sensor
 - Unified meter and A/C amp.
 - ICC sensor
 - ABS actuator and electric unit (control unit)
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and A/T assembly

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector M82
 - Display control unit connector
 - Low tire pressure warning control unit connector
 - AWD control unit connector
 - ICC unit connector
 - Intelligent Key unit connector
 - BCM connector
 - Steering angle sensor connector
 - Unified meter and A/C amp. connector
 - Harness connector M41
2. Check continuity between data link connector M5 terminals 6 (L) and 14 (R).


6 (L) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display control unit
- Harness between data link connector and low tire pressure warning control unit
- Harness between data link connector and AWD control unit
- Harness between data link connector and ICC unit
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



A
B
C
D
E
F
G
H
I
J
LAN
L
M

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M5 terminals 6 (L), 14 (R) and ground.

6 (L) - Ground : Continuity should not exist.


14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and ECM
- Harness between data link connector and harness connector M82
- Harness between data link connector and display control unit
- Harness between data link connector and low tire pressure warning control unit
- Harness between data link connector and AWD control unit
- Harness between data link connector and ICC unit
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and harness connector M41



4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect A/T assembly connector.
2. Check continuity between A/T assembly harness connector F44 terminals 3 (L) and 8 (R).

3 (L) - 8 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair harness between A/T assembly and harness connector F102.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F44 terminals 3 (L), 8 (R) and ground.


3 (L) - Ground : Continuity should not exist.

8 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Repair harness between A/T assembly and harness connector F102.



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector, ICC sensor connector and harness connector E205.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L) and 15 (R).


11 (L) - 15 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205
- Harness between ABS actuator and electric unit (control unit) and ICC sensor



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E56 terminals 11 (L), 15 (R) and ground.

11 (L) - Ground : Continuity should not exist.


15 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E211
- Harness between ABS actuator and electric unit (control unit) and harness connector E205
- Harness between ABS actuator and electric unit (control unit) and ICC sensor



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B8.
2. Check continuity between harness connector B5 terminals 3 (L) and 10 (R).


3 (L) - 10 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B5 terminals 3 (L), 10 (R) and ground.

3 (L) - Ground : Continuity should not exist.


10 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B5 and harness connector B5
- Harness between harness connector B5 and harness connector B8



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B152 terminals 14 (OR) and 15 (SB).

14 (OR) - 15 (SB) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector B151.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B152 terminals 14 (OR), 15 (SB) and ground.


14 (OR) - Ground : Continuity should not exist.

15 (SB) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector B151.



12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between IPDM E/R and harness connector E205.




13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

- 48 (L) - Ground : Continuity should not exist.**
- 49 (R) - Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 14.
- NG >> Repair harness between IPDM E/R and harness connector E205.



14. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-253, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).
- NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00C2Y

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-28, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#).


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00C2Z

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A
B
C
D
E
F
G
H
I
J
LAN
L
M

